



Cisco Catalyst PON Series Switches OLT Command Reference

First Published: 2020-11-09

Americas Headquarters

Cisco Systems, Inc.
170 West Tasman Drive
San Jose, CA 95134-1706
USA
<http://www.cisco.com>
Tel: 408 526-4000
800 553-NETS (6387)
Fax: 408 527-0883

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NON-INFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

All printed copies and duplicate soft copies of this document are considered uncontrolled. See the current online version for the latest version.

Cisco has more than 200 offices worldwide. Addresses and phone numbers are listed on the Cisco website at www.cisco.com/go/offices.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: <https://www.cisco.com/c/en/us/about/legal/trademarks.html>. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1721R)

© 2020 Cisco Systems, Inc. All rights reserved.



CONTENTS

CHAPTER 1

Using the Command-Line Interface 1

- Using the Command-Line Interface 2
- Understanding Command Modes 2
- Understanding the Help System 4
- Understanding Abbreviated Commands 5
- Understanding no Forms of Commands 5
- Understanding CLI Error Messages 5
- Using Command History 6
 - Changing the Command History Buffer Size 6
 - Recalling Commands 6
- Using Editing Features 6
 - Editing Commands through Keystrokes 7
 - Editing Command Lines that Wrap 8
- Searching and Filtering Output of show and more Commands 9
- Accessing the CLI through a Console Connection or through Telnet 10

PART I

Getting Started With OLT Network 11

CHAPTER 2

Getting Started With OLT Network 13

- add inner-vlan 15
- aim 16
- alarm ont register-record 18
- crypto key 19
- default vlan 20
- delete aim 21
- deploy profile 22

description	23
device type	24
ds car bandwidth	25
flow port default	26
flow port etype	27
flow port transparent	29
flow port vlan	30
gemport	32
gemport traffic-mode	34
load keyfile	35
mapping	36
mapping mode	38
no shutdown	39
ont-find distance	40
ont-find interface gpon	42
ont-find interval-time	43
ont-find list-age	45
ont-silent auth-fail	47
ont-silent offline	48
ont auto-config	49
permit loid-lopw	50
permit loid	51
permit lopw	52
permit pw	53
permit sn-pw	54
permit sn	55
show alarm ont register-record	56
show keyfile	57
show ont-find config	58
show ont-find list	59
show ont-silent config	60
show ont-silent list	61
show ont brief count	62
show ont description	63

show ont info	64
show ssh	65
show ssh limit	66
show telnet	67
sip agent	68
sip digitmap	69
sip user	70
sip user mode	71
snmp-server	72
ssh	73
ssh limit	74
stop telnet client	75
stop vty	76
tecont tecont_id	77
telnet disable	78
telnet enable	79
telnet limit	80
telnet server-ip	81
telnetclient timeout	82
timeout	83
translate old-vlan	84
type 1 fix	85
type 2	86
type 3	87
type 4	88
type 5	89
upload keyfile	90
us car	91
us queue	92

PART II**Managing Users 93**

CHAPTER 3**Managing Users 95**

aaa	97
-----	----

auth-secret-key	98
default domain-name	99
domain	100
login-access-list	101
muser local	102
muser radius	103
muser tacacs+	104
radius host	105
radius host binding	106
service password-encryption	107
show domain	108
show login-access-list	109
show muser	110
show running-config oam	111
show tacacs+	112
show username	113
show username privilege-auth	114
show username silent	115
show users	116
state active	117
state block	118
stop	119
tacacs+	120
tacacs+ authentication-type	121
tacacs+ encrypt-key	122
tacacs+ preemption-time	123
timeout	124
username	125
username change-password	127
username change-privilege-pwd	128
username failmax	129
username online-max	130
username privilege-auth-remote-user	131
username privilege-auth	132

username silent-time 133

PART III

OLT Port Configuration 135

CHAPTER 4

OLT Port Configuration 137

channel-group group_id 138

channel-group load-balance 139

channel-group group_id mode 140

clear channel-group 141

clear interface 142

interface range ethernet 143

lACP port-priority 144

lACP system-priority 145

port-control mode master 146

port-control mode slave 147

port-isolation 148

port-rate-statistics interval 149

show description 150

show interface sfp 151

show lACP internal 152

show lACP neighbor 153

show lACP sys-id 154

show port-control mode 155

show port-isolation 156

show statistics interface ethernet 157

show statistics 158

show statistics channel-group 159

show statistics dynamic interface 160

show utilization interface 161

speed 162

PART IV

VLAN Configuration 163

CHAPTER 5

VLAN Configuration 165

- description 166
- ingress acceptable-frame 167
- ingress filtering 168
- interface ethernet 169
- priority 170
- show ingress interface 171
- show interface brief ethernet 172
- show interface ethernet 173
- switchport default vlan 174
- switchport ethernet 175
- switchport hybrid 176
- switchport mode 177
- switchport trunk 178
- vlan 179

PART V

OLT Network Configuration 181

CHAPTER 6

OLT Network Configuration 183

- arp 185
- arp aging-time 186
- description interface-name 187
- dhcp-snooping 188
- dhcp-snooping trust 189
- dlf forward 190
- interface 191
- interface loopback-interface 193
- interface vlan-interface 194
- ip-source-guard 195
- ip-source-guard filter 196
- ip address 197
- ip address mask-ip-address 198
- ip address range 199
- ip icmp mask-reply 200
- ip icmp unreachable 201

mac-address-table	202
mac-address-table learning	203
mac-address-table age-time	204
mac-address-table blackhole	205
mac-address-table max-mac-count	206
mirror destination-interface	207
mirror source-interface	208
show arp	209
show dhcp-snooping clients	210
show dhcp-snooping interface	211
show dlf-forward	213
show ip interface	214
show ip source guard	215
show mac-address-table age-time	216
show mac-address-table	217
show mirror	219
show snmp community	220
show snmp contact	221
show snmp engineid	222
show snmp group	223
show snmp host	224
show snmp location	225
show snmp mib	226
show snmp name	227
show snmp notify	228
show snmp user	229
show snmp view	230
shutdown	231
snmp-server	232
snmp-server community	233
snmp-server community encrypt	234
snmp-server contact	235
snmp-server encrypt	236
snmp-server engineid	237

- snmp-server group 238
- snmp-server host 239
- snmp-server location 241
- snmp-server max-packet-length 242
- snmp-server name 243
- snmp-server trap-source 244
- snmp-server user 245
- snmp-server view 247

PART VI

Quality of Service 249

CHAPTER 7

Quality of Service 251

- bandwidth egress rate 252
- clear traffic-statistic 253
- queue-scheduler cos-map 254
- queue-scheduler strict-priority 255
- queue-scheduler sp-wrr 256
- queue-scheduler wrr 257
- queue-scheduler dscp-map 258
- rate-limit 259
- show bandwidth egress 260
- show qos-info all 261
- show qos-interface 263
- show queue-scheduler 264
- storm-control 266
- traffic-copy-to-cpu 267
- traffic-redirect 268
- traffic-statistic 269

PART VII

Security 271

CHAPTER 8

Security 273

- absolute time-range 275
- access-limit 276

access-list match-order	277
access-group	278
access-list numbered standard	279
access-list standard	280
accounting-on	281
acct-secret-key	282
anti-dos ip fragment	283
anti-dos ip ttl	284
arp anti-spoofing	285
arp anti-spoofing deny-disguiser	286
arp anti-spoofing unknown	287
arp anti-spoofing valid-check	288
arp anti-flood	289
channel-group spanning-tree cost	291
clear cpu-classification	292
clear cpu-statistics	293
cpu-car	294
dhcp anti-attack	295
discard-bpdu	297
access-list extended name	298
access-list numbered extended	299
host-guard bind ip	301
ip route	302
access-list link name	303
access-list link number	304
local-user	306
nas-ipaddress	307
no ip route static all	308
periodic time-range	309
preemption-time	310
{primary-acct-ip second-acct-ip}	311
{primary-auth-ip second-auth-ip}	312
radius	313
realtime-account	316

no access-list	317
scheme	318
show access-list config	319
show access-list runtime	320
show anti-dos	321
show arp anti-flood	322
show arp anti interface	324
show cpu-car	325
show cpu-classification	326
show cpu-statistics	327
show cpu-utilization	328
show dhcp anti-attack	329
show discard-bpdu	330
show dot1x	331
show ip route	336
show radius	337
show shutdown-control interface	339
show spanning-tree interface	340
shutdown-control-recover	342
spanning-tree (global configuration)	343
spanning-tree (interface configuration)	346
time-range	349
username-format	350

PART VIII**Multicast Configuration 351**

CHAPTER 9**Multicast Configuration 353**

igmp-snooping	355
igmp-snooping drop	356
igmp-snooping fast-leave	357
igmp-snooping group-limit action	358
igmp-snooping group-limit	359
igmp-snooping general-query source-ip	360
igmp-snooping host-aging-time	361

igmp-snooping max-response-time	362
igmp-snooping multicast vlan	363
igmp-snooping {permit deny}	364
igmp-snooping profile refer	365
igmp-snooping profile	366
igmp-snooping {permit deny} group-range	367
igmp-snooping query-interval	368
igmp-snooping querier version	369
igmp-snooping querier-vlan	370
igmp-snooping query-max-respond	371
igmp-snooping record-host	372
igmp-snooping router-port-age	373
igmp-snooping route-port forward	374
igmp-snooping report-supression	375
igmp-snooping route-port vlan	376
ip range	377
mac range	378
multicast	379
multicast ds-tag add	380
multicast ds-tag remove	381
multicast ds-tag translate	382
multicast fast-leave disable	383
multicast group-limit	384
multicast interface	385
multicast mode igmp-snooping	386
multicast proxy-interval	387
multicast proxy-port	388
multicast us-tag add	389
multicast us-tag translate	390
profile limit	391
show igmp-snooping	392
show igmp-snooping profile	393
show igmp-snooping record-host	394
show igmp-snooping router-dynamic	395

show igmp-snooping router-static 396
 show multicast igmp-snooping 397
 show ont multicast 398

PART IX
System Management 399

CHAPTER 10
System Management 401

alarm all-packets 403
 alarm all-packets threshold 404
 alarm cpu 405
 alarm cpu threshold 406
 buildrun mode 407
 clear startup-config 408
 clock timezone 409
 copy running-config startup-config 410
 copy startup-config running-config 411
 load ftp 412
 load tftp 413
 load xmodem 414
 local fec 415
 show alarm all-packets 416
 show alarm cpu 417
 show clock 418
 show running-config 419
 show snmp client 420
 show snmp client summer-time 421
 show startup-config 422
 snmp client 423
 snmp client authenticate 424
 snmp client authentication-key 425
 snmp client broadcastdelay 426
 snmp client mode 427
 snmp client poll-interval 428
 snmp client retransmit-interval 429

sntp client retransmit	430
sntp client summer-time daily	431
sntp client summer-time weekly	432
sntp client valid-server	433
sntp server	434
sntp trusted-key	435
upload automatically configuration ftp	436
upload automatically configuration tftp	437
upload ftp	438
upload tftp	439

PART X
ONT Device Configuration 441

CHAPTER 11
ONT Device Configuration 443

alarm profile refer	444
clear ont-logging buffer	445
local bandwidth egress	446
local loop-detect	447
local mac-address-table	448
local neg-mode	449
local ranging-balance	450
local shutdown	451
local switch	452
ont-logging	453
ont-logging buffer	454
ont-logging monitor	455
ont-logging prefix	456
ont-logging timestamps	457
ont active	458
ont deactivate	459
ont neg-mode	460
ont reboot	461
ont shutdown	462
ont upgrade	463

optical power rx threshold	464
show ont-logging	465
show ont-logging buffer	466
show ont mac-address-table	467
show ont port-status	468
show ont statistics	469
show ont upgrade-status	470
show ont version	471



Using the Command-Line Interface

This chapter contains the following topics:

- [Using the Command-Line Interface, on page 2](#)

Using the Command-Line Interface

This chapter describes the command-line interface (CLI) and how to use it to configure your device.

Understanding Command Modes

The user interface is divided into many different modes. The commands available to you depend on which mode you are currently in. Enter a question mark (?) at the system prompt to obtain a list of commands available for each command mode.

When you start a session on the switch, you begin in user mode, often called user EXEC mode. Only a limited subset of the commands are available in user EXEC mode. For example, most of the user EXEC commands are one-time commands, such as **show** commands, which show the current configuration status, and **clear** commands, which clear counters or interfaces. The user EXEC commands are not saved when the switch reboots.

To have access to all commands, you must enter privileged EXEC mode. Normally, you must enter a password to enter privileged EXEC mode. From this mode, you can enter any privileged EXEC command or enter global configuration mode.

Using the configuration modes (global and interface), you can make changes to the running configuration. If you save the configuration, these commands are stored and used when the device reboots. To access the various configuration modes, you must start at global configuration mode. From global configuration mode, you can enter interface configuration mode and line configuration mode.

This table describes the main command modes, how to access each one, the prompt you see in that mode, and how to exit the mode. The examples in the table use the hostname *Device*.

Table 1: Command Mode Summary

Mode	Access Method	Prompt	Exit Method	About This Mode
User EXEC	Begin a session with your device.	Device>	Enter logout or quit .	Use this mode to <ul style="list-style-type: none"> • Change terminal settings. • Perform basic tests. • Display system information.

Mode	Access Method	Prompt	Exit Method	About This Mode
Privileged EXEC	While in user EXEC mode, enter the enable command.	Device#	Enter disable to exit.	Use this mode to verify commands that you have entered. Use a password to protect access to this mode.
Global configuration	While in privileged EXEC mode, enter the configure command.	Device(config)#	To exit to privileged EXEC mode, enter exit or end , or press Ctrl-Z .	Use this mode to configure parameters that apply to the entire switch.
Ethernet interface configuration	While in global configuration mode, enter the interface ethernet command (with a specific interface).	Device(config-if-ethernet-1/1)#	To exit to global configuration mode, enter exit . To return to privileged EXEC mode, press Ctrl-Z or enter end .	Use this mode to configure parameters for the Ethernet ports.
VLAN configuration	While in global configuration mode, enter the vlan vlan-id command.	Device(config-if-vlan)#	To exit to global configuration mode, enter the exit command. To return to privileged EXEC mode, press Ctrl-Z or enter end .	Use this mode to configure VLAN parameters.
AAA configuration	While in global configuration mode, enter the aaa command.	Device(config-aaa)#	To exit to global configuration mode, enter the exit command. To return to privileged EXEC mode, press Ctrl-Z or enter end .	Use this mode to setup the domain.

Mode	Access Method	Prompt	Exit Method	About This Mode
RADIUS configuration	While in global configuration mode, enter the radius host <i>radius-name</i> command.	Device (config-radius-r1) #	To exit to global configuration mode, enter the exit command. To return to privileged EXEC mode, press Ctrl-Z or enter end .	Use this mode to configure RADIUS parameters.
VLAN interface configuration	While in global configuration mode, enter the interface vlan-interface <i>vlan-id</i> command.	Device (config-if-vlaninterface-22) #	To exit to global configuration mode, enter the exit command. To return to privileged EXEC mode, press Ctrl-Z or enter end .	Use this mode to configure VLAN Layer 3 interface

Understanding the Help System

You can enter a question mark (?) at the system prompt to display a list of commands available for each command mode. You can also obtain a list of associated keywords and arguments for any command.

Table 2: Help Summary

Command	Purpose
help	Obtains a brief description of the help system in any command mode.
<i>abbreviated-command-entry</i> ? Device# cl? clear clock cls	Obtains a list of commands that begin with a particular character string.
<i>abbreviated-command-entry</i> <Tab> Device# sh cl <tab> Device# show clock	Completes a partial command name.
? Device> ?	Lists all commands available for a particular command mode.

Command	Purpose
<code>command ?</code> Device <code>show ?</code>	Lists the associated keywords for a command.
<code>command keyword ?</code> Device(config)# <code>clock timezone</code> <code>?</code> STRING<1-32> name of timezone	Lists the associated arguments for a keyword.

Understanding Abbreviated Commands

You need to enter only enough characters for the switch to recognize the command as unique.

This example shows how to enter the `show version` command in an abbreviated form:

```
Device# show ver
```

Understanding no Forms of Commands

Almost every configuration command also has a **no** form. In general, use the **no** form to disable a feature or function or reverse the action of a command. For example, the **no shutdown** interface configuration command reverses the shutdown of an interface. Use the command without the keyword **no** to re-enable a disabled feature or to enable a feature that is disabled by default.

Understanding CLI Error Messages

This table lists some error messages that you might encounter while using the CLI to configure your device.

Table 3: Common CLI Error Messages

Error Message	Meaning	How to Get Help
% Incomplete command.	You did not enter all the keywords or values required by this command.	Re-enter the command followed by a question mark (?) with a space between the command and the question mark. The possible keywords that you can enter with the command appear.
% Invalid input detected at '^' marker.	You entered the command incorrectly. The caret (^) marks the point of the error.	Enter a question mark (?) to display all the commands that are available in this command mode. The possible keywords that you can enter with the command appear.

Using Command History

The software provides a history or record of commands that you have entered. The command history feature is particularly useful for recalling long or complex commands or entries, including access lists. You can customize this feature to suit your needs.

Changing the Command History Buffer Size

By default, the device records ten command lines in its history buffer. You can alter this number for a current terminal session or for all sessions on a particular line. These procedures are optional.

Beginning in privileged EXEC mode, enter this command to change the number of command lines that the switch records during the current terminal session:

```
Device# terminal history [size number-of-lines]
```

The range is from 0 to 256.

Beginning in line configuration mode, enter this command to configure the number of command lines the switch records for all sessions on a particular line:

```
Device(config-line)# history [size number-of-lines]
```

The range is from 0 to 256.

Recalling Commands

To recall commands from the history buffer, perform one of the actions listed in this table. These actions are optional.



Note The arrow keys function only on ANSI-compatible terminals such as VT100s.

Table 4: Recalling Commands

Action	Result
Press Ctrl-P or the up arrow key.	Recalls commands in the history buffer, beginning with the most recent command. Repeat the key sequence to recall successively older commands.
Press Ctrl-N or the down arrow key.	Returns to more recent commands in the history buffer after recalling commands with Ctrl-P or the up arrow key. Repeat the key sequence to recall successively more recent commands.

Using Editing Features

This section describes the editing features that can help you manipulate the command line.

Editing Commands through Keystrokes

This table shows the keystrokes that you need to edit command lines. These keystrokes are optional.



Note The arrow keys function only on ANSI-compatible terminals such as VT100s.

Table 5: Editing Commands through Keystrokes

Capability	Keystroke	Purpose
Move around the command line to make changes or corrections.	Press Ctrl-B , or press the left arrow key.	Moves the cursor back one character.
	Press Ctrl-F , or press the right arrow key.	Moves the cursor forward one character.
	Press Ctrl-A .	Moves the cursor to the beginning of the command line.
	Press Ctrl-E .	Moves the cursor to the end of the command line.
	Press Esc B .	Moves the cursor back one word.
	Press Esc F .	Moves the cursor forward one word.
	Press Ctrl-T .	Transposes the character to the left of the cursor with the character located at the cursor.
Recall commands from the buffer and paste them in the command line. The switch provides a buffer with the last ten items that you deleted.	Press Ctrl-Y .	Recalls the most recent entry in the buffer.
	Press Esc Y .	Recalls the next buffer entry. The buffer contains only the last 10 items that you have deleted or cut. If you press Esc Y more than ten times, you cycle to the first buffer entry.
Delete entries if you make a mistake or change your mind.	Press the Delete or Backspace key.	Erases the character to the left of the cursor.

Capability	Keystroke	Purpose
	Press Ctrl-D .	Deletes the character at the cursor.
	Press Ctrl-K .	Deletes all characters from the cursor to the end of the command line.
	Press Ctrl-U or Ctrl-X .	Deletes all characters from the cursor to the beginning of the command line.
	Press Ctrl-W .	Deletes the word to the left of the cursor.
	Press Esc D .	Deletes from the cursor to the end of the word.
Capitalize or lowercase words or capitalize a set of letters.	Press Esc C .	Capitalizes at the cursor.
	Press Esc L .	Changes the word at the cursor to lowercase.
	Press Esc U .	Capitalizes letters from the cursor to the end of the word.
Designate a particular keystroke as an executable command, perhaps as a shortcut.	Press Ctrl-V or Esc Q .	
<p>Scroll down a line or screen on displays that are longer than the terminal screen can display.</p> <p>Note The More prompt is used for any output that has more lines than can be displayed on the terminal screen, including show command output. You can use the Return and Space bar keystrokes whenever you see the More prompt.</p>	Press the Return key.	Scrolls down one line.
	Press the Space bar.	Scrolls down one screen.
Redisplay the current command line if the switch suddenly sends a message to your screen.	Press Ctrl-L or Ctrl-R .	Redisplays the current command line.

Editing Command Lines that Wrap

You can use a wraparound feature for commands that extend beyond a single line on the screen. When the cursor reaches the right margin, the command line shifts ten spaces to the left. You cannot see the first ten

characters of the line, but you can scroll back and check the syntax at the beginning of the command. The keystroke actions are optional.

To scroll back to the beginning of the command entry, press **Ctrl-B** or the left arrow key repeatedly. You can also press **Ctrl-A** to immediately move to the beginning of the line.



Note The arrow keys function only on ANSI-compatible terminals such as VT100s.

In this example, the **access-list** global configuration command entry extends beyond one line. When the cursor first reaches the end of the line, the line is shifted ten spaces to the left and redisplayed. The dollar sign (\$) shows that the line has been scrolled to the left. Each time the cursor reaches the end of the line, the line is again shifted ten spaces to the left.

```
Device(config)# access-list 101 permit tcp 131.108.2.5 255.255.255.0 131.108.1
Device(config)# $ 101 permit tcp 131.108.2.5 255.255.255.0 131.108.1.20 255.25
Device(config)# $t tcp 131.108.2.5 255.255.255.0 131.108.1.20 255.255.255.0 eq
Device(config)# $108.2.5 255.255.255.0 131.108.1.20 255.255.255.0 eq 45
```

After you complete the entry, press **Ctrl-A** to check the complete syntax before pressing the **Return** key to execute the command. The dollar sign (\$) appears at the end of the line to show that the line has been scrolled to the right:

```
Device(config)# access-list 101 permit tcp 131.108.2.5 255.255.255.0 131.108.1$
```

The software assumes that you have a terminal screen that is 80 columns wide. If you have a width other than that, use the **terminal width** privileged EXEC command to set the width of your terminal.

Use line wrapping with the command history feature to recall and modify previous complex command entries.

Searching and Filtering Output of show and more Commands

You can search and filter the output for **show** and **more** commands. This is useful when you need to sort through large amounts of output or if you want to exclude output that you do not need to see. Using these commands is optional.

To use this functionality, enter a **show** or **more** command followed by the pipe character (|), one of the keywords **begin**, **include**, or **exclude**, and an expression that you want to search for or filter out:

```
command | {begin | include | exclude} regular-expression
```

Expressions are case sensitive. For example, if you enter **| exclude output**, the lines that contain *output* are not displayed, but the lines that contain *Output* appear.

This example shows how to include in the output display only lines where the expression *protocol* appears:

```
Device# show interfaces | include protocol
Vlan1 is up, line protocol is up
Vlan10 is up, line protocol is down
GigabitEthernet1/0/1 is up, line protocol is down
GigabitEthernet1/0/2 is up, line protocol is up
```

Accessing the CLI through a Console Connection or through Telnet

Before you can access the CLI, you must connect a terminal or a PC to the device console or connect a PC to the Ethernet management port and then power on the device, as described in the hardware installation guide that shipped with your device.

CLI access is available before device setup. After your device is configured, you can access the CLI through a remote Telnet session or SSH client.

You can use one of these methods to establish a connection with the device:

- Connect the device console port to a management station or dial-up modem, or connect the Ethernet management port to a PC. For information about connecting to the console or Ethernet management port, see the device hardware installation guide.
- Use any Telnet TCP/IP or encrypted Secure Shell (SSH) package from a remote management station. The device must have network connectivity with the Telnet or SSH client, and the device must have an enable secret password configured.

The device supports up to 16 simultaneous Telnet sessions. Changes made by one Telnet user are reflected in all other Telnet sessions.

The device supports up to five simultaneous secure SSH sessions.

After you connect through the console port, through the Ethernet management port, through a Telnet session or through an SSH session, the user EXEC prompt appears on the management station.



PART I

Getting Started With OLT Network

- [Getting Started With OLT Network, on page 13](#)



Getting Started With OLT Network

- [add inner-vlan, on page 15](#)
- [aim, on page 16](#)
- [alarm ont register-record, on page 18](#)
- [crypto key, on page 19](#)
- [default vlan, on page 20](#)
- [delete aim, on page 21](#)
- [deploy profile, on page 22](#)
- [description, on page 23](#)
- [device type, on page 24](#)
- [ds car bandwidth, on page 25](#)
- [flow port default, on page 26](#)
- [flow port etype, on page 27](#)
- [flow port transparent, on page 29](#)
- [flow port vlan, on page 30](#)
- [gemport, on page 32](#)
- [gemport traffic-mode, on page 34](#)
- [load keyfile, on page 35](#)
- [mapping, on page 36](#)
- [mapping mode, on page 38](#)
- [no shutdown, on page 39](#)
- [ont-find distance, on page 40](#)
- [ont-find interface gpon, on page 42](#)
- [ont-find interval-time, on page 43](#)
- [ont-find list-age, on page 45](#)
- [ont-silent auth-fail, on page 47](#)
- [ont-silent offline, on page 48](#)
- [ont auto-config, on page 49](#)
- [permit loid-lopw, on page 50](#)
- [permit loid, on page 51](#)
- [permit lopw, on page 52](#)
- [permit pw, on page 53](#)
- [permit sn-pw, on page 54](#)
- [permit sn, on page 55](#)

- show alarm ont register-record, on page 56
- show keyfile, on page 57
- show ont-find config, on page 58
- show ont-find list , on page 59
- show ont-silent config, on page 60
- show ont-silent list, on page 61
- show ont brief count, on page 62
- show ont description, on page 63
- show ont info, on page 64
- show ssh, on page 65
- show ssh limit, on page 66
- show telnet, on page 67
- sip agent, on page 68
- sip digitmap, on page 69
- sip user, on page 70
- sip user mode, on page 71
- snmp-server, on page 72
- ssh, on page 73
- ssh limit, on page 74
- stop telnet client, on page 75
- stop vty, on page 76
- tcont *tcont_id*, on page 77
- telnet disable, on page 78
- telnet enable, on page 79
- telnet limit, on page 80
- telnet *server-ip*, on page 81
- telnetclient timeout, on page 82
- timeout, on page 83
- translate old-vlan, on page 84
- type 1 fix, on page 85
- type 2, on page 86
- type 3, on page 87
- type 4, on page 88
- type 5, on page 89
- upload keyfile, on page 90
- us car, on page 91
- us queue, on page 92

add inner-vlan

To configure VLAN stacking rule, use the **add inner-vlan** command in VLAN profile configuration mode. To delete the VLAN stacking rule, use the **no add inner-vlan** command.

add inner-vlan *inner-vlan-id* {*priority* | **outer-vlan** *outer-vlan-id* [*priority*]}

no add inner-vlan *inner-vlan-id* [*priority*]

Syntax Description		
<i>inner-vlan-id</i>		The inner VLAN ID. The range is from 0 to 4094.
<i>outer-vlan-id</i>		The outer VLAN ID. The range is from 0 to 4094.
<i>priority</i>		The 802.1 priority value. The range is from 0 to 7.

Command Modes VLAN profile configuration (deploy-profile-vlan)

Usage Guidelines A VLAN profile type must be configured.
Modifying and activating the VLAN template will cause the ONT that references the template to go online again.

Examples This example shows how to configure VLAN stacking rule.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile vlan
Device(deploy-profile-vlan)# aim 5
Device(deploy-profile-vlan-5)# add inner-vlan 2 3 outer-vlan 2 3
Device(deploy-profile-vlan-5)# active
```

Related Commands	Command	Description
	deploy profile	Deploys a profile type
	aim	Creates aim based on the profile.

aim

To create profile based aim. use the **aim** command in profile configuration mode.

For alarm, dba, line, downstream traffic, upstream traffic and VLAN profile configuration modes

aim {*index_number* | **name** *name*}

For rule and unique profile configuration modes

aim {*slot-num/pon-num/ont-num* | **name** *name*}

Syntax Description		
<i>index_number</i>	The profile index number. The range is from 0 to 1023.	
<i>name</i>	The profile name. The format is string. The string length range is from 1 to 128.	
<i>slot-num/pon-num/ont-num</i>	The ONT ID.	<ul style="list-style-type: none"> • <i>slot-num</i>: The slot number. The value is 0. • <i>pon-num</i>: The PON number. The range is from 1 to 8. • <i>ont-num</i>: The ONT number. The range is from 1 to 128.

Command Modes Profile configuration (deploy-profile)

Usage Guidelines A profile type must be configured.

Examples This example shows how to create a VLAN aim.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile vlan
Device(deploy-profile-vlan)# aim 5
Device(deploy-profile-vlan-5)#
```

Example

This example shows how to create a unique aim.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile unique
Device(deploy-profile-unique)# aim 0/1/1
Device(deploy-profile-unique-0/1/1)#
```


Related Commands

Command	Description
delete aim	Deletes profile based aim.

alarm ont register-record

To enable ONT register record alarm and set an alarm threshold, use the **alarm ont register-record** command in global configuration mode. To disable the alarm, use the **no alarm ont register-record** command.

alarm ont register-record [**threshold**]*threshold_value*

no alarm ont register-record [**threshold**]*threshold_value*

Syntax Description

threshold_value

The threshold value.

The range is from 1 to 128. The default is 64.

Command Modes

Global configuration (config)

Usage Guidelines

You can limit the number of ONTs that can be registered on the PON port by setting a threshold value. If the number of ONTs on the PON port exceeds the threshold value, an alarm is generated. The alarm is cancelled once the number of ONTs is less than the threshold value.

Examples

This example shows how to set an ONT register record alarm threshold value.

```
Device> enable
Device# configure terminal
Device(config)# alarm ont register-record threshold 80
```

Related Commands

Command	Description
show alarm ont register-record	Displays information about register record alarm of an ONT

crypto key

To configure or remove a key, use the **crypto key** command in privileged EXEC mode.

crypto key {generate rsa | refresh | zeroize rsa}

Syntax Description	Command	Description
	generate rsa	Configures a default key.
	refresh	Activates the key.
	zeroize rsa	Removes the key.

Command Modes Privileged EXEC (#)

Usage Guidelines SSH must be enabled on the device.

Examples This example shows how to configure a default key.

```
Device> enable
Device# crypto key generate rsa
Generate default SSH key successfully.
```

This example shows how to activate the key.

```
Device> enable
Device# crypto key refresh
Refresh SSH key successfully.
```

Example

This example shows how to remove the key.

```
Device> enable
Device# crypto key zeroize rsa
Zeroize SSH key successfully.
```

Related Commands	Command	Description
	ssh	Enables SSH on an OLT.

default vlan

To configure the VLAN tagging rule, use the **default vlan** command in VLAN profile configuration mode. To delete the VLAN tagging rule, use the **no default vlan** command.

default vlan *vlan_id* [*priority*]

Syntax Description		
<i>vlan_id</i>	The VLAN ID.	The range is from 1 to 4094.
<i>priority</i>	The 802.1 priority value.	The range is from 0 to 7.

Command Modes VLAN profile configuration (deploy-profile-vlan)

Usage Guidelines A VLAN profile type must be configured.
Modifying and activating the VLAN template will cause the ONT that references the template to go online again.

Examples This example shows how to configure the VLAN tagging rule.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile vlan
Device(deploy-profile-vlan)# aim 5
Device(deploy-profile-vlan-5)# default vlan 5 5
Device(deploy-profile-vlan-5)# active
```

Related Commands	Command	Description
	deploy profile	Deploys a profile type
	aim	Creates aim based on the profile.

delete aim

To delete profile based aim, use the **delete aim** command in profile configuration mode.

For alarm, dba, line, downstream traffic, upstream traffic and VLAN profile configuration modes

```
delete aim {profile_list | name name}
```

For rule and unique profile configuration modes

```
delete aim {slot-num/pon-num/ont-num | name name}
```

Syntax Description		
<i>index_number</i>	The profile index number. The range is from 0 to 1023.	
<i>name</i>	The profile name. The format is string. The string length range is from 1 to 128.	
<i>slot-num/pon-num/ont-num</i>	The ONT ID. <ul style="list-style-type: none"> • <i>slot-num</i>: The slot number. The value is 0. • <i>pon-num</i>: The PON number. The range is from 1 to 8. • <i>ont-num</i>: The ONT number. The range is from 1 to 128. 	

Command Modes Profile configuration (deploy-profile)

Usage Guidelines A profile type and profile based aim must be created on the device.

Examples This example show how to delete a VLAN aim configuration.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile vlan
Device(deploy-profile-vlan)# delete aim 5
```

Related Commands	Command	Description
	deploy profile	Deploys a profile type
	aim	Creates aim based on the profile.

deploy profile

To deploy a profile type, use the **deploy profile** command in global configuration mode.

deploy profile {**alarm** | **dba** | **ds-traffic** | **line** | **rule** | **unique** | **us-traffic** | **vlan**}

Syntax	Description
alarm	The alarm profile.
dba	The DBA profile.
ds-traffic	The downstream traffic profile.
line	The line profile.
rule	The rule profile.
unique	The unique profile.
us-traffic	The upstream traffic profile.
vlan	The VLAN profile.

Command Modes Global configuration (config)

Examples This example shows how to deploy a line profile.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile line
```

Related Commands	Command	Description
	aim	Creates aim based on the profile.

description

To configure an ONT description, use the **description** *ont_description* command in unique profile configuration mode. To delete an ONT description, use the **no description** *ont_description* command.

description *ont_description*

no description *ont_description*

Syntax Description

<i>ont_description</i>	The ONT description.
------------------------	----------------------

Command Modes

Unique profile configuration (deploy-profile-unique)

Usage Guidelines

A unique profile type must be configured.

Examples

This example shows how to configure an ONT description.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile unique
Device(deploy-profile-unique)# aim 0/1/1
Device(deploy-profile-unique-0/1/1)# description cisco
```

Related Commands

Command	Description
deploy profile	Deploys a profile type
aim	Creates aim based on the profile.

device type

To configure a device type, use the **device type** *type* command in line profile configuration mode.

device type *type*

Syntax Description

type

The ONT device type name. The name of the ONT device type should conform to the GPON Terminal Naming Specification formulated.

Command Modes

Line profile configuration (deploy-profile-line)

Usage Guidelines

A line profile type must be configured.

Modifying and activating the line traffic profile will cause the ONT that references the template to go online again.

Examples

This example shows how to configure a device type.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile line
Device(deploy-profile-line)# aim 5
Device(deploy-profile-line-5)# device type c40-100
Device(deploy-profile-line-5)# active
```

Related Commands

Command	Description
deploy profile	Deploys a profile type
aim	Creates aim based on the profile.

ds car bandwidth

To configure committed access rate (CAR) downlink of a GEM port, use the **ds car bandwidth** command in downlink traffic profile configuration mode.

ds car bandwidth *bandwidth_rate*

Syntax Description	<i>bandwidth_rate</i>	The downstream bandwidth in kbps. The value range is from 64 to 2608832.
---------------------------	-----------------------	---

Command Modes Downlink traffic profile (deploy-profile-ds-traffic)

Usage Guidelines A downlink profile type must be configured.
Modifying and activating the downlink traffic profile will cause the ONT that references the template to go online again.

Examples

This example shows how to configure a GEM port

```
Device> enable
Device# configure terminal
Device(config)# deploy profile ds-traffic
Device(deploy-profile-ds-traffic)# aim 5
Device(deploy-profile-ds-traffic-5)# ds car bandwidth 1024
```

Related Commands	Command	Description
	deploy profile	Deploys a profile type
	aim	Creates aim based on the profile.

flow port default

To create a default flow rule, use the **flow *flow_id* port {eth *port-id* | veip | iphost} default** command. To delete a default VLAN flow rule, use the **no** form of this command.

flow *flow_id* port {eth *port-id* | veip | iphost} default vlan *destination_vlan_id* [*priority*]

no flow *flow_id*

Syntax	Description
<i>flow_id</i>	The flow index. The range is from 0 to 63.
<i>port-id</i>	The ONT Ethernet port ID. The range is from 1 to 24.
default	Specifies the default configuration.
<i>destination_vlan_id</i>	The destination VLAN ID The range is from 1 to 4094.
<i>priority</i>	The VLAN priority. The range is from 0 to 7.

Command Modes Line profile configuration (deploy-profile-line)

Usage Guidelines A line profile type must be configured.
Modifying and activating the line traffic profile will cause the ONT that references the template to go online again.

Examples This example shows how to create a default VLAN flow rule.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile line
Device(deploy-profile-line)# aim 5
Device(deploy-profile-line-5)# flow 2 port eth 3 default vlan 3 3
```

Related Commands

Command	Description
deploy profile	Deploys a profile type
aim	Creates aim based on the profile.

flow port etype

To create a flow rule based on ethernet frame type, use the **flow** *flow_id* **port** {**eth** *port-id* | **veip** | **iphost**} **etype** {**arp** | **ipoe** | **pppoe**} {**default** **vlan** *source_vlan_id* *priority* | **transparent** | **vlan** *source_vlan_id* {*priority* | **add** **vlan** *destination_vlan_id* [*priority*] | **keep** | **translate** **vlan** *destination_vlan_id* [*priority*]}}

flow *flow_id* **port** {**eth** *port-id* | **veip** | **iphost**} **etype** {**arp** | **ipoe** | **pppoe**} {**default** **vlan** *source_vlan_id* *priority* | **transparent** | **vlan** *source_vlan_id* {*priority* | **add** **vlan** *destination_vlan_id* [*priority*] | **keep** | **translate** **vlan** *destination_vlan_id* [*priority*]}}

no **flow** *flow_id*

Syntax	Description
<i>flow_id</i>	The flow index. The range is from 0 to 63.
<i>port-id</i>	The ONT Ethernet port ID. The range is from 1 to 24.
default	Specifies the default configuration.
<i>destination_vlan_id</i>	The destination VLAN ID The range is from 1 to 4094.
<i>priority</i>	The VLAN priority. The range is from 0 to 7.
etype	Specifies user ethernet frame type as the configuration.
arp	Specifies ARP as the filter type.
ipoe	Specifies IPoE as the filter type.
pppoe	Specifies PPPOE as the filter type.
<i>source_vlan_id</i>	The source VLAN ID The range is from 1 to 4094.
transparent	Specifies the service type as transparent
add	Adds outer service VLAN
keep	Adds trunk as the service type.
translate	Add translate as the service type.

Command Modes Line profile configuration (deploy-profile-line)

Usage Guidelines A line profile type must be configured.

Modifying and activating the line traffic profile will cause the ONT that references the template to go online again.

Examples

This example shows how to create a translate flow rule based on ethernet frame type.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile line
Device(deploy-profile-line)# aim 5
Device(deploy-profile-line-5)# flow 2 port iphost etype arp vlan 3 translate vlan 4 1
```

Related Commands

Command	Description
deploy profile	Deploys a profile type
aim	Creates aim based on the profile.

flow port transparent

To create a transparent flow rule, use the **flow *flow_id* port {eth *port-id* | veip | iphost} transparent** command. To delete a transparent flow rule, use the **no** form of this command.

flow *flow_id* port {eth *port-id* | veip | iphost} transparent

no flow *flow_id*

Syntax Description		
<i>flow_id</i>	The flow index. The range is from 0 to 63.	
<i>port-id</i>	The ONT Ethernet port ID. The range is from 1 to 24.	
transparent	Specifies the service type as transparent	

Command Modes Line profile configuration (deploy-profile-line)

Usage Guidelines A line profile type must be configured.

Modifying and activating the line traffic profile will cause the ONT that references the template to go online again.

Examples

This example shows how to create a transparent flow rule.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile line
Device(deploy-profile-line)# aim 5
Device(deploy-profile-line-5)# flow 2 port eth 3 transparent
```

Related Commands	Command	Description
	deploy profile	Deploys a profile type
	aim	Creates aim based on the profile.

flow port vlan

To create a VLAN flow rule, use the **flow flow_id port {eth port-id | veip | iphost} vlan** command. To delete a VLAN flow rule, use the **no** form of this command.

flow flow_id port {eth port-id | veip | iphost} vlan source_vlan_id {priority | add vlan destination_vlan_id [priority] | keep | translate vlan destination_vlan_id [priority]}

no flow flow_id

Syntax Description

<i>flow_id</i>	The flow index. The range is from 0 to 63.
<i>port-id</i>	The ONT Ethernet port ID. The range is from 1 to 24.
<i>destination_vlan_id</i>	The destination VLAN ID The range is from 1 to 4094.
<i>priority</i>	The VLAN priority. The range is from 0 to 7.
<i>source_vlan_id</i>	The source VLAN ID The range is from 1 to 4094.
add	Adds outer service VLAN
keep	Adds trunk as the service type.
translate	Add translate as the service type.

Command Modes

Line profile configuration (deploy-profile-line)

Usage Guidelines

A line profile type must be configured.

Modifying and activating the line traffic profile will cause the ONT that references the template to go online again.

Examples

This example shows how to create a VLAN keep flow rule.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile line
Device(deploy-profile-line)# aim 5
Device(deploy-profile-line-5)# flow 2 port eth 3 vlan 2 keep
```

Related Commands

Command	Description
deploy profile	Deploys a profile type
aim	Creates aim based on the profile.

gempport

To create a GEM port and configure the parameters, use the **gempport** *gem_index* **tcont** *tcont_id* command in line profile configuration mode.

For line profile configuration mode

```
gempport gem_index tcont tcont_id {vlan-profile | us-traffic-profile | ds-traffic-profile} {index_number | name name}
```

For unique profile configuration mode.

```
gempport gem_index {vlan-profile | us-traffic-profile | ds-traffic-profile} {index_number | name name}
```

Syntax Description

<i>gem_index</i>	The GEM port index number. The range is from 1 to 1024. Currently, at most 24 GEM ports can be created in each line profile.
<i>tcont_id</i>	The T-CONT ID to bind to the GEM port. The range is from 1 to 8.
vlan-profile	The VLAN profile.
us-traffic-profile	The upstream traffic profile.
ds-traffic-profile	The downstream traffic profile.
<i>index_number</i>	The index of the template. The range is from 0 to M, where M is the maximum number of ONUs supported by the whole machine.
<i>name</i>	The name of the template.

Command Modes

Line profile configuration (deploy-profile-line)

Usage Guidelines

A line profile type must be configured.

Modifying and activating the line traffic profile will cause the ONT that references the template to go online again.

Examples

This example show how to create a gempport and configure a T-CONT to the gempport.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile line
Device(deploy-profile-line)# aim 5
GPON(deploy-profile-line-5)# device type n40-100-1
GPON(deploy-profile-line-5)# tcont 2 profile dba 1
Device(deploy-profile-line-5)# gempport traffic-mode car
Device(deploy-profile-line-5)# gempport 2 tcont 2 vlan-profile 1
```


Related Commands

Command	Description
deploy profile	Deploys a profile type
aim	Creates aim based on the profile.
gemport traffic-mode	Configures the GEM traffic mode

gemport traffic-mode

To configure the GEM traffic mode, use the **gemport traffic-mode** command in line profile configuration mode.

gemport traffic-mode {car | queue}

Syntax Description	car	queue
	Specifies committed access rate (CAR) as GEM traffic mode.	Specifies priority scheduling queue as GEM traffic mode.

Command Modes Line profile configuration (deploy-profile-line)

Usage Guidelines A line profile type must be configured.

Modifying and activating the line traffic profile will cause the ONT that references the template to go online again.

Examples

This example shows how to configure the GEM port traffic mode based on queue.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile line
Device(deploy-profile-line)# aim 5
Device(deploy-profile-line-5)# gemport traffic-mode queue
```

Related Commands

Command	Description
deploy profile	Deploys a profile type
aim	Creates aim based on the profile.

load keyfile

To download the key from the external key server, use the **load keyfile** command in privileged EXEC mode.

Download from a TFTP server

load keyfile {**public** | **private**} **tftp**{**inet** | **inet6**}*server_ip filename*

Download from a FTP server

load keyfile {**public** | **private**} **ftp**{**inet** | **inet6**}*server_ip filename username password*

Syntax Description

public	The public SSH key file
private	The private SSH key file
tftp	Loads the file from the TFTP server.
ftp	Loads the file from FTP server.
inet	The IPv4 address family.
inet6	The IPv6 address family
<i>server_ip</i>	The server IP address
<i>filename</i>	The key filename.
<i>username</i>	The FTP username
<i>password</i>	The FTP password.

Command Modes

Privileged EXEC (#)

Usage Guidelines

SSH must be enabled on the device.

Examples

This example shows how to download the public key from the FTP server

```
Device> enable
Device# load keyfile public ftp inet 100.100.100.11 mykey admin 123456
```

Related Commands

Command	Description
ssh	Enables SSH on an OLT.
upload keyfile	Uploads the local key to the key server.

mapping

To create GEM port mapping, use the **mapping** *index_number* in line profile configuration mode. To disable GEM port mapping, use the **no mapping** *index_number* command.

mapping *index_number* {**port** {*eth port_id* | **veip** | **iphost**} | **priority** *priority_value* | **vlan** *vlan_id*} **gemport** *gemport_index*

no mapping *index_number*

Syntax Description

<i>index_number</i>	The mapping index number. The value range is from 0 to 47.
<i>port_id</i>	The ONT Ethernet port ID. The range is from 1 to 24.
eth	The ONT Ethernet interface. Optional for SFU
veip	The ONT WAN interface. Optional for HGU
iphost	The ONT voice IP interface.
<i>gemport_index</i>	The GEM Port index number. The ranges is from 1 to 1024. Currently, only 24 GEM Ports can be created in each line profile.
<i>priority</i>	The 802.1P. The range is from 0 to 7.
<i>vlan_id</i>	The VLAN ID The range is from 1 to 4094.

Command Modes

Line profile configuration (deploy-profile-line)

Usage Guidelines

A line profile type must be configured.

Modifying and activating the line traffic profile will cause the ONT that references the template to go online again.

Examples

This example shows how to create GEM port mapping using ethernet port.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile line
Device(deploy-profile-line)# aim 5
Device(deploy-profile-line-5)# mapping 2 port eth 3 gemport 3
```

Related Commands

Command	Description
deploy profile	Deploys a profile type
aim	Creates aim based on the profile.

mapping mode

To configure the GEM port mapping mode, use the **mapping mode** command in line profile configuration mode.

mapping mode{**port** | **port-priority** | **port-vlan** | **port-vlan-priority** | **priority** | **vlan** | **vlan-priority**}

Syntax Description		
port		Configures port as the mapping mode.
port-priority		Configures port and 802.1p priority as the mapping mode
port-vlan		Configures port and VLAN as the mapping mode
port-vlan-priority		Configures port, VLAN and 802.1p priority as the mapping mode
priority		Configures 802.1p priority as the mapping mode
vlan		Configures VLAN as the mapping mode
vlan-priority		Configures VLAN and 802.1p priority as the mapping mode

Command Modes Line profile configuration (deploy-profile-line)

Usage Guidelines A line profile type must be configured.

Modifying and activating the line traffic profile will cause the ONT that references the template to go online again.

Examples

This example shows how to configure the GEM port mapping mode as VLAN

```
Device> enable
Device# configure terminal
Device(config)# deploy profile line
Device(deploy-profile-line)# aim 5
Device(deploy-profile-line-5)# mapping mode vlan
```

Related Commands

Command	Description
deploy profile	Deploys a profile type
aim	Creates aim based on the profile.

no shutdown

To enable a shutdown port, use the **no shutdown** command in interface configuration mode. To disable a port use the **shutdown** command.

no shutdown

shutdown

Command Modes

Interface configuration (config-if)

Examples

This example shows how to enable a shutdown port.

```
Device> enable
Device# configure terminal
Device(config)# interface ethernet 1/1
Device(config-if-ethernet-1/1)# no shutdown
```

ont-find distance

To configure the ONT logical distance, use the **ont-find distance** command to global configuration mode. To disable the logical distance, use the **no ont-find distance** command.

ont-find distance min *minimum_distance* **max** *maximum_distance* **interface gpon** {*slot-number/port-number* | **all**}

no ont-find distance interface gpon {*slot-number/port-number* | **all**}

Syntax Description

min <i>minimum_distance</i>	The minimum distance. The range is from 0 to 40. The default is 0.
max <i>maximum_distance</i>	The maximum distance. The distance range is from 0 to 60. The default is 20.
<i>slot-number/port-number</i>	<i>slot-number/port-number</i> : The port ID. <ul style="list-style-type: none"> • <i>slot-number</i>: <ul style="list-style-type: none"> • GPON: The value is 0. • GE Ethernet: The value is 1. • 10GE Ethernet: The value is 2. • <i>port-number</i>: <ul style="list-style-type: none"> • GPON: The range is from 1 to 8. • GE Ethernet: The range is from 1 to 4. • 10GE Ethernet: The range is from 1 to 2.
all	All ports.

Command Modes

Global configuration (config)

Examples

This example shows how to configure the ONT logical distance.

```
Device> enable
Device# configure terminal
Device(config)# ont-find distance min 10 max 30 interface gpon 0/1
Change the logic distance will reset the PON port, are you sure(y/n)?[n]y
Config success: 1, failed: 0.
```

Related Commands

Command	Description
ont-find interface gpon	Enables auto-discover configuration.
ont-find interval-time	Configures the auto-discover interval time.

Command	Description
ont-find list-age	Configures the auto-discover aging time.
show ont-find config	Displays information about ONT auto find configuration and other related parameters.
show ont-find list	Displays information about ONT find list.

ont-find interface gpon

To enable auto-discover configuration, use the **ont-find interface gpon** command to global configuration mode. To disable the logical distance, use the **no ont-find interface gpon** command.

ont-find interface gpon {*slot-number/port-number* | **all**}

no ont-find interface gpon {*slot-number/port-number* | **all**}

Syntax Description

slot-number/port-number

slot-number/port-number : The port ID.

- *slot-number*:
 - GPON: The value is 0.
 - GE Ethernet: The value is 1.
 - 10GE Ethernet: The value is 2.
- *port-number*:
 - GPON: The range is from 1 to 8.
 - GE Ethernet: The range is from 1 to 4.
 - 10GE Ethernet: The range is from 1 to 2.

all

All ports.

Command Modes

Global configuration (config)

Examples

This example shows how to enable auto-discover configuration.

```
Device> enable
Device# configure terminal
Device(config)# ont-find interface gpon 0/1
```

Related Commands

Command	Description
ont-find distance	Configures the ONT logical distance.
ont-find interval-time	Configures the auto-discover interval time.
ont-find list-age	Configures the auto-discover aging time.
show ont-find config	Displays information about ONT auto find configuration and other related parameters.
show ont-find list	Displays information about ONT find list.

ont-find interval-time

To configure the auto-discover interval time, use the **ont-find interval-time** command in global configuration mode. To disable the auto-discover interval time, use the **no ont-find interval-time** command.

ont-find interval-time *interval_time* **interface gpon** {*slot-number/port-number* | **all**}

no ont-find interface gpon {*slot-number/port-number* | **all**}

Syntax Description

<i>interval_time</i>	The interval time. The range is from 3 to 30. The default is 10.
all	All ports.
<i>slot-number/port-number</i>	<p><i>slot-number/port-number</i> : The port ID.</p> <ul style="list-style-type: none"> • <i>slot-number</i>: <ul style="list-style-type: none"> • GPON: The value is 0. • GE Ethernet: The value is 1. • 10GE Ethernet: The value is 2. • <i>port-number</i>: <ul style="list-style-type: none"> • GPON: The range is from 1 to 8. • GE Ethernet: The range is from 1 to 4. • 10GE Ethernet: The range is from 1 to 2.

Command Modes

Global configuration (config)

Examples

This example shows how to configure the ONT auto-discover interval time.

```
Device> enable
Device# configure terminal
Device(config)# ont-find interval-time 20 interface gpon 0/1
Config success: 1, failed: 0.
```

Related Commands

Command	Description
ont-find interface gpon	Enables auto-discover configuration.
ont-find distance	Configures the ONT logical distance.
ont-find list-age	Configures the auto-discover aging time.
show ont-find config	Displays information about ONT auto find configuration and other related parameters.

Command	Description
show ont-find list	Displays information about ONT find list.

ont-find list-age

To configure the auto-discover aging time, use the **ont-find list-age time** command in global configuration mode. Use the **no ont-find list-age time** command.

ont-find list-age time *aging_time* **interface gpon** {*slot-number/port-number* | **all**}

no ont-find list-age interface gpon {*slot-number/port-number* | **all**}

Syntax Description

<i>aging_time</i>	The discovery mode timeout time. The unit is hour. The value range is from 1 to 168.
<i>slot-number/port-number</i>	<p><i>slot-number/port-number</i> : The port ID.</p> <ul style="list-style-type: none"> • <i>slot-number</i>: <ul style="list-style-type: none"> • GPON: The value is 0. • GE Ethernet: The value is 1. • 10GE Ethernet: The value is 2. • <i>port-number</i>: <ul style="list-style-type: none"> • GPON: The range is from 1 to 8. • GE Ethernet: The range is from 1 to 4. • 10GE Ethernet: The range is from 1 to 2.
all	All ports.

Command Modes

Global configuration (config)

Examples

This example shows how to configure the auto-discover aging time.

```
Device> enable
Device# configure terminal
Device(config)# ont-find list-age time 600 interface gpon 0/1
Config success: 1, failed: 0.
```

Related Commands

Command	Description
ont-find interface gpon	Enables auto-discover configuration.
ont-find distance	Configures the ONT logical distance.
ont-find interval-time	Configures the auto-discover interval time.
show ont-find config	Displays information about ONT auto find configuration and other related parameters.

Command	Description
show ont-find list	Displays information about ONT find list.

ont-silent auth-fail

To enable the ONT auth-fail silent configuration, use the **ont-silent auth-fail** command in global configuration mode. To disable the ONT auth-fail silent configuration, use the **no ont-silent auth-fail** command.

ont-silent auth-fail {time *silence_period* | interface **gpon** {*slot-number/port-number* | **all**}}

no ont-silent auth-fail interface gpon {*slot-number/port-number* | **all**}

Syntax Description		
<i>silence_period</i>		The silent period after a failed authentication. The unit in seconds. The range is from 1 to 86400. The default is 60.
<i>slot-number/port-number</i>		<i>slot-number/port-number</i> : The port ID. <ul style="list-style-type: none"> • <i>slot-number</i>: <ul style="list-style-type: none"> • GPON: The value is 0. • GE Ethernet: The value is 1. • 10GE Ethernet: The value is 2. • <i>port-number</i>: <ul style="list-style-type: none"> • GPON: The range is from 1 to 8. • GE Ethernet: The range is from 1 to 4. • 10GE Ethernet: The range is from 1 to 2.
all		All ports.

Command Modes Global configuration (config)

Examples

This example shows how to enable the ONT auth-fail silent configuration.

```
Device> enable
Device# configure terminal
Device(config)# ont-silent auth-fail time 40 interface gpon 0/1
Config success: 1, failed: 0.
```

Related Commands

Command	Description
ont-silent offline	Enables auto-discover configuration.

ont-silent offline

To enable the ONT offline silent configuration, use the **ont-silent offline** command in global configuration mode. To disable the ONT offline silent configuration, use the **no ont-silent offline** command.

ont-silent offline {time *silence_period* | interface **gpon** {*slot-number/port-number* | **all**}}

no ont-silent offline interface gpon {*slot-number/port-number* | **all**}

Syntax Description		
<i>silence_period</i>	The silent period after a failed authentication. The unit in seconds. The range is from 1 to 86400. The default is 60.	
<i>slot-number/port-number</i>	<i>slot-number/port-number</i> : The port ID.	<ul style="list-style-type: none"> • <i>slot-number</i>: <ul style="list-style-type: none"> • GPON: The value is 0. • GE Ethernet: The value is 1. • 10GE Ethernet: The value is 2. • <i>port-number</i>: <ul style="list-style-type: none"> • GPON: The range is from 1 to 8. • GE Ethernet: The range is from 1 to 4. • 10GE Ethernet: The range is from 1 to 2.
all	All ports.	

Command Modes Global configuration (config)

Examples

This example shows how to enable the ONT offline silent configuration.

```
Device> enable
Device# configure terminal
Device(config)# ont-silent offline time 40 interface gpon 0/1
Config success: 1, failed: 0.
```

Related Commands

Command	Description
ont-silent auth-fail	Enables ONT auth-fail silent configuration

ont auto-config

To enable ONT auto-configuration, use the **ont auto-config** command in global configuration mode. To disable ONT auto-configuration, use the **no ont auto-config** command.

```
ont auto-config [{index_number name name | name name }]{all-ont | device-type device_type}
```

```
no ont auto-config [{index_number name name | name name }]{all-ont | device-type device_type}
```

Syntax Description		
	<i>index_number</i>	The index of the template. The range is from 0 to M, where M is the maximum number of ONUs supported by the whole machine.
	<i>name</i>	The name of the template.
	all-ont	All ONTs.
	device-type <i>device_type</i>	The device identifier. The format is in string. The range is 1-256.

Command Modes Global configuration (config)

Examples

This example shows how to enable auto-configuration.

```
Device> enable
Device# configure terminal
Device(config)# ont auto-config
```

permit loid-lopw

To create a logical ONT ID and logical ONT ID password permit profile, use the **permit loid-lopw** command in rule profile configuration mode.

```
permit loid-lopw lopw loid line {profile_line_list | name name} {default line {index_number | name name} | once-on {no-aging | aging-time time}}
```

Syntax Description		
	<i>lopw</i>	The logical ONT ID password.
	<i>loid</i>	The logical ONT ID.
	<i>profile_line_list</i>	The profile line list number.
	<i>index_number</i>	The profile index number. The range is from 0 to 1023.
	<i>name</i>	The profile name. The format is string. The string length range is from 1 to 128.
	no-aging	Configures no timeout for discovery mode.
	aging-time <i>time</i>	Configures timeout for discovery mode. The unit is hour. The range is from 1 to 168.

Command Modes Rule profile configuration (deploy-profile-rule)

Usage Guidelines A rule profile type must be configured.

Examples

This example shows how to create a logical ONT ID permit profile and logical ONT ID password permit profile.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile rule
Device(deploy-profile-rule)# aim 0/1/1
Device(deploy-profile-rule-0/1/1)# permit loid-lopw logical1 password1 line 1 default line
1 once-on no-aging
```

Related Commands

Command	Description
deploy profile	Deploys a profile type
aim	Creates aim based on the profile.

permit loid

To create a logical ONT ID permit profile, use the **permit loid** command in rule profile configuration mode.

```
permit loid loid line {profile_line_list | name name} {default line {index_number | name name} | once-on
{no-aging | aging-time time}}
```

Syntax Description		
<i>loid</i>		The logical ONT ID.
<i>profile_line_list</i>		The profile line list number.
<i>index_number</i>		The profile index number. The range is from 0 to 1023.
<i>name</i>		The profile name. The format is string. The string length range is from 1 to 128.
no-aging		Configures no timeout for discovery mode.
aging-time <i>time</i>		Configures timeout for discovery mode. The unit is hour. The range is from 1 to 168.

Command Modes Rule profile configuration (deploy-profile-rule)

Usage Guidelines A rule profile type must be configured.

Examples This example shows how to create a logical ONT ID permit profile.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile rule
Device(deploy-profile-rule)# aim 0/1/1
Device(deploy-profile-rule-0/1/1)# permit loid logical1 line 1 default line 1 once-on
no-aging
```

Related Commands	Command	Description
	deploy profile	Deploys a profile type
	aim	Creates aim based on the profile.

permit lopw

To create a logical ONT ID password permit profile, use the **permit lopw** command in rule profile configuration mode.

permit lopw *lopw* **line** {*profile_line_list* | **name** *name*} {**default line** {*index_number* | **name** *name*} | **once-on** {**no-aging** | **aging-time** *time*}}

Syntax Description		
	<i>lopw</i>	The logical ONT ID password.
	<i>profile_line_list</i>	The profile line list number.
	<i>index_number</i>	The profile index number. The range is from 0 to 1023.
	<i>name</i>	The profile name. The format is string. The string length range is from 1 to 128.
	no-aging	Configures no timeout for discovery mode.
	aging-time <i>time</i>	Configures timeout for discovery mode. The unit is hour. The range is from 1 to 168.

Command Modes Rule profile configuration (deploy-profile-rule)

Examples

This example shows how to create a logical ONT ID password permit profile.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile rule
Device(deploy-profile-rule)# aim 0/1/1
Device(deploy-profile-rule-0/1/1)# permit lopw password1 line 1 default line 1 once-on
no-aging
```

permit pw

To create a password permit profile, use the **permit pw** command in rule profile configuration mode.

```
permit pw {string string_password | hex hex_password} line {profile_line_list | name name} {default line
{index_number | name name} | once-on {no-aging | aging-time time}}
```

Syntax Description		
<i>string_password</i>		The ONT password in Hex.
<i>hex_password</i>		The ONT password in string.
<i>profile_line_list</i>		The profile line list number.
<i>index_number</i>		The profile index number. The range is from 0 to 1023.
<i>name</i>		The profile name. The format is string. The string length range is from 1 to 128.
no-aging		Configures no timeout for discovery mode.
aging-time <i>time</i>		Configures timeout for discovery mode. The unit is hour. The range is from 1 to 168.

Command Modes Rule profile configuration (deploy-profile-rule)

Usage Guidelines A rule profile type must be configured.

Examples This example shows how to create a password permit profile.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile rule
Device(deploy-profile-rule)# aim 0/1/1
Device(deploy-profile-rule-0/1/1)# permit pw string password1 line 1 default line 1
```

Related Commands	Command	Description
	deploy profile	Deploys a profile type
	aim	Creates aim based on the profile.

permit sn-pw

To create a serial number and password permit profile, use the **permit sn-pw** command in rule profile configuration mode.

permit sn-pw {string-hex *string_serial_number* | hex *hex_serial_number*} {string *string_password* | hex *hex_password*} **line** {*profile_line_list* | **name** *name*} **default line** {*index_number* | **name** *name*}

Syntax Description		
	<i>hex_serial_number</i>	The ONT serial number in Hex.
	<i>string_serial_number</i>	The ONT serial number in string.
	<i>string_password</i>	The ONT password in Hex.
	<i>hex_password</i>	The ONT password in string.
	<i>profile_line_list</i>	The profile line list number.
	<i>index_number</i>	The profile index number. The range is from 0 to 1023.
	<i>name</i>	The profile name. The format is string. The string length range is from 1 to 128.

Command Modes Rule profile configuration (deploy-profile-rule)

Usage Guidelines A rule profile type must be configured.

Examples This example shows how to create a serial number and password permit profile.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile rule
Device(deploy-profile-rule)# aim 0/1/1
Device(deploy-profile-rule-0/1/1)# permit sn-pw string-hex GPON-1790032e string password1
line 1 default line 1
```

Related Commands

Command	Description
deploy profile	Deploys a profile type
aim	Creates aim based on the profile.

permit sn

To create a serial number permit profile, use the **permit sn** command in rule profile configuration mode.

permit sn {**string-hex** *string_serial_number* | **hex** *hex_serial_number*}**line** {*profile_line_list* | **name** *name*}**default line** {*index_number* | **name** *name*}

Syntax Description		
	<i>hex_serial_number</i>	The ONT serial number in Hex.
	<i>string_serial_number</i>	The ONT serial number in string.
	<i>profile_line_list</i>	The profile line list number.
	<i>index_number</i>	The profile index number. The range is from 0 to 1023.
	<i>name</i>	The profile name. The format is string. The string length range is from 1 to 128.

Command Modes Rule profile configuration (deploy-profile-rule)

Usage Guidelines A rule profile type must be configured.

Examples

This example shows how to create a ONT serial number permit profile.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile rule
Device(deploy-profile-rule)# aim 0/1/1
Device(deploy-profile-rule-0/1/1)# permit sn string-hex GPON-1790032e line 1 default line 1
```

Related Commands	Command	Description
	deploy profile	Deploys a profile type
	aim	Creates aim based on the profile.

show alarm ont register-record

To display information about register record alarm of an ONT, use the **show alarm ont register-record** command in privileged EXEC or global configuration mode.

show alarm ont register-record

Command Modes

Privileged EXEC (#)

Global configuration (config)

Examples

This example shows how to view information about register record alarm of an ONT

```
Device> enable
Device# configure terminal
Device(config)# show alarm ont register-record
register ont record threshold alarm status : enable
register ont record threshold value       : 64
register ont record current value        :
gpon port 0/1 : 1(normal)
gpon port 0/2 : 0(normal)
gpon port 0/3 : 0(normal)
gpon port 0/4 : 0(normal)
gpon port 0/5 : 0(normal)
gpon port 0/6 : 0(normal)
gpon port 0/7 : 0(normal)
gpon port 0/8 : 0(normal)
```


show keyfile

To display the key file information, use the **show keyfile** command in privileged EXEC or global configuration mode.

```
show keyfile {public | private}
```

Syntax Description		
	public	The SSH public key file.
	private	The SSH private key file.

Command Modes

- Privileged EXEC (#)
- Global configuration (config)

Examples

This example shows how to view the key file information

```
Device> enable
Device# show keyfile public
```

show ont-find config

To display information about ONT auto find configuration, use the **show ont-find config** command in privileged EXEC or global configuration mode.

show ont-find config interface gpon {*port_list* | **all**}

Syntax Description		
	<i>port_list</i>	The GPON port.
	all	All ports.

Command Modes	
	Privileged EXEC (#)
	Global configuration (config)

Examples

This example shows how to view information about ONT auto find configuration.

```
Device> enable
Device# configure terminal
Device(config)# show ont-find config interface gpon 0/1
Port  Find    Find-interval  Age    Aging-time  D-min  D-max
g0/1  enable  10             enable  600         0      20
```

show ont-find list

To display information about ONT find list, use the **show ont-find list** command in privileged EXEC or global configuration mode.

```
show ont-find list {interface gpon {slot-number/port-number | all} | sn {string-hex string_serial_number | hex hex_serial_number}}
```

Syntax Description		
<i>slot-number/port-number</i>	The port ID.	<ul style="list-style-type: none"> • <i>slot-number</i>: <ul style="list-style-type: none"> • GPON: The value is 0. • GE Ethernet: The value is 1. • 10GE Ethernet: The value is 2. • <i>port-number</i>: <ul style="list-style-type: none"> • GPON: The range is from 1 to 8. • GE Ethernet: The range is from 1 to 4. • 10GE Ethernet: The range is from 1 to 2.
all	All ports.	
<i>hex_serial_number</i>	The ONT serial number in Hex.	
<i>string_serial_number</i>	The ONT serial number in string.	

Command Modes	
	Privileged EXEC (#)
	Global configuration (config)

Examples

This example shows how to view information about ONT find list

```
Device> enable
Device# configure terminal
Device(config)# show ont-find list interface gpon 0/1
```

show ont-silent config

To display information about ONT silent function, use the **show ont-silent config** command in privileged EXEC or global configuration mode.

show ont-silent config interface gpon *{port_list | all}*

Syntax Description		
	<i>port_list</i>	The GPON port.
	all	All ports.

Command Modes	
	Privileged EXEC (#)
	Global configuration (config)

Examples

This example shows how to view the information about ONT silent function.

```
Device> enable
Device# configure terminal
Device(config)# show ont-silent config interface gpon 0/1
Port Auth-fail time Offline time
g0/1 enable 40 disable -
```

show ont-silent list

To display information about silent ONT, use the **show ont-silent list** command in privileged EXEC or global configuration mode.

```
show ont-silent list {interface gpon {slot-number/port-number | all} | sn {string-hex string_serial_number | hex hex_serial_number}}
```

Syntax Description		
<i>slot-number/port-number</i>	The port ID.	<ul style="list-style-type: none"> • <i>slot-number</i>: <ul style="list-style-type: none"> • GPON: The value is 0. • GE Ethernet: The value is 1. • 10GE Ethernet: The value is 2. • <i>port-number</i>: <ul style="list-style-type: none"> • GPON: The range is from 1 to 8. • GE Ethernet: The range is from 1 to 4. • 10GE Ethernet: The range is from 1 to 2.
all	All ports.	
<i>hex_serial_number</i>	The ONT serial number in Hex.	
<i>string_serial_number</i>	The ONT serial number in string.	

Command Modes	
	Privileged EXEC (#)
	Global configuration (config)

Examples

This example shows how to view the information about silent ONT.

```
Device> enable
Device# configure terminal
Device(config)# show ont-silent list interface gpon 0/1
```

show ont brief count

To display brief information about an ONT interface, use the **show ont brief count** command in privileged EXEC or global configuration mode.

show ont brief count interface interface gpon {*slot-number/port-number* | **all**}

Syntax	Description
<i>slot-number/port-number</i>	<p>The port ID.</p> <ul style="list-style-type: none"> • <i>slot-number</i>: <ul style="list-style-type: none"> • GPON: The value is 0. • GE Ethernet: The value is 1. • 10GE Ethernet: The value is 2. • <i>port-number</i>: <ul style="list-style-type: none"> • GPON: The range is from 1 to 8. • GE Ethernet: The range is from 1 to 4. • 10GE Ethernet: The range is from 1 to 2.
all	All ports.

Command Modes	Description
Privileged EXEC (#)	
Global configuration (config)	

Examples

This example shows how to view the brief information about an ONT interface.

```
Device> enable
Device# configure terminal
Device(config)# show ont brief count interface gpon 0/1
Port  Online-num  Offline-num  Total
g0/1  1             4           5
Total entries: 1.
```

show ont description

To display the description of an ONT, use the **show ont description** command in privileged EXEC or global configuration mode.

show ont description {*slot-num/pon-num/ont-num* | **interface gpon** *slot-number/port-number* }

Syntax Description		
<i>slot-num/pon-num/ont-num</i>	The ONT ID.	<ul style="list-style-type: none"> • <i>slot-num</i>: The slot number. The value is 0. • <i>pon-num</i>: The PON number. The range is from 1 to 8. • <i>ont-num</i>: The ONT number. The range is from 1 to 128.
<i>slot-number/port-number</i>	The port ID.	<ul style="list-style-type: none"> • <i>slot-number</i>: <ul style="list-style-type: none"> • GPON: The value is 0. • GE Ethernet: The value is 1. • 10GE Ethernet: The value is 2. • <i>port-number</i>: <ul style="list-style-type: none"> • GPON: The range is from 1 to 8. • GE Ethernet: The range is from 1 to 4. • 10GE Ethernet: The range is from 1 to 2.
Command Modes	Privileged EXEC (#) Global configuration (config)	

Examples

This example shows how to view the description of an ONT

```
Device> enable
Device# configure terminal
Device(config)# show ont description interface gpon 0/1
```

show ont info

To display detailed information about an ONT, use the **show ont info** command in privileged EXEC or global configuration mode.

show ont info *slot-num/pon-num/ont-num*

Syntax Description	<i>slot-num/pon-num/ont-num</i>	The ONT ID.
		<ul style="list-style-type: none"> • <i>slot-num</i>: The slot number. The value is 0. • <i>pon-num</i>: The PON number. The range is from 1 to 8. • <i>ont-num</i>: The ONT number. The range is from 1 to 128.

Command Modes	Privileged EXEC (#)
	Global configuration (config)

Examples

This example shows how to view detailed information about an ONT

```
Device> enable
Device# configure terminal
Device(config)# show ont info 0/1/5
ONT : 0/1/5
Description : -
TYPE : -
Status : online
Distance (m) : 3
Vendor ID : CSCCO
Software Version : 1.1.2.5/1.1.2.6
Firmware Version : N40-428-1
Equipment ID : 4GE-POE-2POTS-CATV
SN : GPON-5aa7012a
Password : 123456
LOID : 000a5aa7012a
LOID Password : a7012a
Uplink PON ports : 1
ETH/POTS/TDM/MOCA ports : 4/2/0/0
CATV ANI/UNI ports : 0/1
T-CONTs/GEM ports : 31/127
Traffic Schedulers : 31
PQs in T-CONT 1-8 : 8/8/8/8/8/8/8/8
DBA method : NSR
IP configuration : not support
Type of flow control : GEMPORT CAR and PQ SCHEDULED
TX power cut off : Not Support
Online/Offline time : 05:04:03 2001/12/08
Up/Down time : 1 day(s) 17 hour(s) 34 minute(s)
```


show ssh

To display SSH configuration, use the **show ssh** command in privileged EXEC or global configuration mode.

show ssh

Command Modes

Privileged EXEC (#)

Global configuration (config)

Examples

This example shows how to view the SSH configuration

```
Device> enable
Device# show ssh
ssh version   : 2.0
ssh state     : on
ssh key file  : available
```

show ssh limit

To display the maximum number of the users, use the **show ssh limit** command in privileged EXEC or global configuration mode.

show ssh limit

Command Modes

Privileged EXEC (#)

Global configuration (config)

Examples

This example shows how to view the maximum number of the users.

```
Device> enable
Device# show ssh limit
SSH user limit is 5, current is 0.
```

show telnet

To display the telnet information, use the **show telnet** command in privileged EXEC or global configuration mode.

show telnet

Command Modes

Privileged EXEC (#)

Global configuration (config)

Examples

This example shows how to display the telnet information.

```
Device> enable
Device# configure terminal
Device(config)# show telnet
Telnet service port is 23, using port is 23, user limit is 5, current is 1.
```

sip agent

To configure the SIP proxy server, use the **sip agent proxy-server** command in unique profile configuration mode. To disable the SIP proxy server, use the **no sip agent proxy-server** command.

sip agent proxy-server *proxy_server_uri* {**outbound-proxy** | **registrar-server** | **signal-port** } *proxy_server_uri*

no sip agent

Syntax Description

<i>proxy_server_uri</i>	The proxy server URI.
outbound-proxy	The outbound proxy.
registrar-server	The registrar server.
signal-port	The signal port.

Command Modes

Unique profile configuration (deploy-profile-unique)

Usage Guidelines

A unique profile type must be configured.

Examples

This example shows how to configure the SIP proxy server.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile unique
Device(deploy-profile-unique)# aim 0/1/1
Device(deploy-profile-unique-0/1/1)# sip agent proxy-server 2
```

Related Commands

Command	Description
deploy profile	Deploys a profile type
aim	Creates aim based on the profile.

sip digitmap

To configure the SIP digit map, use the **sip digitmap** command in unique profile configuration mode.

sip digitmap dial-plan-id *dial_plan_id* **dial-plan-token** *token*

Syntax Description		
	<i>dial_plan_id</i>	The digit map index The range is from 1 to 10.
	<i>token</i>	The token

Command Modes Unique profile configuration (deploy-profile-unique)

Usage Guidelines A unique profile type must be configured.

Examples

This example shows how to configure the SIP digit map.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile unique
Device(deploy-profile-unique)# aim 0/1/1
Device(deploy-profile-unique-0/1/1)# sip digitmap dial-plan-id 3 dial-plan-token token1
```

Related Commands	Command	Description
	deploy profile	Deploys a profile type
	aim	Creates aim based on the profile.

sip user

To configure the SIP users, use the **sip user** *user_id* command in unique profile configuration mode. To disable SIP users, use the **no sip user** *user_id* command.

sip user *pots_number* {**name** *username* **password** *password* | **telno** *telephone_number*}

no sip user *pots_number*

Syntax	Description
<i>pots_number</i>	The ONT POTS port number. The value range is from 1 to 2
<i>username</i>	The SIP username. The username length is from 1 to 25.
<i>password</i>	The SIP password. The password length is from 1 to 25
<i>telephone_number</i>	The ONT local phone number. The digit length is from 1 to 25.

Command Modes Unique profile configuration (deploy-profile-unique)

Usage Guidelines A unique profile type must be configured.

Examples This example shows how to configure the SIP users

```
Device> enable
Device# configure terminal
Device(config)# deploy profile unique
Device(deploy-profile-unique)# aim 0/1/1
Device(deploy-profile-unique-0/1/1)# sip user 2 name user 1 password 123
```

Related Commands

Command	Description
deploy profile	Deploys a profile type
aim	Creates aim based on the profile.

sip user mode

To configure an SIP interface, use the **sip user mode** command in unique profile configuration mode. To disable the SIP interface, use the **no sip user mode** command.

sip user mode {**static ip-address** *ip_address* **mask** *mask* **gateway** *gateway_address* **master-dns** *master_dns_address* **slave-dns** *slave_dns_address* | **dhcp**} **vlan** *vlan_id* **priority** **host** *host_number*

no sip user mode

Syntax Description		
ip-address <i>ip_address</i>		The IP address
mask <i>mask</i>		The IP network mask
gateway <i>gateway_address</i>		The gateway address.
master-dns <i>master_dns_address</i>		The master DNS IP address
slave-dns <i>slave_dns_address</i>		The slabe DNS address
vlan <i>vlan_id</i>		The VLAN ID The range is from 1 to 4094.
priority		The priority The range is from 0 to 7.
host <i>host_number</i>		The host number. The range is from 1 to 4.

Command Modes Unique profile configuration (deploy-profile-unique)

Usage Guidelines A unique profile type must be configured.

Examples This example shows how to configure an SIP interface

```
Device> enable
Device# configure terminal
Device(config)# deploy profile unique
Device(deploy-profile-unique)# aim 0/1/1
Device(deploy-profile-unique-0/1/1)# sip usr mode dhcp vlan 2 4 host 4
```

Related Commands	Command	Description
	deploy profile	Deploys a profile type
	aim	Creates aim based on the profile.

snmp-server

To enable the snmp server to send traps or disable the snmp server, use the **snmp-server** command in global configuration mode.

snmp-server {**enable** | **disable**}

Syntax Description	enable	disable
	Enables the snmp server to send traps.	Disables the snp server.

Command Modes Global configuration (config)

Examples

This example shows how to disable the snmp server.

```
Device> enable
Device# configure terminal
Device(config)# snmp-server disable
```


ssh

To enable SSH, use the **ssh** command in global configuration mode. To disable SSH, use the **no ssh** command.

ssh

no ssh

Command Modes

Global configuration (config)

Examples

This example shows how to enable SSH.

```
Device> enable
Device# configure terminal
Device(config)# ssh
Config SSH state successfully.
```

Related Commands

Command	Description
ssh limit <i>value</i>	Limits the number of user logins on SSH.
stop vty { <i>vty_list</i> all }	Removes logged in users.
crypto key	Configures or removes a key.
upload keyfile	Uploads the local key to the key server
load keyfile	Downloads the key from the external key server

ssh limit

To limit the number of user logins on SSH, use the **ssh limit** command in global configuration mode.

ssh limit *value*

Syntax Description	<i>value</i>	The user login limit value. The range is 0-5.
--------------------	--------------	--

Command Modes Global configuration (config)

Usage Guidelines SSH must be enabled on the device.

Examples This example shows how to limit the number of user logins on SSH.

```
Device> enable
Device# configure terminal
Device(config)# ssh limit 5
```

Related Commands

Command	Description
aim	Creates .

stop telnet client

To remove logged in Telnet clients, use the **stop telnet client** command in privileged EXEC mode.

stop telnet client {*terminal_id* | **all**}

Syntax Description	<i>terminal_id</i>	Telnet clients logged in through a particular terminal. The range is 0-5.
	all	All Telnet clients.

Command Modes Privileged EXEC (#)

Usage Guidelines Use this command on the OLT configured as the Telnet server.

Examples

This example shows how to remove logged in Telnet clients

```
Device> enable
Device# stop telnet client all
Stop all telnet clients successfully.
```

Related Commands	Command	Description
	telnet enable	Enables Telnet on a OLT and configures the OLT as the Telnet server.

stop vty

To remove logged in users, use the **stop vty** command in privileged EXEC mode.

stop vty {*vtv_list* | **all**}

Syntax Description		
	<i>vtv_list</i>	Users on the vty list only
	all	All logged in users.

Command Modes Privileged EXEC (#)

Usage Guidelines SSH must be enabled on the device.

Examples This example shows how to remove logged in users.

```
Device> enable
Device# stop vty 3
```

Related Commands	Command	Description
	ssh	Enables SSH on an OLT.

tcont *tcont_id*

To create a transmission container (T-CONT), use the **tcont** *tcont_id* command in line profile configuration mode. To delete a T-CONT, use the **no tcont** *tcont_id* command.

tcont *tcont_id* **profile dba** {*index_number* | **name** *name*}

no tcont *tcont_id*

Syntax Description		
<i>tcont_id</i>		The T-CONT ID. The range is from 1 to 8.
<i>index_number</i>		The index of the template. The range is from 0 to M, where M is the maximum number of ONUs supported by the whole machine.
<i>name</i>		The name of the template.

Command Modes Line profile configuration (deploy-profile-line)

Usage Guidelines A line profile type must be configured.
Modifying and activating the line traffic profile will cause the ONT that references the template to go online again.

Examples This example shows how to create a T-CONT.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile line
Device(deploy-profile-line)# aim 5
Device(deploy-profile-line-5)# tcont 6 profile dba 100
Device(deploy-profile-line-5)# active
```

Related Commands	Command	Description
	deploy profile	Deploys a profile type
	aim	Creates aim based on the profile.

telnet disable

To disable Telnet on an OLT, use the **telnet disable** command in global configuration mode.

telnet disable

Command Modes Global configuration (config)

Usage Guidelines Use this command on the OLT configured as the Telnet server.

Examples This example shows how to disable Telnet on an OLT.

```
Device> enable
Device# configure terminal
Device(config)# telnet disable
```

Related Commands

Command	Description
telnet enable	Enables Telnet on a OLT and configures the OLT as the Telnet server.

telnet enable

To enable Telnet on an OLT and configures the OLT as the Telnet server , use the **telnet enable** command in global configuration mode.

telnet enable

Command Modes

Global configuration (config)

Examples

This example shows how to enable Telnet on an OLT

```
Device> enable
Device# configure terminal
Device(config)# telnet enable
```

Related Commands

Command	Description
telnet disable	Disables Telnet on an OLT.
telnet limit <i>value</i>	Limits the number of users that can login to the Telnet server.
timeout <i>value</i>	Enables the client timeout and configures the timeout value.
stop telnet client { <i>terminal_id</i> all }	Removes logged in Telnet clients.

telnet limit

To limit the number of users that can login to the Telnet server, use the **telnet limit** command in global configuration mode.

telnet limit *value*

Syntax Description	<i>value</i>	The limit of the number of users. The range is 0-5.
--------------------	--------------	--

Command Modes Global configuration (config)

Usage Guidelines Use this command on the OLT configured as the Telnet server.

Examples This example shows how to limit the number of users that can login to the Telnet server.

```
Device> enable
Device# configure terminal
Device(config)# telnet limit 3
```

Related Commands	Command	Description
	telnet enable	Enables Telnet on a OLT and configures the OLT as the Telnet server.

telnet *server-ip*

To login to the Telnet server, use the **telnet** *server-ip* command in Privileged EXEC mode.

```
telnet server-ip {port-number | /localecho}
```

Syntax	Description
<i>server-ip</i>	The Telnet server IP address
<i>port-number</i>	The port number.
<i>/localecho</i>	

Command Modes Privileged EXEC (#)

Examples

This example shows how to login to the Telnet server.

```
Device> enable
Device# telnet 100.100.100.1
```

Related Commands	Command	Description
	telnetclient timeout <i>value</i>	Enables client timeout and configures the timeout interval.

telnetclient timeout

To enable client timeout , use the **telnetclient timeout** command in global configuration mode. To disable client timeout, use the **no telnetclient timeout** command.

telnetclient timeout [*value*]

no telnetclient timeout

Syntax Description	<i>value</i>	The system idle timeout value. The unit is minutes. The range is from 1 to 480.
--------------------	--------------	--

Command Modes Global configuration (config)

Usage Guidelines Use this command on the OLT configured as the Telnet client. To enable client timeout, use the **telnetclient** command in global configuration mode. To configure the timeout interval, use the **telnetclient value** command.

Examples This example shows how to enable client timeout.

```
Device> enable
Device# configure terminal
Device(config)# telnetclient timeout
```

Related Commands	Command	Description
	telnet <i>server-ip</i>	Logs in to the Telnet server

timeout

To enable the client timeout, use the **timeout** command in privileged EXEC mode. To disable the client timeout function, use the **no timeout** command.

timeout *value*

no timeout

Syntax Description	<i>value</i>	The system idle timeout value. The unit is minutes. The range is from 1 to 480.				
Command Modes	Privileged EXEC (#)					
Usage Guidelines	Use this command on the OLT configured as the Telnet server. To enable the client timeout, use the timeout command. To configure the client timeout value, use the timeout value command.					
Examples	<p>This example shows how to configure a client timeout interval of 30 minutes.</p> <pre>Device> enable Device# timeout 30</pre>					
Related Commands	<table border="1" style="width: 100%;"> <thead> <tr> <th style="border: none;">Command</th> <th style="border: none;">Description</th> </tr> </thead> <tbody> <tr> <td style="border: none;">telnet enable</td> <td style="border: none;">Enables Telnet on a OLT and configures the OLT as the Telnet server.</td> </tr> </tbody> </table>	Command	Description	telnet enable	Enables Telnet on a OLT and configures the OLT as the Telnet server.	
Command	Description					
telnet enable	Enables Telnet on a OLT and configures the OLT as the Telnet server.					

translate old-vlan

To configure the VLAN translate rule, use the **translate old-vlan** command in VLAN profile configuration mode. To disable the **no translate old-vlan** command.

```
translate old-vlan vlan_id {priority | new-vlan vlan_id [priority]}
```

```
no translate old-vlan vlan_id [priority]
```

Syntax Description		
<i>priority</i>		The priority value. The range is from 0 to 7.
<i>vlan_id</i>		The VLAN ID The range is from 1 to 4094.

Command Modes VLAN profile configuration (deploy-profile-vlan)

Usage Guidelines A VLAN profile type must be configured.
Modifying and activating the VLAN template will cause the ONT that references the template to go online again.

Examples This example shows how to configure the VLAN translate rule

```
Device> enable
Device# configure terminal
Device(config)# deploy profile vlan
Device(deploy-profile-vlan)# aim 5
Device(deploy-profile-vlan-5)# translate old-vlan 2 2 new-vlan 10 5
Device(deploy-profile-vlan-5)# active
```

Related Commands	Command	Description
	deploy profile	Deploys a profile type
	aim	Creates aim based on the profile.

type 1 fix

To configure only a fixed bandwidth, use the **type 1 fix** *fixed_bandwidth* command in DBA profile configuration mode.

type 1 fix *fixed_bandwidth*

Syntax Description	<i>fixed_bandwidth</i>	The fixed bandwidth in kbps. The range is from 256 to 800000. The fixed bandwidth must be divisible by 64 kbps. The default is 256 kbps
---------------------------	------------------------	--

Command Modes DBA profile configuration (deploy-profile-dba)

Usage Guidelines Type 1 T-CONT is preferred for services that are sensitive to the data forwarding delay. For example, VoIP services.

A DBA profile type must be configured.

Modifying and activating the DBA profile will cause the ONT that references the template to go online again.

Examples

This example shows how to configure type 1 T-CONT.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile dba
Device(deploy-profile-dba)# aim 5
Device(deploy-profile-dba-5)# type 1 fix 1024
Device(deploy-profile-dba-5)# active
```

Command	Description
deploy profile	Deploys a profile type
aim	Creates aim based on the profile.

type 2

To configure only the assured bandwidth, use the **type 2 assured** *assured_bandwidth* command in DBA profile configuration mode.

type 2 assured *assured_bandwidth*

Syntax Description	<i>assured_bandwidth</i>	The assured bandwidth in kbps. The range is from 0 to 800000. The assured bandwidth must be divisible by 64 kbps. The default is 256 kbps.
--------------------	--------------------------	---

Command Modes DBA profile configuration (deploy-profile-dba)

Usage Guidelines Type 2 T-CONT is preferred for services without strict delay and jitter requirements. For example, IPTV multicast services.

A DBA profile type must be configured.

Modifying and activating the DBA profile will cause the ONT that references the template to go online again.

Examples

This example shows how to configure type 2 T-CONT.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile dba
Device(deploy-profile-dba)# aim 5
Device(deploy-profile-dba-5)# type 2 assured 1024
Device(deploy-profile-dba-5)# active
```

Command	Description
deploy profile	Deploys a profile type
aim	Creates aim based on the profile.

type 3

To configure both assured bandwidth and non-assured bandwidth, use the **type 3 assured** *assured_bandwidth* **max** *max_bandwidth* command in DBA profile configuration mode.

type 3 assured *assured_bandwidth* **max** *max_bandwidth*

Syntax Description		
<i>assured_bandwidth</i>		The assured bandwidth in kbps. The range is from 0 to 800000. The assured bandwidth must be divisible by 64 kbps. The default is 256 kbps.
<i>max_bandwidth</i>		The maximum bandwidth in kbps. The range is from 256 to 1200000. The maximum bandwidth must be divisible by 64 kbps. The default is 256 kbps

Command Modes DBA profile configuration (deploy-profile-dba)

Usage Guidelines Type 3 T-CONT is preferred for services with variable-rate burst traffic.
A DBA profile type must be configured.
Modifying and activating the DBA profile will cause the ONT that references the template to go online again.

Examples

This example show how to configure both assured bandwidth and non-assured bandwidth.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile dba
Device(deploy-profile-dba)# aim 5
Device(deploy-profile-dba-5)# type 3 assured 1024 max 2500
Device(deploy-profile-dba-5)# active
```

Command	Description
deploy profile	Deploys a profile type
aim	Creates aim based on the profile.

type 4

To configure the optimum bandwidth, use the **type 4 max *max_bandwidth*** command in DBA profile configuration mode.

type 4 max *max_bandwidth*

Syntax Description	<i>max_bandwidth</i>	The maximum bandwidth in kbps. The range is from 256 to 1200000. The maximum bandwidth must be divisible by 64 kbps. The default is 256 kbps.
---------------------------	----------------------	--

Command Modes DBA profile configuration (deploy-profile-dba)

Usage Guidelines Type 4 T-CONT is preferred for services with variable-rate burst traffic which does not exhibit delay sensitivity. For example, internet data services.

A DBA profile type must be configured.

Modifying and activating the DBA profile will cause the ONT that references the template to go online again.

Examples

This example show how to configure the optimum bandwidth.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile dba
Device(deploy-profile-dba)# aim 5
Device(deploy-profile-dba-5)# type 4 max 1024
Device(deploy-profile-dba-5)# active
```

Command	Description
deploy profile	Deploys a profile type
aim	Creates aim based on the profile.

type 5

To configure a combination of fixed, assured and best-effort bandwidth, use the **type 5 fix** *fixed_bandwidth* **assured** *assured_bandwidth* **max** *max_bandwidth* command in DBA profile configuration mode.

type 5 fix *fixed_bandwidth* **assured** *assured_bandwidth* **max** *max_bandwidth*

Syntax Description		
<i>fixed_bandwidth</i>		The fixed bandwidth in kbps. The range is from 256 to 800000. The fixed bandwidth must be divisible by 64 kbps. The default is 256 kbps
<i>assured_bandwidth</i>		The assured bandwidth in kbps. The range is from 0 to 800000. The assured bandwidth must be divisible by 64 kbps. The default is 256 kbps.
<i>max_bandwidth</i>		The maximum bandwidth in kbps. The range is from 256 to 1200000. The maximum bandwidth must be divisible by 64 kbps. The default is 256 kbps.

Command Modes DBA profile configuration (deploy-profile-dba)

Usage Guidelines Type 5 T-CONT is preferred for services with general traffic.
A DBA profile type must be configured.
Modifying and activating the DBA profile will cause the ONT that references the template to go online again.

Examples This example show how to configure a combination of fixed, assured and best-effort bandwidth

```
Device> enable
Device# configure terminal
Device(config)# deploy profile dba
Device(deploy-profile-dba)# aim 5
Device(deploy-profile-dba-5)# type 5 fix 1024 assured 1024 max 1024
Device(deploy-profile-dba-5)# active
```

Command	Description
deploy profile	Deploys a profile type
aim	Creates aim based on the profile.

upload keyfile

To upload the local key to the key server, use the **upload keyfile** command in privileged EXEC mode.

Upload to a TFTP server

```
upload keyfile {public | private} tftp {inet | inet6} server_ip filename
```

Upload to a FTP server

```
upload keyfile {public | private} ftp {inet | inet6} server_ip filename
```

Syntax Description

public	The public SSH key file
private	The private SSH key file
tftp	Loads the file from the TFTP server.
ftp	Loads the file from FTP server.
inet	The IPv4 address family.
inet6	The IPv6 address family
<i>server_ip</i>	The server IP address
<i>filename</i>	The key filename.

Command Modes

Privileged EXEC (#)

Usage Guidelines

SSH must be enabled on the device.

Examples

This example shows how to upload the local key to the FTP server

```
Device> enable
Device# upload keyfile public ftp inet 100.100.100.1 mykey admin 123456
```

Related Commands

Command	Description
ssh	Enables SSH on an OLT.
load keyfile	Downloads the key from the external key server

us car

To configure GEM port traffic control, use the **us car cir cir cbs cbs pir pir pbs pbs** command in uplink traffic profile configuration mode.

us car cir cir cbs cbs pir pir pbs pbs

Syntax Description		
cir cir	The committed information rate in kbps. The range is from 64 to 800000	
cbs cbs	The committed burst size in KB. The range is from 2 to 25000.	
pir pir	The peak information rate in kbps. The range is from 64 to 1024000.	
pbs pbs	The peak burst size in KB. The range is from 2 to 25000.	

Command Modes Uplink traffic profile (deploy-profile-us-traffic)

Usage Guidelines An uplink profile type must be configured.
The peak information rate requirement is greater than or equal to committed information rate.
Modifying and activating the uplink traffic profile will cause the ONT that references the template to go online again.

Examples This example shows how to configure GEM port traffic control.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile us-traffic
Device(deploy-profile-us-traffic)# aim 5
Device(deploy-profile-us-traffic-5)# us queue 1
Device(deploy-profile-us-traffic-5)# us car cir 128 cbs 1024 pir 128 pbs 24
Device(deploy-profile-us-traffic-5)# active
```

Related Commands	Command	Description
	deploy profile	Deploys a profile type
	aim	Creates aim based on the profile.

us queue

To configure GEM port queue priority, use the **us queue** command in uplink traffic profile configuration mode.

us queue *priority_queue*

Syntax Description

priority_queue

The priority queue.

The range is from 0 to 7.

Command Modes

Uplink traffic profile (deploy-profile-us-traffic)

Usage Guidelines

An uplink profile type must be configured.

Examples

This example shows how to configure GEM port queue priority

```
Device> enable
Device# configure terminal
Device(config)# deploy profile us-traffic
Device(deploy-profile-us-traffic)# aim 5
Device(deploy-profile-us-traffic-5)# us queue 1
```

Related Commands

Command	Description
deploy profile	Deploys a profile type
aim	Creates aim based on the profile.



PART II

Managing Users

- [Managing Users, on page 95](#)



Managing Users

- [aaa](#), on page 97
- [auth-secret-key](#), on page 98
- [default domain-name](#), on page 99
- [domain](#), on page 100
- [login-access-list](#), on page 101
- [muser local](#), on page 102
- [muser radius](#), on page 103
- [muser tacacs+](#), on page 104
- [radius host](#), on page 105
- [radius host binding](#), on page 106
- [service password-encryption](#), on page 107
- [show domain](#), on page 108
- [show login-access-list](#), on page 109
- [show muser](#), on page 110
- [show running-config oam](#), on page 111
- [show tacacs+](#), on page 112
- [show username](#), on page 113
- [show username privilege-auth](#), on page 114
- [show username silent](#), on page 115
- [show users](#), on page 116
- [state active](#), on page 117
- [state block](#), on page 118
- [stop](#), on page 119
- [tacacs+](#), on page 120
- [tacacs+ authentication-type](#), on page 121
- [tacacs+ encrypt-key](#), on page 122
- [tacacs+ preemption-time](#), on page 123
- [timeout](#), on page 124
- [username](#), on page 125
- [username change-password](#), on page 127
- [username change-privilege-pwd](#), on page 128
- [username failmax](#), on page 129
- [username online-max](#), on page 130

- [username privilege-auth-remote-user](#), on page 131
- [username privilege-auth](#), on page 132
- [username silent-time](#), on page 133

aaa

To enter Authentication Authorization and Accounting (AAA) configuration mode, use the **aaa** command in global configuration mode.

aaa

Command Modes

Global configuration (config)

Examples

This example shows how to enter AAA configuration mode.

```
Device> enable
Device# configure terminal
Device(config)# aaa
Device(config-aaa)#
```

Related Commands

Command	Description
auth-secret-key	Configures a RADIUS authentication key
default domain-name	Enables or disables the default domain
domain <i>domain_name</i>	Specifies a RADIUS domain name

auth-secret-key

To configure a RADIUS authentication key, use the **auth-secret-key** command in AAA configuration mode. To delete the configured RADIUS authentication key, use the **no** form of the command.

auth-secret-key *key*
no auth-secret-key

Syntax Description

<i>key</i>	The secret key.
------------	-----------------

Command Modes

AAA configuration (config-aaa)

Usage Guidelines

Use this command in the AAA configuration mode.

Examples

This example shows how to configure a RADIUS authentication key

```
Device> enable
Device# configure terminal
Device(config)# aaa
Device(config-aaa)# radius host radius1
Device(config-aaa-radius-radius1)# auth-secret-key key1
```

Related Commands

Command	Description
aaa	Enters AAA configuration mode

default domain-name

To enable or disable the default domain, use the **default domain-name** command in AAA configuration mode.

default domain-name {**enable** *domain-name* | **disable**}

Syntax Description

enable	Enables the default domain.
<i>domain-name</i>	The default domain name The format is string.
disable	Disables the default domain.

Command Modes

AAA configuration (config-aaa)

Usage Guidelines

Use this command in the AAA configuration mode.

Examples

This example shows how to configure the default domain.

```
Device> enable
Device# configure terminal
Device(config)# aaa
Device(config-aaa)# domain default1
Device(config-aaa-domain-default1)# radius host binding cisco
Device(config-aaa-domain-default1)# state active
Device(config-aaa-domain-default1)# exit
Device(config-aaa)# default domain-name enable domain1
Succeed in setting default domain.
```

Related Commands

Command	Description
aaa	Enters AAA configuration mode

domain

To specify a RADIUS domain name, use the **domain** *domain_name* command in AAA configuration mode.

domain *domain_name*

Syntax Description

domain_name

The name of the domain.

The format is string.

Command Modes

AAA configuration (config-aaa)

Usage Guidelines

Use this command in the AAA configuration mode.

Examples

This example shows how to specify the RADIUS domain name

```
Device> enable
Device# configure terminal
Device(config)# aaa
Device(config-aaa)# domain domain1
Device(config-aaa-domain-domain1)#
```

Related Commands

Command	Description
aaa	Enters AAA configuration mode

login-access-list

To allow access for specific IP addresses, use the **login-access-list** {snmp | ssh | telnet} command in global configuration mode. To block all IP addresses, use the **no login-access-list** command.

login-access-list {snmp *ip_address mask* | ssh *ip_address mask* | telnet *ip_address mask* | telnet-limit *max_user_number*}

no login-access-list {snmp {all | *ip_address mask*} | ssh {all | *ip_address mask*} | telnet {all | *ip_address mask*} | telnet-limit *max_user_number*}

Syntax	Description
snmp	The SNMP client.
ssh	The SSH client.
telnet	The Telnet client.
all	Deletes all IP address.
<i>ip_address</i>	The IP address.
<i>mask</i>	The IP address mask.
telnet-limit <i>max_user_number</i>	Limit the number of Telnet user logins. The range is from 0 to 5.

Command Modes Global configuration (config)

Usage Guidelines Use the **no login-access-list** {snmp | ssh | telnet} all command to block all IP access.
Use the **login-access-list** {snmp | ssh | telnet} 0.0.0.0 [0.0.0.0 | 255.255.255.255] command to allow all IP access.

Examples This example shows how to delete all IP addresses from the SNMP client.

```
Device> enable
Device# configure terminal
Device(config)# no login-access-list snmp all
Delete access ip address successfully.
```

Related Commands	Command	Description
	show login-access-list	Displays the list of allowed IP addresses.

muser local

To enable local authentication mode, use the **muser local** command in global configuration mode.

muser local

Command Modes Global configuration (config)

Examples

This example shows how to enable local authentication mode

```
Device> enable
Device# configure terminal
Device(config)# muser local
Config manager user authentication successfully.
```

Related Commands

Command	Description
show muser	Displays the authentication configuration

muser radius

To enable RADIUS remote authentication, use the **muser radius** *radius_name* command in global configuration mode.

muser radius *radius_name* {**pap** | **chap**} {**account** | **local**}

Syntax Description

<i>radius_name</i>	The RADIUS host name. The format is string. The range is from 1 to 32.
pap	The password authentication protocol (PAP)
chap	The challenge handshake authentication protocol (CHAP)
account	Manages login accounting through the RADIUS server.
local	Allows local authentication when the remote authentication fails.

Command Modes

Global configuration (config)

Examples

This example shows how to enable RADIUS remote authentication.

```
Device> enable
Device# configure terminal
Device(config)# muser radius cisco pap local
```

Related Commands

Command	Description
show muser	Displays the authentication configuration

muser tacacs+

To enable TACACS+ remote authentication mode, use the **muser tacacs+** command in global configuration mode.

muser tacacs+ {**author** | **account** | **command-account** | **local**}

Syntax Description

author	Allows login authorization through the TACACS+ server
account	Manages login accounting through the TACACS+ server.
command-account	Forwards all the command lines to the TACACS+ server through the TACACS+ account packet.
local	Allows local authentication when the remote authentication fails.

Command Modes

Global configuration (config)

Examples

This example shows how to enable TACACS+ remote authentication.

```
Device> enable
Device# configure terminal
Device(config)# muser tacacs+
```

Related Commands

Command	Description
show muser	Displays the authentication configuration

radius host

To configure a RADIUS server name, use the **radius host** command in AAA configuration mode.

radius host *radius_name*

Syntax Description	<i>radius_name</i>	The name of the RADIUS serve
---------------------------	--------------------	------------------------------

Command Modes AAA configuration (config-aaa)

Usage Guidelines Use this command in the AAA configuration mode.

Examples

This example shows how to configure a RADIUS server name

```
Device> enable
Device# configure terminal
Device(config)# aaa
Device(config-aaa)# radius host radius1
```

Related Commands

Command	Description
aaa	Enters AAA configuration mode
show radius host	Displays the RADIUS host configuration

radius host binding

To bind a domain to the RADIUS server name, use the **radius host binding** command in AAA configuration mode.

radius host binding *radius-name*

Syntax Description

<i>radius-name</i>	The RADIUS name server. The format is string.
--------------------	--

Command Modes

AAA configuration (config-aaa)

Usage Guidelines

Use this command in the AAA configuration mode.

Examples

This example shows how to bind the RADIUS host to the domain.

```
Device> enable
Device# configure terminal
Device(config)# aaa
Device(config-aaa)# domain radius1
Device(config-aaa-domain-radius1)# radius host binding cisco
```

Related Commands

Command	Description
aaa	Enters AAA configuration mode
show radius host	Displays the RADIUS host configuration

service password-encryption

To save a password in cipher text, use the **service password-encryption** command in global configuration mode.

service password-encryption

Command Modes

Global configuration (config)

Examples

This example shows how to save a password in cipher text

```
Device> enable
Device# configure terminal
Device(config)# service password-encryption
```

show domain

To display the domain configuration, use the **show domain** command in privileged EXEC or global configuration mode.

show domain [*domain_name*]

Syntax	Description
<i>domain_name</i>	The name of the domain. The format is string.

Command Modes	Description
Privileged EXEC (#)	
Global configuration (config)	

Examples

This example shows how to display the domain configuration.

```
Device> enable
Device# configure terminal
Device(config)# show domain domain1
  Default domain name : domain1
  DomainName          : domain1
  RADIUSServerName    : cisco
  Access-limit        : disabled
  AccessedNum         : 0
  Scheme               : radius
  State                : Block
```

Total [1] item(s).

show login-access-list

To display the list of allowed IP addresses, use the **show login-access-list** command in privileged EXEC or global configuration mode.

show login-access-list

Command Modes

Privileged EXEC (#)

Global configuration (config)

Examples

This example shows how to view the list of allowed IP addresses.

```
Device> enable
Device# configure terminal
Device(config)# show login-access-list
sno  ipAddress  wildcard bits  terminal
1    0.0.0.0    255.255.255.255 telnet
2    0.0.0.0    255.255.255.255 ssh
```

Related Commands

Command	Description
login-access-list {snmp ssh telnet}	Allows access for specific IP addresses

show muser

To display the authentication configuration, use the **show muser** command in privileged EXEC or global configuration mode.

show muser

Command Modes

Privileged EXEC (#)

Global configuration (config)

Examples

This example shows how to view the authentication configuration.

```
Device> enable
Device# configure terminal
Device(config)# show muser
Show manager user authentication.
Authentication type : local
Admin-Remote-Auth: Disable
```

show running-config oam

To display the timeout configuration, use the **show running-config oam** command in privileged EXEC or global configuration mode.

show running-config oam

Command Modes

Privileged EXEC (#)

Global configuration (config)

Examples

This example shows how to view the timeout configuration.

```
Device> enable
Device# configure terminal
Device(config)# show running-config oam
![OAM]
no login-access-list snmp 0.0.0.0 255.255.255.255
service password-encryption
username text privilege 0 password 7 884863d2
banner
screen-rows per-page 55
hostname 2
telnet limit 3
exit
timeout 100
configure terminal
telnetclient timeout 2
ip icmp mask-reply
```

show tacacs+

To display the TACACS+ configuration, use the **show tacacs+** command in privileged EXEC or global configuration mode.

show tacacs+

Command Modes

Privileged EXEC (#)

Global configuration (config)

Examples

This example shows how to view the TACACS+ configuration.

```
Device> enable
Device# configure terminal
Device(config)# show tacacs+
Primary Server Configurations:
IP address: : 192.168.1.10
Connection port: : 49
Connection timeout: : 5
Key: : 123456

Secondary Server Configurations:
IP address: : 192.168.1.11
Connection port: : 49
Connection timeout: : 5
Key: : 123456
```


show username

To display the user information, use the **show username** command in privileged EXEC or global configuration mode.

show username *username*

Syntax Description	<i>username</i>	The user name.
--------------------	-----------------	----------------

Command Modes	Privileged EXEC (#) Global configuration (config)
---------------	--

Examples

This example shows how to view the user information.

```
Device> enable
Device# configure terminal
Device(config)# show username admin
display user information
Terminal type: C=Console, T=Telnet, S=SSH, W=Web
Global Failmax: n/a
User Name      Role      Terminal  FailMax  Fail    OnLineMax  OnLine
-----
admin          ADMIN    CTSW      n/a      0      n/a        1
```

Related Commands	Command	Description
	username <i>username</i>	Adds a user

show username privilege-auth

To display the privilege password authentication configuration, use the **show username privilege-auth** command in privileged EXEC or global configuration mode.

show username privilege-auth

Command Modes

Privileged EXEC (#)

Global configuration (config)

Examples

This example shows how to view the configuration of second-tier password authentication

```
Device> enable
Device# configure terminal
Device(config)# show username privilege-auth
Privilege-password authentication
  switch: OFF
  remote-user name: remote_admin
  password not configured
```

Related Commands

Command	Description
username privilege-auth	Enables privilege password authentication for a local user

show username silent

To display a user silent period information, use the **show username silent** command in privileged EXEC or global configuration mode.

show username silent

Command Modes

Privileged EXEC (#)

Global configuration (config)

Examples

This example shows how to view a user silent period information

```
Device> enable
Device# configure terminal
Device(config)# show username silent
display user silent period information
Silent Time: 2 minutes
User Name          State      Silent End Time
-----
admin              Off       n/a
text               Off       n/a
```

Related Commands

Command	Description
username <i>username</i>	Adds a user
username silent-time	Configures the silent time
show username	Displays the user information

show users

To display the online users, use the **show users** command in privileged EXEC or global configuration mode.

show users

Command Modes

Privileged EXEC (#)

Global configuration (config)

Examples

This example shows how to view the online users.

```
Device> enable
Device# configure terminal
Device(config)# show users
Only 5 users logged in by telnet are allowed to be in privileged mode.
Now 1 users logged in by telnet have been in privileged mode.

User "admin" logged in at time 2001/12/09 16:53:44
Time passed after login: 0 days 0 hours 12 minutes 32 seconds
Time no operation: 0 minutes 0 seconds
Terminal: telnet 1
Transport: telnet
User's IP address: 10.65.75.54
Authentication: local
Radius hostname: N/A
```

state active

To activate a domain, use the **state active** command in AAA configuration mode.

state active

Command Modes AAA configuration (config-aaa)

Examples

This example shows to activate a configured domain.

```
Device> enable
Device# configure terminal
Device(config)# aaa
Device(config-aaa)# domain default1
Device(config-aaa-domain-default1)# radius host binding cisco
Device(config-aaa-domain-default1)# state active
Device(config-aaa-domain-default1)# exit
```

Related Commands

Command	Description
state block	Deactivates a domain

state block

To deactivate a domain, use the **state block** command in AAA configuration mode.

state block

Command Modes AAA configuration mode

Examples This example shows how to deactivate a domain.

```
Device> enable
Device# configure terminal
Device(config)# aaa
Device(config-aaa)# domain default1
Device(config-aaa-domain-default1)# state block
```

Related Commands

Command	Description
state active	Activates a domain

stop

To force user or users to go offline, use the **stop** command in privileged EXEC mode.

```
stop {username | vty {all vty_list} | telnet {all terminal_id}}
```

Syntax Description

<i>username</i>	The username
all	Stops all.
<i>vty_list</i>	The VTY list.
<i>terminal_id</i>	The terminal ID The range is from 0 to 5.

Command Modes

Privileged EXEC (#)

Examples

This example shows how to force a user offline

```
Device> enable  
Device# stop Jerry
```

tacacs+

To configure the TACACS + server, use the **tacacs+** command in global configuration mode.

tacacs+ {**primary** | **secondary**}**server** *ip_address* [{**encrypt-key** *value* | **key** *key* | **port** *port* | **timeout** *value*}]

Syntax Description

primary	Configures the primary server.
secondary	Configures the secondary server.
server <i>ip_address</i>	The server IP address.
encrypt-key <i>value</i>	The server key encryption.
key <i>key</i>	The server key configuration.
port <i>port</i>	The TCP port. The range is from 1 to 65535.
timeout <i>value</i>	The connection timeout. The range is from 1 to 70. The default is 5.

Command Modes

Global configuration (config)

Examples

This example shows how to configure the TACACS + primary server

```
Device> enable
Device# configure terminal
Device(config)# tacacs+ primary server 192.168.1.10 key 123456
```

Related Commands

Command	Description
show tacacs+	Displays the TACACS+ configuration

tacacs+ authentication-type

To configure an authentication type, use the **tacacs+ authentication-type** command in global configuration mode.

tacacs+ authentication-type {ascii | chap | pap}

Syntax Description	ascii	Configures the ASCII authentication type.
	chap	Configures the Challenge Handshake Authentication Protocol (CHAP) authentication type.
	pap	Configures the Password Authentication Protocol (PAP) authentication type.

Command Modes Global configuration (config)

Examples

This example shows how to configure an ASCII authentication type

```
Device> enable
Device# configure terminal
Device(config)# tacacs+ authentication-type ascii
```

Related Commands	Command	Description
	show tacacs+	Displays the TACACS+ configuration

tacacs+ encrypt-key

To enable password encryption, use the **tacacs+ encrypt-key** command in global configuration mode. To disable password encryption, use the **no tacacs+ encrypt-key** command.

tacacs+ encrypt-key

no tacacs+ encrypt-key

Command Modes

Global configuration (config)

Examples

This example shows how to enable password encryption

```
Device> enable
Device# configure terminal
Device(config)# tacacs+ encrypt-key
```

Related Commands

Command	Description
show tacacs+	Displays the TACACS+ configuration

tacacs+ preemption-time

To configure the recovery time to switch to the TACACS+ primary server, use the **tacacs+ preemption-time** command in global configuration mode.

tacacs+ preemption-time *time*

Syntax Description	<i>time</i>
	The preemption time
	The unit in minutes.
	The range is from 0 to 1440. The default value is 0.

Command Modes Global configuration (config)

Examples

This example shows how to configure the recovery time to switch to the TACACS+ primary server.

```
Device> enable
Device# configure terminal
Device(config)# tacacs+ preemption-time 200
```

Related Commands	Command	Description
	show tacacs+	Displays the TACACS+ configuration

timeout

To configure the system idle timeout, use the **timeout** command in privileged Exec mode. To disable the system idle timeout, use the **no timeout** command.

timeout *value*

no timeout

Syntax Description	<i>value</i>
	The system idle timeout value. The range is 1-480. The default timeout value is 20m.

Command Modes Privileged Exec (#)

Examples

This example shows how to configure the system idle timeout

```
Device> enable
Device# timeout 100
The idle time is : 100 minutes!
```

username

To add a user or modify an existing user privilege level, use the **username** *username* command in global configuration mode. To remove a user, use the **no username** *username* command.

username *username* {**password** {**0** | **7**}*password* | **privilege** *privilege_level* **password** {**0** | **7**}*password* | **terminal** {**all** | **console** | **none** | **ssh** | **telnet** | **web**}}

no username *username*

Syntax Description

<i>username</i>	The username.
password 0 7	The password encryption time. <ul style="list-style-type: none"> • A value of 0 means the password is in plain text. • A value of 7 means the password is in cipher text.
<i>password</i>	The password.
<i>privilege_level</i>	The privilege level. <ul style="list-style-type: none"> • A privilege value of 0 or 1 refers to a normal user. • A privilege value between 2 and 15 refers to administrator user. • Super user (admin) requires no configurations.
terminal	The login mode The options are <ul style="list-style-type: none"> • console • none • SSH • Telnet • Web

Command Modes

Global configuration (config)

Usage Guidelines

If you do not enter a permission value when you create a user, the system will automatically assign it with normal permissions.

Configure the password encryption type as 0 for a new user. When you configure the **service password-encryption** command, a password configured in plain text (0) is decrypted in de-compilation and the decrypted password type changes to 7

Examples

This example shows how to add a new user.

```
Device> enable
Device# configure terminal
Device(config)# username mark privilege 0 password 0 mark@123
Add user successfully.
```

Related Commands

Command	Description
show username	Displays the user information
username change-password	Modifies the user password
username change-privilege-pwd	Configures the second-tier password authentication
username failmax	Configures a limit on the consecutive failed login attempts
username online-max	Configures the duration users are online at the same time
username silent-time	Configures the silent time

username change-password

To modify the user password, use the **username change-password** command in global configuration mode.

username change-password

Command Modes

Global configuration (config)

Examples

This example shows how to modify the user password

```
Device> enable
Device# configure terminal
Device(config)# username change-password
```

Related Commands

Command	Description
username <i>username</i>	Adds a user
show username	Displays the user information

username change-privilege-pwd

To configure the second-tier password authentication, use the **username change-privilege-pwd** command in global configuration mode.

username change-privilege-pwd {0 | 7}

Syntax Description

{ 0 | 7 }

- A value of 0 means the password is in plain text.
- A value of 7 means the password is in cipher text.

Command Modes

Global configuration (config)

Examples

This example shows how to configure the second-tier password authentication.

```
Device> enable
Device# configure terminal
Device(config)# username change-privilege-pwd 0 123456
```

Related Commands

Command	Description
username <i>username</i>	Adds a user
show username	Displays the user information

username failmax

To configure a limit on the consecutive failed login attempts, use the **username failmax** command in global configuration mode. To disable the limit on the consecutive failed login attempts, use the **no username failmax** command.

username failmax *{fail_value | username fail_value}*

no username failmax

Syntax Description

<i>fail_value</i>	The fail value. The range is from 1 to 100.
<i>username</i>	The username.

Command Modes

Global configuration (config)

Examples

This example shows how to configure a limit on the consecutive failed login attempts.

```
Device> enable
Device# configure terminal
Device(config)# username failmax 5
```

Related Commands

Command	Description
username <i>username</i>	Adds a user
show username	Displays the user information

username online-max

To configure the duration users are online at the same time, use the **username online-max** command in global configuration mode.

username online-max *username value*

Syntax Description		
	<i>username</i>	The username.
	<i>value</i>	The duration users are online at the same time The range is from 1 to 100.

Command Modes Global configuration (config)

Examples

This example shows how to configure the duration users are online at the same time.

```
Device> enable
Device# configure terminal
Device(config)# username online-max mark 100
```

Related Commands

Command	Description
username <i>username</i>	Adds a user
show username	Displays the user information

username privilege-auth-remote-user

To enable privilege password authentication for a remote user, use the **username privilege-auth-remote-user** command in global configuration mode. To disable user privilege password authentication, use the **no username privilege-auth** command.

username privilege-auth-remote-user *username*

no username privilege-auth-remote-user

Syntax Description

username The username.

Command Modes

Global configuration (config)

Examples

This example shows how to enable privilege password authentication.

```
Device> enable
Device# configure terminal
Device(config)# username privilege-auth-remote-user mark
Enable Privilege-password authentication OK!
```

Related Commands

Command	Description
show username	Displays the user information

Related Commands

Command	Description
username <i>username</i>	Adds a user
show username	Displays the user information

username privilege-auth

To enable privilege password authentication for a user, use the **username privilege-auth** command in global configuration mode. To disable user privilege password authentication, use the **no username privilege-auth** command.

username privilege-auth [**always**]

no username privilege-auth

Syntax Description	always	Configures privilege password authentication for all users.
--------------------	--------	---

Command Modes Global configuration (config)

Examples

This example shows how to enable user privilege password authentication.

```
Device> enable
Device# configure terminal
Device(config)# username privilege-auth
Enable Privilege-password authentication OK!
```

Related Commands	Command	Description
	show username	Displays the user information

Related Commands	Command	Description
	username <i>username</i>	Adds a user.
	show username	Displays the user information.
	show username privilege-auth	Displays the privilege password authentication configuration.

username silent-time

To configure the silent time, use the **username silent-time** command in global configuration mode.

username silent-time *silent_time*

Syntax Description

silent_time

The silence period time.

The range is from 2 to 1440.

Command Modes

Global configuration (config)

Examples

This example shows how to configure the silent time

```
Device> enable
Device# configure terminal
Device(config)# username silent-time 100
```

Related Commands

Command	Description
show username	Displays the user information

Related Commands

Command	Description
username <i>username</i>	Adds a user
show username	Displays the user information
show username silent	Displays a user silent period information



PART **III**

OLT Port Configuration

- [OLT Port Configuration, on page 137](#)



OLT Port Configuration

- [channel-group group_id](#), on page 138
- [channel-group load-balance](#), on page 139
- [channel-group group_id mode](#), on page 140
- [clear channel-group](#), on page 141
- [clear interface](#) , on page 142
- [interface range ethernet](#), on page 143
- [lacp port-priority](#), on page 144
- [lacp system-priority](#), on page 145
- [port-control mode master](#), on page 146
- [port-control mode slave](#), on page 147
- [port-isolation](#), on page 148
- [port-rate-statistics interval](#), on page 149
- [show description](#), on page 150
- [show interface sfp](#), on page 151
- [show lacp internal](#) , on page 152
- [show lacp neighbor](#), on page 153
- [show lacp sys-id](#), on page 154
- [show port-control mode](#), on page 155
- [show port-isolation](#), on page 156
- [show statistics interface ethernet](#) , on page 157
- [show statistics](#) , on page 158
- [show statistics channel-group](#), on page 159
- [show statistics dynamic interface](#), on page 160
- [show utilization interface](#), on page 161
- [speed](#), on page 162

channel-group group_id

To configure the aggregation group ID, use the **channel-group** *channel_group_id* command in global configuration mode. To disable the aggregation group ID, use the **no channel-group** *channel_group_id* command.

channel-group *channel_group_id*

no channel-group *channel_group_id*

Syntax Description

channel_group_id

The channel group ID.

The range is 0-5.

Command Modes

Global configuration (config)

Examples

This example shows how to configure the aggregation group ID

```
Device> enable
Device# configure terminal
Device(config)# channel-group 4
```

channel-group load-balance

To configure a load balance policy, use the **channel-group load-balance** command in global configuration mode. To disable a load balance policy, use the **no channel-group load-balance** form of this command.

channel-group load-balance {**dst-ip** | **dst-mac** | **src-dst-ip** | **src-dst-mac** | **src-ip** | **src-mac**}

no channel-group load-balance

Syntax Description		
	dst-ip	Configures the load balance policy based on destination IP.
	dst-mac	Configures the load balance policy based on destination MAC.
	src-dst-ip	Configures the load balance policy based on source and destination IP.
	src-dst-mac	Configures the load balance policy based on source and destination MAC.
	src-ip	Configures the load balance policy based on source IP.
	src-mac	Configures the load balance policy based on source MAC.

Command Modes Global configuration (config)

Examples

This example shows how to configure a load balance policy based on source MAC.

```
Device> enable
Device# configure terminal
Device(config)# channel-group load-balance src-mac
```

channel-group group_id mode

To add a port to an aggregation group, use the **channel-group *channel_group_id* mode** command in interface configuration mode. To disable the aggregation group ID, use the **no channel-group *channel_group_id* mode** command.

channel-group *channel_group_id* mode {on | active | passive}

no channel-group *channel_group_id* mode

Syntax Description	<i>channel_group_id</i>	The channel group ID. The range is 0-5.
on		Configures the LACP static mode.
active		Configures the LACP active mode
passive		Configures the LACP passive mode

Command Modes Interface configuration (config-if)

Examples

This example shows how to add a port to an aggregation group.

```
Device> enable
Device# configure terminal
Device(config)# interface ethernet 1/1
Device(config-if-ethernet-1/1)# channel-group 2 mode active
```

clear channel-group

To clear the LACP statistical information, use the **clear channel-group** *channel_group_id* command in global configuration mode.

```
clear channel-group [channel_group_id]
```

Syntax Description

channel_group_id

The channel group ID.

The range is 0-5.

Command Modes

Global configuration (config)

Examples

This example shows how to clear the LACP statistical information.

```
Device> enable  
Device# configure terminal  
Device(config)# clear channel-group  
Clear channel group statistics information record successfully.
```

clear interface

To clear interface statistics information, use the **clear interface** command in global configuration mode.

clear interface {*slot-number* | **ethernet** *slot-number/port-number* | **gpon** *slot-number/port-number* }

Syntax Description

<i>slot-number</i>	The slot number. The range is from 0 to 3.
<i>slot-number/port-number</i>	The port ID. <ul style="list-style-type: none"> • <i>slot-number</i>: <ul style="list-style-type: none"> • GPON: The value is 0. • GE Ethernet: The value is 1. • 10GE Ethernet: The value is 2. • <i>port-number</i>: <ul style="list-style-type: none"> • GPON: The range is from 1 to 8. • GE Ethernet: The range is from 1 to 4. • 10GE Ethernet: The range is from 1 to 2.

Command Modes

Global configuration (config)

Examples

This example shows how to clear interface statistics information

```
Device> enable
Device# configure terminal
Device(config)# clear interface ethernet 0/1
clear ports statistics information record successfully.
```

interface range ethernet

To configure port mode in bulk, use the **interface range ethernet** command in interface configuration mode.

interface range ethernet *slot-number/port-number to ethernet slot-number/port-number*

Syntax Description	<i>slot-number/port-number</i>	The port ID. <ul style="list-style-type: none">• <i>slot-number</i>:<ul style="list-style-type: none">• GPON: The value is 0.• GE Ethernet: The value is 1.• 10GE Ethernet: The value is 2.• <i>port-number</i>:<ul style="list-style-type: none">• GPON: The range is from 1 to 8.• GE Ethernet: The range is from 1 to 4.• 10GE Ethernet: The range is from 1 to 2.
---------------------------	--------------------------------	--

Command Modes Interface configuration (config-if)

Examples

This example shows how to configure port mode in bulk

```
Device> enable
Device# configure terminal
Device(config)# interface ethernet 1/1
Device(config-if-ethernet-1/1)# interface range ethernet 1/1 to ethernet 1/4
Device(config-if-range)#
```

lACP port-priority

To configure port priority, use the **lACP port-priority** command in interface configuration mode. To disable port priority, use the **no lACP port-priority** command.

lACP port-priority *priority_value*

no lACP port-priority

Syntax Description

priority_value

The priority value.

The range is from 1 to 65535.

Command Modes

Interface configuration (config-if)

Examples

This example shows how to configure port priority.

```
Device> enable
Device# configure terminal
Device(config)# interface ethernet 1/1
Device(config-if-ethernet-1/1)# lACP port-priority 8
```


lACP system-priority

To configure system priority, use the **lACP system-priority** command in global configuration mode. To disable port priority, use the **no lACP system-priority** command.

lACP system-priority *priority_value*

no lACP system-priority

Syntax Description

priority_value

The priority value.

The range is from 1 to 65535.

Command Modes

Global configuration (config)

Examples

This example shows how to configure the system priority.

```
Device> enable
Device# configure terminal
Device(config)# lACP system-priority 3
```

port-control mode master

To configure the master mode, use the **port-control mode master** command in interface configuration mode. To disable the master mode, use the **no port-control mode** command.

port-control mode master
no port-control mode

Command Modes

Interface configuration (config-if)

Examples

This example shows how to configure the master mode.

```
Device> enable
Device# configure terminal
Device(config)# interface ethernet 1/1
Device(config-if-ethernet-1/1)# port-control mode master
```

port-control mode slave

To configure the master slave, use the **port-control mode slave** command in interface configuration mode. To disable the master mode, use the **no port-control mode** command.

port-control mode slave
no port-control mode

Command Modes

Interface configuration (config-if)

Examples

This example shows how to configure the master mode.

```
Device> enable
Device# configure terminal
Device(config)# interface ethernet 1/1
Device(config-if-ethernet-1/1)# port-control mode slave
```

port-isolation

To configure port isolation, use the **port-isolation** command in global configuration mode. To disable port isolation, use the **no port-isolation** command.

port-isolation ethernet *slot-number/port-number*

no port-isolation ethernet *slot-number/port-number*

Syntax Description

slot-number/port-number

The port ID.

- *slot-number*:
 - GPON: The value is 0.
 - GE Ethernet: The value is 1.
 - 10GE Ethernet: The value is 2.
- *port-number*:
 - GPON: The range is from 1 to 8.
 - GE Ethernet: The range is from 1 to 4.
 - 10GE Ethernet: The range is from 1 to 2.

Command Modes

Global configuration (config)

Examples

This example shows how to configure port isolation.

```
Device> enable
Device# configure terminal
Device(config)# port-isolation ethernet 1/1
Add port isolation downlink port successfully.
```

Related Commands

Command	Description
show port-isolation	Displays the isolation port

port-rate-statistics interval

To configure port interface statistic interval, use the **port-rate-statistics interval** *value* command in global configuration mode. To restore the default value, use the **no** form of this command.

port-rate-statistics interval *value*

no port-rate-statistics interval

Syntax Description

value

The time interval range.

The range is from 1 to 5. The unit is minutes. The default is 5.

Command Modes

Global configuration (config)

Examples

This example shows how to configure port interface statistic interval.

```
Device> enable
Device# configure terminal
Device(config)# port-rate-statistics interval 3
Port rate statistics interval has been changed, and will
restart calculating port average rate!
```

show description

To display the interface description, use the **show description** command in privileged EXEC or global configuration mode.

show description interface ethernet *slot-number/port-number*

Syntax Description	<i>slot-number/port-number</i>	The port ID.
		<ul style="list-style-type: none"> • <i>slot-number</i>: <ul style="list-style-type: none"> • GPON: The value is 0. • GE Ethernet: The value is 1. • 10GE Ethernet: The value is 2. • <i>port-number</i>: <ul style="list-style-type: none"> • GPON: The range is from 1 to 8. • GE Ethernet: The range is from 1 to 4. • 10GE Ethernet: The range is from 1 to 2.

Command Modes	Privileged EXEC (#)
	Global configuration (config)

Examples

This example shows how to view the interface description.

```
Device> enable
Device# configure terminal
Device(config)# show description interface ethernet 1/1
Port      description
e1/1      text
Total entries: 1.
```

show interface sfp

To display information about SFP parameters, use the **show interface sfp** command in privileged EXEC or global configuration mode.

show interface sfp {**ethernet** | **gpon**} *slot-number/port-number*

Syntax Description	<i>slot-number/port-number</i>	The port ID.
		<ul style="list-style-type: none"> • <i>slot-number</i>: <ul style="list-style-type: none"> • GPON: The value is 0. • GE Ethernet: The value is 1. • 10GE Ethernet: The value is 2. • <i>port-number</i>: <ul style="list-style-type: none"> • GPON: The range is from 1 to 8. • GE Ethernet: The range is from 1 to 4. • 10GE Ethernet: The range is from 1 to 2.

Command Modes	Privileged EXEC (#)	Global configuration (config)

Examples

This example shows how to view the information about SFP parameters

```
Device> enable
Device# configure terminal
Device(config)# show interface sfp ethernet 1/1
```

show lacp internal

To display information of the aggregation group, use the **show lacp internal** command in privileged EXEC or global configuration mode.

show lacp internal [*channel_group_id*]

Syntax Description	<i>channel_group_id</i>	The channel group ID. The range is from 0 to 5.
--------------------	-------------------------	--

Command Modes	Privileged EXEC (#) Global configuration (config)
---------------	--

Examples

This example shows how to view information about the aggregation group.

```
Device> enable
Device# configure terminal
Device(config)# show lacp internal
Load balance: dst-ip

Channel: 2, static channel
Port   State   A-Key   O-Key   Priority   Logic-port   Actor-state
e1/1   down    -       -       -         9            -

Channel: 4, dynamic channel
Port   State   A-Key   O-Key   Priority   Logic-port   Actor-state

actor-state: activity/timeout/aggregation/synchronization
             collecting/distributing/defaulted/expired
```


show lacp neighbor

To display the neighbor information of the aggregation group, use the **show lacp neighbor** command in privileged EXEC or global configuration mode.

show lacp neighbor [*channel_group_id*]

Syntax Description

<i>channel_group_id</i>	The channel group ID. The range is from 0 to 5.
-------------------------	--

Command Modes

Privileged EXEC (#)
Global configuration (config)

Examples

This example shows how to view the neighbor information of the aggregation group

```
Device> enable
Device# configure terminal
Device(config)# show lacp neighbor

Channel: 4
Local Port  Key  Pri  ID          Timeout  Nei-state
nei-state: activity/timeout/aggregation/synchronization
            collecting/distributing/defaulted/expired
```

show lacp sys-id

To display the system priority configuration, use the **show lacp sys-id** command in privileged EXEC or global configuration mode.

show lacp sys-id

Command Modes

Privileged EXEC (#)

Global configuration (config)

Examples

This example shows how to view the system priority configuration.

```
Device> enable
Device# configure terminal
Device(config)# show lacp sys-id

3,000a5a9b1815
```

show port-control mode

To display the configured port-control mode, use the **show port-control mode** command in privileged EXEC or global configuration mode.

show port-control mode

Command Modes

Privileged EXEC (#)

Global configuration (config)

Examples

This example shows how to view the configured port-control mode.

```
Device> enable
Device# configure terminal
Device(config)# show port-control mode
port  negotiate-flag  port-control-mode
e1/1  enable          auto
e1/2  enable          auto
e1/3  enable          auto
e1/4  enable          auto
```

show port-isolation

To display the isolation port, use the **show port-isolation** command in privileged EXEC or global configuration mode.

show port-isolation

Command Modes

Privileged EXEC (#)

Global configuration (config)

Examples

This example shows how to view isolation port configuration.

```
Device> enable
Device# configure terminal
Device(config)# show port-isolation
Port isolation downlink port :
e1/2-e1/4.
```

Related Commands

Command	Description
port-isolation	Configures port isolation

show statistics interface ethernet

To display the port rate statistics information, use the **show statistics interface** command in privileged EXEC or global configuration mode.

show statistics interface ethernet *slot-number/port-number*

Syntax Description	<i>slot-number/port-number</i>	The port ID.
		<ul style="list-style-type: none"> • <i>slot-number</i>: <ul style="list-style-type: none"> • GPON: The value is 0. • GE Ethernet: The value is 1. • 10GE Ethernet: The value is 2. • <i>port-number</i>: <ul style="list-style-type: none"> • GPON: The range is from 1 to 8. • GE Ethernet: The range is from 1 to 4. • 10GE Ethernet: The range is from 1 to 2.

Command Modes Privileged EXEC (#)

Global configuration (config)

Examples

This example shows how to view the port rate statistics information.

```
evic> enable
Device# configure terminal
Device(config)# show statistics interface ethernet 1/3
Port number : e1/3
last 5 minutes input rate 24784 bits/sec, 37 packets/sec
last 5 minutes output rate 1120 bits/sec, 1 packets/sec
64 byte packets:455394067
65-127 byte packets:302514090
128-255 byte packets:17535520
256-511 byte packets:20599116
512-1023 byte packets:4737262
1024-1518 byte packets:475868
788888610 packets input, 69778227468 bytes , 312945536 discarded packets
18800297 unicasts, 270957185 multicasts, 499131128 broadcasts
0 input errors, 0 FCS error, 0 symbol error, 0 false carrier
0 runts, 0 giants
12367313 packets output, 1245119790 bytes, 256 discarded packets
8303627 unicasts, 3620977 multicasts, 442709 broadcasts
0 output errors, 0 deferred, 0 collisions
0 late collisions
Total entries: 1.
```

show statistics

To display port rate statistics information, use the **show statistics interface ethernet** command in privileged EXEC or global configuration mode.

show statistics interface ethernet *slot-number/port-number*

Syntax Description	<i>slot-number/port-number</i>	The port ID.
		<ul style="list-style-type: none"> • <i>slot-number</i>: <ul style="list-style-type: none"> • GPON: The value is 0. • GE Ethernet: The value is 1. • 10GE Ethernet: The value is 2. • <i>port-number</i>: <ul style="list-style-type: none"> • GPON: The range is from 1 to 8. • GE Ethernet: The range is from 1 to 4. • 10GE Ethernet: The range is from 1 to 2.

Command Modes	Privileged EXEC (#) Global configuration (config)
---------------	--

Examples

This example show how to view the port rate statistics information.

```
Device> enable
Device# configure terminal
Device(config)# show statistics interface ethernet 1/1
Port number : e1/1
last 5 minutes input rate 0 bits/sec, 0 packets/sec
last 5 minutes output rate 0 bits/sec, 0 packets/sec
64 byte packets:0
65-127 byte packets:0
128-255 byte packets:0
256-511 byte packets:0
512-1023 byte packets:0
1024-1518 byte packets:0
0 packets input, 0 bytes , 0 discarded packets
0 unicasts, 0 multicasts, 0 broadcasts
0 input errors, 0 FCS error, 0 symbol error, 0 false carrier
0 runts, 0 giants
0 packets output, 0 bytes, 0 discarded packets
0 unicasts, 0 multicasts, 0 broadcasts
0 output errors, 0 deferred, 0 collisions
0 late collisions
Total entries: 1.
```

show statistics channel-group

To display LACP statistical information, use the **show statistics channel-group** command in privileged EXEC or global configuration mode.

show statistics channel-group [*channel_group_id*]

Syntax Description	
<i>channel_group_id</i>	The channel group ID. The range is from 0 to 5.

Command Modes	
	Privileged EXEC (#)
	Global configuration (config)

Examples

This example shows how to view the LACP statistical information

```
Device> enable
Device# configure terminal
Device(config)# show statistics channel-group
Channel group : 2
last 5 minutes input rate 0 bits/sec, 0 packets/sec
last 5 minutes output rate 0 bits/sec, 0 packets/sec
64 byte packets:0
65-127 byte packets:0
128-255 byte packets:0
256-511 byte packets:0
512-1023 byte packets:0
1024-1518 byte packets:0
0 packets input, 0 bytes , 0 discarded packets
0 unicasts, 0 multicasts, 0 broadcasts
0 input errors, 0 FCS error, 0 symbol error, 0 false carrier
0 runts, 0 giants
0 packets output, 0 bytes, 0 discarded packets
0 unicasts, 0 multicasts, 0 broadcasts
0 output errors, 0 deferred, 0 collisions
0 late collisions

Channel group : 4

This channel group does not include any ports!

Total entries: 2.
```

show statistics dynamic interface

To display the real-time statistic information of an interface, use the **show statistics dynamic interface** command in privileged EXEC or global configuration mode.

show statistics dynamic interface

Command Modes

Privileged EXEC (#)

Global configuration (config)

Examples

This example shows how to view the real-time statistic information of an interface.

```
Device> enable
Device# configure terminal
Device(config)# show statistics dynamic interface
Port Statistics          Sun Dec 9 17:40:29 2001
port  link  Tx Pkt  Tx Byte  Rx Pkt  Rx Byte  Rx      Rx
      Status Count  Count    Count   Count   Count   Bcast  Mcast
=====
g0/1   up    1427776E3 122120178E3 3230173  579417376 279481  171727
g0/2   down  0         0          0         0         0       0
g0/3   down  0         0          0         0         0       0
g0/4   down  0         0          0         0         0       0
g0/5   down  0         0          0         0         0       0
g0/6   down  0         0          0         0         0       0
g0/7   down  0         0          0         0         0       0
g0/8   down  0         0          0         0         0       0
e1/1   down  0         0          0         0         0       0
e1/2   down  0         0          0         0         0       0
e1/3   up    12366419 1245034896 788871832 69776674248 499122592 270949818
e1/4   down  2         210        4         256       0       4
e2/1   down  0         0          0         0         0       0
e2/2   down  0         0          0         0         0       0
=====0->Clear Counters U->page up D->page down CR->exit=====
```

Notes: If you see a E number, you can use the command "line width" to get more information.

show utilization interface

To display the interface utilization, use the **show utilization interface** command in privileged EXEC or global configuration mode.

show utilization interface

Command Modes

Privileged EXEC (#)

Global configuration (config)

Examples

This example shows how to view the interface utilization.

```
Device> enable
Device# configure terminal
Device(config)# show utilization interface
Link Utilization Averages          Tue Dec 4 19:06:53 2001
port  link    Receive  Peak Rx  Transmit  Peak Tx
      Status  pkts/sec  pkts/sec pkts/sec  pkts/sec
=====
g0/1  up        0         0        16        16
g0/2  down      0         0         0         0
g0/3  down      0         0         0         0
g0/4  down      0         0         0         0
g0/5  down      0         0         0         0
g0/6  down      0         0         0         0
g0/7  down      0         0         0         0
g0/8  down      0         0         0         0
e1/1  down      0         0         0         0
e1/2  down      0         0         0         0
e1/3  up        37        37        2         2
e1/4  down      0         0         0         0
e2/1  down      0         0         0         0
e2/2  down      0         0         0         0
=====
====spacebar->toggle screen U->page up D->page down CR->exit=====
```

speed

To configure the interface speed, use the **speed** command in interface configuration mode. To disable the interface speed, use the **no speed** command.

speed {1000 | 10000 | auto}

no speed

Syntax Description		
	1000	Port speed is 1000Mbps
	10000	Port speed is 10000Mbps
	auto	Port speed is automatic

Command Modes Interface configuration (config-if)

Examples

This example shows how to configure the interface speed

```
Device> enable
Device# configure terminal
Device(config)# interface ethernet 1/1
Device(config-if-ethernet-1/1)# speed 1000
```



PART **IV**

VLAN Configuration

- [VLAN Configuration, on page 165](#)



VLAN Configuration

- [description](#), on page 166
- [ingress acceptable-frame](#), on page 167
- [ingress filtering](#), on page 168
- [interface ethernet](#), on page 169
- [priority](#), on page 170
- [show ingress interface](#), on page 171
- [show interface brief ethernet](#), on page 172
- [show interface ethernet](#), on page 173
- [switchport default vlan](#), on page 174
- [switchport ethernet](#), on page 175
- [switchport hybrid](#), on page 176
- [switchport mode](#), on page 177
- [switchport trunk](#), on page 178
- [vlan](#), on page 179

description

To add a VLAN name or a description for the VLAN use the **description** command in the VLAN configuration mode.

description *string*

Syntax Description	<i>string</i> Specifies a name or a description for the VLAN. The range is 1-32 characters.
---------------------------	---

Command Default	None
------------------------	------

Command Modes	VLAN Configuration
----------------------	--------------------

Examples	<pre>Device(config)# vlan 11 Device(config-if-vlan)# switchport ethernet 3 Device(config-if-vlan)# description "vlan1"</pre>
-----------------	---

ingress acceptable-frame

To configure the type of frames or VLAN packets that are acceptable on the port, use the `ingress acceptable-frame` command in the Interface configuration mode.

ingress acceptable-frame { **all** | **tagged** }

Syntax Description	all Allows the port to receive tagged and untagged VLAN
	tagged Allows the port to receive only tagged VLAN packets.

Command Default	None
------------------------	------

Command Modes	Interface configuration
----------------------	-------------------------

Examples

This example shows how to configure the **ingress acceptable-frame** command:

```
Device(config)#interface ethernet 1/1
Device(config-if-ethernet-1/1)#ingress acceptable-frame tagged
Config acceptable-frame type successfully!
```

ingress filtering

To enable the forwarding of VLAN packets at the ingress of an interface, use the **ingress filtering** command in the Interface configuration mode. To disable ingress filtering use the **no** form of the command.

ingress filtering
no ingress filtering

Syntax Description

ingress filtering enables ingress filtering of VLAN packets.

Command Default

Ingress filtering is enabled by default

Command Modes

Interface configuration mode

Examples

This example shows how to disable ingress filtering for a port:

```
Device(config)# interface ethernet 1/4  
Device(config-if-ethernet-1/4)# no ingress filtering
```


interface ethernet

To enter interface configuration mode for an Ethernet IEEE 802.3 interface, use the interface ethernet command in the global configuration mode.

interface ethernet *port-number*

Syntax Description	<i>port-number</i> Specifies the port number within a particular slot.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	Global configuration mode
----------------------	---------------------------

Examples	The following example shows how to enter interface configuration mode.
-----------------	--

```
Device(config)# interface ethernet1/4
```

priority

To assign a priority value to a port use the **priority** command in the interface configuration mode. To restore the port priority to the default value use the **no** form of the command.

priority *port-priority*

no priority

Syntax Description	<i>port-priority</i> Assigns a priority value to the port. The value can range from 0-7.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	Interface configuration mode
----------------------	------------------------------

Examples

The following example shows how to configure the priority value of a port.

```
Device(config)# interface ethernet1/4  
Device(config-if-ethernet-1/4)# priority 2
```

show ingress interface

To display the status of filtering on the ingress port use the **show ingress interface** command in the privileged EXEC mode or global configuration mode.

show ingress interface { **ethernet** *port-number* | **gpon** *port-number* }

Syntax Description	
ethernet	Displays information about ethernet port.
gpon	Displays information about gpon port

Command Modes
Privileged EXEC
Global configuration (config)

Examples

The following is sample output for the `show ingress interface` command.

```
Device(config)#show ingress interface ethernet 1/4
Port      Filtering  Acceptable-frame
e1/4      enable     all
Total entries: 1
```

show interface brief ethernet

To display the configurations of a port in brief use the **show interface brief ethernet** command in the privileged EXEC mode.

show interface brief ethernet *port-number*

Syntax Description	<i>port-number</i> Specifies the port for which the configurations will be displayed.
---------------------------	---

Command Default	None
------------------------	------

Command Modes	Privileged EXEC
----------------------	-----------------

Examples

This example shows the sample output for the **show interface brief ethernet** command:

```
Device# show interface brief ethernet 1/4
Port   Desc   Link shutdn Speed      Pri PVID Mode TagVlan  UtVlan
e1/4           down false  auto          2  1  acc      1
Total entries: 1 .
```

show interface ethernet

To display the configurations of a port in detail use the **show interface ethernet** command in the privileged EXEC mode.

show interface ethernet *port-number*

Syntax Description	<i>port-number</i> Specifies the port for which the configurations will be displayed.
---------------------------	---

Command Default	None
------------------------	------

Command Modes	Privileged EXEC
----------------------	-----------------

Examples

The following examples displays the output of the **show interface ethernet** command for the port ethernet 1 / 4 :

```
Device# show interface ethernet 1/4
Gigabit Ethernet e1/4 current state: enabled, port link is down
Hardware address is 00:0a:5a:9b:18:15
SetSpeed is auto, ActualSpeed is unknown, Duplex mode is unknown
Current port type: 1000BASE-T
Priority is 2
Flow control is disabled
Broadcast storm control target rate is 49984pps
PVID is 1
Port mode: access
Untagged VLAN ID: 1
Input  : 0 packets, 0 bytes
         0 broadcasts, 0 multicasts, 0 unicasts
Output : 0 packets, 0 bytes
         0 broadcasts, 0 multicasts, 0 unicasts
```

switchport default vlan

To configure a VLAN as the default VLAN use the **switchport default vlan** command in the interface configuration mode. To restore the default vlan to port 1 use the **no** form of the command.

switchport default vlan*vlan-id*

no switchport default vlan

Syntax Description	<i>vlan-id</i> Specifies the VLAN id that will be used as the default VLAN.
---------------------------	---

Command Default	None
------------------------	------

Command Modes	Interface configuration mode
----------------------	------------------------------

Examples

This example shows how to configure a default vlan:

```
Device(config)# interface ethernet 1/1  
Device(config-if-ethernet-1/1)# switchport mode access  
Device(config-if-ethernet-1/1)# switchport default vlan 100
```

switchport ethernet

To add an VLAN interface to a designated port or to all ports use the **switchport ethernet** command in the VLAN configuration mode.

switchport {**ethernet** *port-number* | **all**}

Syntax Description	all	Specifies that all the ports will be added to the VLAN interface.
	<i>port-number</i>	Specifies the port numbers that will be added to the VLAN interface.

Command Default	None
------------------------	------

Command Modes	VLAN configuration
----------------------	--------------------

Examples

This example shows how to add a VLAN to an ethernet port:

```
Device(config-if-vlan)# switchport ethernet 1/4
```

switchport hybrid

To allow the packets from specified VLANs to pass through the hybrid port, use the **switchport hybrid** command in the interface configuration mode. To prevent the packets from specified VLANs passing through the hybrid port use the **no** form of the command.

switchport hybrid { **tagged** | **untagged** } **vlan** { *vlan-list* | **all** }

no switchport hybrid { **tagged** | **untagged** } **vlan** { *vlan-list* | **all** }

Syntax Description

tagged	Specifies the VLAN packets as tagged.
untagged	Specifies the VLAN packets as untagged.
vlan	Specifies the VLANs whose packets will be allowed to pass through the hybrid port.
<i>vlan-list</i>	Specifies a list of VLANs whose packets will be allowed to pass through the hybrid port.
all	Specifies that packets from all VLANs will be allowed to pass through the hybrid port.

Command Default

None

Command Modes

Interface configuration mode

Examples

This example shows how to allow the packets from the specified VLANs to pass through the hybrid port:

```
Device(config-if-ethernet-1/4)# switchport mode hybrid
Device(config-if-ethernet-1/4)# switchport hybrid tagged 2-4
```


switchport mode

To configure the VLAN mode for the interface use the **switchport mode** command in the interface configuration mode. You can set the VLAN mode to access, hybrid or trunk. The mode is set to hybrid by default.

switchport mode { **access** | **hybrid** | **trunk** }

Syntax Description	
access	Specifies that the interface is in access mode.
hybrid	Specifies that the interface is in hybrid mode.
trunk	Specifies that the interface is in trunk mode.

Command Default	None
------------------------	------

Command Modes	Interface configuration
----------------------	-------------------------

Examples

This example shows how to configure the VLAN mode to trunk on an interface:

```
Device(config)# interface ethernet1/4  
Device(config-if-ethernet-1/4)# switchport mode trunk
```

switchport trunk

To allow the packets from specified VLANs to pass through the trunk port, use the **switchport trunk** command in the interface configuration mode. To prevent the packets from specified VLANs passing through the hybrid port use the **no** form of the command.

switchport trunk allowed vlan { *vlan-list* | **all** }

no switchport trunk allowed vlan { *vlan-list* | **all** }

Syntax Description

allowed Configures the VLANs whose packets will be allowed to pass through the trunk port.

vlan Specifies the VLANs whose packets will be allowed to pass through the trunk port.

vlan-list Specifies VLAN IDs of the allowed VLANs when the interface is in trunking mode.

all Specifies all VLANs to be added to the current list.

Command Default

None

Command Modes

Interface configuration

Examples

This example shows how to allow the packets from the specified VLANs to pass through a trunk port:

```
Device(config-if-ethernet-1/4)# switchport mode trunk
Device(config-if-ethernet-1/4)# switchport trunk tagged 2-4
```

vlan

To add a VLAN and to enter the VLAN configuration mode, use the **vlan** command in global configuration mode. To delete the VLAN, use the **no** form of this command.

vlan *vlan list*

no vlan *vlan list*

Syntax Description

vlan list List of VLAN to be added and configured. The range is 1 to 4094. You can enter a single VLAN ID, a series of VLAN IDs separated by commas, or a range of VLAN IDs separated by hyphens.

Command Default

None

Command Modes

Global Configuration

Examples

This example shows how to create a VLAN and enter the VLAN configuration mode:

```
Device(config)# vlan 1
```




PART **V**

OLT Network Configuration

- [OLT Network Configuration, on page 183](#)



OLT Network Configuration

- [arp](#) , on page 185
- [arp aging-time](#), on page 186
- [description *interface-name*](#), on page 187
- [dhcp-snooping](#) , on page 188
- [dhcp-snooping trust](#) , on page 189
- [dlf forward](#), on page 190
- [interface](#), on page 191
- [interface loopback-interface](#), on page 193
- [interface vlan-interface](#), on page 194
- [ip-source-guard](#), on page 195
- [ip-source-guard filter](#), on page 196
- [ip address](#), on page 197
- [ip address *mask-ip-address*](#), on page 198
- [ip address range](#), on page 199
- [ip icmp mask-reply](#), on page 200
- [ip icmp unreachable](#), on page 201
- [mac-address-table](#), on page 202
- [mac-address-table learning](#), on page 203
- [mac-address-table age-time](#), on page 204
- [mac-address-table blackhole](#), on page 205
- [mac-address-table max-mac-count](#), on page 206
- [mirror destination-interface](#), on page 207
- [mirror source-interface](#), on page 208
- [show arp](#), on page 209
- [show dhcp-snooping clients](#), on page 210
- [show dhcp-snooping interface](#), on page 211
- [show dlf-forward](#), on page 213
- [show ip interface](#), on page 214
- [show ip source guard](#), on page 215
- [show mac-address-table age-time](#), on page 216
- [show mac-address-table](#), on page 217
- [show mirror](#), on page 219
- [show snmp community](#), on page 220

- [show snmp contact](#), on page 221
- [show snmp engineid](#), on page 222
- [show snmp group](#), on page 223
- [show snmp host](#), on page 224
- [show snmp location](#), on page 225
- [show snmp mib](#), on page 226
- [show snmp name](#), on page 227
- [show snmp notify](#), on page 228
- [show snmp user](#), on page 229
- [show snmp view](#), on page 230
- [shutdown](#), on page 231
- [snmp-server](#), on page 232
- [snmp-server community](#), on page 233
- [snmp-server community encrypt](#), on page 234
- [snmp-server contact](#), on page 235
- [snmp-server encrypt](#), on page 236
- [snmp-server engineid](#), on page 237
- [snmp-server group](#), on page 238
- [snmp-server host](#), on page 239
- [snmp-server location](#), on page 241
- [snmp-server max-packet-length](#), on page 242
- [snmp-server name](#), on page 243
- [snmp-server trap-source](#), on page 244
- [snmp-server user](#), on page 245
- [snmp-server view](#), on page 247

arp

To add a static entry in the Address Resolution Protocol (ARP) table, use the **arp** command in the global configuration mode. To remove an entry from the ARP table, use the **no** form of the command.

[no] **arp***ip-address mac**mac-address* [**vid** *vlan-id* | **port** *port-id*]

Syntax Description		
<i>ip-address</i>		IPv4 address for which a permanent entry is added to the ARP table. Enter the IPv4 address in a four-part dotted-decimal format that corresponds to the local data-link address (a 32-bit address)
mac <i>mac-address</i>		Hardware MAC address that the IPv4 address is linked to. Enter the MAC address in dotted-hexadecimal notation.
vid <i>vlan-id</i>		(Optional) Specifies the configured VLAN.
port <i>port-id</i>		(Optional) Specifies the configured port

Command Default None

Command Modes Global configuration (config)

Usage Guidelines You can manually configure and maintain a static ARP entry. It cannot be aged or overwritten by dynamic ARP entry. A static ARP entry can be a long or a short entry. A static ARP entry comprises IP address and the corresponding MAC address. A long static ARP entry comprises the VLAN and egress interface details along with the IP address and MAC address. Long Static ARP entries can be directly used for packet forwarding.

When you manually configure a Long Static ARP entry, the IP address in the entry must be in the same network segment as the IP address of the VLAN interface on which the egress interface resides.

A short static ARP entry comprises the IP Address and the MAC Address. A short static ARP entry cannot be directly used for packet forwarding. A shorts static ARP request packet is sent by the host. If the source IP address and the source MAC address in the received response packet are the same as the configured IP address and MAC address, the ARP entry will be completed. Then it can be used for packet forwarding.

Example

This example shows how to configure a short static ARP entry:

```
Device> enable
Device# configure terminal
Device(config)# arp 192.168.1.19 mac 00:02:9a:3b:94:d9
```

arp aging-time

To specify how long an entry can exist in an ARP table, use the **arp aging-time** command in the global configuration mode.

arp aging-time *aging-time*

Syntax Description	<i>aging-time</i> Specify the timeout period in seconds.
---------------------------	--

Command Default	The default timeout of an ARP table entry is 20 minutes.
------------------------	--

Command Modes	Global configuration (config)
----------------------	-------------------------------

Example

This example shows how to configure the aging time for ARP table entries:

```
Device> enable
Device# configure terminal
Device(config)# arp aging-time 300
```

description *interface-name*

To configure the interface description, use the **description** *interface name* in the VLAN configuration mode. You can delete the interface description by using the **no** form of the command.

description *interface-name*

no description *interface-name*

Syntax Description	<i>interface-name</i> Adds a description for the interface.
---------------------------	---

Command Default	None
------------------------	------

Command Modes	VLAN configuration
----------------------	--------------------

Examples The following example shows how to configure the IP interface description

```
Device(config-if-vlanif)# description interface1
```

dhcp-snooping

To enable Dynamic Host Control Protocol (DHCP) snooping feature on a device, use the **dhcp-snooping** command in the global configuration mode.

dhcp-snooping [**port-down-action fast-remove**]

Syntax Description	port-down-action fast-remove Configures the link down operation on the port.
Command Default	None
Command Modes	Global configuration (config)
Usage Guidelines	<p>When DHCP Snooping is enabled on your device, it monitors and validates the DHCP packets that it receives. Untrusted ports drop the DHCP-ACK and DHCP-OFFER packets that are received from DHCP servers. Trusted ports forward the received DHCP packets to DHCP clients.</p> <p>To configure DHCP Snooping feature, use the dhcp-snooping command.</p> <p>When a link in the network goes down, use the dhcp-snooping port-down-action fast remove command to remove the corresponding entry from the DHCP binding database.</p>

Example

This example shows how to configure DHCP Snooping on a device:

```
Device> enable
Device# configure terminal
Device(config)# dhcp-snooping
```

dhcp-snooping trust

To configure an interface as trusted for Dynamic Host Control Protocol (DHCP) snooping operations, use the **dhcp-snooping trust** command in the interface configuration mode.

dhcp-snooping trust

Command Default None

Command Modes Global configuration (config)

Example

This example shows how to configure a trusted interface for DHCP Snooping:

```
Device> enable
Device# configure terminal
Device(config)# interface g0/1
Device(config-if)# dhcp-snooping trust
```

dlf forward

To enable the forwarding of Destination Lookup Failure (DLF) unicast or multicast packets, use the **dlf forward** command. To enable DLF forwarding on egress packets of all ports, use the command in the global configuration mode. To enable DLF forwarding on the egress packets of a specific port, use the command in the interface configuration mode. DLF Forwarding is disabled by default. To disable it use the **no** form of the command.

dlf-forward { **unicast** | **multicast** }

no dlf-forward { **unicast** | **multicast** }

Syntax Description	
	<i>unicast</i> Enables the forwarding function of DLF unicast packets
	<i>multicast</i> Enables the forwarding function of DLF multicast packets

Command Default DLF forwarding is disabled by default.

Command Modes Global configuration mode.
Interface configuration mode.

Examples

The following example shows how to configure DLF forwarding for unicast packets for all egress ports:

```
Device(config)# dlf-forward unicast
```

The following example shows how to configure DLF forwarding for unicast packets on a specific port:

```
Device(config)# interface ethernet 1/4  
Device(config-if)# dlf-forward unicast
```

The following example shows how to configure DLF forwarding for multicast packets for all egress ports:

```
Device(config)# dlf-forward multicast
```

The following example shows how to configure DLF forwarding for multicast packets on a specific port:

```
Device(config)# interface ethernet 1/4  
Device(config-if)# dlf-forward multicast
```

interface

To configure an interface and enter into Interface configuration mode, use the **interface** command in the global configuration mode.

interface { *port-id* | **ethernet** *slot-num/port-num* | **gpon** *slot-num/port-num* | **loopback-interface** *loopback-int-number* | **meth-interface** *meth-int-number* | **range** { **ethernet** *port-num/slot-num* | **gpon** *port-num/slot-num* } | **vlan-interface** *vlan-id* }

Syntax Description		
<i>port-id</i>		Specifies the port to be configured. It is a string consisting of 4 to 14 characters.
ethernet <i>slot-num/port-num</i>		Enables you to configure Ethernet ports. For a Gigabit Ethernet port, <i>slot-num</i> is 1 and <i>port-num</i> ranges from 1 through 4. For a Ten Gigabit Ethernet port, <i>slot-num</i> is 2 and <i>port-num</i> ranges from 1 through 2.
gpon <i>slot-num/port-num</i>		Enables you to configure GPON ports. <i>slot-num</i> is 0 and <i>port-num</i> ranges from 1 through 8.
loopback-interface <i>loopback-int-number</i>		Enables you to configure a loopback interface. <i>loopback-int-number</i> number can be 0 or 1.
meth-interface <i>meth-int-number</i>		Enables you to configure the Management Interface, MEth, that allows you to log in and perform configurations.
range { ethernet <i>port-num/slot-num</i> gpon <i>port-num/slot-num</i> }		Enables you to configure a range of ethernet interfaces or a range of GPON interfaces.
vlan-interface <i>vlan-id</i>		Enables you to configure a VLAN interface. <i>vlan-id</i> specifies the VLAN id. Values range from 1 through 4094.

Command Modes Global Configuration (config)

Command Default None

Usage Guidelines Use the **interface** command to enter the Interface Configuration mode and configure the interface.

To configure a range of interfaces at once, use the **interface range** command. In the interface range configuration mode, all entered commands are applicable to all interfaces within that range.

Example

The following example configures an Ethernet interface:

```
Device#configure terminal
Device(config)#interface ethernet 1/1
Device(config-if-ethernet-1/1)#
```

The following example configures a range of GPON interfaces:

```
Device#configure terminal
Device(config)#interface range gpon 0/1 to gpon 0/3
```


interface loopback-interface

To create a loopback interface and to enter the loopback interface configuration mode, use the **interface loopback-interface** command in the Global configuration mode.

To disable a loopback interface use the **no** form of the command.

interface loopback-interface *interface-number*

no interface loopback-interface

Syntax Description	loopback-interface Configures a loopback interface.
	<i>interface-number</i> Configures the loopback interface number.

Command Default None

Command Modes Global configuration mode

Examples

The following example shows how to configure a loopback interface:

```
Device(config)# interface loopback-interface 1
```

interface vlan-interface

To create a VLAN interface and enter interface configuration mode, use the **interface vlan-interface** command in the global configuration mode. To remove a VLAN interface, use the **no** form of the command.

interface vlan-interface *vlan-id*

no interface vlan-interface

Syntax Description	<i>vlan-id</i> Sets the VLAN for the interface. The range is from 1-4094.
---------------------------	---

Command Default	None
------------------------	------

Command Modes	Global configuration
----------------------	----------------------

Examples The following example shows how to configure an interface VLAN:

```
Device(config)# interface vlan-interface 1
```

ip-source-guard

To enable IP Source Guard feature on a device, use the **ip-source-guard** command in the global configuration mode.

```
ip-source-guard { vlan vlan-list | permit igmp | bind ip ip-address [mac mac-address interface { ethernet | gpon } interface-id vlan vlan-id] }
```

Syntax Description

vlan <i>vlan-list</i>	Configures IP Source Guard on the VLANs listed by <i>vlan-list</i> .
permit igmp	Configures IP Source Guard to allow Internet Group Management Protocol (IGMP) packets to pass through.
bind ip <i>ip-address</i>	Configures an entry in the static IP source binding table.
mac <i>mac-address</i>	The MAC address that is bound to the IP address.
interface	Specifies the interface to be configured.
ethernet	Specifies the Ethernet interface
gpon	Specifies the GPON interface
vlan <i>vlan-id</i>	Specifies the VLAN to which the interface belongs.

Command Default

None

Command Modes

Global configuration (config)

Usage Guidelines

IP Source Guard feature filters the source IP address on a Layer 2 port to prevent a malicious host from impersonating a legitimate host.

You can enable the IP Source Guard feature only on untrusted ports. For IP Source Guard to function, enable DHCP Snooping.

Use the **ip-source-guard bind** command to configure an IP source binding.

Use the **ip-source-guard vlan** *vlan-list* command to configure IP Source Guard on the listed VLANs.

Use the **ip-source-guard permit igmp** command to allow IGMP packets to pass through.

Example

The following example shows how to configure an entry in the IP source binding table:

```
Device> enable
Device# configure terminal
Device(config)# ip-source-guard bind ip 192.168.11.2
```

The following example shows how to configure ip source guard on three VLANs:

```
Device(config)# ip-source-guard vlan 7,8,10
```

ip-source-guard filter

To configure the port filtering mode for an interface, use the **ip-source-guard** command in the interface configuration mode.

```
ip-source-guard [ip | ip-mac | ip-mac-vlan]
```

Syntax Description	ip	Specifies that the port filter packets are based on source IP, regardless of the MAC address and the VLAN ID.
	ip-mac	Specifies that the port filters packets based on the source IP address and the MAC address of the packet.
	ip-mac-vlan	Specifies that the port filters packets based on source IP address, MAC address, and VLAN ID.

Command Default None

Command Modes Interface Configuration (config-if)

Usage Guidelines IP Source Guard feature filters the source IP address on a Layer 2 port to prevent a malicious host from impersonating a legitimate host.

You can enable the IP Source Guard feature only on untrusted ports. For IP Source Guard to function, enable DHCP Snooping.

Use the **ip-source-guard ip** command on the interface to filter packets are based on source IP, regardless of the MAC address and the VLAN ID.

Use the **ip-source-guard ip-mac vlan-list** command on the interface to filter packets are based on source IP and MAC address, regardless of the VLAN ID.

Use the **ip-source-guard ip-mac-vlan** command on the interface to filter packets are based on source IP, MAC address, and VLAN ID.

If you don't specify the port filtering mode, the port filters packets based on the source IP address, MAC address, and VLAN ID.

Example

The following example shows how to configure the port to filter packets based on the source IP address and MAC address:

```
Device> enable
Device# configure terminal
Device(config)# interface ethernet 1/1

Device(config-if-ethernet-1/1)# ip-source-guard ip-mac
Config IP source guard mode of port successfully.
```

ip address

To configure the primary IP address for the VLAN interface, use the **ip address** command in the VLAN configuration mode.

```
ip address { ip-addressmask-ip-addressoverride | primary ip-address }
```

Syntax Description

Override Overrides the IP address of the VLAN interface.

primary Configures the primary IP address for the VLAN interface.

Command Default

None

Command Modes

VLAN configuration

Examples

The following example shows how to configure the primary IP address for an interface:

```
Device(config-if-vlan)# ip address primary 192.0.2.1
```

ip address *mask-ip-address*

To configure a loopback interface for the IP address, use the **ip address *mask-ip-address*** command in the loopback interface configuration mode.

To disable the loopback loopback interface for the IP address, use the **no** form of the command.

ip address*ip-address mask-ip-address*

no ip address*ip-address mask-ip-address*

Syntax Description	<i>ip-address</i>	It is the IP address of the interface
	<i>mask-ip-address</i>	Configures the loopback IP address for the interface.

Command Default	None
------------------------	------

Command Modes	Loopback interface configuration mode
----------------------	---------------------------------------

Examples

The following example shows how to configure a loopback interface for the IP address

```
Device(config-if-loopbackinterface) # ip address 192.0.2.1 255.255.255.0
```

ip address range

To configure the range of IP addresses for the VLAN interface, use the **ip address range** command in the the VLAN configuration mode. You can delete the range of IP addresses for the VLAN interface using the **no** form of the command.

```
ip address range { start-ip-address end-ip-address }
```

```
no ip address range { start-ip-address end-ip-address }
```

Syntax Description		
	range	Configures the range of IP addresses for the VLAN interface
	<i>start-ip-address</i>	Configures the starting IP address of the range.
	<i>end-ip-address</i>	Configures the ending IP address of the range.

Command Default	None
------------------------	------

Command Modes	VLAN configuration mode
----------------------	-------------------------

Examples

The following example shows how to configure a range of IP addresses for the interface:

```
Device(config-if-vlan)# ip address range 192.0.2.254 192.0.2.255
```

ip icmp mask-reply

To enable the ICMP address mask reply packet, use the **ip icmp mask-reply** command in the global configuration mode. To disable the ICMP address mask reply packet, use the **no** form of the command.

ip icmp mask-reply

no ip icmp mask-reply

Syntax Description	mask-reply Enables the ICMP address mask reply packet.
---------------------------	---

Command Default	None
------------------------	------

Command Modes	Global configuration mode
----------------------	---------------------------

Examples The following example shows how to enable ICMP address mask reply packet:

```
Device(config)# ip icmp mask-reply
```


ip icmp unreachable

To enable the sending of ICMP destination unreachable packets, use the **ip icmp unreachable** command in the VLAN configuration mode. To disable the sending of ICMP destination unreachable packets, use the **no** form of the command.

ip icmp unreachable

no ip icmp unreachable

Syntax Description	unreachable Enables the sending of ICMP destination unreachable packets.
---------------------------	---

Command Default	None
------------------------	------

Command Modes	VLAN configuration mode
----------------------	-------------------------

Examples

The following example shows how to enable the sending of ICMP destination unreachable packets.

```
Device(config-if-vlanif)# ip icmp unreacheable
```

mac-address-table

To add a MAC address manually to the MAC address table, use the **mac-address-table** command in the global configuration mode. To remove a MAC address from the table, use the **no** form of the command.

mac-address-table { **static** | **permanent** | **dynamic** } *mac-address* **interface ethernet***interface-number* **vlan** *vlan-id*

no mac-address-table { **static** | **permanent** | **dynamic** } *mac-address* **interface ethernet***interface-number* **vlan** *vlan-id*

Syntax Description

static	Adds a static MAC address to the MAC address table.
permanent	Adds a MAC address permanently to the MAC address table.
dynamic	Adds a dynamic MAC address to the MAC address table.

Command Default

None

Command Modes

Global configuration

Examples

The following examples shows how to add a static MAC address to a MAC address table:

```
Device(config)# mac-address-table static 00:50:3e:8d:64:00 interface ethernet
1/4 vlan 3
```

mac-address-table learning

To disable dynamic MAC address learning, use the **no mac-address-table learning** command. To disable MAC address learning on all ports use the command in the global configuration mode. To disable MAC address learning on specific ports use the command in the interface configuration mode. MAC address learning is enabled by default.

mac-address-table learning

no mac-address-table learning

Syntax Description	learning Enables or disables MAC address learning.
---------------------------	---

Command Default	MAC address learning is enabled by default.
------------------------	---

Command Modes	Global configuration Interface configuration
----------------------	---

Examples

The following example shows how to disable MAC address learning on an ethernet port:

```
Device(config)# interface ethernet 1/4  
Device(config-if-ethernet-1/4)# no mac-address-table learning
```

mac-address-table age-time

To configure the aging time for entries in the MAC address table, use the **mac-address-table age-time** command in the global configuration mode. To disable the aging process use the **disable** keyword.

mac-address-table age-time { *seconds* | **disable** }

Syntax Description	disable Disables the ageing process for the MAC address table.
	<i>seconds</i> Configures the ageing time for the MAC address table in seconds.

Command Default	None
------------------------	------

Command Modes	Global configuration
----------------------	----------------------

Examples	The following example shows how to configure ageing time for a MAC address table:
-----------------	---

```
Device(config)# mac-address-table age-time 120
```

mac-address-table blackhole

To add the MAC address of an untrusted user as a Blackhole MAC address, use the **mac-address-table blackhole** command in the global configuration mode. To remove a MAC address as a Blackhole MAC address use the **no** form of the command.

mac-address-table blackhole *mac-address* **vlan** *vlan-id*

no mac-address-table blackhole *mac-address* **vlan** *vlan-id*

Syntax Description	blackhole Adds a MAC address as a Blackhole MAC address.
---------------------------	---

Command Default	None
------------------------	------

Command Modes	Global configuration
----------------------	----------------------

Examples

The following example shows how to add a MAC address as a Blackhole MAC address:

```
Device(config)# mac-address-table blackhole 00:05:00:05:00:05 vlan 1
```

mac-address-table max-mac-count

To configure the maximum number of MAC addresses that will be learnt by the MAC Address Table on a port, use the **mac-address-table max-mac-count** command in the interface configuration mode. To keep the number of MAC addresses learnt as unlimited use the **no** form of the command. By default, the number of MAC addresses that are dynamically learnt by the MAC Address Table are unlimited.

mac-address-table max-mac-count *integer*

no mac-address-table max-mac-count *integer*

Syntax Description

max-mac-count *integer* Enables a limit on the number of dynamically learnt MAC addresses added to the table

Command Default

The number of learnt MAC addresses are unlimited by default

Command Modes

Interface configuration

Examples

The following example shows how to enable a maximum learnt MAC address count on a port:

```
Device(config)# interface ethernet 1/4
Device(config-if-ethernet-1/4)# mac-address-table max-mac-count 500
```

mirror destination-interface

To configure a port as destination port for mirroring, use the `mirror destination-interface` command in the global configuration mode. To remove the mirroring configuration, use the **no** form of the command.

[no] **mirror destination-interface** {**ethernet** *slot/port* | **gpon** *slot/port*}

Syntax Description	ethernet <i>slot/port</i>	Specifies the ethernet interface that can be configured as the destination for port mirroring
	gpon <i>slot/port</i>	Specifies the GPON interface as the destination for port mirroring.

Command Default None

Command Modes Global configuration (config)

Usage Guidelines Use this command to configure the destination port that receives the mirrored packets. Port mirroring duplicates the data packets on the monitored (source) port and sends the packets to a destination port for monitoring or analysis. You can mirror inbound packets or outbound packets or both types of packets on the source port.

A port configured as a destination port cannot be used as a normal port.

For a switch, you can configure only one port as destination port.

Example

The following example sets the ethernet port 2/1 as the destination for mirroring.

```
Device#configure terminal
Device(config)#mirror source-interface ethernet 1/1 both
Device(config)#mirror destination-interface ethernet 2/1
```

mirror source-interface

To configure a port to act as a source port for mirroring, use the **mirror source-interface** command in the global configuration mode. To remove the mirroring configuration, use the **no** form of the command.

[no] **mirror source-interface** {**ethernet** *slot/port* | **cpu** | **gpon** *slot/port* } {**ingress** | **egress** | **both**}

Syntax Description		
ethernet <i>slot/port</i>	Specifies the ethernet interface that can be configured as the source for port mirroring	
cpu	Specifies the CPU as the source for port mirroring	
gpon <i>slot/port</i>	Specifies the GPON interface as the source for port mirroring.	
ingress	Specifies that the packets at the ingress of the specified port, which are inbound, are mirrored.	
egress	Specifies that packets at the egress of the specified port, which are outbound, are mirrored.	
both	Specifies that the packets at both the ingress and egress interfaces are mirrored.	

Command Default None

Command Modes Global configuration (config)

Usage Guidelines Use this command to configure the source port for mirroring the packets at the port. You can mirror inbound packets or outbound packets or both types of packets.

Port mirroring duplicates the data packets on the monitored (source) port and sends the packets to a destination port for monitoring or analysis.

You can configure multiple ports as source port for mirroring.

Example

The following example sets the ethernet port 1/1 as the source for mirroring the packets.

```
Device#configure terminal
Device(config)#mirror source-interface ethernet 1/1 both
```


show arp

To display the Address Resolution Protocol (ARP) table entries, use the **show arp** command in privileged or global configuration mode.

show arp {**dynamic** | **static** | **all** }

Syntax Description	
dynamic	Displays all the dynamic ARP table entries
static	Displays all the static ARP table entries
all	Displays all the entries from the ARP table

Command Default None

Command Modes Privileged (#)
Global Configuration (config)

Usage Guidelines The **show arp dynamic** command displays all mappings and information about each entry in the ARP table, including the aging time, VLAN instance, and port.

Example

```
Device#show arp dynamic
Informations of ARP
d - days, h - hours, m - minutes, s - seconds
IpAddress      Mac_Address    Vlan  Port    VPTag  Type      ExpireTime  Status
10.75.171.1    00:23:5d:fd:94:00  100  e1/3    0      dynamic  18m34s     valid
10.75.171.71   00:50:56:92:1d:fb  100  e1/3    0      dynamic  10m51s     valid
10.75.171.79   00:0c:29:80:8b:59  100  e1/3    0      dynamic  17m43s     valid
10.75.171.91   00:0c:29:71:b1:4f  100  e1/3    0      dynamic  10m59s     valid
10.75.171.138  00:0c:29:f9:35:c3  100  e1/3    0      dynamic  11m07s     valid

Total entries:5
```

Table 6: Description of the show arp dynamic Command Output

IpAddress	Specifies the IP address of the ARP table entry
MAC_Address	Specifies the MAC address associated with the IP address
Vlan	Specifies the VLAN to which this interface belongs
Port	Specifies the port that has learnt the ARP entry
VPTag	Specifies the virtual port for GPON routing
Type	Specifies whether it is a dynamic or a static entry
Expire Time	Displays the time remaining before the ARP entry expires
Status	Specifies whether the entry is valid or not.

show dhcp-snooping clients

To display binding between the IP address and the MAC address that is recorded by DHCP Snooping, use the **show dhcp-snooping clients** command in privileged or global configuration mode.

```
show snmp dhcp-snooping clients
```

Command Default None

Command Modes Privileged (#)
Global Configuration (config)

Example

The following example shows a sample format of the output of this command:

```
Device#show dhcp-snooping clients
DHCP client information:
d - days, h - hours, m - minutes, s - seconds
IPAddress      mac                vlan port      LeaseTime      ExceedTime

Total entries: 0. Printed entries: 0.
```

Related Commands

Command	Description
dhcp-snooping	Enables DHCP Snooping on the device.

show dhcp-snooping interface

To display the details of DHCP Snooping on an interface, use the **show dhcp-snooping interface** command in privileged or global configuration mode.

```
show dhcp-snooping interface [ethernet | gpon] [interface-id]
```

Command Default None

Command Modes Privileged (#)

Global Configuration (config)

Usage Guidelines This command displays the DHCP Snooping enabled state, information on the trusted port, the number of DHCP clients allowed on the physical port, and the number of currently connected DHCP clients.

Example

```
Device#show dhcp-snooping interface
Config information of DHCP Snooping:
DHCP Snooping status:Enable
DHCP Snooping port-down-action fast-remove:Enable
Port information:
Port          mode      maxclients  clients(ack)  clients(unack)
g0/1          untrust   2048        0             0
g0/2          untrust   2048        0             0
g0/3          untrust   2048        0             0
g0/4          untrust   2048        0             0
g0/5          untrust   2048        0             0
g0/6          untrust   2048        0             0
g0/7          untrust   2048        0             0
g0/8          untrust   2048        0             0
e1/1          untrust   2048        0             0
e1/2          untrust   2048        0             0
e1/3          untrust   2048        0             0
e1/4          untrust   2048        0             0
e2/1          untrust   2048        0             0
e2/2          untrust   2048        0             0
```

```
Device#show dhcp-snooping interface gpon 0/1

Config information of DHCP Snooping:
DHCP Snooping status:Enable
DHCP Snooping port-down-action fast-remove:Enable
Port information:
Port          mode      maxclients  clients(ack)  clients(unack)
g0/1          untrust   2048        0             0
```

```
Device#show dhcp-snooping interface ethernet 1/1

Config information of DHCP Snooping:
DHCP Snooping status:Enable
DHCP Snooping port-down-action fast-remove:Enable
Port information:
Port          mode      maxclients  clients(ack)  clients(unack)
```

show dhcp-snooping interface

e1/1	untrust	2048	0	0
------	---------	------	---	---

show dlf-forward

To display the DLF forwarding configuration for a port, use the **show dlf-forward** command in the EXEC mode.

show dlf-forward interface { **ethernet** *port-number* | **gpon** *port-number* }

Syntax Description	
ethernet <i>port-number</i>	Displays the DLF Forwarding configuration for the ethernet port.
gpon <i>port-number</i>	Displays the DLF Forwarding configuration for the gpon port.

Command Default None

Command Modes User EXEC
Privileged EXEC

Examples

The following example shows how to display the DLF forwarding configuration for an ethernet port

```
Device# show dlf-forward interface ethernet 1/1
Forwarding unknown unicast packets global status:  disable
Forwarding unknown multicast packets global status:  disable
Port      Forwarding Unknown Unicast      Forwarding Unknown Multicast
e1/1      disable                          disable
```

Examples

The following example shows how to display the DLF forwarding configuration for a GPON port

```
Device# show dlf-forward interface gpon 0/1
Forwarding unknown unicast packets global status:  disable
Forwarding unknown multicast packets global status:  disable
Port      Forwarding Unknown Unicast      Forwarding Unknown Multicast
g0/1      disable                          disable
```

show ip interface

To display the IP interface configuration for the Layer 3 device, use the **show ip interface** command in the EXEC mode.

show ip interface { **loopback-interface** *loopback-interface-number* | **vlan-interface** *vlan-interface-number* | **meth-interface** *meth-interface-number* }

Syntax Description	
<i>loopback-interface-number</i>	Displays information for the loopback interface.
<i>vlan-interface-number</i>	Displays information for the VLAN interface.
<i>meth-interface-number</i>	Displays information for the meth interface.

Command Default None

Command Modes User EXEC
Privileged EXEC

Examples

The following example shows a sample output of a loopback interface:

```
Device# show ip interface loopback-interface 1
Show informations of interface
The mac-address of interface is 00:0a:5a:9b:18:15
Interface name       : LOOPBACK-IF1
Primary ipaddress    : None
Secondary ipaddress  : None
Interface status     : Up
```

Total entries: 1 interface.

The following example shows a sample output of a VLAN interface:

```
Device# show ip interface vlan-interface 1
Show informations of interface
The mac-address of interface is 00:0a:5a:9b:18:15
Interface description : interfacel
Interface name        : VLAN-IF1
Primary ipaddress     : None
Secondary ipaddress   : None
VLAN                  : 1
Address-range         : 192.0.2.254-192.0.2.255,
Interface status      : Up
```

Total entries: 1 interface.

show ip source guard

To display the status and port filter applied on each port, use the **show ip-source-guard** command in privileged or global configuration mode.

```
show ip-source-guard [bind | permit | vlan]
```

Syntax Description	bind	Displays the entries of the static IP source binding table.
	permit	Displays the whether Internet Group Management Protocol (IGMP) packets are permitted or not.
	vlan ip ip-address	Displays VLAN information.

Command Default None

Command Modes Privileged (#)
Global Configuration (config)

Example

```
Device#show ip-source-guard
Port      Status  FilterType
g0/1      disable N/A
g0/2      disable N/A
g0/3      disable N/A
g0/4      disable N/A
g0/5      disable N/A
g0/6      disable N/A
g0/7      disable N/A
g0/8      disable N/A
e1/1      enable  ip+mac+vlan
e1/2      disable N/A
e1/3      disable N/A
e1/4      disable N/A
e2/1      disable N/A
e2/2      disable N/A
```

Total entries:14

The following example displays the status of port filtering on IGMP packets:

```
Device#show ip-source-guard permit igmp
IP source guard permit igmp status:disable
```

Related Commands

Command	Description
ip-source-guard	Configures the IP source guard function on the ports of the device.

show mac-address-table age-time

To display the aging time of the MAC address table, use the **show mac-address-table age-time** command in the EXEC mode.

show mac-address-table age-time

Syntax Description	age-time Displays the aging time of the MAC address table.
---------------------------	---

Command Default	None
------------------------	------

Command Modes	User EXEC Privileged EXEC
----------------------	------------------------------

Examples

The following example shows how to display the aging time for a MAC address table:

```
Device# show mac-address-table age-time  
  
mac address table agingtime is 300 seconds.
```


show mac-address-table

To display information about the MAC address table, use the **show mac-address-table** command in the EXEC mode.

show mac-address-table { **static** | **permanent** | **dynamic** } **blackhole** **learning** **interface ethernet** *interface-number* **vlan** *vlan-id*

Syntax Description		
static	Displays the static MAC address table.	
permanent	Displays the permanent entries in the MAC address table.	
dynamic	Displays the dynamic MAC address table.	
blackhole	Displays the blackhole MAC address table.	
learning	Displays the MAC address learning status.	

Command Default None

Command Modes User EXEC
Privileged EXEC

Examples

The following example shows how to display the dynamic MAC address table:

```
Device# show mac-address-table dynamic
Show ARL table information
MAC Address          VLAN ID  port  status
00:0a:5a:a7:01:34    100     g0/1  dynamic
00:0b:ab:82:2d:82    100     e1/3  dynamic
00:0c:29:07:b6:9b    100     e1/3  dynamic
00:0c:29:15:9e:10    100     e1/3  dynamic
00:0c:29:3c:3b:08    100     e1/3  dynamic
00:0c:29:3c:3b:12    100     e1/3  dynamic
00:0c:29:71:b1:4f    100     e1/3  dynamic
00:0c:29:71:b1:59    100     e1/3  dynamic
00:0c:29:b8:0f:0b    100     e1/3  dynamic
00:0c:29:b8:0f:15    100     e1/3  dynamic
00:11:32:47:9a:30    100     e1/3  dynamic
00:19:bb:2f:5a:81    100     e1/3  dynamic
00:19:bb:30:70:97    100     e1/3  dynamic
00:19:bb:30:a0:6b    100     e1/3  dynamic
00:1f:26:35:7a:9f    100     e1/3  dynamic
00:21:5a:a9:53:14    100     e1/3  dynamic
00:23:5d:fd:94:00    100     e1/3  dynamic
00:30:18:cc:7b:02    100     e1/3  dynamic
00:50:56:92:0a:09    100     e1/3  dynamic
00:50:56:92:88:2f    100     e1/3  dynamic
00:50:56:95:41:5e    100     e1/3  dynamic
00:50:56:bd:2b:cf    100     e1/3  dynamic
00:61:56:60:93:84    100     e1/3  dynamic
00:d0:0a:0b:ea:1c    100     e1/3  dynamic
00:e0:4c:86:70:01    100     e1/3  dynamic
00:eb:d5:5e:02:a0    100     e1/3  dynamic
0c:f5:a4:ba:44:9f    100     e1/3  dynamic
2c:ab:eb:22:76:8d    100     e1/3  dynamic
```

show mac-address-table

```

40:a6:e8:e6:52:de 100 e1/3 dynamic
40:a6:e8:e6:b5:5c 100 e1/3 dynamic
44:8a:5b:98:e9:60 100 e1/3 dynamic
5c:71:0d:bb:35:8b 100 e1/3 dynamic
5c:71:0d:bb:3c:19 100 e1/3 dynamic
5c:71:0d:bb:60:fa 100 e1/3 dynamic
68:9c:e2:a0:7d:3e 100 e1/3 dynamic
68:9c:e2:a0:7d:5e 100 e1/3 dynamic
68:ca:e4:3a:3d:e0 100 e1/3 dynamic
68:ef:bd:f0:d1:08 100 e1/3 dynamic
b0:7d:47:3f:47:ae 100 e1/3 dynamic
c8:f9:f9:45:12:5b 100 e1/3 dynamic
e4:1f:13:43:41:0a 100 e1/3 dynamic
e4:1f:13:77:9f:06 100 e1/3 dynamic
e4:1f:13:77:a0:c8 100 e1/3 dynamic
Total entries: 43 .

```

Examples

The following example shows how to display the static MAC address table:

```

Device# show mac-address-table static
Show ARL table information
MAC Address      VLAN ID  port  status
00:0a:5a:9b:18:15 1        cpu  static
00:0a:5a:9b:18:15 100     cpu  static
Total entries: 2 .

```

Examples

The following example shows how to display the MAC address table learning status:

```

Device# show mac-address-table learning interface ethernet 1/1
Port      Mac learning status
e1/1      enable
Total entries: 1 .

```

show mirror

To see the port mirror configuration, use the **show mirror** command in privileged or global configuration mode.

```
show mirror
```

Command Default None

Command Modes Privileged (#)
Global Configuration (config)

Example

```
Device#show mirror
Information about mirror port(s)
The monitor port           : e1/4
The mirrored egress ports  : cpu,e1/1-e1/2.
The mirrored ingress ports : cpu,e1/1-e1/2.
```

show snmp community

To display the SNMP community strings configured on the switch, use the **show snmp community** command in privileged or global configuration mode.

```
show snmp community
```

Command Default None

Command Modes Privileged (#)
Global Configuration (config)

Example

```
Device#show snmp community
Show snmp community information
Encryption status: OFF
index  community  priority  state  view-name
1      public      ro       permit iso
2      private     rw       permit iso
```

Related Commands

Command	Description
snmp-server community	Sets the SNMP community string

show snmp contact

To display the SNMP contact string, use the **show snmp contact** command in privileged or global configuration mode.

```
show snmp contact
```

Command Default None

Command Modes Privileged (#)
Global Configuration (config)

Example

```
Device#show snmp contact  
Manager contact information : http://
```

Related Commands

Command	Description
snmp-server contact	Sets the SNMP manager contact information

show snmp engineid

To display the identification of the local SNMP engine and all remote engines that have been configured on the device, use the **show snmp engineid** command in privileged or global configuration mode.

```
show snmp engineid {local | remote } [engineid]
```

Command Default None

Command Modes Privileged (#)
Global Configuration (config)

Example

The following is a sample output of the **show snmp engineid local** command

```
Device#show snmp engineid local
Local engine id: : 134640000000000000000000
```

Related Commands

Command	Description
snmp-server engineid	Configures engine ID on the device.

show snmp group

To display the different SNMP group configurations, use the **show snmp group** command in privileged or global configuration mode.

```
show snmp group
```

Command Default

None

Command Modes

Privileged (#)

Global Configuration (config)

Usage Guidelines

Use this command to view the names of configured SNMP groups, the security models being used, and the different views configured under each group.

Example

```
Device#show snmp group
groupname: g3
securitymodel: 3 auth
readview: iso
writeview: iso
notifyview: no specified notifyview
context: default value(NULL)

groupname: initial
securitymodel: 3 noauthpriv
readview: iso
writeview: iso
notifyview: iso
context: default value(NULL)

groupname: initial
securitymodel: 3 auth
readview: iso
writeview: iso
notifyview: iso
context: default value(NULL)

group snmp3 number:3
```

Related Commands

Command	Description
snmp-server group	Configures an SNMP group

show snmp host

To display the recipient details for the SNMP trap notifications, use the **show snmp host** command in privileged or global configuration mode.

```
show snmp host
```

Command Default None

Command Modes Privileged (#)
Global Configuration (config)

Example

```
Device#show snmp host
Show SNMP trap host information
SNMP host ip security version
10.75.166.19 public 2c
```

Related Commands

Command	Description
snmp-server host	Configures the recipient for the SNMP notifications.

show snmp location

To display the SNMP manager location string, use the **show snmp location** command in privileged or global configuration mode.

```
show snmp location
```

Command Default None

Command Modes Privileged (#)
Global Configuration (config)

Example

```
Device#show snmp location  
Switch location information : sample sysLocation factory default
```

Related Commands

Command	Description
snmp-server location	Sets the SNMP manager location string.

show snmp mib

To display the Management Information Base (MIB) module instance identifiers, use the **show snmp mib** command in privileged or global configuration mode.

```
show snmp mib [module module-name]
```

Syntax Description	module	Specifies the MIB module object instance identifier
	<i>module-name</i>	

Command Default None

Command Modes Privileged (#)
Global Configuration (config)

Usage Guidelines SNMP MIB is a repository for information about device parameters and network data. Collections of related objects are defined in MIB modules.

The **show snmp mib** command displays the instance identifiers for all the MIB objects on the system. The MIB module table names are registered when the system initializes.



Note The **show snmp mib** command generates a high volume of output if SNMP is enabled on your system.

Example

The following is a sample output that shows the details of the **gbnL2PppoePlus** MIB module:

```
Device#show snmp mib module gbnL2PppoePlus

gbnL2PppoePlus:pppoeplusType-[1.3.6.1.4.1.9.6.1.120.1.2.4.6.2.0]
gbnL2PppoePlus:pppoeplusFormat-[1.3.6.1.4.1.9.6.1.120.1.2.4.6.3.0]
gbnL2PppoePlus:pppoeplusDelimiter-[1.3.6.1.4.1.9.6.1.120.1.2.4.6.4.0]
gbnL2PppoePlus:pppoeplusCircuitidOrder-[1.3.6.1.4.1.9.6.1.120.1.2.4.6.5.0]
gbnL2PppoePlus:pppoeplusCircuitidString-[1.3.6.1.4.1.9.6.1.120.1.2.4.6.6.0]
gbnL2PppoePlus:pppoeplusRemoteidOrder-[1.3.6.1.4.1.9.6.1.120.1.2.4.6.7.0]
gbnL2PppoePlus:pppoeplusRemoteidString-[1.3.6.1.4.1.9.6.1.120.1.2.4.6.8.0]
gbnL2PppoePlus:pppoeplusPortsIndex-[1.3.6.1.4.1.9.6.1.120.1.2.4.6.9.1.1.1]
gbnL2PppoePlus:pppoeplusPortsOnOff-[1.3.6.1.4.1.9.6.1.120.1.2.4.6.9.1.2.1]
gbnL2PppoePlus:pppoeplusPortsTrust-[1.3.6.1.4.1.9.6.1.120.1.2.4.6.9.1.3.1]
gbnL2PppoePlus:pppoeplusPortsDropPadi-[1.3.6.1.4.1.9.6.1.120.1.2.4.6.9.1.4.1]
gbnL2PppoePlus:pppoeplusPortsDropPado-[1.3.6.1.4.1.9.6.1.120.1.2.4.6.9.1.5.1]
gbnL2PppoePlus:pppoeplusPortsStrategy-[1.3.6.1.4.1.9.6.1.120.1.2.4.6.9.1.6.1]
gbnL2PppoePlus:pppoeplusPortsCircuit-[1.3.6.1.4.1.9.6.1.120.1.2.4.6.9.1.7.1]
```

show snmp name

To display the SNMP system name, use the **show snmp name** command in privileged or global configuration mode.

```
show snmp name
```

Command Default None

Command Modes Privileged (#)
Global Configuration (config)

Example

```
Device#show snmp name  
system name : 2
```

Related Commands

Command	Description
snmp-server name	Sets the SNMP system name.

show snmp notify

To display the configured SNMP notifications on the system, use the **show snmp notify** command in privileged or global configuration mode.

```
show snmp notify
```

Command Default

None

Command Modes

Privileged (#)

Global Configuration (config)

Example

```
Device#show snmp notify
Name      Type  State
bridge    trap  enabled
gbn       trap  enabled
gbnsavecfg trap  enabled
interfaces trap  enabled
rmon      trap  enabled
snmp      trap  enabled
if-ethernet Link-Trap
g0/1      enabled
g0/2      enabled
g0/3      enabled
g0/4      enabled
g0/5      enabled
g0/6      enabled
g0/7      enabled
g0/8      enabled
e1/1      enabled
e1/2      enabled
e1/3      enabled
e1/4      enabled
e2/1      enabled
e2/2      enabled
```

Related Commands

Command	Description
snmp-server trap-source	Configures an the interface that originates SNMP traps.
snmp-server enable	Enables SNMP notifications

show snmp user

To display information about the configured SNMP users, use the **show snmp user** command in privileged or global configuration mode.

```
show snmp user
```

Command Default None

Command Modes Privileged (#)
Global Configuration (config)

Example

```
Device#show snmp user
User name: u3
Engine ID: 1346400000000000000000000000000000
Authentication Protocol: HMACMD5AuthProtocol
Group-name: g3
Validation: valid

User name: initialmd5
Engine ID: 1346400000000000000000000000000000
Authentication Protocol: HMACMD5AuthProtocol
Group-name: initial
Validation: valid

User name: initialsha
Engine ID: 1346400000000000000000000000000000
Authentication Protocol: HMACSHAAuthProtocol
Group-name: initial
Validation: valid

User name: initialnone
Engine ID: 1346400000000000000000000000000000
Authentication Protocol: NoauthProtocol
Group-name: initial
Validation: valid

user number:4
```

Related Commands

Command	Description
snmp-server user	Configures an SNMP user in a group.

show snmp view

To display the details of an SNMP view, use the **show snmp view** command in privileged or global configuration mode.

```
show snmp view [view-name]
```

Command Default None

Command Modes Privileged (#)
Global Configuration (config)

Example

```
Device#show snmp view
View Name  Type      Subtree
iso        Include   1
sysview    Include   1.3.6.1.2.1.1
internet   Include   1.3.6.1

view number:3
```

Related Commands

Command	Description
snmp-server view	Configures an SNMP view

shutdown

To shut down a VLAN interface, use the **shutdown** command in the VLAN configuration mode. You can cancel the shutdown of the VLAN interface by using the **no** form of the command.

shutdown

no shutdown

Syntax Description	shutdown Shuts down the VLAN interface.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	VLAN configuration
----------------------	--------------------

Examples

The following example shows how to shut down a VLAN interface:

```
Device(config-if-vlanif)# shutdown
```

snmp-server

To enable or disable Simple Network Management Protocol (SNMP) on a device use the **snmp-server** command in the global configuration mode.

```
snmp-server {enable [informs |traps][bridge | gbn | gbnsavecfg | interfaces
| rmon | snmp]] | disable}
```

Syntax Description

enable	Enables SNMP traps on the device
disable	Disables the SNMP server
informs	Configures SNMP inform request
traps	Configures SNMP trap notifications
<ul style="list-style-type: none"> • bridge Specifies the type of SNMP informs or traps notifications to be enabled. • gbn If you do not specify the type of SNMP inform or trap, all traps and informs that are configured on your system are enabled. • gbnsavecfg • interfaces • rmon • snmp 	

Command Default

None

Command Modes

Global configuration (config)

Usage Guidelines

The **snmp-server enable** command is optional. SNMP traps and informs are enabled by default, on the device. Use the **snmp-server disable** command to disable SNMP traps or informs on the device.

Example

```
Device#configure terminal
Device(config)#snmp-server enable traps gbn
```


snmp-server community

To set up the community access string to permit access to the Simple Network Management Protocol (SNMP) use the **snmp-server community** command in the global configuration mode. To remove the configured community string, use the **no** form of the command.

```
[no] snmp-server community {name|md5 }{ro|rw}{deny|permit}[view view-name]
```

Syntax Description

name	SNMP community name that consists of 1 to 32 characters
md5	Uses md5 for authentication
ro	Specifies read-only access. Authorized management stations can retrieve only MIB objects
rw	Specifies read-write access. Authorized management stations can both retrieve and modify MIB objects.
permit	Specifies community name string is active
deny	Specifies community name string is not activated
view <i>view-name</i>	(Optional) Specifies a previously defined view. The view defines the objects available to the SNMP community. Default view is ISO.

Command Default

None

Command Modes

Global configuration (config)

Usage Guidelines

The SNMP community name authenticates access to MIB objects. In order for the NMS to access the switch, the community name definitions on the NMS must match at least one of the community name definitions on the switch.

Examples

The following example shows how to set the read/write community string to group1:

```
Device#configure terminal
Device(config)#snmp-server community group1 rw permit
```

The following example shows how to assign the string manager to SNMP and allow read-only access to the objects in the view called restricted:

```
Device(config)#snmp-server community group1 ro permit view restricted
```

The following example shows how to remove the community 1:

```
Device(config)#no snmp-server community 1
```

snmp-server community encrypt

To enable or disable encryption of community access string, use the **snmp-server community encrypt** command in the global configuration mode.

```
snmp-server community encrypt {enable|disable }
```

Syntax Description	enable Enables encryption of the community name string
---------------------------	---

	disable Disables encryption of community name string
--	---

Command Default	The community name string is not encrypted.
------------------------	---

Command Modes	Global configuration (config)
----------------------	-------------------------------

Example

```
Device#configure terminal
Device(config)#snmp-server community encrypt enable
```

snmp-server contact

To configure the SNMP manager contact information, use the **snmp-server contact** command in the global configuration mode. To remove the SNMP manager contact information, use the **no** form of the command.

```
snmp-server contact contact-information
```

Syntax Description	<i>contact-information</i> Specifies the SNMP manager contact details
---------------------------	---

Command Default	SNMP manager contact string is not set.
------------------------	---

Command Modes	Global Configuration (config)
----------------------	-------------------------------

Example

```
Device(config)#snmp-server contact SystemOperator
```

snmp-server encrypt

To enable or disable the encryption of the password for a user, use the **snmp-server encrypt** command in the global configuration mode.

A password is encrypted by default.

```
snmp-server encrypt {enable|disable}
```

Syntax Description	enable Enables the encryption of password
	disable Disables the encryption of password
Command Default	None
Command Modes	Global configuration (config)

Example

```
Device#configure terminal
Device(config)#snmp-server encrypt disable
```

snmp-server engineid

To configure the Simple Network Management Protocol (SNMP) engine ID on a local device or a remote device, use the **snmp-server** command in the global configuration mode.

```
snmp-server engineid local engineid | remote ip-address [udp-portport-num] engineid
```

Syntax Description	
local <i>engineid</i>	Specifies the engine ID of the local device
remote <i>ip-address</i>	Specifies the engine ID of the local device
udp-port <i>port-num</i>	Specifies the UDP port on the remote device

Command Default None

Command Modes Global configuration (config)

Usage Guidelines An SNMP engine ID is a unique string that identifies the device, for administrative purposes.

The engine ID of the local SNMP device is 134640000000000000000000. You can modify the local engine ID, but not delete it. You can create and delete the engine ID of a remote SNMP device. If you delete a remote engine ID, the corresponding users are also deleted. You can configure a maximum number of 32 remote engine IDs.

Example

```
Device#configure terminal
Device(config)#snmp-server engineid remote 172.16.20.4 1
```

snmp-server group

To configure an SNMP group that enables authentication for the members of a specified view, use the **snmp-server group** command in the global configuration mode. To remove the configured authentication for the SNMP group, use the **no** form of the command.

```
[no] snmp-server group group-name3 [auth |noauthpriv |priv] read read-view
write write-view notify notify-view
```

Syntax Description	
auth	Specifies that packets are authenticated but not encrypted.
noauthpriv	Specifies that packets are not authenticated.
priv	Specifies that packets are authenticated and not encrypted.
read <i>read-view</i>	(Optional) Specifies a read view for the SNMP group. This view enables you to view only the contents of the agent. If a <i>read-view</i> is not specified, it defaults to the iso view and auth security level.
write <i>write-view</i>	(Optional) Specifies a write view for the SNMP group. This view enables you to enter data and configure the contents of the agent. write-view does not have defaults. Hence it is mandatory to specify it if write is configured.
notify <i>notify-view</i>	(Optional) Specifies a notify view for the SNMP group. This view enables you to specify a notification or a trap. notify-view does not have defaults. Hence it is mandatory to specify <i>notify-view</i> if notify is configured.
Command Default	None
Command Modes	Global configuration (config)

Examples

```
Device#configure terminal
Device(config)#snmp-server group g1 3 priv write dept-view
```

snmp-server host

To configure the recipient of an SNMP notification operation, use the **snmp-server host** command in the global configuration mode. To remove the configured recipient for the SNMP group, use the **no** form of the command.

```
[no] snmp-server host {inet6 ipv6-address | ipv4-address}{version {1 | 2c | 3{auth | noauthpriv | priv }}} security-name [udp-port udp-port-num] [ notify-type[bridge | gbn | gbnsavecfg | interfaces | rmon | snmp] ]
```

Syntax Description

inet6 <i>ipv6-address</i>	Specifies the IPv6 address of the recipient of SNMP traps
<i>ipv4-address</i>	Specifies the IPv4 address of the recipient of SNMP traps
version {1 2c 3{ auth noauthpriv priv }	Specifies the SNMP version: 1, 2c, 3. If you specify SNMP version 3, ensure that you specify the security levels too: <ul style="list-style-type: none"> • auth: Enables MD5 and SHA packet authentication • noauth: Specifies that the noAuthNoPriv security level applies to this host. This is the default security level for SNMPv3. • priv: Enables Data Encryption Standard (DES) packet encryption.
<i>security-name</i>	Defines a name for this configuration.
udp-port <i>udp-port-num</i>	Specifies the UDP port on the host device.
notify-type	Specifies the type of notification to be sent to the host: <ul style="list-style-type: none"> • bridge • gbn • gbnsavecfg • interfaces • rmon • snmp

Command Default

None

Command Modes

Global configuration (config)

Usage Guidelines

Use the **snmp-server host** command to configure a recipient for the SNMP notifications. If this command is not configured, no notifications are sent. **snmp-server host** command is used in conjunction with the **snmp-server enable** command. For a host to receive most notifications, at least one **snmp-server enable** command and the **snmp-server host** command for that host must be enabled.

Examples

```
Device#configure terminal
```

```
Device(config)#snmp-server host 192.168.5.1 version 2c test-sec udp-port 4
```


snmp-server location

To set the SNMP server location string, use the **snmp-server location** command in the global configuration mode. To remove the SNMP server location information, use the **no** form of the command.

```
[no] snmp-server location syslocation
```

Syntax Description	<i>syslocation</i> String that describes the SNMP server location
---------------------------	---

Command Default	No system location string is set.
------------------------	-----------------------------------

Command Modes	Global Configuration (config)
----------------------	-------------------------------

Example

```
Device(config)#snmp-server location Building13
```

snmp-server max-packet-length

To configure the maximum size of SNMP packets, use the **snmp-server max-packet-length** command in the global configuration mode. To remove the maximum packet length configuration for SNMP packets, use the **no** form of the command.

```
[no] snmp-server max-packet-length length
```

Syntax Description	<i>length</i> Specifies the maximum packet length for SNMP packets. The value ranges from 484 bytes through 8000 bytes. Default value is 1000 bytes.
Command Default	Maximum packet length is set to 1000 bytes.
Command Modes	Global Configuration (config)

Example

```
Device(config)#snmp-server max-packet-length 1200
```

snmp-server name

To set the SNMP system name string, use the **snmp-server name** command in the global configuration mode. To remove the SNMP server name information, use the **no** form of the command.

```
[no] snmp-server name sysname
```

Syntax Description	<i>sysname</i> String that describes the SNMP server name
---------------------------	---

Command Default	No system name string is set.
------------------------	-------------------------------

Command Modes	Global Configuration (config)
----------------------	-------------------------------

Example

```
Device(config)#snmp-server name Building13Server
```

snmp-server trap-source

To specify the interface from which the Simple Network Management Protocol (SNMP) trap should originate, use the **snmp-server trap-source** command in the global configuration mode. To remove the source of SNMP trap, use the **no** form of the command.

```
snmp-server trap-source {inet6 | vlan-interface vlan-id | loopback-interface
interface | vlan-interface vlan-id}
```

Syntax Description		
	inet6	Specifies the IPv6 address family
	vlan-interface <i>vlan-id</i>	Specifies the VLAN id to which the VLAN interfaces that originate the traps, belong.
	loopback-interface <i>interface</i>	Specifies the loopback interface that is configured as the origin of the traps.

Command Default None

Command Modes Global configuration (config)

Usage Guidelines Use this command to monitor notifications from a particular interface.

An SNMP trap or inform that is sent from an SNMP server has a notification address of the interface it went out of at that time.

Example

```
Device#configure terminal
Device(config)#snmp-server trap-source vlan-interface 3
```

snmp-server user

To configure a new user to an SNMP group, use the **snmp-server user** command in the global configuration mode. To remove a configured user from an SNMP group, use the **no** form of this command.

```
[no]snmp-server user username group-name [remote ipaddress [udp-port port-number ]
] [auth {md5 |sha }{auth-password {authpassword |encrypt-authpassword
password} |auth-key{authkey | encrypt-authkeypassword}}][privdes {priv-key{key|
encrypt-privkeykey}| priv-password{password | encrypt-privpasswordprivpassword}
} ] ]
```

Syntax Description		
<i>username</i>	Name of the user created	
<i>group-name</i>	Name of the SNMP group to which the user belongs	
remote	(Optional) A remote SNMP entity to which the user belongs	
<i>ipaddress</i>	(Optional) IP address of the remote SNMP host.	
udp-port <i>port-number</i>	(Optional) UDP port on the remote port	
auth	(Optional) Specifies which authentication level should be used.	
md5	(Optional) Specifies the HMAC-MD5-96 authentication level	
sha	(Optional) Specifies the HMAC-SHA-96 authentication level	
auth-password <i>authpassword</i>	Specifies the authentication password	
auth-key <i>authkey</i>	Specifies the authentication key	
priv	(Optional) Specifies the use of the User-based Security Model (USM) for SNMP version 3 for SNMP message level security.	
des	(Optional) Specifies the use of the 56-bit Digital Encryption Standard (DES) algorithm for encryption.	
<i>priv-key</i>	(Optional) String that specifies the privacy user password.	

Command Default None

Command Modes Global configuration (config)

Usage Guidelines The **snmp-server user** command configures a user for a local engine or a remote engine.

The following three users exist by default and they are reserved as the system users:

- initialmd5
- initialsha
- initialnone

To configure a remote engine user, specify remote ipaddress. If you do not specify remote ipaddress, a local engine user is configured.

For a remote user, the default port number is 162. To configure a different remote port, specify a udp-port port-number .

Three levels of user privileges can be specified:

- **noauthpriv** : Authentication and password encryption are not required. It is the default configuration.
- **auth**: Authentication is required but password encryption is not required.
- **authpriv**: Authentication and password encryption, both are required.



Note The user security level should be the same as the corresponding group security level.

Example

```
Device#configure terminal
Device(config)#snmp-server user u3 g3 auth md5 auth-password password1
```

snmp-server view

To create or update an SNMP server view, use the **snmp-server view** command in the global configuration mode. To remove the configured SNMP server view, use the **no** form of the command.

```
[no] snmp-server view view-name oid-subtree {include | exclude}
```

Syntax Description

oid-subtree Object identifier (OID) of the ASN.1 subtree that is either included or excluded from the view.
A string that can have upto to 64 characters.

view-name Name of the SNMP view that is to be created.

exclude Excludes the OID specified in the *oid-subtree* argument from the SNMP view.

include Includes the OID specified in the *oid-subtree* argument in the SNMP view.

Command Default

None

Command Modes

Global configuration (config)

Usage Guidelines

Use this command to create a view that is a list of SNMP object trees, which you can access. The **iso**, **internet** and **sysview** views exist by default. You cannot delete or modify the **internet** view.

Examples

The following example creates a view named **oneview** and excludes all objects of the subtree:

```
Device#configure terminal
Device(config)#snmp-server view oneview 1.3 exclude
```




PART VI

Quality of Service

- [Quality of Service, on page 251](#)



Quality of Service

- [bandwidth egress rate](#), on page 252
- [clear traffic-statistic](#), on page 253
- [queue-scheduler cos-map](#), on page 254
- [queue-scheduler strict-priority](#), on page 255
- [queue-scheduler sp-wrr](#), on page 256
- [queue-scheduler wrr](#), on page 257
- [queue-scheduler dscp-map](#), on page 258
- [rate-limit](#), on page 259
- [show bandwidth egress](#), on page 260
- [show qos-info all](#), on page 261
- [show qos-interface](#) , on page 263
- [show queue-scheduler](#), on page 264
- [storm-control](#), on page 266
- [traffic-copy-to-cpu](#), on page 267
- [traffic-redirect](#), on page 268
- [traffic-statistic](#), on page 269

bandwidth egress rate

To set the bandwidth limit on the outbound traffic on a port, use the **bandwidth egress rate** command in the interface configuration mode. To remove the configured bandwidth limit, use the **no** form of the command.

```
[no]bandwidth egress target-rate [ target-burst-rate ]
```

Syntax Description

target-rate

Specifies the bandwidth limit in Kbps.

The target rate must be a multiple of 64K and should range between 2048 and 2608832 Kbps:

It should be 2048 to 1024000 Kbps for a GE port, 2048 to 2608832 Kbps for a PON port, and 2048 to 10240000 for a 10GE port.

target-burst-rate

Specifies the burst transmission rate.

Target burst rate (Kbps) must be a multiple of 64K. Values can range between 2048 through 2608832.

Command Default

None

Command Modes

Interface Configuration (config-if)

Example

```
Device#configure terminal
Device(config)#interface e1/1

Device(config-if-ethernet-1/1)#bandwidth egress 2048
```

clear traffic-statistic

To remove the traffic statistics records, use the **clear traffic-statistic** command in the global configuration mode.

```
clear traffic-statistic { [all | [ip-group {num | name } [subitem subitem ] ] ] [link-group {num | name } [subitem subitem ] ] ] }
```

ip-group { num name }	Specifies a standard or extended ACL.
link-group { num name }	Specifies a Layer 2 ACL.
subitem <i>subitem</i>	Specifies the sub item in the ACL.

Command Modes Global Configuration (config)

Command Default None

Usage Guidelines Use the **clear traffic-statistic all** command to remove all traffic statistics records.

Use the **clear traffic-statistic ip-group** or **clear traffic-statistic link-group** command to remove the traffic statistics records that are generated for the specified access control list.

Example

```
Device#configure terminal
Device(config)#clear traffic-statistic ip-group 3
```

queue-scheduler cos-map

To map the 802.1p priorities to the hardware queue, use the **queue-scheduler cos-map** command in the global configuration mode. To restore the default queue scheduler settings, use the **no** form of the command.

```
[no ]queue-scheduler cos-map [queue-class] [priority]
```

Syntax Description		
	<i>queue-class</i>	Specifies the hardware queue value which ranges from 0 through 7.
	<i>priority</i>	Specifies the 802.1p priority. The value ranges from 0 to 7.

Command Default Strict Priority scheduling is followed by default.

Command Modes Global configuration (config)

Usage Guidelines 802.1p is used to classify the outgoing traffic at the egress port based on the 802.1p priority. For each message that enters the switch, the system maps the specific hardware queue priority according to the 802.1p priority of the message.

Changing the mapping relation between 802.1p priority and hardware queues changes the mapping relation between 802.1p priorities and output queues.

If two 802.1p priorities are mapped to the same hardware priority queue, messages of the two 802.1p priorities cannot be forwarded with 1:1 forwarding.

Use the **queue-scheduler cos-map** command to set the 802.1p mapping with hardware queue priority.

Example

The following example shows how to map packets with priority 0 to queue 1:

```
Device#configure terminal
Device(config)#queue-scheduler cos-map 1 0
Config successfully.
```

queue-scheduler strict-priority

To configure the strict priority queue scheduling algorithm on the queue scheduler, use the **queue-scheduler strict-priority** command in the global configuration mode. To restore the default queue scheduler settings, use the **no** form of the command.

```
[no ]queue-scheduler strict-priority
```

Command Default Strict Priority scheduling is followed by default.

Command Modes Global configuration (config)

Usage Guidelines Strict-Priority Queuing is designed for critical business applications wherein the services are prioritized in order to reduce the latency of response when a congestion occurs. The priority queue classifies all messages into eight class: 7,6,5,4,3,2,1, and 0, in the order of priority. The group of critical services is put into the higher priority queue and non-critical business group is put into the lower priority queue. The higher priority queue is first emptied before the messages in the lower priority queue are sent. Messages in the group of non-critical business are transmitted in the idle gap of handling critical business data.

Example

```
Device#configure terminal
Device(config)#queue-scheduler strict-priority
```

queue-scheduler sp-wrr

To configure strict priority and weighted round robin (WRR) queue scheduling algorithm on the queue scheduler, use the **queue-scheduler sp-wrr** command in the global configuration mode. To restore the default queue scheduler settings, use the **no** form of the command.

```
[no ]queue-scheduler sp-wrr {w1| w2| w3| w4| w5| w6| w7| w8}
```

Syntax Description

<i>wx</i>	Specifies the weight of the queue represented by x.
where x can be 1, 2, 3, 4, 5, 6, 7,8	For example, w1 represents the weight of the first queue. w2 represents the weight of the second queue.

Command Default

Strict Priority scheduling is followed by default.

Command Modes

Global configuration (config)

Usage Guidelines

Strict-Priority and WRR queue scheduling combines the algorithms of strict-priority and Weighted round robin scheduling. If the weight of the queue is set to 0, the queue follows the Strict-Priority queuing algorithm to send messages. A non-zero value of the weight puts the queue to the WRR scheduling mechanism.

Example

```
Device#configure terminal
Device(config)#queue-scheduler sp-wrr 1 2 3 4 5 6 7 8
```


queue-scheduler wrr

To configure the weighted round robin (WRR) queue scheduling algorithm on the queue scheduler, use the **queue-scheduler wrr** command in the global configuration mode. To restore the default queue scheduler settings, use the **no** form of the command.

```
[no ]queue-scheduler wrr{ w1| w2| w3| w4| w5| w6| w7| w8}
```

Syntax Description

wx

Specifies the weight of the queue represented by x.

where x can be 1, 2, 3, 4, 5, 6, 7,8

For example, w1 represents the weight of the first queue. w2 represents the weight of the second queue.

Command Default

Strict Priority scheduling is followed by default.

Command Modes

Global configuration (config)

Usage Guidelines

Weighted Round Robin (WRR) queue scheduling divides each port into eight output queues: 7, 6, 5, 4, 3, 2, 1, and 0, in the that order of priority, with 7 being the highest priority. All the queues are scheduled by turns and each queue gets a certain service time. Each queue of WRR can be configured with weighted values of w7, w6, w5, w4, w3, w2, w1, or w0. The weighted value represents the weight of the resource.

An advantage of WRR queuing is that although multiple queues are scheduled by polling, each queue is not assigned a fixed time slot. If a queue is empty, it immediately switches to the next queue schedule. So, the bandwidth and resources of that queue can be fully utilized

Example

```
Device#configure terminal
Device(config)#queue-scheduler wrr 1 2 3 4 5 6 7 8
```

queue-scheduler dscp-map

To configure the strict priority queue scheduling algorithm on the queue scheduler, use the **queue-scheduler dscp-map** command in the global configuration mode. To restore the default queue scheduler settings, use the **no** form of the command.

```
[no ]queue-scheduler dscp-map [dscp-value] [priority]
```

Syntax Description

<i>dscp-value</i>	Specifies the DSCP value which ranges from 0 through 63.
<i>priority</i>	Specifies the 802.1p priority. The value ranges from 0 to 7.

Command Default

Strict Priority scheduling is followed by default.

Command Modes

Global configuration (config)

Usage Guidelines

DSCP mapping is disabled by default. To enable DSCP mapping use the **queue-scheduler dscp-map** command. DSCP allows 64 priority values whereas 802.1p (hardware queue) allows only eight priority values. By default, the following is the mapping between DSCP and 802.1p:

DSCP	802.1p
0-7	0
8-15	1
16-23	2
24-31	3
32-39	4
40-47	5
48-55	6
56-63	7

Example

The following example shows how to map DSCP 56 to 802.1p priority 6:

```
Device#configure terminal
Device(config)#queue-scheduler dscp-map

Device(config)#queue-scheduler dscp-map 56 6
```

rate-limit

To set the traffic rate limit in inbound or outbound direction, use the **rate-limit** command in the global configuration mode. To remove the rate limit, use the **no** form of the command.

```
[no]rate-limit {input | output} { [ip-group {num | name} [subitem subitem] ] [link-group {num | name} [subitem subitem] ] }target-rate
```

input	Specifies the rate limit in inbound direction.
output	Specifies the rate limit in outbound direction.
ip-group {num name }	Specifies a standard or extended ACL.
link-group {num name }	Specifies a Layer 2 ACL.
subitem <i>subitem</i>	Specifies the sub item in the ACL.
<i>target-rate</i>	Specifies target rate which is the traffic rate limit in Kbps. Target rate should be a multiple of 64, and can range from 64 to 1048512.

Command Modes Global Configuration (config)

Command Default None

Usage Guidelines Use the **rate-limit input** command to limit the traffic rate in the inbound direction.
Use the **rate-limit output** command to limit the traffic rate in the outbound direction.
Use this command to monitor the rate of traffic that enters a device. If the traffic exceeds a certain threshold, you can define policies to take suitable measures.

Example

The following example sets the inbound traffic rate limit to 100 Kbps:

```
Device#configure terminal
Device(config)#rate-limit input ip-group 3 100
```

show bandwidth egress

To display the rate limit and the burst rate that are set for the egress interface, use the **show bandwidth egress** command in privileged or global configuration mode.

```
show bandwidth egress[ interface {ethernet | gpon }port-num]
```

Command Default None

Command Modes Privileged (#)
Global Configuration (config)

Example

The following is a sample output of the **show bandwidth** command.

```
Device(config)#show bandwidth egress
g0/1: bandwidth egress
    limit rate: / Kbps      burst: / Kbps

g0/2: bandwidth egress
    limit rate: / Kbps      burst: / Kbps

g0/3: bandwidth egress
    limit rate: / Kbps      burst: / Kbps
....
...
e2/2: bandwidth egress
    limit rate: / Kbps      burst: / Kbps
```

Related Commands

Command	Description
bandwidth egress rate	Sets the bandwidth limit on the outbound traffic on a port.

show qos-info all

To display the parameters that are set for Quality of Service (QoS), use the **show qos-info** command in privileged or global configuration mode.

```
show qos-info {all| traffic-copy-to-cpu | mirrored-to | traffic-priority
| traffic-redirect | traffic-statistic| statistic }
```

Command Default

None

Command Modes

Privileged (#)

Global Configuration (config)

Usage Guidelines

Use the **show qos-info all** command to display all the configured QoS parameters.

Use the **show qos-info statistic** command to display all the statistics for QoS parameters.

Use the **show qos-info traffic-copy-to-cpu** command to display the parameter settings for copying messages to the CPU.

Use the **show qos-info mirrored-to** command to display the parameter settings for traffic mirroring.

Use the **show qos-info traffic-priority** command to display the parameter settings for traffic priority.

Use the **show qos-info traffic-redirect** command to display the parameter settings for message redirection.

Example

```
Device#show qos-info all
mirrored-to(max 3 dest port):
traffic-priority:
traffic-redirect:
traffic-statistic:
traffic-copy-to-cpu:
```

Here is a sample output for the **show qos-info statistic** command:

```
Device#show qos-info statistic
mirrored-to:
total mirrored-to rules          : 0 rules

traffic-priority:
total traffic-priority rules     : 0 rules

traffic-redirect:
total traffic-redirect rules     : 0 rules

traffic-statistic:
total traffic-statistic rules    : 0 rules

traffic-copy-to-cpu:
total traffic-copy-to-cpu rules  : 0 rules

total mirrored-to rules          : 0 rules
total traffic-priority rules     : 0 rules
```

show qos-info all

```
total traffic-redirect rules      : 0 rules
total traffic-statistic rules    : 0 rules
total traffic-copy-to-cpu rules  : 0 rules
total qos-info rules             : 0 rules
```

Related Commands

Command	Description
traffic-copy-to-cpu	Copies all packets to the CPU.
traffic-statistic	Configures the system to collect the traffic statistics
traffic-redirect	Redirects the traffic to a specified interface or to the CPU.

show qos-interface

To display all the policies set for Quality of Service (QoS) on the interface, use the **show qos-interface** command in privileged or global configuration mode.

```
show qos-interface {all| rate-limit | statistic
```

Command Default

None

Command Modes

Privileged (#)

Global Configuration (config)

Usage Guidelines

Use the **show qos-interface all** command to display all the QoS parameters for the interface.

Use the **show qos-interface rate-limit** command to display the rate limit parameters for the interface.

Use the **show qos-interface statistic** command to display the statistics of rate limit for all interfaces.

Example

The following is a sample output of the **show qos-interface all** command:

```
Device#show qos-interface all
total qos-interface rules : 0 rules
```

The following is a sample output of the **show qos-interface rate-limit** command:

```
Device#show qos-interface rate-limit
total rate-limit rules : 0 rules
```

The following is a sample output of the **show qos-interface statistic** command:

```
Device#show qos-interface satistic
total qos-interface rules : 0 rules
```

show queue-scheduler

To display information about the queue scheduler, use the **show queue-scheduler** command in privileged or global configuration mode.

```
show queue-scheduler [ cos-map | dscp-map ]
```

Syntax Description	Parameter	Description
	cos-map	Specifies the 802.1p and hardware queue mapping.
	dscp-map	Specifies the DSCP and 802.1p value mapping.

Command Default None

Command Modes Privileged (#)
Global Configuration (config)

Usage Guidelines Use the **show queue-scheduler** command to display information about the queue scheduler parameters.

Use the **show queue-scheduler cos-map** command to display information about the mapping between 802.1p and hardware.

Use the **show queue-scheduler dscp-map** command to display information about the mapping between 802.1p values and DSCP.

Examples

Following are sample outputs for the **show queue-scheduler** commands.

```
Device#show queue-scheduler
Queue scheduler status : enable
Queue scheduler mode   : SP (Strict Priority)
```

```
Device#show queue-scheduler cos-map
Information about map of cos:
802.1P Priority  Queue of class
-----
0                0
1                1
2                2
3                3
4                4
5                5
6                6
7                7
```

```
Device#show queue-scheduler dscp-map
dscp-pri has been disabled.
```

Related Commands

Command	Description
queue-scheduler wrr	Configures the weighted round robin scheduling mode.

Command	Description
queue-scheduler strict-priority	Configures the strict priority scheduling mode.
queue-scheduler dscp-map	Maps DSCP values to hardware priority values.
queue-scheduler cos-map	Maps 802.1p values to hardware queue map.

storm-control

To enable traffic storm control on an interface and to configure a threshold for the number of packets on the port, use the **storm-control** command in the interface configuration mode. To remove the storm control configuration on an interface, use the **no** form of the command.

```
[no]storm-control {broadcast | multicast | unicast } target-rate
```

Syntax Description		
	broadcast	Specifies broadcast traffic for storm control.
	multicast	Specifies multicast traffic for storm control.
	unicast	Specifies unicast traffic for storm control.
	<i>target-rate</i>	Specifies a threshold limit for the number of packets on the port. Value can range from 64 to 32000000 packets per second (pps) Default value is 49984 pps

Command Default None

Command Modes Interface Configuration (config-if)

Example

```
Device#configure terminal
Device(config)#interface e1/1

Device(config-if-ethernet-1/1)#storm-control unicast 512
Device(config-if-ethernet-1/1)#storm-control multicast 256
Device(config-if-ethernet-1/1)#storm-control broadcast 128
```

traffic-copy-to-cpu

To copy the packets that match an ACL to CPU, use the **traffic-copy-to-cpu** command in the global configuration mode. To remove the traffic copy configuration, use the **no** form of the command.

```
[no] traffic-copy-to-cpu { [ip-group {num | name} [subitem subitem] ] [link-group {num | name} [subitem subitem] ] }
```

ip-group {num name }	Specifies a standard or extended ACL.
link-group {num name }	Specifies a Layer 2 ACL.
subitem <i>subitem</i>	Specifies the sub item in the ACL.

Command Modes Global Configuration (config)

Command Default None

Example

The following example shows how to copy packets that match the subitem number 2 of ACL numbered 3 to CPU:

```
Device#configure terminal
Device(config)#traffic-copy-to-cpu ip-group 3 subitem 2
```

traffic-redirect

To redirect the messages sent to a port, use the **traffic-redirect** command in the global configuration mode. To remove the redirect configuration, use the **no** form of the command.

```
[no] traffic-redirect { [ip-group {num | name} [subitem subitem] ] [link-group {num | name} [subitem subitem] ] [interface interface-num | cpu] }
```

ip-group {num name }	Specifies a standard or extended ACL.
link-group {num name }	Specifies a Layer 2 ACL.
subitem <i>subitem</i>	Specifies the sub item in the ACL.
interface <i>interface-num</i>	Specifies the interface to which the traffic is redirected.
cpu	Specifies that the traffic is redirected to the CPU.

Command Modes Global Configuration (config)

Command Default None

Usage Guidelines Use the **traffic-redirect** command to forward the traffic to an egress port or a CPU, using the specified access control list (ACL) sub items.

Example

The following example shows how to redirect traffic to the ethernet 1/1 interface:

```
Device#configure terminal
Device(config)#traffic-redirect link-group link1 interface ethernet 1/1
```

traffic-statistic

To configure a device to collect traffic statistics, use the **traffic-statistic** command in in global configuration mode. To remove the traffic statistic configuration, use the **no** form of the command.

```
[no] traffic-statistic { [ip-group {num | name} [subitem subitem] ] [link-group {num | name} ] [subitem subitem] ] }
```

ip-group {num name }	Specifies a standard or extended ACL.
link-group {num name }	Specifies a Layer 2 ACL.
subitem <i>subitem</i>	Specifies the sub item in the ACL.

Command Modes Global Configuration (config)

Command Default None

Usage Guidelines Use this command to configure the device to collect traffic statistics. This command displays a cumulative value of the count of the number of packets that matched the ACL rule.

If you reconfigure traffic statistics, the previous information is lost.

Example

```
Device#configure terminal
Device(config)#traffic-statistic ip-group 3
```




PART **VII**

Security

- [Security](#), on page 273



Security

- [absolute time-range](#), on page 275
- [access-limit](#), on page 276
- [access-list match-order](#), on page 277
- [access-group](#), on page 278
- [access-list numbered standard](#), on page 279
- [access-list standard](#), on page 280
- [accounting-on](#), on page 281
- [acct-secret-key](#), on page 282
- [anti-dos ip fragment](#), on page 283
- [anti-dos ip ttl](#), on page 284
- [arp anti-spoofing](#), on page 285
- [arp anti-spoofing deny-disguiser](#), on page 286
- [arp anti-spoofing unknown](#), on page 287
- [arp anti-spoofing valid-check](#), on page 288
- [arp anti-flood](#), on page 289
- [channel-group spanning-tree cost](#), on page 291
- [clear cpu-classification](#), on page 292
- [clear cpu-statistics](#), on page 293
- [cpu-car](#), on page 294
- [dhcp anti-attack](#), on page 295
- [discard-bpdu](#), on page 297
- [access-list extended name](#), on page 298
- [access-list numbered extended](#), on page 299
- [host-guard bind ip](#), on page 301
- [ip route](#), on page 302
- [access-list link name](#), on page 303
- [access-list link number](#), on page 304
- [local-user](#), on page 306
- [nas-ipaddress](#), on page 307
- [no ip route static all](#), on page 308
- [periodic time-range](#), on page 309
- [preemption-time](#), on page 310
- [{primary-acct-ip | second-acct-ip}](#), on page 311

- {primary-auth-ip | second-auth-ip}, on page 312
- radius, on page 313
- realtime-account, on page 316
- no access-list , on page 317
- scheme, on page 318
- show access-list config, on page 319
- show access-list runtime, on page 320
- show anti-dos, on page 321
- show arp anti-flood, on page 322
- show arp anti interface, on page 324
- show cpu-car, on page 325
- show cpu-classification, on page 326
- show cpu-statistics, on page 327
- show cpu-utilization, on page 328
- show dhcp anti-attack, on page 329
- show discard-bpdu, on page 330
- show dot1x, on page 331
- show ip route, on page 336
- show radius, on page 337
- show shutdown-control interface, on page 339
- show spanning-tree interface, on page 340
- shutdown-control-recover, on page 342
- spanning-tree (global configuration), on page 343
- spanning-tree (interface configuration), on page 346
- time-range, on page 349
- username-format, on page 350

absolute time-range

To configure an absolute time range that specifies when an access control list (ACL) is in effect, use the **absolute** command in the time-range configuration mode. To remove the absolute time-range, use the **no** form of the command.

```
[no]absolute [start time-range] [endtime-range]
```

Syntax Description	<i>time-range</i>	Specifies the time in the format of HH:MM:SS YYYY/MM/DD
Command Modes	Global Configuration (config)	
Command Default	None	

Example

```
Device#configure terminal  
Device(config)#time-range weekends  
Device(config-timerange-weekends)#absolute start 04:50:30 2020/04/01 end 09:50:40 2020/04/30
```

access-limit

To enable or disable the number limit of authentication users in the domain and set the number limit of allowed users, use the **access-limit** command in AAA configuration mode.

access-limit { **enable** *allowed-user-number-limit* | **disable** }

Syntax Description	enable	allowed-user-number-limit	disable
	Enables the number limit of authentication users in the domain		
		Sets the number limit of allowed users in the domain. The range is from 1 to 640.	
			Disables the number limit of authentication users in the domain.

Command Modes AAA configuration (config-aaa)

Example

This example shows how to enable the number limit of authentication users in the domain and set the number limit of allowed users:

```
Device> enable
Device# configure terminal
Device(config)# aaa
Device(config-aaa)# domain eee
Device(config-aaa-domain-eee)# exit
Device(config-aaa)# default domain-name enable eee
Device(config-aaa)# domain eee
Device(config-aaa-domain-eee)# access-limit enable 3
Succeed to set MaxLinks of domain.
```

Example

This example shows how to disable the number limit of authentication users in the domain and set the number limit of allowed users:

```
Device> enable
Device# configure terminal
Device(config)# aaa
Device(config-aaa)# default domain-name enable eee
Succeed in setting default domain.
Device(config-aaa)# domain eee
Device(config-aaa-domain-eee)# access-limit disable
Succeed to disable access limit of domain.
```

access-list match-order

To configure the access control list (ACL) matching order, use the **access-list match-order** command in the global configuration mode. The matching order decides which rule is executed.

```
access-list acl-num match-order {auto | config}
```

Syntax Description	auto Matches the ACL rules according to the depth-first rule, wherein the longest subitem in a rule takes priority. The longest subset of a rule is matched first before the rule.
	config Matches the ACL rules according to the configuration order.
Command Default	None
Command Modes	Global configuration (config)
Usage Guidelines	An ACL consists of multiple permit or deny rules. The rules may overlap or conflict. In such cases, the matching order decides which rule is executed.

Example

```
Device#configure terminal
Device(config)#access-list 2 match-order config
```

access-group

To activate an access control list that is already defined, use the **access-group** command in the global configuration mode.

```
access-group [ip-group [name | number ] ] [link-group [name | number ] ] [subitem number]
```

Syntax Description

ip-group [*name* | *number*] Specifies a predefined Standard ACL or Extended ACL.

link-group [*name* | *number*] Specifies a predefined Layer 2 ACL.
]

subitem *number* Specifies the sub item number in the ACL

Command Modes

Global Configuration (config)

Command Default

None

Usage Guidelines

After defining an Access Control List (ACL), it has to be activated to take effect. Use the **access-group ip-group** command to activate a Standard ACL or an Extended ACL. Use the **access-group link-group** command to activate a Layer 2 ACL.

Example

The following example creates a standard access control list (ACL), 10, and activates the subitem number 1 of the ACL.

```
Device#configure terminal
Device(config)#access-list 10 deny any

Device(config)#access-list 10 permit 10.1.1.5 0
Device(config)#access-group ip-group 10
```

access-list numbered standard

To define a numbered Standard Access Control List (ACL), use the **access-list** *number* command in the global configuration mode.

```
access-list num{permit |deny} { source-ipv4 | ipv6-source-prefix | any | ipv6any}
[ time-range timerange-name]
```

Syntax Description

permit	Specifies that the rule defined by the ACL is permitted.
deny	Specifies that the rule defined by the ACL is not permitted.
<i>source-ipv4</i>	Specifies the IPv4 address of the source host.
<i>ipv6-source-prefix</i>	Specifies the IPv6 prefix of the source host.
ipv6any	Specifies any IPv6 host
any	Specifies any IPv4 host
time-range <i>timerange-name</i>	Defines the specific time range to implement the ACL.

Command Default

None

Command Modes

Global configuration (config)

Usage Guidelines

The ACL is identified by the number assigned to it. You can create an ACL and assign a number to it. If you don't specify a number, the system assigns a number to the created ACL. For a Standard ACL, the numbers range from 1 through 99. You can create up to 99 Standard ACLs.

Example

```
Device#configure terminal
Device(config)#access-list 10 permit any
```

access-list standard

To create a named Standard Access Control List, use the **access-list standard** command in the global configuration mode.

```
access-list standard {num|name} [ match-order { auto | config }]
```

Syntax Description

<i>num</i>	Specifies a standard ACL. Values can range from 1 through 99.
<i>name</i>	Specifies a name for the ACL. The name is a string of alphanumeric characters, upto 32 characters in length.
match-order	Defines a matching order for the entries in the ACL.
config	Matches the ACL rules according to the configuration order in the list.
auto	Matches the ACL rules according to the depth-first rule, wherein the longest subitem in a rule takes priority. The longest subset of a rule is matched first before the rule.

Command Default

None

Command Modes

Global configuration (config)

Example

```
Device#configure terminal
Device(config)#access-list standard stdacl
```


accounting-on

To configure accounting-on function, use the **accounting-on** command in AAA configuration mode.

accounting-on {**enable** *packet-number* | **disable**}

Syntax Description		
	enable	Enables accounting-on function.
	<i>packet-number</i>	The number of accounting-on packets sent. The range is 1 to 255.
	disable	Disables accounting-on function.

Command Modes AAA configuration (config-aaa)

Example

This example shows how to enable the accounting-on function:

```
Device> enable
Device# configure terminal
Device(config)# aaa
Device(config-aaa)# accounting-on enable 10
configure success
```

acct-secret-key

To configure the shared key of the secondary RADIUS server, use the **acct-secret-key** command in AAA configuration mode. To delete the configured shared key of the secondary RADIUS server, use the **no** form of the command.

acct-secret-key*key*

no acct-secret-key

Syntax Description*key*The shared secret key.

Command Modes

AAA Configuration (config-aaa)

Example

This example shows how to configure the shared key of a secondary RADIUS server using the **acct-secret-key** command:

```
Device> enable
Device# configure terminal
Device(config)# aaa
Device(config-aaa)# radius host radius1
Device(config-aaa-radius-radius1)# acct-secret-key 1
Modify secret key of RADIUS configuration successfully
```

anti-dos ip fragment

To configure a new threshold value for IP fragmentations, use the **anti-dos ip fragment** command in global configuration mode. To restore the default threshold value, use the **no** form of the command.

anti-dos ip fragment *threshold-value*

no anti-dos ip fragment

Syntax Description	<i>threshold-value</i>	The maximum number of allowed IP fragmentations. The range is 0 to 800. The default value is 800.
---------------------------	------------------------	---

Command Modes Global Configuration (config)

Example

This example shows how to configure a new threshold value for IP fragmentations using the **anti-dos ip fragment** command:

```
Device> enable
Device# configure terminal
Device(config)# anti-dos ip fragment 100
```

anti-dos ip ttl

To enable TTL monitoring and anti-TTL attack, use the **anti-dos ip ttl** command in global configuration mode. To disable TTL monitoring and anti-TTL attack, use the **no** form of the command.

anti-dos ip ttl

no anti-dos ip ttl

Command Default

Messages with TTL with a value of 0 are discarded.

Command Modes

Global Configuration (config)

Example

This example shows how to enable TTL monitoring using the **anti-dos ip ttl** command:

```
Device> enable
Device# configure terminal
Device(config)# anti-dos ip ttl
```

arp anti-spoofing

To enable ARP anti-spoofing, use the **arp anti-spoofing** command in global configuration mode. To disable ARP anti-spoofing, use the **no** form of the command.

arp anti-spoofing

no arp anti-spoofing

Command Modes

Global Configuration (config)

Example

This example shows how to enable ARP anti-spoofing using the **arp anti-spoofing** command:

```
Device> enable
Device# configure terminal
Device(config)# arp anti-spoofing
Device(config)#
```

arp anti-spoofing deny-disguiser

To enable ARP gateway anti-spoofing, use the **arp anti-spoofing deny-disguiser** command in global configuration mode. To disable ARP gateway anti-spoofing, use the **no** form of the command.

arp anti-spoofing deny-disguiser

no arp anti-spoofing deny-disguiser

Command Modes

Global Configuration (config)

Example

This example shows how to enable ARP gateway anti-spoofing using the **arp anti-spoofing deny-disguiser** command:

```
Device> enable
Device# configure terminal
Device(config)# arp anti-spoofing deny-disguiser
Device(config)#
```

arp anti-spoofing unknown

To enable ARP anti-spoofing and configure the device to flood or disable unknown packets, use the **arp anti-spoofing unknown** command in global configuration mode.

arp anti-spoofing unknown {flood | disable}

Syntax Description		
	flood	Floods the unknown packets.
	disable	Disables the unknown packets.

Command Modes Global Configuration (config)

Example

This example shows how to flood the unknown packets using the **arp anti-spoofing unknown flood** command:

```
Device> enable
Device# configure terminal
Device(config)# arp anti-spoofing unknown flood
Device(config)#
```

Example

This example shows how to disable the unknown packets using the **arp anti-spoofing unknown disable** command:

```
Device> enable
Device# configure terminal
Device(config)# arp anti-spoofing unknown disable
Device(config)#
```

arp anti-spoofing valid-check

To enable ARP anti-spoofing and configure source MAC address consistency inspection, use the **arp anti-spoofing valid-check** command in global configuration mode. To disable source MAC address consistency inspection, use the **no** form of the command.

arp anti-spoofing valid-check

no arp anti-spoofing valid-check

Command Modes

Global Configuration (config)

Example

This example shows how to enable source MAC address consistency inspection using the **arp anti-spoofing valid-check** command:

```
Device> enable
Device# configure terminal
Device(config)# arp anti-spoofing valid-check
Device(config)#
```


arp anti-flood

To enable ARP anti-flooding attack and configure its parameters on all ports, use the **arp anti-flood** command in global configuration mode.

To enable ARP anti-flooding attack and configure its parameters on a specific port, use the **arp anti-flood** command in interface configuration mode.

To disable ARP anti-flooding attack, use the **no** form of the command.

```
arp anti-flood [ [action {deny-all | deny-arp}] [threshold threshold-value] | recover {mac-address | all} | recover-time time]
```

```
no arp anti-flood [recover-time | threshold]
```

Syntax Description

action deny-all	Adds the host to a blackhole address list and discards all packets.
action deny-arp	Adds the host to a blackhole address list and discards only ARP packets.
threshold <i>threshold-value</i>	Configures the ARP anti-flood threshold value. The default value is 16 packets per second.
recover <i>mac-address</i>	Manually restores the host with the specified MAC address to transmit again.
recover all	Manually restores all the hosts to transmit again.
recover-time <i>time</i>	Defines the recovery time interval after which a host is allowed to transmit again. The recovery interval is 0 to 1440 minutes. The default value is 10 minutes.

Command Modes

Global configuration (config)
Interface configuration (config-if)

Example

This example shows how to configure ARP anti-flooding attack using the **arp anti-flood** command:

```
Device> enable
Device# configure terminal
Device(config)# arp anti-flood
Device(config)#
```

Example

This example shows how to add the host to a blackhole address list and discard all packets using the **arp anti-flood action deny-all** command:

```
Device> enable
Device# configure terminal
Device(config)# arp anti-flood action deny-all
Device(config)#
```

Example

This example shows how to configure ARP anti-flooding threshold value using the **arp anti-flood threshold *threshold-value*** command:

```
Device> enable
Device# configure terminal
Device(config)# arp anti-flood threshold 30
Device(config)#
```

Example

This example shows how to manually restore the host to transmit again using the **arp anti-flood recover** command:

```
Device> enable
Device# configure terminal
Device(config)# arp anti-flood recover 00:00:00:00:32:33
Device(config)#
```

Example

This example shows how to define the recovery time interval after which a host is allowed to transmit again using the **arp anti-flood recover-time *time*** command:

```
Device> enable
Device# configure terminal
Device(config)# arp anti-flood recover-time 100
Device(config)#
```

channel-group spanning-tree cost

To configure the path cost of an STP aggregation group, use the **channel-group *group-id* spanning-tree cost** command in global configuration mode. To restore the default path cost of an STP aggregation group, use the **no** form of the command.

channel-group *group-id* spanning-tree cost *path-cost*

no channel-group *group-id* spanning-tree cost

Syntax Description

<i>group-id</i>	The channel group ID. The range is 0 to 5.
<i>path-cost</i>	The path cost of the aggregation group. The range is 1 to 200000000.

Command Modes

Global configuration (config)

Example

This example shows how to configure the path cost of an aggregation group using the **channel-group *group-id* spanning-tree cost** command:

```
Device> enable
Device# configure terminal
Device(config)# channel-group 1 spanning-tree cost 2000
Device(config)#
```

clear cpu-classification

To clear the CPU packet classification statistics, run the **clear cpu-classification** command in global configuration mode.

clear cpu-classification interface {**ethernet** | **gpon**}*slot-number/port-number*

Syntax Description	<i>slot-number/port-number</i>	The port ID. <ul style="list-style-type: none"> • <i>slot-number</i>: <ul style="list-style-type: none"> • GPON: The value is 0. • GE Ethernet: The value is 1. • 10GE Ethernet: The value is 2. • <i>port-number</i>: <ul style="list-style-type: none"> • GPON: The range is from 1 to 8. • GE Ethernet: The range is from 1 to 4. • 10GE Ethernet: The range is from 1 to 2.
Command Default	None	
Command Modes	Global configuration (config)	

Example

This example shows how to clear the CPU packet classification statistics:

```
Device> enable
Device# configure terminal
Device(config)# clear cpu-classification interface ethernet 1/3
Clear packets sent to cpu classification statistics successfully
```

clear cpu-statistics

To clear the port statistics, use the **clear cpu-statistics** command in privileged EXEC and global configuration modes.

clear cpu-statistics

Command Default

None

Command Modes

Privileged EXEC (#)
Global configuration (config)

Examples

This example shows how to clear the port statistics.

```
Device> enable
Device# configure terminal
Device(config)# clear cpu-statistics
Clear packet sent to cpu statistic information successfully
```

cpu-car

To configure the CPU-car rate limit for packets, use the **cpu-car** command in global configuration mode. To restore the default CPU-car rate limit, use the **no** form of the command.

cpu-car *rate-limit*

no **cpu-car**

Syntax Description	<i>rate-limit</i>	
		Configures the CPU-car rate limit.
		The range is 1 to 10000 packets per second.
		The default value is 4000 packets per second.

Command Modes Global configuration (config)

Example

This example shows how to configure real time accounting using the **realtime-account** command:

```
Device> enable
Device# configure terminal
Device(config)# aaa
Device(config-aaa)# radius host radius1
Device(config-aaa-radius-radius1)# realtime-account interval 25
Modify realtime_acct configuration of radius server successfully.
```

dhcp anti-attack

To enable DHCP packet monitoring and configure the monitoring parameters on all ports, use the **dhcp anti-attack** command in global configuration mode.

To enable DHCP packet monitoring and configure the monitoring parameters on a specific port, use the **dhcp anti-attack** command in interface configuration mode.

To disable DHCP packet monitoring and restore the parameters to their default values, use the **no** form of the command.

```
dhcp anti-attack [[action {deny-all | deny-dhcp}] [threshold threshold-value] | [bind blackhole
| recover] {mac-address | all} | recover-time time]
```

```
no dhcp anti-attack [recover-time | threshold]
```

Syntax Description

action deny-all	Adds the host to a blackhole address list and discards all packets.
action deny-dhcp	Adds the host to a blackhole address list and discards only DHCP packets.
threshold <i>threshold-value</i>	Configures the rate threshold for DHCP packets globally. The default value is 16 packets per second.
bind blackhole <i>mac-address</i>	Binds the dynamic MAC address generated by DHCP with the static MAC address for the specified MAC address in the blackhole address list.
bind blackhole all	Binds the dynamic MAC address generated by DHCP with the static MAC address for all the MAC addresses in the blackhole address list.
recover <i>mac-address</i>	Manually restores the table items for the host with the specified MAC address.
recover all	Manually restores the table items for all the hosts .
recover-time <i>time</i>	Defines the recovery time interval. The recovery interval is 0 to 1440 minutes. The default value is 10 minutes.

Command Modes

Global configuration (config)
Interface configuration (config-if)

Example

This example shows how to configure DHCP packet monitoring using the **dhcp anti-attack** command:

```
Device> enable
Device# configure terminal
Device(config)# dhcp anti-attack
Device(config)#
```

Example

This example shows how to configure DHCP packet monitoring and discard all packets using the **dhcp anti-attack action deny-all** command:

```
Device> enable
Device# configure terminal
Device(config)# dhcp anti-attack action deny-all
Device(config)#
```

Example

This example shows how to configure the threshold value for DHCP packet globally using the **dhcp anti-attack threshold** command:

```
Device> enable
Device# configure terminal
Device(config)# dhcp anti-attack threshold 10
Device(config)#
```

Example

This example shows how to manually restore the table items for the host using the **dhcp anti-attack recover** command:

```
Device> enable
Device# configure terminal
Device(config)# dhcp anti-attack recover all
Device(config)#
```

Example

This example shows how to configure recovery time interval using the **dhcp anti-attack recover-time** command:

```
Device> enable
Device# configure terminal
Device(config)# dhcp anti-attack recover-time 100
Device(config)#
```


discard-bpdu

To enable the local discard of external BPDU messages, use the **discard-bpdu** command in global configuration mode. To disable the local discard of external BPDU messages, use the **no** form of the command.

discard-bpdu

no discard-bpdu

Command Modes

Global configuration (config)

Example

This example shows how to enable the local discard of external BPDU messages using the **discard-bpdu** command:

```
Device> enable
Device# configure terminal
Device(config)# discard-bpdu
Enable discard bpdu successfully.
```

access-list extended name

To create a named Extended Access Control List, use the **access-list extended** command in the global configuration mode.

```
access-list extended {num|name} [ match-order { auto | config }]
```

Syntax Description

<i>num</i>	Specifies an extended ACL. Values can range from 100 through 199.
<i>name</i>	Specifies a name for the ACL. The name is a string of alphanumeric characters, upto 32 characters in length.
match-order	Defines a matching order for the entries in the ACL.
config	Matches the ACL rules according to the configuration order in the list.
auto	Matches the ACL rules according to the depth-first rule, wherein the longest subitem in a rule takes priority. The longest subset of a rule is matched first before the rule.

Command Default

None

Command Modes

Global configuration (config)

Example

```
Device#configure terminal
Device(config)#access-list extended extacl match-order auto
```

access-list numbered extended

To define a numbered Extended Access Control List (ACL), use the **access-list number** command in the global configuration mode.

```
access-list number {permit |deny} [protocol ] [established] { source-ipv4 |
ipv6-source-prefix | any | ipv6any}[source-port-wildcard]{ dest-ipv4 | ipv6-dest-prefix | any
| ipv6any}[dest-port-wildcard][ icmp type icmp-code][igmp-type] [ traffic-class traffic-class
][ precedence precedence ][ tos tos ][ dscp dscp][ fragments ][ time-range
time-range ]
```

Syntax Description		
permit		Specifies that the rule defined by the ACL is permitted.
deny		Specifies that the rule defined by the ACL is not permitted.
<i>protocol</i>		Specifies the type of Layer 2 protocol. It is in the range of 1 through 255 by number. Select from GRE, ICMP, IGMP, IPinIP, OSPF, TCP, UDP, and ICMPv6 to specify the protocol by name.
established		Defines the SYN flag in TCP. A value 1 indicates that the flag is active. This is applicable only if the <i>protocol</i> is tcp.
<i>source-ipv4</i>		Specifies the IPv4 address of the source host.
<i>ipv6-source-prefix</i>		Specifies the IPv6 prefix of the source host.
ipv6any		Specifies any IPv6 host
<i>dest-ipv4</i>		Specifies the IPv4 address of the destination host.
<i>ipv6-dest-prefix</i>		Specifies the IPv6 prefix of the destination host.
any		Specifies any host.
<i>icmp type icmp-code</i>		Specifies the type of ICMP protocol packet. It is valid only when protocol is configured as icmp or icmpv6 .
<i>igmp-type</i>		Specifies the type of IGMP protocol packet. It is valid only when protocol is configured as igmp .
traffic-class		Specifies the traffic class for IPv6.
precedence		Specifies the precedence priority. IP precedence ranges from 0 through 7.
tos		Specifies the Type of Service (ToS) priority. The values range from 0 through 15.
dscp		Specifies the Differentiated Services Code Point (DSCP) priority value.
fragments		Specifies that the ACL rule is valid for non-first fragmented packets. This helps prevent fragment packet attacks.

time-range*timerange-name* Defines the specific time range to implement the ACL.

Command Default None

Command Modes Global configuration (config)

Usage Guidelines The ACL is identified by the number assigned to it. You can create an ACL and assign a number to it. If you don't specify a number, the system assigns a number to the created ACL. For an Extended ACL, the numbers range from 100 through 199. You can create up to 100 Extended ACLs.

Example

```
Device#configure terminal
Device(config)#access-list 101 permit tcp 10.0.0.1 0 ftp any
```

host-guard bind ip

To configure host protection on a port, use the **host-guard bind ip** command in global configuration mode. To disable host protection on a port, use the **no** form of the command.

host-guard bind ip *ip-address* **interface ethernet** *slot_number/port_number* **[[to ethernet**
slot_number/port_number]

no host-guard bind ip *ip-address* **interface ethernet** *slot_number/port_number* **[[to ethernet**
slot_number/port_number]

Syntax Description

to	Displays the information for a range of ports. If you use the to keyword, specify the same port type before and after the keyword.
<i>slot-number/port-number</i>	The port ID. <ul style="list-style-type: none"> • <i>slot-number</i>: <ul style="list-style-type: none"> • GPON: The value is 0. • GE Ethernet: The value is 1. • 10GE Ethernet: The value is 2. • <i>port-number</i>: <ul style="list-style-type: none"> • GPON: The range is from 1 to 8. • GE Ethernet: The range is from 1 to 4. • 10GE Ethernet: The range is from 1 to 2.

Command Modes

Global configuration (config)

Example

This example shows how to configure host protection on a port using the **host-guard bind ip** command:

```
Device> enable
Device# configure terminal
Device(config)# host-guard bind ip 10.10.10.1 interface ethernet 1/3
Add host guard entry successfully.
```

ip route

To add a static IP route to the routing table, use the **ip route** command in the global configuration mode. To remove a static IP route from the routing table, use the **no** form of the command.

ip route *dest-ip mask [gate-ip]*

no ip route *dest-ip mask [gate-ip]*

Syntax Description		
	<i>dest-ip</i>	The destination address of the static route that needs to be added.
	<i>mask</i>	The mask of the destination address.
	<i>gate-ip</i>	The next-hop address of the static route.

Command Modes Global configuration (config)

Example

This example shows how to add a static IP route to the routing table using the **ip route** command:

```
Device> enable
Device# configure terminal
Device(config)# ip route 10.10.10.10 255.255.0.0 10.0.11.254
```

access-list link name

To create a named Layer 2 Access Control List (ACL), use the **access-list link** command in the global configuration mode.

```
access-list link {num|name} [ match-order { auto | config } ]
```

Syntax Description

<i>num</i>	Specifies an extended ACL. Values can range from 200 through 299.
<i>name</i>	Specifies a name for the ACL. The name is a string of alphanumeric characters, upto 32 characters in length.
match-order	Defines a matching order for the entries in the ACL.
config	Matches the ACL rules according to the configuration order in the list.
auto	Matches the ACL rules according to the depth-first rule, wherein the longest subitem in a rule takes priority. The longest subset of a rule is matched first before the rule.

Command Default

None

Command Modes

Global configuration (config)

Example

```
Device#configure terminal  
Device(config)#access-list link laye2acl match-order auto
```

access-list link number

To define a numbered Layer 2 Access Control List (ACL), use the **access-list number** command in the global configuration mode.

```
access-list number {permit |deny} [protocol] [cos vlan-priority] ingress { {
[inner-vid] [start-vlan-id end-vlan-id] [source-mac-addr source-mac-wildcard] [interface
interface-number] } |any } egress { { [dest-mac-addr dest-mac-wildcard] [interface
interface-num | cpu] } | any} [ time-range time-range ]
```

Syntax Description		
permit		Specifies that the rule defined by the ACL is permitted.
deny		Specifies that the rule defined by the ACL is not permitted.
<i>protocol</i>		Specifies the type of protocol packet carried by the Ethernet frame. In hexadecimal notation, the range is 0 through FFFF. It is optional in case of ARP, IP, RARP.
cos		Defines the SYN flag in TCP. A value 1 indicates that the flag is active. This is applicable only if the <i>protocol</i> is tcp.
ingress		Specifies the rule for the incoming packets at the ingress port.
inner-vid		Specifies the inner VLAN ID of a double-tagged packet.
<i>start-vlan-id end-vlan-id</i>		Specifies the range of VLANs. For a double-tagged packet, it is the VLAN ID of the outer tag.
<i>source-mac-addr</i> <i>source-mac-wildcard</i>		Specifies the source MAC address options. <i>source-mac-wildcard</i> indicates the source MAC range.
interface <i>interface-num</i>		Specifies the physical port number. It can be either the ingress port or the egress port.
CPU		Indicates that the data will be forwarded to the CPU.
any		Specifies any address which can be at ingress or egress directions.
time-range <i>name</i>		Specifies the time range in which the ACL rule takes effect.
time-range <i>timerange-name</i>		Defines the specific time range to implement the ACL.

Command Default None

Command Modes Global configuration (config)

Usage Guidelines The ACL is identified by the number assigned to it. You can create an ACL and assign a number to it. If you don't specify a number, the system assigns a number to the created ACL. For an Extended ACL, the numbers range from 200 through 299. You can create up to 100 Layer 2 ACLs.

Example

```
Device# configure terminal  
Device(config)# access-list 201 permit arp ingress 00:00:00:00:01:01 0 egress any
```

local-user

To configure a local user, use the **local-user** command in the AAA configuration mode. To delete all local users, use the **no** form of the command.

local-user username *username* **password** *password* [**vlan** *vlan-id*]

no local-user {**all** | **user** *username*}

Syntax Description		
	<i>username</i>	Username of the local user.
	<i>password</i>	Password of the local user.
	<i>vlan-id</i>	The VLAN ID. The range is 1 to 4094.

Command Modes AAA configuration (config-aaa)

Example

This example shows how to configure a local user using the **local-user** command:

```
Device> enable
Device# configure terminal
Device(config)# aaa
Device(config-aaa)# local-user username name1 password pass1 vlan 220
Device(config-aaa)#
```

nas-ipaddress

To configure the NAS client IP address for a RADIUS server, use the **nas-ipaddress** command in AAA configuration mode. To delete the configured NAS client IP address for a RADIUS server, use the **no** form of the command.

nas-ipaddress *ip-address*

no nas-ipaddress

Syntax Description

ip-address

IP address of RADIUS client.

Command Modes

AAA configuration (config-aaa)

Example

This example shows how to configure the NAS client IP address for a RADIUS server:

```
Device> enable
Device# configure terminal
Device(config)# aaa
Device(config-aaa)# radius host radius1
Device(config-aaa-radius-radius1)# nas 10.1.1.10
```

no ip route static all

To delete all static IP routes from the routing table, use the **no ip route static all** command in global configuration mode.

no ip route static all

Command Modes

Global configuration (config)

Example

This example shows how to delete all static IP routes from the routing table using the **no ip route static all** command:

```
Device> enable
Device# configure terminal
Device(config)# no ip route static all
```

periodic time-range

To configure a time period that specifies when an access control list (ACL) is in effect, use the **periodic** command in the time-range configuration mode. To remove the absolute time-range, use the **no** form of the command.

```
[no]periodic [days-of-week] HH:MM:SS to [days-of-week ] HH:MM:SS
```

Syntax Description	<i>days-of-week</i>	Specifies the period, which are the days of the week: mon, tue, wed, thu, fri, sat, sun, weekdays , daily weekdays are Monday to Friday.
	<i>HH:MM:SS</i>	Specifies the time in <i>hours:minutes:seconds</i> format.
Command Modes	Global Configuration (config)	
Command Default	None	

Example

```
Device#configure terminal
Device(config)#time-range days
Device(config-timerange-days)#periodic daily 04:50:30 to 09:50:40
```

preemption-time

To configure the recovery time to switch to the primary server, use the **preemption-time** command in AAA configuration mode.

preemption-time *time*

Syntax Description	<i>time</i>	The preemption time The unit in minutes. The range is from 0 to 1440. The default value is 0
--------------------	-------------	--

Command Modes AAA configuration (config-aaa)

Usage Guidelines Use this command in the AAA configuration mode.

Examples This example shows how to configure the recovery time to switch to the primary server.

```
Device> enable
Device# configure terminal
Device(config)# aaa
Device(config-aaa)# radius host radius1
Device(config-aaa-radius-radius1)# preemption-time 200
```

Related Commands

Command	Description
aaa	Enters AAA configuration mode

{primary-acct-ip | second-acct-ip}

To configure the primary and secondary accounting servers, use the **{primary-acct-ip | second-acct-ip}** *ip_address port* command in AAA configuration mode. To disable the configured primary and secondary accounting servers, use the **no** form of the command.

{primary-acct-ip | second-acct-ip} *ip_address port*

no **{primary-acct-ip | second-acct-ip}**

Syntax Description

primary-acct-ip	The primary accounting server.
second-acct-ip	The secondary accounting server.
<i>ip_address</i>	The IP address of the server.
<i>port</i>	The accounting port The range is from 1 to 65535.

Command Modes

AAA configuration (config-aaa)

Examples

This example shows how to configure the primary and secondary accounting server.

```
Device> enable
Device# configure terminal
Device(config)# aaa
Device(config-aaa)# radius host radius1
Device(config-aaa-radius-radius1)# primary-acct-ip 10.1.1.10 333
Device(config-aaa-radius-radius1)# second-acct-ip 10.1.1.11 350
```

{primary-auth-ip | second-auth-ip}

To configure the primary and secondary RADIUS servers, use the **{primary-auth-ip | second-auth-ip}** *ip_address port* command in AAA configuration mode. To disable the configured primary and secondary RADIUS servers, use the **no** form of the command.

{primary-auth-ip | second-auth-ip} *ip_address port*

no **{primary-auth-ip | second-auth-ip}**

Syntax Description		
	primary-auth-ip	The primary RADIUS server.
	second-auth-ip	The secondary RADIUS server.
	<i>ip_address</i>	The IP address of the server.
	<i>port</i>	The server port The range is from 1 to 65535.

Command Default None

Command Modes AAA configuration (config-aaa)

Examples

This example shows how to configure the primary and secondary accounting server

```
Device> enable
Device# configure terminal
Device(config)# aaa
Device(config-aaa)# radius host radius1
Device(config-aaa-radius-radius1)# primary-auth-ip 10.2.1.10 80
Device(config-aaa-radius-radius1)# second-auth-ip 10.2.1.11 90
```


radius

To configure the RADIUS server parameters, use the **radius** command in AAA configuration mode. To restore the default RADIUS server settings, use the **no** version of the command.

```
radius {8021p enable | accounting | attribute client-version | bandwidth-limit enable |
config-attribute {access-bandwidth {downlink vendor-type | unit {bps | kbps} |
uplink vendor-type} | dscp vendor-type | mac-address-number vendor-type} | host host-name |
mac-address-number enable | server-disconnect drop1x | vlan enable}
```

```
no radius {8021p | accounting | attribute client-version | bandwidth-limit enable | host
host-name | mac-address-number | server-disconnect drop1x | vlan}
```

Syntax Description		
8021p enable		Configures RADIUS to distribute port priority.
accounting		Enables accounting function.
attribute client-version		Send the H3C client's version to radius server.
bandwidth limit-enable		Configures RADIUS to distribute bandwidth control.
config-attribute		Configures the RADIUS attribute types with the vendor's attributes.
access-bandwidth		Configures the RADIUS access bandwidth attribute.
downlink		Configures the RADIUS downlink attribute.
uplink		Configures the RADIUS uplink attribute.
unit bps		Configures the RADIUS ACL bandwidth in units of bits per second.
unit kbps		Configures the RADIUS ACL bandwidth in units of kilobits per second.
dscp		Configures the RADIUS DSCP attribute.
config-attribute mac-address-number		Configures the maximum MAC address on the port that is learned for the RADIUS server.
<i>vendor-type</i>		The vendor type. The range is from 1 to 500.
mac-address-number enable		Configures RADIUS to distribute number limit of MAC address.
host <i>host-name</i>		Creates a RADIUS scheme and enters RADIUS scheme mode for the specified host name.
server-disconnect drop1x		Configures the device to shut the user down if the accounting packet does not respond.

vlan enable	Configures RADIUS to distribute port PVID.
--------------------	--

Command Modes

AAA configuration (config-aaa)

Example

This example shows how to configure RADIUS to distribute port priority:

```
Device> enable
Device# configure terminal
Device(config)# aaa
Device(config-aaa)# radius 8021p enable
Configure successfully.
```

Example

This example shows how to enable accounting function:

```
Device> enable
Device# configure terminal
Device(config)# aaa
Device(config-aaa)# radius accounting
Modify accounting configuration of radius server successfully.
```

Example

This example shows how to send the H3C client's version to radius server:

```
Device> enable
Device# configure terminal
Device(config)# aaa
Device(config-aaa)# radius attribute client-version
Device(config-aaa)#
```

Example

This example shows how to configure RADIUS to distribute bandwidth control:

```
Device> enable
Device# configure terminal
Device(config)# aaa
Device(config-aaa)# radius bandwidth limit-enable
Configure successfully.
```

Example

This example shows how to configure the RADIUS access bandwidth and downlink attribute:

```
Device> enable
Device# configure terminal
Device(config)# aaa
Device(config-aaa)# radius config-attribute access-bandwidth downlink 400
Configure successfully.
```

Example

This example shows how to configure the RADIUS DSCP attribute:

```
Device> enable
Device# configure terminal
Device(config)# aaa
Device(config-aaa)# radius config-attribute dscp 1
Configure successfully.
```

Example

This example shows how to create a RADIUS scheme and enters RADIUS scheme mode:

```
Device> enable
Device# configure terminal
Device(config)# aaa
Device(config-aaa)# radius host hostname1
Device(config-aaa-radius-hostname1)#
```

Example

This example shows how to configure RADIUS to distribute number limit of MAC address:

```
Device> enable
Device# configure terminal
Device(config)# aaa
Device(config-aaa)# radius mac-address-number enable
Configure successfully.
```

Example

This example shows how to shut the user down if the accounting packet does not respond:

```
Device> enable
Device# configure terminal
Device(config)# aaa
Device(config-aaa)# radius server-disconnect drop 1x
Configure successfully.
```

Example

This example shows how to configure RADIUS to distribute port PVID:

```
Device> enable
Device# configure terminal
Device(config)# aaa
Device(config-aaa)# radius vlan enable
Configure successfully.
```

realtime-account

To configure realtime accounting and its time interval, use the **realtime-account** command in AAA configuration mode. To disable realtime accounting, use the **no** form of the command.

realtime-account interval *time*

no realtime-account

Syntax Description	interval <i>time</i>	Configures the realtime accounting time interval. The range is 1 to 255 minutes.
--------------------	----------------------	---

Command Modes AAA configuration (config-aaa)

Example

This example shows how to configure real time accounting using the **realtime-account** command:

```
Device> enable
Device# configure terminal
Device(config)# aaa
Device(config-aaa)# radius host radius1
Device(config-aaa-radius-radius1)# realtime-account interval 25
Modify realtime_acct configuration of radius server successfully.
```

no access-list

To remove an entry or all entries from the Access Control List (ACL), use the **no access-list** command in the global configuration mode.

```
no access-list {number| name |all}
```

Syntax Description	<i>number</i> Specifies that numbered ACL to delete
	<i>name</i> Specifies the name of the ACL to delete.

Command Default	None
------------------------	------

Command Modes	Global configuration (config)
----------------------	-------------------------------

Example

```
Device#configure terminal  
Device(config)#no access-list 10
```

scheme

To configure the server authentication scheme, use the **scheme** command in AAA configuration mode.

```
scheme {local | radius [local] }
```

Syntax Description	local	radius	radius local
	Configures to use local user authentication.	Configures to use RADIUS server authentication.	Configures to use local user authentication if RADIUS server authentication fails.

Command Modes AAA configuration (config-aaa)

Example

This example shows how to configure a server authentication scheme using the **scheme** command:

```
Device> enable
Device# configure terminal
Device(config)# aaa
Device(config-aaa)# domain eee
Device(config-aaa-domain-eee)# scheme radius
Device(config-aaa-domain-eee)#
```

show access-list config

To display the Access Controlled List (ACL) configurations, use the **show access-list config** command in the EXEC mode

```
show access-list config {number | all | name | statistic }
```

Syntax Description		
	<i>number</i>	Specifies the numbered ACL. Numbers 1 to 99 represent standard ACL. Numbers 100 to 199 represent extended ACL. Numbers 200 to 299 represent Layer 2 ACL.
	all	Specifies all ACLs.
	name	Specifies an ACL by name.
	statistic	Specifies ACL statistics.

Command Modes EXEC

Command Default None

Usage Guidelines Use the **show access-list config statistic** command to see the statistics of the ACL rules usage.
Use the **show access-list config name** command to see the ACL specified by name.
Use the **show access-list config all** command to all see the ACLs.

Examples

```
Device> enable
Device# show access-list config 1
Standard IP Access List 1, match-order is config, 2 rule:
 0 deny any
permit 1.1.1.1 0.0.0.0
```

show access-list runtime

To display the Access Controlled List (ACL) at run time, use the **show access-list runtime** command in the EXEC mode

show access-list runtime {*number* | **all** | **name** | **statistic** }

Syntax Description		
<i>number</i>		Specifies the numbered ACL. Numbers 1 to 99 represent standard ACL. Numbers 100 to 199 represent extended ACL. Numbers 200 to 299 represent Layer 2 ACL.
all		Specifies all ACLs.
name		Specifies an ACL by name.
statistic		Specifies ACL statistics.

Command Modes EXEC

Command Default None

Usage Guidelines Use the **show access-list runtime statistic** command to see the statistics of the ACL rules usage.
Use the **show access-list runtime name** command to see the ACL specified by name.
Use the **show access-list runtime all** command to all see the ACLs.

Examples

```
Device> enable
Device# show access-list runtime 1
Standard IP Access List 1, match-order is config, 1 rule:
 0 deny any
```


show anti-dos

To display the anti-DDOS configuration information, use the **show anti-dos** command in privileged EXEC or global configuration modes.

show anti-dos

Command Modes

Privileged EXEC (#)
Global Configuration (config)

Example

This example shows a sample output for the **show anti-dos** command:

```
Device> enable
Device# configure terminal
Device(config)# show anti-dos
Informations of AntiDos:
Ip fragment max number:800
Ip fragment number now:0
TTL=0 packet traffic to CPU is disable.
```

show arp anti-flood

To display the ARP anti-flood configuration and attackers list, use the **show arp anti-flood** command in privileged EXEC or global configuration modes.

```
show arp anti-floodport-threshold [{ethernet | gpon} slot-number/port-number [to {ethernet | gpon} slot-number/port-number ] ]
```

Syntax Description

slot-number/port-number

The port ID.

- *slot-number*:
 - GPON: The value is 0.
 - GE Ethernet: The value is 1.
 - 10GE Ethernet: The value is 2.
- *port-number*:
 - GPON: The range is from 1 to 8.
 - GE Ethernet: The range is from 1 to 4.
 - 10GE Ethernet: The range is from 1 to 2.

to

Displays the information for a range of ports. If you use the **to** keyword, specify the same port type before and after the keyword.

Command Modes

Privileged EXEC (#)
Global Configuration (config)

Example

This example shows a sample output for the **show arp anti-flood** command:

```
Device> enable
Device# configure terminal
Device(config)# show arp anti-flood
Arp anti-flood: disabled
Arp rate limit:25pps
User recovery time:234 minutes
Reject type:DenyAll
DeniedSrcMAC      SourceIP      Port      Vlan  DenyType  RemainAgingTime (m)

Total entry:0.
```

Example

This example shows a sample output for the **show arp anti-flood port-threshold** command:

```
Device> enable
Device# configure terminal
Device(config)# show arp anti-flood port-threshold
Arp anti-flood: disabled
Arp rate limit:25pps
User recovery time:234 minutes
Reject type:DenyAll
Port          Port-threshold
g0/1          16
g0/2          16
g0/3          16
g0/4          16
g0/5          16
g0/6          16
g0/7          16
g0/8          16
e1/1          16
e1/2          16
e1/3          16
e1/4          16
e2/1          16
e2/2          16
```

show arp anti interface

To display the state of the interface, use the **show arp anti interface** command in privileged EXEC or global configuration modes.

show arp anti interface [{**ethernet** | **gpon**} *slot-number/port-number*]

Syntax Description

slot-number/port-number

The port ID.

- *slot-number*:
 - GPON: The value is 0.
 - GE Ethernet: The value is 1.
 - 10GE Ethernet: The value is 2.
- *port-number*:
 - GPON: The range is from 1 to 8.
 - GE Ethernet: The range is from 1 to 4.
 - 10GE Ethernet: The range is from 1 to 2.

Command Modes

Privileged EXEC (#)
Global Configuration (config)

Example

This example shows a sample output for the **show arp anti interface** command:

```
Device> enable
Device# configure terminal
Device(config)# show arp anti interface
Port          mode          threshold(anti-flood)
g0/1          untrust      -
g0/2          untrust      -
g0/3          untrust      -
g0/4          untrust      -
g0/5          untrust      -
g0/6          untrust      -
g0/7          untrust      -
g0/8          untrust      -
e1/1          untrust      -
e1/2          untrust      -
e1/3          untrust      -
e1/4          untrust      -
e2/1          untrust      -
e2/2          untrust      -
```

show cpu-car

To display the CPU-car performance, use the **show cpu-car** command in privileged EXEC or global configuration modes.

show cpu-car

Command Modes

Privileged EXEC (#)
Global Configuration (config)

Example

This example shows a sample output for the **show cpu-car** command:

```
Device> enable
Device# configure terminal
Device(config)# show cpu-car
Send packet to cpu rate = 4000 pps.
```

show cpu-classification

To display CPU receiving packet classification statistics, run the **show cpu-classification** command in privileged EXEC or global configuration modes.

show cpu-classification [**interface** {**ethernet** | **gpon**}*slot-number/port-number*]

Syntax Description

slot-number/port-number

The port ID.

- *slot-number*:

- GPON: The value is 0.
- GE Ethernet: The value is 1.
- 10GE Ethernet: The value is 2.

- *port-number*:

- GPON: The range is from 1 to 8.
- GE Ethernet: The range is from 1 to 4.
- 10GE Ethernet: The range is from 1 to 2.

Command Default

None

Command Modes

Privileged EXEC(#)
Global Configuration(config)

Examples

This example shows how to view CPU receiving packet classification statistics.

```
Device> enable
Device# configure terminal
Device(config)# show cpu-classification
Type          Count      Percent (%)
Total         460699064  100

BFDU          8237424    1

ARP           378164060  82

IGMP          607189     0
ICMP          699125     0
OSPF          0           0
RIP           139        0
DHCP          12658100   2

SNMP          4079818    0

Telnet        122166     0
SSH           10788      0
Other         56120236   12
```

show cpu-statistics

To display CPU receiving packet port statistics, use the **show cpu-statistics** command in privileged EXEC and global configuration modes.

show cpu-statistics [**channel-group** *channel-group-number* | {**gpon** | **ethernet**}*slot-number/port-number*] [**to**{**channel-group** *channel-group-number* | {**gpon** | **ethernet**}*slot-number/port-number*}]

Syntax Description	channel-group <i>channel-group-number</i>	The LACP channel group.
	<i>slot-number/port-number</i>	The port ID. <ul style="list-style-type: none"> • <i>slot-number</i>: <ul style="list-style-type: none"> • GPON: The value is 0. • GE Ethernet: The value is 1. • 10GE Ethernet: The value is 2. • <i>port-number</i>: <ul style="list-style-type: none"> • GPON: The range is from 1 to 8. • GE Ethernet: The range is from 1 to 4. • 10GE Ethernet: The range is from 1 to 2.
	to	Displays the information for a range of ports. If you use the to keyword, specify the same port type before and after the keyword.

Command Default None

Command Modes Privileged EXEC (#)
Global configuration (config)

Examples This example shows how to view CPU receiving packet port statistics.

```
Device> enable
Device# configure terminal
Device(config)# show cpu-statistics ethernet 1/1
Show packets sent to cpu statistic information
port 64Byte 128Byte 256Byte 512Byte 1024Byte 2048Byte
e1/1 0 0 0 0 0 0
```

show cpu-utilization

To display CPU utilization, use the **show cpu-utilization** command in global configuration mode.

show cpu-utilization

Command Default None

Command Modes Global configuration (config)

Examples This example shows how to view CPU utilization.

```
Device> enable
Device# configure terminal
Device(config)# show cpu-utilization
CPU Information:
CPU Idle : 79 %
```


show dhcp anti-attack

To display the DHCP anti-attack configuration, use the **show dhcp anti-attack** command in privileged EXEC and global configuration modes.

```
show dhcp anti-attack [interface{ethernet | gpon} slot-number/port-number [to {ethernet | gpon} slot-number/port-number ] ]
```

Syntax Description		
to		Displays the information for a range of ports. If you use the to keyword, specify the same port type before and after the keyword.
<i>slot-number/port-number</i>		The port ID. <ul style="list-style-type: none"> • <i>slot-number</i>: <ul style="list-style-type: none"> • GPON: The value is 0. • GE Ethernet: The value is 1. • 10GE Ethernet: The value is 2. • <i>port-number</i>: <ul style="list-style-type: none"> • GPON: The range is from 1 to 8. • GE Ethernet: The range is from 1 to 4. • 10GE Ethernet: The range is from 1 to 2.

Command Modes

Privileged EXEC (#)
Global Configuration (config)

Example

This example shows a sample output for the **show dhcp anti-attack** command:

```
Device> enable
Device# configure terminal
Device(config)# show dhcp anti-attack
Dhcp anti-attack: enabled
Dhcp rate limit:1pps
User recovery time:3 minutes
Reject type:DenyDHCP
DeniedSrcMAC Port Vlan DenyType RemainAgingTime(m)
00:00:00:01:11:23 e1/1 2 DenyDHCP 3
Total entry: 1.
#After 3 minutes, the attack entry is aged out
```

show discard-bpdu

To display the BPDU status, use the **show discard-bpdu** command in privileged EXEC and global configuration modes.

show discard-bpdu

Command Modes

Privileged EXEC (#)
Global Configuration (config)

Example

This example shows a sample output for the **show discard-bpdu** command:

```
Device> enable
Device# configure terminal
Device(config)# show discard-bpdu
Discard BPDU global status: disable
Discard BPDU enable port:
```

Notes: Once global status is on, the switch will discard all BPDUs.
If want to enable on some ports only, need to disable global function and choose another commands.

show dot1x

To display the 802.1x authentication function details, run the **show dot1x** command in privileged EXEC and global configuration modes.

```
show dot1x [[daemon | detect | eapol-relay | guest-vlan] [interface {ethernet | gpon}
slot-number/port-number] [to {ethernet | gpon} slot-number/port-number] | max-reauth |
max-req | port-auth | quiet-period-value | session [interface {ethernet | gpon}
slot-number/port-number] [to {ethernet | gpon} slot-number/port-number] | mac-address
mac-address-value ] ]
```

Syntax	Description
daemon	Displays the configuration of 802.1x authentication interface watch function.
detect	Displays heartbeat detection configuration.
eapol-relay	Displays EAPOL pass through configuration.
guest-vlan	Displays guest VLAN information.
interface	Displays interface configuration, such as the interface control mode, re-authentication state, the maximum number of users for the interface authentication.
<i>slot-number/port-number</i>	The port ID. <ul style="list-style-type: none"> • <i>slot-number</i>: <ul style="list-style-type: none"> • GPON: The value is 0. • GE Ethernet: The value is 1. • 10GE Ethernet: The value is 2. • <i>port-number</i>: <ul style="list-style-type: none"> • GPON: The range is from 1 to 8. • GE Ethernet: The range is from 1 to 4. • 10GE Ethernet: The range is from 1 to 2.
to	Displays the information for a range of ports. If you use the to keyword, specify the same port type before and after the keyword.
max-reauth	Displays information about maximum count of the EAP requests and identity packets sent by the server.
max-req	Displays information about the maximum count of the EAP requests sent by the server.

port-auth	Displays whether the interface authentication is enabled or disabled.
quiet-period-value	Displays the quiet period.
session	Displays 802.1x session.
mac-address <i>mac-address-value</i>	Displays 802.1x session information for the specified MAC address.

Command Modes

Privileged EXEC (#)
Global Configuration (config)

Example

This example shows the sample output for the **show dot1x daemon**

```
Device> enable
Device# configure terminal
Device(config)# show dot1x daemon
port  daemonstatus  daemontime(s)
g0/1  close          60
g0/2  close          60
g0/3  close          60
g0/4  close          60
g0/5  close          60
g0/6  close          60
g0/7  close          60
g0/8  close          60
e1/1  close          60
e1/2  close          60
e1/3  close          60
e1/4  close          60
e2/1  close          60
e2/2  close          60
```

Example

This example shows the sample output for the **show dot1x detect**

```
Device> enable
Device# configure terminal
Device(config)# show dot1x detect
the user detect interval is 25
port : detect
g0/1 : disable
g0/2 : disable
g0/3 : disable
g0/4 : disable
g0/5 : disable
g0/6 : disable
g0/7 : disable
g0/8 : disable
e1/1 : disable
e1/2 : disable
e1/3 : disable
e1/4 : disable
e2/1 : disable
```

```
e2/2 : disable  
Total [14] item(s), printed [14] item(s).
```

Example

This example shows the sample output for the **show dot1x eapol-relay**

```
Device> enable  
Device# configure terminal  
Device(config)# show dot1x eapol-relay  
Port  EapolRelay  EapolRelayUplink  
g0/1  disabled   false  
g0/2  disabled   false  
g0/3  disabled   false  
g0/4  disabled   false  
g0/5  disabled   false  
g0/6  disabled   false  
g0/7  disabled   false  
g0/8  disabled   false  
e1/1  disabled   false  
e1/2  disabled   false  
e1/3  disabled   false  
e1/4  disabled   false  
e2/1  disabled   false  
e2/2  disabled   false  
  
Total entries: 14.
```

Example

This example shows the sample output for the **show dot1x guest-vlan**

```
Device> enable  
Device# configure terminal  
Device(config)# show dot1x guest-vlan  
Port  GuestVlan  Status  
g0/1  disable   InConfigVlan  
g0/2  disable   InConfigVlan  
g0/3  disable   InConfigVlan  
g0/4  disable   InConfigVlan  
g0/5  disable   InConfigVlan  
g0/6  disable   InConfigVlan  
g0/7  disable   InConfigVlan  
g0/8  disable   InConfigVlan  
e1/1  44        InConfigVlan  
e1/2  disable   InConfigVlan  
e1/3  disable   InConfigVlan  
e1/4  disable   InConfigVlan  
e2/1  disable   InConfigVlan  
e2/2  disable   InConfigVlan  
  
Total entries: 14.
```

Example

This example shows the sample output for the **show dot1x interface**

```
Device> enable
Device# configure terminal
Device(config)# show dot1x interface ethernet 1/3
Authentication of system: disabled
Type of authentication: eap-finish

Total [0] item(s).
```

Example

This example shows the sample output for the **show dot1x max-reauth**

```
Device> enable
Device# configure terminal
Device(config)# show dot1x max-reauth
the max-reauth is 2.
```

Example

This example shows the sample output for the **show dot1x max-req**

```
Device> enable
Device# configure terminal
Device(config)# show dot1x max-req
the max-req is 2.
```

Example

This example shows the sample output for the **show dot1x port-auth**

```
Device> enable
Device# configure terminal
Device(config)# show dot1x port-auth
-----
port 1 auth is close
port 2 auth is close
port 3 auth is close
port 4 auth is close
port 5 auth is close
port 6 auth is close
port 7 auth is close
port 8 auth is close
port 9 auth is close
port 10 auth is close
port 11 auth is close
port 12 auth is close
port 13 auth is close
port 14 auth is close
-----
```

Example

This example shows the sample output for the **show dot1x quiet-period-value**

```
Device> enable
Device# configure terminal
```

```
Device(config)# show dot1x quiet-period-value
the quiet-period-value is 0.
```

Example

This example shows the sample output for the **show dot1x session**

```
Device> enable
Device# configure terminal
Device(config)# show dot1x session
Total [0] item(s).
```

show ip route

To display the related information of specified routes as well as static routes, use the **show ip route** command in privileged EXEC and global configuration modes.

show ip route [*ip-address* [*mask*] | **ospf** | **rip** | **static**]

Syntax Description		
	<i>ip-address</i>	The destination address.
	<i>mask</i>	The destination network segment presented with IP address.
	ospf	Displays all OSPF routes.
	rip	Displays all RIP routes.
	static	Displays all static routes.

Command Modes
Privileged EXEC (#)
Global Configuration (config)

Example

This example shows a sample output for the **show ip route** command:

```
Device> enable
Device# configure terminal
Device(config)# show ip route
Show ip route information

INET route table - vr: 0, table: 254
Route flag: U - up, G - gateway, H - host, R - reject, C - clone, S - static
Destination      Gateway          Flags    Use    Interface      Proto
0.0.0.0/0        10.75.171.1     UGS      659    VLAN-IF100     static
10.75.171.0/24   10.75.171.17   UC       5      VLAN-IF100     local
10.75.171.17     10.75.171.17   UH       0      lo0             local
127.0.0.0/8      127.0.0.1      UR       0      lo0             local
127.0.0.1        127.0.0.1      UH       4      lo0             local
192.168.100.0/24 192.168.100.1  UC       0      METH-IF0       local
192.168.100.1    192.168.100.1  UH       0      lo0             local

Total entries: 7. Printed entries: 7.
```


show radius

To display the RADIUS server details, run the **show radius** command in privileged EXEC mode.

```
show radius {attribute | config-attribute | host [radius-server-name]}
```

Syntax Description	attribute	Displays the H3C client version information that is sent to the RADIUSRADIU server.
	config-attribute	Displays the configured vendor-self attribute type in RADIUS attribute information.
	host	Displays RADIUS host configuration information for all RADIUS servers.
	host radius-server-name	Displays RADIUS host configuration information for the specified RADIUS server.

Command Modes
Privileged EXEC (#)
Global Configuration (config)

Example

This example shows the sample output for the **show radius host** command:

```
Device> enable
Device# configure terminal
Device(config)# show radius host
-----
ServerName = binidng
PrimAuthServerIP = 0.0.0.0          PrimAcctServerIP = 0.0.0.0
SecAuthServerIP = 0.0.0.0          SecAcctServerIP = 0.0.0.0
PrimAuthPort = 1812                PrimAcctPort = 1813
SecAuthPort = 1812                SecAcctPort = 1813
Auth-secretKey = Switch            Acct-secretKey = Switch
UserNameFormat = with-domain
RealTimeAcctSwitch = open          RealTimeAcctTime = 12
RadiusClientIP = 0.0.0.0
-----
ServerName = r1
PrimAuthServerIP = 0.0.0.0          PrimAcctServerIP = 0.0.0.0
SecAuthServerIP = 0.0.0.0          SecAcctServerIP = 0.0.0.0
PrimAuthPort = 1812                PrimAcctPort = 1813
SecAuthPort = 1812                SecAcctPort = 1813
Auth-secretKey = Switch            Acct-secretKey = Switch
UserNameFormat = with-domain
RealTimeAcctSwitch = open          RealTimeAcctTime = 12
RadiusClientIP = 0.0.0.0
-----
ServerName = mmm
PrimAuthServerIP = 0.0.0.0          PrimAcctServerIP = 0.0.0.0
SecAuthServerIP = 0.0.0.0          SecAcctServerIP = 0.0.0.0
PrimAuthPort = 1812                PrimAcctPort = 1813
SecAuthPort = 1812                SecAcctPort = 1813
Auth-secretKey = Switch            Acct-secretKey = Switch
```

```

UserNameFormat = with-domain
RealTimeAcctSwitch = open          RealTimeAcctTime = 12
RadiusClientIP = 0.0.0.0
-----
ServerName = eee
PrimAuthServerIP = 0.0.0.0          PrimAcctServerIP = 0.0.0.0
SecAuthServerIP = 0.0.0.0          SecAcctServerIP = 0.0.0.0
PrimAuthPort = 1812                 PrimAcctPort = 1813
SecAuthPort = 1812                 SecAcctPort = 1813
Auth-secretKey = Switch            Acct-secretKey = Switch
UserNameFormat = with-domain
RealTimeAcctSwitch = open          RealTimeAcctTime = 12
RadiusClientIP = 0.0.0.0
-----
ServerName = cisco
PrimAuthServerIP = 0.0.0.0          PrimAcctServerIP = 0.0.0.0
SecAuthServerIP = 0.0.0.0          SecAcctServerIP = 0.0.0.0
PrimAuthPort = 1812                 PrimAcctPort = 1813
SecAuthPort = 1812                 SecAcctPort = 1813
Auth-secretKey = Switch            Acct-secretKey = Switch
UserNameFormat = with-domain
RealTimeAcctSwitch = open          RealTimeAcctTime = 12
RadiusClientIP = 0.0.0.0
-----
ServerName = 3
PrimAuthServerIP = 0.0.0.0          PrimAcctServerIP = 0.0.0.0
SecAuthServerIP = 0.0.0.0          SecAcctServerIP = 0.0.0.0
PrimAuthPort = 1812                 PrimAcctPort = 1813
SecAuthPort = 1812                 SecAcctPort = 1813
Auth-secretKey = Switch            Acct-secretKey = Switch
UserNameFormat = with-domain
RealTimeAcctSwitch = open          RealTimeAcctTime = 12
RadiusClientIP = 0.0.0.0
-----
ServerName = radius1
PrimAuthServerIP = 0.0.0.0          PrimAcctServerIP = 10.1.1.10
SecAuthServerIP = 0.0.0.0          SecAcctServerIP = 0.0.0.0
PrimAuthPort = 1812                 PrimAcctPort = 333
SecAuthPort = 1812                 SecAcctPort = 1813
Auth-secretKey = Switch            Acct-secretKey = Switch
UserNameFormat = with-domain
RealTimeAcctSwitch = open          RealTimeAcctTime = 12
RadiusClientIP = 0.0.0.0
-----
Total [7] item(s), printed [7] item(s).

```

show shutdown-control interface

To display the shutdown configuration, use the **show shutdown-control interface** command in privileged EXEC or global configuration mode.

show shutdown-control interface [**ethernet** *slot-number/port-number* [**to ethernet** *slot-number/port-number*]]

Syntax Description

slot-number/port-number

The port ID.

- *slot-number*:
 - GPON: The value is 0.
 - GE Ethernet: The value is 1.
 - 10GE Ethernet: The value is 2.
- *port-number*:
 - GPON: The range is from 1 to 8.
 - GE Ethernet: The range is from 1 to 4.
 - 10GE Ethernet: The range is from 1 to 2.

to

Displays the information for a range of ports. If you use the **to** keyword, specify the same port type before and after the keyword.

Command Modes

Privileged EXEC (#)
Global Configuration (config)

Example

This example shows a sample output for the **show shutdown-control interface** command:

```
Device> enable
Device# configure terminal
Device(config)# show shutdown-control interface
port shutdown control recover mode : manual
port shutdown control information :
PortID   Broadcast Broadcast Multicast Multicast Unicast Unicast
         status   value   status   value   status  value
e1/1     disable  -       disable  -       disable -
e1/2     disable  -       disable  -       disable -
e1/3     disable  -       disable  -       disable -
e1/4     disable  -       disable  -       disable -
e2/1     disable  -       disable  -       disable -
e2/2     disable  -       disable  -       disable -
Total entries: 6 .
```

show spanning-tree interface

To display the spanning tree configuration parameters, use the **show spanning-tree interface** command in the privileged EXEC and global configuration modes.

show spanning-tree interface [**brief** | {**ethernet** | **gpon**} *slot-number/port-number* [**to** {**ethernet** | **gpon**} *slot-number/port-number*]]

Syntax Description

slot-number/port-number

The port ID.

- *slot-number*:
 - GPON: The value is 0.
 - GE Ethernet: The value is 1.
 - 10GE Ethernet: The value is 2.
- *port-number*:
 - GPON: The range is from 1 to 8.
 - GE Ethernet: The range is from 1 to 4.
 - 10GE Ethernet: The range is from 1 to 2.

to

Displays the information for a range of ports. If you use the **to** keyword, specify the same port type before and after the keyword.

Command Modes

Privileged EXEC (#)
Global Configuration (config)

Example

This example shows a sample output for the **show spanning-tree interface** command:

```
Device> enable
Device# configure terminal
Device(config)# show spanning-tree interface
Port g0/1 of bridge is Forwarding
  Spanning tree protocol is enabled
Port g0/2 of bridge is DOWN
  Spanning tree protocol is enabled
Port g0/3 of bridge is DOWN
  Spanning tree protocol is enabled
Port g0/4 of bridge is DOWN
  Spanning tree protocol is enabled
Port g0/5 of bridge is DOWN
  Spanning tree protocol is enabled
Port g0/6 of bridge is DOWN
  Spanning tree protocol is enabled
Port g0/7 of bridge is DOWN
  Spanning tree protocol is enabled
```

```
Port g0/8 of bridge is DOWN
  Spanning tree protocol is enabled
Port e1/1 of bridge is DOWN
  Spanning tree protocol is enabled
Port e1/2 of bridge is DOWN
  Spanning tree protocol is enabled
Port e1/3 of bridge is Forwarding
  Spanning tree protocol is enabled
Port e1/4 of bridge is DOWN
  Spanning tree protocol is enabled
Port e2/1 of bridge is DOWN
  Spanning tree protocol is enabled
Port e2/2 of bridge is DOWN
  Spanning tree protocol is enabled
```

shutdown-control-recover

To enable the port recovery mode and configure the port recovery parameters, use the **shutdown-control-recover** command in global configuration mode. To disable the port recovery mode and restore the default parameter values, use the **no** form of the command.

shutdown-control-recover {**automatic-open-time** *open-time* | **mode** {**automatic** | **manual**}}

no shutdown-control-recover {**automatic-open-time** | **mode**}

Syntax Description

automatic-open-time <i>open-time</i>	Configures the time after which the port restarts once the recovery time is expires.
mode automatic	Enables automatic recovery mode.
mode manual	Enables manual recovery mode.

Command Modes

Global Configuration (config)

Example

This example shows how to configure automatic recovery mode on a port using the **shutdown-control-recover** command:

```
Device> enable
Device# configure terminal
Device(config)# shutdown-control-recover mode automatic
Device(config)#
```

spanning-tree (global configuration)

To enable spanning tree globally and configure the spanning tree parameters, use the **spanning-tree** command in global configuration mode. To disable spanning tree, use the **no** form of the command.

spanning-tree [**forward-time** *delay-time* | **hello-time** *hello-time* | **max-age** *age-time* | **mode** {**rstp** | **stp**} | **pathcost-standard** {**dot1d-1998** | **dot1t**} | **priority** *priority-value* | **root-guard** **action** {**block-port** | **drop-packets**}]

no spanning-tree [**forward-time** | **hello-time** | **max-age** | **mode** | **pathcost-standard** | **priority** | **root-guard** **action**]

Syntax Description		
forward-time <i>delay-time</i>		Configures the forwarding delay of the system. The range is 4 to 30 seconds.
hello-time <i>hello-time</i>		Configures the hello message time interval. The range is 1 to 10 seconds.
max-age <i>age-time</i>		Configures the aging time of the system The range is 6 to 40 seconds.
mode rstp		Configures the RSTP spanning tree mode.
mode stp		Configures the STP spanning tree mode.
pathcost-standard dot1d-1998		Sets pathcost standard for dot1d-1998.
pathcost-standard dot1t		Sets pathcost standard for dot1t.
priority <i>priority-value</i>		Configures the switch priority. The range is from 0 to 61440, in steps of 4096.
root-guard action block-port		Enables root protection globally. BPDU configuration messages are discarded and data packets are not forwarded.
root-guard action drop-packets		Enables root protection globally. BPDU configuration messages are discarded and data packets are forwarded.

Command Modes Global configuration (config)

Example

This example shows how to configure the forwarding delay of the system:

```
Device> enable
Device# configure terminal
```

```
Device(config)# spanning-tree forward-time 10
Device(config)#
```

Example

This example shows how to configure the hello message time interval:

```
Device> enable
Device# configure terminal
Device(config)# spanning-tree hello-time 5
Device(config)#
```

Example

This example shows how to configure the aging time of the system:

```
Device> enable
Device# configure terminal
Device(config)# spanning-tree max-age 10
Device(config)#
```

Example

This example shows how to configure RSTP spanning tree mode:

```
Device> enable
Device# configure terminal
Device(config)# spanning-tree mode rstp
Device(config)#
```

Example

This example shows how to configure STP spanning tree mode:

```
Device> enable
Device# configure terminal
Device(config)# spanning-tree mode stp
Device(config)#
```

Example

This example shows how to configure the pathcost standard:

```
Device> enable
Device# configure terminal
Device(config)# spanning-tree pathcost-standard dot1t
Device(config)#
```

Example

This example shows how to configure the switch priority:

```
Device> enable
Device# configure terminal
```



```
Device(config)# spanning-tree priority 3  
Device(config)#
```

Example

This example shows how to enable root guard protection globally and configure the data packets to not be forwarded:

```
Device> enable  
Device# configure terminal  
Device(config)# spanning-tree root-guard action block-port  
Device(config)#
```

spanning-tree (interface configuration)

To enable spanning tree on a specific interface and configure the spanning tree parameters, use the **spanning-tree** command in interface configuration mode. To disable spanning tree, use the **no** form of the command.

spanning-tree [**cost** *cost-value* | **loop-guard** | **mcheck** | **point-to-point** {**auto** | **forcefalse** | **forcetrue**} | **port-priority** *priority-value* | **portfast** | **root-guard** | **transit-limit** *value*]

no spanning-tree [**cost** | **loop-guard** | **point-to-point** | **port-priority** | **portfast** | **root-guard** | **transit-limit**]

Syntax Description

cost <i>cost-value</i>	Modifies the path cost of the STP port. The range is 1 to 200000000.
loop-guard	Enables loop-guard on the port.
mcheck	Configures Mcheck on the port.
point-to-point auto	STP decides the point to point link.
point-to-point forcetrue	Enables the point to point link.
point-to-point forcefalse	Disables the point to point link.
port-priority <i>priority-value</i>	Configures the STP priority of the port. The range is 0 to 240.
portfast	Configures the port as an edge port.
root-guard	Enables root protection locally on the port.
transit-limit <i>value</i>	Configures the port to send the maximum rate of BPDU messages. The range is 1 to 255.

Command Modes

Interface configuration (config-if)

Example

This example shows how to configure the path cost of an STP port:

```
Device> enable
Device# configure terminal
Device(config)# interface ethernet 1/3
Device(config-if-ethernet-1/3)# spanning-tree cost 1000
Device(config-if-ethernet-1/3)#
```

Example

This example shows how to enable loop guard on an STP port:

```
Device> enable
Device# configure terminal
Device(config)# interface ethernet 1/3
Device(config-if-ethernet-1/3)# spanning-tree loop-guard
Device(config-if-ethernet-1/3)#
```

Example

This example shows how to configure Mcheck on an STP port:

```
Device> enable
Device# configure terminal
Device(config)# interface ethernet 1/3
Device(config-if-ethernet-1/3)# spanning-tree mcheck
Device(config-if-ethernet-1/3)#
```

Example

This example shows how to enable point to point link on an STP port:

```
Device> enable
Device# configure terminal
Device(config)# interface ethernet 1/3
Device(config-if-ethernet-1/3)# spanning-tree point-to-point forcetrue
Device(config-if-ethernet-1/3)#
```

Example

This example shows how to configure the STP priority of an STP port:

```
Device> enable
Device# configure terminal
Device(config)# interface ethernet 1/3
Device(config-if-ethernet-1/3)# spanning-tree port-priority 3
Device(config-if-ethernet-1/3)#
```

Example

This example shows how to configure the STP port as an edge port:

```
Device> enable
Device# configure terminal
Device(config)# interface ethernet 1/3
Device(config-if-ethernet-1/3)# spanning-tree portfast
Device(config-if-ethernet-1/3)#
```

Example

This example shows how to enable root protection on an STP port:

```
Device> enable
Device# configure terminal
Device(config)# interface ethernet 1/3
Device(config-if-ethernet-1/3)# spanning-tree root-guard
Device(config-if-ethernet-1/3)#
```

Example

This example shows how to configure an STP port to send the maximum rate of BPDU messages:

```
Device> enable
Device# configure terminal
Device(config)# interface ethernet 1/3
Device(config-if-ethernet-1/3)# spanning-tree transit-limit 200
Device(config-if-ethernet-1/3)#
```

time-range

To specify when an access control list (ACL) is in effect, use the **time-range** command in the global configuration mode. To remove the time range, use the **no** form of the command.

```
[no]time-range name
```

Syntax Description	<i>name</i>	Specifies a unique name for the time range. Name has to begin with an alphabetic character.
---------------------------	-------------	---

Command Modes	Global Configuration (config)
----------------------	-------------------------------

Command Default	None
------------------------	------

Example

```
Device#configure terminal  
Device(config)#time-range weekends
```

username-format

To configure a packet to carry the username when it is passed by the system to the RADIUS server, use the **username-format** command in AAA configuration module.

username-format { **with-domain** | **without-domain** }

Syntax Description	with-domain	without-domain
	Configures the packet to carry the username with the domain.	Configures the packet to carry the username without the domain.

Command Modes AAA configuration (config-aaa)

Example

This example shows how to configure the system to carry the user name when it passes a packet to the RADIUS server using the **username-format** command:

```
Device> enable
Device# configure terminal
Device(config)# aaa
Device(config-aaa)# radius host radius1
Device(config-aaa-radius-radius1)# username-format with-domain
Modify the username format of RADIUS configuration successfully
```



PART **VIII**

Multicast Configuration

- [Multicast Configuration, on page 353](#)



Multicast Configuration

- [igmp-snooping](#), on page 355
- [igmp-snooping drop](#), on page 356
- [igmp-snooping fast-leave](#), on page 357
- [igmp-snooping group-limit action](#), on page 358
- [igmp-snooping group-limit](#), on page 359
- [igmp-snooping general-query source-ip](#), on page 360
- [igmp-snooping host-aging-time](#), on page 361
- [igmp-snooping max-response-time](#), on page 362
- [igmp-snooping multicast vlan](#), on page 363
- [igmp-snooping {permit|deny}](#), on page 364
- [igmp-snooping profile refer](#), on page 365
- [igmp-snooping profile](#), on page 366
- [igmp-snooping {permit|deny} group-range](#), on page 367
- [igmp-snooping query-interval](#), on page 368
- [igmp-snooping querier version](#), on page 369
- [igmp-snooping querier-vlan](#), on page 370
- [igmp-snooping query-max-respond](#), on page 371
- [igmp-snooping record-host](#), on page 372
- [igmp-snooping router-port-age](#), on page 373
- [igmp-snooping route-port forward](#), on page 374
- [igmp-snooping report-supression](#), on page 375
- [igmp-snooping route-port vlan](#), on page 376
- [ip range](#), on page 377
- [mac range](#), on page 378
- [multicast](#), on page 379
- [multicast ds-tag add](#), on page 380
- [multicast ds-tag remove](#), on page 381
- [multicast ds-tag translate](#), on page 382
- [multicast fast-leave disable](#), on page 383
- [multicast group-limit](#), on page 384
- [multicast interface](#), on page 385
- [multicast mode igmp-snooping](#), on page 386
- [multicast proxy-interval](#), on page 387

- [multicast proxy-port](#), on page 388
- [multicast us-tag add](#), on page 389
- [multicast us-tag translate](#), on page 390
- [profile limit](#), on page 391
- [show igmp-snooping](#), on page 392
- [show igmp-snooping profile](#), on page 393
- [show igmp-snooping record-host](#), on page 394
- [show igmp-snooping router-dynamic](#), on page 395
- [show igmp-snooping router-static](#), on page 396
- [show multicast igmp-snooping](#), on page 397
- [show ont multicast](#), on page 398

igmp-snooping

To enable IGMP Snooping, use the **igmp-snooping** in the global configuration mode. To disable IGMP Snooping use the **no** form of the command.

igmp-snooping

no igmp-snooping

Syntax Description	igmp-snooping Enables IGMP Snooping.
---------------------------	---

Command Default	IGMP Snooping is enabled by default.
------------------------	--------------------------------------

Command Modes	Interface configuration
----------------------	-------------------------

Examples	The following example shows how to enable IGMP Snooping.
-----------------	--

```
Device(config)#igmp-snooping
```

igmp-snooping drop

To configure a port to drop query or report packets, use the **igmp-snooping drop** command in the interface configuration mode. To configure the port to start receiving IGMP query or report packets, use the **no** form of the command.

igmp-snooping drop { **query** | **report** }

no igmp-snooping drop

Syntax Description	query Configures the port to drop IGMP query packets.
	report Configures the port to drop IGMP report packets.

Command Default Packet dropping is not enabled by default.

Command Modes Interface configuration

Examples

The following example shows how to configure a port to drop query packets:

```
Device(config-if-ethernet-1/1)# igmp-snooping drop query
```

igmp-snooping fast-leave

To remove the port directly from the multicast group upon receiving an IGMP Leave message, use the **igmp-snooping fast-leave** command in the interface configuration mode. To disable fast leave use the **no** form of the command.

igmp-snooping fast-leave

no igmp-snooping fast-leave

Syntax Description	fast-leave Removes the port directly from the multicast group upon receiving an IGMP Leave message
---------------------------	---

Command Default	Fast leave is not configured by default.
------------------------	--

Command Modes	Interface configuration
----------------------	-------------------------

Examples

The following example shows how to configure fast leave:

```
Device(config-if-ethernet-1/1)#igmp-snooping fast-leave
```

igmp-snooping group-limit action

To configure the action that the port will perform when it reaches the maximum number of multicast groups it can join, use the **igmp-snooping group-limit action** command in the interface configuration mode.

igmp-snooping group-limit action { **drop** | **replace** }

Syntax Description	drop Drops the multicast group. This is the default action.
	replace Replaces an old multicast group with the new group.

Command Default When the group limit is reached, the new group is dropped.

Command Modes Interface configuration

Examples This example shows how to configure the port to drop new multicast groups when it reaches the group limit

```
Device(config-if-ethernet-1/1)#igmp-snooping group-limit action drop
```

igmp-snooping group-limit

To configure the maximum number of multicast groups that an interface or a port can learn or join, use the **igmp-snooping group-limit** command in the interface configuration mode. To undo the limit on the maximum number of multicast groups that a port can join use the **no** form of the command.

igmp-snooping group-limit *number*

no igmp-snooping group-limit

Syntax Description

number Specifies the maximum number of multicast groups that a port can join. The range is 0-1024.

Command Default

No limit is configured by default.

Command Modes

Interface configuration

Examples

The following examples shows how to configure a group limit of 100:

```
Device(config-if-ethernet-1/4)#igmp-snooping group-limit 100
```

igmp-snooping general-query source-ip

To configure the source IP address for sending general query packets, use the **igmp-snooping general-query source-ip** command in the global configuration mode. To disable the source IP address for sending general query, use the **no** form of the command.

igmp-snooping general-query source-ip*ip-address*

no igmp-snooping general-query source-ip*ip-address*

Syntax Description	<i>ip-address</i> Configures the source IP address for sending general query packets.
---------------------------	---

Command Default	None
------------------------	------

Command Modes	Global configuration
----------------------	----------------------

Examples The following example shows how to configure a source IP address for sending general query packets:

```
Device(config)# igmp-snooping general-query source-ip 192.168.1.2
```


igmp-snooping host-aging-time

To configure the aging time of dynamic multicast members, use the **igmp-snooping host-aging-time** command in the global configuration mode. To disable aging time for dynamic multicast members use the **no** form of the command.

igmp-snooping host-aging-time*time*

no igmp-snooping host-aging-time

Syntax Description

time Specifies the aging time for dynamic multicast members. The range is from 10-1000000 seconds. The default value is 300 seconds.

Command Default

The aging time is set to 300 seconds.

Command Modes

Global configuration

Examples

The following example shows how to configure an aging time of 500 seconds:

```
Device(config)# igmp-snooping host-aging-time 500
```

igmp-snooping max-response-time

To configure the maximum waiting time for deleting group ports after receiving a leave packet, use the **igmp-snooping max-resposne-time** command in the global configuration mode. To disable a maximum waiting time use the **no** form of the command.

igmp-snooping max-response-time *time*

no igmp-snooping max-response-time *time*

Syntax Description	<i>time</i> Configures the maximum waiting time for deleting group ports after receiving a leave packet. The range is from 1-100 seconds. The default value is 10 seconds.
---------------------------	--

Command Default	The default maximum waiting time is 10 seconds.
------------------------	---

Command Modes	Global configuration
----------------------	----------------------

Examples

The following example shows how to configure a maximum response time of 20 seconds:

```
Device(config)# igmp-snooping max-response-time 20
```

igmp-snooping multicast vlan

To configure multicast VLAN for IGMP packets, use the **igmp-snooping multicast vlan** command in the interface configuration mode. To disable multicast VLAN for IGMP packets, use the **no** form of the command.

igmp-snooping multicast vlan *vlan-id*

no igmp-snooping multicast vlan

Syntax Description	multicast vlan Configures multicast VLAN for the IGMP packets on the port.
---------------------------	---

Command Default	None
------------------------	------

Command Modes	Interface configuration
----------------------	-------------------------

Examples

The following example shows how to enable multicast VLAN for IGMP packets on VLANs 1-50:

```
Device(config-if-ethernet-1/1) # igmp-snooping multicast vlan 50
```

igmp-snooping {permit|deny}

To configure the default learning rule for multicast groups that are not in the blocked list or the allowed list, use the **igmp-snooping {permit|deny}** command in the global configuration mode. By default, the learning rule for all multicast groups that are not in the blocked list or the allowed list is to learn all multicast groups.

igmp-snooping { permit | deny } { group all | vlanvlan-id

Syntax Description

permit Configures the list of groups that are permitted to join by IGMP snooping.

deny Configures the list of groups that are denied to join by IGMP snooping.

Command Default

Default is to learn all multicast groups that are not in the blocked list or the allowed list

Command Modes

Global configuration

Examples

This example shows how to configure the rule to learn all multicast groups:

```
Device(config)#igmp-snooping permit group all
```

igmp-snooping profile refer

To configure a profile or a list of profiles as a reference for a port, use the **igmp-snooping profile refer** command in the interface configuration mode. You can disable the profile reference of a port using the **no** form of the command.

igmp-snooping profile refer*profile-list*

no igmp-snooping profile refer*profile-list*

Syntax Description	<i>profile-list</i> Configures a list of reference profiles for the port.
---------------------------	---

Command Default	None
------------------------	------

Command Modes	Interface configuration
----------------------	-------------------------

Examples The following example shows how to create reference profile for the port:

```
Device(config-if)# igmp-snooping profile refer 1-5
```

igmp-snooping profile

To create an IGMP Snooping profile, use the **igmp-snooping profile** command in the global configuration mode. To disable IGMP snooping profile use the **no** form of the command.

igmp-snooping profile *profile-id*

no igmp-snooping profile

Syntax Description	<i>profile-id</i> Functions as an identifier for an IGMP Snooping profile. The range is 1-128.
---------------------------	--

Command Default	IGMP Snooping profile is not enabled by default.
------------------------	--

Command Modes	Global configuration
----------------------	----------------------

Examples	The following example shows how to create an IGMP Snooping profile:
-----------------	---

```
Device(config)# igmp-snooping profile 1
```

igmp-snooping {permit|deny} group-range

To configure a port to learn (or not learn) a range of MAC addresses and VLAN ids, use the **igmp-snooping {permit|deny} group-range** command in the interface configuration mode.

igmp-snooping { permit | deny } group-range *MAC-address multi-count multi-count-number* **vlan** *vlan-list*

Syntax Description	multi-count <i>multi-count-number</i> Configures the number of MAC addresses in the group range.
---------------------------	---

Command Default	None
------------------------	------

Command Modes	Interface configuration
----------------------	-------------------------

Examples

The following example shows how to permit a group range of MAC addresses and VLAN ids:

```
Device(config-if-ethernet-1/1)# igmp-snooping permit group-range 01:00:5e:09:08:07 multi-count  
12 vlan 10
```

igmp-snooping query-interval

To configure the interval for sending general query packets, use the **igmp-snooping query-interval** command in the global configuration mode.

igmp-snooping query-interval *interval*

Syntax Description	<i>interval</i> Configures the interval for sending general query packets. The range is from 1 to 30000 seconds.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	Global configuration
----------------------	----------------------

Examples

The following example shows how to configure the IGMP Snooping query interval to 500 seconds:

```
Device(config)# igmp-snooping query-interval 500
```


igmp-snooping querier version

To configure the version of the IGMP Snooping querier, use the **igmp-snooping querier version** command in the global configuration mode. The IGMP snooping querier version is set to 2 by default.

igmp-snooping querier version *version-id*

Syntax Description

version-id Configures the version of the IGMP Snooping querier. The range is 2-3. The default version is 2.

Command Default

the querier is set to version 2 by default.

Command Modes

Global configuration

Examples

The following example shows how to configure the IGMP Snooping querier version to version 3:

```
Device(config)# igmp-snooping querier version 3
```

igmp-snooping querier-vlan

To configure VLANs for general query packets, use the **igmp-snooping querier-vlan** command in the global configuration mode. To disable VLANs for query packets use the **no** form of the command.

igmp-snooping querier-vlan *vlan-list*

no igmp-snooping querier-vlan *vlan-list*

Syntax Description	querier-vlan Configures a list of VLANs for general query packets.
---------------------------	---

Command Default	None
------------------------	------

Command Modes	Global configuration
----------------------	----------------------

Examples

The following example shows how to configure VLANs for the IGMP-Snooping querier:

```
Device(config)# igmp-snooping querier-vlan 1-50
```

igmp-snooping query-max-respond

To configure the maximum response time for general query packets, use the **igmp-snooping query-max-respond** command in the global configuration mode. To disable a maximum response time, use the **no** form of the command.

igmp-snooping query-max-respond *time*

no igmp-snooping query-max-respond *time*

Syntax Description	<i>time</i> Configures the maximum response time for general query packets. The range is from 1 to 25 seconds.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	Global configuration
----------------------	----------------------

Examples

The following example shows how to configure the maximum response time for general query packets to 10 seconds:

```
Device(config)# igmp-snooping query-max-respond 10
```

igmp-snooping record-host

To enable recording the MAC address of the source of an IGMP report packet, use the **igmp-snooping record-host** command in the interface configuration mode. To disable the recording of the host MAC address, use the **no** form of the command.

igmp-snooping record-host

no igmp-snooping record-host

Syntax Description	record-host Enables recording the MAC address of the source of an IGMP report packet
---------------------------	---

Command Default	recording is not enabled by default
------------------------	-------------------------------------

Command Modes	Interface configuration
----------------------	-------------------------

Examples The following example shows how to configure a port to record the host MAC address

```
Device(config-if-ethernet-1/1)# igmp-snooping record-host
```

igmp-snooping router-port-age

To configure the ageing time for the dynamic route port, use the **igmp-snooping router-port-age** command in the global configuration mode. To disable ageing time for the dynamic route port, use the **no** form of the command.

igmp-snooping router-port-age { **on** | **off** | *age-time* }

no igmp-snooping router-port-age { **on** | **off** | *age-time* }

Syntax Description

on Starts router port age

off Stops router port age.

age-time Sets router port age time in seconds. The range is 10-1000000 seconds. The default value is 300 seconds.

Command Default

The router port age is on by default.

Command Modes

Global configuration

Examples

The following example shows how to start the router port age:

```
Device(config)# igmp-snooping router-port-age on
```

igmp-snooping route-port forward

To configure a dynamic route port to forward multicast traffic packets, use the **igmp-snooping route-port forward** command in the global configuration mode. To disable the route port from forwarding multicast traffic packets, use the **no** form of the command.

igmp-snooping route-port forward

no igmp-snooping route-port forward

Syntax Description	forward Configures the port to forward multicast traffic packets.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	Global configuration
----------------------	----------------------

Examples

The following example shows how to configure a dynamic route port to forward multicast traffic packets:

```
Device(config)#igmp-snooping route-port forward
```

igmp-snooping report-suppression

To enable IGMP Snooping suppression of multicast reports, use the **igmp-snooping report-suppression** command in the global configuration mode. To disable the suppression of multicast reports, use the **no** form of the command.

igmp-snooping report-suppression

no igmp-snooping report-suppression

Syntax Description

report-suppression Enables IGMP Snooping suppression of multicast reports.

Command Default

Report suppression is not enabled by default.

Command Modes

Global configuration

Examples

The following example shows how to enable IGMP Snooping report suppression:

```
Device(config)# igmp-snooping report-suppression
```

igmp-snooping route-port vlan

To configure a static route port, use the **igmp-snooping route-port vlan** command in the global configuration mode. You can disable the static route port by using the **no** form of the command.

igmp-snooping route-port vlan *vlan-id* **interface** { **all** | **channel-group** *channel-group-id* | **ethernet** *interface-number*

no igmp-snooping route-port vlan *vlan-id* **interface** { **all** | **channel-group** *channel-group-id* | **ethernet** *interface-number*

Syntax Description	<i>channel-group-id</i> Specifies the number of the channel group. The range is from 0-5.
	<i>interface-number</i> Specifies the ethernet interface number.

Command Default None.

Command Modes Global configuration

Examples

The following examples shows how to configure all the ports of an interface as static route ports:

```
Device(config)# igmp-snooping route-port vlan 50 interface all
```


ip range

To configure the range of IP addresses and VLAN IDs for an IGMP profile, use the **ip range** command in profile configuration mode.

ip range *start-ip-address end-ip-address* **vlan** *vlan-id*

Syntax Description

<i>start-ip-address</i>	Configures the start IP Address for the IGMP Snooping profile. The IP addresses range is from 224.0.0.1 to 239.255.255.254.
<i>end-ip-address</i>	Configures the end IP Address for the IGMP Snooping profile. The IP addresses range is from 224.0.0.1 to 239.255.255.254.
<i>vlan-id</i>	Configures the range of VLAN IDs for the IGMP Snooping profile. The VLAN id range is from 1 to 4094.

Command Default

None

Profile configuration mode

Examples

The following example shows how to configure the range of IP addresses and VLAN ids for an IGMP Snooping profile.

```
Device(config-igmp-profile-1)# ip range 224.0.0.1 239.255.255.254 vlan 50
```

mac range

To configure the range of MAC addresses and VLAN IDs for an IGMP profile, use the **mac range** command in profile configuration mode.

mac range *start-mac-address end-mac-address* **vlan** *vlan-id*

Syntax Description	
<i>start-mac-address</i>	Configures the start MAC Address for the IGMP Snooping profile. The MAC addresses range is 01:00:5e:H:H:H. .
<i>end-mac-address</i>	Configures the end MAC Address for the IGMP Snooping profile. The MAC addresses range is 01:00:5e:H:H:H.
<i>vlan-id</i>	Configures the range of VLAN IDs for the IGMP Snooping profile. The VLAN id range is from 1 to 4094.

Command Default None

Command Modes Profile configuration

Examples

The following example shows how to configure the range of MAC addresses and VLAN ids for an IGMP Snooping profile.

```
Device(config-igmp-profile-1)# mac range 01:00:5e:09:08:07 01:00:5e:09:09:08 vlan 50
```

multicast

To create a static multicast group, use the **multicast** command in the global configuration mode.

```
multicast { mac-address mac-address | ip-address ip-address } vlan vlan-id
```

Syntax Description

ip-address Configures the static multicast IP address. It can only be in the format 224.x.x.x.

mac-address Configures the static multicast MAC address. It can only be in the format 01:00:5e:H:H:H.

vlan-id Configures the VLANs for the static multicast group.

Command Default

Multicast group is not configured by default.

Command Modes

Global configuration

The following example shows how to configure a static multicast group:

```
Device(config)# multicast ip-address 224.0.0.3 vlan 50  
Adding multicast group successfully !
```

multicast ds-tag add

To configure the ONT downlink multicast VLAN tag adding rule, use the **multicast ds-tag add** command in line profile configuration mode.

To disable the ONT uplink multicast VLAN tag adding rule, use the **no multicast ds-tag add** command.

multicast ds-tag add *vlan_id* {*priority* | **port** *port_id*}

no multicast ds-tag port *port_id*

Syntax Description

<i>vlan_id</i>	The VLAN ID The range is from 1 to 4094.
<i>priority</i>	The 802.1 priority value. The range is from 0 to 7.
<i>port_id</i>	The ONT Ethernet port ID. The range is from 1 to 24.

Command Modes

Line profile configuration (deploy-profile-line)

Examples

This example shows how to configure the ONT downlink multicast VLAN tag adding rule.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile line
Device(deploy-profile-line)# aim 5
Device(deploy-profile-line-5)# multicast ds-tag add 3
```

multicast ds-tag remove

To configure the ONT downlink multicast VLAN tag removing rule, use the **multicast ds-tag remove port** command in line profile configuration mode. To delete the ONT downlink multicast VLAN tag, use the **no multicast ds-tag port** command

```
multicast ds-tag remove [port port_id]
```

```
no multicast ds-tag [port port_id]
```

Syntax Description

port_id

The ONT Ethernet port ID. The range is from 1 to 24.

Command Modes

Line profile configuration (deploy-profile-line)

Examples

This example shows how to configure the ONT downlink multicast VLAN tag removing rule.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile line
Device(deploy-profile-line)# aim 5
Device(deploy-profile-line-5)# multicast ds-tag remove
```

multicast ds-tag translate

To configure the ONT downlink multicast VLAN tag translating rule, use the **multicast ds-tag translate** command in line profile configuration mode.

```
multicast ds-tag translate vlan_id [{priority | port port_id}]
```

Syntax Description

<i>vlan_id</i>	The VLAN ID The range is from 1 to 4094.
<i>priority</i>	The 802.1 priority value. The range is from 0 to 7.
<i>port_id</i>	The ONT Ethernet port ID. The range is from 1 to 24.

Command Modes

Line profile configuration (deploy-profile-line)

Usage Guidelines

You must configure a device type.

Examples

This example shows how to configure the ONT downlink multicast VLAN tag translating rule.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile line
Device(deploy-profile-line)# aim 5
Device(deploy-profile-line-5)# multicast ds-tag translate 3
```

multicast fast-leave disable

To disable fast-leave, use the **multicast fast-leave disable** command in global configuration mode.

```
multicast fast-leave disable [port port_id]
```

```
no multicast fast-leave disable [port port_id]
```

Syntax Description

port_id

The ONT Ethernet port ID. The range is from 1 to 24.

Command Modes

Line profile configuration (deploy-profile-line)

Examples

This example shows how to disable fast-leave on a port.

```
Device> enable  
Device# configure terminal  
Device(config)# deploy profile line  
Device(deploy-profile-line)# aim 5  
Device(deploy-profile-line-5)# multicast fast-leave disable
```

multicast group-limit

To configure the limit of multicast groups, use the **multicast group-limit** *limit_number* command in line profile configuration mode. To disable the limit of multicast groups, use the **no multicast group-limit** *limit_number* command.

multicast group-limit *limit_number* [**port** *port_id*]

no multicast group-limit *limit_number* [**port** *port_id*]

Syntax Description		
	<i>limit_number</i>	The multicast group limit. The range is from 1 to 128.
	<i>port_id</i>	The ONT Ethernet port ID. The range is from 1 to 24.

Command Modes Line profile configuration (deploy-profile-line)

Examples

This example shows how to configure the limit of multicast groups.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile line
Device(deploy-profile-line)# aim 5
Device(deploy-profile-line-5)# multicast group-limit 4
```


multicast interface

To add a port to a static multicast group, use the **multicast interface** command in the global configuration mode.

```
multicast { mac-address mac-address | ip-address ip-address } vlan vlan-id interface { all | interface-list }
```

Syntax Description

all Adds all the ports of the interface to the static multicast group.

interface-list Adds the specified ports of the interface to the static multicast group.

Command Default

None.

Command Modes

Global configuration

The following example shows how to add all the ports of an interface to a static multicast group:

```
Device(config)# multicast ip-address 224.0.0.11  
vlan 1 interface all
```

multicast mode igmp-snooping

To enable Internet Group Management Protocol (IGMP) snooping, use the **multicast mode igmp-snooping** command in line profile configuration mode.

multicast mode igmp-snooping [**port** *port_id*]

Syntax Description	<i>port_id</i>	The ONT Ethernet port ID. The range is from 1 to 24.
---------------------------	----------------	--

Command Modes	Line profile configuration (deploy-profile-line)
----------------------	--

Examples

This example shows how to enable IGMP snooping on a port.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile line
Device(deploy-profile-line)# aim 5
Device(deploy-profile-line-5)# multicast mode igmp-snooping port 10
```

multicast proxy-interval

To configure the interval at which the device sends report packets to the multicast source through the proxy port, use the **multicast proxy-interval** command in the global configuration mode.

multicast proxy-interval *seconds*

Syntax Description	proxy-interval Configures the interval at which the device sends report packets to the multicast source through the proxy port.
	<i>seconds</i> Configures the proxy-interval in seconds. The range is from 1-300. The default is 10 seconds.
Command Default	The default interval is 10 seconds.
Command Modes	Global configuration

Example

The following example shows how to configure the proxy-interval to 100 seconds

```
Device(config)# multicast proxy-interval 100
```

multicast proxy-port

To configure a proxy-port for the static multicast group, use the **multicast proxy-port** command in the global configuration mode.

multicast { **mac-address** *mac-address* | **ip-address** *ip-address* } **vlan** *vlan-id* **proxy-port ethernet** *port-id*

Syntax Description	
proxy-port	Configures a proxy port to send the multicast report to the multicast source.
<i>port-id</i>	Configures the port that will act as the proxy port.

Command Default	None
-----------------	------

Command Modes	Global configuration
---------------	----------------------

The following example shows how to configure a proxy port for a static multicast group:

```
Device(config)# multicast ip-address 225.0.0.11 vlan 1 proxy-port ethernet 1/1
```

multicast us-tag add

To configure the ONT uplink multicast VLAN tag adding rule, use the **multicast us-tag add** command in line profile configuration mode. To disable the ONT uplink multicast VLAN tag adding rule, use the **no multicast us-tag add** command.

```
multicast us-tag add vlan_id {priority | port port_id}
```

```
no multicast us-tag port port_id
```

Syntax Description

<i>vlan_id</i>	The VLAN ID The range is from 1 to 4094.
<i>priority</i>	The 802.1 priority value. The range is from 0 to 7.
<i>port_id</i>	The ONT Ethernet port ID. The range is from 1 to 24.

Command Modes

Line profile configuration (deploy-profile-line)

Examples

This example shows how to configure the ONT uplink multicast VLAN tag adding rule

```
Device> enable
Device# configure terminal
Device(config)# deploy profile line
Device(deploy-profile-line)# aim 5
Device(deploy-profile-line-5)# multicast us-tag add 3
```

multicast us-tag translate

To configure the ONT downlink multicast VLAN tag translating rule, use the **multicast us-tag translate** command in line profile configuration mode. To disable the ONT downlink multicast VLAN tag translating rule, use the **no multicast us-tag translate** command

multicast us-tag translate *vlan_id* {*priority* | **port** *port_id*}

no multicast us-tag port *port_id*

Syntax Description

<i>vlan_id</i>	The VLAN ID The range is from 1 to 4094.
<i>priority</i>	The 802.1 priority value. The range is from 0 to 7.
<i>port_id</i>	The ONT Ethernet port ID. The range is from 1 to 24.

Command Modes

Line profile configuration (deploy-profile-line)

Examples

This example shows how to configure the ONT uplink multicast VLAN tag translating rule.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile line
Device(deploy-profile-line)# aim 5
Device(deploy-profile-line-5)# multicast us-tag translate 3
```

profile limit

To configure the IGMP snooping profile type as a permit or deny profile, use the **profile limit** command in the profile configuration mode.

profile limit { **permit** | **deny** }

Syntax Description	permit Configures a list of groups that are permitted by the IGMP Snooping profile.
	deny Configures a list of groups that are denied by the IGMP Snooping profile.

Command Default	None
------------------------	------

Command Modes	Profile configuration
----------------------	-----------------------

Examples

The following example shows how to configure a permit type profile:

```
Device(config-igmp-profile-1)# profile limit permit
```

show igmp-snooping

To displays IGMP Snooping configurations, use the **show igmp-snooping** command in the EXEC mode.

show igmp-snooping

Syntax Description	igmp-snooping	Displays IGMP Snooping configurations.
--------------------	---------------	--

Command Default	None
-----------------	------

Command Modes	User EXEC Privileged EXEC
---------------	------------------------------

Examples

The following example shows the output from **show igmp-snooping** command on an interface where IGMP Snooping is enabled:

```
Device# show igmp-snooping
Enable IGMP-Snooping
Disable IGMP-Snooping report-suppression
The max response time is 10 second(s)
The host aging time is 300 second(s).
Disable IGMP-Snooping route-port forward
The Router port timeout is 300 second(s), Currently aging is running
Denied VLAN:
Black list:
NULL
White list:
NULL
Default group policy is permit
IGMP-Snooping Querier : ON
Querier vlan : 1
Querier Source IP 0.0.0.0 | Max Query Respond Time 10 sec | Query interval 60
sec | Igmp version 2
Port Information:
port  limit  action  fast-leave  mcast-vlan  igmp-profile  drop-type
p0/1  1024    drop    disabled    disabled    disabled      null
p0/2  1024    drop    disabled    disabled    disabled      null
p0/3  1024    drop    disabled    disabled    disabled      null
p0/4  1024    drop    disabled    disabled    disabled      null
p0/5  1024    drop    disabled    disabled    disabled      null
p0/6  1024    drop    disabled    disabled    disabled      null
p0/7  1024    drop    disabled    disabled    disabled      null
p0/8  1024    drop    disabled    disabled    disabled      null
e1/1  1024    drop    disabled    disabled    1             null
e1/2  1024    drop    disabled    disabled    disabled      null
e1/3  1024    drop    disabled    disabled    disabled      null
e1/4  1024    drop    disabled    disabled    disabled      null
e2/1  1024    drop    disabled    disabled    disabled      null
e2/2  1024    drop    disabled    disabled    disabled      null
```


show igmp-snooping profile

To display the details of an IGMP Snooping profile, use the **show igmp-snooping profile** command in the EXEC mode.

show igmp-snooping profile { *profile-id* | **interface** *port-id* | **vlan** *vlan-id* }

Syntax Description

<i>profile-id</i>	Displays the details of the particular IGMP Snooping profile
<i>port-id</i>	Displays the IGMP Snooping profile details for the port.
<i>vlan-id</i>	Displays the IGMP Snooping profile details for the VLANs.

Command Default

None

Command Modes

User EXEC
Privileged EXEC

Examples

The following example displays the output of the **show igmp-snooping profile** command:

```
Device# show igmp-snooping profile 1

IGMP-Snooping profile 1
Profile description :
Profile limit       : permit
Profile referred    : e1/1.
start-address       end-address      vlan
224.0.0.1           239.255.255.254    any
Total ip range: 1, mac range: 0

Total profiles: 1, IP&MAC ranges: 1
```

show igmp-snooping record-host

To display the MAC address of the record host, use the **show igmp-snooping record-host** command in the EXEC mode.

show igmp-snooping record-host [*interface-id*]

Syntax Description	record-host Displays the MAC address of the record host.
	<i>interface-id</i> Displays the MAC address of the record host for the interface.

Command Default	None
------------------------	------

Command Modes	User EXEC Privileged EXEC
----------------------	------------------------------

Examples

The following example shows the output of the **show igmp-snooping record-host** command:

```
Device# show igmp-snooping record-host
show host record information
Total Record: 0
```

show igmp-snooping router-dynamic

To display the dynamic route ports, use the **show igmp-snooping router-dynamic** command in the EXEC mode.

show igmp-snooping router-dynamic

Syntax Description	router-dynamic Displays the dynamic route ports.
---------------------------	---

Command Default	None
------------------------	------

Command Modes	User EXEC Privileged EXEC
----------------------	------------------------------

Examples

The following example shows the output from **show igmp-snooping router-dynamic** command on an interface where IGMP Snooping is enabled:

```
Device# show igmp-snooping router-dynamic
  Port      VID      Age      Type
  e1/3      100     237     { QUERY }
Total Record: 1
```

show igmp-snooping router-static

To display the static route ports on an interface or on a multicast VLAN, use the **show igmp-snooping router-static** command in the EXEC mode.

show igmp-snooping router-static [**interface** { **channel-group** *channel-group-id* | **ethernet** *port* } | **vlan** *vlan-id*]

Syntax Description

router-static	Displays the static router ports.
<i>channel-group-id</i>	Displays the static ports for a LACP channel group. The range is 0-5.
<i>vlan-id</i>	Displays the static ports for Multicast VLANs.

Command Default

None

Command Modes

User EXEC
Privileged EXEC

Examples

The following example shows the output from **show igmp-snooping router-static** command on an interface where IGMP Snooping is enabled:

```
Device# show igmp-snooping router-static interface channel-group 1
  Port      VID      Age      Type
Total Record: 0
```

show multicast igmp-snooping

To display igmp-snooping multicast table information, use the **show multicast igmp-snooping** command in the EXEC mode.

```
show multicast igmp-snooping { interfaceinterface-id | ip-address ip-address }
```

Syntax Description

interface-id Displays the IGMP Snooping multicast table for the interface.

ip-address Displays the IGMP Snooping multicast table for the IP address.

Command Default

None

Command Modes

User EXEC
Privileged EXEC

Examples

The following example displays the output of the **show multicast igmp snooping** command for an interface:

```
Device# show multicast igmp-snooping interface ethernet 1/1  
show igmp-snooping multicast table information Total Record: 0
```

show ont multicast

To display information about the multicast learning table on an ONT, use the **show ont multicast** command in privileged EXEC or global configuration mode.

show ont multicast *slot-num/pon-num/ont-num* [**port** *port-id*]

Syntax Description		
<i>slot-num/pon-num/ont-num</i>	The ONT ID.	<ul style="list-style-type: none"> • <i>slot-num</i>: The slot number. The value is 0. • <i>pon-num</i>: The PON number. The range is from 1 to 8. • <i>ont-num</i>: The ONT number. The range is from 1 to 128.
<i>port-id</i>	The ONT Ethernet port ID.	The range is from 1 to 24.

Command Modes	
	Privileged EXEC (#)
	Global configuration (config)

Examples

This example shows how to view the information about the multicast learning table on an ONT.

```
Device> enable
Device# configure terminal
Device(config)# show ont multicast 0/1/1
```



PART **IX**

System Management

- [System Management, on page 401](#)



System Management

- [alarm all-packets](#), on page 403
- [alarm all-packets threshold](#), on page 404
- [alarm cpu](#), on page 405
- [alarm cpu threshold](#), on page 406
- [buildrun mode](#) , on page 407
- [clear startup-config](#), on page 408
- [clock timezone](#), on page 409
- [copy running-config startup-config](#), on page 410
- [copy startup-config running-config](#), on page 411
- [load ftp](#), on page 412
- [load tftp](#), on page 413
- [load xmodem](#), on page 414
- [local fec](#), on page 415
- [show alarm all-packets](#), on page 416
- [show alarm cpu](#), on page 417
- [show clock](#), on page 418
- [show running-config](#), on page 419
- [show snmp client](#), on page 420
- [show snmp client summer-time](#), on page 421
- [show startup-config](#), on page 422
- [snmp client](#), on page 423
- [snmp client authenticate](#), on page 424
- [snmp client authentication-key](#), on page 425
- [snmp client broadcastdelay](#), on page 426
- [snmp client mode](#), on page 427
- [snmp client poll-interval](#), on page 428
- [snmp client retransmit-interval](#), on page 429
- [snmp client retransmit](#), on page 430
- [snmp client summer-time daily](#), on page 431
- [snmp client summer-time weekly](#), on page 432
- [snmp client valid-server](#), on page 433
- [snmp server](#) , on page 434
- [snmp trusted-key](#), on page 435

- [upload automatically configuration ftp](#), on page 436
- [upload automatically configuration tftp](#), on page 437
- [upload ftp](#), on page 438
- [upload tftp](#), on page 439

alarm all-packets

To enable alarms on all ports, use the **alarm all-packets** command in global configuration mode.

To enable alarms on a specific port, use the **alarm all-packets** command in interface configuration mode.

alarm all-packets

no alarm all-packets

Command Modes

Global configuration (config)

Interface configuration (config-if)

Examples

The following example shows how to enable alarms on all ports of the device:

```
Device> enable
Device# configure terminal
Device(config)# alarm all-packets
Enable port alarm successfully.
```

alarm all-packets threshold

To configure the port threshold information for alarms, use the **alarm all-packets threshold** command in interface configuration mode.

alarm all-packets threshold {**normal** *normal-value* | **exceed** *exceed-value*}

Syntax Description		
normal <i>normal-value</i>		Sets the minimum port bandwidth utilization threshold for the port.
exceed <i>exceed-value</i>		Sets the maximum port bandwidth utilization threshold for the port.

Command Modes Interface configuration mode (config-if)

Examples

The following example shows how to set the port thresholds using the **alarm all-packets threshold** command:

```
Device> enable
Device# configure terminal
Device(config)# interface gpon 0/1
Device(config-if-gpon-0/1)# alarm all-packets threshold exceed 34 normal 4
```

alarm cpu

To enable CPU alarms, use the **alarm cpu** command in global configuration mode.

alarm cpu
no alarm cpu

Command Modes

Global configuration mode (config)

Examples

The following example shows how to enable CPU alarms:

```
Device> enable
Device# configure terminal
Device(config)# alarm cpu
```

alarm cpu threshold

To configure the threshold information for CPU alarms, use the **alarm cpu threshold** command in global configuration mode.

```
alarm cpu threshold {busy busy-value | unbusy unbusy-value}
```

Syntax Description		
	busy <i>busy-value</i>	Sets the minimum CPU utilization threshold.
	unbusy <i>unbusy-value</i>	Sets the maximum CPU utilization threshold.

Command Modes Global configuration mode (config)

Examples

The following example shows how to set the CPU thresholds using the **alarm cpu threshold** command:

```
Device> enable  
Device# configure terminal  
Device(config)# alarm cpu threshold busy 63 unbusy 20
```

buildrun mode

To configure the file execution mode, use the **buildrun mode** command in privileged EXEC mode.

buildrun mode {**continue** | **stop**}

Syntax Description

continue	Sets the execution mode to non-interruptible.
stop	Sets the execution mode to interruptible.

Command Modes

Privileged EXEC (#)

Examples

The following is an example of the **buildrun mode stop** command:

```
Device> enable
Device# buildrun mode stop
```

clear startup-config

To clear the startup configuration, use the **clear startup-config** command in privileged EXEC mode.

clear startup-config

Command Modes

Privileged EXEC (#)

Examples

The following is an example of the **clear startup-config** command:

```
Device> enable
Device# clear startup-config
```


clock timezone

To configure the system time zone, use the **clock timezone** command in global configuration mode.

```
clock timezone timezone-name hours-offset minutes-offset  
no clock timezone
```

Syntax Description		
	<i>timezone-name</i>	Specifies the timezone to the SNTP client.
	<i>hours-offset</i> <i>minutes-offset</i>	Specifies the hours and minutes offset from the timezone to the SNTP client.

Command Modes Global configuration mode (config)

Examples

The following example shows how to configure a timezone on the SNTP client using the **clock timezone** command:

```
Device> enable  
Device# configure terminal  
Device(config)# clock timezone ch 3 43
```

copy running-config startup-config

To copy the current configuration to the flash config file, use the **copy running-config startup-config** command in privileged EXEC mode.

copy running-config startup-config

Command Modes

Privileged EXEC (#)

Examples

The following is an example of the **copy running-config startup-config** command:

```
Device> enable
Device# copy running-config startup-config
Startup config in flash will be updated, are you sure(y/n)? [n]
```

copy startup-config running-config

To copy the startup configuration from the flash config file to the current configuration, use the **copy startup-config running-config** command in privileged EXEC mode.

copy startup-config running-config

Command Modes

Privileged EXEC (#)

Examples

The following is an example of the **copy startup-config running-config** command:

```
Device> enable
Device# copy startup-config running-config
Running config will be updated, are you sure(y/n)? [n]
```

load ftp

To download a file with the FTP server, use the **load ftp** command in privileged EXEC mode.

load {**application** | **configuration** | **edfa** | **epld** | **keyfile**{**private** | **public**} | **ont-image** | **whole-bootrom**} **ftp** {**inet** | **inet6**} *ftp-server-ip-address file-name ftp-username ftp-password*

Syntax Description

application	Specifies the host file.
configuration	Specifies the configuration file.
edfa	Specifies the EDFA file.
epld	Specifies the EPLD file.
keyfile	Specifies the SSH keyfile.
private	Specifies the SSH private keyfile.
public	Specifies the SSH public keyfile.
ont-image	Specifies the ONT image file.
whole-bootrom	Specifies the whole bootrom file.
inet	Specifies IPv4 address family.
inet6	Specifies IPv6 address family.
<i>ftp-server-ip-address</i>	Specifies the IP address of the FTP server.
<i>file-name</i>	Specifies the name of the file to be uploaded.
<i>ftp-username</i>	Specifies the user name of the FTP server.
<i>ftp-password</i>	Specifies the password of the FTP server.

Command Modes

Privileged EXEC (#)

Examples

The following example shows how to download a whole bootrom file with an FTP server using the **load ftp** command:

```
Device> enable
Device# load whole-bootrom tftp inet 10.23.13.1 bootrom1.bin
```

load tftp

To download a file with the TFTP server, use the **load tftp** command in privileged EXEC mode.

load {**application** | **configuration** | **edfa** | **epld** | **keyfile** {**private** | **public**} | **ont-image** | **whole-bootrom**} **tftp** {**inet** | **inet6**} *tftp-server-ip-address* *file-name*

Syntax Description		
application		Specifies the host file.
configuration		Specifies the configuration file.
edfa		Specifies the EDFA file.
epld		Specifies the EPLD file.
keyfile		Specifies the SSH keyfile.
private		Specifies the SSH private keyfile.
public		Specifies the SSH public keyfile.
ont-image		Specifies the ONT image file.
whole-bootrom		Specifies the whole bootrom file.
inet		Specifies IPv4 address family.
inet6		Specifies IPv6 address family.
<i>tftp-server-ip-address</i>		Specifies the IP address of the TFTP server.
<i>file-name</i>		Specifies the name of the file to be uploaded.

Command Modes Privileged EXEC (#)

Examples

The following example shows how to download a whole bootrom file with a TFTP server using the **load tftp** command:

```
Device> enable
Device# load whole-bootrom tftp inet6 10:23::11:1 bootrom1.bin
```

load xmodem

To download a file with the XMODEM, use the **load ftp** command in privileged EXEC mode.

load {application | configuration | whole-bootrom} xmodem

Syntax Description

application	Specifies the host file.
configuration	Specifies the configuration file.
whole-bootrom	Specifies the whole bootrom file.

Command Modes

Privileged EXEC (#)

Examples

The following example shows how to download a whole bootrom file with an XMODEM using the **load xmodem** command:

```
Device> enable
Device# load whole-bootrom xmodem
```

local fec

To enable the ONT uplink FEC, use the **local fec** command in line profile configuration mode. To disable the ONT uplink FEC, use the **no local fec** command.

local fec

no local fec

Command Modes

Line profile configuration (deploy-profile-line)

Examples

This example shows how to enable the ONT uplink FEC

```
Device> enable
Device# configure terminal
Device(config)# deploy profile line
Device(config-profile-line)# aim 5
Device(config-profile-line-5)# local fec
```

show alarm all-packets

To display the port alarm information, use the **show alarm all-packets** command in global configuration mode or interface configuration mode.

```
show alarm all-packets [{interface port-number}]
```

Syntax Description	interface <i>port-number</i>	Specifies the interface.
---------------------------	-------------------------------------	--------------------------

Command Modes	Global configuration mode (config) Interface configuration mode (config-if)
----------------------	--

Examples	The following is a sample output of the show alarm all-packets command:
-----------------	--

show alarm cpu

To display the CPU alarm information, use the **show alarm all-packets** command in global configuration mode.

show alarm cpu

Command Modes

Global configuration mode (config)

Examples

The following is a sample output of the **show alarm cpu** command:

```
Device(config)# show alarm cpu
CPU status alarm : enable
CPU busy threshold(%) : 90
CPU unbusy threshold(%) : 85
CPU status : unbusy
```

show clock

To display the system clock, use the **show clock** command in global configuration mode.

show clock

Command Modes

Global configuration mode (config)

Examples

The following is a sample output of the **show clock** command:

```
Device> enable
Device# configure terminal
Device(config)# show clock
Mon 2020/4/30 04:25:07 CCT 08:00
```

show running-config

To display the current system configuration, use the **show running-config** command in the privileged EXEC mode or global configuration mode.

show running-config {*module* | **interface** {**ethernet** *port-id* | **gpon** *port-id* | **loopback-interface** *loopback-interface-number* | **vlan-interface** *vlan-id*}} **perlines** *lines-per-page*

Syntax Description		
	<i>module</i>	Specifies a module.
	interface	Specifies an interface.
	ethernet <i>port-id</i>	Displays the ethernet port configuration.
	gpon <i>port-id</i>	Displays the GPON port configuration.
	loopback-interface <i>loopback-interface-number</i>	Displays the loopback interface configuration.
	vlan-interface <i>vlan-id</i>	Displays the VLAN configuration.
	perlines <i>lines-per-page</i>	Specifies the number of lines displayed per page.

Command Modes

Privileged EXEC (#)

Global configuration mode (config)

Examples

The following is a sample output from the **show running-config interface vlan-interface** command:

```
Device> enable
Device# show running-config interface vlan-interface

Building configuration...
![vlan-interface 1]
ip address range 192.0.2.254 192.0.2.255
description interfacel
![vlan-interface 100]
ip address 10.75.171.17 255.255.255.0
end
```

show sntp client

To display SNTP client configurations, use the **show sntp client** command in global configuration mode.

show sntp client

Command Modes

Global configuration mode (config)

Examples

The following is a sample output of the **show sntp client** command:

```
Device> enable
Device# configure terminal
Device(config)# show sntp client
Clock state : synchronized          Current mode : anycast
Use server : 192.168.1.99           State : idle
Server state : synchronized        Server stratum : 1
Retrans-times: 3                   Retrans-interval: 30s
Authenticate : enable              Authentication-key: 1
Poll interval : 1000s
Last synchronized time: THU NOV 26 09:22:25 2015
```

show sntp client summer-time

To display the daylight savings time configuration, use the **show sntp client summer-time** command in global configuration mode.

show sntp client summer-time

Command Modes

Global configuration mode (config)

Examples

The following is a sample output of the **show sntp client summer-time** command:

```
Device> enable
Device# configure terminal
Device(config)# show sntp client summer-time
```

show startup-config

To display the startup configuration, use the **show startup-config** command in the privileged EXEC mode or global configuration mode.

show startup-config {*module* | **interface** {**ethernet** *port-id* | **gpon** *port-id* | **loopback-interface** *loopback-interface-number* | **vlan-interface** *vlan-id*}} **perlines** *lines-per-page*

Syntax Description		
	<i>module</i>	Specifies a module.
	interface	Specifies an interface.
	ethernet <i>port-id</i>	Displays the ethernet port configuration.
	gpon <i>port-id</i>	Displays the GPON port configuration.
	loopback-interface <i>loopback-interface-number</i>	Displays the loopback interface configuration.
	vlan-interface <i>vlan-id</i>	Displays the VLAN configuration.
	perlines <i>lines-per-page</i>	Specifies the number of lines displayed per page.

Command Modes Privileged EXEC (#)
Global configuration mode (config)

Examples

The following is a sample output from the **show startup-config interface ethernet** command:

```
Device> enable
Device# show startup-config interface ethernet

Building configuration...
![ethernet 1/1]
channel-group 2 mode on
lACP port-priority 8
description text
switchport hybrid untagged vlan 2-125
igmp-snooping record-host
ip-source-guard ip-mac-vlan
![ethernet 1/2]
switchport hybrid tagged vlan 35,335
switchport hybrid untagged vlan 2-34,36-125,2501-2502
![ethernet 1/3]
switchport default vlan 100
switchport hybrid untagged vlan 2-125
![ethernet 1/4]
priority 2
![ethernet 2/1]
switchport hybrid untagged vlan 2-125
![ethernet 2/2]
switchport hybrid untagged vlan 2-125
end
```

snmp client

To enable SNMP client, use the **snmp client** command in global configuration mode.

snmp client

no snmp client

Command Modes

Global configuration mode (config)

Examples

The following example shows how to enable SNMP client:

```
Device> enable
Device# configure terminal
Device(config)# snmp client
```

sntp client authenticate

To enable authentication of time sources, use the **sntp client authenticate** command in global configuration mode.

sntp client authenticate
no sntp client authenticate

Command Modes

Global configuration mode (config)

Examples

The following example shows how to enable SNTP client authentication using the **sntp client authenticate** command:

```
Device> enable
Device# configure terminal
Device(config)# sntp client authenticate
```


sntp client authentication-key

To configure the password for authentication for trusted time sources, use the **sntp client authentication-key** command in global configuration mode.

sntp client authentication-key *key-number* **md5** *md5-key*
no sntp client authentication-key *key-number*

Syntax Description		
	<i>key-number</i>	Specifies the authentication key for the SNTP client.
	md5 <i>md5-key</i>	Specifies the MD5 authentication key for the SNTP client.

Command Modes Global configuration mode (config)

Examples

The following example shows how to configure SNTP client authentication using the **sntp client authentication-key** command:

```
Device> enable
Device# configure terminal
Device(config)# sntp client authentication-key 3 md5 5
```

sntp client broadcastdelay

To configure the broadcast propagation delay for an SNTP client, use the **sntp client broadcastdelay** command in global configuration mode.

sntp client broadcastdelay *delay-time*

Syntax Description	<i>delay-time</i>	Specifies the round-trip broadcast delay for the SNTP client in milliseconds.
---------------------------	-------------------	---

Command Modes Global configuration mode (config)

Examples

The following example show how to configure the delay time for the SNTP client using the **sntp client broadcastdelay** command:

```
Device> enable
Device# configure terminal
Device(config)# sntp client broadcastdelay 15
```

snmp client mode

To configure the mode of function of the SNMP client, use the **snmp client mode** command in global configuration mode.

snmp client mode {**anycast** {[**key** *key-id*]} | **broadcast** | **multicast** | **unicast**}

Syntax Description		
	anycast	Sets the SNMP client to work in anycast mode.
	key <i>key-id</i>	Specifies the authentication key for anycast mode.
	broadcast	Sets the SNMP client to work in broadcast mode.
	multicast	Sets the SNMP client to work in multicast mode.
	unicast	Sets the SNMP client to work in unicast mode.

Command Modes

Global configuration mode (config)

Examples

The following example show how to configure the SNMP client to unicast mode using the **snmp client mode** command:

```
Device> enable
Device# configure terminal
Device(config)# snmp client mode unicast
```

sntp client poll-interval

To configure the polling interval for an SNTP client, use the **sntp client poll-interval** command in global configuration mode.

sntp client poll-interval *poll-interval-time*

Syntax Description	<i>poll-interval-time</i>	Specifies the polling interval for the SNTP client in seconds.
---------------------------	---------------------------	--

Command Modes Global configuration mode (config)

Examples

The following example show how to configure the polling interval for the SNTP client using the **sntp client poll-interval** command:

```
Device> enable
Device# configure terminal
Device(config)# sntp client poll-interval 800
```

snmp client retransmit-interval

To configure the timeout retransmission interval for an SNMP client, use the **snmp client retransmit-interval** command in global configuration mode.

snmp client retransmit-interval *retransmit-interval-time*

Syntax Description	<i>retransmit-interval-time</i>	Specifies the timeout retransmission interval for the SNMP client in seconds.
---------------------------	---------------------------------	---

Command Modes	Global configuration mode (config)
----------------------	------------------------------------

Usage Guidelines	The configured timeout retransmission mechanism takes effect only when the SNMP client works in the unicast or anycast mode.
-------------------------	--

Examples

The following example show how to configure the retransmission interval for the SNMP client using the **snmp client retransmit-interval** command:

```
Device> enable
Device# configure terminal
Device(config)# snmp client retransmit-interval 8
```

sntp client retransmit

To configure the number of timeout retransmission attempts for an SNTP client, use the **sntp client retransmit** command in global configuration mode.

sntp client retransmit *number*

Syntax Description

number

Specifies the number of timeout retransmission attempts for the SNTP client.

Command Modes

Global configuration mode (config)

Usage Guidelines

The configured timeout retransmission mechanism takes effect only when the SNTP client works in the unicast or anycast mode.

Examples

The following example show how to configure the number of retransmission attempts for the SNTP client using the **sntp client retransmit-interval** command:

```
Device> enable
Device# configure terminal
Device(config)# sntp client retransmit 5
```

sntp client summer-time dayly

To set the SNTP client daylight savings time daily, use the **sntp client summer-time dayly** command in global configuration mode.

sntp client summer-time dayly *start-month start-date start-time end-month end-date end-time*

no sntp client summer-time dayly

Syntax Description		
	<i>start-month</i>	Specifies the start month for daylight savings.
	<i>start-date</i>	Specifies the start date for daylight savings.
	<i>start-time</i>	Specifies the start time for daylight savings.
	<i>end-month</i>	Specifies the end month for daylight savings.
	<i>end-date</i>	Specifies the end date for daylight savings.
	<i>end-time</i>	Specifies the end time for daylight savings.

Command Modes

Global configuration mode (config)

Examples

The following example show how to configure the daylight savings daily for the SNTP client using the **sntp client summer-time dayly** command:

```
Device> enable
Device# configure terminal
Device(config)# sntp client summer-time dayly 3 25 12:00:00 7 25 12:00:00
```

sntp client summer-time weekly

To set the SNTP client daylight savings time weekly, use the **sntp client summer-time weekly** command in global configuration mode.

sntp client summer-time weekly *start-month start-week start-day start-time end-month end-week end-day end-time*

no sntp client summer-time weekly

Syntax Description

<i>start-month</i>	Specifies the start month for daylight savings.
<i>start-week</i>	Specifies the start week for daylight savings.
<i>start-day</i>	Specifies the start day for daylight savings.
<i>start-time</i>	Specifies the start time for daylight savings.
<i>end-month</i>	Specifies the end month for daylight savings.
<i>end-week</i>	Specifies the end week for daylight savings.
<i>end-day</i>	Specifies the end day for daylight savings.
<i>end-time</i>	Specifies the end time for daylight savings.

Command Modes

Global configuration mode (config)

Examples

The following example show how to configure the daylight savings weekly for the SNTP client using the **sntp client summer-time weekly** command:

```
Device> enable
Device# configure terminal
Device(config)# sntp client summer-time weekly 3 3 mon 12:00:00 7 3 fri 12:00:00
```


sntp client valid-server

To configure a legal server list for the SNTP client, use the **sntp client valid-server** command in global configuration mode.

```
sntp client valid-server ip-address wildcard-ip-address  
no sntp client valid-server {all | ip-address wildcard-ip-address}
```

Syntax Description		
	<i>ip-address</i>	Specifies the IP address of the valid SNTP server.
	<i>wildcard-ip-address</i>	Specifies the IP address of the wildcard SNTP server.

Command Modes Global configuration mode (config)

Examples

The following example shows how to configure the valid SNTP servers for an SNTP client using the **sntp client valid-server** command:

```
Device> enable  
Device# configure terminal  
Device(config)# sntp client valid-server 10.23.23.1 23.1.1.4
```

sntp server

To set SNTP server configurations, use the **sntp server** command in global configuration mode.

```
sntp server {ip-address | backup ip-address | key key-number}
```

Syntax Description		
	<i>ip-address</i>	Specifies the IP address of the SNTP server.
	backup <i>ip-address</i>	Specifies the IP address of the SNTP backup server.
	key <i>key-number</i>	Specifies the authentication key for the SNTP server.

Command Modes Global configuration mode (config)

Examples

The following example shows how to configure the SNTP server using the **sntp server** command:

```
Device> enable
Device# configure terminal
Device(config)# sntp server 12.2.2.1
```

snmp trusted-key

To configure a trusted password for multicast and broadcast modes, use the **snmp trusted-key** command in global configuration mode.

```
snmp trusted-key key-number  
no snmp trusted-key key-number
```

Syntax Description	<i>key-number</i>	Specifies the trusted key for the SNMP client.
---------------------------	-------------------	--

Command Modes Global configuration mode (config)

Examples

The following example shows how to configure SNMP client trusted key authentication using the **snmp trusted-key** command:

```
Device> enable  
Device# configure terminal  
Device(config)# snmp trusted-key 243586
```

upload automatically configuration ftp

To automatically upload a configuration file at regular intervals with the FTP server, use the **upload automatically configuration ftp** command in privileged EXEC mode.

upload automatically configuration ftp {**inet** | **inet6**}*ftp-server-ip-address file-name ftp-username ftp-password***per hours** *hours* **minutes** *minutes*

Syntax Description		
	inet	Specifies IPv4 address family.
	inet6	Specifies IPv6 address family.
	<i>ftp-server-ip-address</i>	Specifies the IP address of the FTP server.
	<i>file-name</i>	Specifies the name of the file to be uploaded.
	<i>ftp-username</i>	Specifies the user name of the FTP server.
	<i>ftp-password</i>	Specifies the password of the FTP server.
	per hours <i>hours</i> minutes <i>minutes</i>	Specifies the time interval in hours and minutes after which the configuration file is to be automatically uploaded.

Command Modes Privileged EXEC (#)

Examples

The following example shows how to upload a configuration file using the **upload automatically configuration tftp** command:

```
Device> enable
Device# upload automatically configuration ftp inet 10.23.13.1 config3.txt per hours 12
minutes 10
```

upload automatically configuration tftp

To automatically upload a configuration file at regular intervals with the TFTP server, use the **upload automatically configuration tftp** command in privileged EXEC mode.

upload automatically configuration tftp {**inet** | **inet6**} *tftp-server-ip-address* *file-name* **per hours** *hours* **minutes** *minutes*

Syntax Description		
	inet	Specifies IPv4 address family.
	inet6	Specifies IPv6 address family.
	<i>tftp-server-ip-address</i>	Specifies the IP address of the TFTP server.
	<i>file-name</i>	Specifies the name of the file to be uploaded.
	per hours <i>hours</i> minutes <i>minutes</i>	Specifies the time interval in hours and minutes after which the configuration file is to be automatically uploaded.

Command Modes Privileged EXEC (#)

Examples

The following example shows how to upload a configuration file using the **upload automatically configuration tftp** command:

```
Device> enable
Device# upload automatically configuration tftp inet 10.23.13.1 config2.txt per hours 20
minutes 30
```

upload ftp

To upload a file with the FTP server, use the **upload ftp** command in privileged EXEC mode.

```
upload {application | configuration | keyfile{private | public} | logging}ftp {inet | inet6}ftp-server-ip-address file-name ftp-username ftp-password
```

Syntax Description		
application		Specifies the host file.
configuration		Specifies the configuration file.
keyfile		Specifies the SSH keyfile.
private		Specifies the SSH private keyfile.
public		Specifies the SSH public keyfile.
logging		Specifies the log file.
inet		Specifies IPv4 address family.
inet6		Specifies IPv6 address family.
<i>ftp-server-ip-address</i>		Specifies the IP address of the FTP server.
<i>file-name</i>		Specifies the name of the file to be uploaded.
<i>ftp-username</i>		Specifies the user name of the FTP server.
<i>ftp-password</i>		Specifies the password of the FTP server.

Command Modes Privileged EXEC (#)

Examples

The following example shows how to upload a host file with an FTP server using the **upload ftp** command:

```
Device> enable
Device# upload application ftp 192.168.1.99 host.arj rr 142
```

upload tftp

To upload a file with the TFTP server, use the **upload tftp** command in privileged EXEC mode.

```
upload {application | configuration | keyfile{private | public} | logging} tftp {inet | inet6} tftp-server-ip-address file-name
```

Syntax Description		
application		Specifies the host file.
configuration		Specifies the configuration file.
keyfile		Specifies the SSH keyfile.
private		Specifies the SSH private keyfile.
public		Specifies the SSH public keyfile.
logging		Specifies the log file.
inet		Specifies IPv4 address family.
inet6		Specifies IPv6 address family.
<i>tftp-server-ip-address</i>		Specifies the IP address of the TFTP server.
<i>file-name</i>		Specifies the name of the file to be uploaded.

Command Modes Privileged EXEC (#)

Examples

The following example shows how to upload a configuration file with a TFTP server using the **upload tftp** command:

```
Device> enable
Device# upload application tftp 192.168.1.99 text.txt
```




PART **X**

ONT Device Configuration

- [ONT Device Configuration, on page 443](#)



ONT Device Configuration

- [alarm profile refer](#), on page 444
- [clear ont-logging buffer](#), on page 445
- [local bandwidth egress](#), on page 446
- [local loop-detect](#), on page 447
- [local mac-address-table](#), on page 448
- [local neg-mode](#), on page 449
- [local ranging-balance](#), on page 450
- [local shutdown](#), on page 451
- [local switch](#), on page 452
- [ont-logging](#), on page 453
- [ont-logging buffer](#), on page 454
- [ont-logging monitor](#), on page 455
- [ont-logging prefix](#), on page 456
- [ont-logging timestamps](#), on page 457
- [ont active](#), on page 458
- [ont deactive](#), on page 459
- [ont neg-mode](#), on page 460
- [ont reboot](#), on page 461
- [ont shutdown](#), on page 462
- [ont upgrade](#), on page 463
- [optical power rx threshold](#) , on page 464
- [show ont-logging](#), on page 465
- [show ont-logging buffer](#), on page 466
- [show ont mac-address-table](#), on page 467
- [show ont port-status](#), on page 468
- [show ont statistics](#), on page 469
- [show ont upgrade-status](#), on page 470
- [show ont version](#), on page 471

alarm profile refer

To refer an alarm profile to a line profile, use the **alarm profile refer** command in line profile configuration mode.

alarm profile refer *{index_num | name name}*

Syntax Description		
<i>index_num</i>	The alarm profile index number.	The range is from 1 to 127.
<i>name</i>	The alarm profile name.	The unit is string. The string length is from 1 to 128.

Command Modes Line profile configuration (deploy-profile-line)

Examples

This example shows how to refer an alarm profile to a line profile

```
Device> enable
Device# configure terminal
Device(config)# deploy profile line
Device(deploy-profile-line)# aim 5
Device(deploy-profile-line-5)# alarm profile refer 1
```

clear ont-logging buffer

To clear the ont logging buffer, use the **clear ont-logging buffer** command in global configuration mode.

```
clear ont-logging buffer {ont_id_list | all}
```

Syntax Description

<i>ont_id_list</i>	The list of ONT IDs.
all	All ONTs.

Command Modes

Global configuration (config)

Examples

This example shows how to clear the ONT log buffering

```
Device> enable  
Device# configure terminal  
Device(config)# clear ont-logging buffer all
```

local bandwidth egress

To configure the ONT bandwidth egress, use the **local bandwidth egress port *port_id* cir *cir* cbs *cbs* pir *pir* pbs *pbs*** command in line profile configuration mode. To disable the ONT bandwidth egress, use the **no local bandwidth egress port *port_id*** command.

local bandwidth egress port *port_id* cir *cir* cbs *cbs* pir *pir* pbs *pbs*

no local bandwidth egress port *port_id*

Syntax Description		
<i>port_id</i>		The ONT Ethernet port ID. The range is from 1 to 24.
cir <i>cir</i>		The committed information rate in kbps. The value range is from 64 to 1024000.
cbs <i>cbs</i>		The committed burst size in KB. The value range is from 2 to 32000.
pir <i>pir</i>		The peak information rate in kbps. The value range is from 64 to 1024000 where the PIR requirement is greater than or equal to CIR.
pbs <i>pbs</i>		The peak burst size in KB. The value range is from 2 to 32000.

Command Modes Line profile configuration (deploy-profile-line)

Examples

This example shows how to configure the ONT bandwidth egress.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile line
Device(deploy-profile-line)# aim 5
Device(deploy-profile-line-5)# local bandwidth egress port 3 cir 200 cbs 70 pir 1024 pbs
90
```

local loop-detect

To enable local loop-detect, use the **local loop-detect** command in line profile configuration mode. To disable local loop-detect, use the **no local loop-detect** command.

local loop-detect

no local loop-detect

Command Modes

Line profile configuration (deploy-profile-line)

Examples

This example shows how to enable local loop-detect

```
Device> enable
Device# configure terminal
Device(config)# deploy profile line
Device(deploy-profile-line)# aim 5
Device(deploy-profile-line-5)# local loop-detect
```

local mac-address-table

To configure the ONT maximum MAC count, use the **local mac-address-table** command in line profile configuration mode. To disable the ONT maximum MAC count, use the **no local mac-address-table** command.

local mac-address-table max-mac-count *max_mac_count* [**port** *port_id*]

no local mac-address-table

Syntax Description		
	<i>max_mac_count</i>	The maximum MAC address learning count. The range is from 1 to 255.
	<i>port_id</i>	The ONT Ethernet port ID. The range is from 1 to 24.

Command Modes Line profile configuration (deploy-profile-line)

Examples

This example shows how to configure the ONT maximum MAC count.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile line
Device(deploy-profile-line)# aim 5
Device(deploy-profile-line-5)# local mac-address-table max-mac-count 12
```


local neg-mode

To configure the local Ethernet speed and duplex, use the **local neg-mode speed *speed* duplex *duplex_mode* port *port_id*** command in unique profile configuration mode.

local neg-mode speed *speed* duplex *duplex_mode* port *port_id*

Syntax	Description
<i>speed</i>	The ONT Ethernet port rate mode. The options are <ul style="list-style-type: none"> • 10M • 100M • 1000M • Auto-negotiation
<i>duplex_mode</i>	The ONT Ethernet port duplex mode. The options are <ul style="list-style-type: none"> • Full-duplex • Half-duplex • Auto-negotiation
<i>port_id</i>	The ONT Ethernet port ID. The range is from 1 to 24.

Command Modes Unique profile configuration (deploy-profile-unique)

Examples

This example shows how to configure the local Ethernet speed and duplex

```
Device> enable
Device# configure terminal
Device(config)# deploy profile unique
Device(deploy-profile-unique)# aim 0/1/1
Device(deploy-profile-unique-0/1/1)# local neg-mode speed 10 duplex half port 3
```

local ranging-balance

To configure ONT range compensation, use the **local ranging-balance** command in unique profile configuration mode. To disable the ONT range compensation, use the **no local ranging-balance** command.

local ranging-balance {**decrease** | **increase**} *balance_length*

no local ranging-balance

Syntax	Description
decrease	Decreases the range compensation.
increase	Increases the range compensation.
<i>balance_length</i>	The ONT ranging compensation value The unit is meters. The range is from 1 to 10000.

Command Modes Unique profile configuration (deploy-profile-unique)

Examples

This example shows how to increase ONT range compensation

```
Device> enable
Device# configure terminal
Device(config)# deploy profile unique
Device(deploy-profile-unique)# aim 0/1/1
Device(deploy-profile-unique-0/1/1)# local ranging-balance increase 2000
```

local shutdown

To configure the ONT local shutdown, use the **local shutdown** command in unique profile configuration mode. To disable the ONT local shutdown, use the **no local shutdown** command.

local shutdown {port *port_id* | catv-port *catv_port_id*}

no local shutdown {port *port_id* | catv-port *catv_port_id*}

Syntax Description		
<i>port_id</i>	The ONT Ethernet UNI. The value range is from 1 to 24.	
<i>catv_port_id</i>	The ONT RF interface ID. The value range is from 1 to 4.	

Command Modes Unique profile configuration (deploy-profile-unique)

Examples

This example shows how to configure the ONT local shutdown.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile unique
Device(deploy-profile-unique)# aim 0/1/1
Device(deploy-profile-unique-0/1/1)# local shutdown port 2
```

local switch

To enable the ONT local switching, use the **local switch** command in line profile configuration mode. To disable the ONT local switching, use the **no local switch** command.

local switch

no local switch

Command Modes

Line profile configuration (deploy-profile-line)

Examples

This example shows how to enable the ONT local switching.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile line
Device(deploy-profile-line)# aim 5
Device(deploy-profile-line-5)# local switch
```

ont-logging

To enable ONT logging, use the **ont-logging** command in global configuration mode. To disable ONT logging, use the **no ont-logging** command.

ont-logging

no ont-logging

Command Modes

Global configuration (config)

Examples

This example shows how to enable ONT logging.

```
Device> enable
Device# configure terminal
Device(config)# ont-logging
```

ont-logging buffer

To save the ONT log to a buffer, use the **ont-logging buffer** command in global configuration mode. To disable the ONT logging buffer, use the **no ont-logging buffer** command.

ont-logging buffer {*ont_id_list* | **all**}

no ont-logging buffer

Syntax Description		
	<i>ont_id_list</i>	The list of ONT IDs.
	all	All ONTs.

Command Modes Global configuration (config)

Examples

This example shows how to enable the ONT log buffering.

```
Device> enable
Device# configure terminal
Device(config)# ont-logging buffer all
```

ont-logging monitor

To enable monitor for ONT logs, use the **ont-logging monitor** command in global configuration mode. To disable monitor for ONT logs, use the **no ont-logging monitor** command.

```
ont-logging monitor {monitor_number | all} {ont_id_list | all}
```

```
no ont-logging monitor {monitor_number | all} {ont_id_list | all}
```

Syntax Description		
	<i>monitor_number</i>	The monitor number. The range is from 0 to 5, where 0 is the console and 1 to 5 is the telnet terminal.
	<i>ont_id_list</i>	The list of ONT IDs.
	all	All ONTs.

Command Modes Global configuration (config)

Examples

This example shows how to enable the ONT log monitor

```
Device> enable  
Device# configure terminal  
Device(config)# ont-logging monitor all all
```

ont-logging prefix

To configure log prefixes, use the **ont-logging prefix** command in global configuration mode. To disable log prefixing, use the **no ont-logging prefix** command.

ont-logging prefix {ontid | sn}

no ont-logging prefix

Syntax Description

ontid	The ONT IDs.
sn	The ONT serial number.

Command Modes

Global configuration (config)

Examples

This example shows how to enable the ONT log prefixing

```
Device> enable
Device# configure terminal
Device(config)# ont-logging prefix ontid
```


ont-logging timestamps

To enable log timestamps of an ONT, use the **ont-logging timestamps** command in global configuration mode.

ont-logging timestamps {uptime | notime | datetime}

Syntax Description		
	uptime	Configures logging with uptime duration.
	notime	Configures logging with no time.
	datetime	Configures logging with date and time

Command Modes Global configuration (config)

Examples

This example shows how to enable log timestamps of an ONT

```
Device> enable
Device# configure terminal
Device(config)# ont-logging timestamps datetime
```

ont active

To activate the ONT, use the **ont active** *ont_id_list* command in global configuration mode.

ont active *ont_id_list*

Syntax Description	<i>ont_id_list</i>	The list of ONT IDs.
--------------------	--------------------	----------------------

Command Modes Global configuration (config)

Examples

This example show how to activate the ONT.

```
Device> enable
Device# configure terminal
Device(config)# ont active 0/1/1
Config success: 1, failed: 0.
```

Related Commands	Command	Description
	ont deactivate	Deactivates the ONT.

ont deactivate

To deactivate the ONT, use the **ont deactivate** *ont_id_list* in global configuration mode.

ont deactivate *ont_id_list*

Syntax Description	<i>ont_id_list</i>	The list of ONT IDs.
--------------------	--------------------	----------------------

Command Modes Global configuration (config)

Examples

This example show how to deactivate the ONT.

```
Device> enable
Device# configure terminal
Device(config)# ont deactivate 0/1/1
Config success: 1, failed: 0.
```

Related Commands	Command	Description
	ont active	Activates the ONT.

ont neg-mode

To configure the ONT speed and duplex, use the **ont neg-mode speed *speed* duplex *duplex_mode* slot-num/pon-num/ont-num port *port_id*** command in global configuration mode.

ont neg-mode speed *speed* duplex *duplex_mode* slot-num/pon-num/ont-num port *port_id*

Syntax	Description
<i>speed</i>	The ONT Ethernet port rate mode. The options are <ul style="list-style-type: none"> • 10M • 100M • 1000M • Auto-negotiation
<i>duplex_mode</i>	The ONT Ethernet port duplex mode. The options are <ul style="list-style-type: none"> • Full-duplex • Half-duplex • Auto-negotiation
<i>slot-num/pon-num/ont-num</i>	The ONT ID. <ul style="list-style-type: none"> • <i>slot-num</i>: The slot number. The value is 0. • <i>pon-num</i>: The PON number. The range is from 1 to 8. • <i>ont-num</i>: The ONT number. The range is from 1 to 128.
<i>port_id</i>	The ONT Ethernet port ID. The range is from 1 to 24.

Command Modes Global configuration (config)

Examples

This example shows how to configure the ONT speed and duplex

```
Device> enable
Device# configure terminal
Device(config)# ont neg-mode speed 10 duplex half 0/1/1 port 3
```

ont reboot

To reboot an ONT port, use the **ont reboot** command in global configuration mode.

ont reboot *slot-num/pon-num/ont-num*

Syntax Description

slot-num/pon-num/ont-num

The ONT ID.

- *slot-num*: The slot number. The value is 0.
 - *pon-num*: The PON number. The range is from 1 to 8.
 - *ont-num*: The ONT number. The range is from 1 to 128.
-

Command Modes

Global configuration (config)

Examples

This example shows how to reboot an ONT port.

```
Device> enable
Device# configure terminal
Device(config)# ont reboot 0/1/1
```

ont shutdown

To configure the ONT shutdown, use the **ont shutdown** command in global configuration mode. To disable ONT shutdown, use the **no ont shutdown** command.

ont shutdown *slot-num/pon-num/ont-num* **port** *port_id*

no ont shutdown *slot-num/pon-num/ont-num* **port** *port_id*

Syntax Description		
	<i>slot-num/pon-num/ont-num</i>	The ONT ID. <ul style="list-style-type: none"> • <i>slot-num</i>: The slot number. The value is 0. • <i>pon-num</i>: The PON number. The range is from 1 to 8. • <i>ont-num</i>: The ONT number. The range is from 1 to 128.
	<i>port_id</i>	The ONT Ethernet port ID. The range is from 1 to 24.

Command Modes Global configuration (config)

Examples

This example shows how to configure the ONT shutdown.

```
Device> enable
Device# configure terminal
Device(config)# ont shutdown 0/1/1 port 1
```

ont upgrade

To configure an ONT for reboot, use the **ont upgrade** command in global configuration mode.

ont upgrade {**auto-reboot** | **manual-reboot**} {*slot-num/pon-num/ont-num* | {**exclude** | **include**} | {**device-type** *device_type* | **software-version** *version*} | **sn** | {**string-hex** *string_serial_number* | **hex** *hex_serial_number*}}

Syntax	Description
auto-reboot	Automatically reboots the ONT.
manual-reboot	Manually reboots the ONT
<i>slot-num/pon-num/ont-num</i>	The ONT ID. <ul style="list-style-type: none"> • <i>slot-num</i>: The slot number. The value is 0. • <i>pon-num</i>: The PON number. The range is from 1 to 8. • <i>ont-num</i>: The ONT number. The range is from 1 to 128.
exclude	Excludes the ONT.
include	Includes the ONT.
device-type <i>device_type</i>	The device identifier.
software-version <i>version</i>	The software identifier.
<i>hex_serial_number</i>	The ONT serial number in Hex.
<i>string_serial_number</i>	The ONT serial number in string.

Command Modes Global configuration (config)

Examples

This example shows how to configure an ONT fo auto reboot

```
Device> enable
Device# configure terminal
Device(config)# ont upgrade auto-reboot 0/1/1
```

optical power rx threshold

To configure the threshold of the receive optical power, use the **optical power rx threshold** command in alarm profile configuration mode. To delete the threshold, use the **no optical power rx threshold** command.

optical power rx threshold {**high** *high_rx_power* | **low** *low_rx_power*}

no optical power rx threshold

Syntax	Description
<i>high_rx_power</i>	The highest threshold value. The value must be a multiple of 0.5. The unit is dBm. The range is from -127.0 to 0.0
<i>low_rx_power</i>	The lowest threshold value. The value must be a multiple of 0.5. The unit is dBm. The range is from -127.0 to 0.0

Command Modes Alarm profile configuration (deploy-profile-alarm)

Examples

This example shows how to configure the high threshold value of the receive optical power.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile alarm
Device(deploy-profile-alarm)# aim 5
Device(deploy-profile-alarm-5)# optical power rx threshold high 10
```


show ont-logging

To display the ONT logs, use the **show ont-logging** command in global configuration mode

show ont-logging

Command Modes

Global configuration (config)

Examples

This example shows how to view the ONT logs

```
Device> enable
Device# configure terminal
Device(config)# show ont-logging
logging state: on
logging timestamps: uptime
logging prefix: ontid:on; sn:on
logging buffer: 0/1/1-0/8/128
logging monitor:
 0: 0/1/1-0/8/128
 1: 0/1/1-0/8/128
 2: 0/1/1-0/8/128
 3: 0/1/2-0/8/128
 4: 0/1/1-0/8/128
 5: 0/1/1-0/8/128
```

show ont-logging buffer

To display information about ONT logging buffer, use the **show ont-logging buffer** command in global configuration mode.

show ont-logging buffer {*slot-num/pon-num/ont-num* | **all**}

Syntax Description	<i>slot-num/pon-num/ont-num</i>	The ONT ID.
		<ul style="list-style-type: none"> • <i>slot-num</i>: The slot number. The value is 0. • <i>pon-num</i>: The PON number. The range is from 1 to 8. • <i>ont-num</i>: The ONT number. The range is from 1 to 128.
	all	All ONTs

Command Modes Global configuration (config)

Examples

This example shows how to view the information about ONT logging buffer

```
Device> enable
Device# configure terminal
Device(config)# show ont-logging buffer 0/1/1
32 day 04:28:34 0/1/1 GPON-5a946e77: offline, reason: LOSI.
32 day 04:28:34 0/1/1 GPON-5a946e77: LOAMi on.
32 day 04:28:34 0/1/1 GPON-5a946e77: LOFi on.
32 day 04:28:34 0/1/1 GPON-5a946e77: LOSi on.
32 day 04:28:31 0/1/1 GPON-5a946e77: eth port 1 los on.
32 day 02:58:03 0/1/1 GPON-5a946e77: eth port 1 los off.
32 day 02:58:00 0/1/1 GPON-5a946e77: eth port 1 los on.
31 day 23:28:51 0/1/1 GPON-5a946e77: eth port 1 los off.
31 day 23:28:47 0/1/1 GPON-5a946e77: eth port 1 los on.
26 day 07:26:06 0/1/1 GPON-5a946e77: eth port 1 los off.
26 day 07:26:04 0/1/1 GPON-5a946e77: eth port 1 los on.
26 day 04:14:38 0/1/1 GPON-5a946e77: eth port 1 los off.
26 day 04:14:36 0/1/1 GPON-5a946e77: eth port 1 los on.
26 day 03:57:30 0/1/1 GPON-5a946e77: eth port 1 los off.
26 day 03:57:27 0/1/1 GPON-5a946e77: eth port 1 los on.
26 day 03:57:15 0/1/1 GPON-5a946e77: eth port 1 los off.
25 day 05:33:41 0/1/1 GPON-5a946e77: eth port 1 los on.
25 day 05:33:31 0/1/1 GPON-5a946e77: eth port 1 los off.
25 day 05:33:30 0/1/1 GPON-5a946e77: eth port 1 los on.
24 day 23:51:33 0/1/1 GPON-5a946e77: eth port 1 los off.
24 day 23:51:30 0/1/1 GPON-5a946e77: eth port 1 los on.
24 day 23:51:17 0/1/1 GPON-5a946e77: eth port 1 los off.
21 day 08:12:36 0/1/1 GPON-5a946e77: eth port 1 los on.
21 day 08:12:28 0/1/1 GPON-5a946e77: eth port 1 los off.
!
!
!
output truncated
```

show ont mac-address-table

To display information about the MAC address table of an ONT, use the **show ont mac-address-table** command in global configuration mode.

show ont mac-address-table {*mac_address* | *slot-num/pon-num/ont-num* | **interface gpon** {*slot-number/port-number* | **all**}}

Syntax Description		
<i>mac_address</i>		The MAC address.
<i>slot-num/pon-num/ont-num</i>		The ONT ID. <ul style="list-style-type: none"> • <i>slot-num</i>: The slot number. The value is 0. • <i>pon-num</i>: The PON number. The range is from 1 to 8. • <i>ont-num</i>: The ONT number. The range is from 1 to 128.
<i>slot-number/port-number</i>		The port ID. <ul style="list-style-type: none"> • <i>slot-number</i>: <ul style="list-style-type: none"> • GPON: The value is 0. • GE Ethernet: The value is 1. • 10GE Ethernet: The value is 2. • <i>port-number</i>: <ul style="list-style-type: none"> • GPON: The range is from 1 to 8. • GE Ethernet: The range is from 1 to 4. • 10GE Ethernet: The range is from 1 to 2.
all		All ports.

Command Modes Global configuration (config)

Examples

This example shows how to view information about the MAC address table of an ONT

```
Device> enable
Device# configure terminal
Device(config)# show ont mac-address-table interface gpon 0/1
MAC-Address      VID  ONT-ID  SN          ID/GEM
00:0a:5a:a7:01:34 100  0/1/5   GPON-5aa7012a 4/355
Total entries: 1.
```

show ont port-status

To display status information of an ONT port, use the **show ont port-status** command in global configuration mode.

show ont port-status *slot-num/pon-num/ont-num* {**port** *port_id* | **catv-port** *catv_port_id*}

Syntax	Description
<i>slot-num/pon-num/ont-num</i>	The ONT ID. <ul style="list-style-type: none"> • <i>slot-num</i>: The slot number. The value is 0. • <i>pon-num</i>: The PON number. The range is from 1 to 8. • <i>ont-num</i>: The ONT number. The range is from 1 to 128.
<i>port_id</i>	The ONT Ethernet UNI. The value range is from 1 to 24.
<i>catv_port_id</i>	The ONT RF interface ID. The value range is from 1 to 4.

Command Modes Global configuration (config)

Examples

This example shows how to view the status information of an ONT port.

```
Device> enable
Device# configure terminal
Device(config)# show ont port-status 0/1/5 port 2
Port status is Enable, Linkdown
```

show ont statistics

To display statistical information about an ONT, use the **show ont statistics** command in global configuration mode.

```
show ont statistics slot-num/pon-num/ont-num {gem {broadcast | multicast | unicast gem_index } | {port port-id } | traffic}
```

Syntax Description		
<i>slot-num/pon-num/ont-num</i>	The ONT ID.	<ul style="list-style-type: none"> <i>slot-num</i>: The slot number. The value is 0. <i>pon-num</i>: The PON number. The range is from 1 to 8. <i>ont-num</i>: The ONT number. The range is from 1 to 128.
gem	Displays statistical information about GEM port data frames.	
broadcast	Displays statistical information about broadcast packets.	
multicast	Displays statistical information about multicast packets.	
unicast <i>gem_index</i>	Displays statistical information about unicast packets.	<i>gem_index</i> : The GEM port index number. The range is from 1 to 1024.
<i>port-id</i>	The ONT Ethernet port ID.	The range is from 1 to 24.
traffic	Displays statistical information about ONT uplink and downlink data frames.	

Command Modes Global configuration (config)

Examples

This example shows how to view the statistical information about an ONT.

```
Device> enable
Device# configure terminal
Device(config)# show ont statistics 0/1/1 port 1
Upstream frames : 0
Upstream bytes : 0
Downstream frames : 0
Downstream bytes : 0
Up traffic (kbps) : 0
Down traffic (kbps) : 0
```

show ont upgrade-status

To display the ONT upgrade status, use the **show ont upgrade-status** command in global configuration mode.

show ont upgrade-status {**image** | **xml**} {*slot-num/pon-num/ont-num* | **all**}

Syntax Description		
	<i>slot-num/pon-num/ont-num</i>	The ONT ID. <ul style="list-style-type: none"> • <i>slot-num</i>: The slot number. The value is 0. • <i>pon-num</i>: The PON number. The range is from 1 to 8. • <i>ont-num</i>: The ONT number. The range is from 1 to 128.
	all	All ports.

Command Modes Global configuration (config)

Examples

This example shows how to view the ONT upgrade status

```

evice> enable
Device# configure terminal
Device(config)# show ont upgrade-status image 0/1/1
ONT   Active-version Inactive-version Status
0/1/1 C01R544V00B09 C01R544V00B07  success
Total entries: 1.

```

show ont version

To display an ONT version, use the **show ont version** command in global configuration mode.

show ont version interface gpon *{port_list | all}*

Syntax Description

<i>port_list</i>	The GPON port.
all	All ports.

Command Modes

Global configuration (config)

Examples

This example shows how to view an ONT version

```
Device> enable
Device# configure terminal
Device(config)# show ont version interface gpon 0/1
ONT      SN                Software-version      Firmware-version
0/1/1    GPON-5a946e77      B01D001P010/B01D001P008  N40-428-1
0/1/2    GCOM-5a95efca     C01R539V00B19/-      S40-401
0/1/3    GPON-5aa0e950     B01D001P010/B01D001P007  N40-428-1
0/1/4    GPON-5aa0e9e0     B01D001P007/B01D001P006  N40-428-1
0/1/5    GPON-5aa7012a     1.1.2.5/1.1.2.6        N40-428-1
Total entries: 5.
```

 show ont version