



Collaboration Endpoint Software 8.2  
SEPTEMBER 2016



# Application Programming Interface (API) Reference Guide

Cisco TelePresence DX70 and DX80



## What's in this guide?

The top menu bar and the entries in the table of contents are all hyperlinks, just click on them to go to the topic.

We recommend you visit our web site regularly for updated versions of the user documentation.

Go to: <http://www.cisco.com/go/dx-docs>

## Table of Contents

<b>Introduction .....</b>	<b>3</b>	Commands .....	32
About this guide .....	4	Configurations .....	32
Downloading the user documentation .....	4	Status .....	32
What's new in CE8.2 .....	5	Events .....	33
New features and improvements .....	5	Feedback mechanism .....	34
xConfiguration changes in CE8.2 .....	7	Feedback expressions .....	34
xCommand changes in CE8.2 .....	9	Terminal connections .....	35
xStatus changes in CE8.2 .....	10	Using HTTP .....	36
What's new in CE8.1 .....	11	HTTP XMLAPI Authentication .....	36
New features and improvements .....	11	HTTP XMLAPI Session Authentication .....	36
xConfiguration changes in CE8.1 .....	12	Getting status and configurations .....	37
xCommand changes in CE8.2 .....	13	Sending commands and configurations .....	37
xStatus changes in CE8.2 .....	14	Using HTTP POST .....	37
What's new in CE8.0 .....	15	Feedback from codec over HTTP .....	38
New features and improvements .....	15	Registering for feedback .....	38
xConfiguration changes in CE8.0 .....	17	Translating from terminal mode to XML .....	39
xCommand changes in CE8.0 .....	20	Dos and don'ts .....	40
xStatus changes in CE8.0 .....	23	<b>xConfiguration commands .....</b>	<b>41</b>
<b>About the API .....</b>	<b>26</b>	<b>xCommand commands .....</b>	<b>86</b>
API fundamentals .....	27	<b>xStatus commands .....</b>	<b>121</b>
Connecting to the API .....	27	<b>Appendices .....</b>	<b>167</b>
Password .....	27	About startup scripts .....	168
Telnet .....	27	The SystemTools commands .....	169
SSH .....	27	About disconnect cause types .....	171
HTTP/HTTPS .....	28	User documentation on the Cisco web site .....	172
API output .....	29		
The output modes .....	29		
Using the command line .....	30		
API commands .....	30		
Other commands .....	30		
Command line shortcuts .....	31		
Searching .....	31		
Value types and formats .....	31		



## Chapter 1

# Introduction



## About this guide

This guide introduces you to the Application Programmer Interface (API) for the Collaboration Endpoint software, and serves as a reference guide for the command line commands for the following product:

- Cisco TelePresence DX70 and DX80

### Downloading the user documentation

You can download the user documentation from the Cisco web site, go to: [▶ http://www.cisco.com/go/dx-docs](http://www.cisco.com/go/dx-docs)

Guidelines for how to find the documentation on the Cisco web site are included in the [▶ User documentation on the Cisco web site](#) appendix.

## What's new in CE8.2

This section provides an overview of the new and changed system settings, and the new features and improvements in the Cisco Collaboration Endpoint software version 8.2 (CE8.2) compared to CE8.0.

The list of new commands includes all changes from CE8.0 to CE8.2.

As CE software is based on TC7, the structure and main functionality remains the same as in TC software.

For more details, we recommend reading the Software release notes:

▶ <http://www.cisco.com/c/en/us/support/collaboration-endpoints/desktop-collaboration-experience-dx600-series/products-release-notes-list.html>



**It is important to consider the upgrade requirements of CE8 before upgrading;** otherwise upgrading to CE8 can leave you with a non-functioning deployment that requires you to downgrade.

### New features and improvements

#### LDAP user management

In CE8.2, you can register users with ADMIN role from an external LDAP service to grant them access to the video system's web interface and API. This allows for centralized management of ADMIN users. The LDAP server can be configured from the web interface. Authenticating users with the USER role using LDAP is not supported.

LDAP configuration can be set from CUCM. If the video system requires a certificate for login from LDAP, it must be uploaded to the codec manually as CUCM is unable to provision certificates.

Administrator credentials not needed for remote pairing to a Touch 10

You no longer need to enter administrator credentials when you remote pair a Touch 10 controller to a video system. All user credentials can be used for this purpose. The administrator doesn't have to visit the site or provide administrator credentials in order to pair or re-pair a touch controller to a video system.

Un-pairing the Touch 10 controller and changing advanced settings still require admin credentials.

#### Additional entry points for in-room controls

In-room controls now have an option for multiple panels that are available depending on the context. This provides more flexibility to add multiple panels for various tasks instead of putting all actions into one panel.

There are now three entry points available for in-room controls: Global (introduced in CE8.1), Homescreen and In-Call. The Homescreen entry point is located on the home screen icon tray, next to the Dial, Contacts, and Share buttons. The In-Call entry point is located in the icon tray, and is accessible when the video system is in a call.

New panel icons have been added.

#### Cisco Spark support

CE8.2 introduces support for Cisco Spark activation for SX10 (CTS-SX10-K9), SX20, SX80, MX200 G2, MX300 G2, MX700, MX800, MX800D, DX70 and DX80. A video system registered to the Cisco Spark service can be used together with Cisco Spark mobile and desktop applications.

To register to Cisco Spark:

- Touch 10 must be directly paired (Touch 10 is not supported for Spark registered SX10N, SX10, SX20, DX70 and DX80)
- Encryption Option key must be installed (Does not apply to DX70 and DX80)

When the video system is activated on Cisco Spark, it downloads the newest version of Cisco Spark Room OS.

Cisco Spark Room OS does not have the same management capabilities as Collaboration Endpoint Software as its web and command line interfaces are locked. The Room System is managed by Cisco and if there are any issues, contact Cisco Technical Assistance center through the Cisco Spark mobile application or from the management portal.

For more information on the Cisco Spark Room OS and its features see: ▶ <https://help.webex.com/>

#### Cisco Proximity updates

The application name has changed from Proximity to Cisco Proximity.

The latest release includes the following improvements:

- First time use tutorial for desktop application
- Updated look for the user interface
- Improved pairing experience
- Increased visibility on the user's desktop
- Better information and handling of failure scenarios
- Link to support forums on the client

The Cisco Proximity clients for smartphones and tablets (Android and iOS), and laptops (Windows and OS X) can be

downloaded from [▶ http://proximity.cisco.com](http://proximity.cisco.com). Clients for smartphones and tablets are also available through Google Play (Android) and Apple App Store (iOS).

#### Touch 10 user interface changes

A visual update has been applied to the Setup and Pairing Wizard on the Touch 10. The Touch 10 has a new GUI when registered to Cisco Spark, which is similar to the Cisco TelePresence SX10 on-screen user interface. If the endpoint is registered to on-premise infrastructure, the Touch 10 controller has the same user interface as CE8.1.

#### Default option keys removed

Option keys for features that have become default on all Cisco TelePresence video systems are now removed. The functionalities provided by these options are still present, but the keys are no longer needed.

#### Removed option keys:

- PremiumResolution
- NaturalPresenter
- DualDisplay
- HighDefinition

#### Option keys that are still available:

- Encryption
- MultiSite
- RemoteMonitoring

#### New user role: "RoomControl"

The "RoomControl" user role is added to provide non-admin users or integrators access to the In-Room control editor. The "RoomControl" role can be assigned when a new non-admin user is created from the codec's web interface.

#### Added language support

We have added support for Canadian French (Français – Canada) to the on-screen display and Touch controller menus.

xConfiguration changes in CE8.2

**New configurations**

- Peripherals Profile Cameras
- UserManagement LDAP Mode
- UserManagement LDAP Server Address
- UserManagement LDAP Server Port
- UserManagement LDAP Encryption
- UserManagement LDAP MinimumTLSVersion
- UserManagement LDAP VerifyServerCertificate
- UserManagement LDAP Admin Filter
- UserManagement LDAP Admin Group
- UserManagement LDAP Attribute
- UserManagement LDAP BaseDN

**Configurations that are modified**

- NetworkServices NTP Server [1..3] Address
  - OLD:** String (0, 64)
  - NEW:** String (0, 255)
- NetworkServices SNMP Host [1..3] Address
  - OLD:** String (0, 64)
  - NEW:** String (0, 255)
- Provisioning Connectivity
  - OLD:** User Role: ADMIN
  - NEW:** User Role: ADMIN, USER
- Provisioning ExternalManager Address
  - OLD:** User Role: ADMIN
  - NEW:** User Role: ADMIN, USER
- Provisioning ExternalManager AlternateAddress
  - OLD:** User Role: ADMIN
  - NEW:** User Role: ADMIN, USER

Provisioning ExternalManager Domain

- OLD:** User Role: ADMIN
- NEW:** User Role: ADMIN, USER

Provisioning ExternalManager Path

- OLD:** User Role: ADMIN
- NEW:** User Role: ADMIN, USER

Provisioning ExternalManager Protocol

- OLD:** User Role: ADMIN
- NEW:** User Role: ADMIN, USER

Provisioning HttpMethod

- OLD:** User Role: ADMIN
- NEW:** User Role: ADMIN, USER

Provisioning LoginName

- OLD:** User Role: ADMIN
- NEW:** User Role: ADMIN, USER

Provisioning Mode

- OLD:** User Role: ADMIN
- NEW:** User Role: ADMIN, USER

Proximity Mode

- OLD:** User Role: ADMIN
- NEW:** User Role: ADMIN, USER

Proximity Services CallControl

- OLD:** User Role: ADMIN
- NEW:** User Role: ADMIN, USER

Proximity Services ContentShare FromClients

- OLD:** User Role: ADMIN
- NEW:** User Role: ADMIN, USER

Proximity Services ContentShare ToClients

- OLD:** User Role: ADMIN
- NEW:** User Role: ADMIN, USER

Time Zone

**Change:** The list of time zones is updated. The information in the value space is from the tz database, also called the IANA Time Zone Database.

## UserInterface Language

**OLD:** Arabic / Catalan / ChineseSimplified / ChineseTraditional / Czech / Danish / Dutch / English / Finnish / French / German / Hebrew / Hungarian / Italian / Japanese / Korean / Norwegian / Polish / PortugueseBrazilian / Russian / Spanish / Swedish / Turkish

**NEW:** Arabic / Catalan / ChineseSimplified / ChineseTraditional / Czech / Danish / Dutch / English / Finnish / French / FrenchCanadian / German / Hebrew / Hungarian / Italian / Japanese / Korean / Norwegian / Polish / PortugueseBrazilian / Russian / Spanish / Swedish / Turkish

## Video Input Connector [n] InputSourceType

**OLD:** PC / camera / document\_camera / mediaplayer / other / whiteboard

**NEW:** PC / camera / desktop / document\_camera / mediaplayer / other / whiteboard

## Video Input Connector [n] PresentationSelection

**OLD:** AutoShare / Manual / OnConnect

**NEW:** AutoShare / Desktop / Manual / OnConnect



xCommand changes in CE8.2

**New commands**

Audio Select

Audio VuMeter Start

Audio VuMeter Stop

Audio VuMeter StopAll

Security Session List

Security Session Terminate

**Commands that are modified**

Audio Volume Decrease

**NEW:** Device: <Internal / HeadsetUSB / HandsetUSB>

Audio Volume Set

**NEW:** Device: <Internal / HeadsetUSB / HandsetUSB>

Audio Volume SetToDefault

**NEW:** Device: <Internal / HeadsetUSB / HandsetUSB>

Dial

**OLD:** Protocol: <H320 / Sip>

**NEW:** Protocol: <H320 / H323 / Sip / Spark>

Peripherals Connect

**OLD:** Role: <User;Admin>

**NEW:** Role: <User;Admin;RoomControl>

Peripherals HeartBeat

**OLD:** Role: <User;Admin>

**NEW:** Role: <User;Admin;RoomControl>

Peripherals Pairing Unpair

**OLD:** Role: <Admin>

**NEW:** Role: <User;Admin>

SystemUnit FactoryReset

**OLD:** Role: <Admin>

**NEW:** Role: <User;Admin>

Time DateTime Set

**OLD:** Role: <Admin>

**NEW:** Role: <User;Admin>

UserInterface Extensions Clear

**OLD:** Role: <Admin>

**NEW:** Role: <Admin;RoomControl>

UserInterface Extensions List

**OLD:** Role: <User;Admin>

**NEW:** Role: <User;Admin;RoomControl>

UserInterface Extensions Widget SetValue

**OLD:** Role: <Admin>

**NEW:** Role: <Admin;RoomControl>

UserInterface Extensions Widget UnsetValue

**OLD:** Role: <Admin>

**NEW:** Role: <Admin;RoomControl>

## xStatus changes in CE8.2

### New statuses

- Audio Devices HandsetUSB ConnectionStatus
- Audio Devices HandsetUSB Cradle
- Audio Devices HeadsetAnalog ConnectionStatus
- Audio Devices HeadsetAnalog HasMicrophone
- Audio Devices HeadsetUSB ConnectionStatus
- Audio Devices HeadsetUSB Description
- Audio Devices HeadsetUSB Manufacturer
- Audio SelectedDevice
- Audio VolumeHandsetUsb
- Audio VolumeHeadsetAnalog
- Audio VolumeHeadsetUsb
- Audio VolumeInternal
- SystemUnit Hardware Module CompatibilityLevel
- Video Layout LayoutFamily Local
- Video Layout LayoutFamily Remote

### Statuses that are removed

- SystemUnit Software OptionKeys PremiumResolution

### Statuses that are modified

#### Call [n] Protocol

- OLD:** <H320 / H323 / SIP / Spark>
- NEW:** <Unknown / H320 / H323 / SIP / Spark>

#### Diagnostics Message [n] Type

- OLD:** <CAPFOperationState / CTLInstallation / CUCMVendorConfigurationFile / CallProtocolDualStackConfig / CallProtocolIPStackPlatformCompatibility / CallProtocolVcsProvisioningCompatibility / CameraId / CameraPairing / CameraSerial / CameraSoftwareVersion / CameraStatus / CamerasDetected / ConfigurationFile / DefaultCallProtocolRegistered / EthernetDuplexMatches / FanStatus / PresenterTrack /

- H320GatewayStatus / H323GatekeeperStatus / HasValidReleaseKey / IpCameraStatus / IPv4Assignment / IPv6Assignment / IPv6Mtu / ISDNLinkCompatibility / ISDNLinkIpStack / ITLInstallation / InvalidSIPTransportConfig / LockDown / RoomControl / MediaBlockingDetected / NetLinkStatus / NetSpeedAutoNegotiated / NetworkQuality / NTPStatus / OSDVideoOutput / OutputConnectorLocations / ProvisioningStatus / SIPEncryption / SIPListenPortAndOutboundMode / SIPProfileRegistration / SIPProfileType / SelectedVideoInputSourceConnected / SiplceAndAnatConflict / TCPMediaFallback / TemperatureCheck / TLSVerifyRequiredCerts / TouchPanelConnection / TurnBandwidth / UdpPortRangeViolation / UltrasoundSpeakerAvailability / ValidPasswords / VideoFromInternalCamera / VideoInputStability / SparkSoftwareCompatibility / SparkConnectivity / SpeakerTrackFrontPanelMountedCorrectly / SpeakerTrackMicrophoneConnection / SpeakerTrackVideoInputs / SpeakerTrackEthernetConnection / ANATOnVCS / ECRreferenceDelay / AudioPairingNoise / AudioPairingRate / AudioPairingSNR / AudioPairingInterference / AudioPairingTokenDecode / AudiolInternalSpeakerDisabled / AbnormalCallTermination / HasActiveCallProtocol / SipOrH323ButNotBothEnabled / PresentationSourceSelection / SoftwareUpgrade / PlatformSanity / ContactInfoMismatch / ProximityContentShareToClientsWithMultistream>
- NEW:** <CAPFOperationState / CTLInstallation / CUCMVendorConfigurationFile / CallProtocolDualStackConfig / CallProtocolIPStackPlatformCompatibility / CallProtocolVcsProvisioningCompatibility / CameraId / CameraPairing / CameraSerial / CameraSoftwareVersion / CameraStatus / CamerasDetected / ConfigurationFile / DefaultCallProtocolRegistered / EthernetDuplexMatches / FanStatus / PresenterTrack / H320GatewayStatus / H323GatekeeperStatus / HasValidReleaseKey / IpCameraStatus / IPv4Assignment / IPv6Assignment / IPv6Mtu / ISDNLinkCompatibility / ISDNLinkIpStack / ITLInstallation / InvalidSIPTransportConfig / LockDown / RoomControl / MediaBlockingDetected / NetLinkStatus / NetSpeedAutoNegotiated / NetworkQuality / NTPStatus / OSDVideoOutput / OutputConnectorLocations / ProvisioningStatus / SIPEncryption / SIPListenPortAndOutboundMode / SIPProfileRegistration / SIPProfileType / SelectedVideoInputSourceConnected / SiplceAndAnatConflict / TCPMediaFallback / TemperatureCheck / TLSVerifyRequiredCerts / TouchPanelConnection / TurnBandwidth / UdpPortRangeViolation / UltrasoundSpeakerAvailability / ValidPasswords / VideoFromInternalCamera / VideoInputStability / SparkSoftwareCompatibility / SparkConnectivity / SpeakerTrackFrontPanelMountedCorrectly / SpeakerTrackMicrophoneConnection / SpeakerTrackVideoInputs / SpeakerTrackEthernetConnection / ANATOnVCS / ECRreferenceDelay / AudioPairingNoise / AudioPairingRate / AudioPairingSNR / AudioPairingInterference / AudioPairingTokenDecode / AudiolInternalSpeakerDisabled / AbnormalCallTermination / HasActiveCallProtocol / SipOrH323ButNotBothEnabled / PresentationSourceSelection / SoftwareUpgrade / PlatformSanity / ContactInfoMismatch / MicrophoneReinforcement>NetworkServices NTP Status
- OLD:** <Discarded / Synced / Unknown>
- NEW:** <Discarded / Synced / NotSynced / Unknown>

## What's new in CE8.1

This section provides an overview of the new and changed system settings, and the new features and improvements in the Cisco Collaboration Endpoint software version 8.2 (CE8.2) compared to CE8.0.

The list of new commands includes all changes from CE8.0 to CE8.1.

As CE software is based on TC7, the structure and main functionality remains the same as in TC software.

For more details, we recommend reading the Software release notes:

▶ <http://www.cisco.com/c/en/us/support/collaboration-endpoints/desktop-collaboration-experience-dx600-series/products-release-notes-list.html>



**It is important to consider the upgrade requirements of CE8 before upgrading;** otherwise upgrading to CE8 can leave you with a non-functioning deployment that requires you to downgrade.

## New features and improvements

### In-Room Control

With the In-Room Control feature you can customize the Touch 10 user interface to allow control of peripherals in your meeting room, for example lights and blinds. You get a consistent user experience when the video system and other peripherals in the room are controlled from the same device.

You can create the user interface extensions for Touch 10 with the In-Room Control Editor. This is an easy to use drag-and-drop editor that you launch from the video system's web interface. You can also work offline with a stand-alone version of the editor. The editor is available free of charge; no option key is required.

A third-party control system with hardware drivers for the peripherals, for example Crestron, AMX, Apple HomeKit, or Android is required to control the peripherals. The control system connects to the video system's API, listens for events and executes the programmed actions.

For more information about setting up the In-Room control feature, refer to the user guide:

▶ [www.cisco.com/go/in-room-control-docs](http://www.cisco.com/go/in-room-control-docs)

### User interface update

A new visual design for the Touch 10 user interface is introduced.

### Change in audio only avatar behavior

Full screen avatar for audio only participants has been removed. The audio only participants continue to be visible in the filmstrip during a call.

### Intelligent Proximity updates

Sharing a presentation with Cisco Intelligent Proximity desktop application renders the laptop's mouse pointer on screen. This feature requires the latest version of Cisco Intelligent Proximity for Desktop together with CE8.1.

### Direct content sharing

You can configure a video system to automatically share a presentation with the far-end participants when connecting a presentation source during a call. In previous software versions sharing a presentation with the far-end always required you to manually select "Share" with the Touch controller.

If a presentation source is already connected when a call starts, you must manually select "Share" to share the presentation with the far-end.

For further details, refer to xConfiguration Video Input Connector [n] PresentationSelection.



## xConfiguration changes in CE8.1

### New configurations

NetworkServices HTTPS VerifyClientCertificate  
NetworkServices HTTPS VerifyServerCertificate  
SIP Ice OfferTcpCandidates

### Configurations that are removed

None

### Configurations that are modified

All configurations that were associated with the *USER* user role in CE8.0, are now associated with both the *USER* and *ADMIN* user roles. So all configurations that were designated for the *USER* user role, are now included with the *ADMIN* role too.

**OLD:** User role: USER

**NEW:** User role: USER, ADMIN

Conference DefaultCall Rate

**OLD:** Default value: 1920

**NEW:** Default value: 3072

Conference DoNotDisturb DefaultTimeout

**OLD:** Integer (0..1440)

**NEW:** Integer (1..1440)

SIP DisplayName

**OLD:** String (0, 255)

**NEW:** String (0, 550)

Time Zone

**Change:** The list of time zones is updated. The information in the value space is from the tz database, also called the IANA Time Zone Database.

Video Input Connector [n] PresentationSelection

**OLD:** <Manual / OnConnect>

**NEW:** <AutoShare / Manual / OnConnect>

## xCommand changes in CE8.2

### New commands

Bookings Get  
Cameras PresenterTrack ClearPosition  
Cameras PresenterTrack Set  
Cameras PresenterTrack StorePosition  
SystemUnit OptionKey List  
SystemUnit SoftReset  
UserInterface Extensions Clear  
UserInterface Extensions List  
UserInterface Extensions Widget SetValue  
UserInterface Extensions Widget UnsetValue  
Video PresentationView Set

### Commands that are removed

Provisioning CUCM CTL Delete  
Provisioning CUCM CTL Show

### Commands that are modified

All commands that were associated with the *USER* user role in CE8.0, are now associated with both the *USER* and *ADMIN* user roles. So all commands that were designated for the *USER* user role, are now included with the *ADMIN* role too.

#### Camera Position Control

**OLD:** Pan: <-65535 - 65535>  
**NEW:** Pan: <-10000 - 10000>  
**OLD:** Tilt: <-65535 - 65535>  
**NEW:** Tilt: <-2500 - 2500>  
**OLD:** Zoom: <0-65535>  
**NEW:** Zoom: <0-8000>

#### Conference DoNotDisturb Activate

**OLD:** Timeout: <0 - 1440>  
**NEW:** Timeout: <1 - 1440>

#### SystemUnit SoftwareUpgrade

**NEW:** Forced <False/True>

## xStatus changes in CE8.2

### New statuses

Audio Output Connectors Line[n] DelayMs

Bookings Current Id

SystemUnit Software DisplayName

UserInterface Extensions Widget[n] Value

UserInterface Extensions Widget[n] WidgetId

### Statuses that are removed

SIP Proxy[n] Secure

SIP Proxy[n] Verified

### Statuses that are modified

Diagnostics Message[n] Type

**OLD:** <CAPFOperationState/CTLInstallation/CUCMVendorConfigurationFile/CallProtocolDualStackConfig/CallProtocolIPStackPlatformCompatibility/CallProtocolVcsProvisioningCompatibility/CameraId/CameraPairing/CameraSerial/CameraSoftwareVersion/CameraStatus/CamerasDetected/ConfigurationFile/DefaultCallProtocolRegistered/EthernetDuplexMatches/FollowPresenterCameraConnection/H320GatewayStatus/H323GatekeeperStatus/HasValidReleaseKey/IpCameraStatus/IPv4Assignment/IPv6Assignment/IPv6Mtu/ISDNLinkCompatibility/ISDNLinkIpStack/ITLInstallation/InvalidSIPTransportConfig/LockDown/NetLinkStatus/NetSpeedAutoNegotiated/NTPStatus/OSDVideoOutput/OutputConnectorLocations/ProvisioningStatus/SIPEncryption/SIPListenPortAndOutboundMode/SIPProfileRegistration/SIPProfileType/SelectedVideoInputSourceConnected/SipIccAndAnatConflict/TemperatureCheck/TLSVerifyRequiredCerts/TouchPanelConnection/TurnBandwidth/UdpPortRangeViolation/ValidPasswords/VideoFromInternalCamera/VideoInputStability/SpeakerTrackFrontPanelMountedCorrectly/SpeakerTrackMicrophoneConnection/SpeakerTrackVideoInputs/SpeakerTrackEthernetConnection/ANATOnVCS/ECReferenceDelay/AudioPairingSNR/AudioInternalSpeakerDisabled/AbnormalCallTermination/HasActiveCallProtocol/SipOrH323ButNotBothEnabled/PresentationSourceSelection/SoftwareUpgrade/ContactInfoMismatch>

**NEW:** <CAPFOperationState/CTLInstallation/CUCMVendorConfigurationFile/CallProtocolDualStackConfig/CallProtocolIPStackPlatformCompatibility/CallProtocolVcsProvisioningCompatibility/CameraId/CameraPairing/CameraSerial/CameraSoftwareVersion/CameraStatus/CamerasDetected/ConfigurationFile/DefaultCallProtocolRegistered/EthernetDuplexMatches/FanStatus/PresenterTrack/

H320GatewayStatus/H323GatekeeperStatus/HasValidReleaseKey/IpCameraStatus/IPv4Assignment/IPv6Assignment/IPv6Mtu/ISDNLinkCompatibility/ISDNLinkIpStack/ITLInstallation/InvalidSIPTransportConfig/LockDown/RoomControl/MediaBlockingDetected/NetLinkStatus/NetSpeedAutoNegotiated/NetworkQuality/NTPStatus/OSDVideoOutput/OutputConnectorLocations/ProvisioningStatus/SIPEncryption/SIPListenPortAndOutboundMode/SIPProfileRegistration/SIPProfileType/SelectedVideoInputSourceConnected/SipIccAndAnatConflict/TCPMediaFallback/TemperatureCheck/TLSVerifyRequiredCerts/TouchPanelConnection/TurnBandwidth/UdpPortRangeViolation/UltrasoundSpeakerAvailability/ValidPasswords/VideoFromInternalCamera/VideoInputStability/SparkSoftwareCompatibility/SparkConnectivity/SpeakerTrackFrontPanelMountedCorrectly/SpeakerTrackMicrophoneConnection/SpeakerTrackVideoInputs/SpeakerTrackEthernetConnection/ANATOnVCS/ECReferenceDelay/AudioPairingNoise/AudioPairingRate/AudioPairingSNR/AudioPairingInterference/AudioPairingTokenDecode/AudioInternalSpeakerDisabled/AbnormalCallTermination/HasActiveCallProtocol/SipOrH323ButNotBothEnabled/PresentationSourceSelection/SoftwareUpgrade/PlatformSanity/ContactInfoMismatch/ProximityContentShareToClientsWithMultistream>

Standby State

**OLD:** <Standby/Off>

**NEW:** <Standby/EnteringStandby/Off>

Video Monitors

**OLD:** <Dual/DualPresentationOnly/Quadruple/Single/Triple>

**NEW:** <Dual/DualPresentationOnly/Quadruple/Single/Triple/TriplePresentationOnly>

## What's new in CE8.0

This section provides an overview of the new and changed system settings, and the new features and improvements in the Cisco Collaboration Endpoint software version 8.0 (CE8.0) compared to TC7.3.

As CE software is based on TC7, the structure and main functionality remains the same as in TC software.

For more details, we recommend reading the Software release notes:

► <http://www.cisco.com/c/en/us/support/collaboration-endpoints/desktop-collaboration-experience-dx600-series/products-release-notes-list.html>



**It is important to consider the upgrade requirements of CE8 before upgrading;** otherwise upgrading to CE8 can leave you with a non-functioning deployment that requires you to downgrade.

## New features and improvements

### Products

CE8.0 supports the following products:

- MX200 G2
- MX300 G2
- MX700
- MX800
- SX10 Quick Set
- SX20 Quick Set
- SX80

Cisco TelePresence products in EX Series, C Series, and Profile Series are not supported in CE software; use software version TC7.3 or earlier for these products.

### User interfaces

Products running CE software, must use the following user interfaces:

- Touch 10 controller, available for all products.
- TRC6 remote control, available for SX10 and SX20.

Touch 8 controller and remote control TRC5 are not supported.

### API changes

The number of API commands has been reduced. Some commands have been removed entirely while others are different syntactically to cater for underlying architectural changes.

It is important to consider that current integrations that use the API are likely to need to be reprogrammed in order to work with the new API.

The full list of the changes, as well as a list of new commands are available in this chapter.

### Intelligent Proximity for content sharing

Cisco Proximity allows you to automatically pair your device (smartphone, tablet, or laptop) with the video system when the device comes within range. This feature is by default.

Cisco Proximity offers three services: Content sharing to clients, content sharing from clients and basic call control. These services are disabled by default.

The Cisco Proximity clients for smartphones and tablets (Android and iOS), and laptops (Windows and OS X) can be downloaded from ► <http://proximity.cisco.com>. Clients for smartphones and tablets are also available through Google Play (Android) and Apple App Store (iOS).

### Resolution changes

Collaboration Endpoint Software only supports displays that support 16:9 resolution.

### Remote monitoring

For increased security, it is only possible to take snapshots of the local and far end video streams from the video system's web interface, when a *Remote Monitoring* option key is installed on the video system.

Remote monitoring is enabled once the option key is added, and the video system is rebooted.

No warning messages or indicators are sent to the users of the video system. Please provide adequate notice to the users that the system administrator may monitor and control the camera and screen.

### Removed features

- MultiWay is no longer supported. CUCM ad hoc conferencing or hosted conferences may be used instead.
- Cisco CTMS is no longer supported. Other multipoint



conferencing solutions (involving Cisco TelePresence Server, Cisco TelePresence MCU, and/or Cisco TelePresence Conductor) may be used instead.

- MediaNet is no longer supported.



## xConfiguration changes in CE8.0

### New configurations

- Proximity Mode
- Proximity Services CallControl
- Proximity Services ContentShare FromClients
- Proximity Services ContentShare ToClients

### Configurations that are removed

<path> \* means that all configurations starting with <path> are removed.

- Audio Microphones Mute Enabled
- Conference [1] ActiveControl Mode
- Conference [1] CallProtocolIPStack
- Conference [1] FarEndControl SignalCapability
- Conference [1] MicUnmuteOnDisconnect Mode
- Conference [1] Multipoint Mode
- Conference [1] Presentation \*
- Conference [1] VideoBandwidth \*
- Experimental \*
- FacilityService \*
- Logging Mode
- Network [1] DHCP RequestTFTPServerAddress
- Network [1] TrafficControl Mode
- NetworkServices CTMS Encryption
- NetworkServices CTMS Mode
- NetworkServices HTTPS Mode
- NetworkServices HTTPS OCSP \*
- NetworkServices HTTPS VerifyClientCertificate
- NetworkServices HTTPS VerifyServerCertificate

- NetworkServices Medianet Metadata
- NetworkServices SSH AllowPublicKey
- NetworkServices XMLAPI Mode
- Peripherals Pairing \*
- RTP \*
- Security \*
- SIP ANAT
- SIP AuthenticateTransferror
- SIP OCSP \*
- SIP PreferredIPMedia
- SIP PreferredIPSignaling
- SIP Profile [1] Line
- SIP Profile [1] Mailbox
- SIP Profile [1] Outbound
- SIP Profile [1] Proxy [n] Discovery
- SIP Profile [1] TlsVerify
- SIP Profile [1] Turn BandwidthProbe
- SIP Profile [1] Turn DiscoverMode
- SIP Profile [1] Turn DropRflx
- SIP Profile [1] Type
- SystemUnit CallLogging Mode
- SystemUnit MenuLanguage
- Time OlsonZone
- UserInterface OSD EncryptionIndicator
- UserInterface TouchPanel DefaultPanel
- UserInterface UserPreferences
- UserInterface Wallpaper
- Video AllowWebSnapshots

Video Input Connector [n] RGBQuantizationRange

Video Layout DisableDisconnectedLocalOutputs

Video Layout LocalLayoutFamily

Video Layout PresentationDefault View

Video Layout RemoteLayoutFamily

Video Layout ScaleToFrame

Video Layout ScaleToFrameThreshold

Video Layout Scaling

Video OSD LanguageSelection

Video OSD LoginRequired

Video Output Connector [n] RGBQuantizationRange

Video PIP \*

**Configurations that are modified**

NetworkServices HTTP Mode

**OLD:** <Off / On>

Default value: On

**NEW:** <Off / HTTP+HTTPS / HTTPS>

Default value: HTTP+HTTPS

Phonebook Server[n] Type

**OLD:** <VCS / TMS / CUCM>

Default value: TMS

**NEW:** <Off / VCS / TMS / CUCM>

Default value: Off

Standby BootAction

**OLD:** <None / Preset1 / Preset2 / Preset3 / Preset4 / Preset5 / Preset6 / Preset7 / Preset8 / Preset9 / Preset10 / Preset11 / Preset12 / Preset13 / Preset14 / Preset15 / RestoreCameraPosition / DefaultCameraPosition>

**NEW:** <None / RestoreCameraPosition / DefaultCameraPosition>

Standby WakeupAction

**OLD:** <None / Preset1 / Preset2 / Preset3 / Preset4 / Preset5 / Preset6 / Preset7 / Preset8 / Preset9 / Preset10 / Preset11 / Preset12 / Preset13 / Preset14 / Preset15 / RestoreCameraPosition / DefaultCameraPosition>

**NEW:** <None / RestoreCameraPosition / DefaultCameraPosition>

Time Zone

**Change:** The list of time zones is updated. The information in the value space is from the tz database, also called the IANA Time Zone Database.

Video Input Connector [n] InputSourceType

**OLD:** <other / camera / PC / DVD / document\_camera / whiteboard>

**NEW:** <other / camera / PC / mediaplayer / document\_camera / whiteboard>

Video Input Connector [n] PresentationSelection

**OLD:** <Manual / Automatic / OnConnect>

**NEW:** <Manual / OnConnect>

**Configurations that are renamed**

Audio SoundsAndAlerts KeyTones Mode

**Renamed to:** UserInterface KeyTones Mode

Cameras Camera [n] Backlight

**Renamed to:** Cameras Camera [n] Backlight DefaultMode

Cameras Camera [n] Brightness Level

**Renamed to:** Cameras Camera [n] Brightness DefaultLevel

Conference [1] AutoAnswer Delay

**Renamed to:** Conference AutoAnswer Delay

Conference [1] AutoAnswer Mode

**Renamed to:** Conference AutoAnswer Mode

Conference [1] AutoAnswer Mute

**Renamed to:** Conference AutoAnswer Mute

Conference [1] DefaultCall Rate

**Renamed to:** Conference DefaultCall Rate

Conference [1] DoNotDisturb DefaultTimeout

**Renamed to:** Conference DoNotDisturb DefaultTimeout

Conference [1] Encryption Mode

**Renamed to:** Conference Encryption Mode

Conference [1] FarEndControl Mode

**Renamed to:** Conference FarEndControl Mode



Conference [1] MaxReceiveCallRate

[Renamed to:](#) Conference MaxReceiveCallRate

Conference [1] MaxTotalReceiveCallRate

[Renamed to:](#) Conference MaxTotalReceiveCallRate

Conference [1] MaxTotalTransmitCallRate

[Renamed to:](#) Conference MaxTotalTransmitCallRate

Conference [1] MaxTransmitCallRate

[Renamed to:](#) Conference MaxTransmitCallRate

NetworkServices NTP Address

[Renamed to:](#) NetworkServices NTP Server [n] Address

SIP Profile [1] Authentication [1] LoginName

[Renamed to:](#) SIP Authentication UserName

SIP Profile [1] Authentication [1] Password

[Renamed to:](#) SIP Authentication Password

SIP Profile [1] DefaultTransport

[Renamed to:](#) SIP DefaultTransport

SIP Profile [1] DisplayName

[Renamed to:](#) SIP DisplayName

SIP Profile [1] Ice DefaultCandidate

[Renamed to:](#) SIP Ice DefaultCandidate

SIP Profile [1] Ice Mode

[Renamed to:](#) SIP Ice Mode

SIP Profile [1] Proxy [n] Address

[Renamed to:](#) SIP Proxy [n] Address

SIP Profile [1] Turn Password

[Renamed to:](#) SIP Turn Password

SIP Profile [1] Turn Server

[Renamed to:](#) SIP Turn Server

SIP Profile [1] Turn UserName

[Renamed to:](#) SIP Turn UserName

SIP Profile [1] URI

[Renamed to:](#) SIP URI

SystemUnit ContactInfo Type

[Renamed to:](#) UserInterface ContactInfo Type

Video CamCtrlPip CallSetup Duration

[Renamed to:](#) Video Selfview OnCall Duration

Video CamCtrlPip CallSetup Mode

[Renamed to:](#) Video Selfview OnCall Mode

Video DefaultPresentationSource

[Renamed to:](#) Video Presentation DefaultSource

Video SelfviewDefault FullscreenMode

[Renamed to:](#) Video Selfview Default FullscreenMode

Video SelfviewDefault Mode

[Renamed to:](#) Video Selfview Default Mode

Video SelfviewDefault PIPPosition

[Renamed to:](#) Video Selfview Default PIPPosition

## xCommand changes in CE8.0

### New commands

Camera Preset ActivateDefaultPosition  
 Camera Preset Show

Proximity Services Activate  
 Proximity Services Deactivate  
 SystemUnit OptionKey Remove  
 SystemUnit OptionKey RemoveAll  
 UserManagement User Passphrase Change  
 UserManagement User Passphrase Set

### Commands that are removed

*xCommand <path>* \* means that all configurations starting with *xCommand <path>* are removed.

Audio Sound Play  
 Audio Sound Stop  
 Audio VuMeter \*  
 Camera PanTiltReset  
 Camera PositionActivateFromPreset  
 Camera PositionSet  
 Camera Preset Snapshot \*  
 CamCtrlPip  
 Experimental \*  
 FacilityService Dial  
 FarEndControl Preset Store  
 Key \*  
 Logging ExtendedLogging \*  
 Message Echo

Message FarendMessage  
 Presentation Byod \*  
 Provisioning CUCM CAPF OperationStart  
 Provisioning CUCM ExtensionMobility \*  
 Provisioning CUCM ITL Show  
 Security FIPSMODE Activate  
 SystemUnit AdminPassword Set  
 SystemUnit ConfigurationProfile \*  
 UserInterface OSD Close  
 UserInterface ScreenShot \*  
 Video AutoPresentationStart \*  
  
 Video Layout SetPresentationView

### Commands that are modified

Call Accept  
     **REMOVED:** CallType  
 Call Disconnect  
     **OLD:** CallId (r): <0 - 65534>  
     **NEW:** CallId: <0 - 65534>  
 Call Hold  
     **OLD:** CallId (r): <0 - 65534>  
     **NEW:** CallId: <0 - 65534>  
 Camera PositionReset  
     **NEW:** Axis: <All/Focus/PanTilt/Zoom>  
 Camera Preset Edit  
     **NEW:** DefaultPosition: <False/True>  
 Camera Preset List  
     **NEW:** Camerald: <1 - 7>

**NEW:** DefaultPosition: <False/True>

**REMOVED:** PresetId

Camera Preset Store

**NEW:** DefaultPosition: <False/True>

HttpFeedback Deregister

**OLD:** Required user role: ADMIN

**NEW:** Required user role: USER

HttpFeedback Register

**OLD:** Required user role: ADMIN

**NEW:** Required user role: USER

Peripherals List

**OLD:** Type: <All/BluetoothHeadset/ControlSystem/ISDNLink/Other/TouchPanel>

**NEW:** Type: <All/ControlSystem/ISDNLink/Other/TouchPanel>

Presentation Stop

**NEW:** PresentationSource: <1 - 4>

UserInterface Message Alert Clear

**OLD:** Required user role: ADMIN

**NEW:** Required user role: USER

UserInterface Message Prompt Clear

**OLD:** Required user role: ADMIN

**NEW:** Required user role: USER

UserInterface Message TextLine Clear

**OLD:** Required user role: ADMIN

**NEW:** Required user role: USER

UserManagement User Passphrase Set

**NEW:** YourPassphrase: <S: 0, 255>

### Commands that are renamed or replaced

Boot

**Renamed to:** SystemUnit Boot

Call DisconnectAll

**Included in:** Call Disconnect

Call HoldAll

**Included in:** Call Hold

Conference ActiveSpeaker Reset

**Renamed to:** Conference SpeakerLock Release

Conference ActiveSpeaker Set

**Renamed to:** Conference SpeakerLock Set

DTMFSend

**Renamed to:** Call DTMFSend

FarEndControl Camera Move

**Renamed to:** Call FarEndControl Camera Move

FarEndControl Camera Stop

**Renamed to:** Call FarEndControl Camera Stop

FarEndControl Preset Activate

**Renamed to:** Call FarEndControl RoomPreset Activate

FarEndControl Source Select

**Renamed to:** Call FarEndControl Source Select

Message \*

**Renamed to:** UserInterface Message \*

Preset \*

**Renamed to:** RoomPreset \*

SystemUnit DateTime Get

**Renamed to:** Time DateTime Get

SystemUnit DateTime Set

**Renamed to:** Time DateTime Set

**OLD:** Year: <2008..2037>

**NEW:** Year: <2015..2037>

xCommand SystemUnit Diagnostics Run

**Renamed to:** xCommand Diagnostics Run

xCommand Video Presentation Set

**Renamed to:** xCommand Video PresentationPIP Set

xCommand Video PictureLayoutSet

**Renamed to:** xCommand Video Layout LayoutFamily Set



xCommand Video PIP ActiveSpeaker Set

[Renamed to:](#) xCommand Video ActiveSpeakerPIP Set

xCommand Video PIP Presentation Set

[Renamed to:](#) xCommand Video PresentationPIP Set

xStatus changes in CE8.0

**New statuses**

- Call [n] HoldReason
- Conference Call [n] Capabilities FarendMessage Mode
- Conference Call [n] Capabilities IxChannel Status
- H323 Mode Reason
- Proximity Services Availability
- Standby State
- SIP Mailbox URI
- SystemUnit Software OptionKeys RemoteMonitoring
- UserInterface ContactInfo ContactMethod [n] Number
- UserInterface ContactInfo Name

**Statuses that are removed**

*xStatus <path>* \* means that all configurations starting with *xStatus <path>* are removed.

- Call [n] CallPriority
- Call [n] ModifyState
- Call [n] SecurityStatus
- CallDiagnostics [n] \* (was Diagnostics Call [n] \* )
- Cameras Camera [n] DownloadProgress (was Camera [n] DownloadProgress)
- Cameras Camera [n] HardwareID (was Camera [n] HardwareID)
- Cameras Camera [n] Position \* (was Camera [n] Position \*)
- Cameras Camera [n] UpgradeStatus (was Camera [n] UpgradeStatus)
- Conference Call [n] Appearance (was Conference Site [n] Appearance)
- Conference Call [n] AttendedTransfer (was Conference Site [n] AttendedTransfer)
- Conference Call [n] CalText (was Conference Site [n] CalText)
- Conference Call [n] Preserved (was Conference Site [n] Preserved)
- Conference Call [n] SecurityStatus (was Conference Site [n] SecurityStatus)

- Conference Call [n] UnattendedTransfer (was Conference Site [n] UnattendedTransfer)
- Conference Line [n] Appearance [n] \*
- Conference LoudestSite
- Conference Presentation LastLocalSource
- Conference Presentation LocalSendingMode
- Conference Presentation LocalSource
- Conference Presentation Protocol
- Conference Presentation Resolution \*
- Conference SelectedCallProtocol
- Conference Site [n] ConferenceExtended
- Diagnostics LastRun (was SystemUnit Diagnostics LastRun)
- Experimental \*
- H320 \*
- ICE \*
- Logging \*
- MediaChannels Call [n] \*
- Network [n] IPv4 DHCP \*
- Network [n] IPv4 DNS \*
- Network [n] MTU
- Peripherals ConnectProgress [n] \*
- Peripherals ControllableDevice [n] \*
- Provisioning CUCM \*
- Provisioning NextRetry
- Provisioning Reason
- Provisioning Server
- Provisioning Software PreviousUpgrade \*
- Provisioning Software UpgradeStatus SecondsUntilUpgrade
- RoomPreset [n] \* (was Preset [n] \*)

Security Audit Server Port  
 SystemUnit Hardware BootSoftware  
 SystemUnit Hardware MainBoard \*  
 SystemUnit Hardware Module CompatibilityLevel  
 SystemUnit Hardware Module Identifier  
 SystemUnit Hardware MonitoringSoftware  
 SystemUnit Hardware TemperatureThreshold  
 SystemUnit Hardware UDI  
 SystemUnit MenuLogo  
 SystemUnit Software Application  
 SystemUnit State Subsystem Application  
 SystemUnit State System  
 Time ZoneOlson

Video Layout \*

**Statuses that are modified**

Call [n] Protocol  
 OLD: String  
 NEW: <H320/H323/SIP>

Conference Multipoint Mode  
 OLD: <Auto/CUCMMediaResourceGroupList/MultiSite/MultiWay/Off>  
 NEW: <Auto/CUCMMediaResourceGroupList/MultiSite/Off>

Diagnostics Message [n] Type  
 NEW: TemperatureCheck, AudiolnternalSpeakerDisabled, and ContactInfoMismatch added to the value space

H323 Mode Status  
 OLD: String  
 NEW: <Enabled/Disabled>

Peripherals ConnectedDevice [n] Status  
 OLD: <Connected/ResponseTimedOut>

NEW: <Connected/ResponseTimedOut/Unpairing/LostConnection>

Peripherals ConnectedDevice [n] Type  
 OLD: <BluetoothHeadset/Byod/Camera/ControlSystem/ISDNLink/Other/SpeakerTrack Byod/TouchPanel>  
 NEW: <Byod/Camera/ControlSystem/ISDNLink/Other/SpeakerTrack Byod/TouchPanel>

Peripherals ConnectedDevice [n] UpgradeStatus  
 OLD: <Downloading/Failed/Installing/None/Succeeded>  
 NEW: <Downloading/Failed/Installing/InstallationReady/None/Succeeded/Rebooting/Retrying/Aborted/Paused>

Provisioning Status  
 OLD: <AuthenticationFailed/ConfigError/Failed/Idle/NeedConfig/Provisioned>  
 NEW: <AuthenticationFailed/ConfigErro/Failed/Idle/NeedConfig/Provisioning/Provisioned>

SystemUnit Software OptionKeys PremiumResolution  
 OLD: String  
 NEW: <False/True>

**Statuses that renamed**

*xStatus <path>* \* means that all configurations starting with *xStatus <path>* are removed.

Camera [n] \*  
 Renamed to: Cameras Camera [n] \*

Conference ActiveSpeaker Manual Siteld  
 Renamed to: Conference SpeakerLock Callld

Conference ActiveSpeaker Mode  
 Renamed to: Conference SpeakerLock Mode

Conference ActiveSpeaker Siteld  
 Renamed to: Conference ActiveSpeaker Callld

Conference Presentation Instance[n] LocalSendingMode  
 Renamed to: Conference Presentation LocalInstance[n] SendingMode

Conference Presentation Instance[n] LocalSource  
 Renamed to: Conference Presentation LocalInstance[n] Source

Conference Presentation Siteld





[Renamed to:](#) Conference Presentation CallId

Conference Site [n] \*

[Renamed to:](#) Conference Call [n] \*

Conference Site [n] Hold

[Renamed to:](#) Conference Call [n] Capabilities Hold

NetworkServices NTP Address

[Renamed to:](#) NetworkServices NTP Server [n] Address

SIP Profile [n] \*

[Renamed to:](#) SIP \*

SIP Profile [n] DirectoryURI Alias [n] URI

[Renamed to:](#) SIP AlternateURI Alias [n] URI

SIP Profile [n] DirectoryURI Primary URI

[Renamed to:](#) SIP AlternateURI Primary URI

SystemUnit ContactInfo

[Renamed to:](#) UserInterface ContactInfo ContactMethod [n] Number

SystemUnit ContactName

[Renamed to:](#) UserInterface ContactInfo Name

SystemUnit Diagnostics Message [n] \*

[Renamed to:](#) Diagnostics Message [n] \*

SystemUnit Software MaxAudioCalls

[Renamed to:](#) Capabilities Conference MaxAudioCalls

SystemUnit Software MaxVideoCalls

[Renamed to:](#) Capabilities Conference MaxVideoCalls

SystemUnit State MaxNumberOfActiveCalls

[Renamed to:](#) Capabilities Conference MaxActiveCalls

SystemUnit State MaxNumberOfCalls

[Renamed to:](#) Capabilities Conference MaxCalls

Video Input Source [n] Resolution FormatStatus

[Renamed to:](#) Video Input Source [n] FormatStatus

Video Input Source [n] Resolution FormatType

[Renamed to:](#) Video Input Source [n] FormatType

Video PIP ActiveSpeaker Position

[Renamed to:](#) Video ActiveSpeaker PIPPosition

Video PIP Presentation Position

[Renamed to:](#) Video Presentation PIPPosition



## Chapter 2

# About the API

## API fundamentals

This chapter contains a top-level view of the mechanisms supported by the codec API.

Here you can read about how to access the API, how to use the command line and what the different parts of the API can be used for. This chapter also describes how to use the feedback functions that are available for the codec.

The API consists of four major groups:

- Commands
- Configurations
- Status
- Events

These four groups are hierarchically organized, which makes it easier to find related functionality. You can find the complete lists of all commands, configurations and statuses in the following chapters.

### Connecting to the API

There are several ways to access the codec API. Regardless of which method you choose, the structure of the API stays the same. Choose the connection method that suites your application best. Before you start, please read this section about the different methods, as some of those may require additional configuration changes before being enabled.

The following configurations, apart from password, can be set from the System configuration menu on the web interface or from the command line interface. All of the examples are for the command line interface.

### Password

The video system is delivered with a default user account with full credentials. The user name is admin, and initially, no password is set for the default user.

It is mandatory to set a password for the admin user in order to restrict access to system configuration. You should in addition set a password for any other user with similar credentials.

You can set the password on the codec's web interface. Open a web browser and enter the IP address of the video system in the address bar and log in. Click your user name in the upper right corner and choose *Change password* in the drop down menu.

### Telnet

Telnet can be viewed as the equivalent of the serial protocol in the TCP/IP world. Telnet is disabled by default. Before connecting to the codec with Telnet you have to enable it.

#### Codec configuration

To enable Telnet service, configure the following setting on the codec. Changing this setting does not require a reboot of the device, but it may take some time to take effect.

```
xConfiguration NetworkServices Telnet Mode: On
```

### SSH

SSH is a secure TCP/IP connection and it is enabled by default on the codec. It can be disabled. You need a SSH client, such as PuTTY, to access the API over SSH.

## HTTP/HTTPS

As HTTP/HTTPS are connectionless protocols, there is no persistent connection. There are several ways of communicating with the API over HTTP.

### Codec configuration

In order to enable or disable the HTTP and HTTPS services, configure the following settings on the codec.

```
xConfiguration NetworkServices HTTP Mode:  
<Off/On>  
xConfiguration NetworkServices HTTPS Mode:  
<Off/On>
```

### Connecting

You can inspect the API by entering the IP address or host name of the codec in your favorite web browser. In the web interface, you can find the API documents under the menu section [Integration > Developer API](#). The HTTP POST and GET methods are used to execute commands and get feedback from the codec. This is described in [▶"Using HTTP" on page 28](#) in this document.

## API output

The xPreferences is used to set preferences for the RS-232, Telnet and SSH sessions.

### The output modes

- **Terminal:** Line based output for use with line based control systems
- **XML:** XML output for use with control systems that understand XML.
- **JSON:** JSON format is convenient when integrating with web based systems.

The default output mode is **terminal**. To change this you have to define your preferences for each session individually. Examples in this guide are in terminal mode.

To set output mode to XML, issue the command:

```
xPreferences outputmode xml
```

To revert to terminal mode, issue the command:

```
xPreferences outputmode terminal
```

#### Example: Layout command in terminal mode

```
xCommand Video Layout AssignCall CallId: 2 LayoutId: 1
```

#### Example: Layout command in XML mode

```
<Command>
<Video>
<Layout>
<AssignCall command="True">
<CallId>2</CallId>
<LayoutId>1</LayoutId>
</AssignCall>
</Layout>
</Video>
</Command>
```

## Using the command line

### Help

To get a list of all supported top level commands you can type `?` or `help` after connecting to the TelePresence System using RS-232, Telnet or SSH (Example 1).

### Bye

Typing the `bye` command closes the command line interface.

```

Example 1:
?
          - User Commands -

help      xcommand      xconfiguration  xevent      xfeedback
xgetxml   xdocument      xpreferences    xtransaction xstatus
bye       echo           log             systemtools
OK
    
```

## API commands

### xConfiguration

Configurations are system settings, such as system name and network settings. These are persistent across boots. Refer to ["Configurations" on page 32](#).

### xCommand

Commands instruct the codec to execute actions, such as to dial a number or to search the phone book. Refer to ["Commands" on page 32](#).

### xStatus

A status contains the current state of the codec, such as connected calls, the status of the gatekeeper registration, connected inputs and output sources. Refer to ["Status" on page 32](#).

### xFeedback

The Feedback commands are used to specify what parts of the configuration and status hierarchies to monitor. Feedback is only issued on the RS-232, Telnet or SSH session for which it is specified. If you are connecting to the codec with multiple sessions, you have to define feedback individually for each session. Refer to ["Feedback mechanism" on page 26](#).

### xPreferences

The xPreferences command is used to set preferences for the RS-232, Telnet and SSH sessions. Refer to ["API output" on page 21](#).

### Echo <on/off>

If echo is set to `On` the key inputs are displayed when entering text in a command line interface.

If echo is set to `Off` user input is not displayed when entering text in a command line interface.

### xEvent

The xEvent command returns information on which events are available for feedback. Refer to ["Events" on page 25](#).

### xGetxml

The xGetxml request returns an XML document based on the location parameter attached to the request. The elements (or a complete document) matching the expression will be returned. Refer to ["Feedback mechanism" on page 26](#).

## Other commands

### Systemtools

The systemtools commands are a set of command line tools for administrative control and diagnostics. The commands can be used for advanced troubleshooting together with Cisco technical support. Systemtools are not a part of the programming API. Refer to ["The SystemTools commands" on page 169](#).

### Log

The log command is used to enable advanced logs. It is only used for debugging the system.

## Command line shortcuts

If your client supports it, there are some timesaving shortcuts you can use:

- Tab-completion to complete the commands and arguments.
- Arrow up and arrow down keys to navigate your command history.
- **<CTRL-a>**: Jump to the beginning of the line.
- **<CTRL-e>**: Jump to the end of the line.
- **<CTRL-r>**: Incremental command history search.
- **<CTRL-w>**: Erase the current line.

## Searching

You can use `//` to search for elements anywhere in the status or configuration hierarchy (Example 1).

You can also combine multiple `//`'s (Example 2).

**NOTE:** The search shortcuts work well for inspecting the API, but should not be used in applications. We recommend that you always use the complete paths to avoid command ambiguity when upgrading to newer firmware releases.

### Example 1:

List all configurations that include words that starts with OUT and HDMI:

```
xconfiguration //out//hdmi
*c xConfiguration Audio Output HDMI 1 Level: 0
*c xConfiguration Audio Output HDMI 1 Mode: On
*c xConfiguration Audio Output HDMI 2 Level: 0
*c xConfiguration Audio Output HDMI 2 Mode: Off
** end
```

### Example 2:

Get the resolution width of all connected sources for both inputs and outputs:

```
xStatus //vid//res//wid
*s Video Input Source 1 Resolution Width: 1920
*s Video Input Source 2 Resolution Width: 0
*s Video Input Source 3 Resolution Width: 0
*s Video Input Source 4 Resolution Width: 0
*s Video Output Connector 1 Resolution Width: 1920
*s Video Output Connector 2 Resolution Width: 1280
*s Video Output Connector 3 Resolution Width: 1280
** end
```

## Value types and formats

The system supports the following value types:

- **Integer values:** `<x..y>`  
Defines the valid range for an integer input. x = min value, y = max value.
- **Literal values:** `<X/Y/./Z>`  
Defines the possible values for a given configuration.
- **String values:** `<S: x, y>`  
Defines that the valid input for this configuration is a string with minimum length of x and maximum length of y characters. Strings can have rules that further specify their format and length.

Input values that contain spaces need to be quoted

Any values for configurations and commands containing spaces must be enclosed in quotes. Quotes are not necessary for values without spaces.

### Example:

```
Correct: xCommand dial number: "my number contains spaces"
Correct: xCommand dial number: 12345
Incorrect: xCommand dial number: my number contains spaces
```

### Case sensitivity

All commands are case-insensitive. All of the following commands will work.

```
XCOMMAND DIAL NUMBER: foo@bar.org
xcommand dial number: foo@bar.org
xCommand Dial Number: foo@bar.org
```

## Commands

Commands instruct the codec to execute actions, such as to dial a number or to search the phone book. All commands start with the prefix `xCommand` followed by a command path.

Writing `xCommand ?` on the command line will list all the top level commands.

To view the complete list of commands and their parameters, write `xCommand ??` on the command line.

Command arguments are key-value pairs.

When issuing a `xCommand`, the command consists of one argument and one required parameter. In this document the command usage is described for all `xCommands`, with both required and optional parameters. The optional parameters are in brackets.

**Example:** `xCommand Dial Number: 123`

- `xCommand` is the command prefix. The command to be executed is `Dial`.
- The example contains one argument, `Number: 123`. `Number` is the key and `123` is its value. The key/value pair is separated with `:`.

## Configurations

Configurations are system settings that are persistent across boots. Like commands, also configurations are structured in a hierarchy.

Writing `xConfiguration ?` on the command line lists all the top level configurations.

Writing `xConfiguration ??` lists all configurations and their value spaces.

Writing `xConfiguration` lists all configurations and their current values. To list out only some of the configurations, write `xConfiguration` followed by one or more parts of the configuration paths.

**Example:** Set the H323 Alias ID

Write in:

```
xConfiguration H323 Profile 1 H323Alias ID:
"changed@company.com"
```

**Example:** Get the H323 Alias ID

Write in:

```
xConfiguration H323 Profile 1 H323Alias ID
```

Result:

```
*c xConfiguration H323 Profile 1 H323Alias ID:
"changed@company.com"
**end
```

## Status

A status contains the current state of the codec, such as connected calls, the status of the gatekeeper registration, connected inputs and output sources.

Writing `xStatus ?` on the command line lists all top level statuses.

Writing `xStatus` lists all statuses and their current values.

To list out only some of the statuses, write `xstatus` followed by the relevant part of the status path (address expression):

```
xStatus <address expression>
```



## Events

Event returns information about the events that are available for feedback. This overview presents examples of some the events that are available on the API.

To get an overview of the supported events type [?](#), [??](#) or [help](#) after xEvent:

- [xEvent ?](#) Lists the top level events
- [xEvent ??](#) List all of the available events
- [xEvent help](#) Lists the top level events

The result for events depends on the state of the codec.

### Example 1: Outgoing Call Indication

Outgoing Call Indication is an event reported when an outgoing call is about to be dialed. Returns the CallId the call has been assigned.

```
*e OutgoingCallIndication CallId: x
** end
```

### Example 2: Call Disconnect

Call Disconnect is an event reported when a call is disconnected. Returns the CallId of the disconnected call and reason for the call's disconnection.

```
*e CallDisconnect CallId: x CauseValue: 0
CauseString: "" CauseType: LocalDisconnect
OrigCallDirection: "outgoing"
** end
```

### Example 3: Call Successful

Call Successful is an event reported when a call is connected successfully, that is when all channels are up and established.

```
*e CallSuccessful CallId: 132 Protocol: "h223"
Direction: "outgoing" CallRate: 768 RemoteURI:
"h223:integratorHQ@company.com" EncryptionIn:
"Off" EncryptionOut: "Off"
** end
```

### Example 4: FECC Action request

FECC Action request is an event reported when far end is sending FECC commands.

```
*e FeccActionInd Id: 132 Req: 1 Pan: 1 PanRight:
1 Tilt: 0 TiltUp: 0 Zoom: 0 ZoomIn: 0 Focus: 0
FocusIn: 0 Timeout: 300 VideoSrc: 0 m: 0
** end
```

### Example 5: TString message received

TString message received is an event reported when far end has sent a TString message.

```
*e TString CallId: 132 Message: "ee"
** end
```

### Example 6: SString message received

SString message received is an event reported when far end has sent a SString message.

```
*e SString String: "ee" Id: 132
** end
```

## Feedback mechanism

To build solutions that can reliably keep the state between the application and the codec synchronized, you need to set up a notification system to report the changes in the state of the codec.

The API supports notifications on the following:

- Configuration changes
- Status changes
- Event notifications

These notifications will not be sent unless the user has explicitly told the codec to do so. The user is required to subscribe to all the feedback the application needs. This is done by registering feedback expressions. The way of registering feedback expressions varies according to the connection method used.

When using HTTP, the method of handling feedback differs slightly from what is presented in this section. See [▶"Feedback from codec over HTTP" on page 29](#) for more information.

**WARNING:** A codec may give very much feedback, especially when calls are connected and disconnected. Therefore, you should only subscribe to the feedback that you need.

Never register for all status feedback by issuing `xFeedback register /Status`. This may give the control application too much data to handle, which may lead to sluggish or unpredictable behavior.

## Feedback expressions

The expression used when registering for feedback is a variant of the XPath language. This language describes a way to select nodes from an XML document. CE software contains three main feedback documents:

Document	API command	Path
Status	<code>xStatus</code>	<code>/Status</code>
Configuration	<code>xConfiguration</code>	<code>/Configuration</code>
Event	<code>xEvent</code>	<code>/Event</code>

The syntax for feedback registering is:

```
xFeedback register <path>
```

Never register for all status feedback by issuing `xFeedback register /Status`.

It is safe to register for all configuration changes using `xFeedback register /Configuration`, as configuration changes will most likely not occur that often.

By going through some examples, we can see how this information can be used to build feedback expressions. A good way to verify the expressions is to point your browser to <http://<ip-address>/getxml?location=path> or to execute `xgetxml <path>` from the terminal, and check that the output matches the nodes you want feedback on.

### Example 1: Microphones Mute status.

Terminal query

```
xStatus Audio Microphones Mute
*s Audio Microphones Mute: Off
** end
```

Equivalent feedback expression

```
xFeedback register /Status/Audio/Microphones/Mute
```

### Example 2: Name of all video input connectors.

Terminal query

```
xConfiguration Video Input Connector Name
*c xConfiguration Video Input Connector 1 Name:
"NameA"
*c xConfiguration Video Input Connector 2 Name:
"NameB"
*c xConfiguration Video Input Connector 3 Name:
"NameC"
*c xConfiguration Video Input Connector 4 Name:
"NameD"
*c xConfiguration Video Input Connector 5 Name:
"NameE"
** end
```

Equivalent feedback expression

```
xFeedback register /Configuration/Video/Input/
Connector/Name
```

### Example 3: Name of video input connector 3.

Terminal query

```
xConfiguration Video Input Connector 3 Name
*c xConfiguration Video Input Connector 3 Name:
"NameC"
** end
```

Equivalent feedback expression

```
xFeedback register /Configuration/Video/Input/
Connector[@item='3']/Name
```

## Terminal connections

### Managing feedback subscriptions

To register, list and deregister feedback expressions you use the command xFeedback and its corresponding sub commands.

The registered expressions are only valid for the currently active connection. If you open two Telnet sessions and register to get feedback in one session, you do not receive feedback in the other session. This also means that if you disconnect from a session, you have to re-register all expressions after reconnecting.

You can register up to 38 expressions.

### Feedback output

The feedback output is exactly the same as you get when querying the system using the xConfiguration and xStatus commands. E.g., if you issue the command xStatus Standby Active on the command line the result is:

```
*s Standby Active: On
** end
```

If you have registered for feedback on status changes the feedback you get when the system goes to standby-mode will be exactly the same:

```
*s Standby Active: On
** end
```

This means that when you are programming against the device you only need to handle one format.

### Example: Managing feedback subscriptions

#### A: Register feedback expressions.

```
Write in: xFeedback register /Status/Audio
Result: ** end
        OK
```

```
Write in: xFeedback register /Event/CallDisconnect
Result: ** end
        OK
```

```
Write in: xFeedback register /Configuration/Video/
MainVideoSource
Result: ** end
        OK
```

#### B: List out currently registered expressions.

```
Write in: xFeedback list
Result: /Configuration/Video/MainVideoSource
        /Event/CallDisconnect
        /Status/Audio
        ** end
        OK
```

#### C: Deregister feedback expressions.

```
Write in: xFeedback deregister /Event/
CallDisconnect
Result: ** end
        OK

Write in: xFeedback deregister /Status/Audio
Result: ** end
        OK
```

#### D: List the new feedback expressions.

```
Write in: xFeedback list
Result: /Configuration/Video/MainVideoSource
        ** end
        OK
```

## Using HTTP

The codec supports sending commands and configurations over HTTP and HTTPS. It is also possible to retrieve configurations and statuses this way. This interface exposes the same API as the command line, but in XML format.

### HTTP XMLAPI Authentication

Access to the XMLAPI requires the user to authenticate using HTTP Basic Access Authentication as a user with 'ADMIN' role. Unauthenticated requests prompt a 401 HTTP response containing a Basic Access Authentication challenge. How to use HTTP Basic Access Authentication varies according to the HTTP library or tool that you are using.

If your application will be issuing multiple commands through the API, we highly recommend that you use Session Authentication (see below). The standard basic authentication does a full re-authentication per request, which may affect the performance of your application.

### HTTP XMLAPI Session Authentication

Authenticating with your username and password combination for each API request might introduce too much latency for some use-cases. To mitigate this, the API supports a session-based authentication mechanism.

To open a session, issue a POST to <http://<ip-address>/xmlapi/session/begin> with Basic Access Authentication. The response sets a SessionId-cookie that can be used with subsequent requests.

Note that when using API Session Authentication, it is important to explicitly close the session when you are done. Failing to do so may cause the device to run out of sessions, as there are a limited number of concurrent sessions available, and they do not time out automatically.

### URL cheat sheet

The following table contains the main URLs used when accessing the API over HTTP.

Method	URL	Description
GET	http://<ip-address>/status.xml	Complete status document
GET	http://<ip-address>/configuration.xml	Complete configuration document
GET	http://<ip-address>/command.xml	Complete command document
GET	http://<ip-address>/valuespace.xml	Complete valuespace document
GET	http://<ip-address>/getxml?location=<path>	Retrieve document based on a path
POST	http://<ip-address>/putxml	Configurations and commands in HTTP body

#### Example: Starting a HTTP XMLAPI session

##### Request:

```
POST /xmlapi/session/begin HTTP/1.1
Authorization: Basic <Base64 encoded authentication string>
```

##### Response:

```
HTTP/1.1 204 No Content
Server: nginx/1.8.0
Connection: keep-alive
Set-Cookie: SessionId=f08102c8ce5aaf8fba23a7238cc2ef464b990e18bfbb7fb048820c0e28955c54; Path=/; HttpOnly
```

This session counts toward the systems concurrent sessions limit.

With an open session, provide the SessionId cookie to following requests. Your tool/library may do this automatically.

#### Example: Using a HTTP XMLAPI session

##### Request:

```
GET /configuration.xml HTTP/1.1
Cookie: SessionId=f08102c8ce5aaf8fba23a7238cc2ef464b990e18bfbb7fb048820c0e28955c54
```

##### Response:

```
HTTP/1.1 200 OK
Server: nginx/1.8.0
Content-Type: text/xml; charset=UTF-8
Content-Length: 43549
Connection: keep-alive
<?xml version="1.0"?>
<Configuration product="Cisco Codec"
version="ce8.2.0" apiVersion="4"> ...
</Configuration>
```

To close a session after use, issue a POST to <http://<ip-address>/xmlapi/session/end> with the provided cookie.

#### Example: Closing a HTTP XMLAPI session

##### Request:

```
POST /xmlapi/session/end HTTP/1.1
Cookie: SessionId=f08102c8ce5aaf8fba23a7238cc2ef464b990e18bfbb7fb048820c0e28955c54
```

##### Response:

```
HTTP/1.1 204 No Content
Server: nginx/1.8.0
Connection: keep-alive
Set-Cookie: SessionId=; Max-Age=0; Path=/; HttpOnly
```

## Getting status and configurations

**Example 1:** Get all status entries on the codec.

```
http://<ip-address>/getxml?location=/Status
```

**Example 2:** Get just the audio statuses of the codec.

```
http://<ip-address>/getxml?location=/Status/Audio
```

**Example 3:** Get all configurations of the codec.

```
http://<ip-address>/getxml?location=/Configuration
```

**Example 4:** Get all video configurations of the codec.

```
http://<ip-address>/getxml?location=/Configuration/Video
```

## Sending commands and configurations

### Using HTTP POST

When sending configurations and commands to the codec, it is important that the HTTP header Content-Type is set to text/xml, i.e. [Content-Type: text/xml](#). The body of the POST should contain the XML content.

**Example 1:** Changing the system name.

#### Request

```
POST /putxml HTTP/1.1
Content-Type: text/xml
```

```
<Configuration>
  <SystemUnit>
    <Name>newName</Name>
  </SystemUnit>
</Configuration>
```

**Example 2:** Setting the camera position.

#### Request

```
POST /putxml HTTP/1.1
Content-Type: text/xml
```

```
<Command>
  <Camera>
    <PositionSet command="True">
      <CameraId>1</CameraId>
      <Pan>200</Pan>
      <Tilt>200</Tilt>
    </PositionSet>
  </Camera>
</Command>
```

#### Response

```
HTTP/1.1 200 OK
Content-Type: text/xml
Content-Length: 91
```

```
<?xml version="1.0"?>
<Command>
<CameraPositionSetResult item="1" status="OK"/>
</Command>
```

## Feedback from codec over HTTP

To get notifications from the codec, you need to register HTTP feedback expressions. The codec then uses HTTP POST to send feedback messages to the URL supplied in `ServerUrl`. This means that you have to have a HTTP server running for your application to receive updates from the codec.

### Registering for feedback

The command for registering is `xCommand HttpFeedback Register`. The syntax for this command and its arguments are described in this section.

HttpFeedback Register syntax:

```
xCommand HttpFeedback Register
FeedbackSlot: <1..4>
ServerUrl(r): <S: 1, 2048>
Expression: <S: 1, 255>
Expression: <S: 1, 255>
Expression: <S: 1, 255>
Expression: <S: 1, 255>
Expression: <S: 1, 255>
Expression: <S: 1, 255>
Expression: <S: 1, 255>
Expression: <S: 1, 255>
Expression: <S: 1, 255>
Expression: <S: 1, 255>
Expression: <S: 1, 255>
Expression: <S: 1, 255>
Expression: <S: 1, 255>
Expression: <S: 1, 255>
Expression: <S: 1, 255>
Expression: <S: 1, 255>
```

HttpFeedback Register arguments:

**FeedbackSlot:** The codec can register up to 4 slots of servers requesting HTTP feedback. Set the registering to one of them.

**NOTE:** Avoid using FeedbackSlot 3 in an environment where Cisco TelePresence Management Suite (TMS) is used as TMS uses this feedbackslot to register its expressions.

**ServerUrl:** The URL that you want the codec to post the HTTP feedback messages to.

**Expression 1-15:** Register the expressions you want to receive feedback on. See the ["Feedback mechanism" on page 26](#) section for more information about the expression formats.

**Example:** Registering feedback on configuration changes, disconnect events and call status changes.

```
<Command>
  <HttpFeedback>
    <Register command="True">
      <FeedbackSlot>1</FeedbackSlot>
      <ServerUrl>http://127.0.0.1/
myhttppostscripturl</ServerUrl>
      <Expression item="1">/Configuration</
Expression>
      <Expression item="2">/Event/
CallDisconnect</Expression>
      <Expression item="3">/Status/Call</
Expression>
    </Register>
  </HttpFeedback>
</Command>
```

Feedback output

When the codec notifies the registered HTTP server about changes, the body contains the same XML as when polling. There is however one small difference. The root-node contains an `Identification` node with children that specify the codec from which the notification originated. This means that you can handle multiple codecs with a single HTTP server URI.

**Example:** Audio volume changed.

```
<Configuration xmlns="http://www.company.com/XML/
CUIL/2.0">
  <Identification>
    <SystemName>integrator</SystemName>
    <MACAddress>00:00:de:ad:be:ef</MACAddress>
    <IPAddress>192.168.1.100</IPAddress>
    <ProductType>Cisco Codec</ProductType>
    <ProductID>Cisco Codec C90</ProductID>
    <SWVersion>TC6.0.0.199465</SWVersion>
    <HWBoard>101401-5 [08]</HWBoard>
    <SerialNumber>PH0000000</SerialNumber>
  </Identification>
  <Audio item="1">
    <Volume item="1">60</Volume>
  </Audio>
</Configuration>
```

## Translating from terminal mode to XML

### Translating commands

The XML commands maintain the same structure as the terminal commands, but they use a parent-child relationship to describe the hierarchy. You can see this structure in the examples below.

**Example 1:** Setting up a call.

#### Terminal

```
xCommand Dial Number: "12345" Protocol: H323
```

#### XML

```
<Command>
  <Dial command="True">
    <Number>12345</Number>
    <Protocol>H323</Protocol>
  </Dial>
</Command>
```

**Example 2:** Assigning video layout to a call.

#### Terminal

```
xCommand Video Layout AssignCall CallId: 2
LayoutId: 1
```

#### XML

```
<Command>
  <Video>
    <Layout>
      <AssignCall command="True">
        <CallId>2</CallId>
        <LayoutId>1</LayoutId>
      </AssignCall>
    </Layout>
  </Video>
</Command>
```

### Translating configurations

Translating from xConfiguration to XML is similar to commands, but with the addition of a special attribute item="NN" for specifying the index in arrays.

**Example:** Configuring the input source type for video input connector 2.

#### Terminal

```
xConfiguration Video Input Connector 2
InputSourceType: camera
```

#### XML

```
<Configuration>
  <Video>
    <Input>
      <Connector item="2">
        <InputSourceType>camera</InputSourceType>
      </Connector>
    </Input>
  </Video>
</Configuration>
```

## Dos and don'ts

Here are some best practices when programming the Cisco series API.

### DO use complete commands

You should always use complete commands when programming, i.e. always use xConfiguration Video instead of xconf vid. The shortcuts can be used for searches in the API on the command line, but not for programming. The reason for this is that you might end up with ambiguous code when additional commands are added to the API.

### DO NOT subscribe to unnecessary feedback

Subscribing to too much feedback may congest the control application. Although the amount of feedback may seem fine in the current version, the amount of feedback may grow in future releases.



## Chapter 3

# xConfiguration commands

## Description of the xConfiguration commands

In this chapter, you can find a complete list of the xConfiguration commands. The examples show either the default value or an example of a value.

We recommend you visit our web site regularly for updated versions of the manual.

Go to: <http://www.cisco.com/go/dx-docs>

<b>Audio configuration</b> .....	<b>45</b>	xConfiguration H323 Gatekeeper Address .....	50
xConfiguration Audio DefaultVolume .....	45	xConfiguration H323 H323Alias E164 .....	50
xConfiguration Audio SoundsAndAlerts RingTone.....	45	xConfiguration H323 H323Alias ID.....	50
xConfiguration Audio SoundsAndAlerts RingVolume .....	45	xConfiguration H323 NAT Mode .....	51
xConfiguration Audio Input MicrophoneMode .....	45	xConfiguration H323 NAT Address .....	51
<b>Conference configuration</b> .....	<b>46</b>	<b>Network configuration</b> .....	<b>52</b>
xConfiguration Conference AutoAnswer Mode .....	46	xConfiguration Network [1] DNS Domain Name.....	52
xConfiguration Conference AutoAnswer Mute .....	46	xConfiguration Network [1] DNS Server [1..3] Address .....	52
xConfiguration Conference AutoAnswer Delay .....	46	xConfiguration Network [1] IEEE8021X Mode.....	52
xConfiguration Conference DefaultCall Rate .....	46	xConfiguration Network [1] IEEE8021X TlsVerify .....	52
xConfiguration Conference DoNotDisturb DefaultTimeout .....	47	xConfiguration Network [1] IEEE8021X UseClientCertificate .....	53
xConfiguration Conference Encryption Mode.....	47	xConfiguration Network [1] IEEE8021X Identity .....	53
xConfiguration Conference FarEndControl Mode.....	47	xConfiguration Network [1] IEEE8021X Password.....	53
xConfiguration Conference MaxReceiveCallRate .....	47	xConfiguration Network [1] IEEE8021X AnonymouIdentity.....	53
xConfiguration Conference MaxTransmitCallRate.....	48	xConfiguration Network [1] IEEE8021X Eap Md5.....	54
xConfiguration Conference MaxTotalReceiveCallRate.....	48	xConfiguration Network [1] IEEE8021X Eap Ttls .....	54
xConfiguration Conference MaxTotalTransmitCallRate.....	48	xConfiguration Network [1] IEEE8021X Eap Tls .....	54
		xConfiguration Network [1] IEEE8021X Eap Peap.....	54
<b>H323 configuration</b> .....	<b>49</b>	xConfiguration Network [1] IPStack .....	55
xConfiguration H323 Authentication Mode.....	49	xConfiguration Network [1] IPv4 Assignment .....	55
xConfiguration H323 Authentication LoginName.....	49	xConfiguration Network [1] IPv4 Address.....	55
xConfiguration H323 Authentication Password .....	49	xConfiguration Network [1] IPv4 Gateway .....	55
xConfiguration H323 CallSetup Mode.....	49	xConfiguration Network [1] IPv4 SubnetMask .....	56
xConfiguration H323 Encryption KeySize .....	50	xConfiguration Network [1] IPv6 Assignment.....	56

xConfiguration Network [1] IPv6 Address .....	56	xConfiguration Phonebook Server [1] Type .....	65
xConfiguration Network [1] IPv6 Gateway .....	56	xConfiguration Phonebook Server [1] URL .....	66
xConfiguration Network [1] IPv6 DHCPOptions .....	57	<b>Provisioning configuration .....</b>	<b>66</b>
xConfiguration Network [1] MTU .....	57	xConfiguration Provisioning Connectivity .....	66
xConfiguration Network [1] QoS Mode .....	57	xConfiguration Provisioning Mode .....	67
xConfiguration Network [1] QoS Diffserv Audio .....	58	xConfiguration Provisioning LoginName .....	67
xConfiguration Network [1] QoS Diffserv Video .....	58	xConfiguration Provisioning Password .....	67
xConfiguration Network [1] QoS Diffserv Data .....	59	xConfiguration Provisioning HttpMethod .....	68
xConfiguration Network [1] QoS Diffserv Signalling .....	59	xConfiguration Provisioning ExternalManager Address .....	68
xConfiguration Network [1] QoS Diffserv ICMPv6 .....	60	xConfiguration Provisioning ExternalManager AlternateAddress .....	68
xConfiguration Network [1] QoS Diffserv NTP .....	60	xConfiguration Provisioning ExternalManager Protocol .....	68
xConfiguration Network [1] RemoteAccess Allow .....	60	xConfiguration Provisioning ExternalManager Path .....	69
xConfiguration Network [1] VLAN Voice Mode .....	61	xConfiguration Provisioning ExternalManager Domain .....	69
xConfiguration Network [1] VLAN Voice VlanId .....	61	<b>SerialPort configuration .....</b>	<b>69</b>
<b>NetworkServices configuration .....</b>	<b>61</b>	xConfiguration SerialPort Mode .....	69
xConfiguration NetworkServices CDP Mode .....	61	xConfiguration SerialPort LoginRequired .....	69
xConfiguration NetworkServices H323 Mode .....	61	<b>SIP configuration .....</b>	<b>70</b>
xConfiguration NetworkServices HTTP Mode .....	62	xConfiguration SIP Authentication UserName .....	70
xConfiguration NetworkServices HTTPS VerifyServerCertificate .....	62	xConfiguration SIP Authentication Password .....	70
xConfiguration NetworkServices HTTPS VerifyClientCertificate .....	62	xConfiguration SIP DefaultTransport .....	70
xConfiguration NetworkServices NTP Mode .....	62	xConfiguration SIP DisplayName .....	70
xConfiguration NetworkServices NTP Server [1..3] Address .....	63	xConfiguration SIP Ice Mode .....	71
xConfiguration NetworkServices SIP Mode .....	63	xConfiguration SIP Ice DefaultCandidate .....	71
xConfiguration NetworkServices SNMP Mode .....	63	xConfiguration SIP Ice OfferTcpCandidates .....	71
xConfiguration NetworkServices SNMP Host [1..3] Address .....	63	xConfiguration SIP ListenPort .....	71
xConfiguration NetworkServices SNMP CommunityName .....	64	xConfiguration SIP Proxy [1..4] Address .....	72
xConfiguration NetworkServices SNMP SystemContact .....	64	xConfiguration SIP Turn Server .....	72
xConfiguration NetworkServices SNMP SystemLocation .....	64	xConfiguration SIP Turn UserName .....	72
xConfiguration NetworkServices SSH Mode .....	64	xConfiguration SIP Turn Password .....	72
xConfiguration NetworkServices Telnet Mode .....	65	xConfiguration SIP URI .....	72
xConfiguration NetworkServices WelcomeText .....	65		
<b>Phonebook configuration .....</b>	<b>65</b>		
xConfiguration Phonebook Server [1] ID .....	65		



**Standby configuration ..... 73**

- xConfiguration Standby Control .....73
- xConfiguration Standby Delay .....73

**SystemUnit configuration ..... 73**

- xConfiguration SystemUnit Name .....73

**Time configuration ..... 74**

- xConfiguration Time TimeFormat .....74
- xConfiguration Time DateFormat .....74
- xConfiguration Time Zone .....74

**UserInterface configuration ..... 76**

- xConfiguration UserInterface ContactInfo Type .....76
- xConfiguration UserInterface KeyTones Mode .....76
- xConfiguration UserInterface Language .....76
- xConfiguration UserInterface OSD Output .....77

**UserManagement configuration ..... 77**

- xConfiguration UserManagement LDAP Mode .....77
- xConfiguration UserManagement LDAP Server Address .....77
- xConfiguration UserManagement LDAP Server Port .....78
- xConfiguration UserManagement LDAP Encryption .....78
- xConfiguration UserManagement LDAP MinimumTLSVersion .....78
- xConfiguration UserManagement LDAP VerifyServerCertificate .....78
- xConfiguration UserManagement LDAP Admin Filter .....79
- xConfiguration UserManagement LDAP Admin Group .....79
- xConfiguration UserManagement LDAP Attribute .....79

**Video configuration ..... 80**

- xConfiguration Video DefaultMainSource ..... 80
- xConfiguration Video Input Connector [1..2] CameraControl Mode ..... 80
- xConfiguration Video Input Connector [1..2] CameraControl Camerald ..... 80
- xConfiguration Video Input Connector [1..2] InputSourceType ..... 80
- xConfiguration Video Input Connector [1..2] Name .....81

- xConfiguration Video Input Connector [2] Quality .....81
- xConfiguration Video Input Connector [2] PresentationSelection .....81
- xConfiguration Video Input Connector [1..2] Visibility .....82
- xConfiguration Video Monitors .....82
- xConfiguration Video Output Connector [2] CEC Mode .....82
- xConfiguration Video Output Connector [2] OverscanLevel .....83
- xConfiguration Video Output Connector [1..2] Resolution .....83
- xConfiguration Video Presentation DefaultSource .....83
- xConfiguration Video Selfview Default Mode .....83
- xConfiguration Video Selfview Default FullscreenMode .....84
- xConfiguration Video Selfview Default OnMonitorRole .....84
- xConfiguration Video Selfview Default PIPPosition .....84
- xConfiguration Video Selfview OnCall Mode .....85
- xConfiguration Video Selfview OnCall Duration .....85

## Audio configuration

### xConfiguration Audio DefaultVolume

Define the default volume for the speakers. The volume is set to this value when you switch on or restart the video system. Use the Touch controller or remote control to change the volume while the video system is running. You may also use API commands (xCommand Audio Volume) to change the volume while the video system is running, and to reset to default value.

Requires user role: ADMIN, USER

Default value: 50

#### USAGE:

xConfiguration Audio DefaultVolume: DefaultVolume

where

DefaultVolume: Integer (0..100)

Select a value between 1 and 100. This corresponds to the dB range from -34.5 dB to 15 dB, in steps of 0.5 dB). If set to 0 the audio is switched off.

### xConfiguration Audio SoundsAndAlerts RingTone

Define which ringtone to use for incoming calls.

Requires user role: ADMIN, USER

Default value: Sunrise

#### USAGE:

xConfiguration Audio SoundsAndAlerts RingTone: RingTone

where

RingTone: Sunrise/Mischief/Ripples/Reflections/Vibes/Delight/Evolve/Playful/Ascent/Calculation/Mellow/Ringer

Select a ringtone from the list.

### xConfiguration Audio SoundsAndAlerts RingVolume

Define the ring volume for incoming calls.

Requires user role: ADMIN, USER

Default value: 50

#### USAGE:

xConfiguration Audio SoundsAndAlerts RingVolume: RingVolume

where

RingVolume: Integer (0..100)

The value goes in steps of 5 from 0 to 100 (from -34.5 dB to 15 dB). Volume 0 = Off.

### xConfiguration Audio Input MicrophoneMode

This setting only applies to DX80.

The DX80 has microphones in both legs. If you set the microphone mode to Focused, the microphones can be combined to focus sound sensitivity. As a result, the noise in the room is suppressed, and you can be heard better when sitting right in front of the video system. The voice of people not sitting right in front of the system will be suppressed.

If you set the microphone mode to Wide, the system behaves like any other system. The voice of people sitting beside you will be heard, and also more noise from the room.

We recommend that you use Focused mode when you are the only speaker. Use Wide mode when several speakers are in front of the system.

Requires user role: ADMIN

Default value: Wide

#### USAGE:

xConfiguration Audio Input MicrophoneMode: MicrophoneMode

where

MicrophoneMode: Focused/Wide

Focused: Focused sound sensitivity, suppressing sound from sources that are not right in front of the video system.

Wide: Default microphone operation with normal sound sensitivity.

## Conference configuration

### xConfiguration Conference AutoAnswer Mode

Define the auto answer mode. Use the Conference AutoAnswer Delay setting if you want the system to wait a number of seconds before answering the call, and use the Conference AutoAnswer Mute setting if you want your microphone to be muted when the call is answered.

Requires user role: ADMIN

Default value: Off

#### USAGE:

xConfiguration Conference AutoAnswer Mode: Mode

where

Mode: Off/On

Off: You must answer incoming calls manually by tapping Answer.

On: The system automatically answers incoming calls, except if you are already in a call. You must always answer or decline incoming calls manually when you are already engaged in a call.

### xConfiguration Conference AutoAnswer Mute

Define if the microphone shall be muted when an incoming call is automatically answered. Requires that AutoAnswer Mode is switched on.

Requires user role: ADMIN

Default value: Off

#### USAGE:

xConfiguration Conference AutoAnswer Mute: Mute

where

Mute: Off/On

Off: The incoming call will not be muted.

On: The incoming call will be muted when automatically answered.

### xConfiguration Conference AutoAnswer Delay

Define how long (in seconds) an incoming call has to wait before it is answered automatically by the system. Requires that AutoAnswer Mode is switched on.

Requires user role: ADMIN

Default value: 0

#### USAGE:

xConfiguration Conference AutoAnswer Delay: Delay

where

Delay: Integer (0..50)

The auto answer delay (seconds).

### xConfiguration Conference DefaultCall Rate

Define the Default Call Rate to be used when placing calls from the system.

Requires user role: ADMIN

Default value: 3072

#### USAGE:

xConfiguration Conference DefaultCall Rate: Rate

where

Rate: Integer (64..3072)

The default call rate (kbps).

### xConfiguration Conference DoNotDisturb DefaultTimeout

This setting determines the default duration of a Do Not Disturb session, i.e. the period when incoming calls are rejected and registered as missed calls. The session can be terminated earlier by using the user interface. The default value is 60 minutes.

Requires user role: ADMIN

Default value: 60

#### USAGE:

xConfiguration Conference DoNotDisturb DefaultTimeout: DefaultTimeout

where

DefaultTimeout: Integer (1..1440)

The number of minutes (maximum 1440 minutes = 24 hours) before the Do Not Disturb session times out automatically.

### xConfiguration Conference Encryption Mode

Define the conference encryption mode. A padlock with the text "Encryption On" or "Encryption Off" displays on screen for a few seconds when the conference starts.

NOTE: If the Encryption Option Key is not installed on the video system, the encryption mode is always Off.

Requires user role: ADMIN

Default value: BestEffort

#### USAGE:

xConfiguration Conference Encryption Mode: Mode

where

Mode: Off/On/BestEffort

Off: The system will not use encryption.

On: The system will only allow calls that are encrypted.

BestEffort: The system will use encryption whenever possible.

> In Point to point calls: If the far end system supports encryption (AES-128), the call will be encrypted. If not, the call will proceed without encryption.

> In MultiSite calls: In order to have encrypted MultiSite conferences, all sites must support encryption. If not, the conference will be unencrypted.

### xConfiguration Conference FarEndControl Mode

Lets you decide if the remote side (far end) should be allowed to select your video sources and control your local camera (pan, tilt, zoom).

Requires user role: ADMIN

Default value: On

#### USAGE:

xConfiguration Conference FarEndControl Mode: Mode

where

Mode: Off/On

Off: The far end is not allowed to select your video sources or to control your local camera (pan, tilt, zoom).

On: Allows the far end to be able to select your video sources and control your local camera (pan, tilt, zoom). You will still be able to control your camera and select your video sources as normal.

### xConfiguration Conference MaxReceiveCallRate

Define the maximum receive bit rate to be used when placing or receiving calls. Note that this is the maximum bit rate for each individual call; use the Conference MaxTotalReceiveCallRate setting to set the aggregated maximum for all simultaneous active calls.

Requires user role: ADMIN

Default value: 3072

#### USAGE:

xConfiguration Conference MaxReceiveCallRate: MaxReceiveCallRate

where

MaxReceiveCallRate: Integer (64..3072)

The maximum receive call rate (kbps).

### xConfiguration Conference MaxTransmitCallRate

Define the maximum transmit bit rate to be used when placing or receiving calls. Note that this is the maximum bit rate for each individual call; use the Conference MaxTotalTransmitCallRate setting to set the aggregated maximum for all simultaneous active calls.

Requires user role: ADMIN

Default value: 3072

#### USAGE:

xConfiguration Conference MaxTransmitCallRate: MaxTransmitCallRate

where

MaxTransmitCallRate: Integer (64..3072)

The maximum transmitt call rate (kbps).

### xConfiguration Conference MaxTotalReceiveCallRate

Define the maximum overall receive bit rate allowed. This product does not support multiple simultaneous calls, so the total receive call rate will be the same as the receive bit rate for one call (ref. Conference MaxReceiveCallRate setting).

Requires user role: ADMIN

Default value: 3072

#### USAGE:

xConfiguration Conference MaxTotalReceiveCallRate: MaxTotalReceiveCallRate

where

MaxTotalReceiveCallRate: Integer (64..3072)

The maximum receive call rate (kbps).

### xConfiguration Conference MaxTotalTransmitCallRate

Define the maximum overall transmit bit rate allowed. This product does not support multiple simultaneous calls, so the total transmit call rate will be the same as the transmit bit rate for one call (ref. Conference MaxTransmitCallRate setting).

Requires user role: ADMIN

Default value: 3072

#### USAGE:

xConfiguration Conference MaxTotalTransmitCallRate: MaxTotalTransmitCallRate

where

MaxTotalTransmitCallRate: Integer (64..3072)

The maximum transmit call rate (kbps).



## H323 configuration

### xConfiguration H323 Authentication Mode

Define the authenticatin mode for the H.323 profile.

Requires user role: ADMIN

Default value: Off

#### USAGE:

xConfiguration H323 Authentication Mode: Mode

where

Mode: Off/On

Off: The system will not try to authenticate itself to a H.323 Gatekeeper, but will still try a normal registration.

On: If an H.323 Gatekeeper indicates that it requires authentication, the system will try to authenticate itself to the gatekeeper. Requires the H323 Authentication LoginName and H323 Authentication Password settings to be defined on both the codec and the Gatekeeper.

### xConfiguration H323 Authentication LoginName

The system sends the H323 Authentication Login Name and the H323 Authentication Password to an H.323 Gatekeeper for authentication. The authentication is a one way authentication from the codec to the H.323 Gatekeeper, i.e. the system is authenticated to the gatekeeper. If the H.323 Gatekeeper indicates that no authentication is required, the system will still try to register. Requires the H.323 Authentication Mode to be enabled.

Requires user role: ADMIN

Default value: ""

#### USAGE:

xConfiguration H323 Authentication LoginName: "LoginName"

where

LoginName: String (0, 50)

The authentication login name.

### xConfiguration H323 Authentication Password

The system sends the H323 Authentication Login Name and the H323 Authentication Password to an H.323 Gatekeeper for authentication. The authentication is a one way authentication from the codec to the H.323 Gatekeeper, i.e. the system is authenticated to the gatekeeper. If the H.323 Gatekeeper indicates that no authentication is required, the system will still try to register. Requires the H.323 Authentication Mode to be enabled.

Requires user role: ADMIN

Default value: ""

#### USAGE:

xConfiguration H323 Authentication Password: "Password"

where

Password: String (0, 50)

The authentication password.

### xConfiguration H323 CallSetup Mode

Defines whether to use a Gatekeeper or Direct calling when establishing H.323 calls. Direct H.323 calls can be made also when H323 CallSetup Mode is set to Gatekeeper.

Requires user role: ADMIN

Default value: Gatekeeper

#### USAGE:

xConfiguration H323 CallSetup Mode: Mode

where

Mode: Direct/Gatekeeper

Direct: You can only make an H.323 call by dialing an IP address directly.

Gatekeeper: The system uses a Gatekeeper to make an H.323 call. When choosing this option, the H323 Gatekeeper Address must also be configured.

### xConfiguration H323 Encryption KeySize

Define the minimum or maximum key size for the Diffie–Hellman key exchange method, which is used when establishing the Advanced Encryption Standard (AES) encryption key.

Requires user role: ADMIN

Default value: Max1024bit

#### USAGE:

xConfiguration H323 Encryption KeySize: KeySize

where

KeySize: Min1024bit/Max1024bit/Min2048bit

Min1024bit: The minimum size is 1024 bit.

Max1024bit: The maximum size is 1024 bit.

Min2048bit: The minimum size is 2048 bit.

### xConfiguration H323 Gatekeeper Address

Define the IP address of the Gatekeeper. Requires H323 CallSetup Mode to be set to Gatekeeper.

Requires user role: ADMIN

Default value: ""

#### USAGE:

xConfiguration H323 Gatekeeper Address: "Address"

where

Address: String (0, 255)

A valid IPv4 address, IPv6 address or DNS name.

### xConfiguration H323 H323Alias E164

The H.323 Alias E.164 defines the address of the system, according to the numbering plan implemented in the H.323 Gatekeeper. The E.164 alias is equivalent to a telephone number, sometimes combined with access codes.

Requires user role: ADMIN

Default value: ""

#### USAGE:

xConfiguration H323 H323Alias E164: "E164"

where

E164: String (0, 30)

The H.323 Alias E.164 address. Valid characters are 0-9, \* and #.

### xConfiguration H323 H323Alias ID

Define the H.323 Alias ID, which is used to address the system on a H.323 Gatekeeper and will be displayed in the call lists.

Requires user role: ADMIN

Default value: ""

#### USAGE:

xConfiguration H323 H323Alias ID: "ID"

where

ID: String (0, 49)

The H.323 Alias ID. Example: "firstname.lastname@company.com", "My H.323 Alias ID"

### xConfiguration H323 NAT Mode

The firewall traversal technology creates a secure path through the firewall barrier, and enables proper exchange of audio/video data when connected to an external video conferencing system (when the IP traffic goes through a NAT router). NOTE: NAT does not work in conjunction with gatekeepers.

Requires user role: ADMIN

Default value: Off

#### USAGE:

xConfiguration H323 NAT Mode: Mode

where

Mode: Auto/Off/On

Auto: The system will determine if the H323 NAT Address or the real IP address should be used in signaling. This makes it possible to place calls to endpoints on the LAN as well as endpoints on the WAN. If the H323 NAT Address is wrong or not set, the real IP address will be used.

Off: The system will signal the real IP address.

On: The system will signal the configured H323 NAT Address instead of its real IP address in Q.931 and H.245. The NAT server address will be shown in the startup-menu as: "My IP Address: 10.0.2.1". If the H323 NAT Address is wrong or not set, H.323 calls cannot be set up.

### xConfiguration H323 NAT Address

Define the external/global IP address to the router with NAT support. Packets sent to the router will then be routed to the system. Note that NAT cannot be used when registered to a gatekeeper.

In the router, the following ports must be routed to the system's IP address:

\* Port 1720

\* Port 5555-6555

\* Port 2326-2487

Requires user role: ADMIN

Default value: ""

#### USAGE:

xConfiguration H323 NAT Address: "Address"

where

Address: String (0, 64)

A valid IPv4 address or IPv6 address.

## Network configuration

### xConfiguration Network [1] DNS Domain Name

The DNS Domain Name is the default domain name suffix which is added to unqualified names.

Example: If the DNS Domain Name is "company.com" and the name to lookup is "MyVideoSystem", this will result in the DNS lookup "MyVideoSystem.company.com".

Requires user role: ADMIN

Default value: ""

#### USAGE:

xConfiguration Network *n* DNS Domain Name: "*Name*"

where

*n*: Index that identifies the network. Range: 1..1

*Name*: String (0, 64)

The DNS domain name.

### xConfiguration Network [1] DNS Server [1..3] Address

Define the network addresses for DNS servers. Up to three addresses may be specified. If the network addresses are unknown, contact your administrator or Internet Service Provider.

Requires user role: ADMIN

Default value: ""

#### USAGE:

xConfiguration Network *n* DNS Server *m* Address: "*Address*"

where

*n*: Index that identifies the network. Range: 1..1

*m*: Index that identifies the DNS server. Maximum three DNS servers are allowed. Range: 1..3

*Address*: String (0, 64)

A valid IPv4 address or IPv6 address.

### xConfiguration Network [1] IEEE8021X Mode

The system can be connected to an IEEE 802.1X LAN network, with a port-based network access control that is used to provide authenticated network access for Ethernet networks.

Requires user role: ADMIN

Default value: Off

#### USAGE:

xConfiguration Network *n* IEEE8021X Mode: *Mode*

where

*n*: Index that identifies the network. Range: 1..1

*Mode*: Off/On

Off: The 802.1X authentication is disabled (default).

On: The 802.1X authentication is enabled.

### xConfiguration Network [1] IEEE8021X TlsVerify

Verification of the server-side certificate of an IEEE802.1x connection against the certificates in the local CA-list when TLS is used. The CA-list must be uploaded to the video system. This can be done from the web interface.

This setting takes effect only when Network [1] IEEE8021X Eap Tls is enabled (On).

Requires user role: ADMIN

Default value: Off

#### USAGE:

xConfiguration Network *n* IEEE8021X TlsVerify: *TlsVerify*

where

*n*: Index that identifies the network. Range: 1..1

*TlsVerify*: Off/On

Off: When set to Off, TLS connections are allowed without verifying the server-side X.509 certificate against the local CA-list. This should typically be selected if no CA-list has been uploaded to the codec.

On: When set to On, the server-side X.509 certificate will be validated against the local CA-list for all TLS connections. Only servers with a valid certificate will be allowed.

### xConfiguration Network [1] IEEE8021X UseClientCertificate

Authentication using a private key/certificate pair during an IEEE802.1x connection. The authentication X.509 certificate must be uploaded to the video system. This can be done from the web interface.

Requires user role: ADMIN

Default value: Off

#### USAGE:

xConfiguration Network *n* IEEE8021X UseClientCertificate: *UseClientCertificate*

where

*n*: Index that identifies the network. Range: 1..1

*UseClientCertificate*: Off/On

Off: When set to Off client-side authentication is not used (only server-side).

On: When set to On the client (video system) will perform a mutual authentication TLS handshake with the server.

### xConfiguration Network [1] IEEE8021X Identity

Define the user name for 802.1X authentication.

Requires user role: ADMIN

Default value: ""

#### USAGE:

xConfiguration Network *n* IEEE8021X Identity: "*Identity*"

where

*n*: Index that identifies the network. Range: 1..1

*Identity*: String (0, 64)

The user name for 802.1X authentication.

### xConfiguration Network [1] IEEE8021X Password

Define the password for 802.1X authentication.

Requires user role: ADMIN

Default value: ""

#### USAGE:

xConfiguration Network *n* IEEE8021X Password: "*Password*"

where

*n*: Index that identifies the network. Range: 1..1

*Password*: String (0, 32)

The password for 802.1X authentication.

### xConfiguration Network [1] IEEE8021X AnonymousIdentity

The 802.1X Anonymous ID string is to be used as unencrypted identity with EAP (Extensible Authentication Protocol) types that support different tunneled identity, like EAP-PEAP and EAP-TTLS. If set, the anonymous ID will be used for the initial (unencrypted) EAP Identity Request.

Requires user role: ADMIN

Default value: ""

#### USAGE:

xConfiguration Network *n* IEEE8021X AnonymousIdentity: "*AnonymousIdentity*"

where

*n*: Index that identifies the network. Range: 1..1

*AnonymousIdentity*: String (0, 64)

The 802.1X Anonymous ID string.

### xConfiguration Network [1] IEEE8021X Eap Md5

Define the Md5 (Message-Digest Algorithm 5) mode. This is a Challenge Handshake Authentication Protocol that relies on a shared secret. Md5 is a Weak security.

Requires user role: ADMIN

Default value: On

#### USAGE:

xConfiguration Network *n* IEEE8021X Eap Md5: *Md5*

where

*n*: Index that identifies the network. Range: 1..1

*Md5*: Off/On

Off: The EAP-MD5 protocol is disabled.

On: The EAP-MD5 protocol is enabled (default).

### xConfiguration Network [1] IEEE8021X Eap Ttls

Define the TTLS (Tunneled Transport Layer Security) mode. Authenticates LAN clients without the need for client certificates. Developed by Funk Software and Certicom. Usually supported by Agere Systems, Proxim and Avaya.

Requires user role: ADMIN

Default value: On

#### USAGE:

xConfiguration Network *n* IEEE8021X Eap Ttls: *Ttls*

where

*n*: Index that identifies the network. Range: 1..1

*Ttls*: Off/On

Off: The EAP-TTLS protocol is disabled.

On: The EAP-TTLS protocol is enabled (default).

### xConfiguration Network [1] IEEE8021X Eap Tls

Enable or disable the use of EAP-TLS (Transport Layer Security) for IEEE802.1x connections. The EAP-TLS protocol, defined in RFC 5216, is considered one of the most secure EAP standards. LAN clients are authenticated using client certificates.

Requires user role: ADMIN

Default value: On

#### USAGE:

xConfiguration Network *n* IEEE8021X Eap Tls: *Tls*

where

*n*: Index that identifies the network. Range: 1..1

*Tls*: Off/On

Off: The EAP-TLS protocol is disabled.

On: The EAP-TLS protocol is enabled (default).

### xConfiguration Network [1] IEEE8021X Eap Peap

Define the Peap (Protected Extensible Authentication Protocol) mode. Authenticates LAN clients without the need for client certificates. Developed by Microsoft, Cisco and RSA Security.

Requires user role: ADMIN

Default value: On

#### USAGE:

xConfiguration Network *n* IEEE8021X Eap Peap: *Peap*

where

*n*: Index that identifies the network. Range: 1..1

*Peap*: Off/On

Off: The EAP-PEAP protocol is disabled.

On: The EAP-PEAP protocol is enabled (default).

### xConfiguration Network [1] IPStack

Select if the system should use IPv4, IPv6, or dual IP stack, on the network interface. NOTE: After changing this setting you may have to wait up to 30 seconds before it takes effect.

Requires user role: ADMIN

Default value: Dual

#### USAGE:

xConfiguration Network *n* IPStack: *IPStack*

where

*n*: Index that identifies the network. Range: 1..1

*IPStack*: Dual/IPv4/IPv6

Dual: When set to Dual, the network interface can operate on both IP versions at the same time, and can have both an IPv4 and an IPv6 address at the same time.

IPv4: When set to IPv4, the system will use IPv4 on the network interface.

IPv6: When set to IPv6, the system will use IPv6 on the network interface.

### xConfiguration Network [1] IPv4 Assignment

Define how the system will obtain its IPv4 address, subnet mask and gateway address. This setting only applies to systems on IPv4 networks.

Requires user role: ADMIN

Default value: DHCP

#### USAGE:

xConfiguration Network *n* IPv4 Assignment: *Assignment*

where

*n*: Index that identifies the network. Range: 1..1

*Assignment*: Static/DHCP

Static: The addresses must be configured manually using the Network IPv4 Address, Network IPv4 Gateway and Network IPv4 SubnetMask settings (static addresses).

DHCP: The system addresses are automatically assigned by the DHCP server.

### xConfiguration Network [1] IPv4 Address

Define the static IPv4 network address for the system. Applicable only when Network IPv4 Assignment is set to Static.

Requires user role: ADMIN

Default value: ""

#### USAGE:

xConfiguration Network *n* IPv4 Address: "*Address*"

where

*n*: Index that identifies the network. Range: 1..1

*Address*: String (0, 64)

A valid IPv4 address.

### xConfiguration Network [1] IPv4 Gateway

Define the IPv4 network gateway address. Applicable only when the Network IPv4 Assignment is set to Static.

Requires user role: ADMIN

Default value: ""

#### USAGE:

xConfiguration Network *n* IPv4 Gateway: "*Gateway*"

where

*n*: Index that identifies the network. Range: 1..1

*Gateway*: String (0, 64)

A valid IPv4 address.

### xConfiguration Network [1] IPv4 SubnetMask

Define the IPv4 network subnet mask. Applicable only when the Network IPv4 Assignment is set to Static.

Requires user role: ADMIN

Default value: ""

#### USAGE:

xConfiguration Network *n* IPv4 SubnetMask: "SubnetMask"

where

*n*: Index that identifies the network. Range: 1..1

SubnetMask: String (0, 64)

A valid IPv4 address.

### xConfiguration Network [1] IPv6 Assignment

Define how the system will obtain its IPv6 address and the default gateway address. This setting only applies to systems on IPv6 networks.

Requires user role: ADMIN

Default value: Autoconf

#### USAGE:

xConfiguration Network *n* IPv6 Assignment: Assignment

where

*n*: Index that identifies the network. Range: 1..1

Assignment: Static/DHCPv6/Autoconf

Static: The codec and gateway IP addresses must be configured manually using the Network IPv6 Address and Network IPv6 Gateway settings. The options, for example NTP and DNS server addresses, must either be set manually or obtained from a DHCPv6 server. The Network IPv6 DHCPOptions setting determines which method to use.

DHCPv6: All IPv6 addresses, including options, will be obtained from a DHCPv6 server. See RFC 3315 for a detailed description. The Network IPv6 DHCPOptions setting will be ignored.

Autoconf: Enable IPv6 stateless autoconfiguration of the IPv6 network interface. See RFC 4862 for a detailed description. The options, for example NTP and DNS server addresses, must either be set manually or obtained from a DHCPv6 server. The Network IPv6 DHCPOptions setting determines which method to use.

### xConfiguration Network [1] IPv6 Address

Define the static IPv6 network address for the system. Applicable only when the Network IPv6 Assignment is set to Static.

Requires user role: ADMIN

Default value: ""

#### USAGE:

xConfiguration Network *n* IPv6 Address: "Address"

where

*n*: Index that identifies the network. Range: 1..1

Address: String (0, 64)

A valid IPv6 address including a network mask. Example: 2001:DB8::/48

### xConfiguration Network [1] IPv6 Gateway

Define the IPv6 network gateway address. This setting is only applicable when the Network IPv6 Assignment is set to Static.

Requires user role: ADMIN

Default value: ""

#### USAGE:

xConfiguration Network *n* IPv6 Gateway: "Gateway"

where

*n*: Index that identifies the network. Range: 1..1

Gateway: String (0, 64)

A valid IPv6 address.



### xConfiguration Network [1] IPv6 DHCPOptions

Retrieve a set of DHCP options, for example NTP and DNS server addresses, from a DHCPv6 server.

Requires user role: ADMIN

Default value: On

#### USAGE:

xConfiguration Network *n* IPv6 DHCPOptions: *DHCPOptions*

where

*n*: Index that identifies the network. Range: 1..1

*DHCPOptions*: Off/On

Off: Disable the retrieval of DHCP options from a DHCPv6 server.

On: Enable the retrieval of a selected set of DHCP options from a DHCPv6 server.

### xConfiguration Network [1] MTU

Define the Ethernet MTU (Maximum Transmission Unit) size. The MTU size must be supported by your network infrastructure. The minimum size is 576 for IPv4 and 1280 for IPv6.

Requires user role: ADMIN

Default value: 1500

#### USAGE:

xConfiguration Network *n* MTU: *MTU*

where

*n*: Index that identifies the network. Range: 1..1

*MTU*: Integer (576..1500)

Set a value for the MTU (bytes).

### xConfiguration Network [1] QoS Mode

The QoS (Quality of Service) is a method which handles the priority of audio, video and data in the network. The QoS settings must be supported by the infrastructure. Diffserv (Differentiated Services) is a computer networking architecture that specifies a simple, scalable and coarse-grained mechanism for classifying, managing network traffic and providing QoS priorities on modern IP networks.

Requires user role: ADMIN

Default value: Diffserv

#### USAGE:

xConfiguration Network *n* QoS Mode: *Mode*

where

*n*: Index that identifies the network. Range: 1..1

*Mode*: Off/Diffserv

Off: No QoS method is used.

Diffserv: When you set the QoS Mode to Diffserv, the Network QoS Diffserv Audio, Network QoS Diffserv Video, Network QoS Diffserv Data, Network QoS Diffserv Signalling, Network QoS Diffserv ICMPv6 and Network QoS Diffserv NTP settings are used to prioritize packets.

### xConfiguration Network [1] QoS Diffserv Audio

This setting will only take effect if Network QoS Mode is set to Diffserv.

Define which priority Audio packets should have in the IP network.

The priority for the packets ranges from 0 to 63 - the higher the number, the higher the priority. The recommended class for Audio is CS4, which equals the decimal value 32. If in doubt, contact your network administrator.

The priority set here might be overridden when packets are leaving the network controlled by the local network administrator.

Requires user role: ADMIN

Default value: 0

#### USAGE:

xConfiguration Network *n* QoS Diffserv Audio: *Audio*

where

*n*: Index that identifies the network. Range: 1..1

*Audio*: Integer (0..63)

Set the priority of the audio packets in the IP network - the higher the number, the higher the priority. The default value is 0 (best effort).

### xConfiguration Network [1] QoS Diffserv Video

This setting will only take effect if Network QoS Mode is set to Diffserv.

Define which priority Video packets should have in the IP network. The packets on the presentation channel (shared content) are also in the Video packet category. The priority for the packets ranges from 0 to 63 - the higher the number, the higher the priority. The recommended class for Video is CS4, which equals the decimal value 32. If in doubt, contact your network administrator.

The priority set here might be overridden when packets are leaving the network controlled by the local network administrator.

Requires user role: ADMIN

Default value: 0

#### USAGE:

xConfiguration Network *n* QoS Diffserv Video: *Video*

where

*n*: Index that identifies the network. Range: 1..1

*Video*: Integer (0..63)

Set the priority of the video packets in the IP network - the higher the number, the higher the priority. The default value is 0 (best effort).

### xConfiguration Network [1] QoS Diffserv Data

This setting will only take effect if Network QoS Mode is set to Diffserv.

Define which priority Data packets should have in the IP network.

The priority for the packets ranges from 0 to 63 - the higher the number, the higher the priority. The recommended value for Data is 0, which means best effort. If in doubt, contact your network administrator.

The priority set here might be overridden when packets are leaving the network controlled by the local network administrator.

Requires user role: ADMIN

Default value: 0

#### USAGE:

xConfiguration Network *n* QoS Diffserv Data: *Data*

where

*n*: Index that identifies the network. Range: 1..1

*Data*: Integer (0..63)

Set the priority of the data packets in the IP network - the higher the number, the higher the priority. The default value is 0 (best effort).

### xConfiguration Network [1] QoS Diffserv Signalling

This setting will only take effect if Network QoS Mode is set to Diffserv.

Define which priority Signalling packets that are deemed critical (time-sensitive) for the real-time operation should have in the IP network.

The priority for the packets ranges from 0 to 63 - the higher the number, the higher the priority. The recommended class for Signalling is CS3, which equals the decimal value 24. If in doubt, contact your network administrator.

The priority set here might be overridden when packets are leaving the network controlled by the local network administrator.

Requires user role: ADMIN

Default value: 0

#### USAGE:

xConfiguration Network *n* QoS Diffserv Signalling: *Signalling*

where

*n*: Index that identifies the network. Range: 1..1

*Signalling*: Integer (0..63)

Set the priority of the signalling packets in the IP network - the higher the number, the higher the priority. The default value is 0 (best effort).

### xConfiguration Network [1] QoS Diffserv ICMPv6

This setting will only take effect if Network QoS Mode is set to Diffserv.

Define which priority ICMPv6 packets should have in the IP network.

The priority for the packets ranges from 0 to 63 - the higher the number, the higher the priority. The recommended value for ICMPv6 is 0, which means best effort. If in doubt, contact your network administrator.

The priority set here might be overridden when packets are leaving the network controlled by the local network administrator.

Requires user role: ADMIN

Default value: 0

#### USAGE:

xConfiguration Network n QoS Diffserv ICMPv6: ICMPv6

where

n: Index that identifies the network. Range: 1..1

ICMPv6: Integer (0..63)

Set the priority of the ICMPv6 packets in the IP network - the higher the number, the higher the priority. The default value is 0 (best effort).

### xConfiguration Network [1] QoS Diffserv NTP

This setting will only take effect if Network QoS Mode is set to Diffserv.

Define which priority NTP packets should have in the IP network.

The priority for the packets ranges from 0 to 63 - the higher the number, the higher the priority. The recommended value for NTP is 0, which means best effort. If in doubt, contact your network administrator.

The priority set here might be overridden when packets are leaving the network controlled by the local network administrator.

Requires user role: ADMIN

Default value: 0

#### USAGE:

xConfiguration Network n QoS Diffserv NTP: NTP

where

n: Index that identifies the network. Range: 1..1

NTP: Integer (0..63)

Set the priority of the NTP packets in the IP network - the higher the number, the higher the priority. The default value is 0 (best effort).

### xConfiguration Network [1] RemoteAccess Allow

Define which IP addresses (IPv4/IPv6) are allowed for remote access to the codec from SSH/Telnet/HTTP/HTTPS. Multiple IP addresses are separated by a white space.

A network mask (IP range) is specified by <ip address>/N, where N is 1-32 for IPv4, and N is 1-128 for IPv6. The /N is a common indication of a network mask where the first N bits are set. Thus 192.168.0.0/24 would match any address starting with 192.168.0, since these are the first 24 bits in the address.

Requires user role: ADMIN

Default value: ""

#### USAGE:

xConfiguration Network n RemoteAccess Allow: "Allow"

where

n: Index that identifies the network. Range: 1..1

Allow: String (0, 255)

A valid IPv4 address or IPv6 address.

### xConfiguration Network [1] VLAN Voice Mode

Define the VLAN voice mode. The VLAN Voice Mode will be set to Auto automatically if you have Cisco UCM (Cisco Unified Communications Manager) as provisioning infrastructure. Note that Auto mode will NOT work if the NetworkServices CDP Mode setting is Off.

Requires user role: ADMIN

Default value: Auto

#### USAGE:

xConfiguration Network *n* VLAN Voice Mode: Mode

where

n: Index that identifies the network. Range: 1..1

Mode: Auto/Manual/Off

Auto: The Cisco Discovery Protocol (CDP), if available, assigns an id to the voice VLAN. If CDP is not available, VLAN is not enabled.

Manual: The VLAN ID is set manually using the Network VLAN Voice VlanId setting. If CDP is available, the manually set value will be overruled by the value assigned by CDP.

Off: VLAN is not enabled.

### xConfiguration Network [1] VLAN Voice VlanId

Define the VLAN voice ID. This setting will only take effect if Network VLAN Voice Mode is set to Manual.

Requires user role: ADMIN

Default value: 1

#### USAGE:

xConfiguration Network *n* VLAN Voice VlanId: VlanId

where

n: Index that identifies the network. Range: 1..1

VlanId: Integer (1..4094)

Set the VLAN voice ID.

## NetworkServices configuration

### xConfiguration NetworkServices CDP Mode

Enable or disable the CDP (Cisco Discovery Protocol) daemon. Enabling CDP will make the endpoint report certain statistics and device identifiers to a CDP-enabled switch. If CDP is disabled, the Network VLAN Voice Mode: Auto setting will not work.

Requires user role: ADMIN

Default value: On

#### USAGE:

xConfiguration NetworkServices CDP Mode: Mode

where

Mode: Off/On

Off: The CDP daemon is disabled.

On: The CDP daemon is enabled.

### xConfiguration NetworkServices H323 Mode

Define whether the system should be able to place and receive H.323 calls or not.

Requires user role: ADMIN

Default value: Off

#### USAGE:

xConfiguration NetworkServices H323 Mode: Mode

where

Mode: Off/On

Off: Disable the possibility to place and receive H.323 calls.

On: Enable the possibility to place and receive H.323 calls (default).

### xConfiguration NetworkServices HTTP Mode

Define whether or not to allow access to the video system using the HTTP or HTTPS (HTTP Secure) protocols. Note that the video system's web interface use HTTP or HTTPS. If this setting is switched Off, you cannot use the web interface.

If you need extra security (encryption and decryption of requests, and pages that are returned by the web server), allow only HTTPS.

Requires user role: ADMIN

Default value: HTTP+HTTPS

#### USAGE:

xConfiguration NetworkServices HTTP Mode: Mode

where

Mode: Off/HTTP+HTTPS/HTTPS

Off: Access to the video system not allowed via HTTP or HTTPS.

HTTP+HTTPS: Access to the video system allowed via both HTTP and HTTPS.

HTTPS: Access to the video system allowed via HTTPS, but not via HTTP.

### xConfiguration NetworkServices HTTPS VerifyServerCertificate

When the video system connects to an external HTTPS server (like a phone book server or an external manager), this server will present a certificate to the video system to identify itself.

Requires user role: ADMIN

Default value: Off

#### USAGE:

xConfiguration NetworkServices HTTPS VerifyServerCertificate:  
VerifyServerCertificate

where

VerifyServerCertificate: Off/On

Off: Do not verify server certificates.

On: Requires the system to verify that the server certificate is signed by a trusted Certificate Authority (CA). This requires that a list of trusted CAs are uploaded to the system in advance.

### xConfiguration NetworkServices HTTPS VerifyClientCertificate

When the video system connects to a HTTPS client (like a web browser), the client can be asked to present a certificate to the video system to identify itself.

Requires user role: ADMIN

Default value: Off

#### USAGE:

xConfiguration NetworkServices HTTPS VerifyClientCertificate:  
VerifyClientCertificate

where

VerifyClientCertificate: Off/On

Off: Do not verify client certificates.

On: Requires the client to present a certificate that is signed by a trusted Certificate Authority (CA). This requires that a list of trusted CAs are uploaded to the system in advance.

### xConfiguration NetworkServices NTP Mode

The Network Time Protocol (NTP) is used to synchronize the system's time and date to a reference time server. The time server will be queried regularly for time updates.

Requires user role: ADMIN

Default value: Auto

#### USAGE:

xConfiguration NetworkServices NTP Mode: Mode

where

Mode: Auto/Manual/Off

Auto: The system will use an NTP server for time reference. As default, the server address will be obtained from the network's DHCP server. If a DHCP server is not used, or if the DHCP server does not provide an NTP server address, the NTP server address that is specified in the NetworkServices NTP Server [n] Address setting will be used.

Manual: The system will use the NTP server that is specified in the NetworkServices NTP Server [n] Address setting for time reference.

Off: The system will not use an NTP server. The NetworkServices NTP Server [n] Address setting will be ignored.

### xConfiguration NetworkServices NTP Server [1..3] Address

The address of the NTP server that will be used when NetworkServices NTP Mode is set to Manual, and when NetworkServices NTP Mode is set to Auto and no address is supplied by a DHCP server.

Requires user role: ADMIN

Default value: 0.tandberg.pool.ntp.org

#### USAGE:

xConfiguration NetworkServices NTP Server n Address: "Address"

where

n: Unique ID that identifies the NTP server. Range: 1..3

Address: String (0, 255)

A valid IPv4 address, IPv6 address or DNS name.

### xConfiguration NetworkServices SIP Mode

Define whether the system should be able to place and receive SIP calls or not.

Requires user role: ADMIN

Default value: On

#### USAGE:

xConfiguration NetworkServices SIP Mode: Mode

where

Mode: Off/On

Off: Disable the possibility to place and receive SIP calls.

On: Enable the possibility to place and receive SIP calls (default).

### xConfiguration NetworkServices SNMP Mode

SNMP (Simple Network Management Protocol) is used in network management systems to monitor network-attached devices (routers, servers, switches, projectors, etc) for conditions that warrant administrative attention. SNMP exposes management data in the form of variables on the managed systems, which describe the system configuration. These variables can then be queried (set to ReadOnly) and sometimes set (set to ReadWrite) by managing applications.

Requires user role: ADMIN

Default value: ReadOnly

#### USAGE:

xConfiguration NetworkServices SNMP Mode: Mode

where

Mode: Off/ReadOnly/ReadWrite

Off: Disable the SNMP network service.

ReadOnly: Enable the SNMP network service for queries only.

ReadWrite: Enable the SNMP network service for both queries and commands.

### xConfiguration NetworkServices SNMP Host [1..3] Address

Define the address of up to three SNMP Managers.

The system's SNMP Agent (in the codec) responds to requests from SNMP Managers (a PC program etc.), for example about system location and system contact. SNMP traps are not supported.

Requires user role: ADMIN

Default value: ""

#### USAGE:

xConfiguration NetworkServices SNMP Host n Address: "Address"

where

n: Identifies the SNMP host. Maximum three SNMP hosts are allowed. Range: 1..3

Address: String (0, 255)

A valid IPv4 address, IPv6 address or DNS name.

### xConfiguration NetworkServices SNMP CommunityName

Define the name of the Network Services SNMP Community. SNMP Community names are used to authenticate SNMP requests. SNMP requests must have a password (case sensitive) in order to receive a response from the SNMP Agent in the codec. The default password is "public". If you have the Cisco TelePresence Management Suite (TMS) you must make sure the same SNMP Community is configured there too. NOTE: The SNMP Community password is case sensitive.

Requires user role: ADMIN

Default value: ""

**USAGE:**

xConfiguration NetworkServices SNMP CommunityName: "CommunityName"

where

CommunityName: String (0, 50)

The SNMP community name.

### xConfiguration NetworkServices SNMP SystemContact

Define the name of the Network Services SNMP System Contact.

Requires user role: ADMIN

Default value: ""

**USAGE:**

xConfiguration NetworkServices SNMP SystemContact: "SystemContact"

where

SystemContact: String (0, 50)

The name of the SNMP system contact.

### xConfiguration NetworkServices SNMP SystemLocation

Define the name of the Network Services SNMP System Location.

Requires user role: ADMIN

Default value: ""

**USAGE:**

xConfiguration NetworkServices SNMP SystemLocation: "SystemLocation"

where

SystemLocation: String (0, 50)

The name of the SNMP system location.

### xConfiguration NetworkServices SSH Mode

SSH (or Secure Shell) protocol can provide secure encrypted communication between the codec and your local computer.

Requires user role: ADMIN

Default value: On

**USAGE:**

xConfiguration NetworkServices SSH Mode: Mode

where

Mode: Off/On

Off: The SSH protocol is disabled.

On: The SSH protocol is enabled.



### xConfiguration NetworkServices Telnet Mode

Telnet is a network protocol used on the Internet or Local Area Network (LAN) connections.

Requires user role: ADMIN

Default value: Off

#### USAGE:

xConfiguration NetworkServices Telnet Mode: Mode

where

Mode: Off/On

Off: The Telnet protocol is disabled. This is the factory setting.

On: The Telnet protocol is enabled.

### xConfiguration NetworkServices WelcomeText

Choose which information the user should see when logging on to the codec through Telnet/SSH.

Requires user role: ADMIN

Default value: On

#### USAGE:

xConfiguration NetworkServices WelcomeText: WelcomeText

where

WelcomeText: Off/On

Off: The welcome text is: Login successful

On: The welcome text is: Welcome to <system name>; Software version; Software release date; Login successful.

## Phonebook configuration

### xConfiguration Phonebook Server [1] ID

Define a name for the external phone book.

Requires user role: ADMIN

Default value: ""

#### USAGE:

xConfiguration Phonebook Server n ID: "ID"

where

n: Unique ID that identifies the phonebook server. Range: 1..1

ID: String (0, 64)

The name for the external phone book.

### xConfiguration Phonebook Server [1] Type

Select the phonebook server type.

Requires user role: ADMIN

Default value: Off

#### USAGE:

xConfiguration Phonebook Server n Type: Type

where

n: Unique ID that identifies the phonebook server. Range: 1..1

Type: Off/CUCM/Spark/TMS/VCS

Off: Do not use a phonebook.

CUCM: The phonebook is located on the Cisco Unified Communications Manager.

Spark: The phonebook is located on Spark.

TMS: The phonebook is located on the Cisco TelePresence Management Suite server.

VCS: The phonebook is located on the Cisco TelePresence Video Communication Server.

### xConfiguration Phonebook Server [1] URL

Define the address (URL) to the external phone book server.

Requires user role: ADMIN

Default value: ""

#### USAGE:

xConfiguration Phonebook Server *n* URL: "*URL*"

where

*n*: Unique ID that identifies the phonebook server. Range: 1..1

*URL*: String (0, 255)

A valid address (URL) to the phone book server.

## Provisioning configuration

### xConfiguration Provisioning Connectivity

This setting controls how the device discovers whether it should request an internal or external configuration from the provisioning server.

Requires user role: ADMIN, USER

Default value: Auto

#### USAGE:

xConfiguration Provisioning Connectivity: *Connectivity*

where

*Connectivity*: Internal/External/Auto

Internal: Request internal configuration.

External: Request external configuration.

Auto: Automatically discover using NAPTR queries whether internal or external configurations should be requested. If the NAPTR responses have the "e" flag, external configurations will be requested. Otherwise internal configurations will be requested.

### xConfiguration Provisioning Mode

It is possible to configure a video system using a provisioning system (external manager). This allows video conferencing network administrators to manage many video systems simultaneously. With this setting you choose which type of provisioning system to use. Provisioning can also be switched off. Contact your provisioning system provider/representative for more information.

Requires user role: ADMIN, USER

Default value: Auto

#### USAGE:

xConfiguration Provisioning Mode: Mode

where

Mode: Off/Auto/CUCM/Edge/Spark/TMS/VCS

Off: The video system is not configured by a provisioning system.

Auto: Automatically select the provisioning server.

CUCM: Push configurations to the video system from CUCM (Cisco Unified Communications Manager).

Edge: Push configurations to the video system from CUCM (Cisco Unified Communications Manager). The system connects to CUCM via the Collaboration Edge infrastructure.

Spark: Push configurations to the video system from Spark.

TMS: Push configurations to the video system from TMS (Cisco TelePresence Management System).

VCS: Push configurations to the video system from VCS (Cisco TelePresence Video Communication Server).

### xConfiguration Provisioning LoginName

This is the username part of the credentials used to authenticate the video system with the provisioning server. This setting must be used when required by the provisioning server.

Requires user role: ADMIN, USER

Default value: ""

#### USAGE:

xConfiguration Provisioning LoginName: "LoginName"

where

LoginName: String (0, 80)

A valid username.

### xConfiguration Provisioning Password

This is the password part of the credentials used to authenticate the video system with the provisioning server. This setting must be used when required by the provisioning server.

Requires user role: ADMIN, USER

Default value: ""

#### USAGE:

xConfiguration Provisioning Password: "Password"

where

Password: String (0, 64)

A valid password.

### xConfiguration Provisioning HttpMethod

Select the HTTP method to be used for the provisioning.

Requires user role: ADMIN, USER

Default value: POST

#### USAGE:

xConfiguration Provisioning HttpMethod: HttpMethod

where

HttpMethod: GET/POST

GET: Select GET when the provisioning server supports GET.

POST: Select POST when the provisioning server supports POST.

### xConfiguration Provisioning ExternalManager Address

Define the IP Address or DNS name of the external manager / provisioning system.

If an External Manager Address (and Path) is configured, the system will send a message to this address when starting up. When receiving this message the external manager / provisioning system can return configurations/commands to the unit as a result.

When using CUCM or TMS provisioning, the DHCP server can be set up to provide the external manager address automatically (DHCP Option 242 for TMS, and DHCP Option 150 for CUCM).

An address set in the Provisioning ExternalManager Address setting will override the address provided by DHCP.

Requires user role: ADMIN, USER

Default value: ""

#### USAGE:

xConfiguration Provisioning ExternalManager Address: "Address"

where

Address: String (0, 64)

A valid IPv4 address, IPv6 address or DNS name.

### xConfiguration Provisioning ExternalManager AlternateAddress

Only applicable when the endpoint is provisioned by Cisco Unified Communication Manager (CUCM) and an alternate CUCM is available for redundancy. Define the address of the alternate CUCM. If the main CUCM is not available, the endpoint will be provisioned by the alternate CUCM. When the main CUCM is available again, the endpoint will be provisioned by this CUCM.

Requires user role: ADMIN, USER

Default value: ""

#### USAGE:

xConfiguration Provisioning ExternalManager AlternateAddress: "AlternateAddress"

where

AlternateAddress: String (0, 64)

A valid IPv4 address, IPv6 address or DNS name.

### xConfiguration Provisioning ExternalManager Protocol

Define whether to use the HTTP (unsecure communication) or HTTPS (secure communication) protocol when sending requests to the external manager / provisioning system.

The chosen protocol must be enabled in the NetworkServices HTTP Mode setting.

Requires user role: ADMIN, USER

Default value: HTTP

#### USAGE:

xConfiguration Provisioning ExternalManager Protocol: Protocol

where

Protocol: HTTPS/HTTP

HTTPS: Send requests via HTTPS.

HTTP: Send requests via HTTP.

### xConfiguration Provisioning ExternalManager Path

Define the Path to the external manager / provisioning system. This setting is required when several management services reside on the same server, i.e. share the same External Manager address.

Requires user role: ADMIN, USER

Default value: ""

**USAGE:**

xConfiguration Provisioning ExternalManager Path: "Path"

where

Path: String (0, 255)

A valid path to the external manager or provisioning system.

### xConfiguration Provisioning ExternalManager Domain

Define the SIP domain for the VCS provisioning server.

Requires user role: ADMIN, USER

Default value: ""

**USAGE:**

xConfiguration Provisioning ExternalManager Domain: "Domain"

where

Domain: String (0, 64)

A valid domain name.

### SerialPort configuration

#### xConfiguration SerialPort Mode

Enable/disable the serial port (connection via Micro USB to USB cable). The serial port uses 115200 bps, 8 data bits, no parity and 1 stop bit.

Requires user role: ADMIN

Default value: On

**USAGE:**

xConfiguration SerialPort Mode: Mode

where

Mode: Off/On

Off: Disable the serial port.

On: Enable the serial port.

#### xConfiguration SerialPort LoginRequired

Define if login shall be required when connecting to the serial port.

Requires user role: ADMIN

Default value: On

**USAGE:**

xConfiguration SerialPort LoginRequired: LoginRequired

where

LoginRequired: Off/On

Off: The user can access the codec via the serial port without any login.

On: Login is required when connecting to the codec via the serial port.

## SIP configuration

### xConfiguration SIP Authentication UserName

This is the user name part of the credentials used to authenticate towards the SIP proxy.

Requires user role: ADMIN

Default value: ""

#### USAGE:

xConfiguration SIP Authentication UserName: "UserName"

where

UserName: String (0, 128)

A valid username.

### xConfiguration SIP Authentication Password

This is the password part of the credentials used to authenticate towards the SIP proxy.

Requires user role: ADMIN

Default value: ""

#### USAGE:

xConfiguration SIP Authentication Password: "Password"

where

Password: String (0, 128)

A valid password.

### xConfiguration SIP DefaultTransport

Select the transport protocol to be used over the LAN.

Requires user role: ADMIN

Default value: Auto

#### USAGE:

xConfiguration SIP DefaultTransport: DefaultTransport

where

DefaultTransport: TCP/UDP/Tls/Auto

TCP: The system will always use TCP as the default transport method.

UDP: The system will always use UDP as the default transport method.

Tls: The system will always use TLS as the default transport method. For TLS connections a SIP CA-list can be uploaded to the video system. If no such CA-list is available on the system then anonymous Diffie Hellman will be used.

Auto: The system will try to connect using transport protocols in the following order: TLS, TCP, UDP.

### xConfiguration SIP DisplayName

When configured the incoming call will report the display name instead of the SIP URI.

Requires user role: ADMIN

Default value: ""

#### USAGE:

xConfiguration SIP DisplayName: "DisplayName"

where

DisplayName: String (0, 550)

The name to be displayed instead of the SIP URI.

### xConfiguration SIP Ice Mode

ICE (Interactive Connectivity Establishment, RFC 5245) is a NAT traversal solution that the video systems can use to discover the optimized media path. Thus the shortest route for audio and video is always secured between the video systems.

Requires user role: ADMIN

Default value: Auto

#### USAGE:

xConfiguration SIP Ice Mode: Mode

where

Mode: Auto/Off/On

Auto: ICE is enabled if a TURN server is provided, otherwise ICE is disabled.

Off: ICE is disabled.

On: ICE is enabled.

### xConfiguration SIP Ice DefaultCandidate

The ICE protocol needs some time to reach a conclusion about which media route to use (up to the first 5 seconds of a call). During this period media for the video system will be sent to the Default Candidate as defined in this setting.

Requires user role: ADMIN

Default value: Host

#### USAGE:

xConfiguration SIP Ice DefaultCandidate: DefaultCandidate

where

DefaultCandidate: Host/Rflx/Relay

Host: Send media to the video system's private IP address.

Rflx: Send media to the video system's public IP address, as seen by the TURN server.

Relay: Send media to the IP address and port allocated on the TURN server.

### xConfiguration SIP Ice OfferTcpCandidates

Define whether or not the video system supports sending and receiving media over TCP connections.

Requires user role: ADMIN

Default value: Off

#### USAGE:

xConfiguration SIP Ice OfferTcpCandidates: OfferTcpCandidates

where

OfferTcpCandidates: Off/On

Off: The video system does not allow media over TCP connections.

On: The video system allows media over TCP connections.

### xConfiguration SIP ListenPort

Turn on or off the listening for incoming connections on the SIP TCP/UDP ports. If turned off, the endpoint will only be reachable through the SIP registrar (CUCM or VCS). It is recommended to leave this setting at its default value.

Requires user role: ADMIN

Default value: On

#### USAGE:

xConfiguration SIP ListenPort: ListenPort

where

ListenPort: Off/On

Off: Listening for incoming connections on the SIP TCP/UDP ports is turned off.

On: Listening for incoming connections on the SIP TCP/UDP ports is turned on.

### xConfiguration SIP Proxy [1..4] Address

The Proxy Address is the manually configured address for the outbound proxy. It is possible to use a fully qualified domain name, or an IP address. The default port is 5060 for TCP and UDP but another one can be provided.

Requires user role: ADMIN

Default value: ""

#### USAGE:

xConfiguration SIP Proxy n Address: "Address"

where

n: Index that identifies the proxy (maximum 4 proxys can be defined). Range: 1..4

Address: String (0, 255)

A valid IPv4 address, IPv6 address or DNS name.

### xConfiguration SIP Turn Server

Define the address of the TURN (Traversal Using Relay NAT) server. It is used as a media relay fallback and it is also used to discover the endpoint's own public IP address.

Requires user role: ADMIN

Default value: ""

#### USAGE:

xConfiguration SIP Turn Server: "Server"

where

Server: String (0, 255)

The preferred format is DNS SRV record (e.g. \_turn.\_udp.<domain>), or it can be a valid IPv4 or IPv6 address.

### xConfiguration SIP Turn UserName

Define the user name needed for accessing the TURN server.

Requires user role: ADMIN

Default value: ""

#### USAGE:

xConfiguration SIP Turn UserName: "UserName"

where

UserName: String (0, 128)

A valid user name.

### xConfiguration SIP Turn Password

Define the password needed for accessing the TURN server.

Requires user role: ADMIN

Default value: ""

#### USAGE:

xConfiguration SIP Turn Password: "Password"

where

Password: String (0, 128)

A valid password.

### xConfiguration SIP URI

The SIP URI (Uniform Resource Identifier) is the address that is used to identify the video system. The URI is registered and used by the SIP services to route inbound calls to the system. The SIP URI syntax is defined in RFC 3261.

Requires user role: ADMIN

Default value: ""

#### USAGE:

xConfiguration SIP URI: "URI"

where

URI: String (0, 255)

An address (URI) that is compliant with the SIP URI syntax.



## Standby configuration

### xConfiguration Standby Control

Define whether the system should go into standby mode or not.

Requires user role: ADMIN

Default value: On

#### USAGE:

xConfiguration Standby Control: Control

where

Control: Off/On

Off: The system will not enter standby mode.

On: The system will enter standby mode when the Standby Delay has timed out.

Requires the Standby Delay to be set to an appropriate value.

### xConfiguration Standby Delay

Define how long (in minutes) the system shall be in idle mode before it goes into standby mode.

Requires the Standby Control to be enabled.

Requires user role: ADMIN

Default value: 10

#### USAGE:

xConfiguration Standby Delay: Delay

where

Delay: Integer (1..480)

Set the standby delay (minutes).

## SystemUnit configuration

### xConfiguration SystemUnit Name

Define the system name. The system name will be sent as the hostname in a DHCP request and when the codec is acting as an SNMP Agent.

Requires user role: ADMIN

Default value: ""

#### USAGE:

xConfiguration SystemUnit Name: "Name"

where

Name: String (0, 50)

Define the system name.

## Time configuration

### xConfiguration Time TimeFormat

Define the time format.

Requires user role: ADMIN, USER

Default value: 24H

#### USAGE:

xConfiguration Time TimeFormat: TimeFormat

where

TimeFormat: 24H/12H

24H: Set the time format to 24 hours.

12H: Set the time format to 12 hours (AM/PM).

### xConfiguration Time DateFormat

Define the date format.

Requires user role: ADMIN, USER

Default value: DD\_MM\_YY

#### USAGE:

xConfiguration Time DateFormat: DateFormat

where

DateFormat: DD\_MM\_YY/MM\_DD\_YY/YY\_MM\_DD

DD\_MM\_YY: The date January 30th 2010 will be displayed: 30.01.10

MM\_DD\_YY: The date January 30th 2010 will be displayed: 01.30.10

YY\_MM\_DD: The date January 30th 2010 will be displayed: 10.01.30

### xConfiguration Time Zone

Define the time zone for the geographical location of the video system. The information in the value space is from the tz database, also called the IANA Time Zone Database.

Requires user role: ADMIN, USER

Default value: Etc/UTC

#### USAGE:

xConfiguration Time Zone: Zone

where

Zone: Africa/Abidjan, Africa/Accra, Africa/Addis\_Ababa, Africa/Algiers, Africa/Asmara, Africa/Asmera, Africa/Bamako, Africa/Bangui, Africa/Banjul, Africa/Bissau, Africa/Blantyre, Africa/Brazzaville, Africa/Bujumbura, Africa/Cairo, Africa/Casablanca, Africa/Ceuta, Africa/Conakry, Africa/Dakar, Africa/Dar\_es\_Salaam, Africa/Djibouti, Africa/Douala, Africa/El\_Aaiun, Africa/Freetown, Africa/Gaborone, Africa/Harare, Africa/Johannesburg, Africa/Juba, Africa/Kampala, Africa/Khartoum, Africa/Kigali, Africa/Kinshasa, Africa/Lagos, Africa/Libreville, Africa/Lome, Africa/Luanda, Africa/Lubumbashi, Africa/Lusaka, Africa/Malabo, Africa/Maputo, Africa/Maseru, Africa/Mbabane, Africa/Mogadishu, Africa/Monrovia, Africa/Nairobi, Africa/Ndjamena, Africa/Niamey, Africa/Nouakchott, Africa/Ouagadougou, Africa/Porto-Novo, Africa/Sao\_Tome, Africa/Timbuktu, Africa/Tripoli, Africa/Tunis, Africa/Windhoek, America/Adak, America/Anchorage, America/Anguilla, America/Antigua, America/Araguaina, America/Argentina/Buenos\_Aires, America/Argentina/Catamarca, America/Argentina/ComodRivadavia, America/Argentina/Cordoba, America/Argentina/Jujuy, America/Argentina/La\_Rioja, America/Argentina/Mendoza, America/Argentina/Rio\_Gallegos, America/Argentina/Salta, America/Argentina/San\_Juan, America/Argentina/San\_Luis, America/Argentina/Tucuman, America/Argentina/Ushuaia, America/Aruba, America/Asuncion, America/Atikokan, America/Atka, America/Bahia, America/Bahia\_Banderas, America/Barbados, America/Belem, America/Belize, America/Blanc-Sablon, America/Boa\_Vista, America/Bogota, America/Boise, America/Buenos\_Aires, America/Cambridge\_Bay, America/Campo\_Grande, America/Cancun, America/Caracas, America/Catamarca, America/Cayenne, America/Cayman, America/Chicago, America/Chihuahua, America/Coral\_Harbour, America/Cordoba, America/Costa\_Rica, America/Creston, America/Cuiaba, America/Curacao, America/Danmarkshavn, America/Dawson, America/Dawson\_Creek, America/Denver, America/Detroit, America/Dominica, America/Edmonton, America/Eirunepe, America/El\_Salvador, America/Ensenada, America/Fort\_Nelson, America/Fort\_Wayne, America/Fortaleza, America/Glace\_Bay, America/Godthab, America/Goose\_Bay, America/Grand\_Turk, America/Grenada, America/Guadeloupe, America/Guatemala, America/Guayaquil, America/Guyana, America/Halifax, America/Havana, America/Hermosillo, America/Indiana/Indianapolis, America/Indiana/Knox, America/Indiana/Marengo, America/Indiana/Petersburg, America/Indiana/Tell\_City, America/Indiana/Vevay, America/Indiana/Vincennes, America/Indiana/Winamac, America/Indianapolis, America/Inuvik, America/Iqaluit, America/Jamaica, America/Jujuy, America/Juneau, America/Kentucky/Louisville, America/Kentucky/Monticello, America/Knox\_IN, America/Kralendijk, America/La\_Paz, America/Lima,

America/Los\_Angeles, America/Louisville, America/Lower\_Princes, America/Maceio, America/Managua, America/Manaus, America/Marigot, America/Martinique, America/Matamoros, America/Mazatlan, America/Mendoza, America/Menominee, America/Merida, America/Metlakatla, America/Mexico\_City, America/Miquelon, America/Moncton, America/Monterrey, America/Montevidео, America/Montreal, America/Montserrat, America/Nassau, America/New\_York, America/Nipigon, America/Nome, America/Noronha, America/North\_Dakota/Beulah, America/North\_Dakota/Center, America/North\_Dakota/New\_Salem, America/Ojinaga, America/Panama, America/Pangnirtung, America/Paramaribo, America/Phoenix, America/Port-au-Prince, America/Port\_of\_Spain, America/Porto\_Acre, America/Porto\_Velho, America/Puerto\_Rico, America/Rainy\_River, America/Rankin\_Inlet, America/Recife, America/Regina, America/Resolute, America/Rio\_Branco, America/Rosario, America/Santa\_Isabel, America/Santarem, America/Santiago, America/Santo\_Domingo, America/Sao\_Paulo, America/Scoresbysund, America/Shiprock, America/Sitka, America/St\_Barthelemy, America/St\_Johns, America/St\_Kitts, America/St\_Lucia, America/St\_Thomas, America/St\_Vincent, America/Swift\_Current, America/Tegucigalpa, America/Thule, America/Thunder\_Bay, America/Tijuana, America/Toronto, America/Tortola, America/Vancouver, America/Virgin, America/Whitehorse, America/Winnipeg, America/Yakutat, America/Yellowknife, Antarctica/Casey, Antarctica/Davis, Antarctica/DumontD'Urville, Antarctica/Macquarie, Antarctica/Mawson, Antarctica/McMurdo, Antarctica/Palmer, Antarctica/Rothera, Antarctica/South\_Pole, Antarctica/Syowa, Antarctica/Troll, Antarctica/Vostok, Arctic/Longyearbyen, Asia/Aden, Asia/Almaty, Asia/Amman, Asia/Anadyr, Asia/Aqtau, Asia/Aqtobe, Asia/Ashgabat, Asia/Ashkhabad, Asia/Baghdad, Asia/Bahrain, Asia/Baku, Asia/Bangkok, Asia/Barnaul, Asia/Beirut, Asia/Bishkek, Asia/Brunei, Asia/Calcutta, Asia/Chita, Asia/Chobalsan, Asia/Chongqing, Asia/Chungking, Asia/Colombo, Asia/Dacca, Asia/Damascus, Asia/Dhaka, Asia/Dili, Asia/Dubai, Asia/Dushanbe, Asia/Gaza, Asia/Harbin, Asia/Hebron, Asia/Ho\_Chi\_Minh, Asia/Hong\_Kong, Asia/Hovd, Asia/Irkutsk, Asia/Istanbul, Asia/Jakarta, Asia/Jayapura, Asia/Jerusalem, Asia/Kabul, Asia/Kamchatka, Asia/Karachi, Asia/Kashgar, Asia/Kathmandu, Asia/Katmandu, Asia/Khandyga, Asia/Kolkata, Asia/Krasnoyarsk, Asia/Kuala\_Lumpur, Asia/Kuching, Asia/Kuwait, Asia/Macao, Asia/Macau, Asia/Magadan, Asia/Makassar, Asia/Manila, Asia/Muscat, Asia/Nicosia, Asia/Novokuznetsk, Asia/Novosibirsk, Asia/Omsk, Asia/Oral, Asia/Phnom\_Penh, Asia/Pontianak, Asia/Pyongyang, Asia/Qatar, Asia/Qyzylorda, Asia/Rangoon, Asia/Riyadh, Asia/Saigon, Asia/Sakhalin, Asia/Samarkand, Asia/Seoul, Asia/Shanghai, Asia/Singapore, Asia/Srednekolymsk, Asia/Taipei, Asia/Tashkent, Asia/Tbilisi, Asia/Tehran, Asia/Tel\_Aviv, Asia/Thimbu, Asia/Thimphu, Asia/Tokyo, Asia/Tomsk, Asia/Ujung\_Pandang, Asia/Ulaanbaatar, Asia/Ulan\_Bator, Asia/Urumqi, Asia/Ust-Nera, Asia/Vientiane, Asia/Vladivostok, Asia/Yakutsk, Asia/Yekaterinburg, Asia/Yerevan, Atlantic/Azores, Atlantic/Bermuda, Atlantic/Canary, Atlantic/Cape\_Verde, Atlantic/Faeroe, Atlantic/Faroe, Atlantic/Jan\_Mayen, Atlantic/Madeira, Atlantic/Reykjavik, Atlantic/South\_Georgia, Atlantic/St\_Helena, Atlantic/Stanley, Australia/ACT, Australia/Adelaide, Australia/Brisbane, Australia/Broken\_Hill, Australia/Canberra, Australia/Currie, Australia/Darwin, Australia/Eucla, Australia/Hobart, Australia/LHI, Australia/Lindeman, Australia/Lord\_Howe, Australia/Melbourne, Australia/NSW, Australia/North, Australia/Perth, Australia/Queensland, Australia/South, Australia/Sydney, Australia/Tasmania, Australia/Victoria, Australia/West, Australia/Yancowinna, Brazil/Acre, Brazil/DeNoronha, Brazil/East, Brazil/West, CET, CST6CDT, Canada/

Atlantic, Canada/Central, Canada/East-Saskatchewan, Canada/Eastern, Canada/Mountain, Canada/Newfoundland, Canada/Pacific, Canada/Saskatchewan, Canada/Yukon, Chile/Continental, Chile/EasterIsland, Cuba, EET, EST, EST5EDT, Egypt, Eire, Etc/GMT, Etc/GMT+0, Etc/GMT+1, Etc/GMT+10, Etc/GMT+11, Etc/GMT+12, Etc/GMT+2, Etc/GMT+3, Etc/GMT+4, Etc/GMT+5, Etc/GMT+6, Etc/GMT+7, Etc/GMT+8, Etc/GMT+9, Etc/GMT-0, Etc/GMT-1, Etc/GMT-10, Etc/GMT-11, Etc/GMT-12, Etc/GMT-13, Etc/GMT-14, Etc/GMT-2, Etc/GMT-3, Etc/GMT-4, Etc/GMT-5, Etc/GMT-6, Etc/GMT-7, Etc/GMT-8, Etc/GMT-9, Etc/GMT0, Etc/Greenwich, Etc/UCT, Etc/UTC, Etc/Universal, Etc/Zulu, Europe/Amsterdam, Europe/Andorra, Europe/Astrakhan, Europe/Athens, Europe/Belfast, Europe/Belgrade, Europe/Berlin, Europe/Bratislava, Europe/Brussels, Europe/Bucharest, Europe/Budapest, Europe/Busingen, Europe/Chisinau, Europe/Copenhagen, Europe/Dublin, Europe/Gibraltar, Europe/Guernsey, Europe/Helsinki, Europe/Isle\_of\_Man, Europe/Istanbul, Europe/Jersey, Europe/Kaliningrad, Europe/Kiev, Europe/Kirov, Europe/Lisbon, Europe/Ljubljana, Europe/London, Europe/Luxembourg, Europe/Madrid, Europe/Malta, Europe/Mariehamn, Europe/Minsk, Europe/Monaco, Europe/Moscow, Europe/Nicosia, Europe/Oslo, Europe/Paris, Europe/Podgorica, Europe/Prague, Europe/Riga, Europe/Rome, Europe/Samara, Europe/San\_Marino, Europe/Sarajevo, Europe/Simferopol, Europe/Skopje, Europe/Sofia, Europe/Stockholm, Europe/Tallinn, Europe/Tirane, Europe/Tiraspol, Europe/Ulyanovsk, Europe/Uzhgorod, Europe/Vaduz, Europe/Vatican, Europe/Vienna, Europe/Vilnius, Europe/Volgograd, Europe/Warsaw, Europe/Zagreb, Europe/Zaporozhye, Europe/Zurich, GB, GB-Eire, GMT, GMT+0, GMT-0, GMT0, Greenwich, HST, Hongkong, Iceland, Indian/Antananarivo, Indian/Chagos, Indian/Christmas, Indian/Cocos, Indian/Comoro, Indian/Kerguelen, Indian/Mahe, Indian/Maldives, Indian/Mauritius, Indian/Mayotte, Indian/Reunion, Iran, Israel, Jamaica, Japan, Kwajalein, Libya, MET, MST, MST7MDT, Mexico/BajaNorte, Mexico/BajaSur, Mexico/General, NZ, NZ-CHAT, Navajo, PRC, PST8PDT, Pacific/Apia, Pacific/Auckland, Pacific/Bougainville, Pacific/Chatham, Pacific/Chuuk, Pacific/Easter, Pacific/Efate, Pacific/Enderbury, Pacific/Fakaofu, Pacific/Fiji, Pacific/Funafuti, Pacific/Galapagos, Pacific/Gambier, Pacific/Guadalcanal, Pacific/Guam, Pacific/Honolulu, Pacific/Johnston, Pacific/Kiritimati, Pacific/Kosrae, Pacific/Kwajalein, Pacific/Majuro, Pacific/Marquesas, Pacific/Midway, Pacific/Nauru, Pacific/Niue, Pacific/Norfolk, Pacific/Noumea, Pacific/Pago\_Pago, Pacific/Palau, Pacific/Pitcairn, Pacific/Pohnpei, Pacific/Ponape, Pacific/Port\_Moresby, Pacific/Rarotonga, Pacific/Saipan, Pacific/Samoa, Pacific/Tahiti, Pacific/Tarawa, Pacific/Tongatapu, Pacific/Truk, Pacific/Wake, Pacific/Wallis, Pacific/Yap, Poland, Portugal, ROC, ROK, Singapore, Turkey, UCT, US/Alaska, US/Aleutian, US/Arizona, US/Central, US/East-Indiana, US/Eastern, US/Hawaii, US/Indiana-Starke, US/Michigan, US/Mountain, US/Pacific, US/Pacific-New, US/Samoa, UTC, Universal, W-SU, WET, Zulu

Select a time zone from the list.

## UserInterface configuration

### xConfiguration UserInterface ContactInfo Type

Choose which type of contact information to show in the status field in the upper left corner of the display and Touch controller.

Requires user role: ADMIN

Default value: Auto

#### USAGE:

xConfiguration UserInterface ContactInfo Type: Type

where

Type: Auto/None/IPv4/IPv6/SipUri/SystemName/DisplayName

Auto: Show the address which another system can dial to reach this system. The address depends on the system registration.

None: Do not show any contact information.

IPv4: Show the system's IPv4 address.

IPv6: Show the system's IPv6 address.

SipUri: Show the system's SIP URI (refer to the SIP URI setting).

SystemName: Show the system's name (refer to the SystemUnit Name setting).

DisplayName: Show the system's display name (refer to the SIP DisplayName setting).

### xConfiguration UserInterface KeyTones Mode

You can configure the system to make a keyboard click sound effect (key tone) when pressing a key on the remote control, or when typing text or numbers on the Touch controller.

Requires user role: ADMIN, USER

Default value: On

#### USAGE:

xConfiguration UserInterface KeyTones Mode: Mode

where

Mode: Off/On

Off: There is no key tone sound effect.

On: The key tone sound effect is turned on.

### xConfiguration UserInterface Language

Select the language to be used in menus and messages on the screen and Touch controller.

Requires user role: ADMIN, USER

Default value: English

#### USAGE:

xConfiguration UserInterface Language: Language

where

Language: English/ChineseSimplified/ChineseTraditional/Catalan/Czech/Danish/Dutch/Finnish/French/FrenchCanadian/German/Hungarian/Italian/Japanese/Korean/Norwegian/Polish/PortugueseBrazilian/Russian/Spanish/Swedish/Turkish/Arabic/Hebrew

Select a language from the list.

### xConfiguration UserInterface OSD Output

Define on which monitor the on-screen menus, information and indicators (OSD) should be displayed. The system supports only one monitor, so this value is fixed and cannot be changed.

Requires user role: ADMIN

Default value: 1

#### USAGE:

xConfiguration UserInterface OSD Output: Output

where

Output: Auto/1/2/3

Auto: The system sends the on-screen information and indicators to the system's integrated display.

Range 1-3: The system sends the information and indicators to the specified output. Choose 1 to send the on-screen information and indicators to the integrated display; choose 2 or 3 to send the OSD to a display that is connected to the system's HDMI output.

## UserManagement configuration

### xConfiguration UserManagement LDAP Mode

The video system supports the use of an LDAP (Lightweight Directory Access Protocol) server as a central place to store and validate user names and passwords. Use this setting to configure whether or not to use LDAP authentication. Our implementation is tested for the Microsoft Active Directory (AD) service.

Requires user role: ADMIN

Default value: Off

#### USAGE:

xConfiguration UserManagement LDAP Mode: Mode

where

Mode: Off/On

Off: LDAP authentication is not allowed.

On: Use LDAP authentication.

### xConfiguration UserManagement LDAP Server Address

Set the IP address or hostname of the LDAP server.

Requires user role: ADMIN

Default value: ""

#### USAGE:

xConfiguration UserManagement LDAP Server Address: "Address"

where

Address: String (0, 255)

A valid IPv4 address, IPv6 address or hostname.

### xConfiguration UserManagement LDAP Server Port

Set the port to connect to the LDAP server on. If set to 0, use the default for the selected protocol (see the UserManagement LDAP Encryption setting).

Requires user role: ADMIN

Default value: 0

#### USAGE:

xConfiguration UserManagement LDAP Server Port: Port

where

Port: Integer (0..65535)

The LDAP server port number.

### xConfiguration UserManagement LDAP Encryption

Define how to secure the communication between the video system and the LDAP server. You can override the port number by using the UserManagement LDAP Server Port setting.

Requires user role: ADMIN

Default value: LDAPS

#### USAGE:

xConfiguration UserManagement LDAP Encryption: Encryption

where

Encryption: LDAPS/None/STARTTLS

LDAPS: Connect to the LDAP server on port 636 over TLS (Transport Layer Security).

None: Connect to LDAP server on port 389 with no encryption.

STARTTLS: Connect to LDAP server on port 389, then send STARTTLS to enable TLS encryption.

### xConfiguration UserManagement LDAP MinimumTLSVersion

Set the lowest version of the TLS (Transport Layer Security) protocol that is allowed.

Requires user role: ADMIN

Default value: TLSv1.2

#### USAGE:

xConfiguration UserManagement LDAP MinimumTLSVersion: MinimumTLSVersion

where

MinimumTLSVersion: TLSv1.0/TLSv1.1/TLSv1.2

TLSv1.0: Support TLS version 1.0 or higher.

TLSv1.1: Support TLS version 1.1 or higher.

TLSv1.2: Support TLS version 1.2 or higher.

### xConfiguration UserManagement LDAP VerifyServerCertificate

When the video system connects to an LDAP server, the server will identify itself to the video system by presenting its certificate. Use this setting to determine whether or not the video system will verify the server certificate.

Requires user role: ADMIN

Default value: On

#### USAGE:

xConfiguration UserManagement LDAP VerifyServerCertificate: VerifyServerCertificate

where

VerifyServerCertificate: Off/On

Off: The video system will not verify the LDAP server's certificate.

On: The video system must verify that the LDAP server's certificate is signed by a trusted Certificate Authority (CA). The CA must be on the list of trusted CAs that are uploaded to the system in advance. Use the video system's web interface to manage the list of trusted CAs (see more details in the administrator guide).

### xConfiguration UserManagement LDAP Admin Filter

The LDAP filter is used to determine which users should be granted administrator privileges. If set, this setting takes precedence over the UserManagement LDAP Admin Group setting.

Requires user role: ADMIN

Default value: ""

#### USAGE:

xConfiguration UserManagement LDAP Admin Filter: "Filter"

where

Filter: String (0, 1024)

Refer to the LDAP specification for the syntax of this string. Example: "(CN=adminuser)"

### xConfiguration UserManagement LDAP Admin Group

Members of this AD (Active Directory) group will be given administrator access. This setting is a shorthand for saying (memberOf:1.2.840.113556.1.4.1941:=<group name>). If UserManagement LDAP Admin Filter is set, this setting is ignored.

Requires user role: ADMIN

Default value: ""

#### USAGE:

xConfiguration UserManagement LDAP Admin Group: "Group"

where

Group: String (0, 255)

The distinguishing name of the AD group. Example: "CN=admin\_group, OU=company groups, DC=company, DC=com"

### xConfiguration UserManagement LDAP Attribute

The attribute used to map to the provided username. If not set, sAMAccountName is used.

Requires user role: ADMIN

Default value: ""

#### USAGE:

xConfiguration UserManagement LDAP Attribute: "Attribute"

where

Attribute: String (0, 255)

The attribute name.

## Video configuration

### xConfiguration Video DefaultMainSource

Define which video input source shall be used as the main video source.

Requires user role: ADMIN, USER

Default value: 1

#### USAGE:

xConfiguration Video DefaultMainSource: DefaultMainSource

where

DefaultMainSource: 1

Set the source to be used as the main video source.

### xConfiguration Video Input Connector [1..2] CameraControl Mode

Define whether the camera that is connected to this video input connector can be controlled or not.

Note that camera control is not available for Connector 2 (HDMI) and Connector 3 (VGA).

Requires user role: ADMIN

Default value: Connector 1: On Connector 2,3: Off

#### USAGE:

xConfiguration Video Input Connector n CameraControl Mode: Mode

where

n: Unique ID that identifies the video input connector. Range: 1..2

Mode: Off

Off: Disable camera control.

### xConfiguration Video Input Connector [1..2] CameraControl CameraId

The camera ID is a unique identifier of the cameras that are connected to the video input.

Requires user role: ADMIN

Default value: 1

#### USAGE:

xConfiguration Video Input Connector n CameraControl CameraId: CameraId

where

n: Unique ID that identifies the video input connector. Range: 1..2

CameraId: 1

The camera ID is fixed and cannot be changed.

### xConfiguration Video Input Connector [1..2] InputSourceType

Select which type of input source is connected to the video input.

Note that Connector 1 is the system's integrated camera.

Requires user role: ADMIN

Default value: Connector 1: camera Other connectors: PC

#### USAGE:

xConfiguration Video Input Connector n InputSourceType: InputSourceType

where

n: Unique ID that identifies the video input connector. Range: 1..2

InputSourceType: Connector 1: camera Connector 2: camera/desktop/document\_camera/mediaplayer/PC/whiteboard/other

camera: Use this when a camera is connected to the video input.

desktop: Use this when the video system's monitor is the main screen for the PC / laptop that is connected to this input. The Video Input Connector [n] PresentationSelection setting must then also be set to desktop.

document\_camera: Use this when a document camera is connected to the video input.

mediaplayer: Use this when a media player is connected to the video input.

PC: Use this when a computer is connected to the video input.

whiteboard: Use this when a whiteboard camera is connected to the video input.

other: Use this when the other options do not match.



### xConfiguration Video Input Connector [1..2] Name

Define a name for the video input connector.

Requires user role: ADMIN

Default value: ""

#### USAGE:

xConfiguration Video Input Connector n Name: "Name"

where

n: Unique ID that identifies the video input connector. Range: 1..2

Name: String (0, 50)

Name for the video input connector.

### xConfiguration Video Input Connector [2] Quality

When encoding and transmitting video there is a trade-off between high resolution and high frame rate. For some video sources it is more important to transmit high frame rate than high resolution and vice versa. This setting specifies whether to give priority to high frame rate or to high resolution.

Requires user role: ADMIN

Default value: Sharpness

#### USAGE:

xConfiguration Video Input Connector n Quality: Quality

where

n: Unique ID that identifies the video input connector. Range: 2..2

Quality: Motion/Sharpness

Motion: Gives the highest possible frame rate. Used when there is a need for higher frame rates, typically when a large number of participants are present or when there is a lot of motion in the picture.

Sharpness: Gives the highest possible resolution. Used when you want the highest quality of detailed images and graphics.

### xConfiguration Video Input Connector [2] PresentationSelection

Define how the video system will behave when you connect a presentation source to the video input.

If the video system is in standby mode, it will wake up when you connect a presentation source. Sharing the presentation with the far end requires additional action (select Share on the user interface) except when this setting is set to AutoShare.

Requires user role: ADMIN

Default value: OnConnect

#### USAGE:

xConfiguration Video Input Connector n PresentationSelection:

PresentationSelection

where

n: Unique ID that identifies the video input connector. Range: 2..2

PresentationSelection: AutoShare/Desktop/Manual/OnConnect

AutoShare: While in a call, the content on the video input will automatically be presented to the far end as well as on the local screen when you connect the cable, or when the source is activated otherwise (for example when a connected computer wakes up from sleep mode). You do not have to select Share on the user interface. If a presentation source is already connected when you make or answer a call, you have to manually select Share on the user interface.

Desktop: The content on the video input will be presented on the screen when you connect the cable, or when the source is activated otherwise (for example when a connected computer wakes up from sleep mode). This applies both when idle and in a call. Also, the content on the video input will stay on the screen when you leave the call, provided that it was the active input at the time of leaving.

Manual: The content on the video input will not be presented on the screen until you select Share from the user interface.

OnConnect: The content on the video input will be presented on screen when you connect the cable, or when the source is activated otherwise (for example when a connected computer wakes up from sleep mode). Otherwise, the behavior is the same as in manual mode.

### xConfiguration Video Input Connector [1..2] Visibility

Define the visibility of the video input connector in the menus on the user interface.

Note that Connector 1 is the system's integrated camera, which is not available as a presentation source.

- > The default value is Always for Video Input Connector 2 Visibility (the HDMI connector).
- > The default value is IfSignal for Video Input Connector 3 Visibility (the VGA connector).

Requires user role: ADMIN

Default value: Connector 1: Never Connector 2: Always Connector 3: OnConnect

#### USAGE:

xConfiguration Video Input Connector n Visibility: Visibility

where

n: Unique ID that identifies the video input connector. Range: 1..2

Visibility: Connector 1: Never Connector 2, 3: Never/Always/IfSignal

Never: When the input source is not expected to be used as a presentation source, set to Never.

Always: When set to Always, the menu selection for the video input connector will always be visible on the graphical user interface.

IfSignal: When set to IfSignal, the menu selection for the video input connector will only be visible when something is connected to the video input.

### xConfiguration Video Monitors

Define the monitor layout mode. Note that this video system supports only one monitor, so this value is fixed and cannot be changed.

Requires user role: ADMIN

Default value: Single

#### USAGE:

xConfiguration Video Monitors: Monitors

where

Monitors: Auto/Single/Dual/DualPresentationOnly

Auto: The layout is shown on the video system's integrated monitor. An extra monitor is not supported.

Single: Not applicable.

Dual: Not applicable.

DualPresentationOnly: Not applicable.

### xConfiguration Video Output Connector [2] CEC Mode

This video output (HDMI) supports Consumer Electronics Control (CEC). When this setting is On (default is Off), the system will use CEC to set the monitor in standby when the system itself enters standby. Likewise the system will wake up the monitor when the system itself wakes up from standby. For this to happen, the monitor that is connected to the output must be CEC compatible and CEC must be configured on the monitor.

Note that the different manufacturers uses different marketing names for CEC, for example Anynet+ (Samsung); Aquos Link (Sharp); BRAVIA Sync (Sony); HDMI-CEC (Hitachi); Kuro Link (Pioneer); CE-Link and Regza Link (Toshiba); RIHD (Onkyo); HDAVI Control, EZ-Sync, VIERA Link (Panasonic); EasyLink (Philips); and NetCommand for HDMI (Mitsubishi).

#### USAGE:

xConfiguration Video Output Connector n CEC Mode: Mode

where

n: Unique ID that identifies the video output connector. Range: 1..1

### xConfiguration Video Output Connector [2] OverscanLevel

Some monitors may not present the entire image that they receive. This means that the outer parts of the image that is sent from the video system may be cut off when displayed on the monitor.

Use this setting to instruct the video system not to use the outer part of the available frame. This part might be cut off by the monitor. Both the video and messages on screen will be scaled in this case.

**USAGE:**

xConfiguration Video Output Connector n OverscanLevel: OverscanLevel  
 where  
n: Unique ID that identifies the video output connector. Range: 2..2

### xConfiguration Video Output Connector [1..2] Resolution

Define the resolution and refresh rate for the connected screen. This value is fixed and cannot be changed.

Default value: Auto

**USAGE:**

xConfiguration Video Output Connector n Resolution: Resolution  
 where  
n: Unique ID that identifies the video output connector. Range: 1..2  
Resolution: Connector 1: 1920\_1080\_60  
 1920\_1080\_60: The resolution is 1920 x 1080, and the refresh rate is 60 Hz.

### xConfiguration Video Presentation DefaultSource

Define which video input source to use as a default presentation source. This setting may be used by the API and 3rd party user interfaces. It is not relevant when using the user interfaces provided by Cisco.

Requires user role: ADMIN, USER

Default value: 2

**USAGE:**

xConfiguration Video Presentation DefaultSource: DefaultSource  
 where  
DefaultSource: 2  
 The video input source to use as default presentation source.

### xConfiguration Video Selfview Default Mode

Define if the main video source (self-view) shall be displayed on screen after a call. The position and size of the self-view window is determined by the Video Selfview Default PIPPosition and the Video Selfview Default FullscreenMode settings respectively.

Requires user role: ADMIN

Default value: Current

**USAGE:**

xConfiguration Video Selfview Default Mode: Mode  
 where  
Mode: Off/Current/On  
 Off: self-view is switched off when leaving a call.  
 Current: self-view is left as is, i.e. if it was on during the call, it remains on after the call; if it was off during the call, it remains off after the call.  
 On: self-view is switched on when leaving a call.

### xConfiguration Video Selfview Default FullscreenMode

Define if the main video source (self-view) shall be shown in full screen or as a small picture-in-picture (PiP) after a call. The setting only takes effect when self-view is switched on (see the Video Selfview Default Mode setting).

Requires user role: ADMIN

Default value: Current

**USAGE:**

xConfiguration Video Selfview Default FullscreenMode: FullscreenMode

where

FullscreenMode: Off/Current/On

Off: self-view will be shown as a PiP.

Current: The size of the self-view picture will be kept unchanged when leaving a call, i.e. if it was a PiP during the call, it remains a PiP after the call; if it was fullscreen during the call, it remains fullscreen after the call.

On: The self-view picture will be shown in fullscreen.

### xConfiguration Video Selfview Default OnMonitorRole

**USAGE:**

xConfiguration Video Selfview Default OnMonitorRole: OnMonitorRole

where

### xConfiguration Video Selfview Default PIPPosition

Define the position on screen of the small self-view picture-in-picture (PiP) after a call. The setting only takes effect when self-view is switched on (see the Video Selfview Default Mode setting) and fullscreen view is switched off (see the Video Selfview Default FullscreenMode setting).

Requires user role: ADMIN

Default value: Current

**USAGE:**

xConfiguration Video Selfview Default PIPPosition: PIPPosition

where

PIPPosition: Current/UpperLeft/UpperCenter/UpperRight/CenterLeft/CenterRight/LowerLeft/LowerRight

Current: The position of the self-view PiP will be kept unchanged when leaving a call.

UpperLeft: The self-view PiP will appear in the upper left corner of the screen.

UpperCenter: The self-view PiP will appear in the upper center position.

UpperRight: The self-view PiP will appear in the upper right corner of the screen.

CenterLeft: The self-view PiP will appear in the center left position.

CentreRight: The self-view PiP will appear in the center right position.

LowerLeft: The self-view PiP will appear in the lower left corner of the screen.

LowerRight: The self-view PiP will appear in the lower right corner of the screen.

### xConfiguration Video Selfview OnCall Mode

This setting is used to switch on self-view for a short while when setting up a call. The Video Selfview OnCall Duration setting determines for how long it remains on. This applies when self-view in general is switched off.

Requires user role: ADMIN

Default value: On

#### USAGE:

xConfiguration Video Selfview OnCall Mode: Mode

where

Mode: Off/On

Off: self-view is not shown automatically during call setup.

On: self-view is shown automatically during call setup.

### xConfiguration Video Selfview OnCall Duration

This setting only has an effect when the Video Selfview OnCall Mode setting is switched On. In this case, the number of seconds set here determines for how long self-view is shown before it is automatically switched off.

Requires user role: ADMIN

Default value: 10

#### USAGE:

xConfiguration Video Selfview OnCall Duration: Duration

where

Duration: Integer (1..60)

Range: Choose for how long self-view remains on. The valid range is between 1 and 60 seconds.

## Chapter 4

# xCommand commands

## Description of the xCommand commands

In this chapter, you can find a complete list of all xCommand type commands with parameters.

We recommend you visit our web site regularly for updated versions of the manual.

Go to: <http://www.cisco.com/go/dx-docs>

<b>Audio commands</b> .....	<b>90</b>	xCommand Call FarEndControl Camera Move .....	94
xCommand Audio Microphones Mute.....	90	xCommand Call FarEndControl Camera Stop.....	94
xCommand Audio Microphones Unmute .....	90	xCommand Call FarEndControl RoomPreset Activate .....	94
xCommand Audio Select .....	90	xCommand Call FarEndControl Source Select .....	95
xCommand Audio SoundsAndAlerts Ringtone List .....	90	xCommand Call Hold.....	95
xCommand Audio SoundsAndAlerts Ringtone Play .....	90	xCommand Call Ignore.....	95
xCommand Audio Volume Decrease .....	90	xCommand Call Join .....	95
xCommand Audio Volume Increase .....	91	xCommand Call Reject.....	95
xCommand Audio Volume Mute.....	91	xCommand Call Resume.....	96
xCommand Audio Volume Set .....	91	xCommand Call UnattendedTransfer .....	96
xCommand Audio Volume SetToDefault .....	91		
xCommand Audio Volume Unmute.....	91	<b>CallHistory commands</b> .....	<b>96</b>
xCommand Audio VuMeter Start .....	91	xCommand CallHistory AcknowledgeAllMissedCalls .....	96
xCommand Audio VuMeter Stop.....	92	xCommand CallHistory AcknowledgeMissedCall .....	96
xCommand Audio VuMeter StopAll.....	92	xCommand CallHistory DeleteAll .....	96
		xCommand CallHistory DeleteEntry .....	97
<b>Bookings commands</b> .....	<b>92</b>	xCommand CallHistory Get.....	97
xCommand Bookings Clear.....	92	xCommand CallHistory Recents .....	98
xCommand Bookings Get .....	92		
xCommand Bookings List .....	93	<b>Conference commands</b> .....	<b>98</b>
		xCommand Conference DoNotDisturb Activate .....	98
<b>Call commands</b> .....	<b>93</b>	xCommand Conference DoNotDisturb Deactivate .....	98
xCommand Call Accept.....	93	xCommand Conference SpeakerLock Release .....	98
xCommand Call DTMFSend.....	93	xCommand Conference SpeakerLock Set .....	99
xCommand Call Disconnect.....	94		

<b>Diagnostics commands</b> .....	<b>99</b>	<b>Provisioning commands</b> .....	<b>108</b>
xCommand Diagnostics Run .....	99	xCommand Provisioning CompleteUpgrade .....	108
<b>Dial commands</b> .....	<b>100</b>	xCommand Provisioning PostponeUpgrade .....	108
xCommand Dial .....	100	xCommand Provisioning StartUpgrade .....	108
<b>HttpFeedback commands</b> .....	<b>100</b>	<b>Proximity commands</b> .....	<b>109</b>
xCommand HttpFeedback Deregister .....	100	xCommand Proximity Services Activate .....	109
xCommand HttpFeedback Register .....	100	xCommand Proximity Services Deactivate .....	109
<b>Peripherals commands</b> .....	<b>101</b>	<b>Security commands</b> .....	<b>109</b>
xCommand Peripherals Connect .....	101	xCommand Security Persistency .....	109
xCommand Peripherals HeartBeat .....	101	xCommand Security Session List .....	110
xCommand Peripherals List .....	101	xCommand Security Session Terminate .....	110
xCommand Peripherals Pairing DeviceDiscovery Start .....	102	<b>Standby commands</b> .....	<b>110</b>
xCommand Peripherals Pairing Pair .....	102	xCommand Standby Activate .....	110
xCommand Peripherals Pairing Unpair .....	102	xCommand Standby Deactivate .....	110
xCommand Peripherals Purge .....	102	xCommand Standby ResetTimer .....	110
<b>Phonebook commands</b> .....	<b>103</b>	<b>SystemUnit commands</b> .....	<b>111</b>
xCommand Phonebook Contact Add .....	103	xCommand SystemUnit Boot .....	111
xCommand Phonebook Contact Delete .....	103	xCommand SystemUnit FactoryReset .....	111
xCommand Phonebook Contact Modify .....	104	xCommand SystemUnit Notifications RemoveAll .....	111
xCommand Phonebook ContactMethod Add .....	104	xCommand SystemUnit OptionKey Add .....	111
xCommand Phonebook ContactMethod Delete .....	105	xCommand SystemUnit OptionKey List .....	111
xCommand Phonebook ContactMethod Modify .....	105	xCommand SystemUnit OptionKey Remove .....	112
xCommand Phonebook Folder Add .....	106	xCommand SystemUnit OptionKey RemoveAll .....	112
xCommand Phonebook Folder Delete .....	106	xCommand SystemUnit SoftReset .....	112
xCommand Phonebook Folder Modify .....	106	xCommand SystemUnit SoftwareUpgrade .....	112
xCommand Phonebook Search .....	107	<b>Time commands</b> .....	<b>113</b>
<b>Presentation commands</b> .....	<b>108</b>	xCommand Time DateTime Get .....	113
xCommand Presentation Start .....	108	xCommand Time DateTime Set .....	113
xCommand Presentation Stop .....	108		





<b>UserInterface commands</b> .....	<b>113</b>
xCommand UserInterface Extensions Clear .....	113
xCommand UserInterface Extensions List .....	113
xCommand UserInterface Message Alert Clear .....	113
xCommand UserInterface Message Alert Display .....	114
xCommand UserInterface Message Prompt Clear .....	114
xCommand UserInterface Message Prompt Display .....	114
xCommand UserInterface Message Prompt Response .....	115
xCommand UserInterface Message TextLine Clear .....	115
xCommand UserInterface Message TextLine Display .....	115
xCommand UserInterface OSD Key Click .....	115
xCommand UserInterface OSD Key Press .....	116
xCommand UserInterface OSD Key Release .....	116
<b>UserManagement commands</b> .....	<b>116</b>
xCommand UserManagement RemoteSupportUser Create .....	116
xCommand UserManagement RemoteSupportUser Delete .....	116
xCommand UserManagement RemoteSupportUser DisablePermanently .....	116
xCommand UserManagement RemoteSupportUser GetState .....	117
xCommand UserManagement User Passphrase Change .....	117
xCommand UserManagement User Passphrase Set .....	117
<b>Video commands</b> .....	<b>118</b>
xCommand Video ActiveSpeakerPIP Set .....	118
xCommand Video Input SetMainVideoSource .....	118
xCommand Video Input Source SetActiveConnector .....	118
xCommand Video Layout LayoutFamily Set .....	118
xCommand Video PresentationPIP Set .....	119
xCommand Video PresentationView Set .....	119
xCommand Video Selfview Set .....	119

## Audio commands

### xCommand Audio Microphones Mute

Mute all microphones.

Requires user role: ADMIN, USER

**USAGE:**

`xCommand Audio Microphones Mute`

### xCommand Audio Microphones Unmute

Unmute microphones.

Requires user role: ADMIN, USER

**USAGE:**

`xCommand Audio Microphones Unmute`

### xCommand Audio Select

Select an audio device.

Requires user role: ADMIN, USER

**USAGE:**

`xCommand Audio Select [ : ]`

where

: Internal/HeadsetAnalog/HeadsetUSB/HandsetUSB

Select the type of audio device: the internal speaker, analog headset (DX70 only), USB headset, or USB handset.

### xCommand Audio SoundsAndAlerts Ringtone List

Lists all available ringtones that can be configured using xConfiguration Audio SoundsAndAlerts RingTone.

Requires user role: ADMIN, USER

**USAGE:**

`xCommand Audio SoundsAndAlerts Ringtone List`

### xCommand Audio SoundsAndAlerts Ringtone Play

Play one of the available ringtones. To get a list of the available ringtones use the command xCommand Audio SoundsAndAlerts Ringtone List.

Requires user role: ADMIN, USER

**USAGE:**

`xCommand Audio SoundsAndAlerts Ringtone Play RingTone: "RingTone"`

where

**RingTone:** String (1, 100)

The name of the ringtone.

### xCommand Audio Volume Decrease

Decrease the volume on the endpoint.

Requires user role: ADMIN, USER

**USAGE:**

`xCommand Audio Volume Decrease [Device: Device] [Steps: Steps]`

where

**Device:** Internal/HeadsetAnalog/HeadsetUSB/HandsetUSB

Decrease the internal volume or the volume on an analog headset (DX70 only) or a USB headset or handset.

**Steps:** Integer (1..10)

One step equals 0.5dB decrease in volume.

### xCommand Audio Volume Increase

Increase the volume on the endpoint.

Requires user role: ADMIN, USER

#### USAGE:

```
xCommand Audio Volume Increase [Device: Device] [Steps: Steps]
where
```

**Device:** Internal/HeadsetAnalog/HeadsetUSB/HandsetUSB

Increase the internal volume or the volume on an analog headset (DX70 only) or a USB headset or handset.

**Steps:** Integer (1..10)

One step equals 0.5dB increase in volume.

### xCommand Audio Volume Mute

Mute the volume on the endpoint.

Requires user role: ADMIN, USER

#### USAGE:

```
xCommand Audio Volume Mute
```

### xCommand Audio Volume Set

Set the volume on the endpoint to a specified level.

Requires user role: ADMIN, USER

#### USAGE:

```
xCommand Audio Volume Set [Device: Device] Level: Level
where
```

**Device:** Internal/HeadsetAnalog/HeadsetUSB/HandsetUSB

Set the internal volume or the volume on an analog headset (DX70 only) or a USB headset or handset.

**Level:** Integer (0..100)

Select gain level. The default level 70 equals 0dB gain. Level 100 equals 15db gain.

### xCommand Audio Volume SetToDefault

Set the current volume level as the default for the endpoint.

Requires user role: ADMIN, USER

#### USAGE:

```
xCommand Audio Volume SetToDefault [Device: Device]
where
```

**Device:** Internal/HeadsetAnalog/HeadsetUSB/HandsetUSB

Set the current volume as the default internal volume or the default volume on an analog headset (DX70 only) or a USB headset or handset.

### xCommand Audio Volume Unmute

Set the volume on the endpoint back on after muting.

Requires user role: ADMIN, USER

#### USAGE:

```
xCommand Audio Volume Unmute
```

### xCommand Audio VuMeter Start

Start VuMeter on the specified connector. The VuMeter measures the input level for frequencies below 20 kHz.

Requires user role: ADMIN, USER

#### USAGE:

```
xCommand Audio VuMeter Start [ : ] [ : ]
where
```

: Integer(1..8)

The ID number of the connector.

: HDMI/Line/Microphone

Add description.

### xCommand Audio VuMeter Stop

Stop VuMeter on the specified connector.

Requires user role: ADMIN, USER

**USAGE:**

```
xCommand Audio VuMeter Stop [ : ] [ : ]
where
```

: Integer(1..8)

The ID number of the connector.

: HDMI/Line/Microphone

Add description.

### xCommand Audio VuMeter StopAll

Stop all VuMeters.

Requires user role: ADMIN, USER

**USAGE:**

```
xCommand Audio VuMeter StopAll
```

## Bookings commands

### xCommand Bookings Clear

Clear the current stored list of bookings.

Requires user role: ADMIN, USER

**USAGE:**

```
xCommand Bookings Clear
```

### xCommand Bookings Get

Get the booking information for a specific ID.

Requires user role: ADMIN, USER

**USAGE:**

```
xCommand Bookings Get Id: "Id"
where
```

**Id:** String (0, 128)

The booking ID of a call or conference.

## xCommand Bookings List

List the stored bookings for the system. The list of booking details is received from the management system. All parameters are optional, and can be used to limit the search result. If no parameters are set, past, present and future bookings are all listed. To avoid listing bookings from yesterday and before, use DayOffset = 0.

Requires user role: ADMIN, USER

### USAGE:

```
xCommand Bookings List [Days: Days] [DayOffset: DayOffset] [Limit: Limit]
[Offset: Offset]
```

where

**Days:** Integer (1..365)

Number of days to retrieve bookings from.

**DayOffset:** Integer (0..365)

Which day to start the search from (today: 0, tomorrow: 1...).

**Limit:** Integer (1..65534)

Max number of bookings to list.

**Offset:** Integer (0..65534)

Offset number of bookings for this search.

## Call commands

### xCommand Call Accept

Accept an incoming call. If no CallId is specified, all incoming calls are accepted.

Requires user role: ADMIN, USER

### USAGE:

```
xCommand Call Accept [CallId: CallId]
```

where

**CallId:** Integer (0..65534)

The CallID is returned when the xCommand Dial command is run. During the call you can run the xStatus Call command to see the CallId.

### xCommand Call DTMFSend

Send DTMF tones to the far end.

Requires user role: ADMIN, USER

### USAGE:

```
xCommand Call DTMFSend [CallId: CallId] DTMFString: "DTMFString"
```

where

**CallId:** Integer (0..65534)

The CallID is returned when the xCommand Dial command is run. During the call you can run the xStatus Call command to see the CallId.

**DTMFString:** String (0, 32)

Enter the DTMF string.

### xCommand Call Disconnect

Disconnect a call.

Requires user role: ADMIN, USER

#### USAGE:

xCommand Call Disconnect [CallId: CallId]  
where

**CallId:** Integer (0..65534)

The CallID is returned when the xCommand Dial command is run. During the call you can run the xStatus Call command to see the CallId.

### xCommand Call FarEndControl Camera Move

Move the far end camera (the remote camera).

NOTE: The far end camera moves in the specified direction until the stop command (ref: xCommand FarEndControl Camera Stop) is issued.

Requires user role: ADMIN, USER

#### USAGE:

xCommand Call FarEndControl Camera Move [CallId: CallId] Value: Value  
where

**CallId:** Integer (0..65534)

The CallID is returned when the xCommand Dial command is run. During the call you can run the xStatus Call command to see the CallId.

**Value:** Left/Right/Up/Down/ZoomIn/ZoomOut

Select the action for how to move the camera.

### xCommand Call FarEndControl Camera Stop

Stop the far end camera after the xCommand FarEndControl Camera Move has been issued.

Requires user role: ADMIN, USER

#### USAGE:

xCommand Call FarEndControl Camera Stop [CallId: CallId]  
where

**CallId:** Integer (0..65534)

The CallID is returned when the xCommand Dial command is run. During a call you can run the xStatus Call command to see the CallId.

### xCommand Call FarEndControl RoomPreset Activate

While in a call, this command is used to activate a preset on the far end codec. The preset covers the far end codec's camera positions and input video switcher settings.

The preset must be stored on the far end codec beforehand, either by using the xCommand Preset Store command locally on the far end codec, or by using the xCommand FarEndControl Preset Store command from a remote codec.

Note: The far end codec's xConfiguration Conference FarEndControl Mode setting must be switched On for the FarEndControl commands to work.

Requires user role: ADMIN, USER

#### USAGE:

xCommand Call FarEndControl RoomPreset Activate [CallId: CallId] PresetId: PresetId  
where

**CallId:** Integer (0..65534)

The CallId is required to identify the far end codec only when in a Multipoint call. The CallId is returned when issuing the xCommand Dial command. During a call you can run the xStatus Call command to see the CallId.

**PresetId:** Integer (1..15)

The ID of the preset that is stored on the far end codec.

### xCommand Call FarEndControl Source Select

Select which video input source to use as the main source on the far end system.

Requires user role: ADMIN, USER

**USAGE:**

xCommand Call FarEndControl Source Select [CallId: CallId] SourceId: SourceId  
where

**CallId:** Integer (0..65534)

The CallId is returned when the xCommand Dial command is run. During a call you can run the xStatus Call command to see the CallId.

**SourceId:** Integer (0..15)

Select a video input source on the far end.

### xCommand Call Hold

Put a call on hold.

Requires user role: ADMIN, USER

**USAGE:**

xCommand Call Hold [CallId: CallId] [Reason: Reason]  
where

**CallId:** Integer (0..65534)

The CallId is returned when the xCommand Dial command is run. During a call you can run the xStatus Call command to see the CallId.

**Reason:** Conference/Transfer/Other

Internal usage only.

### xCommand Call Ignore

Turns off the ringtone for the incoming call. The call can still be answered.

Requires user role: ADMIN, USER

**USAGE:**

xCommand Call Ignore CallId: CallId  
where

**CallId:** Integer (0..65534)

The CallId is returned when the xCommand Dial command is run. During a call you can run the xStatus Call command to see the CallId.

### xCommand Call Join

Internal usage only.

Requires user role: ADMIN, USER

**USAGE:**

xCommand Call Join CallId: CallId  
where

**CallId:** Integer (0..65534)

### xCommand Call Reject

Reject incoming call. If no call id is specified, all incoming calls are rejected.

Requires user role: ADMIN, USER

**USAGE:**

xCommand Call Reject [CallId: CallId]  
where

**CallId:** Integer (0..65534)

The CallId is returned when the xCommand Dial command is run. During a call you can run the xStatus Call command to see the CallId.

### xCommand Call Resume

Resume a call that have been put on hold.

Requires user role: ADMIN, USER

**USAGE:**

```
xCommand Call Resume CallId: CallId
where
```

**CallId:** Integer (0..65534)

The CallID is returned when the xCommand Dial command is run. During a call you can run the xStatus Call command to see the CallId.

### xCommand Call UnattendedTransfer

Transfers an ongoing call to another participant. Fully supported for SIP calls only.

Requires user role: ADMIN, USER

**USAGE:**

```
xCommand Call UnattendedTransfer CallId: CallId Number: "Number"
where
```

**CallId:** Integer (0..65534)

The CallID is returned when the xCommand Dial command is run. During a call you can run the xStatus Call command to see the CallId.

**Number:** String (0, 255)

The number the call is transferred to.

## CallHistory commands

### xCommand CallHistory AcknowledgeAllMissedCalls

Turns off the missed calls indicator on the touch controller for all missed calls.

Requires user role: ADMIN, USER

**USAGE:**

```
xCommand CallHistory AcknowledgeAllMissedCalls
```

### xCommand CallHistory AcknowledgeMissedCall

Turns off the missed calls indicator on the touch controller for the specified call.

Requires user role: ADMIN, USER

**USAGE:**

```
xCommand CallHistory AcknowledgeMissedCall CallHistoryId: CallHistoryId
[AcknowledgeConsecutiveDuplicates: AcknowledgeConsecutiveDuplicates]
where
```

**CallHistoryId:** Integer (1..2147483647)

CallHistoryId for the call in question. Run xCommand CallHistory Get to get the id number.

**AcknowledgeConsecutiveDuplicates:** False/True

You can include or exclude all surrounding calls with duplicate information.

### xCommand CallHistory DeleteAll

Deletes all information on previous calls.

Requires user role: ADMIN, USER

**USAGE:**

```
xCommand CallHistory DeleteAll [Filter: Filter]
where
```

**Filter:** All/Missed/Placed/Received

You can filter which calls to delete.



### xCommand CallHistory DeleteEntry

Deletes all information on the specified call.

Requires user role: ADMIN, USER

#### USAGE:

```
xCommand CallHistory DeleteEntry CallHistoryId: CallHistoryId
[AcknowledgeConsecutiveDuplicates: AcknowledgeConsecutiveDuplicates]
where
```

**CallHistoryId:** Integer (1..2147483647)

CallHistoryId for the call in question. Run xCommand CallHistory Get to get the id number.

**AcknowledgeConsecutiveDuplicates:** False/True

You can include or exclude all surrounding calls with duplicate information.

### xCommand CallHistory Get

Retrieve all information on previous calls made on the video system.

Requires user role: ADMIN, USER

#### USAGE:

```
xCommand CallHistory Get [Filter: Filter] [Offset: Offset] [Limit: Limit]
[DetailLevel: DetailLevel] [SearchString: "SearchString"] [CallHistoryId:
CallHistoryId]
where
```

**Filter:** All/Missed/AnsweredElsewhere/Forwarded/Placed/NoAnswer/Received/Rejected/UnacknowledgedMissed

You can filter which calls to retrieve.

**Offset:** Integer (0..65534)

Sets the call from which to start.

**Limit:** Integer (0..65534)

Defines the amount of calls in the output.

**DetailLevel:** Basic/Full

Sets the level of detail for the information on these calls.

**SearchString:** String ( 0, 255)

Allows you to set the command to apply to a specified display name or call back number.

**CallHistoryId:** Integer (0..65534)

CallHistoryId for the call in question.

### xCommand CallHistory Recents

Retrieve aggregated information on previous calls made on the video system.

Requires user role: ADMIN, USER

**USAGE:**

```
xCommand CallHistory Recents [Filter: Filter] [Offset: Offset] [Limit: Limit]
[DetailLevel: DetailLevel] [SearchString: "SearchString"] [CallHistoryId:
CallHistoryId] [Order: Order]
```

where

**Filter:** All/Missed/AnsweredElsewhere/Forwarded/Placed/NoAnswer/Received/Rejected/UnacknowledgedMissed

You can filter which calls to retrieve.

**Offset:** Integer (0..65534)

Sets the call from which to start.

**Limit:** Integer (0..65534)

Defines the amount of calls in the output.

**DetailLevel:** Basic/Full

Sets the level of detail for the information on these calls.

**SearchString:** String (0, 255)

Allows you to set the command to apply to a specified display name or call back number.

**CallHistoryId:** Integer (0..65534)

CallHistoryId for the call in question.

**Order:** OccurrenceTime/OccurrenceFrequency

Define the order in which the previous calls are presented.

## Conference commands

### xCommand Conference DoNotDisturb Activate

This command switches on the Do Not Disturb mode, and the Timeout parameter allows you to control when it is switched off again. When Do Not Disturb is switched on, all incoming calls are rejected and registered as missed calls. The calling side receives a busy signal.

Requires user role: ADMIN, USER

**USAGE:**

```
xCommand Conference DoNotDisturb Activate [Timeout: Timeout]
```

where

**Timeout:** Integer (1..1440)

Set the number of minutes before Do Not Disturb is switched off. If not set, Do Not Disturb times out after 1440 minutes (24 hours).

### xCommand Conference DoNotDisturb Deactivate

Switch off the Do Not Disturb mode. When Do Not Disturb is switched off incoming calls come through as normal.

Requires user role: ADMIN, USER

**USAGE:**

```
xCommand Conference DoNotDisturb Deactivate
```

### xCommand Conference SpeakerLock Release

Releases locked speaker set by xCommand Conference SpeakerLock Set. Default voice switching is switched back on.

Requires user role: ADMIN, USER

**USAGE:**

```
xCommand Conference SpeakerLock Release
```

### xCommand Conference SpeakerLock Set

For manually locking one of the speakers to the prominent speaker position. This overrides the default voice switching.

Requires user role: ADMIN, USER

**USAGE:**

```
xCommand Conference SpeakerLock Set Target: Target [CallId: CallId]  
where
```

**Target:** local/remote

Identifies local or remote participant.

**CallId:** Integer (0..65534)

Identify CallID for the remote participant. Only relevant if Target is set to "remote".

## Diagnostics commands

### xCommand Diagnostics Run

This command runs self-diagnostics commands on the system.

Requires user role: ADMIN

**USAGE:**

```
xCommand Diagnostics Run [ResultSet: ResultSet]  
where
```

**ResultSet:** Alerts/All/None

You can filter the diagnostics results to alerts, all or none. If not set, the result will show all results.

## Dial commands

### xCommand Dial

Dial out from the system. Returns information about the CallId and Conferenceld, which are required for some of the other commands.

Requires user role: ADMIN, USER

#### USAGE:

```
xCommand Dial Number: "Number" [Protocol: Protocol] [CallRate: CallRate]
[CallType: CallType] [BookingId: "BookingId"] [Appearance: Appearance]
[DisplayName: "DisplayName"]
where
```

**Number:** String (0, 255)  
Enter the number or address.

**Protocol:** H320/H323/Sip/Spark  
Select the call protocol.

**CallRate:** Integer (64..6000)  
Set the call rate.

**CallType:** Audio/Video  
Select the call type.

**BookingId:** String (0, 255)  
Any identifier that an external booking system (e.g. TMS, CTS-MAN) can use for its own references to match placed calls with the booking systems internal identifier for a meeting. This can be any string, e.g. a GUID. The booking Id is supplied in call logs, call events etc for the call.

**Appearance:** Integer (1..999999999)  
Internal usage only.

**DisplayName:** String (0, 255)  
The display name of the remote participant.

## HttpFeedback commands

### xCommand HttpFeedback Deregister

Deregister XML feedback over HTTP(S).

Requires user role: ADMIN

#### USAGE:

```
xCommand HttpFeedback Deregister FeedbackSlot: FeedbackSlot
where
```

**FeedbackSlot:** Integer (1..4)  
You can have from 1 to 4 slots for feedback.

### xCommand HttpFeedback Register

Register the system to a HTTP(S) server to return XML feedback over HTTP(S) to specific URLs.

Requires user role: ADMIN

#### USAGE:

```
xCommand HttpFeedback Register [FeedbackSlot: FeedbackSlot] ServerUrl:
"ServerUrl" [Expression[1..15]: "Expression[1..15]"]
where
```

**FeedbackSlot:** Integer (1..4)  
You can have from 1 to 4 slots for feedback.

**ServerUrl:** String (1, 2048)  
Define the URL for the HTTP(S) server.

**Expression[1..15]:** String (1, 255)  
XPath expressions specify which parts of the Status and Configuration XML documents are monitored. You can have from 1 to 15 XPath expressions.

## Peripherals commands

### xCommand Peripherals Connect

Register peripherals that are connected to the codec, such as control systems and touch panels. The registered peripherals are displayed on the web interface under Configuration > Peripherals.

This command should be used when the peripheral connects to the codec for the first time or when the software version on the peripheral has changed. The list of connected devices is available with the command xStatus Peripherals ConnectedDevice [n] Status.

Requires user role: ADMIN, USER

#### USAGE:

```
xCommand Peripherals Connect [HardwareInfo: "HardwareInfo"] ID: "ID" [Name: "Name"] [NetworkAddress: "NetworkAddress"] [SerialNumber: "SerialNumber"] [SoftwareInfo: "SoftwareInfo"] Type: Type
where
```

**HardwareInfo:** String (0, 100)

The device's hardware number.

**ID:** String (1, 100)

A unique ID for the device you are connecting to, typically a MAC address.

**Name:** String (0, 100)

Define a name for the device.

**NetworkAddress:** String (0, 100)

Network address for the device you are connecting to.

**SerialNumber:** String (0, 100)

The device's serial number.

**SoftwareInfo:** String (0, 100)

Software version the device is running.

**Type:** Byod/ControlSystem/Other/TouchPanel

Define the type of device you are connecting to.

### xCommand Peripherals HeartBeat

When a peripheral is registered as a connected device, you can set it to send a heartbeat to the codec to let the codec know that it is still connected.

This will keep the device on the xStatus Peripherals ConnectedDevice list. If the peripheral is not set to send a heartbeat, the device will disappear from the list after a while.

Note: Does not apply to cameras.

Requires user role: ADMIN, USER

#### USAGE:

```
xCommand Peripherals HeartBeat ID: "ID" [Timeout: Timeout]
where
```

**ID:** String (1, 100)

A unique ID for the device you are connecting to, typically a MAC address.

**Timeout:** Integer (1..65535)

Set how long the device will send heartbeat.

### xCommand Peripherals List

Lists all currently and previously connected peripherals.

Requires user role: ADMIN

#### USAGE:

```
xCommand Peripherals List [Connected: Connected] [Type: Type]
where
```

**Connected:** False/True

Limit the search to currently connected devices.

**Type:** All/ControlSystem/ISDNLink/Other/TouchPanel

Limit the search by device type.

### xCommand Peripherals Pairing DeviceDiscovery Start

Start device discovery to detect ISDN Links in the same network.

Requires user role: ADMIN

#### USAGE:

```
xCommand Peripherals Pairing DeviceDiscovery Start [AutoPairing: AutoPairing]
[DeviceType: DeviceType] [Timeout: Timeout]
where
```

#### AutoPairing: On/Off

You can select to automatically pair the detected device to the endpoint.

#### DeviceType: ISDNLink

Only look for ISDN Link.

#### Timeout: Integer (3..60)

Set a maximum time for the search from 3 to 60 seconds.

### xCommand Peripherals Pairing Pair

Pair an ISDN Link to an endpoint.

Requires user role: ADMIN

#### USAGE:

```
xCommand Peripherals Pairing Pair MacAddress: "MacAddress"
where
```

#### MacAddress: String (1, 1450)

Enter the MAC address for the ISDN Link you wish to pair to the endpoint.

### xCommand Peripherals Pairing Unpair

Unpair endpoint from an ISDN Link, when the two have contact.

Requires user role: ADMIN

#### USAGE:

```
xCommand Peripherals Pairing Unpair MacAddress: "MacAddress"
where
```

#### MacAddress: String (1, 100)

MacAddress: Enter the MAC address for the ISDN Link you wish to unpair from the endpoint.

### xCommand Peripherals Purge

Force unpair an endpoint from an ISDN Link when a connection has been lost. Note: You must also unpair the ISDN Link to be able to pair it to another endpoint.

Requires user role: ADMIN, USER

#### USAGE:

```
xCommand Peripherals Purge ID: "ID"
where
```

#### ID: String (1, 100)

Mac address of the ISDN Link in the format "xx:xx:xx:xx:xx:xx".

## Phonebook commands

### xCommand Phonebook Contact Add

Requires user role: ADMIN, USER

**USAGE:**

xCommand Phonebook Contact Add Name: "Name" [FolderId: "FolderId"] [ImageURL: "ImageURL"] [Title: "Title"] [Number: "Number"] [Protocol: "Protocol"] [CallRate: "CallRate"] [CallType: "CallType"] [Device: Device] [Tag: Tag]

where

**Name:** String (0, 255)

The name of the contact.

**FolderId:** String (0, 255)

The unique identifier for the folder that you want to store the contact in. The identifier will be returned by an xCommand Phonebook Search command. It was also returned when the xCommand Phonebook Folder Add command was issued to make the folder.

**ImageURL:** String (0, 255)

Currently not in use.

**Title:** String (0, 255)

The title of the contact.

**Number:** String (0, 255)

The phone number or address of the contact.

**Protocol:** Auto/H320/H323/SIP/Spark

Select the Auto, Spark, SIP, H323 or H320 protocol.

**CallRate:** Integer (0..6000)

Set a call rate.

**CallType:** Audio/Video

Select a call type (audio or video).

**Device:** Mobile/Other/Telephone/Video

Select the device type.

**Tag:** Untagged/Favorite

Tag the contact as a Favorite, or untag an already tagged contact.

### xCommand Phonebook Contact Delete

Delete an existing contact from the local phonebook.

Requires user role: ADMIN, USER

**USAGE:**

xCommand Phonebook Contact Delete ContactId: "ContactId"

where

**ContactId:** String (0, 255)

The unique identifier for the contact. The identifier will be returned by an xCommand Phonebook Search command. It was also returned when the xCommand Phonebook Contact Add command was issued to make the contact.

### xCommand Phonebook Contact Modify

Modify contact details of an existing contact in the local phonebook. The following parameters can be changed using this command: Name, FolderId, ImageURL and Title. You must use the xCommand Phonebook ContactMethod Modify command to change the other parameters: Number, Protocol, CallRate, CallType and Device.

Requires user role: ADMIN, USER

#### USAGE:

```
xCommand Phonebook Contact Modify ContactId: "ContactId" [Name: "Name"]
[FolderId: "FolderId"] [ImageURL: "ImageURL"] [Title: "Title"] [Tag: Tag]
where
```

**ContactId:** String (0, 255)

The unique identifier for the contact you want to modify. The identifier will be returned by an xCommand Phonebook Search command. It was also returned when the xCommand Phonebook Contact Add command was issued to make the contact.

**Name:** String (0, 255)

The name of the contact.

**FolderId:** String (0, 255)

A unique identifier for the folder. The identifier will be returned by an xCommand Phonebook Search command. It was also returned when the xCommand Phonebook Folder Add command was issued.

**ImageURL:** String (0, 255)

Currently not in use.

**Title:** String (0, 255)

The title of the contact.

**Tag:** Untagged/Favorite

Tag the contact as a Favorite, or untag an already tagged contact.

### xCommand Phonebook ContactMethod Add

Add contact details for an existing contact in the local phonebook. The command returns the ContactMethodId, which is a unique string that identifies the contact method; typically the format is "n".

You can add several contact methods to a contact. Note that only the first contact method will appear in the Favorites list on the Cisco TelePresence Touch controller. The first contact method may have been created when issuing the xCommand Phonebook Contact Add command to make the contact. All contact methods are available in the API, on the web interface and when using the remote control.

Requires user role: ADMIN, USER

#### USAGE:

```
xCommand Phonebook ContactMethod Add ContactId: "ContactId" [Device: Device]
Number: "Number" [Protocol: Protocol] [CallRate: CallRate] [CallType: CallType]
where
```

**ContactId:** String (0, 255)

The unique identifier for the contact that you want to add a contact method to. The identifier will be returned by an xCommand Phonebook Search command. It was also returned when the xCommand Phonebook Contact Add command was issued to make the contact.

**Device:** Mobile/Other/Telephone/Video

Set which type of device to call to.

**Number:** String (0, 255)

The phone number or address of the contact.

**Protocol:** Auto/H320/H323/SIP/Spark

Select protocol.

**CallRate:** Integer (0..6000)

Set a call rate.

**CallType:** Audio/Video

Select a call type (audio or video).



### xCommand Phonebook ContactMethod Delete

Delete a contact method from an existing contact in the local phonebook.

Requires user role: ADMIN, USER

#### USAGE:

xCommand Phonebook ContactMethod Delete ContactId: "ContactId" ContactMethodId: "ContactMethodId"  
where

**ContactId:** String (0, 255)

The unique identifier for the contact you want to change. The identifier will be returned by an xCommand Phonebook Search command. It was also returned when the xCommand Phonebook Contact Add command was issued to make the contact.

**ContactMethodId:** String (0, 255)

The unique identifier for the contact method you want to delete. The identifier will be returned by an xCommand Phonebook Search command. It was also returned when the xCommand Phonebook ContactMethod Add command was issued to make the contact method.

### xCommand Phonebook ContactMethod Modify

Modify details about the contact method for an existing contact in the local phonebook.

Requires user role: ADMIN, USER

#### USAGE:

xCommand Phonebook ContactMethod Modify ContactId: "ContactId" ContactMethodId: "ContactMethodId" [Device: Device] [Number: "Number"] [Protocol: Protocol] [CallRate: CallRate] [CallType: CallType]  
where

**ContactId:** String (0, 255)

The unique identifier for the contact. The identifier will be returned by an xCommand Phonebook Search command. It was also returned when the xCommand Phonebook Contact Add command was issued to make the contact.

**ContactMethodId:** String (0, 255)

The unique identifier for the contact method you want to modify. The identifier will be returned by an xCommand Phonebook Search command. It was also returned when the xCommand Phonebook ContactMethod Add or xCommand Phonebook Contact Add commands were issued to make the contact method.

**Device:** Mobile/Other/Telephone/Video

Set which type of device to call to.

**Number:** String (0, 255)

The phone number or address of the contact.

**Protocol:** Auto/H320/H323/SIP/Spark

Select protocol.

**CallRate:** Integer (0..6000)

Set a call rate.

**CallType:** Audio/Video

Select a call type (audio or video).

### xCommand Phonebook Folder Add

Phonebook entries can be stored in folders. Use this command to add a folder to the local phonebook. The command returns the FolderId, which is a unique string that identifies the folder; typically the format is "localGroupId-n".

Requires user role: ADMIN, USER

#### USAGE:

```
xCommand Phonebook Folder Add Name: "Name" [ParentFolderId: "ParentFolderId"]
where
```

**Name:** String (0, 255)

The name of the folder.

**ParentFolderId:** String (0, 255)

The unique identifier for the parent folder. The identifier will be returned by an xCommand Phonebook Search command. It was also returned when the xCommand Phonebook Folder Add command was issued to make the parent folder.

### xCommand Phonebook Folder Delete

Delete an existing folder from the local phonebook.

Requires user role: ADMIN, USER

#### USAGE:

```
xCommand Phonebook Folder Delete FolderId: "FolderId"
where
```

**FolderId:** String (0, 255)

The unique identifier for the folder. The identifier will be returned by an xCommand Phonebook Search command. It was also returned when the xCommand Phonebook Folder Add command was issued to make the folder.

### xCommand Phonebook Folder Modify

Modify an existing phonebook folder.

Requires user role: ADMIN, USER

#### USAGE:

```
xCommand Phonebook Folder Modify FolderId: "FolderId" [Name: "Name"]
[ParentFolderId: "ParentFolderId"]
where
```

**FolderId:** String (0, 255)

The unique identifier for the folder. The identifier will be returned by an xCommand Phonebook Search command. It was also returned when the xCommand Phonebook Folder Add command was issued to make the folder.

**Name:** String (0, 255)

The name of the contact.

**ParentFolderId:** String (0, 255)

The unique identifier for the parent folder. The identifier will be returned by an xCommand Phonebook Search command. It was also returned when the xCommand Phonebook Folder Add command was issued to make the parent folder.

## xCommand Phonebook Search

The search command lets you search in both the local and corporate phone books. A search gives a ResultSet.

The total number of folders and contacts (TotalRows) is always included in the result set when searching the local phone book. When searching a corporate phonebook the total number of folders and contacts may not be included. Whether it is included or not depends on the backend corporate phonebook service (e.g. CUCM, VCS, TMS) and its version.

Requires user role: ADMIN, USER

### USAGE:

```
xCommand Phonebook Search [PhonebookId: "PhonebookId"] [PhonebookType:
PhonebookType] [SearchString: "SearchString"] [SearchField: SearchField] [Offset:
Offset] [FolderId: "FolderId"] [Limit: Limit] [Recursive: Recursive] [ContactType:
ContactType] [Tag: Tag]
```

where

**PhonebookId:** String (0, 255)

The identifier of the phonebook server that will be searched. See the xConfiguration Phonebook Server ID setting.

**PhonebookType:** Corporate/Local

Define whether to search the local phone book or the corporate phonebook.

**SearchString:** String (0, 255)

Search for entries containing this string (note that the entry does not have to begin with the string). If no FolderId is specified, all folders / phonebook directories will be searched.

**SearchField:** Name/Number

Currently not in use.

**Offset:** Integer (0..65534)

Get records starting with this offset in a search. The default value is 0. Offset is used together with Limit to support paging.

**FolderId:** String (0, 255)

Search only in the specified folder. The FolderId (string) is listed in the ResultSet of a search result containing folders.

**Limit:** Integer (0..65534)

Limit the number of records in the result set to this number. For example, if the limit is

set to 10, the ResultSet will contain only 10 entries (Contacts and Folders) even if the total number of hits is larger. The maximum limit is 1000.

**Recursive:** False/True

This parameter will only have effect when searching the local phone book. The setting determines whether a local phone book search should be limited to the given FolderId, or also recursively search in its subfolders. If not specified, the search will be recursive.

When issuing the command without specifying any parameters, all folders, contacts and contact methods in the local phone book will be returned.

**ContactType:** Any/Folder/Contact

Search all contact types, or limit the search to folders or individual contacts.

**Tag:** Untagged/Favorite

Limits the search to either contacts that have been tagged as favorite or the untagged contacts.

## Presentation commands

### xCommand Presentation Start

Open a media stream from the selected presentation source.

Requires user role: ADMIN, USER

**USAGE:**

```
xCommand Presentation Start [PresentationSource: PresentationSource]
[SendingMode: SendingMode] [ConnectorId: ConnectorId] [Instance: Instance]
where
```

**PresentationSource:** Integer (2..3)

Select the video input source to be used for presentation, identified by source number.

**SendingMode:** LocalRemote/LocalOnly

Select whether the presentation is shown locally or locally and remotely.

**ConnectorId:** Integer (2..2)

Select the video input source to be used for presentation, identified by connectorId.

**Instance:** New/1/2/3/4/5/6

Select which local presentation instance you wish to start.

### xCommand Presentation Stop

Stop the media stream from the presentation source.

Requires user role: ADMIN, USER

**USAGE:**

```
xCommand Presentation Stop [Instance: Instance] [PresentationSource:
PresentationSource]
where
```

**Instance:** 1/2/3/4/5/6

Select which local presentation you wish to stop, identified by presentation instance.

**PresentationSource:** Integer (2..2)

Select which local presentation you wish to stop, identified by source number.

## Provisioning commands

### xCommand Provisioning CompleteUpgrade

Starts installing the software upgrade if you wish to install it before it is set to do so.

Requires user role: ADMIN, USER

**USAGE:**

```
xCommand Provisioning CompleteUpgrade
```

### xCommand Provisioning PostponeUpgrade

Postpones the installing of the software upgrade.

Requires user role: ADMIN, USER

**USAGE:**

```
xCommand Provisioning PostponeUpgrade SecondsToPostpone: SecondsToPostpone
where
```

**SecondsToPostpone:** Integer (0..65534)

Set how long to postpone the upgrade. The value is in seconds.

### xCommand Provisioning StartUpgrade

The codec software can be upgraded from the provisioning server. When starting the upgrade the software is automatically downloaded and installed. The codec reboots to complete the software upgrade.

Requires user role: ADMIN, USER

**USAGE:**

```
xCommand Provisioning StartUpgrade
```

## Proximity commands

### xCommand Proximity Services Activate

Reactivate the Proximity services that were deactivated with xCommand Proximity Services Deactivate.

Requires user role: ADMIN, USER

**USAGE:**

xCommand Proximity Services Activate

### xCommand Proximity Services Deactivate

This command deactivates all proximity services on the endpoint. To reactivate proximity services use the command xCommand Proximity Services Activate.

Requires user role: ADMIN, USER

**USAGE:**

xCommand Proximity Services Deactivate

## Security commands

### xCommand Security Persistency

Set the following features to persistent or non-persistent mode. In non-persistent mode the information gathered by the specified feature does not persist a reboot of the system. Persistent mode is the default. This command reboots the system.

Requires user role: ADMIN

**USAGE:**

xCommand Security Persistency Configurations: Configurations CallHistory: CallHistory InternalLogging: InternalLogging LocalPhonebook: LocalPhonebook DHCP: DHCP ConfirmAndReboot: ConfirmAndReboot

where

**Configurations:** NonPersistent/Persistent

In non-persistent mode, all configurations are set back to default when the system reboots.

**CallHistory:** NonPersistent/Persistent

In non-persistent mode call history is deleted when the system reboots.

**InternalLogging:** NonPersistent/Persistent

In non-persistent mode eventlog is deleted when the system reboots.

**LocalPhonebook:** NonPersistent/Persistent

In non-persistent mode local phone book is deleted when the system reboots.

**DHCP:** NonPersistent/Persistent

In non-persistent mode all IP related information is deleted when the system reboots.

**ConfirmAndReboot:** Yes

Reboots the system.

### xCommand Security Session List

List active sessions.

Requires user role: ADMIN, USER

**USAGE:**

`xCommand Security Session List`

### xCommand Security Session Terminate

Terminate a session.

Requires user role: ADMIN, USER

**USAGE:**

`xCommand Security Session Terminate [: ""]`  
 where

: String (0, 32)

The session ID number.

## Standby commands

### xCommand Standby Activate

Set the system in standby mode, which turns off the video outputs and put the camera into sleep mode.

Requires user role: ADMIN, USER

**USAGE:**

`xCommand Standby Activate`

### xCommand Standby Deactivate

Bring the system out of standby mode.

Requires user role: ADMIN, USER

**USAGE:**

`xCommand Standby Deactivate`

### xCommand Standby ResetTimer

Set a temporary standby delay. If the system is in standby mode when the reset timer is set, the system is brought out of standby mode. When left idle for the given delay the system goes into standby mode. Setting the reset timer does not affect the Standby Delay in the Advanced configuration menu (or by xConfiguration Standby Delay). Next time this delay is the valid standby delay.

Requires user role: ADMIN, USER

**USAGE:**

`xCommand Standby ResetTimer Delay: Delay`  
 where

**Delay:** Integer (1..480)

Set the delay in minutes.

## SystemUnit commands

### xCommand SystemUnit Boot

Reboot the system.

Requires user role: ADMIN, USER

**USAGE:**

`xCommand SystemUnit Boot [Action: Action]`

where

**Action:** Restart/Shutdown

As a default the system restarts after a reboot. By selecting Shutdown, the system will not restart.

### xCommand SystemUnit FactoryReset

Reset the codec to factory default settings. The call logs are deleted and all system parameters are reset to default values. All files that have been uploaded to the codec are deleted. Option key(s) are not affected.

As a default the system restarts after the factory reset, but other behaviour can be forced by selecting a different TrailingAction.

Requires user role: ADMIN, USER

**USAGE:**

`xCommand SystemUnit FactoryReset Confirm: Confirm [TrailingAction: TrailingAction]`

where

**Confirm:** Yes

**TrailingAction:** NoAction/Restart/Shutdown

Select Shutdown or NoAction to override the default behaviour (Restart).

### xCommand SystemUnit Notifications RemoveAll

Clears the list of system notifications that are reported by xStatus SystemUnit Notifications Text/Type.

Requires user role: ADMIN

**USAGE:**

`xCommand SystemUnit Notifications RemoveAll`

### xCommand SystemUnit OptionKey Add

Add an option key to support additional features.

Requires user role: ADMIN

**USAGE:**

`xCommand SystemUnit OptionKey Add Key: "Key"`

where

**Key:** String (16, 24)

The key you have received for the option you wish to switch on.

### xCommand SystemUnit OptionKey List

List all option keys.

Requires user role: ADMIN

**USAGE:**

`xCommand SystemUnit OptionKey List`

### xCommand SystemUnit OptionKey Remove

Remove a specified option key.

Requires user role: ADMIN

**USAGE:**

xCommand SystemUnit OptionKey Remove Type: Type  
where

**Type:** Encryption/RemoteMonitoring

### xCommand SystemUnit OptionKey RemoveAll

Remove all option keys.

Requires user role: ADMIN

**USAGE:**

xCommand SystemUnit OptionKey RemoveAll Confirm: Confirm  
where

**Confirm:** Yes

### xCommand SystemUnit SoftReset

Reset most parameters to their default values. This does not include parameters associated with room setup, such as camera position, language, and volume.

Requires user role: ADMIN

**USAGE:**

xCommand SystemUnit SoftReset Confirm: Confirm  
where

**Confirm:** Yes

### xCommand SystemUnit SoftwareUpgrade

Initiate a software upgrade by fetching the software from a given URL. If the server requires username and password these parameters must be included.

Requires user role: ADMIN

**USAGE:**

xCommand SystemUnit SoftwareUpgrade URL: "URL" [UserName: "UserName"] [Password: "Password"] [Forced: Forced]  
where

**URL:** String (0, 255)

The software package location

**UserName:** String (0, 255)

User name to access the server location, if needed.

**Password:** String (0, 255)

Password to access the server location, if needed.

**Forced:** False/True

You can force a system to accept a software upgrade immediately, without giving users a chance to acknowledge or postpone the update.



## Time commands

### xCommand Time DateTime Get

Read the time and date from the system.

Requires user role: ADMIN, USER

**USAGE:**

xCommand Time DateTime Get

### xCommand Time DateTime Set

Set the date and time for the system, if not available from NTP (Network Time Protocol).

Requires user role: ADMIN, USER

**USAGE:**

xCommand Time DateTime Set [Year: Year] [Month: Month] [Day: Day] [Hour: Hour] [Minute: Minute] [Second: Second]  
where

**Year:** Integer (2015..2037)

**Month:** Integer (1..12)

**Day:** Integer (1..31)

**Hour:** Integer (0..23)

**Minute:** Integer (0..59)

**Second:** Integer (0..59)

## UserInterface commands

### xCommand UserInterface Extensions Clear

Delete all user interface extensions (widgets) from the video system.

Requires user role: ADMIN

**USAGE:**

xCommand UserInterface Extensions Clear

### xCommand UserInterface Extensions List

List all user interface extensions (widgets) that exist on the video system.

Requires user role: ADMIN

**USAGE:**

xCommand UserInterface Extensions List

### xCommand UserInterface Message Alert Clear

Remove the message which was displayed using the xCommand Message Alert Display command. This is required when the Duration parameter is not set.

Requires user role: ADMIN, USER

**USAGE:**

xCommand UserInterface Message Alert Clear

### xCommand UserInterface Message Alert Display

Display a message on screen, for a specified duration of time (in seconds).

NOTE: If Duration is not set, the command must be followed by xCommand Message Alert Clear.

Use the xFeedback commands to monitor the feedback from the user. Read more about the xFeedback commands in the API introduction section in this guide.

Requires user role: ADMIN

#### USAGE:

```
xCommand UserInterface Message Alert Display [Title: "Title"] Text: "Text"
[Duration: Duration]
```

where

**Title:** String (0, 255)

Enter a message title.

**Text:** String (0, 255)

Enter the message to be displayed. The <p> and <br> HTML tags will result in line breaks as normal; any other tags will appear as plain text.

**Duration:** Integer (0..3600)

Set how long (in seconds) the message is to be displayed on the screen. If set to 0 (zero) the message does not disappear until a xCommand Message Alert Clear message has been sent.

### xCommand UserInterface Message Prompt Clear

Remove the window displayed using the xCommand Message Alert Display command.

Use the xFeedback commands to monitor the feedback from the user. Read more about the xFeedback commands in the API introduction section in this guide.

Requires user role: ADMIN, USER

#### USAGE:

```
xCommand UserInterface Message Prompt Clear [FeedbackId: "FeedbackId"]
where
```

**FeedbackId:** String (0, 255)

The FeedbackId corresponds to the FeedbackId given by the xCommand Message Prompt Display command.

### xCommand UserInterface Message Prompt Display

Display a small window on screen with a title, text and up to five options for response from the user. The message is displayed on screen until the user gives a response, or until the system receives the following command xCommand Message Prompt Clear.

Use the xFeedback commands to monitor the feedback from the user. Read more about the xFeedback commands in the API introduction section in this guide.

Title:

Text:

FeedbackId:

Option.1 to Option.5:

Requires user role: ADMIN

#### USAGE:

```
xCommand UserInterface Message Prompt Display [Title: "Title"] Text: "Text"
[FeedbackId: "FeedbackId"] [Option.1: "Option.1"] [Option.2: "Option.2"] [Option.3:
"Option.3"] [Option.4: "Option.4"] [Option.5: "Option.5"]
```

where

**Title:** String (0, 255)

Enter the message title.

**Text:** String (0, 255)

Enter the text line to be displayed. The <p> and <br> HTML tags will result in line breaks as normal; any other tags will appear as plain text.

**FeedbackId:** String (0, 255)

To identify the feedback enter a FeedbackId.

**Option.1:** String (0, 255)

Enter the text to appear on the feedback options.

**Option.2:** String (0, 255)

Enter the text to appear on the feedback options.

**Option.3:** String (0, 255)

Enter the text to appear on the feedback options.

**Option.4:** String (0, 255)

Enter the text to appear on the feedback options.

**Option.5:** String (0, 255)

Enter the text to appear on the feedback options.

**xCommand UserInterface Message Prompt Response**

Give a response to the xCommand Message Prompt Display.

Use the xFeedback commands to monitor the feedback from the user. Read more about the xFeedback commands in the API introduction section in this guide.

Requires user role: ADMIN, USER

**USAGE:**

xCommand UserInterface Message Prompt Response [FeedbackId: "FeedbackId"]  
OptionId: OptionId  
where

**FeedbackId:** String (0, 255)

The FeedbackId corresponds to the FeedbackId given by the xCommand Message Prompt Display command.

**OptionId:** Integer (1..5)

The OptionId corresponds to the OptionIds given as possible responses in the xCommand Message Prompt Display command.

**xCommand UserInterface Message TextLine Clear**

Clears the text line which was defined by the xCommand Message TextLine Display command.

Requires user role: ADMIN, USER

**USAGE:**

xCommand UserInterface Message TextLine Clear

**xCommand UserInterface Message TextLine Display**

Display a text line on screen. Optionally you can place the text line at a specified location and for a specified duration of time (in seconds).

NOTE: If Duration is not set, the command must be followed by xCommand Message TextLine Clear.

Requires user role: ADMIN

**USAGE:**

xCommand UserInterface Message TextLine Display Text: "Text" [X: X] [Y: Y]  
[Duration: Duration]  
where

**Text:** String (0, 140)

Enter the text line to be displayed. The <p> and <br> HTML tags will result in line breaks as normal; any other tags will appear as plain text.

**X:** Integer (1..10000)

Enter the X-coordinate (horizontal) on screen. X=0 is in the upper left corner.

**Y:** Integer (1..10000)

Enter the Y-coordinate (vertical) on screen. Y=0 is in the upper left corner.

**Duration:** Integer (0..3600)

Set how long (in seconds) the text line is to be displayed on the screen. If set to 0 (zero) the text line is displayed until a xCommand Message TextLine Clear command has been sent.

**xCommand UserInterface OSD Key Click**

Emulates a remote control key press, followed by a key release.

Requires user role: ADMIN

**USAGE:**

xCommand UserInterface OSD Key Click Key: Key  
where

**Key:** 0/1/2/3/4/5/6/7/8/9/C/Call/Disconnect/Down/F1/F2/F3/F4/F5/Grab/Home/Layout/Left/Mute/MuteMic/Ok/PhoneBook/Presentation/Right/Selfview/Square/SrcAux/SrcCamera/SrcDocCam/SrcPc/SrcVcr/Star/Up/VolumeDown/VolumeUp/ZoomIn/ZoomOut/+/-

Define the remote key to press.

### xCommand UserInterface OSD Key Press

Emulates a remote control key press without releasing it. The Key Press command must be followed

by a Key Release command to emulate releasing the key.

Requires user role: ADMIN

**USAGE:**

xCommand UserInterface OSD Key Press Key: Key  
where

**Key:** 0/1/2/3/4/5/6/7/8/9/C/Call/Disconnect/Down/F1/F2/F3/F4/F5/Grab/Home/Layout/Left/Mute/MuteMic/Ok/PhoneBook/Presentation/Right/Selfview/Square/SrcAux/SrcCamera/SrcDocCam/SrcPc/SrcVcr/Star/Up/VolumeDown/VolumeUp/ZoomIn/ZoomOut/+/-

Define the remote key to press.

### xCommand UserInterface OSD Key Release

Emulates a remote control key release. The Key Release command is issued after a Key Press command.

Requires user role: ADMIN

**USAGE:**

xCommand UserInterface OSD Key Release Key: Key  
where

**Key:** 0/1/2/3/4/5/6/7/8/9/C/Call/Disconnect/Down/F1/F2/F3/F4/F5/Grab/Home/Layout/Left/Mute/MuteMic/Ok/PhoneBook/Presentation/Right/Selfview/Square/SrcAux/SrcCamera/SrcDocCam/SrcPc/SrcVcr/Star/Up/VolumeDown/VolumeUp/ZoomIn/ZoomOut/+/-

Define the remote control key to release.

## UserManagement commands

### xCommand UserManagement RemoteSupportUser Create

Create a remote support user passphrase that Technical Assistance Center (TAC) can use to access the system for troubleshooting.

Requires user role: ADMIN

**USAGE:**

xCommand UserManagement RemoteSupportUser Create [ExpiryDays: ExpiryDays]  
where

**ExpiryDays:** Integer (1..31)

Define the duration for the passphrase validity. Default is 7 days.

### xCommand UserManagement RemoteSupportUser Delete

Delete the remote support user created with the command xCommand UserManagement RemoteSupportUser Create.

Requires user role: ADMIN

**USAGE:**

xCommand UserManagement RemoteSupportUser Delete

### xCommand UserManagement RemoteSupportUser DisablePermanently

Disable the creation of new remote support users. To enable the remote support user again you must factory reset your system.

Requires user role: ADMIN

**USAGE:**

xCommand UserManagement RemoteSupportUser DisablePermanently Confirm: Confirm  
where

**Confirm:** Yes

### xCommand UserManagement RemoteSupportUser GetState

Retrieves the state of the generated remote support user, if one exists.

Requires user role: ADMIN

#### USAGE:

```
xCommand UserManagement RemoteSupportUser GetState
```

### xCommand UserManagement User Passphrase Change

Change the passphrase for the user you logged in as. If you are logged in as the administrator, this will change the administrator passphrase.

Requires user role: ADMIN, USER

#### USAGE:

```
xCommand UserManagement User Passphrase Change NewPassphrase: "NewPassphrase"
OldPassphrase: "OldPassphrase"
where
```

**NewPassphrase:** String (0, 255)

**OldPassphrase:** String (0, 255)

### xCommand UserManagement User Passphrase Set

Set a user passphrase for the specified user. You must be logged in as an administrator to set a user passphrase.

Requires user role: ADMIN

#### USAGE:

```
xCommand UserManagement User Passphrase Set NewPassphrase: "NewPassphrase"
Username: "Username" YourPassphrase: "YourPassphrase"
where
```

**NewPassphrase:** String (0, 255)

**Username:** String (0, 127)

**YourPassphrase:** String (0, 255)

## Video commands

### xCommand Video ActiveSpeakerPIP Set

Sets position for the active speakers PiP (picture in picture).

Requires user role: ADMIN, USER

**USAGE:**

xCommand Video ActiveSpeakerPIP Set Position: Position  
where

**Position:** CenterLeft/CenterRight/LowerLeft/LowerRight/UpperCenter/UpperLeft/UpperRight  
Select one of the predefined positions.

### xCommand Video Input SetMainVideoSource

Set which input source is the main video source. You can identify the source either by the identifier of the connector that it is connected to; or by the identifier of the source itself.

This command requires the use of one, and only one, of these parameters: ConnectorId or SourceId.

Requires user role: ADMIN, USER

**USAGE:**

xCommand Video Input SetMainVideoSource [ConnectorId: ConnectorId] [SourceId: SourceId]  
where

**ConnectorId:** Integer (1..5)

The identifier (ID) of the connector. Connector [n] has ID n. Run the following API command to find the ID: xStatus Video Input Connector. The connector ID is also printed on the codec connector panel.

**SourceId:** Integer (1..4)

The identifier (ID) of the input source. Input Source [n] has ID n. Run the following API command to find the ID: xStatus Video Input Source.

### xCommand Video Input Source SetActiveConnector

Select which connector is active.

Requires user role: ADMIN, USER

**USAGE:**

xCommand Video Input Source SetActiveConnector [ConnectorId: ConnectorId]  
where

**ConnectorId:** Integer (2..4)

The identifier (ID) of the connector. Connector [n] has ID n. Run the following API command to find the ID: xStatus Video Input Connector. The connector ID is also printed on the codec connector panel.

### xCommand Video Layout LayoutFamily Set

Select the screen layout mode.

Requires user role: ADMIN, USER

**USAGE:**

xCommand Video Layout LayoutFamily Set [Target: Target] [: ] LayoutFamily: LayoutFamily [CustomLayoutName: "CustomLayoutName"]  
where

**Target:** local/remote

Select if the target is the local layout or the remote layout.

**:** Integer (0..65534)

The CallID is returned when the xCommand Dial command is run. During the call you can run the xStatus Call command to see the CallID.

**LayoutFamily:** auto/custom/equal/overlay/prominent/single

Select a layout family.

**CustomLayoutName:** String (1, 128)

Enter a name for the layout.

### xCommand Video PresentationPIP Set

Sets position for the presentation PiP (picture in picture).

Requires user role: ADMIN, USER

#### USAGE:

xCommand Video PresentationPIP Set Position: Position  
where

**Position:** CenterLeft/CenterRight/LowerLeft/LowerRight/UpperCenter/UpperLeft/UpperRight  
Select one of the predefined positions.

### xCommand Video PresentationView Set

Set the presentation view mode

Requires user role: ADMIN, USER

#### USAGE:

xCommand Video PresentationView Set View: View  
where

**View:** Default/Maximized/Minimized

Select Default when you want the presentation to be viewed with the default settings for the codec. Select Maximized when you want the presentation to be displayed in full screen. Select

Minimized when you want the presentation to be displayed in a small picture on screen.

### xCommand Video Selfview Set

Sets self-view on/off and specifies its size and position. If the parameter is not specified, current value is used.

Requires user role: ADMIN, USER

#### USAGE:

xCommand Video Selfview Set [Mode: Mode] [FullscreenMode: FullscreenMode]  
[PIPPosition: PIPPosition] [OnMonitorRole: OnMonitorRole]  
where

**Mode:** On/Off

Selfview is set to on or off.

**FullscreenMode:** On/Off

Choose between displaying the self-view in full screen or as picture-in-picture.

**PIPPosition:** CenterLeft/CenterRight/LowerLeft/LowerRight/UpperCenter/UpperLeft/UpperRight

Select the position for the self-view image.

**OnMonitorRole:** First/Fourth/Second/Third

Displays self-view on monitors with this role.





## Chapter 5

# xStatus commands

## Description of the xStatus commands

In this chapter, you can find all of the xStatus commands and the responses. Status type commands return information about the system and system processes. You can query all information or just some of it.

We recommend you visit our web site regularly for updated versions of the manual.

Go to: <http://www.cisco.com/go/dx-docs>

<b>Audio status</b> .....	<b>126</b>	xStatus Call [n] AttendedTransferFrom.....	130
xStatus Audio .....	126	xStatus Call [n] CallbackNumber .....	130
xStatus Audio Devices HandsetUSB Connection Status .....	126	xStatus Call [n] CallType .....	130
xStatus Audio Devices HandsetUSB Cradle .....	126	xStatus Call [n] DeviceType .....	130
xStatus Audio Devices HeadsetAnalog Connection Status.....	126	xStatus Call [n] Direction .....	130
xStatus Audio Devices HeadsetAnalog HasMicrophone .....	126	xStatus Call [n] DisplayName.....	131
xStatus Audio Devices HeadsetUSB Connection Status.....	126	xStatus Call [n] Duration .....	131
xStatus Audio Devices HeadsetUSB Description .....	126	xStatus Call [n] Encryption Type.....	131
xStatus Audio Devices HeadsetUSB Manufacturer .....	127	xStatus Call [n] FacilityServiceId .....	131
xStatus Audio Input Connectors HDMI [n] EcReferenceDelay .....	127	xStatus Call [n] HoldReason .....	131
xStatus Audio Input Connectors Microphone [n] EcReferenceDelay .....	127	xStatus Call [n] PlacedOnHold.....	131
xStatus Audio Input RemoteInput [n] CallId .....	127	xStatus Call [n] Protocol .....	132
xStatus Audio Microphones Mute .....	127	xStatus Call [n] ReceiveCallRate.....	132
xStatus Audio Output Connectors Line [n] DelayMs .....	127	xStatus Call [n] RemoteNumber .....	132
xStatus Audio SelectedDevice.....	128	xStatus Call [n] Status.....	132
xStatus Audio Volume .....	128	xStatus Call [n] TransmitCallRate.....	132
xStatus Audio VolumeHandsetUsb .....	128		
xStatus Audio VolumeHeadsetAnalog .....	128	<b>Cameras status</b> .....	<b>133</b>
xStatus Audio VolumeHeadsetUsb .....	128	xStatus Cameras Camera .....	133
xStatus Audio VolumeInternal .....	128	xStatus Cameras Camera [n] Capabilities Options .....	133
xStatus Audio VolumeMute .....	129	xStatus Cameras Camera [n] Connected.....	133
		xStatus Cameras Camera [n] MacAddress .....	133
<b>Bookings status</b> .....	<b>129</b>	xStatus Cameras Camera [n] Manufacturer .....	133
xStatus Bookings Current .....	129	xStatus Cameras Camera [n] Model.....	133
		xStatus Cameras Camera [n] SerialNumber.....	133
<b>Call status</b> .....	<b>130</b>	xStatus Cameras Camera [n] SoftwareID.....	134
xStatus Call [n].....	130		
xStatus Call [n] AnswerState .....	130		

<b>Capabilities status</b> .....	<b>134</b>	<b>Diagnostics status</b> .....	<b>140</b>
xStatus Capabilities .....	134	xStatus Diagnostics .....	140
xStatus Capabilities Conference MaxActiveCalls .....	134	xStatus Diagnostics Message [n] Description .....	140
xStatus Capabilities Conference MaxAudioCalls .....	134	xStatus Diagnostics Message [n] Level .....	140
xStatus Capabilities Conference MaxCalls .....	134	xStatus Diagnostics Message [n] References .....	140
xStatus Capabilities Conference MaxVideoCalls .....	135	xStatus Diagnostics Message [n] Type .....	140
<b>Conference status</b> .....	<b>135</b>	<b>H323 status</b> .....	<b>141</b>
xStatus Conference .....	135	xStatus H323 .....	141
xStatus Conference ActiveSpeaker CallId .....	135	xStatus H323 Gatekeeper Address .....	141
xStatus Conference Call [n] BookingId .....	135	xStatus H323 Gatekeeper Port .....	141
xStatus Conference Call [n] Capabilities FarendMessage Mode .....	135	xStatus H323 Gatekeeper Reason .....	141
xStatus Conference Call [n] Capabilities FECC Mode .....	136	xStatus H323 Gatekeeper Status .....	141
xStatus Conference Call [n] Capabilities FECC NumberOfPresets .....	136	xStatus H323 Mode Reason .....	141
xStatus Conference Call [n] Capabilities FECC NumberOfSources .....	136	xStatus H323 Mode Status .....	141
xStatus Conference Call [n] Capabilities FECC Source [n] Name .....	136	 	
xStatus Conference Call [n] Capabilities FECC Source [n] Options .....	136	<b>HttpFeedback status</b> .....	<b>142</b>
xStatus Conference Call [n] Capabilities FECC Source [n] SourceId .....	136	xStatus HttpFeedback .....	142
xStatus Conference Call [n] Capabilities Hold .....	137	xStatus HttpFeedback [1..4] Expression [1..15] .....	142
xStatus Conference Call [n] Capabilities IxChannel Status .....	137	xStatus HttpFeedback [1..4] URL .....	142
xStatus Conference Call [n] Capabilities Presentation .....	137	 	
xStatus Conference Call [n] Manufacturer .....	137	<b>Network status</b> .....	<b>142</b>
xStatus Conference Call [n] MicrophonesMuted .....	137	xStatus Network .....	142
xStatus Conference Call [n] SoftwareId .....	137	xStatus Network 1 CDP Address .....	142
xStatus Conference DoNotDisturb .....	138	xStatus Network 1 CDP Capabilities .....	142
xStatus Conference Line [n] Mode .....	138	xStatus Network 1 CDP DeviceId .....	142
xStatus Conference Multipoint Mode .....	138	xStatus Network 1 CDP Duplex .....	143
xStatus Conference Presentation CallId .....	138	xStatus Network 1 CDP Platform .....	143
xStatus Conference Presentation LocalInstance [n] SendingMode .....	139	xStatus Network 1 CDP PortId .....	143
xStatus Conference Presentation LocalInstance [n] Source .....	139	xStatus Network 1 CDP PrimaryMgmtAddress .....	143
xStatus Conference Presentation Mode .....	139	xStatus Network 1 CDP SysName .....	143
xStatus Conference SpeakerLock CallId .....	139	xStatus Network 1 CDP SysObjectId .....	143
xStatus Conference SpeakerLock Mode .....	139	xStatus Network 1 CDP Version .....	144
		xStatus Network 1 CDP VoIPApplianceVlanId .....	144
		xStatus Network 1 CDP VTPMgmtDomain .....	144

xStatus Network 1 DNS Domain Name.....	144	xStatus Provisioning Software UpgradeStatus SessionId .....	150
xStatus Network 1 DNS Server [1..5] Address.....	144	xStatus Provisioning Software UpgradeStatus Status.....	150
xStatus Network 1 Ethernet MacAddress.....	144	xStatus Provisioning Software UpgradeStatus URL .....	150
xStatus Network 1 Ethernet Speed.....	145	xStatus Provisioning Software UpgradeStatus VersionId.....	150
xStatus Network 1 IPv4 Address .....	145	xStatus Provisioning Status.....	150
xStatus Network 1 IPv4 Gateway.....	145	<b>Proximity status.....</b>	<b>151</b>
xStatus Network 1 IPv4 SubnetMask.....	145	xStatus Proximity.....	151
xStatus Network 1 IPv6 Address .....	145	xStatus Proximity Services Availability.....	151
xStatus Network 1 IPv6 Gateway.....	145	<b>Security status.....</b>	<b>151</b>
xStatus Network 1 VLAN Voice VlanId.....	146	xStatus Security .....	151
<b>NetworkServices status .....</b>	<b>146</b>	xStatus Security FIPS Mode.....	151
xStatus NetworkServices.....	146	xStatus Security Persistency CallHistory .....	151
xStatus NetworkServices NTP CurrentAddress .....	146	xStatus Security Persistency Configurations.....	151
xStatus NetworkServices NTP Server [n] Address.....	146	xStatus Security Persistency DHCP.....	152
xStatus NetworkServices NTP Status.....	147	xStatus Security Persistency InternalLogging.....	152
<b>Peripherals status.....</b>	<b>147</b>	xStatus Security Persistency LocalPhonebook .....	152
xStatus Peripherals .....	147	<b>SIP status .....</b>	<b>152</b>
xStatus Peripherals ConnectedDevice [n] HardwareInfo .....	147	xStatus SIP .....	152
xStatus Peripherals ConnectedDevice [n] ID .....	147	xStatus SIP AlternateURI Alias [n] URI.....	152
xStatus Peripherals ConnectedDevice [n] Name .....	147	xStatus SIP AlternateURI Primary [n] URI .....	152
xStatus Peripherals ConnectedDevice [n] SoftwareInfo .....	148	xStatus SIP Authentication.....	152
xStatus Peripherals ConnectedDevice [n] Status.....	148	xStatus SIP CallForward DisplayName.....	153
xStatus Peripherals ConnectedDevice [n] Type .....	148	xStatus SIP CallForward Mode .....	153
xStatus Peripherals ConnectedDevice [n] UpgradeStatus .....	148	xStatus SIP CallForward URI.....	153
<b>Provisioning status .....</b>	<b>149</b>	xStatus SIP Mailbox MessagesWaiting .....	153
xStatus Provisioning.....	149	xStatus SIP Mailbox URI .....	153
xStatus Provisioning Software Current CompletedAt.....	149	xStatus SIP Proxy [n] Address.....	153
xStatus Provisioning Software Current URL .....	149	xStatus SIP Proxy [n] Status .....	154
xStatus Provisioning Software Current VersionId .....	149	xStatus SIP Registration [n] Authentication .....	154
xStatus Provisioning Software UpgradeStatus LastChange.....	149	xStatus SIP Registration [n] Reason .....	154
xStatus Provisioning Software UpgradeStatus Message .....	149	xStatus SIP Registration [n] Status .....	154
xStatus Provisioning Software UpgradeStatus Phase.....	149	xStatus SIP Registration [n] URI.....	154



xStatus SIP Secure..... 155

xStatus SIP Verified..... 155

**Standby status..... 155**

xStatus Standby ..... 155

xStatus Standby State..... 155

**SystemUnit status..... 156**

xStatus SystemUnit ..... 156

xStatus SystemUnit Hardware Module CompatibilityLevel..... 156

xStatus SystemUnit Hardware Module SerialNumber ..... 156

xStatus SystemUnit Hardware Monitoring Fan [n] Status..... 156

xStatus SystemUnit Hardware Temperature ..... 156

xStatus SystemUnit Notifications Notification [n] Text ..... 156

xStatus SystemUnit Notifications Notification [n] Type ..... 157

xStatus SystemUnit ProductId ..... 157

xStatus SystemUnit ProductPlatform..... 157

xStatus SystemUnit ProductType..... 157

xStatus SystemUnit Software DisplayName ..... 157

xStatus SystemUnit Software Name..... 158

xStatus SystemUnit Software OptionKeys RemoteMonitoring ..... 158

xStatus SystemUnit Software ReleaseDate ..... 158

xStatus SystemUnit Software Version ..... 158

xStatus SystemUnit State NumberOfActiveCalls ..... 158

xStatus SystemUnit State NumberOfInProgressCalls ..... 158

xStatus SystemUnit State NumberOfSuspendedCalls ..... 159

xStatus SystemUnit Uptime ..... 159

**Time status ..... 159**

xStatus Time..... 159

xStatus Time SystemTime..... 159

**UserInterface status ..... 160**

xStatus UserInterface..... 160

xStatus UserInterface ContactInfo ContactMethod [n] Number ..... 160

xStatus UserInterface ContactInfo Name ..... 160

**Video status..... 160**

xStatus Video ..... 160

xStatus Video ActiveSpeaker PIPPosition..... 160

xStatus Video Input ..... 160

xStatus Video Input Connector [n] Connected..... 160

xStatus Video Input Connector [n] SignalState ..... 161

xStatus Video Input Connector [n] SourceId ..... 161

xStatus Video Input Connector [n] Type..... 161

xStatus Video Input MainVideoSource..... 161

xStatus Video Input Source [n] ConnectorId ..... 161

xStatus Video Input Source [n] FormatStatus ..... 161

xStatus Video Input Source [n] FormatType ..... 162

xStatus Video Input Source [n] MediaChannelId..... 162

xStatus Video Input Source [n] Resolution Height..... 162

xStatus Video Input Source [n] Resolution RefreshRate ..... 162

xStatus Video Input Source [n] Resolution Width..... 162

xStatus Video Layout LayoutFamily Local..... 162

xStatus Video Layout LayoutFamily Remote ..... 163

xStatus Video Monitors ..... 163

xStatus Video Output ..... 163

xStatus Video Output Connector [n] Connected..... 163

xStatus Video Output Connector [n] ConnectedDevice CEC DeviceType..... 163

xStatus Video Output Connector [n] ConnectedDevice CEC PowerControl ..... 164

xStatus Video Output Connector [n] ConnectedDevice CEC PowerStatus..... 164

xStatus Video Output Connector [n] ConnectedDevice Name ..... 164

xStatus Video Output Connector [n] ConnectedDevice PreferredFormat ..... 164

xStatus Video Output Connector [n] MonitorRole..... 164

xStatus Video Output Connector [n] Resolution Height ..... 164

xStatus Video Output Connector [n] Resolution RefreshRate..... 165

xStatus Video Output Connector [n] Resolution Width ..... 165

xStatus Video Output Connector [n] Type..... 165

xStatus Video Presentation PIPPosition..... 165

xStatus Video Selfview FullscreenMode..... 165

xStatus Video Selfview Mode ..... 165

xStatus Video Selfview OnMonitorRole ..... 166

xStatus Video Selfview PIPPosition ..... 166

## Audio status

### xStatus Audio

Shows the top level overview of the audio status. The identities of the LocalInput, RemoteInput, LocalOutput and RemoteOutput are used when querying additional information.

### xStatus Audio Devices HandsetUSB Connection Status

Shows if a USB handset is connected.

**Value space of the result returned:**

Connected/NotConnected

**Example:**

```
xStatus Audio Devices HandsetUSB Connection Status
*s Connected
** end
```

### xStatus Audio Devices HandsetUSB Cradle

Shows if a USB handset is on hook or off hook.

**Value space of the result returned:**

OnHook/OffHook

**Example:**

```
xStatus Audio Devices HandsetUSB Cradle
*s OnHook
** end
```

### xStatus Audio Devices HeadsetAnalog Connection Status

Shows if an analog headset is connected. (DX70 only)

**Value space of the result returned:**

Connected/NotConnected

**Example:**

```
xStatus Audio Devices HeadsetAnalog Connection Status
*s Connected
** end
```

### xStatus Audio Devices HeadsetAnalog HasMicrophone

Shows if an analog headset has a built-in microphone. (DX70 only)

**Value space of the result returned:**

False/True

**Example:**

```
xStatus Audio Devices HeadsetAnalog HasMicrophone
*s True
** end
```

### xStatus Audio Devices HeadsetUSB Connection Status

Shows if a USB headset is connected.

**Value space of the result returned:**

Connected/NotConnected

**Example:**

```
xStatus Audio Devices HeadsetUSB Connection Status
*s Connected
** end
```

### xStatus Audio Devices HeadsetUSB Description

Shows a description of the attached USB headset.

**Value space of the result returned:**

String

**Example:**

```
xStatus Audio Devices HeadsetUSB Description
*s HeadsetUSB Description: "Description of USB headset."
** end
```

### xStatus Audio Devices HeadsetUSB Manufacturer

Lists the USB headset manufacturer.

**Value space of the result returned:**

String

**Example:**

```
xStatus Audio Devices HeadsetUSB Manufacturer
*s HeadsetUSB Manufacturer: "CompanyName"
** end
```

### xStatus Audio Input Connectors HDMI [n] EcReferenceDelay

Returns the detected latency for each loudspeaker to microphone path for systems supporting HDMI input used as microphone input. The result is in milliseconds.

**Value space of the result returned:**

Integer

**Example:**

```
xStatus Audio Input Connectors HDMI 1 EcReferenceDelay
*s Audio Connectors HDMI 1 EcReferenceDelay: 0
** end
```

### xStatus Audio Input Connectors Microphone [n] EcReferenceDelay

Returns the detected latency for each loudspeaker to microphone path. The result is in milliseconds.

**Value space of the result returned:**

Integer

**Example:**

```
xStatus Audio Input Connectors Microphone 1 EcReferenceDelay
*s Audio Connectors Microphone 1 EcReferenceDelay: 120
** end
```

### xStatus Audio Input RemoteInput [n] CallId

Shows the CallId for the remote audio input.

You can run the command xStatus Audio Input RemoteInput to find the identity [n] of the input.

**Value space of the result returned:**

0..65534

**Example:**

```
xStatus Audio Input RemoteInput 8 CallId
*s Audio Input RemoteInput 8 CallId: 28
** end
```

### xStatus Audio Microphones Mute

Shows whether the microphones are muted.

**Value space of the result returned:**

On/Off

**Example:**

```
xStatus Audio Microphones Mute
*s Audio Microphones Mute: Off
** end
```

### xStatus Audio Output Connectors Line [n] DelayMs

Shows the delay in milliseconds.

**Value space of the result returned:**

Integer (0..290)

**Example:**

```
xStatus Audio Output Connectors Line 1
*s Audio Output Connectors Line 1 DelayMs: 60
** end
```

### xStatus Audio SelectedDevice

Shows the audio device that is selected. Only the DX70 supports analog headsets.

**Value space of the result returned:**

Internal/HeadsetUSB/HeadsetAnalog/HandsetUSB

**Example:**

```
xStatus Audio SelectedDevice
*s HeadsetUSB
** end
```

### xStatus Audio Volume

Shows the volume level (dB) of the loudspeaker output.

**Value space of the result returned:**

0..100

**Example:**

```
xStatus Audio Volume
*s Audio Volume: 70
** end
```

### xStatus Audio VolumeHandsetUsb

Shows the volume level of the USB headset.

**Value space of the result returned:**

Integer

**Example:**

```
xStatus Audio VolumeHandsetUsb
*s 6
** end
```

### xStatus Audio VolumeHeadsetAnalog

Shows the volume level of the analog headset (DX70 only).

**Value space of the result returned:**

Integer

**Example:**

```
xStatus Audio VolumeHeadsetAnalog
*s 6
** end
```

### xStatus Audio VolumeHeadsetUsb

Shows the volume level of the USB headset.

**Value space of the result returned:**

Integer

**Example:**

```
xStatus Audio VolumeHeadsetUsb
*s 6
** end
```

### xStatus Audio VolumeInternal

Shows the internal volume level.

**Value space of the result returned:**

Integer

**Example:**

```
xStatus Audio VolumeInternal
*s 6
** end
```



### xStatus Audio VolumeMute

Shows whether the endpoint volume is set to mute.

**Value space of the result returned:**

Off/On

**Example:**

```
xStatus Audio VolumeMute
*s Audio VolumeMute: Off
** end
```

## Bookings status

### xStatus Bookings Current

The ID of the on going booking event, if any.

**Value space of the result returned:**

String

**Example:**

```
xStatus Bookings Current Id
*s Bookings Current Id: "123"
** end
```

## Call status

### xStatus Call [n]

Shows the top level overview of the call status. The call identity is used when query for additional information about the call.

### xStatus Call [n] AnswerState

Indicates if a call is answered, ignored or has been automatically answered by a system.

**Value space of the result returned:**

Unanswered/Ignored/Autoanswered/Answered

**Example:**

```
xStatus Call AnswerState
*s Call 5 AnswerState: Answered
** end
```

### xStatus Call [n] AttendedTransferFrom

Shows the CallId for the call the current call was transferred from.

**Value space of the result returned:**

Integer

**Example:**

```
xStatus Call 1 AttendedTransferFrom
*s Call 1 AttendedTransferFrom: 1234
** end
```

### xStatus Call [n] CallbackNumber

Shows the remote (far end) number or URI of an incoming or outgoing call, including the call protocol, for call back. You can run the command xStatus Call to find the call identity.

**Value space of the result returned:**

String

**Example:**

```
xStatus Call 27 CallbackNumber
*s Call 27 CallbackNumber: "h323:firstname.lastname@company.com"
** end
```

### xStatus Call [n] CallType

Shows the call type of the incoming or outgoing call. You can run the command xStatus Call to find the call identity.

**Value space of the result returned:**

Video/Audio/AudioCanEscalate/ForwardAllCall/Unknown

**Example:**

```
xStatus Call 27 CallType
*s Call 27 CallType: Video
** end
```

### xStatus Call [n] DeviceType

Indicates whether the remote system is a single endpoint or an MCU. Some Cisco endpoints (SX20, SX80, MX200 G2, MX300 G2) have built-in MCU capabilities.

**Value space of the result returned:**

Endpoint/MCU

**Example:**

```
xStatus Call DeviceType
*s Call 4 DeviceType: Endpoint
** end
```

### xStatus Call [n] Direction

States the direction of the call initiation. You can run the command xStatus Call to find the call identity.

**Value space of the result returned:**

Incoming/Outgoing

**Example:**

```
xStatus Call 27 Direction
*s Call 27 Direction: Outgoing
** end
```

### xStatus Call [n] DisplayName

Shows the name of the remote (far end) participant in an incoming or outgoing call. You can run the command xStatus Call to find the call identity.

**Value space of the result returned:**

String

**Example:**

```
xStatus Call 27 DisplayName
*s Call 27 DisplayName: "firstname.lastname@company.com"
** end
```

### xStatus Call [n] Duration

Shows the duration of a call (in seconds). You can run the command xStatus Call to find the call identity.

**Value space of the result returned:**

Integer

**Example:**

```
xStatus Call 27 Duration
*s Call 27 Duration: 2354
** end
```

### xStatus Call [n] Encryption Type

Shows the encryption type of the call. You can run the command xStatus Call to find the call identity.

**Value space of the result returned:**

None/Aes-128

**Example:**

```
xStatus Call 27 Encryption Type
*s Call 27 Encryption Type: "None"
** end
```

### xStatus Call [n] FacilityServiceId

When calling a facility service, the facility service id is shown. Otherwise the value 0 is returned.

**Value space of the result returned:**

0..5

**Example:**

```
xStatus Call FacilityServiceId
*s Call 3 FacilityServiceId: 1
** end
```

### xStatus Call [n] HoldReason

Shows the reason the current outgoing call was put on hold.  
 Conference: On hold while the call is being merged into a conference.  
 Transfer: On hold while the call is being transferred.  
 None: All other instances.

**Value space of the result returned:**

Conference/Transfer/None

**Example:**

```
xStatus Call 2 HoldReason
*s Call 2 HoldReason: None
** end
```

### xStatus Call [n] PlacedOnHold

Shows the placed on hold status of the call. You can run the command xStatus Call to find the call identity.

**Value space of the result returned:**

True/False

**Example:**

```
xStatus Call 27 PlacedOnHold
*s Call 27 PlacedOnHold: False
** end
```

### xStatus Call [n] Protocol

Shows the call protocol of the incoming or outgoing call. You can run the command xStatus Call to find the call identity.

**Value space of the result returned:**

H320/H323/SIP/Spark/Unknown

**Example:**

```
xStatus Call 27 Protocol
*s Call 27 Protocol: "h323"
** end
```

### xStatus Call [n] ReceiveCallRate

Shows the receive bandwidth in the call in kilobits per second (kbps). You can run the command xStatus Call to find the call identity.

**Value space of the result returned:**

Integer

**Example:**

```
xStatus Call 27 ReceiveCallRate
*s Call 27 ReceiveCallRate: 4000
** end
```

### xStatus Call [n] RemoteNumber

Shows the remote (far end) number or URI of an incoming or outgoing call. You can run the command xStatus Call to find the call identity.

**Value space of the result returned:**

String

**Example:**

```
xStatus Call 27 RemoteNumber
*s Call 27 RemoteNumber: "5585232"
** end
```

### xStatus Call [n] Status

Shows the status of a call. You can run the command xStatus Call to find the call identity.

**Value space of the result returned:**

Idle/Dialling/Ringing/Connecting/Connected/Disconnecting/OnHold/EarlyMedia/Preserved/RemotePreserved

**Example:**

```
xStatus Call 27 Status
*s Call 27 Status: Connected
** end
```

### xStatus Call [n] TransmitCallRate

Shows the transmit bandwidth in the call in kilobits per second (kbps). You can run the command xStatus Call to find the call identity.

**Value space of the result returned:**

Integer

**Example:**

```
xStatus Call 27 TransmitCallRate
*s Call 27 TransmitCallRate: 768
** end
```

## Cameras status

### xStatus Cameras Camera

Shows the top level overview of the camera status.

### xStatus Cameras Camera [n] Capabilities Options

Shows the camera capabilities (ptzf = pan, tilt, zoom, focus).

**Value space of the result returned:**

String

**Example:**

```
xStatus Cameras Camera 1 Capabilities Options
*s Camera 1 Capabilities Options: "ptzf"
** end
```

### xStatus Cameras Camera [n] Connected

Shows if the camera is connected or not.

**Value space of the result returned:**

True/False

**Example:**

```
xStatus Cameras Camera 1 Connected
*s Camera 1 Connected: True
** end
```

### xStatus Cameras Camera [n] MacAddress

Shows the MAC (Media Access Control) address for the camera.

**Value space of the result returned:**

String

**Example:**

```
xStatus Cameras Camera 1 MacAddress
*s Camera 1 MacAddress: ""
** end
```

### xStatus Cameras Camera [n] Manufacturer

Shows the manufacturer of the camera.

**Value space of the result returned:**

String

**Example:**

```
xStatus Cameras Camera 1 Manufacturer
*s Camera 1 Manufacturer: "Cisco"
** end
```

### xStatus Cameras Camera [n] Model

Shows the camera model.

**Value space of the result returned:**

String

**Example:**

```
xStatus Cameras Camera 1 Model
*s Camera 1 Model: "Precision 40"
** end
```

### xStatus Cameras Camera [n] SerialNumber

Shows the camera serial number.

**Value space of the result returned:**

String

**Example:**

```
xStatus Cameras Camera 1 SerialNumber
*s Camera 1 SerialNumber: "B1AB26B00010"
** end
```

### xStatus Cameras Camera [n] SoftwareID

Shows the software identity of the camera.

**Value space of the result returned:**

String

**Example:**

```
xStatus Cameras Camera 1 SoftwareID
*s Camera 1 SoftwareID: "S01718-4.0FINAL [ID:40063] 2014-10-20"
** end
```

## Capabilities status

### xStatus Capabilities

Shows the top level overview of the capabilities status.

### xStatus Capabilities Conference MaxActiveCalls

Shows the the maximum number of simultaneous active calls. Calls that are set on hold/transfer are not counted as active.

**Value space of the result returned:**

0..5

**Example:**

```
xStatus Capabilities Conference MaxNumberOfActiveCalls
*s Capabilities Conference MaxNumberOfActiveCalls: 3
** end
```

### xStatus Capabilities Conference MaxAudioCalls

Shows the the maximum number of simultaneous audio calls that is supported.

**Value space of the result returned:**

Integer

**Example:**

```
xStatus Capabilities Conference MaxAudioCalls
*s Capabilities Conference MaxAudioCalls: 3
** end
```

### xStatus Capabilities Conference MaxCalls

Shows the the maximum number of simultaneous calls.

**Value space of the result returned:**

0..5

**Example:**

```
xStatus Capabilities Conference MaxCalls
*s Capabilities Conference MaxCalls: 3
** end
```

### xStatus Capabilities Conference MaxVideoCalls

Shows the the maximum number of simultaneous video calls that is supported.

**Value space of the result returned:**

Integer

**Example:**

```
xStatus Capabilities Conference MaxVideoCalls
*s Capabilities Conference MaxVideoCalls: 3
** end
```

## Conference status

### xStatus Conference

Shows the top level overview of the conference status. The identity of the Conference Call can only be read during a call.

### xStatus Conference ActiveSpeaker CallId

Shows the CallId of the current active speaker.

**Value space of the result returned:**

Integer

**Example:**

```
xStatus Conference ActiveSpeaker CallId
*s Conference ActiveSpeaker CallId: 3
** end
```

### xStatus Conference Call [n] BookingId

Shows the booking ID of a conference (if assigned). The booking ID can be used for easy identification of a call or conference.

**Value space of the result returned:**

String

**Example:**

```
xStatus Conference Call 2 BookingId
*s Conference Call 2 BookingId: "MyConference"
** end
```

### xStatus Conference Call [n] Capabilities FarendMessage Mode

Not applicable in this release.

**Value space of the result returned:**

On/Off

**Example:**

```
xStatus Conference Call Capabilities FarendMessage Mode
*s Conference Call 4 Capabilities FarendMessage Mode: Off
** end
```

### xStatus Conference Call [n] Capabilities FECC Mode

Shows whether or not you have permission to control the input sources at a far end site.

On: Far end input source control is permitted.

Off: Far end input source control is not permitted.

**Value space of the result returned:**

On/Off

**Example:**

```
xStatus Conference Call 2 Capabilities FECC Mode
*s Conference Call 2 Capabilities FECC Mode: On
** end
```

### xStatus Conference Call [n] Capabilities FECC NumberOfPresets

Shows the number of presets available for the input sources at a far end site.

**Value space of the result returned:**

1..15

**Example:**

```
xStatus Conference Call 2 Capabilities FECC NumberOfPresets
*s Conference Call 2 Capabilities FECC NumberOfPresets: 15
** end
```

### xStatus Conference Call [n] Capabilities FECC NumberOfSources

Shows the number of input sources that can be connected at a far end site.

**Value space of the result returned:**

1..5

**Example:**

```
xStatus Conference Call 2 Capabilities FECC NumberOfSources
*s Conference Call 2 Capabilities FECC NumberOfSources: 5
** end
```

### xStatus Conference Call [n] Capabilities FECC Source [n] Name

Shows the name of an input source that can be connected at a far end site.

**Value space of the result returned:**

String

**Example:**

```
xStatus Conference Call 2 Capabilities FECC Source 1 Name
*s Conference Call 2 Capabilities FECC Source 1 Name: "Main camera"
** end
```

### xStatus Conference Call [n] Capabilities FECC Source [n] Options

Shows available options for an input source that can be connected at a far end site (for a camera: p=pan; t=tilt; z=zoom; f=focus).

**Value space of the result returned:**

String

**Example:**

```
xStatus Conference Call 2 Capabilities FECC Source 1 Options
*s Conference Call 2 Capabilities FECC Source 1 Options: "ptzf"
** end
```

### xStatus Conference Call [n] Capabilities FECC Source [n] SourceId

Shows the ID of an input source that can be connected at a far end site.

**Value space of the result returned:**

Integer

**Example:**

```
xStatus Conference Call 2 Capabilities FECC Source 1 SourceId
*s Conference Call 2 Capabilities FECC Source 1 SourceId: 6
** end
```



### xStatus Conference Call [n] Capabilities Hold

Indicates whether the far-end site can be placed on hold or not.

**Value space of the result returned:**

True/False

**Example:**

```
xStatus Conference Call Capabilities Hold
*s Conference Call 2 Capabilities Hold: True
** end
```

### xStatus Conference Call [n] Capabilities IxChannel Status

Not applicable in this release.

**Value space of the result returned:**

Active/Failed/Off

**Example:**

```
xStatus Conference Call 4 Capabilities IxChannel Status
*s Conference Call 4 Capabilities IxChannel Status: Active
** end
```

### xStatus Conference Call [n] Capabilities Presentation

Lists the presentation capabilities for other participants in the conference.

**Value space of the result returned:**

True/False

**Example:**

```
xStatus Conference Call 2 Capabilities Presentation
*s Conference Call 2 Capabilities Presentation: True
** end
```

### xStatus Conference Call [n] Manufacturer

Shows the manufacturer of the video system at a far end site.

**Value space of the result returned:**

String

**Example:**

```
xStatus Conference Call 2 Manufacturer
*s Conference Call 2 Manufacturer: "Cisco"
** end
```

### xStatus Conference Call [n] MicrophonesMuted

Lists the audio mute status for other participants in the conference.

**Value space of the result returned:**

True/False

**Example:**

```
xStatus Conference Call 2 MicrophonesMuted
*s Conference Call 2 MicrophonesMuted: True
** end
```

### xStatus Conference Call [n] SoftwareID

Shows the ID of the software running of the video system at a far end site.

**Value space of the result returned:**

String

**Example:**

```
xStatus Conference Call 2 SoftwareID
*s Conference Call 2 SoftwareID: "CE8"
** end
```

### xStatus Conference DoNotDisturb

Shows whether DoNotDisturb mode is switched on or not.

**Value space of the result returned:**

Active/Inactive

**Example:**

```
xStatus Conference DoNotDisturb
*s Conference DoNotDisturb: Inactive
** end
```

### xStatus Conference Line [n] Mode

Indicates whether the system is configured as private or shared line on CUCM.

**Value space of the result returned:**

Shared/Private

**Example:**

```
xStatus Conference Line Mode
*s Conference Line 1 Mode: Private
** end
```

### xStatus Conference Multipoint Mode

Shows how the Multipoint video conferences are handled.

Auto: The multipoint method available will be chosen automatically; if none are available the Multipoint Mode will automatically be set to Off. If both MultiWay and MultiSite are available, the MultiWay service takes priority over the built-in MultiSite.

Off: Multiparty conferences are not allowed.

MultiSite: Multiparty conferences are set up using the built-in MultiSite feature. If MultiSite is chosen when the MultiSite feature is not available, the Multipoint Mode will automatically be set to Off.

CUCMMediaResourceGroupList: Multiparty conferences (ad hoc conferences) are hosted by the CUCM configured conference bridge. This setting is provisioned by CUCM in a CUCM environment and should never be set manually by the user.

**Value space of the result returned:**

Auto/CUCMMediaResourceGroupList/MultiSite/Off

**Example:**

```
xStatus Conference Multipoint Mode
*s Conference Multipoint Mode: "Auto"
** end
```

### xStatus Conference Presentation CallId

Shows the identity of the system that sends the presentation.

**Value space of the result returned:**

Integer

**Example:**

```
xStatus Conference Presentation CallId
*s Conference Presentation CallId: 0
** end
```

### xStatus Conference Presentation LocalInstance [n] SendingMode

Shows whether a presentation source is shared locally or with a remote participant. There can be multiple local presentations which all have their own instance.

**Value space of the result returned:**

LocalOnly/LocalRemote/Off

**Example:**

```
xStatus Conference Presentation LocalInstance 1 SendingMode
*s Conference Presentation LocalInstance 1 SendingMode: LocalOnly
** end
```

### xStatus Conference Presentation LocalInstance [n] Source

Shows the SourceId for a current presentation. There can be multiple local presentations which all have their own instance.

**Value space of the result returned:**

Integer

**Example:**

```
xStatus Conference Presentation LocalInstance 1 Source
*s Conference Presentation LocalInstance 1 Source: 1
** end
```

### xStatus Conference Presentation Mode

Shows the status of the secondary video stream.

**Value space of the result returned:**

On/Off

**Example:**

```
xStatus Conference Presentation Mode
*s Conference Presentation Mode: Off
** end
```

### xStatus Conference SpeakerLock CallId

Shows the CallId for the participant locked as the prominent speaker in the conference.

**Value space of the result returned:**

Integer

**Example:**

```
xStatus Conference SpeakerLock CallId
*s Conference SpeakerLock CallId: 0
** end
```

### xStatus Conference SpeakerLock Mode

Shows whether a speaker lock is set or not.

**Value space of the result returned:**

On/Off

**Example:**

```
xStatus Conference SpeakerLock Mode
*s Conference SpeakerLock Mode: Off
** end
```

## Diagnostics status

### xStatus Diagnostics

Shows the top level overview of the diagnostics. The example shows the status for an ongoing call. The identities of the call and channels are used when querying additional information.

### xStatus Diagnostics Message [n] Description

A description of the current diagnostics alerts.

#### Value space of the result returned:

String

#### Example:

```
xStatus Diagnostics Message Description
*s DiagnosticsResult Message 1 Description: "IP configuration incomplete"
** end
```

### xStatus Diagnostics Message [n] Level

Returns information on the level of the diagnostics message.

Error: There is an error in the system. The system can still be used, but there can be some restrictions.

Warning: A problem is detected and a more specific report follows indicating the exact problem.

Critical: The warning level is critical. The system cannot be used.

#### Value space of the result returned:

Error/Warning/Critical

#### Example:

```
xStatus Diagnostics Message 4 Level
*s Diagnostics Message 4 Level: Warning
** end
```

### xStatus Diagnostics Message [n] References

Additional information on the diagnostics alert, if available.

#### Value space of the result returned:

String

#### Example:

```
xStatus Diagnostics Message 10 References
*s Diagnostics Message 10 References: "delay=190"
** end
```

### xStatus Diagnostics Message [n] Type

Returns information on the results of the latest diagnostics on the system.

#### Value space of the result returned:

CAPFOperationState/CTLInstallation/CUCMVendorConfigurationFile/CallProtocolDualStackConfig/CallProtocolIPStackPlatformCompatibility/CallProtocolVcsProvisioningCompatibility/CameraId/CameraPairing/CameraSerial/CameraSoftwareVersion/CameraStatus/CamerasDetected/ConfigurationFile/DefaultCallProtocolRegistered/EthernetDuplexMatches/FanStatus/PresenterTrack/H320GatewayStatus/H323GatekeeperStatus/HasValidReleaseKey/IpCameraStatus/IPv4Assignment/IPv6Assignment/IPv6Mtu/ISDNLinkCompatibility/ISDNLinkIpStack/ITLInstallation/InvalidSIPTransportConfig/LockDown/RoomControl/MediaBlockingDetected/NetLinkStatus/NetSpeedAutoNegotiated/NetworkQuality/NTPStatus/OSDVideoOutput/OutputConnectorLocations/ProvisioningStatus/SIPEncryption/SIPListenPortAndOutboundMode/SIPProfileRegistration/SIPProfileType/SelectedVideoInputSourceConnected/SipIcpeAndAnatConflict/TCPMediaFallback/TemperatureCheck/TLSVerifyRequiredCerts/TouchPanelConnection/TurnBandwidth/UdpPortRangeViolation/UltrasoundSpeakerAvailability/ValidPasswords/VideoFromInternalCamera/VideoInputStability/SparkSoftwareCompatibility/SparkConnectivity/SpeakerTrackFrontPanelMountedCorrectly/SpeakerTrackMicrophoneConnection/SpeakerTrackVideoInputs/SpeakerTrackEthernetConnection/ANATOnVCS/ECReferenceDelay/AudioPairingNoise/AudioPairingRate/AudioPairingSNR/AudioPairingInterference/AudioPairingTokenDecode/AudioInternalSpeakerDisabled/AbnormalCallTermination/HasActiveCallProtocol/SipOrH323ButNotBothEnabled/PresentationSourceSelection/SoftwareUpgrade/PlatformSanity/ContactInfoMismatch/ProximityContentShareToClientsWithMultistream

#### Example:

```
xStatus Diagnostics Message type
*s Diagnostics Message 1 Type: InvalidAdminPassword
** end
```

## H323 status

### xStatus H323

Shows the top level overview of the H323 status.

### xStatus H323 Gatekeeper Address

Displays the IP address of the gatekeeper where the system is registered.

**Value space of the result returned:**

String

**Example:**

```
xStatus H323 Gatekeeper Address
*s H323 Gatekeeper Address: "192.0.1.20"
** end
```

### xStatus H323 Gatekeeper Port

Shows the port which is used when connecting to on the gatekeeper.

**Value space of the result returned:**

Integer

**Example:**

```
xStatus H323 Gatekeeper Port
*s H323 Gatekeeper Port: 1719
** end
```

### xStatus H323 Gatekeeper Reason

Shows the reason for rejected registration.

**Value space of the result returned:**

String

**Example:**

```
xStatus H323 Gatekeeper Reason
*s H323 Gatekeeper Reason: ""
** end
```

### xStatus H323 Gatekeeper Status

Shows the gatekeeper registration status.

**Value space of the result returned:**

Required/Discovering/Discovered/Authenticating/Authenticated/Registering/Registered/  
Inactive/Rejected

**Example:**

```
xStatus H323 Gatekeeper Status
*s H323 Gatekeeper Status: Registered
** end
```

### xStatus H323 Mode Reason

Shows whether there is a conflict between H.323 settings and xStatus H323 Mode Status.

"": When H.323 is set to On and there is no conflict between H.323 Mode configuration and the rest of the system settings.

"SIP is enabled": When H.323 Mode is set to On and SIP is enabled on a system that does not support the two simultaneously.

"Not available": When a system does not support H.323.

**Value space of the result returned:**

String

**Example:**

```
xStatus H323 Mode Reason
*s H323 Mode Reason: ""
** end
```

### xStatus H323 Mode Status

Shows the status for H.323 registration.

Enabled: Registration is enabled.

Disabled: Registration is disable, because SIP is enabled.

**Value space of the result returned:**

Enabled/Disabled

**Example:**

```
xStatus H323 Mode Status
*s H323 Mode Status: "Disabled"
** end
```

## HttpFeedback status

### xStatus HttpFeedback

Shows the top level overview of the HTTP status.

### xStatus HttpFeedback [1..4] Expression [1..15]

Shows the feedback from the HTTP server. There can be up to 15 expressions for each URL. See the xCommand HttpFeedback commands for more information.

**Value space of the result returned:**

String

### xStatus HttpFeedback [1..4] URL

Shows the URL (Uniform Resource Locator) of the HTTP server. There can be up to three HTTP servers, specified by the URL.

**Value space of the result returned:**

String

**Example:**

```
xStatus HttpFeedback 1 URL
*s HttpFeedback 1 URL: "http://tms.company.com/tms/public/feedback/code.aspx"
** end
```

## Network status

### xStatus Network

Shows the top level overview of the network status.

### xStatus Network 1 CDP Address

Returns the first network address of both receiving and sending devices.

**Value space of the result returned:**

String

**Example:**

```
xStatus Network CDP Address
*s Network 1 CDP Address: "192.0.1.20"
** end
```

### xStatus Network 1 CDP Capabilities

Describes the functional capability for the switch in form of a device type. See documentation for CDP protocol for more information.

**Value space of the result returned:**

String

**Example:**

```
xStatus Network CDP Capabilities
*s Network 1 CDP Capabilities: "0x0029"
** end
```

### xStatus Network 1 CDP DeviceId

Identifies the name of the switch in form of a character string.

**Value space of the result returned:**

String

**Example:**

```
xStatus Network CDP DeviceId
*s Network 1 CDP DeviceId: "123456.company.com"
** end
```

### xStatus Network 1 CDP Duplex

Indicates the status (duplex configuration) of the CDP broadcast interface. Used by network operators to diagnose connectivity problems between adjacent network elements.

**Value space of the result returned:**

String

**Example:**

```
xStatus Network CDP Duplex
*s Network 1 CDP Duplex: "Full"
** end
```

### xStatus Network 1 CDP Platform

Returns the hardware platform name of the switch connected to the endpoint.

**Value space of the result returned:**

String

**Example:**

```
xStatus Network CDP Platform
*s Network 1 CDP Platform: "cisco WS-C3750X-48P"
** end
```

### xStatus Network 1 CDP PortID

Returns the identification the switch uses of the port the endpoint is connected to.

**Value space of the result returned:**

String

**Example:**

```
xStatus Network CDP PortID
*s Network 1 CDP PortID: "GigabitEthernet1/0/23"
** end
```

### xStatus Network 1 CDP PrimaryMgmtAddress

Returns the management address used to configure and monitor the switch the endpoint is connected to.

**Value space of the result returned:**

String

**Example:**

```
xStatus Network CDP PrimaryMgmtAddress
*s Network 1 CDP PrimaryMgmtAddress: "10.1.1.2"
** end
```

### xStatus Network 1 CDP SysName

Returns the SysName as configured in the switch the endpoint is connected to.

**Value space of the result returned:**

String

**Example:**

```
xStatus Network CDP SysName
*s Network 1 CDP SysName: ""
** end
```

### xStatus Network 1 CDP SysObjectID

Returns the SysObjectID as configured in the switch the endpoint is connected to.

**Value space of the result returned:**

String

**Example:**

```
xStatus Network CDP SysObjectID
*s Network 1 CDP SysObjectID: ""
** end
```

### xStatus Network 1 CDP Version

Returns information about the software release version the switch is running.

**Value space of the result returned:**

String

**Example:**

```
xStatus Network 1 CDP Version
*s Network 1 CDP Version: "Cisco IOS Software, C3560CX Software (C3560CX-
UNIVERSALK9-M), Version 15.2(3)E, RELEASE SOFTWARE (fc4)*Technical Support:
http://www.cisco.com/techsupport*Copyright (c) 1986-2014 by Cisco Systems,
Inc.*Compiled Sun 07-Dec-14 13:15 by prod_rel_team"
** end
```

### xStatus Network 1 CDP VoIPApplianceVlanID

Identifies the VLAN used for VoIP traffic from the endpoint to the switch. For more information see documentation of the IEEE 802.1Q protocol.

**Value space of the result returned:**

String

**Example:**

```
xStatus Network CDP VoIPApplianceVlanID
*s Network 1 CDP VoIPApplianceVlanID: "300"
** end
```

### xStatus Network 1 CDP VTPMgmtDomain

Returns the switch's configured VTP management domain name-string.

**Value space of the result returned:**

String

**Example:**

```
xStatus Network CDP VTPMgmtDomain
*s Network 1 CDP VTPMgmtDomain: "anyplace"
** end
```

### xStatus Network 1 DNS Domain Name

Shows the domain name.

**Value space of the result returned:**

String

**Example:**

```
xStatus Network 1 DNS Domain Name
*s Network 1 DNS Domain Name: "www.example.com www.example.int"
** end
```

### xStatus Network 1 DNS Server [1..5] Address

Shows the IP address of the DNS server.

**Value space of the result returned:**

String

**Example:**

```
xStatus Network 1 DNS Server 1. Address
*s Network 1 DNS Server 1 Address: "192.0.2.60"
** end
```

### xStatus Network 1 Ethernet MacAddress

Shows the MAC (Media Access Control) address for the Ethernet interface.

**Value space of the result returned:**

String

**Example:**

```
xStatus Network 1 Ethernet MacAddress
*s Network 1 Ethernet MacAddress: "00:50:60:02:FD:C7"
** end
```



### xStatus Network 1 Ethernet Speed

Shows the Ethernet speed in Mbps. The speed can be in full-duplex or half-duplex.

**Value space of the result returned:**

10half/10full/100half/100full/1000full

**Example:**

```
xStatus Network 1 Ethernet Speed
*s Network 1 Ethernet Speed: "100full"
** end
```

### xStatus Network 1 IPv4 Address

Shows the IPv4 address that uniquely identifies this system.

**Value space of the result returned:**

String

**Example:**

```
xStatus Network 1 IPv4 Address
*s Network 1 IPv4 Address: "192.0.2.149"
** end
```

### xStatus Network 1 IPv4 Gateway

Shows the address of the IPv4 gateway.

**Value space of the result returned:**

String

**Example:**

```
xStatus Network 1 IPv4 Gateway
*s Network 1 IPv4 Gateway: "192.0.2.10"
** end
```

### xStatus Network 1 IPv4 SubnetMask

Shows the subnet mask which determines which subnet an IPv4 address belongs to.

**Value space of the result returned:**

String

**Example:**

```
xStatus Network 1 IPv4 SubnetMask
*s Network 1 IPv4 SubnetMask: "255.255.255.0"
** end
```

### xStatus Network 1 IPv6 Address

Shows the IPv6 address that uniquely identifies this system.

**Value space of the result returned:**

String

**Example:**

```
xStatus Network 1 IPv6 Address
*s Network 1 IPv6 Address: ""
** end
```

### xStatus Network 1 IPv6 Gateway

Shows the address of the IPv6 gateway.

**Value space of the result returned:**

String

**Example:**

```
xStatus Network 1 IPv6 Gateway
*s Network 1 IPv6 Gateway: ""
** end
```

### xStatus Network 1 VLAN Voice VlanId

The feedback shows the VLAN Voice ID; or Off if the VLAN Voice Mode is not enabled.

**Value space of the result returned:**

Off/1..4094

**Example:**

```
xStatus Network 1 VLAN Voice VlanId
*s Network 1 VLAN Voice VlanId: "Off"
** end
```

## NetworkServices status

### xStatus NetworkServices

Shows the top level overview of the network services status.

### xStatus NetworkServices NTP CurrentAddress

Returns the address of the NTP server that is currently in use.

**Value space of the result returned:**

String

**Example:**

```
xStatus NetworkServices NTP CurrentAddress
*s NetworkServices NTP CurrentAddress: "123.254.15.121"
** end
```

### xStatus NetworkServices NTP Server [n] Address

Returns the address of the NTP server(s) the codec is using.

**Value space of the result returned:**

String

**Example:**

```
xStatus NetworkServices NTP Address
*s NetworkServices NTP Address: "12.104.193.12 64.104.222.16 144.254.15.121"
** end
```

### xStatus NetworkServices NTP Status

Returns the status of the endpoints synchronizing with the NTP server.

Unknown: State of the synchronization is unknown.

Synced: The system is in sync with the NTP server

Discarded: The NTP result has been discarded.

**Value space of the result returned:**

Unknown/Synced/NotSynced/Discarded

**Example:**

```
xStatus NetworkServices NTP Status
*s NetworkServices NTP Status: Synced
** end
```

## Peripherals status

### xStatus Peripherals

Shows the top level overview of the peripherals status.

### xStatus Peripherals ConnectedDevice [n] HardwareInfo

Shows hardware information about connected device.

**Value space of the result returned:**

String

**Example:**

```
xStatus Peripherals ConnectedDevice 1007 HardwareInfo
*s Peripherals ConnectedDevice 1007 HardwareInfo: "1122330-0"
** end
```

### xStatus Peripherals ConnectedDevice [n] ID

Shows the MAC-address of the connected device.

**Value space of the result returned:**

String

**Example:**

```
xStatus Peripherals ConnectedDevice 1007 ID
*s Peripherals ConnectedDevice 1007 ID: "00:10:20:20:be:21"
** end
```

### xStatus Peripherals ConnectedDevice [n] Name

Shows the product name of connected device.

**Value space of the result returned:**

String

**Example:**

```
xStatus Peripherals ConnectedDevice 1007 Name
*s Peripherals ConnectedDevice 1007 Name: "Cisco TelePresence Touch"
** end
```

### xStatus Peripherals ConnectedDevice [n] SoftwareInfo

Shows information of the software version running on the connected device.

**Value space of the result returned:**

String

**Example:**

```
xStatus Peripherals ConnectedDevice 1007 SoftwareInfo
*s Peripherals ConnectedDevice 1007 SoftwareInfo: "TI7.2.0"
** end
```

### xStatus Peripherals ConnectedDevice [n] Status

Shows peripheral devices that are currently connected to the endpoint.

**Value space of the result returned:**

Connected/ResponseTimedOut

**Example:**

```
xStatus Peripherals ConnectedDevice 1001 Status
*s Peripherals ConnectedDevice 1001 Status: Connected
** end
```

### xStatus Peripherals ConnectedDevice [n] Type

Shows the peripheral types that are connected to the endpoint.

Note: The value space Camera only shows Precision 60 cameras.

**Value space of the result returned:**

Byod/Camera/ControlSystem/ISDNLink/Other/SpeakerTrack/TouchPanel

**Example:**

```
xStatus Peripherals ConnectedDevice 1001 Type
*s Peripherals ConnectedDevice 1001 Type: TouchPanel
** end
```

### xStatus Peripherals ConnectedDevice [n] UpgradeStatus

Shows the status of the previous software upgrade on the currently connected peripherals.

**Value space of the result returned:**

Downloading/Failed/Installing/InstallationReady/None/Succeeded/Rebooting/Retrying/Aborted/Paused

**Example:**

```
xStatus Peripherals ConnectedDevice 1001 UpgradeStatus
*s Peripherals ConnectedDevice 1001 UpgradeStatus: None
** end
```

## Provisioning status

### xStatus Provisioning

Shows the top level overview of the provisioning status.

### xStatus Provisioning Software Current CompletedAt

Shows date and time for when the current software upgrade was completed.

**Value space of the result returned:**

String

**Example:**

```
xStatus Provisioning Software Current CompletedAt
*s Provisioning Software Current CompletedAt: "2011-06-07T07:20:03Z"
** end
```

### xStatus Provisioning Software Current URL

Shows the URL that the current software was uploaded from.

**Value space of the result returned:**

String

**Example:**

```
xStatus Provisioning Software Current URL
*s Provisioning Software Current URL: "http://.../s52020ce8_0_0.pkg"
** end
```

### xStatus Provisioning Software Current VersionId

Shows the version ID of the current software.

**Value space of the result returned:**

String

**Example:**

```
xStatus Provisioning Software Current VersionId
*s Provisioning Software Current VersionId: "s52020ce8_0_0.pkg"
** end
```

### xStatus Provisioning Software UpgradeStatus LastChange

Shows the date and time for the latest software upgrade.

**Value space of the result returned:**

String

**Example:**

```
xStatus Provisioning Software UpgradeStatus LastChange
*s Provisioning Software UpgradeStatus LastChange: "2011-06-07T07:20:03Z"
** end
```

### xStatus Provisioning Software UpgradeStatus Message

Shows the system message for the software upgrade.

**Value space of the result returned:**

String

**Example:**

```
xStatus Provisioning Software UpgradeStatus Message
*s Provisioning Software UpgradeStatus Message: ""
** end
```

### xStatus Provisioning Software UpgradeStatus Phase

Shows the phase of the software upgrade.

**Value space of the result returned:**

None/DownloadPending/FormingHierarchy/Downloading/DownloadPaused/DownloadDone/Seeding/AboutToInstallUpgrade/Postponed/PeripheralsReady/UpgradingPeripherals/Installing/InstallingPeripherals

**Example:**

```
xStatus Provisioning Software UpgradeStatus Phase
*s Provisioning Software UpgradeStatus Phase: None
** end
```

### xStatus Provisioning Software UpgradeStatus SessionId

Shows the ID of the session for the software upgrade.

**Value space of the result returned:**

String

**Example:**

```
xStatus Provisioning Software UpgradeStatus SessionId
*s Provisioning Software UpgradeStatus SessionId: ""
** end
```

### xStatus Provisioning Software UpgradeStatus Status

Shows the status of the software upgrade.

**Value space of the result returned:**

None/InProgress/Failed/InstallationFailed/Succeeded

**Example:**

```
xStatus Provisioning Software UpgradeStatus Status
*s Provisioning Software UpgradeStatus Status: None
** end
```

### xStatus Provisioning Software UpgradeStatus URL

Shows the URL that the new software currently is being uploaded and installed from.

**Value space of the result returned:**

String

**Example:**

```
xStatus Provisioning Software UpgradeStatus URL
*s Provisioning Software UpgradeStatus URL: "http://.../s52020ce8_0_0.pkg"
** end
```

### xStatus Provisioning Software UpgradeStatus VersionId

Shows the version ID of the software currently being uploaded and installed.

**Value space of the result returned:**

String

**Example:**

```
xStatus Provisioning Software UpgradeStatus VersionId
*s Provisioning Software UpgradeStatus VersionId: "s52010ce8_0_0.pkg"
** end
```

### xStatus Provisioning Status

Shows the status of the provisioning.

Failed: The provisioning failed.

AuthenticationFailed: The authentication failed.

Provisioned: The endpoint is provisioned.

Idle: The provisioning is not active.

NeedConfig: The endpoint needs to be configured.

ConfigError: An error occurred during configuration.

**Value space of the result returned:**

Failed/AuthenticationFailed/Provisioned/Idle/NeedConfig/ConfigError

**Example:**

```
xStatus Provisioning Status
*s Provisioning Status: Provisioned
** end
```

## Proximity status

### xStatus Proximity

Shows the top level overview of the proximity status.

### xStatus Proximity Services Availability

Shows whether proximity services are available on the endpoint.

Available: Proximity mode has been enabled with the command xConfiguration Proximity Mode and one or more of the proximity services have been enabled with xConfiguration Proximity Services commands.

Disabled: Proximity mode has been disabled with xConfiguration Proximity Mode, or none of the services have been enabled with the xConfiguration Proximity Services commands.

Deactivated: Proximity services have been deactivated with the command xCommand Proximity Services Deactivate.

**Example:**

```
xStatus Proximity Services Availability
*s Proximity Services Availability: Disabled
** end
```

## Security status

### xStatus Security

Shows the top level overview of the security status.

### xStatus Security FIPS Mode

Shows the FIPS mode status.

**Value space of the result returned:**

On/Off

**Example:**

```
xStatus Security FIPS Mode
*s Security FIPS Mode: Off
** end
```

### xStatus Security Persistency CallHistory

Shows whether call history logging is set to persistent or non-persistent mode. Persistent is the default mode.

**Value space of the result returned:**

NonPersistent/Persistent

**Example:**

```
xStatus Security Persistency CallHistory
*s Security Persistency CallHistory: Persistent
** end
```

### xStatus Security Persistency Configurations

Shows whether the systems all configurations are set to persistent or non-persistent mode. Persistent is the default mode.

**Value space of the result returned:**

NonPersistent/Persistent

**Example:**

```
xStatus Security Persistency Configurations
*s Security Persistency Configurations: Persistent
** end
```

### xStatus Security Persistency DHCP

Shows whether DHCP logging is set to persistent or non-persistent mode. Persistent is the default mode.

**Value space of the result returned:**

NonPersistent/Persistent

**Example:**

```
xStatus Security Persistency DHCP
*s Security Persistency DHCP: Persistent
** end
```

### xStatus Security Persistency InternalLogging

Shows whether internal logging is set to persistent or non-persistent mode. Persistent is the default mode.

**Value space of the result returned:**

NonPersistent/Persistent

**Example:**

```
xStatus Security Persistency InternalLogging
*s Security Persistency InternalLogging: Persistent
** end
```

### xStatus Security Persistency LocalPhonebook

Shows whether local phone book is set to persistent or non-persistent mode. Persistent is the default mode.

**Value space of the result returned:**

NonPersistent/Persistent

**Example:**

```
xStatus Security Persistency LocalPhonebook
*s Security Persistency LocalPhonebook: Persistent
** end
```

## SIP status

### xStatus SIP

Shows the top level overview of the SIP status.

### xStatus SIP AlternateURI Alias [n] URI

**Value space of the result returned:**

String

**Example:**

```
xStatus SIP AlternateURI Alias
*s SIP AlternateURI Alias URI: ""
** end
```

### xStatus SIP AlternateURI Primary [n] URI

**Value space of the result returned:**

String

**Example:**

```
xStatus SIP AlternateURI Primary
*s SIP AlternateURI Primary URI: ""
** end
```

### xStatus SIP Authentication

Shows which authentication mechanism is used when registering to the SIP Proxy Server.  
 Digest: Uses the Digest access authentication method, as specified by RFC 2069.  
 NTLM: Uses the NTLM authentication method, which is a Microsoft authentication protocol.  
 Off: No authentication mechanism is used.

**Value space of the result returned:**

Digest/Off

**Example:**

```
xStatus SIP Authentication
*s SIP Authentication: Off
** end
```



### xStatus SIP CallForward DisplayName

Returns the URI that is displayed on the user interface for the forwarded call.

**Value space of the result returned:**

String

**Example:**

```
xStatus SIP CallForward DisplayName
*s SIP CallForward DisplayName: ""
** end
```

### xStatus SIP CallForward Mode

Indicates whether the call forward mode for SIP is set to on or off.

**Value space of the result returned:**

On/Off

**Example:**

```
xStatus SIP CallForward Mode
*s SIP CallForward Mode: Off
** end
```

### xStatus SIP CallForward URI

Indicates the address the incoming calls are directed to when call forward mode is set on.

**Value space of the result returned:**

String

**Example:**

```
xStatus SIP CallForward URI
*s SIP CallForward URI: ""
** end
```

### xStatus SIP Mailbox MessagesWaiting

Indicates how many new messages are in the mailbox.

**Value space of the result returned:**

Integer

**Example:**

```
xStatus SIP Mailbox MessagesWaiting
*s SIP Mailbox MessagesWaiting: 0
** end
```

### xStatus SIP Mailbox URI

Returns the URI for your SIP mailbox.

**Value space of the result returned:**

String

**Example:**

```
xStatus SIP Mailbox URI
*s SIP Mailbox URI: "12345678"
** end
```

### xStatus SIP Proxy [n] Address

Shows the address of the SIP Proxy that the system communicates with.

**Value space of the result returned:**

String

**Example:**

```
xStatus SIP Proxy 1 Address
*s SIP Proxy 1 Address: "192.0.2.50"
** end
```

### xStatus SIP Proxy [n] Status

Shows the status of the communication between the endpoint and the SIP Proxy server.

Active: The communication between the endpoint and the SIP Proxy is active.

DNSFailed: The attempt to establish communication to the DNS server failed.

Off: There is no communication between the endpoint and the SIP Proxy.

Timeout: The attempt to establish communication to the SIP Proxy timed out.

UnableTCP: The system is unable to use TCP as the transport method.

UnableTLS: The system is unable to use TLS as the transport method.

Unknown: The status of the communication is not known.

AuthenticationFailed: Wrong user name or password.

**Value space of the result returned:**

Active/DNSFailed/Off/Timeout/UnableTCP/UnableTLS/Unknown/AuthenticationFailed

**Example:**

```
xStatus SIP Proxy 1 Status
*s SIP Proxy 1 Status: Active
** end
```

### xStatus SIP Registration [n] Authentication

Shows which authentication mechanism is used when registering to the SIP Proxy Server.

Digest: Uses the Digest access authentication method, as specified by RFC 2069.

NTLM: Uses the NTLM authentication method, which is a Microsoft authentication protocol.

Off: No authentication mechanism is used.

**Value space of the result returned:**

Digest/Off

**Example:**

```
xStatus SIP Registration 1 Authentication
*s SIP Registration 1 Authentication: Off
** end
```

### xStatus SIP Registration [n] Reason

Shows a message to explain the reason why the SIP registration failed.

**Value space of the result returned:**

String

**Example:**

```
xStatus SIP Registration 1 Reason
*s SIP Registration 1 Reason: "404 Not Found"
** end
```

### xStatus SIP Registration [n] Status

Shows the status of the registration to the SIP Proxy Server.

Deregister: The system is in the process of de-registering to the SIP Proxy.

Failed: The system failed to register to the SIP Proxy.

Inactive: The system is not registered to any SIP Proxy.

Registered: The system is registered to the SIP Proxy.

Registering: The system is in the process of registering to the SIP Proxy.

**Value space of the result returned:**

Deregister/Failed/Inactive/Registered/Registering

**Example:**

```
xStatus SIP Registration 1 Status
*s SIP Registration 1 Status: Registered
** end
```

### xStatus SIP Registration [n] URI

Shows the URI used for registration to the SIP Proxy server.

**Value space of the result returned:**

String

**Example:**

```
xStatus SIP Registration 1 URI
*s SIP Registration 1 URI: "firstname.lastname@company.com"
** end
```

### xStatus SIP Secure

Shows the encryption status of the signaling with the SIP Proxy server.

**Value space of the result returned:**

True/False

**Example:**

```
xStatus SIP Secure
*s SIP Secure: True
** end
```

### xStatus SIP Verified

Shows whether or not the SSL certificate of the server that the video system / codec tries to register to is included in the codec's trusted CA-list. The server is typically a Cisco VCS or CUCM.

True: The server's SIP certificate is checked against the trusted CA-list on the codec and found valid. Additionally, the fully qualified domain name of the server matches the valid certificate.

False: A TLS connection is not set up because the SIP certificate verification failed or the domain name did not match. Note that the status also returns False when TLS is not used (xConfiguration SIP DefaultTransport not set to TLS) or certificate verification is switched off (SIP TlsVerify: Off. This setting is accessible through your products web interface).

**Value space of the result returned:**

True/False

**Example:**

```
xStatus SIP Verified
*s SIP Verified: False
** end
```

## Standby status

### xStatus Standby

Shows the top level overview of the standby status.

### xStatus Standby State

Shows whether the system is in standby mode or not.

**Value space of the result returned:**

Standby/EnteringStandby/Off

**Example:**

```
xStatus Standby State
*s Standby State: Off
** end
```

## SystemUnit status

### xStatus SystemUnit

Shows the top level overview of the system unit status.

### xStatus SystemUnit Hardware Module CompatibilityLevel

The Cisco TelePresence endpoints are using a NAND flash memory for general storage. The endpoints running TC software are manufactured with a new version of the flash memory. Endpoints having the new version of the flash memory must run software TC4.2.1 or later. Some previous TC software versions are updated to support the new flash memory. Please check the release note to find if the new version of the flash memory is supported. If your endpoint does not have the CompatibilityLevel command it does not have the new flash memory installed.

The result returned when running the command is either 0 or 1:

0 = The system does not have the new flash memory installed.

1 = The system has the new flash memory installed. If downgraded, it can only be downgraded to previous TC software versions having support for the new version of the flash memory.

**Value space of the result returned:**

1/0

**Example:**

```
xStatus SystemUnit Hardware Module CompatibilityLevel
*s SystemUnit Hardware Module CompatibilityLevel: 1
** end
```

### xStatus SystemUnit Hardware Module SerialNumber

Shows the serial number of the hardware module in the codec.

**Value space of the result returned:**

String

**Example:**

```
xStatus SystemUnit Hardware Module SerialNumber
*s SystemUnit Hardware Module SerialNumber: "F9AA99A00090"
** end
```

### xStatus SystemUnit Hardware Monitoring Fan [n] Status

The feedback shows the speed (rpm) for the specified fan.

**Value space of the result returned:**

String

**Example:**

```
xStatus SystemUnit Hardware Monitoring Fan 1 Status
*s SystemUnit Hardware Monitoring Fan 1 Status: "locked on 1096 rpm"
** end
```

### xStatus SystemUnit Hardware Temperature

Shows the current maximum temperature (degree Celsius) measured in the codec/system.

**Value space of the result returned:**

String

**Example:**

```
xStatus SystemUnit Hardware Temperature
*s SystemUnit Hardware Temperature: "64.0"
** end
```

### xStatus SystemUnit Notifications Notification [n] Text

Lists text related to important system notifications. Notifications are issued e.g. when a system was rebooted because of a software upgrade, or when a factory reset has been performed.

All the notifications can be removed from the list by issuing the xCommand SystemUnit Notifications RemoveAll command.

**Value space of the result returned:**

String

**Example:**

```
xStatus SystemUnit Notifications Notification 1 Text
*s SystemUnit Notifications Notification 1 Text: "OK"
** end
```

### xStatus SystemUnit Notifications Notification [n] Type

Lists the system notification types. Notifications are issued e.g. when a system is rebooted because of a software upgrade, or when a factory reset is performed.

FactoryResetOK: This value is returned after a successful factory reset.

FactoryResetFailed: This value is returned after a failed factory reset attempt.

SoftwareUpgradeOK: This value is returned after a successful software upgrade.

SoftwareUpgradeFailed: This value is returned after a failed software upgrade attempt.

RebootRequired: This value is returned when a reboot is required.

Other: This value is returned for any other notifications.

All the notifications can be removed from the list by issuing the xCommand SystemUnit Notifications RemoveAll command.

**Value space of the result returned:**

FactoryResetOK, FactoryResetFailed, SoftwareUpgradeOK, SoftwareUpgradeFailed, RebootRequired, Other

**Example:**

```
xStatus SystemUnit Notifications Notification 1 Type
*s SystemUnit Notifications Notification 1 Type: SoftwareUpgradeOK
** end
```

### xStatus SystemUnit ProductId

Shows the product identity.

**Value space of the result returned:**

String

**Example:**

```
xStatus SystemUnit ProductId
*s SystemUnit ProductId: "Cisco TelePresence Codec SX80"
** end
```

### xStatus SystemUnit ProductPlatform

Shows the product platform.

**Value space of the result returned:**

String

**Example:**

```
xStatus SystemUnit ProductPlatform
*s SystemUnit ProductPlatform: "SX80"
** end
```

### xStatus SystemUnit ProductType

Shows the product type.

**Value space of the result returned:**

String

**Example:**

```
xStatus SystemUnit ProductType
*s SystemUnit ProductType: "Cisco Codec"
** end
```

### xStatus SystemUnit Software DisplayName

Shows the name of the software that is installed on the codec, as it is displayed in the UI.

**Value space of the result returned:**

String

**Example:**

```
xStatus SystemUnit Software DisplayName
*s SystemUnit Software DisplayName: "Display Name"
** end
```

### xStatus SystemUnit Software Name

Shows the name of the software that is installed on the codec.

**Value space of the result returned:**

String

**Example:**

```
xStatus SystemUnit Software Name
*s SystemUnit Software Name: "s52010"
** end
```

### xStatus SystemUnit Software OptionKeys RemoteMonitoring

Shows whether the system has the remote monitoring option key installed. Remote monitoring option key enables snapshots from the web interface, and from a remote paired Touch 10.

**Value space of the result returned:**

False/True

**Example:**

```
xStatus SystemUnit Software OptionKeys RemoteMonitoring
*s SystemUnit Software OptionKeys RemoteMonitoring: "true"
** end
```

### xStatus SystemUnit Software ReleaseDate

Shows the release date of the software installed on the codec.

**Value space of the result returned:**

String

**Example:**

```
xStatus SystemUnit Software ReleaseDate
*s SystemUnit Software ReleaseDate: "2015-05-05"
** end
```

### xStatus SystemUnit Software Version

Shows the software version installed on the codec.

**Value space of the result returned:**

String

**Example:**

```
xStatus SystemUnit Software Version
*s SystemUnit Software Version: "CE8.0.0"
** end
```

### xStatus SystemUnit State NumberOfActiveCalls

Shows the number of active calls.

**Value space of the result returned:**

0..5

**Example:**

```
xStatus SystemUnit State NumberOfActiveCalls
*s SystemUnit State NumberOfActiveCalls: 0
** end
```

### xStatus SystemUnit State NumberOfInProgressCalls

Shows the number of calls in progress.

**Value space of the result returned:**

0..5

**Example:**

```
xStatus SystemUnit State NumberOfInProgressCalls
*s SystemUnit State NumberOfInProgressCalls: 0
** end
```

### xStatus SystemUnit State NumberOfSuspendedCalls

Shows the number of suspended calls.

**Value space of the result returned:**

0..5

**Example:**

```
xStatus SystemUnit State NumberOfSuspendedCalls
*s SystemUnit State NumberOfSuspendedCalls: 0
** end
```

### xStatus SystemUnit Uptime

Shows the number of seconds since the last restart of the codec.

**Value space of the result returned:**

Integer

**Example:**

```
xStatus SystemUnit Uptime
*s SystemUnit Uptime: 597095
** end
```

## Time status

### xStatus Time

Shows the top level overview of the time status.

### xStatus Time SystemTime

Returns the date and time set on the system.

**Value space of the result returned:**

String

**Example:**

```
xStatus Time SystemTime
*s Time SystemTime: "2014-04-25T10:04:03Z"
** end
```

## UserInterface status

### xStatus UserInterface

Shows the top level overview of the video status.

### xStatus UserInterface ContactInfo ContactMethod [n] Number

Returns the system's active contact information. This address is used to reach this endpoint.

**Value space of the result returned:**

String

**Example:**

```
xStatus UserInterface ContactInfo ContactMethod Number
*s UserInterface ContactInfo ContactMethod 1 Number: "12345678"
** end
```

### xStatus UserInterface ContactInfo Name

Returns the system's active contact name. The result depends on which protocol, if any, the system is registered on. The automatically set contact name may have been overridden with the command xConfiguration UserInterface ContactInfo Type. This results in a diagnostics warning about contact mismatch.

**Value space of the result returned:**

String

**Example:**

```
xStatus UserInterface ContactInfo Name
*s UserInterface ContactInfo Name: "MySystem"
** end
```

## Video status

### xStatus Video

Shows the top level overview of the video status.

### xStatus Video ActiveSpeaker PIPPosition

Shows the position of the active speaker's image on the screen.

**Value space of the result returned:**

UpperLeft/UpperCenter/UpperRight/CenterLeft/CenterRight/LowerLeft/LowerRight

**Example:**

```
xStatus Video ActiveSpeaker PIPPosition
*s Video PIP ActiveSpeaker Position: UpperCenter
** end
```

### xStatus Video Input

Shows the top level overview of the video input status.

### xStatus Video Input Connector [n] Connected

Shows whether is something is connected to the specified connector. Not all connections can be detected.

**Value space of the result returned:**

False/True/Unknown

**Example:**

```
xStatus Video Input Connector 1 Connected
*s Video Input Connector 1 Connected: True
** end
```



### xStatus Video Input Connector [n] SignalState

Shows the signal state for the specified input.

Unknown: The signal format is unknown.

OK: A signal is detected and the signal format is supported.

Unsupported: A signal is detected, but the signal format is not supported.

**Value space of the result returned:**

OK/Unknown/Unsupported

**Example:**

```
xStatus Video Input Connector 1 SignalState
*s Video Input Connector 1 SignalState: OK
** end
```

### xStatus Video Input Connector [n] SourceId

Shows the identifier of the input source that the connector is associated with.

**Value space of the result returned:**

Integer

**Example:**

```
xStatus Video Input Connector 1 SourceId
*s Video Input Connector 1 SourceId: 1
** end
```

### xStatus Video Input Connector [n] Type

Shows which connector type it is.

**Value space of the result returned:**

Composite/DVI/HDMI/Unknown/YC

**Example:**

```
xStatus Video Input Connector 1 Type
*s Video Input Connector 1 Type: HDMI
** end
```

### xStatus Video Input MainVideoSource

Returns the local video input currently used as the main source. The main video source is set with the xConfiguration Video DefaultMainSource command.

**Value space of the result returned:**

Integer

**Example:**

```
xStatus Video Input MainVideoSource
*s Video Input MainVideoSource: 1
** end
```

### xStatus Video Input Source [n] ConnectorId

Shows the identifier of the connector that is associated with the input source.

**Value space of the result returned:**

Integer

**Example:**

```
xStatus Video Input Source 1 ConnectorId
*s Video Input Source 1 ConnectorId: 1
** end
```

### xStatus Video Input Source [n] FormatStatus

Shows the resolution format status for the video input source.

**Value space of the result returned:**

Ok/OutOfRange/NotFound/Interlaced/Error/Unknown

**Example:**

```
xStatus Video Input Source 1 FormatStatus
*s Video Input Source 1 Resolution FormatStatus: Ok
** end
```

### xStatus Video Input Source [n] FormatType

Shows the resolution format type for the video input source.

**Value space of the result returned:**

Unknown/AnalogCVTBlanking/AnalogCVTReducedBlanking/AnalogGTFDefault/  
AnalogGTFSecondary/AnalogDiscreteTiming/AnalogDMTBlanking/AnalogCEABlanking/Digital

**Example:**

```
xStatus Video Input Source 1 FormatType
*s Video Input Source 1 Resolution FormatType: Digital
** end
```

### xStatus Video Input Source [n] MediaChannelId

For internal use only.

**Value space of the result returned:**

Integer

**Example:**

```
xStatus Video Input Source MediaChannelId
*s Video Input Source 1 MediaChannelId: 2
*s Video Input Source 2 MediaChannelId: 3
** end
```

### xStatus Video Input Source [n] Resolution Height

Shows the resolution height (in pixels) for the video input source.

**Value space of the result returned:**

0..3000

**Example:**

```
xStatus Video Input Source 1 Resolution Height
*s Video Input Source 1 Resolution Height: 1080
** end
```

### xStatus Video Input Source [n] Resolution RefreshRate

Shows the resolution refresh rate (Hz) for the video input source.

**Value space of the result returned:**

0..300

**Example:**

```
xStatus Video Input Source 1 Resolution RefreshRate
*s Video Input Source 1 Resolution RefreshRate: 50
** end
```

### xStatus Video Input Source [n] Resolution Width

Shows the resolution width (in pixels) for the video input source.

**Value space of the result returned:**

0..4000

**Example:**

```
xStatus Video Input Source 1 Resolution Width
*s Video Input Source 1 Resolution Width: 1920
** end
```

### xStatus Video Layout LayoutFamily Local

Shows the local screen layout family.

**Value space of the result returned:**

String

**Example:**

```
xStatus Video Layout LayoutFamily Local
*s Video Layout LayoutFamily Local: "equal"
** end
```

### xStatus Video Layout LayoutFamily Remote

Shows the remote screen layout family.

**Value space of the result returned:**

String

**Example:**

```
xStatus Video Layout LayoutFamily Remote
*s Video Layout LayoutFamily Remote: "equal"
** end
```

### xStatus Video Monitors

Returns the monitor layout mode.

Single: The same layout is shown on all monitors.

Dual: The layout is distributed on two monitors.

DualPresentationOnly: All participants in the call will be shown on the first monitor, while the presentation (if any) will be shown on the second monitor.

Quadruple: The layout is distributed on four monitors, so that each remote participant and the presentation will be shown on separate monitors.

**Value space of the result returned:**

Single/Dual/DualPresentationOnly/Triple/TriplePresentationOnly/Quadruple

**Example:**

```
xStatus Video Monitors
*s Video Monitors: Single
** end
```

### xStatus Video Output

Shows the top level overview of the video output status.

### xStatus Video Output Connector [n] Connected

Describes whether a device (for example a display) is connected to the output connector or not. When a display enters standby mode, the endpoint may not be able to detect it. The connector status will then return False/Unknown even if the display is physically connected.

True: A device is connected to the video output connector.

False: Nothing is connected to the video output connector.

**Value space of the result returned:**

True/False

**Example:**

```
xStatus Video Output Connector 1 Connected
*s Video Output Connector 1 Connected: True
** end
```

### xStatus Video Output Connector [n] ConnectedDevice CEC DeviceType

Shows the type of CEC enabled device connected to the HDMI output the codec has detected.

This information is only available when the device connected to the HDMI output has the CEC feature configured on and the codec has the configuration xConfiguration Video Output Connector [n] CEC Mode set to on.

**Value space of the result returned:**

Unknown/TV/Reserved/Recorder/Tuner/Playback/Audio

**Example:**

```
xStatus Video Output Connector 1 ConnectedDevice CEC DeviceType
*s Video Output Connector 1 ConnectedDevice CEC DeviceType: TV
** end
```

### xStatus Video Output Connector [n] ConnectedDevice CEC PowerControl

Shows whether the codec is controlling the CEC enabled device connected to the HDMI output. This information is only available when the device connected to the HDMI output has the CEC feature configured on and the codec has the configuration xConfiguration Video Output Connector CEC Mode set to on.

**Value space of the result returned:**

Unknown/Ok/In progress/Failed to power on/Failed to standby

**Example:**

```
xStatus Video Output Connector 1 ConnectedDevice CEC PowerControl
*s Video Output Connector 1 ConnectedDevice CEC PowerControl: Ok
** end
```

### xStatus Video Output Connector [n] ConnectedDevice CEC PowerStatus

Shows the state of the CEC enabled device connected to the HDMI output. This information is only available when the device connected to the HDMI output has the CEC feature configured on and the codec has the configuration xConfiguration Video Output Connector CEC Mode set to on.

**Value space of the result returned:**

Unknown/Ok/In progress/Failed to power on/Failed to standby

**Example:**

```
xStatus Video Output Connector 1 ConnectedDevice CEC PowerStatus
*s Video Output Connector 1 ConnectedDevice CEC PowerStatus: Ok
** end
```

### xStatus Video Output Connector [n] ConnectedDevice Name

Shows the name of the monitor connected to the HDMI port as defined in the monitors EDID.

**Value space of the result returned:**

String

**Example:**

```
xStatus Video Output Connector 1 ConnectedDevice Name
*s Video Output Connector 1 ConnectedDevice Name: "G2420HDBL"
** end
```

### xStatus Video Output Connector [n] ConnectedDevice PreferredFormat

Shows the preferred input format of the monitor connected to the HDMI port as defined in the monitors EDID. This is not necessarily the format the codec is sending out.

**Value space of the result returned:**

String

**Example:**

```
xStatus Video Output Connector 1 ConnectedDevice PreferredFormat
*s Video Output Connector 1 ConnectedDevice PreferredFormat: "1920x1080@60Hz"
** end
```

### xStatus Video Output Connector [n] MonitorRole

Describes which video stream is shown on the device that is connected to the video output connector.

First/Second/Third: The role of the monitor in a multimonitor setup. In a singlemonitor setup, there is no difference between First, Second and Third.

PresentationOnly: Shows presentation video stream if active.

Recorder: Shows all participants, including the local main video. If active, shows also the presentation.

**Value space of the result returned:**

First/Second/Third/PresentationOnly/Recorder

**Example:**

```
xStatus Video Output Connector 1 MonitorRole
*s Video Output Connector 1 MonitorRole: First
** end
```

### xStatus Video Output Connector [n] Resolution Height

Shows the resolution height (in pixels) for the video output connector.

**Value space of the result returned:**

120..3000

**Example:**

```
xStatus Video Output Connector 1 Resolution Height
*s Video Output Connector 1 Resolution Height: 1080
** en
```

### xStatus Video Output Connector [n] Resolution RefreshRate

Shows the resolution refresh rate (Hz) for the video output connector.

**Value space of the result returned:**

1..300

**Example:**

```
xStatus Video Output Connector 1 Resolution RefreshRate
*s Video Output Connector 1 Resolution RefreshRate: 60
** end
```

### xStatus Video Output Connector [n] Resolution Width

Shows the resolution width (in pixels) for the video output connector.

**Value space of the result returned:**

176..4000

**Example:**

```
xStatus Video Output Connector 1 Resolution Width
*s Video Output Connector 1 Resolution Width: 1920
** end
```

### xStatus Video Output Connector [n] Type

Shows the type of connector.

HDMI: It is an HDMI connector.

DVI: It is an DVI connector.

**Value space of the result returned:**

HDMI/DVI

**Example:**

```
xStatus Video Output Connector 1 Type
*s Video Output Connector 1 Type: HDMI
** end
```

### xStatus Video Presentation PIPPosition

Shows the position of the presentation image on the screen.

**Value space of the result returned:**

UpperLeft/UpperCenter/UpperRight/CenterLeft/CenterRight/LowerLeft/LowerRight

**Example:**

```
xStatus Video Presentation PIPPosition
*s Video PIP Presentation Position: CenterLeft
** end
```

### xStatus Video Selfview FullscreenMode

Shows whether selfview is set on full screen mode or not.

**Value space of the result returned:**

On/Off

**Example:**

```
xStatus Video Selfview FullscreenMode
*s Video Selfview FullscreenMode: Off
** end
```

### xStatus Video Selfview Mode

Shows whether selfview mode is set on or not.

**Value space of the result returned:**

On/Off

**Example:**

```
xStatus Video Selfview Mode
*s Video Selfview Mode: Off
** end
```

### xStatus Video Selfview OnMonitorRole

Identifies which monitor(s) contains the selfview, if present.

**Value space of the result returned:**

First/Second/Third/Fourth

**Example:**

```
xStatus Video Selfview OnMonitorRole
*s Video Selfview OnMonitorRole: First
** end
```

### xStatus Video Selfview PIPPosition

Shows the position of the selfview image on the screen.

**Value space of the result returned:**

UpperLeft/UpperCenter/UpperRight/CenterLeft/CenterRight/LowerLeft/LowerRight

**Example:**

```
xStatus Video Selfview PIPPosition
*s Video Selfview PIPPosition: LowerRight
** end
```



## Chapter 6

# Appendices

## About startup scripts

You can add one or more startup scripts to the codec.

A startup script contains commands (xCommand) and configurations (xConfiguration) that will be executed as part of the start up procedure every time the codec boots. A few commands and configurations cannot be placed in a startup script, e.g. xCommand SystemUnit Boot.

Use the codec's web interface to create and manage startup scripts.

Read more about the web interface and startup scripts in the Administrator guide for your product.



## The SystemTools commands

**NOTE:** The systemtools commands are used for administrative control of the codec and are only available from a command line interface. Systemtools should not be used to program the codec.

Required parameters in angle brackets: <text>

Optional parameters in square brackets: [text]

To get an overview of the supported commands type “systemtools ?”.

Example:

```
systemtools ?
license
network
ntp
passwd
pki
rootsettings
securitysettings
securitystatus
selectsw
sudo
whoami
touch
```

To see the usage of the commands add a question mark after the command.

Example:

```
systemtools network ?
usage: network ping <hostname> | traceroute
<hostname> | netstat | addr | ifconfig
```

### systemtools license list

Lists all the licenses for the codec.

### systemtools license show <name>

Shows the content of a license file, defined by the name.

<name>: The name of the license file.

### systemtools network ping <hostname>

Network debug command.

<hostname>: The IP address or URL of the host.

### systemtools network traceroute <hostname>

Network debug command.

<hostname>: The IP address or URL of the host.

### systemtools network netstat

Network debug command.

### systemtools network addr

Check the systems IP address.

### systemtools network ifconfig

Network debug command.

### systemtools pairing unpair

Remove association with Cisco TelePresence Touch controller.

### systemtools passwd

Change the password for the logged in user.

### systemtools pki list

Lists the codec certificate and CA list if they exist.

### systemtools pki delete <cert-name>

Delete the codec certificate and CA list if they exist.

<cert-name>: The name of the certificate.

### systemtools securitysettings jitc

Set up security requirements so they meet JITC.

Set password and PIN polices enforced on the codec.

### systemtools securitysettings isjtc

Check if the current settings are JTIC compliant.

### systemtools securitysettings default

Revert to default security settings.

### systemtools securitysettings ask

Query for the separate configurations. When issuing this command you can see each policy separately.

- Press enter to keep the current value.
- Enter a number and press enter to change the given policy.
- The default value “0” indicates no restrictions.

Max failed login attempts [0]?

- Number of failed logins until a user is set inactive.

Suspend-time after max failed login attempts (minutes) [0]?

- Number of minutes the user is set inactive after maximum failed login attempts have been exceeded.

Max simultaneous sessions total [0]?

- Maximum number of users that can be logged in simultaneous to web and maximum number of users that can be logged in simultaneous to ssh/Telnet.

Max simultaneous sessions per user [0]?

- Maximum number of simultaneous sessions per user.

Number of passwords to remember [0]?

- Number of previous passwords that the new password must differ from.

Number of PINs to remember [0]?

- Number of previous PINs that the new PIN must differ from.

Maximum time between password renewals (days) [0]?

- If the user has not changed the password within the renewal time the user will be set inactive.

Minimum time between password renewals (hours) [0]?

- The user can only change password once within this limit.

Maximum time between PIN renewals (days) [0]?

- If the user has not changed the PIN within the renewal time the user will be set inactive.

Minimum time between PIN renewals (hours) [0]?

- The user can only change PIN once within this limit.

Maximum time between logins (days) [0]?

- If the user has not logged in within this limit the user will be set inactive.

Max consecutive equal digits in PINs [0]?

- Maximum consecutive equal digits in PINs.

Minimum number of digits in PINs [0]?

- Minimum number of digits in PINs.

Maximum number of digits in PINs [0]?

- Maximum number of digits in PINs.

Max consecutive identical characters in passwords [0]?

- Maximum consecutive identical characters in passwords.

Minimum number of characters in passwords [0]?

- Minimum number of characters in passwords.

Maximum number of characters in passwords [0]?

- Maximum number of characters in passwords.

Minimum number of lower-case letters in passwords [0]?

- Minimum number of lower-case letters in passwords.

Minimum number of upper-case letters in passwords [0]?

- Minimum number of upper-case letters in passwords.

Minimum number of numerical characters in passwords [0]?

- Minimum number of numerical characters in passwords.

Minimum number of special characters in passwords [0]?

- Minimum number of special characters in passwords.

Minimum number of character groups in passwords [0]?

- Minimum number of character groups in passwords.

Minimum number of character changed from previous password [0]?

- Minimum number of character changed from previous password.

systemtools securitystatus

Shows the security status for the codec.

systemtools selectsw

Select which of the available software images to use. Changing the software image will restart the codec.

No argument given: Lists the version of the available software images, and shows which one is active.

*image name*: Swap to the software with this name.

systemtools sudo on

Changes the user role of the current session to the role of the specified user

*<username>*: The name of the sudo user.

*<password>*: The password for the sudo user.

systemtools sudo off

Reverts back to the user role of the signed in user.

systemtools whoami

Lists the name and id of the signed in user, and the user roles held by this user.

## About disconnect cause types

The following parameters are logged when a call is disconnected. The disconnect cause types are used in disconnect events (xEvent).

CauseValue	Proprietary. We recommend the use of CauseType and CauseCode.
CauseType	Describes why the call was disconnected. The value space is { OtherLocal, LocalDisconnect, UnknownRemoteSite, LocalBusy, LocalReject, InsufficientSecurity, OtherRemote, RemoteDisconnect, RemoteBusy, RemoteRejected, RemoteNoAnswer, CallForwarded, NetworkRejected }
CauseString	Describes the Cause Code.
CauseCode	The disconnect Cause Codes are defined in SIP and Q.850.
CauseOrigin	SIP, Q.850, internal.

Example:

```
xEvent DisconnectEvent

*e CallDisconnect CauseValue: 1
  CauseType: "LocalDisconnect"
  CauseString: ""
  OrigCallDirection: "outgoing"
  RemoteURI: "firstname.lastname@company.com"
  CallId: 89
  CauseCode: 0
  CauseOrigin: SIP
** end
```

## User documentation on the Cisco web site

User documentation for the Cisco TelePresence products is available at

▶ <http://www.cisco.com/go/telepresence/docs>

Choose a product category in the right pane until you find the correct product. This is the path you have to follow:

*Collaboration Endpoints >*

*Collaboration Desk Endpoints*

Alternatively, use the following short-link to find the documentation: ▶ [www.cisco.com/go/dx-docs](http://www.cisco.com/go/dx-docs)

The documents are organized in the following categories:

### ***Install and Upgrade > Install and Upgrade Guides***

- *Installation guides:* How to install the product
- *Getting started guide:* Initial configurations required to get the system up and running
- *RCSI guide:* Regulatory compliance and safety information

### ***Maintain and Operate > Maintain and Operate Guides***

- *Getting started guide:* Initial configurations required to get the system up and running
- *Administrator guide:* Information required to administer your product

### ***Maintain and Operate > End-User Guides***

- *User guides:* How to use the product
- *Quick reference guides:* How to use the product

### ***Reference Guides | Command references***

- *API reference guides:* Reference guide for the Application Programmer Interface (API)

### ***Reference Guides > Technical References***

- *CAD drawings:* 2D CAD drawings with measurements

### ***Software Downloads, Release and General Information > Licensing Information***

- *Open source documentation:* Licenses and notices for open source software used in this product

### ***Software Downloads, Release and General Information > Release Notes***

- *Software release notes*

### Intellectual property rights

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

All printed copies and duplicate soft copies are considered un-Controlled copies and the original on-line version should be referred to for latest version.

Cisco has more than 200 offices worldwide. Addresses, phone numbers, and fax numbers are listed on the Cisco website at [www.cisco.com/go/offices](http://www.cisco.com/go/offices).

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: [www.cisco.com/go/trademarks](http://www.cisco.com/go/trademarks). Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1110R)

### Cisco contacts

On our web site you will find an overview of the worldwide Cisco contacts.

Go to: [▶ http://www.cisco.com/web/siteassets/contacts](http://www.cisco.com/web/siteassets/contacts)

Corporate Headquarters

Cisco Systems, Inc.

170 West Tasman Dr.

San Jose, CA 95134 USA