



Hardware Redundancy and Node Administration Commands

This module describes the commands used to manage the hardware redundancy, power, and administrative status of the nodes on a router running Cisco IOS XR software.

- [fpd auto-reload \(Cisco IOS XR 64-bit\), on page 2](#)
- [fpd auto-upgrade, on page 3](#)
- [hw-module reset auto, on page 4](#)
- [hw-module fault-recovery, on page 5](#)
- [power-mgmt redundancy, on page 6](#)
- [power-mgmt action, on page 7](#)
- [show environment, on page 8](#)
- [show fpd package, on page 12](#)
- [show hw-module fpd, on page 15](#)
- [show hw-module profile, on page 19](#)
- [show inventory, on page 20](#)
- [show led, on page 23](#)
- [show operational, on page 25](#)
- [show platform, on page 27](#)
- [show redundancy, on page 29](#)
- [show version, on page 31](#)

fpd auto-reload (Cisco IOS XR 64-bit)

To enable or disable automatic reload of a line card after successful FPD upgrade, use the **fpd auto-reload** command in XR Config mode and System Admin Config mode.

fpd auto-reload { **enable** | **disable** }

Syntax Description	
enable	Enables LC auto reload after FPD auto upgrade.
disable	Disables LC auto reload after FPD auto upgrade.

Command Default None.

Command Modes XR Config mode
System Admin Config mode

Command History	Release	Modification
	Release 7.0.1	This command was introduced.

Usage Guidelines This command is supported on Cisco IOS XR 64-bit OS.

Task ID	Task ID	Operation
	system read, write	

Examples

The following example shows how to enable automatic LC reload after successful FPD upgrades:

```
Router# configure
Router(config)# fpd auto-reload enable
```

fpd auto-upgrade

To enable the automatic upgrade of FPD images during a software upgrade, use the **fpd auto-upgrade** command in XR Config mode and System Admin Config mode. To disable automatic FPD upgrades, use the **no** form of this command.

```
fpd auto-upgrade { enable | disable }
```

Syntax Description

enable Enables FPD auto upgrade.

disable Disables FPD auto upgrade.

Command Default

FPD images are not automatically upgraded.

Command Modes

XR Config mode

System Admin Config mode

Command History

Release	Modification
Release 7.0.1	This command was introduced.

Usage Guidelines

By default automatic upgrades of the FPD images are not performed during a software upgrade. Once the **fpd auto-upgrade** command is enabled, when you upgrade the software and an FPD upgrade is required, the FPD upgrade is done automatically before the router is rebooted. The automatic FPD upgrade works only if the FPD image is upgraded together with the mini installation PIE. For example, use the **install add** and **install activate** commands as shown here:

```
Router# install add ncs5500-mp1s-1.0.0.0-r244142I.x86_64.rpm
Router# install activate ncs5500-mp1s-1.0.0.0-r244142I.x86_64.rpm
```

Task ID

Task ID	Operation
system	read, write

Examples

The following example shows how to enable automatic FPD upgrades:

```
Router# configure
Router(config)# fpd auto-upgrade enable
```

hw-module reset auto

To reset a specific node, use the **hw-module reset auto** command in administration configuration mode. To disable the reset feature on a specific node, use the **no** form of this command.

```
hw-module reset auto [disable] location node-id
no hw-module reset auto [disable] location node-id
```

Syntax Description	disable	location <i>node-id</i>
	Disables the node reset feature on the specified node.	Identifies the node you want to reload. The <i>node-id</i> argument is entered in the <i>rack/slot</i> notation.

Command Default The node reset feature is enabled for all nodes.

Command Modes Administration configuration

Command History	Release	Modification
	Release 7.0.1	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **hw-module reset auto** command is used to reload Cisco IOS XR software on a specific node. The node reloads with the current running configuration and active software set for that node.

Task ID	Task ID	Operations
	root-system	read, write
	root-lr	read, write

The following example shows how to reload a node:

```
Router# configure
Router(config)# hw-module reset auto location 0/2/CPU0

RP/0/RP0/CPU0:router# RP/0/RP0/CPU0:Apr 2 22:04:43.659 : shelfmgr[294]:
%S HELFMGR-3-USER_RESET : Node 0/2/CPU0 is reset due to user reload request
```

hw-module fault-recovery

To configure the number of times a fault recovery can take place before permanently shutting down a line card, fabric card, shelf controller, or a route processor, use the **hw-module fault-recovery** command in System Admin mode.

hw-module fault-recovery location *hw-module-location* **count** *count*

Syntax Description	location	
	<i>hw-module-location</i>	Specifies the hardware module for which fault recovery limit is configured. The <i>hw-module-location</i> argument is expressed in the rack/slot/module notation.
	count <i>count</i>	Specifies the number of times a hardware module can attempt fault recovery before permanently shutting down. The <i>count</i> value can have range from 1 to 3.

Command Default This feature is disabled by default.

Command Modes System Admin Config

Command History	Release	Modification
	Release 24.3.1	The command was introduced.

Usage Guidelines You must enable this command for each location. To apply this configuration to all the locations, specify each location individually and then save your changes. The router prompt displays the *location all* option, but it is not functional.

Task ID	Task ID	Operation
	config-services	read,write

The configuration example shows the fault recovery attempts on the fabric card FC0:

```
Router#configure
Router (config)#hw-module fault-recovery location 0/FC0 count 1
Router (config)#commit
```

power-mgmt redundancy

To control the power budget so as to not exceed the power capacity, use the **power-mgmt redundancy-num-pms** command. To restore default (N+1) power module redundancy, use the **no** form of this command.

By default, power module redundancy is set to (N+1). There is no power tray level redundancy.

```
power-mgmt redundancy-num-pms [ integer ] location { node-id }
no power-mgmt redundancy-num-pms location { node-id }
```

Syntax Description

<i>integer</i>	Number of redundant power modules that the user wants to configure. The total number of functioning power modules in the system is at least <i>integer</i> number more than the number of power modules needed to support the power required for all the cards in the system. Range of <i>integer</i> is from 0 to 8. 0 means no power redundancy is required.
location { <i>node-id</i> all }	Specifies the location of the module. The <i>node-id</i> argument is expressed in the <i>rack/slot</i> notation. Use the all keyword to indicate all nodes.

Command Default

The Cisco ASR9000 router family has one logical power shelf consisting of one or more power trays, where each power tray contains three or four power modules.

Command Modes

System Admin Config

Command History

Release	Modification
Release 7.0.1	This command was introduced.

Usage Guidelines

This command is available in Cisco IOS XR 64 bit OS.

If the system is planned to have power module redundancy (N+x), then this command can be used to set the number of power modules required for power redundancy.

This example shows how to configure power module level redundancy:

```
sysadmin-vm:0_RP0(config)# power-mgmt redundancy-num-pms 2
Mon Apr 29 11:46:18.885 UTC+00:00
```

power-mgmt action

To disable the power budget control, use the **power-mgmt action disable** command in the System Admin Config mode.

power-mgmt action disable

Syntax Description	disable	Disables the power budget control.
---------------------------	----------------	------------------------------------

Command Default	Power budget control is set to (N+1) and enabled by default.
------------------------	--

Command Modes	System Admin Config
----------------------	---------------------

Command History	Release	Modification
	Release 7.0.1	This command was introduced.

Usage Guidelines	This command is available in Cisco IOS XR 64 bit OS.
-------------------------	--

Power-management action is done at the chassis level.

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The power manager automatically calculates power required for each card. The system will only power up line cards if there is sufficient power. Use the **power-mgmt action disable** command to disable enforcement of power budgeting line card boot requests. This is not recommended, allowing for situations where chassis can overdraw current, causing instability or immediate chassis reset.

Use the **show environment** command with the **power** option to display power related information.

Use show power budge profile to view power requirements for each card type.

Before a card powers up its basic or upper layers, it must request budget. If that budget is not available, the boot request is denied.

If **power-mgmt action** command is enabled, it only prevents previously unpowered line cards from coming up in the event of low power budget scenarios. Reloading an operational line card cannot release its reserved budget. Therefore, a line card can be reloaded, even in low power budget scenarios, and allowed to return to operational. If configured with **power-mgmt action disable** command, line cards can always be given an allocated power budget and allowed to boot, regardless of available power.

This example shows you how to disable the chassis power management control:

```
sysadmin-vm:0_RP0# config
sysadmin-vm:0_RP0(config)# power-mgmt action disable
```

show environment

To display environmental monitor parameters for the system, use the **show environment** command in the appropriate mode.

Syntax Description		
	all	(Optional) Displays information for all environmental monitor parameters.
	fans	(Optional) Displays information about the fans.
	power-supply	(Optional) Displays power supply voltage and current information.
	temperatures	(Optional) Displays system temperature information.
	voltages	(Optional) Displays system voltage information.
	<i>node-id</i>	(Optional) Node whose information you want to display. The <i>node-id</i> argument is expressed in the <i>rack/slot</i> notation.

Command Default All environmental monitor parameters are displayed.

Command Modes System Admin EXEC

Command History	Release	Modification
	Release 7.0.1	This command was introduced.

Usage Guidelines The **show environment** command displays information about the hardware that is installed in the system, including fans, LEDs, power supply voltage, and current information and temperatures.

Task ID	Task ID	Operations
	system	read

The following example shows sample output from the **show environment** command with the **temperatures** keyword:

```
sysadmin-vm:0_RP0# show environment temperatures
Mon Apr 29 11:24:32.508 UTC+00:00
=====
Location  TEMPERATURE          Value  Crit Major Minor Minor Major Crit
          Sensor              (deg C) (Lo) (Lo) (Lo) (Hi) (Hi) (Hi)
```


0/0

```

CPU_PVCCIN_TEMP          27   -10   -5    0  105  115  125
CPU_VDDQ_TEMP            26   -10   -5    0  105  115  125
P1V05_CPU_TEMP           26   -10   -5    0  105  115  125
P1V0_ALD_CORE_AVDD_TEMP  26   -10   -5    0  105  115  125
ALDRIN_DIE_TEMP          31   -10   -5    0  103  105  110
P1V2_JER0_HBM_VDDO_TEMP  26   -10   -5    0  105  115  125
P1V2_JER0_HBM_VDCC_TEMP  25   -10   -5    0  105  115  125
P0V8_J2C_TRVDD_TEMP      34   -10   -5    0  105  115  125
J2C_VDDC_TEMP            37   -10   -5    0  105  115  125
J2C_DIE_TEMP             38   -10   -5    0  103  105  110
J2C_TMP421_LOCAL_TEMP    26   -10   -5    0  110  117  125
P0V8_PHY234_VDDC_TEMP    33   -10   -5    0  105  115  125
P0V8_PHY01_VDDC_TEMP     35   -10   -5    0  105  115  125
P1V15_PHY_AVDD12_TEMP    35   -10   -5    0  105  115  125
P3V3_SFP_TEMP            33   -10   -5    0  105  115  125
MT3722_DIE_CHIP0_TEMP    47   -10   -5    0  103  105  110
MT3722_DIE_CHIP1_TEMP    47   -10   -5    0  103  105  110
MT3722_DIE_CHIP2_TEMP    43   -10   -5    0  103  105  110
MT3722_DIE_CHIP3_TEMP    41   -10   -5    0  103  105  110
MT3722_DIE_CHIP4_TEMP    44   -10   -5    0  103  105  110
J2C_HBM_DIE_TEMP         30   -10   -5    0   90   93   95
CPU                       31   -10   -5    0   90   96  102

```

show environment temperatures Field Descriptions describes the significant fields shown in the display.

Table 1: show environment temperatures Field Descriptions

Field	Description
R/S/I	Rack number, slot number, and interface for which information is displayed, in the format <i>rack/slot</i> .
Modules	Module for which temperature information is displayed.
Inlet Temperature (deg C)	Current temperature of the inlet sensor, in degrees Celsius. Note The inlet temperature corresponds to the room air temperature entering the router.
Exhaust Temperature (deg C)	Current temperature of the exhaust sensor, in degrees Celsius. Note The exhaust temperature corresponds to the air being exhausted from the router.
Hotspot Temperature (deg C)	Current temperature of the hotspot, in degrees Celsius.

show environment leds Field Descriptions describes the significant fields shown in the display.

Table 2: show environment leds Field Descriptions

Field	Description
<i>rack_num/slot_num/*</i> :	Rack number and slot number where the node resides.

Field	Description
Module (host) LED status says:	Current LED status of the specified node.

The following example shows sample output from the **show environment** command with the **power-supply** keyword:

```

sysadmin-vm:0_RP0#show environment power
Mon Apr 29 11:25:39.863 UTC+00:00
=====
CHASSIS LEVEL POWER INFO: 0
=====
Total output power capacity (N + 0)      : 18000W + 0W
Total output power required              : 8615W
Total power input                        : 3761W
Total power output                       : 3388W

Power Group 0:
=====
Power  Supply  -----Input-----  -----Output---  Status
Module  Type      Volts   Amps   Volts   Amps
=====
0/PM0   3kW-AC    227.3   2.7   12.2   45.7   OK
0/PM1   3kW-AC    227.3   2.4   12.2   39.0   OK
0/PM2   3kW-AC    227.9   2.7   12.2   45.2   OK
0/PM3   3kW-AC    228.4   2.7   12.2   45.7   OK

Total of Power Group 0:      2391W/ 10.5A      2142W/175.6A

Power Group 1:
=====
Power  Supply  -----Input-----  -----Output---  Status
Module  Type      Volts   Amps   Volts   Amps
=====
0/PM4   3kW-AC    228.2   3.3   12.2   56.6   OK
0/PM5   3kW-AC    228.4   2.7   12.2   45.5   OK

Total of Power Group 1:      1370W/ 6.0A      1246W/102.1A

=====
Location  Card Type          Power  Power  Status
          Type          Allocated  Used
          Type          Watts    Watts
=====
0/0       NC57-48Q2D-S       500    157    ON
0/1       NC55-36X100G-A-SE  1050   500    ON
0/2       NC57-48Q2D-SE-S    500    181    ON
0/3       NC55-24X100G-SE    940    488    ON
0/4       -                  25     -      RESERVED
0/5       NC57-36H6D-S       1000   500    ON
0/6       NC57-48Q2D-SE-S    500    195    ON
0/7       NC55-MOD-A-S       600    181    ON
0/RP0     NC55-RP2-E         80     53     ON
0/RP1     NC55-RP-E          80     40     ON
0/FC0     -                  25     -      RESERVED
0/FC1     NC55-5508-FC2     320    183    ON
0/FC2     NC55-5508-FC2     320    183    ON
0/FC3     NC55-5508-FC2     320    185    ON
0/FC4     -                  25     -      RESERVED
0/FC5     NC55-5508-FC2     320    180    ON
0/FT0     NC55-5508-FAN2    660    85     ON
0/FT1     NC55-5508-FAN2    660    87     ON
0/FT2     NC55-5508-FAN2    660    82     ON

```

0/SC0	NC55-SC	15	15	ON
0/SC1	NC55-SC	15	15	ON

This table describes the significant fields shown in the display.

Table 3: show environment power-supply Field Descriptions

Field	Description
R/S/I	Rack number, slot number, and interface for which information is displayed, in the format PEM/Power Module/* (for example 0/PM0/*).
Modules	Module for which power information is displayed.
Capacity	Power capacity of each power module in Watts.
Status	Operational status of power modules.
Power Draw	Real (measured) power drawn from each power module.
Voltage	Real (measured) power module voltage.
Current	Real (measured) power module current draw.
Power Shelves Type	AC or DC.
Total Power Capacity	Sum of the power capacity of each of the modules installed in the chassis.
Usable Power Capacity	Sum of the power capacity of each of the powered and operational power modules installed in the chassis.
Supply Failure Protected Capacity	Protected power capacity of the chassis with power module redundancy (ASR 9010 AC 3+3, ASR 9010 DC 5+1, ASR 9006 AC 2+1, ASR 9010 DC 2+1).
Feed Failure Protected Capacity	Feed protected power capacity. This value applies to the ASR 9010 AC system only.
Worst Case Power Used	Sum of the estimated power draw of each of the load modules in the chassis. Load modules can be fan trays, RSPs and line cards.
Worst Case Power Available	Usable power capacity minus the worst case power used.
Supply Protected Capacity Available	Supply failure protected capacity minus the worst case power used.
Feed Protected Capacity Available	Feed failure protected capacity minus the worst case power used.
Power Budget Enforcement	This field displays the Power Budget Enforcement status as Enabled or Disabled.
Power Budget Mode	This field displays the power redundancy mode used (for example, N+1).
N+1 Supply Failure Protected Capacity	This field represents the Supply Protected Power capacity of the chassis with power module redundancy in N+1 mode.

show fpd package

To display information about the supported Modular Port Adapters (MPAs) and their interface processors for your current software release. This command provides details on the required Field Programmable Device (FPD) images and the minimum hardware requirements for these modules. Use the **show fpd package** command in EXEC mode.

show fpd package

Syntax Description This command has no keywords or arguments.

Command Default No default behavior or values

Command Modes EXEC

Command History

Release	Modification
Release 7.0.1	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

If there are multiple FPD images for your card, use the **show fpd package** command to determine which FPD image to use if you only want to upgrade a specific FPD type.

Task ID

Task ID	Operations
sysmgr	read

The following example shows sample output from the **show fpd package** command:

```
RP/0/RP0/CPU0:router#show fpd package
Mon Apr 29 14:04:49.225 IST
```

```
=====
                                Field Programmable Device Package
                                =====
Card Type          FPD Description          Req   SW   Min Req  Min Req
=====  =====  =====  =====  =====  =====
NC55-12X100G-SE-PR  Bootloader (A)          YES   1.20   1.20     0.0
                  IOFPGA (A)              YES   0.12   0.12     0.0
                  MIFPGA                  YES   0.03   0.03     0.0
                  SATA-INTEL_240G (A)     NO   1132.00 1132.00   0.0
                  SATA-INTEL_480G (A)     NO   1132.00 1132.00   0.0
                  SATA-M500IT-MC (A)      NO    3.00    3.00     0.0
                  SATA-M500IT-MU-A (A)    NO    5.00    5.00     0.0
                  SATA-M500IT-MU-B (A)    NO    4.00    4.00     0.0
                  SATA-M5100 (A)        NO   75.00   75.00    0.0
                  SATA-M600-MCT (A)     NO    5.00    5.00     0.0
```

	SATA-M600-MU (A)	NO	6.00	6.00	0.0
	SATA-Micron (A)	NO	1.00	1.00	0.0
	SATA-SMART-128G (A)	NO	1241.00	1241.00	0.0

NC55-12X100GE-PROT	Bootloader (A)	YES	1.22	1.22	0.0
	IOFPGA (A)	YES	0.15	0.15	0.0
	MIFPGA	YES	0.09	0.09	0.0
	SATA-INTEL_240G (A)	NO	1132.00	1132.00	0.0
	SATA-INTEL_480G (A)	NO	1132.00	1132.00	0.0
	SATA-M500IT-MC (A)	NO	3.00	3.00	0.0
	SATA-M500IT-MU-A (A)	NO	5.00	5.00	0.0
	SATA-M500IT-MU-B (A)	NO	4.00	4.00	0.0
	SATA-M5100 (A)	NO	75.00	75.00	0.0
	SATA-M600-MCT (A)	NO	5.00	5.00	0.0
	SATA-M600-MU (A)	NO	6.00	6.00	0.0
	SATA-Micron (A)	NO	1.00	1.00	0.0
	SATA-SMART-128G (A)	NO	1241.00	1241.00	0.0

NC55-18H18F	Bootloader (A)	YES	1.20	1.20	0.0
	IOFPGA (A)	YES	0.22	0.22	0.0
	MIFPGA	YES	0.03	0.03	0.0
	SATA-INTEL_240G (A)	NO	1132.00	1132.00	0.0
	SATA-INTEL_480G (A)	NO	1132.00	1132.00	0.0
	SATA-M500IT-MC (A)	NO	3.00	3.00	0.0
	SATA-M500IT-MU-A (A)	NO	5.00	5.00	0.0
	SATA-M500IT-MU-B (A)	NO	4.00	4.00	0.0
	SATA-M5100 (A)	NO	75.00	75.00	0.0
	SATA-M600-MCT (A)	NO	5.00	5.00	0.0
	SATA-M600-MU (A)	NO	6.00	6.00	0.0
	SATA-Micron (A)	NO	1.00	1.00	0.0
	SATA-SMART-128G (A)	NO	1241.00	1241.00	0.0

NC55-24H12F-SE	Bootloader (A)	YES	1.20	1.20	0.0
	IOFPGA (A)	YES	0.09	0.09	0.0
	MIFPGA	YES	0.03	0.03	0.0
	SATA-INTEL_240G (A)	NO	1132.00	1132.00	0.0
	SATA-INTEL_480G (A)	NO	1132.00	1132.00	0.0
	SATA-M500IT-MC (A)	NO	3.00	3.00	0.0
	SATA-M500IT-MU-A (A)	NO	5.00	5.00	0.0
	SATA-M500IT-MU-B (A)	NO	4.00	4.00	0.0
	SATA-M5100 (A)	NO	75.00	75.00	0.0
	SATA-M600-MCT (A)	NO	5.00	5.00	0.0
	SATA-M600-MU (A)	NO	6.00	6.00	0.0
	SATA-Micron (A)	NO	1.00	1.00	0.0
	SATA-SMART-128G (A)	NO	1241.00	1241.00	0.0

NC55-24X100G-SE	Bootloader (A)	YES	1.20	1.20	0.0
	IOFPGA (A)	YES	0.13	0.13	0.0
	MIFPGA	YES	0.03	0.03	0.0
	SATA-INTEL_240G (A)	NO	1132.00	1132.00	0.0
	SATA-INTEL_480G (A)	NO	1132.00	1132.00	0.0
	SATA-M500IT-MC (A)	NO	3.00	3.00	0.0
	SATA-M500IT-MU-A (A)	NO	5.00	5.00	0.0
	SATA-M500IT-MU-B (A)	NO	4.00	4.00	0.0
	SATA-M5100 (A)	NO	75.00	75.00	0.0
	SATA-M600-MCT (A)	NO	5.00	5.00	0.0
	SATA-M600-MU (A)	NO	6.00	6.00	0.0
	SATA-Micron (A)	NO	1.00	1.00	0.0
	SATA-SMART-128G (A)	NO	1241.00	1241.00	0.0

NC55-32T16Q4H-A	Bootloader (A)	YES	0.05	0.05	0.0
	DBFPGA (A)	YES	0.14	0.14	0.0
	IOFPGA (A)	YES	0.93	0.93	0.0
	MIFPGA	YES	0.60	0.60	0.0

show fpd package

SATA-INTEL_240G (A)	NO	1132.00	1132.00	0.0	?
SATA-INTEL_480G (A)	NO	1132.00	1132.00	0.0	
SATA-M500IT-MC (A)	NO	3.00	3.00	0.0	
SATA-M500IT-MU-A (A)	NO	5.00	5.00	0.0	
SATA-M500IT-MU-B (A)	NO	4.00	4.00	0.0	
SATA-M5100 (A)	NO	75.00	75.00	0.0	
SATA-M600-MCT (A)	NO	5.00	5.00	0.0	
SATA-M600-MU (A)	NO	6.00	6.00	0.0	
SATA-Micron (A)	NO	1.00	1.00	0.0	
SATA-SMART-128G (A)	NO	1241.00	1241.00	0.0	
TimingIC-A	YES	7.216	7.216	0.0	
TimingIC-B	YES	7.216	7.216	0.0	

This table describes the significant fields shown in the display:

Table 4: show fpd package Field Descriptions

Field	Description
Card Type	Module part number.
FPD Description	Description of all FPD images available for the line card.
Type	Hardware type. Possible types can be: <ul style="list-style-type: none"> • MPA - Modular Port Adapters • LC - Line card
Subtype	FPD subtype. These values are used in the upgrade hw-module fpd command to indicate a specific FPD image type to upgrade.
SW Version	FPD software version recommended for the associated module running the current Cisco IOS XR software.
Min Req SW Vers	Minimum required FPD image software version to operate the card. Version 0.0 indicates that a minimum required image was not programmed into the card.
Min Req HW Vers	Minimum required hardware version for the associated FPD image. A minimum hardware requirement of version 0.0 indicates that all hardware can support this FPD image version.



Note In the **show fpd package** command output, the “subtype” column shows the FPDs that correspond with each line card image. To upgrade a specific FPD with the **upgrade hw-module fpd** command, replace the *fpga-type* argument with the appropriate FPD from the “subtype” column, as shown in the following example:

```
Router# upgrade hw-module fpd fpga2 location 0/3/1 reload
```

show hw-module fpd

To display field-programmable device (FPD) compatibility for all modules or a specific module, use the **show hw-module fpd** command in the EXEC or administration EXEC mode.

show hw-module fpd location {*node-id* | **all**}

Syntax Description	location { <i>node-id</i> all } Specifies the location of the module. The <i>node-id</i> argument is expressed in the <i>rack/slot</i> notation. Use the all keyword to indicate all nodes.						
Command Default	No default behavior or values						
Command Modes	EXEC Administration EXEC mode						
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 7.0.1</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 7.0.1	This command was introduced.		
Release	Modification						
Release 7.0.1	This command was introduced.						
Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.						
Task ID	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operations</th> </tr> </thead> <tbody> <tr> <td>sysmgr</td> <td>read</td> </tr> <tr> <td>root-lr</td> <td>read</td> </tr> </tbody> </table>	Task ID	Operations	sysmgr	read	root-lr	read
Task ID	Operations						
sysmgr	read						
root-lr	read						

The following is sample output from the **show hw-module fpd**:

```
Router#show hw-module fpd
Mon Apr 29 14:30:53.049 IST

Auto-upgrade:Disabled

                                FPD Versions
                                =====
Location  Card type                HWver FPD device      ATR Status  Running  Programd
-----
0/0      NC57-48Q2D-S            0.2   MIFPGA              CURRENT     0.99     0.21
0/0      NC57-48Q2D-S            1.0   TimingIC-A          CURRENT     7.216    7.216
0/0      NC57-48Q2D-S            1.0   TimingIC-B          CURRENT     7.216    7.216
0/0      NC57-48Q2D-S            0.2   ALDRINFPGA          CURRENT     1.06     1.06
0/0      NC57-48Q2D-S            0.2   Bootloader           CURRENT     1.00     1.00
0/0      NC57-48Q2D-S            0.2   DBFPGA               CURRENT     0.14     0.14
```

show hw-module fpd

0/0	NC57-48Q2D-S	0.2	IOFPGA	CURRENT	0.105	0.105
0/0	NC57-48Q2D-S	0.2	SATA-Micron	CURRENT	1.00	1.00
0/1	NC55-36X100G-A-SE	1.0	MIFPGA	CURRENT	0.03	0.03
0/1	NC55-36X100G-A-SE	1.0	Bootloader	CURRENT	0.15	0.15
0/1	NC55-36X100G-A-SE	1.0	DBFPGA	CURRENT	0.14	0.14
0/1	NC55-36X100G-A-SE	1.0	IOFPGA	CURRENT	0.26	0.26
0/2	NC57-48Q2D-SE-S	0.2	MIFPGA	CURRENT	0.21	0.21
0/2	NC57-48Q2D-SE-S	1.0	TimingIC-A	CURRENT	7.216	7.216
0/2	NC57-48Q2D-SE-S	1.0	TimingIC-B	CURRENT	7.216	7.216
0/2	NC57-48Q2D-SE-S	0.2	ALDRINFPGA	CURRENT	1.06	1.06
0/2	NC57-48Q2D-SE-S	0.2	Bootloader	CURRENT	1.00	1.00
0/2	NC57-48Q2D-SE-S	0.2	DBFPGA	CURRENT	0.14	0.14
0/2	NC57-48Q2D-SE-S	0.2	IOFPGA	CURRENT	0.105	0.105
0/2	NC57-48Q2D-SE-S	0.2	SATA-Micron	CURRENT	1.00	1.00
0/3	NC55-24X100G-SE	1.0	MIFPGA	CURRENT	0.03	0.03
0/3	NC55-24X100G-SE	1.0	Bootloader	CURRENT	1.20	1.20
0/3	NC55-24X100G-SE	1.0	IOFPGA	CURRENT	0.13	0.13
0/3	NC55-24X100G-SE	1.0	SATA-M600-MCT	CURRENT	5.00	5.00
0/5	NC57-36H6D-S	1.0	MIFPGA	CURRENT	0.40	0.40
0/5	NC57-36H6D-S	1.0	TimingIC-A	CURRENT	7.216	7.216
0/5	NC57-36H6D-S	1.0	TimingIC-B	CURRENT	7.216	7.216
0/5	NC57-36H6D-S	1.0	Bootloader	CURRENT	0.02	0.02
0/5	NC57-36H6D-S	1.0	DBFPGA	CURRENT	0.14	0.14
0/5	NC57-36H6D-S	1.0	IOFPGA	CURRENT	0.47	0.47
0/5	NC57-36H6D-S	1.0	SATA-Micron	CURRENT	1.00	1.00
0/6	NC57-48Q2D-SE-S	0.2	MIFPGA	CURRENT	0.21	0.21
0/6	NC57-48Q2D-SE-S	1.0	TimingIC-A	CURRENT	7.216	7.216
0/6	NC57-48Q2D-SE-S	1.0	TimingIC-B	CURRENT	7.216	7.216
0/6	NC57-48Q2D-SE-S	0.2	ALDRINFPGA	CURRENT	1.06	1.06
0/6	NC57-48Q2D-SE-S	0.2	Bootloader	CURRENT	1.00	1.00
0/6	NC57-48Q2D-SE-S	0.2	DBFPGA	CURRENT	0.14	0.14
0/6	NC57-48Q2D-SE-S	0.2	IOFPGA	CURRENT	0.105	0.105

0/6	NC57-48Q2D-SE-S	0.2	SATA-Micron	CURRENT	1.00	1.00
0/7	NC55-MOD-A-S	0.302	MIFPGA	CURRENT	0.16	0.16
0/7	NC55-MOD-A-S	0.302	Bootloader	CURRENT	1.03	1.03
0/7	NC55-MOD-A-S	0.302	DBFPGA	CURRENT	0.14	0.14
0/7	NC55-MOD-A-S	0.302	IOFPGA	CURRENT	0.14	0.14
0/7	NC55-MOD-A-S	0.302	SATA-M600-MCT	CURRENT	5.00	5.00
0/RP0	NC55-RP2-E	1.0	TimingIC-A	CURRENT	7.216	7.216
0/RP0	NC55-RP2-E	1.0	TimingIC-B-0	CURRENT	7.216	7.216
0/RP0	NC55-RP2-E	1.0	TimingIC-B-1	CURRENT	7.216	7.216
0/RP0	NC55-RP2-E	1.0	Bootloader	CURRENT	0.09	0.09
0/RP0	NC55-RP2-E	1.0	IOFPGA	CURRENT	0.50	0.50
0/RP0	NC55-RP2-E	1.0	OMGFPGA	CURRENT	0.52	0.52
0/RP0	NC55-RP2-E	1.0	SATA-Micron	CURRENT	1.00	1.00
0/RP1	NC55-RP-E	1.0	Bootloader	CURRENT	1.24	1.24
0/RP1	NC55-RP-E	1.0	IOFPGA	CURRENT	0.23	0.23
0/RP1	NC55-RP-E	1.0	OMGFPGA	CURRENT	0.61	0.61
0/RP1	NC55-RP-E	1.0	SATA-M5100	CURRENT	75.00	75.00
0/FC1	NC55-5508-FC2	1.0	Bootloader	CURRENT	1.80	1.80
0/FC1	NC55-5508-FC2	1.0	IOFPGA	CURRENT	0.19	0.19
0/FC1	NC55-5508-FC2	1.0	SATA-INTEL_240G	CURRENT	1132.00	1132.00
0/FC2	NC55-5508-FC2	1.0	Bootloader	CURRENT	1.80	1.80
0/FC2	NC55-5508-FC2	1.0	IOFPGA	CURRENT	0.19	0.19
0/FC2	NC55-5508-FC2	1.0	SATA-INTEL_240G	CURRENT	1132.00	1132.00
0/FC3	NC55-5508-FC2	1.0	Bootloader	CURRENT	1.80	1.80
0/FC3	NC55-5508-FC2	1.0	IOFPGA	CURRENT	0.19	0.19
0/FC3	NC55-5508-FC2	1.0	SATA-INTEL_240G	CURRENT	1132.00	1132.00
0/FC5	NC55-5508-FC2	1.0	Bootloader	CURRENT	1.80	1.80
0/FC5	NC55-5508-FC2	1.0	IOFPGA	CURRENT	0.19	0.19
0/FC5	NC55-5508-FC2	1.0	SATA-M5100	CURRENT	75.00	75.00
0/SC0	NC55-SC	1.4	Bootloader	CURRENT	1.74	1.74
0/SC0	NC55-SC	1.4	IOFPGA	CURRENT	0.11	0.11
0/SC1	NC55-SC	1.4	Bootloader	CURRENT	1.74	1.74

```
0/SC1      NC55-SC          1.4  IOFPGA          CURRENT    0.11      0.11
fpd
```

Table 5: show hw-module fpd Field Descriptions

Field	Description
Location	Module location.
Card Type	Module part number.
HW Version	Hardware model version for the module.
FPD device	Specific FPD device on the card.
ATR	The attribute of the FPD, which usually indicates its current status.
Status	Currently running FPD image status.
FPD Versions Running	Currently running FPD image version.
FPD Versions Programd	The version of the FPD that is programmed or available for upgrade.

show hw-module profile

To display the active profiles on the router, use the **show hw-module profile** command in EXEC mode.

```
show hw-module profile { mdb-scale | npu-operating-mode }
```

Syntax Description	Command	Description
	mdb-scale	Display mdb scale profile
	npu-operating-mode	Display NPU operating mode

Command Modes EXEC

Command History	Release	Modification
	Release 7.0.1	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **show hw-module profile** command displays only active profiles. If a profile has been configured and the line card has not be reloaded since the configuration, the profile is not active. Use the **show running-config hw-module profile** command to view configured profiles.

Task ID	Task ID	Operation
	root-lr	read

This example shows sample output from the **show hw-module profile** command with the **mdb-scale** keyword:

```
RP/0/RP0/CPU0:routerS#show hw-module profile mdb-scale
Mon Apr 29 14:33:14.412 IST
MDB scale profile: N/A
```

This example shows sample output from the **show hw-module profile** command with the **npu-operating-mode** keyword:

```
RP/0/RP0/CPU0:router#show hw-module profile npu-operating-mode
Mon Apr 29 14:34:35.151 IST
NPU Operation mode: Compatibility Mode
```

show inventory

To retrieve and display information about all the Cisco products that are installed in the router, use the **show inventory** command in the Admin EXEC mode or XR EXEC mode.

System Admin EXEC mode Mode

show inventory [**all** | **chassis** | **fan** | **location** { *node-id* } | **power** | **raw**]

XR EXEC Mode

show inventory [*locationspecifier* | **all** | **location** { *locationspecifier* | **all** } | **oid** | **raw**]

Syntax Description

all	(Optional) Displays inventory information for all the physical entities in the chassis.
location { <i>node-id</i> }	(Optional) Displays inventory information for a specific node, or for all nodes in the chassis.
raw	(Optional) Displays raw information about the chassis for diagnostic purposes.
chassis	(Optional) Displays inventory information for the entire chassis.
fan	(Optional) Displays inventory information for the fans.
power	(Optional) Displays inventory information for the power supply.

Command Default

All inventory information for the entire chassis is displayed.

Command Modes

EXEC

Administration EXEC

Command History

Usage Guidelines

Enter the **show inventory** command with the **raw** keyword to display every RFC 2737 entity installed in the router, including those without a PID, unique device identifier (UDI), or other physical identification.

If any of the Cisco products do not have an assigned PID, the output displays incorrect PIDs, and version ID (VID) and serial number (SN) elements may be missing.

For UDI compliance products, the PID, VID, and SN are stored in EEPROM. Use the **show inventory** command to display this information.

The following example shows partial sample output from the **show inventory** command with the **raw** keyword:

```
RP/0/RP0/CPU0:router#show inventory raw
Mon Apr 29 14:37:31.513 IST
NAME: "Rack 0-Line Card Slot 0", DESCR: "NC5 Line Card Slot"
PID: N/A, VID: N/A, SN: N/A

NAME: "0/0", DESCR: "NCS 5700 32x1/10/25G + 16x1/10/25/50G + 2x400G Line Card BASE"
PID: NC57-48Q2D-S, VID: V00, SN: JAE262009MM

NAME: "0/0-MPA bay 0", DESCR: "MPA Container"
PID: N/A, VID: N/A, SN: N/A

NAME: "0/0-MPA bay 1", DESCR: "MPA Container"
```

```
PID: N/A , VID: N/A, SN: N/A

NAME: "0/0-Motherboard", DESCR: "Motherboard Module"
PID: N/A , VID: N/A, SN: N/A

NAME: "0/0-CPU_PVCCIN_IOUT", DESCR: "Current Sensor"
PID: N/A , VID: N/A, SN: N/A

NAME: "0/0-CPU_VDDQ_IOUT", DESCR: "Current Sensor"
PID: N/A , VID: N/A, SN: N/A

NAME: "0/0-P1V05_CPU_IOUT", DESCR: "Current Sensor"
PID: N/A , VID: N/A, SN: N/A

NAME: "0/0-P1V0_ALD_CORE_AVDD_IOUT", DESCR: "Current Sensor"
PID: N/A , VID: N/A, SN: N/A

NAME: "0/0-P1V2_JER0_HBM_VDDO_IOUT", DESCR: "Current Sensor"
PID: N/A , VID: N/A, SN: N/A

NAME: "0/0-P1V2_JER0_HBM_VDDC_IOUT", DESCR: "Current Sensor"
PID: N/A , VID: N/A, SN: N/A

NAME: "0/0-P0V8_J2C_TRVDD_IOUT", DESCR: "Current Sensor"
PID: N/A , VID: N/A, SN: N/A

NAME: "0/0-J2C_VDDC_IOUT1", DESCR: "Current Sensor"
PID: N/A , VID: N/A, SN: N/A

NAME: "0/0-J2C_VDDC_IOUT2", DESCR: "Current Sensor"
PID: N/A , VID: N/A, SN: N/A

NAME: "0/0-CPU_PVCCIN_TEMP", DESCR: "Temperature Sensor"
PID: N/A , VID: N/A, SN: N/A

NAME: "0/0-CPU_VDDQ_TEMP", DESCR: "Temperature Sensor"
PID: N/A , VID: N/A, SN: N/A

NAME: "0/0-P1V05_CPU_TEMP", DESCR: "Temperature Sensor"
PID: N/A , VID: N/A, SN: N/A

NAME: "0/0-P1V0_ALD_CORE_AVDD_TEMP", DESCR: "Temperature Sensor"
PID: N/A , VID: N/A, SN: N/A

NAME: "0/0-ALDRIN_DIE_TEMP", DESCR: "Temperature Sensor"
PID: N/A , VID: N/A, SN: N/A

NAME: "0/0-P1V2_JER0_HBM_VDDO_TEMP", DESCR: "Temperature Sensor"
PID: N/A , VID: N/A, SN: N/A

NAME: "0/0-P1V2_JER0_HBM_VDDC_TEMP", DESCR: "Temperature Sensor"
PID: N/A , VID: N/A, SN: N/A

NAME: "0/0-P0V8_J2C_TRVDD_TEMP", DESCR: "Temperature Sensor"
PID: N/A , VID: N/A, SN: N/A

NAME: "0/0-J2C_VDDC_TEMP", DESCR: "Temperature Sensor"
PID: N/A , VID: N/A, SN: N/A

NAME: "0/0-P12V0_DM1_VOUT", DESCR: "Voltage Sensor"
PID: N/A , VID: N/A, SN: N/A

NAME: "0/0-P3V3_ADVANCE_VOUT", DESCR: "Voltage Sensor"
PID: N/A , VID: N/A, SN: N/A
```

show inventory

```
NAME: "0/0-P2V5_ADVANCE_VOUT", DESCR: "Voltage Sensor"  
PID: N/A , VID: N/A, SN: N/A  
  
NAME: "0/0-P1V2_ADVANCE_VOUT", DESCR: "Voltage Sensor"  
PID: N/A , VID: N/A, SN: N/A  
  
NAME: "0/0-P1V8_ADVANCE_VOUT", DESCR: "Voltage Sensor"  
PID: N/A , VID: N/A, SN: N/A  
  
NAME: "0/0-P1V0_ALD_CORE_VDD_VOUT", DESCR: "Voltage Sensor"  
PID: N/A , VID: N/A, SN: N/A
```

show led

To display LED information for the router, or for a specific LED location, use the **show led** command in Administration EXEC mode.

Syntax Description

Command Default

If no node is specified, information about all LEDs on the router is displayed.

Command Modes

Command History

Usage Guidelines

Enter the **show platform** command to see the location of all nodes installed in the router.

The following example sample output from the **show led** command.

```

sysadmin-vm:0_RP0#show led
Mon Apr 29 09:17:24.120 UTC+00:00
=====
Location  LED Name                               Mode      Color
=====
0
    0-Chassis RP Status                   WORKING   GREEN
    0-Chassis FC Status                   WORKING   GREEN
    0-Chassis LC Status                   WORKING   GREEN
    0-Chassis PM Status                   WORKING   GREEN
    0-Chassis PWR MGMT Status             WORKING   GREEN
    0-Chassis Attention (ATTN)            WORKING   OFF
    0-Chassis FT Status                   WORKING   GREEN
0/0
    0/0-Status (STS)                       WORKING   GREEN
    0/0-Attention (ATTN)                   WORKING   OFF
0/1
    0/1-Status (STS)                       WORKING   GREEN
    0/1-Attention (ATTN)                   WORKING   OFF
0/2
    0/2-Status (STS)                       WORKING   GREEN
    0/2-Attention (ATTN)                   WORKING   OFF
0/3
    0/3-Status (STS)                       WORKING   GREEN
    0/3-Attention (ATTN)                   WORKING   OFF
0/5
    0/5-Status (STS)                       WORKING   GREEN
    0/5-Attention (ATTN)                   WORKING   OFF
0/6
    0/6-Status (STS)                       WORKING   GREEN
    0/6-Attention (ATTN)                   WORKING   OFF
0/7
    0/7-Status (STS)                       WORKING   GREEN
    0/7-Attention (ATTN)                   WORKING   OFF
0/RP0
    0/RP0-Status (STS)                     WORKING   GREEN
    0/RP0-Attention (ATTN)                 WORKING   OFF
    0/RP0-Active (ACT)                     WORKING   GREEN
0/RP1
    0/RP1-Status (STS)                     WORKING   GREEN
    0/RP1-Attention (ATTN)                 WORKING   OFF
    0/RP1-Active (ACT)                     WORKING   AMBER
0/FC1
    0/FC1-Status (STS)                     WORKING   GREEN

```

show led

	0/FC1-Attention (ATTN)	WORKING	OFF
0/FC2	0/FC2-Status (STS)	WORKING	GREEN
	0/FC2-Attention (ATTN)	WORKING	OFF
0/FC3	0/FC3-Status (STS)	WORKING	GREEN
	0/FC3-Attention (ATTN)	WORKING	OFF
0/FC5	0/FC5-Status (STS)	WORKING	GREEN
	0/FC5-Attention (ATTN)	WORKING	OFF
0/FT0	0/FT0-FT Status (FT STS)	WORKING	GREEN
	0/FT0-FC Status (FC STS)	WORKING	GREEN
	0/FT0-Attention (ATTN)	WORKING	OFF
0/FT1	0/FT1-FT Status (FT STS)	WORKING	GREEN
	0/FT1-FC Status (FC STS)	WORKING	GREEN
	0/FT1-Attention (ATTN)	WORKING	OFF
0/FT2	0/FT2-FT Status (FT STS)	WORKING	GREEN
	0/FT2-FC Status (FC STS)	WORKING	GREEN
	0/FT2-Attention (ATTN)	WORKING	OFF
0/PM0	0/PM0-Fail	WORKING	OFF
	0/PM0-OK	WORKING	GREEN
0/PM1	0/PM1-Fail	WORKING	OFF
	0/PM1-OK	WORKING	GREEN
0/PM2	0/PM2-Fail	WORKING	OFF
	0/PM2-OK	WORKING	GREEN
0/PM3	0/PM3-Fail	WORKING	OFF
	0/PM3-OK	WORKING	GREEN
0/PM4	0/PM4-Fail	WORKING	OFF
	0/PM4-OK	WORKING	GREEN
0/PM5	0/PM5-Fail	WORKING	OFF
	0/PM5-OK	WORKING	GREEN
0/SC0	0/SC0-Status (STS)	WORKING	GREEN
	0/SC0-Attention (ATTN)	WORKING	OFF
	0/SC0-Active (ACT)	WORKING	GREEN
0/SC1	0/SC1-Status (STS)	WORKING	GREEN
	0/SC1-Attention (ATTN)	WORKING	OFF

show operational

To display all operational data provided as XML schema, use the **show operational** command in EXEC mode.

show operational *mda-class*[*mda-class*][*mda-class/naming=value*][**descriptive**]

Syntax Description	<p><i>mda-class</i> Name of the management data API (MDA) class to output. To specify a class name in hierarchy, all classes must be specified from the top of the class to the specific class name that you are interested in. MDA classes are case-sensitive.</p> <p>To view all available MDA classes, use the question mark (?) online help function.</p> <p>descriptive Displays more descriptive information.</p>				
Command Default	No default behavior or values				
Command Modes	EXEC mode				
Command History					
Usage Guidelines	<p>To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.</p> <p>Although the show operational command uses the schema database, the command displays the information in a string format like the other show commands. No XML related setups or knowledge is required to use the command.</p>				
Task ID	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operations</th> </tr> </thead> <tbody> <tr> <td>Depends on the MDA class for which you are displaying the information</td> <td>read</td> </tr> </tbody> </table>	Task ID	Operations	Depends on the MDA class for which you are displaying the information	read
Task ID	Operations				
Depends on the MDA class for which you are displaying the information	read				

The following example shows sample output from the **show operational** command. Not all the output is shown.

```
RP/0/RP0/CPU0:router# show operational BGP DefaultVRF GlobalProcessInfo descriptive
[BGP DefaultVRF GlobalProcessInfo]
InStandaloneMode: true[Standalone or Distributed mode]
RouterID: 0.0.0.0[Router ID for the local system]
ConfiguredRouterID: 0.0.0.0[Configured router ID]
LocalAS: 10[Local autonomous system #]
RestartCount: 1[No of times BGP has started]
ISRedistributeIBGPToIGPsEnabled: false[Redistribute iBGP into IGPs enabled]
IsFastExternalFalloverEnabled: true[Fast external fallover enabled]
IsBestpathMissingMEDIsWorstEnabled: false[Bestpath: Treat missing MED as worst]
.
.
.
DefaultLocalPreference: 100[Default local preference]
KeepAliveTime: 60[Default keepalive timer (seconds)]
HoldTime: 180[Default hold timer (seconds)]
GenericScanPeriod: 60[Period (in seconds) of generic scanner runs]
.
.
```

show operational

```
.
VrfIsActive: true[VRF state ]
VrfName: "default"[Name of the VRF ]
```

This example shows sample output from the **show operational** command where only the top-level MDA class is specified. Not all of the output is shown.

```
RP/0/RP0/CPU0:router# show operational Inventory
Mon Apr 29 14:53:48.625 IST
[Inventory]
Entities
  Entity/Name=Rack 0
    Attributes
      InvBasicBag
        Description: NCS5500 8 Slot Single Chassis
        VendorType: 1.3.6.1.4.1.9.12.3.1.3.1682
        Name: Rack 0
        HardwareRevision: V01
        SoftwareRevision: 24.2.1.34I
        SerialNumber: FGE2012067X
        ManufacturerName: Cisco Systems, Inc.
        ModelName: NCS-5508
        assetIdStr: FGE2012067X
        IsFieldReplaceableUnit: true
        CompositeClassCode: 65536
        Alias: FGE2012067X
        UnrecognizedFRU: false
        UniqueID: 8384513
        AllocatedPower: 0
        PowerCapacity: 0
      InvAssetBag
        PartNumber: A0
        ManufacturerAssemblyNumber: 73-17789-01
        ManufacturerAssemblyRevision: A0
        ManufacturerCommonLanguageEquipmentIdentifier: CMMT810BRA
      FRUInfo
        CardAdministrativeState: 2
        PowerAdministrativeState: 2
        CardOperationalState: 2
        CardMonitorState: -1

--More--
```

show platform

To display information and status for each node in the system, use the **show platform** command in EXEC or administration EXEC mode.

System Admin EXEC Mode

```
show platform [ detail | slices ] [ location [node-id] ]
```

XR EXEC Mode

```
show platform
```

Syntax Description	location <i>node-id</i>	Specifies the target node. The <i>node-id</i> argument is entered in the <i>rack/slot</i> notation.
	slices	Displays summary of node forwarding slices.
	detail	Specifies details of node type and state

Command Modes EXEC

Command History	Release	Modification
	Release 5.0.0	This command was introduced.
	Release 5.2.3	The output for the detail keyword captures card failure events and the reason for failure when show platform command is run in System Admin EXEC mode.

Usage Guidelines The **show platform** command provides a summary of the nodes in the system, including node type and status. For NCS 6008, EP1 will be displayed as, **Not allowed online**, until the required license is bought.

The following example shows sample output from the **show platform** command:

```
RP/0/RP0/CPU0:router#show platform
Mon Apr 29 14:55:30.938 IST
Node              Type              State              Config state
-----
0/0/CPU0          NC57-48Q2D-S      IOS XR RUN         NSHUT
0/0/NPU0          Slice             UP
0/1/CPU0          NC55-36X100G-A-SE IOS XR RUN         NSHUT
0/1/NPU0          Slice             UP
0/1/NPU1          Slice             UP
0/1/NPU2          Slice             UP
0/1/NPU3          Slice             UP
0/2/CPU0          NC57-48Q2D-SE-S   IOS XR RUN         NSHUT
0/2/NPU0          Slice             UP
0/3/CPU0          NC55-24X100G-SE   IOS XR RUN         NSHUT
0/3/NPU0          Slice             UP
0/3/NPU1          Slice             UP
0/3/NPU2          Slice             UP
0/3/NPU3          Slice             UP
0/5/CPU0          NC57-36H6D-S      IOS XR RUN         NSHUT
0/5/NPU0          Slice             UP
```

show platform

```

0/6/CPU0          NC57-48Q2D-SE-S      IOS XR RUN           NSHUT
0/6/NPU0          Slice                UP
0/7/CPU0          NC55-MOD-A-S         IOS XR RUN           NSHUT
0/7/NPU0          Slice                UP
0/RP0/CPU0        NC55-RP2-E (Active)  IOS XR RUN           NSHUT
0/RP1/CPU0        NC55-RP-E (Standby)  IOS XR RUN           NSHUT
0/FC1             NC55-5508-FC2       OPERATIONAL          NSHUT
0/FC2             NC55-5508-FC2       OPERATIONAL          NSHUT
0/FC3             NC55-5508-FC2       OPERATIONAL          NSHUT
0/FC5             NC55-5508-FC2       OPERATIONAL          NSHUT
0/FT0             NC55-5508-FAN2      OPERATIONAL          NSHUT
0/FT1             NC55-5508-FAN2      OPERATIONAL          NSHUT
0/FT2             NC55-5508-FAN2      OPERATIONAL          NSHUT
0/PM0             N9K-PAC-3000W-B     OPERATIONAL          NSHUT
0/PM1             N9K-PAC-3000W-B     OPERATIONAL          NSHUT
0/PM2             NC55-PWR-3KW-AC     OPERATIONAL          NSHUT
0/PM3             NC55-PWR-3KW-AC     OPERATIONAL          NSHUT
0/PM4             N9K-PAC-3000W-B     OPERATIONAL          NSHUT
0/PM5             N9K-PAC-3000W-B     OPERATIONAL          NSHUT
0/SC0             NC55-SC              OPERATIONAL          NSHUT
0/SC1             NC55-SC              OPERATIONAL          NSHUT

```

The following example shows sample output from the **show platform** command in system admin mode:

```

sysadmin-vm:0_RP0#show platform
Mon Apr 29 09:27:02.124 UTC+00:00
Location  Card Type                HW State    SW State    Config State
-----
0/0       NC57-48Q2D-S             OPERATIONAL OPERATIONAL NSHUT
0/1       NC55-36X100G-A-SE       OPERATIONAL OPERATIONAL NSHUT
0/2       NC57-48Q2D-SE-S         OPERATIONAL OPERATIONAL NSHUT
0/3       NC55-24X100G-SE         OPERATIONAL OPERATIONAL NSHUT
0/5       NC57-36H6D-S            OPERATIONAL OPERATIONAL NSHUT
0/6       NC57-48Q2D-SE-S         OPERATIONAL OPERATIONAL NSHUT
0/7       NC55-MOD-A-S             OPERATIONAL OPERATIONAL NSHUT
0/RP0     NC55-RP2-E               OPERATIONAL OPERATIONAL NSHUT
0/RP1     NC55-RP-E                OPERATIONAL OPERATIONAL NSHUT
0/FC1     NC55-5508-FC2           OPERATIONAL OPERATIONAL NSHUT
0/FC2     NC55-5508-FC2           OPERATIONAL OPERATIONAL NSHUT
0/FC3     NC55-5508-FC2           OPERATIONAL OPERATIONAL NSHUT
0/FC5     NC55-5508-FC2           OPERATIONAL OPERATIONAL NSHUT
0/FT0     NC55-5508-FAN2          OPERATIONAL N/A         NSHUT
0/FT1     NC55-5508-FAN2          OPERATIONAL N/A         NSHUT
0/FT2     NC55-5508-FAN2          OPERATIONAL N/A         NSHUT
0/PM0     NC55-PWR-3KW-AC         OPERATIONAL N/A         NSHUT
0/PM1     NC55-PWR-3KW-AC         OPERATIONAL N/A         NSHUT
0/PM2     NC55-PWR-3KW-AC         OPERATIONAL N/A         NSHUT
0/PM3     NC55-PWR-3KW-AC         OPERATIONAL N/A         NSHUT
0/PM4     N9K-PAC-3000W-B         OPERATIONAL N/A         NSHUT
0/PM5     NC55-PWR-3KW-AC         OPERATIONAL N/A         NSHUT
0/SC0     NC55-SC                  OPERATIONAL OPERATIONAL NSHUT
0/SC1     NC55-SC                  OPERATIONAL OPERATIONAL NSHUT

```

show redundancy

To display the status of route processor redundancy, use the **show redundancy** command in EXEC mode.

show redundancy [**location** {*node-id* | **all**} | **statistics** | **summary**]

Syntax Description		
location { <i>node-id</i> all }		(Optional) Specifies the node for which to display LED information. The <i>node-id</i> argument is expressed in the <i>rack/slot</i> notation. Use the all keyword to indicate all nodes.
statistics		(Optional) Displays redundancy statistics information.
summary		(Optional) Displays a summary of all redundant node pairs in the router.

Command Default Route processor redundancy information is displayed for all nodes in the system.

Command Modes XR EXEC

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **show redundancy** command to display the redundancy status of the . The **show redundancy** command also displays the boot and switchover history for the RPs. . To view the nonstop routing (NSR) status of the standby RPs in the system, use the **summary** keyword.

Task ID	Task ID	Operations
	system	read
	basic-services	read (for statistics keyword)

```
RP/0/RP0/CPU0:router# show redundancy
Mon Apr 29 15:11:38.718 IST
Redundancy information for node 0/RP0/CPU0:
=====
Node 0/RP0/CPU0 is in ACTIVE role
Partner node (0/RP1/CPU0) is in STANDBY role
Standby node in 0/RP1/CPU0 is ready
Standby node in 0/RP1/CPU0 is NSR-ready

Reload and boot info
-----
RP reloaded Sat Apr 27 10:50:01 2024: 2 days, 4 hours, 21 minutes ago
```

show redundancy

```

Active node booted Sat Apr 27 10:50:01 2024: 2 days, 4 hours, 21 minutes ago
Standby node boot Sat Apr 27 15:34:50 2024: 1 day, 23 hours, 36 minutes ago
Standby node last went not ready Mon Apr 29 10:39:47 2024: 4 hours, 31 minutes ago
Standby node last went ready Mon Apr 29 10:39:50 2024: 4 hours, 31 minutes ago
Standby node last went not NSR-ready Sat Apr 27 15:29:44 2024: 1 day, 23 hours, 41 minutes ago
Standby node last went NSR-ready Sat Apr 27 15:39:22 2024: 1 day, 23 hours, 32 minutes ago
There have been 0 switch-overs since reload

```

```

Active node reload "CARD_SHUTDOWN"
Standby node reload "CARD_SHUTDOWN "

```

Table 6: show redundancy Field Descriptions

Field	Description
Node */*/* is in XXX role	<p>Current role of the primary route processor, where (*/*/*) is the route processor ID in the format <i>rack/slot/module</i>, and XXX is the role of the route processor (active or standby).</p> <p>In the example, this field shows that the node with the ID 0/RP0/CPU0 is in active role.</p>
Partner node (*/*/*) is in XXX role	<p>Current role of the secondary (or partner) route processor, where (*/*/*) is the route processor ID in the <i>rack/slot/module</i> format, and XXX is the role of the route processor (active or standby).</p> <p>In the example, this field shows that the node with the ID 0/RP1/CPU0 is in standby role.</p>
Standby node in (*/*/*) is ready	<p>Current state of the standby node, where (*/*/*) is the standby route processor ID.</p> <p>In the example, the standby node is ready.</p>
Standby node in (*/*/*) is NSR-ready	<p>Current state of the standby node regarding nonstop routing (NSR), where (*/*/*) is the standby route processor ID.</p> <p>In the example, the standby node is NSR-ready.</p>
Reload and boot info	<p>General overview of the active and standby route processors' reload and boot history.</p>

show version

To display the configuration of the system hardware, the software version, the names and sources of configuration files, and the boot images, use the **show version** command in appropriate configuration mode.

show version [detail]

Syntax Description	detail	Specifies detail log of system hardware and software status
Command Default	No default behavior or values	
Command Modes	XR EXEC	
Command History	Release	Modification
	Release 5.0.0	This command was introduced.
Usage Guidelines	The show version command displays a variety of system information, including hardware and software version, router uptime, boot settings (configuration register), and active software.	
Task ID	Task ID	Operations
	basic-services	read

This example shows partial output from the **show version** command for for IOS XR 64 Bit version:

```
RP/0/RP0/CPU0:router#show version
Mon Apr 29 15:13:48.798 IST
Cisco IOS XR Software, Version 24.2.1.34I
Copyright (c) 2013-2024 by Cisco Systems, Inc.

Build Information:
  Built By      : swtools
  Built On     : Mon Apr 22 02:27:23 PDT 2024
  Built Host   : iox-ucs-032
  Workspace    : /auto/iox-ucs-032-san1/prod/24.2.1.34I.SIT_IMAGE/ncs5500/ws
  Version     : 24.2.1.34I
  Location    : /opt/cisco/XR/packages/
  Label       : 24.2.1.34I

cisco NCS-5500 () processor
System uptime is 2 days 4 hours 23 minutes
```

The following is sample output from the **show version** command with the detail keyword:

```
RP/0/RP0/CPU0:router#show version detail
Mon Apr 29 15:13:57.610 IST
Cisco IOS XR Software, Version 24.2.1.34I
Copyright (c) 2013-2024 by Cisco Systems, Inc.

Build Information:
  Built By      : swtools
```

show version

```
Built On      : Mon Apr 22 02:27:23 PDT 2024
Built Host   : iox-ucs-032
Workspace    : /auto/iox-ucs-032-san1/prod/24.2.1.34I.SIT_IMAGE/ncs5500/ws
Version      : 24.2.1.34I
Location     : /opt/cisco/XR/packages/
Label       : 24.2.1.34I
```

```
cisco NCS-5500 () processor
Cisco NCS-5508 (Intel(R) Xeon(R) CPU D-1528 @ 1.90GHz) processor with 32GB of memory
MSFT_5508_VigorLS System uptime is 2 days 4 hours 23 minutes
NCS5500 8 Slot Single Chassis
```