



Configuring Administrator Roles for Managing a Service Configuration

- [About Privileges, on page 1](#)
- [Configuring a Role for Device Management, on page 2](#)
- [Configuring a Role for Service Graph Template Management, on page 2](#)
- [Configuring a Role for Uploading Device Package, on page 2](#)
- [Configuring a Role for Exporting Devices, on page 2](#)

About Privileges

You can grant privileges to the roles that you configure in the Application Policy Infrastructure Controller (APIC). Privileges determine what tasks a role is allowed to perform. You can grant the following privileges to the administrator roles:

| Privilege | Description |
|---------------|---|
| nw-svc-policy | The network service policy privilege enables you to do the following: <ul style="list-style-type: none">• Create a service graph template• Attach a service graph template to an application endpoint group (EPG) and a contract• Monitor a service graph |
| nw-svc-device | The network service device privilege enables you to do the following: <ul style="list-style-type: none">• Create a device• Create a concrete device• Create a device context |



Note Only the infrastructure administrator can upload a device package to the Cisco APIC.

Configuring a Role for Device Management

To enable a role to manage devices, you must grant the following privilege to that role:

- nw-svc-device

Configuring a Role for Service Graph Template Management

To enable a role to manage service graph templates, you must grant the following privilege to that role:

- nw-svc-policy

Configuring a Role for Uploading Device Package

A device package can be uploaded only with the APIC infra admin privilege. Infra admin uploads the device packages. All other tenant administrators have read-only access to the device package. Tenant administrators can access and use various functions available from the device package.

Configuring a Role for Exporting Devices

Devices can be exported to enable sharing of devices among tenants. A tenant with the role **nw-device** can create a device. If the tenant that owns the device wants to share these with another tenant, the sharing requires the **nw-svc-devshare** privilege.

The **nw-svc-devshare** privilege allows a tenant to be able to export devices.



Note To be able to use imported devices, other tenants that have imported devices need to have the **nw-svc-policy** privilege.
