



## Layer 2/3 Commands

---

- [avb](#), on page 4
- [channel-group](#), on page 6
- [channel-protocol](#), on page 9
- [clear l2protocol-tunnel counters](#), on page 10
- [clear lacp](#), on page 11
- [clear pagp](#), on page 12
- [clear spanning-tree counters](#), on page 13
- [clear spanning-tree detected-protocols](#), on page 14
- [debug etherchannel](#), on page 15
- [debug lacp](#), on page 16
- [debug pagp](#), on page 17
- [debug platform pm](#), on page 18
- [debug platform udd](#), on page 19
- [debug spanning-tree](#), on page 20
- [instance \(VLAN\)](#), on page 22
- [interface port-channel](#), on page 24
- [l2protocol-tunnel](#), on page 26
- [lacp fast-switchover](#), on page 29
- [lacp max-bundle](#), on page 31
- [lacp port-priority](#), on page 32
- [lacp rate](#), on page 33
- [lacp system-priority](#), on page 34
- [loopdetect](#), on page 35
- [mvrp vlan creation](#), on page 37
- [mvrp registration](#), on page 38
- [mvrp timer](#), on page 40
- [name \(MST\)](#), on page 42
- [no ptp enable](#), on page 43
- [pagp learn-method](#), on page 44
- [pagp port-priority](#), on page 46
- [peer \(PTP\)](#), on page 47
- [policy-map](#), on page 48
- [port-channel](#), on page 50

- port-channel auto, on page 51
- port-channel load-balance, on page 52
- port-channel load-balance extended, on page 55
- port-channel min-links, on page 57
- ptp dot1as extend property, on page 58
- ptp ip dscp, on page 59
- ptp priority1 value, on page 60
- ptp priority2 value, on page 61
- ptp profile dot1as, on page 62
- ptp property, on page 63
- ptp role primary, on page 64
- rep admin vlan, on page 65
- rep block port, on page 66
- rep lsl-age-timer, on page 68
- rep lsl-retries, on page 69
- rep preempt delay, on page 70
- rep preempt segment, on page 71
- rep segment, on page 72
- rep stcn, on page 74
- revision, on page 75
- show avb domain, on page 76
- show avb streams, on page 78
- show dot1q-tunnel, on page 79
- show etherchannel, on page 80
- show interfaces rep detail, on page 83
- show l2protocol-tunnel, on page 84
- show lacp, on page 86
- show loopdetect, on page 90
- show msrp port bandwidth, on page 91
- show msrp streams, on page 93
- show pagp, on page 95
- show platform etherchannel, on page 97
- show platform hardware fed active vlan ingress, on page 98
- show platform pm, on page 99
- show platform software fed active ptp interface loopback, on page 100
- show platform software fed switch ptp, on page 101
- show ptp brief, on page 103
- show ptp clock, on page 104
- show ptp parent, on page 105
- show ptp port, on page 107
- show ptp port loopback, on page 108
- show ptp transport properties, on page 109
- show rep topology, on page 110
- show spanning-tree, on page 112
- show spanning-tree mst, on page 118
- show uddl, on page 121

- show vlan dot1q tag native, on page 125
- source ip interface, on page 126
- spanning-tree backbonefast, on page 127
- spanning-tree bpdudfilter, on page 128
- spanning-tree bpduguard, on page 130
- spanning-tree bridge assurance, on page 132
- spanning-tree cost, on page 133
- spanning-tree etherchannel guard misconfig, on page 135
- spanning-tree extend system-id, on page 137
- spanning-tree guard, on page 138
- spanning-tree link-type, on page 139
- spanning-tree loopguard default, on page 141
- spanning-tree mode, on page 142
- spanning-tree mst, on page 143
- spanning-tree mst configuration, on page 144
- spanning-tree mst forward-time, on page 146
- spanning-tree mst hello-time, on page 147
- spanning-tree mst max-age, on page 148
- spanning-tree mst max-hops, on page 149
- spanning-tree mst pre-standard, on page 150
- spanning-tree mst priority, on page 152
- spanning-tree mst root, on page 153
- spanning-tree mst simulate pvst global, on page 154
- spanning-tree pathcost method, on page 155
- spanning-tree port-priority, on page 156
- spanning-tree portfast edge bpdudfilter default, on page 158
- spanning-tree portfast edge bpduguard default, on page 160
- spanning-tree portfast default, on page 161
- spanning-tree transmit hold-count, on page 163
- spanning-tree uplinkfast, on page 164
- spanning-tree vlan, on page 165
- switchport, on page 168
- switchport access vlan, on page 169
- switchport mode, on page 170
- switchport nonegotiate, on page 172
- switchport trunk, on page 173
- switchport voice vlan, on page 176
- transport unicast ipv4 local loopback, on page 179
- uddl, on page 180
- uddl fast-hello, on page 182
- uddl port, on page 183
- uddl reset, on page 185
- vlan dot1q tag native, on page 186
- vtp mode, on page 187

# avb

To enable Audio Video Bridging (AVB), use the **avb** command in global configuration mode. To disable AVB, use the **no** form of this command.

**avb** [{ **msrp-join-timer** *milliseconds* | **msrp-leave-timer** *milliseconds* | **msrp-leaveall-timer** *milliseconds* | **msrp-tx-slow** | **strict** | **vlan** *vlan-id* }]

**no avb** [{ **msrp-join-timer** | **msrp-leave-timer** | **msrp-leaveall-timer** | **msrp-tx-slow** | **strict** | **vlan** }]

## Syntax Description

<b>msrp-join-timer</b> <i>milliseconds</i>	(Optional) Configures the Multiple Stream Reservation Protocol (MSRP) join timer value in milliseconds. The range is from 100 to 4000. The default is 200.
<b>msrp-leave-timer</b> <i>milliseconds</i>	(Optional) Configures the MSRP leave timer value in milliseconds. The range is from 500 to 60000. The default is 1000.
<b>msrp-leaveall-timer</b> <i>milliseconds</i>	(Optional) Configures the MSRP leaveall timer value in milliseconds. The range is from 10000 to 50000. The default is 10000.
<b>msrp-tx-slow</b>	(Optional) Slows down the default packet sending rate with a gap of 100 milliseconds.
<b>strict</b>	(Optional) Configures the strict mode of AVB.
<b>vlan</b> <i>vlan-id</i>	(Optional) Configures a specified VLAN as the default AVB VLAN. The range is from from 2 to 4094.

## Command Default

AVB is disabled.

## Command Modes

Global configuration (config)

## Command History

Release	Modification
Cisco IOS XE Fuji 16.8.1a	This command was introduced.
Cisco IOS XE Gibraltar 16.12.5	The <b>msrp-join-timer</b> , <b>msrp-leave-timer</b> , <b>msrp-leaveall-timer</b> , <b>msrp-tx-slow</b> keywords were introduced.

## Example

This example shows how to enable AVB:

```
Device> enable
Device# configure terminal
Device(config)# avb
```

This example shows how to configure the MSRP leave timer value:

```
Device> enable
Device# configure terminal
Device(config)# avb msrp-leave-timer 6000
```

This example shows how to set a specified VLAN as the default AVB VLAN:

```
Device> enable
Device# configure terminal
Device(config)# avb vlan 10
```

This example shows how set a specified VLAN as the default AVB VLAN:

```
Device> enable
Device# configure terminal
Device(config)# interface TenGigabitEthernet 1/1/1
Device(config-if)# switchport mode trunk
Device(config-if)# exit
Device(config)# vlan 2
Device(config)# avb vlan 10
```

# channel-group

To assign an Ethernet port to an EtherChannel group, or to enable an EtherChannel mode, or both, use the **channel-group** command in interface configuration mode. To remove an Ethernet port from an EtherChannel group, use the **no** form of this command.

**channel-group** *channel-group-number* **mode** {**active** | **auto** [**non-silent**] | **desirable** [**non-silent**] | **on** | **passive**}  
**no channel-group**

Syntax Description		
	<i>channel-group-number</i>	Channel group number. The range is 1 to 128.
	<b>mode</b>	Specifies the EtherChannel mode.
	<b>active</b>	Unconditionally enables Link Aggregation Control Protocol (LACP).
	<b>auto</b>	Enables the Port Aggregation Protocol (PAgP) only if a PAgP device is detected.
	<b>non-silent</b>	(Optional) Configures the interface for nonsilent operation when connected to a partner that is PAgP-capable. Use in PAgP mode with the <b>auto</b> or <b>desirable</b> keyword when traffic is expected from the other device.
	<b>desirable</b>	Unconditionally enables PAgP.
	<b>on</b>	Enables the on mode.
	<b>passive</b>	Enables LACP only if a LACP device is detected.

**Command Default** No channel groups are assigned.  
No mode is configured.

**Command Modes** Interface configuration

Command History	Release	Modification
	Cisco IOS XE Everest 16.5.1a	This command was introduced.

**Usage Guidelines** For Layer 2 EtherChannels, the **channel-group** command automatically creates the port-channel interface when the channel group gets its first physical port. You do not have to use the **interface port-channel** command

in global configuration mode to manually create a port-channel interface. If you create the port-channel interface first, the *channel-group-number* can be the same as the *port-channel-number*, or you can use a new number. If you use a new number, the **channel-group** command dynamically creates a new port channel.

Although it is not necessary to disable the IP address that is assigned to a physical port that is part of a channel group, we strongly recommend that you do so.

You create Layer 3 port channels by using the **interface port-channel** command followed by the **no switchport** interface configuration command. Manually configure the port-channel logical interface before putting the interface into the channel group.

After you configure an EtherChannel, configuration changes that you make on the port-channel interface apply to all the physical ports assigned to the port-channel interface. Configuration changes applied to the physical port affect only the port where you apply the configuration. To change the parameters of all ports in an EtherChannel, apply configuration commands to the port-channel interface, for example, spanning-tree commands or commands to configure a Layer 2 EtherChannel as a trunk.

Active mode places a port into a negotiating state in which the port initiates negotiations with other ports by sending LACP packets. A channel is formed with another port group in either the active or passive mode.

Auto mode places a port into a passive negotiating state in which the port responds to PAgP packets it receives but does not start PAgP packet negotiation. A channel is formed only with another port group in desirable mode. When auto is enabled, silent operation is the default.

Desirable mode places a port into an active negotiating state in which the port starts negotiations with other ports by sending PAgP packets. An EtherChannel is formed with another port group that is in the desirable or auto mode. When desirable is enabled, silent operation is the default.

If you do not specify non-silent with the auto or desirable mode, silent is assumed. The silent mode is used when the switch is connected to a device that is not PAgP-capable and rarely, if ever, sends packets. An example of a silent partner is a file server or a packet analyzer that is not generating traffic. In this case, running PAgP on a physical port prevents that port from ever becoming operational. However, it allows PAgP to operate, to attach the port to a channel group, and to use the port for transmission. Both ends of the link cannot be set to silent.

In on mode, a usable EtherChannel exists only when both connected port groups are in the on mode.



---

**Caution** Use care when using the on mode. This is a manual configuration, and ports on both ends of the EtherChannel must have the same configuration. If the group is misconfigured, packet loss or spanning-tree loops can occur.

---

Passive mode places a port into a negotiating state in which the port responds to received LACP packets but does not initiate LACP packet negotiation. A channel is formed only with another port group in active mode.

Do not configure an EtherChannel in both the PAgP and LACP modes. EtherChannel groups running PAgP and LACP can coexist on the same switch or on different switches in the stack (but not in a cross-stack configuration). Individual EtherChannel groups can run either PAgP or LACP, but they cannot interoperate.

If you set the protocol by using the **channel-protocol** interface configuration command, the setting is not overridden by the **channel-group** interface configuration command.

Do not configure a port that is an active or a not-yet-active member of an EtherChannel as an IEEE 802.1x port. If you try to enable IEEE 802.1x authentication on an EtherChannel port, an error message appears, and IEEE 802.1x authentication is not enabled.

Do not configure a secure port as part of an EtherChannel or configure an EtherChannel port as a secure port.

For a complete list of configuration guidelines, see the “Configuring EtherChannels” chapter in the software configuration guide for this release.



---

**Caution** Do not enable Layer 3 addresses on the physical EtherChannel ports. Do not assign bridge groups on the physical EtherChannel ports because it creates loops.

---

This example shows how to configure an EtherChannel on a single switch in the stack. It assigns two static-access ports in VLAN 10 to channel 5 with the PAgP mode desirable:

```
Device# configure terminal
Device(config)# interface range GigabitEthernet 2/0/1 - 2
Device(config-if-range)# switchport mode access
Device(config-if-range)# switchport access vlan 10
Device(config-if-range)# channel-group 5 mode desirable
Device(config-if-range)# end
```

This example shows how to configure an EtherChannel on a single switch in the stack. It assigns two static-access ports in VLAN 10 to channel 5 with the LACP mode active:

```
Device# configure terminal
Device(config)# interface range GigabitEthernet 2/0/1 - 2
Device(config-if-range)# switchport mode access
Device(config-if-range)# switchport access vlan 10
Device(config-if-range)# channel-group 5 mode active
Device(config-if-range)# end
```

This example shows how to configure a cross-stack EtherChannel in a switch stack. It uses LACP passive mode and assigns two ports on stack member 2 and one port on stack member 3 as static-access ports in VLAN 10 to channel 5:

```
Device# configure terminal
Device(config)# interface range GigabitEthernet 2/0/4 - 5
Device(config-if-range)# switchport mode access
Device(config-if-range)# switchport access vlan 10
Device(config-if-range)# channel-group 5 mode passive
Device(config-if-range)# exit
Device(config)# interface GigabitEthernet 3/0/3
Device(config-if)# switchport mode access
Device(config-if)# switchport access vlan 10
Device(config-if)# channel-group 5 mode passive
Device(config-if)# exit
```

You can verify your settings by entering the **show running-config** privileged EXEC command.



# channel-protocol

To restrict the protocol used on a port to manage channeling, use the **channel-protocol** command in interface configuration mode. To return to the default setting, use the **no** form of this command.

```
channel-protocol {lACP | pagp}
no channel-protocol
```

## Syntax Description

**lACP** Configures an EtherChannel with the Link Aggregation Control Protocol (LACP).

**pagp** Configures an EtherChannel with the Port Aggregation Protocol (PAgP).

## Command Default

No protocol is assigned to the EtherChannel.

## Command Modes

Interface configuration

## Command History

Release	Modification
Cisco IOS XE Everest 16.5.1a	This command was introduced.

## Usage Guidelines

Use the **channel-protocol** command only to restrict a channel to LACP or PAgP. If you set the protocol by using the **channel-protocol** command, the setting is not overridden by the **channel-group** command in interface configuration mode.

You must use the **channel-group** command in interface configuration mode to configure the EtherChannel parameters. The **channel-group** command also can set the mode for the EtherChannel.

You cannot enable both the PAgP and LACP modes on an EtherChannel group.

PAgP and LACP are not compatible; both ends of a channel must use the same protocol.

You cannot configure PAgP on cross-stack configurations.

This example shows how to specify LACP as the protocol that manages the EtherChannel:

```
Device> enable
Device# configure terminal
Device(config)# interface gigabitethernet2/0/1
Device(config-if)# channel-protocol lACP
```

You can verify your settings by entering the **show etherchannel** [*channel-group-number*] **protocol** command in privileged EXEC mode.

# clear l2protocol-tunnel counters

To clear the protocol counters in protocol tunnel ports, use the **clear l2protocol-tunnel counters** command in privileged EXEC mode.

**clear l2protocol-tunnel counters** [*interface-id*]

<b>Syntax Description</b>	<i>interface-id</i>	(Optional) The interface (physical interface or port channel) whose counters are to be cleared.
---------------------------	---------------------	---

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Privileged EXEC
----------------------	-----------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

<b>Usage Guidelines</b>	Use this command to clear protocol tunnel counters on the switch or on the specified interface.
-------------------------	---

This example shows how to clear Layer 2 protocol tunnel counters on an interface:

```
Device# clear l2protocol-tunnel counters gigabitethernet1/0/3
```

# clear lacp

To clear Link Aggregation Control Protocol (LACP) channel-group counters, use the **clear lacp** command in privileged EXEC mode.

**clear lacp** [*channel-group-number*] **counters**

<b>Syntax Description</b>	<i>channel-group-number</i>	(Optional) Channel group number. The range is 1 to 128.
	<b>counters</b>	Clears traffic counters.

**Command Modes** Privileged EXEC

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
		Cisco IOS XE Everest 16.5.1a

**Usage Guidelines** You can clear all counters by using the **clear lacp counters** command, or you can clear only the counters for the specified channel group by using the **clear lacp *channel-group-number* counters** command.

This example shows how to clear all channel-group information:

```
Device> enable
Device# clear lacp counters
```

This example shows how to clear LACP traffic counters for group 4:

```
Device> enable
Device# clear lacp 4 counters
```

You can verify that the information was deleted by entering the **show lacp counters** or the **show lacp *channel-group-number* counters** command in privileged EXEC mode.

# clear pagp

To clear the Port Aggregation Protocol (PAgP) channel-group information, use the **clear pagp** command in privileged EXEC mode.

**clear pagp** [*channel-group-number*] **counters**

<b>Syntax Description</b>	<i>channel-group-number</i> (Optional) Channel group number. The range is 1 to 128.
	<b>counters</b> Clears traffic counters.

**Command Modes** Privileged EXEC

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Everest 16.5.1a	This command was introduced.

**Usage Guidelines** You can clear all counters by using the **clear pagp counters** command, or you can clear only the counters for the specified channel group by using the **clear pagp** *channel-group-number* **counters** command.

This example shows how to clear all channel-group information:

```
Device> enable
Device# clear pagp counters
```

This example shows how to clear PAgP traffic counters for group 10:

```
Device> enable
Device# clear pagp 10 counters
```

You can verify that the information was deleted by entering the **show pagp** command in privileged EXEC mode.

# clear spanning-tree counters

To clear the spanning-tree counters, use the **clear spanning-tree counters** command in privileged EXEC mode.

**clear spanning-tree counters** [**interface** *interface-id*]

## Syntax Description

**interface** *interface-id*

(Optional) Clears all spanning-tree counters on the specified include physical ports, VLANs, and port channels.

The VLAN range is 1 to 4094.

The port channel range is 1 to 128.

## Command Modes

Privileged EXEC

## Command History

### Release

Cisco IOS XE Everest 16.5.1a

### Modification

This command was introduced.

## Usage Guidelines

If the *interface-id* value is not specified, spanning-tree counters are cleared for all interfaces.

This example shows how to clear spanning-tree counters for all interfaces:

```
Device> enable
Device# clear spanning-tree counters
```

# clear spanning-tree detected-protocols

To restart the protocol migration process and force renegotiation with neighboring devices on the interface, use the **clear spanning-tree detected-protocols** command in privileged EXEC mode.

**clear spanning-tree detected-protocols** [**interface** *interface-id*]

<b>Syntax Description</b>	<b>interface</b> <i>interface-id</i>	(Optional) Restarts the protocol migration process on the specified interface channels. The VLAN range is 1 to 4094. The port channel range is 1 to 128.
---------------------------	--------------------------------------	--

<b>Command Modes</b>	Privileged EXEC
----------------------	-----------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Everest 16.5.1a	This command was introduced.

## Usage Guidelines

A device running the rapid per-VLAN spanning-tree plus (rapid-PVST+) protocol or the Multiple Spanning Tree Protocol (MSTP) supports a built-in protocol migration method that enables it to interoperate with legacy IEEE 802.1D devices. If a rapid-PVST+ or an MSTP device receives a legacy IEEE 802.1D configuration bridge protocol data unit (BPDU) with the protocol version set to 0, the device sends only IEEE 802.1D BPDUs on that port. A multiple spanning-tree (MST) device can also detect that a port is at the boundary of a region when it receives a legacy BPDU, an MST BPDU (Version 3) associated with a different region, or a rapid spanning-tree (RST) BPDU (Version 2).

The device does not automatically revert to the rapid-PVST+ or the MSTP mode if it no longer receives IEEE 802.1D BPDUs because it cannot learn whether the legacy switch has been removed from the link unless the legacy switch is the designated switch. Use the **clear spanning-tree detected-protocols** command in this situation.

This example shows how to restart the protocol migration process on a port:

```
Device> enable
Device# clear spanning-tree detected-protocols interface gigabitethernet2/0/1
```

# debug etherchannel

To enable debugging of EtherChannels, use the **debug etherchannel** command in privileged EXEC mode. To disable debugging, use the **no** form of the command.

```
debug etherchannel [{all | detail | error | event | idb}]
no debug etherchannel [{all | detail | error | event | idb}]
```

## Syntax Description

<b>all</b>	(Optional) Displays all EtherChannel debug messages.
<b>detail</b>	(Optional) Displays detailed EtherChannel debug messages.
<b>error</b>	(Optional) Displays EtherChannel error debug messages.
<b>event</b>	(Optional) Displays EtherChannel event messages.
<b>idb</b>	(Optional) Displays PAgP interface descriptor block debug messages.

## Command Default

Debugging is disabled.

## Command Modes

Privileged EXEC

## Command History

Release	Modification
Cisco IOS XE Everest 16.5.1a	This command was introduced.

## Usage Guidelines

The **undebug etherchannel** command is the same as the **no debug etherchannel** command.



**Note** Although the **linecard** keyword is displayed in the command-line help, it is not supported.

This example shows how to display all EtherChannel debug messages:

```
Device> enable
Device# debug etherchannel all
```

This example shows how to display debug messages related to EtherChannel events:

```
Device> enable
Device# debug etherchannel event
```

# debug lacp

To enable debugging of Link Aggregation Control Protocol (LACP) activity, use the **debug lacp** command in privileged EXEC mode. To disable LACP debugging, use the **no** form of this command.

```
debug lacp [{all | event | fsm | misc | packet}]
no debug lacp [{all | event | fsm | misc | packet}]
```

## Syntax Description

<b>all</b>	(Optional) Displays all LACP debug messages.
<b>event</b>	(Optional) Displays LACP event debug messages.
<b>fsm</b>	(Optional) Displays messages about changes within the LACP finite state machine.
<b>misc</b>	(Optional) Displays miscellaneous LACP debug messages.
<b>packet</b>	(Optional) Displays the receiving and transmitting LACP control packets.

## Command Default

Debugging is disabled.

## Command Modes

Privileged EXEC

## Command History

Release	Modification
Cisco IOS XE Everest 16.5.1a	This command was introduced.

## Usage Guidelines

The **undebg etherchannel** command is the same as the **no debug etherchannel** command.

This example shows how to display all LACP debug messages:

```
Device> enable
Device# debug LACP all
```

This example shows how to display debug messages related to LACP events:

```
Device> enable
Device# debug LACP event
```



# debug pagp

To enable debugging of Port Aggregation Protocol (PAgP) activity, use the **debug pagp** command in privileged EXEC mode. To disable PAgP debugging, use the **no** form of this command.

```
debug pagp [{all | dual-active | event | fsm | misc | packet}]
no debug pagp [{all | dual-active | event | fsm | misc | packet}]
```

Syntax Description	
<b>all</b>	(Optional) Displays all PAgP debug messages.
<b>dual-active</b>	(Optional) Displays dual-active detection messages.
<b>event</b>	(Optional) Displays PAgP event debug messages.
<b>fsm</b>	(Optional) Displays messages about changes within the PAgP finite state machine.
<b>misc</b>	(Optional) Displays miscellaneous PAgP debug messages.
<b>packet</b>	(Optional) Displays the receiving and transmitting PAgP control packets.

**Command Default** Debugging is disabled.

**Command Modes** Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE Everest 16.5.1a	This command was introduced.

**Usage Guidelines** The **undebug pagp** command is the same as the **no debug pagp** command.

This example shows how to display all PAgP debug messages:

```
Device> enable
Device# debug pagp all
```

This example shows how to display debug messages related to PAgP events:

```
Device> enable
Device# debug pagp event
```

# debug platform pm

To enable debugging of the platform-dependent port manager software module, use the **debug platform pm** command in privileged EXEC mode. To disable debugging, use the **no** form of this command.

```
debug platform pm {all | counters | errdisable | fec | if-numbers | l2-control | link-status |
platform | pm-vectors [detail] | ses | vlans}
no debug platform pm {all | counters | errdisable | fec | if-numbers | l2-control | link-status |
platform | pm-vectors [detail] | ses | vlans}
```

## Syntax Description

<b>all</b>	Displays all port manager debug messages.
<b>counters</b>	Displays counters for remote procedure call (RPC) debug messages.
<b>errdisable</b>	Displays error-disabled-related events debug messages.
<b>fec</b>	Displays forwarding equivalence class (FEC) platform-related events debug messages.
<b>if-numbers</b>	Displays interface-number translation event debug messages.
<b>l2-control</b>	Displays Layer 2 control infra debug messages.
<b>link-status</b>	Displays interface link-detection event debug messages.
<b>platform</b>	Displays port manager function event debug messages.
<b>pm-vectors</b>	Displays port manager vector-related event debug messages.
<b>detail</b>	(Optional) Displays vector-function details.
<b>ses</b>	Displays service expansion shelf (SES) related event debug messages.
<b>vlans</b>	Displays VLAN creation and deletion event debug messages.

## Command Default

Debugging is disabled.

## Command Modes

Privileged EXEC

## Command History

Release	Modification
Cisco IOS XE Everest 16.5.1a	This command was introduced.

## Usage Guidelines

The **undebug platform pm** command is the same as the **no debug platform pm** command.

This example shows how to display debug messages related to the creation and deletion of VLANs:

```
Device> enable
Device# debug platform pm vlans
```

# debug platform udd

To enable debugging of the platform-dependent UniDirectional Link Detection (UDLD) software, use the **debug platform udd** command in privileged EXEC mode. To disable debugging, use the **no** form of this command.

```
debug platform udd [{error | event}] [switch switch-number]
no debug platform udd [{error | event}] [switch switch-number]
```

Syntax Description	
<b>error</b>	(Optional) Displays error condition debug messages.
<b>event</b>	(Optional) Displays UDLD-related platform event debug messages.
<b>switch</b> <i>switch-number</i>	(Optional) Displays UDLD debug messages for the specified stack member.

**Command Default** Debugging is disabled.

**Command Modes** Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE Everest 16.5.1a	This command was introduced.

**Usage Guidelines** The **undebbug platform udd** command is the same as the **no debug platform udd** command.

When you enable debugging on a switch stack, it is enabled only on the active switch. To enable debugging on a stack member, you can start a session from the active switch by using the **session *switch-number*** command in privileged EXEC mode. Then enter the **debug** command at the command-line prompt of the stack member.

# debug spanning-tree

To enable debugging of spanning-tree activities, use the **debug spanning-tree** command in EXEC mode. To disable debugging, use the **no** form of this command.

**debug spanning-tree** {all | backbonefast | bpdu | bpdu-opt | config | etherchannel | events | exceptions | general | ha | mstp | pvst+ | root | snmp | synchronization | switch | uplinkfast}  
**no debug spanning-tree** {all | backbonefast | bpdu | bpdu-opt | config | etherchannel | events | exceptions | general | mstp | pvst+ | root | snmp | synchronization | switch | uplinkfast}

## Syntax Description

<b>all</b>	Displays all spanning-tree debug messages.
<b>backbonefast</b>	Displays BackboneFast-event debug messages.
<b>bpdu</b>	Displays spanning-tree bridge protocol data unit (BPDU) debug messages.
<b>bpdu-opt</b>	Displays optimized BPDU handling debug messages.
<b>config</b>	Displays spanning-tree configuration change debug messages.
<b>etherchannel</b>	Displays EtherChannel-support debug messages.
<b>events</b>	Displays spanning-tree topology event debug messages.
<b>exceptions</b>	Displays spanning-tree exception debug messages.
<b>general</b>	Displays general spanning-tree activity debug messages.
<b>ha</b>	Displays high-availability spanning-tree debug messages.
<b>mstp</b>	Debugs Multiple Spanning Tree Protocol (MSTP) events.
<b>pvst+</b>	Displays per-VLAN spanning-tree plus (PVST+) event debug messages.
<b>root</b>	Displays spanning-tree root-event debug messages.
<b>snmp</b>	Displays spanning-tree Simple Network Management Protocol (SNMP) handling debug messages.
<b>switch</b>	Displays switch shim command debug messages. This shim is the software module that is the interface between the generic Spanning Tree Protocol (STP) code and the platform-specific code of various device platforms.
<b>synchronization</b>	Displays the spanning-tree synchronization event debug messages.
<b>uplinkfast</b>	Displays UplinkFast-event debug messages.

**Command Default** Debugging is disabled.

**Command Modes** Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE Everest 16.5.1a	This command was introduced.

**Usage Guidelines** The **undebbug spanning-tree** command is the same as the **no debug spanning-tree** command.

When you enable debugging on a stack, it is enabled only on the active switch. To enable debugging on the standby switch, start a session from the active switch by using the **session** *switch-number* command in privileged EXEC mode. Enter the **debug** command at the command-line prompt of the standby switch.

To enable debugging on the standby switch without first starting a session on the active switch, use the **remote command** *switch-number LINE* command in privileged EXEC mode.

This example shows how to display all spanning-tree debug messages:

```
Device> enable
Device# debug spanning-tree all
```

## instance (VLAN)

To map a VLAN or a group of VLANs to a multiple spanning tree (MST) instance, use the **instance** command in MST configuration mode. To return the VLANs to the default internal spanning tree (CIST) instance, use the **no** form of this command.

**instance** *instance-id* **vlan** *vlan-range*  
**no instance** *instance-id*

### Syntax Description

<i>instance-id</i>	Instance to which the specified VLANs are mapped. The range is from 0 to 4094.
<b>vlan</b> <i>vlan-range</i>	Specifies the number of the VLANs to be mapped to the specified instance. The range is from 1 to 4094.

### Command Default

No VLANs are mapped to any MST instance (all VLANs are mapped to the CIST instance).

### Command Modes

MST configuration mode (config-mst)

### Command History

Release	Modification
Cisco IOS XE Everest 16.5.1a	This command was introduced.

### Usage Guidelines

The **vlan** *vlan-range* is entered as a single value or a range.

The mapping is incremental, not absolute. When you enter a range of VLANs, this range is added or removed to the existing instances.

Any unmapped VLAN is mapped to the CIST instance.

### Examples

The following example shows how to map a range of VLANs to instance 2:

```
Device(config)# spanning-tree mst configuration
Device(config-mst)# instance 2 vlans 1-100
Device(config-mst)#
```

The following example shows how to map a VLAN to instance 5:

```
Device(config)# spanning-tree mst configuration
Device(config-mst)# instance 5 vlans 1100
Device(config-mst)#
```

The following example shows how to move a range of VLANs from instance 2 to the CIST instance:

```
Device(config)# spanning-tree mst configuration
Device(config-mst)# no instance 2 vlans 40-60
Device(config-mst)#
```

The following example shows how to move all the VLANs that are mapped to instance 2 back to the CIST instance:

```
Device(config)# spanning-tree mst configuration
Device(config-mst)# no instance 2
Device(config-mst)#
```

**Related Commands**

<b>Command</b>	<b>Description</b>
<b>name</b> (MST configuration mode)	Sets the name of an MST region.
<b>revision</b>	Sets the revision number for the MST configuration.
<b>show spanning-tree mst</b>	Displays the information about the MST protocol.
<b>spanning-tree mst configuration</b>	Enters MST configuration mode.

# interface port-channel

To access or create a port channel, use the **interface port-channel** command in global configuration mode. Use the **no** form of this command to remove the port channel.

```
interface port-channel port-channel-number
no interface port-channel
```

<b>Syntax Description</b>	<i>port-channel-number</i> Channel group number. The range is 1 to 128.
---------------------------	--

<b>Command Default</b>	No port channel logical interfaces are defined.
------------------------	---

<b>Command Modes</b>	Global configuration
----------------------	----------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Everest 16.5.1a	This command was introduced.

**Usage Guidelines** For Layer 2 EtherChannels, you do not have to create a port-channel interface before assigning physical ports to a channel group. Instead, you can use the **channel-group** command in interface configuration mode, which automatically creates the port-channel interface when the channel group obtains its first physical port. If you create the port-channel interface first, the *channel-group-number* can be the same as the *port-channel-number*, or you can use a new number. If you use a new number, the **channel-group** command dynamically creates a new port channel.

You create Layer 3 port channels by using the **interface port-channel** command followed by the **no switchport** command in interface configuration mode. You should manually configure the port-channel logical interface before putting the interface into the channel group.

Only one port channel in a channel group is allowed.



<b>Caution</b>	When using a port-channel interface as a routed port, do not assign Layer 3 addresses on the physical ports that are assigned to the channel group.
----------------	---



<b>Caution</b>	Do not assign bridge groups on the physical ports in a channel group used as a Layer 3 port channel interface because it creates loops. You must also disable spanning tree.
----------------	--

Follow these guidelines when you use the **interface port-channel** command:

- If you want to use the Cisco Discovery Protocol (CDP), you must configure it on the physical port and not on the port channel interface.
- Do not configure a port that is an active member of an EtherChannel as an IEEE 802.1x port. If IEEE 802.1x is enabled on a not-yet active port of an EtherChannel, the port does not join the EtherChannel.



For a complete list of configuration guidelines, see the “Configuring EtherChannels” chapter in the software configuration guide for this release.

This example shows how to create a port channel interface with a port channel number of 5:

```
Device> enable
Device# configure terminal
Device(config)# interface port-channel 5
```

You can verify your setting by entering either the **show running-config** in privileged EXEC mode or the **show etherchannel *channel-group-number* detail** command in privileged EXEC mode.

# I2protocol-tunnel

To enable tunneling of Layer 2 protocols on an access port, IEEE 802.1Q tunnel port, or a port channel, use the **I2protocol-tunnel** command in interface configuration mode on the switch stack or on a standalone switch. Use the **no** form of this command to disable tunneling on the interface.

```
I2protocol-tunnel [{drop-threshold | shutdown-threshold}] [value] [{cdp | stp | vtp}] [lldp]
[point-to-point | [{pagp | lACP | udld}] ]
no I2protocol-tunnel [{drop-threshold | shutdown-threshold}] [value] [{cdp | stp | vtp}] [lldp]
[point-to-point | [{pagp | lACP | udld}] ]
```

## Syntax Description

<b>drop-threshold</b>	(Optional) Sets a drop threshold for the maximum rate of Layer 2 protocol packets per second to be received before an interface drops packets.
<b>shutdown-threshold</b>	(Optional) Sets a shutdown threshold for the maximum rate of Layer 2 protocol packets per second to be received before an interface is shut down.
<i>value</i>	A threshold in packets per second to be received for encapsulation before the interface shuts down, or the threshold before the interface drops packets. The range is 1 to 4096. The default is no threshold.
<b>cdp</b>	(Optional) Enables tunneling of CDP, specifies a shutdown threshold for CDP, or specifies a drop threshold for CDP.
<b>stp</b>	(Optional) Enables tunneling of STP, specifies a shutdown threshold for STP, or specifies a drop threshold for STP.
<b>vtp</b>	(Optional) Enables tunneling or VTP, specifies a shutdown threshold for VTP, or specifies a drop threshold for VTP.
<b>lldp</b>	(Optional) Enables tunneling of LLDP packets.
<b>point-to-point</b>	(Optional) Enables point-to-point tunneling of PAgP, LACP, and UDLD packets.
<b>pagp</b>	(Optional) Enables point-to-point tunneling of PAgP, specifies a shutdown threshold for PAgP, or specifies a drop threshold for PAgP.
<b>lACP</b>	(Optional) Enables point-to-point tunneling of LACP, specifies a shutdown threshold for LACP, or specifies a drop threshold for LACP.
<b>udld</b>	(Optional) Enables point-to-point tunneling of UDLD, specifies a shutdown threshold for UDLD, or specifies a drop threshold for UDLD.

## Command Default

The default is that no Layer 2 protocol packets are tunneled.

The default is no shutdown threshold for the number of Layer 2 protocol packets.

The default is no drop threshold for the number of Layer 2 protocol packets.

## Command Modes

Interface configuration

**Command History****Release****Modification**

Cisco IOS XE Gibraltar 16.12.1 This command was introduced.

**Usage Guidelines**

You can enable tunneling for Cisco Discovery Protocol (CDP), Spanning Tree Protocol (STP), or VLAN Trunking Protocol (VTP) packets. You can also enable point-to-point tunneling for Port Aggregation Protocol (PAgP), Link Aggregation Control Protocol (LACP), or UniDirectional Link Detection (UDLD) packets.

You must enter this command, with or without protocol types, to tunnel Layer 2 packets.

If you enter this command for a port channel, all ports in the channel must have the same configuration.

Layer 2 protocol tunneling across a service-provider network ensures that Layer 2 information is propagated across the network to all customer locations. When protocol tunneling is enabled, protocol packets are encapsulated with a well-known Cisco multicast address for transmission across the network. When the packets reach their destination, the well-known MAC address is replaced by the Layer 2 protocol MAC address.

You can enable Layer 2 protocol tunneling for CDP, STP, and VTP individually or for all three protocols.

In a service-provider network, you can use Layer 2 protocol tunneling to enhance the creation of EtherChannels by emulating a point-to-point network topology. When protocol tunneling is enabled on the service-provider switch for PAgP or LACP, remote customer switches receive the protocol data units (PDUs) and can negotiate automatic creation of EtherChannels.

To enable tunneling of PAgP, LACP, and UDLD packets, you must have a point-to-point network topology. To decrease the link-down detection time, you should also enable UDLD on the interface when you enable tunneling of PAgP or LACP packets.

You can enable point-to-point protocol tunneling for PAgP, LACP, and UDLD individually or for all three protocols.

**Caution**

PAgP, LACP, and UDLD tunneling is only intended to emulate a point-to-point topology. An erroneous configuration that sends tunneled packets to many ports could lead to a network failure.

Enter the **shutdown-threshold** keyword to control the number of protocol packets per second that are received on an interface before it shuts down. When no protocol option is specified with the keyword, the threshold is applied to each of the tunneled Layer 2 protocol types. If you also set a drop threshold on the interface, the shutdown-threshold value must be greater than or equal to the drop-threshold value.

When the shutdown threshold is reached, the interface is error-disabled. If you enable error recovery by entering the **errdisable recovery cause l2ptguard** global configuration command, the interface is brought out of the error-disabled state and allowed to retry the operation again when all the causes have timed out. If the error recovery function is not enabled for **l2ptguard**, the interface stays in the error-disabled state until you enter the **shutdown** and **no shutdown** interface configuration commands.

Enter the **drop-threshold** keyword to control the number of protocol packets per second that are received on an interface before it drops packets. When no protocol option is specified with a keyword, the threshold is applied to each of the tunneled Layer 2 protocol types. If you also set a shutdown threshold on the interface, the drop-threshold value must be less than or equal to the shutdown-threshold value.

When the drop threshold is reached, the interface drops Layer 2 protocol packets until the rate at which they are received is below the drop threshold.

The configuration is saved in NVRAM.

For more information about Layer 2 protocol tunneling, see the software configuration guide for this release.

## Examples

This example shows how to enable protocol tunneling for CDP packets and to configure the shutdown threshold as 50 packets per second:

```
Device(config-if)# l2protocol-tunnel cdp
Device(config-if)# l2protocol-tunnel shutdown-threshold cdp 50
```

This example shows how to enable protocol tunneling for STP packets and to configure the drop threshold as 400 packets per second:

```
Device> enable
Device# configure terminal
Device(config)# interface gigabitethernet1/0/11
Device(config-if)# l2protocol-tunnel stp
Device(config-if)# l2protocol-tunnel drop-threshold stp 400
```

This example shows how to enable point-to-point protocol tunneling for PAgP and UDLD packets and to configure the PAgP drop threshold as 1000 packets per second:

```
Device> enable
Device# configure terminal
Device(config)# interface gigabitethernet1/0/1
Device(config-if)# switchport access vlan 19
Device(config-if)# switchport mode dot1q-tunnel
Device(config-if)# l2protocol-tunnel point-to-point pagp
Device(config-if)# l2protocol-tunnel point-to-point udld
Device(config-if)# l2protocol-tunnel drop-threshold point-to-point pagp 1000
```

# lACP fast-switchover

To enable Link Aggregation Control Protocol (LACP) 1:1 link redundancy, use the **lACP fast-switchover** command in interface configuration mode. To disable LACP 1:1 link redundancy, use the **no** form of this command.

**lACP fast-switchover** [**dampening time**]  
**no lACP fast-switchover** [**dampening time**]

<b>Syntax Description</b>	<b>dampening time</b> Enables LACP 1:1 hot-standby dampening. The range is 30 to 180 seconds.
---------------------------	---

<b>Command Default</b>	LACP 1:1 link redundancy is disabled by default.
------------------------	--

<b>Command Modes</b>	Interface configuration (config-if)
----------------------	-------------------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Amsterdam 17.3.1	This command was introduced.

**Usage Guidelines**

Prior to entering the **lACP fast-switchover** command, you must ensure the following:

- The port channel protocol type is LACP.
- The **lACP max-bundle 1** command has been entered on the port channel. Note that the **lACP fast-switchover** command will not affect the **lACP max-bundle** command.

Prior to entering the **lACP fast-switchover dampening** command, you must ensure the following:

- The port channel protocol type is LACP.
- The **lACP max-bundle 1** and **lACP fast-switchover** commands have been entered on the port channel.

When you enable LACP 1:1 link redundancy, based on the system priority and port priority, the port with the higher system priority chooses one link as the active link and the other link as the standby link (lower the LACP port priority, higher the preference, and lower the LACP system priority, higher the preference). In the case of the LACP 1:1 Redundancy feature, when the active link fails, the standby link is selected as the new active link without taking down the port channel. When the original active link recovers, it reverts to its active link status. During this changeover, the port channel is also up.

In the case of LACP 1:1 Hot Standby Dampening feature, a timer is configured that delays the switchover back to the higher priority port after it becomes active.



- Note**
- We recommend that you configure only two ports (one active and one hot standby) in the bundle, for optimum performance.
  - LACP 1:1 redundancy must be enabled at both ends of the LACP EtherChannel.
  - LACP 1:1 redundancy and dampening work only on LACP port channels.

## Examples

The following example shows how to enable LACP 1:1 link redundancy:

```
Device> enable
Device# configure terminal
Device(config)# interface port-channel 40
Device(config-if)# lacp fast-switchover
Device(config-if)# lacp max-bundle 1
```

The following example shows how to enable LACP 1:1 hot standby dampening:

```
Device> enable
Device# configure terminal
Device(config)# interface port-channel 40
Device(config-if)# lacp fast-switchover
Device(config-if)# lacp max-bundle 1
Device(config-if)# lacp fast-switchover dampening 70
```

## Related Commands

Command	Description
<b>lacp max-bundle</b>	Assigns and configures an EtherChannel interface to an EtherChannel group.
<b>show etherchannel</b>	Displays the EtherChannel information for a channel.
<b>show lacp</b>	Displays the LACP channel group information.

## lACP max-bundle

To define the maximum number of active LACP ports allowed in a port channel, use the **lACP max-bundle** command in interface configuration mode. To return to the default setting, use the **no** form of this command.

```
lACP max-bundle max_bundle_number
no lACP max-bundle
```

<b>Syntax Description</b>	<i>max_bundle_number</i> The maximum number of active LACP ports in the port channel. The range is 1 to 8. The default is 8.
---------------------------	--

<b>Command Modes</b>	Interface configuration
----------------------	-------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Everest 16.5.1a	This command was introduced.

**Usage Guidelines**

An LACP channel group can have up to 16 Ethernet ports of the same type. Up to eight ports can be active, and up to eight ports can be in hot-standby mode. When there are more than eight ports in an LACP channel group, the device on the controlling end of the link uses port priorities to determine which ports are bundled into the channel and which ports are put in hot-standby mode. Port priorities on the other device (the noncontrolling end of the link) are ignored.

The **lACP max-bundle** command must specify a number greater than the number specified by the **port-channel min-links** command.

Use the **show etherchannel summary** command in privileged EXEC mode to see which ports are in the hot-standby mode (denoted with an H port-state flag in the output display).

This example shows how to specify a maximum of five active LACP ports in port channel 2:

```
Device> enable
Device# configure terminal
Device(config)# interface port-channel 2
Device(config-if)# lACP max-bundle 5
```

## lACP port-priority

To configure the port priority for the Link Aggregation Control Protocol (LACP), use the **lACP port-priority** command in interface configuration mode. To return to the default setting, use the **no** form of this command.

**lACP port-priority** *priority*  
**no lACP port-priority**

### Syntax Description

*priority* Port priority for LACP. The range is 1 to 65535.

### Command Default

The default is 32768.

### Command Modes

Interface configuration

### Command History

Release	Modification
Cisco IOS XE Everest 16.5.1a	This command was introduced.

### Usage Guidelines

The **lACP port-priority** command in interface configuration mode determines which ports are bundled and which ports are put in hot-standby mode when there are more than eight ports in an LACP channel group.

An LACP channel group can have up to 16 Ethernet ports of the same type. Up to eight ports can be active, and up to eight ports can be in standby mode.

In port-priority comparisons, a numerically lower value has a higher priority: When there are more than eight ports in an LACP channel group, the eight ports with the numerically lowest values (highest priority values) for LACP port priority are bundled into the channel group, and the lower-priority ports are put in hot-standby mode. If two or more ports have the same LACP port priority (for example, they are configured with the default setting of 65535), then an internal value for the port number determines the priority.



**Note** The LACP port priorities are only effective if the ports are on the device that controls the LACP link. See the **lACP system-priority** command in global configuration mode for determining which device controls the link.

Use the **show lACP internal** command in privileged EXEC mode to display LACP port priorities and internal port number values.

For information about configuring LACP on physical ports, see the configuration guide for this release.

This example shows how to configure the LACP port priority on a port:

```
Device> enable
Device# configure terminal
Device(config)# interface gigabitEthernet2/0/1
Device(config-if)# lACP port-priority 1000
```

You can verify your settings by entering the **show lACP** [*channel-group-number*] **internal** command in privileged EXEC mode.



# lACP rate

To set the rate at which Link Aggregation Control Protocol (LACP) control packets are ingressed to an LACP-supported interface, use the **lACP rate** command in interface configuration mode. To return to the default settings, use the **no** form of this command

```
lACP rate {normal | fast}
no lACP rate
```

<b>Syntax Description</b>	<p><b>normal</b> Specifies that LACP control packets are ingressed at the normal rate, every 30 seconds after the link is bundled.</p> <p><b>fast</b> Specifies that LACP control packets are ingressed at the fast rate, once every 1 second.</p>				
<b>Command Default</b>	The default ingress rate for control packets is 30 seconds after the link is bundled.				
<b>Command Modes</b>	Interface configuration				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE Everest 16.5.1a</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE Everest 16.5.1a	This command was introduced.
Release	Modification				
Cisco IOS XE Everest 16.5.1a	This command was introduced.				
<b>Usage Guidelines</b>	<p>Use this command to modify the duration of LACP timeout. The LACP timeout value on Cisco switch is three times the LACP rate that is configured on the interface. Using the <b>lACP rate</b> command, you can select the LACP timeout value for a switch to be either 90 seconds or 3 seconds.</p> <p>This command is supported only on LACP-enabled interfaces.</p> <p>This example shows how to specify the fast (1 second) ingress rate on interface GigabitEthernet 0/0:</p> <pre>Device&gt; enable Device# configure terminal Device(config)# interface gigabitEthernet 0/0 Device(config-if)# lACP rate fast</pre>				

# lACP system-priority

To configure the system priority for the Link Aggregation Control Protocol (LACP), use the **lACP system-priority** command in global configuration mode on the device. To return to the default setting, use the **no** form of this command.

**lACP system-priority** *priority*  
**no lACP system-priority**

<b>Syntax Description</b>	<i>priority</i> System priority for LACP. The range is 1 to 65535.
---------------------------	--

<b>Command Default</b>	The default is 32768.
------------------------	-----------------------

<b>Command Modes</b>	Global configuration
----------------------	----------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Everest 16.5.1a	This command was introduced.

**Usage Guidelines** The **lACP system-priority** command determines which device in an LACP link controls port priorities.

An LACP channel group can have up to 16 Ethernet ports of the same type. Up to eight ports can be active, and up to eight ports can be in standby mode. When there are more than eight ports in an LACP channel group, the device on the controlling end of the link uses port priorities to determine which ports are bundled into the channel and which ports are put in hot-standby mode. Port priorities on the other device (the noncontrolling end of the link) are ignored.

In priority comparisons, numerically lower values have a higher priority. Therefore, the system with the numerically lower value (higher priority value) for LACP system priority becomes the controlling system. If both devices have the same LACP system priority (for example, they are both configured with the default setting of 32768), the LACP system ID (the device MAC address) determines which device is in control.

The **lACP system-priority** command applies to all LACP EtherChannels on the device.

Use the **show etherchannel summary** command in privileged EXEC mode to see which ports are in the hot-standby mode (denoted with an H port-state flag in the output display).

This example shows how to set the LACP system priority:

```
Device> enable
Device# configure terminal
Device(config)# lACP system-priority 20000
```

You can verify your settings by entering the **show lACP sys-id** command in privileged EXEC mode.

# loopdetect

To detect network loops, use the **loopdetect** command in interface configuration mode. To disable loop-detection guard use the **no** form of this command.

```
loopdetect [ time | action syslog | source-port ]
no loopdetect [ time | action syslog | source-port ]
```

Syntax Description	
<i>time</i>	(Optional) Time interval at which loop-detect frames are sent, in seconds. Range: 0 to 10. Default: 5.
<b>action syslog</b>	(Optional) Displays a system message when a loop is detected.
<b>source-port</b>	(Optional) Error-disables the source port.

**Command Default** Loop-detection guard is not enabled.

**Command Modes** Interface configuration (config-if)

Command History	Release	Modification
	Cisco IOS XE Amsterdam 17.2.1	This command was introduced.

**Usage Guidelines** You can error-disable either the source port or the destination port depending on your requirement. When the **loopdetect** command is configured without any of the keywords or variables, the feature is enabled and the destination port is error-disabled when a loop is detected. We recommend that you error-disable the source port to better control traffic flow to and from your network.

The **loopdetect action syslog** command displays only a system message and does not error-disable the configured port. The **no loopdetect action syslog** command reverts the system to the last configured option.

## Examples

The following example shows how to enable loop-detection guard. In this example, the destination port is error-disabled by default and loop-detect frames are sent at the default time interval of five seconds:

```
Device# enable
Device# configure terminal
Device(config)# interface tengigabitethernet 1/0/18
Device(config-if)# loopdetect
```

The following example shows how to configure the time interval to send loop-detect frames. In this example, loop-detect frames are sent every 7 seconds and destination port is error-disabled when a loop is detected:

```
Device# enable
Device# configure terminal
Device(config)# interface tengigabitethernet 1/0/18
Device(config-if)# loopdetect 7
```

The following example shows how to enable the feature and only display a system message. There is no action taken on either the destination port or the source port:

```
Device# enable
Device# configure terminal
Device(config)# interface tengigabitethernet 1/0/18
Device(config-if)# loopdetect action syslog
```

The following example shows how to enable the feature and error-disable the source port:

```
Device# enable
Device# configure terminal
Device(config)# interface tengigabitethernet 1/0/18
Device(config-if)# loopdetect source-port
```

The following example shows how the **no loopdetect action syslog** command works. In the first part of the example, the feature has been configured to error disable the source port (**loopdetect source-port**). The feature is then reconfigured to display a system message and not error-disable a port (**loopdetect action syslog**). In the last part of the example, the **no** form of the **loopdetect action syslog** command is configured, which causes the system to revert to the last configured option, that is, to error disable the source port.

Part 1: Error-disabling the source port:

```
Device# enable
Device# configure terminal
Device(config)# interface twentyfivegigabitethernet 1/0/20
Device(config-if)# loopdetect source-port
```

Part 2: Reconfiguring to display a system message and not error-disable a port:

```
Device(config-if)# loopdetect action syslog
```

Part 3: Using the **no** form of **loopdetect action syslog** (see Twe1/0/20):

```
Device(config-if)# no loopdetect action syslog
Device(config-if)# end
```

```
Device# show loopdetect
Interface Interval Elapsed-Time Port-to-Errdisbale ACTION
-----
Twe1/0/1 5 3 errdisable Source Port SYSLOG
Twe1/0/20 5 0 errdisable Source Port ERRDISABLE
Twe2/0/3 5 2 errdisable Dest Port ERRDISABLE
Loopdetect is ENABLED
```

## Related Commands

Command	Description
<b>show loopdetect</b>	Displays details of all the interfaces where loop-detection guard is enabled.

## mvrp vlan creation

To enable dynamic VLAN creation on a device using Multiple VLAN Registration Protocol (MVRP), use the **mvrpvlancreation** command in global configuration mode. To disable dynamic VLAN creation for MVRP, use the **no** form of this command.

**mvrp vlan creation**  
**no mvrp vlan creation**

**Syntax Description** This command has no arguments or keywords.

**Command Default** MVRP is disabled.

**Command Modes** Global configuration (config)

Command History	Release	Modification
	Cisco IOS XE Fuji 16.8.1a	This command was introduced.

**Usage Guidelines** MVRP dynamic VLAN creation can be used only if Virtual Trunking Protocol (VTP) is in transparent mode.

### Examples

The following example shows a command sequence enabling MVRP dynamic VLAN creation. Notice that the device recognizes that the VTP mode is incorrect and rejects the request for dynamic VLAN creation. Once the VTP mode is changed, MVRP dynamic VLAN creation is allowed.

```
Device(config)# mvrp vlan creation
%Command Rejected: VTP is in non-transparent (server) mode.
Device(config)# vtp mode transparent
Setting device to VTP TRANSPARENT mode.
Device(config)# mvrp vlan creation
%VLAN now may be dynamically created via MVRP/
```

Related Commands	Command	Description
	<b>mvrp global</b>	Enables MVRP globally on a device.
	<b>vtp mode</b>	Sets the mode for VTP mode on the device.

## mvrp registration

To set the registrars in a Multiple Registration Protocol (MRP) Attribute Declaration (MAD) instance associated with an interface, use the **mvrpregistration** command in global configuration mode. To disable the registrars, use the **no** form of this command.

**mvrp registration {normal | fixed | forbidden}**  
**no mvrp registration**

### Syntax Description

<b>normal</b>	Registrar responds normally to incoming Multiple VLAN Registration Protocol (MVRP) messages. Normal is the default state.
<b>fixed</b>	Registrar ignores all incoming MVRP messages and remains in the IN state.
<b>forbidden</b>	Registrar ignores all incoming MVRP messages and remains in the EMPTY (MT) state.

### Command Default

Registrars are set to the normal state.

### Command Modes

Global configuration (config)

### Command History

Release	Modification
Cisco IOS XE Fuji 16.8.1a	This command was introduced.

### Usage Guidelines

The **mvrpregistration** command is operational only if MVRP is configured on an interface.

The **nomvrpregistration** command sets the registrar state to the default (normal).

This command can be used to set the registrar in a MAD instance associated with an interface to one of the three states. This command is effective only if MVRP is operational on the interface.

Given that up to 4094 VLANs can be configured on a trunk port, there may be up to 4094 Advanced Services Module (ASM) and Route Switch Module (RSM) pairs in a MAD instance associated with that interface.

### Examples

The following example sets a fixed, forbidden, and normal registrar on a MAD instance:

```
Device(config)# mvrp global
%MVRP is now globally enabled. MVRP is operational on IEEE 802.1q trunk ports only.
Device(config)# interface fastethernet2/1
Device(config-if)# mvrp registration fixed
Device(config-if)# interface fastethernet2/2
Device(config-if)# mvrp registration forbidden
Device(config-if)# interface fastethernet2/3
Device(config-if)# no mvrp registration
```

### Related Commands

Command	Description
<b>clear mvrp statistics</b>	Clears MVRP-related statistics recorded on one or all MVRP-enabled ports.

<b>Command</b>	<b>Description</b>
<b>debug mvrp</b>	Displays MVRP debugging information.
<b>mvrp global</b>	Enables MVRP globally on a device and on a particular interface.
<b>mvrp mac-learning auto</b>	Enables automatic learning of MAC table entries by MVRP.
<b>mvrp timer</b>	Sets period timers that are used in MRP on a given interface.
<b>mvrp vlan create</b>	Enables an MVRP dynamic VLAN.
<b>show mvrp interface</b>	Displays details of the administrative and operational MVRP states of all or one particular IEEE 802.1Q trunk port in the device.
<b>show mvrp summary</b>	Displays the MVRP configuration at the device level.

## mvrp timer

To set period timers that are used in Multiple VLAN Registration Protocol (MVRP) on a given interface, use the **mvrp timer** command in interface configuration mode. To remove the timer value, use the **no** form of this command.

**mvrp timer** {**join** | **leave** | **leave-all** | **periodic**} [*centiseconds*]  
**no mvrp timer**

### Syntax Description

<b>join</b>	Specifies the time interval between two transmit opportunities that are applied to the Applicant State Machine (ASMs).
<b>leave</b>	Specifies the duration time before a registrar is moved to EMPTY (MT) state from leave-all (LV) state.
<b>leave-all</b>	Specifies the time it takes for a LeaveAll timer to expire.
<b>periodic</b>	Sets the timer value to periodic, a fixed value of 100 centiseconds.
<i>centiseconds</i>	Timer value measured in centiseconds. <ul style="list-style-type: none"> <li>• Join timer value range is 20 to 10000000.</li> <li>• Leave timer value range is 60 to 10000000.</li> <li>• LeaveAll timer value range is 10000 and 10000000.</li> <li>• Periodic timer value is fixed at 100 centiseconds.</li> </ul>

### Command Default

Join timer value: 20 centiseconds  
 Leave timer value: 60 centiseconds  
 LeaveAll timer value: 10000 centiseconds

### Command Modes

Interface configuration (config-if)

### Command History

Release	Modification
Cisco IOS XE Fuji 16.8.1a	This command was introduced.

### Usage Guidelines

The **nomvrptimer** command resets the timer value to the default value.

### Examples

The following example sets the timer levels on an interface:

```
Device(config)# mvrp global
%MVRP is now globally enabled. MVRP is operational on IEE 802.1q trunk ports.
Device(config)# interface GigabitEthernet 6/1
Device(config-if)# mvrp timer join 30
Device(config-if)# mvrp timer leave 70
Device(config-if)# mvrp timer leaveAll 15000
```



Related Commands	Command	Description
	<b>clear mvrp statistics</b>	Clears MVRP-related statistics recorded on one or all MVRP enabled ports.
	<b>debug mvrp</b>	Displays MVRP debugging information.
	<b>mvrp global</b>	Enables MVRP globally on a device and on a particular interface.
	<b>mvrp mac-learning auto</b>	Enables automatic learning of MAC table entries by MVRP.
	<b>mvrp registration</b>	Sets the registrars in a MAD instance associated with an interface.
	<b>mvrp vlan create</b>	Enables an MVRP dynamic VLAN.
	<b>show mvrp interface</b>	Displays details of the administrative and operational MVRP states of all or one particular IEEE 802.1q trunk port in the device.
	<b>show mvrp summary</b>	Displays the MVRP configuration at the device level.

## name (MST)

To set the name of a Multiple Spanning Tree (MST) region, use the **name** command in MST configuration submode. To return to the default name, use the **no** form of this command.

**name** *name*  
**no name** *name*

Syntax Description	
name	Name to give the MST region. It can be any string with a maximum length of 32 characters.

**Command Modes** MST configuration (config-mst)

Command History	Release	Modification
	Cisco IOS XE Everest 16.5.1a	This command was introduced.

**Usage Guidelines** Two or more devices with the same VLAN mapping and configuration version number are considered to be in different MST regions if the region names are different.



**Note** Be careful when using the **name** command to set the name of an MST region. If you make a mistake, you can put the device in a different region. The configuration name is a case-sensitive parameter.

### Examples

This example shows how to name a region:

```
Device(config)# spanning-tree mst configuration
Device(config-mst)# name Cisco
Device(config-mst)#
```

Related Commands	Command	Description
	<b>instance</b>	Maps a VLAN or a set of VLANs to an MST instance.
	<b>revision</b>	Sets the revision number for the MST configuration.
	<b>show spanning-tree mst</b>	Displays the information about the MST protocol.
	<b>spanning-tree mst configuration</b>	Enters MST configuration submode.

# no ptp enable

To disable PTP on an interface, use the **no ptp enable** command in interface configuration mode.

To re-enable PTP on the same interface, use the **ptp enable** command in interface configuration mode.

**no ptp enable**  
**ptp enable**

**Syntax Description** This command has no arguments or keywords.

**Command Default** PTP is enabled on all the ports, by default.

**Command Modes** Interface configuration (config-if)

Command History	Release	Modification
	Cisco IOS XE Fuji 16.8.1a	This command was introduced.

## Examples

This example shows how to disable PTP on an interface:

```
Device# configure terminal
Device(config)# interface gigabitethernet2/0/1
Device(config-if)# no ptp enable
```

## Related Commands

Command	Description
<b>ptp (interface)</b>	Configures PTP on interfaces.
<b>ptp profile dot1as</b>	Enables Generalized Precision Time Protocol (gPTP) globally.

# pagp learn-method

To learn the source address of incoming packets received from an EtherChannel port, use the **pagp learn-method** command in interface configuration mode. To return to the default setting, use the **no** form of this command.

```
pagp learn-method {aggregation-port | physical-port}
no pagp learn-method
```

<b>Syntax Description</b>	<p><b>aggregation-port</b> Specifies address learning on the logical port channel. The device sends packets to the source using any port in the EtherChannel. This setting is the default. With aggregation-port learning, it is not important on which physical port the packet arrives.</p> <p><b>physical-port</b> Specifies address learning on the physical port within the EtherChannel. The device sends packets to the source using the same port in the EtherChannel from which it learned the source address. The other end of the channel uses the same port in the channel for a particular destination MAC or IP address.</p>	
<b>Command Default</b>	The default is aggregation-port (logical port channel).	
<b>Command Modes</b>	Interface configuration	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Everest 16.5.1a	This command was introduced.

**Usage Guidelines**

The learn method must be configured the same at both ends of the link.

The device supports address learning only on aggregate ports even though the **physical-port** keyword is provided in the command-line interface (CLI). The **pagp learn-method** and the **pagp port-priority** commands in interface configuration mode have no effect on the device hardware, but they are required for PAGP interoperability with devices that only support address learning by physical ports.

When the link partner to the device is a physical learner, we recommend that you configure the device as a physical-port learner by using the **pagp learn-method physical-port** command in interface configuration mode. We also recommend that you set the load-distribution method based on the source MAC address by using the **port-channel load-balance src-mac** command in global configuration mode. Use the **pagp learn-method** command in interface configuration mode only in this situation.

This example shows how to set the learning method to learn the address on the physical port within the EtherChannel:

```
Device> enable
Device# configure terminal
Device(config)# interface port-channel 2
Device(config-if)# pagp learn-method physical-port
```

This example shows how to set the learning method to learn the address on the port channel within the EtherChannel:

```
Device> enable
Device# configure terminal
```

```
Device(config)# interface port-channel 2  
Device(config-if)# pagp learn-method aggregation-port
```

You can verify your settings by entering either the **show running-config** command in privileged EXEC mode or the **show pagp *channel-group-number* internal** command in privileged EXEC mode.

## pagp port-priority

To select a port over which all Port Aggregation Protocol (PAgP) traffic through the EtherChannel is sent, use the **pagp port-priority** command in interface configuration mode. If all unused ports in the EtherChannel are in hot-standby mode, they can be placed into operation if the currently selected port and link fails. To return to the default setting, use the **no** form of this command.

**pagp port-priority** *priority*  
**no pagp port-priority**

<b>Syntax Description</b>	<i>priority</i> Priority number. The range is from 0 to 255.				
<b>Command Default</b>	The default is 128.				
<b>Command Modes</b>	Interface configuration				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE Everest 16.5.1a</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE Everest 16.5.1a	This command was introduced.
Release	Modification				
Cisco IOS XE Everest 16.5.1a	This command was introduced.				

**Usage Guidelines** The physical port with the highest priority that is operational and has membership in the same EtherChannel is the one selected for PAgP transmission.

The device supports address learning only on aggregate ports even though the **physical-port** keyword is provided in the command-line interface (CLI). The **pagp learn-method** and the **pagp port-priority** commands in interface configuration mode have no effect on the device hardware, but they are required for PAgP interoperability with devices that only support address learning by physical ports, such as the Catalyst 1900 switch.

When the link partner to the device is a physical learner, we recommend that you configure the device as a physical-port learner by using the **pagp learn-method physical-port** command in interface configuration mode. We also recommend that you set the load-distribution method based on the source MAC address by using the **port-channel load-balance src-mac** command in global configuration mode. Use the **pagp learn-method** command in interface configuration mode only in this situation.

This example shows how to set the port priority to 200:

```
Device> enable
Device# configure terminal
Device(config)# interface gigabitethernet2/0/1
Device(config-if)# pagp port-priority 200
```

You can verify your setting by entering the **show running-config** command in privileged EXEC mode or the **show pagp channel-group-number internal** command in privileged EXEC mode.

## peer (PTP)

To connect to a peer Precision Time Protocol-aware (PTP-aware) device, use the **peer** command in property transport sub-configuration mode.

```
peer { ip ip_address | vrf word ip ip_address }
```

Syntax Description	ip ip_address	IP address of a peer PTP device.
	vrf word	Default virtual routing and forwarding (VRF) or user-defined VRF.

**Command Default** None

**Command Modes** Property transport configuration (config-property-transport)

Command History	Release	Modification
	Cisco IOS XE Bengaluru 17.5.1	This command was introduced.

**Usage Guidelines** You must configure the PTP-property name using the **ptp property** command and configure a unicast IPv4 connection from a loopback interface using the **transport unicast ipv4 local loopback** command before connecting to a peer PTP-aware device.

### Examples

The following example shows how to connect to a peer PTP-aware device:

```
Device> enable
Device# configure terminal
Device(config)# ptp property cisco1
Device(config-property)# transport unicast ipv4 local loopback 0
Device(config-property-transport)# peer ip 192.0.2.1
Device(config-property-transport)# end
```

Related Commands	Command	Description
	<b>ptp dot1as extend property</b>	Extends IEEE 802.1AS profile to a PTP property name.
	<b>ptp property</b>	Sets the PTP property name.
	<b>transport unicast ipv4 local loopback</b>	Configures a unicast IPv4 connection from a loopback interface.

# policy-map

To enter policy-map configuration mode and create or modify a policy map that can be attached to one or more interfaces to specify a service policy, use the **policy-map** command in global configuration mode. To delete a policy map, use the **no** form of this command.

**policy-map** [ **type** { **access-control** | **control subscriber** | **packet-service** | **performance-monitor** } ] *policy-map name*

Syntax Description	type	(Optional) Specifies the policy-map type.
	<b>access-control</b>	(Optional) Enables the access-control specific policy map.
	<b>control subscriber</b>	(Optional) Enables subscriber control policy domain.
	<b>packet-service</b>	(Optional) Enables packet service policy map.
	<b>performance-monitor</b>	(Optional) Enables policy map for the performance monitoring feature.
	<i>policy-map name</i>	Specifies the policy map.

**Command Default** The policy map is not configured.

Command History	Release	Modification
	Cisco IOS XE Fuji 16.8.1a	This command was introduced.

**Command Modes** Global configuration (config)

**Usage Guidelines** Use the **policy-map** command to specify the name of the policy map to create (add or modify) before you configure policies for classes whose match criteria are defined in a class map with the **class-map** and **match** commands.



**Note** You can configure class policies in a policy map only if the classes have match criteria defined for them.



**Note** Because you can configure a maximum of 64 class maps, a policy map cannot contain more than 64 class policies.

A single policy map can be attached concurrently to more than one interface. Except as noted, when you attempt to attach a policy map to an interface, the attempt is denied if the available bandwidth on the interface cannot accommodate the total bandwidth requested by the multiple policies. In such cases, if the policy map is already attached to other interfaces, the map is removed.

### Example:

The following is sample output from the **policy-map** command:



```
Device# policy-map AVB-Output-Child-Policy

policy-map AVB-Output-Child-Policy
  class VOIP-PRIORITY-QUEUE
    bandwidth remaining percent 30
    queue-buffers ratio 10
  class MULTIMEDIA-CONFERENCING-STREAMING-QUEUE
    bandwidth remaining percent 15
    queue-limit dscp AF41 percent 80
    queue-limit dscp AF31 percent 80
    queue-limit dscp AF42 percent 90
    queue-limit dscp AF32 percent 90
    queue-buffers ratio 10
  class TRANSACTIONAL-DATA-QUEUE
    bandwidth remaining percent 15
    queue-limit dscp AF21 percent 80
    queue-limit dscp AF22 percent 90
    queue-buffers ratio 10
  class BULK-SCAVENGER-DATA-QUEUE
    bandwidth remaining percent 15
    queue-limit dscp AF11 percent 80
    queue-limit dscp AF12 percent 90
    queue-limit dscp CS1 percent 80
    queue-buffers ratio 15
  class class-default
    bandwidth remaining percent 25
    queue-buffers ratio 25
```

# port-channel

To convert the auto created EtherChannel into a manual channel and adding configuration on the EtherChannel, use the **port-channel** command in privileged EXEC mode.

**port-channel** { *channel-group-number* **persistent** | **persistent** }

## Syntax Description

<i>channel-group-number</i>	Channel group number. The range is 1 to 128.
<b>persistent</b>	Converts the auto created EtherChannel into a manual channel and allows you to add configuration on the EtherChannel.

## Command Modes

Privileged EXEC

## Command History

Release	Modification
Cisco IOS XE Everest 16.5.1a	This command was introduced.

## Usage Guidelines

You can use the **show etherchannel summary** command in privileged EXEC mode to display the EtherChannel information.

## Examples

This example shows how to convert the auto created EtherChannel into a manual channel:

```
Device> enable
Device# port-channel 1 persistent
```

# port-channel auto

To enable the auto-LAG feature on a switch globally, use the **port-channel auto** command in global configuration mode. To disable the auto-LAG feature on the switch globally, use **no** form of this command.

**port-channel auto**  
**no port-channel auto**

---

**Command Default** By default, the auto-LAG feature is disabled globally and is enabled on all port interfaces.

---

**Command Modes** Global configuration

---

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Everest 16.5.1a	This command was introduced.

---

---

**Usage Guidelines** You can use the **show etherchannel auto** command in privileged EXEC mode to verify if the EtherChannel was created automatically.

---

## Examples

This example shows how to enable the auto-LAG feature on the switch:

```
Device> enable
Device# configure terminal
Device(config)# port-channel auto
```

## port-channel load-balance

To set the load-distribution method among the ports in the EtherChannel, use the **port-channel load-balance** command in global configuration mode. To reset the load-balancing mechanism to the default setting, use the **no** form of this command.

```
port-channel load-balance {dst-ip | dst-mac | dst-mixed-ip-port | dst-port | extended | src-dst-ip |
src-dst-mac | src-dst-mixed-ip-port | src-dst-port | src-ip | src-mac | src-mixed-ip-port | src-port |
vlan-dst-ip | vlan-dst-mixed-ip-port | vlan-src-dst-ip | vlan-src-dst-mixed-ip-port | vlan-src-ip |
vlan-src-mixed-ip-port}
```

```
no port-channel load-balance
```

Syntax Description		
<b>dst-ip</b>	Specifies load distribution based on the destination host IP address.	
<b>dst-mac</b>	Specifies load distribution based on the destination host MAC address. Packets to the same destination are sent on the same port, but packets to different destinations are sent on different ports in the channel.	
<b>dst-mixed-ip-port</b>	Specifies load distribution based on the destination IPv4 or IPv6 address and the TCP/UDP (Layer 4) port number.	
<b>dst-port</b>	Specifies load distribution based on the destination TCP/UDP (Layer 4) port number for both IPv4 and IPv6.	
<b>extended</b>	Sets extended load balance methods among the ports in the EtherChannel.	
<b>src-dst-ip</b>	Specifies load distribution based on the source and destination host IP address.	
<b>src-dst-mac</b>	Specifies load distribution based on the source and destination host MAC address.	
<b>src-dst-mixed-ip-port</b>	Specifies load distribution based on the source and destination host IP address and TCP/UDP (layer 4) port number.	
<b>src-dst-port</b>	Specifies load distribution based on the source and destination TCP/UDP (Layer 4) port number.	
<b>src-ip</b>	Specifies load distribution based on the source host IP address.	
<b>src-mac</b>	Specifies load distribution based on the source MAC address. Packets from different hosts use different ports in the channel, but packets from the same host use the same port.	
<b>src-mixed-ip-port</b>	Specifies load distribution based on the source host IP address and TCP/UDP (Layer 4) port number.	
<b>src-port</b>	Specifies load distribution based on the TCP/UDP (Layer 4) port number.	
<b>vlan-dst-ip</b>	Specifies load distribution based on the VLAN ID and destination IP address.	

<b>vlan-dst-mixed-ip-port</b>	Specifies load distribution based on the VLAN ID, destination IP address, and TCP/UDP port number.
<b>vlan-src-dst-ip</b>	Specifies load distribution based on the VLAN ID, source and destination IP address.
<b>vlan-src-dst-mixed-ip-port</b>	Specifies load distribution based on the VLAN ID, source and destination IP address, and TCP/UDP port number.
<b>vlan-src-ip</b>	Specifies load distribution based on the VLAN ID and source IP address.
<b>vlan-src-mixed-ip-port</b>	Specifies load distribution based on the VLAN ID, source IP address, and TCP/UDP port number.

**Command Default**

The default for Cisco Catalyst 9500 Series Switches is **src-mac**

The default for Cisco Catalyst 9500 High Performance Series Switches is **src-dst-mixed-ip-port**

**Command Modes**

Global configuration (config)

**Command History**

Release	Modification
Cisco IOS XE Everest 16.5.1a	This command was introduced.
Cisco IOS XE Gibraltar 16.11.1	This command was modified. The VLAN-based load balancing keywords <b>vlan-dst-ip</b> , <b>vlan-dst-mixed-ip-port</b> , <b>vlan-src-dst-ip</b> , <b>vlan-src-dst-mixed-ip-port</b> , <b>vlan-src-ip</b> , and <b>vlan-src-mixed-ip-port</b> were added on Cisco Catalyst 9500H switches.

**Usage Guidelines**

You can verify your setting by entering either the **show running-config** command in privileged EXEC mode or the **show etherchannel load-balance** command in privileged EXEC mode.



**Note** The VLAN-based load balancing keywords **vlan-dst-ip**, **vlan-dst-mixed-ip-port**, **vlan-src-dst-ip**, **vlan-src-dst-mixed-ip-port**, **vlan-src-ip**, and **vlan-src-mixed-ip-port** are supported only on Cisco Catalyst 9500H switches.

**Examples**

The following example shows how to set the load-distribution method to dst-mac:

```
Device> enable
Device# configure terminal
Device(config)# port-channel load-balance dst-mac
```

**Related Commands**

<b>Command</b>	<b>Description</b>
<b>show etherchannel load-balance</b>	Displays information about EtherChannel load balancing.
<b>show running-config</b>	Displays the running configuration.

## port-channel load-balance extended

To set combinations of load-distribution methods among the ports in the EtherChannel, use the **port-channel load-balance extended** command in global configuration mode. To reset the extended load-balancing mechanism to the default setting, use the **no** form of this command.

```
port-channel load-balance extended {dst-ip | dst-mac | dst-port | ipv6-label | l3-proto | src-ip | src-mac | src-port}
no port-channel load-balance extended
```

### Syntax Description

<b>dst-ip</b>	Specifies load distribution based on the destination host IP address.
<b>dst-mac</b>	Specifies load distribution based on the destination host MAC address. Packets to the same destination are sent on the same port, but packets to different destinations are sent on different ports in the channel.
<b>dst-port</b>	Specifies load distribution based on the destination TCP/UDP (Layer 4) port number for both IPv4 and IPv6.
<b>ipv6-label</b>	Specifies load distribution based on the source MAC address and IPv6 flow label. This keyword is supported only on Cisco Catalyst 9500 Series Switches.
<b>l3-proto</b>	Specifies load distribution based on the source MAC address and Layer 3 protocols. This keyword is supported only on Cisco Catalyst 9500 Series Switches.
<b>src-ip</b>	Specifies load distribution based on the source host IP address.
<b>src-mac</b>	Specifies load distribution based on the source MAC address. Packets from different hosts use different ports in the channel, but packets from the same host use the same port.
<b>src-port</b>	Specifies load distribution based on the TCP/UDP (Layer 4) port number.

### Command Default

The default is **src-mac**.

### Command Modes

Global configuration

### Command History

Release	Modification
Cisco IOS XE Everest 16.5.1a	This command was introduced.
Cisco IOS XE Amsterdam 17.3.x	The command was modified. You have to mandatorily configure atleast one of the keywords for the <b>port-channel load-balance extended</b> command.

### Usage Guidelines

You can verify your setting by entering either the **show running-config** command in privileged EXEC mode or the **show etherchannel load-balance** command in privileged EXEC mode.

---

**Examples**

This example shows how to set the extended load-distribution method:

```
Device> enable
Device# configure terminal
Device(config)# port-channel load-balance extended dst-ip dst-mac src-ip
```



## port-channel min-links

To define the minimum number of LACP ports that must be bundled in the link-up state and bundled in the EtherChannel in order that a port channel becomes active, use the **port-channel min-links** command in interface configuration mode. To return to the default setting, use the **no** form of this command.

```
port-channel min-links min_links_number
no port-channel min-links
```

### Syntax Description

*min\_links\_number* The minimum number of active LACP ports in the port channel.

The range is 2 to 8 if the port channel number is 128 or lesser and the range is 2 to 4 if the port channel number is 129 or greater.

The default is 1.

### Command Modes

Interface configuration

### Command History

Release	Modification
Cisco IOS XE Everest 16.5.1a	This command was introduced.

### Usage Guidelines

An LACP channel group can have up to 16 Ethernet ports of the same type. Up to eight ports can be active, and up to eight ports can be in hot-standby mode. When there are more than eight ports in an LACP channel group, the device on the controlling end of the link uses port priorities to determine which ports are bundled into the channel and which ports are put in hot-standby mode. Port priorities on the other device (the noncontrolling end of the link) are ignored.

The **port-channel min-links** command must specify a number a less than the number specified by the **lACP max-bundle** command.

Use the **show etherchannel summary** command in privileged EXEC mode to see which ports are in the hot-standby mode (denoted with an H port-state flag in the output display).

This example shows how to specify a minimum of three active LACP ports before port channel 2 becomes active:

```
Device> enable
Device# configure terminal
Device(config)# interface port-channel 2
Device(config-if)# port-channel min-links 3
```

## ptp dot1as extend property

To extend IEEE 802.1AS profile to a Precision Time Protocol-property (PTP-property) name, use the **ptp dot1as extend property** command in global configuration mode.

**ptp dot1as extend property** *word*

<b>Syntax Description</b>	<i>word</i>	PTP property name
<b>Command Default</b>	None	
<b>Command Modes</b>	Global configuration (config)	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Bengaluru 17.5.1	This command was introduced.

### Examples

The following example shows how to extend IEEE 802.1AS profile to a PTP-property name:

```
Device> enable
Device# configure terminal
Device(config)# ptp property cisco1
Device(config-property)# transport unicast ipv4 local loopback 0
Device(config-property-transport)# peer ip 192.0.2.1
Device(config-property-transport)# end
Device# configure terminal
Device(config)# ptp dot1as extend property cisco1
Device(config)# end
```

### Related Commands

Command	Description
<b>peer</b>	Connects to a peer PTP-aware device.
<b>ptp property</b>	Sets the PTP property name.
<b>source ip interface</b>	(Optional) Configures the source IP interface.
<b>transport unicast ipv4 local loopback</b>	Configures a unicast IPv4 connection from a loopback interface.

## ptp ip dscp

To configure IP DSCP value for PTP messages, use the **ptp ip dscp** command in global configuration mode. To remove the configuration, use the **no** form of this command.

```
ptp ip dscp value message {event | general}
```

```
no ptp ip dscp value message {event | general}
```

### Syntax Description

**value** IP DSCP value. The range is from 0 to 63.

**event** Configures IP DSCP value for PTP event messages.

**general** Configures IP DSCP value for PTP general messages.

### Command Default

PTP uses 0x2f for general messages and 0x3b for event messages

### Command Modes

Global configuration (config)

### Command History

Release	Modification
Cisco IOS XE Bengaluru 17.6.1	This command was introduced.

### Usage Guidelines

Use this command for IEEE 1588 PTP profiles in IPv4 UDP transport mode only.

### Examples

The following example shows how to configure IP DSCP value for PTP messages:

```
Device> enable
Device# configure terminal
Device(config)# ptp transport-protocol ipv4 udp
Device(config)# ptp mode boundary delay-req
Device(config)# interface range gigabitethernet1/0/1-gigabitethernet1/0/2
Device(config-if-range)# ptp sync interval -3
Device(config-if-range)# ptp delay-req interval -3
Device(config-if-range)# exit
Device(config)# ptp ip dscp 46 message general
Device(config)# ptp ip dscp 46 message event
Device(config)# end
```

### Related Commands

Command	Description
<b>ptp mode boundary delay-req</b>	Configures the device for boundary clock mode using the peer delay request mechanism.
<b>ptp sync interval</b>	Configures the interval between PTP synchronization messages on the interface range.
<b>ptp delay-req interval</b>	Configures the logarithmic mean interval allowed between PTP delay request messages when the port is in the master state.

## ptp priority1 value

To specify the priority 1 value to use when advertising a PTP clock, use the **ptp priority1 value** command in global configuration mode.

**ptp priority1** *value*

<b>Syntax Description</b>	<p><b>value</b> Specifies the priority 1 number to use for this clock.</p> <p>The range is 0 to 255. The default value is 128.</p> <p><b>Note</b> If the value of priority1 is configured to 255, the clock cannot become as Grandmaster.</p>
---------------------------	---

<b>Command Default</b>	Default is 128.
------------------------	-----------------

<b>Command Modes</b>	Global configuration (config)
----------------------	-------------------------------

<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE Fuji 16.8.1a</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE Fuji 16.8.1a	This command was introduced.
Release	Modification				
Cisco IOS XE Fuji 16.8.1a	This command was introduced.				

### Example

This example shows how to specify the priority1 value:

```
Device> enable
Device# configure terminal
Device(config)# ptp priority1 120
```

<b>Related Commands</b>	<table border="1"> <thead> <tr> <th>Command</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td><b>ptp priority2 value</b></td> <td>Specifies the priority 2 number to use for this clock.</td> </tr> <tr> <td><b>no ptp enable</b></td> <td>Disables PTP on an interface.</td> </tr> <tr> <td><b>ptp profile dot1as</b></td> <td>Enables Generalized Precision Time Protocol (gPTP) globally.</td> </tr> </tbody> </table>	Command	Description	<b>ptp priority2 value</b>	Specifies the priority 2 number to use for this clock.	<b>no ptp enable</b>	Disables PTP on an interface.	<b>ptp profile dot1as</b>	Enables Generalized Precision Time Protocol (gPTP) globally.
Command	Description								
<b>ptp priority2 value</b>	Specifies the priority 2 number to use for this clock.								
<b>no ptp enable</b>	Disables PTP on an interface.								
<b>ptp profile dot1as</b>	Enables Generalized Precision Time Protocol (gPTP) globally.								

## ptp priority2 value

To specify the priority 2 number to use when advertising a PTP clock, use the **ptp priority2 value** command in global configuration mode

**ptp priority2** *value*

<b>Syntax Description</b>	<b>value</b> Specifies the priority 2 number to use for this clock. The range is 0 to 255. The default value is 128.
---------------------------	---

<b>Command Default</b>	Default is 128.
------------------------	-----------------

<b>Command Modes</b>	Global configuration (config)
----------------------	-------------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Fuji 16.8.1a	This command was introduced.

### Example

This example shows how to specify the priority2 value:

```
Device> enable
Device# configure terminal
Device(config)# ptp priority 2 120
```

Related Commands	Command	Description
	<b>ptp priority1 value</b>	Specifies the priority 1 number to use for this clock.
	<b>no ptp enable</b>	Disables PTP on an interface.
	<b>ptp profile dot1as</b>	Enables Generalized Precision Time Protocol (gPTP) globally.

## ptp profile dot1as

To enable Generalized Precision Time Protocol (gPTP) globally, use the **ptp profile dot1as** command in global configuration mode. To disable gPTP, use the **no** form of the command.

**ptp profile dot1as**  
**no ptp profile dot1as**

**Command Default** PTP is disabled on interfaces.

**Command Modes** Global configuration (config)

Command History	Release	Modification
	Cisco IOS XE Fuji 16.8.1a	This command was introduced.

### Examples

This example shows how to enable gPTP:

```
Device> enable
Device# configure terminal
Device(config)# ptp profile dot1as
```

### Related Commands

Command	Description
<b>ptp (interface)</b>	Configures PTP on interfaces.
<b>no ptp enable</b>	Disables PTP on an interface.

## ptp property

To set the Precision Time Protocol-property (PTP-property) name, use the **ptp property** command in global configuration mode. To remove the PTP property name, use the **no** form of this command.

```
ptp property word
no ptp property word
```

<b>Syntax Description</b>	<i>word</i>	PTP-property name.
<b>Command Default</b>	None	
<b>Command Modes</b>	Global configuration (config)	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Bengaluru 17.5.1	This command was introduced.

**Usage Guidelines** You can configure more than one IPv4 unicast connection that connects to a different boundary clock under the same property name.

### Examples

The following example shows how to set the PTP-property name:

```
Device> enable
Device# configure terminal
Device(config)# ptp property cisco1
Device(config-property)#
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>peer</b>	Connects to a peer PTP-aware device.
	<b>ptp dot1as extend property</b>	Extends IEEE 802.1AS profile to a PTP property name.
	<b>source ip interface</b>	(Optional) Configures the source IP interface.
	<b>transport unicast ipv4 local loopback</b>	Configures a unicast IPv4 connection from a loopback interface.

## ptp role primary

To set an interface permanently as primary (master), use the **ptp role primary** command in interface configuration mode. To remove an interface as primary (master), use the **no ptp role primary** command.

**ptp role primary**  
**no ptp role primary**

**Command Default** Interface is set as either primary (master) or secondary (slave) based on Best Master Clock Algorithm (BMCA)

**Command Modes** Interface configuration (config-if)

Command History	Release	Modification
	Cisco IOS XE Bengaluru 17.5.1	This command was introduced.

**Usage Guidelines** Setting a port permanently ensures that the port remain as a primary (master) even if a clock connected to the port can be elected as grandmaster clock.



**Note** The command **ptp role primary** must be used only on ports that are used as end nodes on a network that are connected to devices requiring synchronization.

Use the **show ptp port *interface\_id*** command to verify if the port is set as primary (master).

### Examples

The following example shows how to set an interface permanently as primary (master):

```
Device> enable
Device# configure terminal
Device(config)# interface TenGigabitEthernet1/0/1
Device(config-if)# ptp role primary
```

### Related Commands

Command	Description
<b>show ptp port <i>interface_id</i></b>	Displays the details of the port.



## rep admin vlan

To configure a Resilient Ethernet Protocol (REP) administrative VLAN for the REP to transmit hardware flood layer (HFL) messages, use the **rep admin vlan** command in global configuration mode. To return to the default configuration with VLAN 1 as the administrative VLAN, use the **no** form of this command.

**rep admin vlan** *vlan-id* **segment** *segment-id*  
**no rep admin vlan** *vlan-id* **segment** *segment-id*

Syntax Description		
	<i>vlan-id</i>	48-bit static MAC address.
	<b>segment</b>	configures administrative VLAN for an REP segment.
	<i>segment-id</i>	specifies the segment for which the admin VLAN has been assigned. Segment id number ranges from 1-1024
Command Default	Global configuration	
Command Modes	Global configuration	
Command History	Release	Modification
	Cisco IOS XE Everest 16.5.1a	This command was introduced.
	Cisco IOS XE Amsterdam 17.2.1	The <b>segment</b> keyword was introduced.

## rep block port

To configure Resilient Ethernet Protocol (REP) VLAN load balancing on a REP primary edge port, use the **rep block port** command in interface configuration mode. To return to the default configuration with VLAN 1 as the administrative VLAN, use the **no** form of this command.

```
rep block port {id port-id | neighbor-offset | preferred} vlan {vlan-list | all}
no rep block port {id port-id | neighbor-offset | preferred}
```

Syntax Description	
<b>id</b> <i>port-id</i>	Specifies the VLAN blocking alternate port by entering the unique port ID, which is automatically generated when REP is enabled. The REP port ID is a 16-character hexadecimal value.
<i>neighbor-offset</i>	VLAN blocking alternate port by entering the offset number of a neighbor. The range is from -256 to +256. A value of 0 is invalid.
<b>preferred</b>	Selects the regular segment port previously identified as the preferred alternate port for VLAN load balancing.
<b>vlan</b>	Identifies the VLANs to be blocked.
<i>vlan-list</i>	VLAN ID or range of VLAN IDs to be displayed. Enter a VLAN ID from 1 to 4094, or a range or sequence of VLANs (such as 1-3, 22, and 41-44) to be blocked.
<b>all</b>	Blocks all the VLANs.

**Command Default** The default behavior after you enter the **rep preempt segment** command in privileged EXEC (for manual preemption) is to block all the VLANs at the primary edge port. This behavior remains until you configure the **rep block port** command.

If the primary edge port cannot determine which port is to be the alternate port, the default action is no preemption and no VLAN load balancing.

**Command Modes** Interface configuration

Command History	Release	Modification
	Cisco IOS XE Everest 16.5.1a	This command was introduced.

**Usage Guidelines** When you select an alternate port by entering an offset number, this number identifies the downstream neighbor port of an edge port. The primary edge port has an offset number of 1; positive numbers above 1 identify downstream neighbors of the primary edge port. Negative numbers identify the secondary edge port (offset number -1) and its downstream neighbors.



**Note** Do not enter an offset value of 1 because that is the offset number of the primary edge port itself.

If you have configured a preempt delay time by entering the **rep preempt delay seconds** command in interface configuration mode and a link failure and recovery occurs, VLAN load balancing begins after the configured

preemption time period elapses without another link failure. The alternate port specified in the load-balancing configuration blocks the configured VLANs and unblocks all the other segment ports. If the primary edge port cannot determine the alternate port for VLAN balancing, the default action is no preemption.

Each port in a segment has a unique port ID. To determine the port ID of a port, enter the **show interfaces interface-id rep detail** command in privileged EXEC mode.

### Examples

The following example shows how to configure REP VLAN load balancing:

```
Device> enable
Device# configure terminal
Device(config)# interface TenGigabitEthernet 4/1
Device(config-if)# rep block port id 0009001818D68700 vlan 1-100
```

### Related Commands

Command	Description
<b>show interfaces rep detail</b>	Displays detailed REP configuration and status for all the interfaces or the specified interface, including the administrative VLAN.

## rep lsl-age-timer

To configure the Resilient Ethernet Protocol (REP) link status layer (LSL) age-out timer value, use the **rep lsl-age-timer** command in interface configuration mode. To restore the default age-out timer value, use the **no** form of this command.

```
rep lsl-age-timer milliseconds
no rep lsl-age-timer milliseconds
```

<b>Syntax Description</b>	<i>milliseconds</i> REP LSL age-out timer value, in milliseconds (ms). The range is from 120 to 10000 in multiples of 40.				
<b>Command Default</b>	The default LSL age-out timer value is 5 ms.				
<b>Command Modes</b>	Interface configuration				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE Everest 16.5.1a</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE Everest 16.5.1a	This command was introduced.
Release	Modification				
Cisco IOS XE Everest 16.5.1a	This command was introduced.				

**Usage Guidelines** While configuring REP configurable timers, we recommend that you configure the REP LSL number of retries first and then configure the REP LSL age-out timer value.

### Examples

The following example shows how to configure a REP LSL age-out timer value:

```
Device> enable
Device# configure terminal
Device(config)# interface TenGigabitEthernet 4/1
Device(config-if)# rep segment 1 edge primary
Device(config-if)# rep lsl-age-timer 2000
```

### Related Commands

Command	Description
<b>interface interface-type interface-name</b>	Specifies a physical interface or port channel to receive STCNs.
<b>rep segment</b>	Enables REP on an interface and assigns a segment ID.

## rep lsl-retries

To configure the REP link status layer (LSL) number of retries, use the **rep lsl-retries** command in interface configuration mode. To restore the default number of retries, use the **no** form of this command.

```
rep lsl-retries number-of-retries
no rep lsl-retries number-of-retries
```

### Syntax Description

*number-of-retries* Number of LSL retries. The range of retries is from 3 to 10.

### Command Default

The default number of LSL retries is 5.

### Command Modes

Interface configuration

### Command History

Release	Modification
Cisco IOS XE Everest 16.5.1a	This command was introduced

### Usage Guidelines

The **rep lsl-retries** command is used to configure the number of retries before the REP link is disabled. While configuring REP configurable timers, we recommend that you configure the REP LSL number of retries first and then configure the REP LSL age-out timer value.

The following example shows how to configure REP LSL retries.

```
Device> enable
Device# configure terminal
Device(config)# interface TenGigabitEthernet 4/1
Device(config-if)# rep segment 2 edge primary
```

## rep preempt delay

To configure a waiting period after a segment port failure and recovery before Resilient Ethernet Protocol (REP) VLAN load balancing is triggered, use the **rep preempt delay** command in interface configuration mode. To remove the configured delay, use the **no** form of this command.

**rep preempt delay** *seconds*

**no rep preempt delay**

<b>Syntax Description</b>	<i>seconds</i> Number of seconds to delay REP preemption. The range is from 15 to 300 seconds. The default is manual preemption without delay.
---------------------------	--

<b>Command Default</b>	REP preemption delay is not set. The default is manual preemption without delay.
------------------------	--

<b>Command Modes</b>	Interface configuration
----------------------	-------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Everest 16.5.1a	This command was introduced.

<b>Usage Guidelines</b>	<p>Enter this command on the REP primary edge port.</p> <p>Enter this command and configure a preempt time delay for VLAN load balancing to be automatically triggered after a link failure and recovery.</p> <p>If VLAN load balancing is configured after a segment port failure and recovery, the REP primary edge port starts a delay timer before VLAN load balancing occurs. Note that the timer restarts after each link failure. When the timer expires, the REP primary edge port alerts the alternate port to perform VLAN load balancing (configured by using the <b>rep block port</b> command in interface configuration mode) and prepares the segment for the new topology. The configured VLAN list is blocked at the alternate port, and all other VLANs are blocked at the primary edge port.</p>
-------------------------	---

You can verify your settings by entering the **show interfaces rep** command.

### Examples

The following example shows how to configure a REP preemption time delay of 100 seconds on the primary edge port:

```
Device> enable
Device# configure terminal
Device(config)# interface TenGigabitEthernet 4/1
Device(config-if)# rep preempt delay 100
```

### Related Commands

Command	Description
<b>rep block port</b>	Configures VLAN load balancing.
<b>show interfaces rep detail</b>	Displays detailed REP configuration and status for all the interfaces or the specified interface, including the administrative VLAN.

# rep preempt segment

To manually start Resilient Ethernet Protocol (REP) VLAN load balancing on a segment, use the **rep preempt segment** command in privileged EXEC mode.

```
rep preempt segment segment-id
```

## Syntax Description

*segment-id* ID of the REP segment. The range is from 1 to 1024.

## Command Default

Manual preemption is the default behavior.

## Command Modes

Privileged EXEC

## Command History

Release	Modification
Cisco IOS XE Everest 16.5.1a	This command was introduced.

## Usage Guidelines

Enter this command on the segment, which has the primary edge port on the device.

Ensure that all the other segment configurations are completed before setting preemption for VLAN load balancing. When you enter the **rep preempt segment** *segment-id* command, a confirmation message appears before the command is executed because preemption for VLAN load balancing can disrupt the network.

If you do not enter the **rep preempt delay** *seconds* command in interface configuration mode on the primary edge port to configure a preemption time delay, the default configuration is to manually trigger VLAN load balancing on the segment.

Enter the **show rep topology** command in privileged EXEC mode to see which port in the segment is the primary edge port.

If you do not configure VLAN load balancing, entering the **rep preempt segment** *segment-id* command results in the default behavior, that is, the primary edge port blocks all the VLANs.

You can configure VLAN load balancing by entering the **rep block port** command in interface configuration mode on the REP primary edge port before you manually start preemption.

## Examples

The following example shows how to manually trigger REP preemption on segment 100:

```
Device> enable
Device# rep preempt segment 100
```

## Related Commands

Command	Description
<b>rep block port</b>	Configures VLAN load balancing.
<b>rep preempt delay</b>	Configures a waiting period after a segment port failure and recovery before REP VLAN load balancing is triggered.
<b>show rep topology</b>	Displays REP topology information for a segment or for all the segments.

## rep segment

To enable Resilient Ethernet Protocol (REP) on an interface and to assign a segment ID to the interface, use the **rep segment** command in interface configuration mode. To disable REP on the interface, use the **no** form of this command.

**rep segment** *segment-id* [**edge** [**no-neighbor**] [**primary**] ] [**preferred**]  
**no rep segment**

Syntax Description	
<i>segment-id</i>	Segment for which REP is enabled. Assign a segment ID to the interface. The range is from 1 to 1024.
<b>edge</b>	(Optional) Configures the port as an edge port. Each segment has only two edge ports.
<b>no-neighbor</b>	(Optional) Specifies the segment edge as one with no external REP neighbor.
<b>primary</b>	(Optional) Specifies that the port is the primary edge port where you can configure VLAN load balancing. A segment has only one primary edge port.
<b>preferred</b>	(Optional) Specifies that the port is the preferred alternate port or the preferred port for VLAN load balancing.
<b>Note</b>	Configuring a port as a preferred port does not guarantee that it becomes the alternate port; it merely gives it a slight edge among equal contenders. The alternate port is usually a previously failed port.

**Command Default** REP is disabled on the interface.

**Command Modes** Interface configuration

Command History	Release	Modification
	Cisco IOS XE Everest 16.5.1a	This command was introduced.

**Usage Guidelines** REP ports must be a Layer 2 IEEE 802.1Q port or a 802.1AD port. You must configure two edge ports on each REP segment, a primary edge port and a secondary edge port.

If REP is enabled on two ports on a device, both the ports must be either regular segment ports or edge ports. REP ports follow these rules:

- If only one port on a device is configured in a segment, that port should be an edge port.
- If two ports on a device belong to the same segment, both the ports must be regular segment ports.
- If two ports on a device belong to the same segment, and one is configured as an edge port and one as a regular segment port (a misconfiguration), the edge port is treated as a regular segment port.



**Caution** REP interfaces come up in a blocked state and remain in a blocked state until notified that it is safe to unblock. Be aware of this to avoid sudden connection losses.



When REP is enabled on an interface, the default is for that port to be a regular segment port.

## Examples

The following example shows how to enable REP on a regular (nonedge) segment port:

```
Device> enable
Device# configure terminal
Device(config)# interface TenGigabitEthernet 4/1
Device(config-if)# rep segment 100
```

The following example shows how to enable REP on a port and identify the port as the REP primary edge port:

```
Device> enable
Device# configure terminal
Device(config)# interface TenGigabitEthernet 4/1
Device(config-if)# rep segment 100 edge primary
```

The following example shows how to enable REP on a port and identify the port as the REP secondary edge port:

```
Device> enable
Device# configure terminal
Device(config)# interface TenGigabitEthernet 4/1
Device(config-if)# rep segment 100 edge
```

The following example shows how to enable REP as an edge no-neighbor port:

```
Device> enable
Device# configure terminal
Device(config)# interface TenGigabitEthernet 4/1
Device(config-if)# rep segment 1 edge no-neighbor primary
```

## rep stcn

To configure a Resilient Ethernet Protocol (REP) edge port to send segment topology change notifications (STCNs) to another interface or to other segments, use the **rep stcn** command in interface configuration mode. To disable the task of sending STCNs to the interface or to the segment, use the **no** form of this command.

```
rep stcn {interface interface-id | segment segment-id-list}
no rep stcn {interface | segment}
```

<b>Syntax Description</b>	<b>interface</b> <i>interface-id</i> Specifies a physical interface or port channel to receive STCNs.				
	<b>segment</b> <i>segment-id-list</i> Specifies one REP segment or a list of REP segments to receive STCNs. The segment range is from 1 to 1024. You can also configure a sequence of segments, for example, 3 to 5, 77, 100.				
<b>Command Default</b>	Transmission of STCNs to other interfaces or segments is disabled.				
<b>Command Modes</b>	Interface configuration				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE Everest 16.5.1a</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE Everest 16.5.1a	This command was introduced.
Release	Modification				
Cisco IOS XE Everest 16.5.1a	This command was introduced.				

**Usage Guidelines** You can verify your settings by entering the **show interfaces rep detail** command in privileged EXEC mode.

### Examples

The following example shows how to configure a REP edge port to send STCNs to segments 25 to 50:

```
Device> enable
Device# configure terminal
Device(config)# interface TenGigabitEthernet 4/1
Device(config-if)# rep stcn segment 25-50
```

# revision

To set the revision number for the Multiple Spanning Tree (802.1s) (MST) configuration, use the **revision** command in MST configuration submode. To return to the default settings, use the **no** form of this command.

**revision** *version*  
**no revision**

## Syntax Description

version	Revision number for the configuration; valid values are from 0 to 65535.
---------	--

## Command Default

*version* is **0**

## Command Modes

MST configuration (config-mst)

## Command History

Release	Modification
Cisco IOS XE Everest 16.5.1a	This command was introduced.

## Usage Guidelines

Devices that have the same configuration but different revision numbers are considered to be part of two different regions.



**Note** Be careful when using the **revision** command to set the revision number of the MST configuration because a mistake can put the switch in a different region.

## Examples

This example shows how to set the revision number of the MST configuration:

```
Device(config)# spanning-tree mst configuration
Device(config-mst)# revision 5
Device(config-mst)#
```

## Related Commands

Command	Description
<b>instance</b>	Maps a VLAN or a set of VLANs to an MST instance.
<b>name</b> (MST configuration submode)	Sets the name of an MST region.
<b>show spanning-tree</b>	Displays information about the spanning-tree state.
<b>spanning-tree mst configuration</b>	Enters MST-configuration submode.

# show avb domain

To display the AVB domain information, use the **show avb domain** command.

## show avb domain

Command History	Release	Modification
	Cisco IOS XE Fuji 16.8.1a	This command was introduced.

**Command Modes** Global configuration mode (#)

### Example:

The following is sample output from the **show avb domain** command:

```
Device# show avb domain
```

```
AVB Class-A
  Priority Code Point    : 3
  VLAN                  : 2
  Core ports            : 1
  Boundary ports        : 67
```

```
AVB Class-B
  Priority Code Point    : 2
  VLAN                  : 2
  Core ports            : 1
  Boundary ports        : 67
```

Interface	State	Delay	PCP	VID	Information
Te1/0/1	down	N/A			Oper state not up
Te1/0/2	down	N/A			Oper state not up
Te1/0/3	down	N/A			Oper state not up
Te1/0/4	down	N/A			Oper state not up
Te1/0/5	up	N/A			Port is not asCapable
Te1/0/6	down	N/A			Oper state not up
Te1/0/7	down	N/A			Oper state not up
Te1/0/8	down	N/A			Oper state not up
Te1/0/9	down	N/A			Oper state not up
Te1/0/10	down	N/A			Oper state not up
Te1/0/11	down	N/A			Oper state not up
Te1/0/12	down	N/A			Oper state not up
Te1/0/13	down	N/A			Oper state not up
Te1/0/14	down	N/A			Oper state not up
Te1/0/15	down	N/A			Oper state not up
Te1/0/16	down	N/A			Oper state not up
Te1/0/17	down	N/A			Oper state not up
Te1/0/18	down	N/A			Oper state not up
Te1/0/19	up	N/A			Port is not asCapable
Te1/0/20	down	N/A			Oper state not up
Te1/0/21	down	N/A			Oper state not up
Te1/0/22	down	N/A			Oper state not up
Te1/0/23	up	N/A			Port is not asCapable
Te1/0/24	down	N/A			Oper state not up
Te1/0/25	down	N/A			Oper state not up
Te1/0/26	down	N/A			Oper state not up

```

Tel/0/27      down      N/A          Oper state not up
Tel/0/28      down      N/A          Oper state not up
Tel/0/29      up        N/A          Port is not asCapable
Tel/0/30      down      N/A          Oper state not up
Tel/0/31      down      N/A          Oper state not up
Tel/0/32      down      N/A          Oper state not up
Tel/0/33      down      N/A          Oper state not up
Tel/0/34      down      N/A          Oper state not up
Tel/0/35      up        N/A          Port is not asCapable
Tel/0/36      down      N/A          Oper state not up
Tel/0/37      down      N/A          Oper state not up
Tel/0/38      down      N/A          Oper state not up
Tel/0/39      up        507ns
Class- A      core      3          2
Class- B      core      2          2
Tel/0/40      down      N/A          Oper state not up
Tel/0/41      down      N/A          Oper state not up
Tel/0/42      down      N/A          Oper state not up
Tel/0/43      down      N/A          Oper state not up
Tel/0/44      down      N/A          Oper state not up
Tel/0/45      down      N/A          Oper state not up
Tel/0/46      down      N/A          Oper state not up
Tel/0/47      down      N/A          Oper state not up
Tel/0/48      down      N/A          Oper state not up
Tel/1/1       down      N/A          Oper state not up
Tel/1/2       down      N/A          Oper state not up
Tel/1/3       down      N/A          Oper state not up
Tel/1/4       down      N/A          Oper state not up
Tel/1/5       down      N/A          Oper state not up
Tel/1/6       down      N/A          Oper state not up
Tel/1/7       down      N/A          Oper state not up
Tel/1/8       down      N/A          Oper state not up
Tel/1/9       down      N/A          Oper state not up
Tel/1/10      down      N/A          Oper state not up
Tel/1/11      down      N/A          Oper state not up
Tel/1/12      down      N/A          Oper state not up
Tel/1/13      down      N/A          Oper state not up
Tel/1/14      down      N/A          Oper state not up
Tel/1/15      down      N/A          Oper state not up
Tel/1/16      down      N/A          Oper state not up
Fol/1/1       down      N/A          Oper state not up
Fol/1/2       down      N/A          Oper state not up
Fol/1/3       down      N/A          Oper state not up
Fol/1/4       down      N/A          Oper state not up
.
.
.

```

# show avb streams

To display the AVB stream information, use the **show avb streams** command.

## show avb streams

Command History	Release	Modification
	Cisco IOS XE Fuji 16.8.1a	This command was introduced.

**Command Modes** Global configuration mode (#)

### Example:

The following is sample output from the **show avb streams** command:

Device# **show avb streams**

```
Stream ID:          0011.0100.0001:1    Incoming Interface:  Tel/1/1
Destination   : 91E0.F000.FE00
Class         : A
Rank          : 1
Bandwidth     : 6400 Kbit/s
```

Outgoing Interfaces:

```
-----
Interface          State      Time of Last Update      Information
-----
Tel/1/1            Ready     Tue Apr 26 01:25:40.634
```

```
Stream ID:          0011.0100.0002:2    Incoming Interface:  Tel/1/1
Destination   : 91E0.F000.FE01
Class         : A
Rank          : 1
Bandwidth     : 6400 Kbit/s
```

Outgoing Interfaces:

```
-----
Interface          State      Time of Last Update      Information
-----
Tel/1/1            Ready     Tue Apr 26 01:25:40.634
```

```
.
.
.
```

# show dot1q-tunnel

To display information about IEEE 802.1Q tunnel ports, use the **show dot1q-tunnel** in EXEC mode.

**show dot1q-tunnel** [**interface** *interface-id*]

<b>Syntax Description</b>	<b>interface</b> <i>interface-id</i> (Optional) Specifies the interface for which to display IEEE 802.1Q tunneling information. Valid interfaces include physical ports and port channels.
---------------------------	--

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	User EXEC Privileged EXEC
----------------------	------------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

## Examples

The following are examples of output from the **show dot1q-tunnel** command:

```
Device# show dot1q-tunnel
```

```
dot1q-tunnel mode LAN Port(s)
```

```
-----
Gi1/0/1
Gi1/0/2
Gi1/0/3
Gi1/0/6
Po2
```

```
Device# show dot1q-tunnel interface gigabitethernet1/0/1
```

```
dot1q-tunnel mode LAN Port(s)
```

```
-----
Gi1/0/1
```

# show etherchannel

To display EtherChannel information for a channel, use the **show etherchannel** command in user EXEC mode.

```
show etherchannel [{channel-group-number | {detail | port | port-channel | protocol | summary }}]
| [{detail | load-balance | port | port-channel | protocol | summary}]
```

Syntax Description	
<i>channel-group-number</i>	(Optional) Channel group number. The range is 1 to 128.
<b>detail</b>	(Optional) Displays detailed EtherChannel information.
<b>load-balance</b>	(Optional) Displays the load-balance or frame-distribution scheme among ports in the port channel.
<b>port</b>	(Optional) Displays EtherChannel port information.
<b>port-channel</b>	(Optional) Displays port-channel information.
<b>protocol</b>	(Optional) Displays the protocol that is being used in the channel.
<b>summary</b>	(Optional) Displays a one-line summary per channel group.

**Command Modes** User EXEC

Command History	Release	Modification
	Cisco IOS XE Everest 16.5.1a	This command was introduced.

**Usage Guidelines** If you do not specify a channel group number, all channel groups are displayed.

In the output, the passive port list field is displayed only for Layer 3 port channels. This field means that the physical port, which is still not up, is configured to be in the channel group (and indirectly is in the only port channel in the channel group).

This is an example of output from the **show etherchannel** *channel-group-number* **detail** command:

```
Device> show etherchannel 1 detail
Group state = L2
Ports: 2   Maxports = 16
Port-channels: 1 Max Port-channels = 16
Protocol:   LACP
           Ports in the group:
           -----
Port: Gi1/0/1
-----
Port state      = Up Mstr In-Bndl
Channel group = 1      Mode = Active      Gchange = -
Port-channel   =      PolGC = -          Pseudo port-channel = Pol
Port index     =      OLoad = 0x00       Protocol = LACP
```



Flags: S - Device is sending Slow LACPDUs    F - Device is sending fast LACPDU  
 A - Device is in active mode.                P - Device is in passive mode.

Local information:

Port	Flags	State	LACP port Priority	Admin Key	Oper Key	Port Number	Port State
Gi1/0/1	SA	bndl	32768	0x1	0x1	0x101	0x3D
Gi1/0/2	A	bndl	32768	0x0	0x1	0x0	0x3D

Age of the port in the current state: 01d:20h:06m:04s

Port-channels in the group:

-----

Port-channel: Po1 (Primary Aggregator)

Age of the Port-channel = 01d:20h:20m:26s  
 Logical slot/port = 10/1                    Number of ports = 2  
 HotStandBy port = null  
 Port state = Port-channel Ag-Inuse  
 Protocol = LACP

Ports in the Port-channel:

Index	Load	Port	EC state	No of bits
0	00	Gi1/0/1	Active	0
0	00	Gi1/0/2	Active	0

Time since last port bundled: 01d:20h:24m:44s Gi1/0/2

This is an example of output from the **show etherchannel channel-group-number summary** command:

```
Device> show etherchannel 1 summary
Flags: D - down P - in port-channel
       I - stand-alone s - suspended
       H - Hot-standby (LACP only)
       R - Layer3 S - Layer2
       u - unsuitable for bundling
       U - in use f - failed to allocate aggregator
       d - default port
```

Number of channel-groups in use: 1  
 Number of aggregators: 1

Group	Port-channel	Protocol	Ports
1	Po1 (SU)	LACP	Gi1/0/1 (P) Gi1/0/2 (P)

This is an example of output from the **show etherchannel channel-group-number port-channel** command:

```
Device> show etherchannel 1 port-channel
Port-channels in the group:
-----
Port-channel: Po1 (Primary Aggregator)
-----
Age of the Port-channel = 01d:20h:24m:50s
Logical slot/port = 10/1 Number of ports = 2
Logical slot/port = 10/1 Number of ports = 2
Port state = Port-channel Ag-Inuse
Protocol = LACP
```

Ports in the Port-channel:

Index	Load	Port	EC state	No of bits
0	00	Gi1/0/1	Active	0
0	00	Gi1/0/2	Active	0

Time since last port bundled: 01d:20h:24m:44s Gi1/0/2

This is an example of output from **show etherchannel protocol** command:

```
Device# show etherchannel protocol
```

```
Channel-group listing:
```

```
-----
```

```
Group: 1
```

```
-----
```

```
Protocol: LACP
```

```
Group: 2
```

```
-----
```

```
Protocol: PAgP
```

# show interfaces rep detail

To display detailed Resilient Ethernet Protocol (REP) configuration and status for all interfaces or a specified interface, including the administrative VLAN, use the **show interfaces rep detail** command in privileged EXEC mode.

**show interfaces** [*interface-id*] **rep detail**

## Syntax Description

*interface-id* (Optional) Physical interface used to display the port ID.

## Command Modes

Privileged EXEC

## Command History

Release	Modification
Cisco IOS XE Everest 16.5.1a	This command was introduced.

## Usage Guidelines

Enter this command on a segment edge port to send STCNs to one or more segments or to an interface. You can verify your settings by entering the **show interfaces rep detail** command in privileged EXEC mode.

## Examples

The following example shows how to display the REP configuration and status for a specified interface;

```
Device> enable
Device# show interfaces TenGigabitEthernet4/1 rep detail
```

```
TenGigabitEthernet4/1 REP enabled
Segment-id: 3 (Primary Edge)
PortID: 03010015FA66FF80
Preferred flag: No
Operational Link Status: TWO_WAY
Current Key: 02040015FA66FF804050
Port Role: Open
Blocked VLAN: <empty>
Admin-vlan: 1
Preempt Delay Timer: disabled
Configured Load-balancing Block Port: none
Configured Load-balancing Block VLAN: none
STCN Propagate to: none
LSL PDU rx: 999, tx: 652
HFL PDU rx: 0, tx: 0
BPA TLV rx: 500, tx: 4
BPA (STCN, LSL) TLV rx: 0, tx: 0
BPA (STCN, HFL) TLV rx: 0, tx: 0
EPA-ELECTION TLV rx: 6, tx: 5
EPA-COMMAND TLV rx: 0, tx: 0
EPA-INFO TLV rx: 135, tx: 136
```

## Related Commands

Command	Description
<b>rep admin vlan</b>	Configures a REP administrative VLAN for the REP to transmit HFL messages.

# show l2protocol-tunnel

To display information about Layer 2 protocol tunnel ports, use the **show l2protocol-tunnel** in EXEC mode.

**show l2protocol-tunnel** [**interface** *interface-id*] **summary**

Syntax Description	
<b>interface</b> <i>interface-id</i>	(Optional) Specifies the interface for which protocol tunneling information appears. Valid interfaces are physical ports and port channels.  The port-channel range is 1 to 128.
<b>summary</b>	(Optional) Displays only Layer 2 protocol summary information.

**Command Default** None

**Command Modes** User EXEC  
Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

**Usage Guidelines** After enabling Layer 2 protocol tunneling on an access or IEEE 802.1Q tunnel port by using the **l2protocol-tunnel** interface configuration command, you can configure some or all of these parameters:

- Protocol type to be tunneled
- Shutdown threshold
- Drop threshold

If you enter the **show l2protocol-tunnel interface** command, only information about the active ports on which all the parameters are configured appears.

If you enter the **show l2protocol-tunnel summary** command, only information about the active ports on which some or all of the parameters are configured appears.

## Examples

This is an example of output from the **show l2protocol-tunnel** command:

```
Device> show l2protocol-tunnel

COS for Encapsulated Packets: 5
Drop Threshold for Encapsulated Packets: 0

Port          Protocol Shutdown Drop      Encapsulation Decapsulation Drop
              Threshold Threshold Counter      Counter      Counter
-----
Gi3/0/3      ---          ----   ----   ----          ----          ----
              ---          ----   ----   ----          ----          ----
              pagp          ----   ----           0          242500
              lacp          ----   ----   24268        242640
              udld          ----   ----           0          897960
```

Gi3/0/4	---	----	----	----	----	----
	---	----	----	----	----	----
	pagp	1000	----	24249	242700	
	lacp	----	----	24256	242660	
	udld	----	----	0	897960	
Gi6/0/1	cdp	----	----	134482	1344820	
	---	----	----	----	----	----
	---	----	----	----	----	----
	pagp	1000	----	0	242500	
	lacp	500	----	0	485320	
	udld	300	----	44899	448980	
Gi6/0/2	cdp	----	----	134482	1344820	
	---	----	----	----	----	----
	---	----	----	----	----	----
	pagp	----	1000	0	242700	
	lacp	----	----	0	485220	
	udld	300	----	44899	448980	

This is an example of output from the **show l2protocol-tunnel summary** command:

Device> **show l2protocol-tunnel summary**

COS for Encapsulated Packets: 5

Drop Threshold for Encapsulated Packets: 0

Port	Protocol	Shutdown Threshold (cdp/stp/vtp) (pagp/lacp/udld)	Drop Threshold (cdp/stp/vtp) (pagp/lacp/udld)	Status
-----	-----	-----	-----	-----
Gi3/0/2	pagp lacp udld	----/----/----	----/----/----	up
Gi4/0/3	pagp lacp udld	1000/ 500/----	----/----/----	up
Gi9/0/1	pagp ----	----/----/----	1000/----/----	down
Gi9/0/2	pagp ----	----/----/----	1000/----/----	down

# show lacp

To display Link Aggregation Control Protocol (LACP) channel-group information, use the **show lacp** command in user EXEC mode.

**show lacp** [*channel-group-number*] {**counters** | **internal** | **neighbor** | **sys-id**}

## Syntax Description

<i>channel-group-number</i>	(Optional) Channel group number. The range is 1 to 128.
<b>counters</b>	Displays traffic information.
<b>internal</b>	Displays internal information.
<b>neighbor</b>	Displays neighbor information.
<b>sys-id</b>	Displays the system identifier that is being used by LACP. The system identifier consists of the LACP system priority and the device MAC address.

## Command Modes

User EXEC

## Command History

Release	Modification
Cisco IOS XE Everest 16.5.1a	This command was introduced.

## Usage Guidelines

You can enter any **show lacp** command to display the active channel-group information. To display specific channel information, enter the **show lacp** command with a channel-group number.

If you do not specify a channel group, information for all channel groups appears.

You can enter the *channel-group-number* to specify a channel group for all keywords except **sys-id**.

This is an example of output from the **show lacp counters** user EXEC command. The table that follows describes the fields in the display.

```
Device> show lacp counters
          LACPDU      Marker      Marker Response      LACPDU
Port      Sent  Recv      Sent  Recv      Sent  Recv      Pkts  Err
-----
Channel group:1
Gi2/0/1      19   10         0    0         0    0         0
Gi2/0/2      14    6         0    0         0    0         0
```

**Table 1: show lacp counters Field Descriptions**

Field	Description
LACPDU Sent and Recv	The number of LACP packets sent and received by a port.
Marker Sent and Recv	The number of LACP marker packets sent and received by a port.

Field	Description
Marker Response Sent and Recv	The number of LACP marker response packets sent and received by a port.
LACPDUs Pkts and Err	The number of unknown and illegal packets received by LACP for a port.

This is an example of output from the **show lacp internal** command:

```
Device> show lacp 1 internal
Flags: S - Device is requesting Slow LACPDUs
       F - Device is requesting Fast LACPDUs
       A - Device is in Active mode           P - Device is in Passive mode

Channel group 1
Port      Flags  State  LACP port  Admin  Oper  Port  Port
Gi2/0/1   SA     bndl   32768      0x3    0x3   0x4   0x3D
Gi2/0/2   SA     bndl   32768      0x3    0x3   0x5   0x3D
```

The following table describes the fields in the display:

**Table 2: show lacp internal Field Descriptions**

Field	Description
State	<p>State of the specific port. These are the allowed values:</p> <ul style="list-style-type: none"> <li>• <b>--</b>—Port is in an unknown state.</li> <li>• <b>bndl</b>—Port is attached to an aggregator and bundled with other ports.</li> <li>• <b>susp</b>—Port is in a suspended state; it is not attached to any aggregator.</li> <li>• <b>hot-sby</b>—Port is in a hot-standby state.</li> <li>• <b>indiv</b>—Port is incapable of bundling with any other port.</li> <li>• <b>indep</b>—Port is in an independent state (not bundled but able to handle data traffic. In this case, LACP is not running on the partner port).</li> <li>• <b>down</b>—Port is down.</li> </ul>
LACP Port Priority	Port priority setting. LACP uses the port priority to put ports in standby mode when there is a hardware limitation that prevents all compatible ports from aggregating.

Field	Description
Admin Key	Administrative key assigned to this port. LACP automatically generates an administrative key value as a hexadecimal number. The administrative key defines the ability of a port to aggregate with other ports. A port's ability to aggregate with other ports is determined by the port physical characteristics (for example, data rate and duplex capability) and configuration restrictions that you establish.
Oper Key	Runtime operational key that is being used by this port. LACP automatically generates this value as a hexadecimal number.
Port Number	Port number.
Port State	<p>State variables for the port, encoded as individual bits within a single octet with these meanings:</p> <ul style="list-style-type: none"> <li>• bit0: LACP_Activity</li> <li>• bit1: LACP_Timeout</li> <li>• bit2: Aggregation</li> <li>• bit3: Synchronization</li> <li>• bit4: Collecting</li> <li>• bit5: Distributing</li> <li>• bit6: Defaulted</li> <li>• bit7: Expired</li> </ul> <p><b>Note</b> In the list above, bit7 is the MSB and bit0 is the LSB.</p>

This is an example of output from the **show lacp neighbor** command:

```
Device> show lacp neighbor
Flags: S - Device is sending Slow LACPDUs  F - Device is sending Fast LACPDUs
      A - Device is in Active mode          P - Device is in Passive mode

Channel group 3 neighbors

Partner's information:

Port      Partner          Partner          Partner
Gi2/0/1  System ID       Port Number     Age           Flags
        32768,0007.eb49.5e80  0xC             19s          SP

        LACP Partner      Partner          Partner
        Port Priority     Oper Key         Port State
        32768             0x3              0x3C

Partner's information:
```



Port	Partner System ID	Partner Port Number	Age	Partner Flags
Gi2/0/2	32768,0007.eb49.5e80	0xD	15s	SP
	LACP Partner Port Priority	Partner Oper Key	Partner Port State	
	32768	0x3	0x3C	

This is an example of output from the **show lacp sys-id** command:

```
Device> show lacp sys-id
32765,0002.4b29.3a00
```

The system identification is made up of the system priority and the system MAC address. The first two bytes are the system priority, and the last six bytes are the globally administered individual MAC address associated to the system.

# show loopdetect

To display the details of all the interfaces where loop-detection guard is enabled, use the **show loopdetect** command in user EXEC or privileged EXEC mode.

**Syntax Description** This command has no arguments or keywords.

**Command Default** None

**Command Modes** User EXEC (>)  
Privileged EXEC(#)

Command History	Release	Modification
	Cisco IOS XE Amsterdam 17.2.1	This command was introduced.

## Examples

The following is a sample output of the **show loopdetect** command:

```
Device# show loopdetect
Interface Interval Elapsed-Time Port-to-Errdisbale ACTION
-----
Twe1/0/1      5          3      errdisable Source Port  SYSLOG
Twe1/0/20     5          0      errdisable Source Port  ERRDISABLE
Twe2/0/3      5          2      errdisable Dest Port   ERRDISABLE
Loopdetect is ENABLED
```

The table below describes the significant fields shown in the display.

**Table 3: show loopdetect Field Descriptions**

Field	Description
Interface	Displays the interfaces that have loop-detection guard enabled.
Interval	Displays the time interval set to send the loop-detect frames in seconds.
Elapsed-Time	Displays the time elapsed within the set time interval to send loop-detect frames.
Port-to-Errdisbale	Displays the port that is configured to be error-disabled.
Action	Displays the action the system will take when it detects a network loop.

# show msrp port bandwidth

To display Multiple Stream Reservation Protocol (MSRP) port bandwidth information, use the **show msrp port bandwidth** command.

**show msrp port bandwidth**

Command History	Release	Modification
	Cisco IOS XE Fuji 16.8.1a	This command was introduced.

**Command Modes** Global configuration mode (#)

## Example:

The following is sample output from the **show msrp port bandwidth** command:

Device# **show msrp port bandwidth**

Ethernet Interface	Capacity (Kbit/s)	Assigned		Available		Reserved	
		A	B	A	B	A	B
Tel/0/1	10000000	75	0	75	75	0	0
Tel/0/2	10000000	75	0	75	75	0	0
Tel/0/3	1000000	75	0	75	75	0	0
Tel/0/4	10000000	75	0	75	75	0	0
Tel/0/5	10000000	75	0	75	75	0	0
Tel/0/6	10000000	75	0	75	75	0	0
Tel/0/8	10000000	75	0	75	75	0	0
Tel/0/9	10000000	75	0	75	75	0	0
Tel/0/10	10000000	75	0	75	75	0	0
Tel/0/11	10000000	75	0	75	75	0	0
Tel/0/12	10000000	75	0	75	75	0	0
Tel/0/13	1000000	75	0	75	75	0	0
Tel/0/14	10000000	75	0	75	75	0	0
Tel/0/15	10000000	75	0	75	75	0	0
Tel/0/16	10000000	75	0	75	75	0	0
Tel/0/17	10000000	75	0	75	75	0	0
Tel/0/18	10000000	75	0	75	75	0	0
Tel/0/19	1000000	75	0	75	75	0	0
Tel/0/20	10000000	75	0	75	75	0	0
Tel/0/21	10000000	75	0	75	75	0	0
Tel/0/22	10000000	75	0	75	75	0	0
Tel/0/23	10000000	75	0	75	75	0	0
Tel/0/24	10000000	75	0	75	75	0	0
Gi1/1/1	1000000	75	0	75	75	0	0
Gi1/1/2	1000000	75	0	75	75	0	0
Gi1/1/3	1000000	75	0	75	75	0	0
Gi1/1/4	1000000	75	0	75	75	0	0
Tel/1/1	10000000	75	0	75	75	0	0
Tel/1/2	10000000	75	0	75	75	0	0
Tel/1/3	10000000	75	0	75	75	0	0
Tel/1/4	10000000	75	0	75	75	0	0
Tel/1/5	10000000	75	0	75	75	0	0
Tel/1/6	10000000	75	0	75	75	0	0
Tel/1/7	10000000	75	0	75	75	0	0
Tel/1/8	10000000	75	0	75	75	0	0
Fo1/1/1	40000000	75	0	75	75	0	0

```
show msp port bandwidth
```

```
Fo1/1/2    40000000    75 | 0    75 | 75    0 | 0
```

# show msrp streams

To display information about the Multiple Stream Reservation Protocol (MSRP) streams, use the **show msrp streams** command.

**show msrp streams** [ **detailed** | **brief** ]

Syntax Description	Parameter	Description
	<b>detailed</b>	Displays detailed MSRP stream information.
	<b>brief</b>	Displays MSRP stream information in brief.
Command History	Release	Modification
	Cisco IOS XE Fuji 16.8.1a	This command was introduced.
Command Modes	Global configuration mode (#)	

## Example:

The following is sample output from the **show msrp streams** command:

```
Device# show msrp streams

-----
Stream ID Talker Listener
Advertise Fail Ready ReadyFail AskFail
R | D R | D R | D R | D R | D
-----
yy:yy:yy:yy:yy:yy:0001 1 | 2 0 | 0 1 | 0 0 | 1 1 | 0
zz:zz:zz:zz:zz:zz:0002 1 | 0 0 | 1 1 | 0 0 | 0 0 | 1
```

The following is sample output from the **show msrp streams detailed** command:

```
Device# show msrp streams detailed

Stream ID:          0011.0100.0001:1
  Stream Age: 01:57:46 (since Mon Apr 25 23:41:11.413)
  Create Time: Mon Apr 25 23:41:11.413
  Destination Address: 91E0.F000.FE00
  VLAN Identifier: 1
  Data Frame Priority: 3 (Class A)
  MaxFrameSize: 100
  MaxIntervalFrames: 1 frames/125us
  Stream Bandwidth: 6400 Kbit/s
  Rank: 1
  Received Accumulated Latency: 20
  Stream Attributes Table:
-----
Interface          Attr State    Direction    Type
-----
  Gi1/0/1          Register    Talker       Advertise
  Attribute Age: 01:57:46 (since Mon Apr 25 23:41:11.413)
  MRP Applicant: Very Anxious Observer, send None
  MRP Registrar: In
  Accumulated Latency: 20
-----
```

## show msrp streams

```

Te1/1/1          Declare          Talker          Advertise
Attribute Age: 00:19:52 (since Tue Apr 26 01:19:05.525)
MRP Applicant: Quiet Active, send None
MRP Registrar: In
Accumulated Latency: 20
-----
Te1/1/1          Register          Listener        Ready
Attribute Age: 00:13:17 (since Tue Apr 26 01:25:40.635)
MRP Applicant: Very Anxious Observer, send None
MRP Registrar: In
-----
Gi1/0/1          Declare          Listener        Ready
Attribute Age: 00:13:17 (since Tue Apr 26 01:25:40.649)
MRP Applicant: Quiet Active, send None
MRP Registrar: In

```

The following is sample output from the **show msrp streams brief** command:

Device# **show msrp streams brief**

Legend: R = Registered, D = Declared.

```

-----
Stream ID          Destination          Bandwidth    Talkers    Listeners    Fail
                  Address              (Kbit/s)     R | D      R | D
-----
0011.0100.0001:1   91E0.F000.FE00      6400         1 | 1      1 | 1      No
0011.0100.0002:2   91E0.F000.FE01      6400         1 | 1      1 | 1      No
0011.0100.0003:3   91E0.F000.FE02      6400         1 | 1      1 | 1      No
0011.0100.0004:4   91E0.F000.FE03      6400         1 | 1      1 | 1      No
0011.0100.0005:5   91E0.F000.FE04      6400         1 | 1      1 | 1      No
0011.0100.0006:6   91E0.F000.FE05      6400         1 | 1      1 | 1      No
0011.0100.0007:7   91E0.F000.FE06      6400         1 | 1      1 | 1      No
0011.0100.0008:8   91E0.F000.FE07      6400         1 | 1      1 | 1      No
0011.0100.0009:9   91E0.F000.FE08      6400         1 | 1      1 | 1      No
0011.0100.000A:10  91E0.F000.FE09      6400         1 | 1      1 | 1      No

```

# show pagp

To display Port Aggregation Protocol (PAgP) channel-group information, use the **show pagp** command in EXEC mode.

```
show pagp [channel-group-number] {counters | dual-active | internal | neighbor}
```

## Syntax Description

*channel-group-number* (Optional) Channel group number.  
The range is 1 to 128.

**counters** Displays traffic information.

**dual-active** Displays the dual-active status.

**internal** Displays internal information.

**neighbor** Displays neighbor information.

## Command Modes

User EXEC

Privileged EXEC

## Command History

Release	Modification
Cisco IOS XE Everest 16.5.1a	This command was introduced.

## Usage Guidelines

You can enter any **show pagp** command to display the active channel-group information. To display the nonactive information, enter the **show pagp** command with a channel-group number.

## Examples

This is an example of output from the **show pagp 1 counters** command:

```
Device> show pagp 1 counters
          Information          Flush
Port      Sent  Recv      Sent  Recv
-----
Channel group: 1
Gi1/0/1   45   42         0     0
Gi1/0/2   45   41         0     0
```

This is an example of output from the **show pagp dual-active** command:

```
Device> show pagp dual-active
PAgP dual-active detection enabled: Yes
PAgP dual-active version: 1.1

Channel group 1
Port      Dual-Active  Partner          Partner  Partner
          Detect Capable Name              Port      Version
Gi1/0/1   No           -p2              Gi3/0/3   N/A
Gi1/0/2   No           -p2              Gi3/0/4   N/A

<output truncated>
```

This is an example of output from the **show pagp 1 internal** command:

```

Device> show pagp 1 internal
Flags: S - Device is sending Slow hello. C - Device is in Consistent state.
      A - Device is in Auto mode.
Timers: H - Hello timer is running. Q - Quit timer is running.
      S - Switching timer is running. I - Interface timer is running.

```

Channel group 1

Port	Flags	State	Timers	Hello Interval	Partner Count	PAGP Priority	Learning Method	Group Ifindex
Gi1/0/1	SC	U6/S7	H	30s	1	128	Any	16
Gi1/0/2	SC	U6/S7	H	30s	1	128	Any	16

This is an example of output from the **show pagp 1 neighbor** command:

```

Device> show pagp 1 neighbor

```

```

Flags: S - Device is sending Slow hello. C - Device is in Consistent state.
      A - Device is in Auto mode. P - Device learns on physical port.

```

Channel group 1 neighbors

Port	Partner Name	Partner Device ID	Partner Port	Age	Partner Flags	Partner Group Cap.
Gi1/0/1	-p2	0002.4b29.4600	Gi01//1	9s	SC	10001
Gi1/0/2	-p2	0002.4b29.4600	Gi1/0/2	24s	SC	10001



# show platform etherchannel

To display platform-dependent EtherChannel information, use the **show platform etherchannel** command in privileged EXEC mode.

```
show platform etherchannel channel-group-number {group-mask | load-balance mac src-mac
dst-mac [ip src-ip dst-ip [port src-port dst-port]]} [switch switch-number]
```

Syntax Description	
<i>channel-group-number</i>	Channel group number. The range is 1 to 128.
<b>group-mask</b>	Displays EtherChannel group mask.
<b>load-balance</b>	Tests EtherChannel load-balance hash algorithm.
<b>mac</b> <i>src-mac</i> <i>dst-mac</i>	Specifies the source and destination MAC addresses.
<b>ip</b> <i>src-ip</i> <i>dst-ip</i>	(Optional) Specifies the source and destination IP addresses.
<b>port</b> <i>src-port</i> <i>dst-port</i>	(Optional) Specifies the source and destination layer port numbers.
<b>switch</b> <i>switch-number</i>	(Optional) Specifies the stack member.

Command Modes	
	Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE Everest 16.5.1a	This command was introduced.

Usage Guidelines	
	Use this command only when you are working directly with a technical support representative while troubleshooting a problem.

Do not use this command unless a technical support representative asks you to do so.

# show platform hardware fed active vlan ingress

To display if native vlan tagging is enabled or disabled for a particular vlan, use the **show platform hardware fed active vlan ingress**

**show platform hardware fed active vlan *vlan ID* ingress**

## Syntax Description

Syntax	Description
<b>vlan</b> <i>vlan ID</i>	Specifies the VLAN ID.
<b>ingress</b>	Specifies Spanning Tree Protocol (STP) state information in ingress direction.

**Command Modes** Privileged EXEC mode (#)

Command History	Release	Modification
	Cisco IOS XE Gibraltar 16.11.1	This command was introduced.

## Example

The following is sample output from the **show platform hardware fed active vlan ingress** command:

```
Device# show platform hardware fed active vlan 1 ingress
VLAN STP State in hardware

vlan id is:: 1

Interfaces in forwarding state: : Hu1/0/45(Tagged)

flood list: : Hu1/0/45
```

# show platform pm

To display platform-dependent port manager information, use the **show platform pm** command in privileged EXEC mode.

**show platform pm** {**etherchannel** *channel-group-number* **group-mask** | **interface-numbers** | **port-data** *interface-id* | **port-state**}

Syntax Description		
<b>etherchannel</b> <i>channel-group-number</i> <b>group-mask</b>	Displays the EtherChannel group-mask table for the specified channel group.	The range is 1 to 128.
<b>interface-numbers</b>	Displays interface numbers information.	
<b>port-data</b> <i>interface-id</i>	Displays port data information for the specified interface.	
<b>port-state</b>	Displays port state information.	

**Command Modes** Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE Everest 16.5.1a	This command was introduced.

**Usage Guidelines** Use this command only when you are working directly with your technical support representative while troubleshooting a problem.

Do not use this command unless your technical support representative asks you to do so.

# show platform software fed active ptp interface loopback

To display the Precision Time Protocol (PTP) connection details and events of the specified loopback interface, use the **show platform software fed active ptp interface loopback** command in privileged EXEC mode.

**show platform software fed active ptp interface** *value*

<b>Syntax Description</b>	<i>value</i>	Loopback interface number. The maximum number of sessions supported is 127.
<b>Command Default</b>	None	
<b>Command Modes</b>	Privileged EXEC (#)	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Bengaluru 17.5.1	This command was introduced.

## Examples

The following is a sample output of the **show platform software fed active ptp interface loopback** command:

```
Device> enable
Device# show platform software fed active ptp interface loopback 0
```

## show platform software fed switch ptp

To display information about ptp status on the port, use the **show platform software fed switch ptp** command.

```
show platform software fed switch { switch-number | active | standby } ptp { domain domain-value
| if-id value | test }
```

### Syntax Description

<b>switch</b> <i>switch-number</i>	Displays information about the switch. Valid values for <i>switch-number</i> argument are from 0 to 9.
<b>active</b>	Displays information about the active instance of the switch.
<b>standby</b>	Displays information about the standby instance of the switch.
<b>domain</b> <i>domain-value</i>	Displays information about the specified domain.
<b>if-id</b> <i>value</i>	Displays information about the specified interface.
<b>test</b>	Executes ptp test

### Command History

Release	Modification
Cisco IOS XE Fuji 16.8.1a	This command was introduced.

### Command Modes

Global configuration mode (#)

#### Example:

The following is sample output from the **show platform software fed switch active ptp if-id 0x20** command:

```
Device# show platform software fed switch active ptp if-id 0x20
```

```
Displaying port data for if_id 20
=====
Port Mac Address 04:6C:9D:4E:3A:9A
Port Clock Identity 04:6C:9D:FF:FE:4E:3A:80
Port number 28
PTP Version 2
domain_value 0
dot1as_capable: FALSE
sync_recpt_timeout_time_interval 375000000 nanoseconds
sync_interval 125000000 nanoseconds
neighbor_rate_ratio 0.000000
neighbor_prop_delay 0 nanoseconds
compute_neighbor_rate_ratio: TRUE
compute_neighbor_prop_delay: TRUE
port_enabled: TRUE
ptt_port_enabled: TRUE
current_log_pdelay_req_interval 0
pdelay_req_interval 0 nanoseconds
allowed_lost_responses 3
neighbor_prop_delay_threshold 2000 nanoseconds
```

```
is_measuring_delay : FALSE
Port state: : MASTER
sync_seq_num 22023
delay_req_seq_num 23857
num sync messages transmitted 0
num sync messages received 0
num followup messages transmitted 0
num followup messages received 0
num pdelay requests transmitted 285695
num pdelay requests received 0
num pdelay responses transmitted 0
num pdelay responses received 0
num pdelay followup responses transmitted 0
num pdelay followup responses received 0
```

## show ptp brief

To display a brief status of PTP on the interfaces, use the **show ptp brief** command in global configuration mode.

### show ptp brief

**Syntax Description** This command has no arguments or keywords.

**Command Modes** Privileged EXEC (#)

Command History	Release	Modification
	Cisco IOS XE Fuji 16.8.1a	This command was introduced.

### Examples

The following is a sample output from the **show ptp brief** command:

```
Device# show ptp brief

Interface                               Domain   PTP State
FortyGigabitEthernet1/1/1              0       FAULTY
FortyGigabitEthernet1/1/2              0       SLAVE
GigabitEthernet1/1/1                    0       FAULTY
GigabitEthernet1/1/2                    0       FAULTY
GigabitEthernet1/1/3                    0       FAULTY
GigabitEthernet1/1/4                    0       FAULTY
TenGigabitEthernet1/0/1                  0       FAULTY
TenGigabitEthernet1/0/2                  0       FAULTY
TenGigabitEthernet1/0/3                  0       MASTER
TenGigabitEthernet1/0/4                  0       FAULTY
TenGigabitEthernet1/0/5                  0       FAULTY
TenGigabitEthernet1/0/6                  0       FAULTY
TenGigabitEthernet1/0/7                  0       MASTER
TenGigabitEthernet1/0/8                  0       FAULTY
TenGigabitEthernet1/0/9                  0       FAULTY
TenGigabitEthernet1/0/10                 0       FAULTY
TenGigabitEthernet1/0/11                 0       MASTER
TenGigabitEthernet1/0/12                 0       FAULTY
TenGigabitEthernet1/0/13                 0       FAULTY
TenGigabitEthernet1/0/14                 0       FAULTY
TenGigabitEthernet1/0/15                 0       FAULTY
TenGigabitEthernet1/0/16                 0       FAULTY
.
.
.
```

### Related Commands

Command	Description
<b>show ptp clock</b>	Displays PTP clock information.
<b>show ptp parent</b>	Displays the parent clock information.
<b>show ptp port</b>	Displays the PTP port information.
<b>show ptp time-property</b>	Displays the PTP clock time property.

# show ptp clock

To display PTP clock information, use the **show ptp clock** command in global configuration mode.

## show ptp clock

**Syntax Description** This command has no arguments or keywords.

**Command Modes** Privileged EXEC (#)

Command History	Release	Modification
	Cisco IOS XE Fuji 16.8.1a	This command was introduced.

## Examples

The following is a sample output from the **show ptp clock** command:

```
Device# show ptp clock

PTP CLOCK INFO
  PTP Device Type: Boundary clock
  PTP Device Profile: IEEE 802/1AS Profile
  Clock Identity: 0x4:6C:9D:FF:FE:4F:95:0
  Clock Domain: 0
  Number of PTP ports: 38
  PTP Packet priority: 4
  Priority1: 128
  Priority2: 128
  Clock Quality:
    Class: 248
    Accuracy: Unknown
    Offset (log variance): 16640
  Offset From Master(ns): 0
  Mean Path Delay(ns): 0
  Steps Removed: 3
  Local clock time: 00:12:13 UTC Jan 1 1970

-----
```

## Related Commands

Command	Description
<b>show ptp brief</b>	Displays a brief status of PTP on the interfaces.
<b>show ptp parent</b>	Displays the parent clock information.
<b>show ptp port</b>	Displays the PTP port information.
<b>show ptp time-property</b>	Displays the PTP clock time property.



# show ptp parent

To display the PTP parent clock information, use the **show ptp parent** command in global configuration mode.

## show ptp parent

**Syntax Description** This command has no arguments or keywords.

**Command Modes** Privileged EXEC (#)

Command History	Release	Modification
	Cisco IOS XE Fuji 16.8.1a	This command was introduced.

## Examples

The following is a sample output from the **show ptp parent** command:

```
Device# show ptp parent

Steps Removed: 3
Local clock time: 00:12:13 UTC Jan 1 1970
```

-----

This command can be used to view the parent clock information.

```
Device#show ptp parent

PTP PARENT PROPERTIES
Parent Clock:
Parent Clock Identity: 0xB0:7D:47:FF:FE:9E:B6:80
Parent Port Number: 3
Observed Parent Offset (log variance): 16640
Observed Parent Clock Phase Change Rate: N/A

Grandmaster Clock:
Grandmaster Clock Identity: 0x4:6C:9D:FF:FE:67:3A:80
Grandmaster Clock Quality:
Class: 248
Accuracy: Unknown
Offset (log variance): 16640
Priority1: 0
Priority2: 128
```

## Related Commands

Command	Description
<b>show ptp brief</b>	Displays a brief status of PTP on the interfaces.
<b>show ptp clock</b>	Displays PTP clock information.
<b>show ptp port</b>	Displays the PTP port information.

Command	Description
show ptp time-property	Displays the PTP clock time property.

# show ptp port

To display the PTP port information, use the **show ptp port** command in global configuration mode.

## show ptp port

**Syntax Description** This command has no arguments or keywords.

**Command Modes** Privileged EXEC (#)

Command History	Release	Modification
	Cisco IOS XE Fuji 16.8.1a	This command was introduced.

## Examples

The following is a sample output from the **show ptp port** command:

```
Device# show ptp port

PTP PORT DATASET: FortyGigabitEthernet1/1/1
  Port identity: clock identity: 0x4:6C:9D:FF:FE:4E:3A:80
  Port identity: port number: 1
  PTP version: 2
  Port state: FAULTY
  Delay request interval(log mean): 5
  Announce receipt time out: 3
  Peer mean path delay(ns): 0
  Announce interval(log mean): 1
  Sync interval(log mean): 0
  Delay Mechanism: End to End
  Peer delay request interval(log mean): 0
  Sync fault limit: 500000000

PTP PORT DATASET: FortyGigabitEthernet1/1/2
  Port identity: clock identity: 0x4:6C:9D:FF:FE:4E:3A:80
  Port identity: port number: 2
  PTP version: 2
  Port state: FAULTY
  Delay request interval(log mean): 5
  Announce receipt time out: 3
  Peer mean path delay(ns): 0
  Announce interval(log mean): 1
--More--
```

## Related Commands

Command	Description
<b>show ptp brief</b>	Displays a brief status of PTP on the interfaces.
<b>show ptp clock</b>	Displays PTP clock information.
<b>show ptp parent</b>	Displays the parent clock information.
<b>show ptp time-property</b>	Displays the PTP clock time property.

# show ptp port loopback

To display Precision Time Protocol (PTP) configurations of a loopback interface, use the **show ptp port loopback** command in privileged EXEC mode.

**show ptp port loopback** *value*

<b>Syntax Description</b>	<i>value</i>	Loopback interface number. The maximum number of sessions supported is 127.
<b>Command Default</b>	None	
<b>Command Modes</b>	Privileged EXEC (#)	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Bengaluru 17.5.1	This command was introduced.

## Examples

The following is a sample output of the **show ptp port loopback** command:

```
Device> enable
Device# show ptp port loopback
PTP PORT DATASET: Loopback0
  Port identity: clock identity: 0xF8:F:6F:FF:FE:CB:4D:C0
  Port identity: port number: 34818
  PTP version: 2
  PTP port number: 2
  PTP slot number: 17
  Port state: SLAVE
  Delay request interval(log mean): 0
  Announce receipt time out: 3
  Neighbor prop delay(ns): 0
  Announce interval(log mean): 0
  Sync interval(log mean): -2
  Delay Mechanism: End to End
  Peer delay request interval(log mean): 0
  Sync fault limit: 500000000
  ptp role primary : Disabled
```

# show ptp transport properties

To display a Precision Time Protocol (PTP) profile and its properties, use the **show ptp transport properties** command in privileged EXEC mode.

**show ptp transport properties**

---

## Command Default

None

---

## Command Modes

Privileged EXEC (#)

---

## Command History

Release	Modification
Cisco IOS XE Bengaluru 17.5.1	This command was introduced.

---

## Examples

The following is a sample output of the **show ptp transport properties** command:

```
Device> enable
Device# show ptp transport properties
Profile Property flow1 extended to : Dot1as
S.No Transport      Interface      SourceIP      Vrf      PeerIp      Ptp State
-----
  1 IPv4             Loopback0     4.4.4.4      Vrf      192.168.2.2  SLAVE
```

# show rep topology

To display Resilient Ethernet Protocol (REP) topology information for a segment or for all the segments, including the primary and secondary edge ports in the segment, use the **show rep topology** command in privileged EXEC mode.

**show rep topology** [**segment** *segment-id*] [**archive**] [**detail**]

Syntax Description	segment <i>segment-id</i>	(Optional) Specifies the segment for which to display the REP topology information. The <i>segment-id</i> range is from 1 to 1024.
	<b>archive</b>	(Optional) Displays the previous topology of the segment. This keyword is useful for troubleshooting a link failure.
	<b>detail</b>	(Optional) Displays detailed REP topology information.
Command Modes	Privileged EXEC	
Command History	Release	Modification
	Cisco IOS XE Everest 16.5.1a	This command was introduced.

## Examples

The following is a sample output from the **show rep topology** command:

```
Device# show rep topology

REP Segment 1
BridgeName      PortName      Edge Role
-----
10.64.106.63    Te5/4         Pri  Open
10.64.106.228  Te3/4         Open
10.64.106.228  Te3/3         Open
10.64.106.67   Te4/3         Open
10.64.106.67   Te4/4         Alt
10.64.106.63   Te4/4         Sec  Open

REP Segment 3
BridgeName      PortName      Edge Role
-----
10.64.106.63    Gi50/1        Pri  Open
SVT_3400_2      Gi0/3         Open
SVT_3400_2      Gi0/4         Open
10.64.106.68   Gi40/2        Open
10.64.106.68   Gi40/1        Open
10.64.106.63   Gi50/2        Sec  Alt
```

The following is a sample output from the **show rep topology detail** command:

```
Device# show rep topology detail

REP Segment 1
10.64.106.63, Te5/4 (Primary Edge)
  Open Port, all vlans forwarding
  Bridge MAC: 0005.9b2e.1700
  Port Number: 010
```

```
Port Priority: 000
Neighbor Number: 1 / [-6]
10.64.106.228, Te3/4 (Intermediate)
Open Port, all vlans forwarding
Bridge MAC: 0005.9b1b.1f20
Port Number: 010
Port Priority: 000
Neighbor Number: 2 / [-5]
10.64.106.228, Te3/3 (Intermediate)
Open Port, all vlans forwarding
Bridge MAC: 0005.9b1b.1f20
Port Number: 00E
Port Priority: 000
Neighbor Number: 3 / [-4]
10.64.106.67, Te4/3 (Intermediate)
Open Port, all vlans forwarding
Bridge MAC: 0005.9b2e.1800
Port Number: 008
Port Priority: 000
Neighbor Number: 4 / [-3]
10.64.106.67, Te4/4 (Intermediate)
Alternate Port, some vlans blocked
Bridge MAC: 0005.9b2e.1800
Port Number: 00A
Port Priority: 000
Neighbor Number: 5 / [-2]
10.64.106.63, Te4/4 (Secondary Edge)
Open Port, all vlans forwarding
Bridge MAC: 0005.9b2e.1700
Port Number: 00A
Port Priority: 000
Neighbor Number: 6 / [-1]
```

## show spanning-tree

To display spanning-tree information for the specified spanning-tree instances, use the **show spanning-tree** command in privileged EXEC mode.

```
show spanning-tree [bridge-group] [{ active | backbonefast | blockedports | bridge [id] | detail |
inconsistentports | instances | interface interface-type interface-number | mst [{ list | configuration
digest] }] | pathcost method | root | summary [totals] | uplinkfast | vlan vlan-id }
```

### Syntax Description

<i>bridge-group</i>	(Optional) Specifies the bridge group number. The range is 1 to 255.
<b>active</b>	(Optional) Displays spanning-tree information on active interfaces only.
<b>backbonefast</b>	(Optional) Displays spanning-tree BackboneFast status.
<b>blockedports</b>	(Optional) Displays blocked port information.
<b>bridge</b>	(Optional) Displays status and configuration of this switch.
<b>detail</b>	(Optional) Shows status and configuration details.
<b>inconsistentports</b>	(Optional) Displays information about inconsistent ports.
<b>instances</b>	(Optional) Displays information about maximum STP instances.
<b>interface</b> <i>interface-type interface-number</i>	(Optional) Specifies the type and number of the interface. Enter each interface designator, using a space to separate it from the one before and the one after. Ranges are not supported. Valid interfaces include physical ports and virtual LANs (VLANs). See the “Usage Guidelines” for valid values.
<b>mst</b>	(Optional) Specifies multiple spanning-tree.
<i>list</i>	(Optional) Specifies a multiple spanning-tree instance list.
<b>configuration digest</b>	(Optional) Displays the multiple spanning-tree current region configuration.
<b>pathcost</b> <i>method</i>	(Optional) Displays the default path-cost calculation method that is used. See the “Usage Guidelines” section for the valid values.
<b>root</b>	(Optional) Displays root-switch status and configuration.
<b>summary</b>	(Optional) Specifies a summary of port states.
<b>totals</b>	(Optional) Displays the total lines of the spanning-tree state section.
<b>uplinkfast</b>	(Optional) Displays spanning-tree UplinkFast status.
<b>vlan</b> <i>vlan-id</i>	(Optional) Specifies the VLAN ID. The range is 1 to 4094. If the <i>vlan-id</i> value is omitted, the command applies to the spanning-tree instance for all VLANs.
<i>id</i>	(Optional) Identifies the spanning tree bridge.



<b>port-channel</b> <i>number</i>	(Optional) Identifies the Ethernet channel associated with the interfaces.
-----------------------------------	--

**Command Modes** Privileged EXEC (#)

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Everest 16.5.1a	This command was introduced.

**Usage Guidelines** The keywords and arguments that are available with the **show spanning-tree** command vary depending on the platform you are using and the network modules that are installed and operational.

The **port-channel** *number* values from 257 to 282 are supported on the Content Switching Module (CSM) and the Firewall Services Module (FWSM) only.

The *interface-number* argument designates the module and port number. Valid values for *interface-number* depend on the specified interface type and the chassis and module that are used. For example, if you specify a Gigabit Ethernet interface and have a 48-port 10/100BASE-T Ethernet module that is installed in a 13-slot chassis, valid values for the module number are from 2 to 13 and valid values for the port number are from 1 to 48.

When checking spanning tree-active states and you have a large number of VLANs, you can enter the **show spanning-tree summary total** command. You can display the total number of VLANs without having to scroll through the list of VLANs.

The valid values for keyword **pathcoast** *method* are:

- **append**: Appends the redirected output to a URL (supporting the append operation).
- **begin**: Begins with the matching line.
- **exclude**: Excludes matching lines.
- **include**: Includes matching lines.
- **redirect**: Redirects output to a URL.
- **tee**: Copies output to a URL.

When you run the **show spanning-tree** command for a VLAN or an interface the switch router will display the different port states for the VLAN or interface. The valid spanning-tree port states are listening, learning, forwarding, blocking, disabled, and loopback.

```
Device#
show spanning-tree
VLAN0001
  Spanning tree enabled protocol rstp
  Root ID    Priority    32769
            Address    5c71.0dfe.8380
            This bridge is the root
            Hello Time  2 sec    Max Age 20 sec    Forward Delay 15 sec

  Bridge ID  Priority    32769 (priority 32768 sys-id-ext 1)
            Address    5c71.0dfe.8380
            Hello Time  2 sec    Max Age 20 sec    Forward Delay 15 sec
            Aging Time  300 sec
```

## show spanning-tree

```

Interface          Role Sts Cost      Prio.Nbr Type
-----
Gi1/0/1            Desg FWD 20000    128.1   P2p
Gi1/0/18           Desg FWD 20000    128.18  P2p
Gi1/0/21           Desg FWD 20000    128.21  P2p
Te1/0/25           Desg FWD 20000    128.25  P2p
Te1/0/37           Desg FWD 2000     128.37  P2p
Te1/0/38           Desg FWD 2000     128.38  P2p
Te1/0/45           Desg FWD 20000    128.45  P2p
Te1/0/48           Desg FWD 20000    128.48  P2p

```

See the table below for definitions of the port states:

**Table 4: show spanning-tree vlan Command Port States**

Field	Definition
BLK	Blocked is when the port is still sending and listening to BPDU packets but is not forwarding traffic.
DIS	Disabled is when the port is not sending or listening to BPDU packets and is not forwarding traffic.
FWD	Forwarding is when the port is sending and listening to BPDU packets and forwarding traffic.
LBK	Loopback is when the port receives its own BPDU packet back.
LIS	Listening is when the port spanning tree initially starts to listen for BPDU packets for the root bridge.
LRN	Learning is when the port sets the proposal bit on the BPDU packets it sends out

This example shows how to display a summary of interface information:

```

Device#
show spanning-tree
VLAN0001
  Spanning tree enabled protocol rstp
  Root ID      Priority      32769
              Address      6cb2.ae4a.4fc0
              This bridge is the root
              Hello Time  2 sec  Max Age 20 sec  Forward Delay 15 sec

  Bridge ID   Priority      32769 (priority 32768 sys-id-ext 1)
              Address      6cb2.ae4a.4fc0
              Hello Time  2 sec  Max Age 20 sec  Forward Delay 15 sec
              Aging Time  300 sec

```

```

Interface          Role Sts Cost      Prio.Nbr Type
-----
Fif1/0/17          Desg FWD 2000     128.17  P2p
Fif1/0/19          Desg FWD 800     128.19  P2p
Fif1/0/21          Desg FWD 2000    128.21  P2p
Fif1/0/23          Desg FWD 2000    128.23  P2p
TwoH1/0/42         Desg FWD 500     128.42  P2p
Fou1/0/44          Desg FWD 50     128.44  P2p
Fif2/0/17          Back BLK 2000    128.185 P2p
Fif2/0/19          Back BLK 800     128.187 P2p
Fif2/0/21          Back BLK 2000    128.189 P2p
Fif2/0/23          Back BLK 2000    128.191 P2p
Fou2/0/43          Desg FWD 50     128.211 P2p
Fou2/0/44          Back BLK 50     128.212 P2p
Hu5/0/13           Desg FWD 500     128.685 P2p

```

```

Hu5/0/15          Desg FWD 500      128.687 P2p
Hu5/0/21          Back BLK 500      128.693 P2p
Hu5/0/23          Back BLK 500      128.695 P2p
Fou6/0/27         Back BLK 50       128.867 P2p
Hu6/0/29          Desg FWD 200      128.869 P2p
Hu6/0/30          Back BLK 200      128.870 P2p

```

The table below describes the fields that are shown in the example.

**Table 5: show spanning-tree Command Output Fields**

Field	Definition
Port ID Prio.Nbr	Port ID and priority number.
Cost	Port cost.
Sts	Status information.

This example shows how to display information about the spanning tree for this bridge only:

```

Device# show spanning-tree bridge

Vlan                Bridge ID                Hello Time  Max Age  Fwd Dly  Protocol
-----
VLAN0001            32769 (32768, 1) 5c71.0dfe.8380  2       20     15     rstp

```

This example shows how to display detailed information about the interface:

```

Device#
show spanning-tree detail
VLAN0001 is executing the rstp compatible Spanning Tree protocol
  Bridge Identifier has priority 32768, sysid 1, address 5c71.0dfe.8380
  Configured hello time 2, max age 20, forward delay 15, transmit hold-count 6
  We are the root of the spanning tree
  Topology change flag not set, detected flag not set
  Number of topology changes 27 last change occurred 4d19h ago
    from TenGigabitEthernet1/0/48
  Times: hold 1, topology change 35, notification 2
         hello 2, max age 20, forward delay 15
  Timers: hello 0, topology change 0, notification 0, aging 300

Port 1 (GigabitEthernet1/0/1) of VLAN0001 is designated forwarding
  Port path cost 20000, Port priority 128, Port Identifier 128.1.
  Designated root has priority 32769, address 5c71.0dfe.8380
  Designated bridge has priority 32769, address 5c71.0dfe.8380
  Designated port id is 128.1, designated path cost 0
  Timers: message age 0, forward delay 0, hold 0
  Number of transitions to forwarding state: 1
  Link type is point-to-point by default
  BPDU: sent 208695, received 1

Port 18 (GigabitEthernet1/0/18) of VLAN0001 is designated forwarding
!
!
<<output truncated>>

```

This example shows how to display a summary of port states:

```
Device#
```

**show spanning-tree summary**

```
Switch is in rapid-pvst mode
Root bridge for: VLAN0001
Extended system ID           is enabled
Portfast Default             is disabled
PortFast BPDU Guard Default  is disabled
Portfast BPDU Filter Default is disabled
Loopguard Default           is disabled
EtherChannel misconfig guard is enabled
UplinkFast                   is disabled
BackboneFast                 is enabled but inactive in rapid-pvst mode
Configured Pathcost method used is long
```

Name	Blocking	Listening	Learning	Forwarding	STP Active
VLAN0001	1	0	0	26	27
1 vlan	1	0	0	26	27

This example shows how to display the total lines of the spanning-tree state section:

```
Device#
show spanning-tree summary total Switch is in rapid-pvst mode
Root bridge for: VLAN0001
Extended system ID           is enabled
Portfast Default             is disabled
PortFast BPDU Guard Default  is disabled
Portfast BPDU Filter Default is disabled
Loopguard Default           is disabled
EtherChannel misconfig guard is enabled
UplinkFast                   is disabled
BackboneFast                 is enabled but inactive in rapid-pvst mode
Configured Pathcost method used is long
```

Name	Blocking	Listening	Learning	Forwarding	STP Active
1 vlan	1	0	0	26	27

This example shows how to display information about the spanning tree for a specific VLAN:

```
Device#
show spanning-tree vlan 200
VLAN0001
  Spanning tree enabled protocol rstp
  Root ID    Priority    32769
             Address     5c71.0dfe.8380
             This bridge is the root
             Hello Time  2 sec  Max Age 20 sec  Forward Delay 15 sec

  Bridge ID  Priority    32769 (priority 32768 sys-id-ext 1)
             Address     5c71.0dfe.8380
             Hello Time  2 sec  Max Age 20 sec  Forward Delay 15 sec
             Aging Time  300 sec
```

Interface	Role	Sts	Cost	Prio.Nbr	Type
Gi1/0/1	Desg	FWD	20000	128.1	P2p
Gi1/0/18	Desg	FWD	20000	128.18	P2p
Gi1/0/21	Desg	FWD	20000	128.21	P2p
Te1/0/25	Desg	FWD	20000	128.25	P2p
Te1/0/37	Desg	FWD	2000	128.37	P2p
Te1/0/38	Desg	FWD	2000	128.38	P2p
Te1/0/45	Desg	FWD	20000	128.45	P2p

```

Te1/0/48          Desg FWD 20000    128.48    P2p
!
!
<<output truncated>>

```

The table below describes the fields that are shown in the example.

**Table 6: show spanning-tree vlan Command Output Fields**

Field	Definition
Role	Current 802.1w role; valid values are Boun (boundary), Desg (designated), Root, Altn (alternate), and Back (backup).
Sts	Spanning-tree states; valid values are BKN* (broken) <sup>1</sup> , BLK (blocking), DWN (down), LTN (listening), LBK (loopback), LRN (learning), and FWD (forwarding).
Cost	Port cost.
Prio.Nbr	Port ID that consists of the port priority and the port number.
Status	Status information; valid values are as follows: <ul style="list-style-type: none"> <li>• P2p/Shr: The interface is considered as a point-to-point (resp. shared) interface by the spanning tree.</li> <li>• Edge: PortFast has been configured (either globally using the <b>default</b> command or directly on the interface) and no BPDU has been received.</li> <li>• *ROOT_Inc, *LOOP_Inc, *PVID_Inc and *TYPE_Inc: The port is in a broken state (BKN*) for an inconsistency. The port would be (respectively) Root inconsistent, Loopguard inconsistent, PVID inconsistent, or Type inconsistent.</li> <li>• Bound(type): When in MST mode, identifies the boundary ports and specifies the type of the neighbor (STP, RSTP, or PVST).</li> <li>• Peer(STP): When in PVRST rapid-pvst mode, identifies the port connected to a previous version of the 802.1D bridge.</li> </ul>

<sup>1</sup> For information on the \*, see the definition for the Status field.

# show spanning-tree mst

To display the information about the Multiple Spanning Tree (MST) protocol, use the **show spanning-tree mst** command in privileged EXEC mode.

```
show spanning-tree mst [{ configuration [digest] | instance-id-number }] [ interface interface ] [ detail ] [ service instance ]
```

Syntax Description	
<i>instance-id-number</i>	(Optional) Instance identification number. The range is from 0 to 4094.
<b>detail</b>	(Optional) Displays detailed information about the MST protocol.
<i>interface</i>	(Optional) Displays the information about the interfaces. See the “Usage Guidelines” section for valid number values.
<b>configuration</b>	(Optional) Displays information about the region configuration.
<b>digest</b>	(Optional) Displays information about the message digest 5 (MD5) algorithm included in the current MST configuration identifier (MSTCI).
<b>interface</b>	(Optional) Displays information about the interface type.

**Command Modes** Privileged EXEC (#)

Command History	Release	Modification
	Cisco IOS XE Everest 16.5.1a	This command was introduced.

**Usage Guidelines** The valid values for the *interface* argument depend on the specified interface type and the chassis and module that are used. For example, if you specify a Gigabit Ethernet interface and have a 48-port 10/100BASE-T Ethernet module that is installed in a 13-slot chassis, valid values for the module number are from 2 to 13 and valid values for the port number are from 1 to 48.

The number of valid values for **port-channel** *number* are a maximum of 64 values ranging from 1 to 282. The **port-channel** *number* values from 257 to 282 are supported on the Content Switching Module (CSM) and the Firewall Services Module (FWSM) only.

The number of valid values for **vlan** are from 1 to 4094.

In the output display of the **show spanning-tree mst configuration** command, a warning message may be displayed. This message appears if you do not map secondary VLANs to the same instance as the associated primary VLAN. The display includes a list of the secondary VLANs that are not mapped to the same instance as the associated primary VLAN. The warning message is as follows:

```
These secondary vlans are not mapped to the same instance as their primary:
-> 3
```

In the output display of the **show spanning-tree mst configuration digest** command, if the output applies to both standard and prestandard bridges at the same time on a per-port basis, two different digests are displayed.

If you configure a port to transmit prestandard PortFast bridge protocol data units (BPDUs) only, the prestandard flag displays in the **show spanning-tree** commands. The variations of the prestandard flag are as follows:

- Pre-STD (or pre-standard in long format): This flag is displayed if the port is configured to transmit prestandard BPDUs and if a prestandard neighbor bridge has been detected on this interface.
- Pre-STD-Cf (or pre-standard (config) in long format): This flag is displayed if the port is configured to transmit prestandard BPDUs but a prestandard BPDUs has not been received on the port, the autodetection mechanism has failed, or a misconfiguration, if there is no prestandard neighbor, has occurred.
- Pre-STD-Rx (or prestandard (rcvd) in long format): This flag is displayed when a prestandard BPDUs has been received on the port, but it has not been configured to send prestandard BPDUs. The port will send prestandard BPDUs, but Cisco recommends that you change the port configuration so that the interaction with the prestandard neighbor does not rely only on the autodetection mechanism.

If the configuration is not prestandard compliant (for example, a single MST instance has an ID that is greater than or equal to 16,) the prestandard digest is not computed and the following output is displayed:

```
Device# show spanning-tree mst configuration digest

Name      [region1]
Revision  2          Instances configured 3
Digest    0x3C60DBF24B03EBF09C5922F456D18A03
Pre-std Digest  N/A, configuration not pre-standard compatible
```

MST BPDUs include an MSTCI that consists of the region name, region revision, and an MD5 digest of the VLAN-to-instance mapping of the MST configuration.

See the **show spanning-tree mst** command field description table for output descriptions.

## Examples

The following example shows how to display information about the region configuration:

```
Device# show spanning-tree mst configuration

Name      [train]
Revision  2702
Instance  Vlans mapped
-----
0         1-9,11-19,21-29,31-39,41-4094
1         10,20,30,40
-----
```

The following example shows how to display additional MST-protocol values:

```
Device# show spanning-tree mst 3 detail

##### MST03 vlans mapped: 3,3000-3999
Bridge address 0002.172c.f400 priority 32771 (32768 sysid 3)
Root this switch for MST03
GigabitEthernet1/1 of MST03 is boundary forwarding
Port info port id 128.1 priority 128
cost 20000
Designated root address 0002.172c.f400 priority 32771
cost 0
Designated bridge address 0002.172c.f400 priority 32771 port
id 128.1
Timers: message expires in 0 sec, forward delay 0, forward transitions 1
Bpdus (MRecords) sent 4, received 0
FastEthernet4/1 of MST03 is designated forwarding
Port info port id 128.193 priority 128 cost
200000
Designated root address 0002.172c.f400 priority 32771
```

```

cost 0
Designated bridge address 0002.172c.f400 priority 32771 port id
128.193
Timers: message expires in 0 sec, forward delay 0, forward transitions 1
Bpdus (MRecords) sent 254, received 1
FastEthernet4/2 of MST03 is backup blocking
Port info port id 128.194 priority 128 cost
200000
Designated root address 0002.172c.f400 priority 32771
cost 0
Designated bridge address 0002.172c.f400 priority 32771 port id
128.193
Timers: message expires in 2 sec, forward delay 0, forward transitions 1
Bpdus (MRecords) sent 3, received 252

```

The following example shows how to display the MD5 digest included in the current MSTCI:

```
Device# show spanning-tree mst configuration digest
```

```

Name      [mst-config]
Revision  10      Instances configured 25
Digest    0x40D5ECA178C657835C83BBCB16723192
Pre-std Digest 0x27BF112A75B72781ED928D9EC5BB4251

```

## Related Commands

Command	Description
<b>spanning-tree mst</b>	Sets the path cost and port-priority parameters for any MST instance.
<b>spanning-tree mst forward-time</b>	Sets the forward-delay timer for all the instances on the Cisco 7600 series router.
<b>spanning-tree mst hello-time</b>	Sets the hello-time delay timer for all the instances on the Cisco 7600 series router.
<b>spanning-tree mst max-hops</b>	Specifies the number of possible hops in the region before a BPDU is discarded.



## show udld

To display UniDirectional Link Detection (UDLD) administrative and operational status for all ports or the specified port, use the **show udld** command in user EXEC mode.

```
show udld [ANI | AccessTunnel | Auto-Template | BDI | CEM-PG | GMPLS |
GigabitEthernet | HundredGigE | InternalInterface | LISP | Loopback | Null |
PROTECTION_GROUP | Port-channel | SDH_ACR | SERIAL-ACR | Serial-PG | TLS-VIF
| Tunnel | Tunnel-tp | TwentyFiveGigE | VirtualPortGroup | Vlan | nve] interface_number
show udld neighbors
show udld fast-hello interface_number
```

Syntax Description		
<b>ANI</b>	(Optional)	Displays UDLD operational status of the Autonomic-Networking virtual interface.
<b>AccessTunnel</b>	(Optional)	Displays UDLD operational status of the Access Tunnel Interface.
<b>Auto-Template</b>	(Optional)	Displays UDLD operational status of the auto-template interface. The range is from 1 to 999.
<b>BDI</b>	(Optional)	Displays UDLD operational status of the Bridge-Domain interface.
<b>CEM-PG</b>	(Optional)	Displays UDLD operational status of the Circuit Emulation interface with Protection group.
<b>GMPLS</b>	(Optional)	Displays UDLD operational status of the MPLS interface.
<b>GigabitEthernet</b>	(Optional)	Displays UDLD operational status of the GigabitEthernet interface.
<b>HundredGigE</b>	(Optional)	Displays UDLD operational status of the Hundred Gigabit Ethernet.
<b>InternalInterface</b>	(Optional)	Displays UDLD operational status of the internal interface. The range is from 0 to 9.
<b>LISP</b>	(Optional)	Displays UDLD operational status of the Locator/ID Separation Protocol Virtual Interface.
<b>Loopback</b>	(Optional)	Displays UDLD operational status of the loopback interface. The range is from 0 to 2147483647.
<b>Null</b>	(Optional)	Displays UDLD operational status of the null interface.
<b>PROTECTION_GROUP</b>	(Optional)	Displays UDLD operational status of the Protection-group controller.

<b>Port-channel</b>	(Optional) Displays UDLD operational status of the Ethernet channel interfaces. The range is 1 to 128.
<b>SDH_ACR</b>	(Optional) Displays UDLD operational status of the Virtual SDH-ACR controller.
<b>SERIAL-ACR</b>	(Optional) Displays UDLD operational status of the Serial interface with ACR.
<b>Serial-PG</b>	(Optional) Displays UDLD operational status of the Serial interface with Protection Group.
<b>TLS-VIF</b>	(Optional) Displays UDLD operational status of the TLS Virtual Interface.
<b>Tunnel</b>	(Optional) Displays UDLD operational status of the tunnel interface. The range is from 0 to 2147483647.
<b>Tunnel-tp</b>	(Optional) Displays UDLD operational status of the MPLS Transport Profile interface.
<b>TwentyFiveGigE</b>	(Optional) Displays UDLD operational status of the Twenty Five Gigabit Ethernet.
<b>VirtualPortGroup</b>	(Optional) Displays UDLD operational status of the Virtual Port Group.
<b>Vlan</b>	(Optional) Displays UDLD operational status of the VLAN interface. The range is from 1 to 4095.
<i>interface_number</i>	(Optional) ID of the interface and port number. Valid interfaces include physical ports, VLANs, and port channels.
<b>nve</b>	(Optional) Displays UDLD operational status of Network virtualization endpoint interface
<b>neighbors</b>	(Optional) Displays neighbor information only.
<b>fast-hello</b>	(Optional) Displays ports that have fast-hello configured and their fast-hello operational status.
<b>fast-hello</b> <i>interface_number</i>	(Optional) Displays the fast-hello information of a specific interface.

**Command Modes**

User EXEC

**Command History**

<b>Release</b>	<b>Modification</b>
Cisco IOS XE Everest 16.5.1a	This command was introduced.
Cisco IOS XE Fuji 16.9.1	The fast-hello keyword was added to the command.

**Usage Guidelines**

If you do not enter an interface ID, administrative and operational UDLD status for all interfaces appear.

Examples:

This is an example of output from the **show udld *interface-id*** command. For this display, UDLD is enabled on both ends of the link, and UDLD detects that the link is bidirectional.

```
Device> show udld TwentyFiveGigE1/0/1
Interface TwentyFiveGigE1/0/1
---
Port enable administrative configuration setting: Enabled
Port enable operational state: Enabled
Current bidirectional state: Bidirectional
Current operational state: Advertisement - Single neighbor detected
Message interval: 7000 ms
Time out interval: 5000 ms

Port fast-hello configuration setting: Enabled
Port fast-hello interval: 200 ms
Port fast-hello operational state: Enabled
Neighbor fast-hello configuration setting: Enabled
Neighbor fast-hello interval: 200 ms

Entry 1
---
Expiration time: 1400 ms
Cache Device index: 1
Current neighbor state: Bidirectional
Device ID: 0A74286120
Port ID: Hu1/0/2
Neighbor echo 1 device: 0A74286A80
Neighbor echo 1 port: Hu1/0/10

TLV Message interval: 15
TLV fast-hello interval: 500 ms
TLV Time out interval: 5
TLV CDP Device name: SkyFox-59
```

This is an example of output from the **show udld fast-hello *interface-id*** command. For this display, UDLD is enabled on both ends of the link, and UDLD detects that the link is bidirectional. The fast-hello information of the port is displayed along with the UDLD operational status.

```
Device> show udld fast-hello hundredGigE 1/0/10
Interface hundredGigE 1/0/10
---Port enable administrative configuration setting: Enabled
Port enable operational state: Enabled
Current bidirectional state: Bidirectional
Current operational state: Advertisement - Single neighbor detected
Message interval: 500 ms
Time out interval: 5000 ms

Port fast-hello configuration setting: Enabled
Port fast-hello interval: 500 ms
Port fast-hello operational state: Enabled
Neighbor fast-hello configuration setting: Enabled
Neighbor fast-hello interval: 500 ms

Entry 1
---
Expiration time: 1400 ms
Cache Device index: 1
Current neighbor state: Bidirectional
Device ID: 0A74286120
Port ID: Hu1/0/2
```

```
Neighbor echo 1 device: 0A74286A80
Neighbor echo 1 port: Hu1/0/10
```

```
TLV Message interval: 15
TLV fast-hello interval: 500 ms
TLV Time out interval: 5
TLV CDP Device name: SkyFox-59
```

This is an example of output from the **show udd fast-hello** global command.

```
Device> show udd fast-hello
Total ports on which fast hello can be configured: 32
Total ports with fast hello configured: 3
Total ports with fast hello operational: 3
Total ports with fast hello non-operational: 0
```

Port-ID	Hello	Neighbor-Hello	Neighbor-Device	Neighbor-Port	Status
Hu1/0/10	500	500	0A74286120	Hu1/0/2	Operational
Hu1/0/12	500	500	0A74286120	Hu1/0/18	Operational
Hu1/0/14	500	500	0A74286120	Hu1/0/4	Operational

This is an example of output from the **show udd neighbors** command:

```
Device> enable
Device# show udd neighbors
```

Port	Device Name	Device ID	Port-ID	OperState
Gi2/0/1	Switch-A	1	Gi2/0/1	Bidirectional
Gi3/0/1	Switch-A	2	Gi3/0/1	Bidirectional

# show vlan dot1q tag native

To display the status of tagging on the native VLAN use the **show vlan dot1q tag native** command.

**show vlan dot1q tag native**

## Syntax Description

This command has no arguments or keywords.

## Command Modes

Privileged EXEC mode (#)

## Command History

Release	Modification
Cisco IOS XE Everest 16.5.1a	This command was introduced.

## Example

The following is sample output from the **show vlan dot1q tag native** command:

```
Device# show vlan dot1q tag native
*Feb  1 06:47:30.719: %SYS-5-CONFIG_I: Configured from console by console
dot1q native vlan tagging is enabled globally
```

```
Per Port Native Vlan Tagging State
-----
Port          Operational      Native VLAN
              Mode             Tagging State
-----
Hu1/0/45     trunk            enabled
```

# source ip interface

To configure the source IP address, use the **source ip interface** command in property transport sub-configuration mode.

**source ip interface** *interface\_id*

<b>Syntax Description</b>	<i>interface_id</i>	Source IP address.
<b>Command Default</b>	None	
<b>Command Modes</b>	Property transport (config-property-transport)	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Bengaluru 17.5.1	This command was introduced.

**Usage Guidelines** This command is optional. Use this command as an alternative to the **peer** command.

## Examples

The following example shows how to configure the source IP address:

```
Device> enable
Device# configure terminal
Device(config)# ptp property cisco1
Device(config-property)# transport unicast ipv4 local loopback 0
Device(config-property-transport)# source ip interface GigabitEthernet 1/0/1
Device(config-property-transport)# end
```

## Related Commands

Command	Description
<b>ptp dot1as extend property</b>	Extends IEEE 802.1AS profile to a PTP property name.
<b>ptp property</b>	Sets the PTP property name.
<b>transport unicast ipv4 local loopback</b>	Configures a unicast IPv4 connection from a loopback interface.

# spanning-tree backbonefast

To enable BackboneFast to allow a blocked port on a switch to change immediately to a listening mode, use the **spanning-tree backbonefast** command in global configuration mode. To return to the default setting, use the **no** form of this command.

**spanning-tree backbonefast**  
**no spanning-tree backbonefast**

**Syntax Description** This command has no arguments or keywords.

**Command Default** BackboneFast is disabled.

**Command Modes** Global configuration (config)

Command History	Release	Modification
	Cisco IOS XE Everest 16.5.1a	This command was introduced.

**Usage Guidelines** BackboneFast should be enabled on all of the Cisco devices containing an Ethernet switch network module. BackboneFast provides for fast convergence in the network backbone after a spanning-tree topology change. It enables the switch to detect an indirect link failure and to start the spanning-tree reconfiguration sooner than it would under normal spanning-tree rules.

Use the **show spanning-tree** privileged EXEC command to verify your settings.

## Examples

The following example shows how to enable BackboneFast on the device:

```
Device(config)# spanning-tree backbonefast
```

Related Commands	Command	Description
	<b>show spanning-tree</b>	Displays information about the spanning-tree state.

# spanning-tree bpdudfilter

To enable bridge protocol data unit (BPDU) filtering on the interface, use the **spanning-tree bpdudfilter** command in interface configuration or template configuration mode. To return to the default settings, use the **no** form of this command.

**spanning-tree bpdudfilter** { **enable** | **disable** }  
**no spanning-tree bpdudfilter**

Syntax Description	enable	disable
	Enables BPDU filtering on this interface.	Disables BPDU filtering on this interface.

**Command Default** The setting that is already configured when you enter the **spanning-tree portfast edge bpdudfilter default** command .

**Command Modes** Interface configuration (config-if)  
 Template configuration (config-template)

Command History	Release	Modification
	Cisco IOS XE Everest 16.5.1a	This command was introduced.

## Usage Guidelines



**Caution** Be careful when you enter the **spanning-tree bpdudfilter enable** command. Enabling BPDU filtering on an interface is similar to disabling the spanning tree for this interface. If you do not use this command correctly, you might create bridging loops.

Entering the **spanning-tree bpdudfilter enable** command to enable BPDU filtering overrides the PortFast configuration.

When configuring Layer 2-protocol tunneling on all the service-provider edge switches, you must enable spanning-tree BPDU filtering on the 802.1Q tunnel ports by entering the **spanning-tree bpdudfilter enable** command.

BPDU filtering prevents a port from sending and receiving BPDUs. The configuration is applicable to the whole interface, whether it is trunking or not. This command has three states:

- **spanning-tree bpdudfilter enable**: Unconditionally enables BPDU filtering on the interface.
- **spanning-tree bpdudfilter disable**: Unconditionally disables BPDU filtering on the interface.
- **no spanning-tree bpdudfilter**: Enables BPDU filtering on the interface if the interface is in operational PortFast state and if you configure the **spanning-tree portfast bpdudfilter default** command.

Use the **spanning-tree portfast bpdudfilter default** command to enable BPDU filtering on all ports that are already configured for PortFast.



---

**Examples**

This example shows how to enable BPDU filtering on this interface:

```
Device(config-if) # spanning-tree bpdudfilter enable
Device(config-if) #
```

The following example shows how to enable BPDU filtering on an interface using interface template:

```
Device# configure terminal
Device(config) # template user-templatel
Device(config-template) # spanning-tree bpdudfilter enable
Device(config-template) # end
```

---

**Related Commands**

Command	Description
<b>show spanning-tree</b>	Displays information about the spanning-tree state.
<b>spanning-tree portfast edge bpdudfilter default</b>	Enables BPDU filtering by default on all PortFast ports.

# spanning-tree bpduguard

To enable bridge protocol data unit (BPDU) guard on the interface, use the **spanning-tree bpduguard** command in interface configuration and template configuration mode. To return to the default settings, use the **no** form of this command.

```
spanning-tree bpduguard { enable | disable }
no spanning-tree bpduguard
```

Syntax Description	enable	disable
	Enables BPDU guard on this interface.	Disables BPDU guard on this interface.

Command Modes	Interface configuration (config-if) Template configuration (config-template)
---------------	---

Command History	Release	Modification
	Cisco IOS XE Everest 16.5.1a	This command was introduced.

**Usage Guidelines** BPDU guard prevents a port from receiving BPDUs. Typically, this feature is used in a service-provider environment where the network administrator wants to prevent an access port from participating in the spanning tree. If the port still receives a BPDU, it is put in the error-disabled state as a protective measure. This command has three states:

- **spanning-tree bpduguard enable**: Unconditionally enables BPDU guard on the interface.
- **spanning-tree bpduguard disable**: Unconditionally disables BPDU guard on the interface.
- **no spanning-tree bpduguard**: Enables BPDU guard on the interface if it is in the operational PortFast state and if the **spanning-tree portfast bpduguard default** command is configured.

## Examples

This example shows how to enable BPDU guard on this interface:

```
Device(config-if)# spanning-tree bpduguard enable
Device(config-if)#
```

The following example shows how to enable BPDU guard on an interface using interface template:

```
Device# configure terminal
Device(config)# template user-templatel
Device(config-template)# spanning-tree bpduguard enable
Device(config-template)# end
```

Related Commands	Command	Description
	<b>show spanning-tree</b>	Displays information about the spanning-tree state.

Command	Description
<b>spanning-tree portfast edge bpduguard default</b>	Enables BPDU guard by default on all PortFast ports.

# spanning-tree bridge assurance

To enable bridge assurance on all network ports on the device, use the **spanning-tree bridge assurance** command in global configuration mode. To disable bridge assurance, use the **no** form of this command.

**spanning-tree bridge assurance**  
**no spanning-tree bridge assurance**

**Syntax Description** This command has no arguments or keywords.

**Command Default** Bridge assurance is enabled.

**Command Modes** Global configuration (config)

Command History	Release	Modification
	Cisco IOS XE Everest 16.5.1a	This command was introduced.

**Usage Guidelines** Bridge assurance protects against a unidirectional link failure or other software failure and a device that continues to forward data traffic when it is no longer running the spanning tree algorithm.

Bridge assurance is enabled only on spanning tree network ports that are point-to-point links. Both ends of the link must have bridge assurance enabled. If the device on one side of the link has bridge assurance enabled and the device on the other side either does not support bridge assurance or does not have this feature enabled, the connecting port is blocked.

Disabling bridge assurance causes all configured network ports to behave as normal spanning tree ports.

## Examples

This example shows how to enable bridge assurance on all network ports on the switch:

```
Device(config)#
spanning-tree bridge assurance
Device(config)#
```

This example shows how to disable bridge assurance on all network ports on the switch:

```
Device(config)#
no spanning-tree bridge assurance
Device(config)#
```

## Related Commands

Command	Description
<b>show spanning-tree</b>	Displays information about the spanning-tree state.

## spanning-tree cost

To set the path cost of the interface for Spanning Tree Protocol (STP) calculations, use the **spanning-tree cost** command in interface configuration or template configuration mode. To revert to the default value, use the **no** form of this command.

**spanning-tree cost** *cost*  
**no spanning-tree cost**

### Syntax Description

<i>cost</i>	Path cost. The range is from 1 to 200000000.
-------------	--

### Command Modes

Interface configuration (config-if)  
 Template configuration (config-template)

### Command History

Release	Modification
Cisco IOS XE Everest 16.5.1a	This command was introduced.

### Usage Guidelines

When you specify a value for the cost argument, higher values indicate higher costs. This range applies regardless of the protocol type specified.

If a loop occurs, spanning tree uses the path cost when selecting an interface to place into the forwarding state. A lower path cost represents higher-speed transmission.

### Examples

The following example shows how to access an interface and set a path cost value of 250 for the spanning tree VLAN associated with that interface:

```
Router(config)# interface ethernet 2/0
Router(config-if)# spanning-tree cost 250
```

The following example shows how to set a path cost value of 250 for the spanning tree VLAN associated with an interface using an interface template:

```
Device# configure terminal
Device(config)# template user-templatel
Device(config-template)# spanning-tree cost 250
Device(config-template)# end
```

### Related Commands

Command	Description
<b>show spanning-tree</b>	Displays spanning-tree information for the specified spanning-tree instances.
<b>spanning-tree port-priority</b>	Sets an interface priority when two bridges tie for position as the root bridge.

Command	Description
<b>spanning-tree portfast</b> (global)	Enables PortFast mode, where the interface is immediately put into the forwarding state upon linkup without waiting for the timer to expire.
<b>spanning-tree portfast</b> (interface)	Enables PortFast mode, where the interface is immediately put into the forwarding state upon linkup without waiting for the timer to expire.
<b>spanning-tree uplinkfast</b>	Enables the UplinkFast feature.
<b>spanning-tree vlan</b>	Configures STP on a per-VLAN basis.

# spanning-tree etherchannel guard misconfig

To display an error message when a loop due to a channel misconfiguration is detected, use the **spanning-tree etherchannel guard misconfig** command in global configuration mode. To disable the error message, use the **no** form of this command.

**spanning-tree etherchannel guard misconfig**  
**no spanning-tree etherchannel guard misconfig**

## Syntax Description

This command has no arguments or keywords.

## Command Default

Error messages are displayed.

## Command Modes

Global configuration (config)

## Command History

Release	Modification
Cisco IOS XE Everest 16.5.1a	This command was introduced.

## Usage Guidelines

EtherChannel uses either Port Aggregation Protocol (PAgP) or Link Aggregation Control Protocol (LACP) and does not work if the EtherChannel mode of the interface is enabled using the **channel-group** group-number mode on command.

The **spanning-tree etherchannel guard misconfig** command detects two types of errors: misconfiguration and misconnection errors. A misconfiguration error is an error between the port-channel and an individual port. A misconnection error is an error between a device that is channeling more ports and a device that is not using enough Spanning Tree Protocol (STP) Bridge Protocol Data Units (BPDUs) to detect the error. In this case, the device will only error disable an EtherChannel if the switch is a nonroot device.

When an EtherChannel-guard misconfiguration is detected, this error message displays:

```
msgdef(CHNL_MISCFG, SPANTREE, LOG_CRIT, 0, "Detected loop due to etherchannel misconfiguration of %s %s")
```

To determine which local ports are involved in the misconfiguration, enter the **show interfaces status err-disabled** command. To check the EtherChannel configuration on the remote device, enter the **show etherchannel summary** command on the remote device.

After you correct the configuration, enter the **shutdown** and the **no shutdown** commands on the associated port-channel interface.

## Examples

This example shows how to enable the EtherChannel-guard misconfiguration:

```
Device(config)# spanning-tree etherchannel guard misconfig
Device(config)#
```

## Related Commands

Command	Description
<b>show etherchannel summary</b>	Displays the EtherChannel information for a channel.

Command	Description
<b>show interfaces status err-disabled</b>	Displays the interface status or a list of interfaces in an error-disabled state on LAN ports only.
<b>shutdown</b>	Disables an interface.



## spanning-tree extend system-id

To enable the extended-system ID feature on chassis that support 1024 MAC addresses, use the **spanning-tree extend system-id** command in global configuration mode. To disable the extended system identification, use the **no** form of this command.

**spanning-tree extend system-id**  
**no spanning-tree extend system-id**

### Syntax Description

This command has no arguments or keywords.

### Command Default

Enabled on systems that do not provide 1024 MAC addresses.

### Command Modes

Global configuration (config)

### Command History

Release	Modification
Cisco IOS XE Everest 16.5.1a	This command was introduced.

### Usage Guidelines

Enabling or disabling the extended-system ID updates the bridge IDs of all active Spanning Tree Protocol (STP) instances, which might change the spanning-tree topology.

### Examples

This example shows how to enable the extended-system ID:

```
Device(config)# spanning-tree extend system-id
Device(config)#
```

### Related Commands

Command	Description
<b>show spanning-tree</b>	Displays information about the spanning-tree state.

## spanning-tree guard

To enable or disable the guard mode, use the **spanning-tree guard** command in interface configuration and template configuration mode. To return to the default settings, use the **no** form of this command.

```
spanning-tree guard { loop | root | none }
no spanning-tree guard
```

### Syntax Description

<b>loop</b>	Enables the loop-guard mode on the interface.
<b>root</b>	Enables root-guard mode on the interface.
<b>none</b>	Sets the guard mode to none.

### Command Default

Guard mode is disabled.

### Command Modes

Interface configuration (config-if)  
Template configuration (config-template)

### Command History

Release	Modification
Cisco IOS XE Everest 16.5.1a	This command was introduced.

### Examples

This example shows how to enable root guard:

```
Device(config-if)# spanning-tree guard root
Device(config-if)#
```

The following example shows how to enable root guard on an interface using an interface template:

```
Device# configure terminal
Device(config)# template user-templatel
Device(config-template)# spanning-tree guard root
Device(config-template)# end
```

### Related Commands

Command	Description
<b>show spanning-tree</b>	Displays information about the spanning-tree state.
<b>spanning-tree loopguard default</b>	Enables loop guard as a default on all ports of a given bridge.

# spanning-tree link-type

To configure a link type for a port, use the **spanning-tree link-type** command in the interface configuration and template configuration mode. To return to the default settings, use the **no** form of this command.

```
spanning-tree link-type { point-to-point | shared }
no spanning-tree link-type
```

Syntax Description	point-to-point	Specifies that the interface is a point-to-point link.
	shared	Specifies that the interface is a shared medium.

**Command Default** Link type is automatically derived from the duplex setting unless you explicitly configure the link type.

**Command Modes** Interface configuration (config-if)  
Template configuration (config-template)

Command History	Release	Modification
	Cisco IOS XE Everest 16.5.1a	This command was introduced.

**Usage Guidelines** Rapid Spanning Tree Protocol Plus (RSTP+) fast transition works only on point-to-point links between two bridges.

By default, the switch derives the link type of a port from the duplex mode. A full-duplex port is considered as a point-to-point link while a half-duplex configuration is assumed to be on a shared link.

If you designate a port as a shared link, RSTP+ fast transition is forbidden, regardless of the duplex setting.

If you connect a port (local port) to a remote port through a point-to-point link and the local port becomes a designated port, the device negotiates with the remote port and rapidly changes the local port to the forwarding state

## Examples

This example shows how to configure the port as a shared link:

```
Device(config-if)# spanning-tree link-type shared
Device(config-if)#
```

The following example shows how to configure the port as a shared link using an interface template:

```
Device# configure terminal
Device(config)# template user-templatel
Device(config-template)# spanning-tree link-type shared
Device(config-template)# end
```

---

**Related Commands**

<b>Command</b>	<b>Description</b>
<b>show spanning-tree interface</b>	Displays information about the spanning-tree state.

## spanning-tree loopguard default

To enable loop guard as a default on all ports of a given bridge, use the **spanning-tree loopguard default** command in global configuration mode. To disable loop guard, use the **no** form of this command.

**spanning-tree loopguard default**  
**no spanning-tree loopguard default**

**Syntax Description** This command has no arguments or keywords.

**Command Default** Loop guard is disabled.

**Command Modes** Global configuration (config)

Command History	Release	Modification
	Cisco IOS XE Everest 16.5.1a	This command was introduced.

**Usage Guidelines** Loop guard provides additional security in the bridge network. Loop guard prevents alternate or root ports from becoming the designated port due to a failure that could lead to a unidirectional link.

Loop guard operates only on ports that are considered point to point by the spanning tree.

The individual loop-guard port configuration overrides this command.

### Examples

This example shows how to enable loop guard:

```
Device(config)# spanning-tree loopguard default
Device(config)#
```

Related Commands	Command	Description
	<b>show spanning-tree</b>	Displays information about the spanning-tree state.
	<b>spanning-tree guard</b>	Enables or disables the guard mode.

# spanning-tree mode

To switch between Per-VLAN Spanning Tree+ (PVST+), Rapid-PVST+, and Multiple Spanning Tree (MST) modes, use the **spanning-tree mode** command in global configuration mode. To return to the default settings, use the **no** form of this command.

**spanning-tree mode** [{ **pvst** | **mst** | **rapid-pvst** }]  
**no spanning-tree mode**

Syntax Description		
	<b>pvst</b>	(Optional) PVST+ mode.
	<b>mst</b>	(Optional) MST mode.
	<b>rapid-pvst</b>	(Optional) Rapid-PVST+ mode.

**Command Default** pvst

**Command Modes** Global configuration (config)

Command History	Release	Modification
	Cisco IOS XE Everest 16.5.1a	This command was introduced.

## Usage Guidelines



**Note** Be careful when using the **spanning-tree mode** command to switch between PVST+, Rapid-PVST+, and MST modes. When you enter the command, all spanning-tree instances are stopped for the previous mode and are restarted in the new mode. Using this command may cause disruption of user traffic.

## Examples

This example shows how to switch to MST mode:

```
Device(config)# spanning-tree mode mst
Device(config)#
```

This example shows how to return to the default mode (PVST+):

```
Device(config)# no spanning-tree mode
Device(config)#
```

Related Commands	Command	Description
	<b>show spanning-tree mst</b>	Displays the information about the MST protocol.

## spanning-tree mst

To set the priority parameters or configure the device as a root for any Multiple Spanning Tree (MST) instance, use the **spanning-tree mst** command in interface configuration mode. To return to the default settings, use the **no** form of this command.

```
spanning-tree mst instance-id { priority priority | root { primary | secondary } }
no spanning-tree mst instance-id { { priority priority | root { primary | secondary } } }
```

Syntax Description		
<b>priority</b> <i>priority</i>	Port priority for an instance. The range is from 0 to 61440 in increments of 4096.	
<b>root</b>	Configures the device as a root.	

**Command Modes** Interface configuration (config-if)

Command History	Release	Modification
	Cisco IOS XE Everest 16.5.1a	This command was introduced.

### Examples

This example shows how to set the priority:

```
Device(config-if)#
spanning-tree mst 0 priority 1
Device(config-if)#
```

This example shows how to set the device as a primary root:

```
Device(config-if)#
spanning-tree mst 0 root primary
Device(config-if)#
```

Related Commands	Command	Description
	<b>show spanning-tree mst</b>	Displays the information about the MST protocol.

# spanning-tree mst configuration

To enter MST-configuration submode, use the **spanning-tree mst configuration** command in global configuration mode. To return to the default settings, use the **no** form of this command.

**spanning-tree mst configuration**  
**no spanning-tree mst configuration**

**Syntax Description** This command has no arguments or keywords.

**Command Default** The default value for the Multiple Spanning Tree (MST) configuration is the default value for all its parameters:

- No VLANs are mapped to any MST instance (all VLANs are mapped to the Common and Internal Spanning Tree [CIST] instance).
- The region name is an empty string.
- The revision number is 0.

**Command Modes** Global configuration (config)

Command History	Release	Modification
	Cisco IOS XE Everest 16.5.1a	This command was introduced.

**Usage Guidelines** The MST configuration consists of three main parameters:

- Instance VLAN mapping: See the **instance** command.
- Region name: See the **name** command (MST configuration submode).
- Configuration revision number: See the **revision** command.

The **abort** and **exit** commands allow you to exit MST configuration submode. The difference between the two commands depends on whether you want to save your changes or not.

The **exit** command commits all the changes before leaving MST configuration submode. If you do not map secondary VLANs to the same instance as the associated primary VLAN, when you exit MST-configuration submode, a warning message displays and lists the secondary VLANs that are not mapped to the same instance as the associated primary VLAN. The warning message is as follows:

```
These secondary vlans are not mapped to the same instance as their primary:
-> 3
```

The **abort** command leaves MST-configuration submode without committing any changes.

Changing an MST-configuration submode parameter can cause connectivity loss. To reduce service disruptions, when you enter MST-configuration submode, make changes to a copy of the current MST configuration. When you are done editing the configuration, you can apply all the changes at once by using the exit keyword, or you can exit the submode without committing any change to the configuration by using the abort keyword.

In the unlikely event that two users commit a new configuration at exactly at the same time, this warning message displays:



```
% MST CFG:Configuration change lost because of concurrent access
```

## Examples

This example shows how to enter MST-configuration submode:

```
Device(config)# spanning-tree mst configuration  
Device(config-mst)#
```

This example shows how to reset the MST configuration to the default settings:

```
Device(config)# no spanning-tree mst configuration  
Device(config)#
```

## Related Commands

Command	Description
<b>instance</b>	Maps a VLAN or a set of VLANs to an MST instance.
<b>name (MST)</b>	Sets the name of an MST region.
<b>revision</b>	Sets the revision number for the MST configuration.
<b>show spanning-tree mst</b>	Displays the information about the MST protocol.

## spanning-tree mst forward-time

To set the forward-delay timer for all the instances on the device, use the **spanning-tree mst forward-time** command in global configuration mode. To return to the default settings, use the **no** form of this command.

**spanning-tree mst forward-time** *seconds*  
**no spanning-tree mst forward-time**

<b>Syntax Description</b>	<i>seconds</i>	Number of seconds to set the forward-delay timer for all the instances on the device. The range is from 4 to 30 seconds.
<b>Command Default</b>	15 seconds.	
<b>Command Modes</b>	Global configuration (config)	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Everest 16.5.1a	This command was introduced.

### Examples

This example shows how to set the forward-delay timer:

```
Device(config)# spanning-tree mst forward-time 20
Device(config)#
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>show spanning-tree mst</b>	Displays the information about the MST protocol.

# spanning-tree mst hello-time

To set the hello-time delay timer for all the instances on the device, use the **spanning-tree mst hello-time** command in global configuration mode. To return to the default settings, use the **no** form of this command.

**spanning-tree mst hello-time** *seconds*  
**no spanning-tree mst hello-time**

<b>Syntax Description</b>	<i>seconds</i>	Number of seconds to set the hello-time delay timer for all the instances on the device. The range is from 1 to 10 in seconds.
---------------------------	----------------	--

**Command Default** 2 seconds

**Command Modes** Global configuration (config)

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Everest 16.5.1a	This command was introduced.

**Usage Guidelines** If you do not specify the *hello-time* value, the value is calculated from the network diameter.

**Examples** This example shows how to set the hello-time delay timer:

```
Device(config)# spanning-tree mst hello-time 3
Device(config)#
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>show spanning-tree mst</b>	Displays the information about the MST protocol.

## spanning-tree mst max-age

To set the max-age timer for all the instances on the device, use the **spanning-tree mst max-age** command in global configuration mode. To return to the default settings, use the **no** form of this command.

**spanning-tree mst max-age** *seconds*

**no spanning-tree mst max-age**

<b>Syntax Description</b>	<i>seconds</i>	Number of seconds to set the max-age timer for all the instances on the device. The range is from 6 to 40 in seconds.
---------------------------	----------------	---

**Command Default** 20 seconds

**Command Modes** Global configuration (config)

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Everest 16.5.1a	This command was introduced.

### Examples

This example shows how to set the max-age timer:

```
Device(config)# spanning-tree mst max-age 40
Device(config)#
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>show spanning-tree mst</b>	Displays the information about the MST protocol.

## spanning-tree mst max-hops

To specify the number of possible hops in the region before a bridge protocol data unit (BPDU) is discarded, use the **spanning-tree mst max-hops** command in global configuration mode. To return to the default settings, use the **no** form of this command.

**spanning-tree mst max-hops** *hopnumber*  
**no spanning-tree mst max-hops**

<b>Syntax Description</b>	<i>hopnumber</i>	Number of possible hops in the region before a BPDU is discarded. The range is from 1 to 255 hops.
<b>Command Default</b>	20 hops	
<b>Command Modes</b>	Global configuration (config)	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Everest 16.5.1a	This command was introduced.

### Examples

This example shows how to set the number of possible hops:

```
Device(config)# spanning-tree mst max-hops 25
Device(config)#
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>show spanning-tree mst</b>	Displays the information about the MST protocol.

# spanning-tree mst pre-standard

To configure a port to transmit only prestandard bridge protocol data units (BPDUs), use the **spanning-tree mst pre-standard** command in interface configuration mode. To return to the default settings, use the **no** form of this command.

**spanning-tree mst pre-standard**  
**no spanning-tree mst pre-standard**

**Syntax Description** This command has no arguments or keywords.

**Command Default** The default is to automatically detect prestandard neighbors.

**Command Modes** Interface configuration (config-if)

Command History	Release	Modification
	Cisco IOS XE Everest 16.5.1a	This command was introduced.

**Usage Guidelines** Even with the default configuration, the port can receive both prestandard and standard BPDUs. Prestandard BPDUs are based on the Cisco IOS Multiple Spanning Tree (MST) implementation that was created before the IEEE standard was finalized. Standard BPDUs are based on the finalized IEEE standard. If you configure a port to transmit prestandard BPDUs only, the prestandard flag displays in the **show spanning-tree** commands. The variations of the prestandard flag are as follows:

- Pre-STD (or pre-standard in long format): This flag displays if the port is configured to transmit prestandard BPDUs and if a prestandard neighbor bridge has been detected on this interface.
- Pre-STD-Cf (or pre-standard (config) in long format): This flag displays if the port is configured to transmit prestandard BPDUs but a prestandard BPDU has not been received on the port, the autodetection mechanism has failed, or a misconfiguration, if there is no prestandard neighbor, has occurred.
- Pre-STD-Rx (or pre-standard (revd) in long format): This flag displays when a prestandard BPDU has been received on the port but it has not been configured to send prestandard BPDUs. The port will send prestandard BPDUs, but we recommend that you change the port configuration so that the interaction with the prestandard neighbor does not rely only on the autodetection mechanism.

If the MST configuration is not compatible with the prestandard (if it includes an instance ID greater than 15), only standard MST BPDUs are transmitted, regardless of the STP configuration on the port.

## Examples

This example shows how to configure a port to transmit only prestandard BPDUs:

```
Router(config-if)# spanning-tree mst pre-standard
Router(config-if)#
```

**Related Commands**

Command	Description
show spanning-tree mst	Displays the information about the MST protocol.

# spanning-tree mst priority

To set the bridge priority for an instance, use the **spanning-tree mst priority** command in global configuration mode. To return to the default setting, use the **no** form of this command.

**spanning-tree mst** *instance* **priority** *priority*  
**no spanning-tree mst priority**

Syntax Description	Parameter	Description
	<i>instance</i>	Instance identification number; valid values are from 0 to 4094.
	<b>priority</b> <i>priority</i>	Specifies the bridge priority; see the “Usage Guidelines” section for valid values and additional information.

**Command Default** *priority* is **32768**

**Command Modes** Global configuration (config)

Command History	Release	Modification
	Cisco IOS XE Everest 16.5.1a	This command was introduced.

**Usage Guidelines** You can set the bridge priority in increments of 4096 only. When you set the priority, valid values are **0, 4096, 8192, 12288, 16384, 20480, 24576, 28672, 32768, 36864, 40960, 45056, 49152, 53248, 57344, and 61440.**

You can set the *priority* to **0** to make the switch root.

You can enter *instance* as a single instance or a range of instances, for example, 0-3,5,7-9.

## Examples

This example shows how to set the bridge priority:

```
Device(config)# spanning-tree mst 0 priority 4096
Device(config)#
```

Related Commands	Command	Description
	<b>show spanning-tree mst</b>	Displays the information about the MST protocol.



## spanning-tree mst root

To designate the primary and secondary root switch and set the timer value for an instance, use the **spanning-tree mst root** command in global configuration mode. To return to the default settings, use the **no** form of this command.

```
spanning-tree mst instance root { primary | secondary } [ diameter diameter [ hello-time seconds ] ]
no spanning-tree mst instance root
```

Syntax Description		
<i>instance</i>		Instance identification number. The range is from 0 to 4094.
<b>primary</b>		Specifies the high enough priority (low value) to make the root of the spanning-tree instance.
<b>secondary</b>		Specifies the switch as a secondary root, should the primary root fail.
<b>diameter</b> <i>diameter</i>		(Optional) Specifies the timer values for the root switch that are based on the network diameter. The range is from 1 to 7.
<b>hello-time</b> <i>seconds</i>		(Optional) Specifies the duration between the generation of configuration messages by the root switch.

**Command Default** The **spanning-tree mst root** command has no default settings.

**Command Modes** Global configuration (config)

Command History	Release	Modification
	Cisco IOS XE Everest 16.5.1a	This command was introduced.

**Usage Guidelines** You can enter *instance* as a single instance or a range of instances, for example, 0-3,5,7-9. The **spanning-tree mst root secondary** value is 16384. The **diameter** *diameter* and **hello-time** *seconds* keywords and arguments are available for instance 0 only. If you do not specify the *seconds* argument, the value for it is calculated from the network diameter.

**Examples** This example shows how to designate the primary root switch and timer values for an instance:

```
Router(config)# spanning-tree mst 0 root primary diameter 7 hello-time 2
Router(config)# spanning-tree mst 5 root primary
Router(config)#
```

Related Commands	Command	Description
	<b>show spanning-tree mst</b>	Displays the information about the MST protocol.

## spanning-tree mst simulate pvst global

To enable Per-VLAN Spanning Tree (PVST) simulation globally, enter the **spanning-tree mst simulate pvst global** command in global configuration mode. To disable PVST simulation globally, enter the **no** form of this command.

**spanning-tree mst simulate pvst global**  
**no spanning-tree mst simulate pvst global**

**Syntax Description** This command has no arguments or keywords.

**Command Default** PVST simulation is enabled.

**Command Modes** Global configuration (config)

Command History	Release	Modification
	Cisco IOS XE Everest 16.5.1a	Support for this command was introduced.

**Usage Guidelines** PVST simulation is enabled by default so that all interfaces on the device interoperate between Multiple Spanning Tree (MST) and Rapid Per-VLAN Spanning Tree Plus (PVST+). To prevent an accidental connection to a device that does not run MST as the default Spanning Tree Protocol (STP) mode, you can disable PVST simulation. If you disable PVST simulation, the MST-enabled port moves to the blocking state once it detects it is connected to a Rapid PVST+-enabled port. This port remains in the inconsistent state until the port stops receiving Bridge Protocol Data Units (BPDUs), and then the port resumes the normal STP transition process.

To override the global PVST simulation setting for a port, enter the **spanning-tree mst simulate pvst** interface command in the interface command mode.

### Examples

This example shows how to prevent the switch from automatically interoperating with a connecting device that is running Rapid PVST+:

```
Device(config)#
no spanning-tree mst simulate pvst global
Device(config)#
```

### Related Commands

Command	Description
<b>show spanning-tree mst</b>	Displays the information about the MST protocol.

# spanning-tree pathcost method

To set the default path-cost calculation method, use the **spanning-tree pathcost method** command in global configuration mode. To return to the default settings, use the **no** form of this command.

**spanning-tree pathcost method { long | short }**  
**no spanning-tree pathcost method**

## Syntax Description

<b>long</b>	Specifies the 32-bit based values for default port-path costs.
<b>short</b>	Specifies the 16-bit based values for default port-path costs.

## Command Default

**short**

## Command Modes

Global configuration (config)

## Command History

Release	Modification
Cisco IOS XE Everest 16.5.1a	This command was introduced.

## Usage Guidelines

The **long** path-cost calculation method utilizes all 32 bits for path-cost calculation and yields values in the range of 1 through 200,000,000.

The **short** path-cost calculation method (16 bits) yields values in the range of 1 through 65535.

## Examples

This example shows how to set the default path-cost calculation method to long:

```
Device(config)
#) spanning-tree pathcost method long
Device(config)
#)
```

This example shows how to set the default path-cost calculation method to short:

```
Device(config)
#) spanning-tree pathcost method short
Device(config)
#)
```

## Related Commands

Command	Description
<b>show spanning-tree</b>	Displays information about the spanning-tree state.

# spanning-tree port-priority

To set an interface priority when two bridges tie for position as the root bridge, use the **spanning-tree port-priority** command in interface configuration and template configuration mode. To revert to the default value, use the **no** form of this command.

**spanning-tree port-priority** *port-priority*  
**no spanning-tree port-priority**

<b>Syntax Description</b>	<i>port-priority</i> Port priority. The range is from 0 to 240 in increments of 16 . The default is 128.
---------------------------	--

**Command Default** The default port priority is 128.

**Command Modes** Interface configuration (config-if)  
 Template configuration (config-if)

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Everest 16.5.1a	This command was introduced.

**Usage Guidelines** The priority you set breaks the tie between two bridges to be designated as a root bridge.

## Examples

The following example shows how to increase the likelihood that spanning-tree instance 20 is chosen as the root-bridge on interface Ethernet 2/0:

```
Device(config)# interface ethernet 2/0
Device(config-if)# spanning-tree port-priority 20
Device(config-if)#
```

The following example shows how increase the likelihood that spanning-tree instance 20 is chosen as the root-bridge on an interface using an interface template:

```
Device# configure terminal
Device(config)# template user-templatel
Device(config-template)# spanning-tree port-priority 20
Device(config-template)# end
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>show spanning-tree</b>	Displays spanning-tree information for the specified spanning-tree instances.
	<b>spanning-tree cost</b>	Sets the path cost of the interface for STP calculations.
	<b>spanning-tree portfast</b> (global)	Enables PortFast mode, where the interface is immediately put into the forwarding state upon linkup without waiting for the timer to expire.

Command	Description
spanning-tree uplinkfast	Enables the UplinkFast feature.
spanning-tree vlan	Configures STP on a per-VLAN basis.

# spanning-tree portfast edge bpdudfilter default

To enable bridge protocol data unit (BPDU) filtering by default on all PortFast ports, use the **spanning-tree portfast edge bpdudfilter default** command in global configuration mode. To return to the default settings, use the **no** form of this command.

**spanning-tree portfast edge bpdudfilter default**  
**no spanning-tree portfast edge bpdudfilter default**

**Syntax Description** This command has no arguments or keywords.

**Command Default** Disabled

**Command Modes** Global configuration (config)

Command History	Release	Modification
	Cisco IOS XE Everest 16.5.1a	This command was introduced.

**Usage Guidelines** The **spanning-tree portfast edge bpdudfilter** command enables BPDU filtering globally on PortFast ports. BPDU filtering prevents a port from sending or receiving any BPDUs.

You can override the effects of the **portfast edge bpdudfilter default** command by configuring BPDU filtering at the interface level.



**Note** Be careful when enabling BPDU filtering. The feature's functionality is different when you enable it on a per-port basis or globally. When enabled globally, BPDU filtering is applied only on ports that are in an operational PortFast state. Ports send a few BPDUs at linkup before they effectively filter outbound BPDUs. If a BPDU is received on an edge port, it immediately loses its operational PortFast status and BPDU filtering is disabled. When enabled locally on a port, BPDU filtering prevents the device from receiving or sending BPDUs on this port.



**Caution** Be careful when using this command. Using this command incorrectly can cause bridging loops.

## Examples

This example shows how to enable BPDU filtering by default:

```
Device(config)#
spanning-tree portfast edge bpdudfilter default
Device(config)#
```

## Related Commands

Command	Description
<b>show spanning-tree mst</b>	Displays the information about the MST protocol.

Command	Description
spanning-tree bpdudfilter	Enables BPDU filtering on the interface.

# spanning-tree portfast edge bpduguard default

To enable bridge protocol data unit (BPDU) guard by default on all PortFast ports, use the **spanning-tree portfast edge bpduguard default** command in global configuration mode. To return to the default settings, use the **no** form of this command.

**spanning-tree portfast edge bpduguard default**  
**no spanning-tree portfast edge bpduguard default**

**Syntax Description** This command has no arguments or keywords.

**Command Default** Disabled

**Command Modes** Global configuration (config)

Command History	Release	Modification
	Cisco IOS XE Everest 16.5.1a	This command was introduced.

## Usage Guidelines



**Caution** Be careful when using this command. You should use this command only with interfaces that connect to end stations; otherwise, an accidental topology loop could cause a data-packet loop and disrupt the device and network operation.

BPDU guard disables a port if it receives a BPDU. BPDU guard is applied only on ports that are PortFast enabled and are in an operational PortFast state.

## Examples

This example shows how to enable BPDU guard by default:

```
Device(config)#
spanning-tree portfast edge bpduguard default
Device(config)#
```

## Related Commands

Command	Description
<b>show spanning-tree mst</b>	Displays the information about the MST protocol.
<b>spanning-tree bpdupfilter</b>	Enables BPDU filtering on the interface.



## spanning-tree portfast default

To enable PortFast by default on all access ports, use the **spanning-tree portfast** {**edge** | **network** | **normal**} **default** command in global configuration mode. To disable PortFast by default on all access ports, use the **no** form of this command.

```
spanning-tree portfast { edge [{ bpdufilter | bpduguard }] | network | normal } default
no spanning-tree portfast { edge [{ bpdufilter | bpduguard }] | network | normal } default
```

Syntax Description	Parameter	Description
	<b>bpdufilter</b>	Enables PortFast edge BPDU filter by default on all PortFast edge ports.
	<b>bpduguard</b>	Enables PortFast edge BPDU guard by default on all PortFast edge ports.
	<b>edge</b>	Enables PortFast edge mode by default on all switch access ports.
	<b>network</b>	Enables PortFast network mode by default on all switch access ports.
	<b>normal</b>	Enables PortFast normal mode by default on all switch access ports.

**Command Default** PortFast is disabled by default on all access ports.

**Command Modes** Global configuration (config)

Release	Modification
Cisco IOS XE Everest 16.5.1a	This command was introduced.

### Usage Guidelines



**Note** Be careful when using this command. You should use this command only with interfaces that connect to end stations; otherwise, an accidental topology loop could cause a data-packet loop and disrupt the operation of the router or switch and the network.

An interface with PortFast mode enabled is moved directly to the spanning-tree forwarding state when linkup occurs without waiting for the standard forward-time delay.

You can enable PortFast mode on individual interfaces using the **spanning-tree portfast** (interface) command.

### Examples

This example shows how to enable PortFast edge mode with BPDU Guard by default on all access ports:

```
Device(config)#
spanning-tree portfast edge bpduguard default
Device(config)#
```

**Related Commands**

<b>Command</b>	<b>Description</b>
<b>show spanning-tree</b>	Displays information about the spanning-tree state.
<b>spanning-tree portfast (interface)</b>	Enables PortFast on a specific interface.

# spanning-tree transmit hold-count

To specify the transmit hold count, use the **spanning-tree transmit hold-count** command in global configuration mode. To return to the default settings, use the **no** form of this command.

**spanning-tree transmit hold-count** *value*  
**no spanning-tree transmit hold-count**

<b>Syntax Description</b>	<i>value</i>	Number of bridge protocol data units (BPDUs) that can be sent before pausing for 1 second. The range is from 1 to 20.
---------------------------	--------------	---

**Command Default** *value* is **6**

**Command Modes** Global configuration (config)

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Everest 16.5.1a	This command was introduced.

**Usage Guidelines** This command is supported on all spanning-tree modes.  
 The transmit hold count determines the number of BPDUs that can be sent before pausing for 1 second.



**Note** Changing this parameter to a higher value may have a significant impact on CPU utilization, especially in rapid-Per-VLAN Spanning Tree (PVST) mode. Lowering this parameter could slow convergence in some scenarios. We recommend that you do not change the value from the default setting.

If you change the *value* setting, enter the **show running-config** command to verify the change.

If you delete the command, use the **show spanning-tree mst** command to verify the deletion.

## Examples

This example shows how to specify the transmit hold count:

```
Device(config)# spanning-tree transmit hold-count 8
Device(config)#
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>show running-config</b>	Displays the status and configuration of the module or Layer 2 VLAN.
	<b>show spanning-tree mst</b>	Display the information about the MST protocol.

# spanning-tree uplinkfast

To enable UplinkFast, use the **spanning-tree uplinkfast** command in global configuration mode. To disable UplinkFast, use the **no** form of this command.

**spanning-tree uplinkfast** [**max-update-rate** *packets-per-second* ]  
**no spanning-tree uplinkfast** [**max-update-rate**]

## Syntax Description

<b>max-update-rate</b> <i>packets-per-second</i>	(Optional) Specifies the maximum rate (in packets per second) at which update packets are sent. The range is from 0 to 32000.
--	---

## Command Default

The defaults are as follows:

- UplinkFast is disabled.
- *packets-per-second* is 150 packets per second.

## Command Modes

Global configuration (config)

## Command History

Release	Modification
Cisco IOS XE Everest 16.5.1a	This command was introduced.

## Usage Guidelines

Use the **spanning-tree uplinkfast max-update-rate** command to enable UplinkFast (if it is not already enabled) and change the rate at which update packets are sent. Use the **no** form of this command to return to the default rate.

## Examples

This example shows how to enable UplinkFast and set the maximum rate to 200 packets per second:

```
Device(config)#
 spanning-tree uplinkfast max-update-rate 200
Device(config)#
```

## Related Commands

Command	Description
<b>show spanning-tree</b>	Displays information about the spanning-tree state.

## spanning-tree vlan

To configure Spanning Tree Protocol (STP) on a per-virtual LAN (VLAN) basis, use the **spanning-tree vlan** command in global configuration mode. To return to the default settings, use the **no** form of this command.

```
spanning-tree vlan vlan-id [{ forward-time seconds | hello-time seconds | max-age seconds | priority
priority | root [{ primary | secondary }]]]
no spanning-tree vlan vlan-id [{ forward-time | hello-time | max-age | priority | root }]
```

### Syntax Description

<i>vlan id</i>	VLAN identification number. The range is from 1 to 4094.
<b>forward-time</b> <i>seconds</i>	(Optional) Sets the STP forward delay time. The range is from 4 to 30 seconds.
<b>hello-time</b> <i>seconds</i>	(Optional) Specifies the duration, in seconds, between the generation of configuration messages by the root switch. The range is from 1 to 10 seconds.
<b>max-age</b> <i>seconds</i>	(Optional) Sets the maximum number of seconds the information in a bridge packet data unit (BPDU) is valid. the range is from 6 to 40 seconds.
<b>priority</b> <i>priority</i>	(Optional) Sets the STP bridge priority. the range is from 0 to 65535.
<b>root primary</b>	(Optional) Forces this switch to be the root bridge.
<b>root secondary</b>	(Optional) Specifies this switch to act as the root switch should the primary root fail.

### Command Default

The defaults are:

- **forward-time**: 15 seconds
- **hello-time**: 2 seconds
- **max-age**: 20 seconds
- **priority**: The default with IEEE STP enabled is 32768; the default with STP enabled is 128.
- **root** : No STP root

When you issue the **no spanning-tree vlan** *vlan\_id* command, the following parameters are reset to their defaults:

- **priority**: The default with IEEE STP enabled is 32768; the default with STP enabled is 128.
- **hello-time**: 2 seconds
- **forward-time**: 15 seconds
- **max-age**: 20 seconds

### Command Modes

Global configuration (config)

Release	Modification
Cisco IOS XE Everest 16.5.1a	This command was introduced.

## Usage Guidelines



### Caution

- When disabling spanning tree on a VLAN using the **no spanning-tree vlan *vlan-id*** command, ensure that all switches and bridges in the VLAN have spanning tree disabled. You cannot disable spanning tree on some switches and bridges in a VLAN and leave it enabled on other switches and bridges in the same VLAN because switches and bridges with spanning tree enabled have incomplete information about the physical topology of the network.
- We do not recommend disabling spanning tree, even in a topology that is free of physical loops. Spanning tree is a safeguard against misconfigurations and cabling errors. Do not disable spanning tree in a VLAN without ensuring that there are no physical loops present in the VLAN.

When you set the **max-age *seconds*** parameter, if a bridge does not hear bridge protocol data units (BPDUs) from the root bridge within the specified interval, it assumes that the network has changed and recomputes the spanning-tree topology.

The **spanning-tree root primary** command alters this switch's bridge priority to 8192. If you enter the **spanning-tree root primary** command and the switch does not become the root switch, then the bridge priority is changed to 100 less than the bridge priority of the current bridge. If the switch still does not become the root, an error results.

The **spanning-tree root secondary** command alters this switch's bridge priority to 16384. If the root switch should fail, this switch becomes the next root switch.

Use the **spanning-tree root** commands on backbone switches only.

The **spanning-tree etherchannel guard misconfig** command detects two types of errors: misconfiguration and misconnection errors. A misconfiguration error is an error between the port-channel and an individual port. A misconnection error is an error between a switch that is channeling more ports and a switch that is not using enough Spanning Tree Protocol (STP) Bridge Protocol Data Units (BPDUs) to detect the error. In this case, the switch will only error disable an EtherChannel if the switch is a nonroot switch.

## Examples

The following example shows how to enable spanning tree on VLAN 200:

```
Device(config)# spanning-tree vlan 200
```

The following example shows how to configure the switch as the root switch for VLAN 10 with a network diameter of 4:

```
Device(config)# spanning-tree vlan 10 root primary diameter 4
```

The following example shows how to configure the switch as the secondary root switch for VLAN 10 with a network diameter of 4:

```
Device(config)# spanning-tree vlan 10 root secondary diameter 4
```

**Related Commands**

<b>Command</b>	<b>Description</b>
<b>spanning-tree cost</b>	Sets the path cost of the interface for STP calculations.
<b>spanning-tree etherchannel guard misconfig</b>	Displays an error message when a loop due to a channel misconfiguration is detected
<b>spanning-tree port-priority</b>	Sets an interface priority when two bridges tie for position as the root bridge.
<b>spanning-tree uplinkfast</b>	Enables the UplinkFast feature.
<b>show spanning-tree</b>	Displays spanning-tree information for the specified spanning-tree instances.

# switchport

To put an interface that is in Layer 3 mode into Layer 2 mode for Layer 2 configuration, use the **switchport** command in interface configuration mode. To put an interface in Layer 3 mode, use the **no** form of this command.

**switchport**  
**no switchport**

**Command Default** By default, all interfaces are in Layer 2 mode.

**Command Modes** Interface configuration

Command History	Release	Modification
	Cisco IOS XE Everest 16.5.1a	This command was introduced.

**Usage Guidelines** Use the **no switchport** command (without parameters) to set the interface to the routed-interface status and to erase all Layer 2 configurations. You must use this command before assigning an IP address to a routed port.

Entering the **no switchport** command shuts the port down and then reenables it, which might generate messages on the device to which the port is connected.

When you put an interface that is in Layer 2 mode into Layer 3 mode (or the reverse), the previous configuration information related to the affected interface might be lost, and the interface is returned to its default configuration.



**Note** If an interface is configured as a Layer 3 interface, you must first enter the **switchport** command to configure the interface as a Layer 2 port. Then you can enter the **switchport access vlan** and **switchport mode** commands.

The **switchport** command is not used on platforms that do not support Cisco-routed ports. All physical ports on such platforms are assumed to be Layer 2-switched interfaces.

You can verify the port status of an interface by entering the **show running-config** privileged EXEC command.

## Examples

This example shows how to cause an interface to cease operating as a Layer 2 port and become a Cisco-routed port:

```
Device> enable
Device# configure terminal
Device(config)# interface gigabitethernet2/0/1
Device(config-if)# no switchport
```

This example shows how to cause the port interface to cease operating as a Cisco-routed port and convert to a Layer 2 switched interface:

```
Device> enable
Device# configure terminal
Device(config)# interface gigabitethernet2/0/1
Device(config-if)# switchport
```



# switchport access vlan

To configure a port as a static-access port, use the **switchport access vlan** command in interface configuration mode. To reset the access mode to the default VLAN mode for the device, use the **no** form of this command.

```
switchport access vlan {vlan-id }
no switchport access vlan
```

## Syntax Description

*vlan-id* VLAN ID of the access mode VLAN; the range is 1 to 4094.

## Command Default

The default access VLAN and trunk interface native VLAN is a default VLAN corresponding to the platform or interface hardware.

## Command Modes

Interface configuration

## Command History

Release	Modification
Cisco IOS XE Everest 16.5.1a	This command was introduced.

## Usage Guidelines

The port must be in access mode before the **switchport access vlan** command can take effect.

If the switchport mode is set to **access vlan** *vlan-id*, the port operates as a member of the specified VLAN. An access port can be assigned to only one VLAN.

The **no switchport access** command resets the access mode VLAN to the appropriate default VLAN for the device.

## Examples

This example shows how to change a switched port interface that is operating in access mode to operate in VLAN 2 instead of the default VLAN:

```
Device> enable
Device# configure terminal
Device(config)# interface gigabitethernet2/0/1
Device(config-if)# switchport access vlan 2
```

## switchport mode

To configure the VLAN membership mode of a port, use the **switchport mode** command in interface configuration mode. To reset the mode to the appropriate default for the device, use the **no** form of this command.

```
switchport mode {access | dynamic | {auto | desirable} | trunk}
noswitchport mode {access | dynamic | {auto | desirable} | trunk}
```

Syntax Description		
<b>access</b>	Sets the port to access mode (either static-access or dynamic-access depending on the setting of the <b>switchport access vlan</b> interface configuration command). The port is set to access unconditionally and operates as a nontrunking, single VLAN interface that sends and receives nonencapsulated (non-tagged) frames. An access port can be assigned to only one VLAN.	
<b>dynamic auto</b>	Sets the port trunking mode dynamic parameter to auto to specify that the interface convert the link to a trunk link. This is the default switchport mode.	
<b>dynamic desirable</b>	Sets the port trunking mode dynamic parameter to desirable to specify that the interface actively attempt to convert the link to a trunk link.	
<b>trunk</b>	Sets the port to trunk unconditionally. The port is a trunking VLAN Layer 2 interface. The port sends and receives encapsulated (tagged) frames that identify the VLAN of origination. A trunk is a point-to-point link between two switches or between a switch and a router.	

**Command Default** The default mode is **dynamic auto**.

**Command Modes** Interface configuration

Command History	Release	Modification
	Cisco IOS XE Everest 16.5.1a	This command was introduced.

**Usage Guidelines** A configuration that uses the **access**, or **trunk** keywords takes effect only when you configure the port in the appropriate mode by using the **switchport mode** command. The static-access and trunk configuration are saved, but only one configuration is active at a time.

When you enter **access** mode, the interface changes to permanent nontrunking mode and negotiates to convert the link into a nontrunk link even if the neighboring interface does not agree to the change.

When you enter **trunk** mode, the interface changes to permanent trunking mode and negotiates to convert the link into a trunk link even if the interface connecting to it does not agree to the change.

When you enter **dynamic auto** mode, the interface converts the link to a trunk link if the neighboring interface is set to **trunk** or **desirable** mode.

When you enter **dynamic desirable** mode, the interface becomes a trunk interface if the neighboring interface is set to **trunk**, **desirable**, or **auto** mode.

To autonegotiate trunking, the interfaces must be in the same VLAN Trunking Protocol (VTP) domain. Trunk negotiation is managed by the Dynamic Trunking Protocol (DTP), which is a point-to-point protocol. However, some internetworking devices might forward DTP frames improperly, which could cause misconfigurations. To avoid this problem, configure interfaces connected to devices that do not support DTP to not forward DTP frames, which turns off DTP.

- If you do not intend to trunk across those links, use the **switchport mode access** command in interface configuration mode to disable trunking.
- To enable trunking to a device that does not support DTP, use the **switchport mode trunk** and **switchport nonegotiate** commands in interface configuration mode to cause the interface to become a trunk but to not generate DTP frames.

Access ports and trunk ports are mutually exclusive.

The IEEE 802.1x feature interacts with switchport modes in these ways:

- If you try to enable IEEE 802.1x on a trunk port, an error message appears, and IEEE 802.1x is not enabled. If you try to change the mode of an IEEE 802.1x-enabled port to trunk, the port mode is not changed.
- If you try to enable IEEE 802.1x on a port set to **dynamic auto** or **dynamic desirable**, an error message appears, and IEEE 802.1x is not enabled. If you try to change the mode of an IEEE 802.1x-enabled port to **dynamic auto** or **dynamic desirable**, the port mode is not changed.
- If you try to enable IEEE 802.1x on a dynamic-access (VLAN Query Protocol [VQP]) port, an error message appears, and IEEE 802.1x is not enabled. If you try to change an IEEE 802.1x-enabled port to dynamic VLAN assignment, an error message appears, and the VLAN configuration is not changed.

You can verify your settings by entering the **show interfaces interface-id switchport** command in privileged EXEC mode and examining information in the *Administrative Mode* and *Operational Mode* rows.

## Examples

This example shows how to configure a port for access mode:

```
Device> enable
Device# configure terminal
Device(config)# interface gigabitethernet2/0/1
Device(config-if)# switchport mode access
```

This example shows how set the port to dynamic desirable mode:

```
Device> enable
Device# configure terminal
Device(config)# interface gigabitethernet2/0/1
Device(config-if)# switchport mode dynamic desirable
```

This example shows how to configure a port for trunk mode:

```
Device> enable
Device# configure terminal
Device(config)# interface gigabitethernet2/0/1
Device(config-if)# switchport mode trunk
```

# switchport nonegotiate

To specify that Dynamic Trunking Protocol (DTP) negotiation packets are not sent on the Layer 2 interface, use the **switchport nonegotiate** command in interface configuration mode. Use the **no** form of this command to return to the default setting.

**switchport nonegotiate**  
**no switchport nonegotiate**

**Command Default** The default is to use DTP negotiation to learn the trunking status.

**Command Modes** Interface configuration

Command History	Release	Modification
	Cisco IOS XE Everest 16.5.1a	This command was introduced.

**Usage Guidelines** The **no switchport nonegotiate** command removes nonegotiate status.

This command is valid only when the interface switchport mode is access or trunk (configured by using the **switchport mode access** or the **switchport mode trunk** interface configuration command). This command returns an error if you attempt to execute it in dynamic (auto or desirable) mode.

Internetworking devices that do not support DTP might forward DTP frames improperly and cause misconfigurations. To avoid this problem, turn off DTP by using the **switchport nonegotiate** command to configure the interfaces connected to devices that do not support DTP to not forward DTP frames.

When you enter the **switchport nonegotiate** command, DTP negotiation packets are not sent on the interface. The device does or does not trunk according to the **mode** parameter: **access** or **trunk**.

- If you do not intend to trunk across those links, use the **switchport mode access** interface configuration command to disable trunking.
- To enable trunking on a device that does not support DTP, use the **switchport mode trunk** and **switchport nonegotiate** interface configuration commands to cause the interface to become a trunk but to not generate DTP frames.

This example shows how to cause a port to refrain from negotiating trunking mode and to act as a trunk or access port (depending on the mode set):

```
Device> enable
Device# configure terminal
Device(config)# interface gigabitethernet2/0/1
Device(config-if)# switchport nonegotiate
```

You can verify your setting by entering the **show interfaces interface-id switchport** command in privileged EXEC mode.

# switchport trunk

To set the trunk characteristics when the interface is in trunking mode, use the **switchport trunk** command in interface configuration mode. To reset a trunking characteristic to the default, use the **no** form of this command.



**Note** The keyword **native vlan tag** is supported only on Cisco Catalyst 9500 Series Switches - High Performance.

```
switchport trunk {allowed vlan vlan-list | native vlan {tag | vlan-id} | pruning vlan vlan-list}
no switchport trunk {allowed vlan | native vlan [tag] | pruning vlan}
```

## Syntax Description

<b>allowed vlan</b> <i>vlan-list</i>	Sets the list of allowed VLANs that can receive and send traffic on this interface in tagged format when in trunking mode. See the Usage Guidelines for the <i>vlan-list</i> choices.
<b>native vlan</b> <i>vlan-id</i>	Sets the native VLAN for sending and receiving untagged traffic when the interface is in IEEE 802.1Q trunking mode. The range is 1 to 4094.
<b>native vlan tag</b>	Enables native VLAN tagging on a particular trunk port.
<b>pruning vlan</b> <i>vlan-list</i>	Sets the list of VLANs that are eligible for VTP pruning when in trunking mode. See the Usage Guidelines for the <i>vlan-list</i> choices.

## Command Default

VLAN 1 is the default native VLAN ID on the port.  
The default for all VLAN lists is to include all VLANs.

## Command Modes

Interface configuration

## Command History

Release	Modification
Cisco IOS XE Everest 16.5.1a	This command was introduced.
Cisco IOS XE Gibraltar 16.11.1	This command was modified. The keyword <b>native vlan tag</b> was added for Cisco Catalyst 9500 High Performance series of switches.

## Usage Guidelines

The *vlan-list* format is **all** | **none** | [**add** | **remove** | **except**] *vlan-atom* [,*vlan-atom*...]:

- **all** specifies all VLANs from 1 to 4094. This is the default. This keyword is not allowed on commands that do not permit all VLANs in the list to be set at the same time.
- **none** specifies an empty list. This keyword is not allowed on commands that require certain VLANs to be set or at least one VLAN to be set.
- **add** adds the defined list of VLANs to those currently set instead of replacing the list. Valid IDs are from 1 to 1005; extended-range VLANs (VLAN IDs greater than 1005) are valid in some cases.




---

**Note** You can add extended-range VLANs to the allowed VLAN list, but not to the pruning-eligible VLAN list.

---

Separate nonconsecutive VLAN IDs with a comma; use a hyphen to designate a range of IDs.

- **remove** removes the defined list of VLANs from those currently set instead of replacing the list. Valid IDs are from 1 to 1005; extended-range VLAN IDs are valid in some cases.




---

**Note** You can remove extended-range VLANs from the allowed VLAN list, but you cannot remove them from the pruning-eligible list.

---

- **except** lists the VLANs that should be calculated by inverting the defined list of VLANs. (VLANs are added except the ones specified.) Valid IDs are from 1 to 1005. Separate nonconsecutive VLAN IDs with a comma; use a hyphen to designate a range of IDs.
- *vlan-atom* is either a single VLAN number from 1 to 4094 or a continuous range of VLANs described by two VLAN numbers, the lesser one first, separated by a hyphen.

Native VLANs:

- All untagged traffic received on an IEEE 802.1Q trunk port is forwarded with the native VLAN configured for the port.
- If a packet has a VLAN ID that is the same as the sending-port native VLAN ID, the packet is sent without a tag; otherwise, the switch sends the packet with a tag.
- **vlan dot1q tag native** global command needs to be enabled to execute the **switchport trunk native vlan tag** command.
- The **no** form of the **native vlan** command resets the native mode VLAN to the appropriate default VLAN for the device.

Allowed VLAN:

- To reduce the risk of spanning-tree loops or storms, you can disable VLAN 1 on any individual VLAN trunk port by removing VLAN 1 from the allowed list. When you remove VLAN 1 from a trunk port, the interface continues to send and receive management traffic, for example, Cisco Discovery Protocol (CDP), Port Aggregation Protocol (PAgP), Link Aggregation Control Protocol (LACP), Dynamic Trunking Protocol (DTP), and VLAN Trunking Protocol (VTP) in VLAN 1.
- The **no** form of the **allowed vlan** command resets the list to the default list, which allows all VLANs.

Trunk pruning:

- The pruning-eligible list applies only to trunk ports.
- Each trunk port has its own eligibility list.
- If you do not want a VLAN to be pruned, remove it from the pruning-eligible list. VLANs that are pruning-ineligible receive flooded traffic.
- VLAN 1, VLANs 1002 to 1005, and extended-range VLANs (VLANs 1006 to 4094) cannot be pruned.

This example shows how to enable native VLAN tagging on a trunk port:

```
Device> enable
Device(config)# interface HundredGigE 1/0/45
Device(config-if)# switchport trunk native vlan tag
```

This example shows how to configure VLAN 3 as the default for the port to send all untagged traffic:

```
Device> enable
Device(config)# interface gigabitethernet1/0/2
Device(config-if)# switchport trunk native vlan 3
```

This example shows how to add VLANs 1, 2, 5, and 6 to the allowed list:

```
Device> enable
Device(config)# interface gigabitethernet1/0/2
Device(config-if)# switchport trunk allowed vlan add 1,2,5,6
```

This example shows how to remove VLANs 3 and 10 to 15 from the pruning-eligible list:

```
Device> enable
Device(config)# interface gigabitethernet1/0/2
Device(config-if)# switchport trunk pruning vlan remove 3,10-15
```

You can verify your settings by entering the **show interfaces** *interface-id* **switchport** privileged EXEC command.

## switchport voice vlan

To configure voice VLAN on the port, use the **switchport voice vlan** command in interface configuration mode. To return to the default setting, use the **no** form of this command.

**switchport voice vlan** {*vlan-id* | **dot1p** | **none** | **untagged** | **name** *vlan\_name*}  
**no switchport voice vlan**

Syntax Description		
<i>vlan-id</i>		The VLAN to be used for voice traffic. The range is 1 to 4094. By default, the IP phone forwards the voice traffic with an IEEE 802.1Q priority of 5.
<b>dot1p</b>		Configures the telephone to use IEEE 802.1p priority tagging and uses VLAN 0 (the native VLAN). By default, the Cisco IP phone forwards the voice traffic with an IEEE 802.1p priority of 5.
<b>none</b>		Does not instruct the IP telephone about the voice VLAN. The telephone uses the configuration from the telephone key pad.
<b>untagged</b>		Configures the telephone to send untagged voice traffic. This is the default for the telephone.
<b>name</b> <i>vlan_name</i>	(Optional)	Specifies the VLAN name to be used for voice traffic. You can enter up to 128 characters.

**Command Default** The default is not to automatically configure the telephone (**none**).  
 The telephone default is not to tag frames.

**Command Modes** Interface configuration

Command History	Release	Modification
	Cisco IOS XE Everest 16.5.1a	This command was introduced.

**Usage Guidelines** You should configure voice VLAN on Layer 2 access ports.

You must enable Cisco Discovery Protocol (CDP) on the switch port connected to the Cisco IP phone for the device to send configuration information to the phone. CDP is enabled by default globally and on the interface.

When you enter a VLAN ID, the IP phone forwards voice traffic in IEEE 802.1Q frames, tagged with the specified VLAN ID. The device puts IEEE 802.1Q voice traffic in the voice VLAN.

When you select **dot1p**, **none**, or **untagged**, the device puts the indicated voice traffic in the access VLAN.

In all configurations, the voice traffic carries a Layer 2 IP precedence value. The default is 5 for voice traffic.

When you enable port security on an interface that is also configured with a voice VLAN, set the maximum allowed secure addresses on the port to 2. When the port is connected to a Cisco IP phone, the IP phone requires one MAC address. The Cisco IP phone address is learned on the voice VLAN, but not on the access VLAN. If you connect a single PC to the Cisco IP phone, no additional MAC addresses are required. If you connect more than one PC to the Cisco IP phone, you must configure enough secure addresses to allow one for each PC and one for the Cisco IP phone.



If any type of port security is enabled on the access VLAN, dynamic port security is automatically enabled on the voice VLAN.

You cannot configure static secure MAC addresses in the voice VLAN.

The Port Fast feature is automatically enabled when voice VLAN is configured. When you disable voice VLAN, the Port Fast feature is not automatically disabled.

This example show how to first populate the VLAN database by associating a VLAN ID with a VLAN name, and then configure the VLAN (using the name) on an interface, in the access mode: You can also verify your configuration by entering the **show interfaces interface-id switchport** in privileged EXEC command and examining information in the Voice VLAN: row.

Part 1 - Making the entry in the VLAN database:

```
Device> enable
Device# configure terminal
Device(config)# vlan 55
Device(config-vlan)# name test
Device(config-vlan)# end
```

Part 2 - Checking the VLAN database:

```
Device> enable
Device# show vlan id 55
VLAN Name Status Ports
-----
55 test active
VLAN Type SAID MTU Parent RingNo BridgeNo Stp BrdgMode Trans1 Trans2
-----
55 enet 100055 1500 - - - - - 0 0
Remote SPAN VLAN
-----
Disabled
Primary Secondary Type Ports
-----
```

Part 3- Assigning VLAN to the interface by using the name of the VLAN:

```
Device> enable
Device# configure terminal
Device(config)# interface gigabitEthernet3/1/1
Device(config-if)# switchport mode access
Device(config-if)# switchport voice vlan name test
Device(config-if)# end
Device#
```

Part 4 - Verifying configuration:

```
Device> enable
Device# show running-config
interface gigabitEthernet3/1/1
Building configuration...
Current configuration : 113 bytes
!
interface GigabitEthernet3/1/1
switchport voice vlan 55
switchport mode access
Switch#
```

Part 5 - Also can be verified in interface switchport:

```
Device> enable
Device# show interface GigabitEthernet3/1/1 switchport
```

```
Name: Gi3/1/1
Switchport: Enabled
Administrative Mode: static access
Operational Mode: static access
Administrative Trunking Encapsulation: dot1q
Operational Trunking Encapsulation: native
Negotiation of Trunking: Off
Access Mode VLAN: 1 (default)
Trunking Native Mode VLAN: 1 (default)
Administrative Native VLAN tagging: enabled
Voice VLAN: 55 (test)
Administrative private-vlan host-association: none
Administrative private-vlan mapping: none
Administrative private-vlan trunk native VLAN: none
Administrative private-vlan trunk Native VLAN tagging: enabled
Administrative private-vlan trunk encapsulation: dot1q
Administrative private-vlan trunk normal VLANs: none
Administrative private-vlan trunk associations: none
Administrative private-vlan trunk mappings: none
Operational private-vlan: none
Trunking VLANs Enabled: ALL
Pruning VLANs Enabled: 2-1001
Capture Mode Disabled
Capture VLANs Allowed: ALL
Unknown unicast blocked: disabled
Unknown multicast blocked: disabled
Appliance trust: none
```

# transport unicast ipv4 local loopback

To configure a unicast IPv4 connection from a loopback interface, use the **transport unicast ipv4 local loopback** command in property configuration mode.

**transport unicast ipv4 local loopback** *value*

<b>Syntax Description</b>	<i>value</i>	Loopback interface number. The maximum number of sessions supported is 127.
<b>Command Default</b>	None	
<b>Command Modes</b>	Property configuration (config-property)	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Bengaluru 17.5.1	This command was introduced.

**Usage Guidelines** Configure the PTP property name using the **ptp property** command before configuring a unicast IPv4 connection from a loopback interface.

## Examples

The following example shows how to configure a unicast IPv4 connection from a loopback interface:

```
Device> enable
Device# configure terminal
Device(config)# ptp property cisco1
Device(config-property)# transport unicast ipv4 local loopback 0
Device(config-property-transport)# peer ip 192.0.2.1
Device(config-property-transport)# end
```

Related Commands	Command	Description
	<b>peer</b>	Connects to a peer PTP-aware device.
	<b>ptp dot1as extend property</b>	Extends IEEE 802.1AS profile to a PTP-property name
	<b>ptp property</b>	Sets the PTP-property name.
	<b>source ip interface</b>	(Optional) Configures the source IP interface.
	<b>show platform software fed active ptp interface loopback</b>	Displays the PTP connection details and events of the specified loopback interface.
	<b>show ptp port loopback</b>	Displays PTP configurations of a loopback interface.
	<b>show ptp transport properties</b>	Displays PTP profile and its properties.

# udld

To enable aggressive or normal mode in the UniDirectional Link Detection (UDLD) and to set the configurable message timer time, use the **udld** command in global configuration mode. To disable aggressive or normal mode UDLD on all fiber-optic ports, use the **no** form of the command.

```
udld {aggressive | enable | fast-hello error-reporting | message time message-timer-interval
| recovery interval recovery-timer-interval}
no udld {aggressive | enable | message}
```

## Syntax Description

<b>aggressive</b>	Enables UDLD in aggressive mode on all fiber-optic interfaces.
<b>enable</b>	Enables UDLD in normal mode on all fiber-optic interfaces.
<b>fast-hello error-reporting</b>	Reports link failure on the console instead of err-disabling the affected Fast UDLD port.
<b>message time</b> <i>message-timer-interval</i>	Configures the period of time between UDLD probe messages on ports that are in the advertisement phase and are determined to be bidirectional. The range is 1 to 90 seconds. The default is 15 seconds.
<b>recovery interval</b> <i>recovery-timer-interval</i>	Configures the error disable recovery timer value.

## Command Default

UDLD is disabled on all interfaces.  
The message timer is set at 15 seconds.

## Command Modes

Global configuration

## Command History

Release	Modification
Cisco IOS XE Everest 16.5.1a	This command was introduced.
Cisco IOS XE Fuji 16.9.1	The <b>fast-hello error-reporting</b> keyword was added to the command.  The <b>recovery interval</b> <i>recovery-timer-interval</i> keyword was introduced.

## Usage Guidelines

UDLD supports two modes of operation: normal (the default) and aggressive. In normal mode, UDLD detects unidirectional links due to misconnected interfaces on fiber-optic connections. In aggressive mode, UDLD also detects unidirectional links due to one-way traffic on fiber-optic and twisted-pair links and due to misconnected interfaces on fiber-optic links. For information about normal and aggressive modes, see the *Software Configuration Guide (Catalyst 9500 Switches)*.

If you change the message time between probe packets, you are making a compromise between the detection speed and the CPU load. By decreasing the time, you can make the detection-response faster but increase the load on the CPU.

This command affects fiber-optic interfaces only. Use the **udld** interface configuration command to enable UDLD on other interface types.

You can use these commands to reset an interface shut down by UDLD:

- The **udld reset** privileged EXEC command to reset all interfaces shut down by UDLD.
- The **shutdown** and **no shutdown** interface configuration commands.
- The **no udld enable** global configuration command followed by the **udld {aggressive | enable}** global configuration command to reenables UDLD globally.
- The **no udld port** interface configuration command followed by the **udld port** or **udld port aggressive** interface configuration command to reenables UDLD on the specified interface.
- The **errdisable recovery cause udld** and **errdisable recovery interval *interval*** global configuration commands to automatically recover from the UDLD error-disabled state.

This example shows how to enable UDLD on all fiber-optic interfaces:

```
Device> enable
Device# configure terminal
Device(config)# udld enable
```

You can verify your setting by entering the **show udld** command in privileged EXEC mode.

# udld fast-hello

To enable Fast UniDirectional Link Detection (UDLD) on an individual interface which has UDLD configured on it, use the **udld fast-hello** command in interface configuration mode.

**udld fast-hello** *message-timer-interval*

<b>Syntax Description</b>	<i>message-timer-interval</i> Configures time in milliseconds between sending of messages in steady state. The range is from 200 to 1000 milliseconds.
---------------------------	--

<b>Command Default</b>	Fast UDLD is disabled by default.
------------------------	-----------------------------------

<b>Command Modes</b>	Interface configuration
----------------------	-------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Fuji 16.9.1	This command was introduced.

<b>Usage Guidelines</b>	A UDLD-capable port cannot detect a unidirectional link if it is connected to a UDLD-incapable port of another device.
-------------------------	--

UDLD supports two modes of operation: normal (the default) and aggressive. In normal mode, UDLD detects unidirectional links due to misconnected interfaces on fiber-optic connections. In aggressive mode, UDLD also detects unidirectional links due to one-way traffic on fiber-optic and twisted-pair links and due to misconnected interfaces on fiber-optic links.

Fast UDLD enables detection of unidirectional links within the span of a few hundred milliseconds to a second. Fast UDLD runs on top of the UDLD process without interrupting it. To configure a port in Fast UDLD mode, it must first be configured in UDLD mode.

To enable Fast UDLD mode on a port, use the **udld fast-hello***message-timer-interval* interface configuration command.

<b>Examples</b>	This example shows how to enable Fast UDLD on an port:
-----------------	--

```
Device> enable
Device# configure terminal
Device(config)# interface gigabitethernet6/0/1
Device(config-if)# udld fast-hello 200
```

You can verify your settings by entering either the **show running-config** or the **show udld fast-hello interface** command in privileged EXEC mode.

# udld port

To enable UniDirectional Link Detection (UDLD) on an individual interface or to prevent a fiber-optic interface from being enabled by the **udld** command in global configuration mode, use the **udld port** command in interface configuration mode.

**udld port** [**aggressive** | **disable**]  
**no udld port** [**aggressive**]

<b>Syntax Description</b>	<p><b>aggressive</b> (Optional) Enables UDLD in aggressive mode on the specified interface.</p> <p><b>disable</b> (Optional) Disables UDLD on the specified interface despite the global UDLD configuration.</p>	
<b>Command Default</b>	<p>On fiber-optic interfaces, UDLD is disabled and fiber-optic interfaces enable UDLD according to the state of the <b>udld enable</b> or <b>udld aggressive</b> command in global configuration mode.</p> <p>On nonfiber-optic interfaces, UDLD is disabled.</p>	
<b>Command Modes</b>	Interface configuration	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Everest 16.5.1a	This command was introduced.
	Cisco IOS XE Fuji 16.9.1	The <b>disable</b> keyword was introduced.
<b>Usage Guidelines</b>	<p>A UDLD-capable port cannot detect a unidirectional link if it is connected to a UDLD-incapable port of another device.</p> <p>UDLD supports two modes of operation: normal (the default) and aggressive. In normal mode, UDLD detects unidirectional links due to misconnected interfaces on fiber-optic connections. In aggressive mode, UDLD also detects unidirectional links due to one-way traffic on fiber-optic and twisted-pair links and due to misconnected interfaces on fiber-optic links.</p> <p>To enable UDLD in normal mode, use the <b>udld port</b> command in interface configuration mode. To enable UDLD in aggressive mode, use the <b>udld port aggressive</b> command in interface configuration mode.</p> <p>Use the <b>udld port disable</b> command on fiber-optic ports to return control of UDLD to the <b>udld enable</b> command in global configuration mode or to disable UDLD on nonfiber-optic ports.</p> <p>Use the <b>udld port aggressive</b> command on fiber-optic ports to override the setting of the <b>udld enable</b> or <b>udld aggressive</b> command in global configuration mode. Use the <b>udld port disable</b> command on fiber-optic ports to remove this setting and to return control of UDLD enabling to the <b>udld</b> command in global configuration mode or to disable UDLD on nonfiber-optic ports.</p> <p>You can use these commands to reset an interface shut down by UDLD:</p> <ul style="list-style-type: none"> <li>• The <b>udld reset</b> command in privileged EXEC mode resets all interfaces shut down by UDLD.</li> <li>• The <b>shutdown</b> and <b>no shutdown</b> command in interface configuration mode</li> </ul>	

- The **no udld enable** command in global configuration mode, followed by the **udld {aggressive | enable}** command in global configuration mode reenables UDLD globally.
- The **udld port disable** command in interface configuration mode, followed by the **udld port** or **udld port aggressive** command in interface configuration mode reenables UDLD on the specified interface.
- The **errdisable recovery cause udld** and **errdisable recovery interval *interval*** command in global configuration mode automatically recover from the UDLD error-disabled state.

This example shows how to enable UDLD on an port:

```
Device> enable
Device# configure terminal
Device(config)# interface gigabitethernet6/0/1
Device(config-if)# udld port
```

This example shows how to disable UDLD on a fiber-optic interface despite the setting of the **udld** global configuration command:

```
Device> enable
Device# configure terminal
Device(config)# interface gigabitethernet6/0/1
Device(config-if)# udld port disable
```

You can verify your settings by entering the **show running-config** or the **show udld *interface*** command in privileged EXEC mode.



# udld reset

To reset all interfaces disabled by UniDirectional Link Detection (UDLD) and permit traffic to begin passing through them again (though other features, such as spanning tree, Port Aggregation Protocol (PAgP), and Dynamic Trunking Protocol (DTP) still have their normal effects, if enabled), use the **udld reset** command in privileged EXEC mode.

## udld reset

---

**Command Modes** Privileged EXEC

---

Command History	Release	Modification
	Cisco IOS XE Everest 16.5.1a	This command was introduced.

---

---

**Usage Guidelines** If the interface configuration is still enabled for UDLD, these ports begin to run UDLD again and are disabled for the same reason if the problem has not been corrected.

This example shows how to reset all interfaces disabled by UDLD:

```
Device> enable
Device# udld reset
1 ports shutdown by UDLD were reset.
```

## vlan dot1q tag native

To enable tagging of native VLAN frames on all IEEE 802.1Q trunk ports, use the **vlan dot1q tag native** command in global configuration mode. To return to the default setting, use the **no** form of this command.

**vlan dot1q tag native**  
**no vlan dot1q tag native**

### Syntax Description

This command has no arguments or keywords.

### Command Default

The IEEE 802.1Q native VLAN tagging is disabled.

### Command Modes

Global configuration

### Command History

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

### Usage Guidelines

When enabled, native VLAN packets going out of all IEEE 802.1Q trunk ports are tagged.

When disabled, native VLAN packets going out of all IEEE 802.1Q trunk ports are not tagged.

You can use this command with the IEEE 802.1Q tunneling feature. This feature operates on an edge device of a service-provider network and expands VLAN space by using a VLAN-in-VLAN hierarchy and tagging the tagged packets. You must use IEEE 802.1Q trunk ports for sending packets to the service-provider network. However, packets going through the core of the service-provider network might also be carried on IEEE 802.1Q trunks. If the native VLANs of an IEEE 802.1Q trunks match the native VLAN of a tunneling port on the same device, traffic on the native VLAN is not tagged on the sending trunk port. This command ensures that native VLAN packets on all IEEE 802.1Q trunk ports are tagged.

For more information about IEEE 802.1Q tunneling, see the software configuration guide for this release.

This example shows how to enable IEEE 802.1Q tagging on native VLAN frames:

```
Device> enable
Device# configure terminal
Device(config)# vlan dot1q tag native
Device(config)# end
```

You can verify your settings by entering the **show vlan dot1q tag native** privileged EXEC command.

## vtp mode

To configure the VLAN Trunking Protocol (VTP) device mode, use the **vtp mode** command. To revert to the default server mode, use the **no** form of this command.

```
vtp mode {client | off | transparent}
no vtp mode
```

Syntax Description	client	Specifies the device as a client.
	off	Specifies the device mode as off.
	server	Specifies the device as a server.
	transparent	Specifies the device mode as transparent.

<b>Command Default</b>	Server.
------------------------	---------

Command History	Release	Modification
	Cisco IOS XE Fuji 16.8.1a	This command was introduced.

<b>Command Modes</b>	Global configuration mode.
----------------------	----------------------------

**Usage Guidelines** VLAN Trunking Protocol (VTP) is a Cisco Proprietary Layer 2 messaging protocol used to distribute the VLAN configuration information across multiple devices within a VTP domain. Without VTP, you must configure VLANs in each device in the network. Using VTP, you configure VLANs on a VTP server and then distribute the configuration to other VTP devices in the VTP domain.

In VTP transparent mode, you can configure VLANs (add, delete, or modify) and private VLANs. VTP transparent switches do not participate in VTP. A VTP transparent switch does not advertise its VLAN configuration and does not synchronize its VLAN configuration based on received advertisements. The VTP configuration revision number is always set to zero (0). Transparent switches do forward VTP advertisements that they receive out their trunk ports in VTP version 2.

A VTP device mode can be one of the following:

- **server** —You can create, modify, and delete VLANs and specify other configuration parameters, such as VTP version, for the entire VTP domain. VTP servers advertise their VLAN configuration to other switches in the same VTP domain and synchronize their VLAN configuration with other switches based on advertisements received over trunk links. VTP server is the default mode.



**Note** You can configure VLANs 1 to 1005. VLANs 1002 to 1005 are reserved for token ring in VTP version 2.

- **client** —VTP clients behave the same way as VTP servers, but you cannot create, change, or delete VLANs on a VTP client.

- **transparent** —You can configure VLANs (add, delete, or modify) and private VLANs. VTP transparent switches do not participate in VTP. A VTP transparent switch does not advertise its VLAN configuration and does not synchronize its VLAN configuration based on received advertisements. Because of this, the VTP configuration revision number is always set to zero (0). Transparent switches do forward VTP advertisements that they receive out their trunk ports in VTP version 2.
- **off** —In the above three described modes, VTP advertisements are received and transmitted as soon as the switch enters the management domain state. In the VTP off mode, switches behave the same as in VTP transparent mode with the exception that VTP advertisements are not forwarded. You can use this VTP device to monitor the VLANs.



---

**Note** If you use the `no vtp mode` command to remove a VTP device, the device will be configured as a VTP server. Use the `vtp mode off` command to remove a VTP device.

---

### Example

This example shows how to configure a VTP device in transparent mode and add VLANs 2, 3, and 4:

```
Device> enable
Device(config)#vtp mode transparent
Device(config)# vlan 2-4
```

### Example

This example shows how to remove a device configured as a VTP device:

```
Device> enable
Device(config)# vtp mode off
```

### Example

This example shows how to configure a VTP device as a VTP server and adds VLANs 2 and 3:

```
Device> enable
Device# vtp mode server
Device(config)# vlan 2,3
```

### Example

This example shows how to configure a VTP device as a client:

```
Device> enable
Device# vtp mode client
```