



## Overview

---

This chapter includes the following sections:

- [Cisco UCS E-Series Servers and the Cisco UCS E-Series Network Compute Engine Overview, on page 1](#)
- [Server Software, on page 1](#)
- [Managing E-Series Servers and the NCE, on page 2](#)
- [E-Series Server and NCE Options, on page 3](#)
- [Common Terms Used in This Guide, on page 7](#)

## Cisco UCS E-Series Servers and the Cisco UCS E-Series Network Compute Engine Overview

The Cisco UCS E-Series M6 Servers are size-, weight-, and power-efficient blade servers that are housed within the Cisco Catalyst 8300 Series Edge platforms. These servers provide a general-purpose compute platform for branch-office applications deployed either as bare-metal on operating systems, such as Linux, or as virtual machines on hypervisors, such as VMware vSphere Hypervisor.

The UCS E-Series M6 Server is purpose-built with powerful Intel IceLake-D processors for general purpose compute. It comes in the double-wide form factor, that fits into two SM slots.



---

**Note** For information about the E-Series M6 Servers, and the maximum number of servers that can be installed per router, see the "Hardware Requirements" section in the *Hardware Installation Guide for Cisco UCS E-Series M6 Servers*.

---

## Server Software

The UCS E-Series M6 Servers require three major software systems:

- CIMC firmware
- BIOS firmware
- Operating system or hypervisor

### CIMC Firmware

Cisco Integrated Management Controller (CIMC) is a separate management module built into the motherboard of the E-Series M6 Servers. A dedicated processor, separate from the main server CPU, runs the CIMC firmware. The system ships with a running version of the CIMC firmware. You can update the CIMC firmware, but no initial installation is needed.

CIMC is the management service for the E-Series M6 Servers. You can use a web-based GUI or SSH-based CLI to access, configure, administer, and monitor the server.

### BIOS Firmware

BIOS initializes the hardware in the system, discovers bootable devices, and boots them in the provided sequence. It boots the operating system and configures the hardware for the operating system to use. BIOS manageability features allow you to interact with the hardware and use it. In addition, BIOS provides options to configure the system, and manage firmware.

The system ships with a running version of the BIOS firmware. You can update the BIOS firmware, but no initial installation is required.

### Operating System or Hypervisor

The main server CPU runs on an operating system, such as Linux; or on a hypervisor. You can purchase an E-Series M6 Servers with a preinstalled hypervisor.



**Note** For information about the platforms that are available on the E-Series M6 Servers, see the "Software Requirements" section in the *Release Notes for Cisco UCS E-Series M6 Servers*.

## Managing E-Series Servers and the NCE

The following table lists the management interfaces used by the E-Series Server and the NCE.


**Table 1: E-Series Server and NCE Management Interfaces**

Management Interface	Description
Cisco IOS CLI	CLI used to configure the host router and the E-Series Server or the NCE.
CIMC GUI	Web-based GUI used to access, configure, administer, and monitor the E-Series Server and NCE.
CIMC CLI	SSH-based CLI used to access, configure, administer, and monitor the E-Series Server and the NCE.
SNMP	Simple Network Management Protocol (SNMP) traps that allow you to view server configuration and status, and send fault and alert information.

# E-Series Server and NCE Options

The following figure shows the E-Series Server and NCE options.

**Figure 1: E-Series Server or NCE Options**



- Option 1—E-Series Server or NCE without a preinstalled operating system or hypervisor
- Option 2—E-Series Server or NCE with a preinstalled Microsoft Windows Server

At the time of purchase, you can choose the appropriate RAID option that you want enabled on the E-Series Server.




---

**Note** If you purchase this option, the Microsoft Windows Server license is preactivated.

---

- Option 3—E-Series Server or NCE with a preinstalled VMware vSphere Hypervisor

At the time of purchase, you can choose the appropriate RAID option that you want enabled on the E-Series Server.




---

**Note** The default username for the preinstalled VMware vSphere Hypervisor is **root**, which cannot be changed, and the default password is **password**. After you log in, we recommend that you change the password.

---




---


**Important** The RAID feature is applicable to E-Series Servers and the SM E-Series NCE. The RAID feature is not applicable to the EHWIC E-Series NCE and the NIM E-Series NCE.

---

## Basic Workflow for Option 1—E-Series Server or NCE Without a Preinstalled Operating System or Hypervisor

The following figure shows the basic workflow for Option 1—E-Series Server or NCE without a preinstalled operating system or hypervisor.

Figure 2: Basic Workflow—Option 1



**Note** The CIMC Configuration Utility is not applicable to the EHWIC E-Series NCE and the NIM E-Series NCE.



**Note** The RAID feature is applicable to E-Series Servers and the SM E-Series NCE. The RAID feature is not applicable to the EHWIC E-Series NCE and the NIM E-Series NCE.

The following procedure provides the references for the tasks that you must perform when you purchase Option 1—hardware only (E-Series Server or NCE without a preinstalled operating system or hypervisor).

**Procedure**

	Command or Action	Purpose
<b>Step 1</b>	Install the E-Series Server or NCE into the router.	See <a href="#">Installing the E-Series Server or NCE into the Router.</a>

	Command or Action	Purpose
<b>Step 2</b>	Configure the CIMC IP address for CIMC access.	See <a href="#">Configuring Access to the Management Firmware</a> .
<b>Step 3</b>	Access CIMC.	See <a href="#">Accessing the Management Firmware</a> .
<b>Step 4</b>	Configure RAID and make the disk drive bootable.	See <a href="#">Managing Storage Using RAID</a> .  <b>Important</b> The RAID feature is applicable to E-Series Servers and the SM E-Series NCE. The RAID feature is not applicable to the EHWIC E-Series NCE and the NIM E-Series NCE.
<b>Step 5</b>	Install the operating system, and if needed, install the drivers.	See <a href="#">Installing the Operating System or Hypervisor</a> .
<b>Step 6</b>	Configure an internal connection between the router and the E-Series Server or NCE.	Depending on whether you want the traffic to flow through the router or not, do one of the following: <ul style="list-style-type: none"> <li>• If you <i>do not want</i> the traffic to your application or operating system to flow through the router, use the server's host operating system to configure the E-Series Server's or NCE's external interface.</li> <li>• If you <i>want</i> the traffic to your application or operating system to flow through the router, use the Cisco IOS CLI to configure an internal connection between the router and the E-Series Server or NCE. See <a href="#">Configuring a Connection Between the Router and the E-Series Server or NCE</a>.</li> </ul>

## Basic Workflow for Option 2—E-Series Server or NCE With a Preinstalled Microsoft Windows Server

The following procedure provides the references for the tasks that you must perform when you purchase Option 2—E-Series Server or NCE with a preinstalled Microsoft Windows Server.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Install the E-Series Server or NCE into the router.	See <a href="#">Installing the E-Series Server or NCE into the Router</a> .
<b>Step 2</b>	Configure the CIMC IP address for CIMC access.	See <a href="#">Configuring Access to the Management Firmware</a> .

	Command or Action	Purpose
<b>Step 3</b>	Configure an internal connection between the router and the E-Series Server or NCE.	Depending on whether you want the traffic to flow through the router or not, do one of the following: <ul style="list-style-type: none"> <li>• If you <i>do not want</i> the traffic to your application or operating system to flow through the router, use the server's host operating system to configure the E-Series Server's or NCE's external interface.</li> <li>• If you <i>want</i> the traffic to your application or operating system to flow through the router, use the Cisco IOS CLI to configure an internal connection between the router and the E-Series Server or NCE. See <a href="#">Configuring a Connection Between the Router and the E-Series Server or NCE</a>.</li> </ul>
<b>Step 4</b>	Access CIMC, and then access the Microsoft Windows Server from CIMC.	See <a href="#">Accessing the Management Firmware</a> .

## Basic Workflow for Option 3—E-Series Server or NCE With a Preinstalled VMware vSphere Hypervisor

The following procedure provides the references for the tasks that you must perform when you purchase Option 3—E-Series Server or NCE with a preinstalled VMware vSphere Hypervisor.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Install the E-Series Server or NCE into the router.	See <a href="#">Installing the E-Series Server or NCE into the Router</a> .
<b>Step 2</b>	Configure the CIMC IP address for CIMC access.	See <a href="#">Configuring Access to the Management Firmware</a> .
<b>Step 3</b>	Configure an internal connection between the router and the E-Series Server or NCE.	Depending on whether you want the traffic to flow through the router or not, do one of the following: <ul style="list-style-type: none"> <li>• If you <i>do not want</i> the traffic to your application or operating system to flow through the router, use the server's host operating system to configure the E-Series Server's or NCE's external interface.</li> <li>• If you <i>want</i> the traffic to your application or operating system to flow through the router, use the Cisco IOS CLI to configure</li> </ul>

	Command or Action	Purpose
		an internal connection between the router and the E-Series Server or NCE. See <a href="#">Configuring a Connection Between the Router and the E-Series Server or NCE</a> .
<b>Step 4</b>	Access CIMC, and then access the VMware vSphere Hypervisor from CIMC.	See <a href="#">Accessing the Management Firmware</a> .

## Common Terms Used in This Guide

Table 2: Common Terms

Term	Description
BMC	Board Management Controller. BMC is used in the Cisco IOS commands to configure CIMC.
CIMC	Cisco Integrated Management Controller. CIMC is the management service for the E-Series Server. CIMC runs within the server. You can use CIMC to access, configure, administer, and monitor the server.
CLI	Command-line interface.
IMC	Integrated Management Controller. IMC is used in the Cisco IOS commands to configure CIMC.
LOM	LAN on Motherboard. Shared LOM interfaces are used to configure CIMC access.
RAID	Redundant Array of Inexpensive Disks. RAID is used to store E-Series Server data files.

