



Quick Start Basic Configuration



Note

- Use this "Quick Start Basic Configuration" chapter if you just need a list of commands and steps to quickly set up and use the Cisco UCS E-Series Server (E-Series Server) or the Cisco UCS E-Series Network Compute Engine (NCE).
- For detailed instructions, use subsequent chapters.

Use this quick start basic configuration chapter if you purchased Option 1 (E-Series Server or NCE without a preinstalled operating system or hypervisor). Some of the configuration steps are different if you purchased Option 2 (E-Series Server or NCE with a preinstalled Microsoft Windows Server), or Option 3 (E-Series Server or NCE with a preinstalled VMware vSphere Hypervisor).


This chapter includes the following sections:

- [Quick Start Basic Configuration Tasks, on page 1](#)

Quick Start Basic Configuration Tasks

The following figure shows the basic workflow for Option 1—E-Series Server or NCE without a preinstalled operating system or hypervisor.

Figure 1: Basic Workflow—Option 1



Note The CIMC Configuration Utility is not applicable to the EHWIC E-Series NCE and the NIM E-Series NCE.



Note The RAID feature is applicable to E-Series Servers and the SM E-Series NCE. The RAID feature is not applicable to the EHWIC E-Series NCE and the NIM E-Series NCE.

Procedure

Step 1 Install the E-Series Server or NCE into the router.

Step 2 Configure the CIMC IP address for CIMC access. Use one of the following methods:

- If you are a remote user, use the Cisco IOS CLI to configure CIMC access. This basic configuration shows you how to configure CIMC access using the server's external GE2 interface:

a. **enable**

b. configure terminal

c. Use one of the following as appropriate:

- **interface ucse slot/port**—Use for all E-Series Servers or SM E-Series NCE installed in a Cisco ISR G2 or Cisco ISR 4000 series.
- **interface ucse 0/subslot/port**—Use for an EHWIC E-Series NCE installed in a Cisco ISR G2.
- **interface ucse slot/subslot/port**—Use for a NIM E-Series NCE installed in a Cisco ISR 4000 series.
- **ucse subslot slot/subslot**—Use for all E-Series Servers and NCEs installed in a Cisco ISR G2 or Cisco ISR 4000 series.

d. **imc ip address cimc-ip-address subnet-mask default-gateway cimc-gateway-ip-address**

e. **imc access-port shared-lom ge2**

f. **no shut**—Not applicable for an E-Series Server installed in a Cisco ISR 4000 series.

g. **end**

Note For detail configuration, see one of the following topics as appropriate:

- [Configuring CIMC Access Using the E-Series Server's External GE2 or GE3 Interface—Cisco ISR G2](#)
- [Configuring CIMC Access Using the E-Series Server's External GE2 or GE3 Interface—Cisco ISR 4000 Series](#)
- [Configuring CIMC Access Using the EHWIC E-Series NCE's External GE2 Interface](#)
- [Configuring CIMC Access Using the NIM E-Series NCE's External GE2 Interface—Cisco ISR 4000 Series](#)

To use another interface, see [Configuring Access to the Management Firmware](#).

• If you are a local user, use one of the following methods:

- Connect a keyboard and monitor to the front panel of the E-Series Server, and then use the CIMC Configuration Utility to configure CIMC access. See [Configuring CIMC Access Using the CIMC Configuration Utility](#).

Note The CIMC Configuration Utility is not applicable to the EHWIC E-Series NCE and the NIM E-Series NCE.

- Use the Cisco IOS CLI to configure CIMC access (see the configuration for a remote user above).

Step 3 In your web browser, enter the IP address that you configured in Step 2 to access CIMC.

Step 4 Configure RAID and make the disk drive bootable. See [Managing Storage Using RAID](#).

Step 5 Install the operating system or hypervisor and if needed, install drivers. See [Installing the Operating System or Hypervisor](#).

Step 6 Do one of the following:

- If you do not want the traffic to your application or operating system to flow through the router, use the server's host operating system to configure the E-Series Server's external GE2 or GE3 interface or the NCE's external GE2 interface.
 - If you want the traffic to your application or operating system to flow through the router, use the Cisco IOS CLI to configure an internal connection between the router and the E-Series Server or NCE. See [Configuring a Connection Between the Router and the E-Series Server or NCE](#).
-