



Cisco UCS Manager VIC Configuration Guide, Release 4.3

First Published: 2024-05-02

Last Modified: 2024-07-03

Americas Headquarters

Cisco Systems, Inc.
170 West Tasman Drive
San Jose, CA 95134-1706
USA
<http://www.cisco.com>
Tel: 408 526-4000
800 553-NETS (6387)
Fax: 408 527-0883



CONTENTS

PREFACE

Preface	vii
Audience	vii
Conventions	vii
Related Cisco UCS Documentation	ix
Documentation Feedback	ix

CHAPTER 1

Overview of Cisco Virtual Interface Card (VIC) Configuration Guide	1
Overview of VIC Configuration Guide	1
RDMA Over Converged Ethernet (RoCE) v2	1
Single Root I/O Virtualization Overview	1

CHAPTER 2

Guidelines and Limitations	3
RoCEv2 for Windows	3
Guidelines for Using SMB Direct support on Windows using RoCEv2	3
Configuring RoCEv2 Modes 1 and 2 in Windows	5
Windows Requirements	5
RoCEv2 for Linux	6
Guidelines for using NVMe over Fabrics (NVMeoF) with RoCEv2 on Linux	6
Linux Requirements	7
RoCEv2 For ESXi	7
Guidelines for using RoCEv2 Protocol in the Native ENIC driver on ESXi	7
ESXi nENIC RDMA Requirements	8
SR-IOV for ESXi	8
General Guidelines and Limitations for SR-IOV	8
ESXi Requirements for SR-IOV	9

CHAPTER 3	Configuring RDMA Over Converged Ethernet (RoCE) version 2	11
	Configuring RoCEv2 in Windows	11
	Configuring SMB Direct Mode 1 on Cisco UCS Manager	11
	Configuring SMB Direct Mode 1 on the Host System	12
	Configuring Mode 2 on Cisco UCS Manager	14
	Configuring SMB Direct Mode 2 on the Host System	15
	Configuring RoCEv2 in Linux	16
	Configuring NVMeoF Using RoCEv2 on Cisco UCS Manager	16
	Enabling an SR-IOV BIOS Policy	17
	Configuring NVMeoF Using RoCEv2 on the Host	17
	Installing Cisco enic and enic_rdma Drivers	18
	Discovering the NVMe Target	19
	Setting Up Device Mapper Multipath	20
	Deleting the RoCEv2 Interface Using Cisco UCS Manager	21
	Configuring RoCEv2 in ESXi	21
	Installing NENIC Driver	21
	Configuring and Enabling RoCEv2 on UCS Manager	22
	Configuring NVMeoF using RoCEv2 for ESXi on UCS Manager	22
	ESXi NVMe RDMA Host Side Configuration	23
	NENIC RDMA Functionality	23
	Create Network Connectivity Switches	24
	Create VMHBA Ports in ESXi	25
	Displaying vmnic and vmrdma Interfaces	26
	NVMe Fabrics and Namespace Discovery	28
	Using the UCS Manager CLI to Configure or Delete the RoCEv2 Interface	29
	Configure Windows SMB Direct RoCEv2 Interface using UCS Manager CLI	29
	Deleting the Windows RoCEv2 Interface Using the CLI for UCS Manager	30
	Configuring the Linux RoCEv2 Interface Using the UCS Manager CLI	31
	Deleting the Linux RoCEv2 Interface Using the UCS Manager CLI	32
	Configuring the VMware ESXi RoCEv2 Interface Using the UCS Manager CLI	33
	Deleting the ESXi RoCEv2 Interface Using UCS Manager	34
	Known Issues in RoCEv2	34

CHAPTER 4**Single Root I/O Virtualization (SR-IOV) 37**

- Configuring BIOS and Cisco UCS Manager Parameters 37
 - Enabling SR-IOV BIOS Parameters 37
 - Enabling SR-IOV VFs using Cisco UCS Manager GUI 38
 - Disabling SR-IOV VFs Using Cisco UCS Manager GUI 39
 - Enabling SR-IOV VFs using Cisco UCS Manager CLI 39
 - Disabling SR-IOV VFs using Cisco UCS Manager CLI 41
- Configuring SR-IOV VFs on the ESXi Host Server 42
 - Installing Cisco eNIC Driver 42
 - Verifying the Total Number of SR-IOV VFs Per Ports on the Host 42
 - Creating SR-IOV VFs on the Host 43
 - Configuring the Switch 44
 - Creating a Virtual Port 45
 - Creating a New Virtual Machine (VM) 46
 - Adding SR-IOV VF on the Virtual Machine 46
 - Installing OS on Guest VM on ESXi 47



Preface

- [Audience, on page vii](#)
- [Conventions, on page vii](#)
- [Related Cisco UCS Documentation, on page ix](#)
- [Documentation Feedback, on page ix](#)

Audience

This guide is intended primarily for data center administrators with responsibilities and expertise in one or more of the following:

- Server administration
- Storage administration
- Network administration
- Network security

Conventions

Text Type	Indication
GUI elements	GUI elements such as tab titles, area names, and field labels appear in this font . Main titles such as window, dialog box, and wizard titles appear in this font .
Document titles	Document titles appear in <i>this font</i> .
TUI elements	In a Text-based User Interface, text the system displays appears in <code>this font</code> .
System output	Terminal sessions and information that the system displays appear in <code>this font</code> .
CLI commands	CLI command keywords appear in this font . Variables in a CLI command appear in <i>this font</i> .
[]	Elements in square brackets are optional.

Text Type	Indication
{x y z}	Required alternative keywords are grouped in braces and separated by vertical bars.
[x y z]	Optional alternative keywords are grouped in brackets and separated by vertical bars.
string	A nonquoted set of characters. Do not use quotation marks around the string or the string will include the quotation marks.
<>	Nonprinting characters such as passwords are in angle brackets.
[]	Default responses to system prompts are in square brackets.
!, #	An exclamation point (!) or a pound sign (#) at the beginning of a line of code indicates a comment line.



Note Means *reader take note*. Notes contain helpful suggestions or references to material not covered in the document.



Tip Means *the following information will help you solve a problem*. The tips information might not be troubleshooting or even an action, but could be useful information, similar to a Timesaver.



Timesaver Means *the described action saves time*. You can save time by performing the action described in the paragraph.



Caution Means *reader be careful*. In this situation, you might perform an action that could result in equipment damage or loss of data.



Warning IMPORTANT SAFETY INSTRUCTIONS

This warning symbol means danger. You are in a situation that could cause bodily injury. Before you work on any equipment, be aware of the hazards involved with electrical circuitry and be familiar with standard practices for preventing accidents. Use the statement number provided at the end of each warning to locate its translation in the translated safety warnings that accompanied this device.

SAVE THESE INSTRUCTIONS

Related Cisco UCS Documentation

Documentation Roadmaps

For a complete list of all B-Series documentation, see the *Cisco UCS B-Series Servers Documentation Roadmap* available at the following URL: https://www.cisco.com/c/en/us/td/docs/unified_computing/ucs/overview/guide/UCS_roadmap.html

For a complete list of all C-Series documentation, see the *Cisco UCS C-Series Servers Documentation Roadmapdoc roadmap* available at the following URL: https://www.cisco.com/c/en/us/td/docs/unified_computing/ucs/overview/guide/ucs_rack_roadmap.html.

For information on supported firmware versions and supported UCS Manager versions for the rack servers that are integrated with the UCS Manager for management, refer to [Release Bundle Contents for Cisco UCS Software](#).

Documentation Feedback

To provide technical feedback on this document, or to report an error or omission, please send your comments to ucs-docfeedback@external.cisco.com. We appreciate your feedback.



CHAPTER 1

Overview of Cisco Virtual Interface Card (VIC) Configuration Guide

- [Overview of VIC Configuration Guide](#) , on page 1
- [RDMA Over Converged Ethernet \(RoCE\) v2](#) , on page 1
- [Single Root I/O Virtualization Overview](#), on page 1

Overview of VIC Configuration Guide

A Cisco UCS network adapter can be installed to provide options for I/O consolidation and virtualization support. This guide contains configuration details on RDMA over Converged Ethernet version 2 (RoCEv2) and Single Root I/O Virtualization (SR-IOV).

RDMA Over Converged Ethernet (RoCE) v2

RDMA over Converged Ethernet version 2 (RoCEv2) is an *internet layer* protocol, which means that RoCEv2 packets can be routed. RoCEv2 allows direct memory access over the network by encapsulating an Infiniband (IB) transport packet over Ethernet.

The RoCEv2 protocol exists on top of either the UDP/IPv4 or the UDP/IPv6 protocol. The UDP destination port number 4791 has been reserved for RoCEv2. Since RoCEv2 packets are routable, the RoCEv2 protocol is sometimes called Routable RoCE.

RoCEv2 is supported on the Windows, Linux, and ESXi Operating Systems.

Single Root I/O Virtualization Overview

Single Root I/O Virtualization (SR-IOV) allows multiple VMs running a variety of guest operating systems to share a single PCIe network adapter within a host server. SR-IOV allows a VM to move data directly to and from the network adapter, bypassing the hypervisor for increased network throughput and lower server CPU burden. Recent x86 server processors include chipset enhancements, such as Intel VT-x technology, that facilitate direct memory transfers and other operations required by SR-IOV.

The SR-IOV specification defines two device types:

- Physical Function (PF)—Essentially a static vNIC, a PF is a full PCIe device that includes SR-IOV capabilities. PFs are discovered, managed, and configured as normal PCIe devices. A single PF can provide management and configuration for a set of virtual functions (VFs).
- Virtual Function (VF)—A VF is a full or lightweight virtual PCIe device that provides at least the necessary resources for data movements. A VF is not managed directly but is derived from and managed through a PF. One or more VFs can be assigned to a VM.

SR-IOV is defined and maintained by the Peripheral Component Interconnect Special Interest Group (PCI-SIG), an industry organization that is chartered to develop and manage the PCI standard.



CHAPTER 2

Guidelines and Limitations

- [RoCEv2 for Windows, on page 3](#)
- [RoCEv2 for Linux, on page 6](#)
- [RoCEv2 For ESXi, on page 7](#)
- [SR-IOV for ESXi, on page 8](#)

RoCEv2 for Windows

Guidelines for Using SMB Direct support on Windows using RoCEv2

General Guidelines and Limitations

- Cisco UCS Manager release 4.1.x and later releases support Microsoft SMB Direct with RoCEv2 on Microsoft Windows Server 2019 and later. Cisco recommends that you have all KB updates from Microsoft for your Windows Server release. See [Windows Requirements, on page 5](#).



Note RoCEv2 is not supported on Microsoft Windows Server 2016.

- Cisco recommends you check [UCS Hardware and Software Compatibility](#) specific to your Cisco UCS Manager release to determine support for Microsoft SMB Direct with RoCEv2 on Microsoft Windows.
- Microsoft SMB Direct with RoCEv2 is supported only with Cisco UCS VIC 1400 Series, 14000 Series, and 15000 Series adapters. It is not supported with UCS VIC 1200 Series and 1300 Series adapters. SMB Direct with RoCEv2 is supported on all UCS Fabric Interconnects.



Note RoCEv1 is not supported with Cisco UCS VIC 1400 Series, Cisco UCS VIC 14000 Series, and Cisco UCS VIC 15000 Series.

- RoCEv2 configuration is supported only between Cisco adapters. Interoperability between Cisco adapters and third party adapters is not supported.

- RoCEv2 supports two RoCEv2 enabled vNIC per adapter and four virtual ports per adapter interface, independent of SET switch configuration.
- RoCEv2 cannot be used on the same vNIC interface as NVGRE, NetFlow, and VMQ features.
- Support for RoCEv2 protocol for Windows 2019 NDKPI mode 1 and mode 2, with both IPV4 and IPV6.
- RoCEv2-enabled vNIC interfaces must have the no-drop QoS system class enabled in Cisco UCS Manager.
- The RoCE Properties queue pairs setting must for be a minimum of 4 queue pairs.
- Maximum number of queue pairs per adapter is 2048.
- The maximum number of memory regions per rNIC interface is 131072.
- Cisco UCS Manager does not support fabric failover for vNICs with RoCEv2 enabled.
- SMB Direct with RoCEv2 is supported on both IPv4 and IPv6.
- RoCEv2 cannot be used with GENEVE offload.
- The QoS No Drop class configuration must be properly configured on upstream switches such as Cisco Nexus 9000 series switches. QoS configurations may vary between different upstream switches.
- RoCEv2 cannot be used with usNIC.

MTU Properties

- In older versions of the VIC driver, the MTU was derived from either a Cisco UCS Manager service profile or from the Cisco IMC vNIC MTU setting in non-cluster setup. This behavior changes on Cisco UCS VIC 1400 Series and later adapters, where MTU is controlled from the Windows OS Jumbo Packet advanced property. A value configured from Cisco UCS Manager or Cisco IMC has no effect.
- The RoCEv2 MTU value is always power-of-two and the maximum limit is 4096.
- RoCEv2 MTU is derived from the Ethernet MTU.
- RoCEv2 MTU is the highest power-of-two that is less than the Ethernet MTU. For example:
 - if the Ethernet value is 1500, then the RoCEv2 MTU value is 1024
 - if the Ethernet value is 4096, then the RoCEv2 MTU value is 4096
 - if the Ethernet value is 9000, then the RoCEv2 MTU value is 4096

Windows NDPKI Modes of Operation

- The implementation of Network Direct Kernel Provider Interface (NDPKI) supports two modes of operation: Mode 1 and Mode 2. Mode 1 and Mode 2 relate to the implementation of Network Direct Kernel Provider Interface (NDKPI): Mode 1 is native RDMA, and Mode 2 involves configuration for the virtual port with RDMA. Cisco does not support NDPKI Mode 3 operation.
- The recommended default adapter policy for RoCEv2 Mode 1 is Win-HPN-SMBd .
- The recommended default adapter policy for RoCEv2 Mode 2 is MQ-SMBd.
- RoCEv2 enabled vNICs for Mode2 operation require the QoS host control policy set to full.

- Mode 2 is inclusive of Mode 1: Mode 1 must be enabled to operate Mode 2.
- On Windows, the RoCEv2 interface supports MSI & MSIx interrupt modes. By default, it is in MSIx interrupt mode. Cisco recommends you avoid changing interrupt mode when the interface is configured with RoCEv2 properties.

Downgrade Limitations

Cisco recommends you remove the RoCEv2 configuration before downgrading to any non-supported RoCEv2 release. If the configuration is not removed or disabled, downgrade will fail.

Configuring RoCEv2 Modes 1 and 2 in Windows

Configuration of RoCEv2 on the Windows platform requires first configuring RoCEv2 Mode 1, then configuring RoCEv2 Mode 2. Modes 1 and 2 relate to the implementation of Network Direct Kernel Provider Interface (NDKPI): Mode 1 is native RDMA, and Mode 2 involves configuration for the virtual port with RDMA.

To configure RoCEv2 mode 1, you must:

- Configure a no-drop class in CoS System Class. By default, Platinum with CoS 5 is a default in Cisco UCS Manager.
- Configure an Ethernet adapter policy for Mode 1 in Cisco UCS Manager.
- Configure Mode 1 on the host system.

RoCEv2 Mode 1 must be configured before configuring Mode 2.

To configure RoCEv2 mode 2, you will:

- Either create an Ethernet VMQ connection policy for RoCEv2 or use the Cisco UCS Manager MQ-SMBd policy.

Windows Requirements

Configuration and use of RDMA over Converged Ethernet for RoCEv2 in Windows Server requires the following:

- Windows 2019 or Windows Server 2022 with latest Microsoft updates
- UCS Manager release 4.1.1 or later
- VIC Driver version 5.4.0.x or later
- UCS M5 B-Series or C-Series servers with VIC 1400 Series adapters: only Cisco UCS VIC 1400 Series or VIC 15000 series adapters are supported.



Note

All Powershell commands or advanced property configurations are common across Windows 2019 and 2022 unless explicitly mentioned.

RoCEv2 for Linux

Guidelines for using NVMe over Fabrics (NVMeoF) with RoCEv2 on Linux

General Guidelines and Limitations

- Cisco recommends you check [UCS Hardware and Software Compatibility](#) specific to your Cisco UCS Manager release to determine support for NVMeoF. NVMeoF is supported on Cisco UCS M5 and later B-Series and C- Series servers.
- NVMe over RDMA with RoCEv2 is supported with the fourth generation Cisco UCS VIC 1400 Series, Cisco UCS VIC 14000, and Cisco UCS VIC 15000 Series adapters. NVMe over RDMA is not supported on Cisco UCS 6324 Fabric Interconnects or on Cisco UCS VIC 1200 Series and Cisco 1300 Series adapters.
- When creating RoCEv2 interfaces, use Cisco UCS Manager provided Linux-NVMe-RoCE adapter policy.



Note Do not use the default Linux Adapter policy with RoCEv2; RoCEv2 interfaces will not be created in the OS.

- When configuring RoCEv2 interfaces, use both the enic and enic_rdma binary drivers downloaded from Cisco.com and install the matched set of enic and enic_rdma drivers. Attempting to use the binary enic_rdma driver downloaded from Cisco.com with an inbox enic driver will not work.
- RoCEv2 supports maximum two RoCEv2 enabled interfaces per adapter.
- Booting from an NVMeoF namespace is not supported.
- Layer 3 routing is not supported.
- RoCEv2 does not support bonding.
- Saving a crashdump to an NVMeoF namespace during a system crash is not supported.
- NVMeoF cannot be used with usNIC, VMFEX, VxLAN, VMQ, VMMQ, NVGRE, GENEVE Offload, and DPDK features.
- Netflow monitoring is not supported on RoCEv2 interfaces.
- In the Linux-NVMe-RoCE policy, do not change values of Queue Pairs, Memory Regions, Resource Groups, and Priority settings other than to Cisco provided default values. NVMeoF functionality may not be guaranteed with different settings for Queue Pairs, Memory Regions, Resource Groups, and Priority.
- The QoS no drop class configuration must be properly configured on upstream switches such as Cisco Nexus 9000 series switches. QoS configurations will vary between different upstream switches.
- Set MTU size correctly on the VLANs and QoS policy on upstream switches.
- Spanning Tree Protocol (STP) may cause temporary loss of network connectivity when a failover or fallback event occurs. To prevent this issue from occurring, disable STP on uplink switches.

- Cisco UCS Manager does not support fabric failover for vNICs with RoCEv2 enabled.

Interrupts

- Linux RoCEv2 interface supports only MSIx interrupt mode. Cisco recommends avoiding changing interrupt mode when the interface is configured with RoCEv2 properties.
- The minimum interrupt count for using RoCEv2 with Linux is 8.

Downgrade Limitations

Cisco recommends you remove the RoCEv2 configuration before downgrading to any non-supported RoCEv2 release.

Linux Requirements

Configuration and use of RoCEv2 in Linux requires the following:

- InfiniBand kernel API module `ib_core`
- Cisco UCS Manager release 4.1.1 or later
- Minimum VIC firmware 5.1(1x) for IPv4 support and 5.1(2x) for IPv6 support
- Cisco UCS M5 and later B or C-series servers with Cisco UCS VIC 1400 or Cisco UCS VIC 15000 Series adapters
- eNIC driver version 4.0.0.6-802-21 or later provided with the 4.1.1 release package
- `enic_rdma` driver version 1.0.0.6-802-21 or later provided with the 4.1.1 release package



Note Use eNIC driver version 4.0.0.10-802.34 or later and `enic_rdma` driver version 1.0.0.10-802.34 or later for IPv6 support.

- A storage array that supports NVMeoF connection

RoCEv2 For ESXi

Guidelines for using RoCEv2 Protocol in the Native ENIC driver on ESXi

General Guidelines and Limitations

- Cisco UCS Manager release 4.2(3b) supports RoCEv2 only on ESXi 7.0 U3.
- Cisco recommends you check [UCS Hardware and Software Compatibility](#) specific to your Cisco UCS Manager release to determine support for ESXi. RoCEv2 on ESXi is supported on Cisco UCS B-Series and C-Series servers with Cisco UCS VIC 15000 Series and later adapters.

- RoCEv2 on ESXi is not supported on UCS VIC 1200, 1300 and 1400 Series adapters.
- RDMA on ESXi nENIC currently supports only ESXi NVME that is part of the ESXi kernel. The current implementation does not support the ESXi user space RDMA application.
- Multiple MAC addresses and multiple VLANs are supported only on VIC 15000 Series adapters.
- RoCEv2 supports maximum two RoCEv2 enabled interfaces per adapter.
- PvrDMA, VSAN over RDMA, and iSER are not supported.
- The COS setting is not supported on Cisco UCS Manager.

Downgrade Limitations

Cisco recommends you remove the RoCEv2 configuration before downgrading to any non-supported RoCEv2 release.

ESXi nENIC RDMA Requirements

Configuration and use of RoCEv2 in ESXi requires the following:

- VMWare ESXi version 7.0 U3.
- Cisco UCS Manager release 4.2.3 or later
- Nenic-2.0.4.0-IOEM.700.1.0.15843807.x86_64.vib provides both standard eNIC and RDMA support.
- A storage array that supports NVMeoF connection. Currently, tested and supported on Pure Storage with Cisco Nexus 9300 Series switches.

SR-IOV for ESXi

General Guidelines and Limitations for SR-IOV

- Cisco recommends that you check [UCS Hardware and Software Compatibility](#) specific to your Cisco UCS Manager release to determine support for SR-IOV.
- SR-IOV is supported with Cisco UCS VIC 1400 series, 15000 series, and later series adapters. SR-IOV is not supported on Cisco UCS VIC 1200 and 1300 series adapters.
- SR-IOV is supported with Cisco UCS M5, M6, and M7 AMD[®]/Intel[®] based C-Series/B-Series servers.
- SR-IOV cannot be configured on the same vNIC with VXLAN, Geneve Offload, QinQ, VMQ/VMMQ, RoCE, or usNIC.
- aRFS is not supported on SR-IOV VF.
- iSCSI boot is not supported on SR-IOV VF.
- DPDK on SRIOV VF is not supported when the host has Linux OS.
- SR-IOV interface supports MSIx interrupt mode.

- Precision Time Protocol (PTP) is not supported on SR-IOV VF.
- Cisco recommends not do downgrade the adapter firmware to lower than 5.3(2.32) and to remove SR-IOV related configurations before downgrading Cisco UCS Manger to non-supported SR-IOV release.
- For Cisco UCS VIC 1400/14000, Receive Side Scaling (RSS) must be enabled on PF to support VF RSS.



Note RSS turned off on PF disables the RSS on all VFs.

- For Cisco UCS VIC 15000 series adapters, turning off the the RSS on PF works on all the VFs.



Note The PF and VF RSS are independent of each other. The VF driver enables and configures RSS on VF, when there are multiple RQs.

ESXi Requirements for SR-IOV

- Cisco UCS Manager release 4.3.(2b) or later
- Cisco VIC firmware version 5.3(2.32) or later
- VMware ESXi 7.0U3 and 8.0 or later
- VMs with RHEL 8.7 or later and RHEL 9.0 or later
- Cisco NENIC driver version 2.0.10.0 for EXSi 7.0U3 and 2.0.11.0 for 8.0 and later
- Cisco RHEL ENIC driver version 4.4.0.1-930.10 or later



CHAPTER 3

Configuring RDMA Over Converged Ethernet (RoCE) version 2

- [Configuring RoCEv2 in Windows](#) , on page 11
- [Configuring RoCEv2 in Linux](#), on page 16
- [Configuring RoCEv2 in EXSi](#), on page 21
- [Using the UCS Manager CLI to Configure or Delete the RoCEv2 Interface](#) , on page 29
- [Known Issues in RoCEv2](#), on page 34

Configuring RoCEv2 in Windows

Configuring SMB Direct Mode 1 on Cisco UCS Manager

To avoid possible RDMA packet drops, make sure same no-drop COS is configured across the network.

Before you begin

Configure a no-drop class in UCSM QoS Policies and use it for RDMA supported interfaces. Go to **LAN > LAN Cloud > QoS System Class** and enable **Priority Platinum** with CoS 5.

-
- Step 1** In the **Navigation** pane, click **Servers**.
- Step 2** Expand **Servers > Policies**.
- Step 3** Expand the node for the organization where you want to create the policy.
If the system does not include multitenancy, expand the **root** node.
- Step 4** Expand **Adapter Policies** and choose the existing adapter policy for Win-HPN-SMBd.
If using a user-defined adapter policy, use the configuration steps below.
- a) On the **General** tab, scroll down to **RoCE** and click the **Enabled** radio button.
 - b) In the **RoCE Properties** field, under **Version 1**, click the **Disabled** radio button. For **Version 2**, click the **Enabled** radio button.
 - c) For **Queue Pairs**, enter **256**.
 - d) For **Memory Regions**, enter **131072**.

- e) For **Resource Groups**, enter 2.
- f) For **Priority**, choose **Platinum No-Drop COS**. from the dropdown.
- g) Click **Save Changes**.

Step 5 Next, create an Ethernet Adapter Policy. In the Navigation pane, click **LAN**.

Step 6 Expand **LAN > Policies**.

Step 7 Right-click the **vNIC Templates** node and choose **Create vNIC Template**.

Step 8 Go to **vNIC Properties** under the General tab and modify the vNIC policy settings as follows:

- a) Set **MTU** to **1500** or **4096**.
- b) For the Adapter Policy, select **Win-HPN-SMBd**
- c) For the **QoS policy**, specify **Platinum**.

Step 9 Click **Save Changes**.

Step 10 After you save the changes, Cisco UCS Manager will prompt you to reboot. Reboot the system.

What to do next

When the server comes back up, configure RoCEv2 mode 1 on the Host.

Configuring SMB Direct Mode 1 on the Host System

Perform this procedure to configure a connection between smb-client and smb-server on two host interfaces. For each of these servers, smb-client, and smb-server, configure the RoCEv2-enabled vNIC.

Before you begin

Configure RoCEv2 for Mode 1 in Cisco UCS Manager.

Step 1 In the Windows host, go to the **Device Manager** and select the appropriate Cisco VIC Internet Interface.

Step 2 Select the **Advanced** tab and verify that the **Network Direct Functionality** property is **Enabled**. If not, enable it and click **OK**.

Perform this step for both the smb-server and smb-client vNICs.

Step 3 Go to **Tools > Computer Management > Device Manager > Network Adapter > click VIC Network Adapter > Properties > Advanced > Network Direct Functionality**. Perform this operation for both the smb-server and smb-client vNICs.

Step 4 Verify that RoCE is enabled on the host operating system using PowerShell.

Execute the **Get-NetOffloadGlobalSetting** command to verify that **NetworkDirect** is enabled:

```
PS C:\Users\Administrator> Get-NetOffloadGlobalSetting
```

```
ReceiveSideScaling           : Enabled
ReceiveSegmentCoalescing    : Enabled
Chimney                      : Disabled
TaskOffload                  : Enabled
NetworkDirect                : Enabled
NetworkDirectAcrossIPSubnets : Blocked
PacketCoalescingFilter      : Disabled
```

Note If the **NetworkDirect** setting is showing as disabled, enable it using the following command:

```
Set-NetOffloadGlobalSetting -NetworkDirect enabled
```

Step 5 Bring up the Powershell and execute the **get -SmbClientNetworkInterface** command.

```
PS C:\Users\Administrator>
PS C:\Users\Administrator> Get-SmbClientNetworkInterface
Interface Index      RSS Capable      RDMA Capable      Speed      IpAddresses      Friendly Name
-----
14                   True              False              40 Gbps    {10.37.60.162}    vEthernet (vswitch)
26                   True              True               40 Gbps    {10.37.60.158}    vEthernet (vpl)
9                    True              True               40 Gbps    {50.37.61.23}     Ethernet 2
5                    False             False              40 Gbps    {169.254.10.S}    Ethernet (Kernel
Debugger)
8                    True              False              40 Gbps    {169.254.4.26}    Ethernet 3
PS C:\Users\Administrator>
```

Step 6 Enter **enable - netadapterrDMA [-name] ["Ethernetname"]**

Step 7 Verify the overall RoCEv2 Mode 1 configuration at the host:

- a) Use the Powershell command **netstat -xan** to verify the listeners in both the smb-client and smb-server Windows host; listeners will be shown in the command output.

```
PS C:\Users\Administrator>
PS C:\Users\Administrator> netstat -xan
Active NetworkDirect Connections, Listeners, SharedEndpoints
Mode IfIndex Type Local Address Foreign Address PID
-----
Kernel 9 Listener 50.37.61.23:445 NA 0
Kernel 26 Listener 10.37.60.158:445 NA 0
PS C:\Users\Administrator>
```

- b) Go to the smb-client server fileshare and start an I/O operation.
c) Go to the performance monitor and check that it displays the RDMA activity.

Step 8 In the Powershell command window, check the connection entries with the **netstat -xan** output command to make sure they are displayed. You can also run **netstat -xan** from the command prompt. If the connection entry shows up in netstat-xan output, the RoCEv2 mode1 connections are correctly established between client and server.

```
PS C:\Users\Administrator> netstat -xan
Active NetworkDirect Connections, Listeners, SharedEndpoints
Mode IfIndex Type Local Address Foreign Address PID
-----
Kernel 4 Connection 50.37.61.22:445 50.37.61.71:2240 0
Kernel 4 Connection 50.37.61.22:445 50.37.61.71:2496 0
Kernel 11 Connection 50.37.61.122:445 50.37.61.71:2752 0
Kernel 11 Connection 50.37.61.122:445 50.37.61.71:3008 0
Kernel 32 Connection 10.37.60.155:445 50.37.60.61:49092 0
Kernel 32 Connection 10.37.60.155:445 50.37.60.61:49348 0
Kernel 26 Connection 50.37.60.32:445 50.37.60.61:48580 0
Kernel 26 Connection 50.37.60.32:445 50.37.60.61:48836 0
Kernel 4 Listener 50.37.61.22:445 NA 0
Kernel 11 Listener 50.37.61.122:445 NA 0
Kernel 32 Listener 10.37.60.155:445 NA 0
Kernel 26 Listener 50.37.60.32:445 NA 0
```

Step 9 By default, Microsoft's SMB Direct establishes two RDMA connections per RDMA interface. You can change the number of RDMA connections per RDMA interface to one or any number of connections.

For example, to increase the number of RDMA connections to 4, execute the following command in PowerShell:

```
PS C:\Users\Administrator> Set-ItemProperty -Path ` "HKLM:\SYSTEM\CurrentControlSet\Services
\LanmanWorkstation\Parameters" ConnectionCountPerRdmaNetworkInterface -Type DWORD -Value 4 -Force
```

Configuring Mode 2 on Cisco UCS Manager

You will apply the VMQ Connection Policy as vmmq.

Before you begin

Configure RoCEv2 Policies in Mode 1.

Use the pre-defined default adapter policy “MQ-SMBd”, or configure a user-defined Ethernet adapter policy with the following recommended RoCE-specific parameters:

- RoCE: Enabled
- Version 1: disabled
- Version 2: enabled
- Queue Pairs: 256
- Memory Regions: 65536
- Resource Groups: 2
- Priority: Platinum

Create a VMQ connection policy with the following values:

- Multi queue: Enabled
- Number of sub-vNIC: 16
- VMMQ adapter policy: MQ-SMBd

-
- Step 1** In the **Navigation** pane, click **Servers**.
- Step 2** Expand **Servers** > **Service Profiles**.
- Step 3** Expand **Service Profiles** > **vNICs** and choose the VMQ Connection policy profile to configure.
- Step 4** Go to **vNIC Properties** under the General tab and scroll down to the Policies area. Modify the vNIC policy settings as follows:
- a) For the Adapter Policy, make sure it uses **win-HPN-SMBd** or the adapter policy configured earlier for Mode 1.
 - b) For the **QoS policy**, select **best-effort**.
- Step 5** Click **Save Changes**.
- Step 6** In the Navigation pane, click **LAN**.
- Step 7** Expand **LAN** > **Policies** > **QoS Policy Best Effort**.
- Step 8** Set **Host Control** to **Full**.
- Step 9** Click **Save Changes**.

Step 10 After you save the changes, Cisco UCS Manager will prompt you to reboot. Reboot the interface.

What to do next

When the server comes back up, configure Mode 2 on the Host.

Configuring SMB Direct Mode 2 on the Host System

This task uses Hyper-V virtualization software that is compatible with Windows Server 2019 and later.

Before you begin

- Configure and confirm the connection for RoCEv2 Mode 2 for both the Cisco UCS Manager and Host.
- Configure RoCEv2 Mode 2 in Cisco UCS Manager.
- Enable Hyper-V at the Windows host server.

Step 1 Go to the Hyper-V switch manager.

Step 2 Create a new Virtual Network Switch (vswitch) for the RoCEv2-enabled Ethernet interface.

- Choose **External Network** and select **VIC Ethernet Interface 2** and **Allow management operating system to share this network adapter**.
- Click **OK** to create the virtual switch.

Bring up the Powershell interface.

Step 3 Configure the non-default vport and enable RDMA with the following Powershell commands:

```
add-vmNetworkAdapter -switchname vswitch -name vpl -managementOS
```

```
enable-netAdapterRdma -name "vEthernet (vpl)"
```

```
PS C:\Users\Administrator>
```

```
PS C:\Users\Administrator> add - vmNet workAdapter -switchName vswitch -name vpl -managementOS
```

```
PS C:\Users\Administrator> enable-netAdapterRdma -name "vEthernet (vpl)"
```

```
PS C:\Users\Administrator>
```

- Configure the set-switch using the following Powershell command.

```
new-vmSwitch -name setswitch -netAdapterName "Ethernet x" -enableEmbeddedTeam $true
```

This creates the switch. Use the following to display the interfaces:

```
get-netadapterrdma
```

```
add-vmNetworkAdapter -switchname setswtch -name svpl
```

You will see the new vport when you again enter

```
get-netadapterrdma
```

- Add a vport:

```
add-vmNetworkAdapter -switchname setswtch -name svpl
```

You see the new vport when you again enter:

```
get-netadapterrdma
```

- c) Enable the RDMA on the vport:

```
enable-netAdapterRdma -name "vEthernet (svp1)"
```

Step 4 Configure the IPv4 addresses on the RDMA enabled vport in both servers.

Step 5 Create a share in smb-server and map the share in the smb-client.

- a) For smb-client and smb-server in the host system, configure the RoCEv2-enabled vNIC as described above.
 b) Configure the IPv4 addresses of the primary fabric and sub-vNICs in both servers, using the same IP subnet and same unique VLAN for both.
 c) Create a share in smb-server and map the share in the smb-client.

Step 6 Finally, verify the Mode 2 configuration.

- a) Use the Powershell command **netstat -xan** to display listeners and their associated IP addresses.

```
PS C:\Users\Administrator>
PS C:\Users\Administrator> netstat -xan
Active NetworkDirect Connections, Listeners, SharedEndpoints
Mode IfIndex Type Local Address Foreign Address PID
Kernel 9 Listener 50.37.61.23:445 NA 0
Kernel 26 Listener 10.37.60.158:445 NA 0
PS C:\Users\Administrator>
```

- b) Start any RDMA I/O in the file share in smb-client.
 c) Issue the **netstat -xan** command again and check for the connection entries to verify they are displayed.

```
PS C:\Users\Administrator>
PS C:\Users\Administrator> netstat -xan
Active NetworkDirect Connections, Listeners, SharedEndpoints
Mode IfIndex Type Local Address Foreign Address PID
Kernel 9 Connection 50.37.61.23:192 50.37.61.184:445 0
Kernel 9 Connection 50.37.61.23:448 50.37.61.184:445 0
Kernel 9 Connection 50.37.61.23:704 50.37.61.214:445 0
Kernel 9 Connection 50.37.61.23:960 50.37.61.214:445 0
Kernel 9 Connection 50.37.61.23:1216 50.37.61.224:44 05
Kernel 9 Connection 50.37.61.23:1472 50.37.61.224:445 0
Kernel 9 Connection 50.37.61.23:1728 50.37.61.234:445 0
Kernel 9 Connection 50.37.61.23:1984 50.37.61.234:445 0
Kernel 9 Listener 50.37.61.23:445 NA
Kernel 26 Listener 10.37.60.158:445 NA
PS C:\Users\Administrator>
```

Configuring RoCEv2 in Linux

Configuring NVMeoF Using RoCEv2 on Cisco UCS Manager

Use these steps to configure the RoCEv2 interface on Cisco UCS Manager.

Step 1 In the **Navigation** pane, click **Servers**.

Step 2 Expand **Servers** > **Service Profiles**.

Step 3 Expand the node for the organization where you want to create the policy.

If the system does not include multitenancy, expand the **root** node.

- Step 4** Click on **vNICs** and go to the **Network** tab in the work area.
- Modify the vNIC policy, according to the steps below.
- On the **Network** tab, scroll down to the desired vNIC and click on it, then click **Modify**.
 - A popup dialog box will appear. Scroll down to the **Adapter Performance Profile** area, and click on the **Adapter Policy** drop-down. Choose **Linux-NVMe-RoCE** from the drop-down list.
 - Click **OK**.
- Step 5** Click **Save Changes**.

What to do next

[Enabling an SR-IOV BIOS Policy, on page 17](#)

Enabling an SR-IOV BIOS Policy

Use these steps to configure the server's service profile with the SRIOV BIOS policy before enabling the IOMMU in the Linux kernel.

- Step 1** In the the **Navigation** pane, click **Servers**.
- Step 2** Expand **Servers > Service Profiles**.
- Step 3** Expand the node for the organization where you want to create the policy.
- If the system does not include multitenancy, expand the **root** node.
- Step 4** Select the service profile node where you want to enable SR-IOV.
- Step 5** In the Work pane, select **Policies** tab.
- Step 6** In the Policies Area, expand **BIOS Policy**.
- Step 7** Choose the default SR-IOV policy from the **BIOS Policy** drop-down list.
- Step 8** Click **Save Changes**.

Configuring NVMeoF Using RoCEv2 on the Host

Before you begin

Configure the server with RoCEv2 vNIC and the SRIOV-enabled BIOS policy.

- Step 1** Open the `/etc/default/grub` file for editing.
- Step 2** Add `intel_iommu=on` to the end of the line for `GRUB_CMDLINE_LINUX` as shown in the sample file below.

```
sample /etc/default/grub configuration file after adding intel_iommu=on:
# cat /etc/default/grub
GRUB_TIMEOUT=5
GRUB_DISTRIBUTOR="$(sed 's, release .*$,,g' /etc/system-release)"
GRUB_DEFAULT=saved
GRUB_DISABLE_SUBMENU=true
GRUB_TERMINAL_OUTPUT="console"
```

```
GRUB_CMDLINE_LINUX="crashkernel=auto rd.lvm.lv=rhel/root rd.lvm.lv=rhel/swap biosdevname=1 rhgb quiet
intel_iommu=on
GRUB_DISABLE_RECOVERY="true"
```

Step 3 Save the file.

Step 4 After saving the file, run the following command to generate a new grub.cfg file:

- For Legacy boot:

```
# grub2-mkconfig -o /boot/grub2/grub.cfg
```

- For UEFI boot:

```
# grub2-mkconfig -o /boot/grub2/efi?EFI/redhat/grub.cfg
```

Step 5 Reboot the server. You must reboot your server for the changes to take after enabling IOMMU.

Step 6 Verify that the server booted with the `intel_iommu=on` option by checking the output file.

```
cat /proc/cmdline | grep iommu
```

Note its inclusion at the end of the output.

```
[root@localhost basic-setup]# cat /proc/cmdline | grep iommu
BOOT_IMAGE=/vmlinuz-3.10.0-957.27.2.el7.x86_64 root=/dev/mapper/rhel-
root ro crashkernel=auto rd.lvm.lv=rhel/root rd.lvm.lv=rhel/swap rhgb
quiet intel_iommu=on LANG=en_US.UTF-8
```

What to do next

Download the enic and enic_rdma drivers.

Installing Cisco enic and enic_rdma Drivers

The enic_rdma driver requires enic driver. When installing enic and enic_rdma drivers, download and use the matched set of enic and enic_rdma drivers on Cisco.com. Attempting to use the binary enic_rdma driver downloaded from Cisco.com with an inbox enic driver, will not work.

Step 1 Install the enic and enic_rdma rpm packages:

```
# rpm -ivh kmod-enic-<version>.x86_64.rpm kmod-enic_rdma-<version>.x86_64.rpm
```

Note During enic_rdma installation, the enic_rdmalibnvdimm module may fail to install on RHEL 7.7 because the `nvdimm-security.conf` dracut module needs spaces in the `add_drivers` value. For workaround, please follow the instruction from the following links:

<https://access.redhat.com/solutions/4386041>

https://bugzilla.redhat.com/show_bug.cgi?id=1740383

Step 2 The enic_rdma driver is now installed but not loaded in the running kernel. Reboot the server to load enic_rdma driver into the running kernel.

Step 3 Verify the installation of enic_rdma driver and RoCE v2 interface:

```
# dmesg | grep enic_rdma
[ 4.025979] enic_rdma: Cisco VIC Ethernet NIC RDMA Driver, ver 1.0.0.6-802.21 init
```

```
[ 4.052792] enic 0000:62:00.1 eth1: enic_rdma: IPv4 RoCEv2 enabled
[ 4.081032] enic 0000:62:00.2 eth2: enic_rdma: IPv4 RoCEv2 enabled
```

Step 4 Load the vme-rdma kernel module:

```
# modprobe nvme-rdma
```

After server reboot, nvme-rdma kernel module is unloaded. To load nvme-rdma kernel module every server reboot, create nvme_rdma.conf file using:

```
# echo nvme_rdma > /etc/modules-load.d/nvme_rdma.conf
```

Note For more information about enic_rdma after installation, use the `rpm -q -l kmod-enic_rdma` command to extract the README file.

What to do next

Discover targets and connect to NVMe namespaces. If your system needs multipath access to the storage, please go to the section for [Setting Up Device Mapper Multipath, on page 20](#).

Discovering the NVMe Target

Use this procedure to discover the NVMe target and connect NVMe namespaces.

Before you begin

Install `nvme-cli` version 1.6 or later if it is not installed already.



Note Skip to Step 2 below if nvme-cli version 1.7 or later is installed.

Configure the IP address on the RoCE v2 interface and make sure the interface can ping the target IP.

Step 1 Create an nvme folder in /etc, then manually generate host nqn.

```
# mkdir /etc/nvme
# nvme gen-hostnqn > /etc/nvme/hostnqn
```

Step 2 Create a settos.sh file and run the script to set priority flow control (PFC) in IB frames.

Note To avoid failure of sending NVMeoF traffic, you *must* create and run this script after *every* server reboot.

```
# cat settos.sh
#!/bin/bash
for f in `ls /sys/class/infiniband`;
do
    echo "setting TOS for IB interface:" $f
    mkdir -p /sys/kernel/config/rdma_cm/$f/ports/1
    echo 186 > /sys/kernel/config/rdma_cm/$f/ports/1/default_roce_tos
done
```

Step 3 Discover the NVMe target by entering the following command.

```
nvme discover --transport=rdma --traddr=<IP address of transport target port>
```

For example, to discover the target at 50.2.85.200:

```
# nvme discover --transport=rdma --traddr=50.2.85.200

Discovery Log Number of Records 1, Generation counter 2
=====Discovery Log Entry 0=====
trtype: rdma
adrfam: ipv4
subtype: nvme subsystem
treq: not required
portid: 3
trsvcid: 4420
subnqn: nqn.2010-06.com.purestorage:flasharray.9a703295ee2954e
traddr: 50.2.85.200
rdma_prtype: roce-v2
rdma_qptype: connected
rdma_cms: rdma-cm
rdma_pkey: 0x0000
```

Note To discover the NVMe target using IPv6, put the IPv6 target address next to the `traddr` option.

Step 4 Connect to the discovered NVMe target by entering the following command.

```
nvme connect --transport=rdma --traddr=<IP address of transport target port>> -n <subnqn
value from nvme discover>
```

For example, to discover the target at 50.2.85.200 and the subnqn value found above:

```
# nvme connect --transport=rdma --traddr=50.2.85.200 -n nqn.2010-06.com.purestorage:flasharray.
9a703295ee2954e
```

Note To connect to the discovered NVMe target using IPv6, put the IPv6 target address next to the `traddr` option.

Step 5 Use the `nvme list` command to check mapped namespaces:

```
# nvme list
Node          SN                      Model                      Namespace Usage          Format          FW Rev
-----
/dev/nvme0n1  09A703295EE2954E Pure Storage FlashArray 72656 4.29 GB/4.29 GB 512 B + 0 B 99.9.9
/dev/nvme0n2  09A703295EE2954E Pure Storage FlashArray 72657 5.37 GB/5.37 GB 512 B + 0 B 99.9.9
```

Setting Up Device Mapper Multipath

If your system is configured with Device Mapper multipathing (DM Multipath), use the following steps to set up Device Mapper multipath.

Step 1 Install the `device-mapper-multipath` package if it is not installed already

Step 2 Enable and start `multipathd`:

```
# mpathconf --enable --with_multipathd y
```

Step 3 Edit the `etc/multipath.conf` file to use the following values :

```
defaults {
polling_interval    10
path_selector       "queue-length 0"
path_grouping_policy multibus
fast_io_fail_tmo    10
```

```

no_path_retry    0
features        0
dev_loss_tmo    60
user_friendly_names  yes
}

```

Step 4 Flush with the updated multipath device maps.

```
# multipath -F
```

Step 5 Restart multipath service:

```
# systemctl restart multipathd.service
```

Step 6 Rescan multipath devices:

```
# multipath -v2
```

Step 7 Check the multipath status:

```
# multipath -ll
```

Deleting the RoCEv2 Interface Using Cisco UCS Manager

Use these steps to remove the RoCE v2 interface

Step 1 In the **Navigation** pane, click **Servers**.

Step 2 Expand **Servers** > **Service Profiles**.

Step 3 Expand the node for the organization where you want to create the policy.

If the system does not include multitenancy, expand the **root** node.

Step 4 Modify the vNIC policy, according to the steps below.

- a) On the **Network** tab, scroll down to the desired vNIC and click on it, then click **Modify**.
- b) A popup dialog box will be displayed. Scroll down to the **Policies** area, and choose **Linux** from the **Adapter Policy** drop-down list.
- c) Click **OK**.

Step 5 Click **Save Changes**.

Configuring RoCEv2 in EXSi

Installing NENIC Driver

The eNIC drivers, which contain the RDMA driver, are available as a combined package. Download and use the eNIC driver on cisco.com.

These steps assume this is a new installation.



Note While this example uses the `/tmp` location, you can place the file anywhere that is accessible to the ESX console shell.

Step 1 Copy the eNIC VIB or offline bundle to the ESX server. The example below uses the Linux `scp` utility to copy the file from a local system to an ESX server located at `10.10.10.10`: and uses the location `/tmp`.

```
scp nenic-2.0.4.0-1OEM.700.1.0.15843807.x86_64.vib root@
10.10.10.10:/tmp
```

Step 2 Specifying the full path, issue the command shown below.

```
esxcli software vib install -v {VIBFILE}
```

or

```
esxcli software vib install -d {OFFLINE_BUNDLE}
```

Example:

```
esxcli software vib install -v /tmp/nenic-2.0.4.0-1OEM.
700.1.0.15843807.x86_64.vib
```

Note Depending on the certificate used to sign the VIB, you may need to change the host acceptance level. To do this, use the command: `esxcli software acceptance set --level=<level>`

Depending on the type of VIB being installed, you may need to put ESX into maintenance mode. This can be done through the VI Client, or by adding the `--maintenance-mode` option to the above `esxcli` command.

Upgrading NENIC Driver

a. To upgrade NENIC driver, enter the command:

```
esxcli software vib update -v {VIBFILE}
```

or

```
esxcli software vib update -d {OFFLINE_BUNDLE}
```

b. Copy the enic VIB or offline bundle to the ESX server using Step 1 given above.

What to do next

Create and configure the Adapter Policy for ESXi NVMe RDMA in Cisco UCS Manager.

Configuring and Enabling RoCEv2 on UCS Manager

Configuring NVMeoF using RoCEv2 for ESXi on UCS Manager

UCS Manager contains a default adapter policy that is prepopulated with operational parameters, so you do not need to manually create the adapter policy. However, you do need to create the RoCEv2 interface.

Use these steps to configure the RoCEv2 interface on UCS Manager.

-
- Step 1** In the **Navigation** pane, click **Servers**.
- Step 2** Expand **Servers > Service Profiles**.
- Step 3** Expand the node for the organization where you want to create the policy.
If the system does not include multitenancy, expand the **root** node.
- Step 4** Click on a RDMA service profile you created and expand the service profile.
- Step 5** Right-click on **vNICs** and choose **Create vNIC** to create a new vNIC.
The **Create vNIC** pop-up menu is displayed.
Perform the below steps to modify the vNIC policy:
- Name the new vNIC.
 - On the **MAC address** dropdown, select the option from Manual using OUI or Domain Pools in the drop-down.
 - Select which VLAN you want use use from the list.
 - In the Adapter Performance Profile, select the default adapter policy named `VMWareNVMeRoCEv2`.
 - Click **OK**. The interface is now configured for one port.
- Step 6** Click **Save Changes**.
-

What to do next

Configure the Host side for ESXi NVMe RDMA.

ESXi NVMe RDMA Host Side Configuration

NENIC RDMA Functionality

Differences between the use case for RDMA on Linux and ESXi:

- In ESXi, the physical interface (vnic) MAC is not used fo RoCEv2 traffic. Instead, the VMkernel port (vmk) MAC is used.

Outgoing RoCE packets use the vmk MAC in the Ethernet source MAC field, and incoming RoCE packets use the vmk MAC in the Ethernet destination mac field. The vmk MAC address is a VMware MAC address assigned to the vmk interface when it is created.

- In Linux, the physical interface MAC is used in source MAC address field in the RoCE packets. This Linux MAC is usually a Cisco MAC address configured to the vNIC using Cisco UCS Manager.

If you ssh into the host and use the `esxcli network ip interface list` command, you can see the MAC address.

```
vmko
Name: vmko
MAC Address: 2c:f8:9b:a1:4c:e7
Enabled: true
Portset: vSwitch0
Portgroup: Management Network
Netstack Instance: defaultTcpipStack
VDS Name: N/A
VDS UUID: N/A
```

```
VDS Port: N/A
VDS Connection: -1
Opaque Network ID: N/A
Opaque Network Type: N/A
External ID: N/A
MTU: 1500
TSO MSS: 65535
RXDispQueue Size: 2
Port ID: 67108881
```

You must create a vSphere Standard Switch to provide network connectivity for hosts, virtual machines, and to handle VMkernel traffic. Depending on the connection type that you want to create, you can create a new vSphere Standard Switch with a VMkernel adapter, only connect physical network adapters to the new switch, or create the switch with a virtual machine port group.

Create Network Connectivity Switches

Use these steps to create a vSphere Standard Switch to provide network connectivity for hosts, virtual machines, and to handle VMkernel traffic.

Before you begin

Ensure that you have downloaded and installed the NENIC drivers.

-
- Step 1** In the vSphere Client, navigate to the host.
- Step 2** On the **Configure** tab, expand **Networking** and select **Virtual Switches**.
- Step 3** Click on **Add Networking**.

The available network adapter connection types are:

- **Vmkernel Network Adapter**
Creates a new VMkernel adapter to handle host management traffic
- **Physical Network Adapter**
Adds physical network adapters to a new or existing standard switch.
- **Virtual Machine Port Group for a Standard Switch**
Creates a new port group for virtual machine networking.

- Step 4** Select connection type **Vmkernel Network Adapter**.
- Step 5** Select **New Standard Switch** and click **Next**.
- Step 6** Add physical adapters to the new standard switch.
- a) Under **Assigned Adapters**, select **New Adapters**.
 - b) Select one or more adapters from the list and click **OK**. To promote higher throughput and create redundancy, add two or more physical network adapters to the Active list.
 - c) (Optional) Use the up and down arrow keys to change the position of the adapter in the Assigned Adapters list.
 - d) Click **Next**.
- Step 7** For the new standard switch you just created for the VMadapter or a port group, enter the connection settings for the adapter or port group.
- a) Enter a label that represents the traffic type for the VMkernel adapter.

- b) Set a VLAN ID to identify the VLAN the VMkernel uses for routing network traffic.
- c) Select IPV4 or IPV6 or both.
- d) Select an MTU size from the drop-down menu. Select Custom if you wish to enter a specific MTU size. The maximum MTU size is 9000 bytes.

Note You can enable Jumbo Frames by setting an MTU greater than 1500.

- e) After setting the TCP/IP stack for the VMkernel adapter, select a TCP/IP stack.
To use the default TCP/IP stack, select it from the available services.

Note Be aware that the TCP/IP stack for the VMkernel adapter cannot be changed later.

- f) Configure IPV4 and/or IPV6 settings.

Step 8 On the **Ready to Complete** page, click **Finish**.

Step 9 Check the VMkernel ports for the VM Adapters or port groups with NVMe RDMA in the vSphere client, as shown in the Results below.

What to do next

Create vmhba ports on top of vmrdma ports.

Create VMHBA Ports in ESXi

Use the following steps for creating vmhba ports on top of the vmrdma adapter ports.

Before you begin

Create the adapter ports for storage connectivity.

Step 1 Go to vCenter where your ESXi host is connected.

Step 2 Click on **Host>Configure>Storage adapters**.

Step 3 Click **+Add Software Adapter**.

Add Software Adapter dialog box is displayed.

Step 4 Select **Add software NVMe over RDMA adapter** and the vmrdma port you want to use.

Step 5 Click **OK**

The vmhba ports for the VMware NVMe over RDMA storage adapter will be shown.

What to do next

Configure NVMe.

Displaying vmnic and vmrmda Interfaces

ESXi creates a vmnic interface for each enic VNIC configured to the host.

Before you begin

Create Network Adapters and VHBA ports.

Step 1 Use `ssh` to access the host system.

Step 2 Enter `esxcfg-nics -l` to list the vmnics on ESXi.

```

Name PCI Driver Link Speed Duplex MAC Address MTU Description
vmnico 0000:3b:00.0 ixgben Down 0Mbps Half 2c:f8:9b:a1:4c:e6 1500 Intel(R) Ethernet Controller
X550
vmnic1 0000:36:00.1 ixgben Up 1000Mbps Full 2c:f8:9b:a1:4c:e7 1500 Intel(R) Ethernet Controller
X550
vmnic2 0000:1d:00.0 nenic Up 50000Mbps Full 2c:f8:9b:79:8d:bc 1500 Cisco Systems Inc Cisco
VIC Ethernet NIC
vmnic3 0000:1d:00.1 nenic Up 50000Mbps Full 2c:f8:9b:79:8d:bd 1500 Cisco Systems Inc Cisco
VIC Ethernet NIC
vmnic4 0000:63:00.0 nenic Down 0Mbps Half 2c:f8:9b:51:b3:3a 1500 Cisco Systems Inc Cisco
VIC Ethernet NIC
Venic5 0000:63:00.1 nenic Down 0Mbps Half 2c:f8:9b:51:b3:3b 1500 Cisco Systems Inc Cisco
VIC Ethernet NIC

```

esxcli network nic list

```

Name PCI Driver Admin Status Link Status Speed Duplex MAC Address MTU Description
vmnico 0000:3b:00.0 ixgben Up Down 0 Half 2c:f8:9b:a1:4c:e6 1500 Intel(R)
Ethernet Controller X550
vmnic1 0000:36:00.1 ixgben Up Up 1000 Full 2c:f8:9b:a1:4c:e7 1500 Intel(R)
Ethernet Controller X550
vmnic2 0000:1d:00.0 nenic Up Up 50000 Full 2c:f8:9b:79:8d:bc 1500 Cisco Systems
Inc Cisco VIC Ethernet NIC
vmnic3 0000:1d:00.1 nenic Up Up 50000 Full 2c:f8:9b:79:8d:bd 1500 Cisco Systems
Inc Cisco VIC Ethernet NIC
vmnic4 0000:63:00.0 nenic Up Down 0 Half 2c:f8:9b:51:b3:3a 1500 Cisco Systems
Inc Cisco VIC Ethernet NIC
Venic5 0000:63:00.1 nenic Up Down 0 Half 2c:f8:9b:51:b3:3b 1500 Cisco Systems
Inc Cisco VIC Ethernet NIC

```

When the enic driver registers with ESXi the RDMA device for a RDMA capable VNIC, ESXi creates a vmrmda device and links it to the corresponding vmnic.

Step 3 Use `esxcli rdma device list` to list the vmrmda devices.

```

[root@RackServer:~] esxcli rdma device list
Name Driver State MTU Speed Paired Uplink Description
-----
vmrmda0 nenic Active 4096 50 Gbps vmnic1 Cisco UCS VIC 15XXX (A0)
vmrmda1 nenic Active 4096 50 Gbps vmnic2 Cisco UCS VIC 15XXX (A0)
[root@StockholmRackServer:~] esxcli rdma device vmknic list
Device Vmknic NetStack
-----
vmrmda0 vmk1 defaultTcpipStack
vmrmda1 vmk2 defaultTcpipStack

```

Step 4 Use `esxcli rdma device list` to check the protocols supported by the vmrmda interface.

For enic, RoCE v2 will be the only protocol supported from this list. The output of this command should match the RoCEv2 configuration on the VNIC.

Step 5 Use **esxcli rdma device protocol list** to check the protocols supported by the vmdma interface.

For enic RoCE v2 will be the only protocol supported from this list. The output of this command should match the RoCEv2 configuration on the VNIC.

```
[root@RackServer:~] esxcli rdma protocol list
Device  RoCE v1  RoCE v2  iWARP
-----  -
vmdma0  false   true    false
vmdma1  false   true    false
```

Step 6 Use **esxcli nvme adapter list** to list the NVMe adapters and the vmdma and vmnic interfaces it is configured on.

```
[root@RackServer:~] esxcli nvme adapter list
Adapter Adapter Qualified Name      Transport Type Driver  Associated Devices
-----  -
vmhba64 aqn: nvmerdma:2c-f8-9b-79-8d-bc RDMA      nvmerdma vmdmaR, vmnic2
vmhba65 aqn: nvmerdma:2c-f8-9b-79-8d-bd RDMA      nvmerdma vmdma1, vmnic3
```

Step 7 All vmhbas in the system can be listed using **esxcli storage core adapter list**.

```
[root@RackServer:~] esxcli storage core adapter list
HBA Name Driver  Link State UID                               Capabilities  Description
-----  -
vmhba0  nfnic  link-down  fc.10002cf89b798dbe:20002cf89b798dbe Second Level Lun ID (0000:1d:00.2)
Cisco Corporation Cisco
Controller
UCS VIC Fnic
vmhba1  vmw_ahci link-n/a  sata.vmhba1                               (0000:00:11.5)
Intel Corporation Lewisburg
SATA AHCI
Controller
vmhba2  nfnic  link-down  fc.10002cf89b798dbf:20002cf89b798dbf Second Level Lun ID (0000:1d:00.3)
Cisco Corporation Cisco
UCS VIC Fnic
Controller
vmhba3  nfnic  link-down  fc.10002cf89b51b33c:20002cf89b51b33c Second Level Lun ID (0000:63:00.2)
Cisco Corporation Cisco
UCS VIC Fnic
Controller
vmhba4  nfnic  link-down  fc.10002cf89b51b33d:20002cf89b51b33d Second Level Lun ID (0000:63:00.3)
Cisco Corporation Cisco
UCS VIC Fnic
Controller
vmhba5  lsi_mr3 link-n/a  sas.5cc167e9732f9b00                               (0000:3c:00.0)
Broadcom Cisco 126 Modular
Raid Controller
with 2GB cache
vmhba64 nvmerdma link-n/a  rdma.vmnic2:2c:f8:9b:79:8d:bc VMware NVMe over
RDMA Storage Adapter on vmdma0
vmhba65 nvmerdma link-n/a  rdma.vmnic3:2c:f8:9b:79:8d:bd VMware NVMe over
RDMA Storage Adapter on vmdma1
```

What to do next

Configure NVME.

NVMe Fabrics and Namespace Discovery

This procedure is performed through the ESXi command line interface.

Before you begin

Create and configure NVME on the adapter's VMHBAs. The maximum number of adapters is two, and it is a best practice to configure both for fault tolerance.

Step 1 Check and enable NVME on the vmrdma device.

```
esxcli nvme fabrics enable -p RDMA -d vmrdma0
```

The system should return a message showing if NVME is enabled.

Step 2 Discover the NVMe fabric on the array by entering the following command:

```
esxcli nvme fabrics discover -a vmhba64 -l transport_address
```

figure with `esxcli nvme fabrics discover -a vmhba64 -l 50.2.84.100`

The output lists the following information: Transport Type, Address Family, Subsystem Type, Controller ID, Admin Queue, Max Size, Transport Address, Transport Service ID, and Subsystem NQN

You will see output on the NVMe controller.

Step 3 Perform NVMe fabric interconnect.

```
esxcli nvme fabrics discover -a vmhba64 -l transport_address p Transport Service ID -s Subsystem NQN
```

Step 4 Repeat steps 1 through 4 to configure the second adapter.

Step 5 Display the controller list to verify the NVMe controller is present and operating.

```
esxcli nvme controller list RDMA -d vmrdma0
```

```
[root@RackServer:~] esxcli nvme controller list
Name
-----
nqn.2010-06.com.purestorage: flasharray. 258          vmhba64  RDMA          true
5ab274df5b161455#vmhba64#50.2.84.100:4420
nqn.2010-06.com.purestorage: flasharray. 259          vmhba65  RDMA          true
Sab274df5b161455#vmhba65#50.2.83.100:4420
[root@RackServer:~] esxcli nvme namespace list
Name
-----
eui.00e6d65b65a8f34824a9374e00011745 258          71493      512          102400
eui.00e6d65b65a8f34024a9374e00011745 259          71493      512          102400
```

Example

The following example shows esxcli discovery commands executed on the server.

```
[root@RackServer:~] esxcli nvme fabrics enable -p RDMA -d vmrdma0 NVMe already
enabled on vmrdma0
[root@RackServer:~] esxcli nvme fabrics discover -a vmhba64 -l 50.2.84.100
Transport Address Subsystem Controller Admin Queue Transport Transport Subsystem NQN
Type Family Type ID Max Size Address Service ID
-----
RDMA IPV4 NVM 65535 31 50.2.84.100 4420 nq.210-06.com.
purestorage:

flasharray:2dp1239anjkl484
[root@RackServer:~] esxcli nvme fabrics discover -a vmhba64 -l 50.2.84.100 p 4420 -s
nq.210-06.com.
purestorage:flasharray:2dp1239anjkl484 Controller already connected
```

Using the UCS Manager CLI to Configure or Delete the RoCEv2 Interface

Configure Windows SMB Direct RoCEv2 Interface using UCS Manager CLI

Use the following steps to configure the RoCEv2 interface in the Cisco UCS Manager CLI.

Before you begin

You must log in with admin privileges.

Procedure

	Command or Action	Purpose
Step 1	Example: UCS-A # scope service-profile server chassis-id / blade-id or rack_server-id	Enter the service profile for the specified chassis, blade or UCS managed rack server ID.
Step 2	Example: UCS-A /org/service-profile # show vnic	Display the vNICs available on the server.
Step 3	Example: UCS-A /org/service-profile # scope vnic vnic name	Enter the vnic mode for the specified vNIC.
Step 4	To configure Windows SMBDirect RoCEv2 Mode 1: Example: UCS-A /org/service-profile/vnic # set adapter-policy Win-HPN-SMBd	Specifies a Windows SMBDirect RoCEv2 adapter policy for RoCEv2 Mode 1.

	Command or Action	Purpose
Step 5	To configure Windows SMBDirect RoCEv2 Mode 2: Example: <pre>UCS-A# scope org UCS-A /org # create vmq-conn-policy policy name UCS-A /org/vmq-conn-policy* # set multi-queue enabled UCS-A /org/vmq-conn-policy* # set vmmq-sub-vnic-count 64 UCS-A /org/vmq-conn-policy* # set vmmq-adaptor-profile-name MQ-SMBd UCS-A /org/vmq-conn-policy* # commit-buffer UCS-A /org/vmq-conn-policy #</pre>	Configures Windows Mode 2, after creating a VMQ connection policy and assigning the adapter policy MQ-SMBd:
Step 6	Example: <pre>UCS-A /org/service-profile/vnic* # commit-buffer</pre>	Commit the transaction to the system configuration.

This example shows how to configure the RoCEv2 Win-HPN-SMBd adapter policy:

```
UCS-A# scope service-profile server 1/1
UCS-A /org/service-profile # show vnic
```

vNIC:

Name	Fabric ID	Dynamic MAC Addr	Virtualization Preference
eth00	A B	00:25:B5:3A:84:00	NONE
eth01	A	00:25:B5:3A:84:01	NONE
eth02	B	00:25:B5:3A:84:02	NONE

```
UCS-A /org/service-profile # scope vnic eth01
UCS-A /org/service-profile/vnic # set adapter-policy Win-HPN-SMBd
UCS-A /org/service-profile/vnic* # commit-buffer
UCS-A /org/service-profile/vnic #
```

Deleting the Windows RoCEv2 Interface Using the CLI for UCS Manager

Use the following steps to delete the Windows RoCEv2 interface in the Cisco UCS Manager CLI.

Before you begin

You must log in with admin privileges.

Procedure

	Command or Action	Purpose
Step 1	Example: <pre>UCS-A # scope service-profile server chassis-id / blade-id or rack_server-id</pre>	Enter the service profile for the specified chassis, blade or UCS managed rack server ID.
Step 2	Example: <pre>UCS-A /org/service-profile # show vnic</pre>	Display the vNICs available on the server.

	Command or Action	Purpose
Step 3	Example: UCS-A /org/service-profile # scope vnic vnic name	Enter the vnic mode for the specified vNIC.
Step 4	Example: UCS-A /org/service-profile/vnic # set adapter-policy Windows	Removes the Windows RoCEv2 adapter policy by setting the default Windows adapter policy.
Step 5	Example: UCS-A /org/service-profile/vnic* # commit-buffer	Commit the transaction to the system configuration.

What to do next

This example shows how to remove the RoCEv2 interface on the eth01 vNIC on Windows.

```
UCS-A# scope service-profile server 1/1
UCS-A /org/service-profile # show vnic
```

vNIC:

Name	Fabric ID	Dynamic MAC Addr	Virtualization Preference
eth00	A B	00:25:B5:3A:84:00	NONE
eth01	A	00:25:B5:3A:84:01	NONE
eth02	B	00:25:B5:3A:84:02	NONE

```
UCS-A /org/service-profile # scope vnic eth01
UCS-A /org/service-profile/vnic # set adapter-policy Windows
UCS-A /org/service-profile/vnic* # commit-buffer
UCS-A /org/service-profile/vnic #
```

Configuring the Linux RoCEv2 Interface Using the UCS Manager CLI

Use the following steps to configure the RoCEv2 interface for Linux in the Cisco UCS Manager CLI.

Before you begin

You must log in with admin privileges.

Procedure

	Command or Action	Purpose
Step 1	Example: UCS-A # scope service-profile server chassis-id / blade-id or rack_server-id	Enter the service profile for the specified chassis, blade or UCS managed rack server ID.
Step 2	Example: UCS-A /org/service-profile # show vnic	Display the vNICs available on the server.

	Command or Action	Purpose
Step 3	Example: UCS-A /org/service-profile # scope vnic vnic name	Enter the vnic mode for the specified vNIC.
Step 4	Example: UCS-A /org/service-profile/vnic # set adapter-policy Linux-NVMe-RoCE	Specify Linux-NVMe-RoCE as the adapter policy for the vNIC that you want to use for NVMeoF.
Step 5	Example: UCS-A /org/service-profile/vnic* # commit-buffer	Commit the transaction to the system configuration.

This example shows how to configure the RoCEv2 Linux adapter policy on the eth01 vNIC:

Example

```
UCS-A# scope service-profile server 1/1
UCS-A /org/service-profile # show vnic

vNIC:
  Name                Fabric ID Dynamic MAC Addr   Virtualization Preference
  -----
  eth00                A B          00:25:B5:3A:84:00  NONE
  eth01                A            00:25:B5:3A:84:01  NONE
  eth02                B            00:25:B5:3A:84:02  NONE
UCS-A /org/service-profile # scope vnic eth01
UCS-A /org/service-profile/vnic # set adapter-policy Linux-NVMe-RoCE
UCS-A /org/service-profile/vnic* # commit-buffer
UCS-A /org/service-profile/vnic #
```

Deleting the Linux RoCEv2 Interface Using the UCS Manager CLI

Use the following steps to delete the Linux RoCEv2 interface in the Cisco UCS Manager CLI.

Before you begin

You must log in with admin privileges.

Procedure

	Command or Action	Purpose
Step 1	Example: UCS-A # scope service-profile server chassis-id / blade-id or rack_server-id	Enter the service profile for the specified chassis, blade or UCS managed rack server ID.
Step 2	Example: UCS-A /org/service-profile # show vnic	Display the vNICs available on the server.
Step 3	Example: UCS-A /org/service-profile # scope vnic vnic name	Enter the vnic mode for the specified vNIC.

	Command or Action	Purpose
Step 4	Example: UCS-A /org/service-profile/vnic # set adapter-policy <i>Linux</i>	Removes Linux-NVMe-RoCE policy by setting the default Linux adapter policy.
Step 5	Example: UCS-A /org/service-profile/vnic* # commit-buffer	Commit the transaction to the system configuration.

This example shows how to remove the RoCEv2 interface on the eth01 vNIC on Linux.

Example

```
UCS-A# scope service-profile server 1/1
UCS-A /org/service-profile # show vnic

vNIC:
-----
Name                Fabric ID Dynamic MAC Addr  Virtualization Preference
-----
eth00                A B          00:25:B5:3A:84:00  NONE
eth01                A            00:25:B5:3A:84:01  NONE
eth02                B            00:25:B5:3A:84:02  NONE
UCS-A /org/service-profile # scope vnic eth01
UCS-A /org/service-profile/vnic # set adapter-policy Linux
UCS-A /org/service-profile/vnic* # commit-buffer
```

Configuring the VMware ESXi RoCEv2 Interface Using the UCS Manager CLI

Use the following steps to configure the RoCEv2 interface for VMware ESXi in the Cisco UCS Manager CLI.

Before you begin

You must log in with admin privileges.

Procedure

	Command or Action	Purpose
Step 1	Example: UCS-A # scope service-profile server <i>chassis-id / blade-id or rack_server-id</i>	Enter the service profile for the specified chassis, blade or UCS managed rack server ID.
Step 2	Example: UCS-A /org/service-profile # show vnic	Display the vNICs available on the server.
Step 3	Example: UCS-A /org/service-profile # scope vnic <i>vnic name</i>	Enter the vnic mode for the specified vNIC.
Step 4	Example: UCS-A /org/service-profile/vnic # set adapter-policy <i>VMWareNVMeRoCEv2</i>	Specify VMWareNVMeRoCEv2 as the adapter policy for the vNIC that you want to use for NVMeoF.

	Command or Action	Purpose
Step 5	Example: UCS-A /org/service-profile/vnic* # commit-buffer	Commit the transaction to the system configuration.

This example shows how to configure the RoCEv2 VMware adapter policy on the eth01 vNIC:

Example

```
UCS-A# scope service-profile server 1/1
UCS-A /org/service-profile # show vnic

vNIC:
  Name                Fabric ID Dynamic MAC Addr  Virtualization Preference
  -----
  eth00               A B           00:25:B5:3A:84:00  NONE
  eth01               A             00:25:B5:3A:84:01  NONE
  eth02               B             00:25:B5:3A:84:02  NONE
UCS-A /org/service-profile # scope vnic eth01
UCS-A /org/service-profile/vnic # set adapter-policy VMWareNVMeRoCEv2
UCS-A /org/service-profile/vnic* # commit-buffer
UCS-A /org/service-profile/vnic #
```

Deleting the ESXi RoCEv2 Interface Using UCS Manager

Use these steps to remove the RoCE v2 interface for a specific port.

-
- Step 1** In the **Navigation** pane, click **Servers**.
 - Step 2** Expand **Servers > Service Profiles**.
 - Step 3** Expand the node for the profile to delete.
 - Step 4** Click on **vNICs** and select the desired interface. Right click and select **Delete** from the dropdown.
 - Step 5** Click **Save Changes**.
-

Known Issues in RoCEv2

The following known issues are present in the RoCEv2 release.

Symptom	Conditions	Workaround
<p>When sending high bandwidth NVMe traffic on some Cisco Nexus 9000 switches, the switch port that connected to the storage sometimes reaches the max PFC peak and does not automatically clear the buffers. In Nexus 9000 switches, the nxos command "show hardware internal buffer info pkt-stats input peak" shows that the <code>Peak_cell</code> or <code>PeakQos</code> value for the port reaches more than 1000.</p>	<p>The NVMe traffic will drop.</p>	<p>To recover the switch from this error mode.</p> <ol style="list-style-type: none"> 1. Log into the switch. 2. Locate the port that connected to the storage and shut down the port using "shutdown" command 3. Execute the following commands one by one: <pre># clear counters # clear counter buffers module 1 # clear qos statistics</pre> 4. Run no shutdown on the port that was shut down.
<p>On VIC 1400 Series adapters, the neNIC driver for Windows 2019 can be installed on Windows 2016 and the Windows 2016 driver can be installed on Windows 2019. However, this is an unsupported configuration.</p>	<p>Case 1 : Installing Windows 2019 nenic driver on Windows 2016 succeeds-but on Windows 2016 RDMA is not supported.</p> <p>Case 2 : Installing Windows 2016 nenic driver on Windows 2019 succeeds-but on Windows 2019 RDMA comes with default disabled state, instead of enabled state.</p>	<p>The driver binaries for Windows 2016 and Windows 2019 are in folders that are named accordingly. Install the correct binary on the platform that is being built/updated.</p>



CHAPTER 4

Single Root I/O Virtualization (SR-IOV)

- [Configuring BIOS and Cisco UCS Manager Parameters](#) , on page 37
- [Configuring SR-IOV VFs on the ESXi Host Server](#) , on page 42

Configuring BIOS and Cisco UCS Manager Parameters

Enabling SR-IOV BIOS Parameters

Before you begin

- You must have a BIOS policy that is already created with the following options enabled:
 - For Intel based servers, **Intel VT for directed IO** under **Intel Directed IO** tab.
 - For AMD based servers, **IOMMU** and **SVM Mode** under **Processor** tab.

To update BIOS options, see, [Cisco UCS Manager Server Management Guide](#).

- You must have a service profile already created for SR-IOV configuration. To create a Service Profile see [Cisco UCS Manager Server Management Guide](#). Once the Service Profile is created, follow the steps in this procedure to enable SR-IOV in the BIOS policy.

Step 1 In the **Navigation** pane, click **Servers**.

Step 2 Expand **Servers** > **Service Profiles**.

Step 3 Expand the node for the organization that includes the service profile for which you want to enable SR-IOV BIOS parameters.

If the system does not include multi-tenancy, expand the root node.

Step 4 Click the service profile for which you want to enable SR-IOV BIOS parameters.

Step 5 In the **Work** pane, click the **Policies** tab.

Step 6 On the **Policies** tab, expand **BIOS Policy**.

Step 7 From the **BIOS Policy** drop-down list, select the BIOS policy that you have created for SR-IOV configuration.

Ensure that the BIOS policy selected satisfies the per-requisites for this procedure.

Step 8 Save changes and click **Yes** to reboot the server.

Enabling SR-IOV VFs using Cisco UCS Manager GUI

To enable SR-IOV from Cisco UCS Manager, you must

- Create an SRIOV HPN Connection Policy with desired number of VFs.
- Assign the SRIOV HPN Connection Policy to a Service Profile.

Before you begin

- Ensure that the required BIOS options are enabled before performing this procedure.

Step 1 In the **Navigation** pane, click **LAN**.

Step 2 Expand **Policies > root**.

Step 3 To create SRIOV HPN Connection Policy, right click **SRIOV HPN Connection Policies**.

Step 4 You can view and modify the created **SRIOV HPN Connection Policy** properties.

Name	Description
Name field	The name of the policy. This name can be between 1 and 16 alphanumeric characters. You cannot use spaces or any special characters other than - (hyphen), _ (underscore), : (colon), and . (period), and you cannot change this name after the object is saved.
Description field	Brief description of the policy.
Number of SRIOV HPN vnics field	Enter an integer between 1 and 64.
Transmit Queues field	The number of descriptors in each transmit queue. Enter an integer between 1 and 8.
Receive Queues field	The number of receive queue resources to allocate. Enter an integer between 1 and 8.
Completion Queues field	The number of completion queue resources to allocate. In general, the number of completion queue resources you should allocate is equal to the number of transmit queue resources plus the number of receive queue resources. Enter an integer between 1 and 16.

Name	Description
Interrupt Count field	The number of interrupt resources to allocate. In general, this value should be equal to the number of completion queue resources. Enter an integer between 1 and 16.

- Step 5** Provide the policy name with the desired number of SRIOV HPN vNICs and click **OK** to create **SRIOV HPN Connection Policy**.
- Step 6** In the **Navigation** pane, click **Servers**.
- Step 7** Expand **Servers > Service Profiles**.
- Step 8** Expand the node and service profile for the organization that contains the service profile for SR-IOV configuration.
- Step 9** Click the desired service profile for which you wish to apply the SR-IOV VFs.
- Step 10** Expand **vNIC** and select the vNIC for which you wish to apply the SR-IOV VFs.
- Step 11** In the work pane, select the **General** tab.
- Step 12** At the **Adapter Policy** drop-down list, select **SRIOV-HPN**.
- Step 13** Under the **Connection Policies** radio buttons, select **SRIOV-HPN**.
- Step 14** From the **SRIOV HPN Connection Policy** drop-down list, select the policy you have already created for SR-IOV configuration.
- Step 15** Save changes and click **Yes** to reboot the server.

Disabling SR-IOV VFs Using Cisco UCS Manager GUI

- Step 1** In the **Navigation** pane, click **Servers**.
- Step 2** Expand **Servers > Service Profiles**.
Expand the node and service profile for the organization that contains the service profile for SR-IOV configuration.
- Step 3** Click the service profile from which you wish to remove the SR-IOV VFs.
- Step 4** Expand **vNIC** and select the vNIC for which you wish to disable the SR-IOV VFs.
- Step 5** In the work pane, select the **General** tab.
- Step 6** Under the **Connection Policies** radio button options, select **SRIOV-HPN**.
- Step 7** From the **SRIOV HPN Connection Policy** drop-down list, select **not set** to remove the SR-IOV connection policy.
- Step 8** Save changes and click **Yes** to reboot the server.

Enabling SR-IOV VFs using Cisco UCS Manager CLI

To enable SR-IOV from Cisco UCS Manager, you must

- Create an SRIOV HPN Connection Policy with desired number of VFs.
- Assign the SRIOV HPN Connection Policy to a Service Profile.

Before you begin

- Ensure that the required BIOS options are enabled before performing this procedure.

SUMMARY STEPS

1. UCS-A # **scope org** *org-name*
2. UCS-A /org # **create sriov-hpn-conn-policy** *policy-name*
3. UCS-A /org/sriov-hpn-conn-policy* # **set sriov-hpn-count** *sriov hpn count*
4. UCS-A /org/sriov-hpn-conn-policy* # **set transmit-queue-count** *transmit queue count*
5. UCS-A /org/sriov-hpn-conn-policy* # **set receive-queue-count** *receive queue count*
6. UCS-A /org/sriov-hpn-conn-policy* # **set completion-queue-count** *completion-queue count*
7. UCS-A /org/sriov-hpn-conn-policy* # **set interrupt-queue-count** *interrupt queue count*
8. UCS-A /org/sriov-hpn-conn-policy* # **commit-buffer**
9. UCS-A /org/sriov-hpn-conn-policy* # **exit**
10. UCS-A /org # **scope service-profile** *profile-name-for-sriov-config*
11. UCS-A# scope /org/service-profile # **scope vnic** *eth0/eth1*
12. UCS-A /org/service-profile/vnic # **set adapter-policy SRIOV-HPN**
13. UCS-A /org/service-profile/vnic # **enter sriov-hpn-conn-policy-ref** *sriov_hpn_connection_policy_name*
14. UCS-A /org/service-profile/vnic/sriov-hpn-conn-policy-ref* # **commit-buffer**

DETAILED STEPS

	Command or Action	Purpose
Step 1	UCS-A # scope org <i>org-name</i>	Enters organization mode for the specified organization. To enter the root organization mode, type / as the org-name.
Step 2	UCS-A /org # create sriov-hpn-conn-policy <i>policy-name</i>	Specifies the name for the SRIOV HPN connection policy.
Step 3	UCS-A /org/sriov-hpn-conn-policy* # set sriov-hpn-count <i>sriov hpn count</i>	Specifies the SRIOV HPN vNICs count for the SRIOV HPN connection policy. Enter an integer between 1 and 64.
Step 4	UCS-A /org/sriov-hpn-conn-policy* # set transmit-queue-count <i>transmit queue count</i>	Specifies the transmit queue count for the SRIOV HPN connection policy. Enter an integer between 1 and 8.
Step 5	UCS-A /org/sriov-hpn-conn-policy* # set receive-queue-count <i>receive queue count</i>	Specifies the receive queue count for the SRIOV HPN connection policy. Enter an integer between 1 and 8.
Step 6	UCS-A /org/sriov-hpn-conn-policy* # set completion-queue-count <i>completion-queue count</i>	Specifies the completion queue count for the SRIOV HPN connection policy. In general, the number of completion queue resources you should allocate is equal to the number of transmit queue resources plus the number of receive queue resources. Enter an integer between 1 and 16.
Step 7	UCS-A /org/sriov-hpn-conn-policy* # set interrupt-queue-count <i>interrupt queue count</i>	Specifies the interrupt count for the SRIOV HPN connection policy. In general, this value should be equal to the number of completion queue resources. Enter an integer between 1 and 16.

	Command or Action	Purpose
Step 8	UCS-A /org/sriov-hpn-conn-policy* # commit-buffer	Commits the transaction to the system.
Step 9	UCS-A /org/sriov-hpn-conn-policy* # exit	
Step 10	UCS-A /org # scope service-profile <i>profile-name-for-sriov-config</i>	Enters the service profile for the organization that contains the service profile for SR-IOV configuration.
Step 11	UCS-A# scope /org/service-profile # scope vnic <i>eth0/eth1</i>	Select a vNIC for which you wish to apply the SR-IOV VFs.
Step 12	UCS-A /org/service-profile/vnic # set adapter-policy SRIOV-HPN	Sets the adapter policy as SRIOV HPN
Step 13	UCS-A /org/service-profile/vnic # enter sriov-hpn-conn-policy-ref <i>sriov_hpn_connection_policy_name</i>	Assigns the SRIOV HPN connection policy created previously to the vNIC.
Step 14	UCS-A /org/service-profile/vnic/sriov-hpn-conn-policy-ref* # commit-buffer	Commits the transaction to the system.

Disabling SR-IOV VFs using Cisco UCS Manager CLI

To disable the SRIOV VFs, you must delete the associated SRIOV HPN connection policy.

SUMMARY STEPS

1. UCS-A # **scope org** *org-name*
2. UCS-A /org # **scope service-profile** *service_profile_name*
3. UCS-A /org/service-profile # **scope vnic** *eth0/eth1*
4. UCS-A /org/service-profile/vnic # **delete sriov-hpn-conn-policy-ref** *sriov_hpn_connection_policy_name*
5. UCS-A /org/service-profile/vnic* # **commit-buffer**

DETAILED STEPS

	Command or Action	Purpose
Step 1	UCS-A # scope org <i>org-name</i>	Enters organization mode for the specified organization. To enter the root organization mode, type / as the org-name.
Step 2	UCS-A /org # scope service-profile <i>service_profile_name</i>	Enter the service profile withing which you wish to disable the SRIOV VFs.
Step 3	UCS-A /org/service-profile # scope vnic <i>eth0/eth1</i>	Select a vNIC for which you wish to apply the SR-IOV VFs.
Step 4	UCS-A /org/service-profile/vnic # delete sriov-hpn-conn-policy-ref <i>sriov_hpn_connection_policy_name</i>	Deletes the SRIOV HPN Connection policy. This disables the SRIOV VFs.
Step 5	UCS-A /org/service-profile/vnic* # commit-buffer	Commits the transaction to the system.

Configuring SR-IOV VFs on the ESXi Host Server

Installing Cisco eNIC Driver

Before you begin

Ensure that the SR-IOV BIOS parameters and SR-IOV VFs configurations are completed.

Step 1 Install the enic driver on the host.

The following example shows the installation of eNIC driver on EXSi:

```
[root@localhost:/vmfs/volumes/645c8bdd-c655e553-8ba0-e8d32272f6c0] esxcli software vib install -v
/vmfs/volumes/C240M7-Standalone/nenic-2.0.10.0-1OEM.800.1.0.20143090.x86_64.vib --no-sig-check
Installation Result
Message: The update completed successfully, but the system needs to be rebooted for the changes to
be effective.
VIBs Installed: CIS_bootbank_nenic_2.0.10.0-1OEM.800.1.0.20143090
VIBs Removed: CIS_bootbank_nenic_2.0.11.0-1OEM.800.1.0.20143090
VIBs Skipped:
Reboot Required: true
DPU Results:
[root@localhost:/vmfs/volumes/645c8bdd-c655e553-8ba0-e8d32272f6c0]
```

Step 2 Reboot the server to load the enic driver into the running kernel.

Step 3 After reboot, execute the **esxcli software vib list | grep nenic** command to check the driver version.

Verifying the Total Number of SR-IOV VFs Per Ports on the Host

You can verify the total number of SR-IOV VFs in the following two ways:

Step 1 Verify by logging into the VMware ESXi Host Client.:

- Login to the VMware ESXi Host Client.
- Execute the following command to check the vNIC with SR-IOV capability:

```
root@localhost:~] esxcli network sriovnic list
Name      PCI Device      Driver  Link  Speed  Duplex  MAC Address      MTU  Description
-----
vmnic0    0000:1b:00.0    nenic   Up    50000  Full    f4:ee:31:30:80:40 1500 Cisco Systems Inc
Cisco VIC Ethernet NIC
```

The following output shows the number of VF configured on vNIC:

```
[root@localhost:~] esxcli network sriovnic vf list -n vmnic0
VF ID  Active  PCI Address  Owner World ID
0      false  00000:027:00.1  -
1      false  00000:027:00.2  -
2      false  00000:027:00.3  -
3      false  00000:027:00.4  -
4      false  00000:027:00.5  -
5      false  00000:027:00.6  -
```

```

6  false  00000:027:00.7  -
7  false  00000:027:01.0  -

```

Step 2 Alternatively, you can also access your host from vSphere vCenter Client.

For more information on configuring SR-IOV VFs on the host, see [Creating SR-IOV VFs on the Host](#).

After you reboot the host server, do the following:

- Login to the ESXi Host Client, and choose **Networking > Virtual Switches**.
- Click **Add Standard Virtual Switch**.
- Add a switch name in the **vSwitch Name** field, select the vmnic with SR-IOV capability, and click **Add**.
- In the **Port Groups** tab, click **Add Port Group**.
- In the **Add Port Group** dialog-box, add a new port group and select the switch from the **Virtual Switch** drop-down.

Creating SR-IOV VFs on the Host

Step 1 Login to your VMware ESXi Host Client.

Alternatively, you can also access your host from vSphere vCenter Client and browse to **Configure > Networking > Physical adapters**.

Step 2 Go to **Host > Manage** and select the **Hardware** tab.

Step 3 Select **PCI Devices** from the list.

Step 4 From the drop-down list, select **SR-IOV Capable**.

The list shows all the SR-IOV capable devices.

Step 5 Select the vNIC for which you wish to create the VFs.

Step 6 Click **Configure SR-IOV**.

Configure SR-IOV for Cisco VIC Ethernet NIC window is displayed.

Step 7 Perform the following:

Field	Description
Enabled radio button	Select Yes to enable the configuration.
Virtual functions field	Number of VFs as configured on SRIOV connection policy that are available for the configuration. Enter an integer between 1 and 64.

Step 8 Click **Save** and then reboot the host server.

Configuring the Switch

Before you begin

Ensure that the SR-IOV VFs are configured.

- Step 1** Login to your VMware ESXi Host Client.
- Step 2** Navigate to **Host > Networking** and select the **Virtual switches** tab.
- Step 3** Click **Add Standard Virtual Switch**.
- Step 4** Enter the name for the switch.
- Step 5** Select a SR-IOV Capable Vmnic from the list.
- Step 6** Click **Add**.
- Step 7** Complete the following:

Field	Description
vSwitch Name field	Enter a suitable name for the virtual switch.
MTU field	Enter the maximum transmission unit. The default is 1500 bytes.
Uplink 1 drop-down list	From the drop-down list, select the PCIe devices for which you created the SR-IOVs.
Link Discovery	From the drop-down list, select the Mode and the Protocol . Note These fields remain as default.
Security	Choose from the following options: <ul style="list-style-type: none"> • Promiscuous mode—Accept, Reject, or Inherit from vSwitch. • MAC address changes—Accept, Reject, or Inherit from vSwitch. • Forged trasmits—Accept, Reject, or Inherit from vSwitch.

Field	Description
NIC teaming	<p>Choose from the following:</p> <ul style="list-style-type: none"> • Load balancing—From the drop-down list choose the Load balancing. Values are: Inherit from vSwitch, • Network failover detection—From the drop-down list choose the network failover detection. Values are: Inherit from vSwitch, • Notify switches—Choose the notify switches. Values are Yes, No, Inherit from vSwitch. • Fallback—Choose the fallback. Values are Yes, No, Inherit from vSwitch. • Override failover order—From the drop-down list choose the override failover order. Values are Yes or No, • Failover order—Choose the failover order.
Traffic Shaping	<p>Perform the following:</p> <ul style="list-style-type: none"> • Status—Choose the status. Values are Enabled, Disabled, Inherit from vSwitch. • Average bandwidth—Enter the average bandwidth. • Peek bandwidth—Enter the peek bandwidth. • Burst size—Enter the burst size. <p>Note Traffic shaping policy is applied to the traffic of each virtual network adapter attached to the virtual switch.</p>

What to do next

[Creating a Virtual Port, on page 45](#)

Creating a Virtual Port

Before you begin

Ensure that the SR-IOV VFs are configured.

-
- Step 1** Login to your VMware ESXi Host Client.
- Step 2** Go to **Host > Networking** and select the **Port Groups** tab.
- Step 3** Click **Add port group**.
- Add port group-New port group** window is displayed

Step 4 Complete the following:

Field	Description
Name field	Enter a suitable name for the virtual port.
VLAN ID field	Enter the VLAN ID.
Virtual Switch drop-down list	From the drop-down list, select the virtual switch.
Security	Choose from the following options: <ul style="list-style-type: none"> • Promiscuous mode—Accept, Reject, or Inherit from vSwitch. • MAC address changes—Accept, Reject, or Inherit from vSwitch. • Forged trasmits—Accept, Reject, or Inherit from vSwitch.

Step 5 Click **Add**.

Creating a New Virtual Machine (VM)

Before you begin

- Host with Desktop Environment
- sudo user with admin rights
- Virtualization packages are installed
- OS ISO image is copied to the host server

Refer [Installing OS on Guest VM on ESXi, on page 47](#).

Adding SR-IOV VF on the Virtual Machine

Before you begin

The Virtual Machine is powered off.

- Step 1** Select a Virtual Machine Manager from the host, and choose **Edit Settings**.
- Step 2** Choose **Memory** and set the **Reservation** for the memory to **4 GB**.
- Step 3** Check the **Reserve all guest memory (All locked)** check box.

Step 4 On the right, click **Add New Device** and choose **Network Adapter**.

Step 5 In the **New Network** dialog-box, click **Browse** to select the vNIC with SR-IOV capable from the **Select Network** window, and click **OK**.

Table 1: Network Adapter Dialog Box

Field	Description
Status	The status of the network adapter.
Adapter Type	Choose the adapter type from the drop-down list.
Physical Function	The physical function of the network adapter.
MAC Address	The MAC address of the network adapter.
Allow Guest MTU Change	Choose to allow the guest MTU.

Step 6 Choose **PCI Device passthrough** from the **Adapter Type** drop-down.

Step 7 Select the device from the **Device Selection** window, and choose vNIC.

Step 8 Click **OK**.

What to do next

You can now log into the virtual machine, install Cisco eNIC driver 4.5.0.23 with Linux VMs on ESXi, reboot the virtual machine, and then use the `ip link` command to verify the added SR-IOV VF.

Installing OS on Guest VM on ESXi

Before you begin

Upload the Linux operating system ISO on the datastore.

Step 1 Right-click the host node and navigate to **vCenter > New Virtual machine**.

Step 2 Select a **Creation Type > Create New Virtual Machine**, and click **Next**.

Step 3 Enter a name for the folder, and click **Next**.

Step 4 Select a compute resource, choose a node and click **Next**.

Step 5 Select Storage and check the datastore radio-button, and click **Next**.

Step 6 Select the compatibility ESXi 8.0 or later and click **Next**.

Step 7 Select a guest OS version as **RHEL Linux9 (64-bit)**, and click **Next**.

Step 8 Customize the hardware set **CPU** to 2, and **Memory values** to 4 GB.

Step 9 Expand the **Memory** tab, and check **Reserve all guest memory (All lockset)** check box.

Step 10 Select **New CD/DVD Drive (Datastore ISO file)**, and check the **Connect At Power On** check box.

Step 11 Under **CD/DVD Media**, browse and select the Linux ISO image and click **Next**.

Step 12 Click **Finish**.
