Cisco XDR과 FTD(Firepower 위협 방어)의 통합 및 문제 해결

목차

<u>소개</u> <u>사전 요구 사항</u> <u>요구 사항</u> <u>사용되는 구성 요소</u> <u>구성</u> <u>라이센싱</u> <u>계정을 SSE에 연결하고 디바이스를 등록합니다.</u> <u>SSE에 디바이스 등록</u>

소개

이 문서에서는 Cisco XDR을 Firepower FTD(Firepower 위협 방어)와 통합, 확인 및 트러블슈팅하는 데 필 요한 단계에 대해 설명합니다.

사전 요구 사항

요구 사항

다음 주제에 대한 지식을 보유하고 있으면 유용합니다.

- FMC(Firepower Management Center)
- FTD(Firepower Threat Defense)
- 이미지 가상화 옵션

사용되는 구성 요소

- Firepower 위협 방어(FTD) 6.5
- FMC(firepower 관리 센터) 6.5
- SSE(Security Services Exchange)
- Cisco XDR
- Smart License 포털

이 문서의 정보는 특정 랩 환경의 디바이스를 토대로 작성되었습니다. 이 문서에 사용된 모든 디바 이스는 초기화된(기본) 컨피그레이션으로 시작되었습니다. 현재 네트워크가 작동 중인 경우 모든 명령의 잠재적인 영향을 미리 숙지하시기 바랍니다.

라이센싱

가상 어카운트 역할:

Virtual Account Admin 또는 Smart Account Admin에게만 Smart Account를 SSE 어카운트와 연결 할 수 있는 권한이 있습니다.

1단계. Smart Account 역할을 검증하려면 software.cisco.com으로 이동한 후 Administration(관리) 메뉴에서 Manage Smart Account(Smart Account 관리)를 선택합니다.



2단계. 사용자 역할의 유효성을 검사하려면 Users(사용자)로 이동하여, 그림과 같이 Roles(역할)에 서 계정이 Virtual Account Administrator(가상 어카운트 관리자)를 갖도록 설정되어 있는지 확인합 니다.

Cisco Softv	Sisco Software Central > Manage Smart Account > Users									
Account Pro	count Properties Virtual Accounts Users Custom Tags Requests Account Agreements Event Log									
Users	Users									
Users	User Groups									
A	Add Users Remove Selected Export Selected									
	User ↑	Email	Organization	Account Access	Role	User Group	Actions			
	daniebenį			•	-	•				
0	Daniel Benitez danieben	danieben@cisco.com	Cisco Systems, Inc.	All Virtual Accounts Mex-AMP TAC	Smart Account Administrator Virtual Account Administrator		Remove			
							1 User			

3단계. 보안 라이센스가 없는 계정이 SSE에 연결되어 있고 보안 디바이스 및 이벤트가 SSE 포털에 나타나지 않을 경우 SSE에서 연결하도록 선택한 가상 계정에 보안 디바이스에 대한 라이센스가 포 함되어 있는지 확인합니다.

ts	Inventory Convert to Smart Licensing Reports	Preferences On-Prem	Accounts Activity			
tua	Account: Mex-AMP TAC -					Minor Hide Ale
Gent	eral Licenses Product Instances Eve	ent Log				
A	Manage License Tags	License Reservation	on		Search by License	By Name By Tag Q
	License	Billing	Purchased	In Use	Balance Alerts	Actions
0	FPR1010 URL Filtering	Prepaid	10	0	+ 10	Actions 👻
0	FPR4110 Threat Defense Malware Protection	Prepaid	1	0	+ 1	Actions +
0	FPR4110 Threat Defense Threat Protection	Prepaid	1	0	+ 1	Actions -
	FPR4110 Threat Defense URL Filtering	Prepaid	1	0	+ 1	Actions 🔹
	HyperFlex Data Platform Enterprise Edition Subscription	Prepaid	2	0	+ 2	Actions .
0	ISE Apex Session Licenses	Prepaid	1	0	+ 1	Actions -
	ISE Base Session Licenses	Prepaid	10	0	+ 10	Actions +
	ISE Plus License	Prepaid	10	0	+ 10	Actions 👻
	Threat Defense Virtual Malware Protection	Prepaid	10	1	+ 9	Actions -
-	Threat Defense Virtual Threat Protection	Prenaid	10	1	+ 9	Actions -

4단계. FMC가 올바른 Virtual Account에 등록되었는지 확인하려면 System>Licenses>Smart License로 이동합니다.

Smart License Status			Cisco Smart Software Manager	
Usage Authorization:	Ø	Authorized (Last Synchronized On Jun 10 2020)		
Product Registration:	٢	Registered (Last Renewed On Jun 10 2020)		
Assigned Virtual Account:		Mex-AMP TAC		
Export-Controlled Features:		Enabled		
Cisco Success Network:		Enabled (1)		
Cisco Support Diagnostics:		Disabled ()		

Smart Licenses

License Type/Device Name	License Status
> 🟳 Firepower Management Center Virtual (1)	0
> 🟳 Base (1)	0
> 🟳 Malware (1)	0
> 🖓 Threat (1)	٥
> 🔑 URL Filtering (1)	٥
> 🖓 AnyConnect Apex (1)	٥
> 🖓 AnyConnect Plus (1)	٢
AnyConnect VPN Only (0)	

Note: Container Instances of same blade share feature licenses

계정을 SSE에 연결하고 디바이스를 등록합니다.

1단계. SSE 어카운트에 로그온할 때 스마트 어카운트를 SSE 어카운트에 연결해야 합니다. 도구 아이콘을 클릭하고 어카운트 연결을 선택해야 합니다.



어카운트가 연결되면 Smart Account가 모든 Virtual Account와 함께 표시됩니다.

SSE에 디바이스 등록

1단계. 사용자 환경에서 다음 URL이 허용되는지 확인합니다.

미국 지역

- api-sse.cisco.com
- eventing-ingest.sse.itd.cisco.com

EU 지역

- api.eu.sse.itd.cisco.com을 참조하십시오.
- eventing-ingest.eu.sse.itd.cisco.com을 참조하십시오.

APJ 지역

- api.apj.sse.itd.cisco.com
- eventing-ingest.apj.sse.itd.cisco.com

2단계. 다음 이미지에 표시된 대로 이 URL https://admin.sse.itd.cisco.com을 사용하여 SSE 포털에 로그인하고 Cloud Services(클라우드 서비스)로 이동한 다음 Eventing 및 Cisco XDR 위협 대응 옵 션을 모두 활성화합니다.

CISCO Security Services Exchange	Devices Cloud Services Events Audit Log	
Cloud Services for Sourcefire Suppor	t	
	Cisco SecureX threat response Cisco SecureX threat response enablement allows you to utilize supported devices in the course of a cybersecurity investigation. It also allows this platform to send high fidelity security events and observations to Threat Response.	♥
	Eventing Eventing allows you to collect and view events in the cloud.	••

3단계. Firepower Management Center에 로그인하고 System>Integration>Cloud Services로 이동 하여 Cisco Cloud Event Configuration을 활성화하고 클라우드로 전송할 이벤트를 선택합니다.

Overview Analysis Policies Devices Objects AMP	Intelligence	Configuration Lisers Domains Totogration	Deploy 0, System Help
Cloud Services Realms Identity Sources eStr	eamer Host Input Client Smart Software Satellite		
	URL Filtering Last URL Filtering Update: Nev 29, 2019 2:31 PM Update New	AMP for Networks Last Local Malware Detection Update: Nov 28, 2019 3:31 PM	
	Enable Automatic Updates Query Cisco Cloud for Unknown URLs Cached URLs Expire Never	Enable Automatic Local Malware Detection Updates Share URI from Malware Events with Cisco Use Legacy Port 32137 for AMP for Networks	
	Save	Save	
	Cisco Cloud Region	Cisco Cloud Event Configuration	
	Region us-cast-1 (US Recion)	 Send high priority Connection Events to the cloud Send File and Malware Events to the cloud Send Intrusion Events to the cloud Click here to view your Cisco Cloud configuration. Click here to view your events in Cisco Threat Response. 	
	Save	Save	

4단계. SSE 포털로 돌아가 이제 SSE에 등록된 디바이스를 확인할 수 있습니다.

cisco Securit	y Services Exchang	0 Devices Cloud S	Services Events Audit Log				
Devices for Se	ourcefire Support						
♥ Q, the x	1						
	16		Name A	Type	Version	Status	Description
	~	1	frepower	Cisco Firepower Threat Defense for VMWare	6.5.0	O Registered	27 frepower (FMC managed)
	Createst 202	0-06-10 19:51:46 UTC		@ Address: 27			Connector Version:
0	~	2	MEX-AMP-FIND	Cisco Firepower Management Center for VMW.	6.5.0	Registered	.24 MDI-AMP-FMC
	Created: 202	c66577b12 0-06-10 20:17:37 UTC	,	P Address: 24			Connector Version:
Page Size: 25	v Total Entries: 2						

FTD 디바이스에서 이벤트를 전송하고, SSE 포털의 Events로 이동하여 이미지에 표시된 대로 디바 이스에서 SSE로 전송한 이벤트를 확인합니다.

cisco	Secu	urity Services	S Exchange	Devices Cloud Serv	vices Events Audit Log					0 *
Event Stream for Sourcefire Support										
T O R	Q En	ter filter criteria		✓ ■ 08/04	4/2020, 18:50 - 08/05/2020, 18:50	×				
		Talos Disposition	Incident	Destination IP	Event Time	Ingest Time	Message	Protocol	Reporting Device ID	Source IP
		Neutral	° No	.252	2020-08-05 18:48:50 UTC	2020-08-05 18:48:51 UTC		tcp	09d441eedce5	100
		Neutral	° No	145	2020-08-05 18:47:38 UTC	2020-08-05 18:47:38 UTC		tcp	09d441eedce5	100
		Unknown	° No	100	2020-08-05 18:47:30 UTC	2020-08-05 18:47:30 UTC		tcp	09d441eedce5	100
		Neutral	° No	.252	2020-08-05 18:46:50 UTC	2020-08-05 18:46:50 UTC		tcp	09d441eedce5	.100

다음을 확인합니다.

FTD가 이벤트(악성코드 또는 침입)를 생성하는지 확인합니다. 침입 이벤트의 경우 분석>파일 >Malware Events(악성코드 이벤트)는 침입 이벤트의 경우 Analysis>Intrusion>Events로 이동합니 다.

이벤트가 SSE 포털에 등록되었는지 확인합니다(SSE에 디바이스 등록 섹션 4 단계)..

Cisco XDR 대시보드에 정보가 표시되는지 확인하거나 API 로그를 확인하여 API 실패의 원인을 확 인할 수 있습니다.

문제 해결

연결 문제 탐지

action_queue.log 파일에서 일반 연결 문제를 탐지할 수 있습니다. 오류가 발생할 경우 파일에 해당 로그가 있는 것을 볼 수 있습니다.

ActionQueueScrape.pl[19094]: [SF::SSE::Enrollment] canConnect: System (/usr/bin/curl -s --connect-timeo

이 경우 종료 코드 28은 작업 시간이 초과되었음을 의미하며 인터넷 연결을 확인해야 합니다. DNS 확인 문제를 의미하는 종료 코드 6도 표시되어야 합니다

DNS 확인으로 인한 연결 문제

1단계. 연결이 제대로 작동하는지 확인합니다.

root@ftd01:~# curl -v -k https://api-sse.cisco.com
* Rebuilt URL to: https://api-sse.cisco.com/
* getaddrinfo(3) failed for api-sse.cisco.com:443
* Couldn't resolve host 'api-sse.cisco.com'
* Closing connection 0
curl: (6) Couldn't resolve host 'api-sse.cisco.com'

이 출력은 디바이스가 URL https://api-sse.cisco.com을 확인할 수 없음을 보여줍니다. 이 경우 올바 른 DNS 서버가 구성되어 있는지 검증해야 합니다. 전문 CLI의 nslookup으로 검증할 수 있습니다.

root@ftd01:~# nslookup api-sse.cisco.com
;; connection timed out; no servers could be reached

이 출력은 구성된 DNS에 도달하지 않았음을 보여줍니다. DNS 설정을 확인하려면 show network 명령을 사용합니다.

Gateway : x.x.x.1 : Enabled State : Up Link : Management & Events Channels Mode : Non-Autonegotiation MDI/MDIX : Auto/MDIX MTU : 1500 MAC Address : x:x:x:x:9D:A5 -----[IPv4]------Configuration : Manual Address : x.x.x.27 : 255.255.255.0 Netmask Broadcast : x.x.x.255 -----[IPv6]-----Configuration : Disabled =======[Proxy Information]=========== : Disabled : Disabled State Authentication

이 예에서는 잘못된 DNS 서버가 사용되었습니다. 다음 명령을 사용하여 DNS 설정을 변경할 수 있 습니다.

> configure network dns x.x.x.11

이 연결을 다시 테스트할 수 있으며, 이 경우 연결에 성공합니다.

root@ftd01:~# curl -v -k https://api-sse.cisco.com * Rebuilt URL to: https://api-sse.cisco.com/ * Trying x.x.x.66... * Connected to api-sse.cisco.com (x.x.x.66) port 443 (#0) * ALPN, offering http/1.1 * Cipher selection: ALL:!EXPORT:!EXPORT40:!EXPORT56:!aNULL:!LOW:!RC4:@STRENGTH * successfully set certificate verify locations: * CAfile: none CApath: /etc/ssl/certs * TLSv1.2 (OUT), TLS header, Certificate Status (22): * TLSv1.2 (OUT), TLS handshake, Client hello (1): * TLSv1.2 (IN), TLS handshake, Server hello (2): * TLSv1.2 (IN), TLS handshake, Certificate (11): * TLSv1.2 (IN), TLS handshake, Server key exchange (12): * TLSv1.2 (IN), TLS handshake, Request CERT (13): * TLSv1.2 (IN), TLS handshake, Server finished (14): * TLSv1.2 (OUT), TLS handshake, Certificate (11): * TLSv1.2 (OUT), TLS handshake, Client key exchange (16): * TLSv1.2 (OUT), TLS change cipher, Client hello (1): * TLSv1.2 (OUT), TLS handshake, Finished (20): * TLSv1.2 (IN), TLS change cipher, Client hello (1): * TLSv1.2 (IN), TLS handshake, Finished (20): * SSL connection using TLSv1.2 / ECDHE-RSA-AES128-GCM-SHA256 * ALPN, server accepted to use http/1.1

* Server certificate: * subject: C=US; ST=California; L=San Jose; O=Cisco Systems, Inc.; CN=api -sse.cisco.com * start date: 2019-12-03 20:57:56 GMT * expire date: 2021-12-03 21:07:00 GMT * issuer: C=US; O=HydrantID (Avalanche Cloud Corporation); CN=HydrantID S SL ICA G2 * SSL certificate verify result: self signed certificate in certificate c hain (19), continuing anyway. > GET / HTTP/1.1 > Host: api-sse.cisco.com > User-Agent: curl/7.44.0 > Accept: */* < HTTP/1.1 403 Forbidden < Date: Wed, 08 Apr 2020 01:27:55 GMT < Content-Type: text/plain; charset=utf-8 < Content-Length: 9 < Connection: keep-alive < Keep-Alive: timeout=5 < ETag: "5e17b3f8-9" < Cache-Control: no-store < Pragma: no-cache < Content-Security-Policy: default-src 'self' < X-Content-Type-Options: nosniff < X-XSS-Protection: 1; mode=block < Strict-Transport-Security: max-age=31536000; includeSubdomains;

SSE 포털에 등록 문제

FMC와 FTD 모두 관리 인터페이스의 SSE URL에 연결해야 합니다. 연결을 테스트하려면 루트 액 세스로 Firepower CLI에 다음 명령을 입력합니다.

<#root>

curl -v https://api-sse.cisco.com/providers/sse/services/registration/api/v2/clients --cacert /ngfw/etc/

curl -v <u>https://est.sco.cisco.com</u> --cacert /ngfw/etc/ssl/connectorCA.pem

curl -v https://eventing-ingest.sse.itd.cisco.com --cacert /ngfw/etc/ssl/connectorCA.pem

curl -v https://mx01.sse.itd.cisco.com --cacert /ngfw/etc/ssl/connectorCA.pem

인증서 검사는 다음 명령으로 우회할 수 있습니다.

root@ftd01:~# curl -v -k https://api-sse.cisco.com

- * Rebuilt URL to: https://api-sse.cisco.com/
- * Trying x.x.x.66...

* Connected to api-sse.cisco.com (x.x.x.66) port 443 (#0)

```
* ALPN, offering http/1.1
* Cipher selection: ALL:!EXPORT:!EXPORT40:!EXPORT56:!aNULL:!LOW:!RC4:@STRENGTH
* successfully set certificate verify locations:
* CAfile: none
CApath: /etc/ssl/certs
* TLSv1.2 (OUT), TLS header, Certificate Status (22):
* TLSv1.2 (OUT), TLS handshake, Client hello (1):
* TLSv1.2 (IN), TLS handshake, Server hello (2):
* TLSv1.2 (IN), TLS handshake, Certificate (11):
* TLSv1.2 (IN), TLS handshake, Server key exchange (12):
* TLSv1.2 (IN), TLS handshake, Request CERT (13):
* TLSv1.2 (IN), TLS handshake, Server finished (14):
* TLSv1.2 (OUT), TLS handshake, Certificate (11):
* TLSv1.2 (OUT), TLS handshake, Client key exchange (16):
* TLSv1.2 (OUT), TLS change cipher, Client hello (1):
* TLSv1.2 (OUT), TLS handshake, Finished (20):
* TLSv1.2 (IN), TLS change cipher, Client hello (1):
* TLSv1.2 (IN), TLS handshake, Finished (20):
* SSL connection using TLSv1.2 / ECDHE-RSA-AES128-GCM-SHA256
* ALPN, server accepted to use http/1.1
* Server certificate:
* subject: C=US; ST=California; L=San Jose; O=Cisco Systems, Inc.; CN=api -sse.cisco.com
* start date: 2019-12-03 20:57:56 GMT
* expire date: 2021-12-03 21:07:00 GMT
* issuer: C=US; 0=HydrantID (Avalanche Cloud Corporation); CN=HydrantID S SL ICA G2
* SSL certificate verify result: self signed certificate in certificate c hain (19), continuing anyway.
> GET / HTTP/1.1
> Host: api-sse.cisco.com
> User-Agent: curl/7.44.0
> Accept: */*
>
< HTTP/1.1 403 Forbidden
< Date: Wed, 08 Apr 2020 01:27:55 GMT
< Content-Type: text/plain; charset=utf-8
< Content-Length: 9
< Connection: keep-alive
< Keep-Alive: timeout=5
< ETag: "5e17b3f8-9"
< Cache-Control: no-store
< Pragma: no-cache
< Content-Security-Policy: default-src 'self'
< X-Content-Type-Options: nosniff
< X-XSS-Protection: 1; mode=block
< Strict-Transport-Security: max-age=31536000; includeSubdomains;
```

참고: 테스트에서 전송된 매개변수가 SSE의 예상과 다르지만 연결을 검증하기에 충분하므로 403 Forbidden 메시지가 표시됩니다.

SSEConnector 상태 확인

표시된 대로 커넥터 속성을 확인할 수 있습니다.

```
# more /ngfw/etc/sf/connector.properties
registration_interval=180
connector_port=8989
```

SSConnector와 EventHandler 간의 연결을 확인하기 위해 이 명령을 사용할 수 있습니다. 이 예는 잘못된 연결의 예입니다.

root@firepower:/etc/sf# netstat -anlp | grep EventHandler_SSEConnector.sock unix 2 [ACC] STREAM LISTENING 3022791165 11204/EventHandler /ngfw/var/sf/run/EventHandler_SSEConnecto

설정된 연결의 예에서는 스트림 상태가 connected 임을 확인할 수 있습니다.

root@firepower:/etc/sf# netstat -anlp | grep EventHandler_SSEConnector.sock unix 2 [ACC] STREAM LISTENING 382276 7741/EventHandler /ngfw/var/sf/run/EventHandler_SSEConnector.soc unix 3 [] STREAM CONNECTED 378537 7741/EventHandler /ngfw/var/sf/run/EventHandler_SSEConnector.soc

SSE 포털 및 CTR으로 전송된 데이터 확인

FTD 디바이스에서 이벤트를 전송하여 https://eventing-ingest.sse.itd.cisco.com으로 TCP 연결을 설 정해야 하는지 확인하려면 SSE 포털<u>과 FTD 사이</u>에 설정되지 않은 연결의 예입니다.

root@firepower:/ngfw/var/log/connector# lsof -i | grep conn connector 60815 www 10u IPv4 3022789647 0t0 TCP localhost:8989 (LISTEN) connector 60815 www 12u IPv4 110237499 0t0 TCP firepower.cisco.com:53426->ec2-100-25-93-234.compute-1.a

connector.log 로그에서:

time="2020-04-13T14:34:02.88472046-05:00" level=error msg="[firepower.cisco.com][events.go:90 events:co time="2020-04-13T14:38:18.244707779-05:00" level=error msg="[firepower.cisco.com][events.go:90 events:c time="2020-04-13T14:42:42.564695622-05:00" level=error msg="[firepower.cisco.com][events.go:90 events:c time="2020-04-13T14:47:48.484762429-05:00" level=error msg="[firepower.cisco.com][events.go:90 events:c time="2020-04-13T14:47:48.484762429-05:00" level=error msg="[firepower.cisco.com][events.go:90 events:c

참고: 표시된 x.x.x.246 및 1x.x.x.246의 IP 주소는 <u>https://eventing-ingest.sse.itd.cisco.com</u>에 속하므로 변경해야 합니다. 따라서 IP 주소 대신 URL을 기준으로 SSE 포털에 트래픽을 허용 하는 것이 좋습니다.

이 연결이 설정되지 않으면 이벤트가 SSE 포털로 전송되지 않습니다. 다음은 FTD와 SSE 포털 간에 설정된 연결의 예입니다.

root@firep	lsof	-i gr	rep co	onn		
connector	13277	WWW	10u	IPv4	26077573	
connector	13277	www	19u	IPv4	26077679	

0t0 TCP localhost:8989 (LISTEN) 0t0 TCP x.x.x.200:56495->ec2-35-172-147-246.compute-1.

이 번역에 관하여

Cisco는 전 세계 사용자에게 다양한 언어로 지원 콘텐츠를 제공하기 위해 기계 번역 기술과 수작업 번역을 병행하여 이 문서를 번역했습니다. 아무리 품질이 높은 기계 번역이라도 전문 번역가의 번 역 결과물만큼 정확하지는 않습니다. Cisco Systems, Inc.는 이 같은 번역에 대해 어떠한 책임도 지지 않으며 항상 원본 영문 문서(링크 제공됨)를 참조할 것을 권장합니다.