Atualizar HA do FTD Gerenciado pelo FDM

Contents

Introdução
Pré-requisitos
Requisitos
Componentes Utilizados
Overview
Informações de Apoio
Configurar
Etapa 1. Carregar Pacote de Atualização
Etapa 2. Verificar Preparação
Etapa 3. Atualizar o FTD no HA
Etapa 4. Alternar Peer Ativo (Opcional)
Etapa 5. Implantação Final
Validar

Introdução

Este documento descreve o processo de atualização de um Cisco Secure Firewall Threat Defense em alta disponibilidade gerenciado por um gerenciador de dispositivos Firepower.

Pré-requisitos

Requisitos

A Cisco recomenda que você conheça estes tópicos:

- Conceitos e configuração de alta disponibilidade (HA)
- Configuração do Cisco Secure Firepower Device Manager (FDM)
- Configuração do Cisco Secure Firewall Threat Defense (FTD)

Componentes Utilizados

As informações neste documento são baseadas no Virtual Cisco FTD, versão 7.2.8.

As informações neste documento foram criadas a partir de dispositivos em um ambiente de laboratório específico. Todos os dispositivos utilizados neste documento foram iniciados com uma configuração (padrão) inicial. Se a rede estiver ativa, certifique-se de que você entenda o impacto potencial de qualquer comando.

Overview

A maneira como o FDM funciona é atualizar um item de mesmo nível por vez. Primeiro, o Standby e, em seguida, o Ative, realizando um failover antes que o upgrade Ative seja iniciado.

Informações de Apoio

O pacote de atualização deve ser baixado de software.cisco.com antes da atualização.

Em clish de CLI, execute o comando show high-availability config no FTD Ativo para verificar o status do HA.

> show high-availability config Failover On Failover unit Primary Failover LAN Interface: failover-link GigabitEthernet0/2 (up) Reconnect timeout 0:00:00 Unit Poll frequency 1 seconds, holdtime 15 seconds Interface Poll frequency 5 seconds, holdtime 25 seconds Interface Policy 1 Monitored Interfaces 3 of 311 maximum MAC Address Move Notification Interval not set failover replication http Version: Ours 9.18(3)53, Mate 9.18(3)53 Serial Number: Ours 9A1QUNFWPK1, Mate 9A45VNEHB5C Last Failover at: 11:57:26 UTC Oct 8 2024 This host: Primary - Active Active time: 507441 (sec) slot 0: ASAv hw/sw rev (/9.18(3)53) status (Up Sys) Interface diagnostic (0.0.0.0): Normal (Waiting) Interface inside (192.168.45.1): Normal (Waiting) Interface outside (192.168.1.10): Normal (Waiting) slot 1: snort rev (1.0) status (up) slot 2: diskstatus rev (1.0) status (up) Other host: Secondary - Standby Ready

Active time: 8 (sec)

```
Interface diagnostic (0.0.0.0): Normal (Waiting)
Interface inside (0.0.0.0): Normal (Waiting)
Interface outside (0.0.0.0): Normal (Waiting)
slot 1: snort rev (1.0) status (up)
slot 2: diskstatus rev (1.0) status (up)
```

Se nenhum erro estiver visível, prossiga com a atualização.

Configurar

Etapa 1. Carregar Pacote de Atualização

• Carregue o pacote de atualização do FTD no FDM usando a GUI.

Ele deve ser baixado anteriormente do site do software Cisco com base no modelo do FTD e na versão desejada. Navegue até Device > Updates > System Upgrade.



Atualizações

• Procure a imagem baixada anteriormente e escolhaCarregar.



Note: Carregue a imagem nos nós ativo e standby.

6	Important
	This device is a peer in a high availability configuration. You must install upgrades in a precise order. For details, see link [2]
The	e are no software upgrades available on the system.
Unlo	ad an ungrada file to install

Executar Verificação de Preparação

Etapa 2. Verificar Preparação

As verificações de prontidão confirmam se os dispositivos estão prontos para continuar com a atualização.

• Escolha Executar Verificação de Preparação para Atualização.

System Upgrade Current version 7.2.5-2	208
Important This device is a p precise order. For	eer in a high availability configuration. You must install upgrades in a details, see link 🕐
File	Cisco_FTD_Upgrade-7.2.8-25.sh.REL Replace file 14 Oct 2024 05:06 PM
Upgrade to	7.2.8-25
Readiness Check	Not Performed Yet Run Upgrade Readiness Check
UPGRADE NOW	Reboot required

Executar Verificação de Preparação

A Important	
This device is precise order.	a peer in a high availability configuration. You must install upgrades in a For details, see link 🖸
File	Cisco_FTD_Upgrade-7.2.8-25.sh.REL in Replace file
Upgrade to	7.2.8-25
Readiness Check	Not Performed Yet Run Upgrade Readiness Check

Important

This device is a peer in a high availability configuration. You must install upgrades in a precise order. For details, see link 🖸

File	Cisco_FTD_Upgrade-7.2.8-25.sh.REL Replace file 14 Oct 2024 05:06 PM
Upgrade to	7.2.8-25
Readiness Check	ululu Please Wait
UPGRADE NOW	Reboot required

Executar Verificação de Preparação

O andamento pode ser verificado navegando até System > Upgrade.

System Upgrade	e
Current version 7.2.5	5-208
f Important	
This device is a precise order. F	a peer in a high availability configuration. You must install upgrades in a For details, see link 🖸
File	Cisco_FTD_Upgrade-7.2.8-25.sh.REL The second s
Upgrade to	7.2.8-25
Readiness Check	Precheck Success Run Upgrade Readiness Check 14 Oct 2024 05:51 PM
	Pehoot required

A atualização pode ser feita quando a verificação de preparação for concluída no FTD e o resultado for Êxito.

Etapa 3. Atualizar o FTD no HA

• Escolha FDM em Espera e clique em Atualizar Agora.

 Important This device is a 	peer in a high availability configuration. You must install upgrad	les in a
precise order. F	or details, see link 🖸	
File	Cisco_FTD_Upgrade-7.2.8-25.sh.REL 💼 Replace fil 14 Oct 2024 05:06 PM	9
Upgrade to	7.2.8-25	
Readiness Check	Precheck Success Run Upgrade Readiness Check 14 Oct 2024 05:51 PM	
	B Dehoot required	

Atualizar agora

Antes de iniciar a atualização:

- 1. Não inicie uma restauração do sistema ao mesmo tempo que uma atualização do sistema.
- 2. Não reinicialize o sistema durante a atualização. O sistema reinicializa automaticamente no momento apropriado durante a atualização, se uma reinicialização for necessária.
- 3. Não desligue o dispositivo durante a atualização. Interromper a atualização pode tornar o sistema inutilizável.

Você será desconectado do sistema quando a atualização for iniciada. Após a conclusão da instalação, o dispositivo é reinicializado.

Confirm System Upgrade	×
 Before starting the upgrade: 1. Do not start a system restore at the same time as a system upgrade. 2. Do not reboot the system during the upgrade. The system automatically reboots at the appropriate time during upgrade if a reboot is necessary. 3. Do not power off the device during the upgrade. Interrupting the upgrade can leave the system in an unusable state. You will be logged out of the system when the upgrade begins. After the installation completes, the device will be rebooted. 	
Automatically cancel on upgrade failure and roll back to the previous version	
CANCEL	

Continuar



Note: A atualização leva cerca de 20 min por FTD.

Na CLI, o progresso pode ser verificado na pasta de atualização /ngfw/var/log/sf; mova para o modo expert e acesso enterroot.

> expert

admin@firepower:~\$ sudo su

Password:

root@firepower:/home/admin# cd /ngfw/var/log/sf

root@firepower:/ngfw/var/log/sf# ls

Cisco_FTD_Upgrade-7.2.8.

root@firepower:/ngfw/var/log/sf/Cisco_FTD_Upgrade-7.2.8# ls -lrt

root@firepower:/ngfw/var/log/sf/Cisco_FTD_Upgrade-7.2.8# tail -f status.log

ui: Upgrade in progress: (8% done.22 mins to reboot). Preparing to upgrade... (200_pre/011_check_self. ui: Upgrade in progress: (8% done.22 mins to reboot). Preparing to upgrade... (200_pre/015_verify_rpm. ui: Upgrade in progress: (8% done.22 mins to reboot). Preparing to upgrade... (200_pre/100_check_dashb ui: Upgrade in progress: (8% done.22 mins to reboot). Preparing to upgrade... (200_pre/100_get_snort_f ui: Upgrade in progress: (12% done.21 mins to reboot). Preparing to upgrade... (200_pre/110_setup_upgra ui: Upgrade in progress: (12% done.21 mins to reboot). Preparing to upgrade... (200_pre/120_generate_au ui: Upgrade in progress: (12% done.21 mins to reboot). Preparing to upgrade... (200_pre/120_generate_au

ui: Upgrade in progress: (79% done. 5 mins to reboot). Finishing the upgrade... (999_finish/999_zz_inst ui: Upgrade in progress: (83% done. 4 mins to reboot). Finishing the upgrade... (999_finish/999_zzz_com ui: Upgrade complete

ui: The system will now reboot.

ui: System will now reboot.

Broadcast message from root@firepower (Mon Oct 14 12:01:26 2024): System will reboot in 5 seconds due to system upgrade.

Broadcast message from root@firepower (Mon Oct 14 12:01:31 2024): System will reboot now due to system upgrade.

Broadcast message from root@firepower (Mon Oct 14 12:01:39 2024): The system is going down for reboot NOW! Atualize a segunda unidade.

Alternar funções para tornar este dispositivo ativo: Selecione Device> High Availability e, em seguida, selecione Switch Mode no menu de engrenagens. Aguarde o status da unidade para mudar para ativo e confirme se o tráfego está fluindo normalmente. Em seguida, faça logoff.

Atualização: Repita as etapas anteriores para fazer login no novo standby, carregar o pacote, atualizar o dispositivo, monitorar o progresso e verificar o sucesso.



Alta Disponibilidade

Na CLI, vá para LINA (system support diagnostic-cli) e verifique o estado de failover no FTD de standby usando o comando show failover state.

> system support diagnostic-cli
Attaching to Diagnostic CLI ... Press 'Ctrl+a then d' to detach.
Type help or '?' for a list of available commands.

primary_ha> enable

Password:

primary_ha# show failover state

State Last Failure Reason Date/Time

This host - Primary

Standby Ready None Other host - Secondary Active None

====Configuration State===

Sync Skipped - STANDBY

====Communication State===

Mac set

primary_ha#

Etapa 4. Alternar Peer Ativo (Opcional)



Note: Se o dispositivo secundário estiver Ativo, ele não terá nenhum impacto operacional.

Ter o dispositivo primário como ativo e secundário como em espera é uma prática recomendada que ajuda a rastrear qualquer failover que possa ocorrer.

Nesse caso, o FTD Ativo agora está em Espera, um failover manual pode ser usado para redefinilo como Ativo.

• Navegue até Devices > High Availability.

Ф	Firewall Device Manager	题 Monitoring	100 Policies	前回 Objects	Device: firepower	6) 🚑	0	?	admin Administ	tudor ~	cuce SECURE
	Model Cisco Fir	epower Threat Defe	use for VMwa	Software 7.2.8-25	VD8 Intrusion Rule Update 353.0 20220511-1540	Cloud Services	ed Register	High	Availability ary Device	Standby 2	Peer: Active	
			4	Cisco Firepowe	er Threat Defense for VMware ()	Harr			1 D	6 Sever		
		C mare	Network				SP/MAN	Gateway	© **	P Server Imart License		
					808							

Alta Disponibilidade

• EscolhaAlternar modo.

Firewall Device Manager Monitoring Policies Objects Device: firepower	5. 🚑 🗐 ? 🗄 admin Administrator	· diversi SECURE
Device Summary High Availability		
Primary Device Current Device Mode: Standby 2 Peer: Active Eallover, History Deployment History		Resume HA
High Availability Configuration Select and configure the peer device based on the following characteristics.	Fallover Criteria INTERACE FALLIRE THRESHOLD Fallow Criteria	Suspend HA Break HA
GENERAL DEVICE INFORMATION Model Cisco Firepower Threat Defense for VMware	Number of failed interfaces exceeds	1 1-211

Modo de comutação

• Escolha OK para confirmar o failover.

Make This Device the Active Peer						
Please check whether the active unit is currently switch modes while a deployment job is in progre lose your configuration changes. Are you sure you want to switch modes to make t	running a deployme ess, the job will fail a this device the activ	ent job. If you and you will re unit?				
	CANCEL	ОК				

Validação do status de alta disponibilidade ao final da atualização e failover concluída.

Firewall Device Manager Monitoring Policies	Device: firepower	5. 🚑 🗐 ? : admin Administrator ~ deelse SECURE
Model Cisco Firepower Threat Defense for VMwa	Software VD8 Intrusion Rule Update 	Cloud Services High Availability (a) Not Registered Register Primary Device: Active 2 Peer: Standby
	Gisco Firepower Threat Defense for Wilware	EAS Server
C Inside Network		SP/0244/Gateway
	600	CONSOLE

Dispositivos

Etapa 5. Implantação Final

• Implante a política nos dispositivos clicando em IMPLANTAR AGORA na guia Implantação.



Donding	Changes
renuing	Changes

0	\sim
v	\sim

	Last Deployment Completed Successfully 14 Oct 2024 06:26 PM. <u>See Deployment History</u>		
	Deployed Version (14 Oct 2024 06:26 PM)	Pending Version (LEGEND
Ø	Rule Update Version Edited: 20220511-1540		1
	lastSuccessSRUDate: 2024-10-08 06:15:04Z -	2024-10-14 12:53:26Z lspVersions[1]: 20220511-1540	
0	VDB Version Edited: 353		
O	Snort Version Added: 3.1.21.800-2		
	-	<pre>snortVersion: 3.1.21.800-2</pre>	- 1
	-	<pre>snortPackage: /ngfw/var/sf/snort-3.1.21.800-2/snor name: 3.1.21.800-2</pre>	
			_
0	Data SSL Cipher Setting Edited: DefaultDataSSLCipherSetting		
Ø	SSL Cipher Edited: DefaultSSLCipher		
	-	<pre>protocolVersions[0]: TLSV1</pre>	
	-	<pre>protocolVersions[1]: DTLSV1 protocolVersions[2]: TLSV1 1</pre>	
		P	
0	Intrusion Policy Edited: Security Over Connectivity - Cisco Talos		
Ø	Intrusion Policy Edited: Maximum Detection - Cisco Talos		
М	ORE ACTIONS V	CANCEL DEPLOY NOW	~

Implantação de política

Validar

Para validar se o status do HA e a atualização foram concluídos, você deve confirmar o status: Preliminar: Ativo Secundário: Pronto para espera

Ambos estão na versão que foi alterada recentemente (7.2.8 neste exemplo).

Firewall Device Manager Monitoring Policies	Device: firepower	S (a) (a) (c) (c) (c) (c) (c) (c) (c) (c) (c) (c
Model Cisco Firepower Threat Defense for VMws	Software VDB Intrusion Bule Update 7.2.8-25 353.0 20220511-1540	Cloud Services High Availability © Not Registered Register Primary Device: Active 🚯 Peer: Standby
	Cisco Firepower Threat Defense for Villware	MONT
C Inside Network		Constant Con

Failover

• Em cliches de CLI, verifique o estado de failover usando os comandos show failover stateand show failoverpara obter informações mais detalhadas.

Sistema operacional extensível Cisco Firepower (FX-OS) v2.12.1 (build 73) Defesa contra ameaças do Cisco Firepower para VMware v7.2.8 (compilação 25)

> show failover state				
	State	Last Failure Reason Date/Time		
This host -	Primary			
	Active	None		
Other host -	Secondary			
	Standby Ready	None		
====Configurat	ion State===			
Sync Skipped				
====Communication State===				
Mac se	t			
> show failove	r			
Failover On				
Failover unit Primary				
Failover LAN I	nterface: failo	over-link GigabitEthernet0/2 (up)		

Reconnect timeout 0:00:00 Unit Poll frequency 1 seconds, holdtime 15 seconds Interface Poll frequency 5 seconds, holdtime 25 seconds Interface Policy 1 Monitored Interfaces 3 of 311 maximum MAC Address Move Notification Interval not set failover replication http Version: Ours 9.18(4)210, Mate 9.18(4)210 Serial Number: Ours 9A1QUNFWPK1, Mate 9A45VNEHB5C Last Failover at: 14:13:56 UTC Oct 15 2024 This host: Primary - Active Active time: 580 (sec) slot 0: ASAv hw/sw rev (/9.18(4)210) status (Up Sys) Interface diagnostic (0.0.0.0): Normal (Waiting) Interface inside (192.168.45.1): Normal (Waiting) Interface outside (192.168.1.10): Normal (Waiting) slot 1: snort rev (1.0) status (up) slot 2: diskstatus rev (1.0) status (up) Other host: Secondary - Standby Ready Active time: 91512 (sec) Interface diagnostic (0.0.0.0): Normal (Waiting) Interface inside (0.0.0.0): Normal (Waiting) Interface outside (0.0.0.0): Normal (Waiting) slot 1: snort rev (1.0) status (up) slot 2: diskstatus rev (1.0) status (up)

Stateful Failover Logical Update Statistics

Link : failover-link GigabitEthernet0/2 (up)				
Stateful Obj	xmit	xerr	rcv	rerr
General	11797	0	76877	0

sys cmd	11574	0	11484	0
up time	0	0	0	0
RPC services	0	0	0	0
TCP conn	0	0	0	0
UDP conn	176	0	60506	0
ARP tbl	45	0	4561	0
Xlate_Timeout	0	0	0	0
IPv6 ND tbl	0	0	0	0
VPN IKEv1 SA	0	0	0	0
VPN IKEv1 P2	0	0	0	0
VPN IKEv2 SA	0	0	0	0
VPN IKEv2 P2	0	0	0	0
VPN CTCP upd	0	0	0	0
VPN SDI upd	0	0	0	0
VPN DHCP upd	0	0	0	0
SIP Session	0	0	0	0
SIP Tx 0	0	0	0	
SIP Pinhole	0	0	0	0
Route Session	1	0	0	0
Router ID	0	0	0	0
User-Identity	0	0	30	0
CTS SGTNAME	0	0	0	0
CTS PAC	0	0	0	0
TrustSec-SXP	0	0	0	0
IPv6 Route	0	0	0	0
STS Table	0	0	0	0
Umbrella Device	-ID 0	0	0	
Rule DB B-Sync	0	0	30	0
Rule DB P-Sync	1	0	266	0
Rule DB Delete	0	0	0	0

Logical Update Queue Information

	Cur	Max	Total
Recv Q:	0	31	123591
Xmit Q:	0	1	12100

Se ambos os FTDs estiverem na mesma versão e o status do HA estiver íntegro, a atualização será concluída.

Sobre esta tradução

A Cisco traduziu este documento com a ajuda de tecnologias de tradução automática e humana para oferecer conteúdo de suporte aos seus usuários no seu próprio idioma, independentemente da localização.

Observe que mesmo a melhor tradução automática não será tão precisa quanto as realizadas por um tradutor profissional.

A Cisco Systems, Inc. não se responsabiliza pela precisão destas traduções e recomenda que o documento original em inglês (link fornecido) seja sempre consultado.