



Flexible Netflow Export to an IPv6 Address

The Export to an IPv6 Address feature enables Flexible NetFlow to export data to a destination using an IPv6 address.

- [Finding Feature Information, on page 1](#)
- [Information About Flexible Netflow Export to an IPv6 Address, on page 1](#)
- [How to Configure Flexible Netflow Export to an IPv6 Address, on page 1](#)
- [Configuration Examples for Flexible Netflow Export to an IPv6 Address, on page 4](#)
- [Additional References, on page 6](#)

Finding Feature Information

Your software release may not support all the features documented in this module. For the latest caveats and feature information, see [Bug Search Tool](#) and the release notes for your platform and software release. To find information about the features documented in this module, and to see a list of the releases in which each feature is supported, see the feature information table.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to www.cisco.com/go/cfn. An account on Cisco.com is not required.

Information About Flexible Netflow Export to an IPv6 Address

Flexible Netflow Export to an IPv6 Address Overview

This feature enables Flexible NetFlow to export data to a destination using an IPv6 address.

How to Configure Flexible Netflow Export to an IPv6 Address

Configuring the Flow Exporter

Perform this required task to configure the flow exporter.



Note Each flow exporter supports only one destination.
You can export to a destination using either an IPv4 or IPv6 address.

SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **flow exporter** *exporter-name*
4. **description** *description*
5. **destination** *{ip-address | hostname}* [**vrf** *vrf-name*]
6. **dscp** *dscp*
7. **source** *interface-type interface-number*
8. **output-features**
9. **template data timeout** *seconds*
10. **transport udp** *udp-port*
11. **ttl** *seconds*
12. **end**
13. **show flow exporter** *exporter-name*
14. **show running-config flow exporter** *exporter-name*

DETAILED STEPS

	Command or Action	Purpose
Step 1	enable Example: Device> enable	Enables privileged EXEC mode. • Enter your password if prompted.
Step 2	configure terminal Example: Device# configure terminal	Enters global configuration mode.
Step 3	flow exporter <i>exporter-name</i> Example: Device(config)# flow exporter EXPORTER-1	Creates the flow exporter and enters Flexible NetFlow flow exporter configuration mode. • This command also allows you to modify an existing flow exporter.
Step 4	description <i>description</i> Example: Device(config-flow-exporter)# description Exports to the datacenter	(Optional) Configures a description to the exporter that will appear in the configuration and the display of the show flow exporter command.

	Command or Action	Purpose
Step 5	destination <i>{ip-address hostname} [vrf vrf-name]</i> Example: <pre>Device(config-flow-exporter)# destination 172.16.10.2</pre>	Specifies the IP address or hostname of the destination system for the exporter. Note You can export to a destination using either an IPv4 or IPv6 address.
Step 6	dscp <i>dscp</i> Example: <pre>Device(config-flow-exporter)# dscp 63</pre>	(Optional) Configures differentiated services code point (DSCP) parameters for datagrams sent by the exporter. <ul style="list-style-type: none"> The range for the <i>dscp</i> argument is from 0 to 63. Default: 0.
Step 7	source <i>interface-type interface-number</i> Example: <pre>Device(config-flow-exporter)# source ethernet 0/0</pre>	(Optional) Specifies the local interface from which the exporter will use the IP address as the source IP address for exported datagrams.
Step 8	output-features Example: <pre>Device(config-flow-exporter)# output-features</pre>	(Optional) Enables sending export packets using quality of service (QoS) and encryption.
Step 9	template data timeout <i>seconds</i> Example: <pre>Device(config-flow-exporter)# template data timeout 120</pre>	(Optional) Configures resending of templates based on a timeout. <ul style="list-style-type: none"> The range for the <i>seconds</i> argument is 1 to 86400 (86400 seconds = 24 hours).
Step 10	transport udp <i>udp-port</i> Example: <pre>Device(config-flow-exporter)# transport udp 650</pre>	Specifies the UDP port on which the destination system is listening for exported datagrams. <ul style="list-style-type: none"> The range for the <i>udp-port</i> argument is from 1 to 65536.
Step 11	ttl <i>seconds</i> Example: <pre>Device(config-flow-exporter)# ttl 15</pre>	(Optional) Configures the time-to-live (TTL) value for datagrams sent by the exporter. <ul style="list-style-type: none"> The range for the <i>seconds</i> argument is from 1 to 255.
Step 12	end Example: <pre>Device(config-flow-exporter)# end</pre>	Exits flow exporter configuration mode and returns to privileged EXEC mode.
Step 13	show flow exporter <i>exporter-name</i> Example: <pre>Device# show flow exporter FLOW_EXPORTER-1</pre>	(Optional) Displays the current status of the specified flow exporter.

	Command or Action	Purpose
Step 14	show running-config flow exporter <i>exporter-name</i> Example: Device# show running-config flow exporter FLOW_EXPORTER-1	(Optional) Displays the configuration of the specified flow exporter.

Configuration Examples for Flexible Netflow Export to an IPv6 Address

Example: Configuring Multiple Export Destinations

The following example shows how to configure multiple export destinations for Flexible NetFlow for IPv4 or IPv6 traffic. This sample starts in global configuration mode:

The following example shows how to configure multiple export destinations for Flexible NetFlow for IPv4:

```

!
flow exporter EXPORTER-1
 destination 172.16.10.2
 transport udp 90
 exit
!
flow exporter EXPORTER-2
 destination 172.16.10.3
 transport udp 90
 exit
!
flow record v4_r1
 match ipv4 tos
 match ipv4 protocol
 match ipv4 source address
 match ipv4 destination address
 match transport source-port
 match transport destination-port
 collect counter bytes long
 collect counter packets long

flow monitor FLOW-MONITOR-1
 record v4_r1
 exporter EXPORTER-2
 exporter EXPORTER-1
!

ip cef
!
interface GigabitEthernet1/0/0
 ip address 172.16.6.2 255.255.255.0
 ip flow monitor FLOW-MONITOR-1 input
!

```

The following example shows how to configure multiple export destinations for Flexible NetFlow for IPv6:

```
!  
flow exporter EXPORTER-1  
  destination 172.16.10.2  
  transport udp 90  
  exit  
!  
flow exporter EXPORTER-2  
  destination 172.16.10.3  
  transport udp 90  
  exit  
!  
  
flow record v6_r1  
match ipv6 traffic-class  
match ipv6 protocol  
match ipv6 source address  
match ipv6 destination address  
match transport source-port  
match transport destination-port  
collect counter bytes long  
collect counter packets long  
!  
  
!  
flow monitor FLOW-MONITOR-2  
  record v6_r1  
  exporter EXPORTER-2  
  exporter EXPORTER-1  
!  
ip cef  
!  
interface GigabitEthernet1/0/0  
  ipv6 address 2001:DB8:2:ABCD::2/48  
  ipv6 flow monitor FLOW-MONITOR-2 input  
!
```

The following display output shows that the flow monitor is exporting data to the two exporters:

```
Device# show flow monitor FLOW-MONITOR-1  
Flow Monitor FLOW-MONITOR-1:  
  Description:      User defined  
  Flow Record:     v4_r1  
  Flow Exporter:   EXPORTER-1  
                  EXPORTER-2  
  
Cache:  
  Type:            normal (Platform cache)  
  Status:         allocated  
  Size:           4096 entries / 311316 bytes  
  Inactive Timeout: 15 secs  
  Active Timeout:  1800 secs  
  Update Timeout:  1800 secs
```

Additional References

Related Documents

Related Topic	Document Title
Cisco IOS commands	Cisco IOS Master Command List, All Releases
Flexible NetFlow conceptual information and configuration tasks	<i>Flexible NetFlow Configuration Guide</i>
Flexible NetFlow commands	<i>Cisco IOS Flexible NetFlow Command Reference</i>

Standards/RFCs

Standard	Title
No new or modified standards/RFCs are supported by this feature.	—

MIBs

MIB	MIBs Link
None	To locate and download MIBs for selected platforms, Cisco software releases, and feature sets, use Cisco MIB Locator found at the following URL: http://www.cisco.com/go/mibs

Technical Assistance

Description	Link
The Cisco Support and Documentation website provides online resources to download documentation, software, and tools. Use these resources to install and configure the software and to troubleshoot and resolve technical issues with Cisco products and technologies. Access to most tools on the Cisco Support and Documentation website requires a Cisco.com user ID and password.	http://www.cisco.com/cisco/web/support/index.html