



# Cisco Connected Grid Router 2010 Software Configuration Guide

**First Published:** 2010-05-27

**Last Updated:** 2017-10-25

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

All printed copies and duplicate soft copies are considered un-Controlled copies and the original on-line version should be referred to for latest version.

Cisco has more than 200 offices worldwide. Addresses, phone numbers, and fax numbers are listed on the Cisco website at [www.cisco.com/go/offices](http://www.cisco.com/go/offices).

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: [www.cisco.com/go/trademarks](http://www.cisco.com/go/trademarks). Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1721R)

© 2010–2017 Cisco Systems, Inc. All rights reserved.



## Preface

---

**First Published: May 27, 2010, OL-20356-01**  
**Last Updated: October 25, 2017**

## Organization

The document organization is described in the following table:

1	<a href="#">Overview of the Hardware and Software</a>	Describes new hardware and software features in this release, features by platform, new slots, common ports, and getting started tasks.
2	<a href="#">Setup for Initial Configuration</a>	Describes how to perform the initial configuration of the router using the Cisco Setup command facility, verifying the initial configuration, and completing the configuration.
3	<a href="#">Cisco IOS CLI for Initial Configuration</a>	Describes how to perform the initial configuration of the router using the Cisco IOS command-line interface (CLI), and additional configuration procedures for the router.
4	<a href="#">Basic Router Configuration</a>	Describes how to perform the basic router configuration, interface configuration, and routing configuration.
5	<a href="#">Configuring Backup Data Lines and Remote Management</a>	Describes how to configure backup interfaces, configure dial backup, and remote management.
6	<a href="#">Upgrading the Cisco IOS Software</a>	Describes how to upgrade the Cisco IOS software image on the router or the access point.
7	<a href="#">Using CompactFlash Memory</a>	Describes how to use Advanced Capability CompactFlash (CF) memory cards on the router.
8	<a href="#">Using ROM Monitor</a>	Describes how to use the ROM monitor to manually load a system image, upgrade the system image when there are no TFTP servers or network connections, or for disaster recovery.
9	<a href="#">Changing the Configuration Register Settings</a>	Describes the 16-bit configuration register in NVRAM and how to make changes to the register settings using the Cisco IOS CLI.

# Conventions

This document uses the following conventions:

Convention	Indication
<b>bold font</b>	Commands and keywords and user-entered text appear in <b>bold font</b> .
<i>italic font</i>	Document titles, new or emphasized terms, and arguments for which you supply values are in <i>italic font</i> .
[ ]	Elements in square brackets are optional.
{ x   y   z }	Required alternative keywords are grouped in braces and separated by vertical bars.
[ x   y   z ]	Optional alternative keywords are grouped in brackets and separated by vertical bars.
string	A nonquoted set of characters. Do not use quotation marks around the string or the string will include the quotation marks.
<code>courier font</code>	Terminal sessions and information the system displays appear in <code>courier font</code> .
< >	Nonprinting characters such as passwords are in angle brackets.
[ ]	Default responses to system prompts are in square brackets.
!, #	An exclamation point (!) or a pound sign (#) at the beginning of a line of code indicates a comment line.



## Note

Means *reader take note*.



## Tip

Means *the following information will help you solve a problem*.



## Caution

Means *reader be careful*. In this situation, you might perform an action that could result in equipment damage or loss of data.



## Timesaver

Means *the described action saves time*. You can save time by performing the action described in the paragraph.



## Warning

Means ***reader be warned***. In this situation, you might perform an action that could result in **bodily injury**.



# Overview of the Hardware and Software

---

**First Published: May 27, 2010, OL-20356-01**  
**Last Updated: October 25, 2017**

The Cisco Connected Grid Router 2010 (Cisco CGR 2010) router is a member of the Cisco Connected Grid Router 2000 Series family of routers. The Cisco CGR 2010 router is designed to run in the extreme and demanding power substation environment. It is an especially rugged, high-performance router that provides LAN and WAN connectivity, field replaceable parts, and feature upgrades through software licensing. The Cisco CGR 2010 router is designed to withstand hostile environments while continuing to deliver the performance, availability, and reliability to scale mission-critical needs.

## Audience

The Cisco IOS software documentation set is intended primarily for users who configure and maintain Cisco networking devices (such as routers and switches) but who may not be familiar with the tasks, the relationship between tasks, or the Cisco IOS software commands necessary to perform particular tasks. The Cisco IOS software documentation set is also intended for those users experienced with Cisco IOS software who need to know about new features, new configuration options, and new software characteristics in the current Cisco IOS software release.

The Cisco Connected Grid Router 2010 router is described in the following sections.

- [New Features in this Release, page 2](#)
- [Features by Platform, page 3](#)
- [Platform Description, page 3](#)
- [Common Ports, page 4](#)
- [Activating the Cisco Software License, page 4](#)
- [Getting Started, page 4](#)



## Note

---

This document is written for experienced technical workers who install, monitor, and troubleshoot routers under a service contract, or who work for an information technology (IT) department.

---



---

**Americas Headquarters:**  
**Cisco Systems, Inc., 170 West Tasman Drive, San Jose, CA 95134-1706 USA**

© 2010 Cisco Systems, Inc. All rights reserved.

# New Features in this Release

New features in this release are described in [Table 1](#).

**Table 1** *New Features*

Feature	Description
<b>USB Console</b>	Cisco Connected Grid Router 2010 provides an additional mechanism for configuring the system through a personal computer connected to a USB console. The traditional RJ-45 console port is also available.
<b>Advanced Capability CompactFlash</b>	Cisco Connected Grid Router 2010 uses Advanced Capability CompactFlash memory to store the system image, configuration files, and some software data files. The Advanced Capability CompactFlash is capable of supporting PIO mode 6 which provides higher transfer rates. <b>Note</b> If an Advanced Capability Flash is not available, a warning message is displayed.
<b>SFP/Gigabit Ethernet Port</b>	Cisco Connected Grid Router 2010 has an SFP <sup>1</sup> /Gigabit Ethernet port that supports a maximum of two ports of either copper or fiber connections. Media can be configured for failover redundancy when the network goes down. See the <a href="#">Chapter 1, “Configuring Backup Data Lines and Remote Management”</a> . <b>Only</b> the following certified industrial-grade (i-Temp) SFPs are supported: <ul style="list-style-type: none"> <li>GLC-FE-100FX-RGD—100BASE-FX SFP module for Industrial Ethernet 100-MB ports, 1310 nm wavelength, 2 km over MMF; cable distance supported: 1.24 miles (2 km)</li> <li>GLC-FE-100LX-RGD—100BASE-LX SFP module for Industrial Ethernet 100-MB ports, 1310 nm wavelength, 10 km over SMF; cable distance supported: 6.2 miles (10 km)</li> <li>GLC-ZX-SM-RGD 1000BASE-ZX SFP transceiver module for SMF, 1550-nm wavelength, industrial Ethernet; cable distance supported: 43.4 to 62 miles (70 to 100 km)</li> <li>GLC-LX-SM-RGD 1000BASE-LX/LH SFP transceiver module for MMF and SMF, 1300-nm wavelength, industrial Ethernet; cable distance supported: 1804 feet (550 m)</li> <li>GLC-SX-MM-RGD 1000BASE-SX SFP transceiver module for MMF, 850-nm wavelength, industrial Ethernet; cable distance supported: Modal Bandwidth (MHz/km) 400—1640 feet (500 m); Modal Bandwidth 500—1804 feet (550 m)</li> </ul> The RJ-45 supports the 10BASE-T, 100BASE-TX and 1000BASE-T IEEE copper standards.
<b>New Module and Interface Card Features</b>	Cisco CGR 2010 introduces the following new vertical module and GRWICs <sup>2</sup> which are inserted in the router slots. <ul style="list-style-type: none"> <li>GRWIC-1CE1T1-PRI—1-Port T1/E1 GRWIC</li> <li>GRWIC-2CE1T1-PRI—2-Port T1/E1 GRWIC</li> <li>GRWIC-8A/S-232—8-Port A/S Serial GRWIC</li> </ul> <b>Note</b> See the router’s Hardware Installation Guide for a complete list of supported modules and interface cards.

1. Small Form-factor Pluggable

2. Grid Router WAN Interface Cards

## Features by Platform

Table 2 shows new feature support by platform.

**Table 2** *New Features in this Release for the Cisco CGR 2010 Router Platform*

Features	CGR 2010
New Module and Interface Card Features	Y
SFP/Gigabit Ethernet Port	Y
Advanced Capability CompactFlash	Y
Multi-Gigabit Fabric Communication	N

## Platform Description

The following sections describe the Cisco Connected Grid Router 2010.

### Cisco Connected Grid Router 2010 Slots and Ports

Table 3 describes Cisco Connected Grid Router 2010 slots and ports.

**Table 3** *Cisco CGR 2010 Series Models*

Router	SW GRWIC Slots	DW GRWIC Slot	CF Slots	GE/SFP ports
Cisco CGR 2010	4	2	2	2

### GRWIC Form Factors and Slot Numbering

Cisco Connected Grid Router 2010 supports one of the following three GRWIC module options:

- Option 1: Four single-wide GRWIC modules
- Option 2: Two double-wide GRWIC modules
- Option 3: One double-wide and two single-wide GRWIC modules
- Option 4: Two single-wide and one double-wide GRWIC modules

Table 4 shows the form factor capability of each GRWIC slot.

**Table 4** GRWICs Slot Compatibility on Cisco CGR 2010

Options	Slot 3	Slot 2	Slot 1	Slot 0
Option 1	Single-wide GRWIC	Single-wide GRWIC	Single-wide GRWIC	Single-wide GRWIC
Option 2	Double-wide GRWIC		Double-wide GRWIC	
Option 3	Double-wide GRWIC		Single-wide GRWIC	Single-wide GRWIC
Option 4	Single-wide GRWIC	Single-wide GRWIC	Double-wide GRWIC	

## Common Ports

- Gigabit Ethernet RJ45/SFP— Ports available through RJ45 and SFP connectors. Connection will fail over if the secondary connection goes down.
- RS232 Aux Port— Supports modem control lines and remote administration for box-to-box redundancy applications.
- RS232 Console Port— Supports modem control lines and remote administration of the router with the proprietary cable shipped in the box.
- Type A USB 2.0— Supports USB-based flash memory sticks, security tokens, and USB-compliant devices.
- Type B USB Console Port— Supports modem control lines and remote administration of the router using a type B USB-compliant cable.

## Activating the Cisco Software License

For a quick start guide to deploy and activate software for your Cisco Connected Grid Router 2010, see [Cisco IOS Software Activation](#) website. For more information about the Cisco Software Activation process, see [Cisco IOS Software Activation Conceptual Overview](#). For an e-learning presentation about Cisco license activation, see [Introduction to Cisco Software Activation](#).

## Getting Started

Install the router in an appropriate location as described in the Hardware Installation Guide. Connect the router using the appropriate cables, then supply power. Perform the following steps.

- 
- Step 1** See the [Chapter 1, “Setup for Initial Configuration”](#) and perform the initial software configuration using Cisco Configuration Professional Express.
- Step 2** See the [Chapter 1, “Basic Router Configuration”](#) and perform the basic router configuration.
-





# Setup for Initial Configuration

---

**First Published: May 27, 2010, OL-20356-01**  
**Last Updated: October 25, 2017**

This module describes how to perform the initial configuration on the Cisco Connected Grid Router 2010 using the Cisco Setup command facility. However, we recommend using Cisco Configuration Professional Express (Cisco CPE). Cisco CPE is a web-based graphical-user interface that lets you perform the initial configuration.

For cross-platform system requirements, feature support, memory recommendations, platform-specific information, new and changed information, and other information related to Cisco IOS Release 15.1T, see [Release Notes for Cisco IOS Release 15.1T](#).

## Contents

- [Cisco Configuration Professional, page 5](#)
- [Cisco Setup Command Facility, page 6](#)
- [Verifying the Initial Configuration, page 9](#)
- [Completing the Configuration, page 9](#)

## Cisco Configuration Professional

After you connect cables and supply power to the router, download and use the [Cisco Configuration Professional](#) (Cisco CP) or Cisco CPE web-based application to configure the initial router settings.

### Cisco Configuration Professional

Cisco CP is a GUI-based device management tool that allows you to configure Cisco IOS-based access routers, including Cisco Connected Grid Router 2010 routers. Cisco CP simplifies router, security, unified communications, wireless, WAN, and basic LAN configuration through GUI-based, easy-to-use wizards. Cisco CP is installed on a PC. See [Cisco Configuration Professional Quick Start Guide](#) for detailed Cisco CP installation instructions.

For instructions on using the Cisco CP, see the Cisco CP online help.



---

**Americas Headquarters:**  
**Cisco Systems, Inc., 170 West Tasman Drive, San Jose, CA 95134-1706 USA**

© 2010 Cisco Systems, Inc. All rights reserved.

**Cisco Configuration Professional Express**

Cisco CP Express is a light weight version of Cisco CP. You can use Cisco CP Express to configure basic security features on the router's LAN and WAN interfaces. Cisco CP Express is available on the router Flash memory. See the Cisco CP Express online help for detailed instructions.

## Cisco Setup Command Facility

The setup command facility prompts you to enter the information that is needed to quickly configure a router using the IOS command-line interface (CLI). The facility steps you through a initial configuration, including LAN and WAN interfaces. For more general information about the setup command facility, see the following document:

[Cisco IOS Configuration Fundamentals Configuration Guide, Release 12.4](#), see Part 2: Cisco IOS User Interfaces: Using AutoInstall and Setup.

## Using the Setup Command Facility to Perform Initial Configuration

This section explains how to configure a hostname for the router, set passwords, and configure an interface for communication with the management network.

**Note**

The messages that are displayed will vary based on your router model, the installed interface modules, and the software image. The following example and the user entries (in **bold**) are shown as examples only.

**Note**

If you make a mistake while using the **setup** command facility, you can **exit** and run the **setup** command facility again. Press **Ctrl-C**, and enter the **setup** command in privileged EXEC mode (Router#).

**Step 1**

Enter the **setup** command facility using the Cisco IOS command-line interface (CLI) in privileged EXEC mode:

```
Router> enable
Password: password
Router# setup

--- System Configuration Dialog ---
Continue with configuration dialog? [yes/no]: y
```

By entering y(es), you are now in the Setup Configuration Utility.

The prompts in the setup command facility vary; depending on your router model, on the installed interface modules, and on the software image. The following steps and the user entries (in **bold**) are shown as examples only.

**Note**

If you make a mistake while using the setup command facility, you can exit and run the setup command facility again. Press Ctrl-C, and enter the setup command at the privileged EXEC mode prompt (Router#). For more information on using the setup command facility, see [The Setup Command](#) chapter in [Cisco IOS Configuration Fundamentals Command Reference, Release 12.2T](#).

**Step 2** To proceed using the setup command facility, enter **yes**.

```
Continue with configuration dialog? [yes/no]: yes
```

At any point you may enter a question mark '?' for help.  
Use ctrl-c to abort configuration dialog at any prompt.  
Default settings are in square brackets '['].

Basic management setup configures only enough connectivity  
for management of the system, extended setup will ask you  
to configure each interface on the system

**Step 3** Basic management setup configures only enough connectivity.

```
Would you like to enter basic management setup? [yes/no]: yes
```

**Step 4** Enter a hostname for the router (this example uses *myrouter*):

```
Configuring global parameters:  
Enter host name [Router]: myrouter
```

**Step 5** Enter an enable secret password. This password is encrypted (for more security) and cannot be seen when viewing the configuration.

The enable secret is a password used to protect access to  
privileged EXEC and configuration modes. This password, after  
entered, becomes encrypted in the configuration.  
Enter enable secret: **cisco**

**Step 6** Enter an enable password that is different from the enable secret password. This password is *not* encrypted (and is less secure) and can be seen when viewing the configuration.

The enable password is used when you do not specify an  
enable secret password, with some older software versions, and  
some boot images.  
Enter enable password: **cisco123**

**Step 7** Enter the virtual terminal password, which prevents unauthenticated access to the router through ports other than the console port:

The virtual terminal password is used to protect  
access to the router over a network interface.  
Enter virtual terminal password: **cisco**

**Step 8** Respond to the following prompts as appropriate for your network:

```
Configure SNMP Network Management? [no]: yes  
Community string [public]:
```

A summary of the available interfaces is displayed.



**Note** The interface summary includes interface numbering, which is dependent on the router model and the installed modules and interface cards.

Current interface summary

Interface	IP-Address	OK?	Method	Status	Prol
GigabitEthernet0/0	192.168.1.2	YES	NVRAM	administratively down	down
GigabitEthernet0/1	unassigned	YES	NVRAM	up	up
Serial0/0/1	unassigned	YES	NVRAM	administratively down	down
Serial0/0/2	unassigned	YES	NVRAM	administratively down	down

```

Serial0/0/3          unassigned    YES NVRAM  administratively down dow
Serial0/0/4          unassigned    YES NVRAM  administratively down dow
Serial0/0/5          unassigned    YES NVRAM  administratively down dow
Serial0/0/6          unassigned    YES NVRAM  administratively down dow
Serial0/0/7          unassigned    YES NVRAM  administratively down dow
Serial0/0/0          unassigned    YES NVRAM  up           up

```

Enter interface name used to connect to the management network from the above interface summary:

**Step 9** Select one of the available interfaces for connecting the router to the management network:

Enter interface name used to connect to the management network from the above interface summary: **gigabitethernet0/0**

**Step 10** Respond to the following prompts as appropriate for your network:

```

Configuring interface GigabitEthernet0/0:
  Configure IP on this interface? [yes]: yes
    IP address for this interface [1.8.83.134]:
      Subnet mask for this interface [255.0.0.0] : 255.255.255.0
      Class A network is 1.0.0.0, 24 subnet bits; mask is /24

```

The following configuration command script was created:

```

hostname myrouter
enable secret 5 $1$qjk5$63TwshQT6hdlzZcc.v4VK1
enable password lab
line vty 0 4
password cisco
snmp-server community public
!
no ip routing

!
interface GigabitEthernet0/0
no shutdown
ip address 1.8.83.134 255.255.255.0
no mop enabled
!
interface GigabitEthernet0/1
shutdown
no ip address
!
end

```

**Step 11** Respond to the following prompts. Select [2] to save the initial configuration:

```

[0] Go to the IOS command prompt without saving this config.
[1] Return back to the setup without saving this config.
[2] Save this configuration to nvram and exit.

```

Enter your selection [2]: **2**  
Building configuration...

```

Feb 22 04:43:44.835: %SYS-5-CONFIG_I: Configured from console by console[OK]
Use the enabled mode 'configure' command to modify this configuration.

```

The user prompt is displayed:

```
myrouter#
```

---

## Verifying the Initial Configuration

To verify that the new interfaces are operating correctly, perform the following tests:

- To verify that the interfaces and line protocol are in the correct state—up or down—enter the `show interfaces` command.
- To display a summary status of the interfaces configured for IP, enter the `show ip interface brief` command.
- To verify that you configured the correct hostname and password, enter the `show configuration` command.

After you complete and verify the initial configuration, you can configure your Cisco router for specific functions.

## Completing the Configuration

When you have provided all the information requested by the `setup` command facility, the configuration appears. To complete your router configuration, follow these steps:

- Step 1** A `setup` command facility prompts you to save the configuration.
- If you answer **no**, the configuration information you entered is *not* saved, and you return to the router enable prompt (`Router#`). Enter `setup` to return to the System Configuration Dialog.
  - If you answer **yes**, the configuration is saved, and you are returned to the user EXEC prompt (`Router>`).

- Step 2** When the messages stop appearing on your screen, press **Return** to get the `Router>` prompt.



**Note** If you see the next message, it means that no other AppleTalk routers were found on the network attached to the port.

```
%AT-6-ONLYROUTER: Ethernet0/0: AppleTalk port enabled; no neighbors found
```

- Step 3** The `Router>` prompt indicates that you are now at the CLI, and you have just completed a initial router configuration. Nevertheless, this is *not* a complete configuration. At this point, you have two choices:

- Run the setup command facility again, and create another configuration.

```
Router> enable
Password: password
Router# setup
```

- Modify the existing configuration or configure additional features using the CLI:

```
Router> enable
Password: password
Router# configure terminal
Router(config)#
```





# Cisco IOS CLI for Initial Configuration

---

**First Published: May 27, 2010, OL-20356-01**  
**Last Updated: October 25, 2017**

This module describes how to perform the initial configuration using the Cisco Internet Operating System (IOS) command-line interface on Cisco Connected Grid Router 2010.



**Note**

---

We recommend using Cisco Configuration Professional Express, a web-based GUI that lets you perform the initial configuration.

---

## Contents

- [Cisco Configuration Professional Express, page 11](#)
- [Prerequisites for Initial Software Configuration Using the Cisco IOS CLI, page 12](#)
- [Using the Cisco IOS CLI to Perform Initial Configuration, page 12](#)

## Cisco Configuration Professional Express

After you connect cables and supply power to the router, use Cisco Configuration Professional Express web-based application to configure the initial router settings. See [Cisco Configuration Professional Express User Guide](#) for detailed instructions.



---

**Americas Headquarters:**  
**Cisco Systems, Inc., 170 West Tasman Drive, San Jose, CA 95134-1706 USA**

© 2010-2017 Cisco Systems, Inc. All rights reserved.

# Prerequisites for Initial Software Configuration Using the Cisco IOS CLI

Follow the instructions in the Cisco Connected Grid Router 2010 hardware installation guide to install the chassis, connect cables, and supply power to the router.



## Timesaver

Before supplying power to the router, disconnect all WAN cables from the router to keep it from trying to run the AutoInstall process. The router tries to run AutoInstall if you power it on while there is a WAN connection on both ends and the router does not have a valid configuration file stored in NVRAM (for instance, when you add a new interface). It can take several minutes for the router to determine that AutoInstall is not connected to a remote TCP/IP host.

## Using the Cisco IOS CLI to Perform Initial Configuration

This section contains the following procedures:

- [Configuring the Router Hostname, page 12](#) (Optional)
- [Configuring the Enable and Enable Secret Passwords, page 13](#) (Required)
- [Configuring the Console Idle Privileged EXEC Timeout, page 15](#) (Optional)
- [Configuring Gigabit Ethernet Interfaces, page 16](#) (Required)
- [Specifying a Default Route or Gateway of Last Resort, page 19](#) (Required)
- [Configuring Virtual Terminal Lines for Remote Console Access, page 22](#) (Required)
- [Securing Access to the Ethernet Switch Module \(ESM\), page 24](#)
- [Configuring the Auxiliary Line, page 26](#) (Optional)
- [Verifying Network Connectivity, page 28](#) (Required)
- [Saving Your Router Configuration, page 29](#) (Required)
- [Saving Backup Copies of Configuration and System Image, page 29](#) (Optional)
- [Monitoring Environmental Parameters, page 31](#)

## Configuring the Router Hostname

The hostname is used in CLI prompts and default configuration filenames. If you do not configure the router hostname, the router uses the factory-assigned default hostname “Router.”

Do not expect case sensitivity to be preserved in the hostname. Uppercase and lowercase characters are treated identically by many Internet software applications. Conventions dictate that computer names appear in all lowercase characters. For more information, see [RFC 1178, Choosing a Name for Your Computer](#).

The name must also follow the rules for ARPANET hostnames. They must start with a letter, end with a letter or digit, and have only letters, digits, and hyphens as interior characters. Names must be 63 characters or fewer. For more information, see [RFC 1035, Domain Names—Implementation and Specification](#).



## SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **hostname** *name*
4. Verify that the router prompt displays your new hostname.
5. **end**

## DETAILED STEPS

	Command or Action	Purpose
Step 1	<b>enable</b>  <b>Example:</b> Router> enable	Enables privileged EXEC mode. <ul style="list-style-type: none"> <li>• Enter your password if prompted.</li> </ul>
Step 2	<b>configure terminal</b>  <b>Example:</b> Router# configure terminal	Enters global configuration mode.
Step 3	<b>hostname</b> <i>name</i>  <b>Example:</b> Router(config)# hostname myrouter	Specifies or modifies the hostname for the network server.
Step 4	Verify that the router prompt displays your new hostname.  <b>Example:</b> myrouter(config)#	—
Step 5	<b>end</b>  <b>Example:</b> myrouter# end	(Optional) Returns to privileged EXEC mode.

## Configuring the Enable and Enable Secret Passwords

To provide an additional layer of security, particularly for passwords that cross the network or are stored on an unsecured TFTP server, you can use either the **enable password** command or **enable secret** command. Both commands accomplish the same thing—they allow you to establish an encrypted password that users must enter to access privileged EXEC (enable) mode.

We recommend that you use the **enable secret** command because it uses an improved encryption algorithm. Use the **enable password** command only if you boot an older image of the Cisco IOS software or if you boot older boot ROMs that do not recognize the **enable secret** command.

For more information, see the “Configuring Security with Passwords, Privilege Levels, and Login Usernames for CLI Sessions on Networking Devices” chapter in *Cisco IOS Security Configuration Guide: Securing User Services, Release 15.0*. Also, see *Cisco IOS Password Encryption Facts* and *Cisco Guide to Harden Cisco IOS Devices*.

## Restrictions

If you configure the **enable secret** command, it takes precedence over the **enable password** command; the two commands cannot be in effect simultaneously.

## SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **enable password** *password*
4. **enable secret** *password*
5. **end**
6. **enable**
7. **end**

## DETAILED STEPS

	Command or Action	Purpose
Step 1	<b>enable</b>  <b>Example:</b> Router> enable	Enables privileged EXEC mode. <ul style="list-style-type: none"> <li>• Enter your password if prompted.</li> </ul>
Step 2	<b>configure terminal</b>  <b>Example:</b> Router# configure terminal	Enters global configuration mode.
Step 3	<b>enable password</b> <i>password</i>  <b>Example:</b> Router(config)# enable password pswd2	(Optional) Sets a local password to control access to various privilege levels. <ul style="list-style-type: none"> <li>• We recommend that you perform this step only if you boot an older image of the Cisco IOS software or if you boot older boot ROMs that do not recognize the <b>enable secret</b> command.</li> </ul>
Step 4	<b>enable secret</b> <i>password</i>  <b>Example:</b> Router(config)# enable secret greentree	Specifies an additional layer of security over the <b>enable password</b> command. <ul style="list-style-type: none"> <li>• Do not use the same password that you entered in <a href="#">Step 3</a>.</li> </ul>
Step 5	<b>end</b>  <b>Example:</b> Router(config)# end	Returns to privileged EXEC mode.

	Command or Action	Purpose
Step 6	<b>enable</b>  <b>Example:</b> Router> enable	Enables privileged EXEC mode. <ul style="list-style-type: none"> <li>Verify that your new enable or enable secret password works.</li> </ul>
Step 7	<b>end</b>  <b>Example:</b> Router(config)# end	(Optional) Returns to privileged EXEC mode.

## Configuring the Console Idle Privileged EXEC Timeout

This section describes how to configure the console line's idle privileged EXEC timeout. By default, the privileged EXEC command interpreter waits for 10 minutes to detect user input before timing out.

When you configure the console line, you can also set communication parameters, specify autobaud connections, and configure terminal operating parameters for the terminal that you are using. For more information on configuring the console line, see [Cisco IOS Configuration Fundamentals and Network Management Configuration Guide](#). In particular, see the “Configuring Operating Characteristics for Terminals” and “Troubleshooting and Fault Management” chapters.

### SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **line console 0**
4. **exec-timeout** *minutes* [*seconds*]
5. **end**
6. **show running-config**

### DETAILED STEPS

	Command or Action	Purpose
Step 1	<b>enable</b>  <b>Example:</b> Router> enable	Enables privileged EXEC mode. <ul style="list-style-type: none"> <li>Enter your password if prompted.</li> </ul>
Step 2	<b>configure terminal</b>  <b>Example:</b> Router# configure terminal	Enters global configuration mode.
Step 3	<b>line console 0</b>  <b>Example:</b> Router(config)# line console 0	Configures the console line and starts the line configuration command collection mode.

	Command or Action	Purpose
Step 4	<b>exec-timeout</b> <i>minutes</i> [ <i>seconds</i> ]  <b>Example:</b> Router(config-line)# exec-timeout 0 0	Sets the idle privileged EXEC timeout, which is the interval that the privileged EXEC command interpreter waits until user input is detected. <ul style="list-style-type: none"> <li>The example shows how to specify no timeout. Setting the exec-timeout value to 0 will cause the router to never log out once logged in. This could have security implications if you leave the console without manually logging out using the disable command.</li> </ul>
Step 5	<b>end</b>  <b>Example:</b> Router(config)# end	Returns to privileged EXEC mode.
Step 6	<b>show running-config</b>  <b>Example:</b> Router(config)# show running-config	Displays the running configuration file. <ul style="list-style-type: none"> <li>Verify that you properly configured the idle privileged EXEC timeout.</li> </ul>

## Examples

The following example shows how to set the console idle privileged EXEC timeout to 2 minutes 30 seconds:

```
line console
  exec-timeout 2 30
```

The following example shows how to set the console idle privileged EXEC timeout to 10 seconds:

```
line console
  exec-timeout 0 10
```

## Configuring Gigabit Ethernet Interfaces

This sections shows how to assign an IP address and interface description to an Ethernet interface on your router.

For comprehensive configuration information on Gigabit Ethernet interfaces, see the “[Configuring LAN Interfaces](#)” chapter of *Cisco IOS Interface and Hardware Component Configuration Guide, Release 15.0*.

### SUMMARY STEPS

1. **enable**
2. **show ip interface brief**
3. **configure terminal**
4. **interface gigabitethernet 0/port**
5. **media-type {rj45 | sfp}**
6. **description string**
7. **ip address ip-address mask**

8. **no shutdown**
9. **end**
10. **show ip interface brief**

## DETAILED STEPS

	Command or Action	Purpose
Step 1	<b>enable</b>  <b>Example:</b> Router> enable	Enables privileged EXEC mode. <ul style="list-style-type: none"> <li>• Enter your password if prompted.</li> </ul>
Step 2	<b>show ip interface brief</b>  <b>Example:</b> Router# show ip interface brief	Displays a brief status of the interfaces that are configured for IP. <ul style="list-style-type: none"> <li>• Learn which type of Ethernet interface is on your router.</li> </ul>
Step 3	<b>configure terminal</b>  <b>Example:</b> Router# configure terminal	Enters global configuration mode.
Step 4	<b>interface gigabitethernet 0/port</b>  <b>Example:</b> Router(config)# interface gigabitethernet 0/0	Specifies the Gigabit Ethernet interface and enters interface configuration mode.
Step 5	<b>media-type {rj45   sfp}</b>  <b>Example:</b> Router(config-if)# media-type sfp Router(config-if)#  <b>Example:</b> Router(config-if)# media-type rj45 Router(config-if)#	Designates SFP port as the primary media.  or Designates RJ45 as the primary media.
Step 6	<b>description string</b>  <b>Example:</b> Router(config-if)# description GE int to 2nd floor south wing	(Optional) Adds a description to an interface configuration. <ul style="list-style-type: none"> <li>• The description helps you remember what is attached to this interface. The description can be useful for troubleshooting.</li> </ul>
Step 7	<b>ip address ip-address mask</b>  <b>Example:</b> Router(config-if)# ip address 172.16.74.3 255.255.255.0	Sets a primary IP address for an interface.
Step 8	<b>no shutdown</b>  <b>Example:</b> Router(config-if)# no shutdown	Enables an interface.

	Command or Action	Purpose
Step 9	<code>end</code>  <b>Example:</b> Router(config)# end	Returns to privileged EXEC mode.
Step 10	<code>show ip interface brief</code>  <b>Example:</b> Router# show ip interface brief	Displays a brief status of the interfaces that are configured for IP. <ul style="list-style-type: none"> <li>Verify that the Ethernet interfaces are up and configured correctly.</li> </ul>

## Examples

### Sample Output for show interfaces gigabitethernet0/0 and show interfaces gigabitethernet0/1 Commands

```
Router# show interfaces gigabitethernet 0/0
GigabitEthernet0/0 is administratively down, line protocol is down
  Hardware is CN Gigabit Ethernet, address is 0022.bdd4.ba00 (bia 0022.bdd4.ba0)
  Internet address is 192.168.1.2/24
  MTU 1500 bytes, BW 1000000 Kbit/sec, DLY 10 usec,
    reliability 255/255, txload 1/255, rxload 1/255
  Encapsulation ARPA, loopback not set
  Keepalive set (10 sec)
  Full Duplex, 1Gbps, media type is no media
  output flow-control is unsupported, input flow-control is unsupported
  ARP type: ARPA, ARP Timeout 04:00:00
  Last input never, output 01:04:50, output hang never
  Last clearing of "show interface" counters never
  Input queue: 0/75/0/0 (size/max/drops/flushes); Total output drops: 0
  Queueing strategy: fifo
  Output queue: 0/40 (size/max)
  5 minute input rate 0 bits/sec, 0 packets/sec
  5 minute output rate 0 bits/sec, 0 packets/sec
    0 packets input, 0 bytes, 0 no buffer
    Received 0 broadcasts (0 IP multicasts)
    0 runts, 0 giants, 0 throttles
    0 input errors, 0 CRC, 0 frame, 0 overrun, 0 ignored
    0 watchdog, 0 multicast, 0 pause input
    1 packets output, 60 bytes, 0 underruns
    0 output errors, 0 collisions, 0 interface resets
    0 unknown protocol drops
    0 babbles, 0 late collision, 0 deferred
    0 lost carrier, 0 no carrier, 0 pause output
    0 output buffer failures, 0 output buffers swapped out
Router#
```

```
Router# show interfaces gigabitethernet0/1
GigabitEthernet0/1 is up, line protocol is up
  Hardware is CN Gigabit Ethernet, address is 0022.bdd4.ba01 (bia 0022.bdd4.ba0)
  MTU 1500 bytes, BW 1000000 Kbit/sec, DLY 10 usec,
    reliability 255/255, txload 1/255, rxload 1/255
  Encapsulation ARPA, loopback not set
  Keepalive set (10 sec)
  Full Duplex, 1Gbps, media type is RJ45
  output flow-control is XON, input flow-control is XON
  ARP type: ARPA, ARP Timeout 04:00:00
  Last input 00:00:19, output 00:00:08, output hang never
  Last clearing of "show interface" counters never
  Input queue: 0/75/0/0 (size/max/drops/flushes); Total output drops: 0
  Queueing strategy: fifo
```

```

Output queue: 0/40 (size/max)
5 minute input rate 0 bits/sec, 0 packets/sec
5 minute output rate 0 bits/sec, 0 packets/sec
 80 packets input, 20838 bytes, 0 no buffer
Received 78 broadcasts (0 IP multicasts)
 0 runs, 0 giants, 0 throttles
 0 input errors, 0 CRC, 0 frame, 0 overrun, 0 ignored
 0 watchdog, 66 multicast, 0 pause input
473 packets output, 48302 bytes, 0 underruns
 0 output errors, 0 collisions, 0 interface resets
 0 unknown protocol drops
 0 babbles, 0 late collision, 0 deferred
 0 lost carrier, 0 no carrier, 0 pause output
 0 output buffer failures, 0 output buffers swapped out
Router#

```

### Sample Output for the show ip interface brief Command

```

Router# show ip interface brief
Interface                IP-Address      OK? Method Status      Prol
GigabitEthernet0/0      192.168.1.2    YES NVRAM   administratively down dow
GigabitEthernet0/1      unassigned     YES NVRAM   up          up
Serial0/0/1             unassigned     YES NVRAM   administratively down dow
Serial0/0/2             unassigned     YES NVRAM   administratively down dow
Serial0/0/3             unassigned     YES NVRAM   administratively down dow
Serial0/0/4             unassigned     YES NVRAM   administratively down dow
Serial0/0/5             unassigned     YES NVRAM   administratively down dow
Serial0/0/6             unassigned     YES NVRAM   administratively down dow
Serial0/0/7             unassigned     YES NVRAM   administratively down dow
Serial0/0/0             unassigned     YES NVRAM   up          up
Router#

```

## Specifying a Default Route or Gateway of Last Resort

This section describes how to specify a default route with IP routing enabled. For alternative methods of specifying a default route, see the [Configuring a Gateway of Last Resort Using IP Commands](#) tech note.

The Cisco IOS software uses the gateway (router) of last resort if it does not have a better packet route and if the destination is not a connected network. This section describes how to select a network as a default route (a candidate route for computing the gateway of last resort). The way in which routing protocols propagate the default route information varies for each protocol.

For comprehensive configuration information about IP routing and IP routing protocols, see the [Cisco IOS IP Addressing Services Configuration Guide, Release 15.0](#). In particular, see the “Configuring IPv4 Addresses” chapter.

## IP Routing

You can configure integrated routing and bridging (IRB) so the router can route and bridge simultaneously. The router will act as an IP host on the network whether routing is enabled or not. For more information about IRB, see [Integrated Routing and Bridging \(IRB\)](#).

IP routing is automatically enabled in the Cisco IOS software. When IP routing is configured, the system uses a configured or learned route to forward packets, including a configured default route.

**Note**

This task section does not apply when IP routing is disabled. To specify a default route when IP routing is disabled, refer to [Configuring a Gateway of Last Resort Using IP Commands](#).

## Default Routes

A router might not be able to determine the routes to all other networks. To provide complete routing capability, the common practice is to use some routers as smart routers and give the remaining routers default routes to the smart router. (Smart routers have routing table information for the entire internetwork.) These default routes can be passed along dynamically, or can be configured into the individual routers.

Most dynamic interior routing protocols include a mechanism for causing a smart router to generate dynamic default information that is then passed along to other routers.

## Default Network

If a router has an interface that is directly connected to the specified default network, the dynamic routing protocols running on the router will generate or source a default route. In the case of Routing Information Protocol (RIP), the router advertises the pseudonetwork 0.0.0.0. In the case of Interior Gateway Routing Protocol (IGRP), the network itself is advertised and flagged as an exterior route.

A router that is generating the default for a network also may need a default of its own. One way a router can generate its own default is to specify a static route to the network 0.0.0.0 through the appropriate device.

## Gateway of Last Resort

When default information is being passed along through a dynamic routing protocol, no further configuration is required. The system periodically scans its routing table to choose the optimal default network as its default route. In the case of RIP, there is only one choice, network 0.0.0.0. In the case of IGRP, there might be several networks that can be candidates for the system default. The Cisco IOS software uses both administrative distance and metric information to determine the default route (gateway of last resort). The selected default route appears in the gateway of last resort display of the **show ip route EXEC** command.

If dynamic default information is not being passed to the software, candidates for the default route are specified with the **ip default-network** global configuration command. In this usage, the **ip default-network** command takes an unconnected network as an argument. If this network appears in the routing table from any source (dynamic or static), it is flagged as a candidate default route and is a possible choice as the default route.

If the router has no interface on the default network, but does have a route to it, it considers this network as a candidate default path. The route candidates are examined and the best one is chosen, based on administrative distance and metric. The gateway to the best default path becomes the gateway of last resort.

## SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **ip routing**



4. **ip route** *dest-prefix mask next-hop-ip-address* [*admin-distance*] [**permanent**]
5. **ip default-network** *network-number*  
or  
**ip route** *dest-prefix mask next-hop-ip-address*
6. **end**
7. **show ip route**

## DETAILED STEPS

	Command or Action	Purpose
Step 1	<b>enable</b>  <b>Example:</b> Router> enable	Enables privileged EXEC mode. <ul style="list-style-type: none"><li>Enter your password if prompted.</li></ul>
Step 2	<b>configure terminal</b>  <b>Example:</b> Router# configure terminal	Enters global configuration mode.
Step 3	<b>ip routing</b>  <b>Example:</b> Router(config)# ip routing	Enables IP routing.
Step 4	<b>ip route</b> <i>dest-prefix mask next-hop-ip-address</i> [ <i>admin-distance</i> ] [ <b>permanent</b> ]  <b>Example:</b> Router(config)# ip route 192.168.24.0 255.255.255.0 172.28.99.2	Establishes a static route.
Step 5	<b>ip default-network</b> <i>network-number</i> or <b>ip route</b> <i>dest-prefix mask next-hop-ip-address</i>  <b>Example:</b> Router(config)# ip default-network 192.168.24.0  <b>Example:</b> Router(config)# ip route 0.0.0.0 0.0.0.0 172.28.99.1	Selects a network as a candidate route for computing the gateway of last resort.  Creates a static route to network 0.0.0.0 0.0.0.0 for computing the gateway of last resort.
Step 6	<b>end</b>  <b>Example:</b> Router(config)# end	Returns to privileged EXEC mode.
Step 7	<b>show ip route</b>  <b>Example:</b> Router# show ip route	Displays the current routing table information. <ul style="list-style-type: none"><li>Verify that the gateway of last resort is set.</li></ul>

## Examples

### Sample Output for show ip route Command

```

Router# show ip route
Codes: L - local, C - connected, S - static, R - RIP, M - mobile, B - BGP
       D - EIGRP, EX - EIGRP external, O - OSPF, IA - OSPF inter area
       N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2
       E1 - OSPF external type 1, E2 - OSPF external type 2
       i - IS-IS, su - IS-IS summary, L1 - IS-IS level-1, L2 - IS-IS level-2
       ia - IS-IS inter area, * - candidate default, U - per-user static route
       o - ODR, P - periodic downloaded static route, + - replicated route

Gateway of last resort is 172.25.212.1 to network 0.0.0.0

S*    0.0.0.0/0 [1/0] via 172.25.212.1
      172.25.0.0/16 is variably subnetted, 2 subnets, 2 masks
C      172.25.212.0/25 is directly connected, GigabitEthernet0/0
L      172.25.212.39/32 is directly connected, GigabitEthernet0/0
Router#

```

## Configuring Virtual Terminal Lines for Remote Console Access

Virtual terminal lines (vty) are used to allow remote access to the router. This section shows you how to configure the vty with a password, so that only authorized users can remotely access the router.

The router has five vty lines by default. However, you can create additional vty lines as described in [Cisco IOS Terminal Services Configuration Guide, Release 15.0](#). See [Configuring Terminal Operating Characteristics for Dial-In Sessions](#) section.

Line passwords and password encryption is described in the “[Configuring Security with Passwords, Privilege Levels, and Login Usernames for CLI Sessions on Networking Devices](#)” section of [Cisco IOS Security Configuration Guide: Securing User Services, Release 15.0](#). If you want to secure the vty lines with an access list, see the “[IP Access List Overview](#)” chapter of [Cisco IOS Security Configuration Guide: Securing the Data Plane, Release 15.0](#). Also, see [Cisco IOS Password Encryption Facts](#).

### SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **line vty** *line-number* [*ending-line-number*]
4. **password** *password*
5. **login**
6. **end**
7. **show running-config**
8. From another network device, attempt to open a Telnet session to the router.

## DETAILED STEPS

	Command or Action	Purpose
Step 1	<b>enable</b>  <b>Example:</b> Router> enable	Enables privileged EXEC mode. <ul style="list-style-type: none"> <li>Enter your password if prompted.</li> </ul>
Step 2	<b>configure terminal</b>  <b>Example:</b> Router# configure terminal	Enters global configuration mode.
Step 3	<b>line vty</b> <i>line-number</i> [ <i>ending-line-number</i> ]  <b>Example:</b> Router(config)# line vty 0 4	Starts the line configuration command collection mode for the vty for remote console access. <ul style="list-style-type: none"> <li>Make sure that you configure all vty lines on your router.</li> </ul> <p><b>Note</b> To verify the number of vty lines on your router, use the <b>line vty ?</b> command.</p>
Step 4	<b>password</b> <i>password</i>  <b>Example:</b> Router(config-line)# password guessagain	Specifies a password on a line.
Step 5	<b>login</b>  <b>Example:</b> Router(config-line)# login	Enables password checking at login.
Step 6	<b>end</b>  <b>Example:</b> Router(config-line)# end	Returns to privileged EXEC mode.
Step 7	<b>show running-config</b>  <b>Example:</b> Router# show running-config	Displays the running configuration file. <ul style="list-style-type: none"> <li>Verify that you properly configured the virtual terminal lines for remote access.</li> </ul>
Step 8	From another network device, attempt to open a Telnet session to the router.  <b>Example:</b> Router# 172.16.74.3 Password:	Verifies that you can remotely access the router and that the virtual terminal line password is correctly configured.

## Examples

The following example shows how to configure virtual terminal lines with a password:

```
!
line vty 0 4
```

```
password guessagain  
login  
!
```

## What to Do Next

After you configure the vty lines, complete these steps:

- (Optional) To encrypt the virtual terminal line password, see the “[Configuring Security with Passwords, Privilege Levels, and Login Usernames for CLI Sessions on Networking Devices](#)” section of *Cisco IOS Security Configuration Guide: Securing User Services, Release 15.0*. Also, see *Cisco IOS Password Encryption Facts*.
- (Optional) To secure the vty lines with an access list, see *Cisco IOS Security Configuration Guide: Securing the Data Plane, Release 15.0*.
- (Optional) To configure an ACL on the line for the Ethernet Switch Module (ESM) to secure access to the CGR 2010 and ESM, see [Securing Access to the Ethernet Switch Module \(ESM\)](#), page 24.

## Securing Access to the Ethernet Switch Module (ESM)

You can configure an access list on the corresponding line number of the CGR 2010 slot containing the ESM to secure access to the ESM and prevent external access to the CGR 2010 using reverse telnet.

On a CGR2010 with an ESM module, the line number is always either 3 or 131. Perform the following steps to determine the line number and apply the ACL to that line.

### SUMMARY STEPS

1. **enable**
2. **show line**
3. **configure terminal**
4. **line** *line-number*
5. **access-class** *access-list-number* **in**
6. **access-class** *access-list-number* **out**
7. **access-list** *access-list-number* **deny tcp any any eq 2003**
8. **access-list** *access-list-number* **permit ip any any**
9. **end**
10. **write memory**

## DETAILED STEPS

	Command or Action	Purpose
Step 1	<b>enable</b>  <b>Example:</b> Router> enable	Enables privileged EXEC mode. <ul style="list-style-type: none"><li>Enter your password if prompted.</li></ul>
Step 2	<b>show line</b>  <b>Example:</b> Router# show line	Displays information about the terminal lines to determine the slot containing the ESM.
Step 3	<b>configure terminal</b>  <b>Example:</b> Router# configure terminal	Enters global configuration mode.
Step 4	<b>line line-number</b>  <b>Example:</b> Router(config)# line 3	Identifies a specific line for configuration and enters line configuration collection mode.
Step 5	<b>access-class access-list-number in</b>  <b>Example:</b> Router(config-line)# access-class 100 in	Creates an access list to control incoming connections on the line.
Step 6	<b>access-class access-list-number out</b>  <b>Example:</b> Router(config-line)# access-class 100 out	Creates an access list to control outgoing connections on the line.
Step 7	<b>access-list access-list-number deny tcp any any eq 2003</b>  <b>Example:</b> access-list 100 deny tcp any any eq 2003	Denies all TCP connections on port number 2003 (ESM port).
Step 8	<b>access-list access-list-number permit ip any any</b>  <b>Example:</b> access-list 100 permit ip any any	Allows all other IP connections.
Step 9	<b>end</b>  <b>Example:</b> Router(config-line)# end	Returns to privileged EXEC mode.
Step 10	<b>write memory</b>  <b>Example:</b> Router# write memory	Sets to boot the system image from flash memory.

## Example

In the following example, lines 3 and 131 correspond to ESMs in slots 0 and 2, respectively. This example shows configuring the access list for line 3:

```
Router> enable
Router# show line
      Tty Line Typ      Tx/Rx      A Modem  Roty AccO AccI  Uses  Noise Overruns  Int
*      0      0 CTY          - -          - - -    21    0    0/0    -
*      1      1 AUX    9600/9600  - -          - - -     1    0    0/0    -
      3      3 TTY  115200/115200- - -          - - -     2    0    0/0    -
*     131    131 TTY  115200/115200- - -          - - -     6    0    0/0    -
      132    132 VTY          - -          - - -     5    0    0/0    -
      133    133 VTY          - -          - - -     0    0    0/0    -
      134    134 VTY          - -          - - -     0    0    0/0    -
      135    135 VTY          - -          - - -     0    0    0/0    -
      136    136 VTY          - -          - - -     0    0    0/0    -

==
Router# configure terminal
Router(config)# line 3
Router(config-line)# access-class 100 in
Router(config-line)# access-class 100 out
!
Router(config-line)# access-list 100 deny tcp any any eq 2003
Router(config-line)# access-list 100 permit ip any any
!
Router(config-line)# end
Router# write memory
```

## Configuring the Auxiliary Line

This section describes how to enter line configuration mode for the auxiliary (AUX) line. How you configure the auxiliary line depends on your particular implementation of the auxiliary port. See the following documents for detailed information on configuring the auxiliary line:

- Technical Note: [Configuring a Modem on the AUX Port for EXEC Dialin Connectivity](#)
- Sample Configuration: [Configuring Dialout Using a Modem on the AUX Port](#)
- Sample Configuration: [Configuring AUX-to-AUX Port Async Backup with Dialer Watch](#)
- Technical Note: [Modem-Router Connection Guide](#)

### SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **line aux 0**
4. See the tech notes and sample configurations to configure the line for your particular implementation of the AUX port.

## DETAILED STEPS

	Command or Action	Purpose
Step 1	<b>enable</b>  <b>Example:</b> Router> enable	Enables privileged EXEC mode. <ul style="list-style-type: none"><li>• Enter your password if prompted.</li></ul>
Step 2	<b>configure terminal</b>  <b>Example:</b> Router# configure terminal	Enters global configuration mode.
Step 3	<b>line aux 0</b>  <b>Example:</b> Router(config)# line aux 0	Starts the line configuration command collection mode for the auxiliary line.
Step 4	See the tech notes and sample configurations to configure the line for your particular implementation of the AUX port.	—

## Verifying Network Connectivity

This section describes how to verify network connectivity for your router.

### Prerequisites

- Complete all previous configuration tasks in this document.
- The router must be connected to a properly configured network host.

### SUMMARY STEPS

1. **enable**
2. **ping** [*ip-address* | *hostname*]
3. **telnet** {*ip-address* | *hostname*}

### DETAILED STEPS

	Command or Action	Purpose
Step 1	<b>enable</b>  <b>Example:</b> Router> enable	Enables privileged EXEC mode. <ul style="list-style-type: none"> <li>• Enter your password if prompted.</li> </ul>
Step 2	<b>ping</b> [ <i>ip-address</i>   <i>hostname</i> ]  <b>Example:</b> Router# ping 172.16.74.5	Diagnoses initial network connectivity. <ul style="list-style-type: none"> <li>• To verify connectivity, ping the next hop router or connected host for each configured interface to.</li> </ul>
Step 3	<b>telnet</b> { <i>ip-address</i>   <i>hostname</i> }  <b>Example:</b> Router# telnet 172.16.72.3	Logs in to a host that supports Telnet. <ul style="list-style-type: none"> <li>• If you want to test the vty line password, perform this step from a different network device, and use your router's IP address.</li> </ul>

### Examples

The following display shows an example output for the **ping** command when you ping the IP address 172.25.212.39:

```
Router# ping
Protocol [ip]:
Target IP address: 172.25.212.39
Repeat count [5]:
Datagram size [100]:
Timeout in seconds [2]:
Extended commands [n]:
Sweep range of sizes [n]:
Type escape sequence to abort.
Sending 5, 100-byte ICMP Echos to 172.25.212.39, timeout is 2 seconds:
!!!!
Success rate is 100 percent (5/5), round-trip min/avg/max = 1/1/1 ms
Router#
```



The following display shows an example output for the **ping** command when you ping the IP hostname donald:

```
Router# ping donald

Type escape sequence to abort.
Sending 5, 100-byte ICMP Echos to 172.168.7.27, timeout is 2 seconds:
!!!!
Success rate is 100 percent, round-trip min/avg/max = 1/3/4 ms
```

## Saving Your Router Configuration

This section describes how to avoid losing your configuration at the next system reload or power cycle by saving the running configuration to the startup configuration in NVRAM. The NVRAM provides 256KB of storage on the router.

### SUMMARY STEPS

1. **enable**
2. **copy running-config startup-config**

### DETAILED STEPS

	Command or Action	Purpose
Step 1	<b>enable</b>  <b>Example:</b> Router> enable	Enables privileged EXEC mode. <ul style="list-style-type: none"> <li>• Enter your password if prompted.</li> </ul>
Step 2	<b>copy running-config startup-config</b>  <b>Example:</b> Router# copy running-config startup-config	Saves the running configuration to the startup configuration.

## Saving Backup Copies of Configuration and System Image

To aid file recovery and minimize downtime in case of file corruption, we recommend that you save backup copies of the startup configuration file and the Cisco IOS software system image file on a server.

### SUMMARY STEPS

1. **enable**
2. **copy nvram:startup-config {ftp: | rcp: | tftp:}**
3. **show {flash0 | flash1}:**
4. **copy {flash0 | flash1}: {ftp: | rcp: | tftp:}**

## DETAILED STEPS

	Command or Action	Purpose
Step 1	<b>enable</b>  <b>Example:</b> Router> enable	Enables privileged EXEC mode. <ul style="list-style-type: none"> <li>Enter your password if prompted.</li> </ul>
Step 2	<b>copy nvram:startup-config {ftp:   rcp:   tftp:}</b>  <b>Example:</b> Router# copy nvram:startup-config ftp:	Copies the startup configuration file to a server. <ul style="list-style-type: none"> <li>The configuration file copy can serve as a backup copy.</li> <li>Enter the destination URL when prompted.</li> </ul>
Step 3	<b>show {flash0 flash1}:</b>  <b>Example:</b> Router# show {flash0 flash1}:	Displays the layout and contents of a flash memory file system. <ul style="list-style-type: none"> <li>Learn the name of the system image file.</li> </ul> <p><b>Note</b> The command <b>flash:</b> and <b>flash0:</b> refer to the same device.</p>
Step 4	<b>copy {flash0 flash1}: {ftp:   rcp:   tftp:}</b>  <b>Example:</b> Router# copy {flash0 flash1}: ftp:	Copies a file from flash memory to a server. <ul style="list-style-type: none"> <li>Copy the system image file to a server to serve as a backup copy.</li> <li>Enter the filename and destination URL when prompted.</li> </ul>

## Examples

**Copying the Startup Configuration to a TFTP Server: Example**

The following example shows the startup configuration being copied to a TFTP server:

```
Router# copy nvram:startup-config tftp:

Remote host[ ]? 172.16.101.101

Name of configuration file to write [rtr2-config]? <cr>
Write file rtr2-config on host 172.16.101.101?[confirm] <cr>
![OK]
```

**Copying from Flash Memory to a TFTP Server: Example**

The following example shows the use of the **show flash** command in privileged EXEC to learn the name of the system image file and the use of the **copy {flash0}: tftp:** privileged EXEC command to copy the system image to a TFTP server. The router uses the default username and password.

```
Router# show flash
-#- --length-- -----date/time----- path
1   47295716 Feb 12 2010 22:00:58 cgr2010-universalk9-mz.SPA.151-1.T
2   47304696 Mar 04 2010 06:00:48 cgr2010-universalk9-mz.SPA.151-1.T
3     384478 Feb 18 2010 12:17:36 u-boot-cisco_3gorges_ram
4   2812042 Feb 18 2010 22:03:50 C2935R_RM2.srec.SSA
5   47304060 Feb 22 2010 20:45:16 cgr2010-universalk9-mz.SPA.151-1.T
6   47300944 Mar 02 2010 17:51:16 cgr2010-universalk9-mz.SPA.151-1.T
7   2812044 Mar 04 2010 06:12:54 CGR2010_RM2_0227.srec
8   11776175 Mar 30 2010 21:23:24 cgs2520-ipservices-mz.s12
9     146671 Mar 30 2010 23:16:42 crashinfo_20100330-231642-UTC
```

```

46469120 bytes available (207151104 bytes used)

Router#

Router# copy flash0: tftp:

IP address of remote host [255.255.255.255]? 172.16.13.110
filename to write on tftp host? c3600-c2is-mz
writing cgr2010-c2is-mz !!!!!...
successful ftp write.

```

## Monitoring Environmental Parameters

The Cisco Connected Grid Router 2010 includes sensors that measure the status and internal temperature of critical components. Internal component temperatures are measured for the central processor, internal components, and interface cards. A 72-hour temperature history is stored for the central processor at one-hour intervals.

Power consumption and power supplies are monitored. The measured temperature is compared to predetermined threshold limits and, if the temperature does not fall within the limits, the information is recorded and a warning sent to the system administrator by means of Simple Network Management Protocol (SNMP) traps until the temperature falls back to its normal range.

A command-line interface (CLI) command allows the display of the current system environment and temperature status.

Use the following CLI to monitor the system environment:

```
Router# show environment {all | last | table}
```

where:

- all—Displays all environmental monitor parameters
- last—Displays the last environmental monitor parameters
- table—Displays the table of temperature and voltage ranges

The following example shows a sample output of the **show environment all** command. In the following example, the power supplies are external:

```

Router# show environment all
SYSTEM POWER SUPPLY STATUS
=====
Internal Power Supply 1 Type: AC-POE
Internal Power Supply 1 POE Output Status: Normal

Internal Power Supply 2 Type: Absent

SYSTEM TEMPERATURE STATUS
=====
CPU temperature: 63 Celsius, Normal
Riser Card temperature: 39 Celsius, Normal
DRAM temperature: 32 Celsius, Normal
SFP temperature: 31 Celsius, Normal
GRWIC slot 0 temperature: 32 Celsius, Normal

REAL TIME CLOCK BATTERY STATUS
=====
Battery OK (checked at power up)

```

```

SYSTEM WATTAGE
=====
Motherboard Components Power consumption = 19.024 W
Total System Power consumption is: 19.024 W

Environmental information last updated 00:00:21

Router#

```

The following example shows a sample output of the **show environment last** command. In the following example, the power supplies are external:

```

Router# show environment last
SYSTEM POWER SUPPLY STATUS
=====
Internal Power Supply 1 Type: AC-POE
Internal Power Supply 1 POE Output Status: Normal

Internal Power Supply 2 Type: Absent

SYSTEM TEMPERATURE STATUS
=====
CPU temperature: 63 Celsius, Normal
Riser Card temperature: 38 Celsius, Normal
DRAM temperature: 32 Celsius, Normal
SFP temperature: 31 Celsius, Normal
GRWIC slot 0 temperature: 33 Celsius, Normal

REAL TIME CLOCK BATTERY STATUS
=====
Battery OK (checked at power up)

Router#

```

The following example shows a sample output of the **show environment table** command. In the following example, the power supplies are external:

```

Router# show environment table
SYSTEM POWER SUPPLY STATUS
=====
Internal Power Supply 1 Type: AC-POE
Internal Power Supply 1 POE Output Status: Normal

Internal Power Supply 2 Type: Absent

SYSTEM TEMPERATURE STATUS
=====
CPU temperature: 63 Celsius, Normal
Riser Card temperature: 39 Celsius, Normal
DRAM temperature: 32 Celsius, Normal
SFP temperature: 31 Celsius, Normal
GRWIC slot 0 temperature: 33 Celsius, Normal

REAL TIME CLOCK BATTERY STATUS
=====
Battery OK (checked at power up)

SYSTEM ALARMS SETTINGS
=====
CPU Over Temperature Alarm = 100C
Riser Card Over Temperature Alarm = 100C
DRAM Over Temperature Alarm = 85C
SFP Over Temperature Alarm = 85C

```

```
GRWIC slot 0 Over Temperature Alarm = 90C
GRWIC slot 1 Over Temperature Alarm = 90C
GRWIC slot 2 Over Temperature Alarm = 90C
GRWIC slot 3 Over Temperature Alarm = 90C
Power Supply Unit 1 Over Temperature Alarm = 100C
Power Supply Unit 2 Over Temperature Alarm = 100C
```

## SYSTEM VOLTAGES

=====

```
12V voltage = 11.944 V, Normal
5V voltage = 5.028 V, Normal
3.3V voltage = 3.288 V, Normal
2.5V voltage = 2.512 V, Normal
1.8V voltage = 1.801 V, Normal
1.2V voltage = 1.202 V, Normal
ASIC voltage = 1.052 V, Normal
CPU Core voltage = 1.065 V, Normal
```

## SYSTEM WATTAGE

=====

```
Motherboard Components Power consumption = 19.245 W
Total System Power consumption is: 19.245 W
```

```
Environmental information last updated 00:00:02
```

## ENVIRONMENTAL STRESS EVENTS

=====

```
Critical Temperature: Maxium = 0
                        Total Duration = 0
```

## ----- CPU TEMPERATURE SENSOR REGISTERS -----

```
REG: 0x0 : 0x28
REG: 0x1 : 0x3F
REG: 0x2 : 0x0
REG: 0x3 : 0x0
REG: 0x4 : 0x4
REG: 0x5 : 0x73
REG: 0x6 : 0xE7
REG: 0x7 : 0x78
REG: 0x8 : 0xE7
```

## ----- POWER SEQUENCER REGS -----

```
REG: 0x0 : 0x305
REG: 0x1 : 0x51
REG: 0x2 : 0x1
REG: 0x3 : 0x1
REG: 0x4 : 0x0
REG: 0x5 : 0x0
REG: 0x6 : 0x64BD
REG: 0x7 : 0xE713
REG: 0x8 : 0x2F3
REG: 0x9 : 0x2F8
REG: 0xA : 0x237
REG: 0xB : 0x2DA
REG: 0xC : 0x2DD
REG: 0xD : 0x2D8
REG: 0xE : 0x302
REG: 0xF : 0x304
REG: 0x10 : 0x300
REG: 0x11 : 0x319
REG: 0x12 : 0x31E
REG: 0x13 : 0x317
REG: 0x14 : 0x2AA
REG: 0x15 : 0x2AE
```

```
REG: 0x16 : 0x2A6
REG: 0x17 : 0x57
REG: 0x18 : 0x6C
REG: 0x19 : 0x40
REG: 0x1A : 0x1C8
REG: 0x1B : 0x1CD
REG: 0x1C : 0x1C4
REG: 0x1D : 0x18E
REG: 0x1E : 0x196
REG: 0x1F : 0x18C
REG: 0x20 : 0x18F
REG: 0x21 : 0x199
REG: 0x22 : 0x187
REG: 0x23 : 0x0
REG: 0x24 : 0x0
REG: 0x25 : 0x0
REG: 0x26 : 0x0
REG: 0x27 : 0x0
REG: 0x28 : 0x0
REG: 0x29 : 0x0
REG: 0x2A : 0x0
REG: 0x2B : 0x0
REG: 0x2C : 0x0
REG: 0x2D : 0x0
REG: 0x2E : 0x78
REG: 0x2F : 0x0
REG: 0x30 : 0x0
REG: 0x31 : 0x4600
REG: 0x32 : 0x902
REG: 0x33 : 0x905
REG: 0x34 : 0x905
REG: 0x35 : 0x900
REG: 0x36 : 0xC04
REG: 0x37 : 0x903
REG: 0x38 : 0x38
REG: 0x39 : 0xE03
REG: 0x3A : 0x8F
REG: 0x3B : 0x32
REG: 0x3C : 0x38
REG: 0x3D : 0xFFFF
REG: 0x3E : 0x0
REG: 0x3F : 0x0
REG: 0x40 : 0x0
REG: 0x41 : 0x0
REG: 0x42 : 0x0
REG: 0x43 : 0x0
Router#
```



# Basic Router Configuration

---

**First Published: May 27, 2010, OL-20356-01**  
**Last Updated: October 25, 2017**

This document provides basic configuration procedures for the Cisco Connected Grid Router 2010. It also includes configuration examples and verification steps, when possible.

## Basic Configuration

- [Default Configuration, page 34](#)
- [Configuring Basic Parameters, page 35](#)

## Interface Configuration

- [Interface Ports, page 36](#)
- [Configuring Gigabit Ethernet Interfaces, page 36](#)
- [Configuring a Loopback Interface, page 37](#)

## Routing Configuration

- [Configuring Command-Line Access, page 39](#)
- [Configuring Static Routes, page 40](#)
- [Configuring Dynamic Routes, page 42](#)
- [Typical Example of a Cisco CGR 2010 Configuration, page 44](#)



---

**Americas Headquarters:**  
**Cisco Systems, Inc., 170 West Tasman Drive, San Jose, CA 95134-1706 USA**

© 2010 Cisco Systems, Inc. All rights reserved.

## Default Configuration

When you boot up your Cisco router for the first time, you will notice a default configuration has already been performed. Use the **show running-config** command to view the initial configuration, as shown in the following example:

```
Router# show running-config
Building configuration...
Current configuration : 961 bytes
!
! Last configuration change at 20:41:11 UTC Thu Mar 1 1900
!
version 15.1
service timestamps debug datetime msec
service timestamps log datetime msec
no service password-encryption
service internal
!
hostname Router
!
boot-start-marker
boot-end-marker
!
!
no aaa new-model
!
no ipv6 cef
ip source-route
ip cef
!
!
!
!
multilink bundle-name authenticated
!
!
!
!
license udi pid CISCOGR2010/K9 sn FHH1338P007
!
!
!
!
!
!
interface GigabitEthernet0/0
ip address 172.25.212.39 255.255.255.128
duplex auto
speed auto
!
interface GigabitEthernet0/1
no ip address
duplex auto
speed auto
!
ip default-gateway 172.25.212.1
ip forward-protocol nd
!
no ip http server
!
```



```

!
ip route 0.0.0.0 0.0.0.0 172.19.164.1
ip route 0.0.0.0 0.0.0.0 172.25.212.1
!
!
!
!
control-plane
!
!
line con 0
exec-timeout 2 30
line aux 0
line vty 0 4
login
transport input all
!
exception data-corruption buffer truncate
scheduler allocate 20000 1000
end
Router#

```

## Configuring Basic Parameters

To configure the basic parameters on the router, perform one or more of the following tasks:

- [Configuring Global Parameters, page 35](#)
- [Interface Ports, page 36](#)
- [Configuring Gigabit Ethernet Interfaces, page 36](#)
- [Configuring Grid Router WAN Interface Cards, page 37](#)
- [Configuring a Loopback Interface, page 37](#)

## Configuring Global Parameters

To configure the following global parameters for your router, perform these steps:

	Command	Purpose
Step 1	<b>configure terminal</b>  <b>Example:</b> Router> enable Router# configure terminal Router(config)#	Enters global configuration mode, when using the console port.  Use the following to connect to the router with a remote terminal:  <pre>telnet <i>router name or address</i> Login: <i>login id</i> Password: <i>*****</i> Router&gt; enable</pre>
Step 2	<b>hostname <i>name</i></b>  <b>Example:</b> Router(config)# hostname Router Router(config)#	Specifies the name for the router.

	Command	Purpose
Step 3	<b>enable secret</b> <i>password</i>  <b>Example:</b> Router(config)# enable secret cr1ny5ho Router(config)#	Specifies an encrypted password to prevent unauthorized access to the router.
Step 4	<b>no ip domain-lookup</b>  <b>Example:</b> Router(config)# no ip domain-lookup Router(config)#	Disables the router from translating unfamiliar words (typos) into IP addresses.

## Interface Ports

Table 1 lists the interfaces that are supported on the Cisco CGR 2010.

**Table 1** Interfaces by Cisco CGR 2010 Router

Slots, Ports, Logical Interface, Interfaces	Cisco CGR 2010
Onboard GE ports	Gi0/0,Gi0/1
Interfaces on GRWIC	<i>interface0/0/port</i> <i>interface0/1/port</i>
Interfaces on GRWIC	<i>interface0/1/port</i>

## Configuring Gigabit Ethernet Interfaces

To manually define onboard Gigabit Ethernet interfaces, complete the following steps, in global configuration mode.

	Command	Purpose
Step 1	<b>interface gigabitethernet</b> <i>slot/port</i>  <b>Example:</b> Router(config)# interface gigabitethernet 0/1 Router(config-if)#	Enters the configuration mode for a Gigabit Ethernet interface on the router.
Step 2	<b>ip address</b> <i>ip-address mask</i>  <b>Example:</b> Router(config-if)# ip address 192.168.12.2 255.255.255.0 Router(config-if)#	Sets the IP address and subnet mask for the specified Gigabit Ethernet interface.

	Command	Purpose
Step 3	<b>media-type</b> {rj45   sfp}  <b>Example:</b> Router(config-if)# media-type sfp Router(config-if)#  <b>Example:</b> Router(config-if)# media-type rj45 Router(config-if)#	Designates SFP port as the primary media.  or  Designates RJ45 as the primary media.
Step 4	<b>no shutdown</b>  <b>Example:</b> Router(config-if)# no shutdown Router(config-if)#	Enables the Gigabit Ethernet interface, changing its state from administratively down to administratively up.
Step 5	<b>exit</b>  <b>Example:</b> Router(config-if)# exit Router(config)#	Exits configuration mode for the Gigabit Ethernet interface and returns to global configuration mode.

## Configuring Grid Router WAN Interface Cards

The Cisco Connected Grid Router 2010 supports RS-232 low-speed serial Grid Router WAN Interface Cards (GRWICs) and T1/E1 channelized and clear channel GRWICs.

### Configuring the 8-Port RS-232 Serial GRWICs

To configure the 8-port RS-232-8 asynchronous/synchronous serial GRWICs inserted in the GRWIC slots, see the [Configuring Serial Interfaces](#) section of *Cisco IOS Interface and Hardware Component Configuration Guide, Release 15.0*.

### Configuring T1/E1 GRWICs

To configure the one- and two-port channelized T1/E1 GRWICs inserted in the GRWIC slots, see [Configuring 1- and 2-Port T1/E1 GRWICs Guide](#).

## Configuring a Loopback Interface

The loopback interface acts as a placeholder for the static IP address and provides default routing information.

To configure a loopback interface perform these steps, beginning in global configuration mode:

	Command	Purpose
Step 1	<b>interface</b> <i>type number</i>  <b>Example:</b> Router(config)# interface Loopback 0 Router(config-if)#	Enters configuration mode for the loopback interface.
Step 2	<b>ip address</b> <i>ip-address mask</i>  <b>Example:</b> Router(config-if)# ip address 10.108.1.1 255.255.255.0 Router(config-if)#	Sets the IP address and subnet mask for the loopback interface.
Step 3	<b>exit</b>  <b>Example:</b> Router(config-if)# exit Router(config)#	Exits configuration mode for the loopback interface and returns to global configuration mode.

## Example

The loopback interface in this sample configuration is used to support Network Address Translation (NAT) on the virtual-template interface. This configuration example shows the loopback interface configured with an IP address of 200.200.100.1/32, which acts as a static IP address. The loopback interface points back to virtual-template1, which has a negotiated IP address.

```
!
interface Loopback0
 ip address 200.200.100.1 255.255.255.255
!
```

## Verifying Configuration

To verify that you have properly configured the loopback interface, enter the **show interface loopback** command. You should see verification output similar to the following example:

```
Router# show interfaces loopback 0
Loopback0 is up, line protocol is up
  Hardware is Loopback
  Internet address is 200.200.100.1/32
  MTU 1514 bytes, BW 8000000 Kbit/sec, DLY 5000 usec,
    reliability 255/255, txload 1/255, rxload 1/255
  Encapsulation LOOPBACK, loopback not set
  Keepalive set (10 sec)
  Last input never, output never, output hang never
  Last clearing of "show interface" counters never
  Input queue: 0/75/0/0 (size/max/drops/flushes); Total output drops: 0
  Queueing strategy: fifo
  Output queue: 0/0 (size/max)
  5 minute input rate 0 bits/sec, 0 packets/sec
  5 minute output rate 0 bits/sec, 0 packets/sec
    0 packets input, 0 bytes, 0 no buffer
    Received 0 broadcasts (0 IP multicasts)
    0 runts, 0 giants, 0 throttles
    0 input errors, 0 CRC, 0 frame, 0 overrun, 0 ignored, 0 abort
```

```

    0 packets output, 0 bytes, 0 underruns
    0 output errors, 0 collisions, 0 interface resets
    0 unknown protocol drops
    0 output buffer failures, 0 output buffers swapped out
Router#

```

Another way to verify the loopback interface is to ping it:

```
Router#ping 200.200.100.1
```

```

Type escape sequence to abort.
Sending 5, 100-byte ICMP Echos to 200.200.100.1, timeout is 2 seconds:
!!!!
Success rate is 100 percent (5/5), round-trip min/avg/max = 1/1/1 ms
Router#

```

## Configuring Command-Line Access

To configure parameters to control access to the router, perform these steps, beginning in global configuration mode:

	Command	Purpose
Step 1	<b>line</b> [ <b>aux</b>   <b>console</b>   <b>tty</b>   <b>vty</b> ] <i>line-number</i>	Enters line configuration mode, and specifies the type of line.
	<b>Example:</b> Router(config)# line console 0 Router(config-line)#	This example specifies a console terminal for access.
Step 2	<b>password</b> <i>password</i>	Specifies a unique password for the console terminal line.
	<b>Example:</b> Router(config)# password 5dr4Hepw3 Router(config-line)#	
Step 3	<b>login</b>	Enables password checking at terminal session login.
	<b>Example:</b> Router(config-line)# login Router(config-line)#	
Step 4	<b>exec-timeout</b> <i>minutes [seconds]</i>	Sets the interval wherein the EXEC command interpreter waits until user input is detected. The default is 10 minutes. Following entry of the minutes variable, you can optionally add seconds to the interval value.
	<b>Example:</b> Router(config-line)# exec-timeout 5 30 Router(config-line)#	This example shows a timeout of 5 minutes and 30 seconds. Entering a timeout of 0 0 specifies never to time out.
Step 5	<b>line</b> [ <b>aux</b>   <b>console</b>   <b>tty</b>   <b>vty</b> ] <i>line-number</i>	Specifies a virtual terminal for remote console access.
	<b>Example:</b> Router(config-line)# line vty 0 4 Router(config-line)#	

	Command	Purpose
Step 6	<p><b>password</b> <i>password</i></p> <p><b>Example:</b></p> <pre>Router(config-line)# password aldf2ad1 Router(config-line)#</pre>	Specifies a unique password for the virtual terminal line.
Step 7	<p><b>login</b></p> <p><b>Example:</b></p> <pre>Router(config-line)# login Router(config-line)#</pre>	Enables password checking at the virtual terminal session login.
Step 8	<p><b>end</b></p> <p><b>Example:</b></p> <pre>Router(config-line)# end Router#</pre>	Exits line configuration mode, and returns to privileged EXEC mode.

## Example

The following configuration shows the command-line access commands.

You do not need to input the commands marked “(default).” These commands appear automatically in the configuration file generated when you use the **show running-config** command.

```
!
line con 0
exec-timeout 10 0
password 4youreyesonly
login
transport input none (default)
stopbits 1 (default)
line vty 0 4
password secret
login
!
```

## Configuring Static Routes

Static routes provide fixed routing paths through the network. They are manually configured on the router. If the network topology changes, the static route must be updated with a new route. Static routes are private routes unless they are redistributed by a routing protocol.

To configure static routes, perform these steps, beginning in global configuration mode:

	Command	Purpose
Step 1	<pre>ip route prefix mask {ip-address   interface-type interface-number [ip-address]}</pre> <p><b>Example:</b></p> <pre>Router(config)# ip route 192.168.1.0 255.255.0.0 10.10.10.2</pre>	<p>Specifies the static route for the IP packets.</p> <p>For details about this command and about additional parameters that can be set, see <a href="#">Cisco IOS IP Command Reference, Volume 2 of 4: Routing Protocols, Release 12.3</a></p>
Step 2	<pre>end</pre> <p><b>Example:</b></p> <pre>Router(config)# end Router#</pre>	<p>Exits router configuration mode, and enters privileged EXEC mode.</p>

## Example

In the following configuration example, the static route sends out all IP packets with a destination IP address of 192.168.1.0 and a subnet mask of 255.255.255.0 on the Gigabit Ethernet interface to another device with an IP address of 10.10.10.2. Specifically, the packets are sent to the configured permanent virtual circuit.

You do not need to enter the command marked “(default).” This command appears automatically in the configuration file generated when you use the **show running-config** command.

```
!
ip classless (default)
ip route 172.168.1.0 255.255.255.0 10.10.10.2!
```

## Verifying Configuration

To verify that you have properly configured static routing, enter the **show ip route** command and look for static routes signified by the “S.”

You should see verification output similar to the following:

```
Router# show ip route
Codes: L - local, C - connected, S - static, R - RIP, M - mobile, B - BGP
       D - EIGRP, EX - EIGRP external, O - OSPF, IA - OSPF inter area
       N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2
       E1 - OSPF external type 1, E2 - OSPF external type 2
       i - IS-IS, su - IS-IS summary, L1 - IS-IS level-1, L2 - IS-IS level-2
       ia - IS-IS inter area, * - candidate default, U - per-user static route
       o - ODR, P - periodic downloaded static route, + - replicated route

Gateway of last resort is 172.25.212.1 to network 0.0.0.0

S*   0.0.0.0/0 [1/0] via 172.25.212.1
     172.25.0.0/16 is variably subnetted, 2 subnets, 2 masks
C     172.25.212.0/25 is directly connected, GigabitEthernet0/0
L     172.25.212.39/32 is directly connected, GigabitEthernet0/0
     200.200.100.0/32 is subnetted, 1 subnets
C     200.200.100.1 is directly connected, Loopback0
Router#
```

## Configuring Dynamic Routes

In dynamic routing, the network protocol adjusts the path automatically, based on network traffic or topology. Changes in dynamic routes are shared with other routers in the network.

The Cisco routers can use IP routing protocols, such as Routing Information Protocol (RIP) or Enhanced IGRP (EIGRP), to learn routes dynamically. You can configure either of these routing protocols on your router.

- [Configuring Routing Information Protocol](#)
- [Configuring Enhanced Interior Gateway Routing Protocol](#)

## Configuring Routing Information Protocol

To configure the RIP routing protocol on the router perform these steps, beginning in global configuration mode:

	Command	Task
Step 1	<b>router rip</b>  <b>Example:</b> Router> configure terminal Router(config)# router rip Router(config-router)#	Enters router configuration mode, and enables RIP on the router.
Step 2	<b>version {1   2}</b>  <b>Example:</b> Router(config-router)# version 2 Router(config-router)#	Specifies use of RIP version 1 or 2.
Step 3	<b>network ip-address</b>  <b>Example:</b> Router(config-router)# network 192.168.1.1 Router(config-router)# network 10.10.7.1 Router(config-router)#	Specifies a list of networks on which RIP is to be applied, using the address of the network of each directly connected network.
Step 4	<b>no auto-summary</b>  <b>Example:</b> Router(config-router)# no auto-summary Router(config-router)#	Disables automatic summarization of subnet routes into network-level routes. This allows subprefix routing information to pass across classful network boundaries.
Step 5	<b>end</b>  <b>Example:</b> Router(config-router)# end Router#	Exits router configuration mode, and enters privileged EXEC mode.

### Example

The following configuration example shows RIP version 2 enabled in IP network 10.0.0.0 and 192.168.1.0.



To see this configuration, use the **show running-config** command from privileged EXEC mode.

```
!
Router# show running-config
router rip
  version 2
  network 10.0.0.0
  network 192.168.1.0
  no auto-summary
!
```

## Verifying Configuration

To verify that you have properly configured RIP, enter the **show ip route** command and look for RIP routes signified by “R.” You should see a verification output like the example shown below.

```
Router# show ip route
Codes: C - connected, S - static, R - RIP, M - mobile, B - BGP
       D - EIGRP, EX - EIGRP external, O - OSPF, IA - OSPF inter area
       N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2
       E1 - OSPF external type 1, E2 - OSPF external type 2
       i - IS-IS, su - IS-IS summary, L1 - IS-IS level-1, L2 - IS-IS level-2
       ia - IS-IS inter area, * - candidate default, U - per-user static route
       o - ODR, P - periodic downloaded static route

Gateway of last resort is not set

    10.0.0.0/24 is subnetted, 1 subnets
C       10.108.1.0 is directly connected, Loopback0
R       3.0.0.0/8 [120/1] via 2.2.2.1, 00:00:02, Ethernet0/0
```

## Configuring Enhanced Interior Gateway Routing Protocol

To configure EIGRP perform these steps, beginning in global configuration mode:

	Command	Purpose
Step 1	<b>router eigrp</b> <i>as-number</i>  <b>Example:</b> Router(config)# router eigrp 109 Router(config)#	Enters router configuration mode, and enables EIGRP on the router. The autonomous-system number identifies the route to other EIGRP routers and is used to tag the EIGRP information.
Step 2	<b>network</b> <i>ip-address</i>  <b>Example:</b> Router(config)# network 192.145.1.0 Router(config)# network 10.10.12.115 Router(config)#	Specifies a list of networks on which EIGRP is to be applied, using the IP address of the network of directly connected networks.
Step 3	<b>end</b>  <b>Example:</b> Router(config-router)# end Router#	Exits router configuration mode, and enters privileged EXEC mode.

## Example

The following configuration example shows the EIGRP routing protocol enabled in IP networks 192.145.1.0 and 10.10.12.115. The EIGRP autonomous system number is 109.

To see this configuration use the **show running-config** command, beginning in privileged EXEC mode.

```
!
router eigrp 109
  network 192.145.1.0
  network 10.10.12.115
!
```

## Verifying Configuration

To verify that you have properly configured IP EIGRP, enter the **show ip route** command, and look for EIGRP routes indicated by “D.” You should see verification output similar to the following:

```
Router# show ip route
Codes: C - connected, S - static, R - RIP, M - mobile, B - BGP
       D - EIGRP, EX - EIGRP external, O - OSPF, IA - OSPF inter area
       N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2
       E1 - OSPF external type 1, E2 - OSPF external type 2
       i - IS-IS, su - IS-IS summary, L1 - IS-IS level-1, L2 - IS-IS level-2
       ia - IS-IS inter area, * - candidate default, U - per-user static route
       o - ODR, P - periodic downloaded static route

Gateway of last resort is not set

    10.0.0.0/24 is subnetted, 1 subnets
C       10.108.1.0 is directly connected, Loopback0
D       3.0.0.0/8 [90/409600] via 2.2.2.1, 00:00:02, Ethernet0/0
```

## Typical Example of a Cisco CGR 2010 Configuration

Use the **show running-config** command to view the configuration of the Cisco CGR 2010 after the Gigabit Ethernet and serial GRWIC ports have been configured. The following is an example of a typical Cisco CGR 2010 router that is only minimally configured:

```
Router# show running-config
Building configuration...

Current configuration : 1795 bytes
!
! Last configuration change at 03:11:17 UTC Sat Jul 7 1900
!
version 15.1
service timestamps debug datetime msec
service timestamps log datetime msec
no service password-encryption
!
hostname Router
!
boot-start-marker
boot-end-marker
!
!
no aaa new-model
!
```

```
no ipv6 cef
ip source-route
ip cef
!
!
!
!
multilink bundle-name authenticated
!
!
crypto pki token default removal timeout 0
!
!
license feature snasw
license udi pid CGR-2010/K9 sn FHH1338P00S
license boot module cgr2010 technology-package datak9
!
!
!
redundancy
!
!
!
!
bstun peer-name 192.168.1.2
bstun protocol-group 1 async-generic
!
!
!
interface GigabitEthernet0/0
 ip address 192.168.1.2 255.255.255.0
 shutdown
 duplex auto
 speed auto
!
interface GigabitEthernet0/1
 no ip address
 duplex auto
 speed auto
!
interface Serial0/0/1
 no ip address
 shutdown
!
interface Serial0/0/2
 no ip address
 shutdown
!
interface Serial0/0/3
 no ip address
 shutdown
!
interface Serial0/0/4
 no ip address
 shutdown
 clock rate 128000
!
interface Serial0/0/5
 no ip address
 shutdown
 clock rate 128000
!
interface Serial0/0/6
 no ip address
```

```
shutdown
clock rate 128000
!
interface Serial0/0/7
no ip address
shutdown
clock rate 128000
!
interface Serial0/0/0
physical-layer async
no ip address
encapsulation bstun
bstun group 1
bstun route all tcp 192.168.1.1
asp role secondary
asp addr-offset 0
!
!
ip forward-protocol nd
!
no ip http server
no ip http secure-server
!
ip route 0.0.0.0 0.0.0.0 GigabitEthernet0/0
!
!
!
!
!
snmp-server community public RW
!
control-plane
!
!
line con 0
line aux 0
line 0/0/0
no activation-character
stopbits 1
line vty 0 4
login
transport input all
!
exception data-corruption buffer truncate
scheduler allocate 20000 1000
end
```



# Configuring Backup Data Lines and Remote Management

---

**First Published:** May 27, 2010, OL-20356-01  
**Last Updated:** October 25, 2017

The Cisco Connected Grid Router 2010 supports remote management and backup data connectivity. The following sections describe how to configure backup data lines and remote management:

- [Configuring Backup Interfaces, page 47](#)
- [Configuring Dial Backup and Remote Management Through the Console Port or Auxiliary Port, page 49](#)

## Configuring Backup Interfaces

This section describes how to configure backup interfaces for failover redundancy when the network goes down.

## Configuring Gigabit Ethernet Failover Media

Cisco CGR 2010 routers have an SFP-GE port that supports either copper or fiber connections. Media can be configured for failover redundancy when the network goes down. To assign primary and secondary failover media on the SFP-GE port, perform these steps, beginning in EXEC mode.



---

**Americas Headquarters:**  
**Cisco Systems, Inc., 170 West Tasman Drive, San Jose, CA 95134-1706 USA**

© 2010 Cisco Systems, Inc. All rights reserved.

	<b>Command</b>	<b>Purpose</b>
<b>Step 1</b>	<p><b>configure terminal</b></p> <p><b>Example:</b></p> <pre>Router&gt; enable Router# configure terminal Router(config)#</pre>	<p>Enters global configuration mode, when using the console port.</p> <p>Use the following to connect to the router with a remote terminal:</p> <pre>telnet <i>router name or address</i> Login: <i>login id</i> Password: <i>*****</i> Router&gt; enable</pre>
<b>Step 2</b>	<p><b>hostname <i>name</i></b></p> <p><b>Example:</b></p> <pre>Router(config)# hostname Router Router(config)#</pre>	Specifies the name for the router.
<b>Step 3</b>	<p><b>enable secret <i>password</i></b></p> <p><b>Example:</b></p> <pre>Router(config)# enable secret crlnty5ho Router(config)#</pre>	Specifies an encrypted password to prevent unauthorized access to the router.
<b>Step 4</b>	<p><b>interface gigabitethernet <i>slot/port</i></b></p> <p><b>Example:</b></p> <pre>Router(config)# interface gigabitethernet 0/1 Router(config-if)#</pre>	Enters interface configuration mode.
<b>Step 5</b>	<p><b>media-type sfp</b></p> <p><b>Example:</b></p> <pre>Router(config-if)# media-type sfp Router(config-if)#</pre> <p><b>Example:</b></p> <pre>Router(config-if)# media-type rj45 Router(config-if)#</pre>	<p>Designates SFP port as the primary media.</p> <p>or</p> <p>Designates RJ45 as the primary media.</p>
<b>Step 6</b>	<p><b>media-type sfp auto-fail-over</b></p> <p><b>Example:</b></p> <pre>Router(config-if)# media-type RJ45 <b>auto-fail-over</b> Router(config-if)#</pre> <p><b>Example:</b></p> <pre>Router(config-if)# media-type sfp auto-fail-over Router(config-if)#</pre>	<p>System will automatically failover from RJ45 to SFP when it goes down, reloads, and is unable to bring up primary media. Port is configured with RJ45 as the primary media by default.</p> <p>or</p> <p>Configure the port with SFP as the primary media for automatic failover from SFP to RJ45 when the system goes down, reloads, and is unable to bring up primary media.</p>
<b>Step 7</b>	<p><b>end</b></p>	Exits to global configuration mode.

# Configuring Dial Backup and Remote Management Through the Console Port or Auxiliary Port

In dial backup, the switched circuit is used to provide backup service for another type of circuit, such as point-to-point or packet switching. The router is configured so that when a failure is detected on the primary circuit, the dial backup line is initiated. The dial backup line then supports the WAN connection until the primary circuit is restored. When this occurs, the dial backup connection is terminated.

A modem enables data to be transmitted over voice-grade telephone lines. At the source, digital signals are converted to a form suitable for transmission over analog communication facilities. At the destination, these analog signals are returned to their digital form. It is a simple modem-to-modem connection through a WAN.

When customer premises equipment, such as the Cisco Connected Grid Router 2010, are connected to an ISP, an IP address is dynamically assigned to the router, or the IP address is assigned by the router peer through the centrally managed function. The dial backup feature can be added to provide a failover route in case the primary line fails. The Cisco CGR 2010 can use the auxiliary port for dial backup and remote management.

The main WAN link of the Cisco CGR 2010 is the primary connection to the Internet service provider. A modem can serve as the dial backup that serves as a failover link for the Cisco CGR 2010 when the primary connection goes down. For remote management, the PC serves as dial-in access to allow changes or updates to Cisco IOS configurations.

To configure dial backup and remote management for the Cisco Connected Grid Router 2010, complete the following steps, beginning in global configuration mode:

## SUMMARY STEPS

1. **ip name-server** *server-address*
2. **ip dhcp pool** *name*
3. **exit**
4. **chat-script** *script-name expect-send*
5. **interface** *type number*
6. **exit**
7. **interface** *type number*
8. **dialer watch-group** *group-number*
9. **exit**
10. **ip nat inside source** {**list** *access-list-number*} {**interface** *type number* | **pool** *name*} [**overload**]
11. **ip route** *prefix mask* {*ip-address* | *interface-type interface-number* [*ip-address*]}
12. **access-list** *access-list-number* {**deny** | **permit**} *source* [*source-wildcard*]
13. **dialerwatch-list** *group-number* {**ip** *ip-address address-mask* | **delay route-check initial** *seconds*}
14. **line** [**aux** | **console** | **tty** | **vty**] *line-number* [*ending-line-number*]
15. **modem enable**
16. **exit**
17. **line** [**aux** | **console** | **tty** | **vty**] *line-number* [*ending-line-number*]
18. **flowcontrol** {**none** | **software** [**lock**] [**in** | **out**] | **hardware** [**in** | **out**]}

## DETAILED STEPS

	Command	Purpose
Step 1	<p><b>ip name-server</b> <i>server-address</i></p> <p><b>Example:</b> Router(config)# ip name-server 192.168.28.12</p>	<p>Enters your ISP DNS IP address.</p> <p><b>Tip</b> You may add multiple server addresses if available.</p>
Step 2	<p><b>ip dhcp pool</b> <i>name</i></p> <p><b>Example:</b> Router(config)# ip dhcp pool 1</p>	<p>Creates a DHCP address pool on the router and enters DHCP pool configuration mode. The <i>name</i> argument can be a string or an integer.</p> <p>Configure the DHCP address pool. For sample commands that you can use in DHCP pool configuration mode, see the “<a href="#">Example</a>” section on <a href="#">page 52</a>.</p>
Step 3	<p><b>exit</b></p> <p><b>Example:</b> Router(config-dhcp)# exit</p>	<p>Exits DHCP pool configuration mode and enters global configuration mode.</p>
Step 4	<p><b>chat-script</b> <i>script-name expect-send</i></p> <p><b>Example:</b> Router(config)# chat-script Dialout ABORT ERROR ABORT BUSY "" "AT" OK "ATDT 5555102 T" TIMEOUT 45 CONNECT \c</p>	<p>Configures a chat script for use in Dial-on-Demand Routing to give commands for dialing a modem and for logging in to remote systems. The defined script is used to place a call over a modem connected to the public switched telephone network.</p>
Step 5	<p><b>interface</b> <i>type number</i></p> <p><b>Example:</b> Router(config)# interface Async 1</p>	<p>Creates asynchronous interface and enters configuration mode for the asynchronous interface.</p> <p>Configures the asynchronous interface. For sample commands that you can use in asynchronous interface configuration mode, see the “<a href="#">Example</a>” section on <a href="#">page 52</a>.</p>
Step 6	<p><b>exit</b></p> <p><b>Example:</b> Router(config-if)# exit</p>	<p>Exits interface configuration mode and enters global configuration mode.</p>
Step 7	<p><b>interface</b> <i>type number</i></p> <p><b>Example:</b> Router(config)# interface Dialer 3</p>	<p>Creates dialer interface and enters configuration mode for the dialer interface.</p>
Step 8	<p><b>dialer watch-group</b> <i>group-number</i></p> <p><b>Example:</b> Router(config-if)# dialer watch-group 1</p>	<p>Specifies the group number for the dialer watch list.</p>



	Command	Purpose
Step 9	<b>exit</b>  <b>Example:</b> Router(config-if)# exit	Exits interface configuration mode and enters global configuration mode.
Step 10	<b>ip nat inside source {list access-list-number} {interface type number   pool name} [overload]</b>  <b>Example:</b> Router(config)# ip nat inside source list 101 interface Dialer 3 overload	Enables dynamic translation of addresses on the inside interface.
Step 11	<b>ip route prefix mask {ip-address   interface-type interface-number [ip-address]}</b>  <b>Example:</b> Router(config)# ip route 0.0.0.0 0.0.0.0 22.0.0.2#	Sets the IP route to point to the dialer interface as a default gateway.
Step 12	<b>access-list access-list-number {deny   permit} source [source-wildcard]</b>  <b>Example:</b> Router(config)# access-list 1 permit 192.168.0.0 0.0.255.255 any	Defines an extended access list that indicates which addresses need translation.
Step 13	<b>dialerwatch-list group-number {ip ip-address address-mask   delay route-check initial seconds}</b>  <b>Example:</b> Router(config)# dialer watch-list 1 ip 22.0.0.2 255.255.255.255	Evaluates the status of the primary link, based on the existence of routes to the peer. The address 22.0.0.2 is the peer IP address of the ISP.
Step 14	<b>line [aux   console   tty   vty] line-number [ending-line-number]</b>  <b>Example:</b> Router(config)# line console 0#	Enters configuration mode for the line interface.
Step 15	<b>modem enable</b>  <b>Example:</b> Router(config-line)# modem enable	Switches the port from console port to auxiliary port function.
Step 16	<b>exit</b>  <b>Example:</b> Router(config-line)# exit	Exits line configuration mode and returns to global configuration mode.

	Command	Purpose
Step 17	<b>line</b> <i>[aux   console   tty   vty] line-number</i> <i>[ending-line-number]</i>	Enters configuration mode for the auxiliary interface.
	<b>Example:</b> Router(config)# line aux 0	
Step 18	<b>flowcontrol</b> { <b>none</b>   <b>software</b> [ <b>lock</b> ] [ <b>in</b>   <b>out</b> ]   <b>hardware</b> [ <b>in</b>   <b>out</b> ] }	Enables hardware signal flow control.
	<b>Example:</b> Router(config-line)# flowcontrol hardware	

### Example

The following configuration example specifies an IP address for the T1 interface through PPP and IP Control Protocol (IPCP) address negotiation and specifies dial backup over the console port.

```

!
ip name-server 192.168.28.12
ip dhcp excluded-address 192.168.1.1
!
ip dhcp pool 1
  import all
  network 192.168.1.0 255.255.255.0
  default-router 192.168.1.1
!
! Need to use your own correct ISP phone number.
modemcap entry MY-USER_MODEM:MSC=&F1S0=1
chat-script Dialout ABORT ERROR ABORT BUSY "" "AT" OK "ATDT 5555102\T"
TIMEOUT 45 CONNECT \c
!
!
!
!
interface vlan 1
  ip address 192.168.1.1 255.255.255.0
  ip nat inside
  ip tcp adjust-mss 1452
  hold-queue 100 out
!
! Dial backup and remote management physical interface.
interface Async1
  no ip address
  encapsulation ppp
  dialer in-band
  dialer pool-member 3
  async default routing
  async dynamic routing
  async mode dedicated
  ppp authentication pap callin
!
interface Serial0/0/0
  no ip address
  shutdown
  clock rate 128000
!
!
dsl operating-mode auto
!

```

```
! Primary WAN link.
interface Dialer1
  ip address negotiated
  ip nat outside
  encapsulation ppp
  dialer pool 1
  ppp authentication pap callin
  ppp pap sent-username account password 7 pass
  ppp ipcp dns request
  ppp ipcp wins request
  ppp ipcp mask request
!
! Dialer backup logical interface.
interface Dialer3
  ip address negotiated
  ip nat outside
  encapsulation ppp
  no ip route-cache
  no ip mroute-cache
  dialer pool 3
  dialer idle-timeout 60
  dialer string 5555102 modem-script Dialout
  dialer watch-group 1
!
! Remote management PC IP address.
peer default ip address 192.168.2.2
no cdp enable
!
! Need to use your own ISP account and password.
ppp pap sent-username account password 7 pass
ppp ipcp dns request
ppp ipcp wins request
ppp ipcp mask request
!
! IP NAT over Dialer interface using route-map.
ip nat inside source route-map main interface Dialer1 overload
ip nat inside source route-map secondary interface Dialer3 overload
ip classless
!
! When primary link is up again, distance 50 will override 80 if dial backup
! has not timed out. Use multiple routes because peer IP addresses are alternated
! among them when the CPE is connected.
ip route 0.0.0.0 0.0.0.0 64.161.31.254 50
ip route 0.0.0.0 0.0.0.0 66.125.91.254 50
ip route 0.0.0.0 0.0.0.0 64.174.91.254 50
ip route 0.0.0.0 0.0.0.0 63.203.35.136 80
ip route 0.0.0.0 0.0.0.0 63.203.35.137 80
ip route 0.0.0.0 0.0.0.0 63.203.35.138 80
ip route 0.0.0.0 0.0.0.0 63.203.35.139 80
ip route 0.0.0.0 0.0.0.0 63.203.35.140 80
ip route 0.0.0.0 0.0.0.0 63.203.35.141 80
ip route 0.0.0.0 0.0.0.0 Dialer1 150
no ip http server
ip pim bidir-enable
!
! PC IP address behind CPE.
access-list 101 permit ip 192.168.0.0 0.0.255.255 any
access-list 103 permit ip 192.168.0.0 0.0.255.255 any
!
! Watch multiple IP addresses because peers are alternated
! among them when the CPE is connected.
dialer watch-list 1 ip 64.161.31.254 255.255.255.255
dialer watch-list 1 ip 64.174.91.254 255.255.255.255
dialer watch-list 1 ip 64.125.91.254 255.255.255.255
```

```
!  
! Dial backup will kick in if primary link is not available  
! 5 minutes after CPE starts up.  
dialer watch-list 1 delay route-check initial 300  
dialer-list 1 protocol ip permit  
!  
! Direct traffic to an interface only if the dialer is assigned an IP address.  
route-map main permit 10  
  match ip address 101  
  match interface Dialer1  
!  
route-map secondary permit 10  
  match ip address 103  
  match interface Dialer3  
!  
! Change console to aux function.  
line con 0  
  exec-timeout 0 0  
  modem enable  
  stopbits 1  
line aux 0  
  exec-timeout 0 0  
  ! To enable and communicate with the external modem properly.  
  script dialer Dialout  
  modem InOut  
  modem autoconfigure discovery  
  transport input all  
  stopbits 1  
  speed 115200  
  flowcontrol hardware  
line vty 0 4  
  exec-timeout 0 0  
  password cisco  
  login  
!  
scheduler max-task-time 5000  
end
```



# Upgrading the Cisco IOS Software

---

**First Published: May 27, 2010, OL-20356-01**  
**Last Updated: October 25, 2017**

This document describes how to upgrade the Cisco Internetworking Operating System (IOS) software image on the Cisco Connected Grid Router 2010.

## Contents

- [Restrictions for Upgrading the System Image, page 55](#)
- [Information About Upgrading the System Image, page 56](#)
- [How to Upgrade the Cisco IOS Image, page 57](#)

## Restrictions for Upgrading the System Image

Cisco CGR 2010 routers download images to new Advanced Capability CompactFlash (CF) memory cards. There are two slots available for this CF:

- PCMCIA
- USB



### Note

---

Legacy CF will not operate in Cisco CGR 2010 routers. When legacy CF is inserted, the following error message appears:

**WARNING:** *Unsupported compact flash detected. Use of this card during normal operation can impact and severely degrade performance of the system. Please use supported compact flash cards only.*

---

- Cisco IOS images for the access point download images to CF embedded on the access point.



---

**Americas Headquarters:**  
**Cisco Systems, Inc., 170 West Tasman Drive, San Jose, CA 95134-1706 USA**

© 2010 Cisco Systems, Inc. All rights reserved.

**Table 1 Compact Flash Slot Numbering and Naming**

Slot Number	PCMCIA CF Filenames	USB CF Filenames
Slot0 <sup>1</sup>	<b>flash0</b> <sup>2</sup>	<b>usbflash0</b>
Slot1	<b>flash1</b>	<b>usbflash1</b>

1. Slot 0 is the default CF slot. It stores the system image, configurations, and data files. CF must be present in this slot for the router to boot and perform normal file operations.
2. Filenames **flash** and **flash0** refer to the same device.

## Information About Upgrading the System Image

To upgrade the system image on your router, review the following sections:

- [Why Would I Upgrade the System Image?](#), page 56
- [Which Cisco IOS Release Is Running on My Router Now?](#), page 56
- [How Do I Choose the New Cisco IOS Release and Feature Set?](#), page 56
- [Where Do I Download the System Image?](#), page 57

## Why Would I Upgrade the System Image?

System images contain the Cisco IOS software. Your router already has an image on it when it is shipped to you.

At some point, you may want to load a different image onto the router. For example, you may want to upgrade the IOS software to the latest release, or to use the same Cisco IOS release for all the routers in a network. Each system image contains different sets of Cisco IOS features, therefore you must select an appropriate system image to suit your network requirements.

## Which Cisco IOS Release Is Running on My Router Now?

To determine the Cisco IOS release that is currently running on your router, and the filename of the system image, enter the **show version** command in user EXEC or privileged EXEC mode.

## How Do I Choose the New Cisco IOS Release and Feature Set?

Cisco Connected Grid Router 2010 routers support Cisco IOS software entitlement and enforcement. See the [Software Activation on Cisco Integrated Services Routers](#) for feature and package license information.

To determine which Cisco IOS releases and feature sets support your router platform and its required features, go to [Cisco Feature Navigator](#). You must have an account on Cisco.com to access the Cisco Feature Navigator. If you do not have an account or have forgotten your username or password, click **Cancel** at the login dialog box and follow the instructions that appear.

## Where Do I Download the System Image?

To download a system image, you must have an account on Cisco.com to gain access to the following websites. If you do not have an account or have forgotten your username or password, click **Cancel** at the login dialog box, and follow the instructions that appear.

If you know which Cisco IOS release and feature set you want to download, go to the [Download Software](#) website.

If you want more information about downloading software, see [Loading and Managing System Images](#).

## How to Upgrade the Cisco IOS Image

This section provides information about upgrading the Cisco IOS image on the router and Cisco IOS image on the access point.

### Router Upgrade

- [Saving Backup Copies of Your Old System Image and Configuration, page 57](#)
- [DRAM Size and the New System Image, page 59](#)
- [Ensuring Adequate Flash Memory for the New System Image, page 59](#)
- [Copying the System Image into Flash Memory, page 62](#)
- [Loading the New System Image, page 67](#)
- [Saving Backup Copies of Your New System Image and Configuration, page 71](#)

## Saving Backup Copies of Your Old System Image and Configuration

To avoid unexpected downtime if you encounter serious problems using your new system image or startup configuration, we recommend that you save backup copies of your current startup configuration file and Cisco IOS software system image file on a server.

For more detailed information, see the “[Managing Configuration Files](#)” chapter and the “[Loading and Maintaining System Images](#)” chapter of *Cisco IOS Configuration Fundamentals Configuration Guide, Release 15.0*.

To save backup copies of the startup configuration file and the system image file, complete the following steps:

### SUMMARY STEPS

1. `enable`
2. `copy nvram:startup-config {ftp: | rcp: | tftp:}`
3. `dir flash:`
4. `copy flash: {ftp: | rcp: | tftp:}`

## DETAILED STEPS

	Command or Action	Purpose
Step 1	<b>enable</b>  <b>Example:</b> Router> enable	Enables privileged EXEC mode. <ul style="list-style-type: none"> <li>Enter your password if prompted.</li> </ul>
Step 2	<b>copy nvram:startup-config {ftp:   rcp:   tftp:}</b>  <b>Example:</b> Router# copy nvram:startup-config ftp:	Copies the startup configuration file to a server. <ul style="list-style-type: none"> <li>The configuration file copy can serve as a backup copy.</li> <li>Enter the destination URL when prompted.</li> </ul>
Step 3	<b>dir flash:</b>  <b>Example:</b> Router# dir flash:	Displays the layout and contents of a flash memory file system. <ul style="list-style-type: none"> <li>Learn the name of the system image file.</li> </ul>
Step 4	<b>copy flash: {ftp:   rcp:   tftp:}</b>  <b>Example:</b> Router# copy flash: ftp:	Copies a file from flash memory to a server. <ul style="list-style-type: none"> <li>Copy the system image file to a server. This file can serve as a backup copy.</li> <li>Enter the flash memory partition number if prompted.</li> <li>Enter the filename and destination URL when prompted.</li> </ul>

## Examples

The following examples show how to copy a startup configuration to a TFTP server and how to copy from files flash memory to an FTP server.

**Copying the Startup Configuration to a TFTP Server: Example**

The following example shows copying the startup configuration to a TFTP server:

```
Router# copy nvram:startup-config tftp:
Remote host[]? 192.0.0.1
Name of configuration file to write [rtr2-config]? rtr2-config-b4upgrade
Write file rtr2-config-b4upgrade on host 192.0.0.1?[confirm] <cr>
![OK]
```

**Copying from Flash Memory to a TFTP Server: Example**

The following example uses the **dir flash:** command in privileged EXEC mode to learn the name of the system image file and the **copy flash: tftp:** command to copy the system image to a TFTP server.

```
Router# dir flash:
Directory of flash:/

 1  -rw-          166502  Feb 18 2028 22:47:24 +00:00  crashinfo_19000218-224723C

1024655360 bytes total (1024475136 bytes free)
Router#

Router# copy flash: tftp:
```



```
IP address of remote host [255.255.255.255]? 192.0.0.1
filename to write on tftp host? cgr2010
writing cgr2010 !!!!...
successful ftp write.
```

## DRAM Size and the New System Image

This section describes how to check whether your router has enough DRAM for upgrading to the new system image.



### Note

The DRAM in the Cisco CGR 2010 is fixed and cannot be removed and replaced by DRAM with more memory.

## Ensuring Adequate Flash Memory for the New System Image

This section describes how to check whether your router has enough flash memory to upgrade to the new system image and, if necessary, how to properly delete files in flash memory to make room for the new system image.

Cisco CGR 2010 routers have two sets of external CF slots: 2 PCMCIA and 2 USB. Use the secondary CF for overflow files, if required. [Table 2](#) lists CF slot numbering and naming.

**Table 2** CF Slot Numbering and Naming

Slot Number	PCMCIA CF Filenames	USB CF Filenames	Size
Slot0 <sup>1</sup>	flash0 <sup>2</sup>	usbflash0	256MB
Slot1	flash1	usbflash1	0
Total	-	-	4GB

1. Slot 0 is the default CF slot. CF in slot0 stores system image, configuration, and data files. CF must be present in this slot for the router to boot and perform normal file operations.
2. Filenames **flash** and **flash0** refer to the same device.

## Prerequisites

- Choose the Cisco IOS release and system image to which you want to upgrade. See the [“Information About Upgrading the System Image”](#) section on page 56.
- Select the system image in the [Download Software](#) website.

You must have an account on Cisco.com to access this website. If you do not have an account or have forgotten your username or password, click **Cancel** at the login dialog box and follow the instructions that appear.

From the File Download Information table, write down the minimum flash requirements for the image.

## SUMMARY STEPS

1. **enable**
2. **dir flash:**

3. From the displayed output of the **dir flash:** command, compare the number of bytes *available* to the minimum flash requirements for the new system image.
  - a. If the available memory is equal to or greater than the new system image's minimum flash requirements, proceed to the [“Copying the System Image into Flash Memory” section on page 62](#).
  - b. If the available memory is less than the new system image's minimum flash requirements, proceed to [Step 4](#).
4. From the displayed output of the **dir flash:** command, compare the number of bytes *total* to the size of the system image to which you want to upgrade.
  - a. If the total memory is less than the new system image's minimum flash requirements, you **cannot** upgrade your compact flash memory card because the DRAM is fixed. You must delete files in flash memory to make room for the new system image.




---

**Note** The DRAM in the Cisco CGR 2010 router is fixed and cannot be removed and replaced by DRAM with more memory.

---

- b. If the total memory is equal to or greater than the new system image's minimum flash requirements, proceed to [Step 5](#).
5. Enter the **dir /all flash:** command.
6. From the displayed output of the **dir /all flash:** command, write down the names and directory locations of the files that you can delete.
7. (Optional) Enter the **copy flash: {tftp | rcp}** command.
8. (Optional) Repeat [Step 7](#) for each file that you identified in [Step 6](#).
9. Enter the **delete flash:directory-path/filename** command.
10. Repeat [Step 9](#) for each file that you identified in [Step 6](#).
11. Enter the **dir flash:[partition-number:]** command.
12. From the displayed output of the **dir flash:** command, compare the number of bytes *available* to the size of the system image to which you want to upgrade.
  - a. If the available memory is less than the new system image's minimum flash requirements, then you cannot download the new image.
  - b. If the available memory is equal to or greater than the new system image's minimum flash requirements, proceed to the [“Copying the System Image into Flash Memory” section on page 62](#).

## DETAILED STEPS

- 
- Step 1** Use the **enable** command to enter privileged EXEC mode. Enter your password if prompted. For example:

```
Router> enable
Password:
Router#
```

- Step 2** Use the **dir flash:** command to display the layout and contents of flash memory:

```
Router# dir flash:
Directory of flash:/
```

```

1  -rw-      166502  Feb 18 2028 22:47:24 +00:00  crashinfo_19000218-224723C
1024655360 bytes total (1024475136 bytes free)

```

- Step 3** From the displayed output of the **dir flash:** command, compare the number of bytes *available* to the minimum flash requirements for the new system image.
- If the available memory is equal to or greater than the new system image’s minimum flash requirements, proceed to the “[Copying the System Image into Flash Memory](#)” section on page 62.
  - If the available memory is less than the new system image’s minimum flash requirements, proceed to [Step 4](#).

- Step 4** From the displayed output of the **dir flash:** command, compare the number of bytes *total* to the size of the system image to which you want to upgrade.
- If the total memory is less than the new system image’s minimum flash requirements, you **cannot** upgrade your compact flash memory card because the DRAM is fixed. You must delete files in flash memory to make room for the new system image.
  - If the total memory is equal to or greater than the new system image’s minimum flash requirements, proceed to [Step 5](#).

- Step 5** Enter the **dir /all flash:** command to display a list of all files and directories in flash memory:

```

Router# dir /all flash:

Directory of flash:/

1  -rw-      166502  Feb 18 2028 22:47:24 +00:00  crashinfo_19000218-224723C
1024655360 bytes total (1024475136 bytes free)
Router#

```

- Step 6** From the displayed output of the **dir /all flash:** command, write down the names and directory locations of the files that you can delete. If you cannot delete any files, you cannot download the new image.




---

**Note** The DRAM in the Cisco CGR 2010 router is fixed and cannot be removed and replaced by DRAM with more memory.

---




---

**Note** Do not delete the system image that the router already uses. If you are not sure which files can be safely deleted, either consult your network administrator. You **cannot** upgrade your compact flash memory card to a size that can accommodate both the existing files and the new system image.

---

- Step 7** (Optional) Enter the **copy flash:{tftp | rcp}** to copy a file to a server before deleting the file from flash memory. When prompted, enter the filename and the server’s hostname or IP address:

```
Router# copy flash tftp
```

- Step 8** (Optional) Repeat [Step 7](#) for each file that you identified in [Step 6](#).

- Step 9** Enter the **delete flash:directory-path/filename** command to delete a file in flash memory:

```

Router# delete flash:c29xx.tmp

Delete filename [cgr2010.tmp]? <cr>
Delete flash:cgr2010.tmp? [confirm] <cr>

```

- Step 10** Repeat [Step 9](#) for each file that you identified in [Step 6](#).
- Step 11** Enter the **dir flash:** command to display the layout and contents of flash memory.
- Step 12** From the displayed output of the **dir flash:** command, compare the number of bytes *available* to the size of the system image to which you want to upgrade.
- If the available memory is less than the new system image’s minimum flash requirements you **cannot** download the new image.
  - If the available memory is equal to or greater than the new system image’s minimum flash requirements, proceed to the [“Copying the System Image into Flash Memory”](#) section on page 62.
- 

## What to Do Next

Proceed to the [“Copying the System Image into Flash Memory”](#) section on page 62.

## Copying the System Image into Flash Memory

This section describes how to copy the system image into the compact flash memory card for your router. Choose one of the following methods:

- [Using TFTP or Remote Copy Protocol to Copy the System Image into Flash Memory, page 62](#)
- [Using the ROM Monitor to Copy the System Image over a Network, page 64](#)

## Using TFTP or Remote Copy Protocol to Copy the System Image into Flash Memory

This section describes how to use TFTP or Remote Copy Protocol (RCP) to upgrade the system image. This is the recommended and most common method of upgrading the system image.

### Prerequisites

- Install a TFTP server or an RCP server application on a TCP/IP-ready workstation or PC. Many third-party vendors provide free TFTP server software, which you can find by searching for “TFTP server” in a web search engine.

If you use TFTP:

- Configure the TFTP application to operate as a TFTP *server*, not a TFTP *client*.
- Specify the outbound file directory to which you will download and store the system image.
- Download the new Cisco IOS software image into the workstation or PC. See the [“Where Do I Download the System Image?”](#) section on page 57.
- Establish a console session to the router. We recommend that you connect your PC directly to the router console port. See the hardware installation guide that shipped with your router.
- Verify that the TFTP or RCP server has IP connectivity to the router. If you cannot successfully ping between the TFTP or RCP server and the router, do one of the following:
  - Configure a default gateway on the router.
  - Make sure that the server and the router each have an IP address in the same network or subnet. See the tech note, [Determining IP Addresses: Frequently Asked Questions](#).



Tip

For more detailed information on how to perform the prerequisites, see the [Software Installation and Upgrade Procedure](#).

## SUMMARY STEPS

1. **enable**
2. **copy tftp flash:**  
or  
**copy rcp flash:**
3. When prompted, enter the IP address of the TFTP or RCP server.
4. When prompted, enter the filename of the Cisco IOS software image to be installed.
5. When prompted, enter the filename as you want it to appear on the router.
6. If an error message appears that says, “Not enough space on device,” do one of the following, as appropriate:
  - If you are certain that all the files in flash memory should be erased, enter **y** twice when prompted to erase flash before copying.
  - If you are *not* certain that all files in flash memory should be erased, press **Ctrl-Z** and follow the instructions in the “[Ensuring Adequate Flash Memory for the New System Image](#)” section on [page 59](#).
7. If the error message does not appear, enter **no** when prompted to erase the flash memory before copying.

## DETAILED STEPS

- Step 1** Use the **enable** command to enter privileged EXEC mode. Enter your password if prompted:

```
Router> enable
Password: <password>
Router#
```

- Step 2** Enter the **copy tftp flash:** command  
or  
**copy rcp flash** command to copy a file from a server to flash memory.

For example:

```
Router# copy tftp flash:
Address or name of remote host [223.255.254.254]?
Source filename [ypatel/cgs2520-ip-services-mz.s12]?
Destination filename [cgs2520-ip-services-mz.s12]?
Accessing tftp://223.255.254.254/ypatel/cgs2520-ip-services-mz.s12...
Loading ypatel/cgs2520-ip-services-mz.s12 from 223.255.254.254 (via GigabitEthernet0/0):
!!!!!!!
!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!
[OK - 11776175 bytes]

11776175 bytes copied in 20.576 secs (572326 bytes/sec)

Router#
```

- Step 3** When prompted, enter the IP address of the TFTP or RCP server:

```
Address or name of remote host []? 10.10.10.2
```

**Step 4** When prompted, enter the filename of the Cisco IOS software image to be installed:

```
Source filename []? cgr2010-universalk9-mz.SPA.151-1.T
```



**Note** The filename is case sensitive.

**Step 5** When prompted, enter the filename as you want it to appear on the router. Typically, the same filename is entered as was used in [Step 4](#):

```
Destination filename []? cgr2010-universalk9-mz.SPA.151-1.T
```

**Step 6** If an error message appears that says, “Not enough space on device,” do one of the following as appropriate:

- If you are certain that all the files in flash memory should be erased, enter **y** when prompted twice to confirm that flash memory will be erased before copying:

```
Accessing tftp://10.10.10.2/cgr2010-universalk9-mz.SPA.151-1.T.bin...
Erase flash: before copying? [confirm] y
Erasing the flash filesystem will remove all files! Continue? [confirm] y
Erasing device... eeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeee
```

- If you are *not* certain that all the files in flash memory should be erased, press **Ctrl-Z** and follow the instructions in the [“Ensuring Adequate Flash Memory for the New System Image”](#) section on [page 59](#).

**Step 7** If the error message does not appear, enter **no** when prompted to erase the flash memory before copying:

```
Accessing tftp://10.10.10.2/cgr2010-universalk9-mz.SPA.151-1.T.bin...
Erase flash: before copying? [confirm] no
```

## Troubleshooting Tips

See [Resolving Common Image Installation Problems](#).

## What to Do Next

Proceed to the [“Loading the New System Image”](#) section on [page 67](#).

## Using the ROM Monitor to Copy the System Image over a Network

This section describes how to download a Cisco IOS software image from a remote TFTP server to the router flash memory using the **ftpdnld** ROM monitor command.



### Caution

Using the **ftpdnld** ROM monitor command may erase the system image, configuration, and data files. System image, configuration, and data files must be present on USB CF in slot0 for the router to boot and perform normal file operations.

Before you can enter the **ftpdnld** ROM monitor command, you must set the ROM monitor environment variables.

## Prerequisites

Connect the TFTP server to a fixed network port on your router.

## Restrictions

The LAN ports on network modules or interface cards are not active in ROM monitor mode. Therefore, only a fixed port on your router can be used for TFTP download. This can be either a fixed Ethernet port on the router or one of the Gigabit Ethernet ports on routers equipped with them.



### Note

You can use this command only to download files to the router. You cannot use **ftpdnld** to get files from the router.

## SUMMARY STEPS

1. Enter ROM monitor mode
2. Set the IP\_ADDRESS=ip\_address configuration variable.
3. Set the IP\_SUBNET\_MASK=ip\_address configuration variable.
4. Set the DEFAULT\_GATEWAY=ip\_address configuration variable.
5. Set the TFTP\_SERVER=ip\_address configuration variable.
6. Set the TFTP\_FILE=[directory-path/]filename configuration variable.
7. (Optional) Set the GE\_PORT=[0 | 1] port number for download.
8. (Optional) Set the TFTP\_MEDIA\_TYPE=[0 | 1] copper or fiber.
9. (Optional) Set the TFTP\_MACADDR= mac address of unit.
10. (Optional) Set the TFTP\_VERBOSE= [0 | 1 | 2] print setting variable.
11. (Optional) Set the TFTP\_RETRY\_COUNT=retry\_times configuration variable.
12. (Optional) Set the TFTP\_TIMEOUT=timeout of operation in seconds.
13. (Optional) Set the TFTP\_ACK\_RETRY=ack retry in seconds.
14. (Optional) Set the TFTP\_CHECKSUM=[0 | 1] perform checksum test on image.
15. (Optional) Set the TFTP\_DESTINATION=[flash0 | flash1 | usbflash0 | usbflash1] flash destination device for file.
16. (Optional) Set the GE\_SPEED\_MODE= speed configuration.
17. Use the **set** command to verify that you have set the variables correctly.
18. Use the **ftpdnld [-r]** command to download the image.

## DETAILED STEPS

- 
- Step 1** Enter ROM monitor mode.
- Step 2** Set the IP address of the router. For example:
- ```
rommon > IP_ADDRESS=172.16.23.32
```
- Step 3** Set the IP subnet mask. For example:
- ```
rommon > IP_SUBNET_MASK=255.255.255.224
```

- Step 4** Set the default gateway address. For example:
- ```
rommon > DEFAULT_GATEWAY=172.16.23.40
```
- Step 5** Set the TFTP server IP address, which is the location from which the software will be downloaded:
- ```
rommon > TFTP_SERVER=172.16.23.33
```
- Step 6** Set the name and directory location to which the image file will be downloaded onto the router. For example:
- ```
rommon > TFTP_FILE=archive/rel22/<image name>
```
- Step 7** (Optional) Set the input port to use a Gigabit Ethernet port. Usage is GE\_PORT=[0 | 1]. For example:
- ```
rommon > GE_PORT=0
```
- Step 8** (Optional) Set the Ethernet media type. Usage is TFTP\_MEDIA\_TYPE=[0 | 1], where Copper= 0 and Fiber=1:
- ```
rommon > TFTP_MEDIA_TYPE=1
```
- Step 9** (Optional) Decide whether the router will perform a checksum test on the downloaded image. Usage is TFTP\_CHECKSUM=[0 | 1], where 1=checksum test is performed (default) and 0=no checksum test. For example:
- ```
rommon > TFTP_CHECKSUM=0
```
- Step 10** (Optional) Set the number of times that the router will attempt Address Resolution Protocol (ARP) and TFTP download. The default is 7 attempts. For example:
- ```
rommon > TFTP_RETRY_COUNT=10
```
- Step 11** (Optional) Set the amount of time, in seconds, before the download process times out. The default is 2400 seconds (40 minutes). The following example shows 1800 seconds (30 minutes):
- ```
TFTP_TIMEOUT=1800
```
- Step 12** (Optional) Configure the print variable. Usage is TFTP\_VERBOSE= [0 | 1 | 2], where print:
- 0= is quiet.
  - 1= in progress.
  - 2= verbose
- Step 13** Use the **set** command to display the ROM monitor environment variables to verify that you have configured them correctly. For example:
- ```
rommon > set
```
- Step 14** Download the system image, as specified by the ROM monitor environmental variables, using the **tftpdnld [-r]** command. Without the **-r** option, the command downloads the specified image and saves it in flash memory, deleting all existing data in all partitions in flash memory. Using the **-r** option downloads and boots the new software but does not save the software to flash memory.
- ```
rommon> tftpdnld [-r]
A prompt is displayed:
Do you wish to continue? y/n: [n]: y
```
- Entering “y” confirms that you want to continue with the TFTP download.
-



## What to Do Next

Proceed to the [“Loading the New System Image”](#) section on page 67.

## Loading the New System Image

This section describes how to load the new system image that you copied into flash memory. First, determine whether you are in ROM monitor mode or in the Cisco IOS CLI. Then choose one of the following methods of loading the new system image:

- [Loading the New System Image from the Cisco IOS Software, page 67](#)
- [Loading the New System Image from ROM Monitor Mode, page 69](#)

## Loading the New System Image from the Cisco IOS Software

This section describes how to load the new system image from the Cisco IOS software.

### SUMMARY STEPS

1. **dir flash:**
2. **configure terminal**
3. **no boot system**
4. (Optional) **boot system flash** *system-image-filename*
5. (Optional) Repeat to specify the order in which the router should attempt to load any backup system images.
6. **exit**
7. **show version**
8. If the last digit in the configuration register is 0 or 1, proceed to [Step 9](#). However, if the last digit in the configuration register is between 2 and F, proceed to [Step 12](#).
9. **configure terminal**
10. **config-register 0x2102**
11. **exit**
12. **copy run start**
13. **reload**
14. When prompted to save the system configuration, enter **no**.
15. When prompted to confirm the reload, enter **y**.
16. **show version**

### DETAILED STEPS

---

**Step 1** Enter the **dir flash:** command to display a list of all files and directories in flash memory:

```
Router# dir flash:  
  
Directory of flash:/
```

```

    3  -rw-      6458388   Mar 01 1993 00:00:58  c38xx.tmp
  1580 -rw-      6462268   Mar 06 1993 06:14:02  c38xx-ata

```

63930368 bytes total (51007488 bytes free)




---

**Note** Determine whether the new system image is the first file or the only file listed in the **dir flash** command output ( is not required if it is the first file or only file listed).

---

**Step 2** Enter the **configure terminal** command to enter global configuration mode:

```
Router# configure terminal
```

```
Router(config)#
```

**Step 3** Enter the **no boot system** command to delete all entries in the bootable image list, which specifies the order in which the router attempts to load the system images at the next system reload or power cycle:

```
Router(config)# no boot system
```

**Step 4** If the new system image is the first file or the only file displayed in the **dir flash:** command output, you do not need to perform the following step.

Enter the **boot system flash *system-image-filename*** command to load the new system image after the next system reload or power cycle. For example:

```
Router(config)# boot system flash cgr2010-universalk9-mz.SPA.151-1.T.bin
```

**Step 5** (Optional) Repeat to specify the order in which the router should attempt to load any backup system images.

**Step 6** Enter the **exit** command to exit global configuration mode:

```
Router(config)# exit
```

```
Router#
```

**Step 7** Enter the **show version** command to display the configuration register setting:

```
Router# show version
```

```

Cisco Internetwork Operating System Software
.
.
.
Configuration register is 0x0

```

```
Router#
```

**Step 8** If the last digit in the configuration register is 0 or 1, proceed to [Step 9](#). However, if the last digit in the configuration register is between 2 and F, proceed to [Step 12](#).

**Step 9** Enter the **configure terminal** command to enter global configuration mode:

```
Router# configure terminal
```

```
Router(config)#
```

**Step 10** Enter the **config-register 0x2102** command to set the configuration register so that, after the next system reload or power cycle, the router loads a system image from the **boot system** commands in the startup configuration file:

```
Router(config)# config-register 0x2102
```

**Step 11** Enter the **exit** command to exit global configuration mode:

```
Router(config)# exit  
Router#
```

**Step 12** Enter the **copy run start** command to copy the running configuration to the startup configuration:

```
Router# copy run start
```

**Step 13** Enter the **reload** command to reload the operating system:

```
Router# reload
```

**Step 14** When prompted to save the system configuration, enter **no**:

```
System configuration has been modified. Save? [yes/no]: no
```

**Step 15** When prompted to confirm the reload, enter **y**:

```
Proceed with reload? [confirm] y
```

**Step 16** Enter the **show version** command to verify that the router loaded the proper system image:

```
Router# show version  
  
00:22:25: %SYS-5-CONFIG_I: Configured from console by console  
Cisco Internetwork Operating System Software  
.  
.  
.  
System returned to ROM by reload  
System image file is "flash:cgr2010-universalk9-mz.SPA.151-1.T.bin"
```

---

## What to Do Next

Proceed to the [“Saving Backup Copies of Your New System Image and Configuration”](#) section on page 71.

## Loading the New System Image from ROM Monitor Mode

This section describes how to load the new system image from ROM monitor mode.

### SUMMARY STEPS

1. **dir flash0:[partition-number:]**
2. **confreg 0x2102**
3. **boot flash0:[partition-number:]filename**
4. After the system loads the new system image, press **Return** a few times to display the Cisco IOS command-line interface (CLI) prompt.
5. **enable**
6. **configure terminal**
7. **no boot system**
8. **boot system flash0: new-system-image-filename**

9. (Optional) Repeat to specify the order in which the router should attempt to load any backup system images.
10. **exit**
11. **copy run start**

## DETAILED STEPS

- Step 1** Enter the **dir flash0:[partition-number:]** command to list files in flash memory:

```
rommon > dir flash0:
program load complete, entry point: 0x80803000, size: 0x1b340
Directory of flash0:

 2      47089944  -rw- cgr2010-universalk9-mz.SPA.151-1.T
rommon 3 >
```

Note whether the new system image is the first file or the only file listed in the **dir flash0:** command output. ( is not required if the image is the first file or only file listed.)

- Step 2** Enter the **confreg 0x2102** command to set the configuration register so that, after the next system reload or power cycle, the router loads a system image from the boot system commands in the startup configuration file:

```
rommon > confreg 0x2102
```

- Step 3** Enter the **boot flash0:[partition-number:]filename** command to force the router to load the new system image:

```
rommon > boot flash0:cgr2010-universalk9-mz.SPA.151-1.T.bin
```

- Step 4** After the system loads the new system image, press **Return** a few times to display the Cisco IOS CLI prompt.

- Step 5** Enter the **enable** command to enable privileged EXEC mode, and enter your password if prompted:

```
Router> enable
Password: <password>
Router#
```

- Step 6** Enter the **configure terminal** command to enter global configuration mode:

```
Router# configure terminal
Router(config)#
```

- Step 7** Enter the **no boot system** to eliminate all entries in the bootable image list, which specifies the system image that the router loads at startup:

```
Router(config)# no boot system
```

- Step 8** If the new system image is the first file or only the file displayed in the **dir flash0:** command output, this step is not required.

Enter the **boot system flash new-system-image-filename** command to load the new system image after the next system reload or power cycle:

```
Router(config)# boot system flash cgr2010-universalk9-mz.SPA.151-1.T.bin
```

- Step 9** (Optional) Repeat to specify the order in which the router should attempt to load any backup system images.

**Step 10** Enter the **exit** command to exit global configuration mode:

```
Router(config)# exit  
Router#
```

**Step 11** Enter the **copy run start** command to copy the running configuration to the startup configuration:

```
Router# copy run start
```

---

## What to Do Next

Proceed to the [“Saving Backup Copies of Your New System Image and Configuration”](#) section on page 71.

## Saving Backup Copies of Your New System Image and Configuration

To aid file recovery and to minimize downtime in the event of file corruption, we recommend that you save backup copies of the startup configuration file and the Cisco IOS software system image file on a server.



### Tip

Do not erase any existing backup copies of your configuration and system image that you saved before upgrading your system image. If you encounter serious problems using your new system image or startup configuration, you can quickly revert to the previous working configuration and system image, if necessary.

---

For more detailed information, see the [“Managing Configuration Files”](#) chapter and the [“Loading and Maintaining System Images”](#) chapter of *Cisco IOS Configuration Fundamentals Configuration Guide, Release 15.0*.

To save backup copies of the startup configuration file and the system image file, complete the following steps:

## SUMMARY STEPS

1. **enable**
2. **copy nvram:startup-config {ftp: | rcp: | tftp:}**
3. **dir flash0:**
4. **copy flash0: {ftp: | rcp: | tftp:}**

## DETAILED STEPS

	Command or Action	Purpose
Step 1	<b>enable</b>  <b>Example:</b> Router> enable	Enables privileged EXEC mode. <ul style="list-style-type: none"> <li>Enter your password if prompted.</li> </ul>
Step 2	<b>copy nvram:startup-config {ftp:   rcp:   tftp:}</b>  <b>Example:</b> Router# copy nvram:startup-config ftp:	Copies the startup configuration file to a server. <ul style="list-style-type: none"> <li>The configuration file copy serves as a backup copy.</li> <li>Enter the destination URL when prompted.</li> </ul>
Step 3	<b>dir flash0:</b>  <b>Example:</b> Router# dir flash0:	Displays the layout and contents of a flash memory file system. <ul style="list-style-type: none"> <li>Write down the name of the system image file.</li> </ul>
Step 4	<b>copy flash0: {ftp:   rcp:   tftp:}</b>  <b>Example:</b> Router# copy flash0: ftp:	Copies a file from flash memory to a server. <ul style="list-style-type: none"> <li>Copy the system image file to a server to serve as a backup copy.</li> <li>Enter the flash memory partition number if prompted.</li> <li>Enter the filename and destination URL when prompted.</li> </ul>

## Examples

**Copying the Startup Configuration to a TFTP Server: Example**

The following example shows the startup configuration being copied to a TFTP server:

```
Router# copy nvram:startup-config tftp:

Remote host[]? 172.16.101.101

Name of configuration file to write [rtr2-config]? <cr>
Write file rtr2-config on host 172.16.101.101?[confirm] <cr>
![OK]
```

**Copying from Flash Memory to a TFTP Server: Example**

The following example uses the **dir flash:** privileged EXEC command to obtain the name of the system image file and the **copy flash: tftp:** privileged EXEC command to copy the system image to a TFTP server. The router uses the default username and password.

```
Router# dir flash0:

System flash directory:
File Length Name/status
1 4137888 cgr2010-mz
[4137952 bytes used, 12639264 available, 16777216 total]
16384K bytes of processor board System flash (Read/Write)\

Router# copy flash0: tftp:
IP address of remote host [255.255.255.255]? 192.0.0.1
filename to write on tftp host? cgr2010-mz
```

```
writing cgr2010-mz !!!!...
successful ftp write.
```

## Additional References

The following sections provide references related to upgrading the system image on your router.

### Related Documents and Websites

Related Topic	Document Title or Website
Matching Cisco IOS releases and features to hardware	<a href="#">Cisco Feature Navigator</a>
Choosing and downloading system images	Cisco <a href="#">Download Software</a> website
Loading and maintaining system images	<a href="#">Cisco IOS and NX-OS Software, Loading and Managing System Images</a>
Removing, inserting, and upgrading compact flash memory cards	Hardware Installation Guide for your router
Connecting your PC to the router console port	Hardware Installation Guide for your router

### Technical Assistance

Description	Link
Technical Assistance Center (TAC) home page, containing 30,000 pages of searchable technical content, including links to products, technologies, solutions, technical tips, and tools. Registered Cisco.com users can log in from this page to access even more content. <sup>1</sup>	<a href="http://www.cisco.com/public/support/tac/home.shtml">http://www.cisco.com/public/support/tac/home.shtml</a>

1. You must have an account on Cisco.com. If you do not have an account or have forgotten your username or password, click Cancel at the login dialog box and follow the instructions that appear.







# Using CompactFlash Memory

---

**First Published: May 27, 2010, OL-20356-01**

**Last Updated: October 25, 2017**

The Cisco Connected Grid Router 2010 uses Advanced Capability CF external memory to store the system image, configuration files, and some software data files. CF supports true integrated development environment mode and multi-word direct memory access mode.

This document explains how to manage directories and files on the CF in the following sections:

- [Requirements and Restrictions, page 75](#)
- [Online Insertion and Removal, page 76](#)
- [Formatting CompactFlash Memory as a Class C File System, page 76](#)
- [File Operations on CompactFlash Memory Cards, page 77](#)
- [Directory Operations on a CompactFlash Memory Card, page 81](#)

## Requirements and Restrictions

### CompactFlash Support

- Only Advanced Capability CF purchased from Cisco operate in the Cisco CGR 2010 router.
- Legacy CF will not operate in Cisco CGR 2010 router. When legacy CF is inserted, the following error message appears:

```
WARNING: Unsupported compact flash detected. Use of this card during normal operation
can impact and severely degrade performance of the system. Please use supported
compact flash cards only.
```

### Formatting CompactFlash

- Only Class C file systems are supported on Cisco PCMCIA CompactFlash (CF).
- We recommend that you format new CF to initialize a new flash file system. Proper formatting lets the ROM monitor recognize and boot the flash memory. The CF can be formatted on a router, and files can be copied to or from any PC that is equipped with a CF memory reader. If you use a PC to format the CF, use the Microsoft File Allocation Table (FAT32) file system.



---

**Americas Headquarters:**  
**Cisco Systems, Inc., 170 West Tasman Drive, San Jose, CA 95134-1706 USA**

© 2010 Cisco Systems, Inc. All rights reserved.

**CompactFlash Slots and Files**

- Cisco CGR 2010 routers have two types of external CF slots
  - 2— PCMCIA
  - 2— USB
- CF in slot0 can store the system image, configuration, and data files. The CF must be present in this slot for the router to boot and perform normal file operations.



**Note** Use `flash1` in the command syntax to access CF in slot 1. Use `flash0` in the command syntax to access CF in slot 0.

**Table 1 Compact Flash Slot Numbering and Naming**

Slot Number	PCMCIA CF Filenames	USB CF Filenames	Size
Slot0 <sup>1</sup>	<code>flash0</code>	<code>usbflash0</code>	256MB
Slot1	<code>flash1</code>	<code>usbflash1</code>	0
Total	-	-	4GB

1. Slot 0 is the default CF slot. CF in slot0 can store system image, configuration, and data files. CF must be present in this slot for the router to boot and perform normal file operations.

## Online Insertion and Removal

Online insertion and removal (OIR) is a feature that allows you to replace CompactFlash memory cards without turning off the router and without affecting the operation of other interfaces. OIR of CF memory cards provides uninterrupted operation to network users, maintains routing information, and ensures session preservation.

**Caution**

The external CF memory card should not be removed if the flash memory busy “CF” LED on the router is blinking, because this indicates that the software is accessing the CF memory card. Removing the CF memory card may disrupt the network, because some software features use the CF memory card to store tables and other important data.

For instructions on inserting, removing, and replacing the external CF memory card, see the router’s *Hardware Installation Guide*.

## Formatting CompactFlash Memory as a Class C File System

Use the **format flash:** command in privileged EXEC mode to:

- Format CF memory cards with a Class C flash file system
- Remove the files from a CF memory card previously formatted with a Class C flash file system



**Note** Use `flash1` in the command syntax to access CF in slot 1. Use `flash0` in the command syntax to access CF in slot 0.

### Formatting CompactFlash Memory as a Class C Flash File System: Example

```

Router# format flash:
Format operation may take a while. Continue? [confirm]
Format operation will destroy all data in "flash:". Continue? [confirm]
Enter volume ID (up to 64 chars)[default flash]:
Current Low End File System flash card in flash will be formatted into DOS
File System flash card! Continue? [confirm]
Format:Drive communication & 1st Sector Write OK...
Writing Monlib sectors .....
Monlib write complete
Format:All system sectors written. OK...
Format:Total sectors in formatted partition:250592
Format:Total bytes in formatted partition:128303104
Format:Operation completed successfully.
Format of flash complete

```

## File Operations on CompactFlash Memory Cards

This section describes the following file operations for external CF memory cards:

- [Copying Files, page 77](#)
- [Displaying Files, page 78](#)
- [Displaying File Content, page 78](#)
- [Displaying Geometry and Format Information, page 79](#)
- [Deleting Files, page 80](#)
- [Renaming Files, page 80](#)

## Copying Files

To copy files, enter the **copy** command in privileged EXEC mode. To indicate a file that is stored in a CF memory card, precede the filename with **flash**.



**Note** Use **flash1** in the command syntax to access CF in slot 1. Use **flash0** in the command syntax to access CF in slot 0.

### Examples: Copying Files

In the following example, the file my-config1 on the CF memory card is copied into the startup-config file in the system memory:

```

Router# copy flash:my-config1 startup-config

Destination filename [startup-config]?
[OK]
517 bytes copied in 4.188 secs (129 bytes/sec)

```

In the following example, the file my-config2 on the CF memory card is copied into the running-config file in the system memory:

```

Router# copy flash:my-config2 running-config

Destination filename [running-config]?
709 bytes copied in 0.72 secs

```

## Displaying Files

To display a list of files in CF memory, enter the **dir flash:** command in privileged EXEC mode.



**Note** Use **flash1** in the command syntax to access CF in slot 1. Use **flash0** in the command syntax to access CF in slot 0.

```
Router# dir flash:

Directory of flash:/
 1580  -rw-      6462268   Mar 06 2004 06:14:02  c29xx-i-mz.3600ata
    3   -rw-      6458388   Mar 01 2004 00:01:24  c29xx-i-mz
63930368 bytes total (51007488 bytes free)
```

## Displaying CF Platform Support Status and Errors

To display the platform support status of the CF memory, enter the **show platform cf** command in privileged EXEC mode.

```
Router# show platform cf

Platform Support status of Compact Flash:
=====
CF flash0: Compact Flash plugged in is Unsupported
CF flash1: Compact Flash not plugged in.
```

Router

To display platform error status, enter the **show platform error** command in privileged EXEC mode.

```
Router# show platform error
Interface GigabitEthernet0/0:
-----
Unknown Protocol Drops   : 6

Interface GigabitEthernet0/1:
-----
Lost Carrier              : 1

CF Error Status:
-----
Compact Flash 0 Unsupported (HT)
```

Router#

## Displaying File Content

To display the content of a file that is stored in flash memory, enter the **more flash:** command in privileged EXEC mode:



**Note** Use **flash1** in the command syntax to access CF in slot 1. Use **flash0** in the command syntax to access CF in slot 0.

```
Router# more flash:cgr2010-universalk9-mz.SPA.151-1.T
```

```

00000000: 7F454C46 01020100 00000000 00000000 .ELF ....
00000010: 00020061 00000001 80008000 00000034 ...a ....4
00000020: 00000054 20000001 00340020 00010028 ...T ...4. ... (
00000030: 00050008 00000001 0000011C 80008000 ....
00000040: 80008000 00628A44 00650EEC 00000007 .... .b.D .e.l ....
00000050: 0000011C 0000001B 00000001 00000006 ....
00000060: 80008000 0000011C 00004000 00000000 .... ..@. ....
00000070: 00000000 00000008 00000000 00000021 .... ..!
00000080: 00000001 00000002 8000C000 0000411C .... ..@. ..A.
00000090: 00000700 00000000 00000000 00000004 ....
000000A0: 00000000 00000029 00000001 00000003 .... ..) ....
000000B0: 8000C700 0000481C 00000380 00000000 ..G. ..H. ....
000000C0: 00000000 00000004 00000000 0000002F .... .. /
000000D0: 00000001 10000003 8000CA80 00004B9C .... ..J. ..K.
000000E0: 00000020 00000000 00000000 00000008 ... ..
000000F0: 00000000 0000002F 00000001 10000003 .... .. /
00000100: 8000CAA0 00004BBC 00623FA4 00000000 ..J ..K< .b?$ ....
00000110: 00000000 00000008 00000000 3C1C8001 .... ..<... <...
00000120: 679C4A80 3C018001 AC3DC70C 3C018001 g.J. <... ,=G. <...
00000130: AC3FC710 3C018001 AC24C714 3C018001 ,?G. <... ,&G. <...
00000140: AC25C718 3C018001 AC26C71C 3C018001 ,%G. <... ,&G. <...
00000150: AC27C720 3C018001 AC30C724 3C018001 ,'G <... ,0G$ <...
00000160: AC31C728 3C018001 AC32C72C 3C018001 ,1G( <... ,2G, <...
--More-- q

```

## Displaying Geometry and Format Information

To display the geometry and format information of a CF flash file system, enter the **show flash: filesystems** command in privileged EXEC mode.



**Note** Use **flash1** in the command syntax to access CF in slot 1. Use **flash0** in the command syntax to access CF in slot 0.

```

Router# show flash0 filesystems
***** ATA Flash Card Geometry/Format Info *****

```

```

ATA CARD GEOMETRY
  Manufacturer Name
  Model Number          SMART CF    fs:8000
  Serial Number         2009101509D809B20000
  Firmware Revision     20060729
  Number of Heads       16
  Number of Cylinders   1986
  Sectors per Cylinder  63
  Sector Size           512
  Total Sectors         2001888

```

```

ATA PARTITION 1 INFO
  Start Sector          63
  Number of Sectors     2001825
  Size in Bytes         1024934400
  File System Type      FAT16
  Number of FAT Sectors 245
  Sectors Per Cluster   32
  Number of Clusters    62540
  Number of Data Sectors 2001280
  Base FAT Sector       1
  Base Root Sector      491

```

```

Base Data Sector      523

ATA MONLIB INFO
Image Monlib size    121788
Disk Monlib Size     NA
Disk Space Available NA
Name                 NA
End Sector           NA
Start sector         NA
Updated By           NA
Version              NA

Router#

```

## Deleting Files

To delete a file from a CF memory card, enter the **delete flash:** command.




---

**Note** Use **flash1** in the command syntax to access CF in slot 1. Use **flash0** in the command syntax to access CF in slot 0.

---




---

**Note** The **dir flash:** command does not display deleted files and files with errors.

---

## Renaming Files

To rename a file on a CF memory card, enter the **rename** command in privileged EXEC mode.




---

**Note** Use **flash1** in the command syntax to access CF in slot 1. Use **flash0** in the command syntax to access CF in slot 0.

---

```

Router# dir flash:

Directory of flash:/

   3  -rw-     6458388  Mar 01 2009 00:00:58 cgr2010-universalk9-mz.tmp
 1580 -rw-     6462268  Mar 06 2009 06:14:02 cgr2010-universalk9-mz.3600ata

63930368 bytes total (51007488 bytes free)

Router# rename flash:cgr2010-universalk9-mz.SPA.151-1.T.tmp flash:cgr2010-universalk9-mz

Destination filename [cgr2010-universalk9-mz]?

Router# dir flash:

Directory of flash:/

 1580 -rw-     6462268  Mar 06 2009 06:14:02 cgr2010-universalk9-mz.3600ata
   3  -rw-     6458388  Mar 01 2009 00:01:24 cgr2010-universalk9-mz

63930368 bytes total (51007488 bytes free)

```

# Directory Operations on a CompactFlash Memory Card

The following sections describe directory operations for external CF memory cards on Cisco routers:

- [Entering a Directory and Determining Which Directory You Are In](#), page 81
- [Creating a New Directory](#), page 81
- [Removing a Directory](#), page 82

## Entering a Directory and Determining Which Directory You Are In

To enter a directory of a CF memory card, enter the **cd** command in privileged EXEC mode. The **cd** command specifies or changes the default directory or file system. If you enter **cd** only, without specifying a file system, the router enters the default home directory, which is *flash0*. If you enter **cd flash1** or **cd usbflash1**, the router enters the *flash1* directory.

```
Router# cd
```

To determine which directory you are in, enter the **pwd** command in privileged EXEC mode. The CLI displays which directory or file system is specified as the default by the **cd** command.

```
Router# pwd
```

To display a list of files in the directory that you are in, enter the **dir** command in privileged EXEC mode. The command-line interface will display the files in the file system that was specified as the default by the **cd** command.

```
Router# dir flash:
```

```
Directory of flash:/
```

```
 1580  -rw-      6462268   Mar 06 2009 06:14:02 cgr2010-universalk9-mz.3600ata
      3  -rw-      6458388   Mar 01 2009 00:01:24 cgr2010-universalk9-mz
```

```
63930368 bytes total (51007488 bytes free)
```

### Entering a Directory: Example

To enter the /config directory:

```
Router# cd config
```

To verify that you are in the /config directory:

```
Router# pwd
```

```
flash:/config/
```

```
Router# dir
```

```
Directory of flash:/config/
```

```
  380  -rw-      6462268   Mar 08 2004 06:14:02 myconfig1
   203  -rw-      6458388   Mar 03 2004 00:01:24 myconfig2
```

```
63930368 bytes total (51007488 bytes free)
```

## Creating a New Directory

To create a directory in flash memory, enter the **mkdir flash:** command in privileged EXEC mode.




---

**Note** Use **flash1** in the command syntax to access CF in slot 1. Use **flash0** in the command syntax to access CF in slot 0.

---

### Creating a New Directory: Example

In the following example, a new directory named “config” is created; then a new subdirectory named “test-config” is created within the “config” directory.

```
Router# dir flash:

Directory of flash:/

 1580  -rw-      6462268   Mar 06 2009 06:14:02  cgr2010-universalk9-mz.3600ata
    3   -rw-      6458388   Mar 01 2009 00:01:24  cgr2010-universalk9-mz

63930368 bytes total (51007488 bytes free)

Router# mkdir flash:/config

Create directory filename [config]?
Created dir flash:/config

Router# mkdir flash:/config/test-config

Create directory filename [/config/test-config]?
Created dir flash:/config/test-config

Router# dir flash:

Directory of flash:/

    3   -rw-      6458388   Mar 01 2009 00:01:24  cgr2010-universalk9-mz
 1580  drw-          0      Mar 01 2004 23:48:36  config

63930368 bytes total (51007488 bytes free)
```

## Removing a Directory

To remove a directory in flash memory, enter the **rmdir flash:** command in privileged EXEC mode. Before you can remove a directory, you must remove all files and subdirectories from the directory.




---

**Note** Use **flash1** in the command syntax to access CF in slot 1. Use **flash0** in the command syntax to access CF in slot 0.

---

### Example: Removing a Directory

In the following example, the subdirectory test-config is removed.

```
Router# dir

Directory of flash:/config/

 1581  drw-          0      Mar 01 2004 23:50:08  test-config

128094208 bytes total (121626624 bytes free)
```



```
Router# rmdir flash:/config/test-config

Remove directory filename [/config/test-config]?
Delete flash:/config/test-config? [confirm]
Removed dir flash:/config/test-config
Router# dir

Directory of flash:/config/

No files in directory

128094208 bytes total (121630720 bytes free)
```





# Using ROM Monitor

---

**First Published: May 27, 2010, OL-20356-01**  
**Last Updated: October 25, 2017**

Many users do not use the ROM monitor at all, unless during power up or reload, the router does not find a valid system image, the last digit of the boot field in the configuration register is 0, or you enter the Break key sequence of the terminal that is plugged into the router console port during the first 60 seconds after reloading the router.

This document describes how to use the ROM monitor to manually load a system image, upgrade the system image when there are no TFTP servers or network connections, or for disaster recovery.

## Contents

- [Platforms Supported by This Document, page 85](#)
- [Prerequisites for Using the ROM Monitor, page 85](#)
- [Information About the ROM Monitor, page 86](#)
- [How to Use the ROM Monitor—Typical Tasks, page 87](#)
- [Additional References, page 114](#)

## Platforms Supported by This Document

This document describes use of the ROM monitor with the Cisco Connected Grid Router 2010.

## Prerequisites for Using the ROM Monitor

Connect a terminal or PC to the router console port. For help, see the hardware installation guide for your router.



---

**Americas Headquarters:**  
**Cisco Systems, Inc., 170 West Tasman Drive, San Jose, CA 95134-1706 USA**

© 2010 Cisco Systems, Inc. All rights reserved.

# Information About the ROM Monitor

Before using the ROM monitor, you should understand the following concepts:

- [ROM Monitor Mode Command Prompt](#), page 86
- [Why is the Router in ROM Monitor Mode?](#), page 86
- [When do I use ROM Monitor?](#), page 86
- [Tips for Using ROM Monitor Commands](#), page 87
- [Accessibility](#), page 87

## ROM Monitor Mode Command Prompt

The ROM monitor uses the `rommon x >` command prompt. The *x* variable begins at one and increments each time you press **Return** or **Enter** in ROM monitor mode.

## Why is the Router in ROM Monitor Mode?

The router boots to ROM monitor mode when one of the following occurs:

- During power up or reload, the router did not find a valid system image.
- The last digit of the boot field in the configuration register is 0 (for example, 0x100 or 0x0).
- You enter the Break key sequence (typically, **Ctrl-Break**) of the terminal that is plugged into the router console port during the first 60 seconds after reloading the router.

To exit ROM monitor mode, see the [“Exiting ROM Monitor Mode”](#) section on page 112.

## When do I use ROM Monitor?

Use ROM monitor when:

- Manually loading a system image—You can load a system image without configuring the router to load that image in future system reloads or power-cycles. This can be useful for testing a new system image or for troubleshooting. See the [“Loading a System Image \(boot\)”](#) section on page 93.
- Upgrading the system image when there are no TFTP servers or network connections, and a direct PC connection to the router console is the only viable option—See information about upgrading the system image in the configuration documentation for your router.
- Troubleshooting if the router crashes and hangs—See the [“Troubleshooting Crashes and Hangs \(stack, context, frame, sysret, meminfo\)”](#) section on page 107.
- Recovering from a system disaster—Use one of the following methods for recovering the system image or configuration file:

**Note**

Recovering the system image is different from upgrading the system image. You need to recover the system image if it becomes corrupt or if it is deleted because of a disaster that affects the memory device severely enough to require deleting all data on the memory device to load a system image.

- TFTP download (**tftpdnld**)—Use this method if you can connect a TFTP server directly to the fixed LAN port on your router. See the “[Downloading the System Image \(tftpdnld\)](#)” section on page 103.

## Tips for Using ROM Monitor Commands

- ROM monitor commands are case sensitive.
- You can halt any ROM monitor command by entering the Break key sequence (**Ctrl-Break**) on the PC or terminal. The Break key sequence varies, depending on the software on your PC or terminal. If **Ctrl-Break** does not work, see the *Standard Break Key Sequence Combinations During Password Recovery* troubleshooting tech note.
- To find out which commands are available on your router and to display command syntax options, see the “[Displaying Commands and Command Syntax in ROM Monitor Mode \(?, help, -?\)](#)” section on page 92.

## Accessibility

The Cisco Connected Grid Router 2010 can be configured using the Cisco command-line interface (CLI). The CLI conforms to accessibility code 508 because it is text based and it relies on a keyboard for navigation. All functions of the router can be configured and monitored using the CLI.

For a complete list of guidelines and Cisco products adherence to accessibility, see [Cisco Accessibility Products](#).

## How to Use the ROM Monitor—Typical Tasks

This section provides the following procedures:

- [Entering ROM Monitor Mode](#), page 88
- [Displaying Commands and Command Syntax in ROM Monitor Mode \(?, help, -?\)](#), page 92
- [Displaying Files in a File System \(dir\)](#), page 93
- [Loading a System Image \(boot\)](#), page 93
- [Modifying the Configuration Register](#), page 98
- [Obtaining Information on USB Flash Devices](#), page 99
- [Modifying the I/O Memory \(iomemset\)](#), page 100
- [Upgrading of ROM Monitor command Using Cisco IOS](#), page 102
- [Downloading the System Image \(tftpdnld\)](#), page 103
- [Troubleshooting Crashes and Hangs \(stack, context, frame, sysret, meminfo\)](#), page 107
- [Exiting ROM Monitor Mode](#), page 112



### Note

This section does not describe how to perform all possible ROM monitor tasks. Use the command help to list and perform any tasks that are not described in this document. See the “[Displaying Commands and Command Syntax in ROM Monitor Mode \(?, help, -?\)](#)” section on page 92.

## Entering ROM Monitor Mode

This section provides two ways to enter ROM monitor mode:

- [Using the Break Key Sequence to Interrupt the System Reload and Enter ROM Monitor Mode, page 88](#)
- [Setting the Configuration Register to Boot to ROM Monitor Mode, page 90](#)

### Prerequisites

Connect a terminal or PC to the router console port. For help, see the hardware installation guide for your router.

### Using the Break Key Sequence to Interrupt the System Reload and Enter ROM Monitor Mode

This section describes how to enter ROM monitor mode by reloading the router and entering the Break key sequence.

**Note**

---

Bit 8 controls the console Break key (see [Table 1 on page 116](#)):

- Setting bit 8 (Factory default) causes the processor to ignore the console Break key.
- Clearing bit 8 causes the processor to interpret Break as a command to force the router into the ROM monitor mode, halting normal operation.

Break can always be sent in the first 60 seconds while the router is rebooting, regardless of the configuration register settings.

---

### SUMMARY STEPS

1. **enable**
2. **reload**
3. Press **Ctrl-Break**.

## DETAILED STEPS

	Command or Action	Purpose
Step 1	<b>enable</b>  <b>Example:</b> Router> enable	Enables privileged EXEC mode. <ul style="list-style-type: none"> <li>Enter your password if prompted.</li> </ul>
Step 2	<b>reload</b>  <b>Example:</b> Router# reload	Reloads the operating system.
Step 3	Immediately press <b>Ctrl-Break</b> .  <b>Example:</b> Router# send break	Interrupts the router reload and enters ROM monitor mode. <ul style="list-style-type: none"> <li>You must perform this step within 60 seconds after you enter the <b>reload</b> command.</li> <li>The Break key sequence varies, depending on the software on your PC or terminal. If <b>Ctrl-Break</b> does not work, see <a href="#">Standard Break Key Sequence Combinations During Password Recovery</a>.</li> </ul>

## Examples

This section provides an example of the **reload** command:

**Sample Output for the reload Command**

```
Use break key sequence to enter rom monitor
Router# reload
```

```
Proceed with reload? [confirm]
```

```
*Sep 23 15:54:25.871: %SYS-5-RELOAD: Reload requested by console. Reload Reason: Reload
command.
```

**Note**

Clearing bit 8 causes the processor to interpret Break as a command to force the router into the ROM monitor mode, halting normal operation.

```
telnet> send break
```

```
*** System received an abort due to Break Key ***
signal= 0x3, code= 0x0, context= 0x431aaf40
PC = 0x4008b5dc, Cause = 0x20, Status Reg = 0x3400c102
```

## Troubleshooting Tips

The Break key sequence varies, depending on the software on your PC or terminal. See [Standard Break Key Sequence Combinations During Password Recovery](#).

## What to Do Next

- Proceed to the “[Displaying Commands and Command Syntax in ROM Monitor Mode \(?, help, -?\)](#)” section on page 92.

- If you use the Break key sequence to enter ROM monitor mode when the router would otherwise have booted the system image, you can exit ROM monitor mode by doing one of the following:
  - Enter the **i** or **reset** command, which restarts the booting process and loads the system image.
  - Enter the **cont** command to continue the booting process and load the system image.

## Setting the Configuration Register to Boot to ROM Monitor Mode

This section describes how to enter ROM monitor mode by setting the configuration register to boot to ROM monitor mode at the next system reload or power-cycle. For more information about the configuration register, see [Changing the Configuration Register Settings](#).



### Caution

Do not set the configuration register using the **config-register 0x0** command after you have set the baud rate. To set the configuration register without affecting the baud rate, use the current configuration register setting by entering the **show ver | inc configuration** command, and then replacing the last (rightmost) number with a 0 in the configuration register command.

## SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **config-register 0x0**
4. **exit**
5. **write memory**
6. **reload**

## DETAILED STEPS

	Command or Action	Purpose
Step 1	<b>enable</b>  <b>Example:</b> Router> enable	Enables privileged EXEC mode. <ul style="list-style-type: none"> <li>• Enter your password if prompted.</li> </ul>
Step 2	<b>configure terminal</b>  <b>Example:</b> Router# configure terminal	Enters global configuration mode.
Step 3	<b>config-register 0x0</b>  <b>Example:</b> Router(config)# config-register 0x0	Changes the configuration register settings. <ul style="list-style-type: none"> <li>• The 0x0 setting forces the router to boot to the ROM monitor at the next system reload.</li> </ul>
Step 4	<b>exit</b>  <b>Example:</b> Router(config)# exit	Exits global configuration mode.



	Command or Action	Purpose
Step 5	<b>write memory</b>  <b>Example:</b> Router# write memory	Sets to boot the system image from flash memory.
Step 6	<b>reload</b>  <b>Example:</b> Router# reload  <output deleted>  rommon 1>	Reloads the operating system.  <ul style="list-style-type: none"> <li>Because of the 0x0 configuration register setting, the router boots to ROM monitor mode.</li> </ul>

## Examples

The following example shows how to set the configuration register to boot to ROM monitor mode:

```

Router>
Router> enable
Router# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)# config-register 0x0
Router(config)# exit
Router#
*Sep 23 16:01:24.351: %SYS-5-CONFIG_I: Configured from console by console
Router# write memory
Building configuration...
[OK]
Router# reload
Proceed with reload? [confirm]

*Sep 23 16:01:41.571: %SYS-5-RELOAD: Reload requested by console. Reload Reason: Reload
command.

System Bootstrap, Version 12.4(13r)T, RELEASE SOFTWARE (fc1)
Technical Support: http://www.cisco.com/techsupport
Copyright (c) 2006 by cisco Systems, Inc.

Initializing memory for ECC
.
Router platform with 262144 Kbytes of main memory
Main memory is configured to 64 bit mode with ECC enabled

Readonly ROMMON initialized
rommon 1 >

```

## What to Do Next

Proceed to the [“Displaying Commands and Command Syntax in ROM Monitor Mode \(?, help, -?\)”](#) section on page 92.

## Displaying Commands and Command Syntax in ROM Monitor Mode (? , help, -?)

This section describes how to display ROM monitor commands and command syntax options.

### SUMMARY STEPS

1. ?  
or  
**help**
2. *command -?*

### DETAILED STEPS

	Command or Action	Purpose
Step 1	? or <b>help</b>  <b>Example:</b> rommon 1 > ?  <b>Example:</b> rommon 1 > help	Displays a summary of all available ROM monitor commands.
Step 2	<i>command -?</i>  <b>Example:</b> rommon 16 > display -?	Displays syntax information for a ROM monitor command.

### Examples

This section shows the help command example:

```
rommon 10 > help
alias          set and display aliases command
boot          boot up an external process
break        set/show/clear the breakpoint
confreg      configuration register utility
cont         continue executing a downloaded image
context      display the context of a loaded image
cookie       display contents of motherboard cookie PROM in hex
dev          list the device table
dir          list files in file system
frame        print out a selected stack frame
help         monitor builtin command help
history      monitor command history
iomemset    set IO memory percent
meminfo     main memory information
repeat      repeat a monitor command
reset       system reset
rommon-pref Select ROMMON
set         display the monitor variables
showmon     display currently selected ROM monitor
```

```

stack                produce a stack trace
sync                 write monitor environment to NVRAM
sysret               print out info from last system return
tftpdnld             tftp image download
unalias              unset an alias
unset                unset a monitor variable
hwpart              Read HW resources partition
rommon 11 >

```

## Displaying Files in a File System (dir)

To display a list of the files and directories in the file system, use the **dir** command, as shown in the following examples. You might need to enter the **reset** command before viewing the flash memory directory.

```
rommon 1 > reset
```

```
System Bootstrap, Version 12.4(20100226:194457) [petechiu-v150rm7 138], DEVELOPMENT
SOFTWARE Copyright (c) 1994-2010 by cisco Systems, Inc.
```

```
Total memory size = 1024 MB
Field Upgradeable ROMMON Integrity test _____
ROM: Digitally Signed Development Software
CGR-2010/K9 platform with 1048576 Kbytes of main memory Main memory is configured to 72
bit mode with ECC enabled
```

```
Upgrade ROMMON initialized
rommon 1 >
-----
```

```
rommon 1 > dir flash:
program load complete, entry point: 0x80803000, size: 0x1b340
Directory of flash:
```

```
2      47089944  -rw- cgr2010-universalk9-mz.SPA.151-1.T
```

```
rommon 5 > dir usbflash1:
program load complete, entry point: 0x80903000, size: 0x4c440
open(): Open Error = -1
dir: cannot open device "usbflash1:"
```

## Loading a System Image (boot)

This section describes how to load a system image using the **boot** ROM monitor command.

### Prerequisites

Determine the filename and location of the system image that you want to load. Two images can be downloaded for Cisco CGR 2010: cgr2010-universalk9-mz.SPA.151-1.T and cgr2010-universalnovpnk9-mpe-mz.SPA.151-1.T.

## SUMMARY STEPS

1. **boot**  
or  
**boot flash:[filename]**  
or  
**boot filename tftpserver**  
or  
**boot [filename]**  
or  
**boot usbflash:[filename]**

## DETAILED STEPS

Command or Action	Purpose
<p><b>Step 1</b> <b>boot</b></p> <p>or</p> <p><b>boot flash:[filename]</b></p> <p>or</p> <p><b>boot filename tftpserver</b></p> <p>or</p> <p><b>boot [filename]</b></p> <p>or</p> <p><b>boot usbflash:[filename]</b></p> <p><b>Example:</b> ROMMON &gt; boot</p> <p><b>Example:</b> ROMMON &gt; boot flash:</p> <p><b>Example:</b> ROMMON &gt; boot someimage 172.16.30.40</p> <p><b>Example:</b> ROMMON &gt; boot someimage</p> <p><b>Example:</b> ROMMON &gt; boot usbflash0:someimage</p>	<p>In the following order, the examples here direct the router to:</p> <ul style="list-style-type: none"> <li>• Boot the first image in flash memory.</li> <li>• Boot the first image or a specified image in flash memory.</li> </ul> <p><b>Note</b> In IOS, <b>flash0</b> will alias onto <b>flash</b>. But Rommon does not support aliasing. So, the <b>boot</b> system command should always use <b>flash0:</b>.</p> <ul style="list-style-type: none"> <li>• Boot the specified image over the network from the specified TFTP server (hostname or IP address).</li> <li>• Boot from the boothelper image because it does not recognize the device ID. This form of the command is used to boot a specified image from a network (TFTP) server.</li> <li>• Boot the image stored on the USB flash device.</li> </ul> <p><b>Note</b> Platforms can boot from USB in ROM monitor with or without a compact flash device. It is not necessary to use a bootloader image from the compact flash device. Partitions, such as <b>usbflash0:2:image_name</b>, are not supported on USB flash drives. The <b>boot usbflash&lt;x&gt;</b> command will boot the first file on the device, if it is a valid image.</p> <p>You can override the default boothelper image setting by setting the BOOTLDR Monitor environment variable to point to another image. Any system image can be used for this purpose.</p> <ul style="list-style-type: none"> <li>• Options for the <b>boot</b> command are <b>-x</b> (load image but do not execute) and <b>-v</b> (verbose).</li> </ul>

## Examples

The following example shows how to load boot flash memory and the resulting command text output:

```
rommon 6 > boot flash:
Please reset before booting
rommon 1 > reset

System Bootstrap, Version 12.4(20100226:194457) [petechiu-v150rm7 138], DEVELOPMENT
SOFTWARE Copyright (c) 1994-2010 by cisco Systems, Inc.

Total memory size = 1024 MB
Field Upgradeable ROMMON Integrity test _____
ROM: Digitally Signed Development Software
CGR-2010/K9 platform with 1048576 Kbytes of main memory Main memory is configured to 72
bit mode with ECC enabled

Upgrade ROMMON initialized
rommon 1 >
-----

rommon 1 > boot flash:
program load complete, entry point: 0x80803000, size: 0x1b340
program load complete, entry point: 0x80803000, size: 0x1b340

IOS Image Load Test
-----
Digitally Signed Development Software
program load complete, entry point: 0x81000000, size: 0x2ce85e0
Self decompressing the image : #####]

Smart Init is enabled
smart init is sizing iomem
      TYPE      MEMORY_REQ
GRWIC Slot 0    0x00200000
GRWIC Slot 1    0x00200000
GRWIC Slot 2    0x00200000
GRWIC Slot 3    0x00200000
Onboard devices &
buffer pools    0x0228F000
-----
TOTAL:          0x02A8F000

Rounded IOMEM up to: 44Mb.
Using 4 percent iomem. [44Mb/1024Mb]

Restricted Rights Legend

Use, duplication, or disclosure by the Government is
subject to restrictions as set forth in subparagraph
(c) of the Commercial Computer Software - Restricted
Rights clause at FAR sec. 52.227-19 and subparagraph
(c) (1) (ii) of the Rights in Technical Data and Computer
Software clause at DFARS sec. 252.227-7013.

cisco Systems, Inc.
170 West Tasman Drive
San Jose, California 95134-1706
```

Cisco IOS Software, CGR2010 Software (CGR2010-UNIVERSALK9-MZ), Version 15.1-1.T  
 Copyright (c) 1986-2009 by Cisco Systems, Inc.  
 Compiled Mon 30-Nov-09 06:13 by stshen

**Note**

The following warning message does not appear if the proper CompactFlash card is installed in the ISR.

```
WARNING: Unsupported compact flash detected. Use of this card during normal
operation can impact and severely degrade performance of the system.
Please use supported high temperature compact flashcards only.
```

This product contains cryptographic features and is subject to United States and local country laws governing import, export, transfer and use. Delivery of Cisco cryptographic products does not imply third-party authority to import, export, distribute or use encryption. Importers, exporters, distributors and users are responsible for compliance with U.S. and local country laws. By using this product you agree to comply with applicable laws and regulations. If you are unable to comply with U.S. and local laws, return this product immediately.

A summary of U.S. laws governing Cisco cryptographic products may be found at:  
<http://www.cisco.com/wwl/export/crypto/tool/stqrg.html>

If you require further assistance please contact us by sending email to [export@cisco.com](mailto:export@cisco.com).

```
Cisco CISCOCGR2010/K9 (revision 1.0) with 1003520K/45056K bytes of memory.
Processor board ID FHH1338P00R
2 Gigabit Ethernet interfaces
32 Low-speed serial(sync/async) interfaces
DRAM configuration is 64 bits wide with parity enabled.
255K bytes of non-volatile configuration memory.
250880K bytes of ATA System CompactFlash 0 (Read/Write)
```

```
SETUP: new interface NV10 placed in "shutdown" state
```

Press RETURN to get started!

```
*Mar 1 00:00:03.603: %IOS_LICENSE_IMAGE_APPLICATION-6-LICENSE_LEVEL: Module nad
*Mar 1 00:00:03.695: %IOS_LICENSE_IMAGE_APPLICATION-6-LICENSE_LEVEL: Module na9
*Dec 3 18:11:39.235: %IFMGR-7-NO_IFINDEX_FILE: Unable to open nvram:/ifIndex-ty
*Dec 3 18:11:57.355: %HWIC_SERIAL-6-STARTUP: GRWIC Serial initialized
*Dec 3 18:11:59.335: %HWIC_SERIAL-6-STARTUP: GRWIC Serial initialized
*Dec 3 18:12:01.315: %HWIC_SERIAL-6-STARTUP: GRWIC Serial initialized
*Dec 3 18:12:03.291: %HWIC_SERIAL-6-STARTUP: GRWIC Serial initialized
*Dec 3 18:12:06.863: initialized snmp mgmt interface
*Dec 3 18:12:07.131: %LINK-3-UPDOWN: Interface GigabitEthernet0/0, changed stap
*Dec 3 18:12:07.131: %LINK-3-UPDOWN: Interface GigabitEthernet0/1, changed stap
*Dec 3 18:12:07.131: %LINK-3-UPDOWN: Interface Serial0/0/0, changed state to dn
*Dec 3 18:12:07.131: %LINK-3-UPDOWN: Interface Serial0/0/1, changed state to up
*Dec 3 18:12:07.135: %LINK-3-UPDOWN: Interface Serial0/0/2, changed state to dn
*Dec 3 18:12:07.135: %LINK-3-UPDOWN: Interface Serial0/0/3, changed state to dn
*Dec 3 18:12:07.135: %LINK-3-UPDOWN: Interface Serial0/0/4, changed state to up
*Dec 3 18:12:07.135: %LINK-3-UPDOWN: Interface Serial0/0/5, changed state to dn
*Dec 3 18:12:07.135: %LINK-3-UPDOWN: Interface Serial0/0/6, changed state to dn
*Dec 3 18:12:07.135: %LINK-3-UPDOWN: Interface Serial0/0/7, changed state to dn
*Dec 3 18:12:07.135: %LINK-3-UPDOWN: Interface Serial0/1/0, changed state to up
*Dec 3 18:12:07.135: %LINK-3-UPDOWN: Interface Serial0/1/1, changed state to up
*Dec 3 18:12:07.135: %LINK-3-UPDOWN: Interface Serial0/1/2, changed state to dn
*Dec 3 18:12:07.135: %LINK-3-UPDOWN: Interface Serial0/1/3, changed state to dn
```

```

*Dec 3 18:12:07.135: %LINK-3-UPDOWN: Interface Serial0/1/4, changed state to dn
*Dec 3 18:12:07.135: %LINK-3-UPDOWN: Interface Serial0/1/5, changed state to dn
*Dec 3 18:12:07.135: %LINK-3-UPDOWN: Interface Serial0/1/6, changed state to dn
*Dec 3 18:12:07.135: %LINK-3-UPDOWN: Interface Serial0/1/7, changed state to dn
*Dec 3 18:12:07.135: %LINK-3-UPDOWN: Interface Serial0/2/0, changed state to dn
*Dec 3 18:12:07.135: %LINK-3-UPDOWN: Interface Serial0/2/1, changed state to dn
*Dec 3 18:12:07.135: %LINK-3-UPDOWN: Interface Serial0/2/2, changed state to dn
*Dec 3 18:12:07.135: %LINK-3-UPDOWN: Interface Serial0/2/3, changed state to dn
*Dec 3 18:12:07.135: %LINK-3-UPDOWN: Interface Serial0/2/4, changed state to dn
*Dec 3 18:12:07.135: %LINK-3-UPDOWN: Interface Serial0/2/5, changed state to dn
*Dec 3 18:12:07.135: %LINK-3-UPDOWN: Interface Serial0/2/6, changed state to dn
*Dec 3 18:12:07.135: %LINK-3-UPDOWN: Interface Serial0/2/7, changed state to dn
*Dec 3 18:12:07.135: %LINK-3-UPDOWN: Interface Serial0/3/0, changed state to up
*Dec 3 18:12:07.135: %LINK-3-UPDOWN: Interface Serial0/3/1, changed state to up
*Dec 3 18:12:07.135: %LINK-3-UPDOWN: Interface Serial0/3/2, changed state to dn
*Dec 3 18:12:07.135: %LINK-3-UPDOWN: Interface Serial0/3/3, changed state to up
*Dec 3 18:12:07.135: %LINK-3-UPDOWN: Interface Serial0/3/4, changed state to dn
*Dec 3 18:12:07.139: %LINK-3-UPDOWN: Interface Serial0/3/5, changed state to dn
*Dec 3 18:12:07.139: %LINK-3-UPDOWN: Interface Serial0/3/6, changed state to dn
*Dec 3 18:12:07.139: %LINK-3-UPDOWN: Interface Serial0/3/7, changed state to dn
*Dec 3 18:12:08.291: %LINEPROTO-5-UPDOWN: Line protocol on Interface GigabitEtp
*Dec 3 18:12:08.291: %LINEPROTO-5-UPDOWN: Line protocol on Interface GigabitEtp
*Dec 3 18:12:08.291: %LINEPROTO-5-UPDOWN: Line protocol on Interface Serial0/0n
*Dec 3 18:12:08.295: %LINEPROTO-5-UPDOWN: Line protocol on Interface Serial0/0p
*Dec 3 18:12:08.295: %LINEPROTO-5-UPDOWN: Line protocol on Interface Serial0/0n
*Dec 3 18:12:08.295: %LINEPROTO-5-UPDOWN: Line protocol on Interface Serial0/0n
*Dec 3 18:12:08.295: %LINEPROTO-5-UPDOWN: Line protocol on Interface Serial0/0p
*Dec 3 18:12:08.295: %LINEPROTO-5-UPDOWN: Line protocol on Interface Serial0/0n
*Dec 3 18:12:08.295: %LINEPROTO-5-UPDOWN: Line protocol on Interface Serial0/0n
*Dec 3 18:12:08.295: %LINEPROTO-5-UPDOWN: Line protocol on Interface Serial0/0n
*Dec 4 10:12:09.435 PST: %SYS-6-CLOCKUPDATE: System clock has been updated fro.
*Dec 4 10:12:11.187 PST: %LINEPROTO-5-UPDOWN: Line protocol on Interface NVI0,p
*Dec 4 10:12:11.455 PST: %LINK-5-CHANGED: Interface Serial0/0/1, changed staten
*Dec 4 10:12:11.455 PST: %LINK-5-CHANGED: Interface Serial0/0/2, changed staten
*Dec 4 10:12:11.455 PST: %LINK-5-CHANGED: Interface Serial0/0/3, changed staten
*Dec 4 10:12:11.455 PST: %LINK-5-CHANGED: Interface Serial0/0/4, changed staten
*Dec 4 10:12:11.455 PST: %LINK-5-CHANGED: Interface Serial0/0/5, changed staten
*Dec 4 10:12:11.455 PST: %LINK-5-CHANGED: Interface Serial0/0/6, changed staten
*Dec 4 10:12:11.455 PST: %LINK-5-CHANGED: Interface Serial0/0/7, changed staten
*Dec 4 10:12:11.455 PST: %LINK-5-CHANGED: Interface Serial0/1/1, changed staten
*Dec 4 10:12:11.455 PST: %LINK-5-CHANGED: Interface Serial0/1/2, changed staten
*Dec 4 10:12:12.455 PST: %LINEPROTO-5-UPDOWN: Line protocol on Interface Serian
*Dec 4 10:12:12.455 PST: %LINEPROTO-5-UPDOWN: Line protocol on Interface Serian
*Dec 4 10:12:12.455 PST: %LINEPROTO-5-UPDOWN: Line protocol on Interface Serian
*Dec 4 10:12:12.879 PST: %LINEPROTO-5-UPDOWN: Line protocol on Interface Gigabn
*Dec 4 10:12:13.079 PST: %LINEPROTO-5-UPDOWN: Line protocol on Interface Gigabn
*Dec 4 10:12:16.291 PST: %LINK-3-UPDOWN: Interface GigabitEthernet0/0, changeddn
*Dec 4 10:12:16.311 PST: %LINK-3-UPDOWN: Interface GigabitEthernet0/1, changeddn
*Dec 4 10:12:17.283 PST: %SYS-5-CONFIG_I: Configured from memory by console
*Dec 4 10:12:17.819 PST: %SYS-5-RESTART: System restarted --
Cisco IOS Software, CGR2010 Software (CGR2010-UNIVERSALK9-MZ), Version 15.1-1.T
Copyright (c) 1986-2009 by Cisco Systems, Inc.
Compiled Mon 30-Nov-09 06:13 by stshen
*Dec 4 10:12:17.827 PST: %SNMP-5-COLDSTART: SNMP agent on host uut is undergoit
*Dec 4 10:12:19.087 PST: %SSH-5-ENABLED: SSH 2.0 has been enabled
*Dec 4 10:12:19.223 PST: %LINK-5-CHANGED: Interface Serial0/2/1, changed staten
*Dec 4 10:12:19.223 PST: %LINK-5-CHANGED: Interface Serial0/2/2, changed staten
*Dec 4 10:12:19.347 PST: %LINK-5-CHANGED: Interface Serial0/2/3, changed staten
*Dec 4 10:12:19.347 PST: %LINK-5-CHANGED: Interface Serial0/2/4, changed staten
*Dec 4 10:12:19.347 PST: %LINK-5-CHANGED: Interface Serial0/2/5, changed staten
*Dec 4 10:12:19.347 PST: %LINK-5-CHANGED: Interface Serial0/2/6, changed staten
*Dec 4 10:12:19.347 PST: %LINK-5-CHANGED: Interface Serial0/2/7, changed staten
*Dec 4 10:12:19.347 PST: %LINK-5-CHANGED: Interface Serial0/3/2, changed staten
*Dec 4 10:12:19.347 PST: %LINK-5-CHANGED: Interface Serial0/3/3, changed staten

```

```
*Dec  4 10:12:19.347 PST: %LINK-5-CHANGED: Interface Serial0/3/4, changed staten
*Dec  4 10:12:20.347 PST: %LINEPROTO-5-UPDOWN: Line protocol on Interface Serian
*Dec  4 10:12:20.347 PST: %LINEPROTO-5-UPDOWN: Line protocol on Interface NVI0,n
Router>
```

## What to Do Next

If you want to configure the router to load a specified image at the next system reload or power-cycle, see the following documents:

- [Booting Commands](#)” chapter of *Cisco IOS Configuration Fundamentals Command Reference*
- *Cisco IOS Configuration Fundamentals and Network Management Configuration Guide*

## Modifying the Configuration Register

This section describes how to modify the configuration register using the **confreg** ROM monitor command. You can also modify the configuration register setting from the Cisco IOS CLI using the **config-register** command in global configuration mode.



### Caution

Do not set the configuration register using the **config-register 0x0** command after setting the baud rate. To set the configuration register without affecting the baud rate, use the current configuration register setting by entering the **show ver | inc configuration** command and then replacing the last (rightmost) number with a 0 in the configuration register command.

## Restrictions

The modified configuration register value is automatically written into NVRAM, but the new value does not take effect until you reset or power-cycle the router.

## SUMMARY STEPS

1. **confreg** *[value]*

## DETAILED STEPS

	Command or Action	Purpose
Step 1	<b>confreg</b> <i>[value]</i>	Changes the configuration register settings while in ROM monitor mode. <ul style="list-style-type: none"> <li>• Optionally, enter the new hexadecimal value for the configuration register. The value range is from 0x0 to 0xFFFF.</li> <li>• If you do not enter the value, the router prompts for each bit of the 16-bit configuration register.</li> </ul>
	<b>Example:</b> rommon > confreg 0x2102	

## Examples

In the following example, the configuration register is set to boot the system image from flash memory:



```
rommon 3 > confreg 0x2102
```

In the following example, no value is entered; therefore, the system prompts for each bit in the register:

```
rommon 4 > confreg
```

```

      Configuration Summary
(Virtual Configuration Register: 0x2102)
enabled are:
load rom after netboot fails
console baud: 9600
boot: image specified by the boot system commands
      or default to: cisco2-CISCOGR2010/K9

do you wish to change the configuration? y/n [n]: y
enable "diagnostic mode"? y/n [n]: y
enable "use net in IP bcast address"? y/n [n]: y
disable "load rom after netboot fails"? y/n [n]: y
enable "use all zero broadcast"? y/n [n]: y
enable "break/abort has effect"? y/n [n]: y
enable "ignore system config info"? y/n [n]: y
change console baud rate? y/n [n]: y
0=9600, 1=4800, 2=1200, 3=2400, 4=19200, 5=38400, 6=57600, 7=115200
enter rate [0]: 0
change the boot characteristics? y/n [n]: y
enter to boot:
 0 = ROM Monitor
 1 = the boot helper image
 2-15 = boot system
[2]: 0

      Configuration Summary
(Virtual Configuration Register: 0xc440)
enabled are:
diagnostic mode
use net in IP bcast address
use all zero broadcast
break/abort has effect
ignore system config info
console baud: 9600
boot: the ROM Monitor

do you wish to change the configuration? y/n [n]: <cr>
You must reset or power cycle for new config to take effect
rommon 5 >
```

## Obtaining Information on USB Flash Devices

This section describes how to obtain information on USB devices that are installed in the router. For instructions on booting from a USB flash device, see the [“Loading a System Image \(boot\)”](#) section on page 93.

### SUMMARY STEPS

1. **dir usbflash [x]:**
2. **dev**

## DETAILED STEPS

	Command or Action	Purpose
Step 1	<b>dir usbflash [x]:</b>  <b>Example:</b> rommon > dir usbflash1:	Displays the contents of the USB flash device, including directories, files, permissions, and sizes. <ul style="list-style-type: none"> <li>• <b>0</b>—USB flash device inserted in port 0</li> <li>• <b>1</b>—USB flash device inserted in port 1</li> </ul>
Step 2	<b>dev</b>  <b>Example:</b> ROMMON > dev	Shows the targeted USB flash devices that are inserted in the router and the valid device names that may or may not be currently inserted.

## Examples

## Sample Output for the dir usbFlash Command

In some cases, you need to use the reset command first.

```
rommon 8 > dir usbflash:
Please reset before executing this command
rommon 9 > reset

System Bootstrap, Version 12.4(20100226:194457) [petechiu-v150rm7 138], DEVELOPMENT
SOFTWARE Copyright (c) 1994-2010 by cisco Systems, Inc.

Total memory size = 1024 MB
Field Upgradeable ROMMON Integrity test _____
ROM: Digitally Signed Development Software
CGR-2010/K9 platform with 1048576 Kbytes of main memory Main memory is configured to 72
bit mode with ECC enabled

Upgrade ROMMON initialized
rommon 1 >
-----

Upgrade ROMMON initialized
rommon 1 > dir usbflash:
program load complete, entry point: 0x80903000, size: 0x4c440
open(): Open Error = -1
dir: cannot open device "usbflash:"
```

**Note**

The Cisco CGR 2010 in this example does not have USB flash.

## Modifying the I/O Memory (iomemset)

This section describes how to modify the I/O memory percentage setting using the memory-size **iomemset** command.

**Note**

Use the **iomemset** command only if it is needed for temporarily setting the I/O memory percentage from ROM monitor mode. Using this command improperly can adversely affect the functioning of the router.

The Cisco IOS software can override the I/O memory percentage if the **memory-size iomem** command is set in the NVRAM configuration. If the Cisco IOS command is present in the NVRAM configuration, the I/O memory percentage set in the ROM monitor with the **iomemset** command is used only the first time the router is booted up. Subsequent reloads use the I/O memory percentage set using the **memory-size iomem** command that is saved in the NVRAM configuration.

If you need to set the router I/O memory permanently using a manual method, use the **memory-size iomem** Cisco IOS command. If you set the I/O memory percentage from the Cisco IOS software, you must restart the router for I/O memory to be properly set.

**SUMMARY STEPS**

1. **iomemset** *i/o-memory percentage*

**DETAILED STEPS**

	Command or Action	Purpose
Step 1	<b>iomemset</b> <i>i/o-memory percentage</i>  <b>Example:</b> rommon> iomemset 15	<ul style="list-style-type: none"> <li>• Reallocates the percentage of DRAM used for I/O memory and processor memory.</li> </ul>

**Examples**

In the following example, the percentage of DRAM used for I/O memory is set to 15:

```
rommon 2 > iomemset
usage: iomemset [smartinit | 5 | 10 | 15 | 20 | 25 | 30 | 40 | 50 ]
rommon 3 >
rommon 3 > iomemset 15
```

```
Invoking this command will change the io memory percent
*****WARNING:IOS may not keep this value*****
Do you wish to continue? y/n: [n]: y
```

```
rommon 2 > meminfo
-----
Current Memory configuration is:
On-board: Size = 1024 MB: Start Phy Addr = 0x00000000_00000000
-----
Main memory size: 1024 MB in 72 bit mode.
Available main memory starts at 0x81000000, size 1032192KB
Smart Init is enabled.
NVRAM size: 256KB

Manufacturer's JEDEC ID code:
On-board:
rommon 3 >
```



```
CGR-2010/K9 platform with 1048576 Kbytes of main memory Main memory is configured to 72
bit mode with ECC enabled
```

```
Upgrade ROMMON initialized
rommon 1 >
```

## Downloading the System Image (tftpdnld)

This section describes how to download a Cisco IOS software image from a remote TFTP server to the router flash memory using the **tftpdnld** command in ROM monitor mode.



### Caution

Use the **tftpdnld** command only for disaster recovery because it can erase all existing data in flash memory before it downloads a new software image to the router.

Before you can enter the **tftpdnld** command, you must set the ROM monitor environment variables.

## Prerequisites

Connect the TFTP server to a fixed network port on your router.

## Restrictions

- LAN ports on network modules or interface cards are not active in ROM monitor mode. Therefore, only a fixed port on your router can be used for a TFTP download. Use a fixed Ethernet port on the router that is either of the two Gigabit Ethernet ports on Cisco routers with those ports.
- You can only download files to the router. You cannot use the **tftpdnld** command to retrieve files from the router.

## SUMMARY STEPS

1. **IP\_ADDRESS**=*ip\_address*
2. **IP\_SUBNET\_MASK**=*ip\_address*
3. **DEFAULT\_GATEWAY**=*ip\_address*
4. **TFTP\_SERVER**=*ip\_address*
5. **TFTP\_FILE**=[*directory-path*]/*filename*
6. **FE\_PORT**=[0 | 1]
7. **FE\_SPEED\_MODE**=[0 | 1 | 2 | 3 | 4 | 5]
8. **GE\_PORT**=[0 | 1]
9. **GE\_SPEED\_MODE**=[0 | 1 | 2 | 3 | 4 | 5]
10. **MEDIA\_TYPE**=[0 | 1]
11. **TFTP\_CHECKSUM**=[0 | 1]
12. **TFTP\_DESTINATION**=[flash: | usbflash0: | usbflash1:]
13. **TFTP\_MACADDR**=*MAC\_address*

14. `TFTP_RETRY_COUNT=retry_times`
15. `TFTP_TIMEOUT=time`
16. `TFTP_VERBOSE=setting`
17. `set`
18. `tftpdnld [-hr]`
19. `y`

## DETAILED STEPS

	Command or Action	Purpose
Step 1	<code>IP_ADDRESS=ip_address</code>  <b>Example:</b> <code>rommon &gt; IP_ADDRESS=172.16.23.32</code>	Sets the IP address of the router.
Step 2	<code>IP_SUBNET_MASK=ip_address</code>  <b>Example:</b> <code>rommon &gt; IP_SUBNET_MASK=255.255.255.224</code>	Sets the subnet mask of the router.
Step 3	<code>DEFAULT_GATEWAY=ip_address</code>  <b>Example:</b> <code>rommon &gt; DEFAULT_GATEWAY=172.16.23.40</code>	Sets the default gateway of the router.
Step 4	<code>TFTP_SERVER=ip_address</code>  <b>Example:</b> <code>rommon &gt; TFTP_SERVER=172.16.23.33</code>	Sets the TFTP server from which the software will be downloaded.
Step 5	<code>TFTP_FILE=[directory-path/]filename</code>  <b>Example:</b> <code>rommon &gt; TFTP_FILE=archive/rel22/c2801-i-mz</code>	Sets the name and location of the file that will be downloaded to the router.
Step 6	<code>FE_PORT=[0   1]</code>  <b>Example:</b> <code>rommon &gt; FE_PORT=0</code>	(Optional) Sets the input port to use one of the Fast Ethernet ports.
Step 7	<code>FE_SPEED_MODE=[0   1   2   3   4]</code>  <b>Example:</b> <code>rommon &gt; FE_SPEED_MODE=3</code>	(Optional) Sets the Fast Ethernet port speed mode, with these options: <ul style="list-style-type: none"> <li>• 0—10 Mbps, half-duplex</li> <li>• 1—10 Mbps, full-duplex</li> <li>• 2—100 Mbps, half-duplex</li> <li>• 3—100 Mbps, full-duplex</li> <li>• 4—Automatic selection (default)</li> </ul>

	Command or Action	Purpose
Step 8	<b>GE_PORT</b> =[0   1]  <b>Example:</b> rommon > GE_PORT=0	(Optional) Sets the input port to use one of the Gigabit Ethernet ports.
Step 9	<b>GE_SPEED_MODE</b> =[0   1   2   3   4   5]  <b>Example:</b> rommon > GE_SPEED_MODE=3	(Optional) Sets the Gigabit Ethernet port speed mode, with these options: <ul style="list-style-type: none"> <li>• <b>0</b>—10 Mbps, half-duplex</li> <li>• <b>1</b>—10 Mbps, full-duplex</li> <li>• <b>2</b>—100 Mbps, half-duplex</li> <li>• <b>3</b>—100 Mbps, full-duplex</li> <li>• <b>4</b>—1 Gbps, full-duplex</li> <li>• <b>5</b>—Automatic selection (default)</li> </ul>
Step 10	<b>MEDIA_TYPE</b> =[0   1]  <b>Example:</b> rommon > MEDIA_TYPE=1	(Optional) Sets the Gigabit Ethernet connection media type, RJ-45 (0) or SFP (1). Small form-factor pluggable (SFP) mode is applicable only if GE_PORT=0 (gig 0/0); RJ-45 mode is available on both gig 0/0 and gig 0/1 (GE_PORT = 0 or 1).
Step 11	<b>TFTP_CHECKSUM</b> =[0   1]  <b>Example:</b> rommon > TFTP_CHECKSUM=0	(Optional) Determines whether the router performs a checksum test on the downloaded image. <ul style="list-style-type: none"> <li>• <b>1</b>—Checksum test is performed (default).</li> <li>• <b>0</b>—No checksum test is performed.</li> </ul>
Step 12	<b>TFTP_DESTINATION</b> =[flash:   usbflash0:   usbflash1:]  <b>Example:</b> rommon > TFTP_DESTINATION=usbflash0:	(Optional) Designates the targeted flash device as compact flash or USB flash. <ul style="list-style-type: none"> <li>• <b>flash:</b>—Compact flash device (default).</li> <li>• <b>usbflash0:</b>—USB flash device inserted in port 0</li> <li>• <b>usbflash1:</b>—USB flash device inserted in port 1</li> </ul>
Step 13	<b>TFTP_MACADDR</b> = <i>MAC_address</i>  <b>Example:</b> rommon > TFTP_MACADDR=000e.8335.f360	(Optional) Sets the Media Access Controller (MAC) address for this router.
Step 14	<b>TFTP_RETRY_COUNT</b> = <i>retry_times</i>  <b>Example:</b> rommon > TFTP_RETRY_COUNT=10	(Optional) Sets the number of times that the router attempts Address Resolution Protocol (ARP) and TFTP download. The default is 7.
Step 15	<b>TFTP_TIMEOUT</b> = <i>time</i>  <b>Example:</b> TFTP_TIMEOUT=1800	(Optional) Sets the amount of time, in seconds, before the download process times out. The default is 2400 seconds (40 minutes).

	Command or Action	Purpose
Step 16	<b>TFTP_VERBOSE</b> = <i>setting</i>  <b>Example:</b> rommon > TFTP_VERBOSE=2	(Optional) Configures how the router displays file download progress, with these options: <ul style="list-style-type: none"> <li>• <b>0</b>—No progress is displayed.</li> <li>• <b>1</b>—Exclamation points (!!!) are displayed to indicate file download progress. This is the default setting.</li> <li>• <b>2</b>—Detailed progress is displayed during the file download process; for example: <pre> Initializing interface. Interface link state up. ARPing for 1.4.0.1 ARP reply for 1.4.0.1 received. MAC address 00:00:0c:07:ac:01 </pre> </li> </ul>
Step 17	<b>set</b>  <b>Example:</b> rommon > set	Displays the ROM monitor environment variables. Verify that you correctly configured the ROM monitor environment variables.
Step 18	<b>tftpdnld</b> [-h] [-r]  <b>Example:</b> rommon > tftpdnld	Downloads the system image specified by the ROM monitor environment variables. <ul style="list-style-type: none"> <li>• Entering <b>-h</b> displays command syntax help text.</li> <li>• Entering <b>-r</b> downloads and boots the new software but does not save the software to flash memory.</li> <li>• Using no option (that is, using neither <b>-h</b> nor <b>-r</b>) downloads the specified image and saves it in flash memory.</li> </ul>
Step 19	<b>y</b>  <b>Example:</b> Do you wish to continue? y/n: [n]: y	Confirms that you want to continue with the TFTP download.

## Examples

### Sample Output for Recovering the System Image (tftpdnld)

```

rommon 16 > IP_ADDRESS=171.68.171.0
rommon 17 > IP_SUBNET_MASK=255.255.254.0
rommon 18 > DEFAULT_GATEWAY=171.68.170.3
rommon 19 > TFTP_SERVER=171.69.1.129
rommon 20 > TFTP_FILE=c2801-is-mz.113-2.0.3.Q
rommon 21 > tftpdnld

IP_ADDRESS: 171.68.171.0
IP_SUBNET_MASK: 255.255.254.0
DEFAULT_GATEWAY: 171.68.170.3
TFTP_SERVER: 171.69.1.129
TFTP_FILE: c2801-is-mz.113-2.0.3.Q

```

Invoke this command for disaster recovery only.  
WARNING: all existing data in all partitions on flash will be lost!  
Do you wish to continue? y/n: [n]: **y**



```

Receiving c2801-is-mz.113-2.0.3.Q from 171.69.1.129 !!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!
File reception completed.
Copying file c2801-is-mz.113-2.0.3.Q to flash.
Erasing flash at 0x607c0000
program flash location 0x60440000
rommon 22 >

```

### Sample Output for the set ROM Monitor Command

```

rommon 3 > set
PS1=rommon ! >
IP_SUBNET_MASK=255.255.0.0
TFTP_SERVER=223.255.254.254
DEFAULT_GATEWAY=15.1.0.1
IP_ADDRESS=15.1.28.21
BOOT=
GE_PORT=0
RTC_STAT=0
WARM_REBOOT=FALSE
TFTP_FILE=jruiz/cgr2010-universalk9-mz.SSA.151-0.17.T
LICENSE_BOOT_LEVEL=datak9,datak9:cgr2010;
?=1
CRASHINFO=flash:crashinfo_20070725-212015
RET_2_RTS=09:38:37 PST Fri Dec 4 2009
BST=0
RET_2_RCALTS=
RANDOM_NUM=1201472235

```

## What to Do Next

If you want to configure the router to load a specified image at the next system reload or power-cycle, see the “[Loading and Managing System Images](#)” section in *Cisco IOS Configuration Fundamentals Command Reference*.

## Troubleshooting Crashes and Hangs (stack, context, frame, sysret, meminfo)

This section lists and describes some ROM monitor commands that can be used to troubleshoot router crashes and hangs.

Most ROM monitor **debug** commands are functional only when the router crashes or hangs. If you enter a **debug** command when crash information is not available, the following error message appears:

```
"xxx: kernel context state is invalid, can not proceed."
```

The ROM monitor commands in this section are all optional and can be entered in any order.

## Router Crashes

A router or system *crash* is a situation in which the system detects an unrecoverable error and restarts itself. The errors that cause crashes are typically detected by processor hardware, which automatically branches to special error-handling code in the ROM monitor. The ROM monitor identifies the error, prints a message, saves information about the failure, and restarts the system. For detailed information about troubleshooting crashes, see *Troubleshooting Router Crashes* and *Understanding Software-forced Crashes*.

## Router Hangs

A router or system *hang* is a situation in which the system does not respond to input at the console port or to queries, such as Telnet and SNMP, sent from the network.

Router hangs occur when:

- The console does not respond
- Traffic does not pass through the router

Router hangs are discussed in detail in [Troubleshooting Router Hangs](#).

## ROM Monitor Console Communication Failure

Under certain configuration situations where there is improper configuration, it can be impossible to establish a console connection with the router because of a speed mismatch or other incompatibility. The most obvious symptom is a set of erroneous characters in the console display.

If a ROM monitor failure of this type occurs, you may need to change a jumper setting on the motherboard so that the router can reboot for troubleshooting. Procedures for accessing the motherboard and jumper locations are described in the installation of internal components section of the hardware installation document for your router.

The jumper to be changed is DUART DFLT, which sets the console connection data baud rate to 9600, regardless of user configuration. The jumper forces the data rate to an acceptable value.

## Restrictions

Do not manually reload or power-cycle the router unless reloading or power cycling is required for troubleshooting a router crash. System reload or power-cycle can cause important information that is needed for determining the root cause of the problem to be lost.

## SUMMARY STEPS

1. **stack**  
or  
**k**
2. **context**
3. **frame** [*number*]
4. **sysret**
5. **meminfo**

## DETAILED STEPS

	Command or Action	Purpose
Step 1	<p><b>stack</b></p> <p>or</p> <p><b>k</b></p> <p><b>Example:</b> rommon &gt; stack</p>	<p>(Optional) Obtains a stack trace.</p> <ul style="list-style-type: none"> <li>For detailed information on how to effectively use this command in ROM monitor mode, see <a href="#">Troubleshooting Router Hangs</a>.</li> </ul>
Step 2	<p><b>context</b></p> <p><b>Example:</b> rommon &gt; context</p>	<p>(Optional) Displays the CPU context at the time of the fault.</p> <ul style="list-style-type: none"> <li>If it is available, the context from kernel mode and process mode of a loaded image is displayed.</li> </ul>
Step 3	<p><b>frame</b> [number]</p> <p><b>Example:</b> rommon &gt; frame 4</p>	<p>(Optional) Displays an entire individual stack frame.</p> <ul style="list-style-type: none"> <li>The default is 0 (zero), which is the most recent frame.</li> </ul>
Step 4	<p><b>sysret</b></p> <p><b>Example:</b> rommon &gt; sysret</p>	<p>(Optional) Displays return information from the last booted system image.</p> <ul style="list-style-type: none"> <li>The return information includes the reason for terminating the image, a stack dump of up to eight frames, and, if an exception is involved, the address at which the exception occurred.</li> </ul>
Step 5	<p><b>meminfo</b> [-1]</p> <p><b>Example:</b> rommon &gt; meminfo</p>	<p>(Optional) Displays memory information, including:</p> <ul style="list-style-type: none"> <li>Main memory size, starting address, and available range</li> <li>Packet memory size</li> <li>NVRAM size</li> </ul> <p>Alternatively, using the <b>meminfo -l</b> command provides information on supported DRAM configurations for the router.</p>

## Examples

This section provides the following examples:

- [Sample Output for the stack ROM Monitor Command, page 109](#)
- [Sample Output for the context ROM Monitor Command, page 110](#)
- [Sample Output for the frame ROM Monitor Command, page 111](#)
- [Sample Output for the sysret ROM Monitor Command, page 111](#)
- [Sample Output for the meminfo ROM Monitor Command, page 111](#)

**Sample Output for the stack ROM Monitor Command**

```
rommon 6> stack
```

## Kernel Level Stack Trace:

```
Initial SP = 0x642190b8, Initial PC = 0x607a0d44, RA = 0x61d839f8
Frame 0 : FP= 0x642190b8, PC= 0x607a0d44, 0 bytes
Frame 1 : FP= 0x642190b8, PC= 0x61d839f8, 24 bytes
Frame 2 : FP= 0x642190d0, PC= 0x6079b6c4, 40 bytes
Frame 3 : FP= 0x642190f8, PC= 0x6079ff70, 32 bytes
Frame 4 : FP= 0x64219118, PC= 0x6079eaec, 0 bytes
```

## Process Level Stack Trace:

```
Initial SP = 0x64049cb0, Initial PC = 0x60e3b7f4, RA = 0x60e36fa8
Frame 0 : FP= 0x64049cb0, PC= 0x60e3b7f4, 24 bytes
Frame 1 : FP= 0x64049cc8, PC= 0x60e36fa8, 24 bytes
Frame 2 : FP= 0x64049ce0, PC= 0x607a5800, 432 bytes
Frame 3 : FP= 0x64049e90, PC= 0x607a8988, 56 bytes
Frame 4 : FP= 0x64049ec8, PC= 0x64049f14, 0 bytes
```

## Sample Output for the context ROM Monitor Command

```
rommon 7> context
```

## Kernel Level Context:

Reg	MSW	LSW	Reg	MSW	LSW
zero	: 00000000	00000000	s0	: 00000000	34018001
AT	: 00000000	24100000	s1	: 00000000	00000001
v0	: 00000000	00000003	s2	: 00000000	00000003
v1	: 00000000	00000000	s3	: 00000000	00000000
a0	: 00000000	0000002b	s4	: 00000000	64219118
a1	: 00000000	00000003	s5	: 00000000	62ad0000
a2	: 00000000	00000000	s6	: 00000000	63e10000
a3	: 00000000	64219118	s7	: 00000000	63e10000
t0	: 00000000	00070808	t8	: ffffffff	e7400884
t1	: 00000000	00000000	t9	: 00000000	00000000
t2	: 00000000	63e10000	k0	: 00000000	00000000
t3	: 00000000	34018001	k1	: 00000000	63ab871c
t4	: ffffffff	ffff80fd	gp	: 00000000	63c1c2d8
t5	: ffffffff	fffffffe	sp	: 00000000	642190b8
t6	: 00000000	3401ff02	s8	: 00000000	6429274c
t7	: 00000000	6408d464	ra	: 00000000	61d839f8
HI	: ffffffff	e57fce22	LO	: ffffffff	ea545255
EPC	: 00000000	607a0d44	ErrPC	: ffffffff	bfc05f2c
Stat	: 34018002		Cause	: 00000020	

## Process Level Context:

Reg	MSW	LSW	Reg	MSW	LSW
zero	: 00000000	00000000	s0	: 00000000	6401a6f4
AT	: 00000000	63e10000	s1	: 00000000	00000000
v0	: 00000000	00000000	s2	: 00000000	64049cf0
v1	: 00000000	00000440	s3	: 00000000	63360000
a0	: 00000000	00000000	s4	: 00000000	63360000
a1	: 00000000	00070804	s5	: 00000000	62ad0000
a2	: 00000000	00000000	s6	: 00000000	63e10000
a3	: 00000000	00000000	s7	: 00000000	63e10000
t0	: 00000000	00000000	t8	: ffffffff	e7400884
t1	: 00000000	64928378	t9	: 00000000	00000000
t2	: 00000000	00000001	k0	: 00000000	644822e8
t3	: ffffffff	ffff00ff	k1	: 00000000	61d86d84
t4	: 00000000	6079eee0	gp	: 00000000	63c1c2d8
t5	: 00000000	00000001	sp	: 00000000	64049cb0
t6	: 00000000	00000000	s8	: 00000000	6429274c
t7	: 00000000	6408d464	ra	: 00000000	60e36fa8
HI	: ffffffff	e57fce22	LO	: ffffffff	ea545255
EPC	: 00000000	60e3b7f4	ErrPC	: ffffffff	fffffff
Stat	: 3401ff03		Cause	: ffffffff	

**Sample Output for the frame ROM Monitor Command**

```
rommon 6 > frame 2
Stack Frame 2, SP = 0x642190d0, Size = 40 bytes
[0x642190d0 : sp + 0x000] = 0xffffffff
[0x642190d4 : sp + 0x004] = 0xbfc05f2c
[0x642190d8 : sp + 0x008] = 0xffffffff
[0x642190dc : sp + 0x00c] = 0xffffffff
[0x642190e0 : sp + 0x010] = 0x6401a6f4
[0x642190e4 : sp + 0x014] = 0x00000000
[0x642190e8 : sp + 0x018] = 0x64049cf0
[0x642190ec : sp + 0x01c] = 0x63360000
[0x642190f0 : sp + 0x020] = 0x63360000
[0x642190f4 : sp + 0x024] = 0x6079ff70
```

**Sample Output for the sysret ROM Monitor Command**

```
rommon 8> sysret
System Return Info:
count: 19, reason: user break
pc:0x801111b0, error address: 0x801111b0
Stack Trace:
FP: 0x80005ea8, PC: 0x801111b0
FP: 0x80005eb4, PC: 0x80113694
FP: 0x80005f74, PC: 0x8010eb44
FP: 0x80005f9c, PC: 0x80008118
FP: 0x80005fac, PC: 0x80008064
FP: 0x80005fc4, PC: 0xfff03d70
FP: 0x80005ffc, PC: 0x00000000
FP: 0x00000000, PC: 0x00000000
```

**Sample Output for the meminfo ROM Monitor Command**

```
rommon 2 > meminfo
-----
Current Memory configuration is:
On-board: Size = 1024 MB: Start Phy Addr = 0x00000000_00000000
-----
Main memory size: 1024 MB in 72 bit mode.
Available main memory starts at 0x81000000, size 1032192KB
Smart Init is enabled.
NVRAM size: 256KB

Manufacturer's JEDEC ID code:
On-board:
rommon 3 >
```

You can also use the **meminfo -l** command to show the supported DRAM configurations for the router. The following is sample output for the command:

```
rommon 4 > meminfo -l
The following memory configs are supported:
-----
On-board
-----
1024 MB
rommon 3 >
```

## Troubleshooting Tips

See the following documents:

- [Troubleshooting Router Crashes](#)
- [Understanding Software-forced Crashes](#)
- [Troubleshooting Router Hangs](#)

## Exiting ROM Monitor Mode

This section describes how to exit ROM monitor mode and enter the Cisco IOS command-line interface (CLI). The method that you use to exit ROM monitor mode depends on how your router entered ROM monitor mode:

- If you reload the router and enter the Break key sequence to enter ROM monitor mode when the router would otherwise have booted the system image, you can exit ROM monitor mode by doing either of the following:
  - Enter the **i** command or the **reset** command, which restarts the booting process and loads the system image.
  - Enter the **cont** command, which continues the booting process and loads the system image.
- If your router entered ROM monitor mode because it could not locate and load the system image, perform the steps in the following procedure.

### SUMMARY STEPS

1. **dir flash:** *[directory]*
2. **boot flash:** *[directory] [filename]*  
or  
**boot** *filename tftpserver*  
or  
**boot** *[filename]*

## DETAILED STEPS

	Command or Action	Purpose
Step 1	<pre>dir flash:[directory]</pre> <p><b>Example:</b> rommon &gt; dir flash:</p>	<p>Displays a list of the files and directories in flash memory.</p> <ul style="list-style-type: none"> <li>Locate the system image that you want the router to load.</li> <li>If the system image is not in flash memory, use the second or third option in <a href="#">Step 2</a>.</li> </ul>
Step 2	<pre>boot flash:[directory] [filename]</pre> <p>or</p> <pre>boot filename tftpserver</pre> <p>or</p> <pre>boot [filename]</pre> <p><b>Example:</b> ROMMON &gt; boot flash:myimage</p> <p><b>Example:</b> ROMMON &gt; boot someimage 172.16.30.40</p> <p><b>Example:</b> ROMMON &gt; boot</p>	<p>In order, the examples here direct the router to:</p> <ul style="list-style-type: none"> <li>Boot the first image or a specified image in flash memory.</li> <li>Boot the specified image over the network from the specified TFTP server (hostname or IP address).</li> <li>Boot from the boothelper image because it does not recognize the device ID. This form of the command is used to netboot a specified image.</li> </ul> <p>You can override the default boothelper image setting by setting the BOOTLDR Monitor environment variable to point to another image. Any system image can be used for this purpose.</p> <p><b>Note</b> Options to the boot command are <b>-x</b> (load image but do not execute) and <b>-v</b> (verbose).</p>

## Examples

## Sample Output for the dir flash: Command in ROM Monitor mode

```
rommon 2 > dir flash:
program load complete, entry point: 0x80803000, size: 0x1b340
Directory of flash:

2      47089944  -rw-      cgr2010-universalk9-mz.SSA.151-0.17.T
rommon 3 >
```

## What to Do Next

If you want to configure the router to load a specified image at the next system reload or power-cycle, see the “Loading and Managing System Images” section in [Cisco IOS Configuration Fundamentals Command Reference](#).

## Additional References

The following sections provide references related to using the ROM monitor.

### Related Documents

Related Topic	Document Title
Connecting your PC to the router console port	Hardware installation guide for your router
Break key sequence combinations for entering ROM monitor mode within the first 60 seconds of rebooting the router	<i>Standard Break Key Sequence Combinations During Password Recovery</i>
Using the boot image (Rx-boot) to recover or upgrade the system image	<i>How to Upgrade from ROMmon Using the Boot Image</i>
Booting and configuration register commands	<i>Cisco IOS Configuration Fundamentals Command Reference</i>
Loading and maintaining system images; rebooting	<i>Cisco IOS Configuration Fundamentals and Network Management Configuration Guide</i>
Choosing and downloading system images	Software Center at <a href="http://www.cisco.com/kobayashi/sw-center/index.shtml">http://www.cisco.com/kobayashi/sw-center/index.shtml</a>
Router crashes	<i>Troubleshooting Router Crashes</i> <i>Understanding Software-forced Crashes</i>
Router hangs	<i>Troubleshooting Router Hangs</i>

### Technical Assistance

Description	Link
Technical Assistance Center (TAC) home page, containing 30,000 pages of searchable technical content, including links to products, technologies, solutions, technical tips, and tools. Registered Cisco.com users can log in from this page to access even more content. <sup>1</sup>	<a href="http://www.cisco.com/public/support/tac/home.shtml">http://www.cisco.com/public/support/tac/home.shtml</a>

1. You must have an account on Cisco.com. If you do not have an account or have forgotten your username or password, click **Cancel** at the login dialog box and follow the instructions that appear.





# Changing the Configuration Register Settings

---

**First Published: May 27, 2010, OL-20356-01**  
**Last Updated: October 25, 2017**

This document describes the 16-bit configuration register in NVRAM in the following sections:

- [Platforms this Document Supports, page 115](#)
- [About the Configuration Register, page 115](#)
- [Changing the Configuration Register Settings, page 118](#)
- [Displaying the Configuration Register Settings, page 119](#)
- [Configuring the Console Line Speed \(Cisco IOS CLI\), page 119](#)

## Platforms this Document Supports

This document supports the Cisco Connected Grid Router 2010.

## About the Configuration Register

The router has a 16-bit configuration register in NVRAM. Each bit has value 1 (on or set) or value 0 (off or clear), and each bit setting affects the router behavior upon the next reload power cycle.

You can use the configuration register to:

- Force the router to boot into the ROM monitor (bootstrap program)
- Select a boot source and default boot filename
- Enable or disable the Break function
- Control broadcast addresses
- Recover a lost password
- Change the console line speed

[Table 1](#) describes the configuration register bits.



---

**Americas Headquarters:**  
**Cisco Systems, Inc., 170 West Tasman Drive, San Jose, CA 95134-1706 USA**

© 2010 Cisco Systems, Inc. All rights reserved.

**Table 1 Configuration Register Bit Descriptions**

Bit Number	Hexadecimal	Meaning
00–03	0x0000–0x000F	Boot field. The boot field setting determines whether the router loads an operating system and where it obtains the system image. See <a href="#">Table 2</a> for details.
06	0x0040	Causes the system software to ignore the contents of NVRAM.
07	0x0080	Original equipment manufacturer bit enabled.
08	0x0100	Controls the console Break key: <ul style="list-style-type: none"> <li>• (Factory default) Setting bit 8 causes the processor to ignore the console Break key.</li> <li>• Clearing bit 8 causes the processor to interpret Break as a command to force the router into the ROM monitor mode, halting normal operation.</li> </ul> Break can always be sent in the first 60 seconds while the router is rebooting, regardless of the configuration register settings.
09	0x0200	This bit controls the system boot: <ul style="list-style-type: none"> <li>• Setting bit 9 causes the system to use the secondary bootstrap.</li> <li>• (Factory default) Clearing bit 9 causes the system to boot from flash memory.</li> <li>• This bit is typically not modified.</li> </ul>
10	0x0400	Controls the host portion of the IP broadcast address: <ul style="list-style-type: none"> <li>• Setting bit 10 causes the processor to use all zeros.</li> <li>• (Factory default) Clearing bit 10 causes the processor to use all ones.</li> </ul> Bit 10 interacts with bit 14, which controls the network and subnet portions of the IP broadcast address. See <a href="#">Table 3 on page 117</a> for the combined effects of bits 10 and 14.
05, 11, 12	0x0020, 0x0800, 0x1000	Controls the console line speed. See <a href="#">Table 4 on page 118</a> for the eight available bit combinations and console line speeds. Factory default is 9600 baud, where bits 5, 11, and 12 are all zero (clear). <b>Note</b> You cannot change the console line speed configuration register bits from the Cisco IOS command-line interface (CLI). You can, however, change these bits from the ROM monitor. Or, instead of changing the configuration register settings, you can set the console line speed through other Cisco IOS commands.
13	0x2000	Determines how the router responds to a network boot failure: <ul style="list-style-type: none"> <li>• Setting bit 13 causes the router to boot the default ROM software after 6 unsuccessful network boot attempts.</li> <li>• (Factory default) Clearing bit 13 causes the router to indefinitely continue network boot attempts.</li> </ul>

**Table 1** Configuration Register Bit Descriptions (continued)

Bit Number	Hexadecimal	Meaning
14	0x4000	Controls the network and subnet portions of the IP broadcast address: <ul style="list-style-type: none"> <li>Setting bit 10 causes the processor to use all zeros.</li> <li>(Factory default) Clearing bit 10 causes the processor to use all ones.</li> </ul> Bit 14 interacts with bit 10, which controls the host portion of the IP broadcast address. See <a href="#">Table 3 on page 117</a> for the combined effect of bits 10 and 14.
15	0x8000	Enables diagnostic messages and ignores the contents of NVRAM.

[Table 2 on page 117](#) describes the boot field, which is the lowest four bits of the configuration register (bits 3, 2, 1, and 0). The boot field setting determines whether the router loads an operating system and where the router obtains the system image.

**Table 2** Boot Field Configuration Register Bit Descriptions

Boot Field (Bits 3, 2, 1, and 0)	Meaning
0000 (0x0)	At the next power cycle or reload, the router boots to the ROM monitor (bootstrap program). To use the ROM monitor, you must use a terminal or PC that is connected to the router console port. For information about connecting the router to a PC or terminal, see the <i>Hardware Installation Guide</i> for your router.  In ROM monitor mode, you must manually boot the system image or any other image using the <b>boot</b> ROM monitor command.
0001 (0x01)	Boots the first image in flash memory as a system image.
0010 - 1111 (0x02 - 0xF)	At the next power cycle or reload, the router sequentially processes each <b>boot system</b> command in global configuration mode that is stored in the configuration file until the system boots successfully.  If no <b>boot system</b> commands are stored in the configuration file, or if executing those commands is unsuccessful, then the router attempts to boot the first image file in flash memory.

[Table 3](#) shows how each setting combination of bits 10 and 14 affects the IP broadcast address.

**Table 3** Broadcast Address Configuration Register Bit Combinations

Bit 10	Bit 14	Broadcast Address (<net> <host>)
0	0	<ones> <ones>
1	0	<ones> <zeros>
1	1	<zeros> <zeros>
0	1	<zeros> <ones>

Table 4 shows the console line speed for each setting combination of bits 5, 11, and 12.

**Table 4 Console Line Speed Configuration Register Bit Combinations**

Bit 5	Bit 11	Bit 12	Console Line Speed (baud)
1	1	1	115200
1	0	1	57600
1	1	0	38400
1	0	0	19200
0	0	0	9600
0	1	0	4800
0	1	1	2400
0	0	1	1200

## Changing the Configuration Register Settings

You can change the configuration register settings from either the ROM monitor or the Cisco IOS CLI. This section describes how to modify the configuration register settings from the Cisco IOS CLI.

To change the configuration register using the ROM monitor, see [Chapter 1, “Using ROM Monitor”](#).

To change the configuration register settings from the Cisco IOS CLI, complete the following steps:

- 
- Step 1** Connect a terminal or PC to the router console port. If you need help, see the *Hardware Installation Guide* for your router.
- Step 2** Configure your terminal or terminal emulation software for 9600 baud (default), 8 data bits, no parity, and 2 stop bits.
- Step 3** Power on the router.
- Step 4** If you are asked whether you would like to enter the initial dialog, answer **no**:
- ```
Would you like to enter the initial dialog? [yes]: no
```
- After a few seconds, the user EXEC prompt (`Router>`) appears.
- Step 5** Enter privileged EXEC mode by typing **enable** and, if prompted, enter your password:
- ```
Router> enable
Password: password
Router#
```
- Step 6** Enter global configuration mode:
- ```
Router# configure terminal
```
- Enter configuration commands, one per line.  
Edit with DELETE, CTRL/W, and CTRL/U; end with CTRL/Z
- Step 7** To change the configuration register settings, enter the **config-register value** command, where *value* is a hexadecimal number preceded by **0x**:
- ```
Router(config)# config-register 0xvalue
```



**Note** The Cisco IOS software does not allow you to change the console speed bits directly with the **config-register** command. To change the console speed from the Cisco IOS CLI, see the [“Configuring the Console Line Speed \(Cisco IOS CLI\)”](#) section on page 119.

**Step 8** Exit global configuration mode:

```
Router(config)# end
Router#
```

**Step 9** Save the configuration changes to NVRAM:

```
Router# copy run start
```

The new configuration register settings are saved to NVRAM, but they do not take effect until the next router reload or power cycle.

## Displaying the Configuration Register Settings

To display the configuration register settings that are currently in effect and the settings that will be used at the next router reload, enter the **show version** command in privileged EXEC mode.

The configuration register settings are displayed in the last line of the **show version** command output:

```
Configuration register is 0x142 (will be 0x142 at next reload)
```

## Configuring the Console Line Speed (Cisco IOS CLI)

The combined setting of bits 5, 11, and 12 determines the console line speed. You can modify these particular configuration register bits only from the ROM monitor.

To change the configuration register using the ROM monitor, see [Chapter 1, “Using ROM Monitor”](#).

To configure the console line speed from the Cisco IOS command-line interface, complete the following steps:

	Command or Action	Purpose
<b>Step 1</b>	Router> <b>enable</b> Password: <i>password</i> Router#	Enables privileged EXEC mode. Enter your password if prompted.
<b>Step 2</b>	Router# <b>configure terminal</b> Router(config)#	Enters global configuration mode.
<b>Step 3</b>	Router(config)# <b>line console 0</b> Router(config-line)#	Specifies the console line and enters line configuration mode.
<b>Step 4</b>	Router(config-line)# <b>speed baud</b>	Specifies the console line speed. Possible values (in baud): 1200, 2400, 4800, 9600, 19200, 38400, 57600, 115200.





## INDEX

---

### A

- adequate flash memory to upgrade [59](#)
- advanced CompactFlash memory [2](#)
- assigning an interface IP address [16](#)
- auxiliary line configuration [24](#)
- auxiliary port, for dial backup [49](#)

---

### B

- backing up startup configuration [57](#)
- backing up startup configuration file [27](#)
- baud rate
  - setting for console terminal [118](#)
- bridging, configuring [39](#)

---

### C

- choosing Cisco IOS release [56](#)
- Cisco Configuration Professional Express [5, 11](#)
- Cisco IOS
  - choosing release [56](#)
  - downloading images [57](#)
  - upgrading image [57](#)
- command-line access configuration [39](#)
- commands
  - exec-timeout [16](#)
- CompactFlash
  - creating directories [81](#)
  - deleting files [80](#)
  - formatting [76](#)
  - managing directories [81](#)
  - online insertion/removal [76](#)

- removing directories [82](#)
- renaming files [80](#)
- requirements and restrictions [75](#)
- viewing file content [78](#)
- configuration example [52](#)
- configuration examples
  - dynamic routes [42](#)
  - EIGRP [44](#)
  - static route [41](#)
- configuration register
  - changing settings [118](#)
- configuring
  - auxiliary line [24](#)
  - bridging [39](#)
  - command-line access [39](#)
  - default route [19](#)
  - dynamic routes [42](#)
  - EIGRP, IP [43 to 44](#)
  - enable password [13](#)
  - enable secret password [13](#)
  - Gigabit Ethernet interfaces [36](#)
  - global parameters [35](#)
  - GRP [43](#)
  - hostname [12](#)
  - interface cards [37](#)
  - interface description [16](#)
  - IP EIGRP [43 to 44](#)
  - loopback interface [37 to 38](#)
  - modules [37](#)
  - privileged EXEC timeout [15](#)
  - RIP [42](#)
  - RIP routes [42](#)
  - static routes [40](#)

timeout [16](#)  
 virtual terminal lines [22](#)  
 console  
     USB [2](#)  
 console port, for dial backup [49](#)  
 copper connection  
     SFP/gigabit ethernet port [2](#)  
 copying CompactFlash files [77](#)  
 copying image using ROM monitor [64](#)  
 creating CompactFlash directories [81](#)

---

## D

default  
     configuration, viewing [34](#)  
     network [20](#)  
     route configuration [19](#)  
     routes [20](#)  
 deleting files from CompactFlash [80](#)  
 dial backup  
     configuring [49](#)  
 displaying CompactFlash file content [78](#)  
 displaying CompactFlash platform support status and errors [78](#)  
 downloading Cisco IOS images [57](#)  
 DRAM, adequate for upgrading [59](#)  
 dynamic routes  
     configuration [42](#)  
     configuration example [42](#)  
     configuring [42](#)

---

## E

EIGRP configuration example [44](#)  
 enable password configuration [13](#)  
 enable secret password configuration [13](#)

---

## F

failover redundancy [47](#)  
 fiber connection  
     SFP/gigabit ethernet port [2](#)  
 finding the IOS version [56](#)  
 flash memory, adequate to upgrade [59](#)  
 formatting CompactFlash [76](#)

---

## G

gateway of last resort [20](#)  
 Gigabit Ethernet interfaces, configuring [36](#)  
 Gigabit Ethernet ports [4](#)  
 global parameters, setting up [35](#)  
 grid router WAN interface cards  
     router slots [2](#)  
 GRP configuration [43](#)

---

## H

hostname configuration [12](#)

---

## I

initial configuration setup [5](#)  
 integrated routing and bridging configuration [19](#)  
 interface card  
     configuration [37](#)  
 interface description configuration [16](#)  
 interface IP address assignment [16](#)  
 interface port labels [36](#)  
 IP routing [19](#)

---

## L

loading new system IOS image [67](#)  
 loopback interface, configuring [37 to 38](#)



---

**M**

- managing CompactFlash directories [81](#)
- memory
  - advanced CompactFlash [2](#)
- module configuration [37](#)
- modules
  - router slots [2](#)
- monitoring internal router temperature [29](#)

---

**N**

- network connectivity verification [26](#)
- new system IOS image, loading [67](#)

---

**O**

- online insertion/removal of CompactFlash [76](#)

---

**P**

- parameters, setting up global [35](#)
- port
  - SFP-GE [47](#)
- port labels for interfaces [36](#)
- ports
  - Gigabit Ethernet [4](#)
  - RS232 [4](#)
  - USB [4](#)
- privileged EXEC timeout configuration [15](#)

---

**R**

- RCP, upgrading [62](#)
- release
  - new features [2](#)
- remote management, configuring [49](#)
- removing CompactFlash directories [82](#)

- renaming CompactFlash files [80](#)
- RIP
  - configuring [42](#)
- RIP route configuration [42](#)
- ROM monitor, coping image [64](#)
- router, monitoring internal temperature [29](#)
- router slots [2](#)
- RS232 ports [4](#)

---

**S**

- saving router configuration [27](#)
- setup, initial [5](#)
- SFP/gigabit ethernet port
  - copper [2](#)
  - fiber [2](#)
- SFP-GE port [47](#)
- show version command [56](#)
- slots [3](#)
- software upgrades, IOS [56](#)
- startup configuration, backing up [57](#)
- static route configuration [40](#)
- static routes
  - configuration [40](#)
  - configuration example [41](#)
  - configuring [40](#)

---

**T**

- Tables
  - configuration register settings for boot field [117](#)
- TFTP, upgrading [62](#)
- timeout, disabling [16](#)

---

**U**

- upgrading, adequate DRAM [59](#)
- upgrading Cisco IOS image [57](#)

upgrading IOS software [56](#)

## USB

console [2](#)

ports [4](#)

using RCP to upgrade [62](#)

using ROM monitor to copy image [64](#)

using TFTP to upgrade [62](#)

---

## V

### verifying

IP EIGRP configuration [44](#)

network connectivity [26](#)

RIP routing configuration [43](#)

static route configuration [41](#)

virtual terminal line configuration [22](#)