



Cisco ASR 9000 Series Aggregation Services Router System Management Command Reference, Release 6.1.x

First Published: 2016-11-01

Americas Headquarters

Cisco Systems, Inc.
170 West Tasman Drive
San Jose, CA 95134-1706
USA
<http://www.cisco.com>
Tel: 408 526-4000
800 553-NETS (6387)
Fax: 408 527-0883

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NON-INFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

All printed copies and duplicate soft copies of this document are considered uncontrolled. See the current online version for the latest version.

Cisco has more than 200 offices worldwide. Addresses and phone numbers are listed on the Cisco website at www.cisco.com/go/offices.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: [www.cisco.com go trademarks](http://www.cisco.com/go/trademarks). Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1721R)

© 2016 Cisco Systems, Inc. All rights reserved.



Preface

From Release 6.1.2 onwards, Cisco introduces support for the 64-bit Linux-based IOS XR operating system. Extensive feature parity is maintained between the 32-bit and 64-bit environments. Unless explicitly marked otherwise, the contents of this document are applicable for both the environments. For more details on Cisco IOS XR 64 bit, refer to the [Release Notes](#) for Cisco ASR 9000 Series Routers, Release 6.1.2 document.

This guide describes the System Management commands. This chapter contains details on the changes made to this document.

- [Changes to This Document, on page iii](#)
- [Changes to This Document, on page iii](#)
- [Communications, Services, and Additional Information, on page iii](#)

Changes to This Document

This table lists the technical changes made to this document since it was first released.

Table 1: Changes to This Document

Date	Summary
April 2016	Initial release of this document.

Changes to This Document

This table lists the technical changes made to this document since it was first released.

Table 2: Changes to This Document

Date	Summary
November 2016	Initial release of this document.

Communications, Services, and Additional Information

- To receive timely, relevant information from Cisco, sign up at [Cisco Profile Manager](#).

- To get the business impact you're looking for with the technologies that matter, visit [Cisco Services](#).
- To submit a service request, visit [Cisco Support](#).
- To discover and browse secure, validated enterprise-class apps, products, solutions and services, visit [Cisco Marketplace](#).
- To obtain general networking, training, and certification titles, visit [Cisco Press](#).
- To find warranty information for a specific product or product family, access [Cisco Warranty Finder](#).

Cisco Bug Search Tool

[Cisco Bug Search Tool](#) (BST) is a web-based tool that acts as a gateway to the Cisco bug tracking system that maintains a comprehensive list of defects and vulnerabilities in Cisco products and software. BST provides you with detailed defect information about your products and software.



Boot Commands

This module describes the commands used to boot or reset Cisco IOS XR software.

For more information about ROM Monitor (ROMMON) and boot tasks, see *ROM Monitor Configuration Guide for Cisco ASR 9000 Routers* or *Cisco ASR 9000 Series Aggregation Services Router Getting Started Guide*.

- [config-register](#), on page 2
- [mirror](#), on page 5
- [mirror pause](#), on page 7
- [mirror resume](#), on page 8
- [mirror verify](#), on page 9
- [reload](#), on page 10
- [reload \(administration EXEC\)](#), on page 12
- [show epm trace boot](#), on page 14
- [show mirror](#), on page 16
- [show reboot](#), on page 19
- [show variables boot](#), on page 22
- [show variables system](#), on page 24
- [system boot-sequence](#), on page 26

config-register

To define the configuration register boot value, use the **config-register** command in the appropriate mode.

config-register {*value* | **boot-mode** {**exec-mode** | **rom-monitor**} | **console-baud** *baud-rate* | **console-break-key** {**disable** | **enable**} | **password-recovery** {**disable** | **enable**}} [**location** {*node-id* | **all**}]

Syntax Description

<i>value</i>	Hexadecimal or decimal value that represents the 16-bit configuration register value to be used the next time the router is reloaded. Range is from 0x0 to 0xFFFF (0 to 65535 in decimal). For information about common configuration register settings, see Table 3: Common Configuration Register Settings, on page 3 .
boot-mode	Specifies what to do when the system is rebooted.
exec-mode	Specifies to load the Cisco IOS XR software and enter EXEC mode on next system reboot.
rom-monitor	Specifies to enter ROM Monitor mode on next system reboot.
console-baud <i>baud-rate</i>	Specifies the console baud rate.
console-break-key { disable enable }	Specifies to disable or enable the console break key on the next system reboot.
password-recovery { disable enable }	Specifies to enable or disable the password recovery mode on the next reboot.
location { <i>node-id</i> all }	(Optional) Specifies the RSP node for which to define the configuration register boot value. The all keyword specifies all RSP nodes.

Command Default

By default, the configuration register value is 0x102 after a Turboboot.

Command Modes

Administration EXEC

EXEC mode

Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	No modification.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The *configuration register setting* is a 16-bit, user-configurable value that determines how the router switch processor (RSP) functions during initialization. The configuration register can cause the RSP to boot normally from the default configuration, or to enter ROMMON mode during a reload. Configuration register settings can also be used to perform tasks such as password recovery.

The **config-register** command is entered in administration EXEC mode, on the designated shelf controller (DSC) of the system. The DSC is the primary RSP of the owner secure domain router (owner SDR).

When you have two RPs (Primary RP0 and Standby RP1) and the config-registers of the two are different, you must manually set the config-register in RP1 equal to RP0 in order for RP1 to synchronize with the configurations on RP0.

Use the **show variables boot** command in the EXEC mode to see status of the config-register in both the RPs.

Use the **config-register:location** command in the Admin mode to change the config-register in either of the RPs.

When setting the configuration register value for the **config-register** command, note the following conditions:

- If both the primary and standby DSC are up and running when the configuration register value is set, the configuration register value applies to both the primary and standby DSC.
- By contrast, if only the primary DSC is up and running when the configuration register value is set and the standby DSC is introduced into the router at a later time, the router does *not* attempt to synchronize the configuration register value for the standby RSP to that of the active RSP; in this situation, the configuration register setting applied to the standby DSC is determined by the configuration register value set in ROMMON mode.

This table describes the most commonly used configuration register settings.

Table 3: Common Configuration Register Settings

Value	Description
0x0	RSP enters ROMMON mode (rommon B1>) on the next system boot.
0x2	RSP loads the Cisco IOS XR software and default configuration on the next system boot. After logging in, the user can access EXEC mode.
0x102	Router loads the Cisco IOS XR software with the console Break key disabled on the next system boot. Both 0x102 and 0x2102 specify the same functionality, as bit 13 in 0x2102 is not significant for Cisco IOS XR software.
0x40	Router enters the password recovery mode on the next system boot.

If you use the various keywords to set the configuration settings, note that the hexadecimal value is updated in an additive or subtractive manner to represent the keyword used. For example, if the current configuration setting is 0x102 and you use the **config-register** command with the **password-recovery enable** keywords, the value is updated to 0x142.

Task ID	Task ID	Operations
	root-lr	read, write

The following example shows how to set the configuration register on the DSC to 0x2. Setting the configuration registration to 0x2 causes the router to boot the Cisco IOS XR software and enter EXEC mode during a router reload.

```
RP/0/RSP0/CPU0:router(admin)# config-register boot-mode exec-mode  
  
Sun May 31 12:10:36.037 PST Successfully set config-register to  
0x2 on node 0/RSP0/CPU0
```

Related Topics

- [reload](#), on page 10
- [show variables boot](#), on page 22
- [show version](#), on page 408

mirror

To configure disk mirroring on a node, use the **mirror** command in global configuration mode. To disable disk mirroring, use the **no** form of this command.

mirror location [**preconfigure**] *node-id primary-device:secondary-device:*
no mirror location

Syntax Description	
location <i>node-id</i>	Specifies the node of the RP. It can be a node that is not yet installed if the preconfigure keyword is used. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.
preconfigure	(Optional) Enables you to specify a node that is not yet installed.
<i>primary-device</i> :	Specifies the primary boot device used to store installation packages and configuration files. Supported devices are: <ul style="list-style-type: none"> • disk0: • disk1: (if installed) • compactflash: (if installed)
<i>secondary-device</i> :	Storage device on the same RP as the <i>primary-device</i> , to where critical data is replicated. Supported devices are the same as for <i>primary-device</i> :, but <i>secondary-device</i> : must be different than the <i>primary-device</i> :.

Command Default None

Command Modes Global configuration

Command History

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **mirror** command replicates all critical data contained in the primary partition of the primary boot device, onto a second storage device on the same RSP. Therefore, if the primary boot device fails, applications continue to be serviced transparently by the secondary device, without having to switch control to a standby RSP.

Before the **mirror** command can be used, the secondary storage device must be partitioned using the **format** command. If the primary boot device is not partitioned, once mirroring is enabled and all data on the primary boot device is replicated to the secondary device, the primary boot device is partitioned automatically. This

guarantees that only critical data on the primary boot device is mirrored to the secondary device. Noncritical data, such as logging data, should not be mirrored and should, therefore, be saved to the secondary partition on the storage device.

To temporarily suspend disk mirroring without changing the configuration, use the **mirror pause** command in EXEC mode.

Task ID	Task ID	Operations
	root-lr	read, write

The following example shows how to configure disk mirroring from the primary boot device (disk0:) to the secondary storage device (disk1:):

```
RP/0/RSP0/CPU0:router(config)# mirror location 0/rp0/cpu0 disk0: disk1:
```

Related Topics

[format](#)

[mirror pause](#), on page 7

[mirror resume](#), on page 8

mirror pause

To temporarily pause disk mirroring on a node, use the **mirror pause** command in EXEC or administration EXEC mode.

mirror pause [**location** {*node-id* | **all**}]

Syntax Description **location** {*node-id* | **all**} (Optional) Specifies the node of the RSP. The *node-id* argument is entered in the *rack/slot/module* notation. The **all** keyword specifies all RSP nodes.

Command Default If no node is specified, disk mirroring is paused on the active RSP.

Command Modes EXEC

Administration EXEC

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **mirror pause** command temporarily pauses the mirroring of the primary boot device. This command is primarily useful during an installation operation to prevent significant performance degradation on single CPU boards. The **mirror pause** command does not change the configured state of mirroring, but rather causes the mirroring to be suspended until the **mirror resume** command is used.

The **mirror pause** command has no affect if the **mirror** configuration command is not enabled.

Task ID	Task ID	Operations
	root-lr	read, write

The following example shows how to pause disk mirroring on the active RSP:

```
RP/0/RSP0/CPU0:router# mirror pause
```

Related Topics

- [mirror](#), on page 5
- [mirror resume](#), on page 8

mirror resume

To resume disk mirroring on a node after it has been temporarily stopped, use the **mirror resume** command in EXEC or administration EXEC mode.

```
mirror resume [location {node-id | all}]
```

Syntax Description

location {*node-id* | **all**} (Optional) Specifies the node of the RSP. The *node-id* argument is entered in the *rack/slot/module* notation. The **all** keyword specifies all RSP nodes.

Command Modes

EXEC

Administration EXEC

Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	No modification.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **mirror resume** command resumes the mirroring of the primary boot device after it has been temporarily paused with the **mirror pause** command.

The **mirror resume** command has no affect if the **mirror** configuration command is not enabled and the **mirror pause** command has not been used.

Task ID

Task ID	Operations
root-lr	read, write

The following example shows how to resume disk mirroring on the active RSP:

```
RP/0/RSP0/CPU0:router# mirror resume
```

Related Topics

[mirror](#), on page 5

[mirror pause](#), on page 7

mirror verify

To verify disk synchronization for disk mirroring on a node, use the **mirror verify** command in EXEC or administration EXEC mode.

mirror verify [**location** *node-id*]

Syntax Description **location** *node-id* (Optional) Specifies the node of the RSP. The *node-id* argument is entered in the *rack/slot/module* notation.

Command Default If no node is specified, the verification is done on the active RSP.

Command Modes EXEC
Administration EXEC

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **mirror verify** command verifies the synchronization consistency between the primary and secondary media devices being used in mirroring. The command verifies that the full contents are identical between the mirrored devices and reports any inconsistencies found.

Task ID	Task ID	Operations
	root-lr	read, write

The following example shows how to verify the disk mirroring on the active RSP:

```
RP/0/RSP0/CPU0:router# mirror verify
```

```
Mirror Verify Information for 0/RSP0/CPU0.
=====
Primary device and secondary device are fully synchronized.
```

Related Topics

[mirror](#), on page 5

reload

reload

Syntax Description This command has no keywords or arguments.

Command Default No default behavior or values

Command Modes EXEC

Command History

Releases

Modifications

Release 3.7.2

This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **reload** command to cause the RSP to reload the Cisco IOS XR software according to the configuration register setting (for example, 0x0 to enter ROMMON mode and 0x2 to reload the RSP to EXEC mode). If a standby RSP is in the ready redundancy state, the **reload** command also causes the router to fail over to the standby RSP. Use the **show redundancy** command in EXEC mode to display the status of the standby RSP.

When the **reload** command is used and a switchover occurs, the running (active) software configuration is automatically maintained during switchover.



Caution

If a standby RSP is not installed or is not in the ready state, then the router experiences a loss of service while the active RSP is reloading Cisco IOS XR software. To view the status of the standby RSP, issue the **show redundancy** command in EXEC mode.

If you use the **reload** command and there is no available standby node, you are prompted to continue with the reload:

```
RP/0/RSP0/CPU0:router# reload
Standby card not present or not Ready for failover. Proceed?[confirm]y
```

Task ID

Task Operations ID

root-lr execute

The following example shows how to reload the active RSP. If a standby RSP is in the ready state, then the router fails over to the standby RSP. If the standby RSP is not installed or is not in the ready state, then the router enters ROMMON mode and routing operations stop.

```
RP/0/RSP0/CPU0:router# reload
```

```
Updating Commit Database. Please wait...[OK]
Proceed with reload? [confirm] y

PCI0 device[7]: Vendor ID 0x10ee
PCI0 device[7]: Device ID 0x300e
PCI1 device[7]: Device ID 0x1100
PCI1 device[7]: Vendor ID 0x1013
PCI1 device[8]: Device ID 0x649
PCI1 device[8]: Vendor ID 0x1095
PCI1 device[9]: Device ID 0x5618
PCI1 device[9]: Vendor ID 0x14e4
PCI1 device[10]: Device ID 0x5618
PCI1 device[10]: Vendor ID 0x14e4
System Bootstrap, Version 1.15(20040120:002852) ,
Copyright (c) 1994-2004 by cisco Systems, Inc.
Board type is 0x100000 (1048576)
Enabling watchdog
Broadcom 5618 #0 Found on PCI
Broadcom 5618 #1 Found on PCI
No. of BCM 56xx switches found 2 .
BCM Switch #0 initialisation complete.
BCM Switch #1 initialisation complete
G4(7450-SMP-GT64260_A) platform with 2048 Mb of main memory

rommon B1 >
```

Related Topics

[reload \(administration EXEC\)](#), on page 12

[show redundancy](#), on page 406

[config-register](#), on page 2

reload (administration EXEC)

To reload a node or all nodes on a single chassis or multishelf system, use the **reload** command in the appropriate mode.

```
reload [{location {node-id | all} | rack rack-number}]
```

Syntax Description

location {*node-id* | **all**} (Optional) Specifies the node to reload. The *node-id* argument is entered in the *rack/slot/module* notation. The **all** keyword specifies all RP nodes.

rack Reloads all the nodes on a specified chassis.

rack-number Rack number of the line card chassis or fabric chassis.

Command Default

None

Command Modes

Administration EXEC

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.



Note

Before reloading nodes on the router, we recommend using the **dfs check** command to check the sanity of the configuration file system and attempt to recover from internal inconsistencies.

To reload a specific node on the router, specify the **reload** command with the **location** *node-id* keyword and argument. The *node-id* is expressed in the *rack/slot/module* notation.

Task ID

Task ID	Operations
root-system	execute

The following example shows how to reload all nodes on the router:

```
RP/0/RSP0/CPU0:router (admin) # reload location all

Graceful reload of all nodes not supported
Assuming 'force'
Operation may result in file corruptions or loss of config. Proceed [Y/N]? y
```




Note To ensure the sanity of the configuration file system, enter the **cfs check** command on the router.

Related Topics

[cfs check](#)

[reload](#), on page 10

[show redundancy](#), on page 406

[config-register](#), on page 2

show epm trace boot

To display execution path monitoring traces, use the **show epm trace boot** command in administration EXEC mode.

show epm trace boot [**hexdump**] [**last** *n*] [**reverse**] [**stats**] [**tailf**] [**unique**][**verbose**] [**wrapping**][**file** *filename original*] [**location** {*node-id* | **all**}]

Syntax Description		
hexdump	(Optional)	Displays traces in hexadecimal format.
last <i>n</i>	(Optional)	Displays the last <i>n</i> number of traces only.
reverse	(Optional)	Displays the most recent traces first.
stats	(Optional)	Displays execution path statistics.
tailf	(Optional)	Displays new traces as they are added.
unique	(Optional)	Displays unique entries only, along with the count of the number of times this entry appears.
verbose	(Optional)	Displays additional internal debugging information.
wrapping	(Optional)	Displays wrapping entries.
file <i>filename original</i>	(Optional)	Specifies the filename of the file to display. You can specify up to four trace files.
location { <i>node-id</i> all }	(Optional)	Specifies the node of the RSP. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation. You can specify up to four nodes. The all keyword specifies all RSP nodes.

Command Default None

Command Modes Administration EXEC

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **show epm trace boot** command provides a simple way of tracking and time-stamping critical events to clearly understand their temporal relationship to one another and the amount of time spent performing critical operations.

Task ID	Task ID	Operations
	basic	read
	services	

The following example shows sample output from the **show epm trace boot** command:

```
RP/0/RSP0/CPU0:router(admin)# show epm trace boot

Mon Jun 1 03:16:36.946 PST
22 wrapping entries (1024 possible, 0 filtered, 22 total)
Oct 8 07:54:49.610 epm/boot 0/RSP0/CPU0 t1 @ 00:00:06 - [init] process-start
Oct 8 07:55:25.710 epm/boot 0/RSP0/CPU0 t1 @ 00:00:42 - [insthelper] process-start
Oct 8 07:57:08.992 epm/boot 0/RSP0/CPU0 t1 @ 00:02:25 - [sysmgr] process-start
Oct 8 07:57:09.785 epm/boot 0/RSP0/CPU0 t7 @ 00:02:26 - [sysmgr] start-level: start
Oct 8 07:57:10.722 epm/boot 0/RSP0/CPU0 t1 @ 00:02:27 - [sw_dwnld_svr] process-start
Oct 8 07:57:12.482 epm/boot 0/RSP0/CPU0 t11 @ 00:02:29 - [sysmgr] start-level: admin
Oct 8 07:57:13.385 epm/boot 0/RSP0/CPU0 t1 @ 00:02:30 - [instdir] process-start
Oct 8 07:57:19.638 epm/boot 0/RSP0/CPU0 t1 @ 00:02:36 - [instdir_lr] process-start
Oct 8 07:58:07.045 epm/boot 0/RSP0/CPU0 t9 @ 00:03:23 - [sysmgr] admin-plane-up
Oct 8 07:58:52.057 epm/boot 0/RSP0/CPU0 t4 @ 00:04:08 - [cfgmgr-rp] admin-config-start
Oct 8 07:58:59.973 epm/boot 0/RSP0/CPU0 t4 @ 00:04:16 - [cfgmgr-rp] admin-config-done
Oct 8 07:59:00.079 epm/boot 0/RSP0/CPU0 t9 @ 00:04:16 - [sysmgr] start-level: infra
Oct 8 07:59:00.615 epm/boot 0/RSP0/CPU0 t1 @ 00:04:17 - [devc-conaux] exec-available
Oct 8 07:59:02.288 epm/boot 0/RSP0/CPU0 t4 @ 00:04:18 - [cfgmgr-rp] admin-plane-mount-done
Oct 8 07:59:08.157 epm/boot 0/RSP0/CPU0 t6 @ 00:04:24 - [instdir] ready-for-requests
Oct 8 07:59:15.999 epm/boot 0/RSP0/CPU0 t6 @ 00:04:32 - [sysmgr] start-level: active
Oct 8 07:59:32.300 epm/boot 0/RSP0/CPU0 t13 @ 00:04:48 - [sysmgr] start-level: final
Oct 8 07:59:38.143 epm/boot 0/RSP0/CPU0 t9 @ 00:04:54 - [sysmgr] lr-plane-up
Oct 8 07:59:38.189 epm/boot 0/RSP0/CPU0 t4 @ 00:04:54 - [cfgmgr-rp] lr-config-start
Oct 8 07:59:49.898 epm/boot 0/RSP0/CPU0 t4 @ 00:05:06 - [cfgmgr-rp] lr-config-done
Oct 8 07:59:50.259 epm/boot 0/RSP0/CPU0 t4 @ 00:05:06 - [cfgmgr-rp]
bulk-interface-config-start
Oct 8 07:59:50.351 epm/boot 0/RSP0/CPU0 t7 @ 00:05:06 - [cfgmgr-rp] node-config-done
```

In this sample output, the time stamp following the @ sign is the elapsed time in the format hh:mm:ss since the execution phase started (for example, since node start, in the case of a boot).

show mirror

To display disk mirroring information, use the **show mirror** command in EXEC or administration EXEC mode.

show mirror [**location** {*node-id* | **all**}]

Syntax Description	location { <i>node-id</i> all } (Optional) Specifies the node of the RSP for which to display the mirroring information. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation. The all keyword specifies all RSP nodes.
---------------------------	--

Command Default	No default behavior or values
------------------------	-------------------------------

Command Modes	EXEC Administration EXEC
----------------------	-----------------------------

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	filesystem	read

The following is sample output from the **show mirror** command:

```
RP/0/RSP0/CPU0:router# show mirror

Mirror Information for 0/RSP0/CPU0.
=====
Mirroring Enabled
  Configured Primary:      disk0:
  Configured Secondary:   disk1:

Current Mirroring State:  Syncing Files
  Current Physical Primary: disk1:
  Current Physical Secondary: disk0:

Mirroring Logical Device:  disk0:

Physical Device   State   Flags
-----
disk0:            Available  Enabled Formatted
```

```

disk1:           Available      Enabled Formatted
compactflash:   Not Present
disk0a:         Available      Formatted
disk1a:         Available      Formatted
compactflasha:  Not Present

Mirroring Rommon Variable
BOOT_DEV_SEQ_CONF = disk0;;disk1:
BOOT_DEV_SEQ_OPER = disk1:
MIRROR_ENABLE = Y
    
```

Table 4: show mirror Field Descriptions

Field	Description
Mirroring Enabled	Indicates whether mirroring is enabled or disabled.
Configured Primary	If mirroring is enabled, the configured primary disk for mirroring.
Configured Secondary	If mirroring is enabled, the configured secondary disk for mirroring.
Current Mirroring State	Current status of mirroring. Possible values are as follows: Syncing files—Files are being synchronized between the primary and secondary disks. Not Configured—Mirroring is not configured. Mirroring Paused—In this state, no mirroring is being done to the secondary device and the disk redundancy has been removed. The values of the BOOT_DEV_SEQ_OPER and MIRROR_ENABLE variables reflect this. Redundant—The primary and secondary disks are totally in synchronization. Any read or write failure on the primary device results in disk redundancy switchover such that all operations are performed on the secondary device.
Current Physical Primary	Current primary disk.
Current Physical Secondary	Current secondary disk.
Mirroring Logical Device	Device name used by the mirroring process to intercept all application requests to that named device before passing them through to one of the mirrored physical devices.
Physical Device	Physical disk in router.
State	Status of the disk. Possible values are as follows: Available—Disk exists in router and is available. Not present—Disk does not exist in router. Partitioning of disks is available only after the disk has been formatted with the partition keyword.

Field	Description
Flags	<p>Enabled—Disk mirroring has been enabled on this device and the device is part of the mirroring process.</p> <p>Repaired—During the boot, some minor inconsistencies were discovered on the disk and were repaired to make the file system consistent.</p> <p>Formatted—Disk was formatted before mirroring was enabled.</p>
BOOT_DEV_SEQ_CONF=	<p>ROM Monitor environmental variable for the boot disk sequence. This variable is set when mirroring is enabled through the mirror configuration command. The devices in this ROMMON variable declare the primary and the secondary devices of the mirroring process. The first device is the primary device and the second device is the secondary device in the mirroring process.</p> <p>Note This variable is also shared by the disk backup feature. This variable can also be set or unset using the system boot-sequence command of the disk backup feature. But the use of system boot-sequence and system backup commands is blocked, if mirroring is enabled.</p>
BOOT_DEV_SEQ_OPER=	<p>ROM Monitor environmental variable that reflects the state of the disk redundancy status. When mirroring is enabled and the state is redundant, this variable is set to the primary device followed by the secondary device. When mirroring is not in the redundancy state, then this variable is updated to contain only the primary device.</p>
MIRROR_ENABLE	<p>ROM Monitor environmental variable whose value reflects the mirroring status. If it is set to Y, then mirroring is enabled. If it is set to P, then mirroring is paused. If empty, mirroring is not enabled.</p>

Related Topics

[mirror](#), on page 5

[mirror verify](#), on page 9

show reboot

To display reboot information for a node, use the **show reboot** command in EXEC or administration EXEC mode.

show reboot {**history** | [**reverse**] | {**first** | **last**} {**crashinfo** | **syslog** | **trace**} | **graceful**} **location** *node-id*

Syntax Description	Parameter	Description
	first	(Optional) Displays information about the first ungraceful reboot.
	last	(Optional) Displays information about the last ungraceful reboot.
	crashinfo	Displays crash information for an ungraceful reboot.
	syslog	Displays the syslog messages related to an ungraceful reboot.
	trace	Displays trace information for an ungraceful reboot.
	graceful	Displays information about the last graceful reboot.
	history	Displays the reboot history of a specific node.
	reverse	(Optional) Displays the reboot history information in reverse chronological order.
	location <i>node-id</i>	Specifies which node to reload. The <i>node-id</i> argument is expressed in the <i>rack/slot/module</i> notation.

Command Default None

Command Modes EXEC
Administration EXEC

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **history** keyword for the **show reboot** command displays all reboot causes stored for previous node resets.

Crash information (**crashinfo**), syslog, and kernel dumper ltrace (**trace**) can be displayed for the first or last reboot if it is an ungraceful reboot.

Task ID	Task ID	Operations
	system	read

This example shows sample output from the **show reboot** command with the **history** keyword:

The following example shows sample output from the **show reboot** command with the **first crashinfo** keywords:

```
RP/0/RSP0/CPU0:router# show reboot first crashinfo location 0/rp0/cpu0

Crashinfo Timestamp: Thu Jul 19 20:32:57 2007

20070719 20:32:57

Crash Reason: Cause code 0x21000010 Cause: Missed deadline,
  client: sc-reddrv-main, timeout: 5 Process: wd-critical-mon
Traceback: fc1941a0 fc194290 48200738 482013cc 48201c04 fc1d4fb0 Timezone UTC0

Exception at 0xfc1944c8 signal 5 c=1 f=3

Active process(s):
pkg/bin/wd-critical-mon Thread ID 1 on cpu 0
pkg/bin/l3test Thread ID 0 on cpu 1
```

```
REGISTER INFO
  r0      r1      r2      r3
R0  01000000 4817e8c0 4820e208 000000de
   r4      r5      r6      r7
R4  fc1b4856 7fffffff 4817e738 fc1b4856
   r8      r9      r10     r11
R8  00000000 602cf522 00000000 00000000
   r12     r13     r14     r15
R12 602cf51c 4820e1a0 00000000 00000000
   r16     r17     r18     r19
R16 00000000 00000000 00000000 00000000
   r20     r21     r22     r23
R20 00000000 00000000 48200000 48200000
   r24     r25     r26     r27
R24 48200000 48200000 48200000 48200000
   r28     r29     r30     r31
R28 00000028 00000001 21000010 6029b000
   cnt     lr      msr     pc
R32 00000000 fc194290 0002d932 fc1944c8
   cnd     xer
R36 44000094 20000006
```

SUPERVISOR REGISTERS

Memory Management Registers

```
Instruction BAT Registers
  Index #      Value
IBAT0U #      0x1ffe
IBAT0L #      0x12
IBAT1U #      0
IBAT1L #      0
IBAT2U #      0x3000ffe
IBAT2L #      0xf0000032
IBAT3U #      0xfffc0003
```


IBAT3L # 0x40011

Data BAT Registers

Index #	Value
DBAT0U #	0x1ffe
DBAT0L #	0x12
DBAT1U #	0
DBAT1L #	0x10000012
DBAT2U #	0x30000ffe
DBAT2L #	0xf000006a
DBAT3U #	0xfffc0003
DBAT3L #	0x40011

Segment Registers

Index #	SR-Value
0 #	0
1 #	0
2 #	0
3 #	0
4 #	0
5 #	0
6 #	0
7 #	0
8 #	0
9 #	0
10 #	0
11 #	0
12 #	0
13 #	0
14 #	0
15 #	0

Exception Handling Registers

Data Addr Reg #	DSISR
0x602cf440 #	0x42000000
SPRG0 # SPRG1 # SPRG2 # SPRG3	
0x1 # 0x21000010 # 0x6029b000 #	0
SaveNRestore SRR0 # SaveNRestore SRR1	
0xfc1944c4 # 0x2d932	

Miscellaneous Registers

Processor Id Reg #	0
HID0 #	0x8410c0bc
HID1 #	0x9001ac80
MSSCR0 #	0x88000
MSSSR0 #	0

STACK TRACE
 #0 0xfc194290
 #1 0x48200738
 #2 0x482013cc
 #3 0x48201c04
 #4 0xfc1d4fb0

Related Topics

[reload](#), on page 10

show variables boot

To display the configuration register setting and boot file setting for the route switch processors (RSPs) in the system, use the **show variables boot** command in administration

EXEC

mode.

show variables boot [**location** {**all***node-id*}]

Syntax Description	location { <i>node-id</i> all }	(Optional) Specifies the node to reload. The <i>node-id</i> argument is expressed in the <i>rack/slot/module</i> notation. Use the all keyword to indicate all nodes.
---------------------------	---	--

Command Default	No default behavior or values
------------------------	-------------------------------

Command Modes	Administration EXEC
----------------------	---------------------

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **show variables boot** command to display system boot variables for the router. This command displays the configuration register setting and boot file setting for the RSPs in the system. Use the **location** *node-id* keyword and argument to display the configuration register setting for a specific card.

The configuration register setting is set with the **config-register** command. The boot variable is set in ROM Monitor mode. For more information about ROM Monitor mode, see *ROM Monitor Configuration Guide for Cisco ASR 9000 Routers*.

Task ID	Task ID	Operations
	root-lr	read

This example shows sample output from the **show variables boot** command:

```
RP/0/RSP0/CPU0:router# show variables boot

Mon Jun  1 05:21:56.791 PST
BOOT variable = disk0:asr9k-os-mpi-3.9.0.11I/mbiasr9k-rp.vm,1;
CONFREG variable = 0x102
```

Related Topics

[show variables system](#), on page 24

[show version](#), on page 408

[config-register](#), on page 2

show variables system

To display internal system environmental variables set on the router, use the **show variables system** command in

EXEC

mode.

show variables system

Syntax Description This command has no keywords or arguments.

Command Default None

Command Modes EXEC

Command History	Release	Modification
	Release 3.7.2	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **show variables system** command to display system environmental variables for the router.

To display the configuration register setting, use the **show variables boot** command in administration EXEC mode.

Task ID	Task ID	Operations
	basic-services	read

This example illustrates sample output from the **show variables system** command. The output is meant to be interpreted by Cisco personnel.

```
RP/0/RSP0/CPU0:router# show variables system
```

```
TERM=vt220
GDB_PDEBUG=-P1
TERM=vt100
DIR_PREFIX=.
LOADPATH=/pkg
LD_LIBRARY_PATH=/pkg/lib
PATH=/pkg/bin
BFM_CONFIG_PATH=/pkg/bfm/config
BGP_PATH=/pkg/bgp
CONFIGS_PATH=/pkg/configs
CRAFT_PATH=/pkg/cwi
CTF_PATH=/pkg/ctf
DM_RULES_PATH=/pkg/dm/rules
ETC_PATH=/pkg/etc
```

```
FPD_PATH=/pkg/fpd
IM_RULES_PATH=/pkg/rules
INIT_STARTUP_PATH=/pkg/init.d
INSTHELPER_PATH=/pkg/other
MAN_PATH=/pkg/man
MIB_LIBRARY_PATH=/pkg/lib/mib
MIB_PATH=/pkg/mib
NETIO_SCRIPT_PATH=/pkg/script
PARSER_PATH=/pkg/parser
PARTITIONS_PATH=/pkg/partitions
QOS_PATH=/pkg/qos
SCHEMA_PATH=/pkg/schema
STARTUP_PATH=/pkg/startup
TCL_LIBRARY=/pkg/lib/tcl
UCODE_PATH=/pkg/gsr/ucode
UCODE_ROOT_PATH=/pkg/ucode
VCM_RULES_PATH=/pkg/vcmrules
JOB_ID=0
INSTANCE_ID=1
SYSMGR_TUPLE=
SYSMGR_NODE=node0_RSP0_CPU0
EXIT_STATUS=0
SYSMGR_RESTART_REASON=0
AAA_USER=labuser
EXEC_PID=18280619
TASKID_MAP_SIZE=72
HOME=/disk0:/usr
TMPDIR=/disk0:/var/tmp
PWD=/disk0:/usr
```

Related Topics

- [show variables boot](#), on page 22
- [show version](#), on page 408
- [config-register](#), on page 2

system boot-sequence

To define the order of local storage devices used to boot a router, use the **system boot-sequence** command in EXEC or administration EXEC mode.

system boot-sequence {*primary-device* [*secondary-device*] | **disable**} [**location** {*node-id* | **all**}]

Syntax Description

<i>primary-device</i>	Default device where software packages are installed and run. This device is also the default location for router configurations. The value of the <i>primary-device</i> argument is normally disk0 .
<i>secondary-device</i>	(Optional) Secondary (backup) boot device, used by the system backup command to back up system software and configurations. Supported storage devices are: <ul style="list-style-type: none"> • disk0: • disk1: (if installed) • compactflash: (if installed) <p>Note The value of the <i>secondary-device</i> argument must be different from the value of the <i>primary-device</i> argument.</p>
disable	Temporarily disables the automatic recovery mechanism.
location { <i>node-id</i> all }	(Optional) Specifies the node of the RSP for which to define the boot sequence. The <i>node-id</i> argument is expressed in the <i>rack/slot/module</i> notation. The all keyword specifies all RSP nodes.

Command Default

The primary device is **disk0**. The (optional) secondary boot device is not defined.

Command Modes

EXEC

Administration EXEC

Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	No modification.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **system boot-sequence** command to define the local storage devices used to boot a router. You can define two devices with this command.

- The value of the *primary-device* argument defines the default device where software packages are installed and run. This device is also the default location for router configurations.

- The value of the *secondary-device* argument defines the device used by the **system backup** command to back up system software and configurations. This field is optional.
- The secondary device can also be temporarily defined when the **system backup** command is executed with the *target-device* argument. Use the **system boot-sequence** command with the *secondary-device* argument to permanently define the secondary (backup) device.



Note The **system backup** command is not supported on all platforms.



Note The primary and secondary device definitions remain in effect until the **system boot-sequence** command is entered again.

General Guidelines

- The value of the *secondary-device* argument must be different from the value of the *primary-device* argument.
- We recommend disk0: as the primary boot device in the boot sequence, and disk1: as the secondary boot device.
- The boot device specified with the **system boot-sequence** command must be installed in the card or the command is rejected.

Command Mode Options

- Use the **system boot-sequence** command in administration EXEC mode to define the boot sequence for the system.
- Use the **system boot-sequence** command in EXEC mode to define the boot sequence for a specific SDR.

Location Node

- Use the **location** *node-id* keyword and argument to define the boot sequence for a specific route switch processor (RSP).
- Use the **location all** keywords to define the boot sequence for all RSPs in the router.

Disabling Automatic Recovery

Use the **system boot-sequence** command with the **disable** keyword to disable the automatic recovery.

Displaying the Current Boot Sequence Settings

Enter the **show system backup** command to display the currently configured boot sequence devices.

Task ID	Task ID	Operations
	root-lr	read, write

The following example shows how to define the primary and secondary boot device for the active RSP (DSC). In this example, the default location for software and configurations is disk0. The location for backups of software and configurations is disk1.

```
RP/0/RSP0/CPU0:router# admin
RP/0/RSP0/CPU0:router(admin)# system boot-sequence disk0: disk1:

Info:  node0_0_CPU0: command succeeded.
```




Bulk Content Downloader (BCDL) Commands

This module describes the **show** commands that you can use to see the status of the Bulk Content Downloader (BCDL) process. The BCDL provides the Cisco IOS XR software with high-performance downloading capabilities. This capability is used by the following internal applications:

- IPv4 and IPv6 unicast routing protocols—To provide the ability to download forwarding information from the router Global Routing Information Base (GRIB) to the line cards.
- IPv4 and IPv6 multicast routing protocols—To download the Multicast Routing Information Base (MRIB) entries to consumers managing the Multicast Forwarding Information Base (MFIB) on the various line cards.
- MPLS—To download the Label Forwarding Information Base (LFIB) entries to the line card.
- Fabric Management—To update memberships for individual fabric group IDs (FGIDs) to selected portions of the fabric hardware.
- CDS—Context Distribution Service.

There is no configuration necessary for the BCDL.

- [show bcdl, on page 30](#)
- [show bcdl consumers, on page 32](#)
- [show bcdl queues, on page 34](#)
- [show bcdl tables, on page 35](#)
- [show bcdl trace, on page 37](#)

show bcdl

To display Bulk Content Downloader (BCDL) information, use the **show bcdl** command in

EXEC

mode.

show bcdl [*group_name*]

Syntax Description

group_name (Optional) Displays information for a specific BCDL group.

Command Default

No default behavior or values

Command Modes

EXEC

Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	No modification.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
sysmgr	read

The following example shows sample output from the **show bcdl** command:

```
RP/0/RSP0/CPU0:router# show bcdl ipv4_rib

Sun May 31 06:56:12.093 PST
grp ipv4_rib, gid 2040, sg cnt 1, agent jid 124, node 0/RSP0/CPU0, pulse 105,
new mbr 0
sg  lwg  fd  csmr  hdlr-act  dnld-act  susp  wait-lck  seq  pulse-tot  pulse-out
  0 2043 11   4         no         no    no         0 113         103         0
```

Table 5: show bcdl Field Descriptions

Field	Description
group	Type of download and the Group Services Protocol (GSP) group name.
gid	Heavyweight group (HWG) in the GSP. This is the group that a consumer initially joins. It is used by the BCDL agent to send control updates.

Field	Description
sg count	Number of subgroups for this particular download type.
agent.jid	Job identifier of the BCDL agent. The JID is numerical identifier for a particular process and remains the same across process restarts.
node	Node, expressed in the <i>rack/slot/module</i> notation, in which the agent is running.
pulse	Pulse code used by the producer to pulse the BCDL agent.
new mbr	Number of new consumers that have not yet been assigned a subgroup.
sg	Subgroups number.
lwg	Lightweight group in GSP. This is a type of child group of the HWG. The BCDL agent tells the consumers to join this group to receive data.
fd	The connection handle between the producer and the BCDL agent.
csmr	Number of consumers.
hdlr-act	Specifies if there is a download in progress.
dnld-act	Indicates whether the convergence flag has been sent or not.
susp	Indicates whether the download is suspended due to the queue filling up.
wait-lck	If nonzero, some thread is waiting for other thread to take control of this subgroup.
seq	Sequence number of the last message sent on this subgroup.
pulse-tot	Total number of pulses sent by the producer to the BCDL agent.
pulse-out	Total number of outstanding pulses that have not yet been processed by the BCDL agent.

show bcdl consumers

To display Bulk Content Downloader (BCDL) consumer information, use the **show bcdl consumers** command in

EXEC

mode.

show bcdl consumers [*group_name*]

Syntax Description	<i>group_name</i> (Optional) Displays information for a specific BCDL group.
---------------------------	--

Command Default	No default behavior or values
------------------------	-------------------------------

Command Modes	EXEC
----------------------	------

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---

Task ID	Task	Operations
	sysmgr	read

The following example shows sample output using the **show bcdl consumers** command:

```
RP/0/RSP0/CPU0:router# show bcdl consumers ipv4_rib

Sun May 31 06:17:38.209 PST
group ipv4_rib, gsp gid 2040, 4 consumers, agent jid 124, node 0/RSP0/CPU0
(expected 4 consumers to reply, received 4 replies)
  pid      node asg csg  lwg sus  messages      bytes  errs name
  ----  -
  323727 0/RSP0/CPU0  0  0 2043  N    113      54196    0 fib_mgr
  110686 0/6/CPU0    0  0 2043  N    111      54140    0 fib_mgr
  110686 0/4/CPU0    0  0 2043  N    112      54168    0 fib_mgr
  110686 0/1/CPU0    0  0 2043  N    111      54140    0 fib_mgr
```

This table describes the significant fields shown in the display that are not described in [Table 5: show bcdl Field Descriptions, on page 30](#).

Table 6: show bcdl consumers Field Descriptions

Field	Description
PID	Process identifier.
node	Consumer node, expressed in the <i>rack/slot/module</i> notation.
asg	Subgroup to which the BCDL agent thinks this consumer belongs.
csg	Subgroup to which the consumer thinks it belongs.
messages	Number of messages processed by this particular consumer.
bytes	Bytes processed by this particular consumer.
errors	Errors encountered by the consumer. This field indicates the number of times the connection was reset.
name	Name of the consumer process.

show bcdl queues

To display the Bulk Content Downloader (BCDL) queue information, use the **show bcdl queues** command in

EXEC

mode.

show bcdl queues [*group_name*]

Syntax Description	<i>group_name</i> (Optional) Displays information for a specific BCDL group.
---------------------------	--

Command Default	No default behavior or values
------------------------	-------------------------------

Command Modes	EXEC
----------------------	------

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---

Task ID	Task ID	Operations
	sysmgr	read

The following example shows sample output from the **show bcdl queues** command:

```
RP/0/RSP0/CPU0:router# show bcdl queues ipv4_rib

Sun May 31 07:13:28.665 PST
group ipv4_rib, gsp gid 2040, 4 consumers, agent jid 124, node 0/RSP0/CPU0
(expected 4 consumers to reply, received 4 replies)
  pid      node asg csg  lwg sus  msgs_in_q  bytes_in_q  errs name
  323727  0/RSP0/CPU0  0  0  2043  N          0            0      0 fib_mgr
  110686  0/6/CPU0    0  0  2043  N          0            0      0 fib_mgr
  110686  0/1/CPU0    0  0  2043  N          0            0      0 fib_mgr
  110686  0/4/CPU0    0  0  2043  N          0            0      0 fib_mgr
```

[Table 5: show bcdl Field Descriptions, on page 30](#) and [Table 6: show bcdl consumers Field Descriptions, on page 33](#) describe the significant fields shown in the display.

show bcdl tables

To display Bulk Content Downloader (BCDL) table information, use the **show bcdl tables** command in EXEC mode.

```
show bcdl tables [group_name]
```

Syntax Description	<i>group_name</i> Displays information for a specific BCDL group.
---------------------------	---

Command Default	No default behavior or values
------------------------	-------------------------------

Command Modes	EXEC
----------------------	------

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
Release 3.9.0	No modification.	

Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---

Task ID	Task ID	Operations
	sysmgr	read

The following example shows sample output using the **show bcdl tables** command:

```
RP/0/RSP0/CPU0:router# show bcdl tables ipv4_rib

Sun May 31 07:19:29.878 PST
grp ipv4_rib, gid 2040, sg cnt 1, agent jid 124, node 0/RSP0/CPU0, pulse 105, new mbr 0
  sg  lwg fd csmr hdlr-act dnld-act susp wait-lck  seq pulse-tot pulse-out
    0 2043 11  4      no      no  no      0  113      103      0
sgs: 1, table_cnt: 1, table_mid_cnt: 4, buf size: 100
Showing table info for 1 subgroups
sg 0: has 1 tables (messages: 0, bytes: 0)
  table 0xe0000000: 4 members, dnld act: 0, messages: 113, bytes: 54196
  cnsmr 0: pid 323727 on node 0/RSP0/CPU0
  cnsmr 1: pid 110686 on node 0/6/CPU0
  cnsmr 2: pid 110686 on node 0/1/CPU0
  cnsmr 3: pid 110686 on node 0/4/CPU0
```

The significant fields shown in the display that are not described in [Table 5: show bcdl Field Descriptions, on page 30](#) or [Table 6: show bcdl consumers Field Descriptions, on page 33](#) are described in this table.

Table 7: show bcdl tables Field Descriptions

Field	Description
sgs	Number of subgroups.
table_cnt	Number of tables in this subgroup.
sg	Specific subgroup for which information is provided.
has 1 tables	Number of tables in this subgroup.
messages	Messages sent that are not associated with a particular table ID.
bytes	Bytes sent that are not associated with a particular table ID.
table	Specific table ID for which information is provided.
members	Number of consumers associated with this table.
dnld act	Indicates whether or not the convergence flag has been sent.
messages	Number of messages sent for a particular table.
bytes	Number of bytes sent for a particular table.
cnsmr 0: pid 419725 on node 0/RP0/CPU0	Process ID and node information for each consumer in the specified table.

show bcdl trace

To display Bulk Content Downloader (BCDL) trace information, use the **show bcdl trace** command in EXEC mode.

```
show bcdl trace [group_name] [event] [timing] [grpsnd] [{wrapping|unique}] [hexdump] [last n] [reverse] [stats] [tailf] [verbose] [{file filename original location node-id | location {node-id | all}}]
```

Syntax Description	
<i>group_name</i>	(Optional) Displays information for a specific BCDL group.
event	(Optional) Displays event trace entries.
timing	(Optional) Displays timing trace entries.
grpsnd	(Optional) Displays group send trace entries.
wrapping	(Optional) Displays wrapping entries.
unique	(Optional) Displays unique entries only, along with the count of the number of times this entry appears.
hexdump	(Optional) Displays traces in hexadecimal format.
last n	(Optional) Displays the last <i>n</i> number of traces only.
reverse	(Optional) Displays the most recent traces first.
stats	(Optional) Displays execution path statistics.
tailf	(Optional) Displays new traces as they are added.
verbose	(Optional) Displays additional internal debugging information.
file filename original location node-id	(Optional) Specifies a filename and original location of the file to display.
location {node-id all}	Specifies the RP node for which to display the execution path monitoring information. The <i>node-id</i> argument is expressed in the <i>rack/slot/module</i> notation. The all keyword specifies all RP nodes.

Command Default None

Command Modes EXEC

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

show bcdl trace

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID**Task Operations**

Task ID	Task Operations
	sysmgr read

The following example shows sample output using the **show bcdl trace** command:

```
RP/0/RSP0/CPU0:router# show bcdl trace ipv4_rib location 0/1/cpu0

Sun May 31 08:21:07.933 PST
143 wrapping entries (4096 possible, 0 filtered, 143 total)
May 21 15:14:55.790 bcdl/c/ipv4_rib 0/1/CPU0 t4 LE
  bcdl_join_internal: timer_create ret 0, id is 9
May 21 15:14:56.890 bcdl/c/ipv4_rib 0/1/CPU0 t7 LE
  bcdl_join_internal: group_lookup bcdl_ipv4_rib
  returned gid 2040
May 21 15:14:56.966 bcdl/c/ipv4_rib 0/1/CPU0 t7 LE
  join hwg 2040 returns 0
May 21 15:14:56.978 bcdl/c/ipv4_rib 0/1/CPU0 t7 LE
  bcdl_join_internal: joined group bcdl_ipv4_rib,
  member count 5
May 21 15:14:58.969 bcdl/c/ipv4_rib 0/1/CPU0 t7 LE
  rcv gsp mtype 3: connection init sg 1 cur_seq 0
  lwg_gid 2056 table tag 0x00000000 resend state yes
May 21 15:14:58.969 bcdl/c/ipv4_rib 0/1/CPU0 t7 LE
  pc ring high water 0 -> 1, 0 bytes
May 21 15:14:58.969 bcdl/c/ipv4_rib 0/1/CPU0 t4 LE
  c_h deliver msg_id 7 connection init, table event
  0 table tag 0x00000000
May 21 15:14:58.969 bcdl/c/ipv4_rib 0/1/CPU0 t4 LE
  conn init, seq 64206 -> 0, sg 65534 -> 1, gid 2040,
  lwg gid -1 -> 2056
...
```



Call Home Commands

This module describes the Cisco IOS XR software commands for configuring and sending Call Home messages.

For detailed information about Call Home concepts, configuration tasks, and examples, see the *Configuring Call Home on Cisco IOS XR Software* module in *System Management Configuration Guide for Cisco ASR 9000 Series Routers*.

- [active](#), on page 41
- [alert-group disable](#), on page 42
- [call-home](#), on page 43
- [call-home request](#), on page 44
- [call-home send](#), on page 46
- [call-home send alert-group inventory](#), on page 48
- [call-home test](#), on page 49
- [contact smart-licensing](#), on page 50
- [contact-email-addr](#), on page 51
- [contract-id](#), on page 52
- [customer-id](#), on page 53
- [destination address](#), on page 54
- [destination message-size-limit](#), on page 55
- [destination preferred-msg-format](#), on page 56
- [destination transport-method](#), on page 57
- [mail-server](#), on page 58
- [phone-number](#), on page 60
- [profile \(call home\)](#), on page 61
- [rate-limit](#), on page 62
- [sender](#), on page 63
- [service active](#), on page 64
- [show call-home](#), on page 65
- [show call-home alert-group](#), on page 67
- [show call-home mail-server status](#), on page 68
- [show call-home profile](#), on page 69
- [show call-home statistics](#), on page 71
- [show call-home trace](#), on page 73
- [site-id](#), on page 75
- [street-address](#), on page 76

- [subscribe-to-alert-group environment](#), on page 77
- [subscribe-to-alert-group inventory](#), on page 79
- [subscribe-to-alert-group syslog](#), on page 81

active

To enable a Call Home profile, use the **active** command in call home profile configuration mode. To disable a profile, use the **no** form of this command.

active
no active

Syntax Description This command has no keywords or arguments.

Command Default A profile is disabled by default.

Command Modes Call home configuration

Command History	Release	Modification
	Release 4.1.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

You must enable a profile using the **active** command so that call home messages can be triggered.

Task ID	Task ID	Operation
	call-home	read, write

The following example shows how to activate a profile:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config) call-home
RP/0/RSP0/CPU0:router(config-call-home)# profile my-profile
RP/0/RSP0/CPU0:router(config-call-home-profile)# active
```

Related Topics

[call-home](#), on page 43

[profile \(call home\)](#), on page 61

alert-group disable

To disable an individual Call Home alert-group, use the **alert group disable** command in call home configuration mode. To enable an individual Call Home alert-group, use the **no** form of this command.

alert-group *alert-group-name* **disable**
no alert-group *alert-group-name* **disable**

Syntax Description	<i>alert-group-name</i> A keyword that identifies an alert group. Valid values are: <ul style="list-style-type: none"> • syslog • environment • inventory
---------------------------	--

Command Default	Alert groups are enabled by default.
------------------------	--------------------------------------

Command Modes	Call home configuration
----------------------	-------------------------

Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 4.1.0</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 4.1.0	This command was introduced.
Release	Modification				
Release 4.1.0	This command was introduced.				

Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---

By default, alert groups are enabled. Use the **alert-group disable** command to disable alert groups.

Task ID	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operation</th> </tr> </thead> <tbody> <tr> <td>call-home</td> <td>read, write</td> </tr> </tbody> </table>	Task ID	Operation	call-home	read, write
Task ID	Operation				
call-home	read, write				

Example

The following example shows how to disable the inventory alert group:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config) call-home
RP/0/RSP0/CPU0:router(config-call-home) # alert-group inventory disable
```

Related Commands	<table border="1"> <thead> <tr> <th>Command</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>call-home, on page 43</td> <td>Enters call home configuration mode to configure the call home feature.</td> </tr> </tbody> </table>	Command	Description	call-home, on page 43	Enters call home configuration mode to configure the call home feature.
Command	Description				
call-home, on page 43	Enters call home configuration mode to configure the call home feature.				

call-home

To enter call home configuration mode to configure Call Home, use the **call-home** command in global configuration mode. To remove all Call Home settings and set the technical assistance center (TAC) profile as the default, use the **no** form of this command.

call-home
no call-home

Syntax Description This command has no keywords or arguments.

Command Default None

Command Modes Global configuration

Command History	Release	Modification
	Release 4.1.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operation
	call-home	read, write

The following example shows how to enter call home configuration mode:

```
RP/0/RSP0/CPU0:router(config)# call-home
RP/0/RSP0/CPU0:router(config-call-home)#
```

Related Commands	Command	Description
	show call-home, on page 65	Displays information regarding the Call Home configuration.

call-home request

To send a customer request to Cisco, use the **call-home request** command in EXEC mode.

```
call-home request {bugs-list | command-reference | config-sanity | output-analysis "show-command"
| product-advisory} {ccoid ccoid | profile profile-name}
```

Syntax	Description
bugs-list	Sends output of the following commands: <ul style="list-style-type: none"> • show running-config sanitized • show version • show diag
command-reference	Sends output of the following commands: <ul style="list-style-type: none"> • show running-config sanitized • show version • show diag
config-sanity	Sends output of the following commands: <ul style="list-style-type: none"> • show running-config sanitized • show version
output-analysis <i>show-command</i>	Sends output from the specified show command. The <i>show-command</i> argument should be enclosed in quotes ("").
product-advisory	Sends output of all commands included in the inventory message in addition to the output from the show running-config sanitized command.
ccoid <i>ccoid</i>	Specifies the Smart Call Home user registered ID.
profile <i>profile-name</i>	Specifies the profile to which to send the message.

Command Default None

Command Modes EXEC

Command History	Release	Modification
	Release 4.1.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The message uses the specified profile or the CiscoTAC-1 profile if no profile name is specified to send out the request the the Cisco backend. This ensures that users who use a transport gateway can use a different profile than the CiscoTAC-1 profile to send the request to their email server first before forwarding to the Cisco backend. CiscoTAC-1 or any profile specified needs to be enabled before you can send out the request.

If the CCO ID is not specified, the contact email address of the device is used.

Each message sent includes the CLI command output specified for each subcommand. After the message is sent, a syslog message is displayed indicating whether the request was sent successfully or not.

Task ID**Task ID Operation**

call-home read,
write

The following example shows how to send a message with output from the **show version** command to engineer@cisco.com:

```
RP/0/RSP0/CPU0:router(config)# call-home request config-sanity ccoid
xyz
RP/0/RSP0/CPU0:router(config)# call-home request bugs-list
RP/0/RSP0/CPU0:router(config)# call-home request output-analysis "show log"
profile TG
RP/0/RSP0/CPU0:router(config)# call-home request output-analysis "show
running-config"
```

Related Commands

Command	Description
call-home, on page 43	Enters call home configuration mode to configure the call home feature.
show call-home, on page 65	Displays information regarding the Call Home configuration.

call-home send

To send the output from a specific command as a Call Home message, use the **call-home send** command in EXEC mode.

```
call-home send "cli-command" {email email-address | tac-service-request service-number}
```

Syntax Description		
<i>cli-command</i>		Any CLI command that can be run at the prompt.
email <i>email-address</i>		Specifies the email address to which to send the call home message.
tac-service-request <i>service-number</i>		Specifies the Technical Assistance Center (TAC) service request number.

Command Default If no email address is specified, attach@cisco.com is used.

Command Modes EXEC

Command History	Release	Modification
	Release 4.1.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The specified CLI command is generally a show command with output that is required by the TAC to analyze a specific issue. The CLI command must be enclosed in quotes. The CLI command output is sent to the specified email address in long text format with the service request number in the subject of the email. If no email address is specified, the TAC service request number must be specified. By default, messages are sent to attach@cisco.com. If no TAC service request number is specified, TAC email is rejected.

Task ID	Task ID	Operation
	call-home	read, write

The following example shows how to send a message with output from the **show version** command to engineer@cisco.com:

```
RP/0/RSP0/CPU0:router (config) # call-home send "show version" engineer@cisco.com
```

Related Commands	Command	Description
	call-home , on page 43	Enters call home configuration mode to configure the call home feature.

Command	Description
show call-home, on page 65	Displays information regarding the Call Home configuration.

call-home send alert-group inventory

To send an inventory Call Home message to all subscribed profiles or the specified profile, use the **call-home send alert-group inventory** command in EXEC mode.

call-home send alert-group inventory [**profile** *profile-name*]

Syntax Description	profile <i>profile-name</i>	Specifies the profile to which to send the inventory Call Home message.
---------------------------	------------------------------------	---

Command Default If no profile is specified, the message is sent to all subscribed profiles.

Command Modes EXEC

Command History	Release	Modification
	Release 4.1.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The profile specified by the *profile-name* argument does not need to be subscribed to the inventory alert-group.

Task ID	Task ID	Operation
	call-home	read, write

The following example shows how to send an inventory message to the myprofile profile:

```
RP/0/RSP0/CPU0:router(config)# call-home send alert-group inventory profile myprofile
```

Related Commands	Command	Description
	call-home, on page 43	Enters call home configuration mode to configure the call home feature.
	show call-home, on page 65	Displays information regarding the Call Home configuration.

call-home test

To send a test Call Home message to the specified profile, use the **call-home test** command in EXEC mode.

call-home test [*test-message-text*] **profile** *profile-name*

Syntax Description	<i>test-message-text</i>	Text to be sent in the test message. If the message text is not specified, a default message is sent.
	profile <i>profile-name</i>	Specifies the profile to which to send the test call home message.

Command Default None

Command Modes EXEC

Command History	Release	Modification
	Release 4.1.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operation
	call-home	read, write

The following example shows how to send a test Call Home message:

```
RP/0/RSP0/CPU0:router(config)# call-home test "this is a test message" profile myprofile
```

Related Commands	Command	Description
	call-home, on page 43	Enters call home configuration mode to configure the call home feature.
	show call-home, on page 65	Displays information regarding the Call Home configuration.

contact smart-licensing

To send notification emails to your Smart Licensing account, use **contact smart-licensing** command in the **call-home** configuration mode. To disable the contact, use the **no** form of this command.

contact smart-licensing
no contact smart-licensing

Syntax Description This command has no keywords or arguments.

Command Default **contact smart-licensing** is not configured.

Command Modes **call-home** configuration mode.

Command History	Release	Modification
	Release 6.1.2	This command was introduced.

Usage Guidelines The Smart Call Home back-end service uses the email address configured in your Smart Licensing account as the destination address for the notification mails. Enabling Smart Licensing also enables call-home which changes several mandatory configurations in call-home. **contact smart-licensing** is one of the configurations that is automatically added when you enable smart-licensing.



Note The **contact-email-addr** command and the **contact smart-licensing** command cannot be configured simultaneously.

Task ID	Task ID	Operation
	call-home	Read, Write

Example

This example shows how to configure the contact email address:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# call-home
RP/0/RSP0/CPU0:router(config-call-home)# contact smart-licensing
```

contact-email-addr

To specify a contact email address for the system, use the **contact-email-addr** command in call home configuration mode. To disable the contact email address, use the **no** form of this command.

contact-email-addr *email-addr*
no contact-email-addr *email-addr*

Syntax Description

email-addr The email address of the system contact.

Command Default

No contact email address is defined.

Command Modes

Call home configuration

Command History

Release	Modification
Release 4.1.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The contact email address is a mandatory user-configurable field that must be configured before Call Home messages are triggered.

Task ID

Task ID	Operation
call-home	read, write

The following example shows how to configure the contact email address:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config) call-home
RP/0/RSP0/CPU0:router(config-call-home)# contact-email-addr contact@cisco.com
```

contract-id

To specify a contract identifier for the system, use the **contract-id** command in call home configuration mode. To disable the contract identifier, use the **no** form of this command.

contract-id *contract-id-string*
no contract-id *contract-id-string*

Syntax Description

contract-id-string A string that identifies a service contract.

Command Default

No contract ID is defined.

Command Modes

Call home configuration

Command History

Release	Modification
Release 4.1.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The contract ID is an optional user-configurable field that can be used for contract information or any other identification information for the support service.

Task ID

Task ID	Operation
call-home	read, write

The following example shows how to configure the contract ID:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config) call-home
RP/0/RSP0/CPU0:router(config-call-home) # contract-id contract
```


customer-id

To specify a customer identifier for the system, use the **customer-id** command in call home configuration mode. To disable the customer identifier, use the **no** form of this command.

customer-id *contract-id-string*
no customer-id *contract-id-string*

Syntax Description

customer-id-string A string that identifies the customer.

Command Default

No customer ID is defined.

Command Modes

Call home configuration

Command History

Release	Modification
Release 4.1.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The customer ID is an optional user-configurable field that can be used for contract information or any other identification information of a support service.

Task ID

Task ID	Operation
call-home	read, write

The following example shows how to configure the customer ID:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config) call-home
RP/0/RSP0/CPU0:router(config-call-home)# customer-id cisco
```

destination address

To specify an email address to which Call Home messages are sent, use the **destination address** command in call home profile configuration mode. To disable the contract identifier, use the **no** form of this command.

destination address *email-address*
no destination address *email-address*

Syntax Description	<i>email-address</i> Email address to which short-text and long-text Call Home messages and XML-based Call Home messages are to be sent.
---------------------------	--

Command Default	No destination email address is defined.
------------------------	--

Command Modes	Call home profile configuration
----------------------	---------------------------------

Command History	Release	Modification
	Release 4.1.0	This command was introduced.

Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---

You must define a destination email address to send out Call Home messages.

Task ID	Task ID	Operation
	call-home	read, write

The following example shows how to configure the destination email address:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config) call-home
RP/0/RSP0/CPU0:router(config-call-home)# profile my-profile
RP/0/RSP0/CPU0:router(config-call-home-profile)# destination address user@cisco.com
```

Related Commands	Command	Description
	profile (call home), on page 61	Enters call home profile configuration mode to create or configure a Call Home profile.

destination message-size-limit

To specify the message size limit for call home messages for a specific profile, use the **destination message-size-limit** command in Call Home profile configuration mode. To disable the message size limit, use the **no** form of this command.

destination message-size-limit *maximum-size*
no destination message-size-limit *maximum-size*

Syntax Description	<i>maximum-size</i> Maximum message size in bytes.
---------------------------	--

Command Default	The default maximum message size is 3 Mbytes.
------------------------	---

Command Modes	Call home profile configuration
----------------------	---------------------------------

Command History	Release	Modification
	Release 4.1.0	This command was introduced.

Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---

The destination maximum message size can be optionally set to limit the size of Call Home messages.

Task ID	Task ID	Operation
	call-home	read, write

The following example shows how to configure the contract ID:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config) call-home
RP/0/RSP0/CPU0:router(config-call-home)# profile my-profile
RP/0/RSP0/CPU0:router(config-call-home-profile)# destination maximum-message-size 2000
```

Related Commands	Command	Description
	profile (call home), on page 61	Enters call home profile configuration mode to create or configure a Call Home profile.

destination preferred-msg-format

To specify the message format for a profile, use the **destination preferred-msg-format** command in call home profile configuration mode. To revert to the default message format, use the **no** form of this command.

destination preferred-msg-format {long-text | short-text | xml}
no destination preferred-msg-format {long-text | short-text | xml}

Syntax Description

long-text	Specifies to send clear text long Call Home messages, that contain formatting to enable easy readability.
short-text	Specifies to send clear text short Call Home messages, that are designed for use with text pagers.
xml	Specifies to send the same text as the long text messages, with the addition of XML tagging and Adaptive Messaging Language (AML) specific transport information to allow machine-readable parsing and correct routing of the message.

Command Default

The default message format is xml.

Command Modes

Call home profile configuration

Command History

Release	Modification
Release 4.1.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operation
call-home	read, write

The following example shows how to configure the message format to short text:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config) call-home
RP/0/RSP0/CPU0:router(config-call-home) # profile my-profile
RP/0/RSP0/CPU0:router(config-call-home-profile) # destination preferred-msg-format short-text
```

Related Commands

Command	Description
profile (call home), on page 61	Enters call home profile configuration mode to create or configure a Call Home profile.

destination transport-method

To specify the transport method for Call Home messages for a specific profile, use the **destination transport-method** command in call home profile configuration mode. To disable the transport method, use the **no** form of this command.

destination transport-method email
no destination transport-method email

Syntax Description	email Email is used to send call home messages.
---------------------------	--

Command Default	The default transport method is email.
------------------------	--

Command Modes	Call home profile configuration
----------------------	---------------------------------

Command History	Release	Modification
	Release 4.1.0	This command was introduced.

Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---

The only transport method supported in this release is email.

Task ID	Task ID	Operation
	call-home	read, write

The following example shows how to configure the transport method to be email:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config) call-home
RP/0/RSP0/CPU0:router(config-call-home)# profile my-profile
RP/0/RSP0/CPU0:router(config-call-home-profile)# destination transport-method email
```

Related Commands	Command	Description
	profile (call home), on page 61	Enters call home profile configuration mode to create or configure a Call Home profile.

mail-server

To specify and configure the various mail servers for sending Call Home messages, use the **mail-server** command in call home configuration mode. To remove the mail server configuration, use the **no** form of this command.

mail-server *{ip-addressname}* **priority** *priority*
no mail-server *{ip-addressname}* **priority** *priority*

Syntax Description		
	<i>ip-address</i>	An IPv4 address to use as the mail server.
	<i>name</i>	Name of server to use as the mail server.
	priority <i>priority</i>	Priority to be used to determine which of multiple configured servers to use as the mail server. Values can be from 1 to 100. A server with a lower priority is tried first.

Command Default No mail server is defined.

Command Modes Call home configuration

Command History	Release	Modification
	Release 4.1.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

You must configure a mail server if the user profile is configured to send email messages only. Only IPv4 addresses are supported.

Up to five mail servers can be configured. Specify a priority for each mail server so the system knows which to try first.

Task ID	Task ID	Operation
	call-home	read, write

The following example shows how to configure a mail server:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config) call-home
RP/0/RSP0/CPU0:router(config-call-home) # email-server 209.165.200.225
```

Related Commands	Command	Description
	call-home, on page 43	Enters call home configuration mode to configure the call home feature.

phone-number

To specify a phone number to contact regarding the system, use the **phone-number** command in call home configuration mode. To remove the configured phone number, use the **no** form of this command.

phone-number *phone-number-string*
no phone-number *phone-number-string*

Syntax Description	<i>phone-number-string</i> Phone number of the contact for the system. The number should always begin with a plus sign (+).
---------------------------	---

Command Default	No phone number is defined.
------------------------	-----------------------------

Command Modes	Call home configuration
----------------------	-------------------------

Command History	Release	Modification
	Release 4.1.0	This command was introduced.

Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---

The phone number is an optional user-configurable field.

Task ID	Task ID	Operation
	call-home	read, write

The following example shows how to configure the phone number of the system contact:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config) call-home
RP/0/RSP0/CPU0:router(config-call-home) # phone-number +15435432101
```


profile (call home)

To enter call home profile configuration mode to create a user-defined profile or configure an existing Call Home profile, use the **profile** command in call home configuration mode. To delete a user-defined profile, use the **no profile** form of this command.

profile *profile-name*
no profile *profile-name*

Syntax Description	<i>profile-name</i> A string that identifies the name of profile to create or configure.
---------------------------	--

Command Default	The tac profile exists by default.
------------------------	------------------------------------

Command Modes	Call home configuration
----------------------	-------------------------

Command History	Release	Modification
	Release 4.1.0	This command was introduced.

Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---

Use the profile command to create a new profile or modify an existing profile. When you use the **no profile** command, the user-defined profile is deleted and the CiscoTAC-1 profile is set to default. A warning message is displayed when the CiscoTAC-1 profile is set to default.

Task ID	Task ID	Operation
	call-home	read, write

The following example shows how to create a profile called new-profile:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config) call-home
RP/0/RSP0/CPU0:router(config-call-home)# profile new-profile
RP/0/RSP0/CPU0:router(config-call-home-profile)#
```

Related Commands	Command	Description
	active, on page 41	Enables a Call Home profile.
	destination address, on page 54	Specifies an email address to which Call Home messages are sent.

rate-limit

To specify a Call Home event trigger rate limit, use the **rate-limit** command in call home configuration mode. To disable the configured rate limit, use the **no** form of this command.

rate-limit *events-count*
no rate-limit *events-count*

Syntax Description

events-count Number of events that can be triggered per minute. The default is five events. The maximum is five events.

Command Default

5 events per minute

Command Modes

Call home configuration

Command History

Release	Modification
Release 4.1.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operation
call-home	read, write

Example

The following example shows how to configure the rate limit to be 3 events per minute:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config) call-home
RP/0/RSP0/CPU0:router(config-call-home) # rate-limit 3
```

sender

To specify the from and reply-to email addresses for Call Home email messages, use the **sender** command in call-home configuration mode. To remove these email addresses from the configuration, use the **no** form of this command.

```
sender {from | reply-to} email-address
no sender {from | reply-to} email-address
```

Syntax Description	from	Specifies the email address to be used as the from field in Call Home email messages.
	reply-to	Specifies the email address to be used as the reply-to field in Call Home email messages.
	<i>email-address</i>	A string that identifies a valid email address.

Command Default No sender email is configured.

Command Modes Call-home configuration

Command History	Release	Modification
	Release 4.1.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operation
	call-home	read, write

The following example shows how to configure the from and reply-to email addresses:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config) call-home
RP/0/RSP0/CPU0:router(config-call-home) # sender from user1@cisco.com
RP/0/RSP0/CPU0:router(config-call-home) # sender reply-to user1@cisco.com
```

service active

To enable the Call Home capability, use the **service active** command in call home configuration mode. To disable the Call Home capability, use the **no** form of this command.

service active
no service active

Syntax Description This command has no keywords or arguments.

Command Default Call Home is disabled by default.

Command Modes Call home configuration

Command History	Release	Modification
	Release 4.1.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

It is mandatory to enable the Call Home capability using the **service active** command to allow events to get triggered and send out Call Home messages.

Task ID	Task ID	Operation
	call-home	read, write

The following example shows how to enable the Call Home capability:

```
RP/0/RSP0/CPU0:router (config-call-home) # service active
```

show call-home

To display information regarding the Call Home configuration, use the **show call-home** command in EXEC mode.

show call-home [detail]

Syntax Description	detail	Displays Call Home general settings, alert group settings, and all available profiles.				
Command Default	None					
Command Modes	EXEC					
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 4.1.0</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 4.1.0	This command was introduced.	
Release	Modification					
Release 4.1.0	This command was introduced.					
Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.					
Task ID	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operation</th> </tr> </thead> <tbody> <tr> <td>call-home</td> <td>read</td> </tr> </tbody> </table>	Task ID	Operation	call-home	read	
Task ID	Operation					
call-home	read					

The following example shows how to display detailed call home configuration information:

```
RP/0/RSP0/CPU0:router# show call-home detail

Wed Apr  6 02:00:27.789 DST

Current call home settings:
  call home feature : disable
  call home message's from address: Not yet set up
  call home message's reply-to address: Not yet set up

  contact person's email address: Not yet set up

  contact person's phone number: Not yet set up
  street address: Not yet set up
  customer ID: Not yet set up
  contract ID: Not yet set up
  site ID: Not yet set up

Mail-server: Not yet set up
Rate-limit: 5 event(s) per minute

Available alert groups:
  Keyword                State  Description
  -----
  environment            Enable environmental info
```

```

inventory          Enable  inventory info
syslog             Enable  syslog info

```

Profiles:

```

Profile Name: CiscoTAC-1
Profile status: INACTIVE
Preferred Message Format: xml
Message Size Limit: 3145728 Bytes
Transport Method: email
Email address(es): callhome@cisco.com

```

Periodic inventory info message is scheduled every 24 day of the month at 16:35

```

Alert-group          Severity
-----
environment          minor
inventory            normal

Syslog-Pattern      Severity
-----
.*                   major

```

Related Commands	Command	Description
	call-home, on page 43	Enters call home configuration mode to configure the call home feature.

show call-home alert-group

To display available Call Home alert groups, use the **show call-home alert-group** command in EXEC mode.

show call-home alert-group

Syntax Description This command has no keywords or arguments.

Command Default None

Command Modes EXEC

Command History	Release	Modification
	Release 4.1.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operation
	call-home	read, write

The following example shows how to display Call Home alert group information:

```
RP/0/RSP0/CPU0:router# show call-home alert-group
```

```
Tue Apr 5 06:51:02.860 DST
```

```
Available alert groups:
```

Keyword	State	Description
environment	Enable	environmental info
inventory	Enable	inventory info
syslog	Enable	syslog info

show call-home mail-server status

To displays the status of the configured mail servers, use the **show call-home mail-server status** command in EXEC mode.

show call-home mail-server status

Syntax Description This command has no keywords or arguments.

Command Default None

Command Modes EXEC

Command History	Release	Modification
	Release 4.1.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operation
	call-home	read

The following example shows sample output from the **show call-home mail-server status** command:

```
RP/0/RSP0/CPU0:router# show call-home mail-server status

Please wait. Checking for mail server status ...

Mail-server[1]: Address: 64.102.124.15 Priority: 50 [Available]
```

Related Commands	Command	Description
	call-home, on page 43	Enters call home configuration mode to configure the call home feature.

show call-home profile

To display the Call Home profiles, use the **show call-home profile** command in EXEC mode.

show call-home profile {*allprofile-name*}

Syntax Description	all	Displays information for all profiles.
	<i>profile-name</i>	Name of the profile for which to display information.
Command Default	None	
Command Modes	EXEC	
Command History	Release	Modification
	Release 4.1.0	This command was introduced.
Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.	
Task ID	Task ID	Operation
	call-home	read

The following example shows sample output from the **show call-home profile** command:

```
RP/0/RSP0/CPU0:router# show call-home profile CiscoTAC-1

Profile Name: CiscoTAC-1
  Profile status: INACTIVE
  Preferred Message Format: xml
  Message Size Limit: 3145728 Bytes
  Transport Method: email
  Email address(es): callhome@cisco.com

Periodic inventory info message is scheduled every 4 day of the month at 12:19

Alert-group          Severity
-----
environment          minor

Syslog-Pattern      Severity
-----
.*                  major
```

Related Commands	Command	Description
	call-home, on page 43	Enters call home configuration mode to configure the call home feature.

show call-home statistics

To display Call Home statistics, use the **show call-home statistics** command in EXEC mode.

show call-home statistics

Syntax Description This command has no keywords or arguments.

Command Default None

Command Modes EXEC

Command History	Release	Modification
	Release 4.1.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operation
	call-home	read

The following example shows sample output from the **show call-home statistics** command:

```
RP/0/RSP0/CPU0:router# show call-home statistics

Message Types      Total      Email
-----
Total Success     2          2
  Environment     0          0
  Inventory       2          2
  SysLog          0          0
  Test            0          0
  Request         0          0
  Send-CLI       0          0

Total In-Queue    0          0
  Environment     0          0
  Inventory       0          0
  SysLog          0          0
  Test            0          0
  Request         0          0
  Send-CLI       0          0

Total Failed      0          0
  Environment     0          0
  Inventory       0          0
  SysLog          0          0
  Test            0          0
  Request         0          0
  Send-CLI       0          0
```

show call-home statistics

```

Total Ratelimit
  -dropped 0          0
Environment 0         0
Inventory  0         0
SysLog     0         0
Test       0         0
Request    0         0
Send-CLI   0         0

```

```
Last call-home message sent time: 2010-04-21 01:06:44 GMT+00:00
```

Related Commands

Command	Description
call-home, on page 43	Enters call home configuration mode to configure the call home feature.

show call-home trace

To display Call Home trace information, use the **show call-home trace** command in EXEC mode.

```
show call-home trace {all | error | event} {file filename original location node-id | hexdump | last
n | location {node-id | all} | reverse | stats | tailf | unique | verbose | wrapping}
```

Syntax Description	
all	(Optional) Displays both error and event traces.
error	(Optional) Displays error trace entries.
event	(Optional) Displays event trace entries.
file filename original location node-id	(Optional) Specifies a filename and original location of the file to display.
hexdump	(Optional) Displays traces in hexadecimal format.
last n	(Optional) Displays the last <i>n</i> number of traces only.
location {node-id all}	Specifies the RP node for which to display the execution path monitoring information. The <i>node-id</i> argument is expressed in the <i>rack/slot/module</i> notation. The all keyword specifies all RP nodes.
reverse	(Optional) Displays the most recent traces first.
stats	(Optional) Displays execution path statistics.
tailf	(Optional) Displays new traces as they are added.
unique	(Optional) Displays unique entries only, along with the count of the number of times this entry appears.
verbose	(Optional) Displays additional internal debugging information.
wrapping	(Optional) Displays wrapping entries.

Command Default None

Command Modes EXEC

Command History	Release	Modification
	Release 4.1.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operation
	call-home	read

The following example shows how to display Call Home trace information:

```
RP/0/RSP0/CPU0:router# show call-home trace event last 15 stats

Wed Apr  6 05:11:59.984 DST
/dev/shmem/ltrace/call_home/trace wrapping: 28.672 Mbytes/sec for 512 entries
59 wrapping entries (512 possible, 0 filtered, 59 total)
Mar  3 13:26:20.281 call_home/trace 0/RSP0/CPU0 t14 Checking mail server access during
boot-up
Mar  3 13:26:20.281 call_home/trace 0/RSP0/CPU0 t9  processing mail server status checking
event: data1 0x5005784c, str1
Mar  3 13:27:20.283 call_home/trace 0/RSP0/CPU0 t9  Checking mail server access during
boot-up
Mar  3 13:27:20.283 call_home/trace 0/RSP0/CPU0 t14 processing mail server status checking
event: data1 0x5005784c, str1
Mar  3 13:28:20.285 call_home/trace 0/RSP0/CPU0 t14 Checking mail server access during
boot-up
Mar  3 13:28:20.285 call_home/trace 0/RSP0/CPU0 t9  processing mail server status checking
event: data1 0x5005784c, str1
Mar  3 13:29:20.287 call_home/trace 0/RSP0/CPU0 t9  Checking mail server access during
boot-up
Mar  3 13:29:20.287 call_home/trace 0/RSP0/CPU0 t14 processing mail server status checking
event: data1 0x5005784c, str1
Mar  3 13:30:20.289 call_home/trace 0/RSP0/CPU0 t14 Checking mail server access during
boot-up
Mar  3 13:30:20.289 call_home/trace 0/RSP0/CPU0 t9  processing mail server status checking
event: data1 0x5005784c, str1
Mar  3 13:31:20.290 call_home/trace 0/RSP0/CPU0 t9  Checking mail server access during
boot-up
Mar  3 13:31:20.290 call_home/trace 0/RSP0/CPU0 t14 processing mail server status checking
event: data1 0x5005784c, str1
Mar  3 13:32:21.067 call_home/trace 0/RSP0/CPU0 t14 Checking mail server access during
boot-up
Mar  3 13:32:21.067 call_home/trace 0/RSP0/CPU0 t9  processing mail server status checking
event: data1 0x5005784c, str1
Mar  3 13:33:21.069 call_home/trace 0/RSP0/CPU0 t9  Checking mail server access during
boot-up
```

Related Commands	Command	Description
	call-home, on page 43	Enters call home configuration mode to configure the call home feature.

site-id

To specify a site identifier for the system, use the **site-id** command in call-home configuration mode. To disable the site identifier, use the **no** form of this command.

site-id *site-id-string*
no site-id *site-id-string*

Syntax Description	<i>site-id-string</i> A string that identifies the site.				
Command Default	No site ID is defined.				
Command Modes	Call-home configuration				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 4.1.0</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 4.1.0	This command was introduced.
Release	Modification				
Release 4.1.0	This command was introduced.				

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The site ID is an optional user-configurable field that can be used to specify a Cisco-supplied site ID or other data meaningful to the support service.

Task ID	Task ID	Operation
	call-home	read, write

This example shows how to configure the site ID:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config) call-home
RP/0/RSP0/CPU0:router(config-call-home)# site-id Cisco-site
```

street-address

To specify the street address of the system, use the **street-address** command in call home configuration mode. To remove the street address configuration, use the **no** form of this command.

street-address *street-address*
no street-address *street-address*

Syntax Description

street address A string that identifies the street address of the system.

Command Default

No street address is defined.

Command Modes

Call home configuration

Command History

Release	Modification
Release 4.1.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The street address is an optional user-configurable field that can be used to provide the address of the system to the support service.

Task ID

Task ID	Operation
call-home	read, write

This example shows how to configure the street address:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config) call-home
RP/0/RSP0/CPU0:router(config-call-home)# street-address 170 West Tasman Dr.
San Jose, CA 95134 USA
```


subscribe-to-alert-group environment

To configure a destination profile to receive messages for the environment alert group, use the **subscribe-to-alert-group environment** command in call home profile configuration mode. To disable the subscription, use the **no** form of this command.

subscribe-to-alert-group environment severity severity-level
no subscribe-to-alert-group environment severity severity-level

Syntax Description	<p>severity Specifies the the lowest level of severity events to include in an environment alert.</p> <p><i>severity-level</i></p> <ul style="list-style-type: none"> • catastrophic—Includes network-wide catastrophic events in the alert. This is the highest severity. • critical—Includes events requiring immediate attention (system log level 1). • debugging—Includes debug events (system log level 7). This is the lowest severity. • disaster—Includes events with significant network impact. • fatal—Includes events where the system is unusable (system log level 0). • major—Includes events classified as major conditions (system log level 2). • minor—Includes events classified as minor conditions (system log level 3) • normal—Specifies the normal state and includes events classified as informational (system log level 6). This is the default. • notification—Includes events informational message events (system log level 5). • warning—Includes events classified as warning conditions (system log level 4). 				
Command Default	The environment alert group is disabled by default. The default severity for the environment alert group is debugging.				
Command Modes	Call home profile configuration				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 4.1.0</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 4.1.0	This command was introduced.
Release	Modification				
Release 4.1.0	This command was introduced.				
Usage Guidelines	<p>To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.</p> <p>At least one alert group subscription is mandatory for a profile so that a valid event can be triggered.</p>				

Task ID	Task ID	Operation
	call-home	read, write

The following example shows how to configure the environment alert group to include severity major:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config) call-home
RP/0/RSP0/CPU0:router(config-call-home) # profile my-profile
RP/0/RSP0/CPU0:router(config-call-home-profile) # subscribe-to-alert-group environment major
```

Related Commands	Command	Description
	profile (call home), on page 61	Enters call home profile configuration mode to create or configure a Call Home profile.
	subscribe-to-alert-group syslog, on page 81	Configures a destination profile to receive messages for the syslog alert group.
	subscribe-to-alert-group inventory, on page 79	Configures a destination profile to receive messages for the inventory alert group.

subscribe-to-alert-group inventory

To configure a destination profile to receive messages for the inventory alert group, use the **subscribe-to-alert-group inventory** command in call home profile configuration mode. To disable the subscription, use the **no** form of this command.

subscribe-to-alert-group inventory [**periodic** {**daily** | **monthly** *day-of-month* | **weekly** *day-of-week*} *time*]

no subscribe-to-alert-group inventory [**periodic** {**daily** | **monthly** *day-of-month* | **weekly** *day-of-week*} *time*]

Syntax Description		
	periodic	Specifies to send an inventory message periodically.
	daily	Sends daily inventory messages.
	monthly <i>day-of-month</i>	Sends monthly inventory messages on the day of the month specified.
	weekly <i>day-of-week</i>	Sends weekly inventory messages on the day of the week specified.
	<i>time</i>	Time to send the inventory message, in the format <i>hour:minutes</i> .

Command Default The inventory alert group is disabled by default. The default severity for the inventory alert group is normal.

Command Modes Call home profile configuration

Command History	Release	Modification
	Release 4.1.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

At least one alert group subscription is mandatory for a profile so that a valid event can be triggered.

There are two types of subscription for an inventory alert group. One is normal subscription, meaning that the severity is set to normal, and any (online insertion and removal) OIR event triggers the event. The second is periodic subscription, using the **periodic** keyword, meaning that an event is triggered only when the specified time arrives.

Task ID	Task ID	Operation
	call-home	read, write

This example shows how to configure the sending of inventory messages every Monday:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config) call-home
```

```

RP/0/RSP0/CPU0:router(config-call-home)# profile my-profile
RP/0/RSP0/CPU0:router(config-call-home-profile)# subscribe-to-alert-group inventory periodic
weekly monday

```

Related Commands

Command	Description
profile (call home), on page 61	Enters call home profile configuration mode to create or configure a Call Home profile.
subscribe-to-alert-group environment, on page 77	Configures a destination profile to receive messages for the environment alert group.
subscribe-to-alert-group syslog, on page 81	Configures a destination profile to receive messages for the syslog alert group.

subscribe-to-alert-group syslog

To configure a destination profile to receive messages for the syslog alert group, use the **subscribe-to-alert-group syslog** command in call home profile configuration mode. To disable the subscription, use the **no** form of this command.

subscribe-to-alert-group syslog severity severity-level pattern match
no subscribe-to-alert-group syslog severity severity-level pattern match

Syntax Description	
severity	Specifies the the lowest level of severity events to include in a syslog alert.
<i>severity-level</i>	<ul style="list-style-type: none"> • catastrophic—Includes network-wide catastrophic events in the alert. This is the highest severity. • critical—Includes events requiring immediate attention (system log level 1). • debugging—Includes debug events (system log level 7). This is the lowest severity. • disaster—Includes events with significant network impact. • fatal—Includes events where the system is unusable (system log level 0). • major—Includes events classified as major conditions (system log level 2). • minor—Includes events classified as minor conditions (system log level 3) • normal—Specifies the normal state and includes events classified as informational (system log level 6). This is the default. • notification—Includes events informational message events (system log level 5). • warning—Includes events classified as warning conditions (system log level 4).
pattern	Specifies a syslog string pattern to match.
<i>match</i>	A string that when matched in the syslog message, is included in the alert notification. If the pattern contains spaces, you must enclose it in quotes (" ").

Command Default The syslog alert group is disabled by default. The default severity for the syslog alert group is debugging.

Command Modes Call home profile configuration

Command History	Release	Modification
	Release 4.1.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

At least one alert group subscription is mandatory for a profile so that a valid event can be triggered.

Task ID	Task ID	Operation
	call-home	read, write

The following example shows how to configure the syslog alert group to include severity notification:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config) call-home
RP/0/RSP0/CPU0:router(config-call-home) # profile my-profile
RP/0/RSP0/CPU0:router(config-call-home-profile) # subscribe-to-alert-group syslog severity
notification pattern "UPDOWN"
```

Related Commands	Command	Description
	profile (call home), on page 61	Enters call home profile configuration mode to create or configure a Call Home profile.
	subscribe-to-alert-group environment, on page 77	Configures a destination profile to receive messages for the environment alert group.



Cisco Discovery Protocol (CDP) Commands

This module describes the Cisco IOS XR software commands for monitoring the networking device and network using Cisco Discovery Protocol (CDP).

For detailed information about CDP concepts, configuration tasks, and examples, see the *Implementing CDP on Cisco IOS XR Software* module in *System Management Configuration Guide for Cisco ASR 9000 Series Routers*.

- [cdp](#), on page 84
- [cdp advertise v1](#), on page 86
- [cdp holdtime](#), on page 88
- [cdp log adjacency changes](#), on page 89
- [cdp timer](#), on page 91
- [clear cdp counters](#), on page 92
- [clear cdp table](#), on page 93
- [show cdp](#), on page 95
- [show cdp entry](#), on page 97
- [show cdp interface](#), on page 99
- [show cdp neighbors](#), on page 101
- [show cdp traffic](#), on page 104

cdp

To enable the Cisco Discovery Protocol (CDP) globally or on an interface, use the **cdp** command in the appropriate configuration mode. To disable CDP globally or on an interface, use the **no** form of this command.

cdp
no cdp

Syntax Description	This command has no keywords or arguments.
---------------------------	--

Command Default	CDP is disabled.
------------------------	------------------

Command Modes	Interface configuration
----------------------	-------------------------

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
Release 3.9.0	No modification.	

Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---

By default, CDP is disabled globally. To enable CDP, CDP must be enabled globally and then enabled for each interface.

To enable CDP globally, use the **cdp** command in global configuration mode. To disable CDP globally, use the **no** form of this command in global configuration mode.

To enable CDP on a specific interface, use the **cdp** command in interface configuration mode. To disable CDP on a specific interface, use the **no** form of this command in interface configuration mode.

Task ID	Task ID	Operations
	cdp	read, write

The following example shows how to globally enable CDP:

```
RP/0/RSP0/CPU0:router(config)# cdp
```

The following example shows how to enable CDP on an interface:

```
RP/0/RSP0/CPU0:router(config-if)# cdp
```


Related Topics

[show cdp](#), on page 95

cdp advertise v1

To change the version of Cisco Discovery Protocol (CDP) that is used to communicate with neighboring devices to version 1 (CDPv1), use the **cdp advertise v1** command in the appropriate configuration mode. To remove the **cdp advertise v1** command from the configuration file and restore the system to its default condition with respect to this command, use the **no** form of this command.

cdp advertise v1
no cdp advertise [v1]

Syntax Description This command has no keywords or arguments.

Command Default Version 2 is enabled.

Command Modes Global Configuration mode

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

CDPv2 packets are sent by default. CDP also sends and receives CDPv1 packets if the device with which CDP is interacting does not process CDPv2 packets.

CDPv2 adds device information over CDPv1. The additional information that is contained in the CDPv2 messages relates to Native VLAN, VLAN Trunking Protocol (VTP) Management Domain, Ethernet Duplex, and other features.

Task ID	Task ID	Operations
	cdp	read, write

The following example shows how to set a networking device to send and receive only CDPv1 advertisements:

```
RP/0/RSP0/CPU0:router(config)# cdp advertise v1
```

The following example shows how to restore the default condition (sending and receiving CDPv2 advertisements):

```
RP/0/RSP0/CPU0:router(config)# no cdp advertise
```

Related Topics

[cdp](#), on page 84

[show cdp](#), on page 95

cdp holdtime

To specify the time for which the receiving device should hold a Cisco Discovery Protocol (CDP) packet from your networking device before discarding it, use the **cdp holdtime** command in the appropriate configuration mode. To remove the **cdp holdtime** command from the configuration file and restore the system to its default condition with respect to this command, use the **no** form of this command.

cdp holdtime *seconds*

no cdp holdtime

Syntax Description

seconds Holdtime to be sent in the CDP update packets, in seconds. Range is 10 to 255.

Command Default

seconds : 180

Command Modes

Global configuration

Command History

Release

Modification

Release 3.7.2

This command was introduced.

Release 3.9.0

No modification.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

CDP packets are sent with a time-to-live value or holdtime, that is nonzero after an interface is enabled.

The CDP holdtime must be set to a higher number of seconds than the time between CDP transmissions, which is set using the **cdp time** command.

Task ID

Task Operations

cdp read,
write

The following example shows how to specify that the CDP packets sent from the networking device are held by the receiving device for 60 seconds before being discarded. You might want to set the holdtime lower than the default setting of 180 seconds if information about your networking device changes often and you want the receiving devices to purge this information more quickly.

```
RP/0/RSP0/CPU0:router (config)# cdp holdtime 60
```

Related Topics

[cdp timer](#), on page 91

[show cdp](#), on page 95

cdp log adjacency changes

To log changes to the Cisco Discovery Protocol (CDP) adjacency table, use the **cdp log adjacency changes** command in the appropriate configuration mode. To disable the logging, use the **no** form of this command.

cdp log adjacency changes
no cdp log adjacency changes

Syntax Description This command has no keywords or arguments.

Command Default CDP adjacency table logging is disabled.

Command Modes Global Configuration mode

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

When CDP adjacency table logging is enabled, a syslog is generated each time a CDP neighbor is added or removed.

Task ID	Task ID	Operations
	cdp	read, write

The following example shows how to enable CDP adjacency table logging:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# cdp log adjacency changes
```

When CDP adjacency table logging is enabled, a syslog is generated each time a CDP neighbor is added or removed. The following is an example of the log entry:

```
LC/0/5/CPU0:Jun 5 10:51:18.081 : cdp[109]: %L2-CDP-6-DELETED_NEIGHBOR :
CDP Neighbour TBA04110127 on interface GigabitEthernet0/5/0/0
has been deleted, remote interface 3/2

LC/0/5/CPU0:Jun 5 10:51:33.120 : cdp[109]: %L2-CDP-6-NEW_NEIGHBOR :
New CDP neighbor TBA04110127 detected on interface GigabitEthernet0/5/0/0,
remote interface 3/2
```

Related Topics

[show cdp](#), on page 95

cdp timer

To specify how often the software sends Cisco Discovery Protocol (CDP) updates, use the **cdp timer** command in the appropriate configuration mode. To remove the **cdp timer** configuration command from the configuration file and restore the system to its default condition with respect to this command, use the **no** form of this command.

cdp timer *seconds*
no cdp timer

Syntax Description	<i>seconds</i> Frequency with which the Cisco IOS XR software sends CDP updates, in seconds. Range is 5 to 254. The default is 60.
---------------------------	--

Command Default	<i>seconds</i> : 60
------------------------	---------------------

Command Modes	Global Configuration mode
----------------------	---------------------------

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
Release 3.9.0	No modification.	

Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---

A lower timer setting causes CDP updates to be sent more frequently.

Task ID	Task ID	Operations
	cdp	read, write

The following example shows how to set the CDP timer to 80 seconds, which is less frequent than the default setting of 60 seconds:

```
RP/0/RSP0/CPU0:router(config)# cdp timer 80
```

Related Topics

[cdp holdtime](#), on page 88

[show cdp](#), on page 95

clear cdp counters

To reset Cisco Discovery Protocol (CDP) traffic counters to zero (0), use the **clear cdp counters** command in EXEC mode.

clear cdp counters location *node-id*

Syntax Description	location <i>node-id</i> Clears CDP traffic counters for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.
---------------------------	---

Command Default	The counters are set to zero.
------------------------	-------------------------------

Command Modes	EXEC
----------------------	------

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---

Task ID	Task ID	Operations
	cdp	read, write

The following example shows how to clear CDP counters. The **show cdp traffic** output shows that all traffic counters have been reset to zero (0).

```
RP/0/RSP0/CPU0:router# clear cdp counters
RP/0/RSP0/CPU0:router# show cdp traffic

CDP counters:
  Packets output: 0, Input: 0
  Hdr syntax: 0, Chksum error: 0, Encaps failed: 0
  No memory: 0, Invalid packet: 0, Truncated: 0
  CDP version 1 advertisements output: 0, Input: 0
  CDP version 2 advertisements output: 0, Input: 0
  Unrecognize Hdr version: 0, File open failed: 0
```

Related Topics

[show cdp traffic](#), on page 104

[clear cdp table](#), on page 93

clear cdp table

To clear and automatically resize the table that contains Cisco Discovery Protocol (CDP) information about neighbors, use the **clear cdp table** command in EXEC mode.

```
clear cdp table location node-id
```

Syntax Description	location <i>node-id</i> Clears and resizes the CDP table for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.
---------------------------	--

Command Default	No default behavior or values
------------------------	-------------------------------

Command Modes	EXEC
----------------------	------

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
Release 3.9.0	No modification.	

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **clear cdp table** command to clear and resize the CDP table that contains the neighbor entries. The new table size is calculated according to the recommended hash table size, as seen in the **show cdp** command output.

Task ID	Task ID	Operations
	cdp	read, write

The following example shows how to clear and resize the CDP table. The output of the **show cdp neighbors** command before and after use of the **clear cdp table** command shows that all information has been deleted from the table:

```
RP/0/RSP0/CPU0:router# show cdp neighbors

Capability Codes: R - Router, T - Trans Bridge, B - Source Route Bridge
                  S - Switch, H - Host, I - IGMP, r - Repeater

Device ID          Local Intrfce    Holdtme    Capability  Platform  Port ID
TBA04341195(151a  Mg0/RP1/CPU0/0   171        T S         WS-C2924  0/1

RP/0/RSP0/CPU0:router# clear cdp table
RP/0/RSP0/CPU0:router# show cdp neighbors

Capability Codes: R - Router, T - Trans Bridge, B - Source Route Bridge
```

S - Switch, H - Host, I - IGMP, r - Repeater
Device ID Local Intrfce Holdtme Capability Platform Port ID

The **show cdp** command shows that the table has been resized:

```
RP/0/RSP0/CPU0:router# show cdp
```

```
Global CDP information:  
  Sending CDP packets every 60 seconds  
  Sending a holdtime value of 180 seconds  
  Sending CDPv2 advertisements is enabled
```

Related Topics

[show cdp](#), on page 95

[show cdp neighbors](#), on page 101

show cdp

To display global Cisco Discovery Protocol (CDP) information, including CDP version, timer, and holdtime information, use the **show cdp** command in

EXEC

mode.

show cdp

Syntax Description This command has no keywords or arguments.

Command Default No default behavior or values

Command Modes EXEC

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	No modification.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **show cdp** command to display CDP version, timer, and holdtime information relative to CDP operations.

Task ID	Task ID	Operations
	cdp	read

The following example shows how to use the **show cdp** command to verify the CDP global settings:

```
RP/0/RSP0/CPU0:router# show cdp

Global CDP information:
  Sending CDP packets every 20 seconds
  Sending a holdtime value of 30 seconds
  Sending CDPv2 advertisements is not enabled
```

Table 8: show cdp Field Descriptions

Field	Definition
Sending CDP packets every 20 seconds	Interval between transmissions of CDP advertisements. This field is controlled by the cdp timer command.

Field	Definition
Sending a holdtime value of 30 seconds	Time for which the device directs the neighbor to hold a CDP advertisement before discarding it. This field is controlled by the cdp holdtime command.
Sending CDPv2 advertisements is not enabled	State of being enabled or disabled for the transmission of CDP version 2-type advertisements. This field is controlled by the cdp advertise v1 command.

Related Topics

- [cdp advertise v1](#), on page 86
- [cdp holdtime](#), on page 88
- [cdp timer](#), on page 91
- [show cdp entry](#), on page 97
- [show cdp neighbors](#), on page 101
- [show cdp traffic](#), on page 104
- [clear cdp table](#), on page 93
- [show cdp interface](#), on page 99

show cdp entry

To display information about a specific neighboring device or all neighboring devices discovered using Cisco Discovery Protocol (CDP), use the **show cdp entry** command in

EXEC

mode.

show cdp entry *{*entry-name}* [{**protocol** | **version**}]

Syntax Description	
*	Displays all CDP neighbors.
<i>entry-name</i>	Name of a neighbor about which you want information.
protocol	(Optional) Displays protocol information associated with CDP neighbor entries.
version	(Optional) Displays version information associated with CDP neighbor entries.

Command Default This command displays information about a particular device that has been discovered by CDP.

Command Modes EXEC

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	cdp	read, write

The following example shows sample output from the **show cdp entry** command. Information about device ID, address, platform, interface, holdtime, and version is displayed.

```
RP/0/RSP0/CPU0:router# show cdp entry TBA04341195
-----
Device ID: TBA04341195(sys-235)
SysName : sys-235
Entry address(es):
  IP address: 172.16.23.9
Platform: WS-C6006, Capabilities: Trans-Bridge Switch
Interface: MgmtEth0/RP1/CPU0/0
```

show cdp entry

```

Port ID (outgoing port): 4/18
Holdtime : 157 sec

Version :
WS-C6006 Software, Version McpSW: 7.2(2) NmpSW: 7.2(2)
Copyright (c) 1995-2002 by Cisco Systems

advertisement version: 2
VTP Management Domain: 'sys'
Native VLAN: 125
Duplex: full

```

Table 9: show cdp entry Field Descriptions

Field	Description
Device ID	ID code assigned during installation of the router.
Entry address(es)	Addresses of the platform, selected interface, and port ID.
Platform	Platform name.
Capabilities	Special functions that the platform can perform (in this case the platform is a trans-bridge switch).
Interface	Interface location expressed in <i>rack / slot / module / port</i> notation.
Port ID (outgoing port)	Location of the port in use by the interface.
Holdtime	Time (in seconds) for which the device directs the neighbor to hold a CDP advertisement before discarding it. This field is controlled by the cdp holdtime command.
Version	Software version.
advertisement version	Version number of the advertising protocol.
VTP Management Domain	VLAN Trunking Protocol (VTP) domain name of neighbor device.
Native VLAN	VLAN ID.
Duplex	Duplex setting: half or full.

Related Topics

- [show cdp](#), on page 95
- [show cdp neighbors](#), on page 101
- [show cdp traffic](#), on page 104
- [show cdp interface](#), on page 99

show cdp interface

To display information about the interfaces on which Cisco Discovery Protocol (CDP) is enabled, use the **show cdp interface** command in the appropriate mode.

```
show cdp interface [{type interface-path-id | location node-id}]
```

Syntax Description	<p><i>type</i> (Optional) Interface type. For more information, use the question mark (?) online help function.</p> <hr/> <p><i>interface-path-id</i> (Optional) Physical interface or virtual interface.</p> <p>Note Use the show interfaces command to see a list of all interfaces currently configured on the router.</p> <p>For more information about the syntax for the router, use the question mark (?) online help function.</p> <hr/> <p>location node-id (Optional) Displays detailed CDP information for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.</p>
---------------------------	---

Command Default This command displays information about the interfaces on which CDP has been enabled.

Command Modes EXEC

Command History	Release	Modification
	Release 3.7.2	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **show cdp interface** command to display information about any CDP interfaces. When an interface is specified in the command syntax, information is displayed about the specific interface. Not specifying the interface displays information about all interfaces.

Task ID	Task ID	Operations
	cdp	read, write

The following example shows sample output from the **show cdp interface** command. Information about the status, CDP timer, and holdtime settings is displayed for all interfaces on which CDP is enabled.

```
RP/0/RSP0/CPU0:router# show cdp interface
```

show cdp interface

```

POS0/2/0/0 is Up
  Encapsulation HDLC
  Sending CDP packets every 120 seconds
  Holdtime is 240 seconds
POS0/2/0/1 is Up
  Encapsulation HDLC
  Sending CDP packets every 120 seconds
  Holdtime is 240 seconds
POS0/2/0/2 is Up
  Encapsulation HDLC
  Sending CDP packets every 120 seconds
  Holdtime is 240 seconds
POS0/2/0/3 is Up
  Encapsulation HDLC
  Sending CDP packets every 120 seconds
  Holdtime is 240 seconds
MgmtEth0/RP1/CPU0/0 is Up
  Encapsulation ARPA
  Sending CDP packets every 120 seconds
  Holdtime is 240 seconds

```

The following example shows sample output from the **show cdp interface** command with an interface specified. Information about the status, CDP timer, and holdtime settings is displayed for Packet-over-SONET/SDH (POS) interface 0/2/0/1 only.

```

RP/0/RSP0/CPU0:router# show cdp interface pos 0/2/0/1

POS0/2/0/1 is Up
  Encapsulation HDLC
  Sending CDP packets every 60 seconds
  Holdtime is 180 seconds

```

Table 10: show cdp interface Field Descriptions

Field	Description
POS0/2/0/1 is Up	Current condition of POS interface 0/0/2/1.
Encapsulation HDLC	Interface is encoding packets using the Cisco HDLC Layer 2 encapsulation.
Sending CDP packets every 60 seconds	Interval between transmissions of CDP advertisements. This field is controlled by the cdp timer command.
Holdtime is 180 seconds	Time for which the device directs the neighbor to hold a CDP advertisement before discarding it. This field is controlled by the cdp holdtime command.

Related Topics

- [show cdp](#), on page 95
- [show cdp entry](#), on page 97
- [show cdp neighbors](#), on page 101
- [show cdp traffic](#), on page 104

show cdp neighbors

To display detailed information about neighboring devices discovered using Cisco Discovery Protocol (CDP), use the **show cdp neighbors** command in

EXEC

mode.

show cdp neighbors [*{type interface-path-id | location node-id}*] [**detail**]

Syntax Description	
<i>type</i>	(Optional) Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	(Optional) Physical interface or virtual interface.
	<p>Note Use the show interfaces command to see a list of all interfaces currently configured on the router.</p> <p>For more information about the syntax for the router, use the question mark (?) online help function.</p>
location <i>node-id</i>	(Optional) Displays detailed CDP information for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.
detail	(Optional) Displays detailed information about a neighbor or neighbors, including network address, enabled protocols, holdtime, and software version. The output includes information about both IPv4 and IPv6 addresses.

Command Default No default behavior or values

Command Modes EXEC

Command History	Release	Modification
	Release 3.7.2	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **show cdp neighbors** command to display information about any CDP neighbors. When a location is specified in the command syntax, information about the neighbor is displayed for the specified node. Not specifying the location displays information about the neighbor for all interfaces.

Use the command with the **detail** keyword to display additional information, including IPv6 neighbors.

Task ID	Task ID	Operations
	cdp	read

The following example shows sample output from the **show cdp neighbors** command:

```
RP/0/RSP0/CPU0:router# show cdp neighbors

Capability Codes: R - Router, T - Trans Bridge, B - Source Route Bridge
                  S - Switch, H - Host, I - IGMP, r - Repeater

Device ID          Local Intrfce  Holdtme  Capability  Platform  Port ID
TBA04110127       Gi0/7/0/0     173      T S          WS-C6506  3/9
cisco_1            Gi0/7/0/2     171      R
ASR9K
    Gi0/4/0/2
```

Table 11: show cdp neighbors Field Descriptions

Field	Description
Capability Codes	Type of device that can be discovered.
Device ID	Name of the neighbor device.
Local Intrfce	Protocol being used by the connectivity media and the interface number.
Holdtme	Remaining time, in seconds, for which the current device holds the CDP advertisement from a sending router before discarding it.
Capability	Type of the device listed in the CDP Neighbors table. Values are as follows: R—Router T—Transparent bridge B—Source-routing bridge S—Switch H—Host I—Internet Group Management Protocol (IGMP) device r—Repeater
Platform	Product number of the device.
Port ID	Protocol and port number of the device.

The following examples illustrates sample output for IPv4 and IPv6 neighbors from the **show cdp neighbors** command with the **detail** keyword:

```
RP/0/RSP0/CPU0:router# show cdp neighbor detail

-----
Device ID: uut-user
SysName : uut-user
Entry address(es):
IPv4 address: 1.1.1.1
```

```
IPv6 address: 1::1
IPv6 address: 2::2
Platform: cisco 12008/GRP, Capabilities: Router
Interface: Gi0/4/0/3
Port ID (outgoing port): Gi0/2/0/3
Holdtime : 177 sec
```

```
Version :
Cisco IOS XR Software, Version 0.0.0[Default]
Copyright (c) 2005 by cisco Systems, Inc.
```

```
advertisement version: 2
```

Table 12: show cdp neighbors detail Field Descriptions

Field	Definition
Device ID	Name of the neighbor device.
Entry address(es)	List of network addresses of neighbor devices. The address can be in IP or in Connectionless Network Service (CLNS) protocol conventions.
Platform	Product name and number of the neighbor device.
Capabilities	Device type of the neighbor. This device can be a router, a bridge, a transparent bridge, a source-routing bridge, a switch, a host, an IGMP device, or a repeater.
Interface	Interface being used by the connectivity medium.
Port ID	Port number of the port on the current device.
Holdtime	Remaining time (in seconds) for which the current device holds the CDP advertisement from a sending router before discarding it.
Version	Software version of the neighbor device.
advertisement version	Version number of the advertising protocol.

Related Topics

[show cdp](#), on page 95

[show cdp entry](#), on page 97

[show cdp traffic](#), on page 104

[show cdp interface](#), on page 99

show cdp traffic

To display information about the traffic gathered between devices using Cisco Discovery Protocol (CDP), use the **show cdp traffic** command in

EXEC

mode.

show cdp traffic [**location** *node-id*]

Syntax Description	location <i>node-id</i> (Optional) Displays CDP information for the CDP packets sent and received on the designated node only. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.
---------------------------	---

Command Default	Displays CDP information aggregated across all nodes.
------------------------	---

Command Modes	EXEC
----------------------	------

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---

Task ID	Task ID	Operations
	cdp	read

The following example illustrates sample output from the **show cdp traffic** command:

```
RP/0/RSP0/CPU0:router# show cdp traffic

CDP counters :
  Packets output: 50662, Input: 40414
  Hdr syntax: 0, Chksum error: 0, Encaps failed: 0
  No memory: 0, Invalid packet: 0, Truncated: 0
  CDP version 1 advertisements output: 0, Input: 0
  CDP version 2 advertisements output: 50662, Input: 40414
  Unrecognize Hdr version: 0, File open failed: 0
```

Table 13: show cdp traffic Field Descriptions

Field	Definition
Packets output	Number of CDP advertisements sent by the local device. Note that this value is the sum of the CDP version 1 advertisements output field and the CDP version 2 advertisements output field.
Input	Number of CDP advertisements received by the local device. Note that this value is the sum of the CDP version 1 advertisements input field and the CDP version 2 advertisements input field.
Hdr syntax	Number of CDP advertisements having bad headers that have been received by the local device.
Chksum error	Number of times the checksum (verifying) operation failed on incoming CDP advertisements.
Encaps failed	Number of times CDP failed to send advertisements on an interface because of a failure caused by the bridge port of the local device.
No memory	Number of times that the local device did not have enough memory to store the CDP advertisements in the advertisement cache table when the device was attempting to assemble advertisement packets for transmission and parse them when receiving them.
Invalid packet	Number of invalid CDP advertisements received and sent by the local device.
Truncated	Number of times truncated CDP advertisements were sent because there was not enough space in the CDP packet to hold all CDP type-length-values (TLVs).
CDP version 1 advertisements output	Number of CDP version 1 advertisements sent by the local device.
Input	Number of CDP version 1 advertisements received by the local device.
CDP version 2 advertisements output	Number of CDP version 2 advertisements sent by the local device.
Input	Number of CDP version 2 advertisements received by the local device.
Unrecognize Hdr version	Number of packets received from a CDP version that was outside the current configuration.
File open failed	Number of times that CDP failed to connect to one of the underlying services it uses.

Related Topics

[show cdp](#), on page 95

[show cdp entry](#), on page 97

[show cdp neighbors](#), on page 101

[show cdp interface](#), on page 99

```
show cdp traffic
```



Clock Commands

This module describes the commands used to set and display the internal clock settings in Cisco IOS XR software.

For more information about manually setting the router clock, see *Cisco ASR 9000 Series Aggregation Services Router Getting Started Guide*.

For more information about configuring the router to synchronize to Network Time Protocol (NTP), see the *Implementing NTP on Cisco IOS XR Software* module in *System Management Configuration Guide for Cisco ASR 9000 Series Routers*.

- [clock read-calendar](#), on page 108
- [clock set](#), on page 109
- [clock summer-time](#), on page 111
- [clock timezone](#), on page 113
- [clock update-calendar](#), on page 117
- [confdConfig cli timezone local](#), on page 118
- [confdConfig cli utcOffset](#), on page 119
- [confdConfig cli idleTimeout](#), on page 120
- [confdConfig cli timestamp](#), on page 121
- [locale country](#), on page 122
- [locale language](#), on page 124
- [show clock](#), on page 126

clock read-calendar

To manually copy the hardware clock (calendar) settings into the software clock, use the **clock read-calendar** command in EXEC modeAdmin EXEC mode.

clock read-calendar

Syntax Description This command has no keywords or arguments.

Command Default Read calendar is disabled.

Command Modes EXEC mode
Admin EXEC mode

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

Usage Guidelines The *calendar clock* is a hardware system clock that runs continuously, even if the router is powered off or rebooted. The hardware system clock is separate from the software clock settings, which are erased when the router is power cycled or rebooted.

Use the **clock read-calendar** command to manually copy the hardware clock setting into the software clock.

Task ID	Task ID	Operations
	host-services	execute

In the following example, the hardware clock settings are copied to the software clock with the **clock read-calendar** command. The **show clock** command is then entered to display the new software clock settings.

```
RP/0/RSP0/CPU0:router# clock read-calendar
RP/0/RSP0/CPU0:router# show clock

14:31:57.089 PST Tue Feb 10 2008
```

Related Topics

- [clock set](#), on page 109
- [clock update-calendar](#), on page 117
- [show clock](#), on page 126
- [update-calendar](#), on page 466

clock set

To change the software clock settings, use the **clock set** command in EXEC mode Admin EXEC mode.

```
clock set hh:mm:ss {day month | month day} year
```

Syntax Description	
<i>hh:mm:ss</i>	Current time in hours (24-hour format), minutes, and seconds. Colons are required between values.
<i>day</i>	Current day (by date) in the month.
<i>month</i>	Current month (by name).
<i>year</i>	Current year (no abbreviation). Enter a valid four-digit year.

Command Default Clock is not set.

Command Modes EXEC mode
Admin EXEC mode

Command History	Release	Modification
	Release 3.7.2	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Generally, if the system is synchronized by a valid outside timing mechanism, such as a Network Time Protocol (NTP) clock source, or if you have a networking device with calendar capability, you need not set the software clock. Use the **clock set** command if no other time sources are available. The time specified in this command is relative to the configured time zone.

Task ID	Task ID	Operations
	host-services	execute

Setting the Software Clock

This example shows how to set the software clock using the **clock set** command with the *day month* arguments first.

```
RP/0/RSP0/CPU0:router# clock set 14:12:00 10 feb 2005
```

```
14:12:00.114 JST Fri Feb 10 2009
```

This example shows how to set the software clock using the **clock set** command with the *month day* arguments first.

```
RP/0/RSP0/CPU0:router# clock set 14:38:00 feb 10 2005
14:38:00.069 PST Tue Feb 10 2009
```

Displaying the Clock Settings

This example shows how to display the settings of the software clock:

```
RP/0/RSP0/CPU0:router# show clock
14:38:11.292 PST Tue Feb 10 2009
```

This example shows how to use the `clock set` command:

```
RP/0/RSP0/CPU0:router# clock set 06:10:00 12 ?
    january      Month of the Year
    february
    march
    april
    may
    june
    july
    august
    september
    october
    november
    december
```

Related Topics

[clock timezone](#), on page 113

[show clock](#), on page 126

[clock summer-time](#), on page 111

clock summer-time

To configure the system to switch automatically to summer time (daylight saving time), use the **clock summer-time** command in global configuration mode. To remove the daylight saving time setting, use the **no** form of this command.

```
clock summer-time zone {date {date month year hh:mm date month year hh:mm | month date
year hh:mm month date year hh:mm} | recurring week day month hh:mm week day month hh:mm}
[offset]
no clock summer-time
```

Syntax Description

<i>zone</i>	Name of the time zone (for example, PDT) to be displayed when summer time is in effect. Table 14: Common Time Zone Acronyms, on page 113 lists common time zone acronyms used for the <i>zone</i> argument.
date	Indicates that summer time should start on the first specific date listed in the command and end on the second specific date in the command.
<i>date</i>	Date of the month.
<i>month</i>	Month.
<i>year</i>	Year (no abbreviation).
<i>hh:mm</i>	Time (24-hour format) in hours and minutes.
recurring	Indicates that summer time should start and end on the corresponding specified days every year.
<i>week</i>	Week of the month (values are 1 to 5, first or last).
<i>day</i>	Day of the week.
<i>offset</i>	(Optional) Number of minutes to add during summer time.

Command Default

Summer time is not configured.
offset: 60

Command Modes

Global configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	No modification.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **clock summer-time** command if you want the system to switch automatically to summer time (for display only):

- Use the **recurring** keyword to apply the rules on the configured day each year. If **clock summer-time zone recurring** is specified without parameters, the summer time rules default to United States standards. The default for the *offset* argument is 60 minutes.
- Use the **date** keyword to specify a start and end date for summer time if you cannot use the first form.

In both forms of the command, the first part of the command specifies when summer time begins and the second part specifies when it ends. All times are relative to the local time zone. The start time is relative to standard time. The end time is relative to summer time. If the starting month is after the ending month, the system assumes that you are in the Southern Hemisphere.

Task ID	Task ID	Operations
	host-services	read, write

The following example specifies that summer time starts on the first Sunday in April at 02:00 and ends on the last Sunday in October at 02:00. The **recurring** keyword indicates that the rules apply every year.

```
RP/0/RSP0/CPU0:router(config)# clock summer-time PDT recurring 1 Sunday April 2:00
last Sunday October 2:00
```

If you live where summer time does not follow the pattern in the first example, you could set it to start on October 12, 2008 at 02:00 and end on April 26, 2009 at 02:00, with the following example. The **date** keyword indicates that the rules apply for the current year only.

```
RP/0/RSP0/CPU0:router(config)# clock summer-time PDT date 12 October 2008 2:00 26
April 2009 2:00
```

Related Topics

- [clock set](#), on page 109
- [clock timezone](#), on page 113

clock timezone

To set the time zone for display, use the **clock timezone** command in Admin Configuration mode or Global Configuration mode. To remove the time zone setting, use the **no** form of this command.

```
clock timezone zone hours-offset [minutes-offset]
no clock timezone
```

Syntax Description

<i>zone</i>	Name of the time zone to be displayed when standard time is in effect.
<i>hours-offset</i>	Hours offset from Coordinated Universal Time (UTC). Range is from -23 to +23.
<i>region</i>	Sets the offset according to the region specified.
<i>minutes-offset</i>	(Optional) Minutes offset from UTC.

Command Default

UTC

Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	No modification.

Usage Guidelines

Use the **clock timezone** command to display the time zone only when setting the time manually. The system keeps time internally in UTC.

This table lists common time zone acronyms used for the *zone* argument.

Table 14: Common Time Zone Acronyms

Acronym	Time Zone Name and UTC Offset
Europe	
GMT	Greenwich Mean Time, as UTC.
BST	British Summer Time, as UTC plus 1 hour.
IST	Irish Summer Time, as UTC plus 1 hour.
WET	Western Europe Time, as UTC.
WEST	Western Europe Summer Time, as UTC plus 1 hour.

Acronym	Time Zone Name and UTC Offset
CET	Central Europe Time, as UTC plus 1 hour.
CEST	Central Europe Summer Time, as UTC plus 2 hours.
EET	Eastern Europe Time, as UTC plus 2 hours.
EEST	Eastern Europe Summer Time, as UTC plus 3 hours.
MSK	Moscow Time, as UTC plus 3 hours.
MSD	Moscow Summer Time, as UTC plus 4 hours.
United States and Canada	
AST	Atlantic Standard Time, as UTC minus 4 hours.
ADT	Atlantic Daylight Time, as UTC minus 3 hours.
ET	Eastern Time, either as EST or EDT, depending on place and time of year.
EST	Eastern Standard Time, as UTC minus 5 hours.
EDT	Eastern Daylight Saving Time, as UTC minus 4 hours.
CT	Central Time, either as CST or CDT, depending on place and time of year.
CST	Central Standard Time, as UTC minus 6 hours.
CDT	Central Daylight Saving Time, as UTC minus 5 hours.
MT	Mountain Time, either as MST or MDT, depending on place and time of year.
MST	Mountain Standard Time, as UTC minus 7 hours.
MDT	Mountain Daylight Saving Time, as UTC minus 6 hours.
PT	Pacific Time, either as PST or PDT, depending on place and time of year.
PST	Pacific Standard Time, as UTC minus 8 hours.
PDT	Pacific Daylight Saving Time, as UTC minus 7 hours.
AKST	Alaska Standard Time, as UTC minus 9 hours.
AKDT	Alaska Standard Daylight Saving Time, as UTC minus 8 hours.
HST	Hawaiian Standard Time, as UTC minus 10 hours.
Australia	
WST	Western Standard Time, as UTC plus 8 hours.

Acronym	Time Zone Name and UTC Offset
CST	Central Standard Time, as UTC plus 9.5 hours.
EST	Eastern Standard/Summer Time, as UTC plus 10 hours (plus 11 hours during summer time).

This table lists an alternative method for referring to time zones, in which single letters are used to refer to the time zone difference from UTC. Using this method, the letter Z is used to indicate the zero meridian, equivalent to UTC, and the letter J (Juliet) is used to refer to the local time zone. Using this method, the International Date Line is between time zones M and Y.

Table 15: Single-Letter Time Zone Designators

Letter Designator	Word Designator	Difference from UTC
Y	Yankee	UTC minus 12 hours.
X	Xray	UTC minus 11 hours.
W	Whiskey	UTC minus 10 hours.
V	Victor	UTC minus 9 hours.
U	Uniform	UTC minus 8 hours.
T	Tango	UTC minus 7 hours.
S	Sierra	UTC minus 6 hours.
R	Romeo	UTC minus 5 hours.
Q	Quebec	UTC minus 4 hours.
P	Papa	UTC minus 3 hours.
O	Oscar	UTC minus 2 hours.
N	November	UTC minus 1 hour.
Z	Zulu	Same as UTC.
A	Alpha	UTC plus 1 hour.
B	Bravo	UTC plus 2 hours.
C	Charlie	UTC plus 3 hours.
D	Delta	UTC plus 4 hours.
E	Echo	UTC plus 5 hours.
F	Foxtrot	UTC plus 6 hours.
G	Golf	UTC plus 7 hours.

Letter Designator	Word Designator	Difference from UTC
H	Hotel	UTC plus 8 hours.
I	India	UTC plus 9 hours.
K	Kilo	UTC plus 10 hours.
L	Lima	UTC plus 11 hours.
M	Mike	UTC plus 12 hours.

Task ID	Task ID	Operations
	host-services	read, write

The following example shows how to set the time zone to PST and offset 8 hours behind UTC:

```
RP/0/RSP0/CPU0:router(config)# clock timezone PST -8
```

The following example shows how to set the time zone to Newfoundland Standard Time (NST) for Newfoundland, Canada, which is 3.5 hours behind UTC:

```
RP/0/RSP0/CPU0:router(config)# clock timezone NST -3 30
```

Related Topics

- [clock set](#), on page 109
- [show clock](#), on page 126
- [clock summer-time](#), on page 111

clock update-calendar

To copy the software clock settings to the hardware clock (calendar), use the **clock update-calendar** command in EXEC mode Admin EXEC mode.

clock update-calendar

Syntax Description This command has no keywords or arguments.

Command Default No default behavior or values

Command Modes EXEC mode
Admin EXEC mode

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The hardware clock (calendar) runs continuously, even if the router is powered off or rebooted. If the software clock and calendar are not synchronized and the software clock is more accurate, use this command to update the hardware calendar clock to the correct date and time.

Task ID	Task ID	Operations
	host-services	execute

The following example shows how to copy the current time from the software clock to the hardware clock:

```
RP/0/RP0/CPU0:router# clock update-calendar
```

Related Topics

[clock read-calendar](#), on page 108

confdConfig cli timezone local

To specify the timezone that must be used when displaying the time in the CLI, use the **confdConfig cli timezone local** command in System Admin Config mode.

confdConfig cli timezone local

Syntax Description	<i>timezone</i> Specifies the timezone that must be used when displaying the time in the CLI. If local is specified then the timezone that is configured on the device is used.				
Command Default	The default value is local .				
Command Modes	System Admin Config				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 6.3.1</td> <td>By default, the sysadmin confdConfig configuration is visible in the sysadmin running configuration.</td> </tr> </tbody> </table>	Release	Modification	Release 6.3.1	By default, the sysadmin confdConfig configuration is visible in the sysadmin running configuration.
Release	Modification				
Release 6.3.1	By default, the sysadmin confdConfig configuration is visible in the sysadmin running configuration.				
Usage Guidelines	<p>This command is available in Cisco IOS XR 64 bit OS.</p> <p>This example shows you how to configure the timezone:</p> <pre> sysadmin-vm:0_RP0# config Thu May 23 23:19:47.567 UTC+00:00 Entering configuration mode terminal sysadmin-vm:0_RP0(config)# confdconfig cli timezone local Thu May 23 23:19:47.567 UTC+00:00 </pre>				

confdConfig cli utcOffset

To specify the UTC offset measured in minutes, use the **confdConfig cli utcOffset** command in System Admin Config mode.

confdConfig cli utcOffset *integer*

Syntax Description *integer* Specifies the UTC offset measured in minutes.

Command Default The default value is **0**.

Command Modes System Admin Config

Command History	Release	Modification
	Release 6.3.1	By default, the sysadmin confdConfig configuration is visible in the sysadmin running configuration.

Usage Guidelines This command is available in Cisco IOS XR 64 bit OS.

This example shows you how to configure the UTC offset:

```

sysadmin-vm:0_RP0# config
Thu May 23 23:19:47.567 UTC+00:00
Entering configuration mode terminal
sysadmin-vm:0_RP0(config)# confdconfig cli utcOffset 0
Thu May 23 23:19:47.567 UTC+00:00

```

confdConfig cli idleTimeout

To specify the maximum idle time before terminating a CLI session, use the **confdConfig cli idleTimeout** command in System Admin Config mode.

confdConfig cli idleTimeout *time*

Syntax Description	<i>time</i> Specifies the idle timeout value. It must be in this format: (nYnMnDnHnMnS).
---------------------------	--

Command Default	The default value is PT10M , which is 10 minutes. PT0M means no timeout.
------------------------	--

Command Modes	System Admin Config
----------------------	---------------------

Command History	Release	Modification
	Release 6.3.1	By default, the sysadmin confdConfig configuration is visible in the sysadmin running configuration.

Usage Guidelines	This command is available in Cisco IOS XR 64 bit OS.
-------------------------	--

This example shows you how to configure the idle timeout of 25 minutes:

```
sysadmin-vm:0_RP0# config
Thu May 23 23:19:47.567 UTC+00:00
Entering configuration mode terminal
sysadmin-vm:0_RP0(config)# confdconfig cli idleTimeout 25m
Thu May 23 23:19:47.567 UTC+00:00
```

confdConfig cli timestamp

To enable or disable the display of timestamps, use the **confdConfig cli timestamp** command in System Admin Config mode.

confdConfig cli timestamp {*enabled* | *disabled*}

Syntax Description

enabled Enables the display of timestamps.

disabled Disables the display of timestamps.

Command Default

The default value is **enabled**.

Command Modes

System Admin Config

Command History

Release	Modification
Release 6.3.1	By default, the sysadmin confdConfig configuration is visible in the sysadmin running configuration.

Usage Guidelines

This command is available in Cisco IOS XR 64 bit OS.

This example shows you how to enable the display of timestamp:

```
sysadmin-vm:0_RP0# config
Thu May 23 23:19:47.567 UTC+00:00
Entering configuration mode terminal
sysadmin-vm:0_RP0(config)# confdconfig cli timestamp enabled
Thu May 23 23:19:47.567 UTC+00:00
```

locale country

To set the default country of use, use the **locale country** command in global configuration mode. To remove the country setting, use the **no** form of this command.

locale country *country*
no locale country

Syntax Description

country Country, where *country* is a two-character country code. Case is not important.

Command Default

No default behavior or values

Command Modes

Global configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	No modification.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.



Note

This command is not fully supported at this time.

To display a complete listing of the available country codes, use the online help (?) function:

```
RP/0/RSP0/CPU0:router (config)# locale country ?
```

```

AD    Andorra
AE    United Arab Emirates
AF    Afghanistan
AG    Antigua and Barbuda
AI    Anguilla
AL    Albania
AM    Armenia
AN    Netherlands Antilles
AO    Angola
AQ    Antarctica
AR    Argentina
AS    American Samoa
AT    Austria
AU    Australia
AW    Aruba
AZ    Azerbaijan
BA    Bosnia and Herzegovina
BB    Barbados
```

```
BD    Bangladesh
BE    Belgium
--More--
```

Task ID	Task ID	Operations
	host-services	read, write

The following example shows how to set the country of use to Australia:

```
RP/0/RSP0/CPU0:router(config)# locale country au
```

Related Topics

[locale language](#), on page 124

locale language

To set the default language of use, use the **locale language** command in global configuration

mode. To remove the language setting, use the **no** form of this command.

locale language *language*
no locale language

Syntax Description *language* Two-character code that specifies the language. Case is not important.

Command Default No default behavior or values

Command Modes Global configuration

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.



Note This command is not fully supported at this time.

To display a complete listing of the available language codes, use the online help (?) function:

```
RP/0/RSP0/CPU0:router(config)# locale language ?

aa    Afar
ab    Abkhazian
af    Afrikaans
am    Amharic
ar    Arabic
as    Assamese
ay    Aymara
--More--
```

Task ID	Task ID	Operations
	host-services	read, write

The following example shows how to set the language of use to English:

```
RP/0/RSP0/CPU0:router(config)# locale language en
```

Related Topics

[locale country](#), on page 122

show clock

To display the system clock, use the **show clock** command in EXEC mode.

show clock [**detail**]

Syntax Description **detail** (Optional) Indicates the time zone, time source, and current summer time setting (if any).

Command Default No default behavior or values

Command Modes EXEC

Command History	Release	Modification
	Release 3.7.2	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The system clock keeps an “authoritative” flag that indicates whether the time is authoritative (believed to be accurate). If the system clock has been set by a timing source, such as system calendar or Network Time Protocol (NTP), the flag is set. If the time is not authoritative, it is used only for display. Until the clock is authoritative and the “authoritative” flag is set, the flag prevents peers from synchronizing to the clock when the peers have invalid times.

The leading symbols that precede the **show clock** command display are shown in this table

Table 16: show clock Display Leading Symbol Descriptions

Symbol	Description
*	Time is not authoritative.
(blank)	Time is authoritative.
.	Time is authoritative, but NTP is not synchronized.

Task ID	Task ID	Operations
	basic-services	read

The following sample output shows the current clock settings:

```
RP/0/RSP0/CPU0:router# show clock
16:18:28.927 PST Tue Feb 10 2009
```

The following sample output shows the current clock detail, including the time zone and time source:

```
RP/0/RSP0/CPU0:router# show clock detail  
16:18:07.164 PST Tue Feb 10 2009  
Timezone: PST8PST Timesource: User configured
```

Related Topics

[clock set](#), on page 109



Configuration Management Commands

This module describes the Cisco IOS XR commands used to manage your basic configuration.

For detailed information about configuration management concepts, tasks, and examples, see *Cisco ASR 9000 Series Aggregation Services Router Getting Started Guide*.

- [abort](#), on page 131
- [admin](#), on page 132
- [alias](#), on page 133
- [apply-group](#), on page 136
- [apply-group-remove](#), on page 138
- [apply-template](#), on page 139
- [clear comment](#), on page 141
- [clear configuration commits](#), on page 143
- [clear configuration inconsistency](#), on page 145
- [clear configuration inconsistency replica](#), on page 148
- [clear configuration sessions](#), on page 150
- [commit](#), on page 152
- [configuration commit auto-save](#), on page 156
- [configure](#), on page 158
- [description \(interface\)](#), on page 160
- [do](#), on page 161
- [end](#), on page 162
- [end-group](#), on page 164
- [end-template](#), on page 165
- [exclude-group](#), on page 166
- [exit](#), on page 167
- [group \(configuration\)](#), on page 169
- [hostname](#), on page 174
- [load](#), on page 175
- [load commit changes](#), on page 177
- [load configuration failed](#), on page 179
- [load configuration removed](#), on page 181
- [load rollback changes](#), on page 182
- [man](#), on page 184
- [more](#), on page 187

- [pwd \(config\)](#), on page 192
- [rollback configuration](#), on page 193
- [root](#), on page 196
- [save configuration](#), on page 198
- [save configuration changes](#), on page 200
- [save configuration commit changes](#), on page 202
- [save configuration failed](#), on page 204
- [save configuration merge](#), on page 206
- [save configuration removed](#), on page 207
- [save rollback changes](#), on page 209
- [set default-afi](#), on page 211
- [set default-safi](#), on page 213
- [set default-vrf](#), on page 215
- [show](#), on page 217
- [show aliases](#), on page 220
- [show apply-group](#), on page 221
- [show configuration \(config\)](#), on page 222
- [show configuration changes](#), on page 224
- [show configuration commit changes](#), on page 226
- [show configuration commit list](#), on page 230
- [show configuration failed](#), on page 232
- [show configuration failed \(config\)](#), on page 233
- [show configuration failed incompatible](#), on page 235
- [show configuration failed remove](#), on page 236
- [show configuration failed rollback](#), on page 238
- [show configuration failed startup](#), on page 239
- [show configuration history](#), on page 240
- [show configuration inconsistency replica](#), on page 244
- [show configuration persistent](#), on page 246
- [show configuration removed](#), on page 248
- [show configuration rollback changes](#), on page 250
- [show configuration running](#), on page 252
- [show configuration running-config](#), on page 254
- [show configuration sessions](#), on page 257
- [show default-afi-safi-vrf](#), on page 259
- [show history](#), on page 260
- [show running-config](#), on page 262
- [template](#), on page 266

abort

To terminate a configuration session and discard all uncommitted changes without system confirmations, use the **abort** command in any configuration mode.

abort

Syntax Description This command has no keywords or arguments.

Command Default None

Command Modes Any configuration mode

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **abort** command to terminate a configuration session and return to EXEC mode from any configuration mode. This command discards all uncommitted configuration changes. You are prompted to commit the changes.

Task ID	Task ID	Operations
	Task ID for the feature or mode impacted by the command	Operation for the feature or mode impacted by the command

The following example shows how to use the **abort** command to discard all changes made during a configuration session:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# interface gigabitethernet 0/2/0/0
RP/0/RSP0/CPU0:router(config-if)# ipv4 address 1.1.1.1 255.0.0.0
RP/0/RSP0/CPU0:router(config-if)# abort
RP/0/RSP0/CPU0:router#
```

Related Topics

[end](#), on page 162

[exit](#), on page 167

admin

To enter Admin EXEC mode, use the **admin** command in EXEC mode.

admin

Syntax Description This command has no keywords or arguments.

Command Default None

Command Modes EXEC mode

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

Usage Guidelines Use the **admin** command to enter Admin EXEC mode mode. Administration commands are used to execute various administration plane commands.



Note Administration commands can be run only by entering administration mode and not by prefixing the **admin** command with the keyword in EXEC mode mode.

Task ID	Task ID	Operations
	admin	read, write, execute

The following example shows how to enter Admin EXEC mode mode:

```
RP/0/RSP0/CPU0:router# admin
RP/0/RSP0/CPU0:router(admin)#
```

To use administration configuration mode, use the **configure** command in Admin EXEC mode mode:

```
RP/0/RSP0/CPU0:router# admin
RP/0/RSP0/CPU0:router(admin)# configure
RP/0/RSP0/CPU0:router(admin-config)#
```

Related Topics

[configure](#), on page 158

alias

To create a command alias, use the **alias** command in Global Configuration mode. To delete an alias, use the **no alias** form of this command.

```
alias alias-name[(param-list)]content
no alias alias-name
```

Syntax Description

<i>alias-name</i>	Name of the command alias. Alias names can be a single word or multiple words joined by a hyphen (-) or an underscore (_).
<i>param-list</i>	(Optional) Parameters assigned to the alias. These parameters are filled in at execution time.
<i>content</i>	Original command syntax. Valid abbreviations of the original command syntax can be entered for the <i>content</i> argument.

Command Default

No command aliases are configured.

Command Modes

Global Configuration mode
Admin EXEC mode

Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	No modification.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Cisco IOS XR software supports generic alias definitions for various entities. Any physical or logical entity can have an alias as a reference. For example, an alias can refer to a command, a partial command, a group of commands, a location, or an IP address.

An alias must first be defined. The alias can then be used in command lines in place of the defined entity.

Following is a list of properties for an alias:

- An alias can be used anywhere and in any mode.
- An alias can have zero, one, or many parameters.
- An alias can refer to those parameters with the \$ sign.
- If an alias refers to more than one command, the commands must be separated by a semicolon (;).
- The size of the **alias** command is limited to 1024 characters.

The alias command can be used anywhere. If the content referenced by the alias is invalid or inappropriate in that context or mode, the system issues a warning message containing the substituted content.

An alias name should not be a subset of the keywords that it represents as alias. Substitution is done only when the entered input match fails completely. For instance, the attempt to define an alias with “config? as the alias name fails, as shown in the following example:

```
RP/0/RSP0/CPU0:router(config)# alias config set_host hostname router
RP/0/RSP0/CPU0:router(config)# show configuration
```

```
alias set_host hostname router
```

Use the **show aliases** command to display all command aliases or the command aliases in a specified mode.

Task ID

**Task Operations
ID**

```
logging read,
write
```

The following example shows how to create an alias named ipbr for the **show ipv4 interface brief** command, commit the configuration, enter EXEC mode and then enter the configured alias:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# alias ipbr show ipv4 interface brief
RP/0/RSP0/CPU0:router(config)# show configuration

Building configuration...
alias ipbr show ipv4 interface brief
end
RP/0/RSP0/CPU0:router(config)# commit
RP/0/RSP0/CPU0:Feb 21 04:42:57.017 : config[65689]: %MGBL-LIBTARCFG-6-COMMIT :
Configuration committed by user 'lab'. Use 'show configuration commit changes 1000000022'
to view the changes.
RP/0/RSP0/CPU0:router(config)# end
RP/0/RP0/CPU0:Mar 27 22:19:05 : config[65739]: %SYS-5-CONFIG_I : Configured from console
by lab
RP/0/RSP0/CPU0:router# ipbr
RP/0/RSP0/CPU0:router# show ipv4 interface brief

Interface                IP-Address      Status          Protocol
Loopback0                1.1.1.1         Up              Up
Loopback999              unassigned      Up              Up
MgmtEth0/0/CPU0/0       12.29.56.21    Up              Up
RP/0/RSP0/CPU0:router#
```

The following example shows how to define an alias, mycompany-10ge, for POS interface 1/0/2/3 and then how to use that alias to shut down the interface:

```
RP/0/RSP0/CPU0:router(config)# alias mycompany-10ge gigabitethernet1/0/2/3
RP/0/RSP0/CPU0:router(config)# interface mycompany-10ge
RP/0/RSP0/CPU0:router(config-if)# shutdown
RP/0/RSP0/CPU0:router(config-if)# exit
RP/0/RSP0/CPU0:router(config)#
```

The following example shows the use of a parameter name in an alias definition:

```
RP/0/RSP0/CPU0:router(config)# alias shint (intname) show interface $intname
```

The following example shows an alias defined with one parameter and two commands:

```
RP/0/RSP0/CPU0:router(config)# alias shint_both (intname) show interface $intname;show run
interface $intname
```

The following example shows the use of the alias `shint_both` in EXEC mode:

```
RP/0/RSP0/CPU0:router(exec)# shint_both(gigabitethernet1/2/3/4)
```

Two commands are issued, as follows:

```
RP/0/RSP0/CPU0:router(exec)# show interface gigabitethernet1/2/3/4; show run interface
gigabitethernet1/2/3/4
```

Related Topics

[show aliases](#), on page 220

apply-group

To cause the configuration commands contained in a group or multiple groups to be inherited by the router configuration within which it is applied, use the **apply-group** command in the appropriate configuration mode. To remove a group configuration, use the **no** form of this command.

apply-group *group-name* [*group-name*]
no apply-group

Syntax Description	<i>group-name</i> Name of the configuration group to apply. The group must be previously defined. Up to eight group names can be specified at one time.
---------------------------	---

Command Default	None
------------------------	------

Command Modes	Any configuration mode
----------------------	------------------------

Command History	Release	Modification
	Release 4.3.1	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Configuration statements in configuration groups come into effect only when the configuration groups are applied in the system configuration, and the configuration statements have the correct context and inheritance priority in the mode in which the configuration groups are applied. The maximum number of configuration groups that can be specified in a single **apply-group** command is eight.

To change the composition of an **apply-group** command, you must specify all desired groups. For example, if you used the command `apply-group g10 g20 g30`, and now you want to add the group `g15`, use the command `apply-group g10 g15 g20 g30`. If you now want to delete group `g20`, use the command `apply-group g10 g15 g30`. If you use the **no apply-group** command, all groups are removed from the configuration.



Note From the Release 6.3.1 onwards, you are able to enter the Flexible CLI config group definition, **apply-group** and **exclude-group** command in any order as long as the entire commit has all the group definitions needed.



Note Use multi-line configuration style to configure Flexible CLI configuration groups by entering each configuration mode in a separate line, one configuration per line. This is important so that the configuration properties are fully inherited and for better readability during troubleshooting.

Task ID	Task ID	Operation
	config-services	read, write

This example applies a configuration group to a specific OSPF instance:

```
RP/0/RSP0/CPU0:router# configure  
RP/0/RSP0/CPU0:router(config)# router ospf 0  
RP/0/RSP0/CPU0:router(config-ospf)# apply-group G-OSPF-B
```

Related Topics

[group \(configuration\)](#), on page 169

apply-group-remove

To remove one or more configuration groups from an existing apply-group, use the **apply-group-remove** command in the same configuration mode in which the group was applied.

apply-group-remove *group-name* *existing-group-name*

Syntax Description	<i>group-name</i>	Name of the group you want to remove from an existing group. Up to eight group names can be specified in this command at a time.
	<i>existing-group-name</i>	Name of the applied (pre-defined) group from which a group will be removed.

Command Default None

Command Modes Global configuration or any configuration mode

Command History	Release	Modification
	Release 5.1.1	This command was introduced.

Usage Guidelines Consider, you have configured four groups, g10 g20 g30 g40 using the **apply-group** command. To remove g20, you can use the **apply-group-remove** command to edit the **apply-group** command configuration.



Note This command is not a configuration command and will not be seen in **show configuration** or **show run** commands.



Note This command has to be executed in the same configuration mode as the **apply-group** command used to configure the groups.

Task ID	Task ID	Operation
	config-services	read, write

Example

This example shows how to remove the group, G-OSPF-B, using this command:

```
RP/0/RSP0/CPU0:router configure
RP/0/RSP0/CPU0:router (config)# router ospf 0
RP/0/RSP0/CPU0:router (config-ospf)# apply-group-remove G-OSPF-B
```

apply-template

To apply a template to the target configuration, use the **apply-template** command in Global Configuration mode.

apply-template *template-name* [(*param-list*)]

Syntax Description	<i>template-name</i>	Name of the template to be applied to the running configuration. Use the template command to define a template.
	<i>param-list</i>	(Optional) Up to five template parameters.

Command Default No templates are applied to the target configuration.

Command Modes Global Configuration mode

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **apply-template** command to apply a template to the target configuration. Templates allow you to create a template name that represents a group of configuration commands.

Use the **template** command to define a template. Use the **end-template** command to exit template configuration mode and return to global configuration mode. Use the **show-running** command with the optional **template** *template-name* keyword and argument to display the contents of a template.

Task ID	Task ID	Operations
	config-services	read, write

The following example shows how to define a template and then apply the template to the target configuration:

```
RP/0/RSP0/CPU0:router(config)# template hostname-template
RP/0/RSP0/CPU0:router(config-TPL)# hostname router1
RP/0/RSP0/CPU0:router(config-TPL)# end-template
RP/0/RSP0/CPU0:router(config)# apply-template hostname-template
```

Related Topics

[end-template](#), on page 165

[show running-config](#), on page 262
[template](#), on page 266

clear comment

To discard a comment associated with a configuration, use the **clear comment** command in any configuration or Global Configuration mode.

clear comment

Syntax Description This command has no keywords or arguments.

Command Default None

Command Modes Any configuration mode
Global Configuration mode

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

Usage Guidelines The **clear comment** command clears any comments that were added for a specific configuration in the configuration file. After you enter the **clear comment** command, enter the configuration for which you want to delete the comment on a separate line.

To enter configuration comments, enter ! followed by the comment. The comment you enter is associated with the next configuration entered. For example:

```
RP/0/RSP0/CPU0:router#!router1 is located in xxx
RP/0/RSP0/CPU0:router# hostname router1
RP/0/RSP0/CPU0:router# commit
```

The comment is displayed in the output of the **show running-config** command:

```
RP/0/RSP0/CPU0:router# show running-config
...
!router1 is located in xxx
hostname router1
...
```

Task ID	Task ID	Operations
	Task ID for the feature or configuration mode impacted by the command	Operation for the feature or configuration mode impacted by the command

The following example shows how to discard the comment associated with the configuration ipv4 address 1.1.1.1 255.0.0.0.

```
RP/0/RSP0/CPU0:router(config-if)# clear comment
```

```
RP/0/RSP0/CPU0:router(config-if)# ipv4 address 1.1.1.1 255.0.0.0
```

clear configuration commits

To delete old commit IDs from the commit database to free up disk space, use the **clear configuration commits** command in Admin EXEC mode or EXEC mode.

clear configuration commits {*diskspace kilobytes* | **oldest** *number-of-commits*}

Syntax Description		
diskspace <i>kilobytes</i>	Deletes as many commit IDs (beginning with the oldest available commit ID) from the commit database as required to free the number of kilobytes (KB) specified for the <i>kilobytes</i> argument. The range for the number of kilobytes of disk space to free is 1 to 4194304.	Note The amount of disk space freed may vary depending on the size and number of commits present in the commit database.
oldest <i>number-of-commits</i>	Deletes the number of commit IDs specified for the <i>number-of-commits</i> argument.	Note Use the online help (?) function to display the range of commit IDs available for deletion.

Command Default None

Command Modes EXEC mode
Admin EXEC mode

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **clear configuration commits** command to delete the number of commit IDs available for rollback operations. The most recent 100 commits are retained by the system. As new commit IDs are added, the oldest commit IDs are discarded and are no longer available for rollback operations.



Note The **clear configuration commits** command deletes commits from the commit database only. The running configuration, thus, is not changed.



Note When a commit ID is deleted from the commit database, it is no longer available for rollback and can no longer be used to display commit changes (with the **show configuration rollback changes** command).

Use the **rollback configuration** command to roll back the current running configuration to a previous configuration. Use the **show configuration rollback changes** command to display a list of the commit IDs available for rollback operations or to display the changes that would be made by the **rollback configuration** command.

Task ID	Task ID	Operations
	config-services	execute

The following example shows how to delete the oldest 16 commit IDs to free up disk space. After entering this command, you will be prompted to confirm the deletion.

```
RP/0/RSP0/CPU0:router# clear configuration commits oldest 16

Deleting 16 rollback points '1000000021' to '1000000036'
256 KB of disk space will be freed. Continue with deletion?[confirm] y
```

Related Topics

[rollback configuration](#), on page 193

[show configuration rollback changes](#), on page 250

clear configuration inconsistency

To clear an inconsistency alarm for a router configuration or admin plane configuration, use the **clear configuration inconsistency** command in Admin EXEC mode or EXEC mode.

clear configuration inconsistency

Syntax Description

This command has no keywords or arguments.

Command Default

Administration EXEC mode: Clears the inconsistency alarms for the admin plane configuration.

EXEC mode: Clears the inconsistency alarms for an SDR configuration.

Command Modes

Admin EXEC mode

EXEC mode

Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	No modification.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

An inconsistency alarm is set when there is a failure to restore the configuration; this can occur during router startup, or when a line card or route switch processor (RSP) card is inserted or removed.

If an inconsistency alarm is set, a message similar to the following example is displayed:

```
RP/0/0/CPU0:May 26 11:58:40.662 : cfgmgr-rp[130]: %MGBL-CONFIGCLI-3
  BATCH_CONFIG_FAIL : 28 config(s) failed during startup. To view
  failed config(s) use the command - "show configuration failed startup"
```

```
RP/0/0/CPU0:May 26 11:58:41.731 : cfgmgr-rp[130]:
  %MGBL-CONFIG-3-ADMIN_INCONSISTENCY_ALARM : Admin plane configuration
  inconsistency alarm has been raised. Configuration commits will be
  blocked until an ADMIN plane 'clear configuration inconsistency' command
  has been run to synchronize persisted admin plane configuration with
  running admin configuration.
```

When the inconsistency alarm is set, all configuration commit operations fail until the alarm is cleared using the **clear configuration inconsistency** command. This command clears the alarm and removes the failed configuration.

For example, the following configuration commit fails to finish due to an existing inconsistency alarm:

```
RP/0/RSP0/CPU0:router# configure

ADMIN plane running configuration is inconsistent with persistent
configuration.
No configuration commits will be allowed until an admin plane
'clear configuration inconsistency' command is performed.
RP/0/RSP0/CPU0:router(config)# hostname router2
```

```
RP/0/RSP0/CPU0:router(config)#commit
```

ADMIN plane running configuration is inconsistent with persistent configuration.

No configuration commits will be allowed until an admin plane 'clear configuration inconsistency' command is performed.

Enter the **clear configuration inconsistency** command to clear the alarm and allow commit operations to continue.

**Note**

To reapply the failed configuration, you must reapply and recommit the configuration. Use the **load configuration failed** command with the **startup** keyword to populate the target configuration with the contents of the previous failed configuration from the startup configuration.

Use the **show configuration history** command with the **alarm** keyword to view the inconsistency alarm set and alarm clear events in the configuration history log.

Command Modes

To clear the inconsistency alarms for the admin plane configuration, enter the **clear configuration inconsistency** command in administration EXEC mode.

To clear the inconsistency alarms for the router, enter the **clear configuration inconsistency** command in EXEC mode.

Task ID

Task ID	Operations
config-services	execute

The following example shows how to clear the inconsistency alarms for the admin plane configuration by entering the **clear configuration inconsistency** command in administration EXEC mode:

```
RP/0/RSP0/CPU0:router# admin
RP/0/RSP0/CPU0:router(admin)# clear configuration inconsistency

Creating any missing directories in Configuration File system...OK
Initializing Configuration Version Manager...OK
Syncing ADMIN commit database with running configuration...OK
Re-initializing cache files...OK
Updating Commit Database. Please wait...[OK]
```

The following example shows how to clear the inconsistency alarms for a router configuration. The command is entered in EXEC mode.

```
RP/0/RSP0/CPU0:router# clear configuration inconsistency

Creating any missing directories in Configuration File system...OK
Initializing Configuration Version Manager...OK
Syncing commit database with running configuration...OK
Re-initializing cache files...OK
Updating Commit Database. Please wait...[OK]
```

In the following example, a history of the inconsistency alarms set and cleared for the router configuration are displayed using the **show configuration history** command with the **alarm** keyword:

```
RP/0/RSP0/CPU0:router# show configuration history alarm
```

Sno.	Event	Info	Time Stamp
~~~~	~~~~~	~~~~~	~~~~~
1	alarm	inconsistency alarm raised	Thu Jun 22 15:23:15 2009
2	alarm	inconsistency alarm cleared	Thu Jun 22 15:42:30 2009
3	alarm	inconsistency alarm raised	Sun Jul 9 13:39:57 2009
4	alarm	inconsistency alarm cleared	Sun Jul 9 14:15:48 2009
5	alarm	inconsistency alarm raised	Sat Jul 15 18:18:26 2009
6	alarm	inconsistency alarm cleared	Sat Jul 15 19:21:03 2009

### Related Topics

- [load configuration failed](#), on page 179
- [show configuration history](#), on page 240
- [show configuration failed startup](#), on page 239

# clear configuration inconsistency replica

To resolve configuration inconsistencies on a replica node, use the **clear configuration inconsistency replica** command in administration EXEC or EXEC mode.

**clear configuration inconsistency replica location** *node-id*

<b>Syntax Description</b>	<b>location</b> <i>node-id</i> Resolves the configuration inconsistencies on the designated node. The <i>node-id</i> argument is expressed in the <i>rack/slot/module</i> notation.
---------------------------	-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

<b>Command Default</b>	Administration EXEC mode: Resolves any configuration inconsistencies for the admin plane configuration. EXEC mode: Resolves any configuration inconsistencies for the router configuration.
------------------------	------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

<b>Command Modes</b>	Admin EXEC mode EXEC mode
----------------------	------------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

In administration EXEC mode, the replica node for the **clear configuration inconsistency replica** command is the standby designated system controller (DSC). In EXEC mode, the replica nodes are the route switch processors (RSPs) that can become the designated shelf controller (DSC).

Use the **clear configuration inconsistency replica** command if there is a configuration inconsistency between the standby DSC and the current active DSC; or alternatively, if the configuration on any nodes that could become the DSC is not the same as the configuration on the current DSC. To determine if you have a configuration inconsistency, use the **show configuration inconsistency replica** command.

To clear configuration inconsistencies for the admin plane configuration, enter the **clear configuration inconsistency replica** command in administration EXEC mode.

To clear configuration inconsistencies for an SDR configuration, enter the **clear configuration inconsistency replica** command in EXEC mode for that SDR.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	config-services	execute

The following example shows how to clear any configuration inconsistencies for the DSC configuration by using the **clear configuration inconsistency replica** command in EXEC mode:

```
RP/0/RSP0/CPU0:router# clear configuration inconsistency replica location 0/rp1/cpu0
```



The replica has been repaired.

**Related Topics**

[show configuration inconsistency replica](#), on page 244

# clear configuration sessions

To clear (end) an active configuration session, use the **clear configuration sessions** command in administration EXEC or EXEC mode.

**clear configuration sessions** *session-id*

<b>Syntax Description</b>	<i>session-id</i> Identifier for the configuration session to be terminated.
---------------------------	------------------------------------------------------------------------------

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Administration EXEC EXEC mode
----------------------	----------------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

Use the **clear configuration sessions** command to clear a configuration session. This command can be used to end the configuration sessions of another user. Any uncommitted changes to a user's target configuration are discarded.

Use the **show configuration sessions** command to identify active configuration sessions.

When a configuration session is cleared, a message is displayed on the terminal of the terminated user. For example:

```
RP/0/RSP0/CPU0:router(config)# This configuration session was terminated by user 'user_a'
from line 'aux0_0_CPU0'
```

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	config-services	execute

The following example shows how to clear an active configuration session. In this example, the **show configuration sessions** command displays the active configuration session. The **clear configuration sessions** command clears the active configuration session.

```
RP/0/RSP0/CPU0:router# show configuration sessions

Current Configuration Session  Line      User      Date      Lock
00000211-002c409b-00000000    con0_RSPs1_CPU0  UNKNOWN  Mon Feb  2 01:02:09 2009

RP/0/RSP0/CPU0:router# clear configuration sessions 00000211-002c409b-00000000
```

```
session ID '00000211-002cb09b-00000000' terminated
```

**Related Topics**

[show configuration sessions](#), on page 257

# commit

To commit the target configuration to the active (running) configuration, use the **commit** command in any configuration Global Configuration mode Admin Configuration mode.

**commit** [**best-effort**] [**comment** *line*] [**confirmed** [{*seconds* | **minutes** *minutes*}]] [**force**] [**label** *line*] [**replace**] [**save-running** **filename** *file_path*]

Syntax Description		
<b>best-effort</b>		(Optional) Merges the target configuration with the running configuration and commits only valid changes (best effort). Some configuration changes might fail due to semantic errors.
<b>comment</b> <i>line</i>		(Optional) Assigns a comment to a commit. This text comment is displayed in the commit entry displayed in the output for the <b>show configuration commit list</b> command with the optional <b>detail</b> keyword.
<b>confirmed</b> [ <i>seconds</i>   <b>minutes</b> <i>minutes</i> ]		(Optional) Commits the configuration on a trial basis for the time specified in seconds or minutes.  <b>Note</b> The <b>confirmed</b> option is not available in administration configuration mode.
<b>force</b>		(Optional) Forces a commit operation in low-memory conditions.
<b>label</b> <i>line</i>		(Optional) Assigns a meaningful label. This label is displayed (instead of the autogenerated commit ID) in the output for the <b>show configuration commit list</b> .
<b>replace</b>		(Optional) Replaces the entire running configuration with the contents of the target configuration.
<b>save-running</b> <b>filename</b> <i>file_path</i>		(Optional) Saves the running configuration to a specified file.

**Command Default** The default behavior is *pseudo-atomic*, meaning that all changes must succeed for the entire commit operation to succeed. If any errors are found, none of the configuration changes take effect.

**Command Modes** Any configuration mode  
Global Configuration mode  
Admin Configuration mode

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

---

**Usage Guidelines**

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Changes made during a configuration session are inactive until the **commit** command is entered. By default, the commit operation is *pseudo-atomic*, meaning that all changes must succeed for the entire commit operation to succeed. If any errors are found, none of the configuration changes takes effect.

To replace the default numeric ID for the commit, use the optional **label** keyword. This label is displayed (instead of the autogenerated commit ID) in the output for the **show configuration commit list** command.

Enter an optional comment with the **comment** keyword to provide additional information about the commit action. This comment is displayed in the output for the **show configuration commit list** command with the **detail** keyword.

Use the optional **confirmed minutes** keyword and argument to commit a configuration on a trial basis for a minimum of 30 seconds and a maximum of 300 seconds (5 minutes). During the trial configuration period, enter the **commit** command to confirm the configuration. If the **commit** command is not entered, then the system reverts to the previous configuration when the trial time period expires. The confirmed option is not available in administration configuration mode.

You can use the **commit** command in conjunction with the **load** command. Load a new configuration with the **load** command, and use the **commit** command with the **replace** keyword to have the loaded configuration become the active (running) configuration.

Use the optional **save-running filename file_path** keywords and argument to save the running configuration to a specified file. To configure automatic saving of the configuration file on every commit, use the **configuration commit auto-save** command. If automatic saving of the configuration file is already enabled, specifying **save-running filename file_path** with the **commit** command has no additional effect.

In pseudo-atomic commit, if an error occurs on one or more of the configurations in a commit, other configurations which are already part of the running configuration in the same commit are reverted.

**Caution**

Saving the running configuration to a file is CPU intensive.

---

**Note**

If you use the **commit** command without previously loading a target configuration, a blank configuration is committed.

---

**Note**

If you use the **commit** command with the **replace** keyword, it does not affect the mode of an 8-port E1/T1 SPA. If the mode is E1 before using the **commit replace** command, it remains E1. However, since the default mode is T1, the router does not recognize that the mode is E1. To change the mode to T1, you must first use the **hw-module subslot cardtype e1** command to add the E1 mode into the configuration so that it correlates with the system. Then manually reload the router and it boots in T1 mode.

For more information regarding the **hw-module subslot cardtype** command, refer to *Interface and Hardware Component Command Reference for Cisco ASR 9000 Series Routers*.

---

Task ID	Task ID	Operations
	Task ID for the feature or configuration mode impacted by the command	Operation for the feature or configuration mode impacted by the command

### Committing the Target Configuration to the Active Running Configuration

The following example shows how to commit the target configuration to the active running configuration. In this example, the **commit** command saves changes to the router hostname.

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# hostname router1
RP/0/RSP0/CPU0:router(config)# commit

RP/0/RSP0/CPU0:Feb 21 04:42:57.017 : config[65689]: %MGBL-LIBTARCFG-6-COMMIT :
Configuration committed by user 'user_a'.
Use 'show configuration commit changes 1000000033' to view the changes.
```

### Adding a Comment to a Configuration Commit

The following example shows how to use the **commit** command with the optional **comment line** keyword and argument to assign a text description to the commit operation. The comment is then displayed in the output of the **show configuration commit list** command with the **detail** keyword.

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# hostname router2
RP/0/RSP0/CPU0:router(config)# commit comment new name for router

RP/0/RP0/CPU0:Feb 21 04:42:57.017 : config[65689]: %MGBL-LIBTARCFG-6-COMMIT :
Configuration committed by user 'user_a'. Use 'show configuration commit
changes 1000000226' to view the changes.

RP/0/RSP0/CPU0:router2(config)# end
RP/0/RSP0/CPU0:router2# show configuration commit list detail

1) CommitId: 1000000226          Label: NONE
   UserId:   user_a              Line:   con0_RP1_CPU0
   Client:   CLI                 Time:   12:59:26 UTC Wed Feb 04 2004
   Comment:  new name for router

2) CommitId: 1000000225          Label: NONE
   UserId:   user_a              Line:   con0_RP1_CPU0
   Client:   CLI                 Time:   12:58:32 UTC Wed Feb 04 2004
   Comment:  NONE
```

### Changing the Commit ID to a Text Label

The following example shows how to use the **commit** command with the optional **label line** keyword and argument to change the commit ID to a text label for easier identification. The label is then displayed in the output of the **show configuration commit list** command.

```
RP/0/RSP0/CPU0:router2# configure
```

```
RP/0/RSP0/CPU0:router2(config)# hostname router3
RP/0/RSP0/CPU0:router2(config)# commit label new_name

RP/0/RP0/CPU0:Feb 21 04:42:57.017 : config[65689]: %MGBL-LIBTARCFG-6-COMMIT :
Configuration committed by user 'user_a'.
Use 'show configuration commit changes 1000000227' to view the changes.

RP/0/RSP0/CPU0:router3(config)# end
RP/0/RSP0/CPU0:router3# show configuration commit list
```

SNo.	Label/ID	User	Line	Client	Time Stamp
1	new_name	user_a	con0_RSPs1_C	CLI	13:00:53 UTC Wed Feb 04 2004
2	1000000226	user_a	con0_RSPs1_C	CLI	12:59:26 UTC Wed Feb 04 2004
3	1000000225	user_a	con0_RSPs1_C	CLI	12:58:32 UTC Wed Feb 04 2004

### Commit a Configuration for a Specified Time

The following example shows how to use the **commit** command with the optional **confirmed** keyword and number *argument*. The configuration changes are committed only for the specified number of seconds. You can then either confirm the commit operation or discard the changes.

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# hostname router3
RP/0/RSP0/CPU0:router(config)# commit confirmed 30
RP/0/RSP0/CPU0:router3(config)# end
```

### Related Topics

- [abort](#), on page 131
- [end](#), on page 162
- [exit](#), on page 167
- [configuration commit auto-save](#), on page 156
- [load](#), on page 175
- [show configuration rollback changes](#), on page 250

# configuration commit auto-save

To enable automatic saving of the running configuration to a specified file on every commit, use the **configuration commit auto-save** command in Global Configuration mode. To disable automatic saving of the running configuration to a specified file on every commit, use the **no** form of the command.



## Caution

Saving the running configuration to a file is CPU intensive.

```
configuration commit auto-save filename file_path
no configuration commit auto-save
```

## Syntax Description

**filename** *file_path* Specifies the location to which to save the running configuration.

## Command Default

None

## Command Modes

Global Configuration mode  
Admin Configuration mode

## Command History

Release	Modification
Release 3.7.2	This command was introduced
Release 6.1.2	The command was enhanced to save the copy of your config with unique filename

## Usage Guidelines

The **configuration commit auto-save** command configures the system to save the running configuration to the specified file and location every time a **commit** command is run. Alternatively, you can save the configuration on a one-time basis by specifying the **save-running** keyword when you run the **commit** command. Use the following syntax when using **tftp**, **ftp**, or **rcp** as options: Configuration commit auto-save filename

[*tftp|ftp|rcp*]

The **configuration commit auto-save** command saves the copy of your config with unique filename. The unique filename is generated by appending timestamp to the filename.

For example:

```
router(config)# hostname T2
T2(config)# configuration commit auto-save filename disk0:/CONF_BK
T2(config)# end
T2(config)# commit
-----
ios.0/0/CPU0:/disk0:ios.0/0/CPU0disk0: $ ls -lt
total 60
-rwx----- 1 <username> eng 399 Jul 3 17:34 CONF_BK_TS.20160703-173423
```



Task ID	Task ID	Operations
	config-services	write

The following example shows how to configure the system to save the running configuration to the file `disk0:/usr` whenever the **commit** command is used:

```
RP/0/RSP0/CPU0:router(config)# configuration commit auto-save filename disk0:/usr
```

### Related Topics

[commit](#), on page 152

# configure

To enter global configuration mode or administration configuration mode, use the **configure** command in EXEC mode or Admin EXEC mode.

**configure** [{**exclusive** | **terminal**}]

<b>Syntax Description</b>	<b>exclusive</b> (Optional) Locks the router configuration. The system configuration can be made only from the login terminal.
	<b>terminal</b> (Optional) Configures the system from the login terminal. This is the default.

**Command Default** If the **configure** command is entered without a keyword, the system is configured from the login terminal.

**Command Modes** EXEC mode  
Admin EXEC mode

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Configuration modes are used to enter changes to a target configuration session and commit those changes to the running configuration. A router running Cisco IOS XR software contains multiple configurations:

- The configuration for a router. This mode is used to configure router-specific features such as routing protocols.
- The administration configuration for system-wide resources and settings. Some features can be configured only in administration configuration mode.

## Global Configuration mode

Use the **configure** command in EXEC mode to enter Global Configuration mode and create a new target configuration for an SDR. From global configuration mode, you can enter any configuration mode. Configuration changes entered in global configuration mode impact the SDR to which the user is currently logged in.

## Admin Configuration mode

Use the **configure** command in Admin EXEC mode to enter Admin Configuration mode and create a new target configuration. From Admin EXEC mode, you can enter any configuration mode. Configuration changes entered in Admin EXEC mode can impact resources for the entire router. See the command reference documentation for a specific command to determine the impact of commands entered in Admin EXEC mode.

## Router Prompt

After you enter the **configure** command, the system appends “(config)” to the router prompt, indicating that the router is in a configuration mode. For example:

- The following prompt indicates that you are in global configuration mode for an SDR:

```
RP/0/RSP0/CPU0:router (config) #
```

- The following prompt indicates that you are in administration configuration mode:

```
RP/0/RSP0/CPU0:router (admin-config) #
```

## Locking a Configuration Session

To lock the configuration so that no other user can commit changes to the running configuration during your configuration session, issue the **configure** command with the **exclusive** keyword.

## Committing Changes and Returning to EXEC mode or Admin EXEC mode

Changes to the target configuration remain inactive until the **commit** command is entered. To leave global configuration or administration configuration mode and return to the EXEC mode or Admin EXEC mode prompt, issue the **end** or **exit** command; you are prompted to commit any uncommitted changes.

To leave configuration mode and return directly to EXEC mode or Admin EXEC mode without being prompted to commit changes and without saving changes to the target configuration, enter the **abort** command in any configuration mode.

The following example shows how to enter global configuration mode from EXEC mode and then enter interface configuration mode to configure an IPv4 address, the **configure** command commits the configuration, and the **end** command terminates the configuration session and return the router to EXEC mode.

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router (config)# interface tengige 0/1/0/0
RP/0/RSP0/CPU0:router (config-if)# ipv4 address 1.1.1.1 255.0.0.0
RP/0/RSP0/CPU0:router (config-if)# commit
RP/0/RSP0/CPU0:router (config-if)# end
RP/0/RSP0/CPU0:router#
```

## Related Topics

- [abort](#), on page 131
- [end](#), on page 162
- [exit](#), on page 167
- [show configuration \(config\)](#), on page 222
- [show running-config](#), on page 262

# description (interface)

To add a description to an interface configuration, use the **description** command in interface configuration mode. To remove the description, use the **no** form of this command.

**description** *comment*  
**no description**

## Syntax Description

*comment* Comment or a description applied to the interface. The maximum number of characters is 1022.

## Command Default

No description is configured.

## Command Modes

Interface configuration

## Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	No modification.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **description** command to add a description to an interface configuration. The maximum number of characters is 1022.

## Task ID

### Task ID Operations

interface read,  
write

The following example shows how to add a description to an interface configuration. In this example, the **description** command names a Management Ethernet interface.

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# interface mgmteth 0/
RSP
1/CPU0/0
RP/0/RSP0/CPU0:router(config-if)# description Management Ethernet Interface
```

## Related Topics

[show interfaces](#)

# do

To execute an EXEC mode command from a configuration mode, use the **do** command in any configuration mode.

**do** *exec-command*

<b>Syntax Description</b>	<i>exec-command</i> EXEC mode command to be executed.
---------------------------	-------------------------------------------------------

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Any configuration mode
----------------------	------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

To display the various EXEC mode commands that are available to execute with the **do** command, use the online help (?) function at the configuration mode prompt.



<b>Note</b>	The <b>configure</b> and <b>describe</b> commands are not supported with the <b>do</b> command.
-------------	-------------------------------------------------------------------------------------------------

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	Task ID for the EXEC command that you are using	read

The following example shows how to execute an EXEC command from interface configuration mode. In this example, the **do** command displays output from the **show protocols** command within interface configuration mode:

```
RP/0/RSP0/CPU0:router(config)# interface tengige 0/1/0/1
RP/0/RSP0/CPU0:router(config-if)# do show protocols
```

```
Routing Protocol "BGP 1"
```

```
Address Family IPv4 Unicast:
  Distance: external 20 internal 200 local 200
```

# end

To terminate a configuration session and return directly to EXEC mode Admin EXEC mode , use the **end** command in any configuration mode.

**end**

**Syntax Description** This command has no keywords or arguments.

**Command Default** None

**Command Modes** Any configuration mode

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** Use the **end** command to exit any configuration mode and return directly to EXEC mode Admin EXEC mode. If you enter this command without committing the changes to the target configuration, you are prompted to do so:

```
Uncommitted changes found, commit them before exiting(yes/no/cancel)?[cancel]:
```

- Entering **yes** saves configuration changes to the running configuration file, exits the configuration session, and returns the router to EXEC mode Admin EXEC mode.

If errors are found in the running configuration, the configuration session does not end. To view the errors, enter the **show configuration** (config) command with the **failed** keyword.

- Entering **no** exits the configuration session and returns the router to EXEC mode Admin EXEC mode without committing the configuration changes.
- Entering **cancel** leaves the router in the current configuration session without exiting or committing the configuration changes.



**Note** Entering **Ctrl-Z** is functionally equivalent to entering the **end** command.

Use the **abort** command to exit the configuration session and return to EXEC mode Admin EXEC mode without being prompted to commit changes and without saving changes to the target configuration.

Task ID	Task ID	Operations
	config-services	read, write

The following example shows how to use the **end** command to end a configuration session. Changes stored in the target configuration are committed by answering **yes**.

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# interface tengige 0/2/0/0
RP/0/RSP0/CPU0:router(config-if)# ipv4 address 1.1.1.1 255.0.0.0
RP/0/RSP0/CPU0:router(config-if)# end
```

```
Uncommitted changes found, commit them before exiting(yes/no/cancel)? [cancel]: yes
RP/0/RSP0/CPU0:router#
```

### Related Topics

[abort](#), on page 131

[exit](#), on page 167

[show configuration \(config\)](#), on page 222

[commit](#), on page 152

# end-group

To exit from configuration group submode and return to global configuration mode, use the `end-group` command in group configuration mode.

## end-group

**Syntax Description** This command has no keywords or arguments.

**Command Default** None

**Command Modes** Group configuration

Command History	Release	Modification
	Release 4.3.1	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

After you have included all configuration statements that you want in a particular configuration group, use the **end-group** command to exit group configuration mode.

Task ID	Task ID	Operation
	config-services	read, write

This example shows how to complete the configuration of a configuration group and exit group configuration mode:

```
RP/0/RSP0/CPU0:router(config)# group g-int-gige
RP/0/RSP0/CPU0:router(config-GRP)# interface 'GigabitEthernet.*'
RP/0/RSP0/CPU0:router(config-GRP-if)# mtu 1514
RP/0/RSP0/CPU0:router(config-GRP-if)# end-group
RP/0/RSP0/CPU0:router(config)#
```

## Related Topics

[group \(configuration\)](#), on page 169



# end-template

To exit template configuration mode and return to Global Configuration mode, use the **end-template** command in template configuration mode.

## end-template

**Syntax Description** This command has no keywords or arguments.

**Command Default** No default behavior or values.

**Command Modes** Template configuration

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** Use the **end-template** command to exit template configuration mode after you have completed the template definition.

To define a template, use the **template** command. To apply a template to the target configuration, use the **apply-template** command. To view the contents of a template, use the **show running-config** command with the optional **template** *template-name* keyword and argument.

Task ID	Task ID	Operations
	config-services	read, write

The following example shows how to enter template configuration mode, define a template named “hostname-template” and then exit from template configuration mode:

```
RP/0/RSP0/CPU0:router(config)# template hostname-template
RP/0/RSP0/CPU0:router(config-TPL)# hostname router-cs1
RP/0/RSP0/CPU0:router(config-TPL)# end-template
RP/0/RSP0/CPU0:router(config)#
```

## Related Topics

[end](#), on page 162

# exclude-group

To exclude (or override) a configuration group (or groups) to be inherited by the router configuration, use the **exclude-group** command in the appropriate configuration mode. To delete the set exclusion, use the **no** form of this command.

**exclude-group** *group-name*

<b>Syntax Description</b>	<i>group-name</i> Configuration group name that needs to be excluded.
---------------------------	-----------------------------------------------------------------------

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Global configuration
----------------------	----------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 5.1.1	This command was introduced.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

More than one configuration group can be excluded simultaneously. A maximum of eight groups can be specified at one time.



<b>Note</b>	From Release 6.3.1 onwards, you can enter Flexible CLI config groups, <b>apply-group</b> and <b>exclude-group</b> command in any order as long as the entire commit has all the group definitions needed.
-------------	-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	config-services	read, write

## Example

This example shows how to delete the group G_interface using the **exclude-group** command:

```
RP/0/RSP0/CPU0:router (config) # exclude-group G_interface

exclude-group G_INTERFACE
ipv4 address 12.21.50.100 255.255.0.0
!
interface GigabitEthernet0/0/0/1
ipv4 address 12.21.51.100 255.255.0.0
```

# exit

To close an active terminal session and log off the router, use the **exit** command in EXEC mode Admin EXEC mode.

To return the router to the next higher configuration mode, use the **exit** command in any configuration mode.

**exit**

<b>Syntax Description</b>	This command has no keywords or arguments.
---------------------------	--------------------------------------------

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	EXEC mode Any configuration
----------------------	--------------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

To log off from a terminal session, enter the **exit** command in EXEC mode Admin EXEC mode.

When exiting from global or administration configuration mode to EXEC mode Admin EXEC mode, you are prompted to commit any uncommitted configuration changes.

```
Uncommitted changes found, commit them before exiting(yes/no/cancel)?[cancel]:
```

- Entering **yes** saves configuration changes to the running configuration file, exits the configuration session, and returns the router to EXEC mode Admin EXEC mode.  
If errors are found in the running configuration, the configuration session does not end. To view the errors, enter the **show configuration** (config) command with the **failed** keyword.
- Entering **no** exits the configuration session and returns the router to EXEC mode Admin EXEC mode without committing the configuration changes.
- Entering **cancel** leaves the router in the current configuration session without exiting or committing the configuration changes.



<b>Note</b>	Entering the <b>exit</b> command from global configuration is functionally equivalent to entering the <b>end</b> command.
-------------	---------------------------------------------------------------------------------------------------------------------------

Task ID	Task ID	Operations
	config-services	read, write

The following example shows how to return the router to the next higher command mode. In this example, the **exit** command exits from interface configuration mode and returns to global configuration mode. The **exit** command is entered a second time to exit from global configuration mode and return to EXEC mode. Because the configuration has not been committed explicitly (with the **commit** command), the system prompts to commit the configuration changes made during the session.

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# interface tengige 0/2/0/0
RP/0/RSP0/CPU0:router(config-if)# ipv4 address 1.1.1.1 255.0.0.0
RP/0/RSP0/CPU0:router(config-if)# exit
RP/0/RSP0/CPU0:router(config)# exit
Uncommitted changes found, commit them before exiting(yes/no/cancel)?[cancel]: yes
```

The following example shows how to use the **exit** command from EXEC mode to log off from a terminal session:

```
RP/0/RSP0/CPU0:router# exit

router con0_RP1_CPU0 is now available

Press RETURN to get started.
```

### Related Topics

- [abort](#), on page 131
- [end](#), on page 162
- [commit](#), on page 152

# group (configuration)

To define a configuration group containing configuration statements that can be applied in the router configuration, use the **group** command in global configuration mode. To remove a configuration group from the running configuration, use the **no** form of this command.

```
group group-name config-statements
no group group-name
```

<b>Syntax Description</b>	<i>group-name</i> Name of the configuration group.				
	<i>config-statements</i> Series of configuration statements, starting in global configuration mode, that comprise this configuration group.				
<b>Command Default</b>	None				
<b>Command Modes</b>	Global configuration				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 4.3.1</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 4.3.1	This command was introduced.
Release	Modification				
Release 4.3.1	This command was introduced.				

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **group** command enters group configuration mode where you can list a series of configuration statements that can then be used elsewhere in the router configuration. Most configuration commands can be used in group configuration mode. You must be in a user group associated with a task group that includes the appropriate task IDs for each of the command statements that you list within a configuration group.

The *group-name* argument is limited to 32 characters and is case-sensitive. It must not contain any of these special characters:

- ` - grave
- ' - single quote
- " - double quote
- < - less than
- > - greater than
- ( - open parenthesis
- ) - close parenthesis
- [ - open bracket
- ] - close bracket
- { - open brace

- } - close brace
- / - slash
- \ - backslash
- & - ampersand
- ^ - caret
- ! - exclamation point
- ? - question mark
- ~ - tilde
- * - asterisk
- % - percent sign
- = - equal sign
- , - comma
- + - plus sign
- | - vertical bar
- - space

A configuration group can be removed from the running configuration, only if it is not used by a configured **apply-group** command.

To exit from configuration group submode and return to global configuration mode, use the **end-group** command.

Regular expressions are used within the configuration statements to make them widely applicable. POSIX 1003.2 regular expressions are supported in the names of configuration statements. Single quotes are used to delimit a regular expression. For example, to specify the regular expression `GigabitEthernet.*` that matches all GigabitEthernet interfaces, enter the regular expression within single quotes as `'GigabitEthernet.*'`.

To display a list of available interface types for your router configuration, enter **interface ?** at the configuration group prompt:

```
RP/0/RSP0/CPU0:router(config-GRP) # interface ?

ATM          'RegExp': ATM Network Interface(s)
BVI          'RegExp': Bridge-Group Virtual Interface
Bundle-Ether 'RegExp': Aggregated Ethernet interface(s)
Bundle-POS   'RegExp': Aggregated POS interface(s)
GigabitEthernet 'RegExp': GigabitEthernet/IEEE 802.3 interface(s)
IMA          'RegExp': ATM Network Interface(s)
Loopback     'RegExp': Loopback interface(s)
MgmtEth      'RegExp': Ethernet/IEEE 802.3 interface(s)
Multilink    'RegExp': Multilink network interface(s)
Null         'RegExp': Null interface
POS          'RegExp': Packet over SONET/SDH network interface(s)
PW-Ether     'RegExp': PWHE Ethernet Interface
PW-IW        'RegExp': PWHE VC11 IP Interworking Interface
Serial       'RegExp': Serial network interface(s)
tunnel-ip    'RegExp': GRE/IPinIP Tunnel Interface(s)
```

```
tunnel-mte      'RegExp': MPLS Traffic Engineering P2MP Tunnel interface(s)
tunnel-te       'RegExp': MPLS Traffic Engineering Tunnel interface(s)
tunnel-tp       'RegExp': MPLS Transport Protocol Tunnel interface
```



**Note** Although you are required to enter only enough characters for the interface type to be unique, it is recommended that you enter the entire phrase. All interface types used in regular expressions are case-sensitive.

For example, you can use the command `interface 'GigabitEthernet.*'`, but not `interface 'gigabite.*'`. To specify a subinterface, prefix the expression with the characters `\` (backslash period), for example: `interface 'GigabitEthernet.*\.*'`. Refer to the *Configuring Flexible Command Line Interface Configuration Groups* module in the *System Management Configuration Guide for Cisco ASR 9000 Series Routers* for more extensive examples.

Task ID	Task ID	Operation
	config-services	read, write

This example shows the definition of a configuration group to configure Gigabit Ethernet interfaces with ISIS routing parameters:

```
RP/0/RSP0/CPU0:router(config)# group g-isis-gige
RP/0/RSP0/CPU0:router(config-GRP)# router isis '.*'
RP/0/RSP0/CPU0:router(config-GRP-isis)# interface 'GigabitEthernet.*'
RP/0/RSP0/CPU0:router(config-GRP-isis-if)# lsp-interval 20
RP/0/RSP0/CPU0:router(config-GRP-isis-if)# hello-interval 40
RP/0/RSP0/CPU0:router(config-GRP-isis-if)# address-family ipv4 unicast
RP/0/RSP0/CPU0:router(config-GRP-isis-if-af)# metric 10
RP/0/RSP0/CPU0:router(config-GRP-isis-if-af)# end-group
RP/0/RSP0/CPU0:router(config)#
```

To illustrate the use of this configuration group, assume that you want to configure Gigabit Ethernet interfaces with ISIS routing parameters, as shown here:

```
router isis green
interface GigabitEthernet0/0/0/0
  lsp-interval 20
  hello-interval 40
  address-family ipv4 unicast
  metric 10
!
!
interface GigabitEthernet0/0/0/1
  lsp-interval 20
  hello-interval 40
  address-family ipv4 unicast
  metric 10
!
!
interface GigabitEthernet0/0/0/2
  lsp-interval 20
  hello-interval 40
  address-family ipv4 unicast
  metric 10
```

```

!
!
interface GigabitEthernet0/0/0/3
  lsp-interval 20
  hello-interval 40
  address-family ipv4 unicast
  metric 10
!
!
!

```

There are three possible ways to use the configuration group to configure these interfaces. The first is by applying the group within the interface configuration, as shown here:

```

router isis green
  interface GigabitEthernet0/0/0/0
    apply-group g-isis-gige
  !
  !
  interface GigabitEthernet0/0/0/1
    apply-group g-isis-gige
  !
  !
  interface GigabitEthernet0/0/0/2
    apply-group g-isis-gige
  !
  !
  interface GigabitEthernet0/0/0/3
    apply-group g-isis-gige
  !
  !
!

```

The second way to configure these interfaces using the configuration group is to apply the configuration group within the **router isis** configuration, as shown here:

```

router isis green
  apply-group g-isis-gige
  interface GigabitEthernet0/0/0/0
  !
  interface GigabitEthernet0/0/0/1
  !
  interface GigabitEthernet0/0/0/2
  !
  interface GigabitEthernet0/0/0/3
  !
  !
!

```

In this situation, any other Gigabit Ethernet interfaces that you configure in ISIS green configuration inherit the configuration group configurations.

The third way to configure these interfaces using the configuration group is to apply the group at the global level, as shown here:

```

apply-group g-isis-gige
router isis green
  interface GigabitEthernet0/0/0/0
  !
  interface GigabitEthernet0/0/0/1
  !

```



```
interface GigabitEthernet0/0/0/2
!  
interface GigabitEthernet0/0/0/3
!  
!
```

In this example, the configuration of the group is applied to all Gigabit Ethernet interfaces configured for ISIS.

**Related Topics**

[end-group](#), on page 164

[apply-group](#), on page 136

# hostname

To specify or modify the hostname for the router, use the **hostname** command in Global Configuration mode.

**hostname** *name*

---

**Syntax Description**     *name* New hostname for the router.

---



---

**Command Default**     The factory-assigned default hostname is “ios.”

---

**Command Modes**     Global Configuration mode

---

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

---



---

**Usage Guidelines**     The hostname is used in prompts and default configuration filenames.

No blank or space characters are permitted as part of a name. Do not expect case to be preserved. Uppercase and lowercase characters look the same to many Internet software applications. It may seem appropriate to capitalize a name the same way you might do in English, but conventions dictate that computer names appear all lowercase. For more information, see RFC 1178, *Choosing a Name for Your Computer*.

---

Task ID	Task ID	Operations
	root-lr	read, write

---

The following example shows how to change the router hostname:

```
RP/0/RSP0/CPU0:router(config)# hostname router1
```

# load

To populate the target configuration with the contents of a previously saved configuration file, use the **load** command in global configuration or administration configuration mode.

**load** *device:directory-path*

<b>Syntax Description</b>	<i>device: directory-path</i> Storage device and directory path of the configuration file to be loaded into the target configuration.
---------------------------	---------------------------------------------------------------------------------------------------------------------------------------

<b>Command Default</b>	If the full path of the file is not specified, the present working directory is used.
------------------------	---------------------------------------------------------------------------------------

<b>Command Modes</b>	Global configuration Administration configuration
----------------------	------------------------------------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

Use the **load** command to populate the target configuration with the contents of a previously saved configuration. When loading a file, you must specify the device, directory path, and filename of the configuration file.

Use the **commit** command in conjunction with the **load** command. Load a new configuration with the **load** command, and use the **commit** command with the **replace** keyword to have the loaded configuration become the active (running) configuration.

Use the **show configuration failed** (config) command with the optional **load** keyword to display syntax errors that occurred during the last load operation.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	config-services	read, write

The following example shows how to load a target configuration file into the current configuration session. The current configuration session is then populated with the contents of the file.

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# load disk1:myconfig.cfg
RP/0/RSP0/CPU0:router(config)# show config
```

```
Building configuration...
```

```
interface TenGigE 0/3/0/0
  description My 10 GE Interface
  ipv4 address 10.10.11.20 255.0.0.0
!
end
```

**Related Topics**

[show configuration failed \(config\)](#), on page 233

[commit](#), on page 152

# load commit changes

To populate the target configuration with changes from previous configuration commits, use the **load commit changes** command in global configuration or administration configuration mode.

**load commit changes** {*commit-id* | **since** *commit-id* | **last** *number-of-commits*}

Syntax Description		
	<i>commit-id</i>	Specific configuration commit.
	<b>since</b> <i>commit-id</i>	Loads all configuration changes committed into the target buffer since (and including) a specific configuration commit, <i>commit-id</i> .
	<b>last</b> <i>number-of-commits</i>	Loads the configuration changes into the target buffer that have been made during the last number of configuration commits specified with the <i>number-of-commits</i> argument.

**Command Default** None

**Command Modes** Global configuration  
Administration configuration

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **load commit changes** command to populate the target configuration with changes from previous configuration commits. The changes are not applied until you enter the **commit** command.

Use the **show configuration** (config) command to display the target configuration.

Task ID	Task ID	Operations
	config-services	read, write

The following example shows how to populate the target configuration with changes from a previous configuration commit:

```
RP/0/RSP0/CPU0:router(config)# load commit changes since 1000000006

Building configuration...
Loading.
```

```
223 bytes parsed in 1 sec (222)bytes/sec
```

# load configuration failed

To populate the target configuration with the contents of the previous failed configuration commit, use the **load configuration failed** command in global configuration or administration configuration mode.

```
load configuration failed {commit | startup [previous number-of-reloads] [noerror]}
```

Syntax Description	commit	Loads the failed configuration from the last commit.
	startup	Loads the failed configuration from the startup configuration.
	previous <i>number-of-reloads</i>	(Optional) Loads the failed configurations from a previous router reload. Valid <i>number-of-reloads</i> values are 1 to 4.
	noerror	(Optional) Excludes the error reasons when the failed configurations are loaded.

**Command Default** None

**Command Modes** Global configuration  
Administration configuration

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **load configuration failed** command to populate the target configuration with the contents of the previous failed configuration commit.

Task ID	Task ID	Operations
	config-services	read, write

The following example shows how to populate the target configuration with the contents of the previous failed configuration commit:

```
RP/0/RSP0/CPU0:router(config)# load configuration failed startup
Loading.
32 bytes parsed in 1 sec (31)bytes/sec
```

**Related Topics**

[show configuration \(config\)](#), on page 222



# load configuration removed

To populate the target configuration with the contents of the previous removed configuration, use the **load configuration removed** command in global configuration or administration configuration mode.

**load configuration removed** *config-id*

<b>Syntax Description</b>	<i>config-id</i> Identifier of the removed configuration to load.
---------------------------	-------------------------------------------------------------------

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Global configuration Administration configuration
----------------------	------------------------------------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

Use the **load configuration removed** command to populate the target configuration with the contents of the removed configuration during installation operations.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	config-services	read, write

The following example shows how to populate the target configuration with the contents of the removed configuration during installation:

```
RP/0/RSP0/CPU0:router(config)# load configuration removed 20070316021626.cfg
```

## Related Topics

[show configuration persistent](#), on page 246

# load rollback changes

To populate the target configuration with the contents of a previous configuration, use the **load rollback changes** command in global configuration or administration configuration mode.

**load rollback changes** {*commit-id* | **last** *number-of-commits* | **to** *commit-id*}

Syntax Description		
	<i>commit-id</i>	Rolls back the configuration changes for a specific configuration commit.
	<b>last</b> <i>number-of-commits</i>	Rolls back to the configuration that existed before the last number of commits (specified with the <i>number-of-commits</i> argument) were made.
	<b>to</b> <i>commit-id</i>	Rolls back to the running configuration that existed before the configuration specified with the <i>commit-id</i> argument.

**Command Default** None

**Command Modes** Global configuration  
Administration configuration

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **load rollback changes** command to load rollback configuration changes to the target configuration. This command is similar to the **rollback configuration** command. The difference between the commands is that the **load rollback changes** command copies the rollback changes to the target configuration and does not commit the changes until the changes are explicitly committed with the **commit** command.

Use the **show configuration rollback changes** command to display rollback changes.

Task ID	Task ID	Operations
	config-services	read, write

The following example shows how to populate the target configuration with the contents of a previous configuration:

```
RP/0/RSP0/CPU0:router(config)# load rollback changes 100000004

Building configuration...
Loading.
```

```
302 bytes parsed in 1 sec (301)bytes/sec
```

# man

Cisco IOS XR software provides online help for standard command-line interface (CLI) commands using manual (man) pages. To display manual pages, use the **man** command in EXEC mode.

**man** {**command** *command-name* | **feature** [*feature-name*] | **keyword** *keywords*}

## Syntax Description

<b>command</b> <i>command-name</i>	Displays the manual pages for a specific command. The <i>command-name</i> argument must include the complete command name.
<b>feature</b> [ <i>feature-name</i> ]	Displays all commands available in the feature. Use the <b>man</b> command with the <b>feature</b> keyword to list the available feature names.
<b>keyword</b> <i>keywords</i>	Displays a list of command names that match the keywords. Enter one or more keywords to match in a command. When entering multiple keywords, the keywords must be entered in the same sequential order as they are in the command.

## Command Default

None

## Command Modes

EXEC

## Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	No modification.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

You must have the documentation PIE installed before you can use the **man** command. If you attempt to run this command without the documentation PIE installed, an error is displayed as shown in the following example:

```
RP/0/RSP0/CPU0:router# man command show install
Building index table...
Warning. Unable to get directory info for '/pkg/man' :No such file or directory.
Discarding!
```

```
man [5521656]:Building index table failed. No entries found
```

For information about installing optional software PIEs, see the *Upgrading and Managing Cisco IOS XR Software* module in *System Management Configuration Guide for Cisco ASR 9000 Series Routers*.

Use the **man** command to display the manual pages for a specific command on the basis of the command name, a feature, or a keyword. Each man page contains the command name, syntax, command mode, usage, examples, and related commands.

The **man** command queries and displays command information about the router. A query can be based on keywords or a feature. The **feature** *feature-name* keyword and argument display all commands that match the feature. For example, entering **man feature asr9k-base-1** displays all commands that match the asr9k-base-1 feature. The **keyword** *keywords* keyword and argument display all commands that contain the specified keyword. For example, **man keyword ipv4** displays all commands that contain ipv4.

Task ID	Task ID	Operations
	basic-services	read

The following example shows how to display the manual page for the **arp timeout** command:

```
RP/0/RSP0/CPU0:router# man command arp timeout

COMMAND
arp timeout

DESCRIPTION

To specify how long dynamic entries learned on an interface remain in the
Address Resolution Protocol (ARP) cache, use the arp timeout command in
interface configuration mode. To remove the arp timeout command from the
configuration file and restore the system to its default condition with
respect to this command, use the no form of this command.

arp timeout seconds

no arp timeout<seconds>

SYNTAX DESCRIPTION

seconds
Time, in seconds, for which an entry remains in the ARP cache. The
range is from 0 to 4294967. A value of 0 means that entries are never
cleared from the cache. The default is 14400.

DEFAULTS

Entries remain in the ARP cache for 14400 seconds (4 hours).

COMMAND MODES

Interface configuration

COMMAND HISTORY

Release
Modification
```

Release 2.0  
This command was introduced.

#### USAGE GUIDELINES

To use the arp timeout command, you must be a member of a user group associated with the cef task ID.

For detailed information about user groups and task IDs, refer to the Configuring AAA Services on Cisco IOS-XR Software module of the Cisco IOS-XR System Security Configuration Guide.

This command is ignored when issued on interfaces that do not use ARP. Also, ARP entries that correspond to the local interface or that are statically configured by the user never time out.

The show interfaces command displays the ARP timeout value in hours:minutes:seconds, as follows:

```

* * * * * START OF LISTING * * * * *
ARP type: ARPA, ARP Timeout 04:00:00
* * * * * END OF LISTING * * * * *
```

#### EXAMPLES

The following example shows how to set the ARP timeout to 3600 seconds to allow entries to time out more quickly than the default:

```

* * * * * START OF LISTING * * * * *
RP/0/RSP0/CPU0:router# configure

RP/0/RSP0/CPU0:router(config)# interface MgmtEth 0/RP1/CPU0/0

RP/0/RSP0/CPU0:router(config-if)# arp timeout 3600
* * * * * END OF LISTING * * * * *
```

#### RELATED COMMANDS

Command	Description
---------	-------------

clear arp-cache	Deletes all dynamic entries from the ARP cache.
-----------------	-------------------------------------------------

show arp (cache)	Displays the entries in the ARP table.
------------------	----------------------------------------

show interfaces	Displays statistics for all interfaces configured on the networking device.
-----------------	-----------------------------------------------------------------------------

## more

To display the contents of a file, use the **more** command in EXEC or administration EXEC mode.

```
more [{/ascii | /binary | /ebcdic}] filesystem:directory-path location [{node-id | all}]{| begin
regular-expression || exclude regular-expression || include regular-expression}
```

Syntax Description	
<b>/ascii</b>	(Optional) Displays a binary file in ASCII format.
<b>/binary</b>	(Optional) Displays a file in hexadecimal or text format.
<b>/ebcdic</b>	(Optional) Displays a binary file in ebcdic format.
<i>filesystem:directory-path</i>	File system location of the file to be displayed. Include the file system alias for the <i>filesystem</i> argument, followed by a colon, and the directory path of the file to be displayed.
<b>location</b> [ <i>node-id</i>   <b>all</b> ]	(Optional) Displays the contents of a file on a designated node or all nodes.
<i>regular-expression</i>	(Optional) Regular expression found in the file.
	Vertical bar (the “pipe” symbol) indicates that an output processing specification follows.
<b>begin</b>	(Optional) Begins unfiltered output of the <b>more</b> command with the first line that contains the regular expression.
<b>exclude</b>	(Optional) Displays output lines that do not contain the regular expression.
<b>include</b>	(Optional) Displays output lines that contain the regular expression.

**Command Default** None

**Command Modes** EXEC

Administration EXEC

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **more** command to display any text file, especially an ASCII file stored on the router or accessible through the network. The file can be a configuration file or any other text file.

### Filtering Output

This table shows filter options for the output displayed by the **more** command.

**Table 17: Filtering Options**

Command	Purpose
<b>more</b> <i>filesystem:</i>   <b>begin</b> <i>regular-expression</i>	Begins unfiltered output of the <b>more</b> command with the first line that contains the regular expression.
<b>more</b> <i>filesystem:</i>   <b>exclude</b> <i>regular-expression</i>	Displays output lines that do not contain the regular expression.
<b>more</b> <i>filesystem:</i>   <b>include</b> <i>regular-expression</i>	Displays output lines that contain the regular expression.

### Adding a Filter at the --More-- Prompt

You can also specify a filter at the --More-- prompt of a **more** command output. To filter output from the --More-- prompt, enter a forward slash ( / ) followed by a regular expression. The filter remains active until the command output finishes or is interrupted (using **Ctrl-Z** or **Ctrl-C**).

- A second filter cannot be specified at a --More-- prompt if a filter has already been specified at the original command or at a previous --More-- prompt.
- The minus sign ( - ) preceding a regular expression displays output lines that do not contain the regular expression.
- The plus sign ( + ) preceding a regular expression displays output lines that contain the regular expression.



**Note** After you specify a filter for a **more** command, you cannot specify another filter at the next --More-- prompt. The first specified filter remains until the **more begin** command output finishes or until you interrupt the output. The use of the keyword does not constitute a filter.

### Task ID

#### Task ID Operations

filesystem execute

The following example shows partial sample output from the **more** command. The output displays a configuration file saved on the hard disk drive.

```
router# more haddisk:/user/alternate.cfg
!! Last configuration change at 15:52:55 UTC Fri Feb 13 2009 by UNKNOWN
!
line console
exec-timeout 0 0
!
interface MgmtEth0/RP1/CPU0/0
ipv4 address 10.32.45.154 255.0.0.0
```



```

!
interface TenGigE0/1/0/0
  ipv4 address 10.32.45.155 255.0.0.0
  keepalive disable
!
interface TenGigE0/1/0/1
  ipv4 address 10.32.45.156 255.0.0.0
  keepalive disable
!
interface TenGigE0/1/0/2
/ip
  ipv4 address 10.32.45.157 255.0.0.0
  keepalive disable
!
interface TenGigE0/1/0/3
  ipv4 address 10.32.45.158 255.0.0.0
  keepalive disable
!
interface TenGigE0/2/0/0
  ipv4 address 10.32.45.159 255.0.0.0
  keepalive disable
!
--More--

```

The following example shows partial sample output from the **more** command. The output begins with unfiltered output from the first line that contains the regular expression “ipv4.” In this example, a new search is specified that begins with output lines that contain the regular expression “ipv4.”

```

RP/0/RSP0/CPU0:router# more disk0:config.backup | begin ipv4

ipv4 address 2.2.2.2 255.255.255.255
!
interface TenGigE0/3/1/0
  shutdown
!
interface TenGigE0/3/1/2
  shutdown
!
interface TenGigE0/2/1/0
  ipv4 address 1.1.1.1 255.255.255.0
  keepalive disable
!
interface TenGigE0/2/1/1
  ipv4 address 1.1.1.1 255.255.255.0
  keepalive disable
!
interface TenGigE0/2/1/2
  ipv4 address 1.1.1.1 255.255.255.0
  keepalive disable
!
interface TenGigE0/2/1/3
  shutdown
!
  /ipv4

filtering...
  ipv4 address 1.1.1.1 255.255.255.0
  proxy-arp disable
  shutdown
!
interface TenGigE 0/1/0/0
  ipv4 address 1.1.1.1 255.255.255.0

```

```

proxy-arp disable
!
route ipv4 0.0.0.0/0 12.25.26.5
route ipv4 223.255.254.254/32 12.25.0.1
end

```

The following example shows partial sample output of the **more** command on the sample file `config.backup` in `disk0:`. The command usage is `more disk0:config.backup | include log`. At the `--More--` prompt, a new search is specified that begins with output lines that contain the regular expression `“aaa.”`

```

RP/0/RSP0/CPU0:router# more disk0:config.backup | include log

logging trap
logging trap informational
logging console debugging
logging history size 1
.
.
.

/aaa

filtering...
aaa authentication login default none

```

The following example shows partial sample output from the **more** command. The output excludes lines that contain the regular expression `“alias.”` In this example, at the `--More--` prompt, a new search is specified, beginning with output lines that contain the regular expression `“ipv4 address.”`

```

RP/0/RSP0/CPU0:router# more disk0:myconfig/file | exclude alias

Building configuration...
!! Last configuration change at 18:17:00 UTC Thu May 16 2009 by lab
!
hostname router
line console
  exec-timeout 0 0
  width 132
  length 0
  session-timeout 0
/ipv4 address

filtering...
ipv4 address 10.10.1.1 255.255.255.255
!
interface Loopback200
  ipv4 address 10.20.1.1 255.255.255.255
!
interface TenGigE0/0/0/0
  ipv4 address 10.30.1.1 255.255.0.0
  keepalive 100
!
interface preconfigure TenGigE0/1/0/1
  shutdown
end

```

**Related Topics**

[show](#), on page 217

## pwd (config)

To display the current configuration submode from a configuration submode, use the **pwd** command in any supported configuration submode.

### pwd

**Syntax Description** This command has no keywords or arguments.

**Command Default** None

**Command Modes** Any subconfiguration mode

### Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	No modification.

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The following example shows how to use the **pwd** command from an interface configuration submode:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# interface tengige 0/6/4/5
RP/0/RSP0/CPU0:router(config-if)# pwd

interface TenGigE0/6/4/5
RP/0/RSP0/CPU0:router(config-if)#
```

# rollback configuration

To roll back the running configuration to a previous configuration, use the **rollback configuration** command in EXEC or administration EXEC mode.

**rollback configuration** {*last number-of-commits* | *to commit-id*} [**force**] [**label** *label*] **comment** *comment*

Syntax Description		
<b>last</b> <i>number-of-commits</i>		Rolls back to the configuration that existed before the last number of commits (specified with the <i>number-of-commits</i> argument) were made.
<b>to</b> <i>commit-id</i>		Rolls back to the running configuration that existed before the configuration specified with the <i>commit-id</i> argument.
<b>force</b>		(Optional) Specifies to override any commit blocks.
<b>label</b> <i>label</i>		(Optional) Assigns a text label to this rollback. The <i>label</i> argument must begin with a letter.
<b>comment</b> <i>comment</i>		(Optional) Assigns a text comment to this rollback. The <i>comment</i> argument can be up to 60 characters long.

**Command Default** None

**Command Modes** EXEC

Administration EXEC

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Each time the **commit** command is entered, a commit ID is assigned to the new configuration. You can revert the system to the configuration of a previous commit ID with the **rollback configuration** command:

- Use the **to** keyword to revert to the configuration that existed *before* the configuration specified with the *commit-id* argument.
- Use the **last** keyword to revert to the configuration that existed *before* the last number of configuration commits (specified with the *number-of-commits* argument) were made.
- Use **show configuration commit list** to display a list of the commit IDs available for rollback operations.



**Note** The most recent 100 commits are retained by the system. As new commit IDs are added, the oldest commit IDs are discarded and are no longer available for rollback operations.

Use the **force** keyword to override commits that would fail otherwise. This is useful in the event of a low-memory condition on the router, to revert to a commit that would remove a configuration that caused the low-memory condition.



**Note** The rollback operation may fail if you try to rollback two (or more) commits where the individual commits involve the configuration and removing of the configuration of the same item, and there is a dependency of one item over another in any of the individual commit operations.

Task ID	Task ID	Operations
	root-lr (EXEC)	read, write
	root-system (administration EXEC)	read, write

### Rolling Back to a Specific Commit ID

The following example shows how to roll back to a specific commit ID. In this example, the **show configuration commit list** command displays the available rollback points. The configuration is then rolled back to a prior commit with the **rollback configuration** command.

```
RP/0/RSP0/CPU0:router# show configuration commit list

SNo. Label/ID      User      Line      Client      Time Stamp
~~~~ ~~~~~~      ~~~~      ~~~~      ~~~~~~      ~~~~~~
1 1000000009 lab con0_RSPs0_C Rollback 02:41:08 UTC Sun Sep 26 2009
2 1000000008 lab con0_RSPs0_C CLI 02:40:30 UTC Sun Sep 26 2009
3 1000000007 lab con0_RSPs0_C CLI 02:39:54 UTC Sun Sep 26 2009
4 1000000006 lab con0_RSPs0_C Rollback 02:38:40 UTC Sun Sep 26 2009
5 1000000005 lab con0_RSPs0_C CLI 02:37:35 UTC Sun Sep 26 2009
6 1000000004 lab con0_RSPs0_C CLI 02:37:04 UTC Sun Sep 26 2009

RP/0/RSP0/CPU0:router# rollback configuration to 1000000008

Loading Rollback Changes.
Loaded Rollback Changes in 1 sec
Committing.
1 items committed in 1 sec (0)items/sec
Updating.RP/0/RP0/CPU0:Sep 26 02:42:09.318 : config_rollback[65707]: %LIBTARCFG-
6-COMMIT : Configuration committed by user 'lab'. Use 'show commit changes 100
000010' to view the changes.
```

```
Updated Commit database in 1 sec
Configuration successfully rolled back to '1000000008'.
```

### Rolling Back to a Span of Configuration Commits

The following example shows how to roll back to the configuration that existed prior to the last two configuration commits:

```
RP/0/RSP0/CPU0:router# rollback configuration last 2
```

```
Loading Rollback Changes.
Loaded Rollback Changes in 1 sec
Committing.
1 items committed in 1 sec (0)items/sec
Updating.
Updated Commit database in 1 sec
Configuration successfully rolled back 2 commits.
```

### Related Topics

[load rollback changes](#), on page 182

[show configuration rollback changes](#), on page 250

# root

To return to configuration mode from a configuration submode, use the **root** command in any supported configuration submode.

## root

### Syntax Description

This command has no keywords or arguments.

### Command Default

None

### Command Modes

Any subconfiguration mode except the following:

- The **root** command is not available under the route-policy submodes, because it requires the **end-policy** command to exit out of the configuration.
- The **root** command is not available in template submode, but is available in the submodes configurable under the template submode.

### Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	No modification.

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

### Task ID

Task ID	Operations
config-services	read

The following example shows how to use the **root** command to return to configuration mode from the interface configuration submode:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# interface tengige 0/1/0/0
RP/0/RSP0/CPU0:router(config-if)# root
RP/0/RSP0/CPU0:router(config)#
```

The following example shows how to use the **root** command from a submode configurable under the template submode. In this example, the **root** command is used to return to configuration mode from the username submode:



### Note

The recommended range for a user-defined username is 2-253 characters.



```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# template test
RP/0/RSP0/CPU0:router(config-TPL)# username xyz
RP/0/RSP0/CPU0:router(config-un)# root
RP/0/RSP0/CPU0:router(config)# show conf
```

```
Building configuration...
template test
username xyz
!
end-template
end
```



---

**Tip** The **root** command is not available from the template submode, but is available in the submodes configurable under the template submode.

---

# save configuration

To save the contents of a configuration to a file, use the **save configuration** command in global configuration or administration configuration mode.

**save configuration** [**running**] *device:directory-path*

<b>Syntax Description</b>	<b>running</b> (Optional) Saves the contents of the running configuration.
	<i>device: directory-path</i> Storage device and directory path of the configuration file to be loaded into the target configuration.

**Command Default** None

**Command Modes** Global configuration  
Administration configuration

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

To save a configuration to a file, use the **save configuration** command.

To save a configuration that failed to a file, use the **save configuration failed** command.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	config-services	read

The following example shows the configuration saved to disk0: from global configuration mode:

```
RP/0/RSP0/CPU0:router(config)# save configuration disk0:sample3
Destination file name (control-c to abort): [/sample3]?
Building configuration.
1 lines built in 1 second
[OK]
```

The following example shows the configuration saved to disk1 from administration EXEC mode:

```
RP/0/RSP0/CPU0:router(admin-config)# save configuration disk1:sample4
Destination file name (control-c to abort): [/sample4]?
```

```
Building configuration.
1 lines built in 1 second
[OK]
```

**Related Topics**

- [save configuration commit changes](#), on page 202
- [save configuration failed](#), on page 204
- [save configuration merge](#), on page 206
- [save rollback changes](#), on page 209
- [save configuration removed](#), on page 207
- [show configuration commit changes](#), on page 226
- [show configuration commit list](#), on page 230
- [show configuration rollback changes](#), on page 250

# save configuration changes

To save the changes of a configuration to a file, use the **save configuration changes** command in global configuration or administration configuration mode.

**save configuration changes** *device:directory-path*

## Syntax Description

*device: directory-path* Storage device and directory path of the configuration file to be loaded into the target configuration.

## Command Default

None

## Command Modes

Global configuration

Administration configuration

## Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	No modification.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

To save the configuration changes to be made during a replace operation to a file, use the **save configuration changes** command.

## Task ID

Task ID	Operations
config-services	read

The following example shows the configuration saved to disk0: from global configuration mode:

```
RP/0/RSP0/CPU0:router(config)# save configuration changes disk0:sample3

Destination file name (control-c to abort): [/sample3]?
Building configuration.
1 lines built in 1 second
[OK]
```

## Related Topics

[save configuration commit changes](#), on page 202

[save configuration failed](#), on page 204

[save configuration merge](#), on page 206

[save rollback changes](#), on page 209

[save configuration removed](#), on page 207

[show configuration commit changes](#), on page 226

[show configuration commit list](#), on page 230

[show configuration rollback changes](#), on page 250

# save configuration commit changes

To save the changes for a commit, or a series of commits, to a file, use the **save configuration commit changes** command in global configuration or administration configuration mode.

**save configuration commit changes** {*commit-id* | **last** *number-of-commits* | **since** *commit-id*}  
*device:directory-path*

Syntax Description		
	<i>commit-id</i>	Specific commit ID.
	<b>last</b> <i>number-of-commits</i>	Saves changes made in the most recent <i>number-of-commits</i> .
	<b>since</b> <i>commit-id</i>	Saves changes made since (and including) a specific <i>commit-id</i> .
	<i>device: directory-path</i>	Storage device and directory path of the configuration file to be loaded into the target configuration.

**Command Default** None

**Command Modes** Global configuration  
Administration configuration

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **save configuration commit changes** command to save the changes made in a commit operation to a file. You can specify a specific commit ID, all the changes since a specified commit ID, or the changes that occurred during the last *n* commits.

Task ID	Task ID	Operations
	config-services	read

The following example saves the changes from the last two commit operations to disk0:

```
RP/0/RSP0/CPU0:router(admin-config)# save configuration commit changes last 2 disk0:sample1
```

```
Destination file name (control-c to abort): [/sample1]?
Building configuration.
5 lines built in 1 second
```

[OK]

### Related Topics

- [save configuration](#), on page 198
- [save configuration changes](#), on page 200
- [save configuration failed](#), on page 204
- [save configuration merge](#), on page 206
- [save rollback changes](#), on page 209
- [show configuration history](#), on page 240
- [save configuration removed](#), on page 207
- [show configuration commit changes](#), on page 226
- [show configuration commit list](#), on page 230
- [show configuration rollback changes](#), on page 250

# save configuration failed

To save the contents of the failed configuration, use the **save configuration failed** command in global configuration or administration configuration mode.

**save configuration failed** [{load | noerrors | startup [previous number] [noerror]}]  
*device:directory-path*

## Syntax Description

<b>load</b>	(Optional) Saves the failed configuration (syntax errors) in the last reload.
<b>noerrors</b>	(Optional) Excludes the error reasons from the saved configuration.
<b>startup</b>	(Optional) Saves the failed configuration during startup.
<b>previous number</b>	(Optional) Saves a failed startup configuration from the specified previous sessions. The <i>number</i> argument is a value between 1 and 4 that indicates how many failed startup configurations to save.
<i>device: directory-path</i>	Storage device and directory path of the configuration file to be saved.

## Command Default

None

## Command Modes

Global configuration  
 Administration configuration

## Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	No modification.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

To save a configuration to a file, use the **save configuration** command.

To save a configuration that failed to a file, use the **save configuration failed** command.

To save a configuration that failed during startup to a file, use the **save configuration failed** command with the **startup** keyword.

## Task ID

Task ID	Operations
config-services	read

The following example saves the failed configuration to disk0:



```
RP/0/RSP0/CPU0:router(admin-config)# save configuration failed disk1:/configs
```

### Related Topics

- [save rollback changes](#), on page 209
- [show configuration history](#), on page 240
- [save configuration removed](#), on page 207
- [show configuration commit changes](#), on page 226
- [show configuration commit list](#), on page 230
- [show configuration rollback changes](#), on page 250

# save configuration merge

To save the contents of a merged configuration to a file, use the **save configuration merge** command in global configuration or administration configuration mode.

**save configuration merge** *device:directory-path*

<b>Syntax Description</b>	<i>device : directory-path</i> Storage device and directory path of the configuration file to be loaded into the target configuration.
---------------------------	----------------------------------------------------------------------------------------------------------------------------------------

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Global configuration Administration configuration
----------------------	------------------------------------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	config-services	read

The following example shows the configuration saved to disk0:

```
RP/0/RSP0/CPU0:router(admin-config)# save configuration merge disk0:sample3
Destination file name (control-c to abort): [/sample3]?
Building configuration.
1 lines built in 1 second
[OK]
```

## Related Topics

- [save rollback changes](#), on page 209
- [show configuration history](#), on page 240
- [save configuration removed](#), on page 207
- [show configuration commit changes](#), on page 226
- [show configuration commit list](#), on page 230
- [show configuration rollback changes](#), on page 250

# save configuration removed

To save the contents of a removed configuration to a file, use the **save configuration removed** command in global configuration or administration configuration mode.

**save configuration removed** *removed-configuration-file* *device:directory-path*

Syntax Description	
<i>removed-configuration-file</i>	Specifies the name of the removed configuration file.
<i>device:directory-path</i>	Storage device and directory path of the configuration file to be loaded into the target configuration.

**Command Default** None

**Command Modes** Global configuration  
Administration configuration

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

When a package is deactivated, the configuration belonging to that package is removed from the running configuration and saved to a file. To save a copy of the removed configuration file, use the **save configuration removed** command.

Task ID	Task ID	Operations
	config-services	read

To view a list of the available removed configuration files, use the **save configuration removed** command followed by a question mark:

```
RP/0/RSP0/CPU0:router(config)# save configuration removed ?
20051208042507.cfg Removed configuration.
20051208044553.cfg Removed configuration.
<cr>
```

In the following example, a removed configuration is saved to disk0: and assigned the filename "sample3:"

```
RP/0/RSP0/CPU0:router(config)# save configuration removed 20051208042507.cfg disk0:sample3
```

```
Destination file name (control-c to abort): [/sample3]?
Building configuration.
1 lines built in 1 second
[OK]
```

### Related Topics

- [save configuration](#), on page 198
- [save configuration commit changes](#), on page 202
- [save configuration failed](#), on page 204
- [save configuration merge](#), on page 206
- [save rollback changes](#), on page 209
- [show configuration history](#), on page 240
- [show configuration commit changes](#), on page 226
- [show configuration commit list](#), on page 230
- [show configuration rollback changes](#), on page 250

# save rollback changes

To save the rollback changes, use the **save rollback changes** command in global configuration or administration configuration mode.

**save rollback changes** {*commit-id* | **last** *number-of-commits* | **to** *commit-id*} *device:directory-path*

Syntax Description		
	<i>commit-id</i>	Specific commit ID.
	<b>last</b> <i>number-of-commits</i>	Saves the rollback changes for the last <i>n</i> commits
	<b>to</b> <i>commit-id</i>	Saves rollback changes up to a specific <i>commit-id</i> .
	<i>device: directory-path</i>	Storage device and directory path of the configuration file to be loaded into the target configuration.

**Command Default** None

**Command Modes** Global configuration  
Administration configuration

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **save rollback changes** command to save the changes that would be made in a configuration rollback to a specific commit point or for a series of commits.

Task ID	Task ID	Operations
	config-services	read

The following example shows that the rollback changes for the commit point 5 are saved to the file sample4 on disk0:

```
RP/0/RSP0/CPU0:router(admin-config)# save rollback changes last 1 disk0:sample4
Destination file name (control-c to abort): [/sample4]?
Building configuration.
6 lines built in 1 second
[OK]
```

**Related Topics**

[save configuration](#), on page 198

[save configuration commit changes](#), on page 202

[show configuration history](#), on page 240

[show configuration commit list](#), on page 230

[show configuration rollback changes](#), on page 250

# set default-afi

To set the default address family identifier (AFI) for the current session, use the **set default-afi** command in EXEC mode.

```
set default-afi {all | ipv4 | ipv6}
```

## Syntax Description

**all** Sets the default AFI to IPv4 and IPv6 for the current session.

**ipv4** Sets the default AFI to IPv4 for the current session. This is the default setting.

**ipv6** Sets the default AFI to IPv6 for the current session.

## Command Default

The default AFI setting is set to IPv4 for all sessions.

## Command Modes

EXEC

## Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	No modification.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **set default-afi** command to set the default AFI for the current session. This command acts as a keystroke shortcut for **show** commands. If the default AFI setting is set to IPv4, then you would not have to specify the **ipv4** keyword for **show** commands that support the **ipv4** keyword. For example, if the AFI setting is set to IPv4, you could issue the **show route** command without specifying the **ipv4** keyword to display IPv4 routes in the Routing Information Base (RIB).

Use the **show default-afi-safi-vrf** command to display the default AFI setting.

## Task ID

Task ID	Operations
basic-services	read, write

The following example shows how to set the default AFI to IPv6:

```
RP/0/RSP0/CPU0:router# set default-afi ipv6
%% Default Address Family Identifier is set to 'ipv6'
```

## Related Topics

[set default-safi](#), on page 213

[set default-vrf](#), on page 215

[show default-afi-safi-vrf](#), on page 259



## set default-safi

To set the default subaddress family identifier (SAFI) for the current session, use the **set default-safi** command in EXEC mode.

```
set default-safi {all | multicast | unicast}
```

Syntax Description	all	Sets the default SAFI to multicast and unicast for the current session.
	<b>multicast</b>	Sets the default SAFI to multicast for the current session.
	<b>unicast</b>	Sets the default SAFI to unicast for the current session. This is the default setting.

**Command Default** The default SAFI setting is set to unicast for all sessions.

**Command Modes** EXEC

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **set default-safi** command to set the default SAFI setting for the current session. This command acts as a keystroke shortcut for **show** commands. If the default SAFI setting is set to unicast, you would not have to specify the **unicast** keyword for **show** commands that support that keyword. For example, if the default SAFI setting is set to unicast, you could issue the **show router** command without specifying the **unicast** keyword to display information about unicast address prefixes in the Routing Information Base (RIB).

Use the **show default-afi-safi-vrf** command to display the default SAFI setting.

Task ID	Task ID	Operations
	basic-services	read, write

The following example shows how to set the default SAFI to multicast:

```
RP/0/RSP0/CPU0:router# set default-safi multicast
%% Default Sub-Address Family Identifier is set to 'multicast'
```

### Related Topics

[set default-afi](#), on page 211

[set default-vrf](#), on page 215

[show default-afi-safi-vrf](#), on page 259

# set default-vrf

To set the default VPN routing and forwarding (VRF) instance for the current session, use the **set default-vrf** command in EXEC mode.

```
set default-vrf {name | none}
```

## Syntax Description

*name* Default VPN routing and forwarding name.

**none** Sets the default VPN routing and forwarding name to empty.

## Command Default

The default VRF setting is set to empty.

## Command Modes

EXEC

## Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	No modification.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **set default-vrf** command to set the default VRF setting for the current session. This command acts as a keystroke shortcut for **show** commands. For example, if the default VRF is configured, you can issue the **show route** command without specifying the VRF name.

When the default VRF for the session is set to **none**, then IPv4 routes for the system default VRF are displayed.



### Note

To override the default VRF setting, specify the VRF name in the **show** command.

Use the **show default-afi-safi-vrf** command to display the default VRF setting.

## Task ID

Task ID	Operations
basic-services	read, write

In the following example, the default VRF is set to “dft_vrf:”

```
RP/0/RSP0/CPU0:router# set default-vrf dft_vrf
%% Default Virtual Routing/Forwarding is set to 'dft_vrf'
```

In the following command, the **show route** command is entered without specifying a VRF name. The results for the "dft_vrf" VRF are displayed because the default VRF was set to "dft_vrf."

```
RP/0/RSP0/CPU0:router# show route ipv4

% No matching vrf found
```

When the default VRF for the session is set to **none**, the system default VRF routes are displayed. In the following example, the default VRF is set to (empty) and the **show route** command displays the system default VRF information:

```
RP/0/RSP0/CPU0:router# set default-vrf none

%% Default Virtual Routing/Forwarding is set to ''

RP/0/RSP0/CPU0:router# show route ipv4

Codes: C - connected, S - static, R - RIP, M - mobile, B - BGP
 D - EIGRP, EX - EIGRP external, O - OSPF, IA - OSPF inter area
 N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2
 E1 - OSPF external type 1, E2 - OSPF external type 2, E - EGP
 i - ISIS, L1 - IS-IS level-1, L2 - IS-IS level-2
 ia - IS-IS inter area, su - IS-IS summary null, * - candidate default
 U - per-user static route, o - ODR, L - local

Gateway of last resort is 12.29.0.1 to network 0.0.0.0

S* 0.0.0.0/0 [1/0] via 12.29.0.1, 00:31:30
L 10.10.10.10/32 is directly connected, 3d02h, Loopback1
C 12.29.0.0/16 is directly connected, 00:31:30, MgmtEth0/0/CPU0/0
L 12.29.56.21/32 is directly connected, 00:31:30, MgmtEth0/0/CPU0/0
```

### Related Topics

- [set default-afi](#), on page 211
- [set default-safi](#), on page 213
- [show default-afi-safi-vrf](#), on page 259

# show

To display information about the system configuration or operational state, use the **show** command in EXEC mode, administration EXEC mode, or any configuration mode.

```
show command [{ | begin regular-expression | | exclude regular-expression | | file filesystem: | | include regular-expression}]
```

## Syntax Description

<i>command</i>	Supported <b>show</b> command.
	Vertical bar (the “pipe” symbol) indicates that an output processing specification follows.
<i>regular-expression</i>	(Optional) Regular expression found in <b>show</b> command output.
<b>begin</b>	(Optional) Begins unfiltered output of the <b>show</b> command with the first line that contains the regular expression.
<b>exclude</b>	(Optional) Displays output lines that do not contain the regular expression.
<b>file</b> <i>filesystem:</i>	(Optional) Writes the output lines that contain the regular expression to the specified file on the specified file system. Include the file system alias for the <i>filesystem</i> argument, followed by a colon, and the directory path and filename.
<b>include</b>	(Optional) Displays output lines that contain the regular expression.

## Command Default

None

## Command Modes

EXEC

Administration EXEC

Any configuration

## Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	No modification.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **show** commands display information about the system and its configuration. To display a list of the available **show** commands, use the question mark (?) online help function.

## Filtering Output

Search options for the **show** command are shown in this table.

**Table 18: Show Command Search Options**

Command	Purpose
<b>show command</b>   <b>begin</b> <i>regular-expression</i>	Begins unfiltered output of the <b>show</b> command command with the first line that contains the regular expression.
<b>show command</b>   <b>exclude</b> <i>regular-expression</i>	Displays output lines that do not contain the regular expression.
<b>show command</b>   <b>include</b> <i>regular-expression</i>	Displays output lines that contain the regular expression.
<b>show command</b>   <b>file</b> <i>filesystem:</i>	Writes the output lines that contain the regular expression to the specified file on the specified file system.

### Adding a Filter at the --More-- Prompt

You can also specify a filter at the --More-- prompt of a **show** command output. To filter output from the --More-- prompt, enter a forward slash (/) followed by a regular expression. The filter remains active until the command output finishes or is interrupted (using **Ctrl-Z** or **Ctrl-C**).

- If a filter is specified at the original command or a previous --More-- prompt, a second filter cannot be applied.
- The use of the **begin** keyword does not constitute a filter.
- The minus sign (-) preceding a regular expression displays output lines that do not contain the regular expression.
- The plus sign (+) preceding a regular expression displays output lines that contain the regular expression.

## Task ID

Task ID	Operations
Task ID for the feature used with the <b>show</b> command	read

For example, the **show interfaces** command requires read privileges in the interface task ID.

The following example shows output from the **show interface | include protocol** command. In this example, the **show** command includes only lines in which the regular expression “protocol” appears:

```
RP/0/RSP0/CPU0:router# show interface | include protocol

Null0 is up, line protocol is up
0 drops for unrecognized upper-level protocol
TenGigE0/2/0/0 is administratively down, line protocol is administratively down
0 drops for unrecognized upper-level protocol
TenGigE0/2/0/1 is administratively down, line protocol is administratively down
0 drops for unrecognized upper-level protocol
TenGigE0/2/0/2 is administratively down, line protocol is administratively down
0 drops for unrecognized upper-level protocol
TenGigE0/2/0/3 is administratively down, line protocol is administratively down
0 drops for unrecognized upper-level protocol
FastEthernet0/RP0/CPU0/0 is administratively down, line protocol is administratively
```

```
down
FastEthernet0/RP0/CPU0/0 is administratively down, line protocol is administratively
down
0 drops for unrecognized upper-level protocol
```

On most systems, the **Ctrl-Z** key combination can be entered at any time to interrupt the output and return to EXEC mode. For example, use the **show running-config | begin hostname** command to start the display of the running configuration file at the line containing the hostname setting, then use **Ctrl-Z** when you get to the end of the information you are interested in.

The following example shows sample output from the **show configuration running | begin line** command. The output begins with unfiltered output from the first line that contains the regular expression “line.” In this example, at the --More-- prompt, a new search is specified that begins with output lines that contain the regular expression “ipv4.”



---

**Note** The use of the **begin** keyword does not constitute a filter.

---

```
RP/0/RSP0/CPU0:router# show configuration running | begin line

Building configuration...
line console
 exec-timeout 120 120
!
logging trap
--More--
/ipv4

filtering...
route ipv4 0.0.0.0 255.255.0.0 pos0/2/0/0
interface TenGigE0/2/0/0
 ipv4 address 172.19.73.215 255.255.0.0
end
```

### Related Topics

[more](#), on page 187

# show aliases

To display all defined aliases or the aliases defined in a specified mode, use the **show aliases** command in EXEC mode.

**show aliases**

**Syntax Description** This command has no keywords or arguments.

**Command Default** Displays all aliases currently configured on the system.

**Command Modes** EXEC

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **show aliases** command to display all aliases currently configured on the system.

Task ID	Task ID	Operations
	basic-services	read

The following example illustrates sample output from the **show aliases** command. The output displays a summary of all the command aliases configured.

```
RP/0/RSP0/CPU0:router# show aliases

exec mode aliases:
ipv4_brief show ipv4 interface brief

interface mode aliases:
sample_int tengige 0/2/0/0
```

## Related Topics

[alias](#), on page 133



# show apply-group

To display the applied configuration groups, use the **show apply-group** command in EXEC mode.

## show apply group

**Syntax Description** This command has no keywords or arguments.

**Command Default** None

**Command Modes** EXEC

Command History	Release	Modification
	Release 5.1.1	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The output of this show command indicates if the group is a part of the global apply-group or is a part of the sub-mode level apply-group.

Task ID	Task ID	Operation
	config-services	read

## Example

This example shows how to use the **show apply-group** command:

```
RP/0/RSP0/CPU0:router # show apply-group
 Global Non-Global
Groups Reference Count Reference Count

B 1 0
C 1 0
```

Reference count can either be 0 or 1. 0 indicates that the group is not applied globally; 1 indicates that the group is globally applied.

## show configuration (config)

To display information about the current configuration session (target configuration), use the **show configuration** command in any configuration mode.

**show configuration** [**merge**] [**running**]

<b>Syntax Description</b>	<b>merge</b> (Optional) Displays the configuration that occurs if the contents of the uncommitted changed (target configuration) are committed to the running configuration.						
	<b>running</b> (Optional) Displays the running (committed) configuration.						
<b>Command Default</b>	When the <b>show configuration</b> command is entered without an argument, the uncommitted changes to the target configuration are displayed.						
<b>Command Modes</b>	Any configuration						
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 3.7.2</td> <td>This command was introduced.</td> </tr> <tr> <td>Release 3.9.0</td> <td>No modification.</td> </tr> </tbody> </table>	Release	Modification	Release 3.7.2	This command was introduced.	Release 3.9.0	No modification.
Release	Modification						
Release 3.7.2	This command was introduced.						
Release 3.9.0	No modification.						

**Usage Guidelines**

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **show configuration** command to display details on uncommitted configuration changes.

Use the **show configuration** command with the **running** keyword to display the running (active) configuration.

Prior to committing the target configuration, use the **show configuration** command with the **merge** keyword from any configuration mode to display the result of merging the target configuration with the running configuration.

Task ID	Task ID	Operations
	basic-services	read

In this example, the **show configuration** command displays uncommitted changes made during a configuration session:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# interface tengige0/3/0/3
RP/0/RSP0/CPU0:router(config-if)# description faq
RP/0/RSP0/CPU0:router(config-if)# ipv4 address 10.10.11.20 255.0.0.0
RP/0/RSP0/CPU0:router(config-if)# show configuration

Building configuration...
interface TenGigE0/3/0/3
 description faq
```

```
ipv4 address 10.10.11.20 255.0.0.0
end
```

The following example shows sample output from the **show configuration** command with the optional **merge** keyword. The command is entered during a configuration session. The output displays the result of merging the target and running configuration, without committing the changes.

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# interface tengige0/3/0/3
RP/0/RSP0/CPU0:router(config-if)# description faq
RP/0/RSP0/CPU0:router(config-if)# ipv4 address 10.10.11.20 255.0.0.0
RP/0/RSP0/CPU0:router(config-if)# show configuration merge

Building configuration...
hostname router
interface TenGigE0/0/0/0
 ipv4 address 1.2.3.4 255.0.0.0
 exit
interface TenGigE0/3/0/3
 description faq
 ipv4 address 1.1.1.1 255.0.0.0
 shutdown
end
```

### Related Topics

- [show configuration failed \(config\)](#), on page 233
- [show configuration history](#), on page 240
- [show configuration sessions](#), on page 257
- [show running-config](#), on page 262
- [commit](#), on page 152
- [load](#), on page 175
- [show configuration commit changes](#), on page 226
- [show configuration commit list](#), on page 230
- [show configuration failed startup](#), on page 239
- [show configuration rollback changes](#), on page 250
- [show configuration running-config](#), on page 254

# show configuration changes

To display the configuration changes to be made during a replace operation, use the **show configuration changes** command in global configuration or administration configuration Admin Configuration mode .

**show configuration changes [diff]**

<b>Syntax Description</b>	<b>diff</b> (Optional) Displays the changes in UNIX-like format.
---------------------------	------------------------------------------------------------------

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Global Configuration mode Admin Configuration mode
----------------------	-------------------------------------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	config-services	read
	basic-services	read

The following example shows the changes to be made during a replace operation:

```
RP/0/RSP0/CPU0:router(config)# show configuration changes diff

Building configuration...
hostname router
hostname bla
- logging console
- telnet vrf default ipv4 server disable
- domain ipv4 host xhu-u5
- domain ipv4 host coax-u10
- domain ipv4 host coax-u10.cisco.com
- domain name
- interface Loopback1
- ipv4 address 10.0.0.2 255.255.255.224
- !
- interface Loopback2
- description
- !
- interface Loopback5
- description
```

```
- !
- interface Loopback6
- description
- !
- interface MgmtEth0/0/CPU0/0
- ipv4 address 10.0.0.1 255.255.255.224
- !
- interface GigabitEthernet0/2/0/0
- shutdown
- !
- interface GigabitEthernet0/2/0/1
- shutdown
- !
- interface GigabitEthernet0/2/0/2
- shutdown
- !
- router static
- address-family ipv4 unicast
- 0.0.0.0/0 255.255.255.224
- !
- !
end
```

## show configuration commit changes

To display the changes made to the running configuration by previous configuration commits, a configuration commit, or for a range of configuration commits, use the **show configuration commit changes** command in EXEC, administration EXEC, administration configuration, or global configuration mode.

```
show configuration commit changes {commit-id | since commit-id | last number-of-commits | all }
[diff]
```

Syntax Description		
	<b>since</b>	Displays all changes committed to the running configuration since (and including) a specific configuration commit.
	<i>commit-id</i>	Displays configuration changes for a specific configuration commit.
	<b>last</b> <i>number-of-commits</i>	Displays the changes made to the running configuration during the last number of configuration commits specified for the <i>number-of-commits</i> argument.
	<b>all</b>	Displays commit ID and configurations completed for last 100 commits.
	<b>diff</b>	(Optional) Displays added lines, changed lines, and deleted lines.

**Command Default** None

**Command Modes** EXEC  
Administration EXEC  
Administration configuration  
Global configuration

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 5.3.2	Support was added for the <b>all</b> keyword.
	Release 3.9.0	No modification.

**Usage Guidelines**

Each time a configuration is committed with the **commit** command, the configuration commit operation is assigned a commit ID. The **show configuration commit changes** command displays the configuration changes made since the specified commit.

To display a list of the available commit IDs, enter the **show configuration commit list** command. You can also display the commit IDs by entering the **show configuration commit changes** command with the online help function (?).

Task ID	Task ID	Operations
	config-services	read

The following example shows sample output from the **show configuration commit changes** command. The output displays commit IDs.

```
RP/0/RSP0/CPU0:router# show configuration commit list

SNo. Label/ID User Line Client Time Stamp
~~~~ ~~~~~~      ~~~~~
1     1000000077     lab      con0_RSPs1_C  CLI      15:42:45 UTC Fri Jan 30 2009
2     1000000076     lab      con0_RSPs1_C  Rollback 15:30:39 UTC Fri Jan 30 2009
3     1000000075     lab      con0_RSPs1_C  Rollback 15:25:26 UTC Fri Jan 30 2009
4     1000000074     lab      con0_RSPs1_C  Rollback 15:04:29 UTC Fri Jan 30 2009
5     1000000073     lab      con0_RSPs1_C  CLI      14:49:07 UTC Fri Jan 30 2009
6     1000000072     lab      con0_RSPs1_C  CLI      14:48:35 UTC Fri Jan 30 2009
```

The following example shows sample output from the **show configuration commit changes** command with the *commit-id* argument. In this example, the output displays the changes made in the configuration commit assigned commit ID 1000000077.

```
RP/0/RSP0/CPU0:router# show configuration commit changes 1000000077

Building configuration...
alias exec shrun show configuration running
alias exec shver show version
end
```

The following example shows sample output from the **show configuration commit changes** command with the **since** *commit-id* keyword and argument. In this example, the output displays the configuration changes made since the configuration commit assigned commit ID 1000000077 was committed.

```
RP/0/RSP0/CPU0:router# show configuration commit changes since 1000000077

Building configuration...
no hw-module node 0/RP0/CPU0 shutdown
hostname router
logging trap
no logging console
logging history size 1
alias exec shrun show configuration running
alias exec shver show version
interface MgmtEth0/RP1/CPU0/0
  ipv4 address 12.25.34.10 255.255.0.0
  no shutdown
```

## show configuration commit changes

```

!
interface preconfigure MgmtEth0/RP0/CPU0/0
no shutdown
!
no route ipv4 0.0.0.0/0 12.7.0.1
route ipv4 0.0.0.0/0 12.25.0.1
route ipv4 223.255.254.254/32 12.25.0.1
telnet ipv4 server enable
end

```

The following example shows sample output from the **show configuration commit changes** command with the **diff** keyword. In the display, the following symbols signify changes:

+ indicates an added line.

– indicates a deleted line.

# indicates a modified line.

```
RP/0/RSP0/CPU0:router# show configuration commit changes last 1 diff
```

```

Building configuration...
+ interface Loopback1000
+ ipv4 address 190.190.180.1 255.255.255.255
!
end

+ interface Loopback1000
+ ipv4 address 190.190.180.1 255.255.255.255
!
end

```

The following example shows sample output from the **show configuration commit changes** command with the **all** keyword. In this example, the output displays the list of configurations that are committed in last 100 commits along with their commit-ID.

```
RP/0/RSP0/CPU0:router# show configuration commit changes all
```

```
Commit ID : 1000000001
```

```

-----
Building configuration...
!! IOS XR Configuration 0.0.0
interface GigabitEthernet0/0/0/1
speed 100
!
end

```

```
Commit ID : 1000000002
```

```

-----
Building configuration...
!! IOS XR Configuration 0.0.0
interface GigabitEthernet0/0/0/1
no speed 100
!
end

```

```
Commit ID : 1000000003
```

```

-----
Building configuration...
!! IOS XR Configuration 0.0.0
interface GigabitEthernet0/0/0/0
!

```



```
shutdown  
end
```

**Related Topics**

[rollback configuration](#), on page 193

[show configuration rollback changes](#), on page 250

# show configuration commit list

To display information about the configuration commits stored in the commit database, use the **show configuration commit list** command in EXEC, administration EXEC, administration configuration, or global configuration mode.

**show configuration commit list** [*number-of-commits*] [**detail**]

## Syntax Description

*number-of-commits* (Optional) Number of commits (beginning with the most recent commit) that are available for rollback.

**detail** (Optional) Displays detailed commit information, including comments.

## Command Default

If this command is entered without any optional arguments or keywords, the output displays information about all the configuration commits stored in the commit database.

## Command Modes

EXEC

Administration EXEC

Administration configuration

Global configuration

## Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	No modification.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **show configuration commit list** command to list the commit IDs (up to 100) that are available for rollback.



### Note

The most recent 100 commits are retained by the system. As new commit IDs are added, the oldest commit IDs are discarded and are no longer available for rollback operations.

## Task ID

Task ID	Operations
config-services	read

The following example shows sample output from the **show configuration commit list** command. The output displays the commit IDs that are available for rollback.

```
RP/0/RSP0/CPU0:router# show configuration commit list
```

```

SNo. Label/ID      User      Line      Client      Time Stamp
~~~~ ~~~~~~      ~~~~~      ~~~~~      ~~~~~      ~~~~~~
1 1000000010 UNKNOWN con0_RSP0_C Rollback 02:25:53 UTC Fri Feb 06 2009
2 1000000009 UNKNOWN con0_RSP0_C CLI 02:23:09 UTC Fri Feb 06 2009
3 1000000008 UNKNOWN con0_RSP0_C CLI 02:22:54 UTC Fri Feb 06 2009
4 1000000007 UNKNOWN con0_RSP0_C CLI 02:22:18 UTC Fri Feb 06 2009
5 1000000006 UNKNOWN con0_RSP0_C CLI 02:07:21 UTC Fri Feb 06 2009

```

Table 19: [show configuration commit list Field Descriptions](#), on page 231 describes the significant fields shown in the display.

**Table 19: show configuration commit list Field Descriptions**

Field	Description
SNo.	Serial number of the commit entry.
Label/ID	If a label was assigned to a commit, the first 10 characters of the label display; otherwise, the autogenerated commit ID displays.
User	User who executed the commit.
Line	Line in which the user session was established. In some cases, this field may display "UNKNOWN" or "SYSTEM". These fields indicate that an internal commit was made by the system.
Client	The management interface used to make the commit.
Time Stamp	Time and date when the commit was executed.

### Related Topics

- [show configuration \(config\)](#), on page 222
- [show configuration failed \(config\)](#), on page 233
- [show configuration history](#), on page 240
- [show configuration running](#), on page 252
- [show configuration sessions](#), on page 257
- [show running-config](#), on page 262
- [show configuration commit changes](#), on page 226
- [show configuration failed startup](#), on page 239
- [show configuration rollback changes](#), on page 250
- [show configuration running-config](#), on page 254

# show configuration failed

To display information about a configuration that failed during the last commit, use the **show configuration failed** command in EXEC mode.

**show configuration failed** [**inheritance**]

<b>Syntax Description</b>	<b>inheritance</b> Displays the failed configuration details at the inheritance level.
---------------------------	----------------------------------------------------------------------------------------

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	EXEC
----------------------	------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 5.1.1	This command was introduced.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

Without the inheritance keyword, this command displays the failed configuration information in brief.

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	config-services	read

## Example

This example shows how to run the **show configuration failed** command:



<b>Note</b>	When there are two (or more) groups that have failed, the ordering of the failed groups is displayed in the same order as the apply-group statement.
-------------	------------------------------------------------------------------------------------------------------------------------------------------------------

```
RP/0/RSP0/CPU0:router (config) # show config failed
!! SEMANTIC ERRORS: This configuration was rejected by
!! the system due to semantic errors. The individual
!! errors with each failed configuration command can be
!! found below.
apply-group GROUP-1 GROUP-2 GROUP-3 GROUP-4 GROUP-5
!% Please issue "show configuration failed inheritance" for details.
Applying following groups failed: GROUP-2 GROUP-4 GROUP-5
```

## show configuration failed (config)

To display information about a configuration that failed during the last commit, use the **show configuration failed** command in any configuration mode.

```
show configuration failed [{load | noerrors}]
```

<b>Syntax Description</b>	<b>load</b> (Optional) Displays any syntax errors found in a configuration loaded with the <b>load</b> command.						
	<b>noerrors</b> (Optional) Displays the configuration that failed in last commit without the error reasons.						
<b>Command Default</b>	Displays the details of the failed configuration including error reasons.						
<b>Command Modes</b>	Any configuration						
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 3.7.2</td> <td>This command was introduced.</td> </tr> <tr> <td>Release 3.9.0</td> <td>No modification.</td> </tr> </tbody> </table>	Release	Modification	Release 3.7.2	This command was introduced.	Release 3.9.0	No modification.
Release	Modification						
Release 3.7.2	This command was introduced.						
Release 3.9.0	No modification.						
<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.						
<b>Task ID</b>	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operations</th> </tr> </thead> <tbody> <tr> <td>basic-services</td> <td>read</td> </tr> </tbody> </table>	Task ID	Operations	basic-services	read		
Task ID	Operations						
basic-services	read						

The following example shows a failed commit operation:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# taskgroup bgp
RP/0/RSP0/CPU0:router(config-tg)# description this is an example of an invalid task group
RP/0/RSP0/CPU0:router(config-tg)# commit
% Failed to commit one or more configuration items.
Please use 'show configuration failed' to view the errors
```

The following example shows sample output from the **show configuration failed** command. The output displays the configuration items that failed during the last commit operation.

```
RP/0/RSP0/CPU0:router(config-tg)# show configuration failed

!! CONFIGURATION FAILED DUE TO SEMANTIC ERRORS
taskgroup bgp
!!% Usergroup/Taskgroup names cannot be taskid names
!
```

The following example shows sample output from the **show configuration failed** command with the optional **no errors** keyword. The output displays the configuration items that failed during the last commit operation without an error description.

```
RP/0/RSP0/CPU0:router(config-tg)# show configuration failed noerrors

!! CONFIGURATION FAILED DUE TO SEMANTIC ERRORS
taskgroup bgp
!
```

### Related Topics

- [show configuration \(config\)](#), on page 222
- [show configuration history](#), on page 240
- [show configuration running](#), on page 252
- [show configuration sessions](#), on page 257
- [show running-config](#), on page 262
- [show configuration commit changes](#), on page 226
- [show configuration commit list](#), on page 230
- [show configuration failed startup](#), on page 239
- [show configuration rollback changes](#), on page 250
- [show configuration running-config](#), on page 254

# show configuration failed incompatible

To display any configurations that were removed from the running configuration because they were not understood by the software being activated, use the **show configuration failed incompatible** command in EXEC or administration EXEC mode.

**show configuration failed incompatible**

**Syntax Description** This command has no keywords or arguments.

**Command Default** None

**Command Modes** EXEC  
Administration EXEC

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Any configurations in the running configuration that are not understood by new software being installed are removed from the running configuration. To see which configurations were removed, use the **show configuration failed incompatible** command.

Task ID	Task ID	Operations
	config-services	read

## Related Topics

[show running-config](#), on page 262

# show configuration failed remove

To display information about a configuration that failed while being removed during installation operations, use the **show configuration failed remove** command in EXEC or administration EXEC mode.

**show configuration failed remove**

**Syntax Description** This command has no keywords or arguments.

**Command Default** None

**Command Modes** EXEC  
Administration EXEC

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	config-services	read

The following example shows a failed commit operation:

```
RP/0/RSP0/CPU0:router# show configuration failed remove

!! SEMANTIC ERRORS: This configuration was rejected by
!! the system due to semantic errors. The individual
!! errors with each failed configuration command can be
!! found below.

multicast-routing
 no address-family ipv4
 !!% Process did not respond to sysmgr
 address-family ipv4
 no interface all enable
 !!% Process did not respond to sysmgr
 !
 !
```

Because the configuration failed to be removed, it is still displayed in the output from the **show running-configuration** command as expected:

```
RP/0/RSP0/CPU0:router# show running-configuration
```



```
...
router pim vrf default address-family ipv4
 auto-rp candidate-rp GigabitEthernet0/2/0/3 scope 255 group-list 224/4 interval 10
!
multicast-routing
 address-family ipv4
 interface all enable
!
!
```

### Related Topics

- [show configuration \(config\)](#), on page 222
- [show configuration failed \(config\)](#), on page 233
- [show configuration history](#), on page 240
- [show configuration running](#), on page 252
- [show configuration sessions](#), on page 257
- [show running-config](#), on page 262
- [show configuration commit changes](#), on page 226
- [show configuration commit list](#), on page 230
- [show configuration rollback changes](#), on page 250
- [show configuration running-config](#), on page 254

# show configuration failed rollback

To display information about a configuration that failed in the last rollback operation, use the **show configuration failed rollback** command in EXEC or administration EXEC mode.

**show configuration failed rollback**

**Syntax Description** This command has no keywords or arguments.

**Command Default** None

**Command Modes** EXEC  
Administration EXEC

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	config-services	read
	root-lr	read

## Related Topics

- [show configuration \(config\)](#), on page 222
- [show configuration failed \(config\)](#), on page 233
- [show configuration running](#), on page 252
- [show configuration sessions](#), on page 257
- [show running-config](#), on page 262
- [show configuration commit changes](#), on page 226
- [show configuration commit list](#), on page 230
- [show configuration failed startup](#), on page 239
- [show configuration rollback changes](#), on page 250
- [show configuration running-config](#), on page 254

# show configuration failed startup

To display information about a configuration that failed at startup, use the **show configuration failed** command in EXEC or administration EXEC mode.

**show configuration failed startup** [{noerror | previous *number*}]

<b>Syntax Description</b>	<b>noerror</b> (Optional) Displays the configuration that failed at startup without an error reason.						
	<b>previous <i>number</i></b> (Optional) Displays the previous failed startup configuration or configurations. The <i>number</i> argument is a value from 1 to 4, which displays the failed startup configurations in previous of sessions.						
<b>Command Default</b>	If no keywords are specified, this command displays the details of the failed startup configuration including error reasons.						
<b>Command Modes</b>	EXEC Administration EXEC						
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 3.7.2</td> <td>This command was introduced.</td> </tr> <tr> <td>Release 3.9.0</td> <td>No modification.</td> </tr> </tbody> </table>	Release	Modification	Release 3.7.2	This command was introduced.	Release 3.9.0	No modification.
Release	Modification						
Release 3.7.2	This command was introduced.						
Release 3.9.0	No modification.						
<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.						
<b>Task ID</b>	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operations</th> </tr> </thead> <tbody> <tr> <td>config-services</td> <td>read</td> </tr> </tbody> </table>	Task ID	Operations	config-services	read		
Task ID	Operations						
config-services	read						

## Related Topics

- [show configuration \(config\)](#), on page 222
- [show configuration failed \(config\)](#), on page 233
- [show configuration history](#), on page 240
- [show configuration running](#), on page 252
- [show configuration sessions](#), on page 257
- [show running-config](#), on page 262
- [show configuration commit changes](#), on page 226
- [show configuration commit list](#), on page 230
- [show configuration rollback changes](#), on page 250
- [show configuration running-config](#), on page 254

# show configuration history

To display a history of configuration events, use the **show configuration history** command in EXEC, administration EXEC, administration configuration, or global configuration mode.

```
show configuration history [{alarm | backup | cfs-check | commit | rebase | shutdown | startup}]
[{first number | last number | reverse}] [detail]
```

## Syntax Description

<b>alarm</b>	(Optional) Displays alarm events.
<b>backup</b>	(Optional) Displays configuration backup events.
<b>cfs-check</b>	(Optional) Displays CFS check events.
<b>commit</b>	(Optional) Displays commit events.
<b>rebase</b>	(Optional) Displays commit database consolidation events.
<b>shutdown</b>	(Optional) Displays shutdown events.
<b>startup</b>	(Optional) Displays startup events, including alternate configurations, failed configurations, and other events.
<b>first number</b>	(Optional) Displays the first x number of events, where x is the <i>number</i> argument.
<b>last number</b>	(Optional) Displays the last x <i>number</i> events. Replace with the number of events to display.
<b>reverse</b>	(Optional) Displays the most recent events first.
<b>detail</b>	(Optional) Displays detailed information, including comments.

## Command Default

When entered without any optional arguments or keywords, this command displays all configuration events. The oldest events are displayed at the top of the list for each event type.

## Command Modes

EXEC  
Administration EXEC  
Administration configuration  
Global Configuration

## Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	No modification.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **show configuration history** command to display information about the last (up to) 1500 configuration events.

Use one of the available keywords to display the configuration event only for that event type. Use the **first number** and **last number** keywords and arguments to display a specified number of events. Use the **reverse** keyword to display the newest events at the top of the list.

Task ID	Task ID	Operations
	config-services	read

In the following example, the **show configuration history** command is used to display the history of all configuration events for an SDR:

```
RP/0/RSP0/CPU0:router# show configuration history

Sno. Event Info Time Stamp
~~~~  ~~~~~      ~~~~                               ~~~~~
1      alarm      inconsistency alarm raised        Thu Jun 22 15:23:15 2009
2      startup    configuration applied             Thu Jun 22 15:23:32 2009
3      OIR config restore                Thu Jun 22 15:23:25 2009
4      OIR config restore                Thu Jun 22 15:23:33 2009
5      OIR config restore                Thu Jun 22 15:23:33 2009
6      OIR config restore                Thu Jun 22 15:23:34 2009
7      OIR config restore                Thu Jun 22 15:23:34 2009
8      OIR config restore                Thu Jun 22 15:23:35 2009
9      OIR config restore                Thu Jun 22 15:23:36 2009
10     OIR config restore                Thu Jun 22 15:23:37 2009
11     OIR config restore                Thu Jun 22 15:23:37 2009
12     OIR config restore                Thu Jun 22 15:23:38 2009
13     OIR config restore                Thu Jun 22 15:23:38 2009
14     OIR config restore                Thu Jun 22 15:23:39 2009
15     OIR config restore                Thu Jun 22 15:23:39 2009
16     OIR config restore                Thu Jun 22 15:23:40 2009
17     OIR config restore                Thu Jun 22 15:23:40 2009
18     OIR config restore                Thu Jun 22 15:23:42 2009
19     OIR config restore                Thu Jun 22 15:23:42 2009
20     OIR config restore                Thu Jun 22 15:23:42 2009
21     OIR config restore                Thu Jun 22 15:23:43 2009
--More--
```

In the following example, the **show configuration history** command is used to display only the startup configuration events:

```
RP/0/RSP0/CPU0:router# show configuration history startup

Sno.  Event      Info                               Time Stamp
~~~~  ~~~~~      ~~~~                               ~~~~~
1 startup configuration applied Thu Jun 22 15:23:32 2009
2 startup configuration applied Sat Jul 1 15:02:24 2009
3 startup configuration applied Sat Jul 8 17:36:52 2009
4 startup configuration applied Sun Jul 9 13:40:27 2009
5 startup configuration applied Sat Jul 15 18:18:54 2009
```

In the following example, the **show configuration history** command with the **commit detail** keywords is used to display additional details regarding the commit events:

```

RP/0/RSP0/CPU0:router# show configuration history commit detail

1) Event: commit Time: Thu Jun 22 15:44:33 2009
 Commit ID: 1000000001 Label:
 User: lab Line: vty0
 Client: CLI Comment:

2) Event: commit Time: Thu Jun 22 16:58:18 2009
 Commit ID: 1000000002 Label:
 User: lab Line: vty2
 Client: CLI Comment:

3) Event: commit Time: Thu Jun 22 16:58:39 2009
 Commit ID: 1000000003 Label:
 User: lab Line: vty2
 Client: CLI Comment:

4) Event: commit Time: Sat Jul 1 15:29:31 2009
 Commit ID: 1000000001 Label:
 User: lab Line: vty0
 Client: CLI Comment:

5) Event: commit Time: Sat Jul 1 15:32:25 2009
 Commit ID: 1000000002 Label:
 User: lab Line: vty0
--More--

```

**Table 20: show configuration history Field Descriptions**

Field	Description
SNo.	Serial number of the entry.
Event	Type of configuration event.
Info	Summary of the configuration action.
Time Stamp	Time and date when the event was run.
Label/ID	If a label was assigned to a commit, the first 10 characters display; otherwise, the autogenerated commit ID displays.
User	User who issued the command.
Line	Line in which the user session was established. In some cases, this field may display “UNKNOWN” or “SYSTEM”. These fields indicate that an internal action was made by the system.
Client	The management interface used to make the event.

### Related Topics

- [show configuration \(config\)](#), on page 222
- [show configuration failed \(config\)](#), on page 233
- [show configuration history](#), on page 240
- [show configuration running](#), on page 252

[show configuration sessions](#), on page 257

[show running-config](#), on page 262

[show configuration commit changes](#), on page 226

[show configuration commit list](#), on page 230

[show configuration rollback changes](#), on page 250

[show configuration running-config](#), on page 254

# show configuration inconsistency replica

To display any configuration inconsistencies on a replica node, use the **show configuration inconsistency replica** command in EXEC or administration EXEC mode.

**show configuration inconsistency replica location *node-id* [detail]**

<b>Syntax Description</b>	<b>location <i>node-id</i></b> Displays any configuration inconsistencies on the designated node. The <i>node-id</i> argument is expressed in the <i>rack/slot/module</i> notation.
	<b>detail</b> Displays a detailed list of inconsistencies.

**Command Default** Administration EXEC mode: Displays configuration inconsistencies for the admin plane configuration.  
EXEC mode: Displays configuration inconsistencies for an SDR configuration.

**Command Modes** EXEC  
Administration EXEC

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

In administration EXEC or EXEC mode, the replica node for the **show configuration inconsistency replica** command is the standby designated system controller (DSC).

Use the **show configuration inconsistency replica** command, before performing a manual switchover or DSC migration, to verify that the node in line to take over for the DSC is in good shape. If any problems are reported, use the **clear configuration inconsistency replica** command to correct them.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	config-services	read

The following example shows a configuration with inconsistencies:

```
RP/0/RSP0/CPU0:router# show configuration inconsistency replica location 0/rsp1/cpu0

The replica at location 0/RSP1/CPU0 is inconsistent.
Please run 'clear configuration inconsistency replica location 0/RP1/CPU0'.
```

The following example shows sample output after the inconsistencies have been resolved:



```
RP/0/RSP0/CPU0:Router# show configuration inconsistency replica location 0/rspl/cpu0
```

```
Replica is consistent
```

**Related Topics**

[clear configuration inconsistency replica](#), on page 148

# show configuration persistent

To display the persistent configuration, use the **show configuration persistent** command in EXEC mode.

**show configuration persistent [diff]**

## Syntax Description

**diff** (Optional) Displays the difference between the running configuration and persistent configuration. This option is available only on the DSC.

## Command Default

If no argument is specified, the **show configuration persistent** command displays the entire contents of the persistent configuration file.

## Command Modes

EXEC

## Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	No modification.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The persistent configuration is the configuration stored in nonvolatile memory, from which the running configuration is restored after the router is reloaded. The running configuration should be the same as the persistent configuration. Use the **show configuration persistent** command with the **diff** keyword to check if there is a difference between the running configuration and the persistent configuration.

## Task ID

Task ID	Operations
config-services	read

The following example shows that there is no difference between the running configuration and the persistent configuration:

```
RP/0/RSP0/CPU0:router# show configuration persistent diff
Building configuration...
end
```

The following example shows a difference between the running configuration and the persistent configuration:

```
RP/0/RSP0/CPU0:router# show configuration persistent diff
Building configuration...
router vrrp
```

```
interface tengige0/1/0/1.1
vrrp 1 preempt delay 300
!
interface tengiget0/1/0/1.2
vrrp 1 preempt delay 300
!
interface tengige0/1/0/1.3
vrrp 1 preempt delay 300
```

**Related Topics**

[show running-config](#), on page 262

# show configuration removed

To display a configuration removed during installation operations, use the **show configuration removed** command in EXEC or administration EXEC mode.

**show configuration removed** *config-id*

<b>Syntax Description</b>	<i>config-id</i> Name of removed configuration. Type (?) to see a list of the names of all removed configurations.	
<b>Command Default</b>	None	
<b>Command Modes</b>	EXEC Administration EXEC	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.
<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.	
<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	config-services	read

The following example shows a removed configuration:

```
RP/0/RSP0/CPU0:router# show configuration removed 20060301112919.cfg

xml agent corba
http server
end
```

## Related Topics

- [show configuration \(config\)](#), on page 222
- [show configuration failed \(config\)](#), on page 233
- [show configuration history](#), on page 240
- [show configuration running](#), on page 252
- [show configuration sessions](#), on page 257
- [show running-config](#), on page 262
- [commit](#), on page 152
- [load](#), on page 175

[show configuration commit changes](#), on page 226

[show configuration commit list](#), on page 230

[show configuration failed startup](#), on page 239

[show configuration rollback changes](#), on page 250

## show configuration rollback changes

To display changes that would be made by the **rollback configuration** command or to display the list of commit IDs, use the **show configuration rollback changes** command in EXEC, administration EXEC, administration configuration, or global configuration mode.

**show configuration rollback changes** {*commit-id* | **to** *commit-id* | **last** *number-of-commits*} [**diff**]

Syntax Description		
	<i>commit-id</i>	Name of configuration. When a specific <i>commit-id</i> is specified, only the changes that would occur if only the specified commit is rolled back are displayed.
	<b>to</b> <i>commit-id</i>	Displays the changes that will occur to the running configuration if the system is rolled back to the configuration specified with the <i>commit-id</i> argument.
	<b>last</b> <i>number-of-commits</i>	Displays the changes that will occur to the running configuration if the system is rolled back to the last number of commits specified with the <i>number-of-commits</i> argument.
	<b>diff</b>	(Optional) Displays added lines, changed lines, and deleted lines.

**Command Default** None

**Command Modes** EXEC  
Administration EXEC  
Administration configuration  
Global configuration

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.



**Note** The most recent 100 commits are retained by the system. As new commit IDs are added, the oldest commit IDs are discarded and are no longer available for rollback operations.

Use the *commit-id* argument without the **to** keyword to display the changes for a particular commit. This can be useful for troubleshooting actions of the **rollback configuration** command.

Task ID	Task ID	Operations
	config-services	read

The following example shows sample output from the **show configuration rollback changes** command with the **to *commit-id*** keyword and argument. The output displays the configuration changes that would occur if the configuration were to be rolled back to the configuration commit specified for the argument.

```
RP/0/RSP0/CPU0:router# show configuration rollback changes to 1000000007

Building configuration...
hostname old-name
end
```

The following example shows sample output from the **show configuration rollback changes** command **last *number-of-commits*** keyword and argument. The output displays the configuration changes that would occur if the configuration were to be rolled back to the number of configuration commits specified for the argument.

```
RP/0/RSP0/CPU0:router# show configuration rollback changes last 2

Building configuration...
hostname orig_name
interface POS0/1/0/1
 shutdown
!
end
```

The following example shows sample output from the **show configuration rollback changes** command with the **diff** keyword.

In the display, the following symbols signify changes:

- + indicates an added line.
- – indicates a deleted line.
- # indicates a modified line.

```
RP/0/RSP0/CPU0:router
show configuration rollback changes last 1 diff

Building configuration...
 interface Loopback1000
ipv4 address 1.1.1.1 255.255.255.255
!
end
```

### Related Topics

[load rollback changes](#), on page 182

[rollback configuration](#), on page 193

# show configuration running

To display the running configuration, use the **show configuration running** command in the appropriate mode.

```
show configuration running [config-keyword]
```

<b>Syntax Description</b>	<i>config-keyword</i> (Optional) Specific configuration to display.
---------------------------	---------------------------------------------------------------------

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Administration EXEC Administration configuration Global configuration
----------------------	-----------------------------------------------------------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

Use the **show configuration running** command to display the currently active configuration.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	basic-services	read

This example shows the currently running (committed) configuration from administration mode.

```
RP/0/RSP0/CPU0:router (admin) # show configuration running

Building configuration...
username lab
 secret 5 1XNWt$j8RscNdncKSROMSnqSpbj/
 group root-system
!
end
```

## Related Topics

- [show configuration \(config\)](#), on page 222
- [show configuration failed \(config\)](#), on page 233
- [show configuration history](#), on page 240
- [show configuration sessions](#), on page 257
- [show running-config](#), on page 262



[commit](#), on page 152

[load](#), on page 175

[show configuration commit changes](#), on page 226

[show configuration commit list](#), on page 230

[show configuration failed startup](#), on page 239

[show configuration rollback changes](#), on page 250

[show configuration running-config](#), on page 254

## show configuration running-config

To display the running configuration, use the **show configuration running-config** command in EXEC mode.

**show configuration running-config** [**inheritance** [**no-annotation**]] [*config-keyword*]

Syntax Description		
	<b>inheritance</b>	(Optional) Displays the configuration inherited from any applied configuration group.
	<b>no-annotation</b>	(Optional) Suppresses the display of inheritance messages, when the <b>inheritance</b> keyword is used.
	<i>config-keyword</i>	(Optional) Specific configuration to display.

**Command Default** None

**Command Modes** EXEC

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.
	Release 4.3.1	The <b>inheritance</b> and <b>no-annotation</b> keywords were added to support the display of configuration group configurations.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the *config-keyword* argument to display the running configuration for a specific keyword only.

### Display the Configuration from Configuration Groups

By default, if configuration groups are applied in the configuration, they are displayed as they are configured. For example:

```
RP/0/RSP0/CPU0:router# show configuration running-config
!
group G-INTERFACE-MTU
 interface 'GigabitEthernet.*'
 mtu 1500
end-group
!
interface GigabitEthernet1/0/0/7
 apply-group G-INTERFACE-MTU
!
```

To display the actual configuration as inherited from any applied configuration groups, use the **inheritance** keyword:

```
RP/0/RSP0/CPU0:router# show configuration running-config inheritance
!
interface GigabitEthernet1/0/0/7
 ## Inherited from group G-INTERFACE-MTU
 mtu 1500
!
```

Use the **no-annotation** keyword to suppress the display of the Inheritance messages, "## Inherited from group ...".

Task ID	Task ID	Operations
	basic-services	read

This example shows the currently running (committed) configuration:

```
RP/0/RSP0/CPU0:router# show configuration running-config

Building configuration...

!! Last configuration change at 15:36:31 UTC Thu Nov 17 2009 by lab
sessions Users with active configuration sess
!n
hostname router
line consolestartup Sh
 exec-timeout 0 0configuration
!
logging console debugging
| Ou
snmp-server community public RW
<cr>
RP/0/0/
ipv4 source-routeadmin)#show confi
key chain IPSLA ?
key 10
 key-string password 1
 ipv4 address 10.0.0.0 255.255.255.0
 encapsulation ppp
 keepalive disable
!
interface POS0/7/0/0
 shutdown
!
interface POS0/7/0/1
 shutdown
!
interface POS0/7/0/2
 shutdown
!
interface POS0/7/0/3
 shutdown
!
route ipv4 0.0.0.0/0 12.7.0.1
ipsla
 responder
!
!
end
```

**Related Topics**

- [show configuration \(config\)](#), on page 222
- [show configuration failed \(config\)](#), on page 233
- [show configuration history](#), on page 240
- [show configuration running](#), on page 252
- [show configuration sessions](#), on page 257
- [show running-config](#), on page 262
- [commit](#), on page 152
- [load](#), on page 175
- [show configuration commit changes](#), on page 226
- [show configuration commit list](#), on page 230
- [show configuration failed startup](#), on page 239
- [show configuration rollback changes](#), on page 250

# show configuration sessions

To display the active configuration sessions, use the **show configuration sessions** command in EXEC or administration EXEC mode.

**show configuration sessions [detail]**

<b>Syntax Description</b>	<b>detail</b> (Optional) Displays detailed information.
---------------------------	---------------------------------------------------------

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	EXEC Administration EXEC
----------------------	-----------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **show configuration sessions** command to display the active configuration sessions. Use the **clear configuration sessions** command to clear a configuration session. The **show configuration sessions** command can be used with the **clear configuration sessions** command to verify that an active configuration session was cleared.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	config-services	read

The following example shows sample output from the **show configuration sessions** command:

```
RP/0/RSP0/CPU0:router# show configuration sessions

Current Configuration Session Line User Date Lock
00000050-001200bb-00000000 con0_5_CPU cisco Fri Feb 16 17:23:47 2007
```

**Table 21: show configuration sessions Field Descriptions**

Field	Description
Session	System-generated configuration session ID number.
Line	Line in which the user session was established. In some cases, this field may display “UNKNOWN” or “SYSTEM.” These fields indicate that an internal commit was made by the system.

Field	Description
User	User who initiated the configuration session.
Date	Time and date the configuration session was started.
Lock	Locked running-configuration. An asterisk (*) displayed in this field means the session has been locked. Only one session can lock the running configuration at a time.

**Related Topics**

[clear configuration sessions](#), on page 150

# show default-afi-safi-vrf

To display the default address family identifier (AFI), subaddress family identifier (SAFI), and VPN routing and forwarding (VRF) instance for the current session, use the **show default-afi-safi-vrf** command in EXEC mode.

**show default-afi-safi-vrf**

**Syntax Description** This command has no keywords or arguments.

**Command Default** None

**Command Modes** EXEC

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **show default-afi-safi-vrf** command to display the default AFI and SAFI settings for the current session. The AFI and SAFI settings are controlled by the following commands:

- [set default-afi](#), on page 211
- [set default-safi](#), on page 213
- [set default-vrf](#), on page 215

Task ID	Task ID	Operations
	basic-services	read

The following example shows sample output from the **show default-afi-safi-vrf** command:

```
RP/0/RSP0/CPU0:router# show default-afi-safi-vrf

%% Default AFI/SAFI/VRF for this session is:
 Address Family Identifier: 'ipv4'
 Sub-Address Family Identifier: 'unicast'
 Virtual Routing/Forwarding: ''
```

## Related Topics

- [set default-afi](#), on page 211
- [set default-safi](#), on page 213
- [set default-vrf](#), on page 215

# show history

To display a history of commands executed in EXEC, administration EXEC, administration configuration, or global configuration mode use the **show history** command in one of the supported modes.

**show history [detail]**

<b>Syntax Description</b>	<b>detail</b> (Optional) Displays detailed history information.
---------------------------	-----------------------------------------------------------------

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	EXEC Administration EXEC Administration configuration Global configuration
----------------------	-------------------------------------------------------------------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

The **show history** command displays a history of the command entered for the current command mode. For example, enter the **show history** command to display a history of commands entered in EXEC mode. Enter the **show history** command in global configuration mode to display a history of the commands entered in global configuration mode.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	config-services	read
	basic-services	read

In the following example, the **show history** command is run in EXEC mode to display a history of the command entered in EXEC mode:

```
RP/0/RSP0/CPU0:router# show history
configure
admin
show history
```

In the following example, the **show history** command is run in global configuration mode to display a history of the command entered in global configuration mode:



```
RP/0/RSP0/CPU0:router(config)# show history
interface pos 0/1/0/0
ipv4 address 10.0.0.0
root
end
describe line default autocommand config
line default autocommand configure
end
show history
```

# show running-config

To display the contents of the currently running configuration or a subset of that configuration, use the **show running-config** command in the appropriate mode.

**show running-config** [[**exclude**] *command*] [**sanitized**] [**inheritance** [**no-annotation**]]

Syntax Description		
<b>inheritance</b>	(Optional)	Displays the configuration inherited from any applied configuration group.
<b>no-annotation</b>	(Optional)	Suppresses the display of inheritance messages, when the <b>inheritance</b> keyword is used.
<b>exclude</b>	(Optional)	Excludes a specific configuration from the display.
<i>command</i>	(Optional)	Command for which to display the configuration.
<b>sanitized</b>	(Optional)	Displays a sanitized configuration for safe distribution and analysis.

**Command Default** The **show running-config** command without any arguments or keywords displays the entire contents of the running configuration file.

**Command Modes** EXEC  
Administration EXEC

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.
	Release 4.3.1	The <b>inheritance</b> and <b>no-annotations</b> keywords were added to support the display of configuration group configurations.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

You can display either the entire running configuration, or a subset of the running configuration. The subset may be all the commands within a specified command mode.



**Note** In Cisco IOS XR software, the running configuration is automatically used at system startup, reset, or power cycle. The running configuration is the committed configuration.

### Sanitized Output

Use the **show running-config** command with the **sanitized** keyword to display the contents of the active running configuration without installation-specific parameters. Some configuration details, such as IP addresses, are replaced with different addresses. The sanitized configuration can be used to share a configuration without exposing the configuration details.

### Command Modes

When the **show running-config** command is entered in administration configuration mode, the configuration for the administration plane is displayed, including the configured logical routers for the system. When the **show running-config** command is entered in any global configuration mode, or in EXEC mode, the configuration for the specific secure domain router (SDR) is displayed.

The **inheritance** and **no-annotations** keywords are not supported in administration EXEC or configuration modes.

### Excluding Parts of the Display

Use the **exclude** keyword followed by a *command* argument to exclude a specific configuration from the display.

### Display the Configuration from Configuration Groups

By default, if configuration groups are applied in the configuration, they are displayed as they are configured. For example:

```
RP/0/RSP0/CPU0:router# show running-config

group G-INTERFACE-MTU
 interface 'POS.*'
 mtu 1500
 !
end-group

interface POS0/4/1/0
 apply-group G-INTERFACE-MTU
 !
interface POS0/4/1/1
 apply-group G-INTERFACE-MTU
 mtu 2000
 !
```

To display the actual configuration as inherited from any applied configuration groups, use the **inheritance** keyword:

```
RP/0/RSP0/CPU0:router# show running-config inheritance

group G-INTERFACE-MTU
 interface 'POS.*'
 mtu 1500
 !
end-group

interface POS0/4/1/0
 ## Inherited from group G-INTERFACE-MTU
 mtu 1500
 !
interface POS0/4/1/1
 mtu 2000
 !
```

Use the **no-annotations** keyword to suppress the display of the Inheritance messages, "## Inherited from group ...".

Task ID	Task ID	Operations
	config-services	read

This example shows how to enter the **show running-config** command with the question mark (?) online help function to display the available subsets of the running configuration that can be entered to display a subset of the running configuration:

```
RP/0/RSP0/CPU0:router# show running-config ?

aaa Authentication, Authorization and Accounting
alias Create an alias for entity
aps Configure SONET Automatic Protection Switching (APS)
arp Global ARP configuration subcommands
as-path BGP autonomous system path filter
as-path-set Define an AS-path set
banner Define a login banner
cdp Enable CDP, or configure global CDP subcommands
cef CEF configuration commands
cinetd Global Cisco inetd configuration commands
class-map Configure QoS Class-map command
clock Configure time-of-day clock
community-list Add a community list entry
community-set Define a community set
controller Controller configuration subcommands
dhcp Dynamic Host Configuration Protocol
domain Domain service related commands
exception Coredump configuration commands
exclude Exclude a feature or configuration item from display
explicit-path Explicit-path config commands
extcommunity-set Define an extended community set
fault Fault related commands
forward-protocol Controls forwarding of physical and directed IP broadcasts
ftp Global FTP configuration commands
--More--
```

In this example, the **show running-config** command is used to display the running configuration for Packet-over-SONET/SDH (POS) interface 0/2/0/1:

```
RP/0/RSP0/CPU0:router# show running-config interface pos 0/2/0/1

interface POS0/2/0/1
ip address 10.0.0.0 255.0.0.0
```

This example shows sample output from the **show running-config** command with the **sanitized** keyword displays a sanitized version of the running configuration. The sanitized configuration can be used to share a configuration without exposing specific configuration details.

```
RP/0/RSP0/CPU0:router# show running-config sanitized

Building configuration...
```

```
!! Last configuration change at 05:26:50 UTC Thu Jan 19 2009 by <removed>
!
snmp-server traps fabric plane
snmp-server traps fabric bundle state
hostname <removed>
line console
exec-timeout 0 0
!
exception choice 1 compress off filepath <removed>
logging console debugging
telnet vrf <removed> ipv4 server max-servers no-limit
snmp-server ifindex persist
snmp-server host 10.0.0.1 traps version <removed> priv <removed> udp-port 2555
snmp-server view <removed> <removed> included
snmp-server community <removed> RO LROwner
snmp-server community <removed> RO LROwner
snmp-server group <removed> v3 priv read <removed> write <removed>
snmp-server traps snmp
snmp-server traps syslog
interface Loopback10
!
interface Loopback1000
!
--More--
```

### Related Topics

[show configuration \(config\)](#), on page 222

[show configuration running-config](#), on page 254

# template

To create a template name and enter template configuration mode, use the **template** command in global configuration mode. To remove a template definition, use the **no** form of this command.

**template** *name*  
**no template** *name*

<b>Syntax Description</b>	<i>name</i> Unique name for the template to be created.
---------------------------	---------------------------------------------------------

<b>Command Default</b>	No templates are defined.
------------------------	---------------------------

<b>Command Modes</b>	Global configuration
----------------------	----------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **template** command to enter template configuration mode. From template configuration mode, you can group a subset of configuration commands in a named template. Commonly used sets of configuration commands can be grouped into a named template. Defining a template is similar to creating a C macro function. A template provides modularity and ease of use during user configuration.

Use the **end-template** command to exit template configuration mode. After defining a template, use the **apply-template** command to apply the template. Use the **show running-config** command with the optional **template** keyword and *template-name* argument to display the contents of a template.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	config-services	read, write

The following example shows how to enter template configuration mode to create a template. In this example, a template named “pre-pos” is defined for the preconfigured Packet-over-SONET/SDH (POS) interface 0/1/0/1. The **end-template** command is used to exit from template configuration mode.

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# template pre-pos
RP/0/RSP0/CPU0:router(config-TPL)# interface preconfigure pos0/1/0/0
RP/0/RSP0/CPU0:router(config-if-pre)# ipv4 address 10.3.32.154 255.0.0.0
RP/0/RSP0/CPU0:router(config-if-pre)# end-template
RP/0/RSP0/CPU0:router(config)#
```



---

**Note** After configuring a template, you may want to display the contents of the configured template. To display a template configuration, use the **show running-config** command with the **template name** keyword and argument.

---

The following example shows sample output from the **show running-config** command with the **template name** keyword and argument. In this example, the output displays the contents of a template named “pre-pos.”

```
RP/0/RSP0/CPU0:router# show running-config template pre-pos

template pre-pos
 interface preconfigure POS0/1/0/0
 ipv4 address 10.3.32.154 255.0.0.0
 !
end-template
```

### Related Topics

- [apply-template](#), on page 139
- [end-template](#), on page 165
- [show running-config](#), on page 262

template





## File System Commands

---

This chapter describes the Cisco IOS XR software commands used to manage file systems on your router.



---

**Note**

The commands in this module should not be used to access or modify any Cisco IOS XR software or configuration files. Use only the documented commands for installing and configuring the router. Modifying, deleting, or moving configuration or software package files using the manual commands described in this module is not required and can result in router downtime, loss of service, and a corrupted database.

---

- [cd](#), on page 270
- [cfs check](#), on page 271
- [copy](#), on page 272
- [delete](#), on page 277
- [dir](#), on page 278
- [mkdir](#), on page 280
- [pwd](#), on page 281
- [rmdir](#), on page 282
- [show filesystem](#), on page 283
- [show media](#), on page 285

# cd

To change the current working directory, use **cd** command in EXEC mode.

**cd** *filesystem* :

<b>Syntax Description</b>	<i>filesystem</i> : (Optional) Location of the new working directory. Include the file system alias for the <i>filesystem</i> argument, followed by a colon and optionally, the name of a directory.
---------------------------	------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

<b>Command Default</b>	The default file directory is <b>disk0:/usr</b> .
------------------------	---------------------------------------------------

<b>Command Modes</b>	EXEC mode.
----------------------	------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 6.1.2	This command was introduced.

<b>Usage Guidelines</b>	<p>The current working directory is the directory used when EXEC commands that have an optional argument are entered without that argument. Use <b>cd</b> command to define the working directory. For example, when the <b>dir</b> command is entered without specifying the <i>filesystem</i> argument, the files in the current working directory are displayed.</p>
-------------------------	-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

Use **cd** command without an argument to set the working directory back to the default directory, **disk0:/usr**.

The following example shows how to change the current working directory to the root directory on the hard disk. In this example, the **pwd** command confirms that the working directory has changed to the root directory on the hard disk.

```
RP/0/RSP0/CPU0:router# cd harddisk:
RP/0/RSP0/CPU0:router# pwd

harddisk:
```

The following example shows how to change the current working directory to the default file directory by specifying the **cd** command without a location. In this example, the **pwd** command confirms that the working directory has changed to the default file directory.

```
RP/0/RSP0/CPU0:router# cd
RP/0/RSP0/CPU0:router# pwd

disk0:/usr
```

# cfs check

To perform a check on the Configuration File System (CFS), use **cfs check** command in EXEC or administration EXEC mode.

## cfs check

**Syntax Description** This command has no keywords or arguments.

**Command Default** No default behavior or values.

**Command Modes** EXEC mode  
Admin EXEC mode

Command History	Release	Modification
	Release 6.1.2	This command was introduced.

**Usage Guidelines** Use this command to check the sanity of the configuration file system and attempt to recover from internal inconsistencies; one or more rollback points may be lost depending on the severity of the state of the file system.



**Note** While this command runs, redundancy of the designated shelf controller (DSC) is disabled.

The following example shows how to perform a CFS check:

```
RP/0/RSP0/CPU0:router# cfs check

Creating any missing directories in Configuration File system...OK
Initializing Configuration Version Manager...OK
Syncing commit database with running configuration...OK
Re-initializing cache files...OK
Updating Commit Database. Please wait...[OK]
```

## copy

To copy a file from a source (such as a network server) to a destination (such as a flash disk), use **copy** command in EXEC or Admin EXEC mode.

**copy** *source* {**location** *node-id* *destination* **location** {*node-id* | **all**} | **running-config**[**atomic**]}

### Syntax Description

<i>source</i>	<p>Filename including the directory path or network location of the file. The possible sources are:</p> <p><i>directory-path</i> —Directory path of the file from which the file is copied.</p> <p><b>access-list</b> { <b>ipv4</b>   <b>ipv6</b> }—Copies an access list (EXEC mode only).</p> <p><b>bootflash:</b> —Copies from the bootflash: file system.</p> <p><b>compactflash:</b> —Copies from the compactflash: file system.</p> <p><b>compactflasha:</b> —Copies from the compactflasha: file system partition.</p> <p><b>disk0:</b> —Copies from disk0: file system.</p> <p><b>disk0a:</b> —Copies from disk0a: file system partition.</p> <p><b>disk1:</b> —Copies from disk1: file system.</p> <p><b>disk1a:</b> —Copies from disk1a: file system partition.</p> <p><b>flash:</b> —Copies from the flash: file system. The <b>flash:</b> keyword is an alias for bootflash:.</p> <p><b>ftp:</b> —Copies from an FTP network server. The syntax is <b>ftp:</b>[[[//<i>username</i> [<i>:password</i>]@]<i>location</i>]/<i>directory</i>]/<i>filename</i>.</p> <p><b>harddisk:</b> —Copies from the hard disk drive file system (if present).</p> <p><b>harddiska:</b> —Copies from the hard disk partition a.</p> <p><b>harddiskb:</b> —Copies from the hard disk partition b.</p> <p><b>nvr:</b> —Copies from the NVRAM file system.</p> <p><b>prefix-list</b> { <b>ipv4</b>   <b>ipv6</b> }—Copies from a prefix list (EXEC mode only).</p> <p><b>rcp:</b> —Copies from a remote copy protocol (rcp) network server. The syntax is <b>rcp:</b>[[[//<i>username</i>@]<i>location</i>]/<i>directory</i>]/<i>filename</i>.</p> <p><b>running-config</b> —Copies from the current system configuration.</p> <p><b>tftp:</b> —Copies from a TFTP network server. The syntax is <b>tftp:</b>[[[//<i>location</i>]/<i>directory</i>]/<i>filename</i></p> <p><b>xml-schema</b> —Copies the XML schema files as a tar ball file (.tar.gz) [EXEC mode only].</p>
<i>destination</i>	Filename including the directory path or network location of the file.
<b>location</b> <i>node-id</i>	Specifies a node. The <i>node-id</i> argument is expressed in the <i>rack/slot/module</i> notation.
<b>location</b> <b>all</b>	Copies to all nodes.

---

**running-config** Applies the source configuration file to the running configuration of the system.

---

**atomic** (Optional) Applies the changes to the running configuration only if there are no errors

---



---

#### Command Default

No default behavior or values

---

#### Command Modes

EXEC mode.

Admin EXEC mode.

---

#### Command History

Release	Modification
Release 6.1.2	This command was introduced.

---



---

#### Usage Guidelines

Source and destination can each be a configuration file, a text file, or a file system. Enter source and destination URL information, usernames, and passwords and issue the **copy** command. The networking device prompts for any missing information.

The exact format of the *source* and *destination* arguments vary according to the file or directory location. Enter the device or network location for the file system type.

Filenames can include the following characters:

!#\$%&' + 0 1 2 3 4 5 6 7 8 9 ; @ A B C D E F G H I J K L M N O P Q R S T U V W X Y Z [ ] ^ _ a b c d e f g h i j k l m n o p q r s t u v w x y z { } ~

The following characters can be used with the stated limitations:

- ` needs backslash before this character
- – cannot be the first character
- . cannot be the last character
- = cannot be the filename without other characters

The following characters cannot be used in filenames:

" ( ) * , / : < > ? \ |

The maximum length allowed for a filename is 254 characters including the path. If a filename longer than 254 characters is specified, the filename is truncated to 254 characters.

To copy a file from a source on the router to a destination on the router, specify a source **location** *node-id* and a destination **location** *node-id*. To copy the file to all nodes, use the **location all** keywords.

In the alias syntax for the **ftp:**, **rep:**, and **tftp:** keywords, the location is either an IP address or a hostname. The filename is specified relative to the directory used for file transfers.

When no alias is specified, the networking device looks for a file in the current directory. To view the current directory, enter the **pwd** command.




---

#### Note

During processing of the **copy** command, you might see the “C” character. For all files being copied, “C” indicates that the copy process is taking place. The entire copying process might take several minutes and differs from protocol to protocol and from network to network.

---

Table 22: Network Protocols Supported by Cisco IOS XR Software

Prefix	Name	Description
<b>tftp:</b>	Trivial File Transfer Protocol	<i>TFTP</i> is a simplified version of FTP that allows files to be transferred from one computer to another over a network, usually without the use of client authentication (for example, username and password).
<b>ftp:</b>	File Transfer Protocol	<i>FTP</i> is an application protocol, part of the TCP/IP protocol stack, and is used for transferring files between network nodes. FTP requires a username and password.
<b>rcp:</b>	Remote Copy Protocol	The rcp protocol allows users to copy files to and from a file system residing on a remote host or server on the network. The rcp protocol uses TCP to ensure the reliable delivery of data. The rcp protocol downloads require a username.

Additional usage guidelines are in the following sections.

### Invalid Combinations of Source and Destination

Some combinations of source and destination are invalid. Specifically, you cannot copy the following:

- From a running configuration to a running configuration
- From a network device to a network device (for example, **copy ftp: rcp:** )

### Using TFTP

*TFTP* is a simplified version of FTP that allows files to be transferred from one computer to another over a network, usually without the use of client authentication (for example, username and password).

The syntax is as follows:

```
copy tftp://hostname /ipaddress/directory-path pie name target-device [location {node-id | all}]
```

Example:

```
RP/0/RSP0/CPU0:router# copy tftp://1.1.1.1/images/software.pie disk1:
```



#### Note

Some Cisco IOS XR images may be larger than 32 MB, and the TFTP services provided by some vendors may not support a file this large. If you do not have access to a TFTP server that supports files larger than 32 MB, download the software image using FTP or rcp as described in the following sections.

### Using FTP

FTP servers require a username and password for each client request. Cisco IOS XR software sends the first valid username in the following list:

1. The username and password specified in the **copy** command, if a username is specified.

The syntax is as follows:

**copy ftp://username : password @ hostname or ipaddress/directory-path/pie-name target-device [location {node-id | all}]**

Example:

```
RP/0/RSP0/CPU0:router# copy ftp://john:secret@10.1.1.1/images/software.pie disk1:
```

2. An “anonymous” username and password. The anonymous password is “root@ip address,” where “ip address” is the IP address of the local networking device.
3. A password “username@iosname.domain” formed by the networking device. The variable “username” is the username associated with the current session, “iosname” is the configured hostname, and “domain” is the domain of the networking device.

The username and password must be associated with an account on the FTP server. If you are writing to the network server, the FTP server must be properly configured to accept the FTP write request from the user on the networking device.

If the network server has a directory structure, the configuration file or image is written to or copied from the directory associated with the username on the network server. For example, if the system image resides in the home directory of a user on the network server, specify the name of that user as the remote username.

Refer to the documentation for your FTP server for more details.

### Using rcp

The rcp protocol requires a username upon each request. When you copy a configuration file or image between the networking device and an rcp server, the Cisco IOS XR software sends the first valid username in the following list:

1. The remote username specified in the **copy** command, if one is specified.
2. The username set by the **rcp client username** command, if the command is configured.
3. The networking device hostname.

For the rcp copy request to process successfully, an account must be defined on the network server for the remote username. If the network administrator of the destination server did not establish an account for the remote username, this command does not run successfully. If the network server has a directory structure, the configuration file or image is written to or copied from the directory associated with the remote username on the network server. For example, if the system image resides in the home directory of a user on the network server, specify the name of that user as the remote username.

If you are writing to the network server, the rcp server must be properly configured to accept the rcp write request from the user on the networking device. For UNIX systems, add an entry to the .rhosts file for the remote user on the rcp server. Suppose the networking device contains the following configuration lines:

```
hostname Rtr1
ip rcp remote-username User0
```

If the IP address of the networking device translates to company.com, then the .rhosts file for User0 on the rcp server should contain the following line:

```
company.com Rtr1
```

See the documentation for your rcp server for more details.

If you are using a personal computer as a file server, the computer must support remote shell (rsh) protocol.

### Using xml-schema

Use the **xml-schema** keyword to obtain the most up-to-date XML schemas (.xsd files) from the router. Using this keyword is useful to prevent the use of outdated schemas in the event that router software updates include schema updates. The tar ball file includes all active schema files. It does not include schemas that are activated by specific package installation envelopes (PIEs) if those PIEs are not installed and activated on the router.

### Copying to the Running Configuration

When you use the **copy** command to copy a configuration file to the **running-config** destination, the configuration in the file is applied to the running configuration of the system. This is a configuration operation. By default, the copy is carried out in a best-effort manner. This means that if some configuration lines from the file cannot be applied, the remaining configuration is still integrated into the system. In this case, a partial configuration is committed. When the **atomic** keyword is used, partial configurations are not committed. This means that even if one error occurs in the parsing or committing phase, no changes are made to the system. To view any errors when applying the configuration, use the **show configuration failed** command.

---

#### Task ID

---

#### Task ID    Operations

---

filesystem    execute

---

The following example shows how to copy a file from a FTP server to disk1:

```
RP/0/RSP0/CPU0:router#
copy ftp://john:secret@10.1.1.1/images/comp-asr9k-full.pie disk1:
```

The following example shows how to copy a file from an rcp server to disk1:

```
RP/0/RSP0/CPU0:router#
copy rcp://john@10.1.1.1/images/comp-asr9k-full.pie disk1:
```

The following example shows how to copy a file from a TFTP server to disk1:

```
RP/0/RSP0/CPU0:router#
copy tftp://10.1.1.1/images/comp-asr9k-full.pie disk1:
```



# delete

To delete files, use **delete** command in the appropriate mode.

**delete** [/noprompt] [/ena] *filesystem* : *filename* **location** {*node-id* | **all**}

## Syntax Description

<b>/noprompt</b>	(Optional) Causes no prompt for confirmation before deleting the specified files.
<b>/ena</b>	(Optional) Deletes all files from and below the current working directory.
<i>filesystem</i> :	(Optional) Location of the file to be deleted. Include the file system alias for the <i>filesystem</i> argument, followed by a colon, and, optionally, the name of a directory.
<i>filename</i>	Filename of the file to be deleted.
<b>harddisk</b>	Deletes the harddisk
<b>location</b> { <i>node-id</i>   <b>all</b> }	Deletes a file from a designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation. The <b>all</b> keyword specifies to delete the file from all nodes.

## Command Default

A filename must be specified. If a filename is entered without a file system or directory path, the present working directory is used.

## Command Modes

EXEC mode.  
Admin EXEC mode.

## Command History

Release	Modification
Release 6.1.2	This command was introduced.

## Usage Guidelines

When a file is deleted, it is removed from the system and cannot be restored (undeleted).

Use the **dir** command to display the list of files on a storage device.

The following example shows how to delete a file:

```
RP/0/RSP0/CPU0:router# delete rbtest
```

```
Delete disk1:/rbtest[confirm]y
```

# dir

To display a list of files on a file system or in a specific directory, use the **dir** command in EXEC mode Admin EXEC mode.

**dir** [{/all | /ena | /recurse}] [*filesystem* :] [*filename*] **location** {*node-id* | all}

Syntax Description	
<b>/all</b>	(Optional) Lists deleted files, undeleted files, and files with errors.
<b>/ena</b>	(Optional) Recognizes subdirectories.
<b>/recurse</b>	(Optional) Recursively lists subdirectories.
<i>filesystem</i> :	(Optional) Name of the directory containing the files to be displayed. Include the file system alias for the <i>filesystem</i> argument, followed by a colon, and, optionally, the name of a directory.
<i>filename</i>	(Optional) Name of the files to display. The files can be of any type. You can use wildcards in the filename. A wildcard character (*) matches all patterns. Strings following a wildcard are ignored.
<b>location</b> { <i>node-id</i>   all}	(Optional) Specifies the node from which to display a list of files. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation. The <b>all</b> keyword specifies to display files on all nodes.

**Command Default** When **dir** command is entered without keywords or arguments, the contents of the present working directory are displayed.

**Command Modes** EXEC mode.  
Admin EXEC mode.

Command History	Release	Modification
	Release 6.1.2	This command was introduced.

**Usage Guidelines** If you enter the **dir** command without specifying a directory, the contents of the present working directory are displayed. The **all** keyword displays all files, including deleted files. The size associated with the directory name is the total size for all files in that directory.

The following example shows how to display the contents of a directory:

```
RP/0/RSP0/CPU0:router# dir harddisk:/log

Directory of harddisk:/log

5527 drwx 4096 Thu Aug 28 11:21:48 2008 boot_28_Aug_2008_11_21_49
5533 drwx 4096 Thu Aug 28 11:38:54 2008 boot_28_Aug_2008_11_38_54
5538 drwx 4096 Fri Sep 5 13:28:54 2008 boot_05_Sep_2008_13_28_54
5543 drwx 4096 Mon Sep 8 08:55:52 2008 boot_08_Sep_2008_06_59_08
```

--More--

# mkdir

To create a new directory on a file system, use the **mkdir** command in the appropriate mode.

```
mkdir filesystem:[location {node-id | all}]
```

<b>Syntax Description</b>	<i>filesystem</i> :	File system on which to create a new directory.
	<b>location</b> { <i>node-id</i>   <b>all</b> }	(Optional) Specifies the node where the file system is located. The <i>node-id</i> argument is expressed in the <i>rack/slot/module</i> notation. Use the <b>all</b> keyword to indicate all nodes.
<b>Command Default</b>	No default behavior or values	
<b>Command Modes</b>	EXEC Admin EXEC.	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 6.1.2	This command was introduced.

## Usage Guidelines

After you issue the **mkdir** command, Cisco IOS XR software prompts you to specify the name of the directory to be created. When specifying the name of the new directory, include the directory path where you want the new directory to reside. If you do not specify a directory path, the new directory is created in the /usr directory of the file system specified for the *filesystem*: argument.

The following example shows how to create a directory named newdir. The **dir** command is used to verify that the directory has been added.

```
RP/0/RSP0/CPU0:router# mkdir harddisk:

Create directory filename []?newdir
Created dir harddisk:/newdir
RP/0/RP0/CPU0:router# dir harddisk:

Directory of harddisk:

11193 drwx 4096 Fri Feb 13 06:45:05 2009 newdir
37146 drwx 4096 Sun Dec 14 15:30:48 2008 malloc_dump
43030 drwx 4096 Wed Dec 24 11:20:52 2008 tracebacks
43035 drwx 4096 Thu Jan 8 18:59:18 2009 sau
51026 drwx 4096 Sat Dec 27 02:52:46 2008 tempA
51027 drwx 4096 Sat Dec 27 02:04:10 2008 dir.not.del
-430307552 -rwx 342 Fri Jan 16 10:47:38 2009 running-config
-430305504 -rwx 39790 Mon Jan 26 23:45:56 2009 cf.dat

39929724928 bytes total (39883231232 bytes free)
```

# pwd

To display the present working directory, use the **pwd** command in EXEC mode

```
.
```

## pwd

---

**Syntax Description**

This command has no keywords or arguments.

---

**Command Default**

No default behavior or values.

---

**Command Modes**

EXEC

---

**Command History**

Release	Modification
Release 6.1.2	This command was introduced.

---

**Usage Guidelines**

Use the **pwd** command to show what directory or file system is specified as the default by the **cd** command.

The following example shows how to display the present working directory:

```
RP/0/RSP0/CPU0:router# pwd
disk0:/usr
```

# rmdir

To remove an existing directory, use the **rmdir** command in the appropriate mode.

**rmdir** *filesystem*: **location** {*node-id* | **all**}

<b>Syntax Description</b>	<i>filesystem</i>	Name of the file system from which to delete a directory, followed by a colon.
	<b>location</b> { <i>node-id</i>   <b>all</b> }	Specifies the node where the file system is located. The <i>node-id</i> argument is expressed in the <i>rack/slot/module</i> notation. Use the <b>all</b> keyword to indicate all nodes.
<b>Command Default</b>	No default behavior or values	
<b>Command Modes</b>	EXEC Administration EXEC	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 6.1.2	This command was introduced.

**Usage Guidelines** Use the **rmdir** command to remove directories (for example, to free up disk space) from a file system. After you issue the **rmdir** command, the Cisco IOS XR software prompts you to specify the name of the directory to be deleted.

When a directory contains files, you must remove the files before deleting the directory. Use the **delete** command to remove files.

The following example shows how to delete a subdirectory from the hard disk. The **dir** command is used to verify that the directory has been deleted.

```
RP/0/RSP0/CPU0:router# rmdir harddisk:

Remove directory filename []?newdir
Delete harddisk:/newdir[confirm]y
RP/0/RSP0/CPU0:router# dir harddisk:

Directory of harddisk:

 37146 drwx 4096 Sun Dec 14 15:30:48 2008 malloc_dump
 43030 drwx 4096 Wed Dec 24 11:20:52 2008 tracebacks
 43035 drwx 4096 Thu Jan 8 18:59:18 2009 sau
 51026 drwx 4096 Sat Dec 27 02:52:46 2008 tempA
 51027 drwx 4096 Sat Dec 27 02:04:10 2008 dir.not.del
-430307552 -rwx 342 Fri Jan 16 10:47:38 2009 running-config
-430305504 -rwx 39790 Mon Jan 26 23:45:56 2009 cf.dat

39929724928 bytes total (39883235328 bytes free)
```

# show filesystem

To display the layout and contents of file systems, use the **show filesystem** command in EXEC mode

```
show filesystem filesystem:[{firmware | stats | verbose level}] [location {node-id | all}]
```

## Syntax Description

<i>filesystem:</i>	Name of the file system for which to display information, followed by a colon. Possible values are: <b>disk0:</b> , <b>disk1:</b> , <b>harddisk:</b> .
<b>firmware</b>	(Optional) Displays the firmware level.
<b>stats</b>	(Optional) Displays device statistics.
<b>verbose level</b>	(Optional) Changes the device driver verbose level.
<b>location {node-id   all}</b>	(Optional) Specifies the node where the file system is located. The <i>node-id</i> argument is expressed in the <i>rack/slot/module</i> notation. Use the <b>all</b> keyword to indicate all nodes.

## Command Default

The file system for the active RP is displayed.

## Command Modes

EXEC mode

## Command History

Release	Modification
Release 6.1.2	This command was introduced.

## Usage Guidelines

Use the **show filesystem** command to learn the alias names (prefixes) of the file systems supported by your networking device.

The following example shows sample output from the **show filesystem** command:

```
RP/0/RSP0/CPU0:router# show filesystem

File Systems:

 Size(b) Free(b) Type Flags Prefixes
 - - - - -
 - - network rw qsm/dev/fs/tftp: tftp:
 - - network rw qsm/dev/fs/rcp: rcp:
 - - network rw qsm/dev/fs/ftp: ftp:
39929724928 39852978176 harddisk rw harddisk:
1024606208 863584256 flash-disk rw disk0:
 2092032 2059264 nvram rw nvram:
 62390272 62381260 flash rw bootflash:
```

The following example shows sample output from the **show filesystem** command using the optional **location node-id** keyword and argument:

```
RP/0/RSP0/CPU0:router# show filesystem location 0/rp0/cpu0

File Systems:
```

```

 Size(b) Free(b) Type Flags Prefixes
 - - network rw qsm/dev/fs/tftp: tftp:
 - - network rw qsm/dev/fs/rcp: rcp:
 - - network rw qsm/dev/fs/ftp: ftp:
39929724928 39883235328 harddisk rw harddisk:
 2092032 2019328 nvram rw nvram:
 1024606208 847888384 flash-disk rw disk0:
 62390272 62153616 flash rw bootflash:

```

**Table 23: show filesystem Field Descriptions**

Field	Description
Size(b)	Amount of memory in the file system, in bytes.
Free(b)	Amount of free memory in the file system, in bytes.
Type	Type of file system.
Flags	Permissions for file system.
Prefixes	Alias for the file system.



# show media

To display the current state of the disk storage media, use the **show media** command in EXEC or Administration EXEC mode.

**show media location** {*node-id* | **all**}

<b>Syntax Description</b>	<b>location</b> { <i>node-id</i>   <b>all</b> } (Optional) Specifies the node where the file system is located. The <i>node-id</i> argument is expressed in the <i>rack/slot/module</i> notation. Use the <b>all</b> keyword to indicate all nodes.
---------------------------	-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

**Command Default** The disk storage media for the active RP is displayed.

**Command Modes** Administration EXEC  
EXEC

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 6.1.2	This command was introduced.

**Usage Guidelines** Use the **show media** command to view the status of the storage media on your system.

The following example displays the output of the **show media** command:

```

sysadmin-vm:0_RP0 #show media
Thu Nov 30 14:57:14.002 WET
Media Information for local node.

Partition Size Used Percent Avail
rootfs: 2.7G 1.5G 59% 1.1G
apphost: 1.9G 61M 4% 1.7G
/dev/sde 870M 401M 50% 409M
harddisk: 2.4G 966M 43% 1.3G
log: 459M 67M 16% 359M
config: 159M 2.5M 2% 144M
disk0: 1.3G 108M 9% 1.1G

rootfs: = root file system (read-only)
log: = system log files (read-only)
config: = configuration storage (read-only)

```

**Table 24: show media Field Descriptions**

Field	Description
Partition	Partition on the disk.
Size	Size of the partition.
Used	Partition size used.
Percent	Percentage used.

Field	Description
Avail	Available free partition space.



## Frequency Synchronization Commands

This chapter describes the Cisco IOS XR frequency synchronization commands that are used to distribute precision frequency around a network.

For detailed information about frequency synchronization concepts, configuration tasks, and examples, see the *Configuring Frequency Synchronization on Cisco IOS XR Software* configuration module in *System Management Configuration Guide for Cisco ASR 9000 Series Routers*.

- [clear SyncE esmc statistics, on page 288](#)
- [clear SyncE wait-to-restore, on page 289](#)
- [clock-interface timing-mode, on page 290](#)
- [clock-interface sync, on page 292](#)
- [SyncE, on page 293](#)
- [gps-input, on page 294](#)
- [log selection, on page 296](#)
- [port-parameters, on page 297](#)
- [priority \(SyncE\), on page 299](#)
- [quality itu-t option, on page 300](#)
- [quality receive, on page 301](#)
- [quality transmit, on page 304](#)
- [selection input, on page 307](#)
- [show frequency synchronization clock-interfaces, on page 308](#)
- [show SyncE configuration-errors, on page 310](#)
- [show SyncE interfaces, on page 311](#)
- [show SyncE selection, on page 313](#)
- [show frequency synchronization selection back-trace, on page 317](#)
- [show frequency synchronization selection forward-trace, on page 318](#)
- [ssm disable, on page 320](#)
- [time-of-day-priority, on page 321](#)
- [wait-to-restore, on page 322](#)

# clear SyncE esmc statistics

To clear the Ethernet Synchronization Messaging Channel (ESMC) statistics, use the **clear SyncE esmc statistics** command in EXEC mode.

**clear SyncE esmc statistics interface** *{interface | all | summary location {node-id | all}}*

<b>Syntax Description</b>	<p><i>interface</i> The command can be restricted to clear the ESMC statistics for a particular interface by specifying the interface.</p> <p><i>node-id</i> The output can be restricted to clear the ESMC statistics for a particular node by specifying the location. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.</p>
---------------------------	--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

<b>Command Default</b>	No default behavior or values
------------------------	-------------------------------

<b>Command Modes</b>	EXEC
----------------------	------

<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 6.1.2</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 6.1.2	This command was introduced.
Release	Modification				
Release 6.1.2	This command was introduced.				

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

<b>Task ID</b>	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operations</th> </tr> </thead> <tbody> <tr> <td>ethernet-services</td> <td>execute</td> </tr> </tbody> </table>	Task ID	Operations	ethernet-services	execute
Task ID	Operations				
ethernet-services	execute				

<b>Examples</b>	The following example shows how to clear the ESMC statistics:
-----------------	---------------------------------------------------------------

```
RP/0/0RP0/CPU0:router:hostname# clear SyncE esmc statistics interface gigabitethernet 0/1/0/1
```

# clear SyncE wait-to-restore

To clear the SyncE wait-to-restore timer, use the **clear SyncE wait-to-restore** command in EXEC mode.

```
clear SyncE wait-to-restore {{all | sync port-num location node-id} | interface {type interface-path-id | all}}
```

Syntax Description	all	Clears all wait-to-restore timers.
	<b>interface</b> <i>type interface-path-id</i>	Clears the wait-to-restore timers for a specific interface or all interfaces.

**Command Default** No default behavior or values

**Command Modes** EXEC

Command History	Release	Modification
	Release 6.1.2	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	ethernet-services	execute

## Examples

The following example shows how to clear the SyncE wait-to-restore timer on a specific interface:

```
RP/0/0RP0/CPU0:router:hostname#clear SyncE wait-to-restore interface gigabitethernet 0/1/0/1
```

## Related Topics

[wait-to-restore](#), on page 322

# clock-interface timing-mode

To configure the type of timing sources that can be used to drive the output from the clock interfaces on the router, use the **clock-interface timing-mode** command in frequency synchronization configuration mode. To revert to the default timing mode, use the **no** form of this command.

```
clock-interface timing-mode {independent | system}
no clock-interface timing-mode
```

Syntax Description		
	<b>independent</b>	Specifies that the output of clock interfaces is driven only by the line interfaces (Ethernet and SONET). Each clock interface port on the router is completely independent. The same timing source cannot be used on more than one port and no loopbacks are allowed between clock interface ports.
	<b>system</b>	Specifies that the output of a clock interface is driven by the system-selected timing source, which can be either the line interface or the clock interface.

**Command Default** Clock interface output is driven only by input from line interfaces or the internal oscillator.

**Command Modes** Frequency synchronization configuration

Command History	Release	Modification
	Release 3.9.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

In the default clock mode, clock interface loopback detection is turned on. This means that heuristic tests are run to detect if the signal being sent out of one clock interface can be looped back by some external box and sent back in via the same, or another, clock interface. In addition, output from the clock interface is driven only by input from line interfaces (and the internal oscillator). It is never driven by input from another clock interface.

Task ID	Task ID	Operations
	ethernet-services	execute
	sonet-sdh	execute

**Examples** The following examples show how to configure the timing source for the clock interfaces on the router:

```
RP/0/RSP0/CPU0:router# config
RP/0/RSP0/CPU0:router(config)# frequency synchronization
RP/0/RSP0/CPU0:router(config-freqsync)#clock-interface independent

RP/0/RSP0/CPU0:router# config
RP/0/RSP0/CPU0:router(config)# frequency synchronization
RP/0/RSP0/CPU0:router(config-freqsync)#clock-interface system
```

# clock-interface sync

To configure a clock interface for frequency synchronization on a specific node, use the **clock-interface sync** command in global configuration mode. To remove the clock interface from a node, use the **no** form of this command.

```
clock-interface sync port-id location node-id
no clock-interface sync port-id location node-id
```

Syntax Description	port-id	Clock interface port number.
	location node-id	Specifies the node for clock interface frequency synchronization. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.

**Command Default** No default behavior or values

**Command Modes** Global configuration

Command History	Release	Modification
	Release 3.9.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	ethernet-services	execute
	sonet-sdh	execute

## Examples

This example shows how to configure a clock interface for frequency synchronization on a specific node:

```
RP/0/RSP0/CPU0:router# config
RP/0/RSP0/CPU0:router(config)# clock-interface sync 0 location 0/1/cpu0
RP/0/RSP0/CPU0:router(config-clock-if)# frequency synchronization
RP/0/RSP0/CPU0:router(config-clk-freqsync)#
```



# SyncE

To enable SyncE globally on the router and to configure SyncE options for a controller or interface, use the **SyncE** command in the appropriate configuration mode. To disable SyncE, use the **no** form of this command.

**SyncE**  
**no SyncE**

**Syntax Description** This command has no keywords or arguments.

**Command Default** Disabled

**Command Modes** Global configuration (config)  
 Interface configuration (config-interface)

Command History	Release	Modification
	Release 6.1.2	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Configuration of SyncE on the router involves enabling it both in global configuration, and at the interface, where you can configure additional commands.

When you configure SyncE in global configuration mode, the default clocking is configured for line timing mode.

Task ID	Task ID	Operations
	ethernet-services	execute

## Examples

The following example shows how to enable SyncE in global configuration:

```
RP/0/0RP0/CPU0:router:hostname# config
RP/0/0RP0/CPU0:router:hostname(config)# SyncE
RP/0/0RP0/CPU0:router:hostname(config-freqsync)# commit
```

The following example shows how to enable SyncE on an Ethernet interface:

```
RP/0/0RP0/CPU0:router:hostname# config
RP/0/0RP0/CPU0:router:hostname(config)# interface gigabitEthernet 0/5/0/0
RP/0/0RP0/CPU0:router:hostname(config-if)# SyncE
RP/0/0RP0/CPU0:router:hostname(config-if-freqsync)#
```

## gps-input

To configure the GPS input parameters on an interface, use the **gps-input** command in clock interface port parameters configuration mode. To revert to the default parameters, use the **no** form of this command.

```
gps-input tod-format {cisco | ntp4 | gprmc} pps-input {rs422 | ttl} [offset {gps | tai | utc}]
input-phase-delay delay-nanoseconds
```

### Syntax Description

<b>tod-format</b>	Specifies the format of the time-of-day messages.
<b>gprmc</b>	Specifies that the received time of day messages are in the NMEA GPRMC format.
<b>cisco</b>	Specifies that received time-of-day messages are in the Cisco ASCII format.
<b>ntp4</b>	Specifies that received time-of-day messages are in the NTP Type 4 format.
<b>pps-input</b>	Specifies the mode of one pulse-per-second signals.
<b>rs422</b>	Specifies that received 1PPS messages are in RS-422 mode.
<b>ttl</b>	Specifies that received 1PPS messages are in TTL mode.
<b>offset</b>	Specifies the leap second correction to be applied on GPS input time. This is an optional parameter. If no option is specified, the GPS input time is based on UTC (Coordinated Universal Time) and the leap second correction is performed accordingly.
<b>gps</b>	Specifies the GPS input time based on GPS epoch.
<b>tai</b>	Specifies the GPS input time based on TAI (Temps Atomique International also known as International Atomic Time) time scale and no leap second correction is required.
<b>utc</b>	Specifies the GPS input time based on UTC.
<b>input-phase-delay</b> <i>input-phase-delay</i>	Specifies the compensation when there is phase delay. <b>Note</b> When you use an ASR 9000 router as Grand Master (GM), it may be connected to a GPS source. If there is a phase delay that is caused by either the GPS source itself or the cable, use the <b>input-phase-delay</b> keyword to compensate the delay.

### Command Default

GPS parameters are not configured.

### Command Modes

Clock interface port parameters configuration

### Command History

Release	Modification
Release 4.2.0	This command was introduced.
Release 5.1.3	The <b>Offset</b> keyword was introduced.

Release	Modification
Release 5.2.2	Support for GPRMC format.
Release 5.3.2	The <b>input-phase-delay</b> keyword was introduced.
Release 6.2.1	The <b>input-phase-delay</b> keyword was introduced.

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **gps-input** command to specify input parameters for a clock interface that is configured for GPS timing.

The Offset keyword adjusts the GPS input time for leap seconds. ASR 9000 internally converts the TOD received from GPS to TAI time scale and the offset can be specified for correction. This is an optional parameter. If no option is specified, the GPS input time is based on UTC and leap second correction is performed accordingly.

### Task ID

Task ID	Operation
drivers	read, write

This example shows how to specify sample input parameters for a clock interface:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# clock-interface sync 2 location 0/rsp0/cpu0
RP/0/RSP0/CPU0:router(config-clock-if)# port-parameters
RP/0/RSP0/CPU0:router(config-clk-parms)# gps-input tod-format cisco pps-input rs422 offset
utc
```

# log selection

To enable logging of changes or errors to SyncE, use the **log selection** command in SyncE configuration mode. To disable logging, use the **no** form of this command.

```
log selection {changes | errors}
no log selection
```

<b>Syntax Description</b>	<b>changes</b> Logs every time there is a change to the selected source, including any logs that the <b>errors</b> keyword logs.
	<b>errors</b> Logs only when there are no available frequency sources, or when the only available frequency source is the internal oscillator.

<b>Command Default</b>	No default behavior or values
------------------------	-------------------------------

<b>Command Modes</b>	SyncE configuration
----------------------	---------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 6.1.2	This command was introduced.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	ethernet-services	execute

<b>Examples</b>	This example shows how to enable logging of changes to SyncE:
-----------------	---------------------------------------------------------------

```
RP/0/0RP0/CPU0:router:hostname# config
RP/0/0RP0/CPU0:router:hostname# (config)# SyncE
RP/0/0RP0/CPU0:router:hostname# (config-freqsync)# log selection changes

#
```

## port-parameters

To specify the type of external clock source for a clock interface, use the **port-parameters** command in clock interface configuration mode. To remove the clock source definition, use the **no** form of this command.

```
port-parameters {bits-input mode | bits-output mode | dti | ics}
no port-parameters {bits-input mode | bits-output mode | dti | ics}
```

Syntax Description	
	<b>{bits-input }</b> Specifies a building integrated timing supply (BITS) input timing device.
	<b>{bits-output }</b> Specifies a building integrated timing supply (BITS) output timing device.
	<i>mode</i> Type of BITS signal. Valid options are: <ul style="list-style-type: none"> <li>• <b>2m</b></li> <li>• <b>6m-output-only</b></li> <li>• <b>e1</b></li> <li>• <b>t1</b></li> </ul>
	<b>dti</b> Specifies a DOCSIS® Timing Interface (DTI).
	<b>ics</b> Enables inter-chassis clock synchronisation.

**Command Default** No clocking type is defined.

**Command Modes** Clock interface configuration mode

Command History	Release	Modification
	Release 3.9.0	This command was introduced.
	Release 5.3.0	The <b>ics</b> keyword was introduced.
	Release 6.6.2	The <b>bits-default</b> keyword was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operation
	drivers	read, write

This example shows how to configure the external clock source to be DTI:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# clock-interface sync 1 location 0/RSP0/CPU0
RP/0/RSP0/CPU0:router(config-clock-if)# port-parameters dti
```

# priority (SyncE)

To configure the priority of the frequency source on a controller or an interface, use the **priority** command in the appropriate SyncE configuration mode. To return the priority to the default value, use the no form of this command.

**priority** *priority-value*  
**no priority** *priority-value*

<b>Syntax Description</b>	<i>priority-value</i> Priority of the frequency source. The priority is used to select between sources with the same Quality Level (QL). The range is 1 (highest priority) to 254 (lowest priority).
---------------------------	------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

<b>Command Default</b>	100
------------------------	-----

<b>Command Modes</b>	Controller SyncE configuration Interface SyncE configuration
----------------------	-----------------------------------------------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 6.1.2	This command was introduced.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	ethernet-services	execute

## Examples

The following example shows how to configure the SyncE priority on a controller:

```
RP/0/0RP0/CPU0:router:hostname# config
RP/0/0RP0/CPU0:router:hostname# (config)# controller 0/1/0/1
RP/0/0RP0/CPU0:router:hostname# (config-controller)# SyncE
RP/0/0RP0/CPU0:router:hostname# (config-controller-freqsync)# priority 150
RP/0/0RP0/CPU0:router:hostname# (config-controller-freqsync)# commit
```

The following example shows how to configure the SyncE priority on interface:

```
RP/0/0RP0/CPU0:router:hostname# config
RP/0/0RP0/CPU0:router:hostname# (config)# interface gigabitethernet 0/1/0/1
RP/0/0RP0/CPU0:router:hostname# (config-if)# frequency synchronization
RP/0/0RP0/CPU0:router:hostname# (config-if-freqsync)# priority 150
RP/0/0RP0/CPU0:router:hostname# (config-if-freqsync)# commit
```

# quality itu-t option

To configure the ITU-T quality level (QL) options, use the **quality itu-t option** command in SyncE configuration mode. To return to the default levels, use the **no** form of this command.

```
quality itu-t option {1 | 2 generation {1 | 2}}
no quality
```

<b>Syntax Description</b>	<p><b>{1   2 generation}</b> Specifies the quality level for the router. Valid options are:</p> <p><b>{1   2}}</b></p> <ul style="list-style-type: none"> <li>• <b>1</b>—ITU-T QL option 1, which uses the PRC, SSU-A, SSU-B, SEC and DNU quality levels.</li> <li>• <b>2 generation 1</b>—ITU-T QL option 2 generation 1, which uses the PRS, STU, ST2, ST3, SMC, ST4, RES and DUS quality levels.</li> <li>• <b>2 generation 2</b>—ITU-T QL option 2, generation 2, which uses the PRS, STU, ST2, ST3 TNC, ST3E, SMC, ST4, PROV and DUS quality levels.</li> </ul>				
<b>Command Default</b>	ITU-T option 1				
<b>Command Modes</b>	SyncE configuration				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 6.1.2</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 6.1.2	This command was introduced.
Release	Modification				
Release 6.1.2	This command was introduced.				
<b>Usage Guidelines</b>	<p>To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.</p> <p>The QL configured with the <b>quality itu-t option</b> command must match the QL specified in the <b>quality transmit</b> and <b>quality receive</b> commands configured in clock interface or interface SyncE configuration mode.</p>				
<b>Task ID</b>	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operations</th> </tr> </thead> <tbody> <tr> <td>ethernet-services</td> <td>execute</td> </tr> </tbody> </table>	Task ID	Operations	ethernet-services	execute
Task ID	Operations				
ethernet-services	execute				

## Examples

The following example shows how to configure the ITU-T QL options:

```
RP/0/0RP0/CPU0:router:hostname# config
RP/0/0RP0/CPU0:router:hostname# (config)# SyncE
RP/0/0RP0/CPU0:router:hostname# (config-sonet-freqsync)# quality itu-t option 1
```

## Related Topics

- [quality receive](#), on page 301
- [quality transmit](#), on page 304



# quality receive

To configure all the Synchronization Status Message (SSM) quality levels (QLs) for the frequency source from the receive interface, use the **quality receive** command in the appropriate SyncE mode. To return to the default levels, use the no form of this command.

```
quality receive itu-t option {lowest ql-option ql [highest ql] | highest ql-option ql | exact ql-option ql}
```

```
no quality receive receive
```

## Syntax Description

*ql-option* Quality Level (QL) ITU-T options.

Valid values are:

- **1**—ITU-T Option 1
- **2 generation 1**—ITU-T Option 2 Generation 1
- **2 generation 2**—ITU-T Option 2 Generation 2

*ql* Quality Level (QL) value.

For line interfaces and clock interface with SSM support, any of the following combinations of QL values can be specified to modify the QL value received via SSM:

- If the **exact** keyword is used and the received or default QL is not DNU, then this value is used (rather than the received/default QL).
- If the **lowest** keyword is used and the received QL is a lower quality than this, then the received QL value is ignored and DNU is used instead.
- If the **highest** keyword is used and the received QL is higher quality than this, then the received QL value is ignored and this value is used instead.
- If the **lowest** and **highest** keywords are used, the behavior is as above. The maximum QL must be at least as high quality as the minimum QL.

Valid QL values for ITU-T Option 1 are:

- PRC
- SSU-A
- SSU-B
- SEC
- DNU

Valid QL values for ITU-T Option 2 Generation 1 are:

- PRS
- STU
- ST2
- ST3
- SMC
- ST4
- RES
- DUS

---

Valid QL values for ITU-T Option 2 Generation 2 are:

- PRS
  - STU
  - ST2
  - TNC
  - ST3E
  - ST3
  - SMC
  - ST4
  - PROV
  - DUS
- 

---

**Command Default** QL is unmodified.

---

**Command Modes** Interface SyncE

---

Command History	Release	Modification
	Release 6.1.2	This command was introduced.

---



---

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

In cases where the clock interface supports SSM but it is not always enabled, all options are available. For clock interfaces where SSM is disabled or not being received, the QL used with the **exact** keyword specifies a precise QL to use for the interface. The QL specified with the **lowest** and **highest** keywords only acts on a received QL, which is only detected in cases where SSM is not running and a loopback has been detected. In this case the **lowest** and **highest** QL values modify the effective input QL.




---

**Note** If SSM is disabled, only the exact QL option is available.

---



---

Task ID	Task ID	Operations
	ethernet-services	execute

---



---

**Examples** The following example shows how to configure all the SSM quality levels for the frequency source from the receive interface:

```
RP/0/0RP0/CPU0:router:hostname# config
RP/0/0RP0/CPU0:router:hostname(config)# controller sonet 0/1/0/1
RP/0/0RP0/CPU0:router:hostname(config-sonet)# SyncE
RP/0/0RP0/CPU0:router:hostname(config-sonet-freqsync)# quality receive itu-t
option 2 generation 2 ST3
```

**Related Topics**

[quality itu-t option](#), on page 300

# quality transmit

To configure all the Synchronization Status Message (SSM) quality levels for the frequency source from the transmit interface, use the **quality transmit** command in the appropriate SyncE mode. To return to the default levels, use the **no** form of this command.

**quality transmit** *itu-t option* {**lowest** *ql-option ql* [**highest** *ql*] | **highest** *ql-option ql* | **exact** *ql-option ql*}

**no quality transmit**

## Syntax Description

*ql-option* Quality Level (QL) ITU-T options.

Valid values are:

- **1**—ITU-T Option 1
- **2 generation 1**—ITU-T Option 2 Generation 1
- **2 generation 2**—ITU-T Option 2 Generation 2

*ql* Quality Level (QL) value.

- If the **exact** keyword is used and the received or default QL is not DNU, then this value is used (rather than the received/default QL).
- If the **lowest** keyword is used and the received QL is a lower quality than this, then the received QL value is ignored and DNU is used instead.
- If the **highest** keyword is used and the received QL is higher quality than this, then the received QL value is ignored and this value is used instead.
- If the **lowest** and **highest** keywords are used, the behavior is as above. The maximum QL must be at least as high quality as the minimum QL.

Valid QL values for ITU-T Option 1 are:

- PRC
- SSU-A
- SSU-B
- SEC
- DNU

Valid QL values for ITU-T Option 2 Generation 1 are:

- PRS
- STU
- ST2
- ST3
- SMC
- ST4
- RES
- DUS

---

Valid QL values for ITU-T Option 2 Generation 2 are:

- PRS
  - STU
  - ST2
  - TNC
  - ST3E
  - ST3
  - SMC
  - ST4
  - PROV
  - DUS
- 

---

**Command Default** The QL is unmodified

---

**Command Modes** Interface SyncE

---

Command History	Release	Modification
	Release 6.1.2	This command was introduced.

---



---

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

If the interface is the selected source, DNU is always sent regardless of this configuration.

This configuration has no effect when SSM is disabled.




---

**Note** For clock interfaces that do not support SSM, only the lowest QL can be specified. In this case, rather than sending DNU, the output is squelched, and no signal is sent.

---



---

Task ID	Task ID	Operations
	ethernet-services	execute

---



---

**Examples** The following example show how to configure all the SSM quality levels for the frequency source from the transmit interface:

```
RP/0/0RP0/CPU0:router:hostname#(config)#controller sonet 0/1/0/1
RP/0/0RP0/CPU0:router:hostname(config-sonet)#SyncE
RP/0/0RP0/CPU0:router:hostname(config-sonet-freqsync)quality transmit itu-t option 2
generation 2
RP/0/0RP0/CPU0:router:hostname(config-sonet-freqsync)#commit
```

**Related Topics**

[quality itu-t option](#), on page 300

# selection input

To configure an interface so that it is available as a timing source for selection by the system, use the **selection input** command in the appropriate SyncE configuration mode. To remove the interface as an available timing source, use the **no** form of this command.

**selection input**  
**no selection input**

**Syntax Description** This command has no keywords or arguments.

**Command Default** Disabled

**Command Modes** Controller SyncE configuration  
 Interface SyncE configuration

Command History	Release	Modification
	Release 6.1.2	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	ethernet-services	execute

## Examples

The following example shows how to configure an interface so that it is available as a timing source for selection by the system:

```
RP/0/0RP0/CPU0:router:hostname# config
RP/0/0RP0/CPU0:router:hostname(config)# interface gigabitethernet 0/1/0/1
RP/0/0RP0/CPU0:router:hostname(config-if)# SyncE
RP/0/0RP0/CPU0:router:hostname(config-if-freqsync)# selection input
RP/0/0RP0/CPU0:router:hostname(config-if-freqsync)# commit
```

# show frequency synchronization clock-interfaces

To display the frequency synchronization information for all clock-interfaces or for a specific node, use the **show frequency synchronization clock-interfaces** command in EXEC mode.

**show frequency synchronization clock-interfaces** [**brief**] [**location** *node-id*]

Syntax Description		
<b>brief</b>		Displays summary information for all clock interfaces.
<b>location</b> <i>node-id</i>		Displays information for a specific interface. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.

**Command Default** No default behavior or values

**Command Modes** EXEC

Command History	Release	Modification
	Release 3.9.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	ethernet-services	execute
	sonet-sdh	execute

## Examples

The following example shows the output for the **show frequency synchronization clock-interfaces** command:

```
RP/0/RSP0/CPU0:router# show frequency synchronization clock-interfaces
```

```
Node 0/0/CPU0:
```

```
=====
```

```
 Clock interface Sync0 (Up):
 Assigned as input for selection
 SSM supported and enabled
 Input:
 Going down in 00:00:20
 Last received QL: OPT-II,1/PRC
 Effective QL: OPT-II,1/PRC, Priority: 200
 Output:
 Selected source: GigabitEthernet0/0/0/3
```



```

 Selected source QL: OPT-II,1/PRC
 Effective QL: DNU
Next selection points: RP_SELECTOR

Clock interface Sync1 (Down: mode is not configured):
Assigned as input for selection
SSM supported and enabled
Input:
 Restore in 00:02:00
 Last received QL: Opt-II,2/ST3
 Effective QL: Opt-II,2/ST3, Priority: 100
Output:
 Selected source: GigabitEthernet0/0/0/3
 Selected source QL: Opt-II,2/PRC
 Effective QL: DNU
Next selection points: RP_SYSTEM

Clock interface Internal0 (Up):
Input:
 Default QL: OPT-II,2/ST3
 Effective QL: OPT-II,2/ST3, Priority 255
Next selection points: RP_SELECTOR

```



**Note** The last received QL and effective output QL are only shown if SSM is supported and enabled on the clock.

The output in brief mode is as follows:

```

RP/0/RSP0/CPU0:router# show frequency synchronization clock-interfaces brief

Flags: > - Up D - Down S - Assigned for selection
 d - SSM Disabled s - Output squelched L - Looped back
Node 0/0/CPU0:
=====
Fl Clock Interface QLrcv QLuse Pri QLsnd Source
===== ===== ===== ===== === ===== =====
>S Sync0 PRC PRC 100 DNU GigabitEthernet0/0/0/3
DS Sync1 FAILED DNU 100 n/a GigabitEthernet0/0/0/3
>S Internal0 ST3 ST3 255 n/a

```

## show SyncE configuration-errors

To display information about any configuration inconsistencies that are detected, but that are not rejected by verification, use the **show SyncE configuration-errors** command in EXEC mode.

**show SyncE configuration-errors** [**location** *node-id*]

### Syntax Description

**location** Location of the card, specified by *node-id*.

*node-id* The output can be restricted to a particular node by specifying the location. The *node-id* argument is entered in the *rack/slot/module* notation.

### Command Default

No default behavior or values

### Command Modes

EXEC

### Command History

Release	Modification
Release 6.1.2	This command was introduced.

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

### Task ID

Task ID	Operations
ethernet-services	execute

### Examples

This example shows the normal output for the **show SyncE configuration-errors** command:

```
RP/0/ORP0/CPU0:router:hostname# show SyncE configuration-errors
```

```
Node 0/0/CPU0:
```

```
=====
```

```
interface GigabitEthernet0/0/0/0 SyncE
```

```
* SyncE is enabled on this interface, but isn't enabled globally.
```

```
* The QL that is configured is from a different QL option set than is configured globally.
```

# show SyncE interfaces

To show the SyncE information for all interfaces or for a specific interface, use the **show SyncE interfaces** command in EXEC mode.

```
show frequency SyncE {brief | summary [location node-id] | type interface-path-id}
```

Syntax Description		
<b>brief</b>		Displays brief information for all interfaces.
<b>summary [location node-id]</b>		Displays summary information for all notes or a specific node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.
<b>type interface-path-id</b>		Displays information for a specific interface.

**Command Default** No default behavior or values

**Command Modes** EXEC

**Command History**

Release	Modification
Release 6.1.2	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

**Task ID**

Task ID	Operations
ethernet-services	execute

## Examples

The following example shows the display output for the **show SyncE interfaces** command:

**show SyncE interfaces**

```
RP/0/0RP0/CPU0:router:hostname# show SyncE interfaces

Interface GigabitEthernet0/0/0/0 (Up)
 Assigned as input for selection
 SSM Enabled
 Peer Up for 00:01:30, last SSM received 0.345s ago
 Peer has come up 4 times and timed out 3 times
 ESMC SSMs Total Information Event DNU
 Sent: 98765 98665 100 50
 Received: 54321 54320 1 54300
 13 malformed packets received
 11 received packets were not handled
Input:
 Restore in 00:03:30
 Last received QL: Opt-II,2/PRC
 Effective QL: DNU, Priority 100
Output:
```

## show SyncE interfaces

```

Selected source: Sync0 [0/0/CPU0]
Selected source QL: OPT-II,2/SEC
Effective QL: OPT-II,2/SEC
Output is squelched
Next selection points: LC_INGRESS

Interface SONET0/2/0/0 (Up)
Assigned as input for selection
SSM Enabled
Input:
 Restore in 00:03:30
 Last received QL: Opt-II,2/PRC
 Effective QL: DNU, Priority 100
Output:
 Selected source: Sync0 [0/0/CPU0]
 Selected source QL: OPT-II,2/SEC
 Effective QL: OPT-II,2/SEC
 Output is squelched
Next selection points: LC_INGRESS

```

The output in brief mode is as follows:

```

Flags: > - Up D - Down S - Assigned for selection
 d - SSM Disabled x - Peer timed out i - Init state
 s - Output squelched

Fl Interface QLrcv QLluse Pri QLsnd Source
====
>S GigabitEthernet0/0/0/0 ST2 ST3 100 PRC Sync0 [0/0/CPU0]
>S GigabitEthernet0/0/0/1 PROV DNU 100 PRC Sync0 [0/0/CPU0]
DdS GigabitEthernet0/1/0/0 n/a ST3 50 Sync0 [0/0/CPU0]
D SONET0/1/0/0 n/a n/a 100 DNU Sync0 [0/0/CPU0]
> GigabitEthernet0/12/0/13 PRC n/a 200 DNU Sync0 [0/0/CPU0]

```

The output in summary mode is as follows, for each node:

```

Node 0/0/CPU0:
 34 Ethernet interfaces in Synchronous mode, 10 assigned for selection, 23 with SSM enabled

ESMC SSMS Total Information Event DNU
Sent: 198765 189665 9100 650
Received: 654321 654320 91 54321

 12 SONET interfaces in Synchronous mode, 5 assigned for selection, 11 with SSM enabled

```

# show SyncE selection

To display the SyncE selection information for all selection points or for a specific node, use the **show SyncE selection** command in EXEC mode.

**show SyncE selection** {*location node-id*}

<b>Syntax Description</b>	<b>location node-id</b>	Displays information for a specific node on the router. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.
---------------------------	-----------------------------	-----------------------------------------------------------------------------------------------------------------------------------------

**Command Default** No default behavior or values

**Command Modes** EXEC

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 6.1.2	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **show SyncE selection** command shows the status of the timing stream from the timing source

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	ethernet-services	execute

## Examples

This example shows the normal output for the **show SyncE selection** command:

```
RP/0/0RP0/CPU0:router:hostname# show frequency synchronization selection

Node 0/0/CPU0:
=====
Selection point: LC_INGRESS (4 inputs, 2 selected)
 Last programmed 00:01:30 ago, and selection made 00:01:29 ago
 Next selection points:
 SPA scoped : None
 Node scoped : None
 Chassis scoped : None
 Router scoped : RP_SELECTOR RP_CLOCK_INTF_SELECTOR
 S Input Last Selection Point QL Pri Status
 == =====
 1 GigabitEthernet0/0/0/3 n/a PRC 100 Unmonitored
 2 GigabitEthernet0/0/0/0 n/a PRC 200 Down
 GigabitEthernet0/0/0/1 n/a ST2 50 Unmonitored
 GigabitEthernet0/0/0/2 n/a ST3 100 Unmonitored

Selection point: LC_EGRESS (2 inputs, 1 selected)
 Last programmed 00:25:42 ago, and selection made 00:00:15 ago
 Next selection points:
 SPA scoped : None
```

## show SyncE selection

```

Node scoped : None
Chassis scoped: None
Router scoped : None
Used for local line interface output
Used for local clock-interface output
S Input Last Selection Point QL Pri Status
== =====
1 GigabitEthernet0/0/0/3 0/1/CPU0 RP_SELECTOR 1 PRC 100 Ok
 GigabitEthernet0/0/0/3 0/2/CPU0 RP_SELECTOR 1 PRC 100 Ok

Node 0/1/CPU0:
=====
Selection point: RP_SELECTOR (5 inputs, 1 selected)
Last programmed 00:01:32 ago, and selection made 00:01:28 ago
Next selection points:
 SPA scoped : None
 Node scoped : None
 Chassis scoped: None
 Router scoped : LC_EGRESS
S Input Last Selection Point QL Pri Status
== =====
1 GigabitEthernet0/0/0/3 0/0/CPU0 LC_INGRESS 1 PRC 100 Ok
 Sync0 [0/1/CPU0] n/a PRC 50 LOS
 GigabitEthernet0/0/0/3 0/2/CPU0 RP_SELECTOR 1 PRC 100 Ok
 GigabitEthernet0/0/0/0 0/0/CPU0 LC_INGRESS 2 PRC 200 Ok
 Internal0 [0/1/CPU0] n/a ST3 255 Ok

Selection point: RP_CLOCK_INTF_SELECTOR (4 inputs, 1 selected)
Last programmed 00:01:32 ago, and selection made 00:01:28 ago
Next selection points:
 SPA scoped : None
 Node scoped : None
 Chassis scoped: None
 Router scoped : None
Used for local clock-interface output
S Input Last Selection Point QL Pri Status
== =====
1 GigabitEthernet0/0/0/3 0/0/CPU0 LC_INGRESS 1 PRC 100 Ok
 GigabitEthernet0/0/0/3 0/2/CPU0 RP_SELECTOR 1 PRC 100 Ok
 GigabitEthernet0/0/0/0 0/0/CPU0 LC_INGRESS 2 PRC 200 Ok
 Internal0 [0/1/CPU0] n/a ST3 255 Ok

Node 0/2/CPU0:
=====
Selection point: RP_SELECTOR (4 inputs, 1 selected)
Last programmed 00:28:55 ago, and selection made 00:00:20 ago
Next selection points:
 SPA scoped : None
 Node scoped : None
 Chassis scoped: None
 Router scoped : LC_EGRESS
S Input Last Selection Point QL Pri Status
== =====
1 GigabitEthernet0/0/0/3 0/1/CPU0 RP_SELECTOR 1 PRC 100 Ok
 GigabitEthernet0/0/0/3 0/0/CPU0 LC_INGRESS 1 PRC 100 Ok
 GigabitEthernet0/0/0/0 0/0/CPU0 LC_INGRESS 2 PRC 200 Ok
 Internal0 [0/2/CPU0] n/a ST3 255 Ok

Selection point: RP_CLOCK_INTF_SELECTOR (4 inputs, 1 selected)
Last programmed 00:28:55 ago, and selection made 00:00:20 ago
Next selection points:
 SPA scoped : None
 Node scoped : None
 Router scoped : None

```

```

Chassis scoped: None
Used for local clock-interface output
S Input Last Selection Point QL Pri Status
== =====
1 GigabitEthernet0/0/0/3 0/1/CPU0 RP_SELECTOR 1 PRC 100 Ok
 GigabitEthernet0/0/0/3 0/0/CPU0 LC_INGRESS 1 PRC 100 Ok
 GigabitEthernet0/0/0/0 0/0/CPU0 LC_INGRESS 2 PRC 200 Ok
 Internal0 [0/2/CPU0] n/a ST3 255 Ok

```

This example shows output from the **show frequency synchronization selection summary** command. The timing sources which are selected in the system are displayed and are clocking one or more outputs:

```
RP/0/RSP0/CPU0:router# show frequency synchronization selection summary
```

```
GigabitEthernet0/0/0/3 is selected for 2 outputs
Sync0 [0/0/CPU0] is selected for 25 outputs
```

This example displays information relevant to the ICS interfaces:

```

Node 1/RSP0/CPU0:
=====
Selection point: T0-SEL-B (4 inputs, 1 selected)
Last programmed 00:04:59 ago, and selection made 00:02:55 ago
Next selection points
 SPA scoped : None
 Node scoped : T4-SEL-C CHASSIS-TOD-SEL
 Chassis scoped: LC_TX_SELECT
 Router scoped : None
Uses frequency selection
Used for local line interface output
S Input Last Selection Point QL Pri Status
== =====
1 Sync3 [1/RSP0/CPU0] n/a PRC 25 Locked
 GigabitEthernet1/0/0/6 1/0/CPU0 SPA_RXMUX 1 PRC 50 Available
 PTP [1/RSP0/CPU0] n/a SEC 254 Available
 Internal0 [1/RSP0/CPU0] n/a SEC 255 Available

Selection point: T4-SEL-A (1 inputs, 1 selected)
Last programmed 00:22:28 ago, and selection made 00:02:55 ago
Next selection points
 SPA scoped : None
 Node scoped : T4-SEL-C
 Chassis scoped: None
 Router scoped : None
Uses frequency selection
S Input Last Selection Point QL Pri Status
== =====
1 GigabitEthernet1/0/0/6 1/0/CPU0 SPA_RXMUX 1 PRC 50 Available

Selection point: T4-SEL-C (2 inputs, 1 selected)
Last programmed 00:04:47 ago, and selection made 00:02:55 ago
Next selection points
 SPA scoped : None
 Node scoped : None
 Chassis scoped: None
 Router scoped : None
Uses frequency selection
Used for local clock interface output
S Input Last Selection Point QL Pri Status
== =====
1 Sync3 [1/RSP0/CPU0] 1/RSP0/CPU0 T0-SEL-B 1 PRC 25 Locked

```

## show SyncE selection

```

GigabitEthernet1/0/0/6 1/RSP0/CPU0 T4-SEL-A 1 PRC 50 Available

Selection point: CHASSIS-TOD-SEL (3 inputs, 1 selected)
 Last programmed 00:04:47 ago, and selection made 00:04:47 ago
RP/0/RSP1/CPU0:Swordfish#sh freq syn sel loc 1/rsp0/cpu0
Thu Jul 24 10:03:05.764 UTC
Node 1/RSP0/CPU0:
=====
Selection point: T0-SEL-B (4 inputs, 1 selected)
 Last programmed 00:09:35 ago, and selection made 00:07:31 ago
 Next selection points
 SPA scoped : None
 Node scoped : T4-SEL-C CHASSIS-TOD-SEL
 Chassis scoped : LC_TX_SELECT
 Router scoped : None
 Uses frequency selection
 Used for local line interface output
S Input Last Selection Point QL Pri Status
== =====
1 Sync3 [1/RSP0/CPU0] n/a PRC 25 Locked
 GigabitEthernet1/0/0/6 1/0/CPU0 SPA_RXMUX 1 PRC 50 Available
 PTP [1/RSP0/CPU0] n/a SEC 254 Available
 Internal0 [1/RSP0/CPU0] n/a SEC 255 Available

Selection point: T4-SEL-A (1 inputs, 1 selected)
 Last programmed 00:27:04 ago, and selection made 00:07:31 ago
 Next selection points
 SPA scoped : None
 Node scoped : T4-SEL-C
 Chassis scoped : None
 Router scoped : None
 Uses frequency selection
S Input Last Selection Point QL Pri Status
== =====
1 GigabitEthernet1/0/0/6 1/0/CPU0 SPA_RXMUX 1 PRC 50 Available

Selection point: T4-SEL-C (2 inputs, 1 selected)
 Last programmed 00:09:23 ago, and selection made 00:07:31 ago
 Next selection points
 SPA scoped : None
 Node scoped : None
 Chassis scoped : None
 Router scoped : None
 Uses frequency selection
 Used for local clock interface output
S Input Last Selection Point QL Pri Status
== =====
1 Sync3 [1/RSP0/CPU0] 1/RSP0/CPU0 T0-SEL-B 1 PRC 25 Locked
 GigabitEthernet1/0/0/6 1/RSP0/CPU0 T4-SEL-A 1 PRC 50 Available

Selection point: CHASSIS-TOD-SEL (3 inputs, 1 selected)
 Last programmed 00:09:23 ago, and selection made 00:09:23 ago
 Next selection points
 SPA scoped : None
 Node scoped : None
 Chassis scoped : None
 Router scoped : None
 Uses time-of-day selection
S Input Last Selection Point Pri Time Status
== =====
1 Sync3 [1/RSP0/CPU0] n/a 15 Yes Available
 Sync3 [1/RSP0/CPU0] 1/RSP0/CPU0 T0-SEL-B 1 15 Yes Available
 PTP [1/RSP0/CPU0] n/a 100 Yes Available

```



# show frequency synchronization selection back-trace

To display the path that was followed by the clock source that is being used to drive a particular interface use the **show frequency synchronization selection back-trace** command in EXEC mode.

**show frequency synchronization selection back-trace** {**clock-interface sync** *port-nu* | **interface** *type interface-path-id* | **ptp location** *node-id*}

Syntax Description	
<b>clock-interface sync</b> <i>port- nu</i>	Displays the path to the specified clock interface.
<b>interface</b> <i>type interface-path-id</i>	Displays the path to the specified interface.
<b>ptp location</b> <i>node-id</i>	Displays the path to the specified PTP clock location.

**Command Default** None

**Command Modes** EXEC

Command History	Release	Modification
	Release 4.0.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **show frequency synchronization selection back-trace** command displays the trace from the specified target interface, back to the clock source being used to drive it. The display includes the selection points that are being hit along the way.

Task ID	Task ID	Operation
	ethernet-services	read

This example shows sample output from the **show frequency synchronization selection back-trace** command:

```
RP/0/RSP0/CPU0:router# show frequency synchronization selection back-trace interface GigabitEthernet0/2/0/0
```

```
Selected Source: GigabitEthernet0/3/0/0
Selection Points:
 0/2/CPU0 LC_TX_SELECT 1
 0/RSP0/CPU0 T0_SEL_B 1
 0/RSP0/CPU0 T4_SEL_A 1
 0/3/CPU0 ETH_RXMUX 1
 0/3/CPU0 EZ_RX_0_9 1
```

# show frequency synchronization selection forward-trace

To display the path that was recovered from a particular interface, use the **show frequency synchronization selection forward-trace**

**show frequency synchronization selection forward-trace** {**clock-interface sync** *port-nu* | **interface type** *interface-path-id* | **ptp location** *node-id*}

Syntax Description		
<b>clock-interface sync</b> <i>port-nu</i>	Displays the path to the specified clock interface.	
<b>interface type</b> <i>interface-path-id</i>	Displays the path to the specified interface.	
<b>ptp location</b> <i>node-id</i>	Displays the path to the specified PTP clock location.	

**Command Default** None

**Command Modes** EXEC

Command History	Release	Modification
	Release 4.0.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **show frequency synchronization selection forward-trace** command displays the trace from the specified interface, out to all selection points that receive the clock from the interface, and from any interfaces that are potentially being driven by this clock source.

Task ID	Task ID	Operation
	ethernet-services	read

This example shows sample output from the **show frequency synchronization selection forward-trace** command:

```
RP/0/RSP0/CPU0:router# show frequency synchronization selection forward-trace interface
GigabitEthernet0/2/0/0

0/2/CPU0 EZ_RX_0_9
 0/2/CPU0 ETH_RXMUX
 0/RSP0/CPU0 T4_SEL_A
 0/RSP0/CPU0 T0_SEL_B
 0/RSP0/CPU0 CHASSIS_TOD_SEL
 0/RSP0/CPU0 T4_SEL_C
 Sync0 [0/0/CPU0]
 Sync1 [0/0/CPU0]
```

```
0/2/CPU0 LC_TX_SELECT
 GigabitEthernet 0/2/0/3

0/3/CPU0 LC_TX_SELECT
 GigabitEthernet 0/3/0/0
 GigabitEthernet 0/3/0/1

0/RSP0/CPU0 T4_SEL_A
 0/RSP1/CPU0 T0_SEL_B
 0/RSP1/CPU0 CHASSIS_TOD_SEL

 0/RSP1/CPU0 T4_SEL_C
0/2/CPU0 LC_TX_SELECT
0/3/CPU0 LC_TX_SELECT
```

# ssm disable

To disable Synchronization Status Messaging (SSM) on an interface, use the **ssm disable** command in the appropriate SyncE configuration mode. To return SSM to the default value of enabled, use the **no** form of this command.

**ssm disable**  
**no ssm disable**

<b>Command Default</b>	Enabled				
<b>Command Modes</b>	Interface SyncE configuration				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 6.1.2</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 6.1.2	This command was introduced.
Release	Modification				
Release 6.1.2	This command was introduced.				

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

For SyncE interfaces, the **ssm disable** command disables sending ESMC packets, and ignores any received ESMC packets.

The received QL value that is used if SSM is disabled depends on the option:

- Option 1: DNU
- Option 2: STU



**Note** If a clock interface does not support SSM, you are advised to disable SSM on the clock interface. This ensures that the clock interface output is squelched if the output QL from the clock interface would otherwise be DNU.

Task ID	Task ID	Operations
	ethernet-services	execute

## Examples

The following example shows how to disable SSM on an interface:

```
RP/0/0RP0/CPU0:router:hostname# config
RP/0/0RP0/CPU0:router:hostname(config)# interface gigabitethernet 0/1/0/1
RP/0/0RP0/CPU0:router:hostname(config-if)# SyncE
RP/0/0RP0/CPU0:router:hostname(config-if-freqsync)# ssm disable
RP/0/0RP0/CPU0:router:hostname(config-if-freqsync)# commit
```

# time-of-day-priority

To control the order for which sources are selected for time-of-day (ToD), use the **time-of-day-priority** command in the appropriate SyncE configuration mode. To revert to the default time-of-day priority, use the **no** form of this command.

**time-of-day-priority** *priority*  
**no time-of-day-priority**

<b>Syntax Description</b>	<i>priority</i> Priority that is used for SyncE as the source for the ToD. Values can range from 1 (highest priority) to 254 (lowest priority).				
<b>Command Default</b>	The default priority is 100.				
<b>Command Modes</b>	Interface SyncE				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 6.1.2</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 6.1.2	This command was introduced.
Release	Modification				
Release 6.1.2	This command was introduced.				
<b>Usage Guidelines</b>	<p>To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.</p> <p>Use the <b>time-of-day-priority</b> to prioritize between different sources of the ToD source.</p>				
<b>Task ID</b>	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operation</th> </tr> </thead> <tbody> <tr> <td>ethernet-services</td> <td>read, write</td> </tr> </tbody> </table>	Task ID	Operation	ethernet-services	read, write
Task ID	Operation				
ethernet-services	read, write				

This example shows how to configure the ToD priority for SyncE:

```
RP/0/0RP0/CPU0:router:hostname(config)# interface Gig 0/1/0/0
RP/0/0RP0/CPU0:router:hostname(config-if)# SyncE
RP/0/0RP0/CPU0:router:hostname(config-if-freqsync)# time-of-day-priority 200
```

## wait-to-restore

To configure the wait-to-restore time for SyncE on an interface, use the **wait-to-restore** command in the appropriate SyncE configuration mode. To return the wait-to-restore time to the default value, use the **no** form of this command.

**wait-to-restore** *minutes*  
**no wait-to-restore** *minutes*

<b>Syntax Description</b>	<i>minutes</i> The delay time (in minutes) between when an interface comes up and when it is used for synchronization. The range is 0 to 12.
---------------------------	----------------------------------------------------------------------------------------------------------------------------------------------

<b>Command Default</b>	There is a 5-minute delay for SyncE after an interface comes up.
------------------------	------------------------------------------------------------------

<b>Command Modes</b>	Interface SyncE (config-if-freqsync)
----------------------	--------------------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 6.1.2	This command was introduced.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

The wait-to-restore time is in minutes. When the configuration is changed, it does not affect any timers that are currently running. Any currently running wait-to-restore timers can be cleared using the **clear SyncE wait-to-restore** command.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	ethernet-services	execute

### Examples

The following example shows how to configure the wait-to-restore time for SyncE on an interface:

```
RP/0/0RP0/CPU0:router:hostname# config
RP/0/0RP0/CPU0:router:hostname(config)# interface gigabitethernet 0/1/0/1
RP/0/0RP0/CPU0:router:hostname(config-if)# SyncE
RP/0/0RP0/CPU0:router:hostname(config-if-freqsync)# wait-to-restore 0
RP/0/0RP0/CPU0:router:hostname(config-if-freqsync)# selection input
RP/0/0RP0/CPU0:router:hostname(config-sonet-freqsync)# commit
```

### Related Topics

[clear SyncE wait-to-restore](#), on page 289



## Hardware Redundancy and Node Administration Commands

---

This module describes the commands used to manage the hardware redundancy, power, and administrative status of the nodes on a router running Cisco IOS XR software.

- [clear canbus](#), on page 325
- [clear plugin slot counts](#), on page 326
- [environment altitude](#), on page 327
- [hw-module high-bandwidth](#), on page 328
- [hw-module location breakout](#), on page 329
- [hw-module location bay port port-mode](#), on page 331
- [hw-module location reload](#), on page 332
- [hw-module location slice power-down](#), on page 334
- [hw-module power location](#), on page 335
- [hw-module power disable](#), on page 337
- [hw-module power saving](#), on page 339
- [hw-module processor location mode](#), on page 340
- [hw-module profile itcam](#), on page 342
- [hw-module port-control license](#), on page 344
- [hw-module port-control non-combo-mode](#), on page 345
- [hw-module reset auto](#), on page 346
- [hw-module subslot reload](#), on page 347
- [isolation enable](#), on page 348
- [isolation multiple](#), on page 349
- [led mode](#), on page 350
- [power single-feed location](#), on page 352
- [redundancy switchover](#), on page 354
- [show apm psa status](#), on page 356
- [show apm psm status](#), on page 358
- [show canbus](#), on page 359
- [show dsc](#), on page 361
- [show environment](#), on page 362
- [show fpd package](#), on page 367
- [show hw-module fpd](#), on page 370

- [show hw-module subslot brief](#), on page 373
- [show hw-module subslot config](#), on page 375
- [show hw-module subslot counters](#), on page 378
- [show hw-module subslot errors](#), on page 381
- [show hw-module subslot plim-subblock](#), on page 384
- [show hw-module subslot registers](#), on page 386
- [show hw-module subslot status](#), on page 389
- [show inventory](#), on page 391
- [show led](#), on page 394
- [show operational](#), on page 396
- [show platform](#), on page 399
- [show platform](#), on page 401
- [show platform slices](#), on page 403
- [show plugin slot counts](#), on page 404
- [show redundancy](#), on page 406
- [show version](#), on page 408
- [upgrade hw-module fpd](#), on page 411



# clear canbus

To clear the counters used for statistics regarding the CAN bus, use the **clear canbus** command in administration EXEC mode.

```
clear canbus {client-stats | controller-stats | server-stats} location {all|node-id}
```

Syntax Description		
<b>client-stats</b>		Clears CAN bus client statistics.
<b>controller-stats</b>		Clears CAN bus controller statistics.
<b>server-stats</b>		Clears CAN bus server statistics.
<b>location</b> {all   <i>node-id</i> }		Clears the CAN bus statistics for a specific node or all nodes.

**Command Default** None

**Command Modes** Administration EXEC

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operation
	sysmgr	read

The following example illustrates how to use the **clear canbus** command:

```
RP/0/RSP0/CPU0:router(admin)# clear canbus server-stats location all
```

## clear plugin slot counts

To clear the running counts of the backplane connector slot plugins, use the **clear plugin slot counts** command in administration EXEC mode.

**clear plugin slot counts** **location** *node-id*

<b>Syntax Description</b>	<b>location</b> <i>node-id</i> Clears plugin slot counts on the designated node. The <i>node-id</i> argument is expressed in the <i>rack/slot/module</i> notation.
---------------------------	--------------------------------------------------------------------------------------------------------------------------------------------------------------------

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Administration EXEC
----------------------	---------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.9.1	This command was introduced.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

The **clear plugin slot counts** command can be used only if the revised backplane ID card (BPID-02) is installed. If the BPID-02 card is not installed, the following error message is displayed:

```
0/1/CPU0 slot counts 'current' ...Response error: 'ENVMON' detected the 'warning' condition
'Hardware not available'
```

<b>Task ID</b>	<b>Task</b>	<b>Operation</b>
		sysmgr execute

The following example illustrates how to use the **clear plugin slot counts** command:

```
RP/0/RSP0/CPU0:router(admin)# clear plugin slot counts location 0/FT1/SP
Fri Jan 15 10:15:55.388 pst

0/FT1/SP slot counts 'current' ... cleared
RP/0/RSP0/CPU0:router(admin)# show plugin slot counts location 0/FT1/SP
Fri Jan 15 10:16:15.503 pst

Backplane connector slot plugin counters

Current Cumulative
0/FT1/SP 0 14
```

# environment altitude

To specify the chassis altitude, so the system can adjust the fan speed to compensate for lower cooling capability at higher altitudes, use the environment altitude command in administration configuration mode. To remove the altitude setting, use the no form of this command.

**environment altitude** *altitude* **rack** *rack-no*  
**no environment altitude** *altitude* **rack** *rack-no*

Syntax Description		
	<i>altitude</i>	Chassis location altitude in meters. Values can range from 0 to 4000.
	<b>rack</b> <i>rack-no</i>	Specifies the rack number of the chassis.

**Command Default** 1800 meters

**Command Modes** Administration configuration

Command History	Release	Modification
	Release 4.2.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operation
	root-system	read, write

This example specifies that the chassis is located at sea level:

```
RP/0/RSP0/CPU0:router(admin-config)#environment altitude 0 rack 0
```

## hw-module high-bandwidth

To upgrade the RSP3 Lite card from 80Gig per line card capacity to 220Gig per Line card capacity (for Enhanced ethernet linecards), use the **hw-module high-bandwidth** command in the appropriate mode. To restore the default capacity, use the **no** form of the command.

**hw-module high-bandwidth**  
**no hw-module high-bandwidth**

<b>Syntax Description</b>	This command has no keywords or arguments.
---------------------------	--------------------------------------------

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Admin config
----------------------	--------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 5.3.0	This command was introduced.

<b>Usage Guidelines</b>	This command can be used only after applying the appropriate license to RSPLite3. Traditional or smart licensing can be used.
-------------------------	-------------------------------------------------------------------------------------------------------------------------------

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	sysmgr	execute

### Example

This example shows how to use the **hw-module high-bandwidth** command:

```
RP/0/RSP0/CPU0:router (config) # hw-module high-bandwidth
```

## hw-module location breakout

To configure the breakout option for a specified interface, use the **hw-module location breakout** command in the appropriate mode. To delete the breakout option, use the **no** form of the command.

**hw-module location** *node-id* [ **preconfigure** ] **bay** *bay-number* **port** *port-number* **breakout** *interface*  
**no hw-module location** *node-id* [ **preconfigure** ] **bay** *bay-number* **port** *port-number* **breakout** *interface*

Syntax Description	location <i>node-id</i>	Interface details.
	<b>preconfigure</b>	(Optional) Enables the user to preconfigure breakout on an empty slot.
	<b>bay</b> <i>bay-number</i>	Bay number of the device (Upper, left, right, lower).
	<b>port</b> <i>port-number</i>	CPAK port.
	<b>breakout</b> <i>interface</i>	Enables breakout. The modes supported are 10x10 GE.

**Command Default** None

**Command Modes** Global config

Command History	Release	Modification
	Release 5.3.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

SR10 CPAK can operate in the 10x10GE mode.

Use the **show ipv4 interfaces brief** command to get the details of the breakout interfaces:

```
show ipv4 interfaces brief | include Ten
TenGigE0/0/0/2/0 unassigned Shutdown Down
TenGigE0/0/0/2/1 unassigned Shutdown Down
TenGigE0/0/0/2/2 unassigned Shutdown Down
TenGigE0/0/0/2/3 unassigned Shutdown Down
TenGigE0/0/0/2/4 unassigned Shutdown Down
TenGigE0/0/0/2/5 unassigned Shutdown Down
TenGigE0/0/0/2/6 unassigned Shutdown Down
TenGigE0/0/0/2/7 unassigned Shutdown Down
TenGigE0/0/0/2/8 unassigned Shutdown Down
TenGigE0/0/0/2/9 unassigned Shutdown Down
```

Task ID	Task ID	Operation
	sysmgr	read

### Example

This example shows how to use the **hw-module location breakout** command:

```
RP/0/RSP0/CPU0:router (config) # hw-module location 0/0/CPU0 bay 0 port 2 breakout 10xTenGigE
```

# hw-module location bay port port-mode

Use this command to configure an MPA with optics in 200G mode.



**Note** Staircase FEC is supported only in 100gig mode.

**hw-module location** *location* **bay** *bay-number* **port** *port-number* **port-mode** *port-mode*

Syntax Description	Parameter	Description
	<b>location</b> <i>location</i>	Indicates the location of the MPA, that is the line card ID.
	<b>bay</b> <i>bay-number</i>	Indicates the bay number of the line card.
	<b>port</b> <i>port-number</i>	Indicates the port number of the optical-module or optic. You can only configure port number value as 0.
	<b>port-mode</b> <i>port-mode</i>	Configures the 200G port mode. Port mode can be: <ul style="list-style-type: none"> <li>• <i>2xHundredGigE-16QAM</i>: Configures 200G 16QAM port mode for EP.</li> <li>• <i>2xHundredGigE-8QAM</i>: Configures 200G 8QAM port mode for EP.</li> </ul> <p>A higher QAM value leads to higher data transmission rates, but increases the risk of errors that leads to re-sends.</p>

**Command Default** If this command is not configured, the MPA and optics work in 100G mode.

**Command Modes** Global configuration mode

Command History	Release	Modification
	Release 7.0.1	This command was introduced.

**Usage Guidelines** You can only configure this command in port 0 of a router.

Task ID	Task ID	Operations
	root-system	read, write
	root-lr	read, write

This example shows how to configure 200G for an optical module of a router.

```
Router(config)# hw-module location 0/2/CPU0 bay 0 port 0 port-mode 2xHundredGigE-16QAM
```

## hw-module location reload

To reset the power-cycle or reload the hardware for a specific node, or for all nodes installed in the router, use the **hw-module location reload** command in EXEC or administration EXEC mode.

**hw-module location** *node-id* **reload** [*path* | **warm**]

### Syntax Description

*node-id* Node whose hardware attributes you want to configure. The *node-id* is expressed in the *rack/slot/module* notation.

**Note** Enter the **show platform** command to see the location of all nodes installed in the router.

*path* TFTP or disk path to the image you want to download onto the specific node or nodes.

**warm** Specifies a warm reload of the node.

### Command Default

No default behavior or values

### Command Modes

EXEC

Administration EXEC

### Command History

#### Release

#### Modification

Release 3.7.2

This command was introduced.

Release 3.9.0

No modification.

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

To reset a specific node, use the **hw-module location reload** command in EXEC mode.

To reset a specific node or all nodes, use the **hw-module location reload** command in administration EXEC mode.



#### Note

Before reloading nodes, we recommend using the **cfs check** command to check the sanity of the configuration file system and attempt to recover from internal inconsistencies.

### Task ID

#### Task Operations ID

root-lr execute (in EXEC mode)

sysmgr execute (in EXEC mode and administration EXEC mode)



This example shows how to reset the hardware on a specific node from EXEC mode:

```
RP/0/RSP0/CPU0:router # hw-module location 0/1/CPU0 reload
```

This example shows how to reset the hardware on a specific node from administration EXEC mode:

```
RP/0/RSP0/CPU0:router# admin
RP/0/RSP0/CPU0:router(admin)# hw-module location 0/3/CPU0 reload
```

This example shows how to reset the hardware on a specific fabric card node:

```
RP/0/RSP0/CPU0: router (admin) # hw module location 0/fc0/SP reload
```

# hw-module location slice power-down

To power off a specified slice, use the **hw-module location slice power-down** command in the Global Configuration mode. To power on a slice, use the **no** form of the command.

**hw-module location** *node-id* *slice number* **power-down**

<b>Syntax Description</b>	<b>location</b> <i>node-id</i> Specifies the line card node location.
	<b>slice number</b> Specifies the slice number that should be power off.

**Command Default** All slices are power on.

**Command Modes** Global Configuration mode

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.0.1	This command was introduced.

**Usage Guidelines** This feature is supported on the Cisco ASR 9000 4th Generation Ethernet line cards.



**Note** It is necessary to reload the line card after executing the **hw-module location slice power-down** command.

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	sysmgr	read, write

## Example

This example shows how to power down slice 3, and 7 of the line card at node 0:

```
RP/0/RSP0/CPU0:router (config) # hw-module location 0/0/CPU0 slice 3 power-down
RP/0/RSP0/CPU0:router (config) # hw-module location 0/0/CPU0 slice 7 power-down
RP/0/RSP0/CPU0:router (config) # commit
RP/0/RSP0/CPU0:router (config) # end
RP/0/RSP0/CPU0:router # admin
RP/0/RSP0/CPU0:router (sysadmin) # hw-module location 0/0/CPU0 reload
```

# hw-module power location

To power on a specified line card, use the **hw-module power location** command in administration configuration mode.

**hw-module power** [**override**] **location** *node-id*

Syntax Description	
<b>location</b> <i>node-id</i>	Identifies the node to power on. The <i>node-id</i> argument is expressed in the <i>rack/slot/module</i> notation.
<b>override</b>	Allows the card to be powered up even though there is no power consumption value programmed on the manufacturing EEPROM of the card.

**Command Default** Power is on for all nodes.

**Command Modes** Administration configuration

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **hw-module power location** command is available for line cards only; it is not available for route switch processor (RSP) cards.

Use the **hw-module power disable location** command to power off a line card.

Use the **show platform** command to view a summary of the nodes in the router, including status information.

By default, cards that do not have a power consumption value programmed on the manufacturing EEPROM cannot be powered up or booted. To correct an issue with such cards, that possibly is because of an incorrectly programmed EEPROM, you can use the **hw-module power** command with the **override** option.

Task ID	Task ID	Operations
	root-system	read, write
	root-lr	read, write

The following example shows how to power on a line card:

```
RP/0/RSP0/CPU0:router# admin
RP/0/RSP0/CPU0:router(admin)# configure
```

```
RP/0/RSP0/CPU0:router(admin-config)# hw-module power location 0/1/0
```

The following example shows how to disable the power-on feature for a line card:

```
RP/0/RSP0/CPU0:router# admin
RP/0/RSP0/CPU0:router(admin)# configure
RP/0/RSP0/CPU0:router(admin-config)# hw-module power disable location 0/SM3/SP
```

# hw-module power disable

To disable the node power-on feature on a specific line card, use the **hw-module power disable** command in administration configuration mode. To reenable the node power-on feature on a line card, use the **no** form of this command.

```
hw-module power [override] disable location node-id
no hw-module power [override] disable location node-id
```

<b>Syntax Description</b>	<b>override</b>	Specifies to power up the card regardless of the available power budget.
	<b>location</b> <i>node-id</i>	Identifies the node whose power-on feature you want to disable. The <i>node-id</i> argument is expressed in the <i>rack/slot/module</i> notation.

**Command Default** Power is on for all nodes.

**Command Modes** Administration configuration

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **show platform** command to view a summary of the nodes in the router, including status information.

The **hw-module power disable** command is available for line cards only; it is not available for RP cards.

Cards that do not have a power consumption value programmed on the manufacturing EEPROM do not power up or boot. Use the **override** option with the **hw-module power disable** command to power up the card to correct any issue about an incorrectly programmed manufacturing EEPROM. In any event, the system is not allowed to go over the maximum power budget for the system.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	sysmgr	read, write
	root-lr	read, write

The following example shows how to disable the node power-on feature on a line card:

```
RP/0/RSP0/CPU0:router# admin
RP/0/RSP0/CPU0:router(admin)# configure
```

```
RP/0/RSP0/CPU0:router(admin-config)# hw-module power disable location 0/0/CPU0
```

The following example shows how to disable the node power-on feature on a fabric card:

```
RP/0/RSP0/CPU0:router (admin-config) # hw-module power disable location 0/fc0/SP
```

# hw-module power saving

To configure the power saving mode for a specified slice, use the **hw-module power saving** command in the appropriate mode. To delete the power saving option, use the **no** form of the command.

**hw-module power saving location** *location slice number*  
**no hw-module power saving location** *location slice number*

## Syntax Description

**location** *location* The interface details.

**slice number** The slice number on which power save mode needs to be enabled. Each slice has two physical ports. Slice 1, 2 ,3 can be configured to the power saving mode. Power save option is not applicable for slice 0.

## Command Default

None

## Command Modes

Admin config

## Command History

Release	Modification
Release 5.3.0	This command was introduced.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Once a slice is configured in the power saving mode, the interfaces will be deleted and hence all traffic passing through the interfaces will be dropped.

## Task ID

Task ID	Operation
sysmgr	read, write

## Example

This example shows how to use the **hw-module power saving** command:

```
RP/0/RSP0/CPU0:router (admin-config) # hw-module power saving location 0/1/cpu0 slice 3
```

# hw-module processor location mode

To configure processor array clusters setting for an ASR 9900 Series 16-Port 100 Gigabit Ethernet Service Edge Line Card, use the **hw-module processor location mode** command in global configuration mode.

**hw-module processor location *node-id* mode {mode-default | mode-full}**

The **no** format of the above command is not available. To move back to default mode, use the **hw-module processor location *node-id* mode mode-default** command form.

## Syntax Description

<b>location <i>node-id</i></b>	Specifies the node whose hardware attributes you want to configure. (The <i>node-id</i> is expressed in the rack/slot/module notation, such as <b>0/8/CPU0</b> ).
<b>mode-default</b>	Specifies that processor array clusters are used as defined in the (default) line card profile setting.
<b>mode-full</b>	Specifies that all processor array clusters are fully utilized.

## Command Default

The processor array clusters are used as per the line card profile setting (the mode is set to **mode-default**).

## Command Modes

Global configuration

## Command History

Release	Modification
Release 6.6.2	This command was introduced.

## Usage Guidelines

- The **hw-module processor location mode** command is only supported on the Cisco ASR 9900 Series 16-Port 100 Gigabit Ethernet Service Edge Line Card (whose part number is A99-16X100GE-X-SE).
- The command is only applicable for IOS XR 64 Bit version on ASR 9000 Enhanced XR (eXR).
- To change the cluster setting to **mode-full**, use the **hw-module processor location *node-id* mode mode-full** command form.
- To change the cluster setting from **mode-full** to **mode-default**, use the **hw-module processor location *node-id* mode mode-default** command form, and not the **no** form of the command.
- You must reload the line card XR VM after setting the new mode. You cannot enable it when the line card is in use. Any traffic on the line card is impacted until the line card becomes operational with the new mode.

## Example

This example shows how to set the clusters' usage setting on the A99-16X100GE-X-SE line card to **mode-full**:

```
RP/0/RP1/CPU0:ios(config)# hw-module processor location 0/8/CPU0 mode mode-full
RP/0/RP1/CPU0:ios(config)# commit
RP/0/RP1/CPU0:ios(config)# exit
RP/0/RP1/CPU0:ios# reload location 0/8/CPU0
```



```
Proceed with reload? [confirm]
Reloading node 0/8/CPU0
```

This example shows how to set the clusters' usage setting on the A99-16X100GE-X-SE line card from **mode-full** to **mode-default**:

```
RP/0/RP1/CPU0:ios(config)# hw-module processor location 0/8/CPU0 mode mode-default
RP/0/RP1/CPU0:ios(config)# commit
RP/0/RP1/CPU0:ios(config)# exit
RP/0/RP1/CPU0:ios# reload location 0/8/CPU0
Proceed with reload? [confirm]
Reloading node 0/8/CPU0
```

**Related Commands**

Command	Description
<b>show platform</b>	Displays information and status for each node in the system.

# hw-module profile itcam

To configure internal tcam profile partition for line cards on a Global Configuration level, use the **hw-module profile itcam** command in the Admin Configuration mode.

**hw-module profile itcam** {**to-profile-se1** | **to-default**} **location** *location*

*Table 25: Syntax Description*

<b>to-profile-se1</b>	Sets the internal tcam partitions for service edge, that is, L2 limit is increased to 4K entries in the L2 table and V6 limit is increased to 3.5K entries in the V6 table by adjusting 24K V4 entries in the V4 table.
<b>to-default</b>	Sets the default internal tcam partitions where L2 limit is 1K in the L2 table, V4 limit is 24K in the V4 table, and V6 limit is 1.75K entries in the V6 table).
<b>location</b> <i>location</i>	Sets the location.

## Command Mode

Admin Configuration mode on 32-bit IOS-XR

Global Configuration mode on 64-bit IOS-XR

## Command History

Release	Modification
Release 6.6.2	This command was introduced.

## Usage Guidelines

This profile configuration can be applied only on A99-12X100GE or A99-4X100GE line cards. To enable this profile configuration, you have to reload the linecards after the configuration. To return to the default profile mode use the **to-default** option.

Task ID	Operation
root-lr	read, write
system	read, write

## Example

This example shows how to configure **hw-module profile itcam to-profile-se1** command:

```
Router# config
Router(config)#hw-module profile itcam to-profile-se1 location 0/0/CPU0
Sun Mar 3 07:44:23.066 UTC
In order to activate this new internal tcam partition profile, you must manually reload the
line card.
Router(config)#
```

This example shows how to configure **hw-module profile itcam to-default** command:

```
Router# config
Router(config)#hw-module profile itcam to-default location 0/0/CPU0
Sun Mar 3 07:45:22.198 UTC
In order to activate this new internal tcam partition profile, you must manually reload the
line card.
Router(config)#
```

**Related Commands**

Command	Description
<b>show prm server tcam summary all all detail all location 0/0/CPU0</b>	This command output shows modified tcam entries with increased limits for L2 and V6 entries.

## hw-module port-control license

To request (and apply) license for (A9K-4T16GE-TR and A9K-4T16GE-SE) combo card , use the **hw-module port-control license** command in the appropriate mode. To remove the applied license, use the **no** form of the command.

**hw-module port-control license location** *node-id*  
**no hw-module port-control license location** *node-id*

Syntax Description	location <i>node-id</i>
	Interface details.

Command Default	None
-----------------	------

Command Modes	Global configuration
---------------	----------------------

Command History	Release	Modification
	Release 5.3.0	This command was introduced.

Usage Guidelines	<p>The <b>hw-module port-control license</b> command is used to apply the requested license on the combo card. The granted license is permanent , unless the user wants to remove license on this card and use it on some other card. LC reload is mandatory for the license to take effect. When the LC comes up after the reload, the licenses are installed and can be verified using the <b>show license entitlement</b> command.</p>
------------------	-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

If the user wants to use the combo license on some other line-card instead of the current one, then the license has to be removed. The **no hw-module port-control license** command removes the applied license.

Task ID	Task ID	Operation
	sysmgr	execute

### Example

This example shows how to use the **hw-module port-control license** command:

```
RP/0/RSP0/CPU0:router (config) # hw-module port-control license location 0/1/CPU0
```

# hw-module port-control non-combo-mode

To use all the four Tengig ports, instead of the Gigabit ethernet ports, use the **hw-module port-control non-combo-mode** command in the appropriate mode. To remove the non-combo configuration, use the **no** form of the command.

**hw-module port-control non-combo-mode location** *linecard-slot*  
**no hw-module port-control non-combo-mode location** *linecard-slot*

<b>Syntax Description</b>	<b>location</b> <i>linecard-slot</i> The interface and slot details.
---------------------------	----------------------------------------------------------------------

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Global configuration
----------------------	----------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 5.3.0	This command was introduced.

<b>Usage Guidelines</b>	On the (A9K-4T16GE-TR and A9K-4T16GE-SE ) combo card, the customer can either use 16Gigabit Ethernet + 2Tengig or 4Tengig ports. This option is when the customer does not have the Wildchild combo license. If the License is installed, all the ports will be enabled. In case, the license is not available and the customer wants to use all the 4 Tengig ports instead of the Gigabit ethernet ports, then , this command needs to be used. This is the non-combo mode.
-------------------------	------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------



<b>Note</b>	LC reload is mandatory for the mode to take effect.
-------------	-----------------------------------------------------

If the **hw-module port-control non-combo-mode** command is not configured, the line card will operate in the default mode. In the default mode, the two Tengig ports which are enabled are - 0/*/0/16 and 0/*/0/17.

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	sysmgr	execute

## Example

This example shows how to use the **hw-module port-control non-combo-mode** command:

```
RP/0/RSP0/CPU0:router (config) # hw-module port-control non-combo-mode location 0/1/CPU0
```

## hw-module reset auto

To reset a specific node, use the **hw-module reset auto** command in administration configuration mode. To disable the reset feature on a specific node, use the **no** form of this command.

```
hw-module reset auto [disable] location node-id
no hw-module reset auto [disable] location node-id
```

### Syntax Description

<b>disable</b>	Disables the node reset feature on the specified node.
<b>location</b> <i>node-id</i>	Identifies the node you want to reload. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.

### Command Default

The node reset feature is enabled for all nodes.

### Command Modes

Administration configuration

### Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	No modification.

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **hw-module reset auto** command is used to reload Cisco IOS XR software on a specific node. The node reloads with the current running configuration and active software set for that node.

### Task ID

Task ID	Operations
root-system	read, write
root-lr	read, write

The following example shows how to reload a node:

```
RP/0/RSP0/CPU0:router# admin
RP/0/RSP0/CPU0:router(admin)# configure
RP/0/RSP0/CPU0:router(admin-config)# hw-module reset auto location 0/2/CPU0

RP/0/RP0/CPU0:router# RP/0/RP0/CPU0:Apr 2 22:04:43.659 : shelfmgr[294]:
%S HELFMGR-3-USER_RESET : Node 0/2/CPU0 is reset due to user reload request
```

# hw-module subslot reload

To reload Cisco IOS XR software on a specific subslot, use the **hw-module subslot reload** command in EXEC mode.

**hw-module subslot *subslot-id* reload**

<b>Syntax Description</b>	<i>subslot-id</i> Specifies the subslot to be restarted. The <i>subslot-id</i> argument is entered in the <i>rack/slot/subslot</i> notation.				
<b>Command Default</b>	No default behavior or values				
<b>Command Modes</b>	EXEC				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 3.9.0</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 3.9.0	This command was introduced.
Release	Modification				
Release 3.9.0	This command was introduced.				
<b>Usage Guidelines</b>	<p>To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.</p> <p>This command reloads Cisco IOS XR software on the specified shared port adapter (SPA) and restarts the SPA interfaces. The SPA reloads with the current running configuration and active software set for the SPA.</p>				
<b>Task ID</b>	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operations</th> </tr> </thead> <tbody> <tr> <td>root-lr</td> <td>read, write</td> </tr> </tbody> </table>	Task ID	Operations	root-lr	read, write
Task ID	Operations				
root-lr	read, write				

The following example shows how to restart the SPA in slot 2, subslot 1:

```
RP/0/RSP0/CPU0:router# hw-module subslot 0/2/1 reload
```

## isolation enable

To configure the route processor to collect debug information like a process coredump from a failed route processor, when NSR triggers failover, use the **isolation enable** command in global configuration mode. To disable RP isolation during failover, use the **no** form of this command.

**isolation enable**  
**no isolation enable**

<b>Syntax Description</b>	This command has no keywords or arguments.				
<b>Command Default</b>	If the <b>isolation enable</b> is not configured, the <b>nsr process-failures switchover</b> command immediately restarts the active RP during NSR failover and hence the active RP cannot collect the required debug information to identify the cause of the failure.				
<b>Command Modes</b>	Global configuration				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 4.1.0</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 4.1.0	This command was introduced.
Release	Modification				
Release 4.1.0	This command was introduced.				

**Usage Guidelines**

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

During RP failover, the standby RP takes over as the active RP immediately without a protocol flap and NSR restarts the active RP. This switchover time is less than the timeout for the protocol to flap. Because the active RP is restarted immediately, it is not possible to get debug details to identify the cause of the failure.

The **isolation enable** command enables NSR to trigger RP switchover without protocol flap and collect the required debug information to identify the cause of the failure. The RP isolation feature keeps the active RP in an isolated state wherein it continues to operate even after the switchover. Using the **isolation enable** command you can enable RP isolation, thereby providing sufficient time for the failed RP to collect the necessary debug information like a process coredump before restarting a failed route processor.

Task ID	Task ID	Operation
	transport	read, write

This example shows how to configure the route processor to collect debug information when NSR triggers failover:

```
RP/0/RSP0/CPU0:router# config
RP/0/RSP0/CPU0:router(config)# isolation enable
RP/0/RSP0/CPU0:router(config)#
```



# isolation multiple

To configure the route processor to collect debug information of multiple protocols from a failed route processor when multiple protocols trigger NSR, which in turn triggers failover, use the **isolation multiple** command in the global configuration mode. To disable RP isolation during failover, caused by multiple protocols, use the **no** form of this command.

**isolation multiple**  
**no isolation multiple**

<b>Syntax Description</b>	This command has no keywords or arguments.				
<b>Command Default</b>	If the <b>isolation multiple</b> command is not configured and the failover is triggered by multiple protocols, the <b>isolation enable</b> command enables a failed RP to collect the required debug information of only the first failed protocol.				
<b>Command Modes</b>	Global configuration				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 4.2.1</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 4.2.1	This command was introduced.
Release	Modification				
Release 4.2.1	This command was introduced.				
<b>Usage Guidelines</b>	<p>To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.</p> <p>During RP failover, the standby RP takes over as the active RP immediately and restarts the active RP to support NSR without a protocol flap. This switchover time is less than the timeout for the protocol to flap. Because the active RP is restarted immediately, it is not possible to get debug details to identify the cause of the failure.</p> <p>The <b>isolation enable</b> command enables NSR to trigger RP switchover without protocol flap and collect the required debug information to identify the cause of the failure.</p> <p>If multiple protocols trigger NSR, the <b>isolation enable</b> command does not enable the RP to collect the required debug information. Use the <b>isolation multiple</b> command to enable the active RP to collect debug information even if the failure is caused by multiple protocols.</p>				
<b>Task ID</b>	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operation</th> </tr> </thead> <tbody> <tr> <td>transport</td> <td>read, write</td> </tr> </tbody> </table>	Task ID	Operation	transport	read, write
Task ID	Operation				
transport	read, write				

This example shows how to configure the route processor to collect debug information when multiple protocols trigger NSR, which in turn triggers failover:

```
RP/0/RSP0/CPU0:router#config
RP/0/RSP0/CPU0:router(config)#isolation multiple
RP/0/RSP0/CPU0:router(config)#
```

# led mode

To change the message, mode or status of a router card LED display, use the **led mode** command in administration configuration mode. To revert to the default message, mode or status, use the **no** form of this command.

**led mode** {**default** | **scroll**} {**lock** | **unlock**} *message* **location** *node-id*

## Syntax Description

{**default** | **scroll**} Specifies the mode of the card LED display.

{**lock** | **unlock**} Specifies the status of the card LED display.

*message* Specifies the message to display on the card LED.

**location** *node-id* Specifies the node for which to configure the LED information. The *node-id* argument is expressed in the *rack/slot/module* notation.

## Command Default

Mode: default; status: unlocked; message: according to the state of the software

## Command Modes

Administration configuration

## Command History

Release	Modification
Release 3.8.0	This command was introduced.

## Usage Guidelines

You must be in a user group associated with a task group that includes the proper task IDs. The command reference guides include the task IDs required for each command. If you suspect user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **show led** command to display the LED settings for a card or all cards.

## Task ID

Task ID	Operation
system read, write	

This example shows how to change the message displayed on the card LED and the subsequent display in the **show led** command output:

```
RP/0/RSP0/CPU0:router# admin
RP/0/RSP0/CPU0:router(admin)# configure
RP/0/RSP0/CPU0:router(admin-config)# led mode default unlock STBY_RP location 0/rp0/cpu0
RP/0/RSP0/CPU0:router(admin-config)# end
```

Uncommitted changes found, commit them? [yes]:

```
RP/0/RSP0/CPU0:router(admin)# show led location all | i 0/RP0/CPU0
```

```
LOCATION MESSAGE MODE STATUS
=====
```

0/0/SP	IOX-RUN	DEFAULT	UNLOCKED
0/1/SP	IOX-RUN	DEFAULT	UNLOCKED
0/RP0/CPU0	STBY_RP	DEFAULT	UNLOCKED
0/RP1/CPU0	ACTV_RP	DEFAULT	UNLOCKED

## power single-feed location

To configure single-feed mode, where the system supports the operating of one or all power modules (V1 DC, V2 DC, V3 AC and V3 DC) with only one feed, without raising an error message or an alarm for any missing feeds, use the **power single-feed location** command in administration configuration mode. To disable the single-feed mode, use the **no** form of this command.

**power single-feed location** {allname}  
**no power single-feed location** {allname}

### Syntax Description

<b>all</b>	Enables single-feed mode for all the power modules.
<b>name</b>	Specifies the power module node name in the <i>Rack/PSx/My/SP</i> format. Explanation of each component of the naming notation is as follows: <ul style="list-style-type: none"> <li>• <i>Rack</i>- Chassis number of the rack. In a single-shelf system, the rack number is 0. In a multi-shelf system, the LCC rack number range is 0 to 255 and the FCC rack number range is F0 to F7.</li> <li>• <i>PSx</i>- Power Slot.</li> <li>• <i>My</i>- Power Module.</li> <li>• <i>SP</i>- Service Processor node type. This is used for fan trays, power modules and any other node that is not an RSP/RP or an LC.</li> </ul>

### Command Default

Both the power feeds are enabled.

### Command Modes

Administration Configuration

### Command History

Release	Modification
Release 5.3.0	This command was introduced.

### Usage Guidelines

- The power feed configuration is verified by the software at the boot-up time prior to generating any warning messages.
- For a V2 AC power module, configuring the single-feed mode is not possible and an error message is displayed.
- A syslog message is displayed at the boot-up time when the single-feed mode configuration is enabled. The syslog message indicates that notifications are disabled for loss of one feed of each power module.

### Task ID

Task ID	Operation
root-system	read, write

The following example enables the single power feed mode for the 0/PS2/M0/SP power module:

```
RP/0/RSP0/CPU0:router#admin
RP/0/RSP0/CPU0:router(admin)#config
RP/0/RSP0/CPU0:router(admin-config)#power single-feed location 0/PS2/M0/SP
```

# redundancy switchover

To cause the primary (active) route processor (RP) to fail over to the redundant standby RP, use the **redundancy switchover** command in

EXEC or administration EXEC

mode. To disable the forced switchover, use the **no** form of this command.

**redundancy switchover** [**location** *node-id*]  
**no redundancy switchover** [**location** *node-id*]

---

**Syntax Description**      **location** *node-id* (Optional) Specifies the primary RP on which to force a switchover. The *node-id* argument is expressed in the *rack/slot/module* notation.

---



---

**Command Default**      No default behavior or values

---



---

**Command Modes**      EXEC  
Administration EXEC

---



---

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

---



---

**Usage Guidelines**      To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **redundancy switchover** command to trigger a switchover from the primary RP to the standby RP. When the **redundancy switchover** command is issued, the running (committed) configuration is automatically saved and loaded during switchover, and the standby RP becomes the active primary RP, while the original primary RP becomes the standby RP.




---

**Note**      The **redundancy switchover** command can be used only if the standby RP is in the ready state. Use the **show redundancy** command to view the status of the RPs.

---



---

Task ID	Task ID	Operations
	root-lr	read, write

---

The following example shows partial output for a successful redundancy switchover operation:

```

RP/0/RSP0/CPU0:router# show redundancy

Redundancy information for node 0/RP0/CPU0:
=====
Node 0/RP0/CPU0 is in ACTIVE role
Partner node (0/RP1/CPU0) is in STANDBY role
Standby node in 0/RP1/CPU0 is ready

Reload and boot info

RP reloaded Tue Mar 28 09:02:26 2006: 5 hours, 41 minutes ago
Active node booted Tue Mar 28 09:02:56 2006: 5 hours, 41 minutes ago
Last switch-over Tue Mar 28 09:09:26 2006: 5 hours, 34 minutes ago
Standby node boot Tue Mar 28 09:10:37 2006: 5 hours, 33 minutes ago
Standby node last went not ready Tue Mar 28 09:25:49 2006: 5 hours, 18 minutes
go
Standby node last went ready Tue Mar 28 09:25:51 2006: 5 hours, 18 minutes ago
There has been 1 switch-over since reload
....
RP/0/RSP0/CPU0:router# redundancy switchover

Initializing DDR SDRAM...found 2048 MB
Initializing ECC on bank 0
...
Turning off data cache, using DDR for first time

Initializing NVRAM...
Testing a portion of DDR SDRAM ...done
Reading ID EEPROMs ...
Initializing SQUID ...
Initializing PCI ...

PCI0 device[1]: Vendor ID 0x10ee

Configuring MPPs ...
Configuring PCMCIA slots ...
--More--

```

If the standby RP is not in the ready state, the switchover operation is not allowed. The following example shows output for a failed redundancy switchover attempt:

```

RP/0/RSP0/CPU0:router# show redundancy

This node (0/RP0/CPU0) is in ACTIVE role
Partner node (0/RP1/CPU0) is in UNKNOWN role

RP/0/RSP0/CPU0:router# redundancy switchover

Standby card not running; failover disallowed.

```

## show apm psa status

To display the PSA status for APM, use the **show apm psa status** command in EXEC mode.

**show apm psa status location** *node-id*

<b>Syntax Description</b>	<b>location</b> <i>node-id</i> The interface details.
---------------------------	-------------------------------------------------------

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Admin EXEC
----------------------	------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 5.3.0	This command was introduced.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	sysmgr	read

### Example

This example shows how to use the **show apm psa status** command:

```
RP/0/RSP0/CPU0:router (admin) # show apm psa status location 0/0/CPU0
```

```
0/0/CPU0
```

```
PSA Client Status
```

```
DIAG ENVMON INVMGR FIA PCIE LDA \
 PRM
Registered Registered Registered Registered Registered \
Registered Registered
```

```
PSA Slice Status
```

```
Slice 0: Power On Completed 1: Power On Completed 2: Power On \
Completed 3: Power Saving Completed
DIAG Completed Completed Completed Completed \
 Completed
ENVMON Completed Completed Completed Completed \
 Completed
INVMGR Completed Completed Completed Completed \
 Completed
FIA Completed Completed Completed Completed \
 Completed
PCIE Completed Completed Completed Completed \
 Completed
```



```
LDA Completed Completed Completed \
 Completed
PRM Completed Completed Completed \
 Completed
```

## show apm psm status

To display the PSM status for APM, use the **show apm psm status** command in EXEC mode.

**show apm psa status location** *node-id*

<b>Syntax Description</b>	<b>location</b> <i>node-id</i> The interface details.
---------------------------	-------------------------------------------------------

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Admin EXEC
----------------------	------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 5.3.0	This command was introduced.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	sysmgr	read

### Example

This example shows how to use the **show apm psa status** command:

```
RP/0/RSP0/CPU0:router (admin) # show apm psm status location 0/0/CPU0
PSM Status

PSM Client Status
 ENVMON: Registered
 DIAG0: Registered
 DIAG1: Registered
 INVMGR: Registered
 0/0/CPU0 PSA: Registered

LC Status

Line Card Slice Config Status ENVMON DIAG0 \
DIAG1 INVMGR PSA
0/0/CPU0 0 On Completed Completed Completed \
Completed Completed Completed
1 On Completed Completed Completed \
Completed Completed Completed Completed Completed \
Completed Completed Completed Completed Completed \
Completed Completed Saving Completed Completed Completed \
Completed Completed Completed
```

# show canbus

To display statistics regarding the CAN bus, use the **show canbus** command in administration EXEC mode.

**show canbus** {**client-stats** | **controller-stats** | **server-stats**} **location** {**all** | *node-id*}

Syntax Description		
<b>client-stats</b>		Displays CAN bus client statistics.
<b>controller-stats</b>		Displays CAN bus controller statistics.
<b>server-stats</b>		Displays CAN bus server statistics.
<b>location</b> { <b>all</b>   <i>node-id</i> }		Displays the status of the CAN bus for a specific node or all nodes.

**Command Default** None

**Command Modes** Administration EXEC

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **show canbus** command with the **server-stats** keyword to determine if the revised backplane ID board (BPID-02) is installed in the router.

Task ID	Task ID	Operation
	sysmgr	read

## Example

The following example illustrates sample output from the **show canbus** command with the **server-stats** keyword:

```
RP/0/RSP0/CPU0:router(admin)# show canbus server-stats location all

 Slot State Partition-A Rev Partition-B Rev Active-Partition
0/0/CPU0 Online 2.01 2.02 Partition B
0/1/CPU0 Online 2.01 2.02 Partition B
0/2/CPU0 Offline -----
0/3/CPU0 Offline -----
```

## show canbus

```

0/RSP0/CPU0 Online 1.01 1.02 Partition B
0/RSP1/CPU0 Online 1.01 1.02 Partition B
... snip ...
0/FT0/SP Online 4.00 4.00 Partition A
0/FT1/SP Online 4.00 4.00 Partition B
0/BPID0/SP Online 7.00 7.00 Partition B

```

---

**Related Commands**

Command	Description
<a href="#">clear plugin slot counts</a>	Clears the running counts of the backplane connector slot plugins.
<a href="#">show plugin slot counts</a>	Displays cumulative and running counts of card insertions per slot.

# show dsc

To display the current designated shelf controller (DSC) configuration for the shelf or for the system, enter the **show dsc** command in administration EXEC mode.

**show dsc**

**Command Default** This command has no keywords or arguments.

**Command Default** No default behavior or values

**Command Modes** Administration EXEC

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

For more information about identifying and selecting a DSC on your router, see *Cisco ASR 9000 Series Aggregation Services Router Getting Started Guide*.

Task ID	Task ID	Operations
	system	read

The following example shows sample output from the **show dsc** command:

```
RP/0/RSP0/CPU0:PE44_ASR-9010 (admin) # show dsc
Thu Jul 30 02:51:59.628 DST
NODE ROLE
=====
0/RSP0/CPU0 DSC
```

# show environment

To display environmental monitor parameters for the system, use the **show environment** command in the appropriate mode.

EXEC Mode:

**show environment** [{**all** | **last** | **leds** | **table** | **temperatures** | **voltages**}] [*node-id*]

Administration EXEC Mode:

**show environment** [{**all** | **fans** | **last** | **leds** | **power-supply** | **table** | **temperatures** | **trace** | **voltages**}] [*node-id*]

Syntax Description		
	<b>all</b>	(Optional) Displays information for all environmental monitor parameters.
	<b>fans</b>	(Optional) Displays information about the fans.
	<b>last</b>	(Optional) Displays the environmental statistics at the time of the last shutdown.
	<b>leds</b>	(Optional) Displays monitor parameters for LEDs on all cards in the node.
	<b>power-supply</b>	(Optional) Displays power supply voltage and current information.
	<b>table</b>	(Optional) Displays environmental parameter ranges.
	<b>temperatures</b>	(Optional) Displays system temperature information.
	<b>voltages</b>	(Optional) Displays system voltage information.
	<i>node-id</i>	(Optional) Node whose information you want to display. The <i>node-id</i> argument is expressed in the <i>rack/slot/module</i> notation.

**Command Default** All environmental monitor parameters are displayed.

**Command Modes** EXEC

Administration EXEC

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.
	Release 6.3.3	<b>power-supply</b> field descriptions modified to include Power Budget Mode and N+1 mode related details

**Usage Guidelines** The **show environment** command displays information about the hardware that is installed in the system, including fans, LEDs, power supply voltage, and current information and temperatures.

Task ID	Task Operations ID
	system read

The following example shows sample output from the **show environment** command with the **temperatures** keyword:

```
RP/0/RSP0/CPU0:router# show env temperatures

Sun Aug 8 23:18:15.153 ABC

R/S/I Modules Inlet Hotspot
 Temperature Temperature
 (deg C) (deg C)

0/RSP0/*
 host 21.2 30.8
0/RSP1/*
 host 20.5 30.3
0/5/*
 host 23.2 30.9
```

[Table 26: show environment temperatures Field Descriptions, on page 363](#) describes the significant fields shown in the display.

**Table 26: show environment temperatures Field Descriptions**

Field	Description
R/S/I	Rack number, slot number, and interface for which information is displayed, in the format <i>rack/slot/module</i> .
Modules	Module for which temperature information is displayed.
Inlet Temperature (deg C)	Current temperature of the inlet sensor, in degrees Celsius. <b>Note</b> The inlet temperature corresponds to the room air temperature entering the router.

Field	Description
Exhaust Temperature (deg C)	Current temperature of the exhaust sensor, in degrees Celsius.  <b>Note</b> The exhaust temperature corresponds to the air being exhausted from the router.
Hotspot Temperature (deg C)	Current temperature of the hotspot, in degrees Celsius.

```
RP/0/RSP0/CPU0:router# show env leds

Sun Aug 8 23:18:19.416 ABC
R/S/I Modules LED Status
0/RSP0/*
 host Critical-Alarm Off
 host Major-Alarm Off
 host Minor-Alarm Off
 host ACO Off
 host Fail Off
0/RSP1/*
 host Critical-Alarm On
 host Major-Alarm Off
 host Minor-Alarm Off
 host ACO Off
 host Fail Off
```

[Table 27: show environment leds Field Descriptions, on page 364](#) describes the significant fields shown in the display.

**Table 27: show environment leds Field Descriptions**

Field	Description
<i>rack_num/slot_num/*:</i>	Rack number and slot number where the node resides.
Module (host) LED status says:	Current LED status of the specified node.

The following example shows sample output from the **show environment** command the with the **power-supply** keyword:

```
RP/0/RSP0/CPU0:router (admin) # show environment power-supply

Wed Aug 4 23:38:25.033 DST
R/S/I Modules Capacity Status
 (W)
0/PM0/*
 host PM 3000 Ok
0/PM1/*
 host PM 3000 Ok
0/PM2/*
 host PM 3000 Ok

R/S/I Power Draw Voltage Current
 (W) (V) (A)
0/PM0/* 494.9 53.8 9.2
0/PM1/* 581.0 53.8 10.8
0/PM2/* 0.0 54.1 0.0
```



```

Total: 1075.9

Power Shelves Type: AC

Total Power Capacity: 9000W
Usable Power Capacity: 9000W
Supply Failure Protected Capacity: 6000W
Feed Failure Protected Capacity: 3000W
Worst Case Power Used: 2720W

Slot Max Watts
---- -
0/1/CPU0 350
0/RSP0/CPU0 235
0/RSP1/CPU0 235 (default)
0/4/CPU0 350
0/6/CPU0 350
0/FT0/SP 600
0/FT1/SP 600

Worst Case Power Available: 6280W
Supply Protected Capacity Available: 3280W
Feed Protected Capacity Available: 280W

```

This table describes the significant fields shown in the display.

**Table 28: show environment power-supply Field Descriptions**

Field	Description
R/S/I	Rack number, slot number, and interface for which information is displayed, in the format PEM/Power Module/* (for example 0/PM0/*).
Modules	Module for which power information is displayed.
Capacity	Power capacity of each power module in Watts.
Status	Operational status of power modules.
Power Draw	Real (measured) power drawn from each power module.
Voltage	Real (measured) power module voltage.
Current	Real (measured) power module current draw.
Power Shelves Type	AC or DC.
Total Power Capacity	Sum of the power capacity of each of the modules installed in the chassis.
Usable Power Capacity	Sum of the power capacity of each of the powered and operational power modules installed in the chassis.
Supply Failure Protected Capacity	Protected power capacity of the chassis with power module redundancy (ASR 9010 AC 3+3, ASR 9010 DC 5+1, ASR 9006 AC 2+1, ASR 9010 DC 2+1).

Field	Description
Feed Failure Protected Capacity	Feed protected power capacity. This value applies to the ASR 9010 AC system only.
Worst Case Power Used	Sum of the estimated power draw of each of the load modules in the chassis. Load modules can be fan trays, RSPs and line cards.
Worst Case Power Available	Usable power capacity minus the worst case power used.
Supply Protected Capacity Available	Supply failure protected capacity minus the worst case power used.
Feed Protected Capacity Available	Feed failure protected capacity minus the worst case power used.
Power Budget Enforcement	This field displays the Power Budget Enforcement status as Enabled or Disabled.
Power Budget Mode	This field displays the power redundancy mode used (for example, N+1).
N+1 Supply Failure Protected Capacity	This field represents the Supply Protected Power capacity of the chassis with power module redundancy in N+1 mode.

# show fpd package

To display which shared port adapters (SPA) and SPA interface processors (SIPs) are supported with your current Cisco IOS XR software release, which field-programmable device (FPD) image you need for each SPA and SIP, and what the minimum hardware requirements are for the SPA and SIP modules, use the **show fpd package** command in administration EXEC mode.

**show fpd package**

**Syntax Description** This command has no keywords or arguments.

**Command Default** No default behavior or values

**Command Modes** Administration EXEC

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

If there are multiple FPD images for your card, use the **show fpd package** command to determine which FPD image to use if you only want to upgrade a specific FPD type.

Task ID	Task Operations ID
	sysmgr read

The following example shows sample output from the **show fpd package** command:

```
show fpd package
Tue Jan 22 13:56:00.212 UTC

=====
 Field Programmable Device Package
=====
Card Type FPD Description Req SW Min Req Min Req
Reload Ver SW Ver Board Ver
=====
NC55-1200W-ACFW LIT-PrimMCU-ACFW (A) NO 2.09 2.09 0.0

NC55-900W-ACFW-I LIT-PrimMCU-ACFW-I (A) NO 1.04 1.04 0.0

NC55-900W-DCFW-I LIT-PrimMCU-DCFW-I (A) NO 2.260 2.260 0.0

NC55-930W-DCFW-C LIT-PrimMCU-DCFW-C (A) NO 2.259 2.259 0.0

```

## show fpd package

NC55-MPA-12T-S	MPAFPGA	YES	0.27	0.27	0.0
-----					
NC55-MPA-1TH2H-S	-WDM-D-1HL_DCO_2	NO	38.518	38.518	0.1
	MPAFPGA	YES	0.53	0.53	0.0
	WDM-DE-1HL_DCO_2	NO	38.518	38.518	0.1
	WDM-DS-1HL_DCO_2	NO	38.268	38.268	0.1
-----					
NC55-MPA-2TH-HX-S	-WDM-D-1HL_DCO_0	NO	38.518	38.518	0.1
	-WDM-D-1HL_DCO_1	NO	38.518	38.518	0.1
	MPAFPGA	YES	0.53	0.53	0.0
	WDM-DE-1HL_DCO_0	NO	38.518	38.518	0.1
	WDM-DE-1HL_DCO_1	NO	38.518	38.518	0.1
	WDM-DS-1HL_DCO_0	NO	38.268	38.268	0.1
	WDM-DS-1HL_DCO_1	NO	38.268	38.268	0.1
-----					
NC55-MPA-2TH-S	-WDM-D-1HL_DCO_0	NO	38.518	38.518	0.1
	-WDM-D-1HL_DCO_1	NO	38.518	38.518	0.1
	MPAFPGA	YES	0.53	0.53	0.0
	WDM-DE-1HL_DCO_0	NO	38.518	38.518	0.1
	WDM-DE-1HL_DCO_1	NO	38.518	38.518	0.1
	WDM-DS-1HL_DCO_0	NO	38.268	38.268	0.1
	WDM-DS-1HL_DCO_1	NO	38.268	38.268	0.1
-----					
NC55-MPA-4H-HD-S	MPAFPGA	YES	0.53	0.53	0.0
-----					
NC55-MPA-4H-HX-S	MPAFPGA	YES	0.53	0.53	0.0
-----					
NC55-MPA-4H-S	MPAFPGA	YES	0.53	0.53	0.0
-----					
NC55A2-MOD-SE-H-S	Bootloader (A)	YES	1.11	1.11	0.0
	CPU-IOFPGA (A)	YES	1.18	1.18	0.1
	MB-IOFPGA (A)	YES	0.18	0.18	0.1
	MB-MIFPGA	YES	0.19	0.19	0.0
	SATA (A)	NO	5.00	5.00	0.0
-----					
NCS-55A2-MOD-HD-S	Bootloader (A)	YES	1.11	1.11	0.0
	CPU-IOFPGA (A)	YES	1.18	1.18	0.1
	MB-IOFPGA (A)	YES	0.18	0.18	0.1
	MB-MIFPGA	YES	0.19	0.19	0.0
	SATA (A)	NO	5.00	5.00	0.0
-----					
NCS-55A2-MOD-HX-S	Bootloader (A)	YES	1.11	1.11	0.0
	CPU-IOFPGA (A)	YES	1.18	1.18	0.1
	MB-IOFPGA (A)	YES	0.18	0.18	0.1
	MB-MIFPGA	YES	0.19	0.19	0.0
	SATA (A)	NO	5.00	5.00	0.0
-----					
NCS-55A2-MOD-S	Bootloader (A)	YES	1.11	1.11	0.0
	CPU-IOFPGA (A)	YES	1.18	1.18	0.1
	MB-IOFPGA (A)	YES	0.18	0.18	0.1
	MB-MIFPGA	YES	0.19	0.19	0.0
	SATA (A)	NO	5.00	5.00	0.0
-----					
NCS-55A2-MOD-SE-S	Bootloader (A)	YES	1.11	1.11	0.0
	CPU-IOFPGA (A)	YES	1.18	1.18	0.1
	MB-IOFPGA (A)	YES	0.18	0.18	0.1
	MB-MIFPGA	YES	0.19	0.19	0.0
	SATA (A)	NO	5.00	5.00	0.0
	STATSFPGA	YES	0.01	0.01	0.0

This table describes the significant fields shown in the display:

**Table 29: show fpd package Field Descriptions**

Field	Description
Card Type	Module part number.
FPD Description	Description of all FPD images available for the SPA.
Type	Hardware type. Possible types can be: <ul style="list-style-type: none"> <li>• spa—Shared port adapter</li> <li>• lc—Line card</li> </ul>
Subtype	FPD subtype. These values are used in the <b>upgrade hw-module fpd</b> command to indicate a specific FPD image type to upgrade.
SW Version	FPD software version recommended for the associated module running the current Cisco IOS XR software.
Min Req SW Vers	Minimum required FPD image software version to operate the card. Version 0.0 indicates that a minimum required image was not programmed into the card.
Min Req HW Vers	Minimum required hardware version for the associated FPD image. A minimum hardware requirement of version 0.0 indicates that all hardware can support this FPD image version.



**Note** In the **show fpd package** command output, the “subtype” column shows the FPDs that correspond with each SPA image. To upgrade a specific FPD with the **upgrade hw-module fpd** command, replace the *fpga-type* argument with the appropriate FPD from the “subtype” column, as shown in the following example:

```
RP/0/RSP0/CPU0:router(admin)# upgrade hw-module fpd fpga2 location 0/3/1 reload
```

## show hw-module fpd

To display field-programmable device (FPD) compatibility for all modules or a specific module, use the **show hw-module fpd** command in the EXEC or administration EXE mode.

**show hw-module fpd location** {*node-id* | **all**}

### Syntax Description

**location**{*node-id* | **all**} Specifies the location of the module. The *node-id* argument is expressed in the *rack/slot/module* notation. Use the **all** keyword to indicate all nodes.

### Command Default

No default behavior or values

### Command Modes

EXEC

Administration EXEC

### Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	Support was added for the 2-port channelized OC-12/DS0 SPA.
Release 4.3.2	Support for Back-plane identification (BPID) nodes.

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

### Task ID

Task ID	Operations
sysmgr	read
root-lr	read

The following example shows how to display FPD compatibility for all modules in the router:

```
RP/0/RSP1/CPU0:router# show hw-module fpd location all
```

```
Mon Jun 29 05:38:50.332 PST
```

```
===== Existing Field Programmable Devices =====
=====
Location Card Type HW Current SW Upg/
Version Type Subtype Inst Version Dng?
=====
0/RSP0/CPU0 A9K-RSP-4G 4.8 1c fpga3 0 1.13 No
 1c fpga1 0 1.5 No
 1c fpga2 0 1.14 No
 1c cbc 0 1.2 No
=====
```

			lc	fpga4	0	1.6	No
			lc	rommon	0	1.0	No
0/RSP0/CPU0	ASR-9010-FAN	1.0	lc	cbc	1	4.0	No
0/RSP0/CPU0	ASR-9010-FAN	1.0	lc	cbc	2	4.0	No
0/1/CPU0	A9K-40GE-B	1.0	lc	fpga1	0	0.38	No
			lc	fpga2	0	0.8	No
			lc	cbc	0	2.2	No
			lc	cp1d1	0	0.15	No
			lc	rommon	0	1.0	No
0/1/CPU0	A9K-40GE-B	1.0	lc	fpga1	1	0.38	No
0/4/CPU0	A9K-8T/4-B	1.0	lc	fpga1	0	0.38	No
			lc	fpga2	0	0.10	No
			lc	cbc	0	2.2	No
			lc	cp1d2	0	0.7	No
			lc	cp1d1	0	0.15	No
			lc	cp1d3	0	0.3	No
			lc	rommon	0	1.0	No
			lc	fpga3	0	14.42	No
0/4/CPU0	A9K-8T/4-B	1.0	lc	fpga1	1	0.38	No
0/6/CPU0	A9K-4T-B	1.0	lc	fpga1	0	0.38	No
			lc	fpga2	0	0.10	No
			lc	cbc	0	2.2	No
			lc	cp1d2	0	0.7	No
			lc	cp1d1	0	0.15	No
			lc	cp1d3	0	0.3	No
			lc	rommon	0	1.0	No
			lc	fpga3	0	14.42	No
0/6/CPU0	A9K-4T-B	1.0	lc	fpga1	1	0.38	No

The following example shows how to display FPD compatibility for a specific module in the router:

**Table 30: show hw-module fpd Field Descriptions**

Field	Description
Location	Location of the module in the <i>rack/slot/module</i> notation.
Card Type	Module part number.
HW Version	Hardware model version for the module.
Type	Hardware type. Can be one of the following types: <ul style="list-style-type: none"> <li>• spa—Shared port adapter</li> <li>• lc—Line card</li> </ul>

Field	Description
Subtype	<p>FPD type. Can be one of the following types:</p> <ul style="list-style-type: none"> <li>• fabldr—Fabric downloader</li> <li>• fpga1—Field-programmable gate array</li> <li>• fpga2—Field-programmable gate array 2</li> <li>• fpga3—Field-programmable gate array 3</li> <li>• fpga4—Field-programmable gate array 4</li> <li>• fpga5—Field-programmable gate array 5</li> <li>• rommonA—Read-only memory monitor A</li> <li>• rommon—Read-only memory monitor B</li> </ul>
Inst	FPD instance. The FPD instance uniquely identifies an FPD and is used by the FPD process to register an FPD.
Current SW Version	Currently running FPD image version.
Upg/Dng?	Specifies whether an FPD upgrade or downgrade is required. A downgrade is required in rare cases when the version of the FPD image has a higher major revision than the version of the FPD image in the current Cisco IOS XR software package.



## show hw-module subslot brief

To display summary information related to a specified internal hardware device on a shared port adapter (SPA), use the **show hw-module subslot brief** command in

EXEC

mode.

**show hw-module subslot** [*node-id*] **brief** [*device* [*device-index* [*device-subindex*]]]

Syntax Description	
<i>node-id</i>	(Optional) Location for which to display the specified information. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.
<i>device</i>	(Optional) Internal hardware device for which to display the specified information. Valid devices include: <ul style="list-style-type: none"> <li>• <b>analog-digital-converter</b>—Displays analog-to-digital converter information.</li> <li>• <b>c2w</b>—Displays Cisco-to-wire bus device information.</li> <li>• <b>fpga</b>—Displays SPA field-programmable gate array information.</li> <li>• <b>framer</b>—Displays SONET framer information. (Not applicable to Ethernet SPAs.)</li> <li>• <b>hdlc</b>—Displays SPA hdlc information, where applicable.</li> <li>• <b>l2-tcam</b>—Displays SPA Layer 2 ternary content addressable memory information. (Not applicable to POS SPAs.)</li> <li>• <b>mac</b>—Displays SPA MAC information. (Not applicable to POS SPAs.)</li> <li>• <b>pluggable-optics</b>—Displays pluggable-optics module information.</li> <li>• <b>power-margining</b>—Displays power-margining device information.</li> <li>• <b>sar</b>—Displays SPA ATM SAR information.</li> <li>• <b>sdcc</b>—Displays section data communications channel device information. (Not applicable to Ethernet SPAs.)</li> <li>• <b>serdes</b>—Displays SPA serializer/deserializer information.</li> <li>• <b>spi4</b>—Displays system packet interface level 4.2 bus device information.</li> <li>• <b>temperature-sensor</b>—Displays temperature sensor information.</li> </ul>
<i>device-index</i>	(Optional) Index of the specific device if there are multiple devices of the same type.
<i>device-subindex</i>	(Optional) Subindex of the specific device if there are multiple devices of the same device index.
<b>Command Default</b>	No default behavior or values
<b>Command Modes</b>	EXEC

Command History	Release	Modification
	Release 3.9.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

You can also enter a partially qualified location specifier by using the wildcard (*) character. For example, 0/1/* would display information for all modules on slot 1 in rack 0.

Use the **show hw-module subslot brief** command to obtain summary diagnostic information about a device on an interface on the SPA.

Task ID	Task ID	Operations
	root-lr	read

The following example shows sample output for the **show hw-module subslot brief** command:

```
RP/0/RSP0/CPU0:router# show hw-module subslot 0/1/0 brief

Subslot 0/1/0 brief info:

SPA inserted: YES
SPA type: 4xOC3 POS SPA
SPA operational state: READY
SPA cfg admin up: YES
```

**Table 31: show hw-module subslot config Field Descriptions**

Field	Description
SPA inserted	Indicates if a SPA is currently detected in the subslot.
SPA type	Description of SPA including the technology type, number of ports, height of SPA (HHSPA—single height, FHSPA—double height), and optics type.
SPA operational state	Current state of the SPA module.
SPA cfg admin up	Configured state of the SPA: YES—the SPA is not shut down; NO—the SPA is shut down.

## show hw-module subslot config

To display information related to configuration of the specified internal hardware device on a shared port adapter (SPA), use the **show hw-module subslot config** command in EXEC

mode.

```
show hw-module subslot [node-id] config [device [device-index [device-subindex]]]
```

Syntax Description	
<i>node-id</i>	(Optional) Location for which to display the specified information. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.
<i>device</i>	(Optional) Internal hardware device for which to display the specified information. Valid devices include: <ul style="list-style-type: none"> <li>• <b>analog-digital-converter</b>—Displays analog-to-digital converter information.</li> <li>• <b>c2w</b>—Displays Cisco-to-wire bus device information.</li> <li>• <b>fpga</b>—Displays SPA field-programmable gate array information.</li> <li>• <b>framer</b>—Displays SONET framer information. (Not applicable to Ethernet SPAs.)</li> <li>• <b>hdlc</b>—Displays SPA hdlc information, where applicable.</li> <li>• <b>l2-tcam</b>—Displays SPA Layer 2 ternary content addressable memory information. (Not applicable to POS SPAs.)</li> <li>• <b>mac</b>—Displays SPA MAC information. (Not applicable to POS SPAs.)</li> <li>• <b>pluggable-optics</b>—Displays pluggable-optics module information.</li> <li>• <b>power-margining</b>—Displays power-margining device information.</li> <li>• <b>sar</b>—Displays SPA ATM SAR information.</li> <li>• <b>sdcc</b>—Displays section data communications channel device information. (Not applicable to Ethernet SPAs.)</li> <li>• <b>serdes</b>—Displays SPA serializer/deserializer information.</li> <li>• <b>spi4</b>—Displays system packet interface level 4.2 bus device information.</li> <li>• <b>temperature-sensor</b>—Displays temperature sensor information.</li> </ul>
<i>device-index</i>	(Optional) Index of the specific device if there are multiple devices of the same type.
<i>device-subindex</i>	(Optional) Subindex of the specific device if there are multiple devices of the same device index.
<b>Command Default</b>	No default behavior or values
<b>Command Modes</b>	EXEC Release 5.0.0

## show hw-module subslot config

Command History	Release	Modification
	Release 3.9.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

You can also enter a partially qualified location specifier by using the wildcard (*) character. For example, 0/1/* would display information for all modules on slot 1 in rack 0.

Use the **show hw-module subslot config** command to obtain diagnostic information about the configuration of an interface on the SPA.

Task ID	Task ID	Operations
	root-lr	read

The following example shows sample output for the **show hw-module subslot config** command:

```
RP/0/RSP0/CPU0:router# show hw-module subslot 0/6/cpu0 config

Thu Feb 19 00:33:02.921 PST

Subslot 0/6/0 config info:

SPA inserted: YES
SPA cfg admin up: YES
SPA cfg power up: YES

Subslot 0/6/1 config info:

SPA inserted: YES
SPA cfg admin up: YES
SPA cfg power up: YES

Subslot 0/6/2 config info:

SPA inserted: NO
SPA cfg admin up: YES
SPA cfg power up: NO

Subslot 0/6/3 config info:

SPA inserted: NO
SPA cfg admin up: YES
SPA cfg power up: NO

Subslot 0/6/4 config info:

SPA inserted: NO
SPA cfg admin up: YES
SPA cfg power up: NO

Subslot 0/6/5 config info:

SPA inserted: NO
```

```
SPA cfg admin up: YES
SPA cfg power up: NO
```

**Table 32: show hw-module subslot config Field Descriptions**

Field	Description
SPA inserted	Indicates if a SPA is currently detected in the subslot.
SPA cfg admin up	Configured state of the SPA: YES—the SPA is not shut down; NO—the SPA is shut down.
SPA cfg power up	Indicates whether the subslot is currently configured as powered or not.

#### Related Commands

Command	Description
<b>show controllers</b>	Displays the controller type and other information.

## show hw-module subslot counters

To display statistics related to the processing of internal hardware devices for a shared port adapter (SPA), use the **show hw-module subslot counters** command in EXEC

mode.

```
show hw-module subslot [node-id] counters [device [device-index [device-subindex]]]
```

### Syntax Description

*node-id* (Optional) Location for which to display the specified information. The *node-id* argument is entered in the *rack / slot / module* notation.

*device* (Optional) Internal hardware device for which to display the specified information. Valid devices include:

- **analog-digital-converter**—Displays analog-to-digital converter information.
- **c2w**—Displays Cisco-to-wire bus device information.
- **fpga**—Displays SPA field-programmable gate array information.
- **framer**—Displays SONET framer information. (Not applicable to Ethernet SPAs.)
- **hdlc**—Displays SPA hdlc information, where applicable.
- **l2-tcam**—Displays SPA Layer 2 ternary content addressable memory information. (Not applicable to POS SPAs.)
- **mac**—Displays SPA MAC information. (Not applicable to POS SPAs.)
- **pluggable-optics**—Displays pluggable-optics module information.
- **power-margining**—Displays power-margining device information.
- **sar**—Displays SPA ATM SAR information.
- **sdcc**—Displays section data communications channel device information. (Not applicable to Ethernet SPAs.)
- **serdes**—Displays SPA serializer/deserializer information.
- **spi4**—Displays system packet interface level 4.2 bus device information.
- **temperature-sensor**—Displays temperature sensor information.

*device-index* (Optional) Index of the specific device if there are multiple devices of the same type.

*device-subindex* (Optional) Subindex of the specific device if there are multiple devices of the same device index.

**Command Default** No default behavior or values

**Command Modes** EXEC

Command History	Release	Modification
	Release 3.9.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

You can also enter a partially qualified location specifier by using the wildcard (*) character. For example, 0/1/* would display information for all modules on slot 1 in rack 0.

Use the **show hw-module subslot counters** command to display statistics related to the processing by the specified internal hardware device.

Task ID	Task ID	Operations
	root-lr	read

The following example shows sample output for the **show hw-module subslot counters** command:

```
RP/0/RSP0/CPU0:router# show hw-module subslot 0/1/cpu0 counters

Subslot 0/1/0 counts info:

SPA inserted: YES
SPA type: 8xGE SPA
SPA operational state: READY
SPA insertion time: Wed Jan 14 11:33:24 2009
SPA last time ready: Wed Jan 14 11:33:37 2009
SPA uptime [HH:MM:SS]: 852:54:24

Subslot 0/1/1 counts info:

SPA inserted: YES
SPA type: 5xGE SPA
SPA operational state: READY
SPA insertion time: Wed Jan 14 11:33:24 2009
SPA last time ready: Wed Jan 14 11:33:38 2009
SPA uptime [HH:MM:SS]: 852:54:23
--More--
```

**Table 33: show hw-module subslot counters Field Descriptions**

Field	Description
SPA inserted	Indicates if a SPA is currently detected in the subslot.
SPA type	Description of SPA including the technology type, number of ports, height of SPA (HHSPA—single height, FHSPA—double height), and optics type.
SPA operational state	Current state of the SPA module.
SPA insertion time	Time the SPA module was last physically inserted or power-cycled.

Field	Description
SPA last time ready	Time the SPA module last changed state to up or ready (the last time the module was loaded or reloaded).
SPA uptime	The time in service or amount of time since the module was last out of service due to a reload, power cycle, or configuration event.

The following example shows sample output for the **show hw-module subslot counters** command with the **framer** keyword:

```
RP/0/RSP0/CPU0:router# show hw-module subslot counters framer

SPA device framer index 0 subindex 0 info:

Milan Framer counters:
STREAM 0
Rx Bytes (48-bit) (#0x381fa078-0x883c): 163857232569448
Rx Good Bytes (48-bit) (#0x381fa080-0x8840): 1964924
Rx Good Packets (48-bit) (#0x381fa040-0x8820): 26234
Tx Byte Cnt Reg (48-bit) (#0x381fe070-0xa838): 9375380
Tx Good Bytes Cnt Reg (48-bit) (#0x381fe068-0xa834): 8909442
Tx Transmitted Packet Cnt Reg (48-bit) (#0x381fe040-0xa820): 114692
```



## show hw-module subslot errors

To display error information about internal hardware devices for a shared port adapter (SPA), use the **show hw-module subslot errors** command in

EXEC

mode.

**show hw-module subslot** [*node-id*] **errors** [*device* [*device-index* [*device-subindex*]]]

<b>Syntax Description</b>	<i>node-id</i>	(Optional) Location for which to display the specified information. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.
	<i>device</i>	(Optional) Internal hardware device for which to display the specified information. Valid devices include: <ul style="list-style-type: none"> <li>• <b>analog-digital-converter</b>—Displays analog-to-digital converter information.</li> <li>• <b>c2w</b>—Displays Cisco-to-wire bus device information.</li> <li>• <b>fpga</b>—Displays SPA field-programmable gate array information.</li> <li>• <b>framer</b>—Displays SONET framer information. (Not applicable to Ethernet SPAs.)</li> <li>• <b>hdlc</b>—Displays SPA hdlc information, where applicable.</li> <li>• <b>l2-tcam</b>—Displays SPA Layer 2 ternary content addressable memory information. (Not applicable to POS SPAs.)</li> <li>• <b>mac</b>—Displays SPA MAC information. (Not applicable to POS SPAs.)</li> <li>• <b>pluggable-optics</b>—Displays pluggable-optics module information.</li> <li>• <b>power-margining</b>—Displays power-margining device information.</li> <li>• <b>sar</b>—Displays SPA ATM SAR information.</li> <li>• <b>sdcc</b>—Displays section data communications channel device information. (Not applicable to Ethernet SPAs.)</li> <li>• <b>serdes</b>—Displays SPA serializer/deserializer information.</li> <li>• <b>spi4</b>—Displays system packet interface level 4.2 bus device information.</li> <li>• <b>temperature-sensor</b>—Displays temperature sensor information.</li> </ul>
	<i>device-index</i>	(Optional) Index of the specific device if there are multiple devices of the same type.
	<i>device-subindex</i>	(Optional) Subindex of the specific device if there are multiple devices of the same device index.
<b>Command Default</b>	No default behavior or values	
<b>Command Modes</b>	EXEC	

## show hw-module subslot errors

Command History	Release	Modification
	Release 3.9.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

You can also enter a partially qualified location specifier by using the wildcard (*) character. For example, 0/1/* would display information for all modules on slot 1 in rack 0.

Use the **show hw-module subslot errors** command to display error information related to the specified internal hardware device on a SPA.

Task ID	Task ID	Operations
	root-lr	read

The following example shows partial sample output for the **show hw-module subslot errors** command:

```
RP/0/RSP0/CPU0:router# show hw-module subslot 0/1/0 errors
```

```
Subslot 0/1/0 errors info:
```

```

SPA inserted: YES
SPA type: 4xOC3 POS SPA
SPA operational state: READY
SPA last reset reason: UNKNOWN
SPA last failure reason: UNKNOWN
```

```
Subslot 0/1/1 errors info:
```

```

SPA inserted: YES
SPA type: 1x10GE XFP SPA
SPA operational state: READY
SPA last reset reason: UNKNOWN
SPA last failure reason: UNKNOWN
```

```
Subslot 0/1/2 errors info:
```

```

SPA inserted: NO
```

```
Subslot 0/1/3 errors info:
```

```

SPA inserted: NO
```

```
Subslot 0/1/4 errors info:
```

```

SPA inserted: YES
SPA type: 4xOC48 POS/RPR HHSPA
SPA operational state: READY
SPA last reset reason: UNKNOWN
SPA last failure reason: UNKNOWN
```

```
Subslot 0/1/5 errors info:
```

```

```

```

SPA inserted: YES
SPA type: 8xGE SPA
SPA operational state: READY
SPA last reset reason: UNKNOWN
SPA last failure reason: UNKNOWN

--More--

```

**Table 34: show hw-module subslot errors Field Descriptions**

Field	Description
Subslot */*/ errors info	SPA for which error information is being displayed. The location of the SPA is expressed in the <i>rack / slot / module</i> notation.
SPA inserted	Indication if a SPA is currently detected in the subslot.
SPA type	Description of SPA including the technology type, number of ports, height of SPA (HHSPA—single-height, FHSPA—double-height), and optics type.
SPA operational state	Current operational state of the SPA module.
SPA last reset reason	Reason for the most recent reset of this SPA.
SPA last failure reason	Reason for the last failure on this SPA.

#### Related Commands

Command	Description
<b>show controllers</b>	Displays the controller type and other information.

## show hw-module subslot plim-subblock

To display SPA firmware information for a shared port adapter (SPA), use the **show hw-module subslot plim-subblock** command in

EXEC

mode.

**show hw-module subslot** [*node-id*] **plim-subblock**

<b>Syntax Description</b>	<i>node-id</i> (Optional) Location for which to display the specified information. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.
---------------------------	--------------------------------------------------------------------------------------------------------------------------------------------------------------------

<b>Command Default</b>	No default behavior or values
------------------------	-------------------------------

<b>Command Modes</b>	EXEC
----------------------	------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.9.0	This command was introduced.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

Use the **show hw-module subslot plim-subblock** command to display SPA firmware information, both kernel and application information, as well as heartbeat and keepalive information. The **show hw-module subslot plim-subblock** command is mainly used for debugging purposes.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	root-lr	read

The following example shows sample output for the **show hw-module subslot plim-subblock** command:

```
RP/0/0/CPU0:router# show hw-module subslot 0/5/0 plim-subblock

Subslot 0/5/0 Plim Subblock Info:

Firmware information:
 SPA v4.10.1, ifs-spa_ppc_iox.elf
 Application v3.44.0, spa_ct3_pat_apps_iox.tar.gz

SPA keepalive information:
 Heartbeat check disabled : FALSE
 Keepalive seq 372638, seen 372637, Time since last ipc keep 1s
```

**Related Commands**

Command	Description
show controllers	Displays the controller type and other information.

## show hw-module subslot registers

To display register information about internal hardware devices for a shared port adapter (SPA), use the **show hw-module subslot registers** command in

EXEC

mode.

**show hw-module subslot** [*node-id*] **registers** [*device* [*device-index* [*device-subindex*]]]

<b>Syntax Description</b>	<i>node-id</i>	(Optional) Location for which to display the specified information. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.
	<i>device</i>	<p>(Optional) Internal hardware device for which to display the specified information. Valid devices include:</p> <ul style="list-style-type: none"> <li>• <b>analog-digital-converter</b>—Displays analog-to-digital converter information.</li> <li>• <b>c2w</b>—Displays Cisco-to-wire bus device information.</li> <li>• <b>fpga</b>—Displays SPA field-programmable gate array information.</li> <li>• <b>framer</b>—Displays SONET framer information. (Not applicable to Ethernet SPAs.)</li> <li>• <b>hdlc</b>—Displays SPA hdlc information, where applicable.</li> <li>• <b>l2-tcam</b>—Displays SPA Layer 2 ternary content addressable memory information. (Not applicable to POS SPAs.)</li> <li>• <b>mac</b>—Displays SPA MAC information. (Not applicable to POS SPAs.)</li> <li>• <b>pluggable-optics</b>—Displays pluggable-optics module information.</li> <li>• <b>power-margining</b>—Displays power-margining device information.</li> <li>• <b>sar</b>—Displays SPA ATM SAR information.</li> <li>• <b>sdcc</b>—Displays section data communications channel device information. (Not applicable to Ethernet SPAs.)</li> <li>• <b>serdes</b>—Displays SPA serializer/deserializer information.</li> <li>• <b>spi4</b>—Displays system packet interface level 4.2 bus device information.</li> <li>• <b>temperature-sensor</b>—Displays temperature sensor information.</li> </ul>
	<i>device-index</i>	(Optional) Index of the specific device if there are multiple devices of the same type.
	<i>device-subindex</i>	(Optional) Subindex of the specific device if there are multiple devices of the same device index.
<b>Command Default</b>		No default behavior or values
<b>Command Modes</b>		EXEC

Command History	Release	Modification
	Release 3.9.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the command to display the nodes on the router.

You can also enter a partially qualified location specifier by using the wildcard (*) character. For example, 0/1/* would display information for all modules on slot 1 in rack 0.

Use the **show hw-module subslot registers** command to display register information for the specified internal hardware device on the SPA.

Task ID	Task ID	Operations
	root-lr	read

The following example shows sample output for the **show hw-module subslot registers** command:

```
RP/0/RSP0/CPU0:router# show hw-module subslot 0/1/cpu0 registers

Thu Feb 19 00:38:32.908 PST

Subslot 0/1/0 registers info:

SPA hardware ID : 0x0
SPA SW FPGA rev.: 0x1000A

Subslot 0/1/1 registers info:

SPA hardware ID : 0x0
SPA SW FPGA rev.: 0x1000A

Subslot 0/1/2 registers info:

SPA hardware ID : 0x0
SPA SW FPGA rev.: 0x1000A

Subslot 0/1/3 registers info:

SPA hardware ID : 0x0
SPA SW FPGA rev.: 0x1000A

Subslot 0/1/4 registers info:

SPA hardware ID : 0x0
SPA SW FPGA rev.: 0x1000A

Subslot 0/1/5 registers info:

SPA hardware ID : 0x0
SPA SW FPGA rev.: 0x1000A
```

*Table 35: show hw-module subslot registers Field Descriptions*

Field	Description
SPA hardware ID	SPA hardware identifier in hexadecimal format.
SPA SW FPGA rev.	SPA software field-programmable gate array (FPGA) revision number in hexadecimal format.

**Related Commands**

Command	Description
<b>show controllers</b>	Displays the controller type and other information.



## show hw-module subslot status

To display status information about internal hardware devices for a shared port adapter (SPA), use the **show hw-module subslot status** command in EXEC

mode.

```
show hw-module subslot [node-id] status [device [device-index [device-subindex]]]
```

Syntax Description	
<i>node-id</i>	(Optional) Location for which to display the specified information. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.
<i>device</i>	(Optional) Internal hardware device for which to display the specified information. Valid devices include: <ul style="list-style-type: none"> <li>• <b>analog-digital-converter</b>—Displays analog-to-digital converter information.</li> <li>• <b>c2w</b>—Displays Cisco-to-wire bus device information.</li> <li>• <b>fpga</b>—Displays SPA field-programmable gate array information.</li> <li>• <b>framer</b>—Displays SONET framer information. (Not applicable to Ethernet SPAs.)</li> <li>• <b>hdlc</b>—Displays SPA hdlc information, where applicable.</li> <li>• <b>l2-tcam</b>—Displays SPA Layer 2 ternary content addressable memory information. (Not applicable to POS SPAs.)</li> <li>• <b>mac</b>—Displays SPA MAC information. (Not applicable to POS SPAs.)</li> <li>• <b>pluggable-optics</b>—Displays pluggable-optics module information.</li> <li>• <b>power-margining</b>—Displays power-margining device information.</li> <li>• <b>sar</b>—Displays SPA ATM SAR information.</li> <li>• <b>sdcc</b>—Displays section data communications channel device information. (Not applicable to Ethernet SPAs.)</li> <li>• <b>serdes</b>—Displays SPA serializer/deserializer information.</li> <li>• <b>spi4</b>—Displays system packet interface level 4.2 bus device information.</li> <li>• <b>temperature-sensor</b>—Displays temperature sensor information.</li> </ul>
<i>device-index</i>	(Optional) Index of the specific device if there are multiple devices of the same type.
<i>device-subindex</i>	(Optional) Subindex of the specific device if there are multiple devices of the same device index.
<b>Command Default</b>	No default behavior or values
<b>Command Modes</b>	EXEC

**show hw-module subslot status**

Command History	Release	Modification
	Release 3.9.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

You can also enter a partially qualified location specifier by using the wildcard (*) character. For example, 0/1/* would display information for all modules on slot 1 in rack 0.

Use the **show hw-module subslot status** command to obtain status information about an interface on the SPA.

Task ID	Task ID	Operations
	root-lr	read

The following example shows sample output for the **show hw-module subslot status** command with the **temperature-sensor** option:

```
RP/0/RSP0/CPU0:router# show hw-module subslot 0/2/CPU0 status temperature-sensor

SPA device temperature-sensor index 0 subindex 0 info:

DS1631 (0x0803c2e4) device status:
temperature = 0x1c80 (28.5 degree C)

SPA device temperature-sensor index 0 subindex 0 info:

DS1631 (0x08063bec) device status:
temperature = 0x1e00 (30.0 degree C)
```

**Table 36: show hw-module subslot status Field Descriptions**

Field	Description
DS1631 (0x0803c2e4) device status	Device for which the temperature status is displayed.
temperature = 0x1c80 (28.5 degree C)	Current temperature of the specified device, in hexadecimal format and degrees Celsius.

Related Commands	Command	Description
	<b>show controllers</b>	Displays the controller type and other information.

# show inventory

To retrieve and display information about all the Cisco products that are installed in the router, use the **show inventory** command in EXEC or administration EXEC mode.

EXEC Mode

```
show inventory [{node-id | all | location {node-id | all} | raw}]
```

Administration EXEC Mode

```
show inventory [{node-id | all | chassis | fans | location {node-id | all} | power-supply | raw}]
```

## Syntax Description

<i>node-id</i>	(Optional) Location for which to display the specified information. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.
<b>all</b>	(Optional) Displays inventory information for all the physical entities in the chassis.
<b>location</b> { <i>node-id</i>   <b>all</b> }	(Optional) Displays inventory information for a specific node, or for all nodes in the chassis.
<b>raw</b>	(Optional) Displays raw information about the chassis for diagnostic purposes.
<b>chassis</b>	(Optional) Displays inventory information for the entire chassis.
<b>fans</b>	(Optional) Displays inventory information for the fans.
<b>power-supply</b>	(Optional) Displays inventory information for the power supply.

## Command Default

All inventory information for the entire chassis is displayed.

## Command Modes

EXEC

Administration EXEC

## Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	Support was added for the 2-port channelized OC-12/DS0 SPA.

## Usage Guidelines

If a Cisco entity is not assigned a product ID (PID), that entity is not retrieved or displayed.

Enter the **show inventory** command with the **raw** keyword to display every RFC 2737 entity installed in the router, including those without a PID, unique device identifier (UDI), or other physical identification.



### Note

The **raw** keyword is primarily intended for troubleshooting problems with the **show inventory** command itself.

If any of the Cisco products do not have an assigned PID, the output displays incorrect PIDs, and version ID (VID) and serial number (SN) elements may be missing.

For UDI compliance products, the PID, VID, and SN are stored in EEPROM and NVRAM. Use the **show inventory** command to display this information.

Task ID	Task ID	Operations
	sysmgr	read

The following example shows partial sample output from the **show inventory** command with the **raw** keyword:

```
RP/0/RSP0/CPU0:router# show inventory raw

Tue Jul 28 08:49:14.080 DST
NAME: "module 0/RSP0/CPU0", DESCR: "A2K-RSP-4G-HDD="
PID: A2K-RSP-4G-HDD= , VID: VP4, SN: FOC1230803H

NAME: "module 0/RSP0/CPU0", DESCR: "RSP Card host "
PID: , VID: N/A, SN:

NAME: "temperature 0/RSP0/CPU0", DESCR: "Inlet Temperature Sensor"
PID: , VID: N/A, SN:

NAME: "temperature 0/RSP0/CPU0", DESCR: "Hot Temperature Sensor"
PID: , VID: N/A, SN:

NAME: "voltage 0/RSP0/CPU0", DESCR: "Voltage Sensor - 0.75VTT"
PID: , VID: N/A, SN:

NAME: "voltage 0/RSP0/CPU0", DESCR: "Voltage Sensor - 0.9VTT_A"
PID: , VID: N/A, SN:

NAME: "voltage 0/RSP0/CPU0", DESCR: "Voltage Sensor - 0.9VTT_B"
PID: , VID: N/A, SN:

NAME: "voltage 0/RSP0/CPU0", DESCR: "Voltage Sensor - IBV"
PID: , VID: N/A, SN:

NAME: "voltage 0/RSP0/CPU0", DESCR: "Voltage Sensor - 5.0V"
PID: , VID: N/A, SN:

NAME: "module 0/1/CPU0", DESCR: "Cisco ASR 9000 Series SPA Interface Processor-700"
PID: A9K-SIP-700 , VID: P3A, SN: FHH132800F6

NAME: "module 0/1/0" , DESCR: "10-port 1 GbE Shared Port Adapter V2"
PID: SPA-2XOC12C , VID: V02, SN: JAE1239W2AI
--More--
```

[Table 37: show inventory Field Descriptions, on page 393](#) describes the significant fields shown in the display.

Table 37: show inventory Field Descriptions

Field	Description
NAME	Hardware for which the inventory information is displayed. If you are displaying the chassis inventory, this field shows “chassis.” If you are displaying raw inventory, or all inventory information for all nodes in the chassis, this field shows the node name in partially qualified format. For a node, the NAME is expressed in <i>rack/slot/module</i> notation.
DESCR	Describes the chassis or the node. Chassis descriptions provide the name of the chassis and its Gbps. Node descriptions provide the type of node and its software version.
PID	Physical model name of the chassis or node.
VID	Physical hardware revision of the chassis or node.
SN	Physical serial number for the chassis or node.

# show led

To display LED information for the router, or for a specific LED location, use the **show led** command in EXEC or administration EXEC mode.

**show led** [**location** {*node-id* | **all**}]

<b>Syntax Description</b>	<b>location</b> { <i>node-id</i>   <b>all</b> }	(Optional) Specifies the node for which to display LED information. The <i>node-id</i> argument is expressed in the <i>rack/slot/module</i> notation. Use the <b>all</b> keyword to indicate all nodes.
---------------------------	-------------------------------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

**Command Default** If no node is specified, information about all LEDs on the router is displayed.

**Command Modes** EXEC  
Administration EXEC

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** Enter the **show platform** command to see the location of all nodes installed in the router.

<b>Task ID</b>	<b>Task Operations ID</b>
	system read

The following example sample output from the **show led** command with the **all** keyword:

```
RP/0/RP0/CPU0:router# show led location all
Thu Jul 30 05:26:24.896 DST
 Location Message Mode Status
 =====
 0/RSP0/* ACTV DEFAULT UNLOCKED
```

**Table 38: show led location Field Descriptions**

<b>Field</b>	<b>Description</b>
LOCATION	Location of the node. LOCATION is expressed in the <i>rack/slot/module</i> notation.
MESSAGE	Current message displayed by the LED.

<b>Field</b>	<b>Description</b>
MODE	Current operating mode of the specified node.
STATUS	Current status of the specified node.

# show operational

To display all operational data provided as XML schema, use the **show operational** command in EXEC or administration EXEC mode.

**show operational** *mda-class*[*mda-class*][*mda-class/naming=value*][**descriptive**]

## Syntax Description

*mda-class* Name of the management data API (MDA) class to output. To specify a class name in hierarchy, all classes must be specified from the top of the class to the specific class name that you are interested in. MDA classes are case-sensitive.

To view all available MDA classes, use the question mark (?) online help function.

**descriptive** Displays more descriptive information.

## Command Default

No default behavior or values

## Command Modes

EXEC

Administration EXEC

## Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	Support was added for the 2-Port Channelized OC-12/DS0 SPA.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Although the **show operational** command uses the schema database, the command displays the information in a string format like the other **show** commands. No XML related setups or knowledge is required to use the command.

## Task ID

Task ID	Operations
Depends on the MDA class for which you are displaying the information	read

The following example shows sample output from the **show operational** command. Not all the output is shown.

```
RP/0/RSP0/CPU0:router# show operational BGP DefaultVRF GlobalProcessInfo descriptive
[BGP DefaultVRF GlobalProcessInfo]
InStandaloneMode: true[Standalone or Distributed mode]
RouterID: 0.0.0.0[Router ID for the local system]
ConfiguredRouterID: 0.0.0.0[Configured router ID]
LocalAS: 10[Local autonomous system #]
```



```

RestartCount: 1[No of times BGP has started]
ISRedistributeIBGPToIGPsEnabled: false[Redistribute iBGP into IGPs enabled]
IsFastExternalFalloverEnabled: true[Fast external fallover enabled]
IsBestpathMissingMEDIsWorstEnabled: false[Bestpath: Treat missing MED as worst]
.
.
.
DefaultLocalPreference: 100[Default local preference]
KeepAliveTime: 60[Default keepalive timer (seconds)]
HoldTime: 180[Default hold timer (seconds)]
GenericScanPeriod: 60[Period (in seconds) of generic scanner runs]
.
.
.
VrfIsActive: true[VRF state]
VrfName: "default"[Name of the VRF]

```

This example shows sample output from the **show operational** command where only the top-level MDA class is specified. Not all of the output is shown.

```
RP/0/RSP0/CPU0:router# show operational Inventory
```

```

Thu Feb 19 00:54:41.251 PST
[Inventory]
RackTable
 Rack/Number=0
 SlotTable
 Slot/Number=0
 CardTable
 Card/Number=0
 PortSlotTable
 PortSlot/Number=0
 Port
 BasicAttributes
 BasicInfo
 Description: CPU_PORT_0
 VendorType: 1.3.6.1.4.1.9.12.3.1.10
 Name: 0/0/SP/0
 IsFieldReplaceableUnit: false
 CompositeClassCode: 983040
 BasicAttributes
 BasicInfo
 Description: CE Port Slot
 VendorType: 1.3.6.1.4.1.9.12.3.1.5.115
 Name: portslot 0/0/SP/0
 IsFieldReplaceableUnit: false
 CompositeClassCode: 0
 SensorTable
 Sensor/Number=0
 BasicAttributes
 BasicInfo
 Description: Temperature Sensor
 VendorType: 1.3.6.1.4.1.9.12.3.1.8.42
 Name: 0/0/* - host - Inlet0
 CompositeClassCode: 720898
 EnvironmentalMonitorPath: /admin/oper/inventory/
 rack/0/entity/0/entity/0/entity/0/entity/0/attrib/
 Sensor/Number=1
 BasicAttributes
 BasicInfo
 Description: Temperature Sensor
 VendorType: 1.3.6.1.4.1.9.12.3.1.8.42

```

**show operational**

```
Name: 0/0/* - host - Inlet1
CompositeClassCode: 720898
EnvironmentalMonitorPath: /admin/oper/inventory/
 rack/0/entity/0/entity/0/entity/0/entity/1/attrib/
Sensor/Number=2
BasicAttributes
 BasicInfo
 Description: Temperature Sensor
 VendorType: 1.3.6.1.4.1.9.12.3.1.8.42
 Name: 0/0/* - host - Exhaust0
 CompositeClassCode: 720898
```

--More--

# show platform

To display information and status for each node in the system, use the **show platform** command in EXEC or administration EXEC mode.

**show platform** [*node-id*]

<b>Syntax Description</b>	<i>node-id</i>	(Optional) Node for which to display information. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.
<b>Command Default</b>	Status and information are displayed for all nodes in the system.	
<b>Command Modes</b>	Administration EXEC EXEC	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.2	This command was introduced.
	Release 3.9.0	Support was added for the 2-Port Channelized OC-12/DS0 SPA.
<b>Usage Guidelines</b>	<p>The <b>show platform</b> command provides a summary of the nodes in the system, including node type and status.</p> <p>Enter the <b>show platform</b> command in administration EXEC mode to display output for the entire system.</p> <p>Enter the <b>show platform</b> command in EXEC mode to display output for only those nodes that belong to the SDR on which the command is executed.</p> <p>For ASR-9001-S, EP1 will be displayed as, <b>Not allowed online</b>, until the required license is bought.</p>	
<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	system	read (in EXEC mode)
	root-system	read (in administration EXEC mode)

This example shows the sample display output for ASR9912 and ASR9922:

```
RP/0/RSP0/CPU0:router:router(admin) # show platform
Wed Jul 3 11:34:18.487 UTC
Node Type State Config State

0/RP0/CPU0 ASR-9922-RP-SE (Active) IOS XR RUN PWR, NSHUT, MON
0/RP1/CPU0 ASR-9922-RP-TR (Standby) IOS XR RUN PWR, NSHUT, MON
0/FT0/SP FAN TRAY READY
0/FT1/SP FAN TRAY READY
0/0/CPU0 A9K-36x10GE-TR IOS XR RUN PWR, NSHUT, MON
0/1/CPU0 A9K-36x10GE-SE IOS XR RUN PWR, NSHUT, MON
0/2/CPU0 A9K-36x10GE-TR IOS XR RUN PWR, NSHUT, MON
0/3/CPU0 A9K-36x10GE-SE IOS XR RUN PWR, NSHUT, MON
0/4/CPU0 A9K-36x10GE-SE IOS XR RUN PWR, NSHUT, MON
0/5/CPU0 A9K-36x10GE-SE IOS XR RUN PWR, NSHUT, MON
0/6/CPU0 A9K-36x10GE-SE IOS XR RUN PWR, NSHUT, MON
```

## show platform

```

0/7/CPU0 A9K-36x10GE-TR IOS XR RUN PWR, NSHUT, MON
0/8/CPU0 A9K-24x10GE-SE IOS XR RUN PWR, NSHUT, MON
0/9/CPU0 A9K-24x10GE-TR IOS XR RUN PWR, NSHUT, MON
0/PM0/SP PWR-3KW-AC-V2 READY PWR, NSHUT, MON
0/PM1/SP PWR-3KW-AC-V2 READY PWR, NSHUT, MON
0/PM2/SP PWR-3KW-AC-V2 READY PWR, NSHUT, MON
0/PM3/SP PWR-3KW-AC-V2 READY PWR, NSHUT, MON
0/PM4/SP PWR-3KW-AC-V2 READY PWR, NSHUT, MON
0/PM5/SP PWR-3KW-AC-V2 READY PWR, NSHUT, MON
0/FC0/SP ASR-9912-SFC110 OK PWR, NSHUT, MON
0/FC1/SP ASR-9912-SFC110 OK PWR, NSHUT, MON
0/FC2/SP ASR-9912-SFC110 OK PWR, NSHUT, MON
0/FC3/SP ASR-9912-SFC110 OK PWR, NSHUT, MON
0/FC4/SP ASR-9912-SFC110 OK PWR, NSHUT, MON
0/FC5/SP ASR-9912-SFC110 OK PWR, NSHUT, MON
0/FC6/SP ASR-9912-SFC110 OK PWR, NSHUT, MON

```

The following example shows sample output from the **show platform** command:

```
RP/0/RP0/CPU0:router# show platform
```

```

Thu Nov 19 21:44:49.274 UTC
Node Type State Config State

0/RSP0/CPU0 A9K-RSP-4G (Active) IOS XR RUN PWR, NSHUT, MON
0/RSP1/CPU0 A9K-RSP-4G (Standby) IN-RESET PWR, NSHUT, MON
0/1/CPU0 A9K-SIP-700 IOS XR RUN PWR, NSHUT, NMON
0/1/0 SPA-10X1GE-V2 OK PWR, NSHUT, MON
0/1/1 SPA-1X10GE-L-V2 OK PWR, NSHUT, MON
0/3/CPU0 A9K-40GE-B IOS XR RUN PWR, NSHUT, MON
0/4/CPU0 A9K-SIP-700 IOS XR RUN PWR, NSHUT, MON
0/4/1 SPA-2XCHOC12/DS0 OK PWR, NSHUT, MON

```

The following is sample output for the **show platform** command with the *node-id* argument:

```
RP/0/RSP0/CPU0:router# show platform 0/1/cpu0
```

```

Mon Jul 27 22:30:04.752 DST
Node Type State Config State

0/1/CPU0 A9K-40GE-B IOS XR RUN PWR, NSHUT, MON

```

This table describes the significant fields shown in the display.

**Table 39: show platform Field Descriptions**

Field	Description
Node	Identifier of the node in the <i>rack/slot/module</i> notation.
Type	Type of node.
State	Current state of the specified node.
Config State	Current status of the specified node.

# show platform

To display information and status for each node in the system, use the **show platform** command in EXEC or administration EXEC mode.

**show platform** [*node-id*]

<b>Syntax Description</b>	<i>node-id</i>	(Optional) Node for which to display information. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.
---------------------------	----------------	-----------------------------------------------------------------------------------------------------------------------------------

**Command Default** Status and information are displayed for all nodes in the system.

**Command Modes** Administration EXEC  
EXEC

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.2	This command was introduced.
	Release 3.9.0	Support was added for the 2-Port Channelized OC-12/DS0 SPA.

**Usage Guidelines** The **show platform** command provides a summary of the nodes in the system, including node type and status. Enter the **show platform** command in administration EXEC mode to display output for the entire system. Enter the **show platform** command in EXEC mode to display output for only those nodes that belong to the SDR on which the command is executed.

For ASR-9001-S, EP1 will be displayed as, **Not allowed online**, until the required license is bought.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	system	read (in EXEC mode)
	root-system	read (in administration EXEC mode)

This example shows the sample display output for ASR9912 and ASR9922:

```
RP/0/RSP0/CPU0:router:router(admin) # show platform
Wed Jul 3 11:34:18.487 UTC
Node Type State Config State

0/RP0/CPU0 ASR-9922-RP-SE (Active) IOS XR RUN PWR, NSHUT, MON
0/RP1/CPU0 ASR-9922-RP-TR (Standby) IOS XR RUN PWR, NSHUT, MON
0/FT0/SP FAN TRAY READY
0/FT1/SP FAN TRAY READY
0/0/CPU0 A9K-36x10GE-TR IOS XR RUN PWR, NSHUT, MON
0/1/CPU0 A9K-36x10GE-SE IOS XR RUN PWR, NSHUT, MON
0/2/CPU0 A9K-36x10GE-TR IOS XR RUN PWR, NSHUT, MON
0/3/CPU0 A9K-36x10GE-SE IOS XR RUN PWR, NSHUT, MON
0/4/CPU0 A9K-36x10GE-SE IOS XR RUN PWR, NSHUT, MON
0/5/CPU0 A9K-36x10GE-SE IOS XR RUN PWR, NSHUT, MON
0/6/CPU0 A9K-36x10GE-SE IOS XR RUN PWR, NSHUT, MON
```

## show platform

```

0/7/CPU0 A9K-36x10GE-TR IOS XR RUN PWR, NSHUT, MON
0/8/CPU0 A9K-24x10GE-SE IOS XR RUN PWR, NSHUT, MON
0/9/CPU0 A9K-24x10GE-TR IOS XR RUN PWR, NSHUT, MON
0/PM0/SP PWR-3KW-AC-V2 READY PWR, NSHUT, MON
0/PM1/SP PWR-3KW-AC-V2 READY PWR, NSHUT, MON
0/PM2/SP PWR-3KW-AC-V2 READY PWR, NSHUT, MON
0/PM3/SP PWR-3KW-AC-V2 READY PWR, NSHUT, MON
0/PM4/SP PWR-3KW-AC-V2 READY PWR, NSHUT, MON
0/PM5/SP PWR-3KW-AC-V2 READY PWR, NSHUT, MON
0/FC0/SP ASR-9912-SFC110 OK PWR, NSHUT, MON
0/FC1/SP ASR-9912-SFC110 OK PWR, NSHUT, MON
0/FC2/SP ASR-9912-SFC110 OK PWR, NSHUT, MON
0/FC3/SP ASR-9912-SFC110 OK PWR, NSHUT, MON
0/FC4/SP ASR-9912-SFC110 OK PWR, NSHUT, MON
0/FC5/SP ASR-9912-SFC110 OK PWR, NSHUT, MON
0/FC6/SP ASR-9912-SFC110 OK PWR, NSHUT, MON

```

The following example shows sample output from the **show platform** command:

```
RP/0/RP0/CPU0:router# show platform
```

```

Thu Nov 19 21:44:49.274 UTC
Node Type State Config State

0/RSP0/CPU0 A9K-RSP-4G (Active) IOS XR RUN PWR, NSHUT, MON
0/RSP1/CPU0 A9K-RSP-4G (Standby) IN-RESET PWR, NSHUT, MON
0/1/CPU0 A9K-SIP-700 IOS XR RUN PWR, NSHUT, NMON
0/1/0 SPA-10X1GE-V2 OK PWR, NSHUT, MON
0/1/1 SPA-1X10GE-L-V2 OK PWR, NSHUT, MON
0/3/CPU0 A9K-40GE-B IOS XR RUN PWR, NSHUT, MON
0/4/CPU0 A9K-SIP-700 IOS XR RUN PWR, NSHUT, MON
0/4/1 SPA-2XCHOC12/DS0 OK PWR, NSHUT, MON

```

The following is sample output for the **show platform** command with the *node-id* argument:

```
RP/0/RSP0/CPU0:router# show platform 0/1/cpu0
```

```

Mon Jul 27 22:30:04.752 DST
Node Type State Config State

0/1/CPU0 A9K-40GE-B IOS XR RUN PWR, NSHUT, MON

```

This table describes the significant fields shown in the display.

**Table 40: show platform Field Descriptions**

Field	Description
Node	Identifier of the node in the <i>rack/slot/module</i> notation.
Type	Type of node.
State	Current state of the specified node.
Config State	Current status of the specified node.

# show platform slices

To display the status of the slices for an interface, use the **show platform slices** command in the EXEC mode.

```
show platform slices [locationnode-id]
```

<b>Syntax Description</b>	<b>location</b> <i>node-id</i> Interface details.
---------------------------	---------------------------------------------------

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	EXEC
----------------------	------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 5.3.0	

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **hw-module power saving** to power-off / on any of the slices (Slice 0 cannot be powered-off).

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	sysmgr	read

## Example

This example shows how to use the **show platform slices** command:

```
RP/0/RSP0/CPU0:router # sh plat slices
show_slice nodeid 0x0
```

Line Card	Slice	Config	Status
0/0/CPU0	0	Power on	Completed
	1	Power on	Completed
	2	Power on	Completed
	3	Power saving	Completed

# show plugin slot counts

To display cumulative and running counts of card inserts per slot, use the **show plugin slot counts** command in administration EXEC mode.

**show plugin slot counts location** {allnode-id}

<b>Syntax Description</b>	<b>location</b> {all node-id} Displays plugin slot counts on the designated node or all nodes. The <i>node-id</i> argument is expressed in the <i>rack/slot/module</i> notation.
---------------------------	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Administration EXEC
----------------------	---------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.9.1	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **show plugin slot counts** command to display the number of insertions that have been made to the router backplane for a specific line card or RSP. This command can be used only if the BPID-02 card is installed. If the BPID-02 card is not installed, the following error message is displayed:

```
Response error: 'ENVMON' detected the 'warning' condition 'Hardware not available'
```

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	sysmgr	read

## Example

This example illustrates sample output from the **show plugin slot counts** command:

```
RP/0/RSP0/CPU0:router(admin)# show plugin slot counts location all
```

```
Tue Oct 6 13:37:15.706 pst
```

```
Backplane connector slot plugin counters
```

	Current	Cumulative
0/0/CPU0	176	176
0/1/CPU0	11	11
0/2/CPU0	0	0
0/3/CPU0	0	0
0/RSP0/CPU0	0	0
0/RSP1/CPU0	1	1



0/4/CPU0	9	9
0/5/CPU0	0	0
0/6/CPU0	12	12
0/7/CPU0	0	0
0/FT0/SP	4	4
0/FT1/SP	14	14

**Related Commands**

<b>Command</b>	<b>Description</b>
<a href="#">clear plugin slot counts</a>	Clears the running counts of the backplane connector slot plugins.
<a href="#">show canbus</a>	Displays the statistics regarding the CAN bus.

# show redundancy

To display the status of route processor redundancy, use the **show redundancy** command in

EXEC

mode.

**show redundancy** [{**location** {*node-id* | **all**} | **statistics** | **summary**}]

Syntax Description		
<b>location</b> { <i>node-id</i>   <b>all</b> }		(Optional) Specifies the node for which to display LED information. The <i>node-id</i> argument is expressed in the <i>rack/slot/module</i> notation. Use the <b>all</b> keyword to indicate all nodes.
<b>statistics</b>		(Optional) Displays redundancy statistics information.
<b>summary</b>		(Optional) Displays a summary of all redundant node pairs in the router.

**Command Default** Route processor redundancy information is displayed for all nodes in the system.

**Command Modes** EXEC

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **show redundancy** command to display the redundancy status of the route switch processors (RSPs). The **show redundancy** command also displays the boot and switchover history for the RSPs. To view the nonstop routing (NSR) status of the standby RSPs in the system, use the **summary** keyword.

Task ID	Task ID	Operations
	system	read
	basic-services	read (for <b>statistics</b> keyword)

The following example shows sample output from the **show redundancy** command:

```
RP/0/RSP0/CPU0:router# show redundancy location 0/rsp0/cpu0
Thu Jul 30 05:47:12.155 DST
Node 0/RSP0/CPU0 is in ACTIVE role
Node 0/RSP0/CPU0 has no valid partner
```

```

Reload and boot info

A9K-RSP-4G reloaded Tue Jul 14 15:21:30 2009: 2 weeks, 1 day,
14 hours, 25 minutes ago
Active node booted Tue Jul 14 15:21:30 2009: 2 weeks, 1 day,
14 hours, 25 minutes ago

Active node reload "Cause: User initiated forced reload all"

```

**Table 41: show redundancy Field Descriptions**

Field	Description
Node */*/* is in XXX role	<p>Current role of the primary route processor, where (*/*/*) is the route processor ID in the format <i>rack/slot/module</i>, and XXX is the role of the route processor (active or standby).</p> <p>In the example, this field shows that the node with the ID 0/RP0/CPU0 is in active role.</p>
Partner node (*/*/*) is in XXX role	<p>Current role of the secondary (or partner) route processor, where (*/*/*) is the route processor ID in the <i>rack/slot/module</i> format, and XXX is the role of the route processor (active or standby).</p> <p>In the example, this field shows that the node with the ID 0/RP1/CPU0 is in standby role.</p>
Standby node in (*/*/*) is ready	<p>Current state of the standby node, where (*/*/*) is the standby route processor ID.</p> <p>In the example, the standby node is ready.</p>
Standby node in (*/*/*) is NSR-ready	<p>Current state of the standby node regarding nonstop routing (NSR), where (*/*/*) is the standby route processor ID.</p> <p>In the example, the standby node is NSR-ready.</p>
Reload and boot info	<p>General overview of the active and standby route processors' reload and boot history.</p>

# show version

To display the configuration of the system hardware, the software version, the names and sources of configuration files, and the boot images, use the **show version** command in EXEC

mode.

**show version**

**Syntax Description** This command has no keywords or arguments.

**Command Default** No default behavior or values

**Command Modes** EXEC

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **show version** command displays a variety of system information, including hardware and software version, router uptime, boot settings (configuration register), and active software.

Task ID	Task ID	Operations
	basic-services	read

This example shows partial output from the **show version** command:

```
RP/0/RSP0/CPU0:router# show version

Tue Jul 28 05:14:13.670 DST

Cisco IOS XR Software, Version 3.9.0.14I
Copyright (c) 2009 by Cisco Systems, Inc.

ROM: System Bootstrap, Version 1.1(20090521:183759) [ASR9K ROMMON],

PE44_ASR-9010 uptime is 1 week, 6 days, 13 hours, 52 minutes
System image file is "bootflash:disk0/asr9k-os-mbi-3.9.0.14I/mbiasr9k-rp.vm"

cisco ASR9K Series (MPC8641D) processor with 4194304K bytes of memory.
MPC8641D processor at 1333MHz, Revision 2.2

2 Management Ethernet
12 TenGigE
40 GigabitEthernet
219k bytes of non-volatile configuration memory.
```

```

975M bytes of compact flash card.
33994M bytes of hard disk.
1605616k bytes of disk0: (Sector size 512 bytes).
1605616k bytes of disk1: (Sector size 512 bytes).

Configuration register on node 0/RSP0/CPU0 is 0x102
Boot device on node 0/RSP0/CPU0 is disk0:
Package active on node 0/RSP0/CPU0:
asr9k-scfclient, V 3.9.0.14I, Cisco Systems, at disk0:asr9k-scfclient-3.9.0.14I
 Built on Mon Jul 13 08:28:45 DST 2009
 By sjc-lds-208 in /auto/ioxbuild7/production/3.9.0.14I/asr9k/workspace for c4.2.1-p0

asr9k-adv-video, V 3.9.0.14I, Cisco Systems, at disk0:asr9k-adv-video-3.9.0.14I
 Built on Mon Jul 13 10:13:23 DST 2009
 By sjc-lds-208 in /auto/ioxbuild7/production/3.9.0.14I/asr9k/workspace for c4.2.1-p0

asr9k-fpd, V 3.9.0.14I, Cisco Systems, at disk0:asr9k-fpd-3.9.0.14I
 Built on Mon Jul 13 08:44:47 DST 2009
 By sjc-lds-208 in /auto/ioxbuild7/production/3.9.0.14I/asr9k/workspace for c4.2.1-p0

asr9k-diags, V 3.9.0.14I, Cisco Systems, at disk0:asr9k-diags-3.9.0.14I
 Built on Mon Jul 13 08:28:48 DST 2009
 By sjc-lds-208 in /auto/ioxbuild7/production/3.9.0.14I/asr9k/workspace for c4.2.1-p0

asr9k-k9sec, V 3.9.0.14I, Cisco Systems, at disk0:asr9k-k9sec-3.9.0.14I
 Built on Mon Jul 13 08:43:40 DST 2009
 By sjc-lds-208 in /auto/ioxbuild7/production/3.9.0.14I/asr9k/workspace for c4.2.1-p0

asr9k-mgbl, V 3.9.0.14I, Cisco Systems, at disk0:asr9k-mgbl-3.9.0.14I
 Built on Mon Jul 13 10:11:41 DST 2009
 By sjc-lds-208 in /auto/ioxbuild7/production/3.9.0.14I/asr9k/workspace for c4.2.1-p0

asr9k-mcast, V 3.9.0.14I, Cisco Systems, at disk0:asr9k-mcast-3.9.0.14I
 Built on Mon Jul 13 08:40:57 DST 2009
 By sjc-lds-208 in /auto/ioxbuild7/production/3.9.0.14I/asr9k/workspace for c4.2.1-p0

--More--

```

**Table 42: show version Field Descriptions**

Field	Description
Cisco IOS XR Software, Version #	Cisco IOS XR software version number currently running on the router.
ROM	System bootstrap version number currently running on the router.
router uptime	Number of uninterrupted days, hours, minutes, and seconds the system has been up and running.
System image file is	Location and name of the system image file currently running on the router.
Packet over SONET/SDH network interface(s)	Number of Packet-over-SONET/SDH interfaces available on the current router.
SONET/SDH Port controller(s)	Number of SONET or SDH ¹ interfaces available on the current router.

Field	Description
Ethernet/IEEE 802.3 interface(s)	Number of Ethernet or IEEE 802.3 interfaces available on the current router.
GigabitEthernet/IEEE interface(s)	Number of Gigabit Ethernet or IEEE 802.3 interfaces available on the current router.
bytes of non-volatile configuration memory	Available volatile configuration memory, in bytes.
bytes of ATA PCMCIA card at disk 0	ATA PCMCIA ² available on the card in disk 0, in bytes.
Package active on node 0/1/SP	Details about the current software package that is running on the SP node in slot 1.

¹ SDH = Synchronous Digital Hierarchy

² ATA PCMCIA = AT Attachment Personal Computer Memory Card Industry Association

# upgrade hw-module fpd

To manually upgrade the current field-programmable device (FPD) image package on a module, use the **upgrade hw-module fpd** command in Admin EXEC mode.

```
upgrade hw-module fpd {all | fabldr|fpga-type | rommon} [force] location [{node-id | all}]
```

Syntax Description		
<b>all</b>		Upgrades all FPD images on the selected module.
<b>fabldr</b>		Upgrades the fabric-downloader FPD image on the module.
<i>fpga-type</i>		Upgrades a specific field-programmable gate array (FPGA) image on the module. Use the <b>show fpd package</b> command to view all available FPGA images available for a specific module.
<b>rommon</b>		Upgrades the ROMMON image on the module.
<b>force</b>		(Optional) Forces the update of the indicated FPD image package on a shared port adapter (SPA) that meets the minimum version requirements. Without this option, the manual upgrade upgrades only incompatible FPD images.
<b>location</b> { <i>node-id</i>   <b>all</b> }		Specifies the node for which to upgrade the FPD image. The <i>node-id</i> argument is expressed in the <i>rack/slot/subslot</i> notation. Use the <b>all</b> keyword to indicate all nodes.

**Command Default** None

**Command Modes** Admin EXEC mode

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

## Usage Guidelines



**Note** The use of the force option when doing a fpd upgrade is not recommended except under explicit direction from Cisco engineering or TAC.

During the upgrade procedure, the module must be offline (shut down but powered).

Naming notation for the *node-id* argument is *rack/slot/subslot*; a slash between values is required as part of the notation.

- *rack* —Chassis number of the rack.
- *slot* —Physical slot number of the SPA interface processor (SIP).
- *subslot* —Subslot number of the SPA.

For more information about the syntax for the router, use the question mark (?) online help function.

When you start the FPD upgrade procedure or log into a router that is running the FPD upgrade procedure, the following message is displayed to the screen on TTY, console and AUX ports:

```
FPD upgrade in progress on some hardware, reload/configuration change on those
is not recommended as it might cause HW programming failure and result in RMA
of the hardware.
```

If you enter administration mode while the FPD upgrade procedure is running, the following message is displayed to the screen on TTY, console and AUX ports:

```
FPD upgrade in progress on some hardware, reload/configuration change on those
is not recommended as it might cause HW programming failure and result in RMA
of the hardware. Do you want to continue? [Confirm (y/n)]
```

If you enter global configuration mode while the FPD upgrade procedure is running, the following message is displayed to the screen on TTY, console and AUX ports:

```
FPD upgrade in progress on some hardware, configuration change on those is not
recommended as it might cause HW programming failure and result in RMA of the
hardware. Do you want to continue? [Confirm (y/n)]
```

When the FPD upgrade global timer expires, the following warning message displayed to the screen.

```
FPD upgrade has exceeded the maximum time window, the process will terminate now.
Please check the status of the hardware and reissue the upgrade command if required.
```

Task ID	Task ID	Operations
	sysmgr	read, write

The following example shows how to upgrade the default FPGA on a SPA:

```
RP/0/RSP0/CPU0:router# admin
RP/0/RSP0/CPU0:router(admin)# upgrade hw-module fpd fpga location 0/1/4
```

% RELOAD REMINDER:

- The upgrade operation of the target module will not interrupt its normal operation. However, for the changes to take effect, the target module will need to be manually reloaded after the upgrade operation. This can be accomplished with the use of "hw-module <target> reload" command.
- If automatic reload operation is desired after the upgrade, please use the "reload" option at the end of the upgrade command.
- The output of "show hw-module fpd location" command will not display correct version information after the upgrade if the target module is not reloaded.



Continue? [confirm] **y**

```
SP/0/1/SP:Dec 22 05:41:17.920 : upgrade_daemon[125]: programming...with file
/net/node0_RP1_CPU0/asr9k-lc-3.3.83/fpd/ucode/fpga_gladiator_sw0.6.xsvf
SP/0/1/SP:Dec 22 05:41:28.900 : upgrade_daemon[125]: ...programming...
SP/0/1/SP:Dec 22 05:41:28.906 : upgrade_daemon[125]: ...it will take a while...
SP/0/1/SP:Dec 22 05:41:29.004 : upgrade_daemon[125]: ...it will take a while...
SP/0/1/SP:Dec 22 05:43:03.432 : upgrade_daemon[125]: ...programming...
SP/0/1/SP:Dec 22 05:43:03.438 : upgrade_daemon[125]: ...it will take a while...
Successfully upgraded spa fpga instance 4 on location 0/1/4.
```

■ upgrade hw-module fpd



## Manageability Commands

---

This chapter describes the Cisco IOS XR software commands used to enable the HTTP server, enable router management through Extensible Markup Language (XML) agent services, and support the Common Object Request Broker Architecture (CORBA) infrastructure.

The XML Parser Infrastructure provides parsing and generation of XML documents with Document Object Model (DOM), Simple API for XML (SAX), and Document Type Definition (DTD) validation capabilities:

- DOM allows customers to programmatically create, manipulate, and generate XML documents.
- SAX supports user-defined functions for XML tags.
- DTD allows for validation of defined document types.
- [iteration, on page 416](#)
- [streaming, on page 418](#)
- [show xml schema, on page 419](#)
- [throttle, on page 421](#)
- [xml agent, on page 422](#)
- [xml agent ssl, on page 423](#)
- [xml agent tty, on page 424](#)

# iteration

To configure the iteration size for large XML agent responses, use the `iteration` command in xml agent configuration mode. To revert to the default iteration settings, use the `no` form of this command.

**iteration** {**off** | **on** **size** *iteration-size*}  
**no iteration**

Syntax Description	off	on	size <i>iteration-size</i>
	Disables iteration, meaning that the entire XML response is returned, regardless of its size. Use of this option is not recommended.	Enables iteration, meaning that large XML responses are broken into chunks according to the iteration chunk size.	Specifies the size of the iteration chunk, in Kbytes. Values can range from 1 to 100,000.

**Command Default** Iteration is enabled; the *iteration-size* is 48.

**Command Modes** XML agent  
 TTY XML agent  
 SSL XML agent

Command History	Release	Modification
	Release 3.9.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

When the XML agent returns a large response, it splits the response into chunks and returns one chunk at a time. External clients then need to send a GetNext request to obtain the next chunk. Use the **iteration** command to control the size of iteration chunks. A larger chunk value allows larger chunks to be received in a shorter period of time, possibly making the router system busier. A smaller chunk value allows smaller chunks to be received over a longer period of time, but does not make the router busy. You can also specify to disable iteration completely using the **iteration off** command.



**Note** It is not recommended to disable iteration, since this could result in large transient memory usage.

To specify the TTY or SSL iteration size specifically, use the **iteration** command from the appropriate command mode.

Task ID	Task ID	Operations
	config-services	read, write

### Example

The following example shows how to configure the iteration chunk size to 100 Kbytes.

```
RP/0/RSP0/CPU0:router(config)# xml agent
RP/0/RSP0/CPU0:router(config-xml)# iteration on size 100
```

The following example shows how to disable iteration:

```
RP/0/RSP0/CPU0:router(config)# xml agent
RP/0/RSP0/CPU0:router(config-xml)# iteration off
```

The following example shows how to turn on iteration with the default iteration size:

```
RP/0/RSP0/CPU0:router(config)# xml agent
RP/0/RSP0/CPU0:router(config-xml)# no iteration off
```

The following example shows how to change the iteration size to the default iteration size.

```
RP/0/RSP0/CPU0:router(config)# xml agent
RP/0/RSP0/CPU0:router(config-xml)# no iteration on size 100
```

The following example shows how to change the iteration size of the TTY agent to 3 Kbytes:

```
RP/0/RSP0/CPU0:router(config)# xml agent tty
RP/0/RSP0/CPU0:router(config-xml-tty)# iteration on size 3
```

The following example shows how to turn off the iteration of the SSL agent:

```
RP/0/RSP0/CPU0:router(config)# xml agent ssl
RP/0/RSP0/CPU0:router(config-xml-ssl)# iteration off
```

### Related Topics

[xml agent](#), on page 422

[xml agent ssl](#), on page 423

[xml agent tty](#), on page 424

# streaming

To configure the streaming size of the response while the XML agent is retrieving data from the source, use the **streaming** command in the appropriate mode.

**streaming on** *size size in kbytes*

<b>Syntax Description</b>	<b>size</b> <i>size in kbytes</i> Streaming size of the xml response. Range is 1 to 100000.
---------------------------	---------------------------------------------------------------------------------------------

<b>Command Default</b>	Default is 48 KB.
------------------------	-------------------

<b>Command Modes</b>	XML agent mode
----------------------	----------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 4.1	This command was introduced.

<b>Usage Guidelines</b>	Iteration must be off. The sub-response block size is a configurable value specific to each transport mechanisms on the router (the XML agent for the dedicated TCP connection and Secure Shell (SSH), Telnet, or Secure Sockets Layer (SSL) dedicated TCP connection).
-------------------------	-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	config-services	read, write

## Example

This example shows how to configure the streaming size to 100 KB:

```
RP/0/RSP0/CPU0:router (config) # xml agent
RP/0/RSP0/CPU0:router (config-xml) # streaming on size 100
```

# show xml schema

To browse the XML schema and data, use the **show xml schema** command in

EXEC

mode.

**show xml schema**

**Syntax Description** This command has no keywords or arguments.

**Command Default** None

**Command Modes** EXEC

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **show xml schema** command runs the XML schema browser so that you can browse the XML schema and data.

Task ID	Task ID	Operations
	config-services	read

This example shows how to enter the XML schema browser and the available commands:

```
RP/0/RSP0/CPU0:router# show xml schema

Username: xxxx
Password:
Enter 'help' or '?' for help
xml-schema[config]:> ?

config oper action
adminoper adminaction cd
pwd classinfo list
ls datalist walk
walkdata get hierarchy
quit exit help
xml-schema[config]:>
```

## Related Topics

[copy](#)



# throttle

To configure the XML agent processing capabilities, use the **throttle** command in XML agent configuration mode.

```
throttle {memory size | process-rate tags}
```

Syntax Description	memory	process-rate
	<i>size</i>	<i>tags</i>
	Specifies the XML agent memory size.	Specifies the XML agent processing rate.
	Maximum memory usage of XML agent per session in MB. Values can range from 100 to 600. The default is 300.	Number of tags that the XML agent can process per second. Values can range from 1000 to 30000.

**Command Default** The process rate is not throttled; memory size is 300 MB.

**Command Modes** XML agent configuration

Command History	Release	Modification
	Release 3.8.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **throttle** command to control CPU time used by the XML agent when it handles large data.

Task ID	Task ID	Operation
	config-services	read, write

## Example

This example illustrates how to configure the number of tags that the XML agent can process to 1000:

```
RP/0/RSP0/CPU0:router(config)# xml agent
RP/0/RSP0/CPU0:router(config-xml-agent)# throttle process-rate 1000
```

# xml agent

To enable Extensible Markup Language (XML) requests over a dedicated TCP connection and enter XML agent configuration mode, use the **xml agent** command in

global configuration

mode. To disable XML requests over the dedicated TCP connection, use the **no** form of this command.



**Note** This command enables a new, enhanced-performance XML agent. The **xml agent tty** command enables the legacy XML agent and is supported for backward compatibility.

**xml agent**  
**no xml agent**

**Command Default** XML requests are disabled.

**Command Modes** Global configuration

Command History	Release	Modification
	Release 3.8.0	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

There are two XML agents: a legacy XML agent and an enhanced-performance XML agent. We recommend that you use the enhanced-performance XML agent. The legacy agent is supported for backward compatibility. Use the **xml agent** command to enable the enhanced-performance XML agent. Use the **xml agent tty** command to enable the legacy XML agent.

Use the **no** form of the **xml agent** command to disable the enhanced-performance XML agent.

Task ID	Task ID	Operations
	config-services	read, write

This example shows how to enable XML requests over a dedicated TCP connection:

```
RP/0/RSP0/CPU0:router(config)# xml agent
```

# xml agent ssl

To enable Extensible Markup Language (XML) requests over Secure Socket Layer (SSL) and enter SSL XML agent configuration mode, use the **xml agent ssl** command in

global configuration

mode. To disable XML requests over SSL, use the **no** form of this command.

**xml agent ssl**  
**no xml agent ssl**

---

**Command Default** SSL agent is disabled by default.

---

**Command Modes** Global configuration

---

Command History	Release	Modification
	Release 3.9.0	This command was introduced.

---



---

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The k9sec package is required to use the SSL agent. The configuration is rejected during commit when the security software package is not active on the system. When the security software package is deactivated after configuring SSL agent, the following syslog message is displayed to report that the SSL agent is no longer available.

```
xml_dedicated_ssl_agent[420]:
%MGBL-XML_TTY-7-SSLINIT : K9sec pie is not active, XML service over
SSL is not available.
```

---

Task ID	Task ID	Operations
	config-services	read, write

---

This example shows how to enable XML requests over SSL:

```
RP/0/RSP0/CPU0:router(config)# xml agent ssl
```

# xml agent tty

To enable Extensible Markup Language (XML) requests over Secure Shell (SSH) and Telnet and enter TTY XML agent configuration mode, use the **xml agent tty** command in

global configuration

mode. To disable XML requests over SSH and Telnet, use the **no** form of this command.



**Note** This command enables a legacy XML agent that has been superseded by an enhanced performance XML agent and is supported only for backward compatibility. To enable the enhanced-performance XML agent, use the **xml agent** command.

**xml agent tty**  
**no xml agent tty**

**Command Default** XML requests over SSH and Telnet are disabled.

**Command Modes** Global configuration

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

There are two XML agents: a legacy XML agent and an enhanced-performance XML agent. We recommend that you use the enhanced-performance agent. The legacy agent is supported for backward compatibility. The **xml agent tty** command enables the legacy XML agent. Use the **xml agent** command to enable the enhanced-performance XML agent.

Use the **no** form of the **xml agent tty** command to disable the legacy XML agent.

Task ID	Task ID	Operations
	config-services	read, write

This example shows how to enable XML requests over Secure Shell (SSH) and Telnet:

```
RP/0/RSP0/CPU0:router(config)# xml agent tty
```



## Network Time Protocol (NTP) Commands

This chapter describes the Cisco IOS XR Network Time Protocol (NTP) commands used to perform basic network time management tasks, including synchronizing time settings and coordinating time distribution over the network.

When an NTP server or client is configured, NTP features are available on all router interfaces. NTP features can be disabled for any specified interface, local or remote, to the route processor (RP).

For detailed information about NTP concepts, configuration tasks, and examples, see the *Implementing NTP on Cisco IOS XR Software* configuration module in *System Management Configuration Guide for Cisco ASR 9000 Series Routers*.

- [access-group \(NTP\)](#), on page 426
- [authenticate \(NTP\)](#), on page 428
- [authentication-key \(NTP\)](#), on page 430
- [broadcast](#), on page 432
- [broadcast client](#), on page 434
- [broadcastdelay](#), on page 435
- [interface \(NTP\)](#), on page 436
- [master](#), on page 438
- [master primary-reference-clock](#), on page 440
- [max-associations](#), on page 442
- [multicast client](#), on page 443
- [multicast destination](#), on page 444
- [ntp](#), on page 445
- [ntp clear](#), on page 447
- [ntp reset drift](#), on page 448
- [peer \(NTP\)](#), on page 450
- [server \(NTP\)](#), on page 453
- [show calendar](#), on page 456
- [show ntp associations](#), on page 457
- [show ntp status](#), on page 461
- [source \(NTP\)](#), on page 463
- [trusted-key](#), on page 465
- [update-calendar](#), on page 466

## access-group (NTP)

To control access to Network Time Protocol (NTP) services for an IPv4 or IPv6 access list, use the **access-group** command in one of the NTP configuration modes. To remove the **access-group** command from the configuration file and restore the system to its default condition with respect to this command, use the **no** form of this command.

```
access-group [vrf vrf-name] [{ipv4 | ipv6}] {peer | query-only | serve | serve-only} access-list-name
no access-group [vrf vrf-name] [{ipv4 | ipv6}] {peer | query-only | serve | serve-only}
```

### Syntax Description

<b>vrf</b> <i>vrf-name</i>	(Optional) Applies the access control configuration to a specified nondefault VRF. If not specified, the configuration is applied to the default VRF.
<b>ipv4</b>	(Optional) Specifies an IPv4 access list (default).
<b>ipv6</b>	(Optional) Specifies an IPv6 access list.
<b>peer</b>	Allows time requests and NTP control queries and allows a networking device to synchronize to the remote system.
<b>query-only</b>	Allows only NTP control queries. Cisco IOS XR software uses NTP Version 4, but the RFC for Version 3 (RFC 1305: <i>Network Time Protocol (Version 3)—Specification, Implementation and Analysis</i> ) still applies.
<b>serve</b>	Allows time requests and NTP control queries, but does not allow the networking device to synchronize to the remote system.
<b>serve-only</b>	Allows only time requests.
<i>access-list-name</i>	Name of an IPv4 or IPv6 access list.

### Command Default

No NTP access control is configured.

### Command Modes

NTP configuration  
VRF-specific NTP configuration

### Command History

Release	Modification
Release 3.7.2	This command was introduced.

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The access group options are scanned in the following order from least restrictive to most restrictive:

1. **peer**—Allows time requests and NTP control queries and allows the router to synchronize itself to a system whose address passes the access list criteria.

2. **serve**—Allows time requests and NTP control queries, but does not allow the router to synchronize itself to a system whose address passes the access list criteria.
3. **serve-only**—Allows only time requests from a system whose address passes the access list criteria.
4. **query-only**—Allows only NTP control queries from a system whose address passes the access list criteria.

Access is granted for the first match that is found. If no access groups are specified, all access is granted to all sources. If any access groups are specified, only the specified access is granted. This facility provides minimal security for the time services of the system. However, it can be circumvented by a determined programmer. If tighter security is desired, use the NTP authentication facility.

If you use the **access-group** command in a VRF-specific NTP configuration mode, the command is applied to the specific VRF. If you are not in a VRF-specific NTP configuration mode, the command is applied to the default VRF unless you use the **vrf** *vrf-name* keyword and argument to specify a VRF.

**Task ID****Task ID    Operations**


---

```
ip-services read,
 write
```

---

The following example shows how to configure the router to allow itself to be synchronized by a peer from an IPv4 access list named `access1` and to restrict access to allow only time requests from an IPv4 access list named `access2`:

```
RP/0/RSP0/CPU0:router(config-ntp)# access-group peer access1
RP/0/RSP0/CPU0:router(config-ntp)# access-group serve-only access2
```

The following example shows how to configure the router to allow itself to be synchronized by peers from the IPv6 access list named `access20` that route through the `vrf10` VRF:

```
RP/0/RSP0/CPU0:router(config-ntp)# access-group vrf vrf10 ipv6 peer access20
```

**Related Commands**

Command	Description
<b>ipv4 access-list</b>	Defines an IPv4 access list by name.
<b>ipv6 access-list</b>	Defines an IPv6 access list by name.
<b>vrf</b>	Configures a VRF instance for a routing protocol.

# authenticate (NTP)

To enable Network Time Protocol (NTP) authentication, use the **authenticate** command in NTP configuration mode. To restore the system to its default condition, use the **no** form of this command.

**authenticate**  
**no authenticate**

**Syntax Description** This command has no keywords or arguments.

**Command Default** No NTP authentication is configured.

**Command Modes** NTP configuration

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **authenticate** command to prevent the system from synchronizing with unauthenticated and unconfigured network peers.

If the **authenticate** command is specified, and when a symmetric active, broadcast, or multicast NTP packet is received, the system will not synchronize to the peer unless the packet carries one of the authentication keys specified in the **trusted-key** command.

You must enable **authenticate** when enabling **broadcast client** or **multicast client** command in NTP configuration mode unless you have other measures (such as using the **access-group** command in NTP configuration mode) to prevent unauthorized hosts from communicating with the NTP service on the device.

The **authenticate** command does not ensure authentication of peer associations that are created using the **server** and **peer** commands in NTP configuration mode. When creating associations using the **server** and **peer** commands in NTP configuration mode, specify the **key** keyword to ensure the authentication of packets that move to and from the remote peer.

Use the **no authenticate** command to allow synchronizing with unauthenticated and unconfigured network peers.

Task ID	Task ID	Operations
	ip-services	read, write

The following example shows how to configure the system to synchronize only to a system that provides an authentication key 42 in its NTP packets:



```
RP/0/RSP0/CPU0:router(config)# ntp
RP/0/RSP0/CPU0:router(config-ntp)# authenticate
RP/0/RSP0/CPU0:router(config-ntp)# authentication-key 42 md5 clear key1
RP/0/RSP0/CPU0:router(config-ntp)# trusted-key 42
```

### Related Topics

[authentication-key \(NTP\)](#), on page 430

[trusted-key](#), on page 465

# authentication-key (NTP)

To define an authentication key for a trusted Network Time Protocol (NTP) time source, use the **authentication-key** command in NTP configuration mode. To restore the system to its default condition, use the **no** form of this command.

```
authentication-key key-number md5 [{clear | encrypted}] key-name
no authentication-key key-number
```

## Syntax Description

<i>key-number</i>	Authentication key. A number in the range from 1 to 65535.
<b>md5</b>	Provides message authentication support using the Message Digest 5 (MD5) algorithm.
<b>clear</b>	(Optional) Specifies that the key value entered after this keyword is unencrypted.
<b>encrypted</b>	(Optional) Specifies that the key value entered after this keyword is encrypted.
<i>key-name</i>	Key value. The maximum length is 32 characters.

## Command Default

No authentication key is defined for NTP.

## Command Modes

NTP configuration

## Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	No modification.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **authentication-key** command to define authentication keys for use with trusted NTP time sources.



### Note

When this command is written to NVRAM, the key is encrypted so that it is not displayed when the configuration is displayed.

## Task ID

Task ID	Operations
ip-services	read, write

The following example shows how to configure the system to synchronize only to systems providing authentication key 42 in their NTP packets:

```
RP/0/RSP0/CPU0:router (config) # ntp
```

```
RP/0/RSP0/CPU0:router(config-ntp)# authenticate
RP/0/RSP0/CPU0:router(config-ntp)# authentication-key 42 md5 clear key1
RP/0/RSP0/CPU0:router(config-ntp)# trusted-key 42
```

### Related Topics

[authenticate \(NTP\)](#), on page 428

[peer \(NTP\)](#), on page 450

[server \(NTP\)](#), on page 453

[trusted-key](#), on page 465

# broadcast

To create a Network Time Protocol (NTP) broadcast server on a specified NTP interface, use the **broadcast** command in NTP interface configuration mode. To remove the command from the configuration file and restore the system to its default condition, use the **no** form of this command.

**broadcast** [**destination** *ip-address*] [**key** *key-id*] [**version** *number*]  
**no broadcast** [**destination** *ip-address*] [**key** *key-id*] [**version** *number*]

## Syntax Description

<b>destination</b> <i>ip-address</i>	(Optional) Specifies the host IPv4 address.
<b>key</b> <i>key-id</i>	(Optional) Defines the authentication key, where <i>key-id</i> is the authentication key to use when sending packets to this peer. The key identified by the <i>key-id</i> value is also used for packets received from the peer.
<b>version</b> <i>number</i>	(Optional) Specifies a number from 1 to 4, indicating the NTP version.

## Command Default

No NTP broadcast servers are configured.

## Command Modes

NTP interface configuration

## Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	No modification.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **broadcast** command to create an NTP broadcast server on an NTP interface to send NTP broadcast packets.

Use the **broadcast client** command to set a specific interface to receive NTP broadcast packets.

## Task ID

Task ID	Operations
ip-services	read, write

The following example shows how to configure interface 0/0/0/1 to send NTP packets to destination host IP address 10.0.0.0:

```
RP/0/RSP0/CPU0:router(config)# ntp
RP/0/RSP0/CPU0:router(config-ntp)# interface tengige 0/0/0/1
RP/0/RSP0/CPU0:router(config-ntp-int)# broadcast destination 10.0.0.0
```

**Related Topics**

[broadcast client](#), on page 434

[broadcastdelay](#), on page 435

# broadcast client

To allow a networking device to receive Network Time Protocol (NTP) broadcast packets on an interface, use the **broadcast client** command in NTP interface configuration mode. To remove the configuration and restore the system to its default condition, use the **no** form of this command.

**broadcast client**  
**no broadcast client**

**Syntax Description** This command has no keywords or arguments.

**Command Default** No NTP broadcast clients are configured.

**Command Modes** NTP interface configuration

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **broadcast client** command to configure and create an NTP broadcast client and to associate the client with an interface to receive and handle NTP broadcast packets. If no NTP client has been created for an interface, the received NTP broadcast packets are dropped. Use this command to allow the system to listen to broadcast packets on an interface-by-interface basis.

To prevent synchronization with unauthorized systems, whenever this command is specified, authentication must be enabled using the **authenticate (NTP)** command or access must be restricted to authorized systems using the **access-group (NTP)** command. See the documentation of the respective commands for more information.

Task ID	Task ID	Operations
	ip-services	read, write

The following example shows how to configure interface 0/0/0/1 to send NTP packets:

```
RP/0/RSP0/CPU0:router(config)# ntp interface tengige 0/0/0/1
RP/0/RSP0/CPU0:router(config-ntp-int)# broadcast client
```

## Related Topics

[broadcast](#), on page 432

[broadcastdelay](#), on page 435

# broadcastdelay

To set the estimated round-trip delay between a Network Time Protocol (NTP) client and an NTP broadcast server, use the **broadcastdelay** command in NTP configuration mode. To restore the system to its default condition, use the **no** form of this command.

**broadcastdelay** *microseconds*  
**no broadcastdelay** *microseconds*

<b>Syntax Description</b>	<i>microseconds</i> Estimated round-trip time for NTP broadcasts, in microseconds. The range is from 1 to 999999. The default is 3000.
---------------------------	----------------------------------------------------------------------------------------------------------------------------------------

<b>Command Default</b>	<i>microseconds</i> : 3000
------------------------	----------------------------

<b>Command Modes</b>	NTP configuration
----------------------	-------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **broadcastdelay** command to change the default round-trip delay time on a networking device that is configured as a broadcast client.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	ip-services	read, write

The following example shows how to set the estimated round-trip delay between a networking device and the broadcast client to 5000 microseconds:

```
RP/0/RSP0/CPU0:router(config-ntp) # broadcastdelay 5000
```

# interface (NTP)

To enter a Network Time Protocol (NTP) interface mode and run NTP interface configuration commands, use the **interface** command in one of the NTP configuration modes. To remove an NTP interface configuration, use the **no** form of this command.

```
interface type interface-path-id [vrf vrf-name] [disable]
no interface type interface-path-id [disable]
```

## Syntax Description

<i>type</i>	Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	Physical interface or virtual interface.
<b>Note</b>	Use the <b>show interfaces</b> command to see a list of all interfaces currently configured on the router.
	For more information about the syntax for the router, use the question mark (?) online help function.
<b>vrf</b> <i>vrf-name</i>	(Optional) Applies the interface configuration to a specific nondefault VRF.
<b>disable</b>	(Optional) Disables NTP on the specified interface.

## Command Default

No NTP interfaces are configured.

## Command Modes

NTP configuration mode  
VRF-specific NTP configuration mode

## Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	Support was added for the <b>vrf</b> keyword and the <i>vrf-name</i> argument.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **interface** command to place the router in NTP interface configuration mode, from which NTP broadcast and multicast servers and clients can be configured. By default, after the NTP process is started, NTP features become available for all interfaces. To exit NTP interface configuration mode, use the **exit** command.

If you use the **interface** command in a VRF-specific NTP configuration mode, the command is applied to the specific VRF. If you are not in a VRF-specific NTP configuration mode, the command is applied to the default VRF unless you use the **vrf** *vrf-name* keyword and argument to specify a VRF.

By default, NTP is enabled on every interface. To disable NTP on a specific interface, use the **interface** command with the **disable** keyword. To reenable NTP on an interface, use the **no** form of the **interface** command with the **disable** keyword.



Task ID	Task ID	Operations
	ip-services	read, write

The following example shows how to enter NTP configuration mode, specify an NTP interface to be configured, and enter NTP interface configuration mode:

```
RP/0/RSP0/CPU0:router(config)# ntp
RP/0/RSP0/CPU0:router(config-ntp)# interface POS 0/1/0/0
RP/0/RSP0/CPU0:router(config-ntp-int)#
```

The following example shows how to enter a VRF-specific NTP interface configuration mode:

```
RP/0/RSP0/CPU0:router(config)# ntp
RP/0/RSP0/CPU0:router(config-ntp)# interface TenGigE 0/1/1/0 vrf vrf_10
RP/0/RSP0/CPU0:router(config-ntp-int)#
```

The following example shows a different way to enter a VRF-specific NTP interface configuration mode:

```
RP/0/RSP0/CPU0:router(config)# ntp vrf vrf_10
RP/0/RSP0/CPU0:router(config-ntp-vrf)# interface TenGigE 0/1/1/0
RP/0/RSP0/CPU0:router(config-ntp-int)#
```

# master

To configure the router to use its own Network Time Protocol (NTP) master clock to synchronize with peers when an external NTP source becomes unavailable, use the **master** command in NTP configuration mode. To restore the system to its default condition, use the **no** form of this command.

**master** [*stratum*]  
**no master** [*stratum*]

## Syntax Description

*stratum* (Optional) NTP stratum number that the system claims. Range is from 1 to 15. The default is 8.

## Command Default

By default, the master clock function is disabled. When the function is enabled, the default stratum is 8.

## Command Modes

NTP configuration

## Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	No modification.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

NTP uses the concept of a “stratum” to describe how many NTP “hops” away a machine is from an authoritative time source. A stratum 1 time server has a radio or atomic clock attached directly. A stratum 2 time server receives its time through NTP from a stratum 1 time server, a stratum 3 from a stratum 2, and so on.



### Caution

Use the **master** command with extreme caution. It is easy to override other valid time sources using this command, especially if a low-stratum number is configured. Configuring multiple machines in the same network with the **master** command can lead to instability in time-keeping if the machines do not agree on the time.

The networking device is normally synchronized, directly or indirectly, with an external system that has a clock. Cisco IOS XR software does not support directly attached radio or atomic clocks. The **master** command should be used only when there is a temporary disruption in a reliable time service. It should not be employed as an alternative source by itself in the absence of a real-time service.

If the system has the **master** command configured and it cannot reach any clock that has a lower stratum number, the system claims to be synchronized at the configured stratum number. Other systems synchronize with it through NTP.



### Note

The system clock must have been manually set from some source before the **master** command has an effect. This precaution protects against the distribution of erroneous time after the system is restarted.

Task ID	Task ID	Operations
	ip-services	read, write

The following example shows how to configure a networking device as an NTP master clock to which peers may synchronize:

```
RP/0/RSP0/CPU0:router(config)# ntp
RP/0/RSP0/CPU0:router(config-ntp)# master 9
```

# master primary-reference-clock

To configure the router to use PTP and external timing sources, such as PTP grandmaster, Data over Cable Service Interface Specification (DOCSIS) Timing Interface [DTI] or global positioning system (GPS) clock, as the time-of-day source for NTP and operating system time, use the **master primary-reference-clock** command in NTP configuration mode. To remove the PTP configuration, use the **no** form of this command.

**master primary-reference-clock**  
**no master primary-reference-clock**

**Syntax Description** This command has no keywords or arguments.

**Command Default** PTP is not used as the time-of-day source for NTP.

**Command Modes** NTP configuration

Command History	Release	Modification
	Release 4.3.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

PTP must be enabled on the router before this command can be used. If PTP is not enabled, you receive an error message similar to the following when you try to commit the configuration:

```
RP/0/RSP0/CPU0:router(config)# ntp master primary-reference-clock
RP/0/RSP0/CPU0:router(config)# commit

% Failed to commit one or more configuration items. Please issue
'show configuration failed' from this session to view the errors

RP/0/RSP0/CPU0:router(config)# show configuration failed
[:::]
ntp
 master primary-reference-clock
!!% 'ip-ntp' detected the 'fatal' condition 'PTP is not supported on this platform'
!
end
```

To verify that PTP is used as the reference clock, use the **show ntp association** command.

```
RP/0/RSP0/CPU0:router# show ntp association

 address ref clock st when poll reach delay offset disp
*~127.127.45.1 .PTP. 0 54 64 377 0.00 6.533 1.905

* sys_peer, # selected, + candidate, - outlayer, x falseticker, ~ configured
```

Task ID	Task ID	Operation
	ip-services	read, write

This example shows how to configure PTP as the reference clock for NTP:

```
RP/0/RSP0/CPU0:router(config)# ntp
RP/0/RSP0/CPU0:router(config-ntp)# master primary-reference-clock
```

### Related Topics

[master](#), on page 438

# max-associations

To set the maximum number of Network Time Protocol (NTP) associations, use the **max-associations** command in NTP configuration mode. To restore the default setting, use the **no** form of this command.

**max-associations** *number*  
**no max-associations** *number*

<b>Syntax Description</b>	<i>number</i> Maximum number of NTP associations. Range is from 0 to 4294967295. The default is 100.
---------------------------	------------------------------------------------------------------------------------------------------

<b>Command Default</b>	The default setting for the maximum number of NTP associations is 100.
------------------------	------------------------------------------------------------------------

<b>Command Modes</b>	NTP configuration
----------------------	-------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

Use the **max-associations** command to specify the maximum number of associations for an NTP server.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	ip-services	read, write

The following example shows how to set the maximum number of associations to 200:

```
RP/0/RSP0/CPU0:router(config)# ntp
RP/0/RSP0/CPU0:router(config-ntp)# max-associations 200
```

## Related Topics

[show ntp associations](#), on page 457

# multicast client

To configure an NTP interface as an NTP multicast client, use the **multicast client** command in NTP interface configuration mode. To remove the NTP multicast client configuration from an interface, use the **no** form of this command.

```
multicast client [ip-address]
no multicast client [ip-address]
```

<b>Syntax Description</b>	<i>ip-address</i> IPv4 or IPv6 IP address of the multicast group to join. The default is the IPv4 address 224.0.1.1.				
<b>Command Default</b>	The interface is not configured as an NTP multicast client.				
<b>Command Modes</b>	NTP interface configuration				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 3.9.0</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 3.9.0	This command was introduced.
Release	Modification				
Release 3.9.0	This command was introduced.				

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **multicast client** command to configure an NTP interface to receive multicast packets that are sent to an IPv4 or IPv6 multicast group IP address. If you do not specify an IP address, the interface is configured to receive multicast packets sent to the IPv4 multicast group address 224.0.1.1. You can configure multiple multicast groups on the same interface.

To prevent synchronization with unauthorized systems, whenever this command is specified, authentication must be enabled using the **authenticate (NTP)** command or access must be restricted to authorized systems using the **access-group (NTP)** command. See the documentation of the respective commands for more information.

Task ID	Task ID	Operations
	ip-services	read, write

The following example shows how to configure the router to receive NTP multicast packets to the multicast group address of 224.0.1.1:

```
RP/0/RSP0/CPU0:router(config)# ntp interface TenGigE 0/1/1/0
RP/0/RSP0/CPU0:router(config-ntp-int)# multicast client
```

## Related Topics

[multicast destination](#), on page 444

# multicast destination

To configure an NTP interface as an NTP multicast server, use the **multicast destination** command in NTP interface configuration mode. To remove the NTP multicast server configuration from an interface, use the **no** form of this command.

```
multicast destination ip-address [key key-id] [ttl ttl] [version number]
no multicast destination ip-address [key key-id] [ttl ttl] [version number]
```

Syntax Description		
	<i>ip-address</i>	The IPv4 or IPv6 multicast group IP address to which to send NTP multicast packets.
	<b>key</b> <i>key-id</i>	(Optional) Specifies an authentication key, where the value of the <i>key-id</i> argument is the authentication key to use when sending multicast packets to the specified multicast group.
	<b>ttl</b> <i>ttl</i>	(Optional) Specifies the time to live (TTL) of a multicast packet.
	<b>version</b> <i>number</i>	(Optional) Specifies the NTP version number.

**Command Default** The interface is not configured as an NTP multicast server.

**Command Modes** NTP interface configuration

Command History	Release	Modification
	Release 3.9.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	ip-services	read, write

The following example shows how to configure the router to send NTP multicast packets to the multicast group address of 224.0.1.1:

```
RP/0/RSP0/CPU0:router(config)# ntp interface TenGigE 0/1/1/0
RP/0/RSP0/CPU0:router(config-ntp-int)# multicast destination 224.0.1.1
```

## Related Topics

[multicast client](#), on page 443



# ntp

To enter Network Time Protocol (NTP) configuration mode and run NTP configuration commands, use the **ntp** command in

global

configuration mode.

**ntp** [**vrf** *vrf-name*]

<b>Syntax Description</b>	<b>vrf</b> <i>vrf-name</i> (Optional) Enters a VRF-specific NTP configuration mode.
---------------------------	-------------------------------------------------------------------------------------

<b>Command Default</b>	No defaults behavior or values
------------------------	--------------------------------

<b>Command Modes</b>	Global configuration
----------------------	----------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.2	This command was introduced.
	Release 3.9.0	Support was added for the <b>vrf</b> <i>vrf-name ip-address</i> keyword and arguments.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

NTP configuration commands can also be run from global configuration mode by preceding the command string with the **ntp** keyword. From NTP configuration mode, the following NTP configuration commands are available:

```
RP/0/RSP0/CPU0:router(config-ntp)# ?
```

```

access-group Control NTP access
authenticate Authenticate time sources
authentication-key Authentication key for trusted time sources
broadcastdelay Estimated round-trip delay
commit Commit the configuration changes to running
default Set a command to its defaults
describe Describe a command without taking real actions
do Run an exec command
exit Exit from this submode
interface Configure NTP on an interface
master Act as NTP master clock
max-associations Set maximum number of associations
no Negate a command or set its defaults
peer Configure NTP peer
port Enable NTP port
server Configure NTP server
show Show contents of configuration
source Configure interface for source address
trusted-key Key numbers for trusted time sources

```

```
update-calendar Periodically update calendar with NTP time
```

Use the **ntp** command with the **vrf** *vrf-name* keyword and argument to enter an NTP configuration mode specific to the specified VRF.

Task ID	Task ID	Operations
	ip-services	read, write

The following example shows how to enter NTP configuration mode:

```
RP/0/RSP0/CPU0:router(config)# ntp
RP/0/RSP0/CPU0:router(config-ntp)#
```

The following example shows how to enter an NTP configuration mode for a VRF called VRF1:

```
RP/0/RSP0/CPU0:router(config)# ntp vrf vrf1
RP/0/RSP0/CPU0:router(config-ntp-vrf)#
```

# ntp clear

To clear all Network Time Protocol (NTP) peers or a specific NTP peer, use the **ntp clear** command in EXEC

mode.

```
ntp clear {peer | all | vrf vrf-name ip-address}
```

## Syntax Description

<i>peer</i>	IPv4 address or hostname of the NTP peer to be cleared.
<b>all</b>	Clears all NTP peers.
<b>vrf</b> <i>vrf-name</i>	Clears a peer on the specified nondefault VRF.
<i>ip-address</i>	IPv4 or IPv6 IP address of the peer.

## Command Default

No defaults behavior or values

## Command Modes

EXEC

## Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	Support was added for the <b>vrf vrf-name ip-address</b> keyword and arguments.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

## Task ID

Task ID	Operations
ip-services	read, write

The following example shows how to clear all NTP peers:

```
RP/0/RSP0/CPU0:router# ntp clear all
```

# ntp reset drift

To reset the NTP drift and loopfilter state, use the **ntp reset drift** command in EXEC mode.

## ntp reset drift

**Syntax Description** This command has no keywords or arguments.

**Command Default** No defaults behavior or values

**Command Modes** EXEC

Command History	Release	Modification
	Release 3.9.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **ntp reset drift** command to set the loopfilter state to NSET (never set) and reset the drift. Resetting the loopfilter state and drift enables the router to relearn the frequency of the NTP server clock. This is necessary if there is a synchronization error caused by a large frequency error. This can arise, for example, if the router switches from synchronizing with one NTP server to synchronizing with another NTP server with a different frequency.

Task ID	Task ID	Operations
	ip-services	read, write

The following example shows how to reset the NTP drift and loopfilter state:

```
RP/0/RSP0/CPU0:router# ntp reset drift
Thu Nov 13 11:21:04.381 JST
```

The following example shows NTP status before and after resetting NTP drift and loopfilter state:

```
RP/0/RSP0/CPU0:router# show ntp status
Thu Nov 13 11:20:53.122 JST

Clock is synchronized, stratum 3, reference is 192.168.128.5
nominal freq is 1000.0000 Hz, actual freq is 1000.2787 Hz, precision is 2**24
reference time is CCC60CBE.9F836478 (11:17:34.623 JST Thu Nov 13 2008)
clock offset is -3.172 msec, root delay is 189.289 msec
```

```
root dispersion is 70.03 msec, peer dispersion is 0.11 msec
loopfilter state is 'CTRL' (Normal Controlled Loop), drift is -0.0002785891 s/s
system poll interval is 128, last update was 199 sec ago
```

```
RP/0/RSP0/CPU0:router# ntp reset drift
Thu Nov 13 11:21:04.381 JST
```

```
RP/0/RSP0/CPU0:router# show ntp status
Thu Nov 13 11:21:10.595 JST
```

```
Clock is unsynchronized, stratum 16, no reference clock
nominal freq is 1000.0000 Hz, actual freq is 1000.0000 Hz, precision is 2**24
reference time is CCC60CBE.9F836478 (11:17:34.623 JST Thu Nov 13 2008)
clock offset is -3.172 msec, root delay is 0.000 msec
root dispersion is 0.09 msec, peer dispersion is 0.00 msec
loopfilter state is 'NSET' (Never set), drift is 0.0000000000 s/s
system poll interval is 64, last update was 216 sec ago
```

### Related Topics

[show ntp status](#), on page 461

## peer (NTP)

To configure the system clock to synchronize a peer or to be synchronized by a peer, use the **peer** command in one of the NTP configuration modes. To remove the **peer** command from the configuration file and restore the system to its default condition with respect to the command, use the **no** form of this command.

```
peer [vrf vrf-name] [{ipv4 | ipv6}] ip-address [version number] [key key-id] [minpoll interval]
[maxpoll interval] [source type interface-path-id] [prefer] [burst] [iburst]
no peer [vrf vrf-name] [{ipv4 | ipv6}] ip-address
```

### Syntax Description

<b>vrf</b> <i>vrf-name</i>	(Optional) Applies the peer configuration to the specified nondefault VRF.
<b>ipv4</b>	(Optional) Specifies an IPv4 IP address.
<b>ipv6</b>	(Optional) Specifies an IPv6 IP address.
<i>ip-address</i>	IPv4 or IPv6 address of the peer providing or being provided with the clock synchronization.
<b>version</b> <i>number</i>	(Optional) Defines the Network Time Protocol (NTP) version number, where the <i>number</i> argument is a value from 1 to 4. The default is 4.
<b>key</b> <i>key-id</i>	(Optional) Defines the authentication key, where the <i>key-id</i> argument is the authentication key to use when packets are sent to this peer. The authentication key is also used for packets received from the peer. By default, no authentication key is used.
<b>minpoll</b> <i>interval</i>	(Optional) Defines the shortest polling interval, where the <i>interval</i> argument is specified in powers of two seconds. Range is from 4 to 17. The default value is 6.
<b>maxpoll</b> <i>interval</i>	(Optional) Defines the longest polling interval, where the <i>interval</i> argument is specified in powers of two seconds. Range is from 4 to 17. The default value is 10.
<b>source</b>	(Optional) IP source address. The default is the outgoing interface.
<i>type</i>	(Optional) Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	(Optional) Physical interface or virtual interface.
	<p><b>Note</b> Use the <b>show interfaces</b> command to see a list of all interfaces currently configured on the router.</p> <p>For more information about the syntax for the router, use the question mark (?) online help function.</p>
<b>prefer</b>	(Optional) Makes this peer the preferred peer that provides synchronization.
<b>burst</b>	(Optional) Sends a series of packets instead of a single packet within each synchronization interval to achieve faster synchronization.
<b>iburst</b>	(Optional) Sends a series of packets instead of a single packet within the initial synchronization interval to achieve faster initial synchronization.

**Command Default** No peers are configured by default.

**Command Modes** NTP configuration  
VRF-specific NTP configuration

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	Support was added for the following keywords and arguments: <ul style="list-style-type: none"> <li>• <b>vrf</b> <i>vrf-name</i></li> <li>• <b>ipv4</b></li> <li>• <b>ipv6</b></li> <li>• <b>burst</b></li> <li>• <b>iburst</b></li> </ul>

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **peer** command to allow this machine to synchronize with the peer, or conversely.



**Caution** Although using the **prefer** keyword can help reduce the switching among peers, you should avoid using the keyword because it interferes with the source selection mechanism of NTP and can result in a degradation in performance.

The value for the **minpoll** keyword must be less than or equal to the value for the **maxpoll** keyword. If this is not the case, the system issues an error message.

To provide peer-level service (as opposed to client/server-level service), it may be necessary to explicitly specify the NTP version for the peer if it is not version 4.

If you use the **peer** command in a VRF-specific NTP configuration mode, the command is applied to the specific VRF. If you are not in a VRF-specific NTP configuration mode, the command is applied to the default VRF unless you use the **vrf** *vrf-name* keyword and argument to specify a VRF.



**Note** To change the configuration of a specific IP address from peer to server or from server to peer, use the **no** form of the **peer** or **server** command to remove the current configuration before you perform the new configuration. If you do not remove the old configuration before performing the new configuration, the new configuration does not overwrite the old configuration.

Task ID	Task ID	Operations
	ip-services	read, write

The following example shows how to configure a networking device to allow its system clock to be synchronized with the clock of the peer (or conversely) at IP address 10.0.0.0 using NTP. The source IP address is the address of interface 0/0/0/1.

```
RP/0/RSP0/CPU0:router(config)# ntp
RP/0/RSP0/CPU0:router(config-ntp)# peer 10.0.0.0 minpoll 8 maxpoll 12 source tengige 0/0/0/1
```

### Related Topics

[authentication-key \(NTP\)](#), on page 430

[server \(NTP\)](#), on page 453

[source \(NTP\)](#), on page 463



## server (NTP)

To allow the system clock to be synchronized by a time server, use the **server** command in one of the NTP configuration modes. To remove the **server** command from the configuration file and restore the system to its default condition with respect to this command, use the **no** form of this command.

```
server [vrf vrf-name][{ipv4 | ipv6}] ip-address [version number] [key key-id] [minpoll interval]
[maxpoll interval] [source type interface-path-id][prefer] [burst] [iburst]
no server [vrf vrf-name] [{ipv4 | ipv6}] ip-address
```

### Syntax Description

<b>vrf</b> <i>vrf-name</i>	(Optional) Applies the server configuration to the specified nondefault VRF.
<b>ipv4</b>	(Optional) Specifies an IPv4 IP address.
<b>ipv6</b>	(Optional) Specifies an IPv6 IP address.
<i>ip-address</i>	IPv4 or IPv6 address of the time server providing the clock synchronization.
<b>version</b> <i>number</i>	(Optional) Defines the Network Time Protocol (NTP) version number, where the <i>number</i> argument is a value from 1 to 4. The default is 4.
<b>key</b> <i>key-id</i>	(Optional) Defines the authentication key, where the <i>key-id</i> argument is the authentication key to use when packets are sent to this peer. By default, no authentication key is used.
<b>minpoll</b> <i>interval</i>	(Optional) Defines the shortest polling interval, where the <i>interval</i> argument is specified in powers of two seconds. Range is from 4 to 17. The default value is 6.
<b>maxpoll</b> <i>interval</i>	(Optional) Defines the longest polling interval, where the <i>interval</i> argument is specified in powers of two seconds. Range is from 4 to 17. The default value is 10.
<b>source</b>	(Optional) Specifies the IP source address. The default is the outgoing interface.
<i>type</i>	(Optional) Interface type. For more information, use the question mark ( ? ) online help function.
<i>interface-path-id</i>	(Optional) Physical interface or virtual interface.
<b>Note</b>	Use the <b>show interfaces</b> command to see a list of all interfaces currently configured on the router.
	For more information about the syntax for the router, use the question mark ( ? ) online help function.
<b>prefer</b>	(Optional) Makes this peer the preferred server that provides synchronization.
<b>burst</b>	(Optional) Sends a series of packets instead of a single packet within each synchronization interval to achieve faster synchronization.
<b>iburst</b>	(Optional) Sends a series of packets instead of a single packet within the initial synchronization interval to achieve faster initial synchronization.

### Command Default

No servers are configured by default.

<b>Command Modes</b>	NTP configuration VRF-specific NTP configuration
----------------------	-----------------------------------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.2	This command was introduced.
	Release 3.9.0	Support was added for the following keywords and arguments: <ul style="list-style-type: none"> <li>• <b>vrf</b> <i>vrf-name</i></li> <li>• <b>ipv4</b></li> <li>• <b>ipv6</b></li> <li>• <b>burst</b></li> <li>• <b>iburst</b></li> </ul>

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The value for the **minpoll** keyword must be less than or equal to the value for the **maxpoll** keyword. If this is not the case, the system issues an error message.

Using the **prefer** keyword reduces switching back and forth among servers.

If you use the **server** command in a VRF-specific NTP configuration mode, the command is applied to the specific VRF. If you are not in a VRF-specific NTP configuration mode, the command is applied to the default VRF unless you use the **vrf vrf-name** keyword and argument to specify a VRF.



**Note** To change the configuration of a specific IP address from peer to server or from server to peer, use the **no** form of the **peer** or **server** command to remove the current configuration before you perform the new configuration. If you do not remove the old configuration before performing the new configuration, the new configuration does not overwrite the old configuration.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	ip-services	read, write

The following example shows how to configure a router to allow its system clock to be synchronized with the clock of the peer at IP address 209.165.201.1 using NTP:

```
RP/0/RSP0/CPU0:router(config)# ntp
RP/0/RSP0/CPU0:router(config-ntp)# server 209.165.201.1 minpoll 8 maxpoll 12
```

**Related Topics**

[authentication-key \(NTP\)](#), on page 430

[peer \(NTP\)](#), on page 450

[source \(NTP\)](#), on page 463

# show calendar

To display the system time and date, use the **show calendar** command in the EXEC .

**show calendar**

**Syntax Description** This command has no keywords or arguments.

**Command Default** None

**Command Modes** EXEC

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** The time format of the **show calendar** output depends on the time format set using the **clock timezone** command.

Task ID	Task ID	Operations
	basic-services	read

The following example shows sample output from the **show calendar** command:

```
RP/0/RSP0/CPU0:router# show calendar
01:29:28 UTC Thu Apr 01 2004
```

## Related Topics

[show clock](#), on page 126

# show ntp associations

To display the status of Network Time Protocol (NTP) associations, use the **show ntp associations** command in privileged EXEC mode.

```
show ntp associations [detail] [location node-id]
```

<b>Syntax Description</b>	<b>detail</b>	(Optional) Displays detailed information about each NTP association.
	<b>location node-id</b>	(Optional) Displays the status of NTP associations from the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.
<b>Command Default</b>	None	
<b>Command Modes</b>	EXEC	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.2	This command was introduced.
	Release 3.9.0	The output was modified to display nondefault VRF instances and to accommodate IPv6 addresses.
<b>Usage Guidelines</b>	<p>To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.</p> <p>Output for the <b>show ntp associations</b> command is displayed only if NTP is configured on the router.</p>	
<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	ip-services	read

This example shows sample output from the **show ntp associations** command:

```
RP/0/RSP0/CPU0:router# show ntp associations

Wed Jul 30 04:03:13.471 PST DST

 address ref clock st when poll reach delay offset disp
~172.19.69.1 172.24.114.33 3 25 64 3 2.89 57550122 39377
~2001:db8::feed .INIT. 16 - 64 0 0.00 0.000 15937
~2001:db8::beef vrf vrf_1
 .INIT. 16 - 64 0 0.00 0.000 16000
* sys_peer, # selected, + candidate, - outlayer, x falseticker, ~ configured
```

Table 43: show ntp associations Field Descriptions

Field	Description
*	Peer has been declared the system peer and lends its variables to the system variables.
#	Peer is a survivor, but not among the first six peers sorted by synchronization distance. If the association is ephemeral, it may be demobilized to conserve resources.
+	Peer is a survivor and a candidate for the combining algorithm.
-	Peer is discarded by the clustering algorithm as an outlier.
x	Peer is discarded by the intersection algorithm as a falseticker.
~	Indicates peer is statically configured.
address	IPv4 or IPv6 address of the peer. If a nondefault VRF is configured for the peer, the VRF follows the address.
ref clock	Reference clock type or address for the peer.
st	Stratum setting for the peer.
when	Time since last NTP packet was received from peer, in milliseconds.
poll	Polling interval, in seconds.
reach	Peer reachability (bit string, in octal).
delay	Round-trip delay to peer, in milliseconds.
offset	Relative time difference between a peer clock and a local clock, in milliseconds.
disp	Dispersion.

This example shows sample output from the **show ntp associations** command with the **detail** keyword:

```
RP/0/RSP0/CPU0:router# show ntp associations detail

172.19.69.1 configured, our_master, sane, valid, stratum 2
ref ID 171.68.10.150, time C4143AAE.00FCF396 (18:27:58.003 UTC Tue Mar 30 2004)
our mode client, peer mode server, our poll intvl 64, peer poll intvl 64
root delay 5.23 msec, root disp 4.07, reach 3, sync dist 0.0077
delay 1.9829 msec, offset -3.7899 msec, dispersion 0.0358
precision 2**18, version 4
org time C4143B8D.7EBD5FEF (18:31:41.495 UTC Tue Mar 30 2004)
rcv time C4143B8D.801DFA44 (18:31:41.500 UTC Tue Mar 30 2004)
xmt time C4143B8D.7F595E44 (18:31:41.497 UTC Tue Mar 30 2004)
filtdelay = 2.99 1.98 1.98 1.99 1.99 1.99 2.98 1.98
filtoffset = -3.89 -3.74 -3.78 -3.81 -3.76 -3.73 -4.08 -3.64
filtererror = 0.00 0.02 0.03 0.05 0.06 0.08 0.09 0.32

2001:0DB8::FEED vrf xxx configured, candidate, sane, valid, stratum 2
ref ID 64.103.34.14, time CB0C8C66.38285D84 (14:00:22.219 JST Fri Dec 14 2007)
our mode client, peer mode server, our poll intvl 64, peer poll intvl 64
root delay 181.17 msec, root disp 3.19, reach 377, sync dist 0.1463
```

```

delay 104.9158 msec, offset -15.4552 msec, dispersion 0.0439
precision 2**16, version 4
org time CB0C8D0A.70282853 (14:03:06.438 JST Fri Dec 14 2007)
rcv time CB0C8D0A.81CA0E2B (14:03:06.506 JST Fri Dec 14 2007)
xmt time CB0C8D0A.66AAB677 (14:03:06.401 JST Fri Dec 14 2007)
filtdelay = 105.90 104.92 104.91 104.91 105.90 105.85 105.90 104.91
filtoffset = -15.92 -15.67 -15.54 -15.59 -15.58 -15.54 -15.41 -14.36
filterror = 0.02 0.03 0.05 0.06 0.08 0.09 0.11 1.05

2001:0DB8::BEEF vrf yyy configured, our_master, sane, valid, stratum 2
ref ID 64.104.193.12, time CB0C8CC1.2C14CED1 (14:01:53.172 JST Fri Dec 14 2007)
our mode client, peer mode server, our poll intvl 64, peer poll intvl 64
root delay 160.83 msec, root disp 4.35, reach 377, sync dist 0.1372
delay 104.9302 msec, offset -14.6327 msec, dispersion 0.0183
precision 2**18, version 4
org time CB0C8CCB.684619D8 (14:02:03.407 JST Fri Dec 14 2007)
rcv time CB0C8CCB.79782B09 (14:02:03.474 JST Fri Dec 14 2007)
xmt time CB0C8CCB.5E9A5429 (14:02:03.369 JST Fri Dec 14 2007)
filtdelay = 104.93 104.93 104.93 104.93 104.93 104.93 104.93 104.93
filtoffset = -14.71 -14.53 -14.78 -14.73 -14.70 -14.52 -14.59 -14.50
filterror = 0.00 0.02 0.03 0.05 0.06 0.08 0.09 0.11

```

Table 44: show ntp associations detail Field Descriptions

Field	Descriptions
vrf	Nondefault VRF, if specified for this peer.
configured	Statically configured peer.
dynamic	Dynamically discovered peer.
our_master	Synchronization of the local machine to this peer.
sane	Passing of basic sanity checks by this peer.
ref ID	Address of machine to which the peer is synchronized.
time	Last time stamp that the peer received from its master.
our mode	Mode relative to peer (active/passive/client/server/bdcast/bdcast client).
peer mode	Mode of peer relative.
our poll intvl	Poll interval to peer.
peer poll intvl	Poll interval of interval.
root delay	Delay along path to root (ultimate stratum 1 time source).
root disp	Dispersion of path to root.
reach	Peer reachability (bit string in octal).
sync dist	Peer synchronization distance.

Field	Descriptions
delay	Round-trip delay to peer.
offset	Offset of peer clock relative to this clock.
dispersion	Dispersion of peer clock.
precision	Precision of peer clock in (Hertz) Hz.
version	NTP version number that peer is using.
org time	Originate time stamp.
rcv time	Receive time stamp.
xmt time	Transmit time stamp.
filtdelay	Round-trip delay of each sample, in milliseconds.
filtoffset	Clock offset of each sample, in milliseconds.
filterror	Approximate error of each sample.

**Related Topics**

[show ntp status](#), on page 461



# show ntp status

To display the status of Network Time Protocol (NTP), use the **show ntp status** command in

EXEC

mode.

**show ntp status** [**location** *node-id*]

<b>Syntax Description</b>	<b>location</b> <i>node-id</i> (Optional) Displays the status of NTP from the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.
---------------------------	--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

<b>Command Default</b>	No defaults behavior or values
------------------------	--------------------------------

<b>Command Modes</b>	EXEC
----------------------	------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.2	This command was introduced.
	Release 3.9.0	The output was modified to display nondefault VRF instances and IPv6 addresses.  The loopfilter state, drift, system poll interval, and last update display fields were added to the output.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	ip-services	read

This example shows sample output from the **show ntp status** command:

```
RP/0/RSP0/CPU0:router# show ntp status
```

```
Clock is synchronized, stratum 3, reference is 192.168.128.5
nominal freq is 1000.0000 Hz, actual freq is 1000.0021 Hz, precision is 2**24
reference time is CC38EC6A.8FCCA1C4 (10:10:02.561 JST Tue Jul 29 2008)
clock offset is -124.051 msec, root delay is 174.060 msec
root dispersion is 172.37 msec, peer dispersion is 0.10 msec
loopfilter state is 'CTRL' (Normal Controlled Loop), drift is -0.0000021106 s/s
system poll interval is 32, last update was 19 sec ago
```

Table 45: show ntp status Field Descriptions

Field	Description
synchronized	Synchronized system to an NTP peer.
stratum	NTP stratum of this system.
reference	IPv4 address or first 32 bits of the MD5 hash of the IPv6 address of the peer to which clock is synchronized.
vrf	VRF through which the peer routes.
nominal freq	Nominal frequency in Hertz (Hz) of the system hardware clock.
actual freq	Measured frequency in Hz of the system hardware clock.
precision	Precision of the clock of this system in Hz.
reference time	Reference time stamp.
clock offset	Offset of clock to synchronized peer, in milliseconds.
root delay	Total delay along path to root clock, in milliseconds.
root dispersion	Dispersion of root path.
peer dispersion	Dispersion of synchronized peer.
loopfilter state	The state of the clock state machine transition function.
drift	Drift of the hardware clock.
system poll interval	Poll interval of the peer.
last update	Time the router last updated its NTP information.

**Related Topics**

[show ntp associations](#), on page 457

## source (NTP)

To use a particular source address in Network Time Protocol (NTP) packets, use the **source** command in one of the NTP configuration modes. To remove the **source** command from the configuration file and restore the system to its default condition, use the **no source** form of this command.

```
source [vrf vrf-name] type interface-path-id
no source
```

Syntax Description	
<b>vrf</b> <i>vrf-name</i>	(Optional) Applies the source address configuration to the specified nondefault VRF.
<i>type</i>	(Optional) Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	(Optional) Physical interface or virtual interface.
<b>Note</b>	Use the <b>show interfaces</b> command to see a list of all interfaces currently configured on the router.
	For more information about the syntax for the router, use the question mark (?) online help function.

**Command Default** The source address is determined by the outgoing interface.

**Command Modes** NTP configuration  
VRF-specific NTP configuration

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	Support was added for the <b>vrf</b> <i>vrf-name</i> keyword and argument.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **source** command to use a particular source IP address for all NTP packets. The address is taken from the named interface. This command is useful if the address on an interface cannot be used as the destination for reply packets. If the **source** keyword has been configured with the **server** (NTP) or **peer** (NTP) command, that value overrides the global value.

Use the **source** command in a VRF-specific NTP configuration mode or use the **vrf** *vrf-name* keyword and argument to configure the source address for a specific nondefault VRF. Otherwise, the configuration is applied to the default VRF.

Task ID	Task ID	Operations
	ip-services	read, write

This example shows how to configure the router to use the IP address of interface 0/0/0/1 as the source address of all outgoing NTP packets:

```
RP/0/RSP0/CPU0:router(config)# ntp
RP/0/RSP0/CPU0:router(config-ntp)# source tngige 0/0/0/1
```

### Related Topics

[peer \(NTP\)](#), on page 450

[server \(NTP\)](#), on page 453

# trusted-key

To designate a Network Time Protocol (NTP) trusted key, use the **trusted-key** command in NTP configuration mode. To remove the **trusted-key** command from the configuration file and restore the system to its default condition with respect to this command, use the **no** form of this command.

**trusted-key** *key-number*  
**no trusted-key** *key-number*

<b>Syntax Description</b>	<i>key-number</i> Authentication key number to be trusted. Range is from 1 to 65535.
---------------------------	--------------------------------------------------------------------------------------

<b>Command Default</b>	No NTP trusted key is designated.
------------------------	-----------------------------------

<b>Command Modes</b>	NTP configuration
----------------------	-------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

If authentication is enabled, use the **trusted-key** command to define one or more key numbers (corresponding to the keys defined with the **authentication-key** [NTP] command) that a NTP system must provide in its NTP packets for this system to synchronize to it. Because the other system must know the correct authentication key, this precaution provides protection against accidentally synchronizing the system to a system that is not trusted.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	ip-services	read, write

The following example shows how to configure the system to synchronize only to systems providing authentication key 42 in its NTP packets:

```
RP/0/RSP0/CPU0:router(config)# ntp
RP/0/RSP0/CPU0:router(config-ntp)# authenticate
RP/0/RSP0/CPU0:router(config-ntp)# authentication-key 42 md5 clear key1
RP/0/RSP0/CPU0:router(config-ntp)# trusted-key 42
```

## Related Topics

- [authenticate \(NTP\)](#), on page 428
- [authentication-key \(NTP\)](#), on page 430

# update-calendar

To update the calendar periodically from Network Time Protocol (NTP), use the **update-calendar** command in NTP configuration mode. To remove the **update-calendar** command from the configuration file and restore the system to its default condition with respect to the command, use the **no** form of this command.

**update-calendar**  
**no update-calendar**

**Syntax Description** This command has no keywords or arguments.

**Command Default** This command is disabled.

**Command Modes** NTP configuration

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Your router has a calendar that is separate from the software clock. This calendar runs continuously, even if the router is powered off or rebooted.

If a router is synchronized to an outside time source through NTP, it is a good idea to update the router's calendar with the time learned from NTP. Otherwise, the calendar may gradually lose or gain time.

After you configure the **update-calendar** command, NTP updates the calendar with the software clock every hour.

Task ID	Task ID	Operations
	ip-services	read, write

This example shows how to configure the router to update the calendar periodically from the software clock:

```
RP/0/RSP0/CPU0:router(config)# ntp
RP/0/RSP0/CPU0:router(config-ntp)# update-calendar
```

## Related Topics

[clock read-calendar](#), on page 108

[clock update-calendar](#), on page 117



## Object Tracking Commands

---

This chapter describes the Cisco IOS XR software commands used to track objects. For information about how to use these commands to configure object tracking, see *System Management Configuration Guide for Cisco ASR 9000 Series Routers*.

- [delay](#), on page 468
- [interface \(track\)](#), on page 470
- [line-protocol track](#), on page 472
- [object](#), on page 474
- [route ipv4](#), on page 476
- [show track](#), on page 477
- [track](#), on page 479
- [threshold percentage](#), on page 481
- [threshold weight](#), on page 482
- [type line-protocol state](#), on page 483
- [type list boolean](#), on page 484
- [type list threshold percentage](#), on page 486
- [type list threshold weight](#), on page 487
- [type route reachability](#), on page 488
- [type rtr](#), on page 490
- [vrf \(track\)](#), on page 491

# delay

To configure the delay, in seconds, before the track or interface state should be polled for a change in status, use the **delay** command in track configuration mode. To delete the configuration of delay tracking, use the **no** form of this command.

```
delay {up | down} seconds
no delay {up | down} [seconds]
```

Syntax Description	Command	Description
	<b>delay up</b> <i>seconds</i>	Sets delay of from 1 to 180 seconds before communication of up status of the tracked object or list of objects.
	<b>delay down</b> <i>seconds</i>	Sets delay of from 1 to 180 seconds before communication of down status of the tracked object or list of objects.

**Command Default** No default behavior or values

**Command Modes** Track configuration

Command History	Release	Modification
	Release 3.7.0	No modification.
	Release 3.8.0	No modification.
	Release 3.9.0	No modification.
	Release 4.0.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **delay** command can be used in conjunction with all track types:

- [type line-protocol state, on page 483](#)
- [type list boolean, on page 484](#)
- [type route reachability, on page 488](#)

When using the **no** form of the command, the use of the *seconds* argument is optional.

Task ID	Task ID	Operations
	sysmgr	read, write

The following example shows that the tracking process is configured to notify the network administrator that the interface should be polled for its up state in five-second intervals:



```
RP/0/RSP0/CPU0:router# configuration
RP/0/RSP0/CPU0:router(config)# track name1
RP/0/RSP0/CPU0:router(config-track)# delay up 5
```

### Related Topics

[track](#), on page 479

## interface (track)

To select an interface object type for tracking purposes, use the **interface** command in interface configuration mode. To delete the configuration of a track based on a particular interface object type, use the **no** form of this command.

```
interface type interface-path-id
no interface type interface-path-id
```

<b>Syntax Description</b>	<i>type</i>	(Optional) Interface type. For more information, use the question mark (?) online help function.
	<i>interface-path-id</i>	(Optional) Physical interface or virtual interface.
	<b>Note</b>	Use the <b>show interfaces</b> command to see a list of all interfaces currently configured on the router.
		For more information about the syntax for the router, use the question mark (?) online help function.

**Command Default** No default behavior or values

**Command Modes** Interface configuration

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.0	No modification.
	Release 3.8.0	No modification.
	Release 3.9.0	No modification.
	Release 4.0.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

To access the **interface** command, you must be in line protocol tracking configuration submenu.

For information about interface keywords, see *Interface and Hardware Component Command Reference for Cisco ASR 9000 Series Routers*.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	sysmgr	read, write

The following example shows the **interface** command in the context of object tracking:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# track track12
RP/0/RSP0/CPU0:router(config-track)# type line-protocol state
RP/0/RSP0/CPU0:router(config-track-line-prot)# interface atm 0/2/0/0.1
```

### Related Topics

[track](#), on page 479

[type line-protocol state](#), on page 483

[type list boolean](#), on page 484

[type route reachability](#), on page 488

# line-protocol track

To associate a specific track with an IPsec or GRE interface object, use the **line-protocol track** command in interface configuration mode. To delete the association between the track and the IPsec or GRE interface object, use the **no** form of this command.

**line-protocol track** *object-name*  
**no line-protocol track** *object-name*

<b>Syntax Description</b>	<i>object-name</i> Name of object being tracked.
---------------------------	--------------------------------------------------

<b>Command Default</b>	No default behavior or values
------------------------	-------------------------------

<b>Command Modes</b>	Interface configuration
----------------------	-------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.0	No modification.
	Release 3.8.0	No modification.
	Release 3.9.0	No modification.
	Release 4.0.0	This command was introduced.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

<b>Task ID</b>	<b>Task Operations</b>
	sysmgr read, write

The following example shows how the **line-protocol track** command is used:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# track PREFIX1
RP/0/RSP0/CPU0:router(config-track)# type route reachability
RP/0/RSP0/CPU0:router(config-track-route)# route ipv4 7.0.0.0/24
RP/0/RSP0/CPU0:router(config-track-route)# interface service-ipsec 1
RP/0/RSP0/CPU0:router(config-if)# vrf 1
RP/0/RSP0/CPU0:router(config-if)# ipv4 address 70.0.0.2 255.25.255.0
RP/0/RSP0/CPU0:router(config-if)# line-protocol track PREFIX1
```

**Related Topics**

[interface \(track\)](#), on page 470

[track](#), on page 479

# object

To configure an object for tracking, use the **object** command in list tracking configuration mode. To delete a previously configured track based on an object, use the **no** form of this command.

**object** *object-name* [**not**]

**no object** *object-name*

## Syntax Description

*object-name* Name of the object to be tracked.

**not** (Optional) Deletes a previously configured track based on whether an interface object is not up or down.

## Command Default

No default behavior or values

## Command Modes

List tracking configuration

## Command History

### Release

### Modification

Release 3.7.0

No modification.

Release 3.8.0

No modification.

Release 3.9.0

No modification.

Release 4.0.0

This command was introduced.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

To delete a previously configured track based on whether an interface object is *not* up or down, use the **not** keyword together with the **object** command in a list of tracked objects based on a Boolean expression.

The **object** command can be used only for a track based on a Boolean expression.

## Task ID

### Task Operations ID

sysmgr read,  
write

The following example shows how to configure an object, using the optional **not** keyword, in a tracked list of objects based on a Boolean calculation:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# track connection100
RP/0/RSP0/CPU0:router(config-track-list)# type list boolean and
RP/0/RSP0/CPU0:router(config-track-list)# object obj3 no
```

**Related Topics**

[track](#), on page 479

[type list boolean](#), on page 484

# route ipv4

To configure that an IP prefix and subnet mask should be used as the basis to track route reachability, use the **route ipv4** command in route tracking configuration mode. To remove this configuration, use the **no** form of the command.

**route ipv4** *IP prefix and subnet mask*  
**no route ipv4**

<b>Syntax Description</b>	<i>IP prefix and subnet mask</i> Network and subnet mask; for example, 10.56.8.10/16.
---------------------------	---------------------------------------------------------------------------------------

<b>Command Default</b>	No default behavior or values
------------------------	-------------------------------

<b>Command Modes</b>	Route tracking configuration
----------------------	------------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.0	No modification.
Release 3.8.0	No modification.	
Release 3.9.0	No modification.	
Release 4.0.0	This command was introduced.	

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

The *IP prefix* and *subnet mask* arguments are optional for the **no** form of this command.

<b>Task ID</b>	<b>Task Operations ID</b>
	sysmgr read, write

The following example displays use of the **route ipv4** command:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# track track22
RP/0/RSP0/CPU0:router(config-track)# type route reachability
RP/0/RSP0/CPU0:router(config-track-route)# route ipv4 10.56.8.10/16
```

## Related Topics

[type route reachability](#), on page 488

[vrf \(track\)](#), on page 491



# show track

To display information about objects that were tracked and to specify the format of the report, use the **show track** command in EXEC mode.

```
show track [{track-name | interface | ipv4 route}] [brief]
```

Syntax Description	
<b>track-name</b>	(Optional) Name of track used for tracking objects; for example, track1.
<b>brief</b>	(Optional) Displays a single line of information related to the preceding argument or keyword.
<b>interface</b>	(Optional) Displays tracked interface objects.
<b>ipv4 route</b>	(Optional) Displays the tracked IPv4 route objects.

Command Default	
	No default behavior or values

Command Modes	
	EXEC

Command History	Release	Modification
	Release 3.7.0	No modification.
	Release 3.8.0	No modification.
	Release 3.9.0	No modification.
	Release 4.0.0	This command was introduced.

Usage Guidelines	
	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **show track** command to display information about objects that are tracked by the tracking process. When no arguments or keywords are specified, information for all objects is displayed.

Task ID	Task Operations ID
	sysmgr read

The following sample output illustrates use of the **show track** command:

```
RP/0/RSP0/CPU0:router# show track Track_name3

Track_name3
 List boolean and is DOWN
 1 change, last change 10:26:20 SJC Sun Aug 05 2007
 object name2 not UP
 object name1 UP
```

**Related Topics**

[track](#), on page 479

# track

To initiate or identify a tracking process used to track the status of an object or list of objects, use the **track** command in global configuration mode. To remove the tracking process, use the **no** form of this command.

**track** *track-name*  
**no track** *track-name*

<b>Syntax Description</b>	<b>track</b> <i>track-name</i> Name of track used for tracking objects; for example, track1.
---------------------------	----------------------------------------------------------------------------------------------

<b>Command Default</b>	No default behavior or values
------------------------	-------------------------------

<b>Command Modes</b>	Global configuration
----------------------	----------------------

Command History	Release	Modification
	Release 3.7.0	No modification.
Release 3.8.0	No modification.	
Release 3.9.0	No modification.	
Release 4.0.0	This command was introduced.	

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

When you use the **track** command, you enter track configuration mode.

Task ID	Task Operations ID
	sysmgr read, write

This example shows that the tracking process is configured to notify the network administrator about the up state of the tracked object list every five seconds:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# track LIST2
RP/0/RSP0/CPU0:router# track LIST2 delay up 5
```

## Related Topics

- [delay](#), on page 468
- [show track](#), on page 477
- [type line-protocol state](#), on page 483

[type list boolean](#), on page 484

[type route reachability](#), on page 488

# threshold percentage

To configure tracking threshold values based on percentages, use the **threshold percentage** command in track list threshold configuration mode. To remove a threshold percentage, use the **no** form of the command.

**threshold percentage up** *weight* [**down** *weight*]

Syntax Description	up	Maximum threshold value for the specific range beyond which a track is set to the DOWN state.
	<i>weight</i>	Percentage limit to define the maximum threshold value.
	down	Minimum threshold value for the specific range below which a track is set to the DOWN state.
	<i>weight</i>	Percentage limit to define the minimum threshold value.

**Command Default** None

**Command Modes** Track list threshold configuration

Command History	Release	Modification
	Release 4.2.1	This command was introduced.

**Usage Guidelines** Use the **threshold percentage** command to specify the tracking threshold value used to determine the state of a percentage threshold-weighted list.

- A percentage threshold-weighted list is set to the UP state when the percentage of objects is between UP threshold value and DOWN threshold value.
- A percentage threshold-weighted list is set to the DOWN state when the percentage of objects is out of the range in a configuration.

Task ID	Task ID	Operation
	sysmgr	read, write

This example shows how to specify the weight thresholds for a threshold-weighted list:

```
RP/0/RSP0/CPU0:router(config)# track 4
RP/0/RSP0/CPU0:router(config-track)# type list threshold weight
RP/0/RSP0/CPU0:router(config-track-list-threshold)# threshold percentage up 50 down 33
```

## Related Topics

[type list threshold percentage](#), on page 486

# threshold weight

To configure tracking threshold values based on weights, use the **threshold weight** command in track list threshold configuration mode. To remove a threshold weight, use the **no** form of the command.

**threshold weight up** *weight* [**down** *weight*]

<b>Syntax Description</b>	<b>up</b>	Maximum threshold value for the specific range beyond which a track is set to the DOWN state.
	<i>weight</i>	Percentage limit to define the maximum threshold value.
	<b>down</b>	Minimum threshold value for the specific range below which a track is set to the DOWN state.
	<i>weight</i>	Percentage limit to define the minimum threshold value.

**Command Default** None

**Command Modes** Track list threshold configuration

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 4.2.1	This command was introduced.

**Usage Guidelines** Use the **threshold weight** command to specify the threshold value used to determine the state of a threshold-weighted list.

- A threshold-weighted list is set to the UP state when the cumulative sum of the weight of objects is between UP threshold value and DOWN threshold value.
- A threshold-weighted list is set to the DOWN state when the cumulative sum of the weight of objects is out of the range in a configuration.

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	sysmgr	read, write

This example shows how to specify the weight thresholds for a threshold-weighted list:

```
RP/0/RSP0/CPU0:router(config)# track 4
RP/0/RSP0/CPU0:router(config-track)# type list threshold weight
RP/0/RSP0/CPU0:router(config-track-list-threshold)# threshold weight up 18 down 5
```

## Related Topics

[type list threshold weight](#), on page 487

# type line-protocol state

To configure tracking of the line protocol state of an interface object, use the **type line-protocol** command in track configuration mode. To delete the configuration of line-protocol tracking, use the **no** form of this command.

**type line-protocol state**  
**no type line-protocol state**

**Command Default** No default behavior or values

**Command Modes** Track configuration

Command History	Release	Modification
	Release 3.7.0	No modification.
	Release 3.8.0	No modification.
	Release 3.9.0	No modification.
	Release 4.0.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **type line-protocol state** command can be used in conjunction with the **delay** command to configure the delay, in seconds, before the track or interface state should be polled for a change in its status.

The **type line-protocol state** command enters line-protocol tracking configuration mode.

Task ID	Task Operations ID
	sysmgr read, write

This example shows how to use the **type line-protocol state** command:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# track track12
RP/0/RSP0/CPU0:router(config-track)# type line-protocol state
```

## Related Topics

- [delay](#), on page 468
- [interface \(track\)](#), on page 470
- [show track](#), on page 477
- [track](#), on page 479

## type list boolean

To configure a tracked list of objects based on a Boolean calculation, use the **type list boolean** command in track configuration mode. To remove an object tracking list based on a Boolean calculation, use the **no** form of the command.

```
type list boolean {and | or}
no type list boolean {and | or}
```

<b>Syntax Description</b>	<b>and</b> Specifies that the list is up if all objects are up, or down if one or more objects are down. For example, when tracking two interfaces, up means that both interfaces are up, and down means that either interface is down.
	<b>or</b> Specifies that the list is up if at least one object is up. For example, when tracking two interfaces, up means that either interface is up, and down means that both interfaces are down.

**Command Default** No default behavior or values

**Command Modes** Track configuration

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.0	No modification.
	Release 3.8.0	No modification.
	Release 3.9.0	No modification.
	Release 4.0.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **type list boolean** command enters the list tracking configuration mode, and can be used in conjunction with the **delay** command to configure the delay, in seconds, before the track or interface state should be polled for a change in its status.

To remove a track based on whether an interface object is *not* up or down, use the **not** keyword together with the **object** command as shown in the example that follows.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	sysmgr	read, write

This example shows how to use the **type list boolean** command in creating a list of objects to be tracked:



```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# track LIST2
RP/0/RSP0/CPU0:router(config-track)# type list boolean and
RP/0/RSP0/CPU0:router(config-track-list)# object IPsec1 not
RP/0/RSP0/CPU0:router(config-track-list)# object IPsec2
RP/0/RSP0/CPU0:router(config-track-list)# object PREFIX1
RP/0/RSP0/CPU0:router(config-track-list)# exit
RP/0/RSP0/CPU0:router(config)# track IPsec1
RP/0/RSP0/CPU0:router(config-track)# type line-protocol state
RP/0/RSP0/CPU0:router(config-track-line-prot)# interface tengige 0/0/0/3
RP/0/RSP0/CPU0:router(config-track-line-prot)# exit
RP/0/RSP0/CPU0:router(config-track)# track IPsec2
RP/0/RSP0/CPU0:router(config-track)# type line-protocol state
RP/0/RSP0/CPU0:router(config-track-line-prot)# interface ATM0/2/0.1
RP/0/RSP0/CPU0:router(config-track-line-prot)# exit
RP/0/RSP0/CPU0:router(config)# track PREFIX1
RP/0/RSP0/CPU0:router(config-track)# type route reachability
RP/0/RSP0/CPU0:router(config-track-route)# route ipv4 7.0.0.0/24
RP/0/RSP0/CPU0:router(config-track-route)# exit
RP/0/RSP0/CPU0:router(config-track)# interface service-ipsec 1
RP/0/RSP0/CPU0:router(config-if)# vrf 1
RP/0/RSP0/CPU0:router(config-if)# ipv4 address 70.0.0.2 255.255.255.0
RP/0/RSP0/CPU0:router(config-if)# profile vrf_1_ipsec
RP/0/RSP0/CPU0:router(config-if)# line-protocol track LIST2
RP/0/RSP0/CPU0:router(config-if)# tunnel source 80.0.0.2
RP/0/RSP0/CPU0:router(config-if)# tunnel destination 80.0.0.1
RP/0/RSP0/CPU0:router(config-if)# service-location preferred-active 0/2/0
RP/0/RSP0/CPU0:router(config-if)# commit
```

### Related Topics

- [delay](#), on page 468
- [line-protocol track](#), on page 472
- [object](#), on page 474
- [show track](#), on page 477
- [track](#), on page 479
- [type line-protocol state](#), on page 483
- [type route reachability](#), on page 488

## type list threshold percentage

To configure a tracked list of objects based on a percentage threshold, use the **type list threshold percentage** command in track configuration mode. To remove an object tracking list based on a percentage threshold, use the **no** form of the command.

### type list threshold percentage

**Syntax Description** This command has no keywords or arguments.

**Command Default** None

**Command Modes** Track configuration

Command History	Release	Modification
	Release 4.2.1	This command was introduced.

**Usage Guidelines** Use the **threshold percentage** command to specify the tracking threshold value used to determine the state of a percentage threshold-weighted list. A percentage threshold-weighted list is set to the UP state when the percentage of objects in the UP state is between UP threshold value to DOWN threshold value. A percentage threshold-weighted list is set to the DOWN state when the percentage of objects is out of the range in a configuration.

Use the **object** command to add tracked objects to the threshold-weighted list. A maximum of 200 track objects are allowed.

Task ID	Task	Operation
	sysmgr	read, write

This example shows how to add objects to a percentage threshold-weighted list:

```
RP/0/RSP0/CPU0:router(config)# track 4
RP/0/RSP0/CPU0:router(config-track)# type list threshold percentage
RP/0/RSP0/CPU0:router(config-track-list-threshold)# object 1
RP/0/RSP0/CPU0:router(config-track-list-threshold)# object 2
RP/0/RSP0/CPU0:router(config-track-list-threshold)# object 3
```

### Related Topics

[object](#), on page 474

[threshold percentage](#), on page 481

# type list threshold weight

To configure a tracked list of objects based on a weight threshold, use the **type list threshold weight** command in track configuration mode. To remove an object tracking list based on a weight threshold, use the **no** form of the command.

## type list threshold weight

**Syntax Description** This command has no keywords or arguments.

**Command Default** None

**Command Modes** Track configuration

Command History	Release	Modification
	Release 4.2.1	This command was introduced.

**Usage Guidelines** Use the **threshold weight** command to specify the threshold value used to determine the state of a threshold-weighted list. When the cumulative sum of the weight of objects in the UP state is between UP threshold value to DOWN threshold value, the threshold-weighted list is set to the UP state. A threshold-weighted list is set to the DOWN state when the cumulative sum of the weight of objects in the UP state is out of the range in a configuration.

Use the **object** command to add tracked objects to the threshold-weighted list. A maximum of 200 track objects are allowed.

Task ID	Task	Operation
	sysmgr	read, write

This example illustrates how to add objects to a threshold-weighted list:

```
RP/0/RSP0/CPU0:router(config)# track t4
RP/0/RSP0/CPU0:router(config-track)# type list threshold weight
RP/0/RSP0/CPU0:router(config-track-list-threshold)# object 1
RP/0/RSP0/CPU0:router(config-track-list-threshold)# object 1 weight 10
RP/0/RSP0/CPU0:router(config-track-list-threshold)# object 2 weight 5
RP/0/RSP0/CPU0:router(config-track-list-threshold)# object 3 weight 3
```

## Related Topics

[object](#), on page 474

[threshold weight](#), on page 482

## type route reachability

To configure the routing process to notify the tracking process when the route state changes due to a routing update, use the **type route reachability** command in track configuration mode. To remove a track based on route reachability, use the **no** form of this command.

**type route reachability**  
**no type route reachability**

**Syntax Description** This command has no keywords or arguments.

**Command Default** No default behavior or values

**Command Modes** Track configuration

Command History	Release	Modification
	Release 3.7.0	No modification.
	Release 3.8.0	No modification.
	Release 3.9.0	No modification.
	Release 4.0.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

A tracked IP-route object is considered up and reachable when a routing-table entry exists for the route and the route is not inaccessible.

The **type route reachability** command can be used in conjunction with the **delay** command to configure the delay, in seconds, before the track or interface state should be polled for a change in its status.

The route reachability tracking process is based on either of the following, depending on your router type:

- **vrf**—A VRF table name.
- **route**—An IPv4 prefix consisting of the network and subnet mask (for example, 10.56.8.10/16).

Task ID	Task ID	Operations
	sysmgr	read, write

This example shows how to track for route reachability:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# track track22
```

```
RP/0/RSP0/CPU0:router(config-track)# type route reachability
```

### Related Topics

[delay](#), on page 468

[show track](#), on page 477

[track](#), on page 479

## type rtr

To configure the router to track the return code of IP service level agreement (SLA) operations, use the **type rtr** command in track configuration mode. To remove a track based on IP SLA return code, use the **no** form of this command.

```
type rtr ipsla-no reachability
no type rtr
```

<b>Syntax Description</b>	<i>ipsla-no</i> IP SLA operation number. Values can range from 1 to 2048.
	<b>reachability</b> Tracks whether the route is reachable or not.

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Track configuration
----------------------	---------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 4.0.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **type rtr** command in conjunction with a configuration that uses:

- The **track** keyword in the **permit** command within an ACL definition. For example:

```
ipv4 access-list abf-track
 10 permit any any nexthop track track1 1.2.3.4
```

- An IP service level agreement configuration.

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	sysmgr	read, write

This example shows how to configure IPSLA object tracking:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# track track22
RP/0/RSP0/CPU0:router(config-track)# type rtr 1 reachability
```

# vrf (track)

To configure a VRF table to be used as the basis to track route reachability, use the **vrf** command in route tracking configuration mode. To delete the configuration of a VRF table for the purpose of IP route tracking purposes, use the **no** form of the command.

```
vrf vrf-table-name
no vrf [vrf-table-name]
```

<b>Syntax Description</b>	<i>vrf-table-name</i> Network and subnet; for example, 10.56.8.10/16.	
<b>Command Default</b>	No default behavior or values	
<b>Command Modes</b>	Route tracking configuration	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.0	No modification.
	Release 3.8.0	No modification.
	Release 3.9.0	No modification.
	Release 4.0.0	This command was introduced.
<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.	
<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	sysmgr	read, write

The following example displays the use of the **vrf** command:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# track track22
RP/0/RSP0/CPU0:router(config-track)# type route reachability
RP/0/RSP0/CPU0:router(config-track-route)# vrf vrf1
```

## Related Topics

- [delay](#), on page 468
- [route ipv4](#), on page 476
- [type route reachability](#), on page 488







## Precision Time Protocol (PTP) Commands

This module describes the commands used to configure the Precision Time Protocol (PTP) in Cisco IOS XR software. PTP is a protocol that provides the ability to distribute time around the network and is based on the IEEE 1588-2008 standard.

For more information about manually setting the router clock, see *Cisco ASR 9000 Series Aggregation Services Router Getting Started Guide*.

For more information about configuring the router to use PTP see the Configuring PTP on *System Management Configuration Guide for Cisco ASR 9000 Series Routers*.

- [announce](#), on page 495
- [clock](#), on page 497
- [clock operation](#), on page 498
- [clock-advertisement telecom-profile](#), on page 499
- [clock-class](#), on page 500
- [clock profile](#), on page 501
- [clock-selection telecom-profile](#), on page 503
- [cos](#), on page 504
- [delay-request](#), on page 505
- [domain](#), on page 506
- [delay-response](#), on page 507
- [dscp](#), on page 509
- [identity](#), on page 510
- [local-priority](#), on page 511
- [log best-master-clock changes](#), on page 512
- [master](#), on page 513
- [min-clock-class](#), on page 515
- [multicast](#), on page 516
- [priority1](#), on page 517
- [priority2](#), on page 518
- [profile \(interface\)](#), on page 519
- [profile \(PTP\)](#), on page 520
- [port state](#), on page 522
- [ptp](#), on page 523
- [show ptp advertised-clock](#), on page 525
- [show ptp foreign-masters](#), on page 526

- [show ptp interfaces](#), on page 529
- [show ptp local-clock](#), on page 532
- [show ptp packet-counters](#), on page 533
- [show ptp unicast-peers](#), on page 537
- [source ipv4 address](#), on page 539
- [sync](#), on page 540
- [timescale](#), on page 542
- [time-of-day](#), on page 543
- [time-source](#), on page 544
- [transport](#), on page 545
- [uncalibrated-clock-class](#), on page 546
- [unicast-grant invalid-request](#), on page 547

# announce

To configure options for configuring PTP profile announcement messages, use the **announce** command in PTP profile configuration or interface PTP configuration mode. To remove the setting, use the **no** form of this command.

```
announce{frequency frequency | interval interval | grant-duration duration | timeout timeout}
no announce{frequency | interval | grant-duration | timeout}
```

Syntax Description	Parameter	Description
	<b>frequency</b> <i>frequency</i>	Use to specify multiple announce messages per second (2, 4, 8, 16, 32, 64, or 128). Frequency of 4 means that four messages are sent per second.
	<b>interval</b> <i>interval</i>	Use to specify one or fewer announce messages per second (every 1, 2, 4, 8, or 16 seconds). Interval of 2 means that an announce message is sent every two seconds.
	<b>grant-duration</b> <i>duration</i>	Specifies the length of time that permission to send unicast messages is granted (60-1000 seconds).
	<b>timeout</b> <i>timeout</i>	Specifies the number of announce intervals that PTP ports will wait in the Listen state before transitioning to the Master state (2-10).

**Command Default** Defaults: grant-duration 600, interval 2, timeout 3.

**Command Modes** PTP profile configuration

Command History	Release	Modification
	Release 4.2.0	This command was introduced.
	Release 4.3.0	The grant duration option was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **announce** command can be used to configure the global PTP configuration profile which can then be associated with many interfaces. Similarly it can be used in interface PTP configuration mode to set the announce message settings for a specific interface. Any values set in interface PTP configuration mode override the settings in the PTP configuration profile associated with the interface.

The **grant-duration** keyword is used for the ITU-T Telecom Profile.

Task ID	Task ID	Operation
	ethernet-services	read, write

The following sets the announcement interval to 8 seconds in the PTP configuration profile.

```
RP/0/RSP0/CPU0:router(config)# ptp
```

```
RP/0/RSP0/CPU0:router(config-ptp)# profile p1
RP/0/RSP0/CPU0:router(config-ptp-profile)# announce interval 8
```

# clock

To enter Precision Time Protocol (PTP) clock configuration mode and run PTP clock configuration command, use the **clock** command in PTP configuration mode.

**clock**  
**no clock**

<b>Syntax Description</b>	This command has no keywords or arguments.				
<b>Command Default</b>	This command has no default values or behavior.				
<b>Command Modes</b>	Global PTP configuration				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 4.2.0</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 4.2.0	This command was introduced.
Release	Modification				
Release 4.2.0	This command was introduced.				

**Usage Guidelines**

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

PTP clock configuration commands can also be run from global configuration mode by preceding the command string with the **ptp clock** keywords. From PTP clock configuration mode, the various PTP clock settings can be configured.

Task ID	Task ID	Operation
	ethernet-services	read, write

The following example shows how to enter PTP clock configuration mode from global configuration mode.

```
RP/0/RSP0/CPU0:router(config)# ptp
RP/0/RSP0/CPU0:router(config-ptp)# clock
RP/0/RSP0/CPU0:router(config-ptp-clock)#
```

Related Commands	Command	Description
	<a href="#">ptp, on page 523</a>	Enters PTP configuration mode

## clock operation

To configure the type of PTP clock operation, use the **clock operation** command in PTP interface or profile configuration or interface PTP configuration mode. To remove the setting, use the **no** form of this command.

**clock operation** {**one-step** | **two-step**}  
**no clock operation**

### Syntax Description

**one-step** Specifies that the timestamp for the time synchronization message is directly in the synchronization message itself.

**two-step** Specifies that the timestamp for the time synchronization message is sent in a message that follows the synchronization message.

### Command Default

The default is two-step.

### Command Modes

PTP profile configuration

Interface PTP configuration

### Command History

Release	Modification
Release 4.2.0	This command was introduced.

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **clock operation** command can be used to configure the global PTP configuration profile which can then be associated with many interfaces. Similarly it can be used in interface PTP configuration mode to set the clock operation for a specific interface. Any values set in interface PTP configuration mode override the settings in the PTP configuration profile associated with the interface.

### Task ID

Task ID	Operation
ethernet-services	read, write

The following example sets PTP clock operation to two-step.

```
RP/0/RSP0/CPU0:router(config)# ptp
RP/0/RSP0/CPU0:router(config-ptp)# profile p1
RP/0/RSP0/CPU0:router(config-ptp-profile)# clock operation two-step
```

# clock-advertisement telecom-profile

To specify that the clock-advertisement behavior (the parameters used in announce messages) will follow the Telecom Profile for frequency (ITU-T G.8265.1), use the **clock-advertisement telecom-profile** command in PTP configuration mode. To remove the setting, use the **no** form of this command.

**clock-advertisement telecom-profile**  
**no clock-advertisement**

<b>Syntax Description</b>	This command has no keywords or arguments.						
<b>Command Default</b>	The default clock advertisement is compliant with the PTP 1588 standard.						
<b>Command Modes</b>	PTP configuration						
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 4.3.0</td> <td>This command was introduced.</td> </tr> <tr> <td>Release 6.1.2</td> <td>This command has been deprecated from Release 6.1.2.</td> </tr> </tbody> </table>	Release	Modification	Release 4.3.0	This command was introduced.	Release 6.1.2	This command has been deprecated from Release 6.1.2.
Release	Modification						
Release 4.3.0	This command was introduced.						
Release 6.1.2	This command has been deprecated from Release 6.1.2.						

**Usage Guidelines**

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The clock advertisement mode configuration controls the content of announce packets and the port numbers advertised by the router. Use this command to specify that clock advertisement is compliant with Telecom Profile mode instead of the PTP 1588 standard.

Task ID	Task ID	Operation
	ethernet-services	read, write

The following example shows how to set the clock advertisement profile.

```
RP/0/RSP0/CPU0:router(config)# ptp
RP/0/RSP0/CPU0:router(config-ptp)# clock-advertisement telecom-profile
```

Related Commands	Command	Description
	<a href="#">ptp, on page 523</a>	Enters PTP configuration mode.

# clock-class

To configure the clock class to use when advertising a PTP clock, use the **clock-class** command in PTP clock configuration mode. To remove the setting, use the **no** form of this command.

**clock-class** *class*  
**no clock-class**

## Syntax Description

*class* Specifies the clock class to use when advertising this clock. Values can range from 0 to 255.

## Command Default

The default is that the clock class is derived from platform properties.

## Command Modes

PTP clock configuration

## Command History

Release	Modification
Release 4.3.0	This command was introduced.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use this command to override the platform value, if needed.

## Task ID

Task ID	Operation
ethernet-services	read, write

The following example sets the clock class to 100.

```
RP/0/RSP0/CPU0:router(config)# ptp
RP/0/RSP0/CPU0:router(config-ptp)# clock
RP/0/RSP0/CPU0:router(config-ptp-clock)# clock-class 100
```

## Related Commands

Command	Description
<a href="#">ptp, on page 523</a>	Enters PTP configuration mode.



# clock profile

To configure the ITU-T Telecom profile and clock type that can be used in all local PTP sessions, use the **clock profile** command in the PTP configuration mode. To remove the configuration, use the **no** form of this command.

```
clock profile {g.8265.1 | g.8275.1}{clock-type T-GM | T-BC | T-TSC}
no clock profile {g.8265.1 | g.8275.1}{clock-type T-GM | T-BC | T-TSC}
```

<b>Syntax Description</b>	<p><b>clock-type T-GM   T-BC   T-TSC</b> Indicates the clock type for G.8275.1 profile. G.8275.1 profile supports three clock types:</p> <ul style="list-style-type: none"> <li>• T-GM: Telecom Grandmaster</li> <li>• T-BC: Telecom Boundary Clock</li> <li>• T-TSC: Telecom Time Slave Clock</li> </ul>
---------------------------	-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

**Command Default** The default PTP profile defined in the IEEE-1588 standard is used if this configuration is not used.

**Command Modes** PTP configuration

<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 6.1.2</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 6.1.2	This command was introduced.
Release	Modification				
Release 6.1.2	This command was introduced.				

**Usage Guidelines** The **clock-type** can be configured only when G.8275.1 is selected as the PTP profile.



**Note** The **clock-selection telecom-profile** and **clock-advertisement telecom-profile** commands are deprecated from Release 6.1.2. They are replaced by the **clock profile** command.

The following example shows configuring G.8265.1 profile:

```
RP/0/RSP0/CPU0:router(config)# ptp
RP/0/RSP0/CPU0:router(config-ptp)# clock profile g.8265.1
```



**Note** Configuring the G.8265.1 profile using **clock profile** command is equivalent to using **clock-selection telecom-profile** and **clock-advertisement telecom-profile** commands to configure the G.8265.1 profile in the earlier releases.

The following example shows configuring G.8275.1 profile with T-BC clock type:

```
RP/0/RSP0/CPU0:router(config)# ptp
```

```
RP/0/RSP0/CPU0:router(config-ptp)# clock profile g.8275.1 T-BC
```

# clock-selection telecom-profile

To specify that clock-selection behavior (the best-master-clock-algorithm in use) follows the telecom profile for frequency (ITU-T G.8265.1), use the **clock-selection telecom-profile** command in PTP configuration mode. To remove the setting, use the **no** form of this command.

**clock-selection telecom-profile**  
**no clock-selection**

<b>Syntax Description</b>	This command has no keywords or arguments.
<b>Command Default</b>	By default, the clock selection algorithm is compliant with the PTP 1588 standard.
<b>Command Modes</b>	PTP configuration

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 4.3.0	This command was introduced.
	Release 6.1.2	This command has been deprecated from Release 6.1.2.

<b>Usage Guidelines</b>	<p>To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.</p> <p>The clock selection mode configuration controls which best master clock algorithm is used. Use this command to specify that the algorithm is compliant with Telecom Profile mode.</p>
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	ethernet-services	read, write

The following example shows how to set the clock advertisement profile.

```
RP/0/RSP0/CPU0:router(config-ptp)# clock-selection telecom-profile
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<a href="#">ptp, on page 523</a>	Enters PTP configuration mode.

## COS

To specify the CoS value to use for Precision Time Protocol (PTP) packets sent by the router, use the **cos** command in PTP profile configuration mode or interface PTP configuration mode. To remove the setting, use the **no** form of this command.

```
cos number
no cos
```

<b>Syntax Description</b>	<i>number</i> Specifies the CoS value to use (0-7).
---------------------------	-----------------------------------------------------

<b>Command Default</b>	The default CoS value is 6.
------------------------	-----------------------------

<b>Command Modes</b>	PTP profile configuration Interface PTP configuration
----------------------	----------------------------------------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 4.2.0	This command was introduced.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

The **cos** command can be used to configure the global PTP configuration profile which can then be associated with many interfaces. Similarly it can be used in interface PTP configuration mode to set the CoS value for a specific interface. Any values set in interface PTP configuration mode override the settings in the PTP configuration profile associated with the interface.

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	ethernet-services	read, write

The following example sets the CoS value to 3 in the PTP configuration profile p1.

```
RP/0/RSP0/CPU0:router(config)# ptp
RP/0/RSP0/CPU0:router(config-ptp)# profile p1
RP/0/RSP0/CPU0:router(config-ptp-profile)# cos 3
```

The following example overrides the CoS value in the profile and sets it to be 2 for the interface:

```
RP/0/RSP0/CPU0:router(config)# interface TenGigE 0/0/0/10
RP/0/RSP0/CPU0:router(config-if) ptp
RP/0/RSP0/CPU0:router(config-if-ptp)# profile p1
RP/0/RSP0/CPU0:router(config-if-ptp)# cos 2
```

# delay-request

To configure settings for the PTP delay request message, use the **delay-request** command in PTP profile configuration or interface PTP configuration mode. To remove the setting, use the **no** form of this command.

**delay-request** {*frequency number* | *interval number*}  
**no delay-request**

## Syntax Description

*frequency* Specifies multiple announce messages per second (2, 4, 8, 16, 32, 64, or 128). Frequency of 4 means that four messages are sent per second.

*interval* Specifies one or fewer announce messages per second (every 1, 2, 4, 8, or 16 seconds). Interval of 2 means that an announce message is sent every two seconds.

## Command Default

The default is one second between messages.

## Command Modes

PTP configuration mode

Interface PTP configuration

## Command History

Release	Modification
Release 4.2.0	This command was introduced.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **delay-request** command can be used to configure the global PTP configuration profile which can then be associated with many interfaces. Similarly it can be used in interface PTP configuration mode to set the delay-request message settings for a specific interface. Any values set in interface PTP configuration mode override the settings in the PTP configuration profile associated with the interface.

## Task ID

Task ID	Operation
ethernet-services	read, write

The following example sets the delay request interval in the PTP configuration profile to 8 seconds.

```
RP/0/RSP0/CPU0:router(config)# ptp
RP/0/RSP0/CPU0:router(config-ptp)# profile p1
RP/0/RSP0/CPU0:router(config-ptp-profile)# delay-request interval 8
```

# domain

To specify the domain number for the PTP clock, use the **domain** command in PTP clock configuration mode. To remove the setting, use the **no** form of this command.

**domain** *number*  
**no domain**

## Syntax Description

*number* Specifies the domain number to use for this clock (0-255).

## Command Default

Default is 0.

## Command Modes

PTP clock configuration

## Command History

Release	Modification
Release 4.2.0	This command was introduced.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

PTP uses the specified domain number in all its PTP messages and ignores all PTP messages received from a different domain.

## Task ID

Task ID	Operation
ethernet-services	read, write

The following example sets the domain to 200.

```
RP/0/RSP0/CPU0:router(config)# ptp
RP/0/RSP0/CPU0:router(config-ptp)# clock
RP/0/RSP0/CPU0:router(config-ptp-clock)# domain 200
```

## Related Commands

Command	Description
<a href="#">ptp, on page 523</a>	Enters PTP configuration mode.

# delay-response

To configure settings for the PTP delay response message, use the **delay-response** command in PTP profile configuration or interface PTP configuration mode. To remove the setting, use the **no** form of this command.

**delay-response** {**grant-duration** *duration* | **timeout** *value*}

**no delay-response** {**grant-duration** | **timeout**}

## Syntax Description

*duration* Specifies the announce grant duration (60-1000 seconds). If port is in slave state, this is the length of grant which is requested. If the port is in master state, this is the maximum grant which will be allowed.

*value* Specifies delay response message timeout value (100-10000 milliseconds). If delay-response messages are not received from a master clock for longer than this timeout, the master is no longer qualified for selection. This setting applies only applies if the clock-selection telecom-profile is specified.

## Command Default

Default is grant-duration 600, timeout 5000.

## Command Modes

PTP profile configuration

Interface PTP configuration

## Command History

Release	Modification
Release 4.3.0	This command was introduced.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **delay-response** command can be used configure the global PTP configuration profile which can then be associated with many interfaces. Similarly it can be used in interface PTP configuration mode to set the delay response value for a specific interface. Any values set in interface PTP configuration mode override the settings in the PTP configuration profile associated with the interface.

## Task ID

Task ID	Operation
ethernet-services	read, write

The following example sets the PTP delay response timeout to 200 milliseconds in the PTP configuration profile:

```
RP/0/RSP0/CPU0:router(config)# ptp
RP/0/RSP0/CPU0:router(config-ptp)# profile p1
RP/0/RSP0/CPU0:router(config-ptp-profile)# delay-response timeout 200
```

The following example overrides the delay response timeout value in the profile and sets it to be 150 milliseconds for the interface:

```
RP/0/RSP0/CPU0:router(config)# interface TenGigE 0/0/0/10
RP/0/RSP0/CPU0:router(config-if) ptp
RP/0/RSP0/CPU0:router(config-if-ptp) # profile p1
RP/0/RSP0/CPU0:router(config-if-ptp) # delay-response timeout 150
```



# dscp

To set the DSCP value for use in Precision Time Protocol (PTP) packets sent by the router, use the **dscp** command in PTP profile configuration or interface PTP configuration mode. To remove the setting, use the **no** form of this command.

**dscp** *number*  
**no dscp**

<b>Syntax Description</b>	<i>number</i>	Specifies the DSCP value to use (0-63).
<b>Command Default</b>	The default DSCP value is 46.	
<b>Command Modes</b>	PTP profile configuration Interface PTP configuration	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 4.2.0	This command was introduced.
<b>Usage Guidelines</b>	<p>To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.</p> <p>The <b>dscp</b> command can be used configure the global PTP configuration profile which can then be associated with many interfaces. Similarly it can be used in interface PTP configuration mode to set the DSCP value for a specific interface. Any values set in interface PTP configuration mode override the settings in the PTP configuration profile associated with the interface.</p>	
<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	ethernet-services	read, write

The following example sets the DSCP value to 20 for PTP operation.

```
RP/0/RSP0/CPU0:router(config)# ptp
RP/0/RSP0/CPU0:router(config-ptp)# profile p1
RP/0/RSP0/CPU0:router(config-ptp-profile)# dscp 20
```

The following example overrides the DSCP value in the profile and sets it to be 42 for the interface:

```
RP/0/RSP0/CPU0:router(config)# interface TenGigE 0/0/0/10
RP/0/RSP0/CPU0:router(config-if) ptp
RP/0/RSP0/CPU0:router(config-if-ptp)# profile p1
RP/0/RSP0/CPU0:router(config-if-ptp)# dscp 42
```

# identity

To configure the PTP clock identity, use the **identity** command in PTP clock configuration mode. To remove the setting, use the **no** form of this command.

```
identity {eui-64 number | mac-address address}
no identity {eui-64 number | mac-address address}
```

## Syntax Description

<b>eui-64</b> <i>number</i>	Specifies the full EUI-64 number to determine the clock identity.
<b>mac-address</b> <i>address</i>	Specifies the router to determine the clock identity. Use one of the following addressing options to identify the router: <ul style="list-style-type: none"> <li>• <b>router</b>. Use the router's built-in MAC address as the clock identity</li> <li>• <b>address</b>. Enter a MAC address (H.H.H format).</li> </ul>

## Command Default

The router for clock identity is derived from the router MAC address.

## Command Modes

PTP clock configuration

## Command History

Release	Modification
Release 4.2.0	This command was introduced.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

You can specify a MAC address or a complete EUI-64 value to derive the clock identity. If you do not use this command, the clock identify is derived from the router's MAC address.

## Task ID

Task ID	Operation
ethernet-services	read, write

The following example sets the clock identity to MAC address A.B.C.

```
RP/0/RSP0/CPU0:router(config)# ptp
RP/0/RSP0/CPU0:router(config-ptp)# clock
RP/0/RSP0/CPU0:router(config-ptp-clock)# identity mac-address A.B.C
```

## Related Commands

Command	Description
<a href="#">ptp, on page 523</a>	Enters PTP configuration mode.

# local-priority

To configure priority for a port in the G.8275.1 profile, use the **local-priority** command in the PTP profile configuration mode or the Interface PTP configuration mode.

**local-priority** {*priority-value*}

## Syntax Description

*priority-value* Indicates the priority to be set for a port in the G.8275.1 profile. This priority value is used in the profile's alternate Best Master Clock Algorithm (BMCA).

**Note** Lower number indicates higher priority value.

## Command Default

The allowed range for the priority values are from 1 to 255. The default priority value is 128.

## Command Modes

PTP configuration

Interface PTP configuration

## Command History

Release	Modification
Release 6.1.2	This command was introduced.

## Usage Guidelines

The configured local priority value will be ignored if the G.8275.1 BMCA is not in use and a warning message will be displayed in the **show ptp configuration-errors** command.



**Note** The per-master priority value configured on a master clock overrides the per-port local priority value.

The following example shows configuring priority 1 for a port in the G.8275.1 profile:

```
RP/0/RSP0/CPU0:router(config)# ptp
RP/0/RSP0/CPU0:router(config-ptp)# local-priority 1
```

## log best-master-clock changes

To enable logging of changes to the best master clock for Precision Time Protocol (PTP), use the **log best-master-clock changes** command in PTP configuration mode. To remove the setting, use the **no** form of this command.

**log best-master-clock changes**  
**no log best-master-clock changes**

**Syntax Description** This command has no keywords or arguments.

**Command Default** None

**Command Modes** PTP configuration

Command History	Release	Modification
	Release 4.2.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task	Operation ID
	logging	read, write

The following example sets up PTP to log the best master clock changes.

```
RP/0/RSP0/CPU0:router(config)# ptp
RP/0/RSP0/CPU0:router(config-ptp)# log best-master-clock changes
```

Related Commands	Command	Description
	<a href="#">ptp, on page 523</a>	Enters PTP configuration mode.

# master

To add a master to the list of acceptable Precision Time Protocol (PTP) masters for an interface or profile, use the **master** command in PTP profile configuration or Interface PTP configuration mode. To remove the setting, use the **no** form of this command.

```

master {ipv4 address | ipv6 address} [{clock-class class | delay-symmetry number | multicast |
non-negotiated | priority number}]
no master {ipv4 address | ipv6 address} [{clock-class class | delay-symmetry number | multicast |
non-negotiated | priority number}]

```

## Syntax Description

<b>ipv4</b> <i>address</i>	Specifies the IPv4 address of a master.
<b>ipv6</b> <i>address</i>	Specifies the IPv6 address of a master.
<b>clock-class</b> <i>class</i>	Overrides the clock class received in announce messages from this master.
<b>delay-symmetry</b> <i>number</i>	Specifies the expected asymmetry.
<b>multicast</b>	Indicates that the master sends multicast message.
<b>non-negotiated</b>	Specifies non-negotiated unicast message.
<b>priority</b> <i>number</i>	Indicates the priority for selecting between multiple masters (lower numbers are high priority).
<b>clock-class</b> <i>class</i>	Overrides the clock class received in announce messages from this master.

## Command Default

This command has no default values or behavior.

## Command Modes

PTP profile configuration

## Command History

Release	Modification
Release 4.2.0	This command was introduced.
Release 6.2x	This command was modified. Support was extended to IPv6 addresses.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The address type used to configure the master must match the PTP transport type configured on the interface. If multiple masters are configured, the router attempts to communicate with all configured masters and selects between the available ones based on priority.



**Note** IPv4 multicast for PTP is not supported on Cisco ASR 9000 Routers.

Task ID	Task ID	Operation
	ethernet-services	read, write

The following example assigns two masters to the profile and gives higher priority to the master with IPv4 address 10.10.4.5.

```
RP/0/RSP0/CPU0:router(config)# ptp
RP/0/RSP0/CPU0:router(config-ptp)# profile p1
RP/0/RSP0/CPU0:router(config-ptp-profile)# master ipv4 10.10.4.5 priority 1
RP/0/RSP0/CPU0:router(config-ptp-profile)# master ipv4 10.10.4.7 priority 2
```

# min-clock-class

To configure minimum clock class accepted from a PTP master, use the **min-clock-class** command in the PTP configuration mode. To remove the configuration, use the **no** form of this command.

**min-clock-class** *class*  
**no min-clock-class** *class*

## Syntax Description

*class* Indicates the minimum clock class accepted. The range is between 0 and 255.

## Command Default

The default clock class can be obtained from the platform properties.

## Command Modes

PTP configuration

## Command History

Release	Modification
Release 6.1.2	This command was introduced.

## Usage Guidelines

The clocks with clock-class number higher than the minimum clock class number will not be considered for a parent clock selection. This command is used to override the platform value (if needed).



**Note** clock-class values are not numerically ordered (lower value of clock-class has higher importance).

The following example configures the minimum clock class to 7:

```
RP/0/RSP0/CPU0:router(config)# ptp
RP/0/RSP0/CPU0:router(config-ptp)# min-clock-class 7
```

# multicast

To allow PTP multicast messages to be sent, use the **multicast** command in PTP profile configuration mode or Interface PTP configuration mode. To remove the setting, use the **no** form of this command.

```
multicast {target-address ethernet{forwardable mac-address | non-forwardable mac-address}}
no multicast {target-address ethernet{forwardable mac-address | non-forwardable mac-address}}
```

<b>Syntax Description</b>	<p><b>target-address ethernet</b> <i>forwardable mac-address</i>   <i>non-forwardable mac-address</i></p>	<p>Indicates the Ethernet multicast group address to send the multicast messages. This command supports either forwardable or non-forwardable Ethernet mac addresses only.</p> <ul style="list-style-type: none"> <li>• Forwardable mac-address: 01-1B-19-00-00-00</li> <li>• Non-forwardable mac-address: 01-80-C2-00-00-0E</li> </ul>
---------------------------	-------------------------------------------------------------------------------------------------------------------	-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

**Command Default** By default, multicast messaging is disabled for PTP.

**Command Modes** PTP profile configuration  
Interface PTP configuration

<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 4.2.0</td> <td>This command was introduced.</td> </tr> <tr> <td>Release 6.1.2</td> <td>Support for ethernet multicast address was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 4.2.0	This command was introduced.	Release 6.1.2	Support for ethernet multicast address was introduced.
Release	Modification						
Release 4.2.0	This command was introduced.						
Release 6.1.2	Support for ethernet multicast address was introduced.						

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

When multicast is configured, announce and sync messages are sent as multicast messages, but delay-response messages are sent as unicast messages.

<b>Task ID</b>	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operation</th> </tr> </thead> <tbody> <tr> <td>ethernet-services</td> <td>read, write</td> </tr> </tbody> </table>	Task ID	Operation	ethernet-services	read, write
Task ID	Operation				
ethernet-services	read, write				

The following example enables PTP multicast messages in the configuration profile to be sent to the forwardable mac-address:

```
RP/0/RSP0/CPU0:router(config)# ptp
RP/0/RSP0/CPU0:router(config-ptp)# profile p1
RP/0/RSP0/CPU0:router(config-ptp-profile)# multicast target-address ethernet 01-1B-19-00-00-00
```



# priority1

To specify the priority 1 number to use when advertising a PTP clock, use the **priority1** command in PTP clock configuration mode. To remove the setting, use the **no** form of this command.

**priority1** *number*  
**no priority1**

## Syntax Description

*number* Specifies the priority 1 number to use for this clock (0-255).

## Command Default

Default is 128.

## Command Modes

PTP clock configuration

## Command History

Release	Modification
Release 4.2.0	This command was introduced.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

## Task ID

Task ID	Operation
ethernet-services	read, write

The following example sets the priority 1 number to 50

```
RP/0/RSP0/CPU0:router(config)# ptp
RP/0/RSP0/CPU0:router(config-ptp)# clock
RP/0/RSP0/CPU0:router(config-ptp-clock)# priority1 50
```

## Related Commands

Command	Description
<a href="#">ptp, on page 523</a>	Enters PTP configuration mode.
<a href="#">priority2, on page 518</a>	Specifies the priority 2 number to use when advertising a PTP clock.

# priority2

To specify the priority 2 number to use when advertising a PTP clock, use the **priority2** command in PTP clock configuration mode. To remove the setting, use the **no** form of this command.

**priority2** *number*  
**no priority2**

## Syntax Description

*number* Specifies the priority 2 number to use for this clock (0-255).

## Command Default

Default is 128.

## Command Modes

PTP clock configuration

## Command History

Release	Modification
Release 4.2.0	This command was introduced.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

## Task ID

Task ID	Operation
ethernet-services	read, write

The following example sets the priority 2 number to 50

```
RP/0/RSP0/CPU0:router(config)# ptp
RP/0/RSP0/CPU0:router(config-ptp)# clock
RP/0/RSP0/CPU0:router(config-ptp-clock)# priority2 50
```

## Related Commands

Command	Description
<a href="#">ptp, on page 523</a>	Enters PTP configuration mode
<a href="#">priority1, on page 517</a>	Specifies the priority 1 number to use when advertising a PTP clock.

# profile (interface)

To assign a Precision Time Protocol (PTP) configuration profile to an interface, use the **profile** command in interface PTP configuration mode. To remove the configuration profile from the interface, use the **no** form of this command.

```
profile profile-name
no profile profile-name
```

<b>Syntax Description</b>	<i>profile-name</i> Name of profile to associate with the Interface.
---------------------------	----------------------------------------------------------------------

<b>Command Default</b>	No configuration profile is associated with the interface.
------------------------	------------------------------------------------------------

<b>Command Modes</b>	Interface PTP configuration
----------------------	-----------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 4.2.0	This command was introduced.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

A PTP profile is a configuration template that can be applied to multiple interfaces. Define the profile using the **profile** command in PTP configuration mode.

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	ethernet-services	read, write

The following example shows how to assign a configuration profile to a specific interface.

```
RP/0/RSP0/CPU0:router(config)# interface TenGigE 0/0/0/10
RP/0/RSP0/CPU0:router(config-if)# ptp
RP/0/RSP0/CPU0:router(config-if-ptp)# profile tp128
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<a href="#">profile (PTP), on page 520</a>	Enters Precision Time Protocol (PTP) profile configuration mode.

## profile (PTP)

To enter Precision Time Protocol (PTP) profile configuration mode and run PTP profile configuration commands, use the **profile** command in PTP configuration mode or interface PTP configuration mode.

**profile** *name*

<b>Syntax Description</b>	<i>name</i> Enters PTP profile configuration mode for the specified profile name.
---------------------------	-----------------------------------------------------------------------------------

<b>Command Default</b>	No default behavior or values
------------------------	-------------------------------

<b>Command Modes</b>	PTP configuration
----------------------	-------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 4.2.0	This command was introduced.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

A Precision Time Protocol ( PTP) profile is a configuration template that can be applied to multiple interfaces. From PTP profile configuration mode, the following PTP profile configuration commands are available:

```
RP/0/RSP0/CPU0:router(config-ptp-profile)# ?

announce Announce message options
clear Clear the uncommitted configuration
clock PTP clock-operation to use
commit Commit the configuration changes to running
cos Specify the CoS-bits value to use
delay-request Configure the sending of delay-request messages
delay-response Delay-Response message options
describe Describe a command without taking real actions
do Run an exec command
dscp Specify the DSCP value to use
exit Exit from this submode
master Add a master to listen to on interfaces using this profile
multicast Allow multicast messages to be sent
no Negate a command or set its defaults
port PTP port options
pwd Commands used to reach current submode
root Exit to the global configuration mode
show Show contents of configuration
source PTP source address options
sync Configure how often Sync messages are sent
sync Sync message options
transport PTP transport type to use on this interface
unicast-grant Unicast grant options
```

Task ID	Task ID	Operation
	ethernet-services	read, write

The following example shows how to configure the profile tp128:

```
RP/0/RSP0/CPU0:router(config)# ptp
RP/0/RSP0/CPU0:router(config-ptp)# profile tp128
RP/0/RSP0/CPU0:router(config-ptp-profile)#
```

Related Commands	Command	Description
	<a href="#">profile (interface), on page 519</a>	Assigns a PTP configuration profile to an interface.

## port state

To configure the state for a PTP port, use the **port state** command in the PTP profile configuration mode or the Interface PTP configuration mode. To remove the setting, use the **no** form of this command.

```
port state {slave-only | master-only}
no port state
```

### Syntax Description

**slave-only** Configures the port state to be a slave.

**master-only** Configures the port state to be a master. The **master-only** keyword is used for multicast transport mode.

### Command Default

Dynamic port state changes are based on the peers with which the port communicates.

### Command Modes

PTP profile configuration

Interface PTP configuration

### Command History

Release	Modification
Release 4.2.0	This command was introduced.
Release 6.1.2	<b>master-only</b> keyword was introduced.

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

### Task ID

Task ID	Operation
ethernet-services	read, write

The following example configures the PTP port state to be slave-only:

```
RP/0/RSP0/CPU0:router(config)# ptp
RP/0/RSP0/CPU0:router(config-ptp)# profile p1
RP/0/RSP0/CPU0:router(config-ptp)# port state slave-only
```

The following example configures the PTP port state to be master-only:

```
RP/0/RSP0/CPU0:router(config)# ptp
RP/0/RSP0/CPU0:router(config-ptp)# profile p1
RP/0/RSP0/CPU0:router(config-ptp)# port state master-only
```

# ptp

To enter Precision Time Protocol (PTP) configuration mode and run PTP configuration commands, use the **ptp** command. Using the command from global configuration mode enters PTP configuration mode. Using the command from interface configuration mode enters interface PTP configuration mode. To remove PTP settings, use the **no** form of this command.

**ptp**  
**no ptp**

**Syntax Description** This command has no keywords or arguments.

**Command Default** No default behavior or values.

**Command Modes** Global configuration  
Interface configuration

Command History	Release	Modification
	Release 4.3.1	Support was added for this command in Bundle Ethernet interface configuration mode.
	Release 4.3.1	Support was added for this command in Bundle Ethernet interface configuration mode.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

PTP configuration commands can also be run from global configuration mode by preceding the command string with the **ptp** keyword. From PTP configuration mode, the following PTP configuration commands are available:

```
RP/0/RSP0/CPU0:router(config-ptp)# ?
clear Clear the uncommitted configuration
clock PTP Clock Configuration
clock-advertisement Clock advertisement configuration
clock-selection Clock selection configuration
commit Commit the configuration changes to running
describe Describe a command without taking real actions
do Run an exec command
exit Exit from this submode
log Precision Time Protocol logging configuration
no Negate a command or set its defaults
profile PTP Profile Configuration
pwd Commands used to reach current submode
root Exit to the global configuration mode
show Show contents of configuration
time-of-day Precision Time Protocol time-of-day configuration
```

PTP commands can be run on Gigabit Ethernet interfaces or Bundle Ethernet interfaces.

Task ID	Task ID	Operation
	ethernet-services	read, write

The following example shows how to enter PTP configuration mode from global configuration mode.

```
RP/0/RSP0/CPU0:router(config)# ptp
RP/0/RSP0/CPU0:router(config-ptp)#
```

The following example shows how to enter interface PTP configuration mode.

```
RP/0/RSP0/CPU0:router(config)# interface TenGigE 0/0/0/10
RP/0/RSP0/CPU0:router(config-if)# ptp
RP/0/RSP0/CPU0:router(config-if-ptp)#
```

#### Related Commands

Command	Description
<a href="#">profile (PTP), on page 520</a>	Enters PTP profile configuration mode.



# show ptp advertised-clock

To display properties of the clock that the system advertises over Precision Time Protocol (PTP), use the **show ptp advertised-clock** command in EXEC mode.

**show ptp advertised-clock**

<b>Syntax Description</b>	This command has no keywords or arguments.
---------------------------	--------------------------------------------

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	EXEC
----------------------	------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 4.2.0	This command was introduced.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	ethernet-services	read

## Example

The following shows information about the PTP advertised clock. The output displays the clock identity and the clock properties.

```
RP/0/RSP0/CPU0:router# show ptp advertised-clock

Fri Jan 9 04:54:33.345 PST
Clock ID: Local Clock (2651ffffec41c26)
Clock properties:
 Priority1: 128, Priority2: 128, Class: 6, Accuracy: 0xfe
 Offset scaled log variance: 0xffff
 Domain: 0, Time Source: GPS, Timescale: PTP
 Frequency-traceable, Time-traceable
 Current UTC offset: 34 seconds
```

# show ptp foreign-masters

To display the Precision Time Protocol (PTP) foreign master clocks that are available to the router, use the **show ptp foreign-masters** command in EXEC mode.

```
show ptp foreign-masters [brief] {interface name | location node}
show ptp foreign-masters best
```

## Syntax Description

<i>brief</i>	Lists all foreign-masters known on the router, ordered by the interface on which they were discovered.  If this option is omitted, the output also includes detailed clock properties, unicast messages that are granted from the master, length of time the master has been qualified, and information about the clock peer.
<i>name</i>	Displays foreign masters that were discovered the specified interface. For more information, use the question mark ( ? ) online help function
<i>node</i>	Displays foreign masters that were discovered the specified node
<b>best</b>	Displays the state of the best foreign master found in the network

## Command Default

None

## Command Modes

EXEC

## Command History

Release	Modification
Release 4.2.0	This command was introduced.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

This command displays the state of foreign masters for the PTP processes. It is only relevant when running as a boundary clock; in grandmaster mode, no relevant output gets displayed.

The **show ptp foreign-masters** command with the **best** keyword collects grandmaster information from all RPs and filters out all but the grandmaster on the active timing card. If the active timing card does not support running as slave, no foreign masters are displayed and instead, it is indicated that slaving is not supported (refer examples section).

## Task ID

Task ID	Operation
ethernet-services	read

## Example

The following shows output with the brief option.

```
RP/0/RSP0/CPU0:router# show ptp foreign-masters brief
```

M=Multicast,Q=Qualified,GM=Grandmaster

Interface	Transport	Address	Priority1	State
Gi0/2/0/0	IPv4	192.168.172.122	13	M,Q
	IPv4	192.168.172.123	17	M
Gi0/2/0/1	IPv6	fe80::2b0:4aff:fe6b:f4fc	1	Q,GM
	IPv6	fe80::2b0:4aff:fe6b:1234	18	Q
Gi0/3/0/0	Ethernet	00b0.4a6b.f4fc		

The example indicates if the foreign-master is multicast and the clock that is being used as the grandmaster.

The following example shows output for the location 0/2/CPU0, including the brief option.

```
RP/0/RSP0/CPU0:router# show ptp foreign-masters brief location 0/2/CPU0
```

M=Multicast,Q=Qualified,GM=Grandmaster

Interface	Transport	Address	Priority1	State
Gi0/2/0/0	IPv4	192.168.172.122	13	M,Q
	IPv4	192.168.172.123	17	M
Gi0/2/0/1	IPv6	fe80::2b0:4aff:fe6b:f4fc	1	Q,GM
	IPv6	fe80::2b0:4aff:fe6b:1234	18	Q

The following example shows output for the interface GigabitEthernet0/2/0/0, without the brief option.

```
RP/0/RSP0/CPU0:router# show ptp foreign-masters brief interface GigabitEthernet0/2/0/0
```

Interface GigabitEthernet0/2/0/3 (PTP port number 27):

```
IPv4, Address 172.108.11.25
 Configured priority: None
 Announce granted: every 2 seconds, 600 seconds
 Sync granted: 16 per-second, 400 seconds
 Delay-Resp granted: 16 per-second, 600 seconds
 Qualified for 6 days, 2 hours, 11 minutes
 Clock ID: ACDE48FFFE234567
 Clock properties:
 Priority1: 1, Priority2: 83, Class: 6, Accuracy: 0x2B
 Offset scaled log variance: 0x27FF, Steps-removed: 5
 Domain: 0, Time Source: GPS, Timescale: PTP
 Frequency-traceable, Time-traceable
 Current UTC offset: 25 seconds
 Parent properties:
 Clock-ID: BADE48FFFE234367
 Port number: 3, Steps Removed: 2

IPv4, Address 172.108.11.23, Multicast
 Configured priority: 27
 Announce granted: every 2 seconds, 600 seconds
 Qualified for 5 days, 4 hours, 27 minutes
 Clock ID: ACDE48FFFE234567
 Clock properties:
 Priority1: 7, Priority2: 83, Class: 6, Accuracy: 0x2B
 Offset scaled log variance: 0x27FF, Steps-removed: 5
```

**show ptp foreign-masters**

```

Domain: 0, Time Source: GPS, Timescale: PTP
Frequency-traceable, Time-traceable
Current UTC offset: 25 seconds
Parent properties:
Clock-ID: BADE48FFFE234367
Port number: 5, Steps Removed: 1

IPv4, Address 172.108.11.18, Multicast
Configured priority: 11
Not qualified

```

The following example shows state information for the best foreign master in the network.

```

RP/0/RSP0/CPU0:router# show ptp foreign-masters best

Used to set system frequency and time
IPv4, Address 1.2.3.4
Received on interface GigabitEthernet0/2/0/3 (port number 0x1007)
Clock ID: ACDE48FFFE234567
Best foreign-master for 5 days, 4 hours, 27 minutes
Advertised for 5 days, 4 hours, 20 minutes
Clock properties:
Priority1: 7, Priority2: 83, Class: 6, Accuracy: 0x2B
Offset scaled log variance: 0x27FF, Steps-removed: 5
Domain: 0, Time Source: GPS, Timescale: PTP
Frequency-traceable, Time-traceable
Current UTC offset: 25 seconds
Parent properties:
Clock-ID: BADE48FFFE234367
Port number: 0x0005

```

This example indicates the display when slaving is not supported on the active timing card.

```

RP/0/RSP0/CPU0:router # show ptp foreign-masters best
PTP slaving is not supported on the RSP.

```

## show ptp interfaces

To display a summary of the Precision Time Protocol (PTP) port state for the specified interface, use the **show ptp interfaces** command in EXEC mode.

```
show ptp interfaces [brief] {interface | all}
show ptp interfaces summary location node
```

Syntax Description	interface	Specifies the interface. For more information, use the question mark ( ? ) online help function.
	all	Displays information for all interfaces.
	brief	Displays a one-line summary of the functional state of the interface (or all interfaces).
	location node	Displays information for the specified node

**Command Default** None

**Command Modes** EXEC

Command History	Release	Modification
	Release 4.2.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operation
	ethernet-services	read

### Example

The following shows the output for GigabitEthernet0/2/0/3 interface in master state.

The output displays Local Priority value only if the configured profile is G.8275.1 profile.

```
RP/0/RSP0/CPU0:router# show ptp interfaces GigabitEthernet0/2/0/3
```

```
GigabitEthernet0/2/0/3 is in MASTER state
PTP port number: 1
IPv4 transport: IPv4 address 1.2.3.4
Linestate: Up
Local Priority: 128
Mechanism: Two-step delay-request-response
 Sync rate: every 2 seconds
 Announce rate: every 8 seconds, timeout 5
 Delay-Req rate: every 4 seconds
CoS: 6, DSCP: 46
```

```

Platform capabilities:
 Supported: One-step, Ethernet
 Not-Supported: IPv6, Multicast, Slave
 Max-Sync-rate: 4 per second
Master state only
23 Unicast peers

```

### Example

The following shows that the GigabitEthernet0/1/0/3 interface is in the un-calibrated state.

```
RP/0/RSP0/CPU0:router# show ptp interfaces GigabitEthernet0/1/0/3
```

```

GigabitEthernet0/1/0/3 is in UNCALIBRATED state
PTP port number: 4
IPv4 transport: IPv4 address 5.4.3.2
Linestate: Up
Mechanism: Two-step delay-request-response, Slave-only
 Sync rate: 2 per second
 Announce rate: 2 per second, timeout 4
 Delay-Req interval: 4 per second
CoS: 5, DSCP: 23
Platform capabilities:
 Supported: One-step, Ethernet, Multicast, Slave
 Not-Supported: IPv6
 Max-Sync-rate: 2 per second
Master table:
(K = Known, Q = Qualified, GM = Grandmaster)
 IPv4 address 5.4.3.3: priority 5, multicast, K,Q,GM
 IPv4 address 5.4.3.4: priority not set
 MAC-address 12ab.7431.327c: priority 3, K
Slave state only

```

### Example

The following shows output with the **brief** keyword specified.

```
RP/0/RSP0/CPU0:router# show ptp interfaces brief
```

Intf Name	Port Number	Port State	Line Transport	State	Mechanism
Gi0/2/0/0	1	MASTER	IPv4	Up	2-step DRRM
Gi0/2/0/1	5	PASSIVE	Ethernet	Up	1-step DRRM
Gi0/2/0/2	23	MASTER	Ethernet	Up	2-step DRRM
Gi0/2/0/0	6	INIT	IPv4	Down	2-step DRRM

### Example

The following shows summary output for the location 0/2/cpu0.

```
RP/0/RSP0/CPU0:router# show ptp interfaces summary location 0/2/cpu0
```

```

=====
Interface port states

```

```
=====
INIT 11
LISTENING 27
PASSIVE 12
PRE-MASTER 2
MASTER 50
UNCALIBRATED 0
SLAVE 1
FAULTY 0

Total 103
```

# show ptp local-clock

To display properties of the local Precision Time Protocol (PTP) clock, use the **show ptp local-clock** command in EXEC mode.

**show ptp local-clock**

<b>Syntax Description</b>	This command has no keywords or arguments.
---------------------------	--------------------------------------------

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	EXEC
----------------------	------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 4.2.0	This command was introduced.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	ethernet-services	read

## Example

The following shows information about the local PTP clock.

```
RP/0/RSP0/CPU0:router# show ptp local-clock

Sat Jul 28 14:15:54.357 UTC
Clock ID: 2651ffffec4496e
Clock properties:
 Priority1: 128, Priority2: 128, Class: 248, Accuracy: 0xfe
 Offset scaled log variance: 0xffff
 Domain: 0, Time Source: Internal, Timescale: ARB
 No frequency or time traceability
 Current UTC offset: 34 seconds
```



# show ptp packet-counters

To display counters for packets received and send by Precision Time Protocol (PTP), use the **show ptp packet-counters** command in EXEC mode.

```
show ptp packet-counters location node
show ptp packet-counters interface detail
show ptp packet-counters interface master {ipv4 ipv4-address | ethernet ethernet-address}
```

Syntax Description	location node	Displays information for the specified node
	interface	Specifies the interface.
	detail	Displays detailed information.
	master	Displays information regarding the PTP master.
	ipv4-address	Specifies an IPv4 address.
	ethernet-address	Specifies an Ethernet address.

**Command Default** None

**Command Modes** EXEC

Command History	Release	Modification
	Release 4.2.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operation
	ethernet-services	read

## Example

The following displays the packet counters for the GigabitEthernet0/2/0/1 interface.

```
RP/0/RSP0/CPU0:router# show ptp packet-counters GigabitEthernet0/2/0/1
```

Packets	Sent	Received	Dropped
Announce	3	83	11
Sync	0	32	5
Follow-Up	0	31	0
Delay-Req	22	0	0
Delay-Resp	0	21	7

## show ptp packet-counters

Pdelay-Req	0	7	0
Pdelay-Resp	0	0	0
Pdelay-Resp-Follow-Up	0	0	0
Signaling	2	1	0
Management	0	0	0
Other	0	3	12
	----	----	----
TOTAL	27	178	35

**Example**

The following displays the packet counters with additional details for the GigabitEthernet0/2/0/1 interface.

```
RP/0/RSP0/CPU0:router# show ptp packet-counters GigabitEthernet0/2/0/1 details
```

Packets	Sent	Received	Dropped
Announce	3	83	11
Sync	0	32	5
Follow-Up	0	31	0
Delay-Req	22	0	0
Delay-Resp	0	21	7
Pdelay-Req	0	7	0
Pdelay-Resp	0	0	0
Pdelay-Resp-Follow-Up	0	0	0
Signaling	2	1	0
Management	0	0	0
Other	0	3	12
	----	----	----
TOTAL	27	178	35

```
Master IPv4 5.4.3.4:
```

Packets	Sent	Received	Dropped
Announce	1	40	1
Sync	0	23	4
Follow-Up	0	14	0
Delay-Req	12	0	0
Delay-Resp	0	10	7
Pdelay-Req	0	7	0
Pdelay-Resp	0	0	0
Pdelay-Resp-Follow-Up	0	0	0
Signaling	2	1	0
Management	0	0	0
Other	0	3	12
	----	----	----
TOTAL	15	98	24

```
Master Ethernet 12ab.7431.327c:
```

Packets	Sent	Received	Dropped
Announce	2	43	10
Sync	0	9	1
Follow-Up	0	17	0
Delay-Req	10	0	0
Delay-Resp	0	11	0
Pdelay-Req	0	0	0
Pdelay-Resp	0	0	0
Pdelay-Resp-Follow-Up	0	0	0
Signaling	0	0	0

Management	0	0	0
Other	0	0	0
	----	----	----
TOTAL	12	80	11

**Example**

The following displays the packet counters for the master with IPv4 address 5.4.3.4 for the GigabitEthernet0/2/0/1 interface.

```
RP/0/RSP0/CPU0:router# show ptp packet-counters GigabitEthernet0/2/0/1 master ipv4 5.4.3.4
```

```
Master IPv4 5.4.3.4:
Packets Sent Received Dropped

Announce 1 40 1
Sync 0 23 4
Follow-Up 0 14 0
Delay-Req 12 0 0
Delay-Resp 0 10 7
Pdelay-Req 0 7 0
Pdelay-Resp 0 0 0
Pdelay-Resp-Follow-Up 0 0 0
Signaling 2 1 0
Management 0 0 0
Other 0 3 12

TOTAL 15 98 24
```

**Example**

The following displays the packet counters for the location 0/2/cpu0 for the GigabitEthernet0/2/0/1 interface.

```
RP/0/RSP0/CPU0:router# show ptp packet-counters location 0/2/cpu0
```

```
Packets Sent Received Dropped

Announce 1735 101 52
Sync 3753 32 5
Follow-Up 3751 32 7
Delay-Req 0 4073 108
Delay-Resp 4073 0 0
Pdelay-Req 0 7 0
Pdelay-Resp 0 0 0
Pdelay-Resp-Follow-Up 0 0 0
Signaling 73 18 0
Management 0 0 0
Other 0 3 218

TOTAL 13385 4266 390

Drop Reason Drop Count

Not ready for packets 289
Wrong domain number 71
Packet too short 1
Local packet received, same port number 7
```

## show ptp packet-counters

```
Local packet received, higher port number 11
Local packet received, lower port number 11
No timestamp received with packet 0
Zero timestamp received with packet 0

TOTAL
```

## show ptp unicast-peers

To display information on the peers to which Precision Time Protocol (PTP) is sending unicast messages, use the **show ptp unicast-peers** command in EXEC mode.

**show ptp unicast-peers** *interface*

<b>Syntax Description</b>	<i>interface</i> Displays information for the specified interface.
---------------------------	--------------------------------------------------------------------

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	EXEC
----------------------	------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 4.2.0	This command was introduced.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	ethernet-services	read

The following example shows PTP unicast peer information for the GigabitEthernet0/2/0/1 interface.

```
RP/0/RSP0/CPU0:router# show ptp unicast-peers GigabitEthernet0/2/0/1

Interface GigabitEthernet0/2/0/1:
 IPv4-address 1.2.3.4
 Announce granted: every 2 seconds, 600 seconds
 Sync granted: 16 per second, 600 seconds
 Delay-Resp granted: 16 per second, 600 seconds
 IPv4-address 1.2.3.5
 Announce granted: every 1 second, 400 seconds
 IPv4-address 1.2.3.6
 Delay-Resp granted: 16 per second, 600 seconds
```

The following example shows PTP unicast peer information for all interfaces.

```
RP/0/RSP0/CPU0:router# show ptp unicast-peers

Interface GigabitEthernet0/2/0/1:
 IPv4-address 1.2.3.4
 Announce granted: every 2 seconds, 600 seconds
 Sync granted: 16 per second, 600 seconds
 Delay-Resp granted: 16 per second, 600 seconds
 IPv4-address 1.2.3.5
```

**show ptp unicast-peers**

```
Announce granted: every 1 second, 400 seconds
IPv4-address 1.2.3.6
Delay-Resp granted: 16 per second, 600 seconds

Interface GigabitEthernet0/3/0/2:
Mac-address 00b0.4a6b.f4fc
Announce granted: every 2 seconds, 600 seconds
Sync granted: 16 per second, 600 seconds
Delay-Resp granted: 16 per second, 600 seconds
Mac-address 00b0.4a6b.f4fd
Announce granted: every 1 second, 400 seconds

Interface GigabitEthernet0/3/0/3:
No known peers
```

## source ipv4 address

To specify the source IPv4 address to use when sending IPv4 packets, use the **source ipv4 address** command in PTP profile configuration or interface PTP configuration mode. To remove the setting, use the **no** form of this command.

```
source ipv4 address address
no source ipv4 address
```

### Syntax Description

*address* Specifies an IPv4 address.

### Command Default

This command has no default values or behavior.

### Command Modes

PTP profile configuration  
Interface PTP configuration

### Command History

Release	Modification
Release 4.2.0	This command was introduced.

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **source ipv4 address** command can be used configure the global PTP configuration profile which can then be associated with many interfaces. Similarly it can be used in interface PTP configuration mode to set the source IPv4 address for a specific interface. Any values set in interface PTP configuration mode override the settings in the PTP configuration profile associated with the interface.

### Task ID

Task ID	Operation
ethernet-services	read, write

The following example specifies the source IPv4 address 10.10.10.4 for PTP packets.

```
RP/0/RSP0/CPU0:router(config)# ptp
RP/0/RSP0/CPU0:router(config-ptp)# profile p1
RP/0/RSP0/CPU0:router(config-ptp-profile)# source ipv4 address 10.10.10.4
```

The following example overrides the source IPv4 address in the profile and sets it to be 10.10.10.6 for the interface:

```
RP/0/RSP0/CPU0:router(config)# interface TenGigE 0/0/0/10
RP/0/RSP0/CPU0:router(config-if) ptp
RP/0/RSP0/CPU0:router(config-if-ptp)# profile p1
RP/0/RSP0/CPU0:router(config-if-ptp)# source ipv4 address 10.10.10.6
```

# sync

To configure settings for PTP sync messages, use the **sync** command in PTP profile configuration or interface PTP configuration mode. To remove the setting, use the **no** form of this command.

```
sync {frequency frequency | grant-duration duration | interval interval | timeout timeout}
no sync {frequency | grant-duration | interval | timeout}
```

## Syntax Description

<b>frequency</b> <i>frequency</i>	Use to specify multiple sync messages per second (2, 4, 8, 16, 32, 64, or 128). Frequency of 4 means that four messages are sent per second.
<b>grant-duration</b> <i>duration</i>	Specifies the announce grant duration (60-1000 seconds). If the port is in the slave state, this is the grant that is requested. If the port is in the master state, this is the maximum grant that is allowed.
<b>interval</b> <i>interval</i>	Use to specify one or fewer sync messages per second (every 1, 2, 4, 8, or 16 seconds). Interval of 2 means that a sync message is sent every two seconds.
<b>timeout</b> <i>timeout</i>	Specifies the time after which the sync message times out (100-10000 milliseconds).

## Command Default

Defaults: grant-duration 600, interval 1, timeout 5000.

## Command Modes

PTP profile configuration  
Interface PTP configuration

## Command History

Release	Modification
Release 4.2.0	This command was introduced.
Release 4.3.0	The <b>grant-duration</b> and <b>timeout</b> keywords were added.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **sync** command can be used to configure the global PTP configuration profile which can then be associated with many interfaces. Similarly it can be used in interface PTP configuration mode to set the sync value for a specific interface. Any values set in interface PTP configuration mode override the settings in the PTP configuration profile associated with the interface.

The **grant-duration** and **timeout** keywords are used for the ITU-T Telecom Profile. A frequency value of 128 messages per second is valid for the ITU-T Telecom Profile only.



Task ID	Task ID	Operation
	ethernet-services	read, write

The following example sets the PTP sync timeout to 2000 milliseconds.

```
RP/0/RSP0/CPU0:router(config)# ptp
RP/0/RSP0/CPU0:router(config-ptp)# profile p1
RP/0/RSP0/CPU0:router(config-ptp-profile)# sync frequency 2000
```

The following example overrides the sync frequency value in the profile and sets it to be 1500 milliseconds for the interface:

```
RP/0/RSP0/CPU0:router(config)# interface TenGigE 0/0/0/10
RP/0/RSP0/CPU0:router(config-if) ptp
RP/0/RSP0/CPU0:router(config-if-ptp)# profile p1
RP/0/RSP0/CPU0:router(config-if-ptp)# sync frequency 1500
```

# timescale

To set the time scale to use when advertising time for Precision Time Protocol (PTP), use the **timescale** command in PTP clock configuration mode. To remove the setting, use the **no** form of this command.

**timescale** {ARB | PTP}  
**no timescale**

Syntax Description	ARB	Specifies ARB (arbitrary) time.
	PTP	Specifies PTP time.

**Command Default** The default value is derived from platform properties.

**Command Modes** PTP clock configuration

Command History	Release	Modification
	Release 4.2.1	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use this command to override the platform value, if needed.

Task ID	Task ID	Operation
	ethernet-services	read, write

The following example sets the time scale to ARB.

```
RP/0/RSP0/CPU0:router(config)# ptp
RP/0/RSP0/CPU0:router(config-ptp)# clock
RP/0/RSP0/CPU0:router(config-ptp-clock)# timescale ARB
```

Related Commands	Command	Description
	<a href="#">ptp, on page 523</a>	Enters PTP configuration mode.

## time-of-day

To set the priority used by Precision Time Protocol (PTP) when selecting between PTP and other sources for time-of-day on the router (for example GPS), use the **time-of-day** command in PTP configuration mode. To remove the setting, use the **no** form of this command.

**time-of-day** *priority number*  
**no time-of-day** *priority*

<b>Syntax Description</b>	<b>priority</b> <i>number</i> Specifies the time of day priority to rank a foreign PTP grand master against other time sources, such as GPS (1-255).				
<b>Command Default</b>	The default is priority 100.				
<b>Command Modes</b>	PTP configuration				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 4.2.0</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 4.2.0	This command was introduced.
Release	Modification				
Release 4.2.0	This command was introduced.				
<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.				
<b>Task ID</b>	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operation</th> </tr> </thead> <tbody> <tr> <td>ethernet-services</td> <td>read, write</td> </tr> </tbody> </table>	Task ID	Operation	ethernet-services	read, write
Task ID	Operation				
ethernet-services	read, write				

The following example sets the time of day priority to 200.

```
RP/0/RSP0/CPU0:router(config)# ptp
RP/0/RSP0/CPU0:router(config-ptp)# time-of-day priority 200
```

## time-source

To set the time source advertised in announcement messages by the local clock for Precision Time Protocol (PTP), use the **clock time-source** command in PTP clock configuration mode. To remove the setting, use the **no** form of this command.

**time-source** *source*

**no time-source**

<b>Syntax Description</b>	<i>source</i> Specifies the type of time source: GPS, NTP, PTP, atomic-clock, hand-set, internal oscillator, other, or terrestrial radio.
---------------------------	-------------------------------------------------------------------------------------------------------------------------------------------

**Command Default** The default is the value specified by the platform.

**Command Modes** PTP clock configuration

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 4.2.1	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use this command to override the platform value, if needed, using any of the time-source values specified in the IEEE 1588-2008 standard.

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	ethernet-services	read, write

The following example sets the time source to PTP.

```
RP/0/RSP0/CPU0:router(config)# ptp
RP/0/RSP0/CPU0:router(config-ptp)# clock
RP/0/RSP0/CPU0:router(config-ptp-clock)# time-source ptp
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<a href="#">ptp, on page 523</a>	Enters PTP configuration mode.

# transport

To specify the PTP transport type, use the **transport** command in PTP profile configuration or interface PTP configuration mode. To remove the setting, use the **no** form of this command.

```
transport {ethernet | ipv4}
no transport
```

## Syntax Description

**ethernet** Specifies that Ethernet is used as the transport type on the interface.

**ipv4** Specifies IPv4 is used as the transport type on the interface

## Command Default

This command has no default values or behavior.

## Command Modes

PTP profile configuration

Interface PTP configuration

## Command History

Release	Modification
Release 4.2.0	This command was introduced.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **transport** command can be used configure the global PTP configuration profile which can then be associated with many interfaces. Similarly it can be used in interface PTP configuration mode to set the transport type for a specific interface. Any values set in interface PTP configuration mode override the settings in the PTP configuration profile associated with the interface.

## Task ID

Task ID	Operation
ethernet-services	read, write

The following example sets the transport type to be Ethernet.

```
RP/0/RSP0/CPU0:router(config)# ptp
RP/0/RSP0/CPU0:router(config-ptp)# profile p1
RP/0/RSP0/CPU0:router(config-ptp-profile)# transport ethernet
```

The following example overrides the transport type in the profile and sets it to be ipv4 for the interface:

```
RP/0/RSP0/CPU0:router(config)# interface TenGigE 0/0/0/10
RP/0/RSP0/CPU0:router(config-if) ptp
RP/0/RSP0/CPU0:router(config-if-ptp)# profile p1
RP/0/RSP0/CPU0:router(config-if-ptp)# transport ipv4
```

## uncalibrated-clock-class

To configure the clock class that is advertised when PTP is in ACQUIRING state and interface connected to the Best Master is in Uncalibrated state, use the **uncalibrated-clock-class** command in the PTP configuration mode. To remove the configuration, use the **no** form of this command.

**uncalibrated-clock-class** *class*  
**no uncalibrated-clock-class** *class*

<b>Syntax Description</b>	<i>class</i> Indicates the clock class to be advertised when PTP is in ACQUIRING state. The range is between 0 and 255.
---------------------------	-------------------------------------------------------------------------------------------------------------------------

<b>Command Default</b>	The default clock class can be obtained from the platform properties.
------------------------	-----------------------------------------------------------------------

<b>Command Modes</b>	PTP configuration
----------------------	-------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 6.1.2	This command was introduced.

<b>Usage Guidelines</b>	This command is used to override the platform value (if needed).
-------------------------	------------------------------------------------------------------

The following example configures the clock class to 255:

```
RP/0/RSP0/CPU0:router(config)# ptp
RP/0/RSP0/CPU0:router(config-ptp)# uncalibrated-clock-class 255
```

<b>Related Commands</b>	<a href="#">clock-class</a> Configures the clock class that can be used to advertise a PTP clock.
-------------------------	---------------------------------------------------------------------------------------------------

# unicast-grant invalid-request

To specify whether unicast grant requests with unacceptable parameters are denied or granted with reduced parameters, use the **unicast-grant invalid-request** command in PTP profile configuration or interface PTP configuration mode. To remove the setting, use the **no** form of this command.

```
unicast-grant invalid-request {deny | reduce}
no unicast-grant invalid-request
```

## Syntax Description

**deny** Indicates that unicast grant requests with unacceptable parameters are denied.

For example, assume that a request for a grant is received with a packet interval of 1 per second and duration of 600 seconds, and that the maximum packet interval is 2 per second and duration is 500 seconds. If **deny** is configured, the grant will be denied.

**reduce** Indicates that unicast grant requests with unacceptable parameters are granted with reduced parameters.

For example, assume that a request for a grant is received with a packet interval of 1 per second and duration of 600 seconds, and that the maximum packet interval is 2 per second and duration is 500 seconds. If **reduce** is configured, a grant with packet interval of 2-per-second and duration of 500 seconds will be granted.

## Command Default

The default is **reduce**.

## Command Modes

PTP profile configuration

Interface PTP configuration

## Command History

Release	Modification
Release 4.2.1	This command was introduced.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **unicast-grant invalid-request** command can be used to configure the global PTP configuration profile which can then be associated with many interfaces. Similarly it can be used in interface PTP configuration mode to set the unicast-grant invalid-request value for a specific interface. Any values set in interface PTP configuration mode override the settings in the PTP configuration profile associated with the interface.

## Task ID

Task ID	Operation
ethernet-services	read, write

The following example determines that unicast grant requests with unacceptable parameters are granted with reduced parameters.

```
RP/0/RSP0/CPU0:router(config)# ptp
RP/0/RSP0/CPU0:router(config-ptp)# profile p1
RP/0/RSP0/CPU0:router(config-ptp-profile)# unicast-grant invalid-request reduce
```

The following example overrides the unicast grant value in the profile and sets it to be deny for the interface:

```
RP/0/RSP0/CPU0:router(config)# interface TenGigE 0/0/0/10
RP/0/RSP0/CPU0:router(config-if) ptp
RP/0/RSP0/CPU0:router(config-if-ptp)# profile p1
RP/0/RSP0/CPU0:router(config-if-ptp)# unicast-grant invalid-request deny
```





## Process and Memory Management Commands

This chapter describes the Cisco IOS XR software commands used to manage processes and memory.

For more information about using the process and memory management commands to perform troubleshooting tasks, see *Cisco ASR 9000 Series Aggregation Services Router Getting Started Guide*.

- [clear context](#), on page 550
- [dumpcore](#), on page 551
- [exception coresize](#), on page 554
- [exception filepath](#), on page 556
- [exception pakmem](#), on page 560
- [exception sparse](#), on page 562
- [exception sprsize](#), on page 564
- [follow](#), on page 566
- [monitor threads](#), on page 573
- [process](#), on page 577
- [process core](#), on page 580
- [process mandatory](#), on page 582
- [show context](#), on page 584
- [show dll](#), on page 587
- [show exception](#), on page 590
- [show memory](#), on page 592
- [show memory compare](#), on page 595
- [show memory heap](#), on page 598
- [show processes](#), on page 602

# clear context

To clear core dump context information, use the **clear context** command in the appropriate mode.

```
clear context location {node-id | all}
```

<b>Syntax Description</b>	<b>location</b> { <i>node-id</i>   <b>all</b> }	(Optional) Clears core dump context information for a specified node. The <i>node-id</i> argument is expressed in the <i>rack/slot/module</i> notation. Use the <b>all</b> keyword to indicate all nodes.
---------------------------	-------------------------------------------------	-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

<b>Command Default</b>	No default behavior or values
------------------------	-------------------------------

<b>Command Modes</b>	Administration EXEC EXEC mode
----------------------	----------------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

Use the **clear context** command to clear core dump context information. If you do not specify a node with the **location** *node-id* keyword and argument, this command clears core dump context information for all nodes.

Use the **show context** command to display core dump context information.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	diag	execute

The following example shows how to clear core dump context information:

```
RP/0/RSP0/CPU0:router# clear context
```

## Related Topics

[show context](#), on page 584

# dumpcore

To manually generate a core dump, use the **dumpcore** command in EXEC mode Admin EXEC mode.

**dumpcore** {**running** | **suspended**} *job-id* **location** *node-id*

Syntax Description		
<b>running</b>		Generates a core dump for a running process.
<b>suspended</b>		Suspends a process, generates a core dump for the process, and resumes the process.
<i>job-id</i>		Process instance identifier.
<b>location</b> <i>node-id</i>		Generates a core dump for a process running on the specified node. The <i>node-id</i> argument is expressed in the <i>rack/slot/module</i> notation.

**Command Default** No default behavior or values

**Command Modes** Admin EXEC mode  
EXEC mode

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** When a process crashes on the Cisco IOS XR software, a core dump file of the event is written to a designated destination without bringing down the router. Upon receiving notification that a process has terminated abnormally, the Cisco IOS XR software then respawns the crashed process. Core dump files are used by Cisco Technical Support Center engineers and development engineers to debug the Cisco IOS XR software.

Core dumps can be generated manually for a process, even when a process has not crashed. Two modes exist to generate a core dump manually:

- **running** —Generates a core dump for a running process. This mode can be used to generate a core dump on a critical process (a process whose suspension could have a negative impact on the performance of the router) because the core dump file is generated independently, that is, the process continues to run as the core dump file is being generated.
- **suspended** —Suspends a process, generates a core dump for the process, and resumes the process. Whenever the process is suspended, this mode ensures data consistency in the core dump file.

Core dump files contain the following information about a crashed process:

- Register information
- Thread status information
- Process status information
- Selected memory segments

The following scenarios are applicable for creating full or sparse core dumps:

- Without the **exception sparse** configuration or exception sparse OFF, and default core size (4095 MB), a full core is created till the core size. Beyond this, only stack trace is collected.
- With non-default core size and without the **exception sparse** configuration, or exception sparse OFF , a full core is created until the core size limit is reached. Beyond the core size limit, only the stack trace is collected.
- With the exception sparse ON and default core size (4095 MB), a full core is created until the sparse size limit is reached, and a sparse core is created thereafter till the core size. Beyond this, only stack trace is collected.
- With non-default core size and with the exception sparse ON, a full core is created until the sparse size limit is reached. Beyond the sparse size limit, only the stack trace is collected.



**Note** By default, full core dumps are created irrespective of the **exception sparse** configuration. If there is not enough free shared memory available, then the core dump process fails.

#### Task ID

#### Task Operations

Task ID	Operations
diag	read, write

The following example shows how to generate a core dump in suspended mode for the process instance 52:

```
RP/0/RSP0/CPU0:router# dumpcore suspended 52

RP/0/RP0/CPU0:Sep 22 01:40:26.982 : sysmgr[71]: process in stop/continue state 4104
RP/0/RP0/CPU0Sep 22 01:40:26.989 : dumper[54]: %DUMPER-4-CORE_INFO : Core for pid = 4104
(pkg/bin/devc-conaux) requested by pkg/bin/dumper_gen@node0_RP0_CPU0
RP/0/RP0/CPU0Sep 22 01:40:26.993 : dumper[54]: %DUMPER-6-SPARSE_CORE_DUMP :
Sparse core dump as configured dump sparse for all
RP/0/RP0/CPU0Sep 22 01:40:26.995 : dumper[54]: %DUMPER-7-DLL_INFO_HEAD : DLL path
Text addr. Text size Data addr. Data size Version
RP/0/RP0/CPU0Sep 22 01:40:26.996 : dumper[54]: %DUMPER-7-DLL_INFO :
/pkg/lib/libplatform.dll 0xfc0d5000 0x0000a914 0xfc0e0000 0x00002000 0
RP/0/RP0/CPU0Sep 22 01:40:26.996 : dumper[54]: %DUMPER-7-DLL_INFO :
/pkg/lib/libsysmgr.dll 0xfc0e2000 0x0000ab48 0xfc0c295c 0x00000368 0
RP/0/RP0/CPU0Sep 22 01:40:26.997 : dumper[54]: %DUMPER-7-DLL_INFO :
/pkg/lib/libinfra.dll 0xfc0ed000 0x00032de0 0xfc120000 0x00000c90 0
RP/0/RP0/CPU0Sep 22 01:40:26.997 : dumper[54]: %DUMPER-7-DLL_INFO :
/pkg/lib/libbios.dll 0xfc121000 0x0002c4bc 0xfc14e000 0x00002000 0
RP/0/RP0/CPU0Sep 22 01:40:26.997 : dumper[54]: %DUMPER-7-DLL_INFO :
/pkg/lib/libc.dll 0xfc150000 0x00077ae0 0xfc1c8000 0x00002000 0
RP/0/RP0/CPU0Sep 22 01:40:26.998 : dumper[54]: %DUMPER-7-DLL_INFO :
/pkg/lib/libsyslog.dll 0xfc1d2000 0x0000530c 0xfc120c90 0x00000308 0
RP/0/RP0/CPU0Sep 22 01:40:26.998 : dumper[54]: %DUMPER-7-DLL_INFO :
/pkg/lib/libbackplane.dll 0xfc1d8000 0x0000134c 0xfc0c2e4c 0x000000a8 0
RP/0/RP0/CPU0Sep 22 01:40:26.999 : dumper[54]: %DUMPER-7-DLL_INFO :
/pkg/lib/libnodeid.dll 0xfc1e5000 0x00009114 0xfc1e41a8 0x00000208 0
RP/0/RP0/CPU0Sep 22 01:40:26.999 : dumper[54]: %DUMPER-7-DLL_INFO :
```

```

/pkg/lib/libttyserver.dll 0xfc1f1000 0x0003dfcc 0xfc22f000 0x00002000 0
RP/0/RP0/CPU0Sep 22 01:40:27.000 : dumper[54]: %DUMPER-7-DLL_INFO :
/pkg/lib/libttytrace.dll 0xfc236000 0x00004024 0xfc1e44b8 0x000001c8 0
RP/0/RP0/CPU0Sep 22 01:40:27.000 : dumper[54]: %DUMPER-7-DLL_INFO :
/pkg/lib/libdebug.dll 0xfc23b000 0x0000ef64 0xfc1e4680 0x00000550 0
RP/0/RP0/CPU0Sep 22 01:40:27.001 : dumper[54]: %DUMPER-7-DLL_INFO :
/pkg/lib/lib_procfs_util.dll 0xfc24a000 0x00004e2c 0xfc1e4bd0 0x000002a8 0
RP/0/RP0/CPU0Sep 22 01:40:27.001 : dumper[54]: %DUMPER-7-DLL_INFO :
/pkg/lib/libsysdb.dll 0xfc24f000 0x000452e0 0xfc295000 0x00000758 0
RP/0/RP0/CPU0Sep 22 01:40:27.001 : dumper[54]: %DUMPER-7-DLL_INFO :
/pkg/lib/libsysdbutils.dll 0xfc296000 0x0000ae08 0xfc295758 0x000003ec 0
RP/0/RP0/CPU0Sep 22 01:40:27.002 : dumper[54]: %DUMPER-7-DLL_INFO :
/pkg/lib/lib_tty_svr_error.dll 0xfc2a1000 0x0000172c 0xfc1e4e78 0x00000088 0
RP/0/RP0/CPU0Sep 22 01:40:27.002 : dumper[54]: %DUMPER-7-DLL_INFO :
/pkg/lib/lib_tty_error.dll 0xfc2a3000 0x00001610 0xfc1e4f00 0x00000088 0
RP/0/RP0/CPU0Sep 22 01:40:27.003 : dumper[54]: %DUMPER-7-DLL_INFO :
/pkg/lib/libwd_evm.dll 0xfc2a5000 0x0000481c 0xfc295b44 0x00000188 0
RP/0/RP0/CPU0Sep 22 01:40:27.003 : dumper[54]: %DUMPER-7-DLL_INFO :
/pkg/lib/libttydb.dll 0xfc2aa000 0x000051dc 0xfc295ccc 0x00000188 0
RP/0/RP0/CPU0Sep 22 01:40:27.004 : dumper[54]: %DUMPER-7-DLL_INFO :
/pkg/lib/libttydb_error.dll 0xfc23a024 0x00000f0c 0xfc295e54 0x00000088 0
RP/0/RP0/CPU0Sep 22 01:40:27.004 : dumper[54]: %DUMPER-7-DLL_INFO :
/pkg/lib/librs232.dll 0xfc2b0000 0x00009c28 0xfc2ba000 0x00000470 0
RP/0/RP0/CPU0Sep 22 01:40:27.005 : dumper[54]: %DUMPER-7-DLL_INFO :
/pkg/lib/lib_rs232_error.dll 0xfc2bb000 0x00000f8c 0xfc295edc 0x00000088 0
RP/0/RP0/CPU0Sep 22 01:40:27.005 : dumper[54]: %DUMPER-7-DLL_INFO :
/pkg/lib/libst16550.dll 0xfc2bc000 0x000008ed4 0xfc2ba470 0x00000430 0
RP/0/RP0/CPU0Sep 22 01:40:27.006 : dumper[54]: %DUMPER-7-DLL_INFO :
/pkg/lib/libconaux.dll 0xfc2c5000 0x00001dc0 0xfc2ba8a0 0x000001a8 0
RP/0/RP0/CPU0Sep 22 01:40:27.006 : dumper[54]: %DUMPER-7-DLL_INFO :
/pkg/lib/lib_conaux_error.dll 0xfc1ee114 0x00000e78 0xfc295f64 0x00000088 0
RP/0/RP0/CPU0Sep 22 01:40:27.007 : dumper[54]: %DUMPER-7-DLL_INFO :
/pkg/lib/libttyutil.dll 0xfc2c7000 0x00003078 0xfc2baa48 0x00000168 0
RP/0/RP0/CPU0Sep 22 01:40:27.007 : dumper[54]: %DUMPER-7-DLL_INFO :
/pkg/lib/libbag.dll 0xfc431000 0x0000ee98 0xfc40cc94 0x00000368 0
RP/0/RP0/CPU0Sep 22 01:40:27.008 : dumper[54]: %DUMPER-7-DLL_INFO :
/pkg/lib/libchkpt.dll 0xfc474000 0x0002ecf8 0xfc4a3000 0x00000950 0
RP/0/RP0/CPU0Sep 22 01:40:27.008 : dumper[54]: %DUMPER-7-DLL_INFO :
/pkg/lib/libsysdbbackend.dll 0xfc8ed000 0x0000997c 0xfc8d3aa8 0x0000028c 0
RP/0/RP0/CPU0Sep 22 01:40:27.008 : dumper[54]: %DUMPER-7-DLL_INFO :
/pkg/lib/libttygmtconnection.dll 0xfce85000 0x00004208 0xfce8a000 0x00000468
0
RP/0/RP0/CPU0Sep 22 01:40:27.009 : dumper[54]: %DUMPER-7-DLL_INFO :
/pkg/lib/libttygmt.dll 0xfcea4000 0x0000e944 0xfce8abf0 0x000003c8 0
RP/0/RP0/CPU0Sep 22 01:40:27.009 : dumper[54]: %DUMPER-7-DLL_INFO :
/pkg/lib/libttynmspc.dll 0xfcec7000 0x00004a70 0xfcec6644 0x000002c8 0
RP/0/RP0/CPU0Sep 22 01:40:28.396 : dumper[54]: %DUMPER-5-CORE_FILE_NAME :
Core for process pkg/bin/devc-conaux at harddisk:/coredump/devc-conaux.by.
dumper_gen.sparse.20040922-014027.node0_RP0_CPU0.ppc.Z
RP/0/RP0/CPU0Sep 22 01:40:32.309 : dumper[54]: %DUMPER-5-DUMP_SUCCESS : Core dump success

```

# exception coresize

Halts the creation of the core file beyond the configured core file size limit.

**exception coresize** *size*  
**no exception coresize**

## Syntax Description

**coresize** *size* Defines the maximum limit of the core file size beyond which the core file creation is halted and only the stack trace output is printed on the screen.  
 The core file size limit can range from 1 to 4095 MB.

## Command Default

This command has no default behavior.

## Command Modes

Global configuration

## Command History

Release	Modification
Release 5.1.1	This command was introduced.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The following scenarios are applicable for creating full or sparse core dumps:

- Without the **exception sparse** configuration or exception sparse OFF, and default core size (4095 MB), a full core is created till the core size. Beyond this, only stack trace is collected.
- With non-default core size and without the **exception sparse** configuration, or exception sparse OFF, a full core is created until the core size limit is reached. Beyond the core size limit, only the stack trace is collected.
- With the exception sparse ON and default core size (4095 MB), a full core is created until the sparse size limit is reached, and a sparse core is created thereafter till the core size. Beyond this, only stack trace is collected.
- With non-default core size and with the exception sparse ON, a full core is created until the sparse size limit is reached. Beyond the sparse size limit, only the stack trace is collected.



### Note

By default, full core dumps are created irrespective of the **exception sparse** configuration. If there is not enough free shared memory available, then the core dump process fails.

Task ID	Task ID	Operations
	diag	read, write

The following example shows how you can disable the creation of core dump files by specifying the limit for core file size.

```
RP/0/RSP0/CPU0:router(config)# exception coresize 1024
RP/0/RSP0/CPU0:router(config)# commit
```

## exception filepath

To modify core dump settings, use the **exception filepath** command in the appropriate configuration mode. To remove the configuration, use the **no** form of this command.

**exception** [**choice preference**] [**compress {on | off}**] **filename filename lower-limit-higher-limit filepath filepath-name**

**no exception** [**choice preference**] [**compress {on | off}**] **filename filename lower-limit-higher-limit filepath filepath-name**

### Syntax Description

**choice preference** (Optional) Configures the order of preference for the destination of core dump files. Up to the three destinations can be defined. Valid values are 1 to 3.

**compress {on | off}** (Optional) Specifies whether or not the core dump file should be sent compressed. By default, core dump files are sent compressed. If you specify the **compress** keyword, you must specify one of the following required keywords:

- **on** —Compresses the core dump file before sending it.
- **off** —Does not compress the core dump file before sending it.

**filename filename lower-limit-higher-limit** (Optional) Specifies the filename to be appended to core dump files and the lower and higher limit range of core dump files to be sent to a specified destination before being recycled by the circular buffer.

**filename filename lower-limit-higher-limit** See [Table 46: Default Core Dump File Naming Convention Description, on page 558](#) for a description of the default core dump file naming convention.

Valid **filename filename lower-limit-higher-limit** values for the *lower-limit* argument are 0 to 4. Valid values for the *higher-limit* argument are 5 to 64. A hyphen ( - ) must immediately follow the *lower-limit* argument.

**Note** To uniquely identify each core dump file, a value is appended to each core dump file, beginning with the lower limit value configured for the *lower-limit* argument and continuing until the higher limit value configured for the *higher-limit* argument has been reached. After the higher limit value has been reached, the Cisco IOS XR software begins to recycle the values appended to core dump files, beginning with the lower limit value.

**filepath-name** Local file system or network protocol, followed by the directory path. All local file systems are supported. The following network protocols are supported: TFTP and FTP.

### Command Default

If you do not specify the order of preference for the destination of core dump files using the **choice preference** keyword and argument, the default preference is the primary location or 1.

Core dump files are sent compressed.

The default file naming convention used for core dump files is described in [Table 46: Default Core Dump File Naming Convention Description, on page 558](#).



**Command Modes** Administration configuration  
Global configuration

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **exception filepath** command to modify core dump settings, such as the destination file path to store core dump files, file compression, and the filename appended to core dumps.

Up to three user-defined locations may be configured as the preferred destinations for core dump files:

- Primary location—The primary destination for core dump files. Enter the **choice** keyword and a value of **1** (that is, **choice 1**) for the *preference* argument to specify a destination as the primary location for core dump files.
- Secondary location—The secondary fallback choice for the destination for core dump files, if the primary location is unavailable (for example, if the hard disk is set as the primary location and the hard disk fails). Enter the **choice** keyword and a value of **2** (that is, **choice 2**) for the *preference* argument to specify a destination as the secondary location for core dump files.
- Tertiary location—The tertiary fallback choice as the destination for core dump files, if the primary and secondary locations fail. Enter the **choice** keyword and a value of 3 (that is, **choice 3**) for the *preference* argument to specify a destination as the tertiary location for core dump files.

When specifying a destination for a core dump file, you can specify an absolute file path on a local file system or on a network server. The following network protocols are supported: TFTP and FTP.



**Note** We recommend that you specify a location on the hard disk as the primary location.

In addition to the three preferred destinations that can be configured, Cisco IOS XR software provides three default fallback destinations for core dump files in the event that user-defined locations are unavailable.

The default fallback destinations are:

- harddisk:/dumper
- disk1:/dumper
- disk0:/dumper



**Note** If a default destination is a boot device, the core dump file is not sent to that destination.

We recommend that you configure at least one preferred destination for core dump files as a preventive measure if the default fallback paths are unavailable. Configuring at least one preferred destination also ensures that core dump files are archived because the default fallback destinations store only the first and last core dump files for a crashed process.



**Note** Cisco IOS XR software does not save a core file on a local storage device if the size of the core dump file creates a low-memory condition.

By default, Cisco IOS XR software assigns filenames to core dump files according to the following format:

*process* [.by. *requester* |.abort][.sparse]. *date-time* . *node* . *processor-type* [.Z]

For example:

```
packet.by.dumper_gen.20040921-024800.node0_RP0_CPU0.ppc.Z
```

[Table 46: Default Core Dump File Naming Convention Description, on page 558](#) describes the default core dump file naming convention.

**Table 46: Default Core Dump File Naming Convention Description**

Field	Description
<i>process</i>	Name of the process that generated the core dump.
.by. <i>requester</i>   .abort	If the core dump was generated because of a request by a process (requester), the core filename contains the string “.by. <i>requester</i> ” where the <i>requester</i> variable is the name or process ID (PID) of the process that requested the core dump. If the core dump was due to a self-generated abort call request, the core filename contains the string “.abort” instead of the name of the requester.
.sparse	If a sparse core dump was generated instead of a full core dump, “sparse” appears in the core dump filename.
. <i>date-time</i>	Date and time the dumper process was called by the process manager to generate the core dump. The <i>.date-time</i> time-stamp variable is expressed in the <i>yyyy.mm.dd-hh.mm.ss</i> format. Including the time stamp in the filename uniquely identifies the core dump filename.
. <i>node</i>	Node ID, expressed in the <i>rack/slot/module</i> notation, where the process that generated the core dump was running.
. <i>processor-type</i>	Type of processor (mips or ppc).
.Z	If the core dump was sent compressed, the filename contains the .Z suffix.

You can modify the default naming convention by specifying a filename to be appended to core dump files with the optional **filename** *filename* keyword and argument and by specifying a lower and higher limit ranges of values to be appended to core dump filenames with the *lower-limit* and *higher-limit* arguments, respectively. The filename that you specify for the *filename* argument is appended to the core dump file and the lower and higher limit ranges of core dump files to be sent to a specified destination before the filenames are recycled. Valid values for the *lower-limit* argument are 0 to 4. Valid values for the *higher-limit* argument

are 5 to 64. A hyphen (-) must immediately follow the *lower-limit* argument. In addition, to uniquely identify each core dump file, a value is appended to each core dump file, beginning with the lower-limit value specified with the *lower-limit* argument and continuing until the higher-limit value specified with the *higher-limit* argument has been reached. When the configured higher-limit value has been reached, Cisco IOS XR software begins to recycle the values appended to core dump files, beginning with the lower-limit value.

Task ID	Task ID	Operations
	diag	read, write

The following example shows how to configure the core dump setting for the primary user-defined preferred location. In this example, core files are configured to be sent uncompressed; the filename of core dump files is set to “core” (that is, all core filenames will be named core); the range value is set from 0 to 5 (that is, the values 0 to 5 are appended to the filename for the first five generated core dump files, respectively, before being recycled); and the destination is set to a directory on the hard disk.

```
RP/0/RP0/CPU0:router(config)# exception choice 1 compress off
 filename core 0-5 filepath /harddisk:/corefile
```

#### Related Topics

- [exception pakmem](#), on page 560
- [exception sparse](#), on page 562
- [exception sprsize](#), on page 564
- [show exception](#), on page 590

## exception pakmem

To configure the collection of packet memory information in core dump files, use the **exception pakmem** command in administration configuration mode or in global configuration mode. To remove the configuration, use the **no** form of this command.

```
exception pakmem {on | off}
no exception pakmem {on | off}
```

<b>Syntax Description</b>	<b>on</b> Enables the collection of packet memory information in core dump files.
	<b>off</b> Disables the collection of packet memory information in core dump files.

<b>Command Default</b>	Packet memory information is not included in core dump files.
------------------------	---------------------------------------------------------------

<b>Command Modes</b>	Administration configuration
	Global configuration

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

Use the **exception pakmem** command with the **on** keyword to configure the collection of packet memory information in core dump files. Cisco Technical Support Center engineers and development engineers use packet memory information to debug packet memory issues related to a process.



<b>Caution</b>	Including packet memory information in core dump files significantly increases the amount of data generated in the core dump file, which may delay the restart time for the process.
----------------	--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	diag	read, write

The following example shows how to configure core dumps to include packet memory information:

```
RP/0/RSP0/CPU0:router (config) # exception pakmem on
```

**Related Topics**

[exception filepath](#), on page 556

[exception sparse](#), on page 562

[exception sprsize](#), on page 564

[show exception](#), on page 590

## exception sparse

To enable or disable sparse core dumps, use the **exception sparse** command in administration configuration mode or in global configuration mode. To remove the configuration, use the **no** form of this command.

```
exception sparse {on | off}
no exception sparse
```

<b>Syntax Description</b>	<b>on</b> Enables sparse core dumps.
	<b>off</b> Disables sparse core dumps.

<b>Command Default</b>	Sparse core dumps are disabled.
------------------------	---------------------------------

<b>Command Modes</b>	Administration configuration Global configuration
----------------------	------------------------------------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

Use the **exception sparse** command to reduce the amount of data generated in the core dump file. Sparse core dumps reduce the amount of time required to generate the core dump file because only referenced data is generated in the core file (at the cost of lost information in the core file). Reducing the time required to generate core dump files corresponds to faster process restart times.



<b>Note</b>	Use the <b>exception sparse off</b> command in administration configuration mode to get a complete coredump of the transient processes on the RP.
-------------	---------------------------------------------------------------------------------------------------------------------------------------------------

Sparse core dumps contain the following information about crashed processes:

- Register information for all threads, and any memory pages referenced in these register values
- Stack information for all threads, and any memory pages referenced in these threads
- All memory pages referenced by a loaded dynamic loadable library (DLL) data section, if the final program counter falls in a DLL data section
- Any user-specified marker pages from the lib_dumper_marker DLL

The **exception sparse** command dumps memory pages based on trigger addresses found in the previously listed dump information, according to the following criteria:

- If the trigger address in the memory page is in the beginning 128 bytes of the memory page, the previous memory page in the continuous address region is dumped also.
- If the trigger address in the memory page is in the final 128 bytes of the memory page, the next memory page in the continuous address region is dumped also.
- In all other instances, only the memory page that includes the trigger address is dumped.

The following scenarios are applicable for creating full or sparse core dumps:

- Without the **exception sparse** configuration or exception sparse OFF, and default core size (4095 MB), a full core is created till the core size. Beyond this, only stack trace is collected.
- With non-default core size and without the **exception sparse** configuration, or exception sparse OFF , a full core is created until the core size limit is reached. Beyond the core size limit, only the stack trace is collected.
- With the exception sparse ON and default core size (4095 MB), a full core is created until the sparse size limit is reached, and a sparse core is created thereafter till the core size. Beyond this, only stack trace is collected.
- With non-default core size and with the exception sparse ON, a full core is created until the sparse size limit is reached. Beyond the sparse size limit, only the stack trace is collected.



**Note** By default, full core dumps are created irrespective of the **exception sparse** configuration. If there is not enough free shared memory available, then the core dump process fails.

Task ID	Task ID	Operations
	diag	read, write

The following example shows how to enable sparse core dumps:

```
RP/0/RSP0/CPU0:router(config)# exception sparse on
```

#### Related Topics

- [exception filepath](#), on page 556
- [exception pakmem](#), on page 560
- [exception sprsize](#), on page 564
- [show exception](#), on page 590

## exception sprsize

To specify the maximum file size for core dumps, use the **exception sprsize** command in administration configuration mode or in global configuration mode. To remove the configuration, use the **no** form of this command.

**exception sprsize** *megabytes*  
**no exception sprsize**

<b>Syntax Description</b>	<i>megabytes</i> Size in megabytes (MB).
---------------------------	------------------------------------------

<b>Command Default</b>	<i>megabytes</i> : 192
------------------------	------------------------

<b>Command Modes</b>	Administration configuration Global configuration
----------------------	------------------------------------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **exception sprsize** command to specify the maximum file size for core dumps. The maximum file size configured for the *megabytes* argument is used with the configuration set for the [exception sparse, on page 562](#) command to determine whether or not to generate a sparse core dump file. If sparse core dumps are disabled and a core dump file is predicted to exceed the default value (192 MB) uncompressed or the value specified for the *megabytes* argument uncompressed, a sparse core dump file is generated. If sparse core dumps are enabled, a sparse core dump file is generated, regardless of the size of the core dump file.

The following scenarios are applicable for creating full or sparse core dumps:

- Without the **exception sparse** configuration or exception sparse OFF, and default core size (4095 MB), a full core is created till the core size. Beyond this, only stack trace is collected.
- With non-default core size and without the **exception sparse** configuration, or exception sparse OFF , a full core is created until the core size limit is reached. Beyond the core size limit, only the stack trace is collected.
- With the exception sparse ON and default core size (4095 MB), a full core is created until the sparse size limit is reached, and a sparse core is created thereafter till the core size. Beyond this, only stack trace is collected.
- With non-default core size and with the exception sparse ON, a full core is created until the sparse size limit is reached. Beyond the sparse size limit, only the stack trace is collected.





**Note** By default, full core dumps are created irrespective of the **exception sparse** configuration. If there is not enough free shared memory available, then the core dump process fails.

---

**Task ID**

---

**Task ID**    **Operations**

---

diag	read, write
------	----------------

---

The following example shows how to set the file size of sparse core dumps to 300 MB:

```
RP/0/RSP0/CPU0:router(config)# exception sprsize 300
```

**Related Topics**

[exception sparse](#), on page 562

# follow

To unobtrusively debug a live process or a live thread in a process, use the **follow** command in EXEC modeAdmin EXEC mode.

**follow** {**job** *job-id* | **process** *pid* | **location** *node-id*} [**all**] [**blocked**] [**debug** *level*] [**delay** *seconds*] [**dump** *address size*] [**iteration** *count*] [**priority** *level*] [**stackonly**] [**thread** *tid*] [**verbose**]

## Syntax Description

<b>job</b> <i>job-id</i>	Follows a process by job ID.
<b>process</b> <i>pid</i>	Follows the process with the process ID (PID) specified for the <i>pid</i> argument.
<b>location</b> <i>node-id</i>	Follows the target process on the designated node. The <i>node-id</i> argument is expressed in the <i>rack/slot/module</i> notation.
<b>all</b>	(Optional) Follows all threads.
<b>blocked</b>	(Optional) Follows the chain of thread IDs (TIDs) or PIDs that are blocking the target process.
<b>debug</b> <i>level</i>	(Optional) Sets the debug level for the following operation. Valid values for the <i>level</i> argument are 0 to 10.
<b>delay</b> <i>seconds</i>	(Optional) Sets the delay interval between each iteration. Valid values for the <i>seconds</i> argument are 0 to 255 seconds.
<b>dump</b> <i>address size</i>	(Optional) Dumps the memory segment starting with the specified memory address and size specified for the <i>address</i> and <i>size</i> arguments.
<b>iteration</b> <i>count</i>	(Optional) Specifies the number of times to display information. Valid values for the <i>count</i> argument are 0 to 255 iterations.
<b>priority</b> <i>level</i>	(Optional) Sets the priority level for the following operation. Valid values for the <i>level</i> argument are 1 to 63.
<b>stackonly</b>	(Optional) Displays only stack trace information.
<b>thread</b> <i>tid</i>	(Optional) Follows the TID of a process or job ID specified for the <i>tid</i> argument.
<b>verbose</b>	(Optional) Displays register and status information pertaining to the target process.

## Command Default

Entering the **follow** command without any optional keywords or arguments performs the operation for five iterations from the local node with a delay of 5 seconds between each iteration. The output includes information about all live threads. This command uses the default scheduling priority from where the command is being run.

## Command Modes

EXEC mode  
Admin EXEC mode

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

### Usage Guidelines

Use this command to unintrusively debug a live process or a live thread in a process. This command is particularly useful for debugging deadlock and livelock conditions, for examining the contents of a memory location or a variable in a process to determine the cause of a corruption issue, or in investigating issues where a thread is stuck spinning in a loop. A livelock condition is one that occurs when two or more processes continually change their state in response to changes in the other processes.

The following actions can be specified with this command:

- Follow all live threads of a given process or a given thread of a process and print stack trace in a format similar to core dump output.
- Follow a process in a loop for a given number of iterations.
- Set a delay between two iterations while invoking the command.
- Set the priority at which this process should run while this command is being run.
- Dump memory from a given virtual memory location for a given size.
- Display register values and status information of the target process.

Take a snapshot of the execution path of a thread asynchronously to investigate performance-related issues by specifying a high number of iterations with a zero delay.

Task ID	Task ID	Operations
	basic-services	read

The following example shows how to use the **follow** command to debug the process associated with job ID 257 for one iteration:

```
RP/0/RSP0/CPU0:router# follow job 257 iteration 1
```

```
Attaching to process pid = 28703 (pkg/bin/packet)
No tid specified, following all threads
```

```
DLL Loaded by this process
```

```

```

DLL path	Text addr.	Text size	Data addr.	Data size	Version
/pkg/lib/libovl.dll	0xfc0c9000	0x0000c398	0xfc0c31f0	0x0000076c	0
/pkg/lib/libplatform.dll	0xfc0d6000	0x0000aa88	0xfc0e1000	0x00002000	0
/pkg/lib/libsysmgr.dll	0xfc0e3000	0x0000aeac	0xfc0c395c	0x00000388	0
/pkg/lib/libinfra.dll	0xfc0ee000	0x000332ec	0xfc122000	0x00000c70	0
/pkg/lib/libbios.dll	0xfc123000	0x0002c4bc	0xfc150000	0x00002000	0
/pkg/lib/libc.dll	0xfc152000	0x00077ae0	0xfc1ca000	0x00002000	0
/pkg/lib/libsyslog.dll	0xfc1d4000	0x0000530c	0xfc122c70	0x00000308	0
/pkg/lib/libbackplane.dll	0xfc1da000	0x0000134c	0xfc0c3e6c	0x000000a8	0
/pkg/lib/libnodeid.dll	0xfc1e7000	0x000091fc	0xfc1e61a8	0x00000208	0
/pkg/lib/libdebug.dll	0xfc23e000	0x0000ef64	0xfc1e6680	0x00000550	0
/pkg/lib/lib_procfs_util.dll	0xfc24d000	0x00004e2c	0xfc1e6bd0	0x000002a8	0

```

/pkg/lib/libsysdb.dll 0xfc252000 0x00046224 0xfc299000 0x0000079c 0
/pkg/lib/libsysdbutils.dll 0xfc29a000 0x0000ae04 0xfc29979c 0x000003ec 0
/pkg/lib/libwd_evm.dll 0xfc2a9000 0x0000481c 0xfc299b88 0x00000188 0
/pkg/lib/lib_mutex_monitor.dll 0xfc35e000 0x00002414 0xfc340850 0x00000128 0
/pkg/lib/libchkpt.dll 0xfc477000 0x0002ee04 0xfc474388 0x00000950 0
/pkg/lib/libpacket_common.dll 0xfc617000 0x000130f0 0xfc6056a0 0x000007b0 0

```

```
Iteration 1 of 1
```

```

```

```
Current process = "pkg/bin/packet", PID = 28703 TID = 1
```

```

trace_back: #0 0xfc1106dc [MsgReceivev]
trace_back: #1 0xfc0fc840 [msg_receivev]
trace_back: #2 0xfc0fc64c [msg_receive]
trace_back: #3 0xfc0ffa70 [event_dispatch]
trace_back: #4 0xfc0ffc2c [event_block]
trace_back: #5 0x48204410 [<N/A>]

```

```
ENDOFSTACKTRACE
```

```
Current process = "pkg/bin/packet", PID = 28703 TID = 2
```

```

trace_back: #0 0xfc1106dc [MsgReceivev]
trace_back: #1 0xfc0fc840 [msg_receivev]
trace_back: #2 0xfc0fc64c [msg_receive]
trace_back: #3 0xfc0ffa70 [event_dispatch]
trace_back: #4 0xfc0ffc2c [event_block]
trace_back: #5 0xfc48d848 [chk_evm_thread]

```

```
ENDOFSTACKTRACE
```

```
Current process = "pkg/bin/packet", PID = 28703 TID = 3
```

```

trace_back: #0 0xfc17d54c [SignalWaitinfo]
trace_back: #1 0xfc161c64 [sigwaitinfo]
trace_back: #2 0xfc10302c [event_signal_thread]

```

```
ENDOFSTACKTRACE
```

```
Current process = "pkg/bin/packet", PID = 28703 TID = 4
```

```

trace_back: #0 0xfc1106c4 [MsgReceivePulse]
trace_back: #1 0xfc0fc604 [msg_receive_async]
trace_back: #2 0xfc0ffa70 [event_dispatch]
trace_back: #3 0xfc0ffc5c [event_block_async]
trace_back: #4 0xfc35e36c [receive_events]

```

```
ENDOFSTACKTRACE
```

```
Current process = "pkg/bin/packet", PID = 28703 TID = 5
```

```

trace_back: #0 0xfc17d564 [SignalWaitinfo_r]
trace_back: #1 0xfc161c28 [sigwait]
trace_back: #2 0x48203928 [<N/A>]

```

```
ENDOFSTACKTRACE
```

The following example shows how to use the **follow** command to debug TID 5 of the process associated with job ID 257 for one iteration:

```
RP/0/RSP0/CPU0:router# follow job 257 iteration 1 thread 5
```

Attaching to process pid = 28703 (pkg/bin/packet)

DLL Loaded by this process

-----

DLL path	Text addr.	Text size	Data addr.	Data size	Version
/pkg/lib/libovl.dll	0xfc0c9000	0x0000c398	0xfc0c31f0	0x0000076c	0
/pkg/lib/libplatform.dll	0xfc0d6000	0x0000aa88	0xfc0e1000	0x00002000	0
/pkg/lib/libsysmgr.dll	0xfc0e3000	0x0000aeac	0xfc0c395c	0x00000388	0
/pkg/lib/libinfra.dll	0xfc0ee000	0x000332ec	0xfc122000	0x00000c70	0
/pkg/lib/libios.dll	0xfc123000	0x0002c4bc	0xfc150000	0x00002000	0
/pkg/lib/libc.dll	0xfc152000	0x00077ae0	0xfc1ca000	0x00002000	0
/pkg/lib/libsyslog.dll	0xfc1d4000	0x0000530c	0xfc122c70	0x00000308	0
/pkg/lib/libbackplane.dll	0xfc1da000	0x0000134c	0xfc0c3e6c	0x000000a8	0
/pkg/lib/libnodeid.dll	0xfc1e7000	0x000091fc	0xfc1e61a8	0x00000208	0
/pkg/lib/libdebug.dll	0xfc23e000	0x0000ef64	0xfc1e6680	0x00000550	0
/pkg/lib/lib_procfs_util.dll	0xfc24d000	0x00004e2c	0xfc1e6bd0	0x000002a8	0
/pkg/lib/libsysdb.dll	0xfc252000	0x00046224	0xfc299000	0x0000079c	0
/pkg/lib/libsysdbutils.dll	0xfc29a000	0x0000ae04	0xfc29979c	0x000003ec	0
/pkg/lib/libwd_evm.dll	0xfc2a9000	0x0000481c	0xfc299b88	0x00000188	0
/pkg/lib/lib_mutex_monitor.dll	0xfc35e000	0x00002414	0xfc340850	0x00000128	0
/pkg/lib/libchkpt.dll	0xfc477000	0x0002ee04	0xfc474388	0x00000950	0
/pkg/lib/libpacket_common.dll	0xfc617000	0x000130f0	0xfc6056a0	0x000007b0	0

Iteration 1 of 1

-----

Current process = "pkg/bin/packet", PID = 28703 TID = 5

trace_back: #0 0xfc17d564 [SignalWaitinfo_r]

trace_back: #1 0xfc161c28 [sigwait]

trace_back: #2 0x48203928 [<N/A>]

ENDOFSTACKTRACE

The following example shows how to use the **follow** command to debug the chain of threads blocking thread 2 associated with the process assigned PID 139406:

```
RP/0/RSP0/CPU0:router# follow process 139406 blocked iteration 1 thread 2
```

Attaching to process pid = 139406 (pkg/bin/lpts_fm)

DLL Loaded by this process

-----

DLL path	Text addr.	Text size	Data addr.	Data size	Version
/pkg/lib/libplatform.dll	0xfc0d6000	0x0000aa88	0xfc0e1000	0x00002000	0
/pkg/lib/libsysmgr.dll	0xfc0e3000	0x0000aeac	0xfc0c395c	0x00000388	0
/pkg/lib/libinfra.dll	0xfc0ee000	0x000332ec	0xfc122000	0x00000c70	0
/pkg/lib/libios.dll	0xfc123000	0x0002c4bc	0xfc150000	0x00002000	0
/pkg/lib/libc.dll	0xfc152000	0x00077ae0	0xfc1ca000	0x00002000	0
/pkg/lib/libltrace.dll	0xfc1cc000	0x00007f5c	0xfc0c3ce4	0x00000188	0
/pkg/lib/libsyslog.dll	0xfc1d4000	0x0000530c	0xfc122c70	0x00000308	0
/pkg/lib/libbackplane.dll	0xfc1da000	0x0000134c	0xfc0c3e6c	0x000000a8	0
/pkg/lib/libnodeid.dll	0xfc1e7000	0x000091fc	0xfc1e61a8	0x00000208	0
/pkg/lib/libdebug.dll	0xfc23e000	0x0000ef64	0xfc1e6680	0x00000550	0
/pkg/lib/lib_procfs_util.dll	0xfc24d000	0x00004e2c	0xfc1e6bd0	0x000002a8	0
/pkg/lib/libsysdb.dll	0xfc252000	0x00046224	0xfc299000	0x0000079c	0
/pkg/lib/libsysdbutils.dll	0xfc29a000	0x0000ae04	0xfc29979c	0x000003ec	0
/pkg/lib/libwd_evm.dll	0xfc2a9000	0x0000481c	0xfc299b88	0x00000188	0
/pkg/lib/libbag.dll	0xfc40c000	0x0000ee98	0xfc41b000	0x00000368	0

follow

```

/pkg/lib/libwd_notif.dll 0xfc4f8000 0x00005000 0xfc4fd000 0x00001000 0
/pkg/lib/libifmgr.dll 0xfc665000 0x00029780 0xfc68f000 0x00003000 0
/pkg/lib/libnetio_client.dll 0xfca6a000 0x000065c8 0xfca2c4f8 0x000001b4 0
/pkg/lib/libpa_client.dll 0xfcec5000 0x00006e9c 0xfcecc000 0x00003000 0
/pkg/lib/libltimes.dll 0xfcecf000 0x00002964 0xfcdc4f20 0x000000a8 0

```

Iteration 1 of 1

Current process = "pkg/bin/lpts_fm", PID = 139406 TID = 2

```

trace_back: #0 0xfc110744 [MsgSendv]
trace_back: #1 0xfc0fbf04 [msg_sendv]
trace_back: #2 0xfc0fbbd8 [msg_send]
trace_back: #3 0xfcec7580 [pa_fm_close]
trace_back: #4 0xfcec78b0 [pa_fm_process_0]

```

ENDOFSTACKTRACE

REPLY (node node0_RP1_CPU0, pid 57433)

No specific TID, following all threads of 57433 (pkg/bin/lpts_pa)

DLL Loaded by this process

DLL path	Text addr.	Text size	Data addr.	Data size	Version
/pkg/lib/libplatform.dll	0xfc0d6000	0x0000aa88	0xfc0e1000	0x00002000	0
/pkg/lib/libsysmgr.dll	0xfc0e3000	0x0000aeac	0xfc0c395c	0x00000388	0
/pkg/lib/libinfra.dll	0xfc0ee000	0x000332ec	0xfc122000	0x00000c70	0
/pkg/lib/libbios.dll	0xfc123000	0x0002c4bc	0xfc150000	0x00002000	0
/pkg/lib/libc.dll	0xfc152000	0x00077ae0	0xfc1ca000	0x00002000	0
/pkg/lib/libltrace.dll	0xfc1cc000	0x00007f5c	0xfc0c3ce4	0x00000188	0
/pkg/lib/libsyslog.dll	0xfc1d4000	0x0000530c	0xfc122c70	0x00000308	0
/pkg/lib/libbackplane.dll	0xfc1da000	0x0000134c	0xfc0c3e6c	0x000000a8	0
/pkg/lib/libnodeid.dll	0xfc1e7000	0x000091fc	0xfc1e61a8	0x00000208	0
/pkg/lib/libdebug.dll	0xfc23e000	0x0000ef64	0xfc1e6680	0x00000550	0
/pkg/lib/lib_procfs_util.dll	0xfc24d000	0x00004e2c	0xfc1e6bd0	0x000002a8	0
/pkg/lib/libsysdb.dll	0xfc252000	0x00046224	0xfc299000	0x0000079c	0
/pkg/lib/libsysdbutils.dll	0xfc29a000	0x0000ae04	0xfc29979c	0x000003ec	0
/pkg/lib/libwd_evm.dll	0xfc2a9000	0x0000481c	0xfc299b88	0x00000188	0
/pkg/lib/lrdlib.dll	0xfc2f6000	0x0000a900	0xfc2f551c	0x00000610	0
/pkg/lib/liblrfuncs.dll	0xfc30e000	0x00001998	0xfc2ebd80	0x000001ec	0
/pkg/lib/libdscapi.dll	0xfc310000	0x0000457c	0xfc2f5b2c	0x0000035c	0
/pkg/lib/liblrdshared.dll	0xfc315000	0x00005fec	0xfc31b000	0x00002000	0
/pkg/lib/libbag.dll	0xfc40c000	0x0000ee98	0xfc41b000	0x00000368	0
/pkg/lib/libchkpt.dll	0xfc477000	0x0002ee04	0xfc474388	0x00000950	0
/pkg/lib/libwd_notif.dll	0xfc4f8000	0x00005000	0xfc4fd000	0x00001000	0
/pkg/lib/libltrace_sdt.dll	0xfc65c000	0x000034fc	0xfc65b73c	0x00000568	0
/pkg/lib/libfabhandle.dll	0xfc6be000	0x00003354	0xfc65bca4	0x00000248	0
/pkg/lib/libfsdb_ltrace_util_rt.dll	0xfc6ea000	0x00001b74	0xfc605e50	0x00000108	0
/pkg/lib/libbcdl.dll	0xfc6fb000	0x0000f220	0xfc6fa6e8	0x0000045c	0
/pkg/lib/liblpts_pa_fgid.dll	0xfc8d7000	0x00006640	0xfc7acd5c	0x00000208	0
/pkg/lib/libfgid.dll	0xfc910000	0x0001529c	0xfc926000	0x00002000	0
/pkg/lib/libltimes.dll	0xfcecf000	0x00002964	0xfcdc4f20	0x000000a8	0

Current process = "pkg/bin/lpts_pa", PID = 57433 TID = 1

```

trace_back: #0 0xfc1106dc [MsgReceivev]
trace_back: #1 0xfc0fc840 [msg_receivev]
trace_back: #2 0xfc0fc64c [msg_receive]
trace_back: #3 0xfc0ffa70 [event_dispatch]
trace_back: #4 0xfc0ffc2c [event_block]

```

```

trace_back: #5 0x48201904 [<N/A>]
trace_back: #6 0x48201e3c [<N/A>]

ENDOFSTACKTRACE

Current process = "pkg/bin/lpts_pa", PID = 57433 TID = 2

trace_back: #0 0xfc1106dc [MsgReceivev]
trace_back: #1 0xfc0fc840 [msg_receivev]
trace_back: #2 0xfc0fc64c [msg_receive]
trace_back: #3 0xfc0ffa70 [event_dispatch]
trace_back: #4 0xfc0ffc2c [event_block]
trace_back: #5 0x4821e978 [<N/A>]

ENDOFSTACKTRACE

Current process = "pkg/bin/lpts_pa", PID = 57433 TID = 3

trace_back: #0 0xfc1106dc [MsgReceivev]
trace_back: #1 0xfc0fc840 [msg_receivev]
trace_back: #2 0xfc0fc64c [msg_receive]
trace_back: #3 0xfc0ffa70 [event_dispatch]
trace_back: #4 0xfc0ffc2c [event_block]
trace_back: #5 0x482064c4 [<N/A>]

ENDOFSTACKTRACE

```

The following example shows how to use the **follow** command to debug the chain of threads blocking thread 2 associated with the process assigned PID 139406:

```

RP/0/RSP0/CPU0:router# follow process 139406 blocked iteration 1 stackonly thread 2

Attaching to process pid = 139406 (pkg/bin/lpts_fm)

Iteration 1 of 1

Current process = "pkg/bin/lpts_fm", PID = 139406 TID = 2

trace_back: #0 0xfc110744 [MsgSendv]
trace_back: #1 0xfc0fbf04 [msg_sendv]
trace_back: #2 0xfc0fbbd8 [msg_send]
trace_back: #3 0xfccec7580 [pa_fm_close]
trace_back: #4 0xfccec78b0 [pa_fm_process_0]

ENDOFSTACKTRACE

REPLY (node node0_RP1_CPU0, pid 57433)

No specific TID, following all threads of 57433 (pkg/bin/lpts_pa)

Current process = "pkg/bin/lpts_pa", PID = 57433 TID = 1

trace_back: #0 0xfc1106dc [MsgReceivev]
trace_back: #1 0xfc0fc840 [msg_receivev]
trace_back: #2 0xfc0fc64c [msg_receive]
trace_back: #3 0xfc0ffa70 [event_dispatch]
trace_back: #4 0xfc0ffc2c [event_block]
trace_back: #5 0x48201904 [<N/A>]
trace_back: #6 0x48201e3c [<N/A>]

```

```
ENDOFSTACKTRACE
```

```
Current process = "pkg/bin/lpts_pa", PID = 57433 TID = 2
```

```
trace_back: #0 0xfc1106dc [MsgReceivev]
trace_back: #1 0xfc0fc840 [msg_receivev]
trace_back: #2 0xfc0fc64c [msg_receive]
trace_back: #3 0xfc0ffa70 [event_dispatch]
trace_back: #4 0xfc0ffc2c [event_block]
trace_back: #5 0x4821e978 [<N/A>]
```

```
ENDOFSTACKTRACE
```

```
Current process = "pkg/bin/lpts_pa", PID = 57433 TID = 3
```

```
trace_back: #0 0xfc1106dc [MsgReceivev]
trace_back: #1 0xfc0fc840 [msg_receivev]
trace_back: #2 0xfc0fc64c [msg_receive]
trace_back: #3 0xfc0ffa70 [event_dispatch]
trace_back: #4 0xfc0ffc2c [event_block]
trace_back: #5 0x482064c4 [<N/A>]
```

```
ENDOFSTACKTRACE
```

### Related Topics

[monitor threads](#), on page 573

[show processes](#), on page 602



# monitor threads

To display auto-updating statistics on threads in a full-screen mode, use the **monitor threads** command in administration EXEC mode or in EXEC mode.

**monitor threads** [**dumbtty**] [**iteration** *number*] [**location** *node-id*]

## Syntax Description

<b>dumbtty</b>	(Optional) Displays the output of the command as if on a dumb terminal (the screen is not refreshed).
<b>iteration</b> <i>number</i>	(Optional) Number of times the statistics display is to be updated, in the range from 0 to 4294967295.
<b>location</b> <i>node-id</i>	(Optional) Displays the output from the command from the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.

## Command Default

When all keywords are omitted, the **monitor threads** command displays the first ten threads for the local node, sorted in descending order by the time used. The display is cleared and updated every 5 seconds until you quit the command.

## Command Modes

EXEC, Admin EXEC

## Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	No modification.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **monitor threads** command to show the top ten threads based on CPU usage. The display refreshes every 10 seconds.

- To change the parameters displayed by the **monitor threads** command, enter one of the key commands described in [Table 47: Interactive Display Commands for the monitor threads Command, on page 574](#).
- To terminate the display and return to the system prompt, enter the **q** key.
- To list the interactive commands, type **?** during the display.

[Table 47: Interactive Display Commands for the monitor threads Command, on page 574](#) describes the available interactive display commands.

Table 47: Interactive Display Commands for the monitor threads Command

Command	Description
?	Displays the available interactive commands.
d	Changes the delay interval between updates.
k	Kills a process.
l	Refreshes the screen.
n	Changes the number of threads to be displayed.
q	Quits the interactive display and returns the prompt to EXEC mode.

Task ID	Task ID	Operations
	basic-services	execute

The following example shows sample output from the **monitor threads** command:

```
RP/0/RSP0/CPU0:router# monitor threads

195 processes; 628 threads;
CPU states: 98.2% idle, 0.9% user, 0.7% kernel
Memory: 2048M total, 1576M avail, page size 4K

 JID TID LAST_CPU PRI STATE HH:MM:SS CPU COMMAND
 1 12 1 10 Rcv 0:00:09 0.42% procnto-600-smp-cisco-instr
 1 25 1 10 Run 0:00:30 0.36% procnto-600-smp-cisco-instr
 342 1 1 19 Rcv 0:00:07 0.20% wdsysmon
 52 5 0 21 Rcv 0:00:03 0.15% devc-conaux
 52 3 1 18 Rcv 0:00:02 0.07% devc-conaux
532670 1 0 10 Rply 0:00:00 0.07% top
 293 6 0 55 Rcv 0:00:06 0.03% shelfmgr
 55 8 0 10 Rcv 0:00:02 0.03% eth_server
 315 3 0 10 Rcv 0:00:11 0.03% sysdb_svr_local
 55 7 0 55 Rcv 0:00:11 0.02% eth_server
```

The following example shows sample output from the **monitor threads** command using the optional **location** keyword:

```
RP/0/RSP0/CPU0:router# monitor threads location 0/RP0/CPU0

Computing times...195 processes; 628 threads;
CPU states: 95.1% idle, 2.7% user, 2.0% kernel
Memory: 2048M total, 1576M avail, page size 4K

 JID TID LAST_CPU PRI STATE HH:MM:SS CPU COMMAND
 1 25 0 10 Run 0:00:32 2.08% procnto-600-smp-cisco-instr
 265 5 0 10 SigW 0:00:09 0.89% packet
 279 1 1 10 Rcv 0:00:00 0.65% qsm
557246 1 0 10 Rply 0:00:00 0.51% top
 293 5 1 55 Rcv 0:00:01 0.07% shelfmgr
 180 13 1 10 Rcv 0:00:02 0.07% gsp
 315 3 0 10 Rcv 0:00:12 0.07% sysdb_svr_local
```

```

55 7 1 55 Rcv 0:00:12 0.04% eth_server
180 1 0 10 Rcv 0:00:01 0.04% gsp
298 9 0 10 Rcv 0:00:01 0.04% snmpd

```

Table 48: [monitor threads Field Descriptions, on page 575](#) describes the significant fields shown in the display.

**Table 48: monitor threads Field Descriptions**

Field	Description
JID	Job ID.
TIDS	Thread ID.
LAST_CPU	Number of open channels.
PRI	Priority level of the thread.
STATE	State of the thread.
HH:MM:SS	Run time of process since last restart.
CPU	Percentage of CPU used by process thread.
COMMAND	Process name.

### Using Interactive Commands

When the **n** or **d** interactive command is used, the **monitor threads** command prompts for a number appropriate to the specific interactive command. The following example shows sample output from the **monitor threads** command using the interactive **n** command after the first display cycle to change the number of threads:

```

RP/0/RSP0/CPU0:router# monitor threads

Computing times... 87 processes; 249 threads;
CPU states: 84.8% idle, 4.2% user, 10.9% kernel
Memory: 256M total, 175M avail, page size 4K

 JID TID PRI STATE HH:MM:SS CPU COMMAND
 --- --- --- --- ---:---:--- --- ---
 1 6 10 Run 0:00:10 10.92% kernel
553049 1 10 Rply 0:00:00 4.20% top
 58 3 10 Rcv 0:00:24 0.00% sysdsbvr
 1 3 10 Rcv 0:00:21 0.00% kernel
 69 1 10 Rcv 0:00:20 0.00% wdsysmon
 1 5 10 Rcv 0:00:20 0.00% kernel
 159 2 10 Rcv 0:00:05 0.00% qnet
 160 1 10 Rcv 0:00:05 0.00% netio
 157 1 10 NSlp 0:00:04 0.00% envmon_periodic
 160 9 10 Intr 0:00:04 0.00% netio

n

Enter number of threads to display: 3
Please enter a number between 5 and 40
Enter number of threads to display: 8

```

```
87 processes; 249 threads;
CPU states: 95.3% idle, 2.9% user, 1.7% kernel
Memory: 256M total, 175M avail, page size 4K
```

JID	TID	PRI	STATE	HH:MM:SS	CPU	COMMAND
1	6	10	Run	0:00:11	1.76%	kernel
69	1	10	Rcv	0:00:20	1.11%	wdsysmon
58	3	10	Rcv	0:00:24	0.40%	sysdbsvr
157	1	10	NSlp	0:00:04	0.23%	envmon_periodic
159	19	10	Rcv	0:00:02	0.20%	qnet
553049	1	10	Rply	0:00:00	0.20%	top
159	12	10	Rcv	0:00:03	0.13%	qnet
160	1	10	Rcv	0:00:05	0.10%	netio

When a number outside the acceptable range is entered, the acceptable range is displayed:

```
Please enter a number between 5 and 40
Enter number of threads to display:
```

### Related Topics

[monitor processes](#)

# process

To start, terminate, or restart a process, use the **process** command in admin EXEC mode.

**process** {**crash** | **restart** | **shutdown** | **start**} {*executable-name**job-id*} **location** {*node-id* | **all**}

## Syntax Description

<b>crash</b>	Crashes a process.
<b>restart</b>	Restarts a process.
<b>shutdown</b>	Stops a process. The process is not restarted (even if considered “mandatory ◆?”).
<b>start</b>	Starts a process.
<i>executable-name</i>	Executable name of the process to be started, terminated, or restarted. Supplying an executable name for the <i>executable-name</i> argument performs the action for all the simultaneously running instances of the process, if applicable.
<i>job-id</i>	Job ID of the process instance to be started, terminated, or restarted. Supplying a job ID for the <i>job-id</i> argument performs the action for only the process instance associated with the job ID.
<b>location</b> { <i>node-id</i>   <b>all</b> }	Starts, terminates, or restarts a process on the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation. The <b>all</b> keyword specifies all nodes.

## Command Default

None

## Command Modes

Admin EXEC

## Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	No modification.

## Usage Guidelines

Under normal circumstances, processes are started and restarted automatically by the operating system as required. If a process crashes, it is automatically restarted.

Use this command to manually start, stop, or restart individual processes.



### Caution

Manually stopping or restarting a process can seriously impact the operation of a router. Use these commands only under the direction of a Cisco Technical Support representative.

**process shutdown**

The **process shutdown** command shuts down (terminates) the specified process and copies associated with the specified process. The process is not restarted, even if considered “mandatory.” Use the **show processes** command to display a list of executable processes running on the system.

**Caution**

Stopping a process can result in an RP switchover, system failure or both. This command is intended for use only under the direct supervision of a Cisco Technical Support representative.

**process restart**

The **process restart** command restarts a process, such as a process that is not functioning optimally.

**process start**

The **process start** command starts a process that is not currently running, such as a process that was terminated using the **process kill** command. If multiple copies are on the system, all instances of the process are started simultaneously.

**Task ID**

Task ID	Task	Operations
	root-lr	execute

The following example shows how to restart a process. In this example, the IS-IS process is restarted:

```
RP/0/RSP0/CPU0:router# process restart isis

RP/0/RSP0/CPU0:router#RP/0/RSP0/CPU0:Mar 30 15:24:41 : isis[343]: %ISIS-6-INFO_ST
RTUP_START : Cisco NSF controlled start beginning
RP/0/RSP0/CPU0:router#RP/0/RSP0/CPU0:Mar 30 15:24:52 : isis[352]: %ISIS-6-INFO_ST
RTUP_FINISH : Cold controlled start completed
```

The following example shows how to terminate a process. In this example, the IS-IS process is stopped:

```
RP/0/RSP0/CPU0:router# process shutdown isis
RP/0/RSP0/CPU0:router#
```

The following example shows how to start a process. In this example, the IS-IS process is started:

```
RP/0/RSP0/CPU0:router# process start isis

RP/0/RSP0/CPU0:router#RP/0/RSP0/CPU0:Mar 30 15:27:19 : isis[227]:
%ISIS-6-INFO_STARTUP_START : Cold controlled start beginning
RP/0/RSP0/CPU0:Mar 30 15:27:31 : isis[352]: %ISIS-6-INFO_STARTUP_FINISH :
Cold controlled start completed
```

This example shows how to restart a process:

**Related Topics**

[process mandatory](#), on page 582

[show processes](#), on page 602

## process core

To modify the core dump options for a process, use the **process core** command in administration EXEC mode.

**process** {*executable-name**job-id*} **core** {**context** | **copy** | **fallback** | **iomem** | **mainmem** | **off** | **sharedmem** | **sparse** | **sync** | **text**} [**maxcore** *value*] **location** *node-id*

### Syntax Description

<i>executable-name</i>	Executable name of the process for which you want to change core dump options. Specifying a value for the <i>executable-name</i> argument changes the core dump option for multiple instances of a running process.
<i>job-id</i>	Job ID associated with the process instance. Specifying a <i>job-id</i> value changes the core dump option for only a single instance of a running process.
<b>context</b>	Dumps only context information for a process.
<b>copy</b>	Copies a core dump locally before performing the core dump.
<b>fallback</b>	Sets the core dump options to use the fallback options (if needed).
<b>iomem</b>	Dumps the I/O memory of a process.
<b>mainmem</b>	Dumps the main memory of a process.
<b>off</b>	Indicates that a core dump is not taken on the termination of the specified process.
<b>sharedmem</b>	Dumps the shared memory of a process.
<b>sparse</b>	Enables sparse core dumps of a process.
<b>sync</b>	Enables only synchronous core dumping.
<b>text</b>	Dumps the text of a process.
<b>maxcore</b> <i>value</i>	(Optional) Specifies the maximum number of core dumps allowed for the specified process on its creation.
<b>location</b> <i>node-id</i>	Sets the core dump options for a process on a designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.

### Command Default

By default, processes are configured to dump shared memory, text area, stack, data section, and heap information.

### Command Modes

Administration EXEC

### Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	No modification.



**Usage Guidelines**

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The modular architecture of Cisco IOS XR software allows core dumps for individual processes. By default, processes are configured to dump shared memory, text area, stack, data section, and heap information.

Specifying an executable name for the *executable-name job-id* argument changes the core dump option for all instances of the process. Specifying a job ID for the value changes the core dump option for a single instance of a running process.

**Task ID**

Task ID	Operations
root-lr	execute

The following example shows how to enable the collection of shared memory of a process:

```
RP/0/RSP0/CPU0:router# process ospf core sharedmem
```

The following example shows how to turn off core dumping for a process:

```
RP/0/RSP0/CPU0:router# process media_ether_config_di core off
```

**Related Topics**

[show processes](#), on page 602

## process mandatory

To set the mandatory reboot options for a process, use the **process mandatory** command in the appropriate mode.

### process mandatory

**process mandatory** {on | off} {executable-namejob-id} **location** node-id

### process mandatory reboot

**process mandatory reboot** {enable | disable}

### process mandatory toggle

**process mandatory toggle** {executable-namejob-id} **location** node-id

#### Syntax Description

<b>on</b>	Turns on mandatory process attribute.
<b>off</b>	Turns off the mandatory process attribute. The process is not considered mandatory.
<b>reboot</b> { <b>enable</b>   <b>disable</b> }	Enables or disables the reboot action when a mandatory process fails.
<b>toggle</b>	Toggles a mandatory process attribute.
<i>executable-name</i>	Executable name of the process to be terminated. Specifying an executable name for the <i>executable-name</i> argument terminates the process and all the simultaneously running copies, if applicable.
<i>job-id</i>	Job ID associated with the process to be terminated. Terminates only the process associated with the job ID.
<b>location</b> <i>node-id</i>	Sets the mandatory settings for a process on a designated node. The node-id argument is expressed in the <i>rack/slot/module</i> notation.

#### Command Default

No default behavior or values

#### Command Modes

Administration EXEC

EXEC

#### Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	No modification.

#### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

If a process unexpectedly goes down, the following action occurs based on whether the process is considered mandatory.

- If the process is mandatory and the process cannot be restarted, the node automatically reboots.
- If the process is not mandatory and cannot be restarted, it stays down and the node does not reboot.

Task ID	Task ID	Operations
	root-lr	execute

The following example shows how to turn on a mandatory attribute. In this example, the mandatory attribute is turned on for the `media_ether_config_di` process.

```
RP/0/RSP0/CPU0:router# process mandatory on media_ether_config_di
```

The following example shows how to turn the reboot option on. In this example, the router is set to reboot the node if a mandatory process goes down and cannot be restarted.

```
RP/0/RSP0/CPU0:router# process mandatory reboot enable
```

```
RP/0/RSP00/CPU0:Mar 19 19:28:10 : sysmgr[71]: %SYSMGR-4-MANDATORY_REBOOT_ENABLE :
mandatory reboot option enabled by request
```

The following example shows how to turn off the reboot option. In this example, the router is set *not* to reboot the node if a mandatory process goes down and cannot be restarted. In this case, the mandatory process is restarted, but the node is not rebooted.

```
RP/0/RSP0/CPU0:router# process mandatory reboot disable
```

```
RP/0/RSP00/CPU0:Mar 19 19:31:20 : sysmgr[71]: %SYSMGR-4-MANDATORY_REBOOT_OVERRIDE
: mandatory reboot option overridden by request
```

### Related Topics

[show processes](#), on page 602

# show context

To display core dump context information, use the **show context** command in administration EXEC mode or in EXEC mode.

**show context** [*coredump-occurrence* | **clear**] [**location** {*node-id* | **all**}]

<b>Syntax Description</b>	<i>coredump-occurrence</i>	(Optional) Core dump context information to be displayed based on the occurrence of the core dump. Valid values are 1 to 10.
	<b>clear</b>	(Optional) Clears the current context information.
	<b>location</b> { <i>node-id</i>   <b>all</b> }	Displays core dump information that occurred on the designated node. The <i>node-id</i> argument is expressed in the <i>rack/slot/module</i> notation. The <b>all</b> keyword specifies to display information for all nodes.

**Command Default** If no *coredump-occurrence* value is specified, core dump context information for all core dumps is displayed.

**Command Modes** EXEC, Administration EXEC

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **show context** command to display core dump context information. This command displays context information for the last ten core dumps. Cisco Technical Support Center engineers and development engineers use this command for post-analysis in the debugging of processes.

Use the [clear context, on page 550](#) command to clear core dump context information.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	diag	read

The following example shows sample output from the **show context** command:

```
RP/0/RSP0/CPU0:router# show context

Crashed pid = 20502 (pkg/bin/mbi-hello)
Crash time: Thu Mar 25, 2004: 19:34:14
```

```
Core for process at disk0:/mbi-hello.20040325-193414.node0_RP0_CPU0
```

```
Stack Trace
#0 0xfc117c9c
#1 0xfc104348
#2 0xfc104154
#3 0xfc107578
#4 0xfc107734
#5 0x482009e4

Registers info
 r0 r1 r2 r3
R0 0000000e 481ffa80 4820c0b8 00000003
 r4 r5 r6 r7
R4 481ffb18 00000001 481ffa88 48200434
 r8 r9 r10 r11
R8 00000000 00000001 00000000 fc17ac58
 r12 r13 r14 r15
R12 481ffb08 4820c080 481ffc10 00000001
 r16 r17 r18 r19
R16 481ffc24 481ffc2c 481ffc44 00000000
 r20 r21 r22 r23
R20 00398020 00000000 481ffb6c 4820a484
 r24 r25 r26 r27
R24 00000000 00000001 4820efe0 481ffb88
 r28 r29 r30 r31
R28 00000001 481ffb18 4820ef08 00000001
 cnt lr msr pc
R32 fc168d58 fc104348 0000d932 fc117c9c
 cnd xer
R36 24000022 00000004
```

```
DLL Info
DLL path Text addr. Text size Data addr. Data size Version
/pkg/lib/libinfra.dll 0xfc0f6000 0x00032698 0xfc0f5268 0x00000cb4
```

The following example shows sample output from the **show context** command. The output displays information about a core dump from a process that has not crashed.

```
RP/0/RSP0/CPU0:router# show context

node: node0_RP0_CPU0

Crashed pid = 28703 (pkg/bin/packet)
Crash time: Tue Sep 21, 2004: 02:48:00
Core for process at harddisk:/packet.by.dumper_gen.20040921-024800.node0_RP0_CPU0.ppc.Z
```

[Table 49: show context Field Descriptions, on page 585](#) describes the significant fields shown in the display.

**Table 49: show context Field Descriptions**

Field	Description
Crashed pid	Process ID (PID) of the crashed process followed by the executable path.
Crash time	Time and date the crash occurred.
Core for process at	File path to the core dump file.

Field	Description
Stack Trace	Stack trace information.
Registers Info	Register information related to crashed threads.
DLL Info	Dynamically loadable library (DLL) information used to decode the stack trace.

**Related Topics**

[clear context](#), on page 550

# show dll

To display dynamically loadable library (DLL) information, use the **show dll** command in administration EXEC mode or in EXEC mode.

```
show dll [{jobid job-id [virtual] | [symbol]address virtual-address | dllname dll-virtual-path | memory | virtual}] [location node-id]
```

Syntax Description		
<b>jobid</b> <i>job-id</i>	(Optional) Displays DLL information for the specified job identifier.	
<b>virtual</b>	(Optional) Displays the virtual path of DLLs. The virtual path is expressed in the /pkg/lib/library-name.dll format where the library name is the name of the DLL followed by the .dll suffix.	
<b>symbol</b>	(Optional) Displays the symbol at the virtual address specified for the <i>virtual-address</i> argument.	
<b>address</b> <i>virtual-address</i>	(Optional) Displays the DLL that is mapped at the virtual address specified for the <i>virtual-address</i> argument.	
<b>dllname</b> <i>dll-virtual-path</i>	(Optional) Displays the process IDs (PIDs) of the process that have downloaded the DLL specified for the <i>dll-virtual-path</i> argument.	
<b>memory</b>	(Optional) Displays a summary of DLL memory usage.	
<b>location</b> <i>node-id</i>	(Optional) Displays DLLs for the specified node. The <i>node-id</i> argument is expressed in the <i>rack/slot/module</i> notation.	

**Command Default** No default behavior or values

**Command Modes** EXEC, Administration EXEC

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	basic-services	read

The following example shows sample output from the **show dll** command. In this example, the output displays all the DLLs loaded on the router.

```
RP/0/RSP0/CPU0:router# show dll
```

DLL path	Text VA	Text Sz	Data VA	Data Sz	Refcount
/lib/libui.dll	0xfc000000	0x00007000	0xfc007000	0x00001000	1
/disk0/asr9k-base-0.48.0/lib/liblogin.dll	0xfc008000	0x00006000	0xfc00e000	0x00001000	1
/mbi/lib/libbanner.dll	0xfc00f000	0x00003000	0xfc012000	0x00001000	1
/disk0/asr9k-base-0.48.0/lib/libaaav2.dll	0xfc013000	0x0000f000	0xfc022000	0x00001000	1
/disk0/asr9k-base-0.48.0/lib/libaaatty.dll	0xfc023000	0x00004000	0xfc027000	0x00001000	1
/mbi/lib/libtermcap.dll	0xfc028000	0x00003000	0xfc02b000	0x00001000	1
/mbi/lib/lib_show_dll.dll	0xfc02c000	0x00004000	0xfc030000	0x00001000	1
/mbi/lib/libihplatform.dll	0xfc0bf2d4	0x0000c18	0xfc1e4f88	0x0000068	1
/lib/libovl.dll	0xfc0c8000	0x0000c3b0	0xfc0c21f0	0x0000076c	23
/disk0/asr9k-admin-0.48.0/lib/libfqm_ltrace_util_common.dll	0xfc0d43b0	0x00000bfc	0xfc391f7c	0x00000068	1
/lib/libplatform.dll	0xfc0d5000	0x0000aa88	0xfc0e0000	0x00002000	165
/lib/libsysmgr.dll	0xfc0e2000	0x0000ab48	0xfc0c295c	0x00000368	166
/lib/libinfra.dll	0xfc0ed000	0x0003284c	0xfc120000	0x0000c70	169
/lib/libbios.dll	0xfc121000	0x0002c4bc	0xfc14e000	0x00002000	166
/lib/libc.dll	0xfc150000	0x00077ae0	0xfc1c8000	0x00002000	175
/mbi/lib/libltrace.dll	0xfc1ca000	0x00007f5c	0xfc0c2cc4	0x00000188	96
/lib/libsyslog.dll	0xfc1d2000	0x0000530c	0xfc120c70	0x00000308	129
/disk0/asr9k-base-0.48.0/lib/liblpts_ifib_platform.dll	0xfc1d730c	0x00000cc8	0xfcef4000	0x00000068	1
/lib/libbackplane.dll	0xfc1d8000	0x0000134c	0xfc0c2e4c	0x000000a8	163
/disk0/asr9k-base-0.48.0/lib/libipv6_platform_client.dll	0xfc1d934c	0x00000c48	0xfcef4f8c	0x00000068	1
/mbi/lib/libpkgfs_node.dll	0xfc1da000	0x000092d4	0xfc1e4000	0x000001a8	3

The following example shows sample output from the **show dll** command with the optional **jobid** *job-id* keyword and argument:

```
RP/0/RSP0/CPU0:router# show dll jobid 186
```

DLLs mapped by PID 86111					
DLL path	Text VA	Text Sz	Data VA	Data Sz	Refcount
/lib/libovl.dll	0xfc0c8000	0x0000c3b0	0xfc0c21f0	0x0000076c	23
/lib/libplatform.dll	0xfc0d5000	0x0000aa88	0xfc0e0000	0x00002000	165
/lib/libsysmgr.dll	0xfc0e2000	0x0000ab48	0xfc0c295c	0x00000368	167
/lib/libinfra.dll	0xfc0ed000	0x0003284c	0xfc120000	0x0000c70	169
/lib/libbios.dll	0xfc121000	0x0002c4bc	0xfc14e000	0x00002000	166
/lib/libc.dll	0xfc150000	0x00077ae0	0xfc1c8000	0x00002000	175
/mbi/lib/libltrace.dll	0xfc1ca000	0x00007f5c	0xfc0c2cc4	0x00000188	96
/lib/libsyslog.dll	0xfc1d2000	0x0000530c	0xfc120c70	0x00000308	129
/lib/libbackplane.dll	0xfc1d8000	0x0000134c	0xfc0c2e4c	0x000000a8	163
/lib/libnodeid.dll	0xfc1e5000	0x000091fc	0xfc1e41a8	0x00000208	163
/mbi/lib/libinst_mem.dll	0xfc232000	0x000044f8	0xfc1e43b0	0x00000108	4
/lib/libdebug.dll	0xfc23c000	0x0000ef64	0xfc1e4680	0x00000550	159

[Table 50: show dll Field Descriptions, on page 589](#) describes the significant fields shown in the display.



**Table 50: show dll Field Descriptions**

Field	Description
DLL path	Physical path of the DLL on the router.
Text VA	Virtual address of the text segment of the DLL.
Text Sz	Size of the text segment of the DLL.
Data VA	Virtual address of the data segment of the DLL.
Data Sz	Size of the data segment of the DLL.
Refcount	Number of clients using the DLL.

The following example shows sample output from the **show dll** command with the optional **dllname** *dll-virtual-path* keyword and optional argument:

```
RP/0/RSP0/CPU0:router# show dll dllname /pkg/lib/libinst_mem.dll

PID: 4102 Refcount: 1
PID: 4105 Refcount: 1
PID: 24600 Refcount: 1
PID: 86111 Refcount: 1
```

[Table 51: show dll dllname Field Descriptions, on page 589](#) describes the significant fields shown in the display.

**Table 51: show dll dllname Field Descriptions**

Field	Description
PID:	Process ID of the process.
Refcount	Number of references to the DLL by the process.

The following example shows sample **show dll** output from the command with the optional **memory** keyword:

```
RP/0/RSP0/CPU0:router# show dll memory

Total DLL Text - 14778896 bytes Total DLL Data - 12688500 bytes
Total DLL Memory - 27467396 bytes
```

# show exception

To display the configured core dump settings, use the **show exception** command in administration EXEC mode or in EXEC mode.

**show exception** [**core-options** [**process** *process-name*] **location** *node-id*]

## Syntax Description

<b>core-options</b>	(Optional) Displays process core option values.
<b>process</b> <i>process-name</i>	(Optional) Specifies the process for which to display the information.
<b>location</b> <i>node-id</i>	(Optional) Displays configured settings for a specified node. The <i>node-id</i> argument is expressed in the <i>rack/slot/module</i> notation.

## Command Default

None

## Command Modes

EXEC, Administration EXEC

## Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	Support for the <b>core-options</b> keyword was added.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **show exception** command to display the configured core dump settings. The output from this command displays the core dump settings configured with the following commands:

- [exception filepath](#), on page 556
- [exception pakmem](#), on page 560
- [exception sparse](#), on page 562
- [exception sprsize](#), on page 564

## Task ID

Task ID	Operations
diag	read

The following example shows sample output from the **show exception** command with the **location** keyword. All processes for the specified node are displayed.

```
RP/0/RSP0/CPU0:router# show excep core-options location 0/rp0/cpu0
Mon Nov 30 01:31:31.391 PST
```

```

Process
 Options
attach_server:
 TEXT SHAREDMEM MAINMEM
attachd:
 TEXT SHAREDMEM MAINMEM
ksh-aux:
 TEXT SHAREDMEM MAINMEM
bcm_logger:
 TEXT SHAREDMEM MAINMEM
devf-scrp:
 TEXT SHAREDMEM MAINMEM
bfm_server:
 TEXT SHAREDMEM MAINMEM
ksh:
 TEXT SHAREDMEM MAINMEM
dllmgr:
 COPY
dumper:
 TEXT SHAREDMEM MAINMEM
eth_server:
 COPY SPARSE
inflator:
 TEXT SHAREDMEM MAINMEM
insthelper:
 TEXT SHAREDMEM MAINMEM
mbi-hello:
 TEXT SHAREDMEM MAINMEM
cat:
 TEXT SHAREDMEM MAINMEM
mq:
 COPY
mqueue:
 TEXT SHAREDMEM MAINMEM
nname:
 TEXT SHAREDMEM MAINMEM
nvram:
 TEXT SHAREDMEM MAINMEM
--More--

```

The following example shows sample output from the **show exception** command for a specific process:

```

RP/0/RSP0/CPU0:router# show excep core-options process upgrade_daemon location 0/6/cpu0

Mon Nov 30 01:32:20.207 PST
Process
 Options
upgrade_daemon:
 TEXT SHAREDMEM MAINMEM

```

### Related Topics

- [exception filepath](#), on page 556
- [exception pakmem](#), on page 560
- [exception sparse](#), on page 562
- [exception sprsize](#), on page 564

# show memory

To display the available physical memory and memory usage information of processes on the router, use the **show memory** command in EXEC or administration EXEC mode.

**show memory** [*jobid* | **summary** [{*bytes* | *detail*}] ] **location** *node-id*

Syntax Description	
<i>job id</i>	(Optional) Job ID associated with a process instance. Specifying a job ID for the <i>job-id</i> argument displays the memory available and memory usage information for only the process associated with the specified job ID. If the <i>job-id</i> argument is not specified, this command displays information for all running processes.
<b>summary</b>	(Optional) Displays a summary of the physical memory and memory usage information.
<b>bytes</b>	(Optional) Displays numbers in bytes for an exact count.
<b>detail</b>	(Optional) Displays numbers in the format “nnn.dddM” for more detail.
<b>location</b> <i>node-id</i>	Displays the available physical memory from the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.

**Command Default** None

**Command Modes** Administration EXEC  
EXEC

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To display detailed memory information for the entire router, enter the **show memory** command without any parameters.

Task ID	Task ID	Operations
	basic-services	read

This example shows partial sample output from the **show memory** command entered without keywords or arguments. This command displays details for the entire router.

```
RP/0/RSP0/CPU0:router# show memory

Physical Memory:2048M total
Application Memory :1802M (1636M available)
Image:116M (bootram:116M)
Reserved:128M, IOMem:0, flashfsys:0
Total shared window:0
```

```

kernel:jid 1
Address Bytes What
0008f000 12288 Program Stack
000b2000 12288 Program Stack
Total Allocated Memory:0
Total Shared Memory:0

sbin/devc-pty:jid 68
Address Bytes What
4817f000 4096 Program Stack (pages not allocated)
48180000 516096 Program Stack (pages not allocated)
481fe000 8192 Program Stack
48200000 28672 Physical Mapped Memory
48207000 4096 ANON FIXED ELF SYSRAM
48208000 4096 ANON FIXED ELF SYSRAM

```

This example shows sample output from the **show memory** command entered with the job ID 7 to show the memory usage information for the process associated with this job identifier:

```

RP/0/RSP0/CPU0:router# show memory 7

Physical Memory: 256M total
Application Memory : 249M (217M available)
Image: 2M (bootram: 2M)
Reserved: 4M, IOMem: 0, flashfsys: 0

sbin/pipe: jid 7
Address Bytes What
07f7c000 126976 Program Stack (pages not allocated)
07f9b000 4096 Program Stack
07f9d000 126976 Program Stack (pages not allocated)
07fbc000 4096 Program Stack
07fbe000 126976 Program Stack (pages not allocated)
07fdd000 4096 Program Stack
07fdf000 126976 Program Stack (pages not allocated)
07ffe000 4096 Program Stack
08000000 122880 Program Stack (pages not allocated)
0801e000 8192 Program Stack
08020000 12288 Physical Mapped Memory
08023000 4096 Program Text or Data
08024000 4096 Program Text or Data
08025000 16384 Allocated Memory
08029000 16384 Allocated Memory
7c001000 319488 DLL Text libc.dll
7e000000 8192 DLL Data libc.dll

```

This example shows how to display a detailed summary of memory information for the router:

```

RP/0/RSP0/CPU0:router# show memory summary detail

Physical Memory: 256.000M total
Application Memory : 140.178M (15.003M available)
Image: 95.739M (bootram: 95.739M)
Reserved: 20.000M, IOMem: 0, flashfsys: 0
Shared window fibv6: 257.980K
Shared window PFI_IFH: 207.925K
Shared window aib: 8.972M
Shared window infra_statsd: 3.980K
Shared window ipv4_fib: 1.300M

```

```

Shared window atc_cache: 35.937K
Shared window qad: 39.621K
Total shared window: 10.805M
Allocated Memory: 49.933M
Program Text: 6.578M
Program Data: 636.000K
Program Stack: 4.781M

```

**Table 52: show memory summary Field Descriptions**

Field	Description
Physical Memory	Available physical memory on the router.
Application Memory	Current memory usage of all the processes on the router.
Image	Memory that is currently used by the image and available memory.
Reserved	Total reserved memory.
IOMem	Available I/O memory.
flashfsys	Total flash memory.
Shared window fibv6	Internal shared window information.
Shared window PFI_IFH	Internal shared window information.
Shared window aib	Internal shared window information.
Shared window infra_statsd	Internal shared window information.
Shared window ipv4_fib	Internal shared window information.
Shared window atc_cache	Internal shared window information.
Shared window qad	Internal shared window information.
Total shared window	Internal shared window information.
Allocated Memory	Amount of memory allocated for the specified node.
Program Text	Internal program test information.
Program Data	Internal program data information.
Program Stack	Internal program stack information.

### Related Topics

[show memory heap](#), on page 598

[show processes](#), on page 602

# show memory compare

To display details about heap memory usage for all processes on the router at different moments in time and compare the results, use the **show memory compare** command in EXEC or administration EXEC mode.

**show memory compare** {start | end | report}

Syntax Description	
<b>start</b>	Takes the initial snapshot of heap memory usage for all processes on the router and sends the report to a temporary file named /tmp/memcmp_start.out.
<b>end</b>	Takes the second snapshot of heap memory usage for all processes on the router and sends the report to a temporary file named /tmp/memcmp_end.out. This snapshot is compared with the initial snapshot when displaying the heap memory usage comparison report.
<b>report</b>	Displays the heap memory comparison report, comparing heap memory usage between the two snapshots of heap memory usage.

**Command Default** None

**Command Modes** Administration EXEC  
EXEC

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** Use the **show memory compare** command to display details about the heap memory usage of all processes on the router at different moments in time and compare the results. This command is useful for detecting patterns of memory usage during events such as restarting processes or configuring interfaces.

Use the following steps to create and compare memory snapshots:

1. Enter the **show memory compare** command with the **start** keyword to take the initial snapshot of heap memory usage for all processes on the router.



**Note** The snapshot is similar to that resulting from entry of the [show memory heap, on page 598](#) command with the optional **summary** keyword.

2. Perform the test you want to analyze.
3. Enter the **show memory compare** command with the **end** keyword to take the snapshot of heap memory usage to be compared with the initial snapshot.
4. Enter the **show memory compare** command with the **report** keyword to display the heap memory usage comparison report.

## show memory compare

Task ID	Task ID	Operations
	basic-services	read

This example shows sample output from the **show memory compare** command with the **report** keyword:

```
RP/0/RSP0/CPU0:router# show memory compare report
```

JID	name	mem before	mem after	difference	mallocs	restarted
---	----	-----	-----	-----	-----	-----
84	driver_infra_partner	577828	661492	83664	65	
279	gsp	268092	335060	66968	396	
236	snap_transport	39816	80816	41000	5	
237	mpls_lsd_agent	36340	77340	41000	5	
268	fint_partner	24704	65704	41000	5	
90	null_caps_partner	25676	66676	41000	5	
208	aib	55320	96320	41000	5	
209	ipv4_io	119724	160724	41000	5	
103	loopback_caps_partne	33000	74000	41000	5	
190	ipv4_arm	41432	82432	41000	5	
191	ipv6_arm	33452	74452	41000	5	
104	sysldr	152164	193164	41000	5	
85	nd_partner	37200	78200	41000	5	
221	clns	61520	102520	41000	5	
196	parser_server	1295440	1336440	41000	5	
75	bundlemgr_distrib	57424	98424	41000	5	
200	arp	83720	124720	41000	5	
201	cdp	56524	97524	41000	5	
204	ether_caps_partner	39620	80620	41000	5	
206	qosmgr	55624	96624	41000	5	
240	imd_server	92880	104680	11800	28	
260	improxy	77508	88644	11136	10	
111	nrssvr	29152	37232	8080	60	
275	sysdb_svr_local	1575532	1579056	3524	30	
205	cfgmgr	31724	33548	1824	25	
99	sysdb_svr_shared	1131188	1132868	1680	14	
51	mbus-rp	26712	27864	1152	4	
66	wdsysmon	298068	299216	1148	15	
168	netio	1010912	1012060	1148	6	
283	itrace_manager	17408	17928	520	3	
59	devc-conaux	109868	110300	432	4	
67	syslogd_helper	289200	289416	216	2	
117	fctl	41596	41656	60	2	
54	sysmgr	171772	171076	-696	-5	
269	ifmgr	539308	530652	-8656	-196	*

**Table 53: show memory compare report Field Descriptions**

Field	Description
JID	Process job ID.
name	Process name.
mem before	Heap memory usage at start (in bytes).



Field	Description
mem after	Heap memory usage at end (in bytes).
difference	Difference in heap memory usage (in bytes).
mallocs	Number of unfreed allocations made during the test period.
restarted	Indicates if the process was restarted during the test period.

**Related Topics**

[show memory heap](#), on page 598

[show processes](#), on page 602

# show memory heap

To display information about the heap space for a process, use the **show memory heap** command in EXEC or administration EXEC mode.

**show memory heap** [**allocated**] [**dllname**] [**failure**] [**free**] {*jobid* | **all**}

Syntax Description		
<b>allocated</b>	(Optional)	Displays a list of all allocated heap blocks.
<b>dllname</b>	(Optional)	Displays heaps with dynamic link library (DLL) names.
<b>failure</b>	(Optional)	Displays a summary of heap failures.
<b>free</b>	(Optional)	Displays a list of all free heap blocks.
<b>summary</b>	(Optional)	Displays a summary of the information about the heap space.
<i>job-id</i>		Job ID associated with the process instance.
<b>all</b>	(Optional)	Displays information about the heap space for all processes. The <b>all</b> keyword is only available when the <b>failure</b> or <b>summary</b> keywords are used.

**Command Default** None

**Command Modes** Administration EXEC  
EXEC

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	basic-services	read

This example shows sample output from the **show memory heap** command, specifying a job ID for the *job-id* argument:

```
RP/0/RSP0/CPU0:router# show memory heap 111
```

```

Malloc summary for pid 16433:
 Heapsize 16384: allocd 6328, free 8820, overhead 1236
 Calls: mallocs 144; reallocs 73; frees 5; [core-allocs 1; core-frees 0]
Block Allocated List
Total Total Block Name/ID/Caller
Usizes Sizes Counts
0x000008c1 0x000008cc 0x00000001 0x7c018a10
0x000005ac 0x00000974 0x00000079 0x7c02b9e0
0x000004f0 0x000004f8 0x00000001 0x7c02b6fc
0x00000080 0x00000088 0x00000001 0x7c01936c
0x00000034 0x00000048 0x00000001 0x7c018954
0x00000024 0x00000030 0x00000001 0x7c019278
0x00000018 0x00000020 0x00000001 0x7c019b2c
0x00000008 0x00000010 0x00000001 0x7c017178
0x00000008 0x00000010 0x00000001 0x7c00fb54
0x00000008 0x00000010 0x00000001 0x7c00fb80
0x00000008 0x00000010 0x00000001 0x7c00fbb8

```

Table 54: show memory heap Field Descriptions

Field	Description
Malloc summary for pid	System-defined process ID (PID).
Heapsize	Size of the heap as allocated from the system by the malloc library.
allocd	Bytes allocated to the process.
free	Bytes available in the heap.
overhead	Malloc library overhead in bytes.
mallocs	Number of malloc calls.
reallocs	Number of realloc calls.
frees	Number of invocations to the caller interface provided in the malloc library for deallocating the memory.
[core-allocs 1; core-frees 0]	Number of core memory units, the memory units in the malloc library allocated by the system for the heap, allocated, and freed.

The following example shows sample output from the **show memory heap** command, specifying the **summary job-id** keyword and argument:

```

RP/0/RSP0/CPU0:router# show memory heap summary 65

Malloc summary for pid 20495 process pcmciad:
 Heapsize 65536: allocd 40332, free 16568, overhead 8636
 Calls: mallocs 883; reallocs 3; frees 671; [core-allocs 4; core-frees 0]
Band size 16, element per block 48, nbuint 1
Completely free blocks: 0
Block alloced: 2, Block freed: 0
allocs: 85, frees: 20
allocmem: 1040, freemem: 496, overhead: 448

```

## show memory heap

```

blocks: 2, blknodes: 96
Band size 24, element per block 34, nbuint 1
Completely free blocks: 0
Block allocated: 1, Block freed: 0
allocs: 243, frees: 223
allocmem: 480, freemem: 336, overhead: 168
blocks: 1, blknodes: 34
Band size 32, element per block 26, nbuint 1
Completely free blocks: 0
Block allocated: 1, Block freed: 0
allocs: 107, frees: 97
allocmem: 320, freemem: 512, overhead: 136
blocks: 1, blknodes: 26
Band size 40, element per block 22, nbuint 1
Completely free blocks: 0
Block allocated: 2, Block freed: 0
allocs: 98, frees: 74
allocmem: 960, freemem: 800, overhead: 240
blocks: 2, blknodes: 44
Band size 48, element per block 18, nbuint 1
Completely free blocks: 0
Block allocated: 1, Block freed: 0
allocs: 53, frees: 42
allocmem: 528, freemem: 336, overhead: 104
blocks: 1, blknodes: 18
Band size 56, element per block 16, nbuint 1
Completely free blocks: 0
Block allocated: 1, Block freed: 0
allocs: 8, frees: 4
allocmem: 224, freemem: 672, overhead: 96
blocks: 1, blknodes: 16
Band size 64, element per block 14, nbuint 1
Completely free blocks: 0
Block allocated: 1, Block freed: 0
allocs: 6, frees: 2
allocmem: 256, freemem: 640, overhead: 88
blocks: 1, blknodes: 14
Band size 72, element per block 12, nbuint 1
Completely free blocks: 0
Block allocated: 1, Block freed: 0
allocs: 1, frees: 0
allocmem: 72, freemem: 792, overhead: 80
blocks: 1, blknodes: 12

```

Table 55: show memory heap summary Field Descriptions

Field	Description
Malloc summary for pid	System-defined process ID (pid).
Heapsize	Size of the heap as allocated from the system by the malloc library.
allocd	Bytes allocated to the process.
free	Bytes available in the heap.
overhead	Malloc library overhead in bytes.
mallocs	Number of malloc calls.

Field	Description
reallocs	Number of realloc calls.
frees	Number of invocations to the caller interface provided in the malloc library for deallocating the memory.
[core-allocs 1; core-frees 0]	Number of core memory units, the memory units in the malloc library allocated by the system for the heap, allocated and freed.
Band size	Small memory elements are arranged in bands. The band size specifies the size of elements within the band.
element per block	Number of elements per block in the band.
nbunit	Number of memory unit one block consists of. Any block in any band should be of a size that is an integer multiple of this basic unit.
Completely free blocks	Number of blocks in the band completely free (available for allocation).
Block alloced	Number of blocks currently allocated for the band.
allocs	Number of allocations currently performed from the band.
frees	Number of free calls that resulted in memory being returned to the band.
allocmem	Amount of memory currently allocated from the band.
overhead	Amount of memory in bytes as overhead for managing the band.
blocks	Number of blocks currently in the band.
blknodes	Number of nodes (elements) in all the blocks in the band.

**Related Topics**

[show memory](#), on page 592

## show processes

To display information about active processes, use the **show processes** command in EXEC or administration EXEC mode.

**show processes** {*job-id**process-name* | **aborts** | **all** | **blocked** | **boot** | **cpu** | **distribution** *process-name* | **dynamic** | **failover** | **family** | **files** | **location** *node-id* | **log** | **mandatory** | **memory** | **pidin** | **searchpath** | **signal** | **startup** | **threadname**} [**location** *node-id*] [**detail**] [**run**]

Syntax	Description
<i>job-id</i>	Job identifier for which information for only the process instance associated with the <i>job-id</i> argument is displayed.
<i>process-name</i>	Process name for which all simultaneously running instances are displayed, if applicable.
<b>aborts</b>	Displays process abort information.
<b>all</b>	Displays summary process information for all processes.
<b>blocked</b>	Displays details about reply, send, and mutex blocked processes.
<b>boot</b>	Displays process boot information.
<b>cpu</b>	Displays CPU usage for each process.
<b>distribution</b>	Displays the distribution of processes.
<b>dynamic</b>	Displays process data for dynamically created processes.
<b>failover</b>	Displays process switchover information.
<b>family</b>	Displays the process session and family information.
<b>files</b>	Displays information about open files and open communication channels.
<b>location</b> <i>node-id</i>	Displays information about the active processes from a designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.
<b>log</b>	Displays process log.
<b>mandatory</b>	Displays process data for mandatory processes.
<b>memory</b>	Displays information about the text, data, and stack usage for processes.
<b>pidin</b>	Displays all processes using the QNX command.
<b>searchpath</b>	Displays the search path.
<b>signal</b>	Displays the signal options for blocked, pending, ignored, and queued signals.
<b>startup</b>	Displays process data for processes created at startup.
<b>threadname</b>	Displays thread names.

<b>detail</b>	(Optional) Displays more detail. This option is available only with the <i>process-name</i> argument.
<b>run</b>	(Optional) Displays information for only running processes. This option is available only with the <i>process-name</i> argument.

**Command Default** None

**Command Modes** Administration EXEC  
EXEC

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** Use the **show processes** command to display general information about the active processes. To display more detailed information for a process, specify a job ID or process for the *job-id* argument or *process-name* argument, respectively.

You can also use the **monitor processes** command to determine the top processes and threads based on CPU usage.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	basic-services	read

The **show processes** command with the *process-name* argument displays detailed information about a process:

```
RP/0/RSP0/CPU0:router# show processes ospf

Tue Jul 28 09:23:17.212 DST
 Job Id: 338
 PID: 336152
 Executable path: /disk0/asr9k-rout-3.9.0.14I/bin/ospf
 Instance #: 1
 Version ID: 00.00.0000
 Respawn: ON
 Respawn count: 1
 Max. spawns per minute: 12
 Last started: Tue Jul 14 15:26:26 2009
 Process state: Run
 Package state: Normal
 Started on config: cfg/gl/ipv4-ospf/proc/100/ord_z/config
 core: MAINMEM
 Max. core: 0
 Placement: Placeable
 startup_path: /pkg/startup/ospf.startup
 Ready: 1.312s
 Available: 1.334s
 Process cpu time: 93.382 user, 13.902 kernel, 107.284 total
JID TID CPU Stack pri state TimeInState HR:MM:SS:MSEC NAME
```

## show processes

```

338 1 0 116K 10 Receive 0:00:00:0375 0:00:47:0139 ospf
338 2 0 116K 10 Receive 0:00:05:0734 0:00:00:0029 ospf
338 3 1 116K 10 Receive 0:00:06:0765 0:00:00:0056 ospf
338 4 1 116K 10 Receive 0:00:00:0096 0:00:00:0698 ospf
338 5 1 116K 10 Receive 0:49:33:0609 0:00:00:0129 ospf
338 6 1 116K 10 Sigwaitinfo 329:56:49:0531 0:00:00:0000 ospf
338 7 0 116K 10 Receive 0:00:00:0816 0:00:58:0676 ospf
338 8 1 116K 10 Receive 0:00:06:0765 0:00:00:0043 ospf
338 9 1 116K 10 Condvar 82:30:01:0311 0:00:00:0029 ospf
338 10 1 116K 10 Receive 82:30:05:0188 0:00:00:0478 ospf
338 11 0 116K 10 Receive 329:54:49:0318 0:00:00:0005 ospf

```

Table 56: show processes Field Descriptions

Field	Description
Job id	Job ID. This field remains constant over process restarts.
PID	Process ID. This field changes when process is restarted.
Executable path	Path for the process executable.
Instance	There may be more than one instance of a process running at a given time (each instance may have more than one thread).
Version ID	API version.
Respawn	ON or OFF. The field indicates if this process restarts automatically in case of failure.
Respawn count	Number of times this process has been started or restarted (that is, the first start makes this count 1).
Max. spawns per minute	Number of respawns not to be exceeded in 1 minute. If this number is exceeded, the process stops restarting.
Last started	Date and time the process was last started.
Process state	Current state of the process.
Started on config	Configuration command that started (or would start) this process.
core	Memory segments to include in core file.
Max. core	Number of times to dump a core file. 0 = infinity.

The **show processes** command with the **memory** keyword displays details of memory usage for a given process or for all processes, as shown in the following example:

```

RP/0/RSP0/CPU0:router# show processes memory

JID Text Data Stack Dynamic Process
55 28672 4096 69632 17072128 eth_server
317 167936 4096 45056 10526720 syslogd
122 512000 4096 77824 9797632 bgp
265 57344 4096 57344 5877760 parser_server

```



```

254 40960 4096 143360 3084288 netio
63 8192 4096 24576 2314240 nvram
314 4096 4096 36864 1699840 sysdb_svr_local
341 495616 4096 40960 1576960 wdsysmon
259 53248 4096 28672 1490944 nvgen_server
189 32768 4096 32768 1425408 hd_drv
69 77824 4096 110592 1421312 qnet
348 323584 4096 40960 1392640 ospf
347 323584 4096 40960 1392640 ospf
346 323584 4096 40960 1392640 ospf
345 323584 4096 40960 1392640 ospf
344 323584 4096 40960 1392640 ospf
261 323584 4096 40960 1392640 ospf
--More--

```

Table 57: show processes memory Field Descriptions

Field	Description
JID	Job ID.
Text	Size of text region (process executable).
Data	Size of data region (initialized and uninitialized variables).
Stack	Size of process stack.
Dynamic	Size of dynamically allocated memory.
Process	Process name.

The **show processes** command with the **all** keyword displays summary information for all processes, as shown in the following example:

```
RP/0/RSP0/CPU0:router# show processes all
```

```

 JID LAST STARTED STATE RE- PLACE- MANDA- MAINT- NAME (IID) ARGS
 START MENT TORY MODE

 82 03/16/2007 14:54:52.488 Run 1 M Y wd-mpi(1)
 58 03/16/2007 14:54:52.488 Run 1 M Y dllmgr(1) -r 60 -u
30
 74 03/16/2007 14:54:52.488 Run 1 M Y pkgfs(1)
 57 03/16/2007 14:54:52.488 Run 1 Y devc-conaux(1) -h
-d
 librs232.dll -m
 libconaux.dll -u
 libst16550.dll
 76 03/16/2007 14:54:52.488 Run 1 Y devc-pty(1) -n 32
 56 Not configured None 0 Y clock_chip(1) -r
-b
--More--

```

Table 58: show processes all Field Description

Field	Description
JID	Job ID.
Last Started	Date when the process was last started.
State	State of the process.
Restart	Number of times the process has restarted since the node was booted. If a node is reloaded, the restart count for all processes is reset. Normally, this value is 1, because usually processes do not restart. However, if you restart a process using the <b>process restart</b> command, the restart count for the process increases by one.
Placement	Indicates whether the process is a placeable process or not. Most processes are not placeable, so the value is blank. ISIS, OSPF, and BGP are examples of placeable processes.
Mandatory	M indicates that the process is mandatory. A mandatory process must be running. If a mandatory process cannot be started (for example, sysmgr starts it but it keeps crashing), after five attempts the sysmgr causes the node to reload in an attempt to correct the problem. A node cannot function properly if a mandatory process is not running.
Maint Mode	Indicates processes that should be running when a node is in maintenance mode. Maintenance mode is intended to run as few processes as possible to perform diagnostics on a card when a problem is suspected. However, even the diagnostics require some services running.
Name (IID)	Name of the process followed by the instance ID. A process can have multiple instances running, so the IID is the instance ID.
Args	Command-line arguments to the process.

**Related Topics**

[monitor processes](#)

[monitor threads](#), on page 573



## Secure Domain Router Commands

---

Secure domain routers (SDRs) are a means of dividing a single physical system into multiple logically separated routers. Cisco ASR 9000 Series Routers are single-shelf routers that only support one SDR—the Owner SDR.

For detailed information about secure domain router concepts, configuration tasks, and examples, see the *Configuring Secure Domain Routers on Cisco IOS XR Software* module in *System Management Configuration Guide for Cisco ASR 9000 Series Routers*.

- [show sdr, on page 608](#)

# show sdr

To display information about the currently defined secure domain routers (SDRs), use the **show sdr** command in the appropriate configuration mode.

## Administration EXEC Mode

**show sdr** [{name *sdr-name* [detail] | summary}]

## EXEC Mode

**show sdr** [detail]

### Syntax Description

<b>name</b> <i>sdr-name</i>	Specifies a specific SDR.
<b>detail</b>	Displays more detailed information for a specific SDR.
<b>summary</b>	Displays summary information about all SDRs in the system.

### Command Default

Administration EXEC Mode Mode:

- Displays information for the Owner SDR.
- If you are logged into a specific SDR as the admin user, then information about the local SDR is displayed.

EXEC Mode Mode:

- Displays information about the local SDR.

### Command Modes

EXEC

Administration EXEC

### Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	No modification.

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **show sdr** command in administration EXEC mode to display the inventory of nodes in the Owner SDR or in a specific named SDR. The **show sdr** command in EXEC mode displays the inventory of nodes in the current SDR.

### Task ID

Task ID	Operations
system	read

This example shows sample output from the **show sdr** command in

EXEC

mode:

```
RP/0/RSP0/CPU0:router# show sdr
Thu Feb 15 04:09:06.179 PST
```

```
SDR Inventory

```

Type	NodeName	NodeState	RedState	PartnerName
RP (0)	0/RSP0/CPU0	IOS XR RUN	Active	0/RSP1/CPU0
RP (0)	0/RSP1/CPU0	NOT_PRESENT	Standby	0/RSP0/CPU0
LC (2)	0/1/CPU0	IOS XR RUN	NONE	NONE
LC (2)	0/4/CPU0	IOS XR RUN	NONE	NONE
LC (2)	0/6/CPU0	IOS XR RUN	NONE	NONE

**Table 59: show sdr Field Descriptions**

Field	Description
Type	Type of card, which can be Linecard, RP, or DRP.
NodeName	Name of the node, expressed in the <i>rack/slot/module</i> notation.
NodeState	Run state of the card, which can be failure, present, booting, running, and so on.
RedState	Redundancy state of the card, which can be active, standby, or none.
PartnerName	Partner of the card, expressed in the <i>rack/slot/module</i> notation.

This example shows sample output from the **show sdr** command in administration EXEC mode with the **summary** keyword:

```
RP/0/RSP0/CPU0:router(admin)# show sdr summary
Thu Feb 15 04:13:27.508 PST
```

```
SDRs Configured:
SDR-Names SDRid dSDRSC StbydSDRSC Primary1 Primary2 MacAddr

Owner 0 0/RSP0/CPU0 NONE 0/RSP0/CPU0 0/RSP1/CPU0 001d.e5eb.c0ae
```

**Table 60: show sdr summary Field Descriptions**

Field	Description
SDRid	Identifier of the SDR.
dSDRSC	Designated secure domain router shelf controller. This refers to the controller of the SDR.
StbydSDRSC	Standby DSDRSC. This refers to the standby controller of the SDR.
Primary1	Configured primary node.

Field	Description
Primary2	Configured primary node pair.
MacAddr	MAC address associated with the SDR.



## Smart Licensing Commands

---

This module describes the commands used to configure Smart Licensing.

For detailed information about Smart Licensing concepts, configuration tasks, and examples, see the *Implementing Smart Licensing on Cisco IOS XR Software* module in *System Management Configuration Guide for Cisco ASR 9000 Series Routers*.

- [license smart enable, on page 612](#)
- [show license all, on page 613](#)
- [show license certificate, on page 614](#)
- [show license entitlement, on page 615](#)
- [show license features \(chassis\), on page 616](#)
- [show license ha, on page 617](#)
- [show license pool, on page 618](#)
- [show license register-status, on page 619](#)
- [show license scheduler, on page 620](#)
- [show license status \(compliance\), on page 621](#)
- [show license udi \(smart\), on page 622](#)
- [show license version, on page 623](#)

# license smart enable

To enable Smart Licensing for your product, use the **license smart enable** command in the Administration Configuration mode. Use the **no** form of this command to disable Smart Licensing and return to the default traditional mode of licensing.

**license smart enable**  
**no license smart enable**

**Syntax Description** This command has no keywords or arguments.

**Command Default** By default, traditional licensing mode is on.

**Command Modes** Administration configuration

Command History	Release	Modification
	Release 5.2.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Smart Licensing components are packaged into the asr9k mini image. By default, traditional licensing mode is on. Use the **license smart enable** command to switch to the Smart Licensing model.

Task ID	Task ID	Operation
	pkg-mgmt	Read, Write, Execute

## Example

This example shows how to run the command to enable Smart Licensing, and the configuration with Smart Licensing enabled.

```
RP/0/RSP0/CPU0:router(admin)# configure
RP/0/RSP0/CPU0:router(admin-config)#license smart enable
RP/0/RSP0/CPU0:router(admin-config)#show config
Building configuration...
!! IOS XR Configuration 5.2.0.19I
license smart enable
end
```



# show license all

To display all entitlements in use the **show license all** command in the Administration mode.

**show license all**

**Syntax Description** This command has no keywords or arguments.

**Command Default** None

**Command Modes** Administration

Command History	Release	Modification
	Release 5.2.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operation
	pkg-mgmt	Read

## Example

This example displays the use of the **show license all** command.

```
RP/0/RSP0/CPU0:router(admin)#show license all
```

# show license certificate

To display details of the licensing certificate use the **show license certificate** command in the Administration mode.

## show license certificate

**Syntax Description** This command has no keywords or arguments.

**Command Default** None

**Command Modes** Administration

Command History	Release	Modification
	Release 5.2.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operation
	pkg-mgmt	Read

## Example

This example shows the output of the **show license certificate** command.

```
RP/0/RSP0/CPU0:router(admin)#show license cert
Licensing Certificates:
ID Cert Info:
Start Date: Mon Mar10 2014 05:58:28 UTC.
Expiry Date:Tue Mar10 2015 05:58:28 UTC
Serial Number: 34506
Version: 3
Subject/SN: 144a76ed-75de-4a8e-969e-30cf683c
Common Name: 5daab5111895b37e21e164dacc::1,2
ID Cert Info:
Start Date: Fri Jun14 2013 20:18:52 UTC.
Serial Number: 3
Expiry Date:Sun Apr24 2033 21:55:42 UTC
Version: 3
```

# show license entitlement

To display the details of the various entitlements you own use the **show license entitlement** command in the Administration mode.

## show license entitlement

**Syntax Description** This command has no keywords or arguments.

**Command Default** None

**Command Modes** Administration

Command History	Release	Modification
	Release 5.2.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operation
	pkg-mgmt	Read

## Example

This example shows the output of the **show license entitlement** command.

```
RP/0/RSP0/CPU0:router(admin)#show license entitlement
Entitlement:Tag: regid.2014-04.com.cisco.S-A9K-IVRF-LIC,1.0_0bb7,
Version: 1.0, Enforce Mode: Authorized
Requested Time : Mon May 19 2014 16:59:24 PST,
Requested Count: 1 Vendor String:
Tag: S-A9K-iVRF-LIC, Version: 1.0, Enforce Mode: Waiting
Requested Time : Mon Mar 10 2014 11:33:12 UTC,
Requested Count: 1 Vendor String:
Tag: regid.2014-04.com.cisco.S-A9K-IVRF-LIC,1.0_1bealf,
Version: 1.0, Not In Use
Requested Time : NA, Requested Count: NA
Vendor String:
Tag:S-A9K-9001-AIP-LIC,Version:1.0,Enforce Mode:Eval period
```

## show license features (chassis)

To display the licenses that are supported on a given chassis, use the **show license features** command in the Administration mode.

### show license features

<b>Syntax Description</b>	This command has no keywords or arguments.
---------------------------	--------------------------------------------

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Administration
----------------------	----------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 5.2.0	This command was introduced.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	pkg-mgmt	Read

### Example

This example shows the output for the **show license features** command.

```
RP/0/RSP0/CPU0:router(admin)#show license features
Platform Feature ID:
A9K-iVRF-LIC
A9K-9001-AIP-LIC
A9K-9001-OPT-LIC
A9K-9001-VID-LIC
A9K-NVSAT1-LIC
A9K-NVSAT5-LIC
A9K-NVSAT20-LIC
A9K-NVSAT1S-LIC
A9K-NVSAT5S-LIC
A9K-NVSAT20S-LIC
A9K-NV-CLUSTR-LIC
A9K-9001-MOB-LIC
```

# show license ha

To display the Smart Licensing high availability status, whether it is in active or standby mode, use the **show license ha** command in the Administration mode.

**show license ha**

**Syntax Description** This command has no keywords or arguments.

**Command Default** None

**Command Modes** Administration

Command History	Release	Modification
	Release 5.2.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operation
	pkg-mgmt	Read

## Example

This example shows the output of the **show license ha** command.

```
RP/0/RSP0/CPU0:router(admin)#show license ha
HA Info:
RP Role: Active
Chassis Role: Active
HA Sudi:
Role: Active PID:ASR-9001,SN:FOC1741NC0Z
```

# show license pool

To display the pool to which the device belongs, use the **show license pool** command in the Administration mode.

## show license pool

**Syntax Description** This command has no keywords or arguments.

**Command Default** None

**Command Modes** Administration

Command History	Release	Modification
	Release 5.2.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operation
	pkg-mgmt	Read

## Example

This example shows the output of the **show license pool** command.

```
RP/0/RSP0/CPU0:router(admin)#show license pool
Assigned Pool Info: IMC0_POOL
```

# show license register-status

To display the Smart Licensing registration status, use the **show license register-status** command in the Administration mode.

**show license register-status**

**Syntax Description** This command has no keywords or arguments.

**Command Default** None

**Command Modes** Administration

Command History	Release	Modification
	Release 5.2.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operation
	pkg-mgmt	Read

## Example

This example shows the output for the **show license register-status** command.

```
RP/0/RSP0/CPU0:router(admin)#show license register-status
Registration Status: Completed
Step 3
for connectivity issues with the Cisco license
manager or register the device with a new token
ID.
Registration Start Time: Fri May 02 2014 17:19:53 PST
Next ID Cert Renew Time: Wed Oct 29 2014 17:21:55 PST
Next ID Cert Expiration Time: May02 2015 17:18:50 PST
Last Response Time: Fri May 02 2014 17:20:11 PST
Last Response Message: OK
```

# show license scheduler

To display the Smart Licensing scheduler information use the **show license scheduler** command in the Administration mode.

## show license scheduler

<b>Syntax Description</b>	This command has no keywords or arguments.
---------------------------	--------------------------------------------

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Administration
----------------------	----------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 5.2.0	This command was introduced.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	pkg-mgmt	Read

## Example

This example shows how to use the **show license scheduler** command, and its output.

```
RP/0/RSP0/CPU0:router(admin)#show license scheduler
Upcoming Scheduled Jobs:
 Job Name: Daily Job
 Recurring: Yes, Cancelled: No
 Next Run Time : Sat May 31 2014 03:58:02 PST
 Job Name: Authorization Renewal Job
 Recurring: No, Cancelled: Yes
 Next Run Time : NA
 Job Name: Init Flag Check Job
 Recurring: No, Cancelled: Yes
 Next Run Time : NA
 Job Name: Evaluation Expiration Check Job
 Recurring: No, Cancelled: No
 Next Run Time : Wed Aug 20 2014 11:18:42 PST
 Job Name: Register Period Expiration Check Job
 Recurring: No, Cancelled: No
 Next Run Time : Fri May 30 2014 04:15:06 PST
```



# show license status (compliance)

To display the compliance status of Smart Licensing, use the **show license status** command in the Administration mode.

**show license status**

**Syntax Description** This command has no keywords or arguments.

**Command Default** None

**Command Modes** Administration

Command History	Release	Modification
	Release 5.2.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operation
	pkg-mgmt	Read

## Example

This example shows you to use show license status command to display the current status of your license.

```
RP/0/RSP0/CPU0:router(admin)#show license status
Compliance Status: Eval period
```

## show license udi (smart)

To display the Smart Licensing UDI, use the **show license udi** command in the Administration mode.

**show license udi**

<b>Syntax Description</b>	This command has no keywords or arguments.
---------------------------	--------------------------------------------

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Administration
----------------------	----------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 5.2.0	This command was introduced.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	pkg-mgmt	Read

### Example

This example shows you how to use the **show license udi** command, and a sample output.

```
RP/0/RSP0/CPU0:router#admin
RP/0/RSP0/CPU0:router(admin)#show license udi
UDI:
PID:ASR-9001, SN:FOC1741NCOZ
```

# show license version

To display the Smart Licensing version information, use the **show license version** in the Administration mode.

**show license version**

**Syntax Description** This command has no keywords or arguments.

**Command Default** None

**Command Modes** Administration

Command History	Release	Modification
	Release 5.2.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operation
	pkg-mgmt	Read

## Example

This example displays how to use the **show license version** command, and the output.

```
RP/0/RSP0/CPU0:router(admin)#show license version
Cisco Smart Licensing Agent, Version 1.1.0_dev/240
```

show license version



# Simple Network Management Protocol (SNMP) Server Commands

This chapter describes the Cisco IOS XR software commands used to configure and monitor the Simple Network Management Protocol (SNMP) for network monitoring and management.

For detailed information about SNMP concepts, configuration tasks, and examples, see the *Implementing SNMP on Cisco IOS XR Software* configuration module in *System Management Configuration Guide for Cisco ASR 9000 Series Routers*.



**Note** The **snmp-server** commands enable SNMP on Management Ethernet interfaces by default. For information about how to enable SNMP server support on other inband interfaces, see the *Implementing Management Plane Protection on Cisco IOS XR Software* module in *System Security Configuration Guide for Cisco ASR 9000 Series Routers*.

- [add \(bulkstat object\)](#), on page 629
- [buffer-size](#), on page 630
- [clear snmp counters](#), on page 631
- [enable \(bulkstat\)](#), on page 632
- [format \(bulkstat\)](#), on page 634
- [index persistence](#), on page 636
- [instance \(bulkstat schema\)](#), on page 637
- [instance range](#), on page 639
- [instance repetition](#), on page 640
- [notification linkupdown](#), on page 642
- [object-list](#), on page 644
- [poll-interval](#), on page 645
- [retain](#), on page 646
- [retry](#), on page 648
- [schema](#), on page 650
- [show snmp](#), on page 651
- [show snmp context](#), on page 654
- [show snmp context-mapping](#), on page 655
- [show snmp engineid](#), on page 657

- [show snmp group](#), on page 658
- [show snmp host](#), on page 660
- [show snmp interface](#), on page 662
- [show snmp interface notification](#), on page 664
- [show snmp interface regular-expression](#), on page 666
- [show snmp mib](#), on page 667
- [show snmp mib bulkstat transfer](#), on page 670
- [show snmp request duplicates](#), on page 672
- [show snmp request incoming-queue detail](#), on page 673
- [show snmp request type summary](#), on page 675
- [show snmp request type detail](#), on page 677
- [show snmp request drop summary](#), on page 678
- [show snmp request overload stats](#), on page 680
- [show snmp statistics oid group](#), on page 681
- [show snmp statistics pdu](#), on page 683
- [show snmp statistics slow oid](#), on page 685
- [show snmp statistics poll oid all](#), on page 687
- [Show snmp statistics poll oid nms](#), on page 689
- [show snmp statistics slow oid \[after/before\] hh:mm:ss day mday year](#), on page 690
- [show snmp mib ifmib general](#), on page 692
- [show snmp mib ifmib cache](#), on page 694
- [show snmp mib ifmib statsd](#), on page 696
- [show snmp traps details](#), on page 698
- [show snmp informs details](#), on page 700
- [show snmp users](#), on page 702
- [show snmp view](#), on page 704
- [snmp-server chassis-id](#), on page 705
- [snmp-server community](#), on page 706
- [snmp-server community-map](#), on page 708
- [snmp-server contact](#), on page 710
- [snmp-server context](#), on page 711
- [snmp-server context mapping](#), on page 712
- [snmp-server drop report acl](#), on page 714
- [snmp-server drop unknown-user](#), on page 715
- [snmp-server engineid local](#), on page 716
- [snmp-server engineid remote](#), on page 717
- [snmp-server entityindex persist](#), on page 718
- [snmp-server group](#), on page 719
- [snmp-server host](#), on page 722
- [snmp-server ifindex persist](#), on page 726
- [snmp-server ifmib ifalias long](#), on page 727
- [snmp-server ifmib internal cache max-duration](#), on page 728
- [snmp-server ifmib ipsubscriber](#), on page 729
- [snmp-server ifmib stats cache](#), on page 730
- [snmp-server inform](#), on page 731
- [snmp-server interface](#), on page 732

- `snmp-server interface subset`, on page 734
- `snmp-server ipv4 dscp`, on page 736
- `snmp-server ipv4 precedence`, on page 737
- `snmp-server location`, on page 739
- `snmp-server mib bulkstat max-procmem-size`, on page 740
- `snmp-server mib bulkstat object-list`, on page 741
- `snmp-server mib bulkstat schema`, on page 742
- `snmp-server mib bulkstat transfer-id`, on page 744
- `snmp-server mibs cbqosmib cache`, on page 746
- `snmp-server mibs cbqosmib persist`, on page 748
- `snmp-server mibs eventmib congestion-control`, on page 749
- `snmp-server mibs eventmib packet-loss`, on page 751
- `snmp-server mibs sensormib cache`, on page 753
- `snmp-server mibs subscriber threshold`, on page 754
- `snmp-server mibs subscriber threshold access-if`, on page 756
- `snmp-server notification-log-mib`, on page 758
- `snmp-server packetsize`, on page 760
- `snmp-server queue-length`, on page 761
- `snmp-server target list`, on page 762
- `snmp-server throttle-time`, on page 763
- `snmp-server timeouts subagent`, on page 764
- `snmp-server timeouts duplicate`, on page 765
- `snmp-server trap authentication vrf disable`, on page 766
- `snmp-server trap link ietf`, on page 767
- `snmp-server trap throttle-time`, on page 768
- `snmp-server traps`, on page 769
- `snmp-server traps bgp`, on page 776
- `snmp-server traps frequency synchronization`, on page 778
- `snmp-server traps mpls l3vpn`, on page 779
- `snmp-server traps ospf errors`, on page 781
- `snmp-server traps ospf lsa`, on page 783
- `snmp-server traps ospf retransmit`, on page 785
- `snmp-server traps ospf state-change`, on page 787
- `snmp-server traps ospfv3 errors`, on page 789
- `snmp-server traps ospfv3 state-change`, on page 791
- `snmp-server traps pim interface-state-change`, on page 793
- `snmp-server traps pim invalid-message-received`, on page 795
- `snmp-server traps pim neighbor-change`, on page 797
- `snmp-server traps pim rp-mapping-change`, on page 799
- `snmp-server traps rsvp`, on page 801
- `snmp-server traps selective-vrf-download role-change`, on page 802
- `snmp-server traps snmp`, on page 803
- `snmp-server traps syslog`, on page 805
- `snmp-server trap-source`, on page 806
- `snmp-server traps subscriber session-aggregation`, on page 808
- `snmp-server trap-timeout`, on page 809

- [snmp-server user](#), on page 811
- [snmp-server view](#), on page 814
- [snmp-server vrf](#), on page 816
- [transfer-interval](#), on page 818
- [url](#), on page 820



## add (bulkstat object)

To add a MIB object to a Simple Network Management Protocol (SNMP) bulk statistics object list, use the **add** command in bulk statistics object list configuration mode. To remove a MIB object from an SNMP bulk statistics object list, use the **no add** form of this command.

```
add {object-nameOID}
no add {object-nameOID}
```

### Syntax Description

*object-name* Name of the MIB object to add to the list. Object names are limited to those with mappings shown in the **show snmp mib object-name** command.

*OID* Object identifier (OID) of the MIB object to add to the list.

### Command Default

No MIB objects are configured for an object list.

### Command Modes

Bulk statistics object list configuration

### Command History

Release	Modification
Release 4.2.0	This command was introduced.

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

All object names and OIDs in a single object list should belong to the same MIB index, but the objects need not belong to the same MIB table. For example, it is possible to group ifInoctets and a CISCO-IF-EXTENSION-MIB object in the same schema because the containing tables are indexed by the ifIndex (in the IF-MIB).

The **add** command should be repeated as necessary until all MIB objects have been added to the object list.

### Task ID

Task ID	Operation
snmp	read, write

The following example shows how to add various MIB objects to an object list.

```
RP/0/RSP0/CPU0:router(config-bulk-objects)# add 1.3.6.1.2.1.2.2.1.11
RP/0/RSP0/CPU0:router(config-bulk-objects)# add ifAdminStatus
RP/0/RSP0/CPU0:router(config-bulk-objects)# add ifDescr
```

### Related Topics

[show snmp mib](#), on page 667

# buffer-size

To configure a maximum buffer size for the transfer of bulk statistics files, use the **buffer-size** command in bulk statistics transfer configuration mode. To remove a previously configured buffer size from the configuration, use the **no** form of this command.

**buffer-size** *bytes*  
**no buffer-size** [*bytes*]

<b>Syntax Description</b>	<i>bytes</i> Size of the bulk statistics transfer buffer, in bytes. The valid range is from 1024 to 2147483647. The default is 2048.
---------------------------	--------------------------------------------------------------------------------------------------------------------------------------

<b>Command Default</b>	The default bulk statistics transfer buffer is 2048 bytes.
------------------------	------------------------------------------------------------

<b>Command Modes</b>	Bulk statistics transfer configuration
----------------------	----------------------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 4.2.0	This command was introduced.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

A configured buffer size limit is available primarily as a safety feature. Normal bulk statistics files should not generally meet or exceed the default value while being transferred.

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	snmp	read, write

This example shows how to set the buffer size to 1024 bytes:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# snmp-server mib bulkstat transfer bulkstat1
RP/0/RSP0/CPU0:router(config-bulk-tr)# buffer-size 1024
```

# clear snmp counters

To clear the Simple Network Management Protocol (SNMP) packet statistics shown by the **show snmp** command, use the **clear snmp counters** command in EXEC mode.

**clear snmp counters**

**Syntax Description** This command has no keywords or arguments.

**Command Default** None

**Command Modes** EXEC mode

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **clear snmp counters** command provides the ability to clear all SNMP counters used in the **show snmp** command without restarting any processes.

Task ID	Task ID	Operations
	snmp	read, write

The following example shows how to clear the SNMP counters:

```
RP/0/RSP0/CPU0:router# clear snmp counters
```

## Related Topics

[show snmp](#), on page 651

## enable (bulkstat)

To begin the bulk statistics data collection and transfer process for a specific bulk statistics configuration, use the **enable** command in bulk statistics transfer configuration mode. To disable the bulk statistics data collection and transfer process for a specific bulk statistics configuration, use the **no** form of this command.

**enable**  
**no enable**

<b>Syntax Description</b>	This command has no keywords or arguments.
---------------------------	--------------------------------------------

<b>Command Default</b>	Bulk statistics transfer is disabled.
------------------------	---------------------------------------

<b>Command Modes</b>	Bulk statistics transfer configuration
----------------------	----------------------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 4.2.0	This command was introduced.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

Specific bulk statistics configurations are identified with a name, as specified in the **snmp-server mib bulkstat transfer-id** command. The **enable** command begins the periodic MIB data collection and transfer process.

Collection (and subsequent file transfer) starts only if this command is used. Conversely, the **no enable** command stops the collection process. Subsequently, issuing the **enable** command starts the operations again.

Each time the collection process is started using the **enable** command, data is collected into a new bulk statistics file. When the **no enable** command is used, the transfer process for any collected data immediately begins (in other words, the existing bulk statistics file are transferred to the specified management station).

To successfully enable a bulk statistics configuration, at least one schema with a non-zero number of objects must be configured.

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	snmp	read, write

The following example shows the bulk statistics transfer configuration named bulkstat1 as enabled:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# snmp-server mib bulkstat transfer bulkstat1
RP/0/RSP0/CPU0:router(config-bulk-tr)# schema ATM2/0-IFMIB
RP/0/RSP0/CPU0:router(config-bulk-tr)# url primary ftp://user:pswrd@host/folder/bulkstat1
RP/0/RSP0/CPU0:router(config-bulk-tr)# enable
RP/0/RSP0/CPU0:router(config-bulk-tr)# exit
```

**Related Topics**

[show snmp mib bulkstat transfer](#), on page 670

[snmp-server mib bulkstat transfer-id](#), on page 744

## format (bulkstat)

To specify the format to be used for the bulk statistics data file, use the **format** command in bulk statistics transfer configuration mode. To disable a previously configured format specification and return to the default, use the **no** form of this command.

```
format {bulkBinary | bulkASCII | schemaASCII}
no format [{bulkBinary | bulkASCII | schemaASCII}]
```

Syntax Description	
<b>bulkBinary</b>	Binary format.
<b>bulkASCII</b>	ASCII format.
<b>schemaASCII</b>	A human-readable ASCII format that contains additional bulk statistics schema tags. This is the default.

**Command Default** The default bulk statistics transfer format is schemaASCII

**Command Modes** Bulk statistics transfer configuration

Command History	Release	Modification
	Release 4.2.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The bulk statistics data file (VFile) contains two types of fields: tags and data. Tags are used to set off data to distinguish fields of the file. All other information is in data fields.

Transfers can only be performed using schemaASCII format.

For each transfer/schema pair there is a header with tags for each object collected, followed by the collected data. For example, if the transfer name is T1 and the schemas in it are S1 (which collects ifInOctets and ifOutOctets) and S2 (which collects ifInUcastPkts and ifInDiscards). Then the output file looks like this:

```
Schema-def cempt1.cempWild "%u, %s, %s, %d" Epochtime instanceoid
1.3.6.1.4.1.9.9.221.1.1.1.1.3 1.3.6.1.4.1.9.9.221.1.1.1.1.2
cempt1.cempWild: 1339491515, 8695772.1, processor, 2
cempt1.cempWild: 1339491515, 8695772.2, reserved, 11
cempt1.cempWild: 1339491515, 8695772.3, image, 12
cempt1.cempWild: 1339491575, 8695772.1, processor, 2
cempt1.cempWild: 1339491575, 8695772.2, reserved, 11
cempt1.cempWild: 1339491575, 8695772.3, image, 12
Schema-def cempt1.cempRepeat "%u, %s, %s, %d" Epochtime instanceoid
1.3.6.1.4.1.9.9.221.1.1.1.1.3 1.3.6.1.4.1.9.9.221.1.1.1.1.2
cempt1.cempRepeat: 1339491515, 8695772.1, processor, 2
cempt1.cempRepeat: 1339491515, 8695772.2, reserved, 11
cempt1.cempRepeat: 1339491515, 8695772.3, image, 12
cempt1.cempRepeat: 1339491515, 26932192.1, processor, 2
cempt1.cempRepeat: 1339491515, 26932192.2, reserved, 11
cempt1.cempRepeat: 1339491515, 26932192.3, image, 12
```

```

cempt1.cempRepeat: 1339491515, 35271015.1, processor, 2
cempt1.cempRepeat: 1339491515, 35271015.2, reserved, 11
cempt1.cempRepeat: 1339491515, 35271015.3, image, 12
cempt1.cempRepeat: 1339491515, 36631989.1, processor, 2
cempt1.cempRepeat: 1339491515, 36631989.2, reserved, 11
cempt1.cempRepeat: 1339491515, 36631989.3, image, 12
cempt1.cempRepeat: 1339491515, 52690955.1, processor, 2
cempt1.cempRepeat: 1339491515, 52690955.2, reserved, 11
cempt1.cempRepeat: 1339491515, 52690955.3, image, 12

```

Task ID	Task ID	Operation
	snmp	read, write

This example shows how to specify the data format:

```

RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# snmp-server mib bulkstat transfer bulkstat1
RP/0/RSP0/CPU0:router(config-bulk-tr)# format schemaASCII

```

### Related Topics

- [show snmp mib bulkstat transfer](#), on page 670
- [snmp-server mib bulkstat transfer-id](#), on page 744

# index persistence

To enable index persistence on an Simple Network Management Protocol (SNMP) interface, use the **index persistence** command in SNMP interface configuration mode. To restore the default conditions with respect to this command, use the **no** form of this command.

**index persistence**  
**no index persistence**

**Syntax Description** This command has no keywords or arguments.

**Command Default** Index persistence is disabled.

**Command Modes** SNMP interface configuration

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **index persistence** command to enable ifIndex persistence for individual entries (corresponding to individual interfaces) in the ifIndex table of the IF-MIB. IfIndex persistence retains the mapping between the ifName object values and the ifIndex object values (generated from the IF-MIB) across reboots, allowing for consistent identification of specific interfaces using SNMP.

Task ID	Task ID	Operations
	snmp	read, write

The following example shows how to assign ifIndex persistence on interface 0/0/1/0:

```
RP/0/RSP0/CPU0:router(config)# snmp-server interface tengige 0/0/1/0
RP/0/RSP0/CPU0:router(config-snmp-if)# index persistence
```

## Related Topics

- [show snmp interface](#), on page 662
- [snmp-server engineid local](#), on page 716
- [snmp-server ifindex persist](#), on page 726
- [snmp-server interface](#), on page 732



## instance (bulkstat schema)

To configure the MIB object instances to be used in a Simple Network Management Protocol (SNMP) bulk statistics schema, use the **instance** command in bulk statistics configuration mode. To remove the instance definition, use the **no** form of this command.

```
instance {exact | wild } {interface interface-id [sub-if] | oid oid}
no instance
```

Syntax Description		
<b>exact</b>		Specifies that the specified interface or object identifier (OID), when appended to the object list, is the complete OID to be used in this schema.
<b>wild</b>		Specifies that all instances that fall within the the specified OID or interface are included in this schema.
<b>interface</b> <i>interface-id</i>		Specifies an interface to be used to define the schema instance.
[ <b>sub-if</b> ]		(Optional) Specifies that the object instances are polled for all subinterfaces of the specified interface in addition to the object instances for the main interface.
<b>oid</b> <i>oid</i>		Specifies an OID to be used to define the schema instance.

**Command Default** No instances are configured.

**Command Modes** Bulk statistics schema configuration

Command History	Release	Modification
	Release 4.2.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **instance** command specifies the instance information for objects in the schema being configured. The specific instances of MIB objects for which data is collected are determined by appending the value of the instance command to the objects specified in the associated object list. In other words, the schema object-list when combined with the schema instance specifies a complete MIB object identifier.

The **instance exact** command indicates that the specified instance, when appended to the object list, is the complete OID.

The **instance wild** command indicates that all subindices of the specified OID belong to this schema. For example, the command `instance wild oid 1` includes all subindices of the instance, such as 1.1, 1.2 and so on. It does not include other instances that start with the number 1, such as 10 and 11.

Instead of specifying an OID, you can specify a specific interface. The **interface** *interface-id* keyword and argument allow you to specify an interface name and number (for example, gigabitethernet 0/6/5/0) instead of specifying the ifIndex OID for the interface.

The optional **sub-if** keyword, when added after specifying an interface, includes the ifIndexes for all subinterfaces of the interface you specified.

Only one **instance** command can be configured per schema. If multiple **instance** commands are used, the later commands overwrite the earlier ones.

Task ID	Task ID	Operation
	snmp	read, write

The following examples show two different ways to configure an instance.

```
RP/0/RSP0/CPU0:router(config-bulk-sc)# instance wild oid 1
```

```
RP/0/RSP0/CPU0:router(config-bulk-sc)# instance exact interface FastEthernet 0/1.25
```

### Related Topics

[instance range](#), on page 639

[instance repetition](#), on page 640

[snmp-server mib bulkstat schema](#), on page 742

# instance range

To specify a range of instances for objects in a schema, use the **instance** command in bulk statistics schema configuration mode. To remove the configured instance information, use the **no** form of this command.

**instance range start start-oid end end-oid**  
**no instance**

## Syntax Description

**start start-oid** Specifies the first OID value of a range of values.

**end end-oid** Specifies the last OID value of a range of values.

## Command Default

No instances are configured.

## Command Modes

Bulk statistics schema configuration

## Command History

Release	Modification
Release 4.2.0	This command was introduced.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Only one **instance** command can be configured per schema. If multiple **instance** commands are used, the later commands overwrite the earlier ones.

## Task ID

Task ID	Operation
snmp	read, write

The following example shows how to configure a range of instances.

```
RP/0/RSP0/CPU0:router(config-bulk-sc)# instance range start 1 end 2
```

## Related Topics

[instance \(bulkstat schema\)](#), on page 637

[snmp-server mib bulkstat schema](#), on page 742

# instance repetition

To configure bulk statistics data collection to begin at a particular instance of a MIB object and to repeat for a given number of instances, use the **instance repetition** command in bulk statistics schema configuration mode. To delete a previously configured repetition of instances, use the **no** form of this command.

```
instance repetition oid-instance max repeat-number
no instance
```

<b>Syntax Description</b>	<i>oid-instance</i>	Object ID of the instance to be monitored.
	<b>max</b> <i>repeat-number</i>	Specifies the number of times the instance should repeat.

**Command Default** No instance repetition is configured.

**Command Modes** Bulk statistics schema configuration

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 4.2.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **instance repetition** command is used to configure data collection to repeat for a certain number of instances of a MIB object.

Only one **instance** command can be configured per schema. If multiple **instance** commands are used, the later commands overwrite the earlier ones.

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	snmp	read, write

The following example configures 4 repetitions of the OID of value 1.

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# snmp-server mib bulkstat object-list ifmib
RP/0/RSP0/CPU0:router(config-bulk-objects)# add ifOutOctets
RP/0/RSP0/CPU0:router(config-bulk-objects)# add ifInOctets

RP/0/RSP0/CPU0:router(config-bulk-objects)# exit
RP/0/RSP0/CPU0:router(config)# snmp mib-server bulkstat schema IFMIB

RP/0/RSP0/CPU0:router(config-bulk-sc)# object-list ifmib
RP/0/RSP0/CPU0:router(config-bulk-sc)# poll-interval 1
```

```
RP/0/RSP0/CPU0:router(config-bulk-sc)# instance repetition 1 max 4
```

### Related Topics

[instance \(bulkstat schema\)](#), on page 637

[instance range](#), on page 639

[snmp-server mib bulkstat schema](#), on page 742

# notification linkupdown

To enable or disable linkUp and linkDown trap notifications on a Simple Network Management Protocol (SNMP) interface, use the **notification linkupdown** command in SNMP interface configuration mode. To revert to the default setting, use the **no** form of this command.

**notification linkupdown disable**  
**no notification linkupdown disable**

<b>Syntax Description</b>	<b>disable</b>	Disables linkUp and linkDown trap notifications on an SNMP interface.
<b>Syntax Description</b>	This command has no keywords or arguments.	
<b>Command Default</b>	By default, for all main interfaces the linkUp and linkDown trap notifications are enabled; for all subinterfaces they are disabled.	
<b>Command Modes</b>	SNMP interface configuration SNMP interface subset configuration	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.2	This command was introduced.
	Release 3.9.0	This command was supported in the SNMP interface subset configuration mode.
<b>Usage Guidelines</b>	<p>To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.</p> <p>Enabling of linkUp and linkDown notifications is performed globally using the <b>snmp-server traps snmp</b> command. Issue the <b>notification linkupdown</b> command to disable linkUp and linkDown notifications on an interface.</p> <p>Use the <b>no</b> form of this command to enable linkUp and linkDown notifications on an interface, if linkUp and linkDown notifications have been disabled.</p> <p>You can also use the <b>snmp-server interface subset</b> command to enable or disable groups of interfaces.</p>	
<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	snmp	read, write

The following example shows how to disable linkUp and linkDown trap notifications on interface 0/0/1/0:

```
RP/0/RSP0/CPU0:router(config)# snmp-server interface tengige 0/0/1/0
RP/0/RSP0/CPU0:router(config-snmp-if)# notification linkupdown disable
```

### Related Topics

- [show snmp interface](#), on page 662
- [snmp-server engineid local](#), on page 716
- [snmp-server ifindex persist](#), on page 726
- [snmp-server interface](#), on page 732
- [snmp-server interface subset](#), on page 734
- [snmp-server traps snmp](#), on page 803

# object-list

To specify the bulk statistics object list to be used in the bulk statistics schema, use the **object-list** command in bulk statistics schema configuration mode. To remove an object list from the schema, use the **no** form of this command.

**object-list** *list-name*  
**no object-list** [*list-name*]

<b>Syntax Description</b>	<i>list-name</i> Name of a previously configured bulk statistics object list.
---------------------------	-------------------------------------------------------------------------------

<b>Command Default</b>	No bulk statistics object list is specified.
------------------------	----------------------------------------------

<b>Command Modes</b>	Bulk statistics schema configuration
----------------------	--------------------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 4.2.0	This command was introduced.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

This command associates a bulk statistics object list with the schema being configured. The object list should contain a list of MIB objects to be monitored. Only one object list can be specified for each schema. Use the **snmp-server mib bulkstat object-list** command to create an object list.

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	snmp	read, write

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# snmp-server mib bulkstat schema schemal
RP/0/RSP0/CPU0:router(config-bulk-sc)# object-list obj1
```

## Related Topics

- [show snmp mib bulkstat transfer](#), on page 670
- [snmp-server mib bulkstat schema](#), on page 742
- [snmp-server mib bulkstat object-list](#), on page 741



# poll-interval

To configure the polling interval for a bulk statistics schema, use the **poll-interval** command in bulk statistics schema configuration mode. To remove a previously configured polling interval, use the **no** form of this command.

**poll-interval** *minutes*  
**no poll-interval**

<b>Syntax Description</b>	<i>minutes</i> Integer in the range from 1 to 20000 that specifies, in minutes, the polling interval of data for this schema. The default is 5.
---------------------------	-------------------------------------------------------------------------------------------------------------------------------------------------

<b>Command Default</b>	Object instances are polled once every five minutes.
------------------------	------------------------------------------------------

<b>Command Modes</b>	Bulk statistics schema configuration
----------------------	--------------------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 4.2.0	This command was introduced.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

The **poll-interval** command sets how often the MIB instances specified by the schema and associated object list are to be polled. Collected data is stored in the local bulk statistics file for later transfer.

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	snmp	read, write

In this example, the polling interval for bulk statistics collection is set to once every 3 minutes in the schema called GigE2/1-CAR:

```
RP/0/RSP0/CPU0:router# config
RP/0/RSP0/CPU0:router(config)# snmp-server mib bulk schema GigE2/1-CAR
RP/0/RSP0/CPU0:router(config-bulk-sc)# poll-interval 3
```

## Related Topics

[snmp-server mib bulkstat schema](#), on page 742

# retain

To configure the retention interval for bulk statistics files, use the **retain** command in bulk statistics transfer configuration mode. To remove a previously configured retention interval from the configuration, use the **no** form of this command.

**retain** *minutes*

**no retain** [*minutes*]

## Syntax Description

*minutes* Length of time, in minutes, that the local bulk statistics file should be kept in system memory (the retention interval). The valid range is 0 to 20000. The default is 0.

## Command Default

The bulk statistics file retention interval is 0 minutes.

## Command Modes

Bulk statistics transfer configuration

## Command History

Release	Modification
Release 4.2.0	This command was introduced.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **retain** command specifies how long the bulk statistics file should be kept in system memory, in minutes, after the completion of the collection interval and a transmission attempt is made. The default value of zero (0) indicates that the file is deleted immediately from local memory after a successful transfer.

If the **retry** command is used, you should configure a retention interval greater than 0. The interval between retries is the retention interval divided by the retry number. For example, if **retain 10** and **retry 2** are configured, retries are attempted once every 5 minutes. Therefore, if the **retain** command is not configured (retain default is 0), no retries are attempted.



### Note

Once a successful transmission has occurred the bulk file is not retained regardless of the retain time.

## Task ID

Task ID	Operation
snmp	read, write

In the following example, the bulk statistics transfer retention interval is set to 10 minutes:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# snmp-server mib bulkstat transfer bulkstat1
RP/0/RSP0/CPU0:router(config-bulk-tr)# schema ATM2/0-IFMIB
```

```
RP/0/RSP0/CPU0:router(config-bulk-tr)# url primary ftp://user:pswrd@host/folder/bulkstat1
RP/0/RSP0/CPU0:router(config-bulk-tr)# retry 2
RP/0/RSP0/CPU0:router(config-bulk-tr)# retain 10
RP/0/RSP0/CPU0:router(config-bulk-tr)# exit
```

### Related Topics

[retry](#), on page 648

[show snmp mib bulkstat transfer](#), on page 670

[snmp-server mib bulkstat transfer-id](#), on page 744

# retry

To configure the number of retries that should be attempted for a bulk statistics file transfer, use the **retry** command in bulk statistics transfer configuration mode. To return the number of bulk statistics retries to the default, use the **no** form of this command.

**retry** *number*  
**no retry** [*number*]

<b>Syntax Description</b>	<i>number</i> Number of transmission retries. The valid range is from 0 to 100.
---------------------------	---------------------------------------------------------------------------------

<b>Command Default</b>	No retry attempts are made.
------------------------	-----------------------------

<b>Command Modes</b>	Bulk statistics transfer configuration
----------------------	----------------------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 4.2.0	This command was introduced.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

If an attempt to send the bulk statistics file fails, the system can be configured to attempt to send the file again using the **retry** command. One retry includes an attempt first to the primary destination and then, if the transmission fails, to the secondary location; for example, if the retry value is 1, an attempt will be made first to the primary URL, then to the secondary URL, then to the primary URL again, and then to the secondary URL again.

If the **retry** command is used, you should also use the **retain** command to configure a retention interval greater than 0. The interval between retries is the retention interval divided by the retry number. For example, if **retain 10** and **retry 2** are configured, retries are attempted once every 5 minutes. Therefore, if the **retain** command is not configured (or the **retain 0** command is used) no retries are attempted.

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	snmp	read, write

In the following example, the number of retries for the bulk statistics transfer is set to 2:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# snmp-server mib bulkstat transfer bulkstat1
RP/0/RSP0/CPU0:router(config-bulk-tr)# schema ATM2/0-IFMIB
RP/0/RSP0/CPU0:router(config-bulk-tr)# url primary ftp://user:pswrd@host/folder/bulkstat1
RP/0/RSP0/CPU0:router(config-bulk-tr)# retry 2
RP/0/RSP0/CPU0:router(config-bulk-tr)# retain 10
```

```
RP/0/RSP0/CPU0:router(config-bulk-tr)# exit
```

### Related Topics

[retain](#), on page 646

[show snmp mib bulkstat transfer](#), on page 670

[snmp-server mib bulkstat transfer-id](#), on page 744

# schema

To specify the bulk statistics schema to be used in a specific bulk statistics transfer configuration, use the **schema** command in bulk statistics transfer configuration mode. To remove a previously configured schema from a specific bulk statistics transfer configuration, use the **no** form of this command.

**schema** *schema-name*

**no schema** [*schema-name*]

<b>Syntax Description</b>	<i>schema-name</i> Name of a previously configured bulk statistics schema.
---------------------------	----------------------------------------------------------------------------

<b>Command Default</b>	No bulk statistics schema is specified.
------------------------	-----------------------------------------

<b>Command Modes</b>	Bulk statistics transfer configuration
----------------------	----------------------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 4.2.0	This command was introduced.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

The schema must be previously defined using the **snmp-server mib bulkstat schema** command.

Repeat the **schema** command as desired for a specific bulk statistics transfer configuration. Multiple schemas can be associated with a single transfer configuration; all collected data will be in a single bulk statistics data file (VFile).

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	snmp	read, write

This example adds three different schemas to a bulk statistics transfer configuration:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# snmp-server mib bulkstat transfer-id bulkstat1
RP/0/RSP0/CPU0:router(config-bulk-tr)# schema ATM2/0-IFMIB
RP/0/RSP0/CPU0:router(config-bulk-tr)# schema ATM2/0-CAR
RP/0/RSP0/CPU0:router(config-bulk-tr)# schema Ethernet2/1-IFMIB
```

## Related Topics

[show snmp mib bulkstat transfer](#), on page 670

[snmp-server mib bulkstat schema](#), on page 742

# show snmp

To display the status of Simple Network Management Protocol (SNMP) communications, use the **show snmp** command in

EXEC

mode.

**show snmp**

<b>Syntax Description</b>	This command has no keywords or arguments.
---------------------------	--------------------------------------------

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	EXEC
----------------------	------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

Use the `show snmp` command to show counter information for SNMP operations. It also displays the chassis ID string defined with the `snmp-server chassis-id` command.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	snmp	read

This example shows sample output from the `show snmp` command:

```
RP/0/RSP0/CPU0:router# show snmp

Chassis: 01506199
37 SNMP packets input
0 Bad SNMP version errors
4 Unknown community name
0 Illegal operation for community name supplied
0 Encoding errors
24 Number of requested variables
0 Number of altered variables
0 Get-request PDUs
28 Get-next PDUs
0 Set-request PDUs
78 SNMP packets output
0 Too big errors (Maximum packet size 1500)
0 No such name errors
```

```

0 Bad values errors
0 General errors
24 Response PDUs
13 Trap PDUs
SNMP logging: enabled
Logging to 172.25.58.33.162, 0/10, 13 sent, 0 dropped.

```

[Table 61: show snmp Field Descriptions, on page 652](#) describes the significant fields shown in the display.

**Table 61: show snmp Field Descriptions**

Field	Description
Chassis	Chassis ID string.
SNMP packets input	Total number of SNMP packets input.
Bad SNMP version errors	Number of packets with an invalid SNMP version.
Unknown community name	Number of SNMP packets with an unknown community name.
Illegal operation for community name supplied	Number of packets requesting an operation not allowed for that community.
Encoding errors	Number of SNMP packets that were improperly encoded.
Number of requested variables	Number of variables requested by SNMP managers.
Number of altered variables	Number of variables altered by SNMP managers.
Get-request PDUs	Number of get requests received
Get-next PDUs	Number of get-next requests received.
Set-request PDUs	Number of set requests received.
SNMP packets output	Total number of SNMP packets sent by the device.
Too big errors	Number of SNMP packets that were larger than the maximum packet size.
Maximum packet size	Maximum size of SNMP packets.
No such name errors	Number of SNMP requests that specified a MIB object that does not exist.
Bad values errors	Number of SNMP set requests that specified an invalid value for a MIB object.
General errors	Number of SNMP set requests that failed due to some other error. (It is not a noSuchName error, badValue error, or any of the other specific errors.)
Response PDUs	Number of responses sent in reply to requests.



Field	Description
Trap PDUs	Number of SNMP traps sent.
SNMP logging	Enabled or disabled logging.
sent	Number of traps sent.
dropped	Number of traps dropped. Traps are dropped when the trap queue for a destination exceeds the maximum length of the queue, as set by the <b>snmp-server queue-length</b> command.

**Related Topics**

[show snmp mib](#), on page 667

[snmp-server chassis-id](#), on page 705

[snmp-server queue-length](#), on page 761

# show snmp context

To display the enhanced SNMP context mappings, use the **show snmp context** command in EXEC mode.

## show snmp context

**Syntax Description** This command has no keywords or arguments.

**Command Default** None

**Command Modes** EXEC

Command History	Release	Modification
	Release 4.2.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **show snmp context** command to display the protocol instance, topology and VRF mappings associated with an SNMP context.

Task ID	Task ID	Operation
	snmp	read

This example illustrates sample output from the **show snmp context** command:

```
RP/0/RSP0/CPU0:router# show snmp context

Tue Dec 21 03:41:08.065 PST
Context-name Vrf-name Topology-Name Instance-Name Feature
con5 vf5 tp5 in5 OSPF
con6 vf6 tp6 in6 OSPF
con7 vf7 tp7 in7 OSPF
con8 vf8 tp8 in8 OSPF
```

## Related Topics

[snmp-server context mapping](#), on page 712

# show snmp context-mapping

To display the SNMP context mapping table, use the **show snmp context-mapping** command in EXEC mode.

## show snmp context-mapping

**Syntax Description** This command has no keywords or arguments.

**Command Default** None

**Command Modes** EXEC

Command History	Release	Modification
	Release 3.8.0	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The SNMP agent handles queries based on SNMP contexts created by client features. Use the **show snmp context-mapping** command to display the SNMP context mapping table. Each entry in the table includes the name of an SNMP context created by a client instance and the name of the client that created the context.

Task ID	Task ID	Operations
	snmp	read

The following example shows sample output from the **show snmp context-mapping** command:

```
RP/0/RSP0/CPU0:router# show snmp context-mapping

Wed Aug 6 01:42:35.227 UTC
Context-name Feature-name Feature
ControlEthernet0_RP0_CPU0_S0 ControlEthernet0_RP0_CPU0_S0 BRIDGEINST
ControlEthernet0_RP1_CPU0_S0 ControlEthernet0_RP1_CPU0_S0 BRIDGEINST
```

**Table 62: show snmp context-mapping Field Descriptions**

Field	Definition
Context-name	Name of an SNMP context.

**show snmp context-mapping**

<b>Field</b>	<b>Definition</b>
Feature-name	Name of the instance that created the context.
Feature	Name of the client whose instance created the context.

# show snmp engineid

To display the identification of the local Simple Network Management Protocol (SNMP) engine that has been configured on the router, use the **show snmp engineid** command in EXEC mode.

**show snmp engineid**

**Syntax Description** This command has no keywords or arguments.

**Command Default** None

**Command Modes** EXEC mode

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

An *SNMP engine* is a copy of SNMP that can reside on a local device.

Task ID	Task ID	Operations
	snmp	read

The following example shows sample output from the **show snmp engineid** command:

```
RP/0/RSP0/CPU0:router# show snmp engineid
Local SNMP engineID: 00000009020000000C025808
```

## Related Topics

[snmp-server engineid local](#), on page 716

# show snmp group

To display the names of groups on the router, security model, status of the different views, and storage type of each group, use the **show snmp group** command in

EXEC

mode.

## show snmp group

**Syntax Description** This command has no keywords or arguments.

**Command Default** None

**Command Modes** EXEC

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	snmp	read

This example shows sample output from the **show snmp group** command:

```
RP/0/RSP0/CPU0:router# show snmp group

groupname: public security model:snmpv1
readview : vldefault writeview: -
notifyview: vldefault
row status: nonVolatile

groupname: public security model:snmpv2c
readview : vldefault writeview: -
notifyview: vldefault
row status: nonVolatile
```

**Table 63: show snmp group Field Descriptions**

Field	Definition
groupname	Name of the Simple Network Management Protocol (SNMP) group or collection of users that have a common access policy.
readview	String identifying the read view of the group.
security model	Security model used by the group, either v1, v2c, or v3.
writeview	String identifying the write view of the group.
notifyview	String identifying the notify view of the group.
row status	Settings that are set in volatile or temporary memory on the device, or in nonvolatile or persistent memory where settings remain after the device is turned off and on again.

**Related Topics**

[snmp-server group](#), on page 719

# show snmp host

To display the configured Simple Network Management Protocol (SNMP) notification recipient host, User Datagram Protocol (UDP) port number, user, and security model, use the **show snmp host** command in

EXEC

mode.

## show snmp host

**Syntax Description** This command has no keywords or arguments.

**Command Default** None

**Command Modes** EXEC

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task Operations ID
	snmp read

The following example shows sample output from the **show snmp host** command:

```
RP/0/RSP0/CPU0:router# show snmp host

Notification host: 10.50.32.170 udp-port: 2345 type: trap
user: userV3auth security model: v3 auth

Notification host: 10.50.32.170 udp-port: 2345 type: trap
user: userV3noauth security model: v3 noauth

Notification host: 10.50.32.170 udp-port: 2345 type: trap
user: userV3priv security model: v3 priv

Notification host: 10.50.32.170 udp-port: 2345 type: trap
user: userv2c security model: v2c
```



**Table 64: show snmp host Field Descriptions**

<b>Field</b>	<b>Definition</b>
Notification host	Name or IP address of target host.
udp-port	UDP port number to which notifications are sent.
type	Type of notification configured.
user	Security level of the user.
security model	Version of SNMP used to send the trap, either v1, v2c, or v3.

# show snmp interface

To display the interface index identification numbers (ifIndex values) for all the interfaces or a specified interface, use the **show snmp interface** command in the appropriate mode.

**show snmp interface** [*type interface-path-id ifindex*]

<b>Syntax Description</b>	<i>type</i>	(Optional) Interface type. For more information, use the question mark (?) online help function.
	<i>interface-path-id</i>	(Optional) Physical interface or virtual interface.  <b>Note</b> Use the <b>show interfaces</b> command to see a list of all interfaces currently configured on the router.  For more information about the syntax for the router, use the question mark (?) online help function.
	<b>ifindex</b>	(Optional) Displays the ifIndex value for the specified interface.

**Command Default** Enter the **show snmp interface** command without keywords or arguments to display the ifIndex value for all interfaces.

**Command Modes** EXEC

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	snmp	read

This example displays the ifIndex value for a specific interface:

```
RP/0/RSP0/CPU0:router# show snmp interface pos 0/1/0/1 ifindex
ifName : POS0/1/0/1 ifIndex : 12
```

The following example displays the ifIndex value for all interfaces:

```
RP/0/RSP0/CPU0:router# show snmp interface

ifName : Loopback0 ifIndex : 1
ifName : POS0/1/0/1 ifIndex : 12
ifName : POS0/1/4/2 ifIndex : 14
ifName : POS0/1/4/3 ifIndex : 15
ifName : POS0/6/0/1 ifIndex : 2
ifName : POS0/6/4/4 ifIndex : 18
ifName : POS0/6/4/5 ifIndex : 19
ifName : POS0/6/4/6 ifIndex : 20
ifName : Bundle-POS24 ifIndex : 4
ifName : Bundle-Ether28 ifIndex : 5
ifName : Bundle-Ether28.1 ifIndex : 7
ifName : Bundle-Ether28.2 ifIndex : 8
ifName : Bundle-Ether28.3 ifIndex : 9
ifName : MgmtEth0/RP0/CPU0/0 ifIndex : 6
ifName : MgmtEth0/RP1/CPU0/0 ifIndex : 10
ifName : GigabitEthernet0/1/5/0 ifIndex : 11
ifName : GigabitEthernet0/1/5/1 ifIndex : 13
ifName : GigabitEthernet0/1/5/2 ifIndex : 3
ifName : GigabitEthernet0/6/5/1 ifIndex : 16
ifName : GigabitEthernet0/6/5/2 ifIndex : 17
ifName : GigabitEthernet0/6/5/7 ifIndex : 21
```

**Table 65: show snmp interface Field Descriptions**

Field	Definition
ifName	Interface name.
ifIndex	ifIndex value.

### Related Topics

[snmp-server ifindex persist](#), on page 726

[snmp-server interface](#), on page 732

## show snmp interface notification

To display the linkUp and linkDown notification status for a subset of interfaces, use the **show snmp interface notification** command in EXEC mode.

```
show snmp interface notification {subset subset-number | regular-expression expression | [type
interface-path-id]}
```

### Syntax Description

<b>subset</b> <i>subset-number</i>	Specifies the identifier of the interface subset. The subset-number argument is configured using the <b>snmp-server interface subset</b> command.
<b>regular-expression</b> <i>expression</i>	Specifies a subset of interfaces matching a regular expression, for which to display information.
<i>type</i>	(Optional) Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	(Optional) Physical interface or virtual interface.  <b>Note</b> Use the <b>show interfaces</b> command to see a list of all interfaces currently configured on the router.  For more information about the syntax for the router, use the question mark ( ? ) online help function.

### Command Default

None

### Command Modes

EXEC

### Command History

Release	Modification
Release 3.9.0	This command was introduced.

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Regular expressions have two constraints:

- Regular expressions must always be entered within double quotes to ensure that the CLI interprets each character correctly.
- All characters that are part of a regular expression are considered regular characters with no special meaning. In order to enter special characters, such as "\" or "?," they must be preceded by the backslash character "\." For example, to enter the regular expression ([A-Z][A-Z0-9]*)\b[^\>]*>(.*)<\1, you would enter ([A-Z][A-Z0-9]*)\b[^\>]*>(.*)<\1.

Refer to the *Understanding Regular Expressions, Special Characters, and Patterns* module in *Cisco ASR 9000 Series Aggregation Services Router Getting Started Guide* for more information regarding regular expressions.

When using the **subset** or **regular-expression** keywords, the actual display might not match the configuration if there are higher priority *subset-number* values that actually apply to the interface. This can happen for a set of interfaces that are included in two or more configured regular expressions or where an individual interface configuration is enabled.

Task ID	Task ID	Operation
	snmp	read

The following example illustrates how to display linkUp and linkDown notification status for a subset of interfaces identified by a specific *subset-number* :

```
RP/0/RSP0/CPU0:router# show snmp interface notification subset 3
```

This example illustrates how to display linkUp and linkDown notification status for a subset of interfaces identified by a regular expression:

```
RP/0/RSP0/CPU0:router# show snmp interface notification regular-expression
"^Gig[a-zA-Z]+[0-9/]+\."
```

# show snmp interface regular-expression

To display interface names and indices assigned to interfaces that match a regular expression, use the **show snmp interface regular-expression** command in EXEC mode.

**show snmp interface regular-expression** *expression*

<b>Syntax Description</b>	<i>expression</i> Specifies a subset of interfaces matching a regular expression, for which to display information.
---------------------------	---------------------------------------------------------------------------------------------------------------------

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	EXEC
----------------------	------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.9.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

All characters that are part of a regular expression are considered regular characters with no special meaning. In order to enter special characters, such as "\" or "?," they must be preceded by the backslash character "\". For example, to enter the regular expression ([A-Z][A-Z0-9]*)\b[^\>]*>(.*)<\1, you would enter ([A-Z][A-Z0-9]*)\b[^\>]*>(.*)<\1.

Refer to the *Understanding Regular Expressions, Special Characters, and Patterns* module in *Cisco ASR 9000 Series Aggregation Services Router Getting Started Guide* for more information regarding regular expressions.

<b>Task ID</b>	<b>Task</b>	<b>Operation</b>
		snmp

This example illustrates how to display information for interfaces that match the given regular expression:

```
RP/0/RSP0/CPU0:router# show snmp interface regular-expression "^Gig[a-zA-Z]+[0-9/]+\."
```

## Related Topics

[snmp-server interface subset](#), on page 734

# show snmp mib

To display a list of MIB module object identifiers (OIDs) registered on the system, use the **show snmp mib** command in

EXEC

mode.

**show snmp mib** [*{object-name | dll}*]

<b>Syntax Description</b>	<i>object-name</i> (Optional) Specific MIB object identifier or object name.
	<b>dll</b> (Optional) Displays a list of all MIB DLL filenames and the OID supported by each DLL filename on the system.

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	EXEC
----------------------	------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.2	This command was introduced.
	Release 3.9.0	The <b>detailed</b> keyword was not supported.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **show snmp mib** command to display a list of the MIB module instance identifiers registered on the system.

Although the **show snmp mib** command can be used to display a list of MIB OIDs registered on the system, the use of a Network Management System (NMS) application is the recommended alternative for gathering this information.

The **show snmp mib** command is intended only for network managers who are familiar with Abstract Syntax Notation One (ASN.1) syntax and the Structure of Management Information (SMI) of Open Systems Interconnection (OSI) Reference Model.

SNMP management information is viewed as a collection of managed objects residing in a virtual information store termed the *MIB*. Collections of related objects are defined in MIB modules. These modules are written using a subset of ASN.1 termed the *SMI*.

The definitions for the OIDs displayed by this command can be found in the relevant RFCs and MIB modules. For example, RFC 1907 defines the system.x, sysOREntry.x, snmp.x, and snmpTrap.x OIDs, and this information is supplemented by the extensions defined in the CISCO-SYSTEM-MIB.

Use the **detailed** keyword to display a list of the MIB module instance identifiers registered on the system. The output displays additional details, such as DLL and configuration information.

Use the **dll** keyword to display a list of the MIB modules loaded into the agent. This command can be used to find the supported MIBs.



**Note** This command produces a high volume of output if SNMP is enabled on the system. To exit from a --More-- prompt, press **Ctrl-Z**.

---

**Task ID**


---

**Task ID    Operations**


---

 snmp    read
 

---

The following example shows sample output from the **show snmp mib** command:

```
RP/0/RSP0/CPU0:router# show snmp mib

1.3.6.1.2.1.47.1.1.1.1.2
1.3.6.1.2.1.47.1.1.1.1.3
1.3.6.1.2.1.47.1.1.1.1.4
1.3.6.1.2.1.47.1.1.1.1.5
1.3.6.1.2.1.47.1.1.1.1.6
1.3.6.1.2.1.47.1.1.1.1.7
1.3.6.1.2.1.47.1.1.1.1.8
1.3.6.1.2.1.47.1.1.1.1.9
1.3.6.1.2.1.47.1.1.1.1.10
1.3.6.1.2.1.47.1.1.1.1.11
1.3.6.1.2.1.47.1.1.1.1.12
1.3.6.1.2.1.47.1.1.1.1.13
1.3.6.1.2.1.47.1.1.1.1.14
1.3.6.1.2.1.47.1.1.1.1.15
1.3.6.1.2.1.47.1.1.1.1.16
1.3.6.1.2.1.47.1.2.1.1.2
1.3.6.1.2.1.47.1.2.1.1.3
1.3.6.1.2.1.47.1.2.1.1.4
1.3.6.1.2.1.47.1.2.1.1.5
1.3.6.1.2.1.47.1.2.1.1.6
1.3.6.1.2.1.47.1.2.1.1.7
1.3.6.1.2.1.47.1.2.1.1.8
1.3.6.1.2.1.47.1.3.1.1.1
--More--
```

This example shows sample output from the **show snmp mib** command with the **detailed** keyword:

```
RP/0/RSP0/CPU0:router# show snmp mib detailed

Entitymib:dll=/pkg/lib/mib/libEntitymib.dll, config=Entity.mib, loaded
1.3.6.1.2.1.47.1.1.1.1.2
1.3.6.1.2.1.47.1.1.1.1.3
1.3.6.1.2.1.47.1.1.1.1.4
1.3.6.1.2.1.47.1.1.1.1.5
1.3.6.1.2.1.47.1.1.1.1.6
1.3.6.1.2.1.47.1.1.1.1.7
1.3.6.1.2.1.47.1.1.1.1.8
1.3.6.1.2.1.47.1.1.1.1.9
1.3.6.1.2.1.47.1.1.1.1.10
1.3.6.1.2.1.47.1.1.1.1.11
```



```

1.3.6.1.2.1.47.1.1.1.1.12
1.3.6.1.2.1.47.1.1.1.1.13
1.3.6.1.2.1.47.1.1.1.1.14
1.3.6.1.2.1.47.1.1.1.1.15
1.3.6.1.2.1.47.1.1.1.1.16
1.3.6.1.2.1.47.1.2.1.1.2
1.3.6.1.2.1.47.1.2.1.1.3
1.3.6.1.2.1.47.1.2.1.1.4
1.3.6.1.2.1.47.1.2.1.1.5
1.3.6.1.2.1.47.1.2.1.1.6
1.3.6.1.2.1.47.1.2.1.1.7
1.3.6.1.2.1.47.1.2.1.1.8
--More--

```

This example shows sample output from the **show snmp mib** command with the **dll** keyword:

```
RP/0/RSP0/CPU0:router# show snmp mib dll
```

```

Entitymib:dll=/pkg/lib/mib/libEntitymib.dll, config=Entity.mib, loaded
bgp4mib:dll=/pkg/lib/mib/libbgp4mib.dll, config=bgp4.mib, loaded
cdpmib:dll=/pkg/lib/mib/libcdpmib.dll, config=cdp.mib, loaded
ciscoprocessmib:dll=/pkg/lib/mib/libciscoprocessmib.dll,
 config=ciscoprocess.mib, loaded
ciscosyslogmib:dll=/pkg/lib/mib/libciscosyslogmib.dll,
 config=ciscosyslog.mib, loaded
ciscosystemmib:dll=/pkg/lib/mib/libciscosystemmib.dll,
 config=ciscosystem.mib, loaded
confcopymib:dll=/pkg/lib/mib/libconfcopymib.dll, config=confcopy.mib,
 loaded
configmanmib:dll=/pkg/lib/mib/libconfigmanmib.dll, config=configman.mib,
 loaded
dot3admib:dll=/pkg/lib/mib/libdot3admib.dll, config=dot3ad.mib,
 loaded
fabhfrmib:dll=/pkg/lib/mib/libfabhfrmib.dll, config=fabhfr.mib,
 loaded
fabmcastapplmib:dll=/pkg/lib/mib/libfabmcastapplmib.dll,
 config=fabmcastappl.mib, loaded
fabmcastmib:dll=/pkg/lib/mib/libfabmcastmib.dll, config=fabmcast.mib,
 loaded
flashmib:dll=/pkg/lib/mib/libflashmib.dll, config=flash.mib,
 loaded
hsrpmib:dll=/pkg/lib/mib/libhsrpmib.dll, config=hsrp.mib, loaded
icmpmib:dll=/pkg/lib/mib/libicmpmib.dll, config=icmp.mib, loaded
ifmib:dll=/pkg/lib/mib/libifmib.dll, config=if.mib, loaded
ipmib:dll=/pkg/lib/mib/libipmib.dll, config=ip.mib, loaded
mempoolmib:dll=/pkg/lib/mib/libmempoolmib.dll, config=mempool.mib,
 loaded
mplsldpmib:dll=/pkg/lib/mib/libmplsldpmib.dll, config=mplsldp.mib,
 loaded
.
.
.

```

### Related Topics

[show snmp](#), on page 651

# show snmp mib bulkstat transfer

To display completed local bulk statistics files, use the **show snmp mib bulkstat transfer** command in EXEC mode.

**show snmp mib bulkstat transfer** [*transfer-name*]

<b>Syntax Description</b>	<i>transfer-name</i> Specifies a named transfer file to display.
---------------------------	------------------------------------------------------------------

<b>Syntax Description</b>	This command has no keywords or arguments.
---------------------------	--------------------------------------------

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	EXEC
----------------------	------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 4.2.0	This command was introduced.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

The **show snmp mib bulkstat transfer** command lists all bulk statistics virtual files (VFiles) on the system that have finished collecting data. (Data files that are not complete are not displayed.)

The output lists all of the completed local bulk statistics files, the remaining time left before the bulk statistics file is deleted (remaining retention period), and the state of the bulk statistics file. The state of the bulk statistics file should be Retry. Retry indicates that one or more transfer attempts have failed and that the file transfer will be attempted again. The number of retry attempts remaining is displayed in parenthesis. After the successful retry or retry attempts, the local files created by the MIB process in the router are deleted and data collection begins again.

To display only the status of a named transfer (as opposed to all configured transfers), specify the name of the transfer in the *transfer-name* argument. The *transfer-name* argument names a file which is supposed to be created even before the retries.

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	snmp	read

```
RP/0/RSP0/CPU0:router# show snmp mib bulkstat transfer
```

```
Transfer Name : ifmib
Retained files
```

```
File Name : Time Left (in seconds) :STATE

```

```
ifmib_Router_020421_100554683 : 173 : Retry (2 Retry attempt(s) Left)
```

# show snmp request duplicates

To display the number of duplicate protocol data unit (PDU) requests dropped by the SNMP agent, use the **show snmp request duplicates** command in

EXEC

mode.

## show snmp request duplicates

<b>Syntax Description</b>	This command has no keywords or arguments.
---------------------------	--------------------------------------------

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	EXEC
----------------------	------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 4.0.0	This command was introduced.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	snmp	read

This example illustrates sample output from the **show snmp request duplicates** command:

```
RP/0/RSP0/CPU0:router# show snmp request duplicates
```

```
No of Duplicate request received/Dropped : 0
```

# show snmp request incoming-queue detail

To show the details of the queue of incoming SNMP requests, use the **show snmp request incoming-queue detail** command in EXEC mode.

## show snmp request incoming-queue detail

This command has no keywords or arguments.

**Command Modes** Global configuration

Command History	Release	Modification
	Release 5.2.2	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

This command shows an output for maximum of 15 queues and an additional general queue. The entry will be deleted when any queue is not polled for 30 minutes.

This command shows these details:

Field	Description
NMS Address	Source address (IPv4 or IPv6) of network management system (NMS) queue. Specifies the NMS packet requests in this queue.
Q Depth	Number of packets to be processed in the queue.
Deque Count	Number of packets that are processed.
Priority	Priority of queue with packets to be processed. The priority ranges from 1 to 5, 1 indicates low priority and 5 indicates high priority.
Enque time	Time stamp of last request in the queue.

Task ID	Task ID	Operations
	snmp	read, write

```
RP/0/RSP0/CPU0:router# show snmp request incoming-queue detail
Wed Mar 12 05:16:59.505 PDT
```

```
NMS ADDRESS Q Depth Deque count Priority Enque time
```

## show snmp request incoming-queue detail

```

4.5.6.7 0 1223 1 Wed Mar 12
05:16:25

1.2.3.4 0 1193 1 Wed Mar 12
05:15:06

General Q 0 0 0 Wed Mar 12
05:14:49

```

```
NMS ADDRESS : 4:5:6::7
```

Q Depth	Deque count	Priority	Enque time
0	1220	1	Wed Mar 12 05:16:02

```
NMS ADDRESS : 1:2:3::4
```

Q Depth	Deque count	Priority	Enque time
0	1221	1	Wed Mar 12 05:15:37

# show snmp request type summary

To show the types of requests sent from each network management system (NMS), use the **show snmp request type summary** command in EXEC mode.

## show snmp request type summary

This command has no keywords or arguments.

**Command Modes** Global configuration

Command History	Release	Modification
	Release 5.2.2	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **show snmp request type summary** command shows these details:

Field	Description
NMS address	IP address of the NMS that sent the request.
Get	Number of requests of Get type.
Getnext	Number of requests of Getnext type.
Getbulk	Number of requests of Getbulk type.
Set	Number of requests of Set type.
Test	Number of requests of Test type that is part of Set request.

Task ID	Task ID	Operations
	snmp	read, write

```
RP/0/RSP0/CPU0:router# show snmp request type summary
Wed Mar 12 05:17:14.643 PDT
NMS Address Get GetNext GetBulk Set Test
1.2.3.4 0 1254 0 0 0
4.5.6.7 0 5101 0 0 0

NMS Address : 1:2:3::4
Get GetNext GetBulk Set Test
0 2536 0 0 0
```

## show snmp request type summary

```
NMS Address : 4:5:6::7
Get GetNext GetBulk Set Test
0 3817 0 0 0
```



# show snmp request type detail

To shows the group that is polled frequently and from which network management system (NMS), use the **show snmp request type detail** command in EXEC mode.

## show snmp request type detail

This command has no keywords or arguments.

**Command Modes** Global configuration

Command History	Release	Modification
	Release 5.2.2	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **show snmp request type detail** command shows these details:

Field	Description
NMS Address	Address of Network Management Station from which the request is received.
Request	Number of requests from NMS.
SNMPD	Number of requests to snmpd.
Interface	Number of requests to mibd_interface.
Entity	Number of requests to mibd_entity.
Route	Number of requests to mibd_route.
Infra	Number of requests to mibd_infra.

Task ID	Task ID	Operations
	snmp	read, write

```
RP/0/RSP0/CPU0:router# show snmp request type detail
Wed Mar 12 05:17:34.838 PDT
NMS Address Request AGENT INTERFACE ENTITY ROUTE INFRA
1.2.3.4 1193 52 742 70 267 123
4.5.6.7 1223 52 742 100 267 123
1:2:3::4 1221 52 742 100 265 123
4:5:6::7 1220 52 742 100 265 122
```

## show snmp request drop summary

To show the summary of overall packet drop, use the **show snmp request drop summary** command in EXEC mode.

### show snmp request drop summary

This command has no keywords or arguments.

#### Command Modes

Global configuration

#### Command History

Release	Modification
Release 5.2.2	This command was introduced.

#### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **show snmp request drop summary** command shows these details:

Field	Description
NMS Address	Address of network management station from which request is received.
IN Q	Number of packets dropped in incoming queue as the dropped packets are not processed more than 10 seconds.
Encode	Number of packets dropped because of encode errors.
Duplicate	Number of requests dropped with duplicate request feature.
Stack	Numbers of requests are dropped in stack.
AIPC	Number of packets dropped at AIPC module.
Overload	Number of packets dropped because of overload control notification.
Timeout	Number of packets are dropped because of slow response from MIB.
Internal	Number of packets dropped because of internal failures.

Task ID	Task ID	Operations
	snmp	read, write

```
RP/0/RSP0/CPU0:router# show snmp request drop summary
```

```
 Fri Mar 14 05:32:31.732 PDT
```

NMS Address	INQ	Encode	Duplicate	Stack	AIPC	Overload	Timeout	Internal
1.2.3.4	0	0	0	0	0	218	0	0

```
NMS Address : 1:2:3::4
```

INQ	Encode	Duplicate	Stack	AIPC	Overload	Timeout	Internal
0	0	0	0	0	109	0	0

## show snmp request overload stats

To show the number of packets dropped due to overload feature, use the **show snmp request overload stats** command in EXEC mode.

### show snmp request overload stats

This command has no keywords or arguments.

**Command Modes** Global configuration

Command History	Release	Modification
	Release 5.2.2	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

This command displays the latest 100 entries.

The show snmp request overload stats command shows these details:

Field	Description
StartTime	Time when overload control notification is received.
InQInDrop	Number of packet drops before inserting in incoming queue.
InQOutDrop	Number of packets dropped from incoming queue.
EndTime	Time when overload control notification ends.

Task ID	Task ID	Operations
	snmp	read, write

```
RP/0/RSP0/CPU0:router# show snmp request overload stats
```

```
Thu Mar 13 07:00:45.575 UTC
```

StartTime	InQInDrop	InQOutDrop	EndTime
Thu Mar 13 07:00:28	1	0	Thu Mar 13 07:00:38

# show snmp statistics oid group

To show the statistics of object ID (OID), use the **show snmp statistics oid group** command in EXEC mode.

```
show snmp statistics oid group {interface | infra | route | entity}
```

Syntax Description	
<b>interface</b>	mibd_interface sub-agent process
<b>infra</b>	mibd_infra sub-agent process
<b>route</b>	mibd_route sub-agent process
<b>entity</b>	mibd_entity sub-agent process

**Command Modes** Global configuration

Command History	Release	Modification
	Release 5.2.2	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The latest 500 entries for each group is displayed and a maximum of 2000 entries is displayed for four groups.

The **show snmp statistics oid group** command shows these details:

Field	Description
SerNum	Unique serial number for each request processing in sub-agents.
Type	Request type.
NumObj	Number of OIDs processing in this request.
MIBMGR-IN	Time stamp of request received from AIPC.
PDU-IN	Time stamp of request sent to MIB for processing. This will be offset in milli seconds from MIBMGR_IN time stamp.
FROM-MIB	Time stamp of response sent from MIB after processing. This will be offset in milli seconds from MIBMGR_IN time stamp.
PDU-OUT	Time stamp of response sent to SNMP through AIPC. This will be offset in milli seconds from MIBMGR_IN.
OID	OID info processing this request.

## show snmp statistics oid group

Field	Description
MIB-IN	Time stamp of the request sent to MIB for each OID.
MIB-OUT	Time stamp of response sent from MIB after processing. This will be offset in milli seconds from MIB-IN.
ExpNext	Request Exp-Next.

## Task ID

Task ID	Operations
---------	------------

snmp	read, write
------	----------------

```
RP/0/RSP0/CPU0:router# show snmp statistics oid group interface
Thu Mar 13 07:10:30.310 UTC
SerNum: 2489 Type: GETNEXT NumObj: 1
 MIBMGR-IN PDU-IN[ms] PDU-OUT[ms] MIBMGR-OUT[ms]
 Mar 13 07:00:49.933 1030 1030
 OID: 1.3.6.1.2.1.10.32.4.2.0 Exp-Next: Yes
 MIB-IN : Mar 13 07:00:49.933 MIB-OUT[ms] : 1030
SerNum: 10203 Type: GETNEXT NumObj: 1
 MIBMGR-IN PDU-IN[ms] PDU-OUT[ms] MIBMGR-OUT[ms]
 Mar 13 06:36:16.976 0 1031 1031
 OID: 1.3.6.1.2.1.10.32.4.2.0 Exp-Next: Yes
 MIB-IN : Mar 13 06:36:16.976 MIB-OUT[ms] : 1031
```

# show snmp statistics pdu

To show if processing time of any protocol data unit (PDU) is more than threshold limit, use the **show snmp statistics pdu nms** command in EXEC mode.

**show snmp statistics pdu nms[address]**

Syntax Description	nms [address]	Address of Network Management Station from which request has arrived. The PDU statistics is filtered for each NMS.
--------------------	------------------	--------------------------------------------------------------------------------------------------------------------

**Command Modes** Global configuration

Command History	Release	Modification
	Release 5.2.2	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The PDU processing time can exceed the threshold limit in these scenarios:

- SNMPD not able to dispatch the request to MIB because of any failures in snmpd.
- MIB response after threshold limit.
- MIB does not respond to SNMPD.

Default threshold limit is 2 seconds. To change the default threshold value, use the command:

```
snmp-server timeouts pdu stats <1-10>
```

The maximum number of entries per network management system (NMS) is 500 and the maximum number of NMS is 30.

This command shows these details:

Field	Description
NMS	Address of Network Management Station from which request has arrived.
Port	Port number of application that requested the SNMP query.
REQID	Request ID for each PDU.
Type	Type of PDU.
SerNum	The unique number generated for every request and sent to all MIBDs.

**show snmp statistics pdu**

Field	Description
Timeout	If the request was timeout out set to TRUE, else set to FALSE.
InputQ-In	Time stamp of the PDU when queued into input Q.
InputQ-Out	Time stamp of the PDU when queued into input Q, This will be in milliseconds, Offset from INPUT-IN time stamp.
ProcQ-In	Time stamp of the PDU when queued into Processing Q. This will be in milliseconds, Offset from INPUT-IN time stamp.
Response	Time stamp in milli seconds of the PDU when response is received from sub agents. Offset from INPUT-IN time stamp.

**Task ID****Task ID    Operations**


---

 snmp read,  
 write
 

---

```

RP/0/RSP0/CPU0:router# show snmp statistics pdu nms
Thu Mar 13 08:03:17.322 UTC
NMS: 64.103.222.6 PORT: 35028
REQID:962974264 TYPE: 161 SerNum: 9428 TIMEOUT: No
INPUTQ-IN INPUTQ-OUT [ms] PROCQ-IN [ms] RESPONSE [ms]
Mar 13 08:03:15.269 0 0 1056

```



## show snmp statistics slow oid

To show the object ID (OID) that has exceeded beyond the threshold time for processing and the number of times that the threshold limit is exceeded with the latest timestamp, use the **show snmp statistics slow oid** command in EXEC mode.

### show snmp statistics slow oid

This command has no keywords or arguments.

#### Command Modes

Global configuration

#### Command History

Release	Modification
Release 5.2.2	This command was introduced.

#### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Default threshold limit for this data as 500 milli seconds. To change the default value, use the command:

```
snmp-server logging threshold oid-processing < <0-20000>
```

The latest 500 entries for each sub agent is displayed and a total of upto 2000 entries is maintained.

The **show snmp statistics slow oid** command shows these details:

Field	Description
Type	Request type for slow OID.
Exact OID	Requested OID from NMS.
Resp OID	Response OID for the Request type and EXACT OID.
Slow Count	Number of times OID is slow.
Slow Time	Time taken for processing the OID in milli seconds.
Time Stamp	Time stamp of the slow OID when MIB responded to MIBD.

#### Task ID

Task ID	Operations
snmp	read, write

This example shows a slow OIDs that exceeds the specified threshold time.

```
RP/0/RSP0/CPU0:router# show snmp statistics slow oid
```

## show snmp statistics slow oid

Group:agent

```

TYPE : GETNEXT
REQ_OID : 1.3.6.1.2.1.1.1.0
RESP_OID : 1.3.6.1.2.1.1.1.2
COUNT : 2
TIME [ms] : 0
TIME_STAMP : Mar 13 05:36:52.279

```

Group:infra

Group:route

```

TYPE : GETNEXT
REQ_OID :
1.3.6.1.2.1.4.34.1.3.4.20.254.128.0.0.0.0.0.0.0.254.8.255.254.203.38.197.0.0.0.2
RESP_OID :
1.3.6.1.2.1.4.34.1.3.4.20.254.128.0.0.0.0.0.0.0.254.8.255.254.203.38.197.0.0.0.2
COUNT : 4
TIME [ms] : 14
TIME_STAMP : Mar 13 05:36:52.279
TYPE : GET
REQ_OID :
1.3.6.1.2.1.4.34.1.3.4.20.254.128.0.0.0.0.0.0.0.254.8.255.254.203.38.197.0.0.0.2
RESP_OID :
1.3.6.1.2.1.4.34.1.3.4.20.254.128.0.0.0.0.0.0.0.254.8.255.254.203.38.197.0.0.0.2
COUNT : 4
TIME [ms] : 14
TIME_STAMP : Mar 13 05:36:52.279

```

Group:entity

Group:interface

```

TYPE : GETNEXT
REQ_OID : 1.3.6.1.2.1.2.1
RESP_OID : 1.3.6.1.2.1.2.1.0
COUNT : 1
TIME [ms] : 0
TIME_STAMP : Mar 13 05:36:52.279

```

# show snmp statistics poll oid all

To show all object IDs (OIDs) polled from all network management system (NMS) and how many times it has polled, use the **show snmp statistics poll oid all** command in EXEC mode.

For this command to work, the following configuration has to be committed:

```
(config)#snmp-server oid-poll-stats
```

## show snmp statistics poll oid all

This command has no keywords or arguments.

**Command Modes** Global configuration

Command History	Release	Modification
	Release 5.2.2	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The maximum number of entries equals the number of OIDs that were polled. The maximum number of NMS details for each OID is 15.

The **show snmp statistics poll oid all** command shows these details:

Field	Description
Object ID	OID requested from NMS.
NMS	List of NMS IP address requested for each OID.
Count	Number of times OID is polled for each NMS.

Task ID	Task ID	Operations
	snmp	read, write

```
RP/0/RSP0/CPU0:router# show snmp statistics poll oid all
Object ID : 1.3.6.1.2.1.1.3
NMS COUNT
10.2.1.3 10
10.3.1.2 30
10.4.1.3 20
10.12.1.3 5

Object ID : 1.3.6.1.2.1.1.4
NMS COUNT
10.2.1.3 10
```

```
show snmp statistics poll oid all
```

```
10.3.1.2 5
10.4.1.3 20
10.12.1.3 30

Object ID : 1.3.6.1.2.1.1.5
NMS COUNT
10.2.1.3 10
10.3.1.2 3
10.4.1.3 2
```

# Show snmp statistics poll oid nms

To show which object ID (OID) is polled from which network management system (NMS) and how many times it has polled, use the **show snmp statistics poll oid nms** command in EXEC mode.

**show snmp statistics poll oid nms**<V4 / V6 address>

This command has no keywords or arguments.

**Command Modes** Global configuration

Command History	Release	Modification
	Release 5.2.2	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **show snmp statistics poll oid nms** command shows these details:

Field	Description
Object ID	OID requested from NMS.
NMS	List of NMS IP address requested for each OID.
Count	Number of times OID is polled for each NMS.

Task ID	Task ID	Operations
	snmp	read, write

```
RP/0/RSP0/CPU0:router# show snmp statistics poll nms 1.2.3.4
 NMS Address : 1.2.3.4
Object ID Count
1.3.6.1.2.1.2.2.1.2 14
```

```
show snmp statistics slow oid [after/before] hh:mm:ss day mday year
```

## show snmp statistics slow oid [after/before] hh:mm:ss day mday year

To show the object ID (OID) that has exceeded beyond the threshold time for processing and the number of times that the threshold limit is exceeded with the latest timestamp, use the **show snmp statistics slow oid [after/before] hh:mm:ss day mday year** command in EXEC mode.

**show snmp statistics slow oid[after/before] hh:mm:ss day mday year**

This command has no keywords or arguments.

**Command Modes** Global configuration

Command History	Release	Modification
	Release 5.2.2	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Default threshold limit for this data as 500 milli seconds. To change the default value, use the command:

```
snmp-server logging threshold oid-processing < <0-20000>
```

The latest 500 entries for each sub agent is displayed and a total of upto 2000 entries is maintained.

The **show snmp statistics slow oid [after/before] hh:mm:ss day mday year** command shows these details:

Field	Description
Type	Request type for slow OID.
Exact OID	Requested OID from NMS.
Resp OID	Response OID for the Request type and EXACT OID.
Slow Count	Number of times OID is slow.
Slow Time	Time taken for processing the OID in milli seconds.
Time Stamp	Time stamp of the slow OID when MIB responded to MIBD.

Task ID	Task ID	Operations
	snmp	read, write

This example shows a slow OIDs that exceeds the specified threshold time.

```
RP/0/RSP0/CPU0:router# show snmp statistics slow oid
```

```
Group:agent
```

```
TYPE : GETNEXT
REQ_OID : 1.3.6.1.2.1.1.1.0
RESP_OID : 1.3.6.1.2.1.1.1.2
COUNT : 2
TIME[ms] : 0
TIME_STAMP : Mar 13 05:36:52.279
```

```
Group:infra
```

```
Group:route
```

```
TYPE : GETNEXT
REQ_OID :
1.3.6.1.2.1.4.34.1.3.4.20.254.128.0.0.0.0.0.0.0.254.8.255.254.203.38.197.0.0.0.2
RESP_OID :
1.3.6.1.2.1.4.34.1.3.4.20.254.128.0.0.0.0.0.0.0.254.8.255.254.203.38.197.0.0.0.2
COUNT : 4
TIME[ms] : 14
TIME_STAMP : Mar 13 05:36:52.279
```

```
TYPE : GET
REQ_OID :
1.3.6.1.2.1.4.34.1.3.4.20.254.128.0.0.0.0.0.0.0.254.8.255.254.203.38.197.0.0.0.2
RESP_OID :
1.3.6.1.2.1.4.34.1.3.4.20.254.128.0.0.0.0.0.0.0.254.8.255.254.203.38.197.0.0.0.2
COUNT : 4
TIME[ms] : 14
TIME_STAMP : Mar 13 05:36:52.279
```

```
Group:entity
```

```
Group:interface
```

```
TYPE : GETNEXT
REQ_OID : 1.3.6.1.2.1.2.1
RESP_OID : 1.3.6.1.2.1.2.1.0
COUNT : 1
TIME[ms] : 0
TIME_STAMP : Mar 13 05:36:52.279
```

# show snmp mib ifmib general

To show how many requests get data from internal cache and how many requests are sent to statsd to get data, use the **show snmp mib ifmib general** command in EXEC mode.

## show snmp mib ifmib general

This command has no keywords or arguments.

**Command Modes** Global configuration

Command History	Release	Modification
	Release 5.2.2	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Default IFMIB internal cache is 15 seconds. To change the duration, use the command:

```
snmp-server ifmib internal cache max-duration <0-60>
```

The default duration is 15 seconds, 0 seconds to disable the IFMIB internal cache.

To service the requests from Stats cache instead of Drivers, use the command:

```
snmp-server ifmib stats cache
```

The **show snmp mib ifmib general** command shows these details:

Field	Description
Cache Hit	Number of times the request retrieves data from IFMIB internal cache.
Cache Miss	Number of times the request processed from statsd, and not from IFMIB internal cache
Last Access Time	Latest time stamp of corresponding hit or miss.
Count	Number of times the data is retrieved.

The Cache Hit and Cache Miss are 32 bit counters. The maximum value is  $2^{31}$  and reset to 0 if the maximum value is exceeded.

Task ID	Task ID	Operations
	snmp	read, write

```
RP/0/RSP0/CPU0:router# Show snmp mib ifmib general
```



Fri Mar 14 05:05:50.408 PDT

Type	Count	Last Access Time
Cache Hit	328	Mar 14 05:05:47.480
Cache Miss	2	Mar 14 05:05:47.386

## show snmp mib ifmib cache

To show the Ifindex that has exceeded the threshold time for processing, the request type and the time stamp, use the **show snmp mib ifmib cache** command in EXEC mode. The threshold time for the data to create an entry is 500 milli seconds.

### show snmp mib ifmib cache

This command has no keywords or arguments.

#### Command Modes

Global configuration

#### Command History

Release	Modification
Release 5.2.2	This command was introduced.

#### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

This command displays the latest 500 entries. An entry will be added when the difference between Cache in and Cache out time is more than 500 milli seconds. The timeout value cannot be changed.

The **show snmp mib ifmib cache** command shows these details:

Field	Description
Index	Interface index.
MIB IN	Time stamp of the request when IFMIB starts processing.
Cache In	Time stamp in milli seconds when data retrieval from the cache starts for the request. It is offset from MIB IN time stamp.
Cache Out	Time stamp in milli seconds when data is retrieved from cache. It is offset from MIB IN time stamp.
MIB Out	Time stamp in milli seconds of the response from IF MIB. It is offset from MIB IN time stamp.

#### Task ID

Task ID	Operations
snmp	read, write

```
RP/0/RSP0/CPU0:router# show snmp mib ifmib cache
IFIndex Type MIB IN CACHE IN[ms] CACHE OUT[ms]
```

```
 MIB OUT[ms]
2 NEXT Mar 18 07:14:41.815 4 701
 701
2 NEXT Mar 18 07:15:36.815 0 679
 679
2 NEXT Mar 18 07:16:00.735 0 684
 684
```

# show snmp mib ifmib statsd

To show the Ifindex that has exceeded the threshold time for processing, the request type and the time stamp, use the **show snmp mib ifmib statsd** command in EXEC mode. The threshold time for the data to create an entry is 500 milli seconds.

## show snmp mib ifmib statsd

This command has no keywords or arguments.

### Command Modes

Global configuration

### Command History

Release	Modification
Release 5.2.2	This command was introduced.

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

This command displays the latest 500 entries. An entry will be added when the difference between Stats in and Stats out time is more than 500 milli seconds. The timeout value cannot be changed.

The **show snmp mib ifmib statsd** command shows these details:

Field	Description
Index	Interface index.
MIB IN	Time stamp of the request when IFMIB starts processing.
Stats In	Time stamp in milli seconds when data retrieval from the Statsd starts for the request. It is offset from MIB IN time stamp.
Stats Out	Time stamp in milli seconds when data is retrieved from Statsd. It is offset from MIB IN time stamp.
MIB Out	Time stamp in milli seconds of the response from IF MIB. It is offset from MIB IN time stamp.

### Task ID

Task ID	Operations
snmp	read, write

```
RP/0/RSP0/CPU0:router# show snmp mib ifmib statsd
IFIndex Type MIB IN STATS IN[ms] STATS OUT[ms] MIB
```

```
OUT [ms]
2 NEXT Mar 18 07:14:41.815 4 701
701
2 NEXT Mar 18 07:15:36.815 0 679
679
2 NEXT Mar 18 07:16:00.735 0 684
684
```

# show snmp traps details

To show the details about the traps generated for each host, the sent and drop count and the timestamp, use the **show snmp traps details** command in EXEC mode.

## show snmp traps details

This command has no keywords or arguments.

**Command Modes** Global configuration

Command History	Release	Modification
	Release 5.2.2	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **show snmp traps details** command shows these details:

Field	Description
TrapOID	Generated trap.
Sent	Number of times the trap sent from the host and port configured.
Drop	Number of times the trap dropped from the host and port configured.
Last-sent	Time stamp when the last trap was sent from the host and port.
Last-drop	Time stamp when the last trap dropped from the host and port.
Host	Configured address of the host to receive traps
udp-port	Configured port to receive traps

Task ID	Task ID	Operations
	snmp	read, write

```
RP/0/RSP0/CPU0:router# show snmp traps details
Mon Apr 7 17:14:07.241 UTC
HOST:9.22.24.150, udp-port:3333
```

```

TrapOID Sent Drop Last-sent Last-drop
ciscoConfigManMIB.2.0.1 2 0 Mon Apr 07 14 17:12:29 ~
ciscoFlashDeviceInsertedNotif 1 0 Mon Apr 07 14 17:12:28 ~
ciscoFlashDeviceRemovedNotif 1 0 Mon Apr 07 14 17:12:28 ~
```

## show snmp informs details

To show the details about the informs generated for each host, the drop and retry count and the timestamp, use the **show snmp informs details** command in EXEC mode.

### show snmp informs details

This command has no keywords or arguments.

**Command Modes** Global configuration

Command History	Release	Modification
	Release 5.2.2	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **show snmp informs details** command shows these details:

Field	Description
InformOID	Generated inform.
Sent	Number of times the Inform is sent from the inform host and port configured.
Drop	Number of times the Inform is sent from the inform host and port configured.
Retry	Number of times the Inform retries from the inform host and port configured
Last-sent	Time stamp when the last inform was sent from the host and port.
Last-drop	Time stamp when the last inform dropped from the host and port.
Host	Configured address of the host to receive traps.
udp-port	Configured port to receive traps.

Task ID	Task ID	Operations
	snmp	read, write



```
RP/0/RSP0/CPU0:router# show snmp informs details
```

```
Mon Apr 7 17:14:17.212 UTC
```

```
HOST:9.22.24.150, udp-port:5555
```

```

```

InformOID	Sent	Drop	Retry	Last-sent	
Last-drop					
ciscoConfigManMIB.2.0.1	8	2	6	Mon Apr 07 14 17:12:54	Mon
Apr 07 14 17:12:42					
ciscoFlashDeviceInsertedNotif	4	1	3	Mon Apr 07 14 17:12:55	Mon
Apr 07 14 17:12:42					
ciscoFlashDeviceRemovedNotif	4	1	3	Mon Apr 07 14 17:12:54	Mon
Apr 07 14 17:12:42					
ciscoMgmt.117.2.0.1	8	2	6	Mon Apr 07 14 17:12:53	Mon
Apr 07 14 17:12:42					
ciscoMgmt.117.2.0.2	4	1	3	Mon Apr 07 14 17:12:52	Mon
Apr 07 14 17:12:42					

# show snmp users

To display information about the configured characteristics of Simple Network Management Protocol (SNMP) users, use the **show snmp users** command in

EXEC

mode.

**show snmp users**

**Syntax Description** This command has no keywords or arguments.

**Command Default** None

**Command Modes** EXEC

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

An SNMP user must be part of an SNMP group, as configured using the **snmp-server user** command.

Use the **show snmp users** command to display information about all configured users.

When configuring SNMP, you may see the logging message “Configuring snmpv3 USM user.” USM stands for the User-Based Security Model (USM) for SNMP Version 3 (SNMPv3). For further information about USM, see RFC 3414, *User-based Security Model (USM) for version 3 of the Simple Network Management Protocol (SNMPv3)*.

Task ID	Task ID	Operations
	snmp	read

This example shows sample output from the **show snmp users** command:

```
RP/0/RSP0/CPU0:router# show snmp users

User name:user1
Engine ID:localSnmpID
storage-type:nonvolatile active
```

**Table 66: show snmp users Field Descriptions**

Field	Definition
User name	String identifying the name of the SNMP user.
Engine ID	String identifying the name of the copy of SNMP on the device.
storage-type	Settings that are set in volatile or temporary memory on the device, or in nonvolatile or persistent memory where settings remain after the device is turned off and on again.

**Related Topics**

[snmp-server group](#), on page 719

[snmp-server user](#), on page 811

# show snmp view

To display the configured views and the associated MIB view family name, storage type, and status, use the **show snmp view** command in

EXEC

mode.

## show snmp view

**Syntax Description** This command has no keywords or arguments.

**Command Default** None

**Command Modes** EXEC

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	snmp	read

This example shows sample output from the **show snmp view** command:

```
RP/0/RSP0/CPU0:router# show snmp view
view1 1.3 - included nonVolatile active
vldefault 1.3.6.1 - included nonVolatile active
```

## Related Topics

[snmp-server group](#), on page 719

[snmp-server user](#), on page 811

# snmp-server chassis-id

To provide a message line identifying the Simple Network Management Protocol (SNMP) server serial number, use the **snmp-server chassis-id** command in

global configuration

mode. To restore the default value, if any, use the **no** form of this command.

**snmp-server chassis-id** *serial-number*  
**no snmp-server chassis-id**

<b>Syntax Description</b>	<i>serial-number</i> Unique identification string to identify the chassis serial number.
---------------------------	------------------------------------------------------------------------------------------

<b>Command Default</b>	On hardware platforms, where the serial number can be read by the device, the default is the serial number. For example, some Cisco devices have default chassis ID values of their serial numbers.
------------------------	-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

<b>Command Modes</b>	Global configuration
----------------------	----------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.2	This command was introduced.
Release 3.9.0	No modification.	

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

Use the **snmp-server chassis-id** command to provide a message line identifying the SNMP server serial number.

The chassis ID message can be displayed with the **show snmp** command.

<b>Task ID</b>	<b>Task</b>	<b>Operations</b>
		snmp

The following example shows how to specify the chassis serial number 1234456:

```
RP/0/RSP0/CPU0:router# snmp-server chassis-id 1234456
```

## Related Topics

[show snmp](#), on page 651

## snmp-server community

To configure the community access string to permit access to the Simple Network Management Protocol (SNMP), use the **snmp-server community** command in

global configuration

mode. To remove the specified community string, use the **no** form of this command.

```
snmp-server community [{clear | encrypted}] community-string [view view-name] [{RO | RW}]
[{{SDROwner | SystemOwner}}] [access-list-name]
no snmp-server community community-string
```

### Syntax Description

<b>clear</b>	(Optional) Specifies that the entered <i>community-string</i> is clear text and should be encrypted when displayed by the <b>show running</b> command.
<b>encrypted</b>	(Optional) Specifies that the entered <i>community-string</i> is encrypted text and should be displayed as such by the <b>show running</b> command.
<i>community-string</i>	Community string that acts like a password and permits access to the SNMP protocol. The maximum length of the <i>community-string</i> argument is 32 alphabetic characters.  If the <b>clear</b> keyword was used, <i>community-string</i> is assumed to be clear text. If the <b>encrypted</b> keyword was used, <i>community-string</i> is assumed to be encrypted. If neither was used, <i>community-string</i> is assumed to be clear text.
<b>view view-name</b>	(Optional) Specifies the name of a previously defined view. The view defines the objects available to the community.
<b>RO</b>	(Optional) Specifies read-only access. Authorized management stations are able only to retrieve MIB objects.
<b>RW</b>	(Optional) Specifies read-write access. Authorized management stations are able both to retrieve and to modify MIB objects.
<b>SDROwner</b>	(Optional) Limits access to the owner service domain router (SDR).
<b>SystemOwner</b>	(Optional) Provides system-wide access.
<i>access-list-name</i>	(Optional) Name of an access list of IP addresses allowed to use the community string to gain access to the SNMP agent.

### Command Default

By default, an SNMP community string permits read-only access to all MIB objects.

By default, a community string is assigned to the SDR owner.

### Command Modes

Global configuration

### Command History

Release	Modification
Release 3.7.2	This command was introduced.

Release	Modification
Release 3.9.0	No modification.

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **snmp-server community** command to configure the community access string to permit access to SNMP.

To remove the specified community string, use the **no** form of this command.

Use the **clear** keyword to specify that the clear text community string you enter is displayed encrypted in the **show running** command output. To enter an encrypted string, use the **encrypted** keyword. To enter a clear text community string that is not encrypted by the system, use neither of these keywords.

When the **snmp-server community** command is entered with the **SDROwner** keyword, SNMP access is granted only to the MIB object instances in the owner SDR.

When the **snmp-server community** command is entered with the **SystemOwner** keyword, SNMP access is granted to the entire system.

### Task ID

Task ID	Operations
snmp	read, write

This example shows how to assign the string comaccess to SNMP, allowing read-only access, and to specify that IP access list 4 can use the community string:

```
RP/0/RSP0/CPU0:router(config)# snmp-server community comaccess ro 4
```

The following example shows how to assign the string mgr to SNMP, allowing read-write access to the objects in the restricted view:

```
RP/0/RSP0/CPU0:router(config)# snmp-server community mgr view restricted rw
```

This example shows how to remove the community comaccess:

```
RP/0/RSP0/CPU0:router(config)#no snmp-server community comaccess
```

### Related Topics

[snmp-server view](#), on page 814

## snmp-server community-map

To associate a Simple Network Management Protocol (SNMP) community with an SNMP context, security name, or a target-list use the **snmp-server community-map** command in

global configuration

mode. To change an SNMP community mapping to its default mapping, use the **no** form of this command.

```
snmp-server community-map [{clear | encrypted}] community-string [context context-name]
[security-name security-name] [target-list target]
no snmp-server community-map [{clear | encrypted}] community-string
```

Syntax Description		
<b>clear</b>	(Optional)	Specifies that the <i>community-string</i> argument is clear text.
<b>encrypted</b>	(Optional)	Specifies that the <i>community-string</i> argument is encrypted text.
<i>community-string</i>		Name of the community.
<b>context</b> <i>context-name</i>	(Optional)	Name of the SNMP context to which this community name is to be mapped.
<b>security-name</b> <i>security-name</i>	(Optional)	Security name for this community. By default, the <i>string</i> is the security name.
<b>target-list</b> <i>target</i>	(Optional)	Name of the target list for this community.

**Command Default** The value of the *community-string* argument is also the security name.

**Command Modes** Global configuration

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **snmp-server community-map** command to map an SNMPv1 or SNMPv2c community name to one or more of the following:

- **context name**—Maps a community name to a specific SNMP context name. This allows MIB instances in an SNMP context to be accessed through SNMPv1 or SNMPv2c using this community name.
- **security name**—By default, the community name is used to authenticate SNMPv1 and SNMPv2c. Configure a security name for a community name to override the default and authenticate SNMP with the security name.



- **target**—Target list identifies a list of valid hosts from which SNMP access can be made using a specific security name. When such mapping is done for a particular community name, SNMP access is allowed only from hosts included in the target list.

Use the **clear** keyword to specify that the clear text community string you enter is displayed encrypted in the **show running** command output. To enter an encrypted string, use the **encrypted** keyword. To enter a clear text community string that is not encrypted by the system, use neither of these keywords.

Task ID	Task ID	Operations
	snmp	read, write

This example maps the community name “sample 2” to the SNMP context name “sample1”:

```
RP/0/RSP0/CPU0:router(config)# snmp-server community-map sample2 context sample1
```

### Related Topics

- [snmp-server context](#), on page 711
- [snmp-server target list](#), on page 762

## snmp-server contact

To set the Simple Network Management Protocol (SNMP) system contact, use the **snmp-server contact** command in

global configuration

mode. To remove the system contact information, use the **no** form of this command.

**snmp-server contact** *system-contact-string*

**no snmp-server contact**

<b>Syntax Description</b>	<i>system-contact-string</i> String that describes the system contact information. The maximum string length is 255 alphanumeric characters.
---------------------------	----------------------------------------------------------------------------------------------------------------------------------------------

<b>Command Default</b>	No system contact is set.
------------------------	---------------------------

<b>Command Modes</b>	Global configuration
----------------------	----------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

Use the **snmp-server contact** command to set the system contact string. Use the **no** form of this command to remove the system contact information.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	snmp	read, write

This example shows how to specify a system contact string:

```
RP/0/RSP0/CPU0:router(config)# snmp-server contact Dial System Operator at beeper # 27345
```

### Related Topics

[snmp-server location](#), on page 739

## snmp-server context

To create a Simple Network Management Protocol (SNMP) context, use the **snmp-server context** command in

global configuration

mode. To remove an SNMP context, use the **no** form of this command.

```
snmp-server context context-name
no snmp-server context context-name
```

<b>Syntax Description</b>	<i>context-name</i> Name of the SNMP context.
---------------------------	-----------------------------------------------

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Global configuration
----------------------	----------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.2	This command was introduced.
Release 3.9.0	No modification.	

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

This command creates an SNMP context. By default, all the SNMP MIB instances are in a default context. Create an SNMP context and map it to a particular feature to enable similar instances of the same object to co-exist in different SNMP contexts.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	snmp	read, write

This example creates a new SNMP context named "sample1:"

```
RP/0/RSP0/CPU0:router(config)# snmp-server context sample1
```

### Related Topics

[snmp-server community-map](#), on page 708

[snmp-server vrf](#), on page 816

## snmp-server context mapping

To map an SNMP context with a protocol instance, topology or VRF entity, use the **snmp-server context mapping** command in global configuration mode.

**snmp-server context mapping** *context-name* [**feature** *feature-name*] [**instance** *instance-name*] [**topology** *topology-name*] [**vrf** *vrf-name*]

Syntax Description		
	<i>context-name</i>	Name of the SNMP context.
	<b>feature</b> <i>feature-name</i>	Specifies the protocol for which to map the context. Available options are: <ul style="list-style-type: none"> <li>• <b>bridge</b>—Layer 2 VPN bridge</li> <li>• <b>vrf</b>—Virtual Routing and Forwarding</li> </ul>
	<b>instance</b> <i>instance-name</i>	Maps the context to the specified protocol instance.
	<b>topology</b> <i>topology-name</i>	Maps the context to the specified protocol topology.
	<b>vrf</b> <i>vrf-name</i>	Maps the context to the specified VRF logical entity.

**Command Default** No context mappings exist by default.

**Command Modes** Global configuration

Command History	Release	Modification
	Release 4.2.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

A device can support multiple instances of a logical network entity, such as protocol instances or VRFs. Most existing MIBs cannot distinguish between these multiple logical network entities. For example, the original OSPF-MIB assumes a single protocol instance on a device, but you can now configure multiple OSPF instances on a device.

The **snmp-server context mapping** command maps a context to a protocol instance, topology or VRF logical entity.



**Note** The **snmp-server context mapping** command does not work for OSPF and OSPFv3. Refer to the **snmp context** commands.

Task ID	Task ID	Operation
	snmp	read, write

This example illustrates how to map an snmp context to an OSPF instance:

```
RP/0/RSP0/CPU0:router(config)# snmp-server context mapping con5 feature ospf instance in1
```

### Related Topics

[snmp context \(OSPF\)](#)

[snmp context \(OSPFv3\)](#)

[show snmp context](#), on page 654

# snmp-server drop report acl

To apply an ACL policy for restricting an SNMPv3 unknown engine-id report to be sent out to NMS, use the **snmp-server drop report acl** command in the configuration mode.

**snmp-server drop report acl IPv4** *IPv4-acl-name* **IPv6** *IPv6-acl-name*

Syntax Description	Parameter	Description
	<b>acl</b>	Specifies IP Access Control Lists (ACL) policy
	<b>IPv4</b> <i>IPv4-acl-name</i>	Defines an IPv4 ACL name.
	<b>IPv6</b> <i>IPv6-acl-name</i>	Defines an IPv6 ACL name.

**Command Default** Unknown engine-id reports will be sent to all polling stations (even if other ACLs are configured).

**Command Modes** Configuration mode

Command History	Release	Modification
	Release 6.2.3	This command was introduced.

**Usage Guidelines** To drop an unknown engine-id report, you can either configure IPv4/IPv6 ACL name or both. When router is polled with wrong engine-id or no engine-id during a snmpv3 packet exchange, the unknown engine-id report will be sent based on the ACL policy that is configured.

Unknown engine-id reports will be sent only to polling station addresses that are permitted by ACL.

Task ID	Task ID	Operation
	snmp	read, write

## Example

This example shows how to configure the SNMP server to drop the unknown engine-id report:

```
RP/0/RSP0/CPU0:router (config) # snmp-server drop report acl IPv4 nms-block IPv6 nms-block-ipv6
```

# snmp-server drop unknown-user

To avoid error PDUs being sent out of router when polled with incorrect SNMPv3 user name, use the **snmp-server drop unknown-user** command in the appropriate mode. If the configuration is not set, by default it will respond with error PDUs.

## snmp-server drop unknown-user

<b>Syntax Description</b>	<b>drop unknown-user</b> Drop the error PDUs to be sent when router is polled with incorrect SNMPv3 user name.				
<b>Command Default</b>	Unknown error PDUs will be sent when router is polled with incorrect SNMPv3 user name.				
<b>Command Modes</b>	XR config				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 6.2.3</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 6.2.3	This command was introduced.
Release	Modification				
Release 6.2.3	This command was introduced.				
<b>Usage Guidelines</b>	No specific guidelines impact the use of this command.				
<b>Task ID</b>	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operation</th> </tr> </thead> <tbody> <tr> <td>snmp</td> <td>read, write</td> </tr> </tbody> </table>	Task ID	Operation	snmp	read, write
Task ID	Operation				
snmp	read, write				

### Example

This example shows how to configure the SNMP server to drop the error PDUs:

```
RP/0/RSP0/CPU0:router (config) # snmp-sever drop unknown-user
```

# snmp-server engineid local

To specify Simple Network Management Protocol (SNMP) engine ID on the local device, use the **snmp-server engineid local** command in

global configuration

mode. To return the engine ID to the default, use the **no** form of this command.

**snmp-server engineid local** *engine-id*  
**no snmp-server engineid local** *engine-id*

<b>Syntax Description</b>	<i>engine-id</i> Character string that identifies the engine ID. Consists of up to 24 characters in hexadecimal format. Each hexadecimal number is separated by a colon (:).
---------------------------	------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

<b>Command Default</b>	An SNMP engine ID is generated automatically.
------------------------	-----------------------------------------------

<b>Command Modes</b>	Global configuration
----------------------	----------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

<b>Task ID</b>	<b>Task</b>	<b>Operations</b>
	snmp	read, write

This example shows how to configure the SNMP engine ID on the local device:

```
RP/0/RSP0/CPU0:router(config)# snmp-server engineID local 00:00:00:09:00:00:00:a1:61:6c:20:61
```

## Related Topics

[show snmp engineid](#), on page 657



# snmp-server engineid remote

To specify a Simple Network Management Protocol (SNMP) engine ID on a remote device, use the **snmp-server engineid remote** command in

global configuration

mode. To return the engine ID to the default, use the **no** form of this command.

```
snmp-server engineid remote ip-address engine-id udp-port port
no snmp-server engineid remote ip-address engine-id udp-port port
```

Syntax Description		
<i>ip-address</i>	IP address of remote SNMP notification host	
<i>engine-id</i>	Character string that identifies the engine ID. Consists of up to 24 characters in hexadecimal format. Each hexadecimal number is separated by a colon (:).	
<b>udp-port port</b>	(Optional) Specifies the User Datagram Protocol (UDP) port of the host to use. Range is from 1 to 65535. The default UDP port is 161.	

**Command Default** An SNMP engine ID is generated automatically.

**Command Modes** Global configuration

Command History	Release	Modification
	Release 3.7.2	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operation
	snmp	read, write

This example shows how to configure the SNMP engine ID on the local device:

```
RP/0/RP0/CPU0:Router(config)# snmp-server engineID remote 172.16.4.1
00:00:00:09:00:00:00:a1:61:6c:20:61
```

## Related Topics

[show snmp engineid](#), on page 657

[snmp-server engineid local](#), on page 716

# snmp-server entityindex persist

To enable the persistent storage of ENTITY-MIB data across process restarts, switchovers, and device reloads, use the **snmp-server entityindex persist** command in

global configuration

mode. To disable the persistent storage of ENTITY-MIB data, use the **no** form of this command.

**snmp-server entityindex persist**  
**no snmp-server entityindex persist**

**Syntax Description** This command has no keywords or arguments.

**Command Default** None

**Command Modes** Global configuration

Command History	Release	Modification
	Release 3.9.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operation
	snmp	read, write

## Example

This example illustrates how to enable persistent storage of ENTITY-MIB indices:

```
RP/0/RSP0/CPU0:router(config)# snmp-server entityindex persist
```

## Related Topics

[snmp-server mibs cbqosmib persist](#), on page 748

## snmp-server group

To configure a new Simple Network Management Protocol (SNMP) group, or a table that maps SNMP users to SNMP views, use the **snmp-server group** command in

global configuration

mode. To remove a specified SNMP group, use the **no** form of this command.

```
snmp-server group name {v1 | v2c | v3 {auth | noauth | priv}} [read view] [write view] [notify
view] [context context-name] [access-list-name]
no snmp-server group name
```

Syntax Description		
<i>name</i>		Name of the group.
<b>v1</b>		Specifies a group that uses the SNMPv1 security model. The SNMP v1 security model is the least secure of the possible security models.
<b>v2c</b>		Specifies a group that uses the SNMPv2c security model. The SNMPv2c security model is the second least secure of the possible security models.
<b>v3</b>		Specifies a group that uses the SNMPv3 security model. The SNMP v3 security is the most secure of the possible security models.
<b>auth</b>		Specifies authentication of a packet without encrypting it.
<b>noauth</b>		Specifies no authentication of a packet.
<b>priv</b>		Specifies authentication of a packet with encryption.
<b>read</b> <i>view</i>		(Optional) Specifies a read view string (not to exceed 64 characters) that is the name of the view that allows only the contents of the agent to be viewed.
<b>write</b> <i>view</i>		(Optional) Specifies a write view string (not to exceed 64 characters) that is the name of the view used to enter data and configure the contents of the agent.
<b>notify</b> <i>view</i>		(Optional) Specifies a notify view string (not to exceed 64 characters) that is the name of the view used to specify a notify or trap.
<b>context</b> <i>context-name</i>		(Optional) Specifies the SNMP context to associate with this SNMP group and associated views.
<i>access-list-name</i>		(Optional) Access list string (not to exceed 64 characters) that is the name of the access list.

**Command Default** See [Table 67: snmp-server group Default Descriptions, on page 720](#).

**Command Modes** Global configuration

Command History	Release	Modification
	Release 3.7.2	This command was introduced.

Release	Modification
Release 3.9.0	No modification.

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

This table describes the default values for the different views:

**Table 67: snmp-server group Default Descriptions**

Default	Definition
<b>read view</b>	Assumed to be every object belonging to the Internet (1.3.6.1) object identifier (OID) space, unless the user uses the <b>read</b> option to override this state.
<b>write view</b>	Nothing is defined for the write view (that is, the null OID). You must configure write access.
<b>notify view</b>	Nothing is defined for the notify view (that is, the null OID). If a view is specified, any notifications in that view that are generated are sent to all users associated with the group (provided an SNMP server host configuration exists for the user).

### Configuring Notify Views

Do not specify a notify view when configuring an SNMP group for the following reasons:

- The **snmp-server host** command autogenerates a notify view for the user, and then adds it to the group associated with that user.
- Modifying the notify view of the group affects all users associated with that group.

The notify view option is available for two reasons:

- If a group has a notify view that is set using SNMP, you may need to change the notify view.
- The **snmp-server host** command may have been configured before the **snmp-server group** command. In this case, reconfigure the **snmp-server host** command or specify the appropriate notify view.

Instead of specifying the notify view for a group as part of the **snmp-server group** command, use the following commands in global configuration mode:

- **snmp-server user**—Configures an SNMP user.
- **snmp-server group**—Configures an SNMP group, without adding a notify view.
- **snmp-server host**—Autogenerates the notify view by specifying the recipient of a trap operation.

### Working with Passwords and Digests

No default values exist for authentication or privacy algorithms when this command is configured. In addition, no default passwords exist. The minimum length for a password is one character, although we recommend using eight characters for security. A plain-text password or localized Message Digest 5 (MD5) password can be specified. Forgotten passwords cannot be recovered, and the user must be reconfigured.

## SNMP Contexts

SNMP contexts provide Virtual Private Network (VPN) users with a secure way of accessing MIB data. When a VPN is associated with a context, that VPN's specific MIB data exists in that context. Associating a VPN with a context enables service providers to manage networks with multiple VPNs. Creating and associating a context with a VPN enables a provider to prevent the users of one VPN from accessing information about users of other VPNs on the same networking device.

Task ID	Task ID	Operations
	snmp	read, write

The following example shows how to configure an SNMP version 3 group named group1 that requires the authentication of packets with encryption:

```
RP/0/RSP0/CPU0:router(config)# snmp-server group group1 v3 priv
```

## Related Topics

- [show snmp](#), on page 651
- [show snmp group](#), on page 658
- [snmp-server host](#), on page 722
- [snmp-server view](#), on page 814

## snmp-server host

To specify the recipient of a Simple Network Management Protocol (SNMP) notification operation, use the **snmp-server host** command in

global configuration

mode. To remove the specified host, use the **no** form of this command.

```
snmp-server host address [{clear|encrypted}] [informs] [traps] [version {1|2c|3} {auth|noauth|priv}] community-string [udp-port port] [notification-type]
nosnmp-server host address [{clear|encrypted}] [informs] [traps] [version {1|2c|3} {auth|noauth|priv}] community-string [udp-port port] [notification-type]
```

### Syntax Description

<i>address</i>	Name or IP address of the host (the targeted recipient).
<b>clear</b>	(Optional) Specifies that the <i>community-string</i> argument is clear text.
<b>encrypted</b>	(Optional) Specifies that the <i>community-string</i> argument is encrypted text.
<b>informs</b>	(Optional) Specifies to send inform messages to this host.
<b>traps</b>	(Optional) Specifies that notifications should be sent as traps. This is the default.
<b>version</b>	(Optional) Specifies the version of the SNMP used to send the traps.
<b>1</b>	Specifies SNMPv1, the default.
<b>2c</b>	Specifies SNMPv2C.
<b>3</b>	Specifies SNMPv3. Version 3 is the most secure model because it allows packet encryption. If you specify the SNMPv3 keyword, you must specify the security level.
<b>auth</b>	Enables Message Digest 5 (MD5) algorithm and Secure Hash Algorithm (SHA) packet authentication.
<b>noauth</b>	Specifies that the noAuthNoPriv security level applies to this host. This is the default security level for SNMPv3.
<b>priv</b>	Enables Data Encryption Standard (DES) packet encryption (also called “privacy”).
<i>community-string</i>	Password-like community string sent with the notification operation. We recommend defining this string using the <b>snmp-server community</b> command prior to using the <b>snmp-server host</b> command.
<b>udp-port port</b>	(Optional) Specifies the User Datagram Protocol (UDP) port of the host to use. Range is from 1 to 65535. The default UDP port is 161.

*notification-type*

(Optional) Type of notification to be sent to the host. If no type is specified, all available notifications are sent. The notification type can be one or more of these keywords:

- **bgp** —Enables SNMP Border Gateway Protocol Version 4 (BGPv4) traps.
- **config** —Controls configuration notifications, as defined in the CISCO-CONFIG-MAN-MIB (enterprise 1.3.6.1.4.1.9.9.43.2). The notification type is (1) ciscoConfigManEvent.
- **copy-complete** —Enables CISCO-CONFIG-COPY-MIB ccCopyCompletion traps.
- **entity** —Controls Entity MIB modification notifications. This notification type is defined in the ENTITY-MIB (enterprise 1.3.6.1.2.1.47.2) as: (1) entConfigChange.
- **fabric** —Enables SNMP fabric traps.
- **fru-ctrl** —Enables SNMP entity field-replaceable unit (FRU) control traps.
- **mpls** —Enables SNMP Multiprotocol Label Switching (MPLS) traps.
- **sensor** —Enables SNMP entity sensor traps.
- **snmp** —Enables SNMP traps.
- **syslog** —Controls error message notifications (Cisco-syslog-MIB). Specify the level of messages to be sent with the **logging history** command.

**Command Default**

This command is disabled by default. No notifications are sent.

The default UDP port is 161.

When this command is entered without keywords, the default is to send all trap types to the host.

If no version keyword is entered, the default is version 1.

If version 3 is specified, but the security level is not specified, the default security level is noauth.

**Command Modes**

Global configuration

**Command History**

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	No modification.
Release 4.1.0	The <b>informs</b> keyword was added.

**Usage Guidelines**

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

SNMP notifications can be sent as traps. Traps are unreliable because the receiver does not send acknowledgments when it receives traps. The sender cannot determine if the traps were received. Traps are discarded as soon as they are sent. Traps are also sent only once.

When the **snmp-server host** command is not entered, no notifications are sent. To configure the device to send SNMP notifications, configure at least one **snmp-server host** command. When the command is entered without keywords, all trap types are enabled for the host.

To enable multiple hosts, issue a separate **snmp-server host** command for each host. You can specify multiple notification types in the command for each host.

When multiple **snmp-server host** commands are given for the same host and kind of notification (trap), each succeeding **snmp-server host** command overwrites the previous command. Only the last **snmp-server host** command is in effect. For example, if an **snmp-server host** command with the **traps** keyword is entered for a host and then another command with the **traps** keyword is entered for the same host, the second command replaces the first.

Either a host name or IP address can be used to specify the host.

The **snmp-server host** command is used with the **snmp-server engineid** command. Use the **snmp-server traps** command to specify which SNMP notifications are sent globally. For a host to receive most notifications, at least one **snmp-server traps** command and the **snmp-server host** command for that host must be enabled.

However, some notification types cannot be controlled with the **snmp-server traps** command. For example, some notification types are always enabled. Other notification types are enabled by a different command.

The availability of a notification-type depends on the device type and Cisco software features supported on the device.

To display which notification types are available on the system, use the question mark (?) online help function at the end of the **snmp-server host** command.

The **no snmp-server host** command used with no keywords disables traps.

Use the **clear** keyword to specify that the clear text community string you enter is displayed encrypted in the **show running** command output. To enter an encrypted string, use the **encrypted** keyword. To enter a clear text community string that is not encrypted by the system, use neither of these keywords.

If the **informs** keyword is used, the SNMP version can be only SNMPv2C or SNMPv3.

---

**Task ID**


---

**Task ID      Operations**


---

snmp    read,  
         write

---

This example shows how to send RFC 1157 SNMP traps to the host specified by the name myhost.cisco.com. Other traps are enabled, but only SNMP traps are sent because only the **snmp** keyword is specified in the **snmp-server host** command. The community string is defined as comaccess.

```
RP/0/RSP0/CPU0:router(config)# snmp-server traps
RP/0/RSP0/CPU0:router(config)# snmp-server host myhost.cisco.com comaccess snmp
```

This example shows how to send the SNMP traps to address 172.30.2.160:

```
RP/0/RSP0/CPU0:router(config)# snmp-server traps snmp
RP/0/RSP0/CPU0:router(config)# snmp-server host 172.30.2.160 public snmp
```



This example shows how to enable the router to send all traps to the host, myhost.cisco.com, using the community string public:

```
RP/0/RSP0/CPU0:router(config)# snmp-server traps
RP/0/RSP0/CPU0:router(config)# snmp-server host myhost.cisco.com public
```

This example shows how to prevent traps from being sent to any host. The BGP traps are enabled for all hosts, but only the configuration traps are enabled to be sent to a host.

```
RP/0/RSP0/CPU0:router(config)# snmp-server traps bgp
RP/0/RSP0/CPU0:router(config)# snmp-server host hostabc public config
```

This example shows how to send SNMPv3 informs to a host:

```
RP/0/RSP0/CPU0:router(config)# snmp-server host 172.30.2.160 informs version 3
```

### Related Topics

[snmp-server engineid local](#), on page 716

[snmp-server traps bgp](#), on page 776

[snmp-server inform](#), on page 731

## snmp-server ifindex persist

To enable ifIndex persistence globally on all Simple Network Management Protocol (SNMP) interfaces, use the **snmp-server ifindex persist** command in global configuration mode. To disable global interface persistence, use the **no** form of this command.

**snmp-server ifindex persist**  
**no snmp-server ifindex persist**

**Syntax Description** This command has no keywords or arguments.

**Command Default** Global interface persistence is disabled.

**Command Modes** Global configuration

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **snmp-server ifindex persist** command to enable ifIndex persistence on all interfaces that have entries in the ifIndex table of the IF-MIB. When enabled, this command retains the mapping between the ifName object values and the ifIndex object values (generated from the IF-MIB) persistent during reloads, allowing for consistent identification of specific interfaces using SNMP. Applications such as device inventory, billing, and fault detection depend on this feature.

Task ID	Task ID	Operations
	snmp	read, write

This example shows how to enable ifIndex persistence globally:

```
RP/0/RSP0/CPU0:router(config)# snmp-server ifindex persist
```

### Related Topics

- [index persistence](#), on page 636
- [notification linkupdown](#), on page 642
- [show snmp interface](#), on page 662

# snmp-server ifmib ifalias long

To enable the ifAlias IF-MIB object to accept an interface alias name that exceeds the 64-byte default, use the **snmp-server ifmib ifalias long** command. Use the **no** form of this command to revert to the default length.

```
snmp-server ifmib ifalias long
no snmp-server ifmib ifalias long
```

**Syntax Description** This command has no keywords or arguments.

**Command Default** Global interface persistence is disabled.  
The alias name is 64 bytes in length.

**Command Modes** Global configuration

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **snmp-server ifmib ifalias long** command to enable the IF-MIB object ifAlias to accept an interface alias name that is greater than 64 bytes in length. The default length for the alias name is 64 bytes.

Task ID	Task ID	Operations
	snmp	read, write

This example shows how to enable the IF-MIB object ifAlias:

```
RP/0/RSP0/CPU0:router(config)# snmp-server ifmib ifalias long
RP/0/RSP0/CPU0:router(config)# exit
```

```
Uncommitted changes found, commit them before exiting(yes/no/cancel)? [cancel]:yes
RP/0/RSP0/CPU0:router#
```

## snmp-server ifmib internal cache max-duration

To configure the refresh interval for the IF-MIB statistics cache, use the **snmp-server ifmib internal cache max-duration** command in global configuration mode. To revert to the default cache interval, use the **no** form of this command.

**snmp-server ifmib internal cache max-duration** *timeout*

<b>Syntax Description</b>	<i>timeout</i> Length of time before the cache is refreshed. Values can range from 0 to 60 seconds. The default is 15.
---------------------------	------------------------------------------------------------------------------------------------------------------------

<b>Command Default</b>	<i>timeout</i> : 15 seconds
------------------------	-----------------------------

<b>Command Modes</b>	Global configuration
----------------------	----------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 4.2.3	This command was introduced.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

The **snmp-server ifmib internal cache max-duration** command controls the refresh interval of the cache. If the *timeout* value in the **snmp-server ifmib internal cache max-duration** command is set to zero, the cache is disabled. By default, the counters are cached for 15 secs in the ifmib internal cache, after which it will be discarded.

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	snmp	read, write

This example shows how to change the refresh interval for the IF-MIB statistics cache.

```
RP/0/RSP0/CPU0:routerrouter(config)# snmp-server ifmib internal cache max-duration 60
```

### Related Topics

[snmp-server ifmib stats cache](#), on page 730

# snmp-server ifmib ipsubscriber

To enable IP subscriber interfaces in the interfaces MIB (IF-MIB), use the **snmp-server ifmib ipsubscriber** command in global configuration mode. To disable IP subscriber interfaces, use the **no** form of this command.

**snmp-server ifmib ipsubscriber**  
**no snmp-server ifmib ipsubscriber**

**Syntax Description** This command has no keywords or arguments.

**Command Default** Ip subscriber interfaces are not enabled.

**Command Modes** Global configuration

Command History	Release	Modification
	Release 4.2.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operation
	snmp	read, write

This example shows how to enable IP subscriber interfaces in the IF-MIB:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# snmp-server ifmib ipsubscriber
```

## snmp-server ifmib stats cache

To enable retrieval of cached statistics instead of real-time statistics, use the **snmp-server ifmib stats cache** command. To revert to the default, use the **no** form of this command.

**snmp-server ifmib stats cache**  
**no snmp-server ifmib stats cache**

**Syntax Description** This command has no keywords or arguments.

**Command Default** Cached statistics are not enabled.

**Command Modes** Global configuration

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Cisco IOS XR statistics infrastructure maintains a cache of statistics for all interfaces. This cache is updated every 30 seconds. Use the **snmp-server ifmib stats cache** command to enable the IF-MIB to retrieve these cached statistics rather than real-time statistics. Accessing cached statistics is less CPU-intensive than accessing real-time statistics.

Task ID	Task ID	Operations
	snmp	read, write

This example shows how to enable the IF-MIB caches statistics:

```
RP/0/RSP0/CPU0:router(config)# snmp-server ifmib stats cache
RP/0/RSP0/CPU0:router(config)# exit
```

```
Uncommitted changes found, commit them before exiting(yes/no/cancel)? [cancel]:yes
RP/0/RSP0/CPU0:router#
```

### Related Topics

[snmp-server ifmib internal cache max-duration](#), on page 728

# snmp-server inform

To configure Simple Network Management Protocol (SNMP) inform message options, use the **snmp-server inform** command in global configuration mode. To revert to the default informs options, use the **no** form of this command.

```
snmp-server inform {pending max-no | retries no-retries | timeout seconds}
no snmp-server inform {pending max-no | retries no-retries | timeout seconds}
```

Syntax Description		
<b>pending</b> <i>max-no</i>		Specifies the maximum number of inform messages to hold in the queue. The default is 25.
<b>retries</b> <i>no-retries</i>		Specifies the retry count for inform messages. Values can be from 1 to 100. The default is three.
<b>timeout</b> <i>seconds</i>		Specifies the inform message timeout value in seconds. The default is 15.

**Command Default** None

**Command Modes** Global configuration

Command History	Release	Modification
	Release 4.2.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

To enable the sending of SNMP inform messages, use the **snmp-server host** command with the **informs** keyword. When SNMP server informs are enabled, the SNMP version can be only SNMPv2C or SNMPv3.

Task ID	Task ID	Operations
	snmp	read, write

This example shows how to configure SNMP inform messages:

```
RP/0/RSP0/CPU0:router(config)# snmp-server host myhost.cisco.com informs comaccess
RP/0/RSP0/CPU0:router(config)# snmp-server inform pending 40
RP/0/RSP0/CPU0:router(config)# snmp-server inform retries 10
```


## Related Topics

[snmp-server host](#), on page 722

## snmp-server interface

To enable an interface to send Simple Network Management Protocol (SNMP) trap notifications and enter SNMP interface configuration mode, use the **snmp-server interface** command in global configuration mode. To disable the sending of SNMP trap notifications on an interface, use the **no** form of this command.

```
snmp-server interface type interface-path-id
no snmp-server interface type interface-path-id
```

<b>Syntax Description</b>	<i>type</i>	Interface type. For more information, use the question mark (?) online help function.
	<i>interface-path-id</i>	Physical interface or virtual interface.
	<b>Note</b>	Use the <b>show interfaces</b> command to see a list of all interfaces currently configured on the router.
		For more information about the syntax for the router, use the question mark (?) online help function.
<b>Command Default</b>	Ethernet interfaces are enabled to send SNMP trap notifications. SNMP trap notifications are disabled on all other physical and logical interfaces.	
<b>Command Modes</b>	Global configuration	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.
<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.	
	The <b>snmp-server interface</b> command enters SNMP interface configuration mode for you to configure the available SNMP options.	
		
	<b>Note</b>	In references to a Management Ethernet interface located on a route switch processor card, the physical slot number is numeric (0 through n-1 where n is the number of line card slots in the chassis) and the module is CPU0. Example: interface MgmtEth0/1/CPU0/0.
<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	snmp	read, write



This example shows how to assign ifIndex persistence on Packet-over-SONET/SDH (POS) interface 0/0/1/0:

```
RP/0/RSP0/CPU0:router(config)# snmp-server interface pos 0/0/1/0
RP/0/RSP0/CPU0:router(config-snmp-if)#
```

### Related Topics

[show snmp interface](#), on page 662

[snmp-server engineid local](#), on page 716

[snmp-server ifindex persist](#), on page 726

## snmp-server interface subset

To enter snmp-server interface subset configuration mode for a set of interfaces, use the **snmp-server interface subset** command in global configuration mode. To revert to the default interface settings, use the **no** form of this command.

```
snmp-server interface subset subset-number regular-expression expression
no snmp-server interface subset subset-number
```

<b>Syntax Description</b>	<i>subset-number</i>	Identifying number of the interface subset, which also indicates its relative priority.
	<b>regular-expression</b> <i>expression</i>	Specifies for which subset of interfaces to enter snmp-server interface subset configuration mode. The <i>expression</i> argument must be entered surrounded by double quotes.
<b>Command Default</b>	None	
<b>Command Modes</b>	Global configuration	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.9.0	This command was introduced.

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The *subset-number* argument is used to set the priority for an interface that matches more than one configured regular expressions. Lower values of the *subset-number* have a higher priority. If a single interface becomes part of a multiple-interface configured regular expression, the configuration with the lower *subset-number* value is applied.

Regular expressions have two constraints:

- Regular expressions must always be entered within double quotes to ensure that the CLI interprets each character correctly.
- All characters that are part of a regular expression are considered regular characters with no special meaning. In order to enter special characters, such as "\" or "?," they must be preceded by the backslash character "\." For example, to enter the regular expression ([A-Z][A-Z0-9]*)b[^>]*>(.*)<^1, you would enter ([A-Z][A-Z0-9]*)\b[^>]*>(.*)<^1.

Refer to the *Understanding Regular Expressions, Special Characters, and Patterns* module in *Cisco ASR 9000 Series Aggregation Services Router Getting Started Guide* for more information regarding regular expressions.

From the snmp-server interface mode of a subset of interfaces, SNMP linkUp and linkDown notifications can be enabled or disabled using the **notification linkupdown disable** command.

Task ID	Task ID	Operation
	snmp	read, write

This example illustrates how to configure all Gigabit Ethernet interfaces:

```
RP/0/RSP0/CPU0:router# config
RP/0/RSP0/CPU0:router(config)# snmp-server int subset 2
regular-expression "^Gig[a-zA-Z]+[0-9/]+\."
```

### Related Topics

[notification linkupdown](#), on page 642

[show snmp interface notification](#), on page 664

[show snmp interface regular-expression](#), on page 666

## snmp-server ipv4 dscp

To mark packets with a specific differentiated services code point (DSCP) value, use the **snmp-server ipv4 dscp** command in global configuration mode. To remove matching criteria, use the **no** form of this command.

```
snmp-server ipv4 dscp value
no snmp-server ipv4 dscp [value]
```

### Syntax Description

*value* Value of the DSCP. The DSCP value can be a number from 0 to 63, or it can be one of the following keywords: **default**, **ef**, **af11**, **af12**, **af13**, **af21**, **af22**, **af23**, **af31**, **af32**, **af33**, **af41**, **af42**, **af43**, **cs1**, **cs2**, **cs3**, **cs4**, **cs5**, **cs6**, **cs7**.

### Command Default

The IP DSCP default value for SNMP traffic is 0.

### Command Modes

Global configuration

### Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	No modification.

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **snmp-server ipv4 dscp** command to specify an IP DSCP value to give SNMP traffic higher or lower priority in your network.

### Task ID

Task ID	Operations
snmp	read, write

This example shows how to configure the DSCP value to af32:

```
RP/0/RSP0/CPU0:router (config) # snmp-server ipv4 dscp af32
```

## snmp-server ipv4 precedence

To mark packets with a specific precedence level to use for packet matching, use the **snmp-server ipv4 precedence** command in global configuration mode. To restore the system to its default interval values, use the **no** form of this command.

**snmp-server ipv4 precedence** *value*  
**no snmp-server ipv4 precedence** [*value*]

<b>Syntax Description</b>	<p><i>value</i> Value of the precedence. The precedence value can be a number from 0 to 7, or it can be one of the following keywords:</p> <p><b>critical</b> Set packets with critical precedence (5)</p> <p><b>flash</b> Set packets with flash precedence (3)</p> <p><b>flash-override</b> Set packets with flash override precedence (4)</p> <p><b>immediate</b> Set packets with immediate precedence (2)</p> <p><b>internet</b> Set packets with internetwork control precedence (6)</p> <p><b>network</b> Set packets with network control precedence (7)</p> <p><b>priority</b> Set packets with priority precedence (1)</p> <p><b>routine</b> Set packets with routine precedence (0)</p>						
<b>Command Default</b>	The IP Precedence default value for SNMP traffic is 0.						
<b>Command Modes</b>	Global configuration						
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 3.7.2</td> <td>This command was introduced.</td> </tr> <tr> <td>Release 3.9.0</td> <td>No modification.</td> </tr> </tbody> </table>	Release	Modification	Release 3.7.2	This command was introduced.	Release 3.9.0	No modification.
Release	Modification						
Release 3.7.2	This command was introduced.						
Release 3.9.0	No modification.						

**Usage Guidelines**

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **snmp-server ipv4 precedence** command to specify an IP Precedence value to give SNMP traffic higher or lower priority in your network.

**Task ID**

Task ID	Operations
snmp	read, write

This example shows how to set the precedence to 2:

```
RP/0/RSP0/CPU0:router(config)# snmp-server ipv4 precedence 2
```

# snmp-server location

To specify the system location for Simple Network Management Protocol (SNMP), use the **snmp-server location** command in

global configuration

mode. To remove the location string, use the **no** form of this command.

**snmp-server location** *system-location*

**no snmp-server location**

<b>Syntax Description</b>	<i>system-location</i> String indicating the physical location of this device. The maximum string length is 255 alphanumeric characters.
---------------------------	------------------------------------------------------------------------------------------------------------------------------------------

<b>Command Default</b>	No system location string is set.
------------------------	-----------------------------------

<b>Command Modes</b>	Global configuration
----------------------	----------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.2	This command was introduced.
Release 3.9.0	No modification.	

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

<b>Task ID</b>	<b>Task</b>	<b>Operations</b>
		snmp

This example shows how to specify a system location string:

```
RP/0/RSP0/CPU0:router(config)# snmp-server location Building 3/Room 214
```

## Related Topics

[snmp-server contact](#), on page 710

## snmp-server mib bulkstat max-procmem-size

To configure the overall per-process memory size limit used by all bulk statistics files in the process, use the **snmp-server mib bulkstat max-procmem-size** command in

global configuration

mode. To remove the overall per-process memory size, use the **no** form of this command.

**snmp mib bulkstat max-procmem-size** *size*  
**no snmp mib bulkstat max-procmem-size** [*size*]

<b>Syntax Description</b>	<i>size</i> Overall per-process memory size limit in kilobytes. The valid range is from 100 to 200000. The default is 200000.
---------------------------	-------------------------------------------------------------------------------------------------------------------------------

<b>Command Default</b>	The maximum process memory size is 200000 KB.
------------------------	-----------------------------------------------

<b>Command Modes</b>	Global configuration
----------------------	----------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 4.2.0	This command was introduced.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

Currently 300 MB is the maximum process memory available for MIB and SNMP processes.

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	snmp	read, write

This example sets the maximum process memory size to 100000 KB.

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# snmp-server mib bulkstat max-procmem-size 100000
```



## snmp-server mib bulkstat object-list

To configure a Simple Network Management Protocol (SNMP) bulk statistics object list and enter bulk statistics objects configuration mode, use the **snmp-server mib bulkstat object-list** in

global configuration

mode. To remove an SNMP object list configuration, use the **no** form of this command.

**snmp-server mib bulkstat object-list** *object-list-name*

**no snmp-server mib bulkstat object-list** *object-list-name*

<b>Syntax Description</b>	<i>object-list-name</i> Name or object identifier (OID) of the bulk statistics object list to configure.
---------------------------	----------------------------------------------------------------------------------------------------------

<b>Command Default</b>	No SNMP bulk statistics object list is configured.
------------------------	----------------------------------------------------

<b>Command Modes</b>	Global configuration
----------------------	----------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 4.2.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **snmp-server mib bulkstat object-list** command allows you to name an object list. Bulk statistics object lists are used for the Periodic MIB Data Collection and Transfer Mechanism. Use the **add** command to add objects to the object list configured with the **snmp-server mib bulkstat object-list** command. Bulk statistics object lists can be reused in multiple schemas.

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	snmp	read, write

In this example, a bulk statistics object list called ifmib is configured to include two objects:

```
RP/0/RSP0/CPU0:router# config
RP/0/RSP0/CPU0:router(config)# snmp-server mib bulkstat object-list ifmib
RP/0/RSP0/CPU0:router(config-bulk-objects)# add ifOutOctets
RP/0/RSP0/CPU0:router(config-bulk-objects)# add ifInOctets
```

### Related Topics

[add \(bulkstat object\)](#), on page 629

[show snmp mib bulkstat transfer](#), on page 670

## snmp-server mib bulkstat schema

To configure a Simple Network Management Protocol (SNMP) bulk statistics schema and enter bulk statistics schema configuration mode, use the **snmp-server mib bulkstat schema** command in

global configuration

mode. To remove the SNMP bulk statistics schema, use the **no** form of this command.

**snmp-server mib bulkstat schema** *schema-name*

**no snmp-server mib bulkstat schema** *schema-name*

<b>Syntax Description</b>	<i>schema-name</i> Specifies the name of the schema to configure.
---------------------------	-------------------------------------------------------------------

<b>Command Default</b>	No schemas are configured.
------------------------	----------------------------

<b>Command Modes</b>	Global configuration
----------------------	----------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 4.2.0	This command was introduced.

**Usage Guidelines**

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **snmp-server mib bulkstat schema** command names the schema and enters bulk statistics schema configuration mode. Bulk statistics schema configuration mode is used to configure the object list, instance, and polling interval to be used in the schema.

The specific instances of MIB objects for which data should be collected are determined by appending the value of the **instance** command to the objects specified in the object list.

Multiple schemas can be associated with a single bulk statistics file when configuring the bulk statistics transfer options.

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	snmp	read, write

The following example shows how to configure a bulk statistics schema called GigE0/6/5/0:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# snmp-server mib bulkstat schema tengige 0/6/5/0
RP/0/RSP0/CPU0:router(config-bulk-sc)# object-list ifmib
RP/0/RSP0/CPU0:router(config-bulk-sc)# poll-interval 3
RP/0/RSP0/CPU0:router(config-bulk-sc)# instance exact interface tengige 0/6/5/0 subif
```

```
RP/0/RSP0/CPU0:router(config-bulk-sc)# exit
```

### Related Topics

[instance \(bulkstat schema\)](#), on page 637

[poll-interval](#), on page 645

## snmp-server mib bulkstat transfer-id

To identify the bulk statistics transfer configuration and enter bulk statistics transfer configuration mode, use the **snmp-server mib bulkstat transfer-id** command in

global configuration

mode. To remove a previously configured transfer, use the **no** form of this command

```
snmp-server mib bulkstat transfer-id transfer-id
no snmp-server mib bulkstat transfer-id transfer-id
```

<b>Syntax Description</b>	<i>transfer-id</i> Name of the transfer configuration.
---------------------------	--------------------------------------------------------

<b>Command Default</b>	Bulk statistics transfer is not configured.
------------------------	---------------------------------------------

<b>Command Modes</b>	Global configuration
----------------------	----------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 4.2.0	This command was introduced.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

The name, *transfer-id*, you specify for the bulk statistics transfer configuration is used in the filename of the bulk statistics file when it is generated and is used to identify the transfer configuration in the output of the **show snmp mib bulkstat transfer** command.

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	snmp	read, write

In this example, The bulk statistics transfer is given the name bulkstat1 and contains two schemas:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# snmp-server mib bulkstat transfer-id bulkstat1
RP/0/RSP0/CPU0:router(config-bulk-tr)# schema IFMIB
RP/0/RSP0/CPU0:router(config-bulk-tr)# schema CAR
RP/0/RSP0/CPU0:router(config-bulk-tr)# url primary
ftp://user1:pswr@cbin2-host/users/user1/bulkstat1
RP/0/RSP0/CPU0:router(config-bulk-tr)# url secondary
tftp://user1@10.1.0.1/tftpboot/user1/bulkstat1
RP/0/RSP0/CPU0:router(config-bulk-tr)# format schemaASCII
RP/0/RSP0/CPU0:router(config-bulk-tr)# transfer-interval 30
RP/0/RSP0/CPU0:router(config-bulk-tr)# retry 5
RP/0/RSP0/CPU0:router(config-bulk-tr)# buffer-size 1024
```

```
RP/0/RSP0/CPU0:router(config-bulk-tr)# retain 30
RP/0/RSP0/CPU0:router(config-bulk-tr)# end
```

### Related Topics

- [buffer-size](#), on page 630
- [format \(bulkstat\)](#), on page 634
- [retain](#), on page 646
- [retry](#), on page 648
- [schema](#), on page 650
- [show snmp mib bulkstat transfer](#), on page 670
- [transfer-interval](#), on page 818
- [url](#), on page 820

## snmp-server mibs cbqosmib cache

To enable and configure caching of the QoS MIB statistics, use the **snmp-server mibs cbqosmib cache** command in global configuration mode. To disable caching, use the **no** form of this command.

```
snmp-server mibs cbqosmib cache {refresh time time | service-policy count count}
no snmp-server mibs cbqosmib cache [{refresh time time | service-policy count count}]
```

Syntax Description	Parameter	Description
	<b>refresh</b>	Enables QoS MIB caching with a specified cache refresh time.
	<b>time</b> <i>time</i>	Specifies the cache refresh time, in seconds. The <i>time</i> argument can be between 5 and 60. The default is 30.
	<b>service-policy</b>	Enables QoS MIB caching with a limited number of service policies to cache.
	<b>count</b> <i>count</i>	Specifies the maximum number of service policies to cache. The count argument can be between 1 and 5000.

**Command Default** None

**Command Modes** Global configuration

Command History	Release	Modification
	Release 3.9.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task	Operation
	snmp	read, write

### Example

This example illustrates how to enable QoS MIB caching with a refresh time:

```
RP/0/RSP0/CPU0:router(config)# snmp-server mibs cbqosmib cache refresh time 45
```

This example illustrates how to enable QoS MIB caching with a service policy count limitation:

```
RP/0/RSP0/CPU0:router(config)# snmp-server mibs cbqosmib cache service-policy count 10
```

**Related Topics**

[snmp-server entityindex persist](#), on page 718

[snmp-server mibs cbqosmib persist](#), on page 748

## snmp-server mibs cbqosmib persist

To enable persistent storage of the CISCO-CLASS-BASED-QOS-MIB data across process restarts, switchovers, and device reloads, use the **snmp-server mibs cbqosmib persist** command in global configuration mode. To disable persistent storage of the MIB data, use the **no** form of this command.

**snmp-server mibs cbqosmib persist**  
**no snmp-server mibs cbqosmib persist**

<b>Syntax Description</b>	This command has no keywords or arguments.
---------------------------	--------------------------------------------

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Global configuration
----------------------	----------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.9.0	This command was introduced.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

<b>Task ID</b>	<b>Task</b>	<b>Operation</b>
	snmp	read, write

### Example

This example illustrates how to enable persistent storage of CISCO-CLASS-BASED-QOS-MIB data:

```
RP/0/RSP0/CPU0:router(config)# snmp-server mibs cbqosmib persist
```

### Related Topics

[snmp-server entityindex persist](#), on page 718



# snmp-server mibs eventmib congestion-control

To configure the generation of SNMP traps when congestion exceeds configured thresholds, use the **snmp-server mibs eventmib congestion-control** command in global configuration mode. To restore the default values, use the **no** form of this command.

```
snmp-server mibs eventmib congestion-control type interface-path-id falling lower-threshold
interval sampling-interval rising upper-threshold
no snmp-server mibs eventmib congestion-control type interface-path-id
```

Syntax Description		
<i>type</i>		Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>		Physical interface or virtual interface. <b>Note</b> Use the show interfaces command to see a list of all interfaces currently configured on the router.  For more information about the syntax for the router, use the question mark (?) online help function.
<b>falling</b> <i>lower-threshold</i>		Specifies the lower threshold for which to determine whether an mteTriggerFalling SNMP Trap is generated.
<b>interval</b> <i>sampling-interval</i>		Specifies how often the congestion statistics are polled. The <i>interval</i> argument, in minutes, can be between 5 and 1440; it must be a multiple of 5.
<b>rising</b> <i>upper-threshold</i>		Specifies the upper threshold for which to determine whether an mteTriggerRising SNMP Trap is generated.

**Command Default** None

**Command Modes** Global configuration

Command History	Release	Modification
	Release 4.2.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.



**Note** A maximum of 100 interfaces can be monitored for congestion.

Congestion configurations using the **snmp-server mibs eventmib congestion-control** command cannot be modified using SNMP SET and vice versa.

When the congestion between two intervals increases above the *upper-threshold* argument, an `mteTriggerRising` SNMP trap is generated. This trap is not generated until the congestion drops below the lower threshold and then rises above the upper threshold.

When the congestion between two intervals falls below the *lower-threshold* argument, and an SNMP `mteTriggerRising` trap was generated previously, an SNMP `mteTriggerFalling` trap is generated. The `mteTriggerRising` trap is not generated until the congestion goes above the upper threshold and then falls back below the lower threshold.

The *lower-threshold* value (falling) should be set to a value less than or equal to the *upper-threshold* value (rising).

The **snmp-server mibs eventmib congestion-control** command is configured on a specific interface and is supported on the following cards:

- 8-port 10 Gigabit Ethernet PLIM
- 16-port OC-48c/STM-16 POS/DPT PLIM
- 1-port OC-768c/STM-256 POS PLIM
- 4-port OC-192c/STM-64 POS/DPT PLIM
- All Ethernet SPAs
- 2-port and 4-port OC-3c/STM-1 POS SPAs
- 2-port, 4-port, and 8-port OC-12c/STM-4 POS SPAs
- 2-port and 4-port OC-48c/STM-16 POS/RPR SPAs
- 1-port OC-192c/STM-64 POS/RPR SPA

Task ID	Task ID	Operations
	snmp	read, write

This example shows how to configure the generation of SNMP traps in response to congestion:

```
RP/0/RSP0/CPU0:router(config)# snmp-server mibs eventmib congestion-control pos 0/1/0/0
 falling 1 interval 5 rising 2
```

## snmp-server mibs eventmib packet-loss

To configure the generation of SNMP traps when packet loss exceeds configured thresholds, use the **snmp-server mibs eventmib packet-loss** command in global configuration mode. To restore the default values, use the **no** form of this command.

**snmp-server mibs eventmib packet-loss** *type interface-path-id* **falling** *lower-threshold interval sampling-interval* **rising** *upper-threshold*

**no snmp-server mibs eventmib packet-loss** *type interface-path-id*

### Syntax Description

<i>type</i>	Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	Physical interface or virtual interface. <b>Note</b> Use the show interfaces command to see a list of all interfaces currently configured on the router.  For more information about the syntax for the router, use the question mark (?) online help function.
<b>falling</b> <i>lower-threshold</i>	Specifies the lower threshold for which to determine whether an mteTriggerFalling SNMP Trap is generated.
<b>interval</b> <i>sampling-interval</i>	Specifies how often the packet loss statistics are polled. The <i>interval</i> argument, in minutes, can be between 5 and 1440; it must be a multiple of 5.
<b>rising</b> <i>upper-threshold</i>	Specifies the upper threshold for which to determine whether an mteTriggerRising SNMP Trap is generated.

### Command Default

None

### Command Modes

Global configuration

### Command History

Release	Modification
Release 3.9.0	This command was introduced.

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.



#### Note

A maximum of 100 interfaces can be monitored for packet loss.

Packet loss configurations using the **snmp-server mibs eventmib packet-loss** command cannot be modified using SNMP SET and vice versa.

When the packet loss between two intervals increases above the *upper-threshold* argument, an `mteTriggerRising` SNMP trap is generated. This trap is not generated until the packet loss drops below the lower threshold and then rises above the upper threshold.

When the packet loss between two intervals falls below the *lower-threshold* argument, and an SNMP `mteTriggerRising` trap was generated previously, an SNMP `mteTriggerFalling` trap is generated. The `mteTriggerRising` trap is not generated until the packet loss goes above the upper threshold and then falls back below the lower threshold.

The *lower-threshold* value (falling) should be set to a value less than or equal to the *upper-threshold* value (rising).

The **snmp-server mibs eventmib packet-loss** command is configured on a specific interface and is supported on the following cards:

- 8-port 10 Gigabit Ethernet PLIM
- 16-port OC-48c/STM-16 POS/DPT PLIM
- 1-port OC-768c/STM-256 POS PLIM
- 4-port OC-192c/STM-64 POS/DPT PLIM
- All Ethernet SPAs
- 2-port and 4-port OC-3c/STM-1 POS SPAs
- 2-port, 4-port, and 8-port OC-12c/STM-4 POS SPAs
- 2-port and 4-port OC-48c/STM-16 POS/RPR SPAs
- 1-port OC-192c/STM-64 POS/RPR SPA

---

**Task ID**


---

**Task ID**


---

**Task ID**


---

**Operations**


---

snmp

---

read, write

This example shows how to configure the generation of SNMP traps in response to packet loss:

```
RP/0/RSP0/CPU0:router(config)# snmp-server mibs eventmib packet-loss pos 0/1/0/0
 falling 1 interval 5 rising 2
```

## snmp-server mibs sensormib cache

To enable and configure caching for sensor mib values, use **snmp-server mibs sensormib cache** command in global configuration mode. To restore the default values, use the **no** form of this command.

### **snmp-server mibs sensormib cache**

---

**Syntax Description** This command has no keywords or arguments.

---

**Command Default** None

---

**Command Modes** Global configuration mode.

---

<b>Release</b>	<b>Modification</b>
Release 5.3.0	This command was introduced.

---

---

**Usage Guidelines** No specific guidelines impact the use of this command.

### **Example**

```
RP/0/RSP0/CPU0:router(config)# snmp-server mibs sensormib cache
```

## snmp-server mibs subscriber threshold

To set the snmp-server mibs server threshold parameters, use the **snmp-server mibs subscriber threshold** command in the global configuration mode. To delete any of the set parameters, use the **no** form of the command.

**snmp-server mibs subscriber threshold** [ **rising** | **falling** | **delta-loss percent** | **delta-loss evaluation** ] [ **access-if location** *interface-path-id* **interval seconds** ] [ **session-count** ]

**nosnmp-server mibs subscriber threshold**

Syntax Description		
<b>rising</b>		Rising threshold value. The set value triggers the traps. Traps are generated when the number of sessions exceed the rising threshold value.
<b>falling</b>		Falling threshold value. The set value triggers the traps. Traps are generated when the number of sessions are lesser than the falling threshold value.
<b>delta-loss percent</b>		Delta-loss percentage.
<b>delta-loss evaluation</b>		The actual subscriber sessions (after delta-loss) . This is based on the set delta-loss percentage. If the number of sessions exceed the loss percentage, traps are generated.
<b>access-if</b>		Access-interface.
<b>location</b> <i>name</i>		Location name.
<b>interval</b> <i>seconds</i>		Interval between the rising and the falling thresholds (in seconds).
<b>session-count</b>		Subscriber-session count.

**Command Default** None

**Command Modes** Global configuration

Command History	Release	Modification
	Release 5.1	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The minimum delta loss interval is 30 seconds and can be incremented by 10 seconds till the time period reaches 5 minutes.

Task ID	Task ID	Operation
	snmp	read, write

### Example

```
RP/0/RSP0/CPU0:router (config) # snmp-server mibs subscriber threshold delta-loss evaluation
access-if tengige 0/4/0/0 interval 100
```

## snmp-server mibs subscriber threshold access-if

To disable the per-session access notifications by the session monitoring process, use the **snmp-server mibs subscriber threshold access-if** in the global configuration mode. To enable notifications, use the **no** form of the command.

**snmp-server mibs subscriber threshold access-if** *subsetnumber* **regular expression** *word* **notification**  
**rising-falling** **disable**  
**no snmp-server mibs subscriber threshold access-if**

Syntax Description		
	<b>subset</b> <i>number</i>	Subset number of the subscriber threshold. Lower the subset value, higher is the priority. Range is 1 to 255.
	<b>regular expression</b> <i>word</i>	Regular expression to match the interface name. Traps on the corresponding access interface(s) are disabled.
	<b>notification</b>	Name of the notification.
	<b>rising-falling</b>	The rising and falling thresholds.
	<b>disable</b>	Disables the access interface notifications.

**Command Default** Session monitoring is enabled by default

**Command Modes** Global configuration

Command History	Release	Modification
	Release 5.1	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **regular expression** keyword disables notifications of the access-interface.

Task ID	Task ID	Operation
	snmp	read, write



### Example

```
RP/0/RSP0/CPU0:router (config) # snmp-server mibs subscriber threshold access-if subset 100
regular expression notification rising-falling disable
```

## snmp-server notification-log-mib

To configure the NOTIFICATION-LOG-MIB, use the **snmp-server notification-log-mib** command in global configuration

mode. To remove the specified configuration, use the **no** form of this command.

```
snmp-server notification-log-mib {globalAgeOut time | globalSize size | default | disable | size size}
no snmp-server notification-log-mib {globalAgeOut | globalSize | default | disable | size}
```

Syntax Description	
<b>globalAgeOut</b> <i>time</i>	Specifies how much time, in minutes, a notification remains in the log. Values for the <i>time</i> argument can range from 0 to 4294967295; the default is 15.
<b>globalSize</b> <i>size</i>	Specifies the maximum number of notifications that can be logged in all logs. The default is 500.
<b>default</b>	Specifies to create a default log.
<b>disable</b>	Specifies to disable logging to the default log.
<b>size</b> <i>size</i>	Specifies the maximum number of notifications that the default log can hold. The default is 500.

**Command Default** NOTIFICATION-LOG-MIB notifications are not logged.

**Command Modes** Global configuration

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Logging of NOTIFICATION-LOG-MIB notifications begins when the default log is created. Named logs are not supported, therefore only the default log can be created.

Task ID	Task	Operations
	snmp	read, write

The following example creates a default log for notifications:

```
RP/0/RSP0/CPU0:router(config)# snmp-server notification-log-mib default
```

This example removes the default log:

```
RP/0/RSP0/CPU0:router(config)# no snmp-server notification-log-mib default
```

This example configures the size of all logs to be 1500:

```
RP/0/RSP0/CPU0:router(config)# snmp-server notification-log-mib globalSize 1500
```

### Related Topics

[snmp-server community-map](#), on page 708

## snmp-server packetsize

To establish control over the largest Simple Network Management Protocol (SNMP) packet size permitted when the SNMP server is receiving a request or generating a reply, use the **snmp-server packetsize** command in

global configuration

mode. To restore the default value, use the **no** form of this command.

**snmp-server packetsize** *size*  
**no snmp-server packetsize**

<b>Syntax Description</b>	<i>size</i> Packet size, in bytes. Range is from 484 to 65500. The default is 1500.
---------------------------	-------------------------------------------------------------------------------------

<b>Command Default</b>	<i>size</i> : 1500
------------------------	--------------------

<b>Command Modes</b>	Global configuration
----------------------	----------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

Use the **snmp-server packetsize** command to establish control over the largest SNMP packet size permitted when the SNMP server is receiving a request or generating a reply.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	snmp	read, write

This example shows how to set the maximum size of SNMP packets to 1024 bytes:

```
RP/0/RSP0/CPU0:router(config)# snmp-server packetsize 1024
```

## snmp-server queue-length

To establish the message queue length for each trap host for Simple Network Management Protocol (SNMP), use the **snmp-server queue-length** command in

global configuration

mode. To restore the default value, use the **no** form of this command.

**snmp-server queue-length** *length*

**no snmp-server queue-length**

<b>Syntax Description</b>	<b>length</b> Integer that specifies the number of trap events that can be held before the queue must be emptied. Range is from 1 to 5000.
---------------------------	--------------------------------------------------------------------------------------------------------------------------------------------

<b>Command Default</b>	<i>length</i> : 100
------------------------	---------------------

<b>Command Modes</b>	Global configuration
----------------------	----------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.2	This command was introduced.
Release 3.9.0	No modification.	

<b>Usage Guidelines</b>	<p>To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.</p>
-------------------------	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

Use the **snmp-server queue-length** command to define the length of the message queue for each trap host. After a trap message is successfully sent, Cisco IOS XR software continues to empty the queue at a throttled rate to prevent trap flooding.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	snmp	read, write

This example shows how to set the SNMP notification queue to 20 events:

```
RP/0/RSP0/CPU0:router(config)# snmp-server queue-length 20
```

## snmp-server target list

To create a Simple Network Management Protocol (SNMP) target list, use the **snmp-server target list** command in

global configuration

mode. To remove an SNMP target list, use the **no** form of this command.

```
snmp-server target list target-list {vrf vrf-name | host hostname}
no snmp-server target list target-list
```

### Syntax Description

<i>target-list</i>	Name of the target list.
<b>vrf</b> <i>vrf-name</i>	Specifies the name of the VRF hosts included in the target list.
<b>host</b> <i>hostname</i>	Assigns a hostname to the target list. The <i>hostname</i> variable is a name or IP address.

### Command Default

None

### Command Modes

Global configuration

### Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	No modification.

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use this command to create an SNMP target list and assign hosts to the list. When a target list is mapped to a community name using the **snmp-server community-map** command, SNMP access is restricted to the hosts in the target list (for that community name).

### Task ID

Task ID	Operations
snmp	read, write

In this example, a new target list “sample3” is created and assigned to the vrf server “server2:”

```
RP/0/RSP0/CPU0:router(config)# snmp-server target list sample3 vrf server2
```

### Related Topics

[snmp-server community-map](#), on page 708

# snmp-server throttle-time

To specify the throttle time for handling incoming Simple Network Management Protocol (SNMP) messages, use the **snmp-server throttle-time** command in

global configuration

mode. To restore the throttle time to its default value, use the **no** form of this command.

**snmp-server throttle-time** *time*  
**no snmp-server throttle-time**

<b>Syntax Description</b>	<i>time</i> Throttle time for the incoming queue, in milliseconds. Values can be from 50 to 1000.
---------------------------	---------------------------------------------------------------------------------------------------

<b>Command Default</b>	<i>time</i> : 0
------------------------	-----------------

<b>Command Modes</b>	Global configuration
----------------------	----------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.2	This command was introduced.
Release 3.9.0	No modification.	

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	snmp	read, write

In the following example, the throttle time is set to 500 milliseconds:

```
RP/0/RSP0/CPU0:router(config)# snmp-server throttle-time 500
```

## Related Topics

[snmp-server community-map](#), on page 708

## snmp-server timeouts subagent

To change the timeout used by the SNMP agent while it waits for a response from a subagent, use the **snmp-server timeouts subagent** command in

global configuration

mode. SNMP subagents are feature-specific entities that register with the SNMP agent and implement sets of MIB objects.

**snmp-server timeouts subagent** *timeout*

**no snmp-server timeouts subagent** *timeout*

<b>Syntax Description</b>	<i>timeout</i> The timeout used by the SNMP agent when waiting for a response from a MIB module, in seconds. The default is 10.
---------------------------	---------------------------------------------------------------------------------------------------------------------------------

<b>Command Default</b>	<i>timeout</i> : 10
------------------------	---------------------

<b>Command Modes</b>	Global configuration
----------------------	----------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.8.0	This command was introduced.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	snmp	read, write

In the following example, the timeout is set to 8 seconds:

```
RP/0/RSP0/CPU0:router (config) # snmp-server timeouts subagent 8
```



# snmp-server timeouts duplicate

To set the timeout value for the snmp-server duplicate request feature, use the **snmp-server timeouts duplicate** command in the appropriate mode. To delete the set value, use the **no** form of the command.

**snmp-server timeouts duplicate** *timeout-value*  
**no snmp-server timeouts duplicate** *timeout-value*

## Syntax Description

*timeout-value* Timeout value in seconds. Range is 0 to 20 seconds.

- 0- To Remove this feature support. i.e SNMP will process all the packets irrespective of duplicate (retry) Packets.
- 1- This is the default value, i.e if no configuration is present , then, the timeout value is set to 1. If any packet takes more than 1 second for getting processed, then the Duplicate drop feature is enabled.
- 2 to 20 - if the packet processing is done between 2 and 20 seconds, then the Duplicate drop feature is enabled.

## Command Default

1 second

## Command Modes

Global configuration

## Command History

Release	Modification
Release 5.1.1	This feature was introduced.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

## Task ID

Task ID	Operation
snmp	read, write

## Example

This example shows how to use the **snmp-server timeouts duplicate** command:

```
RP/0/RSP0/CPU0:router (config) # snmp-server timeouts duplicate 10
```

# snmp-server trap authentication vrf disable

To disable authentication traps on VPNs, use the **snmp-server trap authentication vrf disable** command in global configuration

mode.

## snmp-server trap authentication vrf disable

**Syntax Description** This command has no keywords or arguments.

**Command Default** Authentication traps are enabled on VPNs by default.

**Command Modes** Global configuration

Command History	Release	Modification
	Release 3.7.2	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operation
	snmp	read, write

This example illustrates how to disable authentication traps on VPNs:

```
RP/0/RSP0/CPU0:router(config)# snmp-server trap authentication vrf disable
```

## Related Topics

[snmp-server vrf](#), on page 816

# snmp-server trap link ietf

To enable the varbind used for linkUp and linkDown SNMP traps to utilize the RFC 2863 standard varbind, use the **snmp-server trap link ietf** command in

global configuration

mode. To restore the default value, use the **no** form of this command..

**snmp-server trap link ietf**  
**no snmp-server trap link ietf**

**Syntax Description** This command has no keywords or arguments.

**Command Default** The default varbind used is cisco.

**Command Modes** Global configuration

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

For more information about linkUP and linkDown notifications, see RFC 2863, *The Interface Group MIB*, and RFC 3418, *Management Information Base (MIB) for the Simple Network Management Protocol (SNMP)*.

Task ID	Task ID	Operations
	snmp	read, write

This example shows how to enable the RFC 2863 standard varbind:

```
RP/0/RSP0/CPU0:router# snmp-server trap link ietf
```

## Related Topics

[snmp-server engineid local](#), on page 716

[snmp-server host](#), on page 722

[snmp-server traps bgp](#), on page 776

[snmp-server traps snmp](#), on page 803

[snmp-server traps syslog](#), on page 805

## snmp-server trap throttle-time

To specify the throttle time for handling more Simple Network Management Protocol (SNMP) traps, use the **snmp-server trap throttle-time** command in

global configuration

mode. To restore the throttle time to its default value, use the **no** form of this command.

**snmp-server trap throttle-time** *time*

**no snmp-server trap throttle-time**

<b>Syntax Description</b>	<i>time</i> Throttle time in milliseconds. Values can be from 10 to 500.
---------------------------	--------------------------------------------------------------------------

<b>Command Default</b>	250
------------------------	-----

<b>Command Modes</b>	Global configuration
----------------------	----------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	snmp	read, write

In the following example, the trap throttle time is set to 500 milliseconds:

```
RP/0/RSP0/CPU0:router(config)# snmp-server trap throttle-time 500
```

### Related Topics

[snmp-server throttle-time](#), on page 763

## snmp-server traps

To enable Simple Network Management Protocol (SNMP) trap notifications, use the **snmp-server traps** command in

global configuration

mode. To disable SNMP notifications, use the **no** form of this command.

**snmp-server traps** *notification-type*

**no snmp-server traps** [*notification-type*]

---

**Syntax Description**     *notification-type*

(Optional) Type of notification (trap) to enable or disable. If no type is specified, all notifications available on the device are enabled or disabled.

The notification type can be one or more of the following keywords:

**bfd**

Enables Bidirectional Forwarding Detection (BFD) traps.

**bgp**

Enables BGP4-MIB and CISCO-BGP4-MIB traps.

**bridgemib**

Enables SNMP traps for the Bridge MIB.

**config**

Controls configuration notifications, as defined in the CISCO-CONFIG-MAN-MIB (enterprise 1.3.6.1.4.1.9.9.43.2). The notification type is: (1) ciscoConfigManEvent.

**copy-complete**

Enables CISCO-CONFIG-COPY-MIB ccCopyCompletion traps.

**ds1**

Enables SNMP Cisco DS1 traps.

**ds2**

Enables SNMP Cisco DS2 traps.

**entity**

Controls Entity MIB modification notifications. This notification type is defined in the ENTITY-MIB (enterprise 1.3.6.1.2.1.47.2) as: (1) entConfigChange.

**ethernet**

Enables Ethernet link OAM and 802.1ag connectivity fault management traps.

**flash insertion**

Enables ciscoFlashDeviceInsertedNotif.

**flash removal**

Enables ciscoFlashDeviceRemovedNotif.

**fru-ctrl**

Enables SNMP entity field-replaceable unit (FRU) control traps.

**hsrp**

Enables SNMP HSRP traps.

**ipsec tunnel start**

Enables SNMP IPsec tunnel start traps.

**ipsec tunnel stop**

Enables SNMP IPsec tunnel stop traps.

**isakmp**

Enables ISAKMP traps.

**l2vpn all**

Enables all Layer 2 VPN traps.

**l2vpn vc-down**

Enables Layer 2 VPN VC down traps.

**l2vpn vc-up**

Enables Layer 2 VPN VC up traps.

**mpls frr all**

Enables all MPLS fast reroute MIB traps.

**mpls frr protected**

Enables MPLS fast reroute tunnel protected traps.

**mpls ldp**

Enables SNMP Multiprotocol Label Switching (MPLS) Label Distribution Protocol (LDP) traps.

**mpls traffic-eng**

Enables SNMP MPLS traffic engineering traps.

**msdp peer-state-change**

Enables SNMP MSDP Peer state change traps.

**ntp**

Enables SNMP Cisco NTP traps.

**otn**

Enables SNMP Cisco optical transport network (OTN) traps.

**pim**

Enables SNMP PIM traps.

**rf**

Enables RF-MIB traps.

**sensor**

Enables SNMP entity sensor traps.

**snmp**

Enables SNMP traps.

**sonet**

Enables SONET traps.



**syslog**

Controls error message notifications (Cisco-syslog-MIB). Specify the level of messages to be sent with the **logging history** command.

**system**

Enables SNMP SYSTEMMIB-MIB traps.

**vpls**

Enables virtual private LAN service (VPLS) traps.

**vrrp events**

Enables Virtual Router Redundancy Protocol (VRRP) traps.

**Note** To display the trap notifications supported on a platform, use the online help ( ? ) function.

**Command Default**

SNMP notifications are disabled by default.

**Command Modes**

Global configuration

**Command History**

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	The <b>bridgemib</b> , <b>ds1</b> , <b>ds3</b> , <b>otn</b> , , <b>system</b> , and <b>vrrp events</b> keywords were introduced.

**Usage Guidelines**

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **snmp-server traps** command to enable trap requests for the specified notification types. To configure the router to send SNMP notifications, specify at least one **snmp-server traps** command. When the command is entered with no keyword, all notification types are enabled. When a notification type keyword is specified, only the notification type related to that keyword is enabled. To enable multiple types of notifications, issue a separate **snmp-server traps** command for each notification type.

More information about individual MIBs can be found in the SNMP Object Navigator, available through cisco.com at <http://tools.cisco.com/Support/SNMP/do/BrowseMIB.do?local=en&step=2>.

The **snmp-server traps** command is used with the **snmp-server host** command. Use the **snmp-server host** command to specify which host or hosts receive SNMP notifications.

**Task ID**

Task ID	Operations
snmp	read, write

Some SNMP trap notifications require additional Task IDs as indicated in the following table:

Notification Type	Task ID	Operations
bfd	bgp	read, write
	ospf	read, write
	isis	read, write
	mpls-te	read, write
	snmp	read, write
bgp	bgp	read, write
copy-complete	config-services	read, write
ipsec	crypto	read, write
isakmp	crypto	read, write
l2vpn	l2vpn	read, write
mpls fir	mpls-ldp	read, write
	mpls-te	read, write
mpls l3vpn	ipv4	read, write
	mpls-ldp	read, write
	mpls-te	read, write
mpls ldp	mpls-ldp	read, write
	mpls-te	read, write
mpls traffic-eng	mpls-ldp	read, write
	mpls-te	read, write
ospf	ospf	read, write
syslog	sysmgr	read, write
vpls	l2vpn	read, write

This example shows how to enable the router to send all traps to the host specified by the name myhost.cisco.com, using the community string defined as public:

```
RP/0/RSP0/CPU0:router(config)# snmp-server traps
RP/0/RSP0/CPU0:router(config)# snmp-server host myhost.cisco.com public
```

### Related Topics

[snmp-server host](#), on page 722

[snmp-server traps bgp](#), on page 776  
[snmp-server traps snmp](#), on page 803  
[snmp-server traps syslog](#), on page 805

## snmp-server traps bgp

To enable Border Gateway Protocol (BGP) state-change Simple Network Management Protocol (SNMP) notifications, use the **snmp-server traps bgp** command in global configuration mode. To disable BGP state-change SNMP notifications, use the **no** form of this command.

**snmp-server traps bgp**  
**no snmp-server traps bgp**

**Syntax Description** This command has no keywords or arguments.

**Command Default** SNMP notifications are disabled by default.

**Command Modes** Global configuration

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

SNMP notifications can be sent as traps.

Use the **snmp-server traps bgp** command to enable or disable BGP server state-change notifications, as defined in the BGP4-MIB (enterprise 1.3.6.1.2.1.15.7). The notifications types are:

- bgpEstablished
- bgpBackwardTransition

The BGP notifications are defined in the BGP-4 MIB as follows:

```

bgpTraps OBJECT IDENTIFIER ::= { bgp 7 }

bgpEstablished NOTIFICATION-TYPE
OBJECTS { bgpPeerLastError,
 bgpPeerState }
STATUS current
DESCRIPTION
"The BGP Established event is generated when the BGP FSM enters the ESTABLISHED
state."
::= { bgpTraps 1 }

bgpBackwardTransition NOTIFICATION-TYPE
OBJECTS { bgpPeerLastError,
 bgpPeerState }
STATUS current
DESCRIPTION
"The BGP BackwardTransition Event is generated when the BGP FSM moves from a higher
numbered state to a lower numbered state."
::= {bgpTraps 2}

```

For a complete description of these notifications and additional MIB functions, see the BGP4-MIB in the SNMP Object Navigator, available through [cisco.com](http://tools.cisco.com/Support/SNMP/do/BrowseMIB.do?local=en&step=2) at <http://tools.cisco.com/Support/SNMP/do/BrowseMIB.do?local=en&step=2>.

The **snmp-server traps bgp** command is used with the **snmp-server host** command. Use the **snmp-server host** command to specify which host or hosts receive SNMP notifications.

Task ID	Task ID	Operations
	snmp	read, write
	bgp	read, write

The following example shows how to enable the router to send BGP state-change notifications to the host at the address myhost.cisco.com using the community string defined as public:

```
RP/0/RSP0/CPU0:router(config)# snmp-server traps bgp
RP/0/RSP0/CPU0:router(config)# snmp-server host myhost.cisco.com version 2c public
```

### Related Topics

- [snmp-server engineid local](#), on page 716
- [snmp-server host](#), on page 722
- [snmp-server traps snmp](#), on page 803
- [snmp-server traps syslog](#), on page 805

## snmp-server traps frequency synchronization

To enable frequency synchronization MIB traps, use the **snmp-server traps frequency synchronization** command in global configuration mode. To disable frequency synchronization MIB traps, use the **no** form of this command.

**snmp-server traps frequency synchronization**  
**no snmp-server traps frequency synchronization**

**Syntax Description** This command has no keywords or arguments.

**Command Default** Frequency synchronization MIB traps are disabled.

**Command Modes** Global configuration

Command History	Release	Modification
	Release 4.3.1	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operation
	snmp	read, write

This example shows how to enable frequency synchronization MIB traps:

```
RP/0/RSP0/CPU0:router(config)# snmp-server traps frequency synchronization
```

## snmp-server traps mpls l3vpn

To enable the sending of MPLS Layer 3 VPN Simple Network Management Protocol (SNMP) notifications, use the **snmp-server traps mpls l3vpn** command in global configuration mode. To disable MPLS Layer 3 VPN SNMP notifications, use the **no** form of this command.

```
snmp-server traps mpls l3vpn {all | max-threshold-cleared | max-threshold-exceeded |
max-threshold-reissue-notif-time seconds | mid-threshold-exceeded | vrf-down | vrf-up}
no snmp-server traps mpls l3vpn
```

Syntax Description		
<b>all</b>		Enables all MPLS Layer 3 VPN traps.
<b>max-threshold-cleared</b>		Enables maximum threshold cleared traps.
<b>max-threshold-exceeded</b>		Enables maximum threshold exceeded traps.
<b>max-threshold-reissue-notif-time</b> <i>seconds</i>		Specifies the time interval for reissuing a maximum threshold notification, in seconds.
<b>mid-threshold-exceeded</b>		Enables mid-threshold exceeded traps.
<b>vrf-down</b>		Enables VRF down traps.
<b>vrf-up</b>		Enables VRF up traps.

**Command Default** SNMP notifications are disabled by default.

**Command Modes** Global configuration

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	snmp	read, write

The following example shows how to enable the device to send MPLS Layer 3 VPN traps:

```
RP/0/RSP0/CPU0:router(config)# snmp-server traps mpls l3vpn all
```

**Related Topics**

[snmp-server traps](#), on page 769



## snmp-server traps ospf errors

To enable Open Shortest Path First (OSPF) error Simple Network Management Protocol (SNMP) notifications, use the **snmp-server traps ospf errors** command in global configuration mode. To disable OSPF error SNMP notifications, use the **no** form of this command.

```
snmp-server traps ospf errors {authentication-failure | bad-packet | config-error |
virt-authentication-failure | virt-bad-packet | virt-config-error}
no snmp-server traps ospf errors {authentication-failure | bad-packet | config-error |
virt-authentication-failure | virt-bad-packet | virt-config-error}
```

Syntax Description		
<b>authentication-failure</b>	Enables SNMP traps for authentication failure errors on physical interfaces.	
<b>bad-packet</b>	Enables SNMP traps for bad packet errors on physical interfaces.	
<b>config-error</b>	Enables SNMP traps for configuration errors on physical interfaces.	
<b>virt-authentication-failure</b>	Enables SNMP traps for authentication failure errors on virtual interfaces.	
<b>virt-bad-packet</b>	Enables SNMP traps for bad packet errors on virtual interfaces.	
<b>virt-config-error</b>	Enables SNMP traps for configuration errors on virtual interfaces.	

**Command Default** SNMP notifications are disabled by default.

**Command Modes** Global configuration

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

SNMP notifications can be sent as traps.

For a complete description of OSPF error notifications and additional MIB functions, see the OSPF-TRAP-MIB in the SNMP Object Navigator, available through cisco.com at <http://tools.cisco.com/Support/SNMP/do/BrowseMIB.do?local=en&step=2>.

The **snmp-server traps ospf errors** command is used with the **snmp-server host** command. Use the **snmp-server host** command to specify which host or hosts receive SNMP notifications.

Task ID	Task ID	Operations
	snmp	read, write

This example shows how to enable the router to send OSPF error notifications to the host at the address myhost.cisco.com using the community string defined as public:

```
RP/0/RSP0/CPU0:router(config)# snmp-server traps ospf errors
RP/0/RSP0/CPU0:router(config)# snmp-server host myhost.cisco.com version 2c public
```

### Related Topics

[snmp-server engineid local](#), on page 716

[snmp-server host](#), on page 722

[snmp-server traps snmp](#), on page 803

[snmp-server traps syslog](#), on page 805

## snmp-server traps ospf lsa

To enable Open Shortest Path First (OSPF) link-state advertisement Simple Network Management Protocol (SNMP) notifications, use the **snmp-server traps ospf lsa** command in global configuration mode. To disable OSPF link state SNMP notifications, use the **no** form of this command.

```
snmp-server traps ospf lsa {lsa-maxage | lsa-originate}
no snmp-server traps ospf lsa {lsa-maxage | lsa-originate}
```

<b>Syntax Description</b>	<b>lsa-maxage</b> Enables SNMP traps for link-state advertisement maxage.						
	<b>lsa-originate</b> Enables SNMP traps for new link-state advertisement origination.						
<b>Command Default</b>	SNMP notifications are disabled by default.						
<b>Command Modes</b>	Global configuration						
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 3.7.2</td> <td>This command was introduced.</td> </tr> <tr> <td>Release 3.9.0</td> <td>No modification.</td> </tr> </tbody> </table>	Release	Modification	Release 3.7.2	This command was introduced.	Release 3.9.0	No modification.
Release	Modification						
Release 3.7.2	This command was introduced.						
Release 3.9.0	No modification.						

**Usage Guidelines**

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

SNMP notifications can be sent as traps.

For a complete description of OSPF link-state advertisement notifications and additional MIB functions, see the OSPF-TRAP-MIB in the SNMP Object Navigator, available through cisco.com at <http://tools.cisco.com/Support/SNMP/do/BrowseMIB.do?local=en&step=2>.

The **snmp-server traps ospf lsa** command is used with the **snmp-server host** command. Use the **snmp-server host** command to specify which host or hosts receive SNMP notifications.

Task ID	Task Operations ID
	snmp read, write

This example shows how to enable the router to send OSPF link-state advertisement notifications to the host at the address myhost.cisco.com using the community string defined as public:

```
RP/0/RSP0/CPU0:router(config)# snmp-server traps ospf lsa lsa-maxage
RP/0/RSP0/CPU0:router(config)# snmp-server host myhost.cisco.com version 2c public
```

**Related Topics**

[snmp-server engineid local](#), on page 716

[snmp-server host](#), on page 722

[snmp-server traps snmp](#), on page 803

[snmp-server traps syslog](#), on page 805

## snmp-server traps ospf retransmit

To enable Open Shortest Path First (OSPF) retransmission Simple Network Management Protocol (SNMP) notifications, use the **snmp-server traps ospf retransmit** command in global configuration mode. To disable OSPF retransmission SNMP notifications, use the **no** form of this command.

```
snmp-server traps ospf retransmit {packets | virt-packets}
no snmp-server traps ospf retransmit {packets | virt-packets}
```

<b>Syntax Description</b>	<b>packets</b> Enables SNMP traps for packet retransmissions on physical interfaces.						
	<b>virt-packets</b> Enables SNMP traps for packet retransmissions on virtual interfaces.						
<b>Command Default</b>	SNMP notifications are disabled by default.						
<b>Command Modes</b>	Global configuration						
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 3.7.2</td> <td>This command was introduced.</td> </tr> <tr> <td>Release 3.9.0</td> <td>No modification.</td> </tr> </tbody> </table>	Release	Modification	Release 3.7.2	This command was introduced.	Release 3.9.0	No modification.
Release	Modification						
Release 3.7.2	This command was introduced.						
Release 3.9.0	No modification.						
<b>Usage Guidelines</b>	<p>To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.</p> <p>SNMP notifications can be sent as traps.</p> <p>For a complete description of OSPF retransmission notifications and additional MIB functions, see the OSPF-TRAP-MIB in the SNMP Object Navigator, available through cisco.com at <a href="http://tools.cisco.com/Support/SNMP/do/BrowseMIB.do?local=en&amp;step=2">http://tools.cisco.com/Support/SNMP/do/BrowseMIB.do?local=en&amp;step=2</a>.</p> <p>The <b>snmp-server traps ospf retransmit</b> command is used with the <b>snmp-server host</b> command. Use the <b>snmp-server host</b> command to specify which host or hosts receive SNMP notifications.</p>						

Task ID	Task ID	Operations
	snmp	read, write

This example shows how to enable the router to send OSPF retransmission notifications to the host at the address myhost.cisco.com using the community string defined as public:

```
RP/0/RSP0/CPU0:router(config)# snmp-server traps ospf retransmit packets
RP/0/RSP0/CPU0:router(config)# snmp-server host myhost.cisco.com version 2c public
```

**Related Topics**

[snmp-server engineid local](#), on page 716

[snmp-server host](#), on page 722

[snmp-server traps snmp](#), on page 803

[snmp-server traps syslog](#), on page 805

## snmp-server traps ospf state-change

To enable Simple Network Management Protocol (SNMP) notifications for Open Shortest Path First (OSPF) neighbor state change, use the **snmp-server traps ospf state-change** command in global configuration mode. To disable OSPF state-change SNMP notifications, use the **no** form of this command.

```
snmp-server traps ospf state-change {if-state-change | neighbor-state-change | virtif-state-change |
virtneighbor-state-change}
no snmp-server traps ospf state-change {if-state-change | neighbor-state-change | virtif-state-change
| virtneighbor-state-change}
```

Syntax Description	if-state-change	Enables SNMP traps for OSPF non-virtual interface state changes.
	neighbor-state-change	Enables SNMP traps for OSPF neighbor state changes.
	virtif-state-change	Enables SNMP traps for OSPF virtual interface state changes.
	virtneighbor-state-change	Enables SNMP traps for OSPF virtual neighbor state changes.

**Command Default** SNMP notifications are disabled by default.

**Command Modes** Global configuration

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

SNMP notifications can be sent as traps.

Use the **snmp-server traps ospf state-change** command to enable or disable OSPF server state-change notifications, as defined in the MIB. One notification type is ospfNbrStateChange.

For example, the OSPF ospfNbrStateChange notification is defined in the OSPF MIB as follows:

```
! ospfNbrStateChange NOTIFICATION-TYPE
! OBJECTS {
! ospfRouterId, -- The originator of the trap
! ospfNbrIpAddress,
! ospfNbrAddressLessIndex,
! ospfNbrRtrId,
! ospfNbrState -- The new state
! }
! STATUS current
```

For a complete description of these notifications and additional MIB functions, see the OSPF-TRAP-MIB in the SNMP Object Navigator, available through cisco.com at <http://tools.cisco.com/Support/SNMP/do/BrowseMIB.do?local=en&step=2>.

The **snmp-server traps ospf state-change** command is used with the **snmp-server host** command. Use the **snmp-server host** command to specify which host or hosts receive SNMP notifications.

Task ID	Task ID	Operations
	snmp	read, write

The following example shows how to enable the router to send OSPF state-change notifications to the host at the address myhost.cisco.com using the community string defined as public:

```
RP/0/RSP0/CPU0:router(config)# snmp-server traps ospf state-change neighbor-state-change
RP/0/RSP0/CPU0:router(config)# snmp-server host myhost.cisco.com version 2c public
```

### Related Topics

- [snmp-server engineid local](#), on page 716
- [snmp-server host](#), on page 722
- [snmp-server traps snmp](#), on page 803
- [snmp-server traps syslog](#), on page 805



## snmp-server traps ospfv3 errors

To enable Open Shortest Path First (OSPF) Version 3 error Simple Network Management Protocol (SNMP) notifications, use the **snmp-server traps ospfv3 errors** command in global configuration mode. To disable OSPFv3 error SNMP notifications, use the **no** form of this command.

```
snmp-server traps ospfv3 errors [{bad-packet | config-error | virt-bad-packet | virt-config-error}]
no snmp-server traps ospfv3 errors [{bad-packet | config-error | virt-bad-packet | virt-config-error}]
```

<b>Syntax Description</b>	<b>bad-packet</b>	Enables SNMP traps for bad packet errors on physical interfaces.
	<b>config-error</b>	Enables SNMP traps for configuration errors on physical interfaces.
	<b>virt-bad-packet</b>	Enables SNMP traps for bad packet errors on virtual interfaces.
	<b>virt-config-error</b>	Enables SNMP traps for configuration errors on virtual interfaces.
<b>Command Default</b>	SNMP notifications are disabled by default.	
<b>Command Modes</b>	Global configuration	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 4.2.1	This command was introduced.
<b>Usage Guidelines</b>	<p>To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.</p> <p>SNMP notifications can be sent as traps.</p> <p>For a complete description of OSPFv3 error notifications and additional MIB functions, see the OSPFV3-MIB in the SNMP Object Navigator, available through cisco.com at <a href="http://tools.cisco.com/Support/SNMP/do/BrowseMIB.do?local=en&amp;step=2">http://tools.cisco.com/Support/SNMP/do/BrowseMIB.do?local=en&amp;step=2</a>.</p> <p>The <b>snmp-server traps ospfv3 errors</b> command is used with the <b>snmp-server host</b> command. Use the <b>snmp-server host</b> command to specify which host or hosts receive SNMP notifications.</p>	
<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	snmp	read, write

This example shows how to enable the router to send OSPF error notifications to the host at the address myhost.cisco.com using the community string defined as public:

```
RP/0/RSP0/CPU0:router(config)# snmp-server traps ospfv3 errors
RP/0/RSP0/CPU0:router(config)# snmp-server host myhost.cisco.com version 2c public
```

**Related Topics**

[snmp-server engineid local](#), on page 716

[snmp-server host](#), on page 722

[snmp-server traps snmp](#), on page 803

[snmp-server traps syslog](#), on page 805

## snmp-server traps ospfv3 state-change

To enable Simple Network Management Protocol (SNMP) notifications for Open Shortest Path First (OSPF) Version 3 state changes, use the **snmp-server traps ospfv3 state-change** command in global configuration mode. To disable OSPFv3 state-change SNMP notifications, use the **no** form of this command.

```
snmp-server traps ospfv3 state-change [{if-state-change | neighbor-state-change | nssa-state-change
| restart-helper-status-change | restart-status-change | restart-virtual-helper-status-change |
virtif-state-change | virtneighbor-state-change}]
no snmp-server traps ospfv3 state-change [{if-state-change | neighbor-state-change | nssa-state-change
| restart-helper-status-change | restart-status-change | restart-virtual-helper-status-change |
virtif-state-change | virtneighbor-state-change}]
```

Syntax Description		
<b>if-state-change</b>		Enables SNMP traps for OSPFv3 non-virtual interface state changes.
<b>neighbor-state-change</b>		Enables SNMP traps for OSPFv3 neighbor state changes
<b>nssa-state-change</b>		Enables SNMP traps for OSPFv3 not so stubby area (NSSA) status changes.
<b>restart-helper-status-change</b>		Enables SNMP traps for OSPFv3 restart helper status changes.
<b>restart-status-change</b>		Enables SNMP traps for OSPFv3 restart status changes.
<b>restart-virtual-helper-status-change</b>		Enables SNMP traps for OSPFv3 virtual helper restart status changes.
<b>virtif-state-change</b>		Enables SNMP traps for OSPFv3 virtual interface state changes.
<b>virtneighbor-state-change</b>		Enables SNMP traps for OSPFv3 virtual neighbor state changes.

**Command Default** SNMP notifications are disabled by default.

**Command Modes** Global configuration

Command History	Release	Modification
	Release 4.2.1	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

SNMP notifications can be sent as traps.

Use the **snmp-server traps ospfv3 state-change** command to enable or disable the various OSPFv3 server state-change notifications, as defined in the MIB.

The **snmp-server traps ospfv3 state-change** command is used with the **snmp-server host** command. Use the **snmp-server host** command to specify which host or hosts receive SNMP notifications.

Task ID	Task ID	Operations
	snmp	read, write

The following example shows how to enable the router to send OSPFv3 NSSA state-change notifications to the host at the address myhost.cisco.com using the community string defined as public:

```
RP/0/RSP0/CPU0:router(config)# snmp-server traps ospfv3 state-change nssa-state-change
RP/0/RSP0/CPU0:router(config)# snmp-server host myhost.cisco.com version 2c public
```

### Related Topics

[snmp-server engineid local](#), on page 716

[snmp-server host](#), on page 722

[snmp-server traps snmp](#), on page 803

[snmp-server traps syslog](#), on page 805

# snmp-server traps pim interface-state-change

To enable Protocol Independent Multicast (PIM) interface status notification, use the **snmp-server traps pim interface-state-change** command in global configuration mode. To disable this command so no notification is sent, use the **no** form of this command.

```
snmp-server traps pim interface-state-change
no snmp-server traps pim interface-state-change
```

<b>Syntax Description</b>	This command has no keywords or arguments.	
<b>Command Default</b>	Simple Network Management Protocol (SNMP) notifications are disabled by default.	
<b>Command Modes</b>	Global configuration	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines**

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **snmp-server host** command to specify which host or hosts receive SNMP notifications.

Use the **snmp-server traps pim interface-state-change** command to send notifications when a PIM interface changes status from up to down. When the status is up, the notification signifies the restoration of a PIM interface. When the status is down, the notification signifies the loss of a PIM interface.

PIM notifications are defined in the CISCO-PIM-MIB.my and PIM-MIB.my files that can be accessed from the SNMP Object Navigator, available through cisco.com at <http://tools.cisco.com/Support/SNMP/do/BrowseMIB.do?local=en&step=2>.

Task ID	Task ID	Operations
	snmp	read, write

This example shows how to use the **snmp-server traps pim interface-state-change** command:

```
RP/0/RSP0/CPU0:router(config)# snmp-server traps pim interface-state-change
RP/0/RSP0/CPU0:router(config)# snmp-server host myhost.cisco.com version 2c public
```

## Related Topics

- [snmp-server engineid local](#), on page 716
- [snmp-server host](#), on page 722

[snmp-server traps pim invalid-message-received](#), on page 795

[snmp-server traps pim neighbor-change](#), on page 797

[snmp-server traps pim rp-mapping-change](#), on page 799

[snmp-server traps snmp](#), on page 803

[snmp-server traps syslog](#), on page 805

# snmp-server traps pim invalid-message-received

To enable notifications for monitoring invalid Protocol Independent Multicast (PIM) protocol operations, such as invalid register received and invalid join or prune received, use the **snmp-server traps pim invalid-message-received** command in global configuration mode. To disable this command so that no notification is sent, use the **no** form of this command.

```
snmp-server traps pim invalid-message-received
no snmp-server traps pim invalid-message-received
```

## Syntax Description

This command has no keywords or arguments.

## Command Default

Simple Network Management Protocol (SNMP) notifications are disabled by default.

## Command Modes

Global configuration

## Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	No modification.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **snmp-server host** command to specify which host or hosts receive SNMP notifications.

A router can receive a join or prune message in which the RP specified in the packet is not the RP for the multicast group. Or a router can receive a register message from a multicast group in which it is not the RP.

PIM notifications are defined in the CISCO-PIM-MIB.my and PIM-MIB.my files that can be accessed from the SNMP Object Navigator, available through cisco.com at <http://tools.cisco.com/Support/SNMP/do/BrowseMIB.do?local=en&step=2>.

## Task ID

Task ID	Operations
snmp	read, write

The following example shows how to use the **snmp-server traps pim invalid-message-received** command:

```
RP/0/RSP0/CPU0:router(config)# snmp-server traps pim invalid-message-received
RP/0/RSP0/CPU0:router(config)# snmp-server host myhost.cisco.com version 2c public
```

## Related Topics

[snmp-server engineid local](#), on page 716

[snmp-server host](#), on page 722  
[snmp-server traps pim interface-state-change](#), on page 793  
[snmp-server traps pim neighbor-change](#), on page 797  
[snmp-server traps pim rp-mapping-change](#), on page 799  
[snmp-server traps snmp](#), on page 803  
[snmp-server traps syslog](#), on page 805



# snmp-server traps pim neighbor-change

To enable Protocol Independent Multicast (PIM) neighbor status down notifications, use the **snmp-server traps pim neighbor-change** command in global configuration mode. To disable PIM neighbor down notifications, use the **no** form of this command.

**snmp-server traps pim neighbor-change**  
**no snmp-server traps pim neighbor-change**

## Syntax Description

This command has no keywords or arguments.

## Command Default

PIM Simple Network Management Protocol (SNMP) notifications are disabled by default.

## Command Modes

Global configuration

## Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	No modification.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **snmp-server traps pim neighbor-change** command to send notifications when a PIM neighbor changes status from up to down on an interface. Use the **snmp-server host** command to specify which host or hosts receive SNMP notifications.

PIM notifications are defined in the CISCO-PIM-MIB.my and PIM-MIB.my files that can be accessed from the SNMP Object Navigator, available through cisco.com at <http://tools.cisco.com/Support/SNMP/do/BrowseMIB.do?local=en&step=2>.

## Task ID

Task ID	Operations
snmp	read, write

This example shows how to enable the router to send PIM neighbor status down notifications to the host at the address myhost.cisco.com using the community string defined as public:

```
RP/0/RSP0/CPU0:router(config)# snmp-server traps pim neighbor-change
RP/0/RSP0/CPU0:router(config)# snmp-server host myhost.cisco.com version 2c public
```

## Related Topics

[snmp-server engineid local](#), on page 716

[snmp-server host](#), on page 722

[snmp-server traps pim interface-state-change](#), on page 793  
[snmp-server traps pim invalid-message-received](#), on page 795  
[snmp-server traps pim rp-mapping-change](#), on page 799  
[snmp-server traps snmp](#), on page 803  
[snmp-server traps syslog](#), on page 805

# snmp-server traps pim rp-mapping-change

To enable notifications indicating a change in the rendezvous point (RP) mapping information due to either Auto-RP or bootstrap router (BSR) messages, use the **snmp-server traps pim rp-mapping-change** command in global configuration mode. To disable this command so no notification is sent, use the **no** form of this command.

**snmp-server traps pim rp-mapping-change**  
**no snmp-server traps pim rp-mapping-change**

**Syntax Description** This command has no keywords or arguments.

**Command Default** PIM SNMP notifications are disabled by default.

**Command Modes** Global configuration

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **snmp-server host** command to specify which host or hosts receive SNMP notifications.

PIM notifications are defined in the CISCO-PIM-MIB.my and PIM-MIB.my files that can be accessed from the SNMP Object Navigator, available through cisco.com at <http://tools.cisco.com/Support/SNMP/do/BrowseMIB.do?local=en&step=2>.

Task ID	Task	Operations
	snmp	read, write

This example shows how to use the **snmp-server traps pim rp-mapping-change** command:

```
RP/0/RSP0/CPU0:router(config)# snmp-server traps pim rp-mapping-change
RP/0/RSP0/CPU0:router(config)# snmp-server host myhost.cisco.com version 2c public
```

## Related Topics

[snmp-server engineid local](#), on page 716

[snmp-server host](#), on page 722

[snmp-server traps pim interface-state-change](#), on page 793

[snmp-server traps pim neighbor-change](#), on page 797

[snmp-server traps pim invalid-message-received](#), on page 795

[snmp-server traps snmp](#), on page 803

[snmp-server traps syslog](#), on page 805

## snmp-server traps rsvp

To enable the sending of Resource Reservation Protocol (RSVP) notifications, use the **snmp-server traps rsvp** command in global configuration mode. To disable RSVP notifications, use the **no** form of this command.

**snmp-server traps rsvp** {all | lost-flow | new-flow}

Syntax Description	all	lost-flow	new-flow
	Enables the sending of both new flow lost flow traps.	Enables the sending of traps when a flow is deleted.	Enables the sending of traps when a flow is created.

**Command Default** None

**Command Modes** Global configuration

Command History	Release	Modification
	Release 3.9.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operation
	mpls-te	read, write
	ouni	read, write
	snmp	read, write

This example illustrates how to enable all SNMP RSVP MIB traps.

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# snmp-server traps rsvp all
```

## snmp-server traps selective-vrf-download role-change

To attempt to download only those prefixes and labels to a physical entity required to forward traffic through the physical entity, use the **snmp-server trap selective-vrf-download role-change** command in global configuration mode.

### snmp-server trap selective-vrf-download role-change

This command has no keywords or arguments.

<b>Command Default</b>	Selective VRF downloads are disabled.
------------------------	---------------------------------------

<b>Command Modes</b>	Global configuration
----------------------	----------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 4.2.0	This command was introduced.

### Usage Guidelines

The selective VRF download feature makes a best effort to download only those prefixes and labels to a physical entity required to forward traffic through the physical entity. This is accomplished by characterizing roles for physical entities based on their configuration.

From a network management point of view the CISCO-SELECTIVE-VRF-DOWNLOAD-MIB:

- Lists the state relating to the selective VRF download feature for each physical entity capable of forwarding packets.
- Lists the role change history per address family (ipv4 and ipv6) for each physical entity capable of forwarding packets.
- Lists the VRF tables selectively downloaded to each physical entity capable of forwarding packets.

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	snmp	read, write
	basic-services	read, write

This example shows how to enable the selective VRF downloads:

```
RP/0/RSP0/CPU0:router(config)# snmp-server traps selective-vrf-download role-change
```

## snmp-server traps snmp

To enable the sending of RFC 1157 Simple Network Management Protocol (SNMP) notifications, use the **snmp-server traps snmp** command in the appropriate configuration mode. To disable RFC 1157 SNMP notifications, use the **no** form of this command.

```
snmp-server traps snmp [{authentication | coldstart | linkdown | linkup | warmstart}]
no snmp-server traps snmp [{authentication | coldstart | linkdown | linkup | warmstart}]
```

Syntax Description	authentication	(Optional) Controls the sending of SNMP authentication failure notifications.
	linkup	(Optional) Controls the sending of SNMP linkUp notifications
	linkdown	(Optional) Controls the sending of SNMP linkDown notifications
	coldstart	(Optional) Controls the sending of SNMP coldStart notifications.
	warmstart	(Optional) Controls the sending of SNMP warmStart notifications.

**Command Default** SNMP notifications are disabled by default.

**Command Modes** Global configuration

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	The <b>authentication</b> , <b>linkup</b> , <b>linkdown</b> , <b>coldstart</b> , and <b>warmstart</b> keywords were added.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **snmp-server traps snmp** command is used with the **snmp-server host** command. Use the **snmp-server host** command to specify which host or hosts receive SNMP notifications.

The optional **authentication** keyword controls the sending of SNMP authentication failure notifications. In order to send notifications, you must configure at least one **snmp-server host** command. An authentication Failure (4) trap signifies that the sending device is the addressee of a protocol message that is not properly authenticated. The authentication method depends on the version of SNMP being used. For SNMPv1 or SNMPv2, authentication failure occurs for packets with an incorrect community string. For SNMPv3, authentication failure occurs for packets with an incorrect Secure Hash Algorithm (SHA) or Message Digest 5 (MD5) authentication key or for a packet that is outside the authoritative SNMP engine's window, for

example, the packets that are configured outside access lists or time ranges. In such an instance, only a report Protocol Data Unit (PDU) is generated, and authentication failure traps are not generated.

The optional **linkup** keyword controls the sending of SNMP linkUp notifications. The linkUp(3) trap signifies that the sending device recognizes one of the communication links represented in the agent's configuration coming up.

The optional **linkdown** keyword controls the sending of SNMP linkDown notifications. The linkDown(2) trap signifies that the sending device recognizes a failure in one of the communication links represented in the agent's configuration.

The **snmp-server traps snmp** command with the **linkup** or **linkdown** keywords globally enables or disables SNMP linkUp and linkDown traps. After enabling either of these traps globally, you can enable or disable these traps on specific interfaces using the **no notification linkupdown disable** command in interface configuration mode. According to RFC 2863, linkUp and linkDown traps are enabled for interfaces that do not operate on top of any other interface (as defined in the ifStackTable), and are disabled otherwise. This means that you do not have to enable linkUp and linkdown notifications on such interfaces. However, linkUp and linkDown notifications will not be sent unless you enable them globally using the **snmp-server traps snmp** command.

The optional **coldstart** keyword controls the sending of SNMP coldStart notifications. The coldStart(0) trap signifies that the sending device is reinitializing itself such that the agent's configuration or the protocol entity implementation may be altered.

The optional **warmstart** keyword controls the sending of SNMP coldStart notifications. The warmStart(1) trap signifies that the sending device is reinitializing itself such that neither the agent configuration nor the protocol entity implementation is altered.

Task ID	Task ID	Operations
	snmp	read, write

This example shows how to enable the device to send all traps to the host myhost.cisco.com using the community string defined as public:

```
RP/0/RSP0/CPU0:router(config)# snmp-server traps snmp
RP/0/RSP0/CPU0:router(config)# snmp-server host myhost.cisco.com public snmp
```

The following example shows how to enable only linkUp and linkDown traps:

```
RP/0/RSP0/CPU0:router(config)# snmp-server traps snmp linkup
RP/0/RSP0/CPU0:router(config)# snmp-server traps snmp linkdown
```

### Related Topics

- [snmp-server engineid local](#), on page 716
- [snmp-server host](#), on page 722
- [snmp-server traps bgp](#), on page 776
- [snmp-server traps syslog](#), on page 805



# snmp-server traps syslog

To enable Simple Network Management Protocol (SNMP) notifications of Cisco-syslog-MIB error messages, use the **snmp-server traps syslog** command in the appropriate configuration mode. To disable these types of notifications, use the **no** form of this command.

**snmp-server traps syslog**  
**no snmp-server traps syslog**

**Syntax Description** This command has no keywords or arguments.

**Command Default** SNMP notifications are disabled by default.

**Command Modes** Global configuration

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **snmp-server traps syslog** command is used with the **snmp-server host** command. Use the **snmp-server host** command to specify which host or hosts receive SNMP notifications.

Task ID	Task ID	Operations
	snmp	read, write

The following example shows how to enable Cisco-syslog-MIB error message notifications to the host at the address myhost.cisco.com, using the community string defined as public:

```
RP/0/RSP0/CPU0:router(config)# snmp-server traps syslog
RP/0/RSP0/CPU0:router(config)# snmp-server host myhost.cisco.com version 2c public
```

## Related Topics

- [snmp-server engineid local](#), on page 716
- [snmp-server host](#), on page 722
- [snmp-server traps bgp](#), on page 776
- [snmp-server traps snmp](#), on page 803

## snmp-server trap-source

To specify the interface (and hence the corresponding IP address) from which a Simple Network Management Protocol (SNMP) trap should originate, use the **snmp-server trap-source** command in

global configuration

mode. To remove the source designation, use the **no** form of this command.

**snmp-server trap-source** *type interface-path-id*

**no snmp-server trap-source**

### Syntax Description

*type* Interface type. For more information, use the question mark (?) online help function.

*interface-path-id* Physical interface or virtual interface.

**Note** Use the **show interfaces** command to see a list of all interfaces currently configured on the router.

For more information about the syntax for the router, use the question mark (?) online help function.

### Command Default

No interface is specified.

### Command Modes

Global configuration

### Command History

#### Release

#### Modification

Release 3.7.2

This command was introduced.

Release 3.9.0

No modification.

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

When an SNMP trap is sent from a Cisco SNMP device, it has a notification address of the interface it happened to exit at that time. Use the **snmp-server trap-source** command to monitor notifications from a particular interface.



#### Note

In references to a Management Ethernet interface located on a route switch processor card, the physical slot number is numeric (0 through n-1 where n is the number of line card slots in the chassis) and the module is CPU0. Example: interface MgmtEth0/1/CPU0/0.

Task ID	Task ID	Operations
	snmp	read, write

The following example shows how to specify that the IP address for interface 0/0/1/0 is the source for all SNMP notifications:

```
RP/0/RSP0/CPU0:router(config)# snmp-server trap-source tengige 0/0/1/0
```

### Related Topics

- [snmp-server engineid local](#), on page 716
- [snmp-server host](#), on page 722
- [snmp-server traps bgp](#), on page 776
- [snmp-server traps snmp](#), on page 803
- [snmp-server traps syslog](#), on page 805

## snmp-server traps subscriber session-aggregation

To set the session aggregation parameters, use the **snmp-server traps subscriber session** command in global configuration mode. To delete the set parameters, use the no form of the command.

**snmp-server traps subscriber session-aggregation** [ **access-interface** | **node** ]

**no snmp-server traps subscriber session-aggregation** [ **access-interface** | **node** ]

Syntax Description	
<b>access-interface</b>	Subscriber notification at access interface level.
<b>node</b>	Subscriber notification at node level.

**Command Default** None

**Command Modes** Global configuration

Command History	Release	Modification
	Release 5.1	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **snmp-server traps subscriber session-aggregation** command to enable CISCO-SUBSCRIBER-SESSION-MIB notifications (traps). Notifications will include MIB's asynchronous events.

Task ID	Task ID	Operation
	snmp	read, write

### Example

```
RP/0/RSP0/CPU0:router (config)# snmp-server traps subscriber session-aggregation node
```

# snmp-server trap-timeout

To define how often to try resending trap messages on the retransmission queue, use the **snmp-server trap-timeout** command in

global configuration

mode. To restore the default value, use the **no** form of this command.

**snmp-server trap-timeout** *seconds*  
**no snmp-server trap-timeout** *seconds*

<b>Syntax Description</b>	<i>seconds</i> Integer that sets the interval for resending the messages, in seconds). Value can be from 1 to 1000.
---------------------------	---------------------------------------------------------------------------------------------------------------------

<b>Command Default</b>	<i>seconds</i> : 30
------------------------	---------------------

<b>Command Modes</b>	Global configuration
----------------------	----------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.2	This command was introduced.
Release 3.9.0	No modification.	

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

Before Cisco IOS XR software tries to send a trap, it looks for a route to the destination address. If there is no known route, the trap is saved in a retransmission queue. Use the **snmp-server trap-timeout** command to determine the number of seconds between retransmission attempts.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	snmp	read, write

The following example shows how to set an interval of 20 seconds to try resending trap messages on the retransmission queue:

```
RP/0/RSP0/CPU0:router(config)# snmp-server trap-timeout 20
```

## Related Topics

[snmp-server engineid local](#), on page 716

[snmp-server host](#), on page 722

[snmp-server traps bgp](#), on page 776

[snmp-server traps snmp](#), on page 803

[snmp-server traps syslog](#), on page 805

## snmp-server user

To configure a new user to a Simple Network Management Protocol (SNMP) group, use the **snmp-server user** command in

global configuration

mode. To remove a user from an SNMP group, use the **no** form of this command.

```
snmp-server user username groupname {v1 | v2c | v3 [auth {md5 | sha} {clear | encrypted}
auth-password [priv {3des | aes aes-bit-encryption | des56} {clear | encrypted} priv-password]]}
[{SDROwner | SystemOwner}] [access-list-name]
no snmp-server user username groupname
```

### Syntax Description

<i>username</i>	Name of the user on the host that connects to the agent. <b>Note</b> The recommended range for a user-defined username is 2-253 characters.
<i>groupname</i>	Name of the group to which the user belongs.
<b>v1</b>	Specifies that the SNMPv1 security model should be used.
<b>v2c</b>	Specifies that the SNMPv2c security model should be used.
<b>v3</b>	Specifies that the SNMPv3 security model should be used.
<b>auth</b>	(Optional) Specifies which authentication level should be used. If this keyword is used, you must specify an authentication level and an authorization password.
<b>md5</b>	Specifies the HMAC-MD5-96 authentication level.
<b>sha</b>	Specifies the HMAC-SHA-96 authentication level.
<b>clear</b>	Specifies that an unencrypted password follows.
<b>encrypted</b>	Specifies that an encrypted password follows.
<i>auth-password</i>	Authentication password, which is a string (not to exceed 64 characters) that enables the agent to receive packets from the host.
<b>priv</b>	(Optional) Specifies that encryption parameters follow.
<b>3des</b>	Specifies the 168-bit Triple Data Encryption Standard (3DES) level of encryption for the user.
<b>aes</b> <i>aes-bit-encryption</i>	Specifies the Advanced Encryption Standard (AES) level of encryption for the user. Supported options are 128, 192 and 256 bit encryption.
<b>des56</b>	Specifies the 56-bit Data Encryption Standard (DES) level of encryption for the user.

<i>priv-password</i>	Privacy password, which can be clear or encrypted text, according to what is specified.
<b>SDROwner</b>	(Optional) Limits access to the agents for the owner secure domain router (SDR) only.
<b>SystemOwner</b>	(Optional) Provides system-wide access to the agents for all SDRs.
<i>access-list-name</i>	(Optional) Access list to be associated with this SNMP user. The <i>access-list-name</i> argument represents a value from 1 to 99, that is, the identifier of the standard IP access list.

**Command Default** By default, access is limited to agents on the owner SDR only.

See also [Table 68: snmp-server user Default Descriptions, on page 812](#).

**Command Modes** Global configuration

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.2	This command was introduced.
	Release 3.9.0	AES and 3DES encryption formats were supported.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

To use 3DES and AES encryption standards, you must have installed the security package (k9sec). For information on installing software packages, see *Upgrading and Managing Cisco IOS XR Software* in *System Management Configuration Guide for Cisco ASR 9000 Series Routers*.



**Note** Only one remote host can be assigned to the same username for SNMP version 3. If you configure the same username with different remote hosts, only the last username and remote host combination will be accepted and will be seen in the **show running** configuration. In the case of multiple SNMP managers, multiple unique usernames are required.

**Table 68: snmp-server user Default Descriptions**

<b>Characteristic</b>	<b>Default</b>
passwords	Text strings are assumed.
access lists	Access from all IP access lists is permitted.

### **SDR and System-wide Access**

When the **snmp-server user** command is entered with the **SDROwner** keyword, SNMP access is granted only to the MIB object instances in the owner SDR.



When the **snmp-server user** command is entered with the **SystemOwner** keyword, SNMP access is granted to the entire system.

Task ID	Task ID	Operations
	snmp	read, write

The following example shows how to enter a plain-text password for the string *abcd* for user2 in group2:

```
RP/0/RSP0/CPU0:router(config)# snmp-server user user2 group2 v3 auth md5 clear abcd
```

To learn if this user has been added to the configuration, use the **show snmp user** command.

If the localized Message Digest 5 (MD5) or Secure Hash Algorithm (SHA) digest is known, specify that string instead of the plain-text password. The digest should be formatted as AA:BB:CC:DD where AA, BB, CC, and DD are hexadecimal values. The digest should also be exactly 16 octets long.

This example shows how to specify the command with a digest name of 00:11:22:33:44:55:66:77:88:99:AA:BB:CC:DD:EE:FF:

```
RP/0/RSP0/CPU0:router(config)# snmp-server user user2 group2 v3 auth md5 encrypted
00:11:22:33:44:55:66:77:88:99:AA:BB:CC:DD:EE:FF
```

### Related Topics

[snmp-server group](#), on page 719

## snmp-server view

To create or update a Simple Network Management Protocol (SNMP) view entry, use the **snmp-server view** command in

global configuration

mode. To remove the specified server view entry, use the **no** form of this command.

```
snmp-server view view-name oid-tree {excluded | included}
no snmp-server view view-name oid-tree {excluded | included}
```

### Syntax Description

<i>view-name</i>	Label for the view record being updated or created. The name is used to reference the record.
<i>oid-tree</i>	Object identifier (OID) of the ASN.1 subtree to be included or excluded from the view. To identify the subtree, specify a text string consisting of numbers, such as 1.3.6.2.4, or a word, such as <i>system</i> . Replace a single subidentifier with the asterisk (*) wildcard to specify a subtree family; for example 1.3.*.4.
<b>excluded</b>	Excludes the MIB family from the view.
<b>included</b>	Includes the MIB family in the view.

### Command Default

No view entry exists.

### Command Modes

Global configuration

### Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	No modification.

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Other SNMP commands require a view as a keyword. Use the **snmp-server view** command to create a view to be used as keywords for other commands that create records including a view.

Instead of defining a view explicitly, you can rely on the following predefined views, which are supported by the SNMP agent:

#### **all**

Predefined view indicating that a user can see all objects.

#### **CfgProt**

Predefined view indicating that a user can see all objects except the SNMPv3 configuration tables.

#### **vacmViewTreeFamilyEntry**

Predefined view indicating that a user can see the default configuration of vacmViewTreeFamilyEntry.

The predefined views supported on Cisco IOS XR software, however, do not match the predefined views specified in RFC 3415.

Task ID	Task ID	Operations
	snmp	read, write

This example creates a view that includes all objects in the MIB-II subtree:

```
RP/0/RSP0/CPU0:router(config)# snmp-server view mib2 1.3.6.1.2.1 included
```

This example shows how to create a view that includes all objects in the MIB-II system group and all objects in the Cisco enterprise MIB:

```
RP/0/RSP0/CPU0:router(config)# snmp-server view view1 1.3.6.1.2.1.1 included
RP/0/RSP0/CPU0:router(config)# snmp-server view view1 1.3.6.1.4.1.9 included
```

This example shows how to create a view that includes all objects in the MIB-II system group except for sysServices (System 7) and all objects for interface 1 in the MIB-II interfaces group:

```
RP/0/RSP0/CPU0:router(config)# snmp-server view view1 1.3.6.1.2.1.1 included
RP/0/RSP0/CPU0:router(config)# snmp-server view view1 1.3.6.1.2.1.1.7 excluded
RP/0/RSP0/CPU0:router(config)# snmp-server view view1 1.3.6.1.2.1.2.2.1.*.1 included
```

### Related Topics

[show snmp view](#), on page 704

[snmp-server group](#), on page 719

## snmp-server vrf

To configure the VPN routing and forwarding (VRF) properties of Simple Network Management Protocol (SNMP), use the **snmp-server vrf** command in

global configuration

mode. To remove the configuration, use the **no** form of this command.

**snmp-server vrf** *vrf-name* [**host** *address* [{**clear** | **encrypted**}]] [**traps**] [**version** {**1** | **2c** | **3** *security-level*}] [*community-string*] [**udp-port** *port*] [**context** *context-name*]

**no snmp-server vrf** *vrf-name*

Syntax Description	
<i>vrf-name</i>	Name of the VRF.
<b>host</b> <i>address</i>	(Optional) Specifies the name or IP address of the host (the targeted recipient).
<b>clear</b>	(Optional) Specifies that the <i>community-string</i> argument is clear text.
<b>encrypted</b>	(Optional) Specifies that the <i>community-string</i> argument is encrypted text.
<b>traps</b>	(Optional) Specifies that notifications should be sent as traps. This is the default.
<b>version</b> { <b>1</b>   <b>2c</b>   <b>3</b> }	(Optional) Specifies the version of the SNMP used to send the traps. The default is SNMPv1. When the <b>version</b> keyword is used, one of these keywords must be specified: <ul style="list-style-type: none"> <li>• <b>1</b>—SNMPv1</li> <li>• <b>2c</b>—SNMPv2C</li> <li>• <b>3</b>—SNMPv3</li> </ul>
<i>security-level</i>	(Optional) Security level for SNMPv3. Options are: <ul style="list-style-type: none"> <li>• <b>auth</b>—authNoPriv</li> <li>• <b>noauth</b>—noAuthNoPriv</li> <li>• <b>priv</b>—authPriv</li> </ul>
<i>community-string</i>	Specifies the community string for SNMPv1 and SNMPv2, or the SNMPv3 user.
<b>udp-port</b> <i>port</i>	(Optional) Specifies the UDP port to which notifications should be sent.
<b>context</b> <i>context-name</i>	(Optional) Name of the context that must be mapped to VRF identified by value of the <i>vrf-name</i> argument.

**Command Default** None

**Command Modes** Global configuration

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use this command to enter SNMP VRF configuration mode and configure an SNMP notification recipient on a VRF. You can also map a VRF to an SNMP context.

SNMP notification recipient that is reachable by way of a VRF can be configured. Notification is forwarded to the recipient represented by its address using the routing table instance identified by the VRF name.

The *address* argument can be either a host name or an IP address.

Use the **clear** keyword to specify that the clear text community string you enter is displayed encrypted in the **show running** command output. To enter an encrypted string, use the **encrypted** keyword. To enter a clear text community string that is not encrypted by the system, use neither of these keywords.

An SNMP context identified by the value of the *context-name* argument can be mapped to a VRF in this mode. This context must be created using **snmp-server context** command.

Task ID	Task ID	Operations
	snmp	read, write

This example shows how to configure a host IP address for a VRF name:

```
RP/0/RSP0/CPU0:router(config)# snmp-server vrf vrfa
RP/0/RSP0/CPU0:router(config-snmp-vrf)# host 12.21.0.1 traps version
2c public udp-port 2525
```

### Related Topics

[snmp-server context](#), on page 711

[snmp-server host](#), on page 722

# transfer-interval

To configure how long bulk statistics should be collected before a bulk statistics transfer is initiated, use the **transfer-interval** command in bulk statistics transfer configuration mode. To remove a previously configured interval from a bulk statistics configuration, use the **no** form of this command.

**transfer-interval** *minutes*  
**no transfer-interval** *minutes*

<b>Syntax Description</b>	<i>minutes</i> Length of time, in minutes, that the system should collect MIB data before attempting the transfer operation. The valid range is from 1 to 2147483647. The default is 30.
---------------------------	------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

<b>Command Default</b>	Bulk statistics file transfer operations start 30 minutes after the <b>enable (bulkstat)</b> command is used.
------------------------	---------------------------------------------------------------------------------------------------------------

<b>Command Modes</b>	Bulk statistics transfer configuration
----------------------	----------------------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 4.2.0	This command was introduced.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

Bulk statistics data is collected into a new file when a transfer attempt begins, which means that this command also configures the collection interval.

If the maximum buffer size for a bulk statistics file is reached before the transfer interval time expires, the transfer operation is still initiated, and bulk statistics MIB data are collected into a new file in the system buffer.

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	snmp	read, write

The following example shows how to configure a transfer interval of 20 minutes for the bulk statistics configuration bulkstat1:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# snmp-server mib bulkstat transfer-id bulkstat1
RP/0/RSP0/CPU0:router(config-bulk-tr)# transfer-interval 20
```

## Related Topics

- [enable \(bulkstat\)](#), on page 632
- [show snmp mib bulkstat transfer](#), on page 670

[snmp-server mib bulkstat transfer-id](#), on page 744

# url

To specify the host to which bulk statistics files should be transferred, use the **url** command in bulk statistics transfer configuration mode. To remove a previously configured destination host, use the **no** form of this command.

```
url [{primary | secondary}] url
no url [{primary | secondary}] url
```

Syntax Description	
<b>primary</b>	Specifies the URL to be used first for bulk statistics transfer attempts.
<b>secondary</b>	Specifies the URL to be used for bulk statistics transfer attempts if the transfer to the primary URL is not successful.
<i>url</i>	<p>Destination URL address for the bulk statistics file transfer. Use FTP or TFTP. The syntax for these URLs is as follows:</p> <ul style="list-style-type: none"> <li>• <b>ftp</b>:[[[/username [:password]@]location]/directory]/filename</li> <li>• <b>tftp</b>:[[/location]/directory]/filename</li> </ul> <p>The location argument is typically an IP address.</p>

Command Default	
	No host is specified.

Command Modes	
	Bulk statistics transfer configuration

Command History	Release	Modification
	Release 4.2.0	This command was introduced.

Usage Guidelines	
	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

For bulk statistics transfer retry attempts, a single retry consists of an attempt to send first to the primary URL, and then to the secondary URL.

Task ID	Task ID	Operation
	snmp	read, write

In the following example, an FTP server is used as the primary destination for the bulk statistics file. If a transfer to that address fails, an attempt is made to send the file to the TFTP server at 192.168.10.5. No retry command is specified, which means that only one attempt to each destination will be made.

```
RP/0/RSP0/CPU0:router# configure
```



```
RP/0/RSP0/CPU0:router(config)# snmp-server mib bulkstat transfer ifMibTesting
RP/0/RSP0/CPU0:router(config-bulk-tr)# schema carMibTesting1
RP/0/RSP0/CPU0:router(config-bulk-tr)# schema carMibTesting2
RP/0/RSP0/CPU0:router(config-bulk-tr)# url primary
ftp://user2:pswd@192.168.10.5/functionality/
RP/0/RSP0/CPU0:router(config-bulk-tr)# url secondary tftp://user2@192.168.10.8/tftpboot/
RP/0/RSP0/CPU0:router(config-bulk-tr)# enable
RP/0/RSP0/CPU0:router(config-bulk-tr)# exit
```

### Related Topics

[show snmp mib bulkstat transfer](#), on page 670

url



## Data Collection Manager (DCM) Commands

This module describes the commands used to set and configure the Data Collection Manager (DCM) and bulkstat commands.

For more information about DCM, see the DCM chapter in the *System Management Configuration Guide for Cisco ASR 9000 Series Routers*.

- [add cmd](#) , on page 824
- [bulkstat data](#), on page 825
- [context](#), on page 826
- [data-group](#), on page 827
- [discard](#), on page 828
- [enable](#), on page 829
- [bulkstat filter](#), on page 830
- [interval](#), on page 831
- [object](#), on page 832
- [process](#), on page 833
- [bulkstat profile](#), on page 834
- [range](#), on page 835
- [repetition](#), on page 836
- [show bulkstat data-group](#), on page 837
- [show bulkstat profile](#) , on page 839
- [show dcm assa](#), on page 840
- [show dcm client](#) , on page 841
- [show dcm data-providers](#), on page 842
- [show dcm session](#), on page 843

# add cmd

To add a show command to a command data set, use the **add cmd** command in command data set mode. To remove a show command from the data set, use the **no** form of this command.

**add cmd** *command-line*  
**no add cmd** *command-line*

<b>Syntax Description</b>	<i>command-line</i> Specifies show commands for which the output should be collected.
---------------------------	---------------------------------------------------------------------------------------

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Command bulkstat data set configuration
----------------------	-----------------------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 5.2.2	This command was introduced.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	bulkstat	read, write

## Example

This example shows how to use the **add cmd** command:

```
RP/0/RSP0/CPU0:router # config
RP/0/RSP0/CPU0:router (config) # bulkstat data show-snmp type command
RP/0/RSP0/CPU0:router (config-bs-ds-cmd) # add cmd show ip interface brief
```

# bulkstat data

To configure a bulkstat data set for command type, use the **bulkstat data** command in global configuration mode. To remove the data set configuration from command type, use the **no** form of this command.

**bulkstat data** *show-stats* **type** **command**  
**no bulkstat data** *show-stats* **type** **command**

Syntax Description	
<i>show-stats</i>	Name of a data set.
<b>type</b>	Specifies the type of a data set.
<b>command</b>	Creates a command data set.

**Command Default** None

**Command Modes** Global configuration

Command History	Release	Modification
	Release 5.2.2	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task	Operation
	bulkstat	read, write

## Example

This example shows how to run the **bulkstat data** command:

```
RP/0/RSP0/CPU0:router # config
RP/0/RSP0/CPU0:router (config) # bulkstat data show-snmp type command
```

# context

To configure context for a data group, use the **context** command under bulkstat data group configuration mode. To remove the context for a data group, use the **no** form of this command.

**context** *name*  
**no context** *name*

<b>Syntax Description</b>	<i>name</i> Context name to collect data.
---------------------------	-------------------------------------------

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Bulkstat data group configuration
----------------------	-----------------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 5.2.2	This command was introduced.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	bulkstat	read, write

## Example

```
RP/0/RSP0/CPU0:router (config-bs-dg) # context cont1
```

# data-group

To add a data group to a data profile, use the **data-group** command in bulkstat profile configuration mode. To remove a data group from a profile, use the no form of this command.

**data-group** *name*  
**no data-group** *name*

<b>Syntax Description</b>	<i>name</i> Data group name. The data group should already be configured before being used to add a data group to a profile.				
<b>Command Default</b>	None				
<b>Command Modes</b>	Bulkstat profile configuration				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 5.2.2</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 5.2.2	This command was introduced.
Release	Modification				
Release 5.2.2	This command was introduced.				
<b>Usage Guidelines</b>	<p>To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.</p> <p>You can add one or more data groups to a profile, but one data group can be linked to one data profile only.</p>				
<b>Task ID</b>	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operation</th> </tr> </thead> <tbody> <tr> <td>bulkstat</td> <td>read, write</td> </tr> </tbody> </table>	Task ID	Operation	bulkstat	read, write
Task ID	Operation				
bulkstat	read, write				

## Example

This example shows how to use the **data-group** command:

```
RP/0/RSP0/CPU0:router # config
RP/0/RSP0/CPU0:router (config) # bulkstat profile p1
RP/0/RSP0/CPU0:router (config-bs-profile) # data-group data1
```

# discard

To discard the raw data for a data group, use the **discard** command under data group configuration mode. To reset back to default, use the **no** form of this command.

**discard**  
**no discard**

**Syntax Description** This command has no keywords or arguments.

**Command Default** None

**Command Modes** Bulkstat data group configuration

Command History	Release	Modification
	Release 5.2.2	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operation
	bulkstat	read, write

## Example

This example shows how to use the **discard** command:

```
RP/0/RSP0/CPU0:router (config) # bulkstat data-group d1
RP/0/RSP0/CPU0:router (config-bs-dg) # discard
```



# enable

To enable a profile for collection and transfer, use the **enable** command in bulkstat profile configuration mode. To disable the profile, use the **no** form of this command.

**enable** *force*  
**no enable** *force*

<b>Syntax Description</b>	<i>force</i> Disables the profile collection. The polling operation for all data groups are stopped. All state full data information--collection options, process, threshold and collected non-transferred data are purged. All retained files are deleted and transfer operation stopped. If the profile is transferring a file, then it is deleted after the transfer.
---------------------------	--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Bulkstat profile configuration
----------------------	--------------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 5.2.2	This command was introduced.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

If the **enable** command is used multiple times, one after the other, the last one in the sequence is considered final.

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	bulkstat	read, write

## Example

This example shows how to use the **enable** command:

```
RP/0/RSP0/CPU0:router (config) # bulkstat profile p1
RP/0/RSP0/CPU0:router (config-bs-profile) # enable
```

# bulkstat filter

To configure a bulk-statistics filter set, use the **bulkstat filter** command in global configuration mode. To remove the filter set configuration, use the **no** form of this command.

**bulkstat filter** *filter-set-name*  
**no bulkstat filter** *filter-set-name*

<b>Syntax Description</b>	<i>filter-set-name</i> Name of the bulkstat filter set.
---------------------------	---------------------------------------------------------

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Global configuration
----------------------	----------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 5.2.2	This command was introduction.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	bulkstat	read, write

## Example

This example shows how to use the **bulkstat filter** command:

```
RP/0/RSP0/CPU0:router # config
RP/0/RSP0/CPU0:router (config) # bulkstat filter vlan1
```

# interval

To configure interval parameters for a data group, use the **interval** command in bulkstat data group configuration mode. To reset the interval parameters for a data group to the default value, use the **no** form of this command.

```
interval transfer { process | raw } seconds
no interval transfer { process | raw } seconds
```

## Syntax Description

**process** Process files.

**raw** Raw files.

*seconds* Period in seconds.

## Command Default

None

## Command Modes

Bulkstat datagroup configuration

## Command History

Release	Modification
Release 5.2.2	This command was introduced.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

## Task ID

Task ID	Operation
bulkstat	read, write

## Example

This example shows how to use the **interval** command:

```
RP/0/RSP0/CPU0:router (config-bs-profile) # interval transfer process 1000
```

# object

To add an object to an Simple Network Management Protocol (SNMP) data set, use the **object** command in bulkstat snmp data set configuration mode. To remove an object from a data set, use the **no** form of this command.

```
object {oid | word } alias alias-name
noobject {oid | word } alias alias-name
```

Syntax Description	Parameter	Description
	<i>oid</i>	Object identifier (in dotted decimal notation).
	<i>word</i>	Object descriptor.
	<b>alias</b> <i>alias-name</i>	Name that is associated with an object. If the SNMP agent only can understand the dotted notation OID, you can specify an alias name. This name is used to represent the object in the file containing the collected data.

**Command Default** None

**Command Modes** Bulkstat snmp data set configuration

Command History	Release	Modification
	Release 5.2.2	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task	Operation
	bulkstat	read, write

## Example

This example shows how to use the **object** command:

```
RP/0/RSP0/CPU0:router # config
RP/0/RSP0/CPU0:router (config) # bulkstat data interface-stats type snmp
RP/0/RSP0/CPU0:router (config-bs-ds-snmp) # object 1.3.6.1.2.1.2.2.1.10
```

# process

To configure process related parameters for a data group, use the **process** command in bulkstat data group configuration mode. To remove process related parameters from a data group, use the **no** form of this command.

**process**  
**no process**

**Syntax Description** This command has no keywords or arguments.

**Command Default** None

**Command Modes** Bulkstat data-group configuration

Command History	Release	Modification
	Release 5.2.2	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operation
	bulkstat	read, write

## Example

This example shows how to use the **process** command:

```
RP/0/RSP0/CPU0:router (config) bulkstat data-group dl
RP/0/RSP0/CPU0:router (config-bs-dg) # process
```

# bulkstat profile

To configure a bulkstat profile, use the **bulkstat profile** command in global configuration mode. To remove the bulkstat profile configuration, use the **no** form of this command.

**bulkstat profile** *profile-name*  
**no bulkstat profile** *profile-name*

<b>Syntax Description</b>	<i>profile-name</i> Name of a bulkstat profile.
---------------------------	-------------------------------------------------

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Global configuration
----------------------	----------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 5.2.2	This command was introduced.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	bulkstat	read, write

## Example

This example shows how to use the **bulkstat profile** command:

```
RP/0/RSP0/CPU0:router # config
RP/0/RSP0/CPU0:router (config) # bulkstat profile bulk1
```

# range

To configure a range instance use the **range** command under bulkstat snmp instance configuration mode. To remove the range instance from instance-set configuration, use the **no** form of this command.

```
range start id end id
no range start id end id
```

<b>Syntax Description</b>	<b>start id</b> Range Start Instance identifier in OID format.
	<b>end id</b> Range End Instance identifier in OID format.

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Bulkstat snmp instance configuration
----------------------	--------------------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 5.2.2	This command was introduced.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
	Multiple range(s) can be configured in the same instance set. Overlapping of instances is allowed. System will not check for overlapping instance configuration.

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	bulkstat	read, write

## Example

This example shows how to use the **range** command:

```
RP/0/RSP0/CPU0:router # config
RP/0/RSP0/CPU0:router (config) # bulkstat instance in-name type snmp
RP/0/RSP0/CPU0:router (config-bs-is-snmp) # range start 1 end 10
```

# repetition

To configure a repetition instance, use the **repetition** command under bulkstat snmp instance configuration mode. To remove the repetition instance from instance set configuration, use the **no** form of this command.

**repetition oid** *name* **max** *value*  
**no repetition oid** *name* **max** *value*

<b>Syntax Description</b>	<b>oid</b> <i>name</i>	Object Identifier or descriptor.
	<b>max</b> <i>value</i>	Number of maximum possible repetitions. Range is 1-2147483647.

**Command Default** None

**Command Modes** Bulkstat snmp instance configuration

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 5.2.2	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

You can configure multiple repetitions in the same instance set, however, you must avoid overlapping of instances.

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	bulkstat	read, write

## Example

This example shows how to run the **repetition** command:

```
RP/0/RSP0/CPU0:router # config
RP/0/RSP0/CPU0:router (config) # bulkstat instance in-name type snmp
RP/0/RSP0/CPU0:router (config-bs-is-snmp) # repetition oid 1.1 max 100
```



# show bulkstat data-group

To display the details of the bulkstat data-group , use the **show bulkstat data-group** command in EXEC mode.

```
show bulkstat data-group [word data-group name process] [distribution | object | percentile | summary]
```

Syntax Description	word	Displays details for the data-group name.
	<b>process</b>	Displays processing data.
	<b>distribution</b>	Displays distribution data.
	<b>object</b>	Displays object-processed data.
	<b>percentile</b>	Displays percentile data.
	<b>summary</b>	Displays summary data .

**Command Default** None

**Command Modes** EXEC

Command History	Release	Modification
	Release 5.2.2	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operation
	bulkstat	read

## Example

This example shows how to use the **show bulkstat data-group** command:

```
RP/0/RSP0/CPU0:router # show bulkstat data-group
Data-group Name : dg
Oper state : Active
Repetitions left : -
Polling Interval : 10 (secs)
Discard Raw Data : No
Collect type : snmp
Data set name : ds
Instance set name : is
```

**show bulkstat data-group**

```
DCM Config Result : /local/snmp/1
DCM Subscription ID: 1
```

# show bulkstat profile

To display the details of the bulkstat profile, use the **show bulkstat profile** command in the EXEC mode.

```
show bulkstat profile [file file-name | name profile-name]
```

Syntax Description	file file-name	Bulkstat profile-file details.
	name profile-name	Bulkstat profile details.

**Command Default** None

**Command Modes** EXEC

Command History	Release	Modification
	Release 5.2.2	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operation
	bulkstat	read

## Example

This example show how to use the **show bulkstat profile** command:

```
RP/0/RSP0/CPU0:router # show bulkstat profile
Profile Name : pf
Admin Status : Enabled
Enable Reason : Config
Oper Status : Active
```

```
Data-group's in profile:
Name Oper State Repetitions Left

dg Active
```

This example show how to use the **show bulkstat profile** command with the **file** keyword:

```
RP/0/RSP0/CPU0:router # show bulkstat profile file
Profile Name : pf
Curr file size : 3010 (bytes)
Time left for raw data transfer : 22 (secs)
```

# show dcm assa

To display the Active Session Slot Array (ASSA) details for DCM, use the **show dcm assa** command in EXEC mode.

## show dcm assa

**Syntax Description** This command has no keywords or arguments.

**Command Default** None

**Command Modes** EXEC

Command History	Release	Modification
	Release 5.2.2	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operation
	dcm	read

## Example

This example show the output for the **show dcm assa** command:

```
RP/0/RSP0/CPU0:router # show dcm assa
slot state

0 DCM_ASSA_FREE
1 DCM_ASSA_FREE
2 DCM_ASSA_FREE
3 DCM_ASSA_FREE
4 DCM_ASSA_FREE
5 DCM_ASSA_FREE
6 DCM_ASSA_FREE
7 DCM_ASSA_FREE
8 DCM_ASSA_FREE
9 DCM_ASSA_FREE
10 DCM_ASSA_FREE
```

# show dcm client

To get the details of the Data Collection Manager (DCM) client(s), use the **show dcm client** command in the EXEC mode.

**show dcm client** [*id* | *name*] **subscription id** *value*

Syntax Description	<i>id</i>	Client id.
	<i>name</i>	Client name.
	<b>subscription id</b> <i>value</i>	Subscription id.

**Command Default** None

**Command Modes** EXEC

Command History	Release	Modification
	Release 5.2.2	This command was added.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operation
	dcm	read

## Example

This example shows the output for the **show dcm client** commands:

```
RP/0/RSP0/CPU0:router # show dcm client bulkstat-client subscription id 1
client name: Bulkstat-Client
client id: 1
subscriptions: 1,

data-provider: snmp
config id subscription

1 1
```

# show dcm data-providers

To display the data-providers for DCM, use the **show dcm data-providers** command in EXEC mode.

## show dcm data-providers

**Syntax Description** This command has no keywords or arguments.

**Command Default** None

**Command Modes** EXEC

Command History	Release	Modification
	Release 5.2.2	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operation
	dcm	read

## Example

This example shows the output for the **show dcm data-providers** command:

```
RP/0/RSP0/CPU0:router # show dcm data-providers
data-provider name data provider id

cli 1
snmp 3
expression 2

Router#show bulkstat profile
Profile Name : pf
Admin Status : Enabled
Enable Reason : Config
Oper Status : Active

Data-group's in profile:
Name Oper State Repetitions Left

dg Active
```

# show dcm session

To display the active sessions for DCM, use the **show dcm session** command in EXEC mode.

## show dcm session

**Syntax Description** This command has no keywords or arguments.

**Command Default** None

**Command Modes** EXEC

Command History	Release	Modification
	Release 5.2.2	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operation
	dcm	read, write

## Example

This example shows the display output of the **show dcm session** command:

```
RP/0/RSP0/CPU0:router # show dcm session
```

**show dcm session**





## Network Configuration Protocol Commands

---

This chapter includes commands to configure the Network Configuration (Netconf) Protocol. More details on the Netconf protocol and the Yang model, please see the *System Security Configuration Guide for Cisco ASR 9000 Series Routers*.

- [clear netconf-yang agent session](#), on page 846
- [clear netconf-yang agent rate-limit](#), on page 847
- [netconf-yang agent ssh](#), on page 848
- [netconf-yang agent session](#), on page 849
- [netconf-yang agent rate-limit](#), on page 850
- [netconf-yang agent yfw idle-timeout](#), on page 851
- [show netconf-yang clients](#), on page 852
- [show netconf-yang rate-limit](#), on page 853
- [show netconf-yang statistics](#), on page 854
- [ssh server netconf port](#), on page 856
- [ssh server capability netconf-xml](#), on page 858

# clear netconf-yang agent session

To clear the specified netconf agent session, use the **clear netconf-yang agent session** in EXEC mode.

**clear netconf-yang agent session** *session-id*

<b>Syntax Description</b>	<i>session-id</i> The session-id which needs to be cleared.
---------------------------	-------------------------------------------------------------

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	EXEC mode
----------------------	-----------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 5.3.0	This command was introduced.

<b>Usage Guidelines</b>	No specific guidelines impact the use of this command. The <b>show netconf-yang clients</b> command can be used to get the required session-id(s).
-------------------------	-------------------------------------------------------------------------------------------------------------------------------------------------------

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	config-services	read, write

## Example

This example shows how to use the **clear netconf-yang agent session** command:

```
RP/0/RSP0/CPU0:router (config) # clear netconf-yang agent session 32125
```

# clear netconf-yang agent rate-limit

To clear the set rate-limit statistics, use the **clear netconf-yang agent rate-limit** command in the appropriate mode.

**clear netconf-yang agent rate-limit**

**Syntax Description** This command has no keywords or arguments.

**Command Default** None

**Command Modes** EXEC

Command History	Release	Modification
	Release 5.3.1	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

Task ID	Task ID	Operation
	config-services	read, write

## Example

This example shows how to use the **clear netconf-yang agent rate-limit** command:

```
RP/0/RSP0/CPU0:router # clear netconf-yang agent rate-limit
```

# netconf-yang agent ssh

To enable netconf agent over SSH (Secure Shell) , use the **netconf-yang agent ssh** command in the global configuration mode. To disable netconf, use the **no** form of the command.

**netconf-yang agent ssh**  
**no netconf-yang agent ssh**

<b>Syntax Description</b>	This command has no keywords or arguments.
---------------------------	--------------------------------------------

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Global Configuration
----------------------	----------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 5.3.0	This command was introduced.

<b>Usage Guidelines</b>	SSH is currently the supported transport method for Netconf.
-------------------------	--------------------------------------------------------------

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	config-services	read, write

## Example

This example shows how to use the **netconf-yang agent ssh** command:

```
RP/0/RSP0/CPU0:router (config) # netconf-yang agent ssh
```

## netconf-yang agent session

To set the session details (limits and timeouts) for a netconf-yang agent, use the **netconf-yang agent session** command in the appropriate mode. To remove the configured session limits and timeouts, use the **no** form of the command.

```
netconf-yang agent session { limit value | absolute-timeout value | idle-timeout value }
no netconf-yang agent session { limit value | absolute-timeout value | idle-timeout value }
```

Syntax Description	limit <i>value</i>	absolute-timeout <i>value</i>	idle-timeout <i>value</i>
	Sets the maximum count for concurrent netconf-yang sessions. Range is 1 to 1024.	Enables session absolute timeout and sets the absolute session lifetime. Range is 1 to 1440. Unit is minutes.	Enables session idle timeout and sets the idle session lifetime. Range is 1 to 1440. Unit is minutes.

**Command Default** By default, no limits are set

**Command Modes** Global Configuration mode

Command History	Release	Modification
	Release 5.3.1	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

Task ID	Task ID	Operation
	config-services	read, write

### Example

This command shows how to use the **netconf-yang agent session** command:

```
RP/0/RSP0/CPU0:router (config) # netconf-yang agent session limit
```

# netconf-yang agent rate-limit

To set the rate-limit for the netconf yang agent, use the **netconf-yang agent rate-limit** command in the appropriate mode. To delete the set rate-limit, use the **no** form of the command.

**netconf-yang agent rate-limit** *bytes*  
**no netconf-yang agent rate-limit** *bytes*

<b>Syntax Description</b>	<i>bytes</i> The number of bytes to process per second. Range is 4096-4294967295. It is based on the size of the request(s) from the client to the netconf server.
---------------------------	--------------------------------------------------------------------------------------------------------------------------------------------------------------------

<b>Command Default</b>	By default, no limit is set
------------------------	-----------------------------

<b>Command Modes</b>	Global Configuration mode
----------------------	---------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 5.3.1	This command was introduced.

<b>Usage Guidelines</b>	No specific guidelines impact the use of this command.
	Use the <b>show netconf-yang rate-limit</b> command to check if the set limit is adequate.

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	config-services	read, write

## Example

This example shows how to use the **netconf-yang agent rate-limit** command:

```
RP/0/RSP0/CPU0:router # netconf-yang agent rate-limit 5000
```

## netconf-yang agent yfw idle-timeout

To configure idle timeout value for the operational yang model use the **netconf-yang agent yfw idle-timeout** command. Idle timeout indicates the duration for which there is no netconf process activity. If the idle timeout value is configured, all the operational yang models that are not being used for the specified duration, are released from the memory.

**netconf-yang agent yfw idle-timeout** *time in seconds*

---

**Syntax Description**

Specify the time in seconds. The valid value must be between the range of 1 to 4294967295 seconds

---

**Command Default**

If this command is not configured, the operational yang models are not released from the memory. To manually release the yang models, the Netconf process should be restarted.

---

**Command Modes**

Global Configuration mode

---

**Command History**

Release	Modification
Release 6.0	This command was introduced.

**Example**

This example shows how to use the **netconf-yang agent yfw idle-timeout** command:

```
RP/0/RSP0/CPU0:router (config) # netconf-yang agent yfw idle-timeout 60
```

# show netconf-yang clients

To display the client details for netconf-yang, use the **show netconf-yang clients** command in EXEC mode.

## show netconf-yang clients

**Syntax Description** This command has no keywords or arguments.

**Command Default** None

**Command Modes** EXEC

Command History	Release	Modification
	Release 5.3.0	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

Task ID	Task ID	Operation
	config-services	read

## Example

This example shows how to use the **show netconf-yang clients** command:

```
RP/0/RSP0/CPU0:router (config) # sh netconf-yang clients
Netconf clients
client session ID| NC version| client connect time| last OP time| last
OP type| <lock>|
 22969| 1.1| 0d 0h 0m 2s| 11:11:24|
close-session| No|
 15389| 1.1| 0d 0h 0m 1s| 11:11:25|
get-config| No|
```

**Table 69: Field descriptions**

Field name	Description
Client session ID	Assigned session identifier
NC version	Version of the Netconf client as advertised in the hello message
Client connection time	Time elapsed since the client was connected
Last OP time	Last operation time
Last OP type	Last operation type
Lock (yes or no)	To check if the session holds a lock on the configuration datastore



# show netconf-yang rate-limit

To display the statistics of the total data dropped , due to the set rate-limit, use the **show netconf-yang rate-limit** command in the appropriate mode.

**show netconf-yang rate-limit**

<b>Syntax Description</b>	This command has no keywords or arguments.
---------------------------	--------------------------------------------

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	EXEC
----------------------	------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 5.3.1	This command was introduced.

<b>Usage Guidelines</b>	No specific guidelines impact the use of this command.
-------------------------	--------------------------------------------------------

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	config-services	read

## Example

This example shows how to use the **show netconf-yang rate-limit** command:

```
RP/0/RSP0/CPU0:router # show netconf-yang rate-limit
rate-limit statistics
Total data dropped: 0 Bytes
```

# show netconf-yang statistics

To display the statistical details for netconf-yang, use the **show netconf-yang statistics** command in EXEC mode.

## show netconf-yang statistics

**Syntax Description** This command has no keywords or arguments.

**Command Default** None

**Command Modes** EXEC

Command History	Release	Modification
	Release 5.3.0	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

Task ID	Task ID	Operation
	config-services	read

## Example

This example shows how to use the **show netconf-yang statistics** command:

```
RP/0/RSP0/CPU0:router (config) # sh netconf-yang statistics
Summary statistics

```

time per request	# requests	total time	min time per request	max
avg time per request				
other	0	0h 0m 0s 0ms	0h 0m 0s 0ms	
close-session	4	0h 0m 0s 3ms	0h 0m 0s 0ms	
kill-session	0	0h 0m 0s 0ms	0h 0m 0s 0ms	
get-schema	0	0h 0m 0s 0ms	0h 0m 0s 0ms	
get	0	0h 0m 0s 0ms	0h 0m 0s 0ms	
get-config	1	0h 0m 0s 1ms	0h 0m 0s 1ms	
edit-config	3	0h 0m 0s 2ms	0h 0m 0s 0ms	
commit	0	0h 0m 0s 0ms	0h 0m 0s 0ms	
cancel-commit	0	0h 0m 0s 0ms	0h 0m 0s 0ms	
lock	0	0h 0m 0s 0ms	0h 0m 0s 0ms	
unlock	0	0h 0m 0s 0ms	0h 0m 0s 0ms	
discard-changes	0	0h 0m 0s 0ms	0h 0m 0s 0ms	

```

0h 0m 0s 0ms | 0h 0m 0s 0ms | 0h 0m 0s 0ms |
validate 0 | 0h 0m 0s 0ms | 0h 0m 0s 0ms |
0h 0m 0s 0ms | 0h 0m 0s 0ms | 0h 0m 0s 0ms |
xml parse 8 | 0h 0m 0s 4ms | 0h 0m 0s 0ms |
0h 0m 0s 1ms | 0h 0m 0s 0ms | 0h 0m 0s 0ms |
netconf processor 8 | 0h 0m 0s 6ms | 0h 0m 0s 0ms |
0h 0m 0s 1ms | 0h 0m 0s 0ms |

```

**Table 70: Field descriptions**

Field name	Description
Requests	Total number of processed requests of a given type
Total time	Total processing time of all requests of a given type
Min time per request	Minimum processing time for a request of a given type
Max time per request	Maximum processing time for a request of a given type
Avg time per request	Average processing time for a request type

## ssh server netconf port

To configure a port for the netconf SSH server, use the **ssh server netconf port** command in the global configuration mode. To return to the default port, use the **no** form of the command.

**ssh server netconf port** *port number*  
**no ssh server netconf port***port number*

<b>Syntax Description</b>	<b>port</b> <i>port-number</i> <i>port-number</i>	Port number for the netconf SSH server (default port number is 830).
<b>Command Default</b>	The default port number is 830.	
<b>Command Modes</b>	Global configuration	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 5.3.0	This command was introduced.
	Release 6.0	The <b>ssh server netconf</b> command is no longer auto completed to configure the default port. This command is now optional
<b>Usage Guidelines</b>	<p>To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.</p> <p>Starting with IOS-XR 6.0.0 it is no longer sufficient to configure a netconf port to enable netconf subsystem support. ssh server netconf needs to be at least configured for one vrf.</p>	
<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	crypto	read, write
<b>Examples</b>	<p>This example shows how to use the ssh server netconf port command with port 831:</p> <pre>RP/0/RSP0/CPU0:router# configure RP/0/RSP0/CPU0:router(config)# ssh server netconf port 831</pre>	
<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	ssh server netconf	Configures the vrf(s), where netconf subsystem requests are to be received.

Command	Description
netconf-yang agent ssh	Configures the <b>ssh netconf-yang backend</b> for the netconf subsystem (Required to allow the system to service netconf-yang requests).  For more information, see the <i>Cisco ASR 9000 Series Aggregation Services Router System Management Command Reference</i> .

## ssh server capability netconf-xml

To enable NETCONF reach XML subsystem via port 22, use the **ssh server capability netconf-xml** command in the Global Configuration mode. Use **no** form of this command to disable NETCONF reach XML subsystem.

**ssh server capability netconf-xml**

---

### Syntax Description

This command has no keywords or arguments.

---

### Command Default

Port 22 is the default port.

### Command Modes

Global configuration

---

### Command History

Release	Modification
Release 6.1.4	This command was introduced.

---



---

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

---

### Task ID

Task ID	Operations
crypto	read, write

---



## Software Entitlement Commands

---

For detailed information about software entitlement concepts, configuration tasks, and examples, see the *Software Entitlement on Cisco IOS XR Software* module in *System Management Configuration Guide for Cisco ASR 9000 Series Routers*.

- [clear license](#), on page 860
- [clear license log](#), on page 861
- [license add](#), on page 862
- [license backup](#), on page 864
- [license move](#), on page 865
- [license move slot](#), on page 867
- [license remove](#), on page 869
- [license restore](#), on page 871
- [license cm update](#), on page 872
- [show license](#), on page 873
- [show license active](#), on page 876
- [show license allocated](#), on page 878
- [show license available](#), on page 880
- [show license backup](#), on page 882
- [show license chassis](#), on page 884
- [show license evaluation](#), on page 885
- [show license expired](#), on page 887
- [show license features](#), on page 889
- [show license log](#), on page 890
- [show license pools](#), on page 892
- [show license udi](#), on page 894

# clear license

To delete all licenses from the router persistent storage, use the **clear license** command in administration EXEC mode.

## clear license

### Command Default

No default behavior or values

### Command Modes

Administration EXEC

### Command History

Release	Modification
Release 3.9.0	This command was introduced.

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **clear license** command removes all licenses from the router persistent storage.

### Task ID

Task ID	Operations
pkg-mgmt	execute

In the following example, all licenses are removed from the router:

```
RP/0/RSP0/CPU0:router# admin
RP/0/RSP0/CPU0:router(admin)# clear license
```



# clear license log

To clear the operational or administrative logs for the license system, use the **clear license log** command in administration EXEC mode.

```
clear license log {operational | administration}
```

## Syntax Description

**operational** Clears the operational logs for the license system.

**administration** Clears the administration logs for the license system.

## Command Default

No default behavior or values

## Command Modes

Administration EXEC

## Command History

Release	Modification
Release 3.9.0	This command was introduced.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **clear license log** command to clear either the operational or administrative logs for the license system. To view the logs, use the **show license log** command. The license log does not persist between reloads.

## Task ID

Task ID	Operations
pkg-mgmt	read

The following example illustrates how to use the **clear license log** command to clear the operational logs:

```
RP/0/RSP0/CPU0:router# admin
RP/0/RSP0/CPU0:router (admin)# clear license log operational
```

## Related Topics

[show license log](#), on page 890

# license add

To add a license to a secure domain router (SDR) license pool, use the **license add** command in administration EXEC mode.

```
license add [tar] license-name [sdr sdr-name]
```

Syntax Description		
<b>tar</b>		(Optional) Indicates that the license file is contained in a tar file.
<i>license-name</i>		Name and location of the license file to be added. The license file can be local to the system or a remote file on a TFTP server.
<b>sdr sdr-name</b>		(Optional) Adds the license to the specified SDR license pool. The default is owner. The <i>sdr-name</i> argument is the name assigned to the SDR.

**Command Default** License is added to the owner SDR.

**Command Modes** Administration EXEC

Command History	Release	Modification
	Release 3.9.0	This command was introduced.
	Release 4.0.0	The <b>tar</b> keyword was added.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **license add** command to add a license to an SDR license pool. The license file can be local to the system or a remote file on a TFTP server. The license file is stored in persistent storage on the router.

To acquire a license file, you must provide a manufacturing supplied product authorization key (PAK) and the license unique device identifier (UDI) of the chassis to the license registration tool at: <https://tools.cisco.com/SWIFT/Licensing/RegistrationServlet>. To obtain the UDI of your chassis, use the **show license udi** command.

By default, there is one license pool available.

Task ID	Task ID	Operations
	pkg-mgmt	execute

The following example shows how to add a software license to the owner SDR:

```
RP/0/RSP0/CPU0:router# admin
RP/0/RSP0/CPU0:router(admin)# license add disk1:/P1-LIC-8_TBA09370035_20070207195224661.lic
```

```
License command "license add disk1:/P1-LIC-8_TBA09370035_20070207195224661.lic
sdr Owner" completed successfully.
```

### Related Topics

[license move](#), on page 865

[show license udi](#), on page 894

# license backup

To back up all licenses contained on the persistent storage of the router, use the **license backup** command in administration EXEC mode.

**license backup** *backup-file*

<b>Syntax Description</b>	<i>backup-file</i> Name and location of the backup file to be created or modified. This can be a local file, or a remote file on a TFTP or rcp server.
---------------------------	--------------------------------------------------------------------------------------------------------------------------------------------------------

<b>Command Default</b>	No default behavior or values
------------------------	-------------------------------

<b>Command Modes</b>	Administration EXEC
----------------------	---------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.9.0	This command was introduced.

**Usage Guidelines**

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **license backup** command to back up the licenses stored in the persistent storage on the router. We recommend this so that you can restore the licenses at one time while recovering from a failed disk situation. The destination location can be local to the system; in other words, a flash disk or hard disk. Alternatively, it can be a remote file on a TFTP or rcp server. The license information includes the licenses as well as the operational information, such as the slot the licenses are allocated to and the current license operation identifier.

If the backup file already exists, you are prompted to confirm before the file is overwritten.

When licenses are backed up, they can be restored as required using the **license restore** command.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	pkg-mgmt	execute

The following example shows how to back up the licenses on a router:

```
RP/0/RSP0/CPU0:router# admin
RP/0/RSP0/CPU0:router(admin)# license backup disk1:/license_back

License command "license backup disk1:/license_back" completed successfully.
```

## Related Topics

[license restore](#), on page 871

[show license backup](#), on page 882

# license move

To move a license from one secure domain router (SDR) license pool to another, use the **license move** command in administration EXEC mode.

```
license move feature-id {allcount} sdr source-sdr-name sdr dest-sdr-name[{evaluation | permanent}]
```

## Syntax Description

<i>feature-id</i>	Identifier for the feature entitled in the licenses to be moved. You can display available licenses using the <b>show license</b> command.
<b>all</b>	Specifies to move all available licenses with the specific feature identifier.
<i>count</i>	Number of licenses to move.
<b>sdr</b> <i>source-sdr-name</i>	Specifies the SDR license pool from which to move the specified licenses. The <i>source-sdr-name</i> argument is the name assigned to the SDR.
<b>sdr</b> <i>dest-sdr-name</i>	Specifies the SDR license pool to which the license should be moved. The <i>source-sdr-name</i> argument is the name assigned to the SDR.
<b>evaluation</b>	Specifies to move an evaluation license.
<b>permanent</b>	Specifies to move a permanent license.

## Command Default

No default behavior or values

## Command Modes

Administration EXEC

## Command History

Release	Modification
Release 3.9.0	This command was introduced.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

By default, there is only one license pool available. If you have created multiple license pools, you can use the **license move** command to move the license to a different SDR license pool.

The **license move** command is used only to move licenses between SDR license pools on the same router. To move licenses between routers, you must first remove the license from the original router using the **license remove** command, and then add it to the new router using the **license add** command. To move licenses between routers, you also need to generate a new license key on Cisco.com. The license registration tool is located at <https://tools.cisco.com/SWIFT/Licensing/RegistrationServlet>.

Licenses can be moved only if they are in the available state. In other words, you have to clear the feature configuration before a license can be released back to the appropriate license pool.

Task ID	Task ID	Operations
	pkg-mgmt	execute

The following example shows how to move a license from one license pool to another:

```
RP/0/RSP0/CPU0:router# admin
RP/0/RSP0/CPU0:router (admin) # license move a9k-adv-optic-lic sdr owner sdr mysdr
```

### Related Topics

[license add](#), on page 862

[show license](#), on page 873

# license move slot

To move a license from one slot to another, use the **license move slot** command in EXEC or administration EXEC mode.

```
license move feature-id slot [count] from {node-id | allocated} to {node-id | available} [{evaluation | permanent}]
```

## Syntax Description

<i>feature-id</i>	Identifier for the feature entitled in the licenses to be moved. You can display available licenses using the <a href="#">show license, on page 873</a> command.
<i>count</i>	Number of licenses to move. This argument cannot be used in conjunction with the <b>allocated</b> and <b>available</b> keywords.
<b>from</b>	Specifies from where to move the specified licenses.
<i>node-id</i>	Specific node from which to move the license.
<b>allocated</b>	Specifies to move all allocated licenses with the specific feature identifier. This keyword must be used in conjunction with the <b>available</b> keyword.
<b>to</b>	Specifies to where to move the specified licenses.
<i>node-id</i>	Specific node to which to move the license.
<b>available</b>	Specifies to move the specified allocated licenses into the available state. This keyword must be used in conjunction with the <b>allocated</b> keyword.
<b>evaluation</b>	Specifies to move an evaluation license.
<b>permanent</b>	Specifies to move a permanent license.

## Command Default

One license is moved.

## Command Modes

Administration EXEC

EXEC

## Command History

Release	Modification
Release 3.9.0	This command was introduced.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **license move slot** command moves slot-based licenses from one slot to another slot on the same router.

Use the **allocated** keyword to move all allocated licenses into the available state. The **allocated** keyword must be used in conjunction with the **available** keyword. If no allocated licenses are available that match the feature identifier, the **license move slot** command revokes used licenses on the given slot.

If licenses are going to be revoked on the source card, a warning prompt is displayed.

Licenses can be moved only if they are in the available state. In other words, you have to clear the feature configuration before a license can be released back to the appropriate license pool.

Task ID	Task ID	Operations
	pkg-mgmt	execute

The following example shows how to move a license from one slot to another:

```
RP/0/RSP0/CPU0:router# admin
RP/0/RSP0/CPU0:router(admin)# license move a9k-adv-optic-lic slot 1 from 0/1/cpu0 to 0/4/cpu0
```

The following example shows how to move all licenses to the available state:

```
RP/0/RSP0/CPU0:router# admin
RP/0/RSP0/CPU0:router(admin)# license move a9k-adv-optic-lic from allocated to available
```

### Related Topics

[license add](#), on page 862

[show license](#), on page 873



# license remove

To remove a license permanently from a router, use the **license remove** command in administration EXEC mode.

```
license remove feature-id {id | ticket permission-ticket rehost-ticket} [sdr sdr-name] {evaluation | permanent}
```

Syntax Description		
<i>feature-id</i>		Identifier for the feature entitled in the licenses to be removed. You can display available features using the show license command.
<b>id</b>		Specifies to remove licenses using a unique identifier of the license.
<b>sdr</b> <i>sdr-name</i>		Removes the license from the specified SDR license pool.
<b>evaluation</b>		Specifies to move an evaluation license.
<b>permanent</b>		Specifies to move a permanent license.

**Command Default** None

**Command Modes** Administration EXEC

Command History	Release	Modification
	Release 3.9.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **license remove** command permanently removes a license from the router and outputs a key or rehost ticket that can be used to prove that the license has been removed. This command accepts a permission ticket, obtained from CCO, that includes the UDI, feature ID and count of licenses to remove. Refer to the license registration tool on CCO for more information: <https://tools.cisco.com/SWIFT/Licensing/RegistrationServlet>.

If you use a permission ticket that was previously used, the same rehost ticket is created, but no licenses are removed.

Licenses can be removed only if they are in the available state. In other words, you have to clear the feature configuration before that the license can be released back to the appropriate license pool.

Task ID	Task ID	Operation
	pkg-mgmt	execute

### Example

The following example shows how to remove a license from a license pool:

```
RP/0/RSP0/CPU0:router# admin
RP/0/RSP0/CPU0:router(admin)# license remove a9k-adv-optic-lic
ticket disk1:/my_permission disk1:/optic_lic
```

### Related Topics

[show license](#), on page 873

# license restore

To restore the licenses on a router using an earlier backup copy, use the **license restore** command in administration EXEC mode.

**license restore** *backup-file*

<b>Syntax Description</b>	<i>backup-file</i> Name and location of the backup file to be used for the license restore. This can be a local file, or a remote file on a TFTP or rcp server.
---------------------------	-----------------------------------------------------------------------------------------------------------------------------------------------------------------

<b>Command Default</b>	No default behavior or values
------------------------	-------------------------------

<b>Command Modes</b>	Administration EXEC
----------------------	---------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.9.0	This command was introduced.

**Usage Guidelines**

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **license restore** command restores the licenses on the router using an earlier backup copy that was created using the **license backup** command. The source location can be local to the system, in other words, a flash disk or hard disk. Alternatively, it can be a remote file on a TFTP or rcp server.

Before the licenses are restored, the license manager verifies the following:

- The backup format is valid.
- The licenses are issued for the chassis where the CLI is being run.
- The license operation identifier in the backup file matches the one on the router EEPROM.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	pkg-mgmt	execute

The following example shows how to move a license from one license pool to another:

```
RP/0/RSP0/CPU0:router# admin
RP/0/RSP0/CPU0:router(admin)# license restore disk1:/license_back
```

```
Info: This command will erase all existing licenses.
Info: It is strongly recommended to backup existing licenses first. Do you wish to
proceed? [yes/no]: y
```

```
License command "license restore disk1:/license_back" completed successfully.
```

## Related Topics

[license backup](#), on page 864

# license cm update

To perform update of usage on the router and the back end entitlement reporting, run the **license cm update** command on the administration plane.

## admin license cm update

### Command Default

By default, the license cm update is ON and runs once every 24 hours.

### Command Modes

Administration EXEC mode.

### Command History

Release	Modification
Release 5.3.2	This command was introduced.

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

### Task ID

Task ID	Operation
license cm update	Read, Write, Execute

### Verification of CM Update

To verify if the cm update has completed, check for the following log message:

```
RP/0/RSP1/CPU0:PE4#sh logging | inc CM
RP/0/RSP1/CPU0:Aug 17 15:09:38.765 : plat_sw_agent[370]:
%LICENSE-ASR9K_LICENSE-6-UPDATE_STARTED : CM entitlement update has started.
RP/0/RSP1/CPU0:Aug 17 15:26:23.041 : plat_sw_agent[370]:
%LICENSE-ASR9K_LICENSE-6-UPDATE_COMPLETED : CM entitlement update is completed.
```

# show license

To display all license information, use the **show license** command in EXEC or administration EXEC mode.

```
show license [{feature-id | location node-id | sdr sdr-name}]
```

Syntax Description	
<i>feature-id</i>	(Optional) Identifier for the feature entitled in the licenses to be displayed.
<b>location</b> <i>node-id</i>	(Optional) Specifies the location of the card. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.
<b>sdr</b> <i>sdr-name</i>	(Optional) Displays the licenses in the specified SDR license pool. The <i>sdr-name</i> argument is the name assigned to the SDR.

**Command Default** No default behavior or values

**Command Modes** Administration EXEC

EXEC

Command History	Release	Modification
	Release 3.9.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **show license** command displays all license information. Alternatively, you can display license information for a specific feature identifier, slot location, or SDR by using the available options.

If the feature process has supplied an opaque string while checking out the license, that string is displayed next to the feature identifier in the command output.

Task ID	Task ID	Operations
	pkg-mgmt	read

The following example shows sample output from the **show license** command:

```
RP/0/RSP0/CPU0:router(admin)# show license
Wed Aug 4 09:52:24.352 DST

FeatureID: A9K-ADV-OPTIC-LIC (Slot based, Permanent)
Total licenses 1
Available for use 1
Allocated to location 0
Active 0
Store name Permanent
```

```

Store index 1
 Pool: Owner
 Total licenses in pool: 1
 Status: Available 1 Operational: 0

FeatureID: A9K-ADV-VIDEO-LIC (Slot based, Permanent)
Total licenses 1
Available for use 1
Allocated to location 0
Active 0
Store name Permanent
Store index 2
 Pool: Owner
 Total licenses in pool: 1
 Status: Available 1 Operational: 0

FeatureID: A9K-AIP-LIC-B (Slot based, Permanent)
Total licenses 1
Available for use 1
Allocated to location 0
Active 0
Store name Permanent
Store index 3
 Pool: Owner
 Total licenses in pool: 1
 Status: Available 1 Operational: 0

FeatureID: A9K-AIP-LIC-E (Slot based, Permanent)
Total licenses 1
Available for use 1
Allocated to location 0
Active 0
Store name Permanent
Store index 4
 Pool: Owner
 Total licenses in pool: 1
 Status: Available 1 Operational: 0

FeatureID: A9K-iVRF-LIC (Slot based, Permanent)
Total licenses 1
Available for use 1
Allocated to location 0
Active 0
Store name Permanent
Store index 5
 Pool: Owner
 Total licenses in pool: 1
 Status: Available 1 Operational: 0

```

**Table 71: show license Field Descriptions**

Field	Description
FeatureID	<p>Feature to which the licenses apply. The type of license is designated as one of the following:</p> <ul style="list-style-type: none"> <li>• Permanent licenses—Enable a designated feature permanently as long as the license resides on the router.</li> <li>• Evaluation or metered licenses—Enable a feature for a limited period of time.</li> <li>• Implicit licenses—Metered licenses that are included with the software image (upgrade or initial installation).</li> </ul>

Field	Description
Total licenses	Number of licenses on the router.
Available for use	Number of licenses that are not currently active.
Allocated to location	Number of licenses allocated to a slot but not used.
Active	Number of licenses currently checked out or being used by applications.
Pool	License pool to which the licenses belong.
Total licenses in pool	Number of licenses in the specific pool.
Status	<p>Indicates the number of licenses in each state. Licenses can have the following states:</p> <p>Available—License is available in the pool and can be assigned to a slot/feature process. For example, a recently added 40-Gbps license to the router is available before it gets checked out by a card.</p> <p>Allocated—License is assigned to a slot but is unused. In other words, the feature process is not using the license. For example, a 40-Gbps license is allocated to slot 5 if the license was previously used but the card is currently in the shutdown state.</p> <p>Active—Feature process has checked out a license. Generally this happens when the feature is actively using the license. For example, if a card is in IOS XR RUN state and is passing traffic at 40 Gbps, a 40-Gbps license is in the used state in that slot.</p> <p>Operational—All licenses that are either active or allocated.</p> <p>Expired—License has expired. This is applicable only for evaluation licenses or licenses granted by Cisco.</p>
Locations with licenses	Slot where the licenses are being used, followed by an indication of whether the license is active or allocated, and to which license pool it belongs.

# show license active

To display license information for all licenses that are currently checked out or being used by an application, use the **show license active** command in EXEC or administration EXEC mode.

**show license active** [*feature-id* | **location** *node-id* | **sdr** *sdr-name*]

Syntax Description		
	<i>feature-id</i>	(Optional) Identifier for the feature entitled in the licenses to be displayed.
	<b>location</b> <i>node-id</i>	(Optional) Specifies the location of the card. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.
	<b>sdr</b> <i>sdr-name</i>	(Optional) Displays the licenses in the specified secure domain router (SDR) license pool. The <i>sdr-name</i> argument is the name assigned to the SDR.

**Command Default** No default behavior or values

**Command Modes** Administration EXEC  
EXEC

Command History	Release	Modification
	Release 3.9.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **show license active** command displays all license information regarding licenses that are currently checked out or being used by an application. You can display the information for a specific feature identifier, slot location, or SDR by using the available options.

Task ID	Task ID	Operations
	pkg-mgmt	read

The following example displays sample output from the **show license active** command:

```
RP/0/RSP0/CPU0:router# admin
RP/0/RSP0/CPU0:router (admin)# show license active

FeatureID:
a9k-adv-optic-lic
 (Slot based, Implicit[Remaining time: 90 days])
 Status: Active 2
 SDR: Owner
 Operational: 2

Location: 0/1/CPU0 1
```



```
0/6/CPU0 1
```

See [Table 71: show license Field Descriptions, on page 874](#) for a description of the significant fields shown in the display.

# show license allocated

To display license information for all licenses allocated to a slot but not used, use the **show license allocated** command in EXEC or administration EXEC mode.

**show license allocated** [*feature-id* | **location** *node-id* | **sdr** *sdr-name*]

Syntax Description	
<i>feature-id</i>	(Optional) Identifier for the feature entitled in the licenses to be displayed.
<b>location</b> <i>node-id</i>	(Optional) Specifies the location of the card. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.
<b>sdr</b> <i>sdr-name</i>	(Optional) Displays the licenses in the specified secure domain router (SDR) license pool. The <i>sdr-name</i> argument is the name assigned to the SDR.

**Command Default** No default behavior or values

**Command Modes** Administration EXEC  
EXEC

Command History	Release	Modification
	Release 3.9.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **show license allocated** command displays all license information regarding licenses that are allocated to a slot but are not currently being used. You can display the information for a specific feature identifier, slot location, or SDR by using the available options.

Task ID	Task ID	Operations
	pkg-mgmt	read

The following example displays sample output from the **show license allocated** command:

```
RP/0/RSP0/CPU0:router# admin
RP/0/RSP0/CPU0:router (admin) # show license allocated

FeatureID:
A9K-ADV-OPTIC-LIC
 (Slot based, Permanent)
 Status: Allocated 1
 SDR: Owner
 Status: Operational: 1
 Locations with licenses: (Active/Allocated)
 0/1/CPU0 (0/1)
```

See [Table 71: show license Field Descriptions, on page 874](#) for a description of the significant fields shown in the display.

# show license available

To display all licenses that are not currently in use or allocated to specific slots, use the **show license available** command in EXEC or administration EXEC mode.

**show license available** *{feature-id | location node-id | sdr sdr-name}*

## Syntax Description

<i>feature-id</i>	Identifier for the feature entitled in the licenses to be displayed.
<b>location</b> <i>node-id</i>	Specifies the location of the card. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.
<b>sdr</b> <i>sdr-name</i>	Displays the licenses in the specified secure domain router (SDR) license pool. The <i>sdr-name</i> argument is the name assigned to the SDR.

## Command Default

No default behavior or values

## Command Modes

Administration EXEC  
EXEC

## Command History

Release	Modification
Release 3.9.0	This command was introduced.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **show license available** command displays all licenses that currently are not being used or allocated to a specific slot. You can display only licenses with a specific feature identifier, slot location, or SDR by using the available options.

## Task ID

Task ID	Operations
pkg-mgmt	read

The following example displays sample output from the **show license available** command with only implicit licenses available:

```
RP/0/RSP0/CPU0:router# admin
RP/0/RSP0/CPU0:router(admin)# show license available

FeatureID:
A9K-ADV-OPTIC-LIC
 (Slot based, Implicit[Remaining time: 90
 days]) Status: Available 0 SDR: Owner Status: Available 0 Location: 0/1/CPU0 1 0/6/CPU0 1
```

The following example displays sample output from the **show license available** command with permanent licenses installed:

```
RP/0/RSP0/CPU0:router# admin
RP/0/RSP0/CPU0:router(admin)# show license available

FeatureID:
A9K-ADV-OPTIC-LIC
 (Slot based, Permanent)
 Status: Available 7
 SDR: Owner Status:
 Available 7
```

See [Table 71: show license Field Descriptions, on page 874](#) for a description of the significant fields shown in the display.

# show license backup

To display the backup license file, use the **show license backup** command in administration EXEC mode.

**show license backup** *file-name*

<b>Syntax Description</b>	<i>file-name</i> Name of the backup license file.
---------------------------	---------------------------------------------------

<b>Command Default</b>	No default behavior or values
------------------------	-------------------------------

<b>Command Modes</b>	Administration EXEC
----------------------	---------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.9.0	This command was introduced.
	Release 4.0.0	Command output was changed.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

The **show license backup** command displays the UDI information and license summary of a backup database, so that you can confirm the contents of a particular backup file before restoring it. Create the backup license file using the **license backup** command. Restore licenses from a backup using the **license restore** command.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	pkg-mgmt	read

The following example shows sample output from the **show license backup** command:

```
RP/0/RSP0/CPU0:router# admin
RP/0/RSP0/CPU0:router(admin)# show license backup disk0:/lic_backup.pkg

Tue Jul 27 17:12:44.982 pst

Local Chassis UDI Information:
S/N : FOX1316G5TL
Operation ID: 9

FeatureID: A9K-ADV-OPTIC-LIC (Slot based, Permanent)
Total licenses 1
Pool: Owner 1
Allocated Node(s):
0/0/CPU0 1 [Owner]

FeatureID: A9K-ADV-VIDEO-LIC (Slot based, Evaluation)
Total licenses 1
Pool: Owner 1
Allocated Node(s):
```

```

0/RSP0/CPU0 1 [Owner]

FeatureID: A9K-AIP-LIC-B (Slot based, Permanent)
Total licenses 2
Pool: Owner 2
Allocated Node(s):
 0/6/CPU0 1 [Owner]
 0/1/CPU0 1 [Owner]

FeatureID: A9K-AIP-LIC-E (Slot based, Permanent)
Total licenses 2
Pool: Owner 2
Allocated Node(s):
 0/4/CPU0 1 [Owner]

FeatureID: A9K-iVRF-LIC (Slot based, Permanent)
Total licenses 1
Pool: Owner 1

FeatureID: A9K-iVRF-LIC (Slot based, Evaluation)
Total licenses 3
Pool: Owner 3
Allocated Node(s):
 0/1/CPU0 1 [Owner]

```

**Table 72: show license backup Field Descriptions**

Field	Description
S/N	Chassis serial number.
Operation ID	License operation ID number. The license operation ID is incremented by the license manager every time there is a successful license add or remove operation.
FeatureID	Feature to which the licenses apply.
Type	Type of license: slot-based or chassis-based; permanent, evaluation, or implicit.
#installed	Number of such licenses installed.

**Related Topics**

[license backup](#), on page 864

[license restore](#), on page 871

# show license chassis

To display all licenses with their serial number information, use the **show license chassis** command in administration EXEC mode.

**show license chassis**

**Syntax Description** This command has no keywords or arguments.

**Command Default** None

**Command Modes** Administration EXEC

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operation
	pkg-mgmt	read



# show license evaluation

To display information about any evaluation licenses currently allocated, available, or in use, use the **show license evaluation** command in EXEC or administration EXEC mode.

**show license evaluation** [{*feature-id* | **location** *node-id* | **sdr** *sdr-name*}]

Syntax Description	
<i>feature-id</i>	(Optional) Identifier for the feature entitled in the licenses to be displayed.
<b>location</b> <i>node-id</i>	(Optional) Specifies the location of the card. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.
<b>sdr</b> <i>sdr-name</i>	(Optional) Displays the licenses in the specified secure domain router (SDR) license pool. The <i>sdr-name</i> argument is the name assigned to the SDR.

**Command Default** No default behavior or values

**Command Modes** Administration EXEC  
EXEC

Command History	Release	Modification
	Release 3.9.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **show license evaluation** command displays information regarding any evaluation licenses that are currently allocated, available, or in use, including the number of days left until they expire. You can display the information for a specific feature identifier, slot location, or SDR by using the available options.

Task ID	Task ID	Operations
	pkg-mgmt	read

The following example displays sample output from the **show license evaluation** command:

```
RP/0/RSP0/CPU0:router# admin
RP/0/RSP0/CPU0:router(admin)# show license evaluation

FeatureID: XC-L3VPN (Non slot based, Evaluation[Valid])
Valid for 2day(s) from 15:13:16 Nov 17 2006
Remaining time: 1 day(s) 21:07:46
Status: Available 6 Allocated 0 Active 0
 SDR: Owner
 Status: Available 6 Operational: 0
```

See [Table 71: show license Field Descriptions, on page 874](#) for a description of the significant fields shown in the display.

# show license expired

To display information regarding evaluation licenses that have expired, use the **show license expired** command in EXEC or administration EXEC mode.

```
show license expired [{feature-id | location node-id | sdr sdr-name}]
```

Syntax Description	
<i>feature-id</i>	(Optional) Identifier for the feature entitled in the licenses to be displayed.
<b>location</b> <i>node-id</i>	(Optional) Specifies the location of the card. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.
<b>sdr</b> <i>sdr-name</i>	(Optional) Displays the licenses in the specified secure domain router (SDR) license pool. The <i>sdr-name</i> argument is the name assigned to the SDR.

**Command Default** No default behavior or values

**Command Modes** Administration EXEC  
EXEC

Command History	Release	Modification
	Release 3.9.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **show license expired** command displays information regarding evaluation licenses that have expired. You can display the information for a specific feature identifier, slot location, or SDR by using the available options.

Task ID	Task ID	Operations
	pkg-mgmt	read

The following example displays sample output from the **show license expired** command:

```
RP/0/RSP0/CPU0:router# admin
RP/0/RSP0/CPU0:router(admin)# show license expired

FeatureID: XC-L3VPN (Non slot based, Evaluation[Expired])

Status: Available 6 Allocated 0 Active 0

SDR: Owner

Status: Available 6 Operational: 0
```

See [Table 71: show license Field Descriptions, on page 874](#) for a description of the significant fields shown in the display.

# show license features

To display all features that can be licensed on the router, use the **show license features** command in administration EXEC mode.

**show license features**

**Syntax Description** This command has no keywords or arguments.

**Command Default** None

**Command Modes** Administration EXEC

Command History	Release	Modification
	Release 3.9.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operation
	pkg-mgmt	read

## Example

The following example illustrates sample output from the **show license features** command.

```
RP/0/RSP0/CPU0:router(admin)# show license features
```

```
Tue Aug 18 06:36:09.180 DST
```

```
Platform Feature ID:
```

```
A9K-G709-LIC
A9K-VidMon-LIC
A9K-iVRF-LIC
A9K-AIP-LIC-B
A9K-AIP-LIC-E
```

# show license log

To display the operational or administrative logs for the license system, use the **show license log** command in EXEC or administration EXEC mode.

**show license log** {**operational** | **administration**} {*request-id**feature-id* | **sdr** *sdr-name*}

## Syntax Description

<b>operational</b>	Displays the operational logs for the license system.
<b>administration</b>	Displays the administration logs for the license system.
<i>request-id</i>	Identifier of a particular log entry.
<i>feature-id</i>	Identifier for the feature entitled in the licenses to be displayed.
<b>sdr</b> <i>sdr-name</i>	Displays the licenses in the specified secure domain router (SDR) license pool. The <i>sdr-name</i> argument is the name assigned to the SDR.

## Command Default

No default behavior or values

## Command Modes

Administration EXEC  
EXEC

## Command History

Release	Modification
Release 3.9.0	This command was introduced.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **show license log** command displays the operational or administrative logs for the license system. The administrative log displays all licenses that are added, removed, or moved along with a timestamp and username of the person who initiated the request. This log persists across reloads. The operation log displays when a license was checked out or released by a feature. The license release can be done by the license manager if it detects that the feature is not responding. This log does not persist between reloads.

You can display license information for a specific feature identifier or SDR by using the available options.

## Task ID

Task ID	Operations
pkg-mgmt	read

The following example displays sample output from the **show license log** command:

```
RP/0/RSP0/CPU0:router# admin
RP/0/RSP0/CPU0:router(admin)# show license log operational
#ID :SDR :FeatureID :NodeID :Time: Log
```

```
1 :Owner :
A9K-ADV-OPTIC-LIC
 :0/6/CPU0 :Tue Feb 6 21:33:16 2007:
 license_acquire: opaque_string , result(No error)
2 :Owner :
A9K-ADV-OPTIC-LIC
 :0/1/CPU0 :Tue Feb 6 21:33:16 2007:
 license_acquire: opaque_string , result(No error)
```

See [Table 71: show license Field Descriptions, on page 874](#) for a description of the significant fields shown in the display.

# show license pools

To display the currently configured set of license pools, use the **show license pools** command in administration EXEC mode.

**show license pools** [**detail**]

<b>Syntax Description</b>	<b>detail</b> (Optional) Displays the locations of the licenses in each pool.
---------------------------	-------------------------------------------------------------------------------

<b>Command Default</b>	No default behavior or values
------------------------	-------------------------------

<b>Command Modes</b>	Administration EXEC
----------------------	---------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.9.0	This command was introduced.

**Usage Guidelines**

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **show license pools** command displays all license pools, and the features that are enabled with the licenses in each pool. By default, all licenses are contained in the owner SDR pool. If you have created SDR license pools with the **license pool create** command, you can place licenses in separate pools.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	pkg-mgmt	read

The following example displays sample output from the **show license pools** command. In this example, the owner SDR has both 40-Gbps and Layer_3 VPN licenses, while the SDR sdr2 has only 40-Gbps licenses.

```
RP/0/RSP0/CPU0:router# admin
RP/0/RSP0/CPU0:router(admin)# show license pools

Pool Name Feature
=====
Owner
A9K-ADV-OPTIC-LIC
```

**Table 73: show license pools Field Descriptions**

Field	Description
Owner	SDR license pool.



Field	Description
Feature	Feature that is enabled in the specified license pool.

# show license udi

To display unique device identifier (UDI) information for the router, use the **show license udi** command in administration EXEC mode.

## show license udi

**Syntax Description** This command has no keywords or arguments.

**Command Default** No default behavior or values

**Command Modes** Administration EXEC

Command History	Release	Modification
	Release 3.9.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **show license udi** command displays the complete UDI of the router to which any license is associated. The UDI comprises the chassis serial number, along with a license operation ID number. The UDI is used to acquire a license file using the license registration tool on CCO. The license tool is located at <https://tools.cisco.com/SWIFT/Licensing/RegistrationServlet?>

Task ID	Task ID	Operations
	pkg-mgmt	read

The following example displays sample output from the **show license udi** command:

```
RP/0/RSP0/CPU0:router# admin
RP/0/RSP0/CPU0:router(admin)# show license udi
Mon Apr 26 06:40:06.234 DST

Local Chassis UDI Information:
 PID : ASR-9010-AC
 S/N : FOX1232H67M
 Operation ID: 5
```

**Table 74: show license udi Field Descriptions**

Field	Description
PID	Product ID number.
S/N	Chassis serial number.

Field	Description
Operation ID	License operation ID number. The license operation ID is incremented by the license manager every time there is a successful license add or remove operation.





## Software Package Management Commands

This chapter describes the Cisco IOS XR commands used to add packages to a router storage device, activate or deactivate packages, upgrade or downgrade existing packages, and display information about packages.

For detailed information about the concepts and tasks necessary to manage Cisco IOS XR software see *Cisco ASR 9000 Series Aggregation Services Router Getting Started Guide*.

- [clear install boot-options, on page 899](#)
- [clear install label, on page 900](#)
- [clear install log-history oldest, on page 901](#)
- [clear install rollback oldest, on page 903](#)
- [install abort, on page 905](#)
- [install activate, on page 907](#)
- [install activate \(IOS XR 64 bit\), on page 915](#)
- [install add, on page 918](#)
- [install attach, on page 924](#)
- [install auto-abort-timer stop, on page 926](#)
- [install boot-options, on page 927](#)
- [install commit, on page 929](#)
- [install deactivate, on page 931](#)
- [install deactivate \(IOS XR 64 bit\), on page 937](#)
- [install label, on page 939](#)
- [install remove, on page 942](#)
- [install rollback to, on page 945](#)
- [install upgrade source , on page 949](#)
- [show install, on page 952](#)
- [show install active, on page 955](#)
- [show install audit, on page 958](#)
- [show install auto-abort-timer, on page 961](#)
- [show install boot-options, on page 962](#)
- [show install inactive, on page 964](#)
- [show install issu inventory, on page 968](#)
- [show install issu stage, on page 969](#)
- [show install log, on page 970](#)
- [show install package, on page 975](#)
- [show install pie-info, on page 978](#)

- [show install request](#), on page 981
- [show install rollback](#), on page 983
- [show install which](#), on page 987
- [show issu-warm-reload control-protocol trace](#), on page 990
- [show zapdisk locations](#), on page 992
- [zapdisk start location](#), on page 993

# clear install boot-options

To clear the boot options for a specified location or for all locations, use the **clear install boot-options** command in administration EXEC mode.

```
clear install boot-options [location {node-id | all}]
```

<b>Syntax Description</b>	<b>location</b> { <i>node-id</i>   <b>all</b> } (Optional) Specifies a node. The <i>node-id</i> argument is expressed in the <i>rack/slot/module</i> notation. The <b>all</b> keyword specifies all nodes.						
<b>Command Default</b>	If no location is specified, the <b>clear install boot-options</b> command prompts you for confirmation and clears boot options for all locations.						
<b>Command Modes</b>	Administration EXEC						
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 3.7.2</td> <td>This command was introduced.</td> </tr> <tr> <td>Release 3.9.0</td> <td>No modification.</td> </tr> </tbody> </table>	Release	Modification	Release 3.7.2	This command was introduced.	Release 3.9.0	No modification.
Release	Modification						
Release 3.7.2	This command was introduced.						
Release 3.9.0	No modification.						
<b>Usage Guidelines</b>	<p>To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.</p> <p>Use the <b>clear install boot-options</b> command to clear boot options that were set using the <b>install boot-options</b> command.</p>						
<b>Task ID</b>	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operations</th> </tr> </thead> <tbody> <tr> <td>pkg-mgmt</td> <td>read, write</td> </tr> </tbody> </table>	Task ID	Operations	pkg-mgmt	read, write		
Task ID	Operations						
pkg-mgmt	read, write						

The following example shows how to clear the boot options for all locations:

```
RP/0/RSP0/CPU0:router(admin)#clear install boot-options
Install operation 4 '(admin) clear install boot-options location all' started
by user 'salevy' via CLI at 14:03:34 DST Sat Mar 15 2008.
Proceed with clearing boot options for all nodes? [confirm]
Install operation 4 completed successfully at 14:03:49 DST Sat Mar 15 2008.
```

## Related Topics

- [install boot-options](#), on page 927
- [show install boot-options](#), on page 962

# clear install label

To clear a label from an installation rollback point, use the **clear install label** command in EXEC or administration EXEC mode.

**clear install label** *label*

---

**Syntax Description**     *label* Label defined for an installation rollback point.

---



---

**Command Default**     No default behavior or values

---



---

**Command Modes**     EXEC  
Administration EXEC

---



---

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

---



---

**Usage Guidelines**     To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **clear install label** command to remove a label associated with an installation rollback point. Labels are assigned using the **install label** command.

---

Task ID	Task ID	Operations
	pkg-mgmt	read, write

---

In the following example, the label `brians_smu` is removed from the associated installation rollback point.

```
RP/0/RSP0/CPU0:router# clear install label brians_smu
```

```
Install operation 6 'clear install label brians_smu' started by user 'usr'
on SDR Owner via CLI at 09:28:04 DST Thu Aug 09 2007.
Install operation 6 completed successfully at 09:28:04 DST Thu Aug 09 2007.
```

## Related Topics

[install label](#), on page 939



# clear install log-history oldest

To clear the oldest log items from the installation history log, use the **clear install log-history oldest** command in EXEC or administration EXEC mode.

**clear install log-history oldest** *number*

<b>Syntax Description</b>	<i>number</i> Specifies the number of log entries to clear. The oldest log entries are cleared.
---------------------------	-------------------------------------------------------------------------------------------------

<b>Command Default</b>	No default behavior or values
------------------------	-------------------------------

<b>Command Modes</b>	EXEC Administration EXEC
----------------------	-----------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

Enter the **clear install log-history oldest** command in EXEC mode to clear the oldest installation history log entries only for the current secure domain router (SDR) user. (The log entries for the admin user are not cleared.)

Enter the **clear install log-history oldest** command in administration EXEC mode to clear the oldest installation history log entries for all users. (This command impacts all users when entered in administration EXEC mode.)

Use the *number* argument to specify the number of the old log entries to be deleted.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	pkg-mgmt	read, write

In the following example, the two oldest installation log history entries are cleared. Because this command is entered in EXEC mode, only the log entries for the current SDR user are deleted:

```
RP/0/RSP0/CPU0:router# clear install log-history oldest 2
```

```
Install operation 5 'clear install log-history oldest 2' started by user
'user_b' at 13:28:27 UTC Sat Aug 26 2006.
Info: Successfully deleted the following historylog points:
Info: 1, 2
Install operation 5 completed successfully at 13:28:29 UTC Sat Aug 26 2006.
```

In the following example, the five oldest installation log history entries are cleared for all users in the system. Because this command is entered in administration EXEC mode, the log entries for all SDR users are deleted:

```
RP/0/RSP0/CPU0:router# admin
RP/0/RSP0/CPU0:router(admin)# clear install log-history oldest 5

Install operation 6 '(admin) clear install log-history oldest 5' started by
user 'user_b' at 13:35:50 UTC Sat Aug 26 2006.
Info: Successfully deleted the following historylog points:
Info: 1, 2, 3, 4, 5
Install operation 6 completed successfully at 13:35:50 UTC Sat Aug 26 2006.
```

### Related Topics

[show install log](#), on page 970

[clear install rollback oldest](#), on page 903

# clear install rollback oldest

To delete saved installation points from the installation buffer, use the **clear install rollback oldest** command in EXEC or administration EXEC mode.

**clear install rollback oldest** *points*

<b>Syntax Description</b>	<i>points</i> Number of saved installation points to delete, beginning with the oldest saved installation point.						
<b>Command Default</b>	No default behavior or values						
<b>Command Modes</b>	EXEC Administration EXEC						
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 3.7.2</td> <td>This command was introduced.</td> </tr> <tr> <td>Release 3.9.0</td> <td>No modification.</td> </tr> </tbody> </table>	Release	Modification	Release 3.7.2	This command was introduced.	Release 3.9.0	No modification.
Release	Modification						
Release 3.7.2	This command was introduced.						
Release 3.9.0	No modification.						
<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.						
<b>Command Modes</b>	Enter the <b>clear install rollback oldest</b> command in administration EXEC or EXEC mode.						
<b>Task ID</b>	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operations</th> </tr> </thead> <tbody> <tr> <td>pkg-mgmt</td> <td>read, write</td> </tr> </tbody> </table>	Task ID	Operations	pkg-mgmt	read, write		
Task ID	Operations						
pkg-mgmt	read, write						

In the following example, the **show install rollback ?** command is used to display the available rollback points. The **clear install rollback oldest 2** command is then used to delete the two oldest rollback points. The **show install rollback ?** command is used again to display the remaining rollback points.

```
RP/0/RSP0/CPU0:router# admin
RP/0/RSP0/CPU0:router(admin)# show install rollback ?

 0 ID of the rollback point to show package information for
 2 ID of the rollback point to show package information for
 4 ID of the rollback point to show package information for
 9 ID of the rollback point to show package information for
10 ID of the rollback point to show package information for

RP/0/RSP0/CPU0:router(admin)# clear install rollback oldest 2

Install operation 11 'clear install rollback oldest 2' started by user 'user_b'
at 18:11:19 UTC Sat Apr 08 2006.
```

```
Info: Successfully deleted the following rollback points:
Info: 0, 2
Install operation 11 completed successfully at 18:11:21 UTC Sat Apr 08 2006.
```

```
RP/0/RSP0/CPU0:router(admin)# show install rollback ?
```

```
 4 ID of the rollback point to show package information for
 9 ID of the rollback point to show package information for
10 ID of the rollback point to show package information for
```

### Related Topics

[show install log](#), on page 970

[install rollback to](#), on page 945

[show install rollback](#), on page 983

# install abort

To abort an installation transaction, use the **install abort** command in administration EXEC mode.

```
install abort [request-id]
```

## Syntax Description

*request-id* (Optional) Request ID assigned to an installation operation.

## Command Default

Abort the current installation operation.

## Command Modes

Administration EXEC

## Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	No modification.
Release 4.0.0	This command was removed from EXEC mode.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **install abort** command to halt a software installation operation that is in process or that has been suspended.

Only activation, deactivation, and rollback operations can be aborted. Specifically, the **install abort** command cannot be aborted, but the **install add** command with the **activate** keyword can be aborted.

Use the **install abort** command with the *request-id* argument to halt a specific installation operation if the *request-id* is currently in process.

## Task ID

### Task ID Operations

```
pkg-mgmt read,
write
```

The following example shows how to halt an installation operation:

```
RP/0/RSP0/CPU0:router# admin
RP/0/RSP0/CPU0:router(admin)# install abort
```

```
Info: Please confirm your 'install abort' request by pressing Enter or y, or pressing n to
cancel it.
```

```
Do you really want to abort install operation 15? [confirm] <enter>
```

```
Abort confirmed.
```

```
Please check console to verify the operation is aborted.
```

**Related Topics**

[install activate](#), on page 907

[install add](#), on page 918

[install deactivate](#), on page 931

# install activate

To add software functionality to the active software set, use the **install activate** command in Admin EXEC mode or EXEC mode.

```
install activate {device:package | id add-id} [auto-abort-timer time] [location node-id] [issu]
[if-active] [{asynchronous | synchronous}] [parallel-reload] [prompt-level {default | none}] [test]
[pause sw-change]
```

Syntax Description	
<i>device:package</i>	<p>Device and package, expressed in concatenated form (for example, disk0:asr9k-mgbl-4.0.0).</p> <p>For the <i>device</i> argument, the value is a specified storage device, typically disk0:. This is the local storage device where the package was added with the <b>install add</b> command.</p> <p>Press ? after a partial package name to display all possible matches available for activation. If there is only one match, press the <b>Tab</b> key to fill in the rest of the package name. Up to 16 device–package pairs can be specified.</p> <p><b>Note</b> Multiple packages can be activated at one time. Up to 16 packages can be specified in a single <b>install activate</b> command. Multiple packages can be specified using the wildcard syntax, for example, harddisk:*4.0*. If multiple Software Maintenance Upgrades (SMUs) are activated, some SMUs may require a reload. If the operation requires a node reload, the user is prompted before the installation operation occurs.</p>
<b>id</b> <i>add-id</i>	<p>Specifies the ID number of an <b>install add</b> operation. The command activates all packages that were added in the specified <b>install add</b> operation. The ID number of an <b>install add</b> operation is indicated in the syslog displayed during the operation and in the output of the <b>show install log</b> command. Up to 16 <b>install add</b> operations can be specified.</p>
<b>auto-abort-timer</b> <i>time</i>	<p>(Optional) Specifies an abort timer value, in minutes, which when expired loads the last committed loadpath.</p>

<b>location</b> <i>node-id</i>	(Optional) Activates a package on the designated node. The <i>node-id</i> argument is expressed in <i>rack/slot/module</i> notation.  <b>Note</b> A package cannot be activated on a single node unless some version of the package being activated is already active on all nodes. For example, a Multiprotocol Label Switching (MPLS) package cannot be active on only one node. If a version of the MPLS package is already active on all nodes, an MPLS package then could be upgraded or downgraded on a single node.  <b>Note</b> To activate a package on all supported nodes, do not specify a location.
<b>issu</b>	Performs an in-service software upgrade.
<b>if-active</b>	(Optional. Administration EXEC mode only) Activates an optional package or SMU for an optional package only if an earlier version of the package is already active.
<b>asynchronous</b>	(Optional) Performs the command in asynchronous mode. In asynchronous mode, the command runs in the background, and the EXEC prompt is returned as soon as possible. This is the default mode.
<b>synchronous</b>	(Optional) Performs the command in synchronous mode. This mode allows the installation process to finish before the prompt is returned.
<b>parallel-reload</b>	(Optional) Forces all cards on the router to reload at the same time and then come up with the new software, rather than proceeding according to the option encoded in the install package.
<b>prompt-level</b> { <b>default</b>   <b>none</b> }	(Optional) Specifies when you are prompted for input during the procedure.  <ul style="list-style-type: none"> <li>• <b>default</b>—You are prompted only when input is required by the operation.</li> <li>• <b>none</b>—You are never prompted.</li> </ul>
<b>test</b>	(Optional) Verifies the effects of proposed operations without making changes to the Cisco IOS XR software.
<b>pause sw-change</b>	(Optional) Pauses the operation after the preparatory stage and before locking the configuration for the actual software change. While the operation is paused, you can perform configuration changes. You control the resumption of the operation from the command-line interface (CLI) prompt.

**Command Default**

If the **install prepare** command was not executed prior to **install activate**, executing the **install activate** command without any keywords aborts the process.

- Package is activated for all supported nodes in the system.
- Operation is performed in asynchronous mode: The **install activate** command runs in the background, and the EXEC prompt is returned as soon as possible.



**Command Modes** Admin EXEC mode  
EXEC mode

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.
	Release 4.0.0	This command was removed from EXEC mode. Support for the <b>sdr</b> keyword was removed.
	Release 4.1.0	The auto-abort timer was changed to enabled by default. The <b>off</b> keyword was added to disable the auto-abort timer. The <b>issu</b> keyword was added.

**Usage Guidelines** Use the **install activate** command to activate software packages or SMUs for all valid cards. Information within the package is used to verify compatibility with the target cards and with the other active software. Actual activation is performed only after the package compatibility and application program interface (API) compatibility checks have passed.

### Specifying Packages to Activate

You can either use the **id add-id** keyword and argument to activate all packages that were added in one or more specific **install add** operations, or specify packages by name. The operation ID of an **install add** operation is indicated in the syslog displayed during the operation and in the output of the **show install log** command. If you specify packages according to operation ID, all the packages that were added by the specified operation must still be on the router.

### Upgrading and Downgrading Packages

- To upgrade a package, activate the later version of the package; the earlier version is automatically deactivated.
- To downgrade a package, activate the earlier version of the package; the later version is automatically deactivated.



**Caution** Downgrading to Cisco IOS XR Software Release 3.7.0 or earlier is not supported if you are using a FAT32 flash disk. If you are using a FAT32 flash disk, and you must downgrade, convert the flash disk to FAT16 before downgrading. If you do not convert the flash disk to FAT16 before the downgrade, the disk becomes unreadable and the router does not boot. Converting from FAT32 to FAT16 is a complex procedure.



**Note** Activating a Software Maintenance Update (SMU) does not cause any earlier SMUs, or the package to which the SMU applies, to be automatically deactivated.

### Activating New Versions of the Currently Active Packages

Use the **install activate** command with the **if-active** keyword to activate the package only on SDRs where an earlier version of the package is already active. This command is available only in administration EXEC mode.

The **if-active** keyword is used only for optional packages or SMUs for optional packages.

### Router Reloads Following Package Activation

If the activation requires a reload of the SDR, a confirmation prompt appears. Use the **install activate** command with the **prompt-level none** keywords to automatically ignore any reload confirmation prompts and proceed with the package activation. The router reloads if required.

### Node Reloads Following Package Activation

If the software activation requires a router reload, a confirmation prompt appears.

### Node Reloads Following Package Activation

If a software operation requires a node reload, the config-register for that node should be set to autoboot. If the config-register for the node is not set to autoboot, the system automatically changes the setting and the node reloads. A message describing the change is displayed.

### Synchronous Mode

Use the **install activate** command with the **synchronous** keyword to complete the operation before the prompt is returned. A progress bar indicates the status of the operation. For example:

```
- 1% complete: The operation can still be aborted (ctrl-c for options)
\ 10% complete: The operation can still be aborted (ctrl-c for options)
```

When the **install activate** command is run in asynchronous mode, the system may stay in synchronous mode for a short period of time while the system checks for questions to ask the user.

Press **Ctrl-C** during a synchronous operation to abort the operation or make the operation asynchronous.

### Test Option

Use the **test** keyword to verify the effects of the proposed operations and determine whether the installation can be completed. After previewing the effects of the proposed operations, use the **show install log** command for more details about the effects of the proposed operations.

### Auto-abort Option

Use the **auto-abort-timer** keyword to provide a safety mechanism for the instance that a package is activated and access to the router is lost. This option automatically rolls back to the current committed loadpath, thereby undoing any changes that are activated with the **install activate** command. After the installation, if the activated software is working correctly, use the **install commit** command to cancel the timer and commit the new loadpath. The auto-abort timer is enabled to 60 minutes by default.



**Note** The changes made to the active software set are not persistent during route processor (RP) reloads. Use the **install commit** command to make changes persistent.

### Parallel Reload

Install operations are activated according to the method encoded in the package being activated. Generally, this method has the least impact for routing and forwarding purposes, but it may not be the fastest method from start to finish and can require user interaction by default. To perform the installation procedure as quickly as possible, you can specify the **parallel-reload** keyword. This action forces the installation to perform a parallel reload, so that all cards on the router reload simultaneously and then come up with the new software. This impacts routing and forwarding, but it ensures that the installation is performed without other issues.

### Pausing Before Configuration Lock

Use the **pause sw-change** keywords to pause the operation before locking the configuration. An **install activate** operation begins with preparatory steps, such as software checks, and then proceeds with the actual activation of the new software. The configuration is locked for the activation. If you specify the **pause sw-change** keywords, the operation pauses before locking the configuration and provides you with the option to hold the operation while you perform configuration changes, and you can proceed with the activation whenever you choose. This action is useful, for example, if your workflow involves configuring a router out of the network during software installation and you want to minimize the time that the router is out of the network. You can specify these keywords for both asynchronous and synchronous operations. In both cases, follow the onscreen instructions to control the pausing and completion of the operation.

### ISSU

Note the following prerequisites before activating software packages using ISSU:

- You must have a sufficient amount of free memory available on the line cards being upgraded.

Line Card	Part Numbers	Required Memory ³
Cisco ASR 9000 Series 24-Port 10 Gigabit Ethernet Line Cards Cisco ASR 9000 Series 36-Port 10 Gigabit Ethernet Line Cards	A9K-24X10GE-xx A9K-36X10GE-xx	1099 MB
Cisco ASR 9000 Series 2-Port 100 Gigabit Ethernet Line Cards	A9K-2X100GE-xx	1091 MB
Cisco ASR 9000 Series Modular Line Cards	A9K-MOD80-xx A9K-MOD160-xx	1087 MB
SIP 700 for the ASR 9000 router	A9K-SIP-700	1563 MB
4-Port 10GE Medium Queue Line Card	A9K-4T-B	1071 MB
40-Port GE Medium Queue Line Card	A9K-40G-B	1071 MB
8-Port 10GE Medium Queue Oversubscribed Line Card	A9K-8T/4-B	1071 MB

Line Card	Part Numbers	Required Memory ³
2-Port 10GE, 20-Port GE Medium Queue Combo Line Card	A9K-2T20GE-B	1071 MB
8-Port 10GE Medium Queue Line Card	A9K-8T-B	711 MB
16-Port 10GE Medium Queue Oversubscribed Line Card	A9K-16/8T-B	711 MB
4-Port 10GE High Queue Line Card	A9K-4T-E	711 MB
40-Port GE High Queue Line Card	A9K-40G-E	711 MB
8-Port 10GE High Queue Oversubscribed Line Card	A9K-8T/4-E	711 MB
2-Port 10GE, 20-Port GE High Queue Combo Line Card	A9K-2T20GE-E	711 MB
8-Port 10GE High Queue Line Card	A9K-8T-E	711 MB

³ Approximate value for low to medium scale.

- You must have enough disk space for V1 and V2 images, PIEs and SMUs. This prerequisite is no different than that of a non-ISSU upgrade.
- All software packages currently running on the system must be included in the software upgrade image.
- Cisco recommends that you do a backup of the ASCII configuration before each upgrade.

Note the following restrictions regarding ISSU:

- Refer to your release notes for a complete list of hardware that cannot be upgraded during the ISSU process. If you have any non-supported hardware running in your system, the upgrade process automatically shuts them down and reloads them after the upgrade is complete.
- Ethernet OAM flaps after an ISSU upgrade.
- ISSU downgrade is not supported.
- ISSU is not supported on the NV cluster set-up.

## Task ID

## Task ID Operations

pkg-mgmt execute

The following example shows how to display the packages available for activation using the online help system. In this example, ? is entered after a partial package name to display all possible matches:

```
RP/0/RSP0/CPU0:router# admin
RP/0/RSP0/CPU0:router(admin)# install activate disk0:?

disk0:comp-asr9k-mini-3.7.2 disk0:asr9k-admin-3.7.2 disk0:asr9k-base-3.7.2
disk0:asr9k-diags-3.7.2
disk0:asr9k-fwgd-3.7.2 disk0:asr9k-k9sec-3.7.2 disk0:asr9k-lc-3.7.2
disk0:asr9k-mcast-3.7.2
```

```
disk0:asr9k-mgbl-3.7.2 disk0:asr9k-mpls-3.7.2 disk0:asr9k-os-mbi-3.7.2.1
I disk0:asr9k-rout-3.7.2
```

The following example shows how to activate a package that was installed in an **install add** operation that was assigned install operation id 2:

```
RP/0/RSP0/CPU0:router(admin)# install activate id 2

Install operation 3 '(admin) install activate id 2' started by user 'lab' via
CLI at 01:10:21 UTC Thu Jan 03 2008.
Info: This operation will activate the following package:
Info: disk0:asr9k-mcast-3.7.0
Info: Install Method: Parallel Process Restart
The install operation will continue asynchronously.
Info: The changes made to software configurations will not be persistent
Info: across system reloads. Use the command '(admin) install commit' to
Info: make changes persistent.
Info: Please verify that the system is consistent following the software
Info: change using the following commands:
Info: show system verify
Info: install verify packages
Install operation 3 completed successfully at 01:11:30 UTC Thu Jan 03 2008.
```

The following example shows how to activate a package on all nodes. Use the **install commit** command to make the changes persistent across designated secure domain router shelf controller (DSDRSC) reloads.

```
RP/0/RSP0/CPU0:router# admin
RP/0/RSP0/CPU0:router(admin)# install activate disk0:asr9k-mpls-3.4.0 synchronous

Install operation 15 'install activate disk0:asr9k-mpls-3.4.0 synchronous'
started by user 'user_b' at 19:15:33 UTC Sat Apr 08 2006.
Info: The changes made to software configurations will not be persistent
Info: across system reloads. Use the command 'admin install commit' to make
Info: changes persistent.
Info: Please verify that the system is consistent following the software
Info: change using the following commands:
Info: show system verify
Info: install verify
Install operation 15 completed successfully at 19:16:18 UTC Sat Apr 08 2006.

RP/0/RSP0/CPU0:router(admin)# install commit

Install operation 16 'install commit' started by user 'user_b' at 19:18:58 UTC
Sat Apr 08 2006.
Install operation 16 completed successfully at 19:19:01 UTC Sat Apr 08 2006.
```

The following example shows how to activate multiple software packages using the wildcard syntax:

```
RP/0/RSP0/CPU0:router# admin
RP/0/RSP0/CPU0:router(admin)# install activate disk0:*3.7.2*

Install operation 2 '(admin) install activate disk0:*3.7.2*' started by user
'user_a' via CLI at 04:30:01 PST Fri Dec 28 2007.
Info: This operation will activate the following packages:
Info: disk0:asr9k-rout-3.7.2
Info: disk0:asr9k-lc-3.7.2
Info: disk0:asr9k-fwdg-3.7.2
```

```

Info: disk0:asr9k-admin-3.7.2
Info: disk0:asr9k-base-3.7.2
Info: disk0:asr9k-os-mpi-3.7.2
Info: disk0:asr9k-fpd-3.7.2
Info: disk0:asr9k-diags-3.7.2
Info: disk0:asr9k-mgbl-3.7.2
Info: disk0:asr9k-mpls-3.7.2
Info: disk0:asr9k-mcast-3.7.2
Info: disk0:asr9k-k9sec-3.7.2
Warning: The following packages are already active on the specified nodes:
Warning: asr9k-os-mpi-3.7.2
Warning: asr9k-base-3.7.2
Warning: asr9k-admin-3.7.2
Warning: asr9k-fwdg-3.7.2
Warning: asr9k-lc-3.7.2
Warning: asr9k-rout-3.7.2
Warning: Please check:
Warning: - check the name of the packages being activated.
Warning: - check the set of active packages using 'show install active'.
Info: Install Method: Parallel Process Restart
Info: The changes made to software configurations will not be persistent
across system reloads. Use the command '(admin)
Info: install commit' to make changes persistent.
Info: Please verify that the system is consistent following the software
change using the following commands:
Info: show system verify
Info: install verify packages
Install operation 2 completed successfully at 04:32:01 PST Fri Dec 28 2007.

```

The warning messages are expected, because the packages are already active.


### Related Topics

- [install add](#), on page 918
- [install deactivate](#), on page 931
- [install commit](#), on page 929
- [install activate \(IOS XR 64 bit\)](#), on page 915
- [install deactivate \(IOS XR 64 bit\)](#), on page 937

## install activate (IOS XR 64 bit)

To enable the package configurations to be made active on the router so new features and software fixes take effect, use the **install activate** command in EXEC mode or Admin EXEC mode.

```
install activate package_name
install activate id operation_id
```

<b>Syntax Description</b>	<p><i>package_name</i></p> <p>Enter the package names separated by space.</p> <p><b>Note</b> Up to 16 packages can be specified in a single <b>install activate</b> command at a time. Multiple packages can be specified using the wildcard syntax, for example, <code>asr9k-*-x64-*3I</code>.</p>				
	<p><i>id operation_id</i></p> <p>The <i>operation_id</i> is the ID from the <b>install add</b> operation.</p> <p>The <b>show install request</b> command displays the operation id number of the <b>install add</b> operation and its status. You can also find the <i>operation_id</i> in the <b>show install log</b> command output.</p>				
<b>Command Default</b>	<p>The <b>install activate</b> command activates all packages that were added in the specified <b>install add</b> operation and the operation is performed in an asynchronous mode. The command runs in the background and the EXEC prompt is returned soon after.</p> <p>If you use the operation ID (from the add operation) to activate packages, all packages that were added in the specified install add operation are activated together. You do not have to activate the packages individually.</p> <p>For example, if five packages are added in operation 6, all the five packages are activated together by executing <b>install activate id 6</b> command.</p>				
 <p><b>Note</b></p>	<ul style="list-style-type: none"> <li>• Activation takes some time and does not happen instantaneously.</li> <li>• Activation of some SMUs require a manual reloading of the router. When such SMUs are activated, a warning message is displayed to perform reload. The components of the SMU get activated only after the reload is complete.</li> </ul>				
<b>Command Modes</b>	<p>EXEC mode</p> <p>Admin EXEC mode</p>				
<b>Command History</b>	<table border="1"> <thead> <tr> <th data-bbox="383 1717 797 1770">Release</th> <th data-bbox="797 1717 1528 1770">Modification</th> </tr> </thead> <tbody> <tr> <td data-bbox="383 1770 797 1820">Release 6.1.2</td> <td data-bbox="797 1770 1528 1820">Support for IOS XR 64 bit <b>install activate</b> command was added.</td> </tr> </tbody> </table>	Release	Modification	Release 6.1.2	Support for IOS XR 64 bit <b>install activate</b> command was added.
Release	Modification				
Release 6.1.2	Support for IOS XR 64 bit <b>install activate</b> command was added.				

**Usage Guidelines**

- Only inactive packages can be activated. Use the **show install inactive** command to identify the inactive packages that are present in the repository.
- If you want to activate packages using the **install activate id *operation_id*** command syntax, use the **show install log** command to identify the operation ID of the add operation.

The following example lets you activate packages by specifying the package names:

```
RP/0/RSP0/CPU0:router# install activate asr9k-m2m-x64-2.0.0.0-r61106I.x86_64
asr9k-optic-x64-1.0.0.0-r61106I.x86_64

Jun 22 14:09:25 Package list:
Jun 22 14:09:25 asr9k-m2m-x64-2.0.0.0-r61106I.x86_64
Jun 22 14:09:25 asr9k-optic-x64-1.0.0.0-r61106I.x86_64
Jun 22 14:09:35 Install operation will continue in the background

RP/0/RSP0/CPU0:router#
```

The following example lets you activate packages by specifying the id from the add operation:

```
RP/0/RSP0/CPU0:router# install activate id 6

Jun 22 15:02:24 Package list:
Jun 22 15:02:24 asr9k-bgp-x64-1.0.0.0-r61106I.x86_64
Jun 22 15:02:24 asr9k-isis-x64-1.0.0.0-r61106I.x86_64
Jun 22 15:02:24 asr9k-k9sec-x64-1.1.0.0-r61106I.x86_64
Jun 22 15:02:24 asr9k-li-x64-1.1.0.0-r61106I.x86_64
Jun 22 15:02:24 asr9k-parser-x64-1.0.0.0-r61106I.x86_64
Jun 22 15:02:24 asr9k-m2m-x64-2.0.0.0-r61106I.x86_64
Jun 22 15:02:24 asr9k-mgbl-x64-2.0.0.0-r61106I.x86_64
Jun 22 15:02:24 asr9k-optic-x64-1.0.0.0-r61106I.x86_64
Jun 22 15:02:24 asr9k-mcast-x64-1.1.0.0-r61106I.x86_64
Jun 22 15:02:24 asr9k-mpls-te-rsvp-x64-1.0.0.0-r61106I.x86_64
Jun 22 15:02:24 asr9k-eigrp-x64-1.0.0.0-r61106I.x86_64
Jun 22 15:02:24 asr9k-ospf-x64-1.0.0.0-r61106I.x86_64
Jun 22 15:02:24 asr9k-mpls-x64-2.0.0.0-r61106I.x86_64
Jun 22 15:02:25 Skipped packages which were already active:
Jun 22 15:02:25 asr9k-bgp-x64-1.0.0.0-r61106I.x86_64
Jun 22 15:02:25 asr9k-m2m-x64-2.0.0.0-r61106I.x86_64
Jun 22 15:02:25 asr9k-optic-x64-1.0.0.0-r61106I.x86_64
Jun 22 15:02:33 Install operation will continue in the background

RP/0/RSP0/CPU0:router#
```

The following example lets you activate multiple packages using the wildcard syntax:

```
RP/0/RSP0/CPU0:router#install activate asr9k-*-x64-*3I

Jun 16 19:35:06 Install operation 105 started by root:
install activate pkg asr9k-*-x64-*3I
Jun 16 19:35:06 Package list:
Jun 16 19:35:06 asr9k-eigrp-x64-1.0.0.0-r61103I.x86_64
Jun 16 19:35:06 asr9k-ospf-x64-1.0.0.0-r61103I.x86_64
Jun 16 19:35:06 asr9k-m2m-x64-2.0.0.0-r61103I.x86_64
Jun 16 19:35:06 asr9k-k9sec-x64-1.1.0.0-r61103I.x86_64
```



```
Jun 16 19:35:06 asr9k-mpls-x64-1.1.0.0-r61103I.x86_64
Jun 16 19:35:06 asr9k-bgp-x64-1.0.0.0-r61103I.x86_64
Jun 16 19:35:06 asr9k-isis-x64-1.0.0.0-r61103I.x86_64
Jun 16 19:35:06 asr9k-mini-x64-6.1.1.03I
Jun 16 19:35:06 asr9k-mgbl-x64-2.0.0.0-r61103I.x86_64
Jun 16 19:35:06 asr9k-parser-x64-1.0.0.0-r61103I.x86_64
Jun 16 19:35:06 asr9k-optic-x64-1.0.0.0-r61103I.x86_64
Jun 16 19:35:06 asr9k-mcast-x64-1.1.0.0-r61103I.x86_64
Jun 16 19:35:06 asr9k-mpls-te-rsvp-x64-1.0.0.0-r61103I.x86_64
Jun 16 19:35:06 asr9k-li-x64-1.0.0.0-r61103I.x86_64
Jun 22 15:02:33 Install operation will continue in the background
```

```
RP/0/RSP0/CPU0:router#
```

# install add

To copy the contents of a package installation envelope (PIE) file to a storage device, use the **install add** command in Admin EXEC mode EXEC mode.

```
install add [{source source-path | tar}] file [activate [pause sw-change] [auto-abort-timer time]
[location node-id] [issu]] [{asynchronous | synchronous}] [parallel-reload] [prompt-level {default
| none}] [if-active]
```

## Syntax Description

<b>source</b> <i>source-path</i>	(Optional) Specifies the source location of the PIE files to be appended to the PIE filenames. Location options are as follows: <ul style="list-style-type: none"> <li>• <b>disk0:</b></li> <li>• <b>disk1:</b></li> <li>• <b>compactflash:</b></li> <li>• <b>harddisk:</b></li> <li>• <b>ftp://username :password@hostname</b> or <i>ip-address / directory-path</i></li> <li>• <b>rcp://username@hostname</b> or <i>ip-address / directory-path</i></li> <li>• <b>tftp://hostname</b> or <i>ip-address / directory-path</i></li> </ul>
<b>tar</b>	(Optional) Indicates that the PIE file is contained in a tar file.
<i>file</i>	Name and location of the PIE file (composite package) to install. If a source path location is specified using the <b>source</b> keyword, the <i>file</i> argument can be either a fully specified PIE file path, or a path to the PIE file relative to the source path. <p><b>Note</b> Up to 32 PIE files can be added to a device in a single <b>install add</b> operation.</p> <p>If the <b>tar</b> keyword is used, the <i>file</i> argument is a tar file that contains one or more PIE files, or directories containing PIE files. Up to 16 tar files can be added, out of the possible 32 install files.</p>
<b>activate</b>	(Optional) Activates the package or packages. This option is run only if the <b>install add</b> operation is successful.
<b>pause sw-change</b>	(Optional) Pauses the operation before locking the configuration for the software activation. While the operation is paused, you can perform configuration changes. You control the resumption of the operation at the CLI prompt.
<b>auto-abort-timer</b> <i>time</i>	(Optional) Specifies an abort timer value, <i>time</i> , in minutes, which when expired loads the last committed loadpath.

<b>location</b> <i>node-id</i>	(Optional) Activates a package on the designated node. The <i>node-id</i> argument is expressed in <i>rack/slot/module</i> notation.  <b>Note</b> A package cannot be activated on a single node unless some version of the package being activated is already active on all nodes. For example, a Multiprotocol Label Switching (MPLS) package cannot be active on only one node. If a version of the MPLS package is already active on all nodes, an MPLS package then could be upgraded or downgraded on a single node.
<b>issu</b>	Performs an in-service software upgrade. Refer to the <b>install activate</b> command for more detailed information.
<b>asynchronous</b>	(Optional) Performs the command in asynchronous mode. In asynchronous mode, this command runs in the background, and the EXEC prompt is returned as soon as possible. This is the default mode.
<b>synchronous</b>	(Optional) Performs the command in synchronous mode. This mode allows the installation process to finish before the prompt is returned.
<b>parallel-reload</b>	(Optional) Forces all cards on the router to reload at the same time and then come up with the new software, rather than proceeding according to the option encoded in the install package.
<b>prompt-level</b> { <b>default</b>   <b>none</b> }	(Optional) Specifies when you are prompted for input during the procedure.  <ul style="list-style-type: none"> <li>• <b>default</b>—You are prompted only when input is required by the operation.</li> <li>• <b>none</b>—You are never prompted.</li> </ul>
<b>if-active</b>	(Optional. Administration EXEC mode only.) Activates the optional packages only if a version is already active.

**Command Default**

Packages are added to the storage device, but are not activated.

The operation is performed in asynchronous mode. The **install add** command runs in the background, and the EXEC prompt is returned as soon as possible.

**Command Modes**

EXEC mode  
Admin EXEC mode

**Command History**

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	No modification.

Release	Modification
Release 4.0.0	This command was removed from EXEC mode. The <b>sdr</b> keyword was removed.
Release 4.1.0	The <b>issu</b> keyword was added.
Release 6.0.1	The syntax of the command was modified to append a forward slash (/) to the source location (disk0:, disk1:, compactflash:, harddisk: and so on) of the PIE file.

### Usage Guidelines

Use the **install add** command to unpack the package software files from a PIE file and copy them to the boot device (usually disk0:).

From Cisco IOS XR Software Release 6.0.1 onwards, you must use a forward slash (/) to the source location of the PIE file while using **install add** command. For example, instead of **install add harddisk:file**, use **install add harddisk:/file**.

The package software files are added to the boot device of the designated secure domain router system controller (DSDRSC) for all SDRs on the router, as well as all active and standby Route Processors (RPs) and fabric shelf controllers (SCs) installed on the router.

### Adding and Activating a Package

Software packages remain inactive until activated with the [install activate, on page 907](#) command.

To add and activate a package at the same time, use the **install add** command with the **activate** keyword. When this command is used, the keywords and rules for package activation apply. See [install activate, on page 907](#) for more information.



**Note** SDR-specific activation is supported for specific packages and upgrades, such as optional packages and Software Maintenance Upgrades (SMUs). Packages that do not support SDR-specific activation can be activated for all SDRs simultaneously only from administration EXEC mode. For detailed instructions, see the *Managing Cisco IOS XR Software Packages* module of *System Management Configuration Guide for Cisco ASR 9000 Series Routers*.



**Note** If a software activation requires a node reload, the config-register for that node should be set to autoboot. If the config-register for the node is not set to autoboot, then the system automatically changes the setting and the node reloads. A message describing the change is displayed.

### Synchronous Mode

Use the **install add** command with the **synchronous** keyword to complete the operation before the prompt is returned. A progress bar indicates the status of the operation. For example:

```
- 1% complete: The operation can still be aborted (ctrl-c for options)
\ 10% complete: The operation can still be aborted (ctrl-c for options)
```

### TFTP Services and Image Size

Some Cisco IOS XR images may be larger than 32 MB, and the TFTP services provided by some vendors may not support a file this large. If you do not have access to a TFTP server that supports files larger than 32 MB:

- Download the software image using FTP or rcp.
- Use a third-party or freeware TFTP server that supports file sizes larger than 32 MB.

### Adding tar Files

Use the **tar** keyword to add one or more PIE files in the tar file format. If the **tar** keyword is used, only a single tar file can be added.



---

**Note** Multiple tar files or a combination of PIE and tar files is not supported.

---

Note the following regarding tar files:

- The *file* argument must include the complete location of the tar file.
- The tar file can contain only PIE files and directories containing PIE files. For example:
  - The tar file pies.tar containing the files x.tar and y.pie fails because x.tar is not a PIE file.
  - The tar file pies.tar containing the file x.pie and the directory dir_a, where dir_a contains a PIE file y.pie succeeds.
  - The tar file pies.tar containing the file x.pie and the directory dir_a, where dir_a contains a tar file y.tar fails because y.tar is not a PIE file.
  - The tar file pies.tar containing the PIE files x.pie, y.pie, ...*.pie succeeds.
- The **source** keyword is not supported with the **tar** keyword.

Following is a valid example of using the **tar** keyword:

```
RP/0/RSP0/CPU0:router(admin)# install add tar
tftp://223.255.254.254/install/files/pies.tar
```

You can add and activate tar files at the same time. In other words, the **install add** command is supported using the **tar** and the **activate** keywords simultaneously.

### Adding Multiple Packages

To add multiple PIE files, use the **source** keyword to specify the directory path location of the PIE files. Then list all the PIE filenames, as necessary. This alleviates the need to repeat the directory location for each PIE file. Up to 32 files can be added, of which 16 can be tar files.

Following is an example of the **install add** command using the **source** keyword:

```
RP/0/0/CPU0:router(admin)# install add source
tftp://192.168.201.1/images/myimages/comp-asr9k-mini.pie
asr9k-mgbl-p.pie asr9k-mpls-p.pie
asr9k-mcast-p.pie
```

The following example also illustrates a valid use of the **install add** command with the **source** keyword:

```
RP/0/RSP0/CPU0:router(admin)# install add source
tftp://192.168.254.254/images/user/asr9k-mcast-p.pie
pies/asr9k-mpls-p.pie
ftp://1.2.3.4/other_location/asr9k-mgbl-p.pie
```

In the previous example, three PIE files are added from the following locations:

- tftp://192.168.254.254/images/user/asr9k-mcast-p.pie
- tftp://192.168.254.254/images/user/pies/asr9k-mpls-p.pie
- ftp://1.2.3.4/other_location/asr9k-mgbl-p.pie

### Parallel Reload

Installation operations are activated according to the method encoded in the package being activated. Generally, this method has the least impact for routing and forwarding purposes, but it may not be the fastest method from start to finish and can require user interaction by default. To perform the installation procedure as quickly as possible, you can specify the **parallel-reload** keyword. This forces the installation to perform a parallel reload, so that all cards on the router reload simultaneously, and then come up with the new software. This impacts routing and forwarding, but it ensures that the installation is performed without other issues.

### Pausing Activation Before Configuration Lock

If you specify the **activate** keyword, use the **pause sw-change** keywords to pause the software activation operation before locking the configuration. A software activation operation begins with preparatory steps, such as software checks, and then proceeds with the actual activation of the new software. The configuration is locked for the activation. If you specify the **pause sw-change** keywords, the operation pauses before locking the configuration and provides you with the option to hold the operation while you perform configuration changes, and proceed with the activation whenever you choose. This is useful, for example, if your workflow involves configuring a router out of the network during software installation and you want to minimize the time that the router is out of the network. You can specify these keywords for both asynchronous and synchronous operations. In both cases, follow the onscreen instructions to control the pausing and completion of the operation.

### Task ID

#### Task ID Operations

```
pkg-mgmt execute
```

The following example shows how to add a PIE file for all SDRs in the system. In the following example, a Multiprotocol Label Switching (MPLS) package is added in synchronous mode. This operation copies the files required for the package to the storage device. This package remains inactive until it is activated with the **install activate** command.

```
RP/0/RSP0/CPU0:router# admin
RP/0/RSP0/CPU0:router(admin)# install add
tftp://209.165.201.1/asr9k-mpls.pie synchronous
```

```
Install operation 4 'install add /tftp://209.165.201.1/asr9k-mpls.pie synchronous'
 started by user
'user_b' at 03:17:05 UTC Mon Nov 14 2005.
Info: The following package is now available to be activated:
Info:
```

```
Info: disk0:asr9k-mpls-3.3.80
Info:
Install operation 4 completed successfully at 03:18:30 UTC Mon Nov 14 2005.
```

In the following example, a package is added and activated with a single command:

```
RP/0/RSP0/CPU0:router# admin
RP/0/RSP0/CPU0:router(admin)# install add disk1:/asr9k-mpls-px.pie-6.0.1activate

Install operation 4 'install add /disk1:/asr9k-mpls-px.pie-6.0.1 activate' started
by user 'user_b' at 07:58:56 UTC Wed Mar 01 2006.
The install operation will continue asynchronously.
:router(admin)#Part 1 of 2 (add software): Started
Info: The following package is now available to be activated:
Info:
Info: disk0:asr9k-mpls-px.pie-6.0.1
Info:
Part 1 of 2 (add software): Completed successfully
Part 2 of 2 (activate software): Started
Info: The changes made to software configurations will not be persistent across
system reloads. Use the command 'admin install
Info: commit' to make changes persistent.
Info: Please verify that the system is consistent following the software change
using the following commands:
Info: show system verify
Info: install verify
Part 2 of 2 (activate software): Completed successfully
Part 1 of 2 (add software): Completed successfully
Part 2 of 2 (activate software): Completed successfully
Install operation 4 completed successfully at 08:00:24 UTC Wed Mar 01 2006.
```

### Related Topics

- [install activate](#), on page 907
- [show install log](#), on page 970
- [show install request](#), on page 981
- [install commit](#), on page 929

# install attach

To attach a terminal to an installation operation, use the **install attach** command in administration EXEC configuration mode.

```
install attach [request-id] [{asynchronous | synchronous}]
```

Syntax Description	
<i>request-id</i>	(Optional) Request ID assigned to an installation operation.
<b>asynchronous</b>	(Optional) Performs the command in asynchronous mode. In asynchronous mode, this command runs in the background, and the EXEC prompt is returned as soon as possible. This is the default mode.
<b>synchronous</b>	(Optional) Performs the command in synchronous mode. This mode allows the installation process to finish before the prompt is returned.

**Command Default** The command operates in synchronous mode.

**Command Modes** Administration EXEC

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.
	Release 4.0.0	This command was removed from EXEC mode.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **install attach** command to attach a terminal to an installation operation. This is similar to making the installation operation synchronous, and is used for the following reasons:

- To change an asynchronous installation operation to a synchronous installation operation.
- The installation operation is asynchronous but the terminal that ran the command has been lost (due to a switchover or terminal timeout).



**Note** An asynchronous operation runs in the background, and the EXEC prompt is returned as soon as possible. This is the default mode. A synchronous operation allows the installation process to finish before the prompt is returned.

Task ID	Task ID	Operations
	pkg-mgmt	read, write



The following example, a software package is activated in asynchronous mode. In asynchronous mode, the command runs in the background, and the CLI prompt is returned as soon as possible.

Use the **install attach** command to attach the terminal to an installation operation. This switches the operation to synchronous mode, which allows the installation process to finish before the prompt is returned.

In the following example, the **install activate** command is entered in asynchronous mode. The CLI prompt returns before the operation is complete.

```
RP/0/RSP0/CPU0:router# admin
RP/0/RSP0/CPU0:router(admin)# install activate
disk0:asr9k-mcast-3.7.6

Install operation 14 'install activate
disk0:RP/0/RSP0/CPU0:router-mcast-3.7.6'
started by user 'user_b' at 08:04:31 UTC Mon Nov 14 2005.
The install operation will continue asynchronously.

RP/0/RSP0/CPU0:router(admin)#
Info: SDR Owner: Checking running configuration version compatibility with
Info: newly activated software ...
Info: SDR Owner: No incompatibilities found between the activated software
Info: and router running configuration.
```

In the following example, the **install attach** command is used to attach the terminal to the installation operation and complete the operation in synchronous mode. The CLI prompt is returned only after the installation operation is complete.

```
RP/0/RSP0/CPU0:router(admin)# install attach

Install operation 14 'install activate
disk0:asr9k-mcast-3.7.6'
started by user 'user_b' at 08:04:31 UTC Mon Nov 14 2005.
Info: SDR Owner: Checking running configuration version compatibility with
Info: newly activated software ...
Info: SDR Owner: No incompatibilities found between the activated software
Info: and router running configuration.
Info: The changes made to software configurations will not be persistent
Info: across system reloads. Use the command 'admin install commit' to make
Info: changes persistent.
Info: Please verify that the system is consistent following the software
Info: change using the following commands:
Info: show system verify
Info: install verify
```

The currently active software is not committed. If the system reboots then the committed software will be used. Use 'install commit' to commit the active software.

Install operation 14 completed successfully at 08:06:12 UTC Mon Nov 14 2005.

### Related Topics

[install activate](#), on page 907

[install add](#), on page 918

[install deactivate](#), on page 931

# install auto-abort-timer stop

To deactivate the auto-abort-timer that is set in the **install activate** or **install deactivate** commands, use the **install auto-abort-timer stop** command in administration EXEC mode.

**install auto-abort-timer stop**

## Syntax Description

This command has no keywords or arguments.

## Command Default

When activated, the auto-abort-timer runs to expiration and then loads the last committed loadpath.

## Command Modes

Administration EXEC

## Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	No modification.
Release 4.0.0	This command was removed from EXEC mode.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **install auto-abort-timer stop** command to halt the auto-abort-timer that was activated with the **install activate** or **install deactivate** command. Alternatively, you can use the **install commit** command to halt the timer.

If you do not halt the auto-abort-timer, the software loads to the last committed loadpath when the timer expires. If the software has installed successfully, and you intend to continue using the new software, you should disable the auto-abort-timer.

## Task ID

### Task ID Operations

pkg-mgmt read,  
write

The following example shows how to halt the auto-abort-timer:

```
RP/0/RSP0/CPU0:router# admin
RP/0/RSP0/CPU0:router(admin)# install auto-abort-timer stop
```

## Related Topics

- [install activate](#), on page 907
- [install deactivate](#), on page 931
- [install commit](#), on page 929

# install boot-options

To set boot options for a specified node, use the **install boot-options** command. Boot options include formatting and cleaning the disk in the specified node during the boot process.

**install boot-options** {**clean** | **format**} **location** *node-id*

Syntax Description	clean	Cleans the card installed in the specified node during the next reboot.
	<b>format</b>	Formats the card installed in the specified node during the next reboot.
	<b>location</b> <i>node-id</i>	Specifies a node. The <i>node-id</i> argument is expressed in <i>rack/slot/module</i> notation.

**Command Default** None

**Command Modes** Administration EXEC

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **install boot-options** command to clean or format a card during the next reboot. This command affects only the next reboot that a user initiates. To initiate a reboot during which the boot option you set are applied, reboot the card from a disk in another node. You can use the **hw-module location reload** command with the *path* argument to download a boot image using TFTP from a remote node. When the reboot is complete, the boot options are reset.

Task ID	Task ID	Operations
	pkg-mgmt	read, write

The following example shows how to set the card located in node 0/0/CPU0 to be cleaned during the next reboot:

```
RP/0/RSP0/CPU0:router(admin)# install boot-options clean location 0/0/CPU0

Install operation 7 '(admin) install boot-options clean location 0/
RSP0/CPU0'
started by user '' via CLI at 09:15:46 GMT Mon Mar 10 2008.
Info: The boot option will be in effect when the node is reloaded and will
Info: be cleared when the node preparation is complete.
Install operation 7 completed successfully at 09:15:46 GMT Mon Mar 10 2008.
RP/0/RSP0/CPU0:router(admin)#
```

The following example shows how to set the card located in node 0/0/CPU0 to be formatted during the next reboot:

```
RP/0/RSP0/CPU0:router(admin)# install boot-options format location 0/0/CPU0

Install operation 8 '(admin) install boot-options format location 0/
RSP0/CPU0'
started by user '' via CLI at 09:15:52 GMT Mon Mar 10 2008.
Info: The boot option will be in effect when the node is reloaded and will
Info: be cleared when the node preparation is complete.
Install operation 8 completed successfully at 09:15:52 GMT Mon Mar 10 2008.
RP/0/RSP0/CPU0:router(admin)#
```

# install commit

To save the active software set to be persistent across designated system controller (DSC) reloads, use the **install commit** command in Admin EXEC mode EXEC mode.

```
install commit [{location node-id}]
```

<b>Syntax Description</b>	<b>location</b> <i>node-id</i> (Optional. Admin EXEC mode mode only.) Specifies a node. The <i>node-id</i> argument is expressed in <i>rack/slot/module</i> notation.	
<b>Command Default</b>	Admin EXEC mode: Commits the active software set for all SDRs.	
<b>Command Modes</b>	Admin EXEC mode EXEC mode	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.
	Release 4.0.0	This command was removed from EXEC mode. Support for the <b>sdr</b> keyword was removed.
<b>Usage Guidelines</b>	<p>When a package is activated, it becomes part of the current running configuration. To make the package activation persistent across designated secure domain router shelf controller (DSDRSC) reloads, enter the <b>install commit</b> command. On startup, the DSDRSC of the SDR loads this committed software set.</p> <p>If the system is restarted before the active software set is saved with the <b>install commit</b> command, the previously committed software set is used.</p>	
<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	pkg-mgmt	read, write

The following example shows how to make the current active software set persistent across DSDRSC reloads for all SDRs in the system:

```
RP/0/RSP0/CPU0:router# admin
RP/0/RSP0/CPU0:router(admin)# install commit
```

```
Install operation 16 'install commit' started by user 'user_b' at 19:18:58 UTC
Sat Apr 08 2006.
Install operation 16 completed successfully at 19:19:01 UTC Sat Apr 08 2006.
```

**Related Topics**

[show install log](#), on page 970

# install deactivate

To remove a package from the active software set, use the **install deactivate** command in Admin EXEC mode.

```
install deactivate {id add-id | device:package } [auto-abort-timer time] [location node-id]
[asynchronous | synchronous] [parallel-reload] [prompt-level {default | none}] [test] [pause
sw-change][superceded]
```

Syntax	Description
<b>id</b> <i>add-id</i>	Specifies the ID number of an <b>install add</b> operation. The command deactivates all packages that were added in the specified <b>install add</b> operation. The ID number of an <b>install add</b> operation is indicated in the syslog displayed during the operation and in the output of the <b>show install log</b> command.  Up to 16 <b>install add</b> operations can be specified.
<i>device</i> : <i>package</i>	Device and package, expressed in concatenated form (for example, disk0:asr9k-mgbl-3.8.0). For the <i>device</i> argument, the value is a specified storage device, typically <b>disk0</b> .  Press ? after a partial package name to display all possible matches available for activation. If there is only one match, press [TAB] to fill in the rest of the package name.  Up to 32 <i>device</i> : <i>package</i> pairs can be specified.
<b>auto-abort-timer</b> <i>time</i>	(Optional) Specifies an abort timer value, <i>time</i> , in minutes, which when expired loads the last committed loadpath.
<b>location</b> <i>node-id</i>	(Optional) Deactivates a package from the designated node. The <i>node-id</i> argument is entered in <i>rack/slot/module</i> notation.  <b>Note</b> In most cases, a package cannot be deactivated from a node, because some version of that package must be running on all supported nodes after the deactivation operation finishes.
<b>asynchronous</b>	(Optional) Performs the command in asynchronous mode. In asynchronous mode, this command runs in the background, and the EXEC prompt is returned as soon as possible. This is the default mode.
<b>synchronous</b>	(Optional) Performs the command in synchronous mode. This mode allows the installation process to finish before the prompt is returned.
<b>parallel-reload</b>	(Optional) Forces all cards on the router to reload at the same time and then come up with the new software, rather than proceeding according to the option encoded in the install package.
<b>prompt-level</b> { <b>default</b>   <b>none</b> }	(Optional) Specifies when you are prompted for input during the procedure. <ul style="list-style-type: none"> <li><b>default</b>—You are prompted only when input is required by the operation.</li> <li><b>none</b>—You are never prompted.</li> </ul>

<b>test</b>	(Optional) Verifies the effects of proposed operations without making changes to the Cisco IOS XR software.
<b>pause sw-change</b>	(Optional) Pauses the operation after the preparatory stage and before locking the configuration for the actual deactivation. While the operation is paused, you can perform configuration changes. You control the resumption of the operation at the CLI prompt.
<b>superseded</b>	Deactivates the superseded packages.

**Command Default**

The **install deactivate** operation is performed in asynchronous mode: The command runs in the background, and the router prompt is returned as soon as possible.

**Command Modes**

Admin EXEC mode

**Command History**

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	No modification.
Release 4.0.0	This command was removed from EXEC mode. Support was removed for the <b>sdr</b> keyword.

**Usage Guidelines**

Deactivating a package removes the activated package from the active software set from all nodes or from a single node. When a deactivation is attempted, the system runs an automatic check to ensure that the package is not required by other active packages. The deactivation is permitted only after all compatibility checks have passed.

The following conditions apply to software deactivation:

- A feature package cannot be deactivated if active packages need it to operate.
- To downgrade a package, activate the earlier version. The later package version is deactivated automatically.

**Specifying Packages to Deactivate**

You can either use the **id add-id** keyword and argument to deactivate all packages that were added in one or more specific **install add** operations, or specify packages by name. The operation ID of an **install add** operation is indicated in the syslog displayed during the operation and in the output of the **show install log** command. If you specify packages according to operation ID, all the packages that were added by the specified operation must still be on the router.

**Router Reloads**

If the deactivation requires a router reload, a confirmation prompt appears. Use the **install deactivate** command with the **prompt-level none** keywords to automatically ignore any reload confirmation prompts and proceed with the package deactivation. The router reloads if required.



### Node Reloads

If a software operation requires a node reload, the config-register for that node should be set to autoboot. If the config-register for the node is not set to autoboot, then the system automatically changes the setting and the node reloads. A message describing the change is displayed.

### Synchronous Operation

Use the **install deactivate** command with the **synchronous** keyword to complete the operation before the prompt is returned. A progress bar indicates the status of the operation. For example:

```
- 1% complete: The operation can still be aborted (ctrl-c for options)
\ 10% complete: The operation can still be aborted (ctrl-c for options)
```

### Test Option

Use the **test** keyword to verify the effects of the deactivation without making changes to the system. Use this option to determine if the deactivation can be completed. After previewing the effects of the proposed operations, use the [show install log, on page 970](#) command for more details about the effects of the proposed operations.

### Auto Abort Option

Use the **auto-abort-timer** keyword to provide a safety mechanism for the instance that a package is deactivated and for some reason access to the router is lost. This option automatically rolls back to the current committed loadpath, thereby undoing any changes that are deactivated with the **install deactivate** command. After the installation, if the activated software is working correctly, use the **install commit** command to cancel the timer and commit the new loadpath.

Use the **install commit** command to make changes persistent across route processor (RP) reloads.

### Pausing Before Configuration Lock

Use the **pause sw-change** keywords to pause the operation before locking the configuration. The deactivation operation begins with preparatory steps, such as software checks, and then proceeds with the actual deactivation. The configuration is locked for the actual deactivation. If you specify the **pause sw-change** keywords, the operation pauses before locking the configuration and provides you with the option to hold the operation while you perform configuration changes, and proceed with the deactivation whenever you choose. This is useful, for example, if your workflow involves configuring a router out of the network during software changes and you want to minimize the time that the router is out of the network. You can specify these keywords for both asynchronous and synchronous operations. In both cases, follow the onscreen instructions to control the pausing and completion of the operation.

### Superseded SMUs

When you install a reload SMU which supersedes the existing SMU the router reboots and SMU is placed in the superseded list automatically. If the superseded reload SMU is deactivated and fully supersedes the existing SMU, then router will not reboot when you run the **install deactivate superseded** command

Task ID	Task ID	Operations
	pkg-mgmt	execute

To deactivate all the fully superceded SMUs, use the `install deactivate superceded` command in the admin mode.

```
RP/0/RSP0/CPU0:router router(admin) # install deactivate superceded
```

The following example shows how to display the packages available for deactivation using the online help system. In this example, `?` is entered after a partial package name to display all possible matches.

```
RP/0/RSP0/CPU0:router# admin
RP/0/RSP0/CPU0:router(admin)# install deactivate disk0:?

disk0:comp-asr9k-mini-3.8.0 disk0:asr9k-admin-3.8.0 disk0:asr9k-base-3.8.0
 disk0:asr9k-diags-3.8.0
disk0:asr9k-fwdg-3.8.0 disk0:asr9k-k9sec-3.8.0 disk0:asr9k-lc-3.8.0
 disk0:asr9k-mcast-3.8.0
disk0:asr9k-mgbl-3.8.0 disk0:asr9k-mpls-3.8.0 disk0:asr9k-os-mbi-3.8.0.1
I disk0:asr9k-rout-3.8.0
```

The following example shows how to deactivate a package on all supported nodes. The operation is performed in synchronous mode.

```
RP/0/RSP0/CPU0:router(admin)# install deactivate
disk0:asr9k-mpls-3.8.0 synchronous

Install operation 14 'install deactivate disk0:asr9k-mpls-3.8.0 synchronous'
started by user 'user_b' at 18:38:37 UTC Sat Apr 08 2006.
Info: The changes made to software configurations will not be persistent
Info: across system reloads. Use the command 'admin install commit' to make
Info: changes persistent.
Info: Please verify that the system is consistent following the software
Info: change using the following commands:
Info: show system verify
Info: install verify
Install operation 14 completed successfully at 18:39:20 UTC Sat Apr 08 2006.
```

You cannot deactivate a package if other packages or nodes require that package. In the following example, an attempt to deactivate a package is rejected:

```
RP/0/RP0/CPU0:router(admin)# install deactivate disk0:asr9k-diags-3.7.90 location 0/6/cpu0

Install operation 25 'install deactivate disk0:asr9k-diags-3.7.90 on node
0/6/CPU0' started by user 'user_b' at 23:01:38 UTC Sat Apr 15 2009.
Error: Cannot proceed with the deactivation because of the following package
Error: incompatibilities:
Error: asr9k-diags-3.7.90 on nodes of type RP needs asr9k-diags-3.7.90, or
Error: equivalent, to be active on node 0/6/CPU0 on secure domain router
Error: Owner.
Error: asr9k-diags-3.7.90 on nodes of type SP needs asr9k-diags-3.7.90, or
Error: equivalent, to be active on node 0/6/CPU0 on secure domain router
Error: Owner.
Error: asr9k-diags-3.7.90 on nodes of type LC needs asr9k-diags-3.7.90, or
Error: equivalent, to be active on node 0/6/CPU0 on secure domain router
Error: Owner.
Error: Suggested steps to resolve this:
Error: - check the installation instructions.
Error: - activate or deactivate the specified packages on the specified
Error: nodes.
```

Install operation 25 failed at 23:01:44 UTC Sat Apr 15 2009.

The following example shows how to deactivate a package, pausing the operation before locking the configuration for the actual software deactivation. While the operation is paused, you can enter a configuration mode and perform configurations. When you want to complete the operation, you enter the **install operation *id* complete** command or the **install operation *id* attach synchronous** command.

```
RP/0/RSP0/CPU0:router(admin)# install deactivate
disk0:comp-asr9k-3.8.0.07I.CSCsr09575-1.0.0
pause sw-change
```

```
Install operation 12 '(admin) install deactivate disk0:comp-asr9k-3.8.0.07I.CSCsr09575-1.0.0
```

```
 pause sw-change' started by user 'admin' via CLI at 09:06:26 BST Mon Jul 07 2008.
Info: This operation will reload the following nodes in parallel:
Info: 0/0/CPU0 (RP) (SDR: Owner)
Info: 0/1/CPU0 (LC(E3-GE-4)) (SDR: Owner)
Info: 0/5/CPU0 (LC(E3-OC3-POS-4)) (SDR: Owner)
Proceed with this install operation (y/n)? [y]
The install operation will continue asynchronously.
RP/0/RSP0/CPU0:ensoft-gsr13(admin)#
Info: Install Method: Parallel Reload
Info: Install operation 12 is pausing before the config lock is applied
 for the software change as requested by the user.
Info: No further install operations will be allowed until the operation
 is resumed.
Info: Please continue the operation using one of the following steps:
Info: - run the command '(admin) install operation 12 complete'.
Info: - run the command '(admin) install operation 12 attach synchronous'
 and then answer the query.
```

In the following example, the operation is synchronous and the **pause sw-change** keywords are used to pause the operation before configuration lock. In this case, you are prompted to enter one of three options at the pause stage: **abort/complete/cli**. If you enter **abort**, the operation is aborted. If you enter **complete**, the operation is immediately resumed. If you enter **cli**, the CLI prompt returns, enabling you to perform configurations before resuming the operation. Alternatively, you can leave the prompt open while you open a separate CLI session to perform configurations. Then, you can return to the prompt and enter **complete** when you are ready to resume the operation.

```
RP/0/RSP0/CPU0:router# install deactivate
disk0:asr9k-mpls-3.8.0.10I
sync pause sw-change
Wed Jul 23 14:42:11.273 UTC
Install operation 8 'install deactivate disk0:asr9k-mpls-3.8.0.10I
 synchronous pause sw-change' started by user 'salevy' on SDR
Owner via CLI at 14:42:12 UTC Wed Jul 23 2008.
Info: Install Method: Parallel Process Restart
The install operation has paused before the configuration is locked as
 requested by user 'salevy'.
Please perform any changes to the configuration that are required before
 the operation is to continue.
How should the operation continue?
Abort the operation (abort)
Lock the config and complete the operation (complete)
Suspend the operation and return to the Command Line Interface (cli)
Please confirm an option (abort/complete/cli): [complete] cli
Use the command 'install operation 8 ?' to find how to continue the operation.

RP/0/RSP0/CPU0:router# install operation 8 ?
```

```
abort Abort the operation
attach Attach to the operation
complete Phase to run to end of
```

```
RP/0/RSP0/CPU0:router# install operation 8 complete
```

```
Wed Jul 23 14:43:04.562 UTC
RP/0/RSP0/CPU0:router# Info: Install operation 8 has been resumed.
Info: The changes made to software configurations will not be persistent
 across system reloads. Use the command '(admin)
Info: install commit' to make changes persistent.
Info: Please verify that the system is consistent following the
 software change using the following commands:
Info: show system verify
Info: install verify packages
Install operation 8 completed successfully at 14:43:53 UTC Wed Jul 23 2008.
```

### Related Topics

- [install activate](#), on page 907
- [install remove](#), on page 942
- [show install inactive](#), on page 964
- [show install log](#), on page 970
- [show install request](#), on page 981
- [install activate \(IOS XR 64 bit\)](#), on page 915
- [install deactivate \(IOS XR 64 bit\)](#), on page 937
- [install commit](#), on page 929

# install deactivate (IOS XR 64 bit)

To remove a package from the active software set, use the **install deactivate** command in EXEC mode or Admin EXEC mode.

```
install deactivate package_name
install deactivate id operation_id
```

## Syntax Description

*package_name*

Enter the package names separated by space.

**Note** Up to 16 packages can be specified in a single **install deactivate** command at a time. Multiple packages can be specified using the wildcard syntax, for example, `asr9k-*-x64-*3I`.

*id operation_id*

The *operation_id* is the ID from the **install add** operation.

The **show install request** command displays the operation id number of the **install add** operation and its status. You can also find the *operation_id* in the **show install log** command output.

## Command Default

The **install deactivate** command deactivates all features and software patches associated with the specified activated packages. This operation is performed in an asynchronous mode and the command runs in the background.

If you use the operation ID (from the add operation) to deactivate packages, all packages that were added in the specified **install add** operation are deactivated together. You do not have to deactivate the packages individually.

For example, if five packages are added in operation 6, all the five packages are deactivated together by executing **install deactivate id 6** command.



**Note** The System admin packages that were added as a part of the **install add** operation (of the ID used in deactivate operation) will also be deactivated.

## Command Modes

EXEC mode  
Admin EXEC mode

## Command History

Release	Modification
Release 6.1.2	Support for IOS XR 64 bit <b>install deactivate</b> command was added.

## Usage Guidelines

- Only active packages can be deactivated. Use the **show install active** command to identify the active packages.

- If you want to deactivate packages using the **install deactivate id** *operation_id* command syntax, use the **show install log** command to identify the operation ID of the add operation.
- If you want to remove the inactive packages from the repository, use the **show install inactive** command to identify the deactivated packages that are now listed as inactive packages.

Then, use the **install remove** command to remove the packages from the repository.

The following example lets you deactivate packages by specifying the package names:

```
RP/0/RSP0/CPU0:router# install deactivate asr9k-m2m-x64-2.0.0.0-r61106I.x86_64
asr9k-optic-x64-1.0.0.0-r61106I.x86_64

Jun 22 14:09:25 Package list:
Jun 22 14:09:25 asr9k-m2m-x64-2.0.0.0-r61106I.x86_64
Jun 22 14:09:25 asr9k-optic-x64-1.0.0.0-r61106I.x86_64
Jun 22 14:09:35 Install operation will continue in the background

RP/0/RSP0/CPU0:router#
```

The following example lets you deactivate packages by specifying the id from the add operation:

```
RP/0/RSP0/CPU0:router# install deactivate id 6

Jun 22 15:02:24 Package list:
Jun 22 15:02:24 asr9k-bgp-x64-1.0.0.0-r61106I.x86_64
Jun 22 15:02:24 asr9k-isis-x64-1.0.0.0-r61106I.x86_64
Jun 22 15:02:24 asr9k-k9sec-x64-1.1.0.0-r61106I.x86_64
Jun 22 15:02:24 asr9k-li-x64-1.1.0.0-r61106I.x86_64
Jun 22 15:02:33 Install operation will continue in the background

RP/0/RSP0/CPU0:router#
```

The following example lets you deactivate multiple packages using the wildcard syntax:

```
RP/0/RSP0/CPU0:router# install deactivate *-r61103I

Jun 16 19:35:06 Install operation 108 started by root:
install deactivate pkg asr9k-mpls-x64-1.1.0.0-r61103I asr9k-mpls-te-rsvp-x64-1.0.0.0-r61103I
asr9k-mcast-x64-1.1.0.0-r61103I
Jun 16 19:35:06 Package list:
Jun 16 19:35:06 asr9k-mpls-x64-1.1.0.0-r61103I
Jun 16 19:35:06 asr9k-mpls-te-rsvp-x64-1.0.0.0-r61103I
Jun 16 19:35:06 asr9k-mcast-x64-1.1.0.0-r61103I
Jun 16 19:35:06 Install operation will continue in the background

RP/0/RSP0/CPU0:router#
```

# install label

To add a label or description to a state associated with a rollback point, use the **install label** command in administration EXEC mode.

```
install label point-id {description description | label-name label}
```

Syntax Description		
	<i>point-id</i>	Installation point ID number.
	<b>description</b> <i>description</i>	Specifies a description for the specified rollback point.
	<b>label-name</b> <i>label</i>	Specifies a label for the specified rollback point.

**Command Default** No default behavior or values

**Command Modes** Administration EXEC

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.
	Release 4.0.0	This command was removed from EXEC mode.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **install label** command to put a label and description on an installation rollback point that can be used to identify the rollback point in other commands. Commands that support the rollback label include:

- **clear install rollback**
- **install rollback**
- **show install rollback**

The label can be a maximum of 15 characters which must adhere to the following rules:

- No white-space
- Cannot include any of the following CLI keywords:
  - **active**
  - **all**
  - **asynchronous**
  - **brief**
  - **committed**
  - **description**

- **detail**
  - **differences**
  - **from**
  - **force**
  - **inactive**
  - **install**
  - **label**
  - **label-name**
  - **location**
  - **noprompt**
  - **rollback**
  - **sdr**
  - **summary**
  - **synchronous**
  - **test**
  - **to**
  - **verbose**
- Cannot contain any of the following characters:
    - Comma (,)
    - Semi-colon (;)
    - Colon (:)
    - Single-quote (')
    - Double-quote ("")
  - Cannot contain uppercase alphabetic characters
  - Cannot contain numeric characters only

Task ID	Task ID	Operations
	pkg-mgmt	read, write

The following example shows how to define a label for an installation operation:

```
RP/0/RSP0/CPU0:router# admin
RP/0/RSP0/CPU0:router(admin)# install label 0 label-name brians-smu
```



```
Install operation 5 'install label 0 label-name brians_smu' started by user
'user' on SDR Owner via CLI at 09:26:43 DST Thu Aug 09 2007.
Install operation 5 completed successfully at 09:26:44 DST Thu Aug 09 2007.
```

### Related Topics

[install activate](#), on page 907

# install remove

To delete inactive packages from a storage device, use the **install remove** command in EXEC mode.

```
install remove {id add-id | device:package | inactive} [prompt-level {default | none}] [{asynchronous | synchronous}] [test]
```

## Syntax Description

<b>id</b> <i>add-id</i>	Specifies the ID number of an <b>install add</b> operation. The command deletes all packages that were added in the specified <b>install add</b> operation. The ID number of an <b>install add</b> operation is indicated in the syslog displayed during the operation and in the output of the <b>show install log</b> command.  Up to 16 <b>install add</b> operations can be specified
<i>device : package</i>	Device and package, expressed in concatenated form (for example, disk0:asr9k-mgbl-3.8.0). For the <i>device</i> argument, the value is a specified storage device, typically <b>disk0</b> .  <b>Note</b> Multiple packages can be removed at the same time. Up to 32 <i>device : package</i> pairs can be specified.
<b>inactive</b>	Removes all inactive, noncommitted packages from the boot device (usually disk0:).
<b>prompt-level</b> { <b>default</b>   <b>none</b> }	(Optional) Specifies when you are prompted for input during the procedure. <ul style="list-style-type: none"> <li><b>default</b> —You are prompted only when input is required by the operation.</li> <li><b>none</b> —You are never prompted.</li> </ul>
<b>asynchronous</b>	(Optional) Performs the command in asynchronous mode. In asynchronous mode, this command runs in the background, and the EXEC prompt is returned as soon as possible. This is the default mode.
<b>synchronous</b>	(Optional) Performs the command in synchronous mode. This mode allows the installation process to finish before the prompt is returned.
<b>test</b>	(Optional) Verifies the effects of proposed operations without making changes to the Cisco IOS XR software.

## Command Default

The operation is performed in asynchronous mode: The **install remove** command runs in the background, and the EXEC prompt is returned as soon as possible.

## Command Modes

### Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	No modification.
Release 4.0.0	This command was removed from EXEC mode. Support was removed for the <b>sdr</b> keyword.

## Usage Guidelines



**Note** Only inactive packages can be removed. (Packages cannot be in the active or committed software set.)

- To remove all inactive packages from the boot device (usually **disk0:**), use the **install remove** command with the **inactive** keyword.
- To remove a specific inactive package from a storage device, use the **install remove** command with the *device: package* arguments.



**Note** When removing all inactive packages from the boot device, use the **show version**, **show install active**, or **show install committed** command to determine the device used as the boot device.

- To remove all packages that were added in one or more specific **install add** operations, use the **id add-id** keyword and argument. The operation ID of an **install add** operation is indicated in the syslog displayed during the operation and in the output of the **show install log** command. If you specify packages according to operation ID, all the packages that were added by the specified operation must still be on the router.

### User Prompts

Use the **install remove** command with the **prompt-level none** keywords to automatically ignore any confirmation prompts and proceed with the package removal.

### Test Operation

Use the **test** keyword to verify the effects of the package removal operation and determine whether the operation can be completed. After previewing the effects of the proposed operations, use the [show install log, on page 970](#) command for more details about the effects of the proposed operations.



**Note** When removing a package, note that the **install remove** command ignores secure domain router (SDR) boundaries and performs the operation in global scope.

## Task ID

### Task ID Operations

pkg-mgmt execute

The following example shows how to remove a specific inactive package. In this example, the operation is run in test mode. The operation is then confirmed and the package is removed.

```
RP/0/RSP0/CPU0:router# admin
RP/0/RSP0/CPU0:router(admin)# install remove
disk0:asr9k-diags-3.7.90 test
```

```
Install operation 30 'install remove disk0:asr9k-diags-3.7.90 test' started by user 'user_b'
at 23:40:22 UTC Sat Apr 15 2006.
```

```
Warning: No changes will occur due to 'test' option being specified. The
```

```
Warning: following is the predicted output for this install command.
```

```
Info: This operation will remove the following package:
```

```
Info: disk0:asr9k-diags-3.7.90
Info: After this install remove the following install rollback points will
Info: no longer be reachable, as the required packages will not be present:
Info: 4, 9, 10, 14, 15, 17, 18
Proceed with removing these packages? [confirm] y
```

```
The install operation will continue asynchronously.
Install operation 30 completed successfully at 23.
```

The following example shows how to remove all inactive packages from the boot device:

```
RP/0/RSP0/CPU0:router# admin
RP/0/RSP0/CPU0:router(admin)# install remove inactive synchronous

RP/0/RSP0/CPU0:Aug 15 09:25:41.020 :
 instdir[198]: %INSTALL-INSTMGR-6-INSTALL_OPERATION_STARTED :
Install operation 8 '(admin) install remove inactive' started by user 'user_b'
Install operation 8 '(admin) install remove inactive' started by user 'user_b' at
 09:25:41 UTC Tue Aug 15 2006.
Info: This operation will remove the following package:
Info: disk0:asr9k-compmgmt__installmgr-0.0.5
Proceed with removing these packages? [confirm]
The install operation will continue asynchronously.
```

### Related Topics

- [install add](#), on page 918
- [show install log](#), on page 970
- [show install inactive](#), on page 964
- [show install request](#), on page 981

# install rollback to

To roll back the software set to a saved installation point or to the last committed installation point, use the **install rollback to** command in administration EXEC mode.

Administration EXEC Mode:

```
install rollback to {point-idlabel | committed} [auto-abort-timer time] location node-id
[{asynchronous | synchronous}] [parallel-reload] [prompt-level {default | none}] [test] [pause
sw-change]
```

Syntax Description	
<i>point-id</i>	Installation point ID number.
<i>label</i>	Label associated with an installation point.
<b>committed</b>	Rolls the Cisco IOS XR software back to the last committed installation point.
<b>auto-abort-timer</b> <i>time</i>	(Optional) Specifies an abort timer value, <i>time</i> , in minutes, which when expired loads the last committed loadpath.
<b>location</b> <i>node-id</i>	Specifies a node. The <i>node-id</i> argument is expressed in <i>rack/slot/module</i> notation.
<b>asynchronous</b>	(Optional) Performs the command in asynchronous mode. In asynchronous mode, this command runs in the background, and the EXEC prompt is returned as soon as possible. This is the default mode.
<b>synchronous</b>	(Optional) Performs the command in synchronous mode. This mode allows the installation process to finish before the prompt is returned.
<b>parallel-reload</b>	(Optional) Forces all cards on the router to reload at the same time and then come up with the new software, rather than proceeding according to the option encoded in the install package.
<b>prompt-level</b> { <b>default</b>   <b>none</b> }	(Optional) Specifies when you are prompted for input during the procedure. <ul style="list-style-type: none"> <li>• <b>default</b> —You are prompted only when input is required by the operation.</li> <li>• <b>none</b> —You are never prompted.</li> </ul>
<b>test</b>	(Optional) Verifies the effects of proposed operations without making changes to the Cisco IOS XR software.
<b>pause sw-change</b>	(Optional) Pauses the operation after the preparatory stage and before locking the configuration for the actual software change. While the operation is paused, you can perform configuration changes. You control the resumption of the operation at the CLI prompt.

**Command Default** The operation is performed in asynchronous mode. The **install rollback to** command runs in the background, and the EXEC prompt is returned as soon as possible.

**Command Modes** Administration EXEC

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.
	Release 4.0.0	This command was removed from EXEC mode. Support was removed for the <b>sdr</b> keyword.

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **install rollback to** command to roll back the configuration to a saved installation point or to the last committed installation point. Rollback points are created when the router is booted and when packages are activated, deactivated, or committed. When an installation point is created, Cisco IOS XR software assigns an ID number to that rollback point. To roll back to a saved installation point, enter the installation point ID number assigned to it for the *point-id* argument. When a software configuration is committed with the **install commit** command, that configuration is also saved as the last committed installation point. Use the **committed** keyword to roll back to the last committed installation point.

Labels can be assigned to installation points using the **install label** command. Then these labels can be used to identify a specific installation point that you want to roll back to.

To display the saved rollback points available, use the online help function:

```
RP/0/RSP0/CPU0:router(admin)# install rollback to ?
0 Specify the id for the install point to rollback to
1 Specify the id for the install point to rollback to
12 Specify the id for the install point to rollback to
15 Specify the id for the install point to rollback to
2 Specify the id for the install point to rollback to
4 Specify the id for the install point to rollback to
6 Specify the id for the install point to rollback to
7 Specify the id for the install point to rollback to
8 Specify the id for the install point to rollback to
9 Specify the id for the install point to rollback to
committed Rollback to the last committed installation point
```

If a rollback operation is beyond two saved installation points, a router reload is required to avoid system instability. If a reload is required, a confirmation prompt appears before the reload occurs. Use the **install rollback to** command with the **prompt-level none** keywords to automatically ignore any reload confirmation prompts and proceed with the rollback operation.

If a software operation requires a node reload, the config-register for that node should be set to autoboot. If the config-register for the node is not set to autoboot, then the system automatically changes the setting and the node reloads. A message describing the change is displayed.

If a rollback operation requires that a package be activated that is no longer on the system (because the package had been removed), a message appears in the output of the **install rollback to** command indicating that the specified installation point is unavailable and that the required package must be added to roll back the software set to the specified installation point.

Use the **test** keyword to verify the effects of the proposed operations and determine whether the rollback operation can be completed. After previewing the effects of the proposed operations, use the **show install log** command for more details about the effects of the proposed operations.

Use the **clear install rollback oldest** command to delete saved installation points from the installation buffer.

Use the **show install rollback** command to display the software set associated with a saved installation point.

### Pausing Before Configuration Lock

Use the **pause sw-change** keywords to pause the operation before locking the configuration. A rollback operation begins with preparatory steps, such as software checks, and then proceeds with the actual software change. The configuration is locked for the actual software change. If you specify the **pause sw-change** keywords, the operation pauses before locking the configuration and provides you with the option to hold the operation while you perform configuration changes, and proceed with the software change whenever you choose. This is useful, for example, if your workflow involves configuring a router out of the network during software change and you want to minimize the time that the router is out of the network. You can specify these keywords for both asynchronous and synchronous operations. In both cases, follow the onscreen instructions to control the pausing and completion of the operation.

#### Task ID

Task ID	Operations
pkg-mgmt	read, write

The following example shows how to roll back to a saved installation point:

```
RP/0/RSP0/CPU0:router# admin
RP/0/RSP0/CPU0:router(admin)# install rollback to 8

Install operation 10 'install rollback to 8' started by user
 'user_b' at 07:49:26
UTC Mon Nov 14 2005.
The install operation will continue asynchronously.
RP/0/RSP0/CPU0:router(admin)#Info:
The changes made to software configurations will not be persistent
Info: across system reloads. Use the command
 'admin install commit' to make
Info: changes persistent.
Info: Please verify that the system is consistent following
 the software
Info: change using the following commands:
Info: show system verify
Info: install verify

The currently active software is the same as the committed
 software.

Install operation 10 completed successfully at 07:51:24 UTC Mon
 Nov 14 2005.
```

In the following example, the software is rolled back to the last committed installation point and the rollback is paused before configuration lock and then completed when the user enters the **install operation complete** command:

```
RP/0/RSP0/CPU0:router# install rollback to committed pause sw-change
```

```
Wed Jul 23 15:37:53.377 UTC
Install operation 16 'install rollback to committed pause sw-change'
 started by user 'userb' on SDR Owner via CLI at 15:37:54 UTC
Wed Jul 23 2008.
The install operation will continue asynchronously.
RP/0/RSP0/CPU0:router#Info: Install Method: Parallel Process Restart
Info: Install operation 16 is pausing before the config lock is
 applied for the software change as requested by the user.
Info: No further install operations will be allowed until the
 operation is resumed.
Info: Please continue the operation using one of the following
 steps:
Info: - run the command 'install operation 16 complete'.
Info: - run the command 'install operation 16 attach synchronous'
 and then answer the query.
RP/0/RSP0/CPU0:router# install operation 16 complete

Wed Jul 23 15:38:35.197 UTC
RP/0/RSP0/CPU0:router#Info: Install operation 16 has been resumed.
Info: The changes made to software configurations will not be persistent
 across system reloads. Use the command '(admin)
 install commit' to make changes persistent.
Info: Please verify that the system is consistent following the
 software change using the following commands:
Info: show system verify
Info: install verify packages
Install operation 16 completed successfully at 15:39:18 UTC Wed
 Jul 23 2008.

RP/0/RSP0/CPU0:router#
```

### Related Topics

- [show install log](#), on page 970
- [show install request](#), on page 981
- [clear install rollback oldest](#), on page 903
- [install commit](#), on page 929
- [install label](#), on page 939
- [show install rollback](#), on page 983



# install upgrade source

To upgrade the software package, use the **install upgrade source** command in administration EXEC mode.

```
install upgrade source [{ftp | tftp} system-disk] [path directory-path] [{file-name | version
version-number | packages}] [source-file] [synchronous] [pause-reload]
```

Syntax	Description
<b>source</b>	Specify the source location of the PIE files to be appended to the PIE filenames. Location options are as follows:  <b>ftp:</b> —Copies from an FTP network server. The syntax is <b>ftp: [[[/username [:password]@] location]/directory]/filename</b> . <b>tftp:</b> —Copies from a TFTP network server. The syntax is <b>tftp: [[[/location]/directory]/filename</b> <i>system disk</i> —Copies package source from system disk. Location options are as follows: <ul style="list-style-type: none"> <li>• <b>harddisk:</b> —Copies from the hard disk drive file system (if present).</li> <li>• <b>disk1:</b> —Copies from disk1: file system.</li> </ul>
<b>path</b> <i>directory-path</i>	Specify the storage device and directory for the file search. The search is performed for the specified directory and all subdirectories in that directory tree.  The syntax for <i>directory-path</i> is: <i>device</i> :[/ <i>directory-path</i> ]  If a directory path is not specified, then the search is performed in the current directory (a path of . [dot] is assumed).
<i>file-name</i>	Only for TFTP, with file that contains a list of packages to be installed  <b>Note</b> Directory listing is not possible
<b>version</b> <i>version-number</i>	Specify the package version that is to be installed
<b>packages</b>	Specify the package names to install (packages can be <i>tar</i> file)
<i>source-file</i>	Specify the source location of the PIE files on the system
<b>synchronous</b>	(Optional) Performs the command in synchronous mode. This mode allows the installation process to be completed before the prompt is returned.  <b>Note</b> By default, installation operations are performed in asynchronous mode. In asynchronous mode, the command will run without expecting any user inputs while holding the prompt.

**pause-reload**

(Optional) Pauses the operation before any reload occurs. The configuration remains locked for the activation. This keyword precedes the following two keywords:

- **pause-reload allow-sw-change**—The operation pauses before locking the configuration and provides the option to hold the operation while you perform configuration changes. You can proceed with the activation whenever you choose.
- **pause-reload disallow-sw-change**—The operation pauses before reload but this will not allow you to make any configuration changes.

**Note** These keywords are applicable for asynchronous and synchronous operations. In both cases, follow onscreen instructions to control the pausing and completion of the operation.

**Command Default**

By default **install upgrade source** picks active version packages.

**Command Modes**

Administration EXEC

**Command History**

Release	Modification
Release 5.3.2	This command was introduced.

**Usage Guidelines****FTP**

Use the following options to upgrade the system using FTP as source:

- Only repository without version—It picks delta packages (ignoring optional packages) of the active version; that is, the difference between packages present in the file specified and packages active on the system.
- Repository with version—It picks packages of the specified version. If a mini package of the specified version is found in the file, it will upgrade the system, provided all dependency and package compatibility checks are completed successfully.
- Packages—Specifies the list of packages to add or upgrade the system. This option can be used to add *tar* files.

**TFTP**

Use the following options to upgrade the system using TFTP as source:

- File-name—This option requires the package list to be provided in a file, which can then be used to upgrade the system or update the packages or SMU's. It picks delta packages (ignoring optional packages) of the active version; that is, the difference between packages present in the file specified and packages active on the system.
- File-name with version—It picks packages of the specified version. If a mini package of the specified version is found in the file, it will upgrade the system, provided all dependency and package compatibility checks are completed successfully.

- **Packages**—Specifies the list of packages to add or upgrade the system. This option can be used to add *tar* files.

### harddisk

Use the following options to upgrade the system using harddisk as source:

- **Only repository without version**—It picks delta packages (ignoring optional packages) of the active version; that is, the difference between packages present in the file specified and packages active on the system.
- **Repository with version**—It picks packages of the specified version. If a mini package of the specified version is found in the file, it will upgrade the system, provided all dependency and package compatibility checks are completed successfully.
- **Packages**—Specifies the list of packages to add or upgrade the system. This option can be used to add *tar* files.

Task ID	Task ID	Operation
	pkg-mgmt	execute

### Example

This example shows how to upgrade a package to 5.2.4 version with image `asr9k-mini-px.pie-5.2.4` from the FTP repository, using the **install upgrade source** command:

```
RP/0/RSP0/CPU0:router#admin
RP/0/RSP0/CPU0:router(admin)#install upgrade source ftp://10.10.10.10/yum_like_upgrade
asr9k-mini-px.pie-5.2.4 synchronous
```

This example shows how to upgrade a package to 5.3.2 version from the on-system repository, using the **install upgrade source** command:

```
RP/0/RSP0/CPU0:router#admin
RP/0/RSP0/CPU0:router(admin)#install upgrade source harddisk:/images/532 version 5.3.2
synchronous
```

This example shows how to upgrade package to release 5.1.0 from the TFTP repository, using the **install upgrade source** command:

```
RP/0/RSP0/CPU0:router#admin
RP/0/RSP0/CPU0:router(admin)# install upgrade source tftp://10.10.10.10/auto/tftpboot/userid
file-name packages.txt version 5.1.0 synchronous
```

This example shows how to add and activate the package or SMU of active version using the **install upgrade source** command:

```
RP/0/RSP0/CPU0:router#admin
RP/0/RSP0/CPU0:router(admin)# install upgrade source tftp://10.10.10.10/packages pkg1,pkg2
```

`pkg1` is an optional package and `pkg2` is a SMU. Both are active versions, but inactive on the system. The **install upgrade source** command checks whether the package or SMU is already inactive on system. If it is in inactive, the command skips its downloading, and adds as well as activates optional packages or SMUs along with its pre requisites.

# show install

To display active packages, use the **show install** command in EXEC or administration EXEC mode.

## Administration EXEC Mode

**show install** [{detail | summary | verbose}] [{sdr *sdr-name* | location *node-id*}

## EXEC Mode

**show install** [{detail | summary | verbose}] [location *node-id*]

Syntax Description	Option	Description
	<b>detail</b>	(Optional) Displays a detailed summary of the active packages for a system, secure domain router (SDR), or node.
	<b>summary</b>	(Optional) Displays a summary of the active packages in a system or SDR. Use this command to display the default software profile for SDRs
	<b>verbose</b>	(Optional) Displays a detailed summary of the active packages for a system, SDR, or node, including component and file information for each package.
	<b>sdr</b> <i>sdr-name</i>	(Optional. Administration EXEC mode only.) Displays the active packages for a specific SDR. The <i>sdr-name</i> argument is the name assigned to the SDR. The only SDR available is Owner, which refers to the entire router.
	<b>location</b> <i>node-id</i>	(Optional) Displays the active packages for a designated node. The <i>node-id</i> argument is expressed in <i>rack/slot/module</i> notation.

**Command Default** No default behavior or values

**Command Modes** EXEC  
Administration EXEC

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.



**Note** This command displays output that is similar to the **show install active** command.

Use the **show install** command to display the active software set for all nodes, or for specific nodes. Enter the command in administration EXEC mode to display information for all nodes in all SDRs.

### Displaying Information for a Specific SDR

- To display information for a specific SDR from administration EXEC mode, use the **sdr** *sdr-name* keyword and argument.
- To display information for an SDR when logged into that SDR, enter the command in EXEC mode.

### Displaying Information for a Specific Node

Use the **location** *node-id* keyword and argument to display information for a specific node. If you do not specify a location with the **location** *node-id* keyword and argument, this command displays information from all nodes.

### Summary, Detailed, and Verbose Information

Use the **summary** keyword to display a summary of the active packages in a system or SDR. Use the **detail** keyword to display the active packages for each node in an SDR, or in all SDRs. Use the **verbose** keyword to display additional information, including component and file information for each package.



**Note** This command displays output that is similar to the **show install active** command.

### Displaying the Default SDR Software Profile

When an SDR is created, the nodes assigned to that SDR are configured with the default software profile. To view a summary of the default SDR software configuration, enter the **show install summary** command in administration EXEC mode. Any new nodes that are configured to become a part of an SDR boot with the default software profile listed in the output of this command.

#### Task ID

#### Task ID Operations

pkg-mgmt read

Use the **location** *node-id* keyword and argument to display the active packages for a designated node:

```
RP/0/RSP0/CPU0:router# show install location 0/rp0/cpu0
Thu May 20 10:08:54.666 DST
Node 0/RP0/CPU0 [HRP] [SDR: Owner]
Boot Device: disk0:
Boot Image: /disk0/asr9k-os-mbi-3.9.0/mbi-rp.vm
Active Packages:
 disk0:asr9k-k9sec-p-3.9.0
 disk0:asr9k-mppls-p-3.9.0
 disk0:asr9k-mgbl-p-3.9.0
 disk0:asr9k-mcast-p-3.9.0
 disk0:asr9k-doc-p-3.9.0
 disk0:comp-asr9k-mini-3.9.0
 disk0:asr9k-fpd-3.9.0
 disk0:asr9k-diags-p-3.9.0
```

Use the **summary** keyword to display a summary of the active packages in the system. This command also shows the default software profile used for new SDRs.

```
RP/0/RSP0/CPU0:router# show install summary
```

```
Thu May 20 10:14:38.919 DST
Active Packages:
 disk0:asr9k-upgrade-p-3.9.0
 disk0:asr9k-k9sec-p-3.9.0
 disk0:asr9k-mpis-p-3.9.0
 disk0:asr9k-mgbl-p-3.9.0
 disk0:asr9k-mcast-p-3.9.0
 disk0:asr9k-doc-p-3.9.0
 disk0:comp-asr9k-mini-3.9.0
 disk0:asr9k-fpd-3.9.0
 disk0:asr9k-diags-p-3.9.0
```

**Table 75: show install Field Descriptions**

Field	Description
Boot Device	Device where the node stores the active software.
Boot Image	Location on the DSC of the active minimum boot image (MBI) used to boot the node.
Active Packages	Active packages loaded on the node.

### Related Topics

- [install activate](#), on page 907
- [show install active](#), on page 955
- [show install package](#), on page 975
- [show install pie-info](#), on page 978
- [show install which](#), on page 987

# show install active

To display active packages, use the **show install active** command in EXEC or administration EXEC mode.

## Administration EXEC Mode

```
show install active [{detail | summary | verbose}] [{location node-id}]
```

## EXEC Mode

```
show install active [{detail | summary | verbose}] [location node-id]
```

Syntax Description	detail	(Optional) Displays a detailed summary of the active packages for a system, secure domain router (SDR), or node.
	summary	(Optional) Displays a summary of the active packages in a system or SDR.
	verbose	(Optional) Displays a detailed summary of the active packages for a system, SDR, or node, including component information for each package.
	sdr sdr-name	(Optional. Administration EXEC mode only.) Displays the active packages for a specific SDR. The <i>sdr-name</i> argument is the name assigned to the SDR.
	location node-id	(Optional) Displays the active packages for a designated node. The <i>node-id</i> argument is expressed in <i>rack/slot/module</i> notation.

**Command Default** None

**Command Modes** Administration EXEC  
EXEC

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

## Usage Guidelines



**Note** This command displays output that is similar to the **show install** command.

Use the **show install active** command to display the active software set for all nodes, or for specific nodes.

### Displaying Information for a Specific Node

Use the **location node-id** keyword and argument to display information for a specific node. If you do not specify a location with the **location node-id** keyword and argument, this command displays information from all nodes.

### Summary, Detailed, and Verbose Information

Use the **summary** keyword to display a summary of the active packages in a system or SDR. Use the **detail** keyword to display the active packages for each node in an SDR, or in all SDRs. Use the **verbose** keyword to display additional information, including component and file information for each package.

### For Superseded SMUs

The **show install active** command does not display superseded SMUs. To get details of the superseded SMUs, use the **show install superseded** command.

Task ID	Task ID	Operations
	pkg-mgmt	read

The following example illustrates sample output from the **show install active** command with the **location node-id** keyword and argument specified:

```
RP/0/RSP0/CPU0:router# show install active location 0/1/cpu0

Node 0/1/CPU0 [LC] [SDR: Owner]
 Boot Device: bootflash:
 Boot Image: /disk0/asr9k-os-mpi-3.9.0.30I/mbiasr9k-lc.vm
 Active Packages:
 disk0:asr9k-adv-video-3.9.0.14I
 disk0:asr9k-fpd-3.9.0.30I
 disk0:asr9k-diags-3.9.0.30I
 disk0:asr9k-k9sec-3.9.0.30I
 disk0:asr9k-mcast-3.9.0.30I
 disk0:asr9k-mpis-3.9.0.30I
 disk0:comp-
asr9k-mini-3.9.0.30I
```

The following example illustrates sample output from the **show install active** command with the **summary** keyword specified:

```
RP/0/RSP0/CPU0:router (admin)# show install active summary

Wed May 26 12:01:27.993 PST
Default Profile:
 Admin Resources
 SDRs:
 Owner
 Active Packages:

 disk0:asr9k-doc-3.9.0.03I
 disk0:asr9k-adv-video-3.9.0.14I
 disk0:asr9k-fpd-3.9.0.03I
 disk0:asr9k-diags-3.9.0.03I
 disk0:asr9k-k9sec-3.9.0.03I
 disk0:asr9k-mgbl-3.9.0.03I
 disk0:asr9k-mcast-3.9.0.03I
 disk0:asr9k-mpis-3.9.0.03I
 disk0:comp-
asr9k-mini-3.9.0.03I
```



**Table 76: show install active Field Descriptions**

Field	Description
Boot Device	Device where the node stores the active software.
Boot Image	Location on the DSC of the active minimum boot image (MBI) used to boot the node.
Active Packages	Active packages loaded on the node.

**Related Topics**

[install activate](#), on page 907

[show install package](#), on page 975

[install activate \(IOS XR 64 bit\)](#), on page 915

[show install pie-info](#), on page 978

[show install which](#), on page 987

# show install audit

To compare the current active packages and software maintenance upgrades (SMUs) on the router with a list of packages and SMUs that should be active, use the **show install audit** command in EXEC or administration EXEC mode.

## Administration EXEC Mode

```
show install audit file file-name [{sdr sdr-name | location node-id}] [verbose]
```

## EXEC Mode

```
show install audit file file-name [location node-id] [verbose]
```

Syntax Description	Parameter	Description
	<b>file</b> <i>file-name</i>	Specifies the location and name of the installation audit file.
	<b>sdr</b> <i>sdr-name</i>	(Optional. Administration EXEC mode only.) Audits the active packages on a specific secure domain router (SDR). The <i>sdr-name</i> argument is the name assigned to the SDR. The only SDR available is Owner, which refers to the entire router.
	<b>location</b> <i>node-id</i>	(Optional) Audits the active packages on a designated node. The <i>node-id</i> argument is expressed in <i>rack/slot/module</i> notation.
	<b>verbose</b>	(Optional) Displays a detailed summary of the audit and can be used for troubleshooting.

**Command Default** No default behavior or values

**Command Modes** EXEC  
Administration EXEC

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **show install audit** command to compare the currently active packages and SMUs on the router with a list of packages and SMUs that should be active. The file should be a simple text file with a flat list of packages that should be active on the router. It should be placed in a location accessible from the router.

Note the following about the audit file:

- Each package or SMU name must be on a separate line.



**Note** For accurate results, make sure that every line in the audit file, including the last line, is terminated with a line break.

- Comments are allowed and must begin with the pound character: #
- SMUs can be specified with a package name only; regular packages should be specified as “package-version”. For SMUs, if a version is not specified, the default version of “1.0.0” is used.
- Composite package names are allowed.
- PIE extensions are allowed at the end of the package name, and they are stripped off.
- Maximum number of lines in a file is limited to 100; the maximum length of each line is limited to 256 characters.

Following are the contents of a valid audit file:

```
R3.7.2
some comments
#
comp-
asr9k-mini-3.7.2
asr9k-mgbl-3.7.2
asr9k-mcast-3.7.2
asr9k-mpls-3.7.2
asr9k-base-3.7.2.CSCek42760
asr9k-base-3.7.2.CSCse14607
asr9k-mpls-3.7.2.CSCse00294
comp-asr9k-3.7.2.CSCsd07147
```

### Displaying Information for a Specific SDR

- To display information for a specific SDR from administration EXEC mode, use the **sdr** *sdr-name* keyword and argument.
- To display information for an SDR when logged into that SDR, enter the **show install audit** command in EXEC mode.

### Displaying Information for a Specific Node

Use the **location** *node-id* keyword and argument to display information for a specific node. If you do not specify a location with the **location** *node-id* keyword and argument, this command displays information for all nodes.

### Verbose Information

Use the **verbose** keyword to display additional information, including component and file information for each package.

### Command Output

Output from the **show install audit** command provides the following information about the audit:

- Command completes successfully, and the result of the audit is success. This means that all packages listed in the audit file are active, and there are no extra packages active on all nodes where the audit was requested. This can refer to the entire router, a particular SDR, or a particular node.
- Command completes successfully, and the result of the audit is failure. Audit failure means that there are discrepancies between the set of packages listed in the audit file and the packages active on the nodes where audit is done.

The following additional messages indicate the type of discrepancy found in the audit:

- Package specified in the audit file is not present at all. In other words, there was no **install add** performed for this package.
- Package specified in the audit file is present, but is not active on all nodes where it should be active. For example, a package that goes only to route processors (RPs) is not active on all RPs audited (either the entire router or a specific SDR, depending on the scope of command).
- Package specified in the audit file is present, but is not active on some nodes where it should be active. In this case, a list is provided of the nodes where the package is not active.
- Extra package that is not present in the audit file is active on all nodes being audited.
- Extra package that is not present in the audit file is active on some nodes being audited. In this case, a list is provided of the nodes where the package is active.

Task ID	Task ID	Operations
	pkg-mgmt	read

The following sample output indicates that the audit is successful:

```
RP/0/RSP0/CPU0:router# admin
RP/0/RSP0/CPU0:router(admin)# show install audit file tftp://10.2.2.2/install_list.txt

Install audit operation completed.
Install audit result: SUCCESS
```

The following sample output indicates that there are discrepancies between the packages installed on the router and the supplied audit file:

```
RP/0/RSP0/CPU0:router(admin)# show install audit file tftp://10.2.2.2/install_list.txt

Info: Package (asr9k-base-3.2.4.CSCxx12345) is not active only on node(s)
Info: 0/5/CPU0, 0/3/CPU0.
Install audit operation completed.
Install audit result: FAILED (discrepancies found)
```

### Related Topics

- [install activate](#), on page 907
- [show install active](#), on page 955
- [show install package](#), on page 975
- [show install pie-info](#), on page 978
- [show install which](#), on page 987

# show install auto-abort-timer

To display the current auto-abort-timer, use the **show install auto-abort-timer** command in EXEC or administration EXEC mode.

**show install auto-abort-timer**

**Syntax Description** This command has no keywords or arguments.

**Command Default** None

**Command Modes** EXEC  
Administration EXEC

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **show install auto-abort-timer** command displays the timer value configured with the **install activate** and **install deactivate** commands.

Task ID	Task ID	Operations
	pkg-mgmt	read

The following sample output displays the current auto-abort-timer value:

```
RP/0/RSP0/CPU0:router# show install auto-abort-timer
```

```
No Auto Abort Timer(s) present
```

## Related Topics

[install activate](#), on page 907

[install deactivate](#), on page 931

# show install boot-options

To display the boot options set for a specified location or for all locations, use the **show install boot-options** command in administration EXEC mode or EXEC mode.

```
show install boot-options [{location node-id | all}]
```

## Syntax Description

**location** {*node-id* | **all**} (Optional) Specifies a node. The *node-id* argument is expressed in *rack/slot/module* notation. The **all** keyword specifies all nodes.

## Command Default

If no location is specified, the **show install boot-options** command displays boot options for all locations.

## Command Modes

Administration EXEC  
EXEC

## Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	No modification.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **show install boot-options** command to display boot options that were set using the **install boot-options** command.

## Task ID

Task ID	Operations
pkg-mgmt	read

The following example shows how to display the boot options for all locations:

```
RP/0/RSP0/CPU0:router# show install boot-options

Thu Jul 30 05:00:30.652 DST
Node Boot Options
-----+-----
0/RSP0/CPU0 no boot options set.
0/1/CPU0 no boot options set.
0/4/CPU0 no boot options set.
0/6/CPU0 no boot options set.
```

## Related Topics

[reload \(administration EXEC\)](#), on page 12

[hw-module location reload](#), on page 332  
[clear install boot-options](#), on page 899  
[show install boot-options](#), on page 962  
[install boot-options](#), on page 927

# show install inactive

To display the inactive packages on the designated shelf controller (DSC) for one or more secure domain routers (SDRs), use the **show install inactive** command in EXEC or administration EXEC mode.

## Administration EXEC Mode

**show install inactive** [{detail | summary | verbose}] [{sdr *sdr-name* | location *node-id*}

## EXEC Mode

**show install inactive** [{detail | summary | verbose}] [location *node-id*]

Syntax Description		
	<b>detail</b>	(Optional) Displays summary and component information for inactive packages.
	<b>summary</b>	(Optional) Displays a summary of inactive packages.
	<b>verbose</b>	(Optional) Displays summary, component, and file information for inactive packages.
	<b>sdr</b> <i>sdr-name</i>	(Optional. Administration EXEC mode only.) Displays the inactive packages for a the boot device in a specific secure domain router (SDR). The <i>sdr-name</i> argument is the name assigned to the SDR. The only SDR available is Owner, which refers to the entire router.
	<b>location</b> <i>node-id</i>	(Optional) Displays the inactive software set from a designated node. The <i>node-id</i> argument is expressed in <i>rack/slot/module</i> notation.

**Command Default** None

**Command Modes** Administration EXEC  
EXEC

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** Use the **show install inactive** command to display the inactive packages for the DSC.



**Note** Use the **show version**, **show install active**, or **show install committed** command to determine the device used as the boot device.

Enter the command in administration EXEC mode to display information for the DSDRSC in all SDRs.



### Displaying Information for a Specific SDR

- To display information for a specific SDR from administration EXEC mode, use the **sdr** *sdr-name* keyword and argument.
- To display information for an SDR when logged into that SDR, enter the command in EXEC mode.

### Displaying Information for a Specific Node

Use the **location** *node-id* keyword and argument to display information for a specific node. If you do not specify a location with the **location** *node-id* keyword and argument, this command displays information from all nodes.

### Summary, Detailed, and Verbose Information

Use the **summary** keyword to display summary of inactive packages in a system or SDR. Use the **detail** keyword to display the packages for each node in an SDR, or in all SDRs. Use the **verbose** keyword to display additional information, including component and file information for each package.

Task ID	Task ID	Operations
	pkg-mgmt	read

The following example shows sample output from the **show install inactive** command:

```
RP/0/RP0/CPU0:router# show install inactive
```

```
Node 0/1/CPU0 [LC] [SDR: Owner]
 Boot Device: bootflash:
 Inactive Packages:
 disk0:comp-asr9k-mini-3.7.2
 disk0:asr9k-infra-test-3.7.2
 disk0:asr9k-fpd-3.7.2
 disk0:asr9k-diags-3.7.2
 disk0:asr9k-mcast-3.7.2
 disk0:asr9k-mpls-3.7.2
 disk0:asr9k-base-3.7.2
 disk0:asr9k-os-mpi-3.7.2

Node 0/4/CPU0 [LC] [SDR: Owner]
 Boot Device: bootflash:
 Inactive Packages:
 disk0:comp-asr9k-mini-3.7.2
 disk0:asr9k-infra-test-3.7.2
 disk0:asr9k-fpd-3.7.2
 disk0:asr9k-diags-3.7.2
 disk0:asr9k-mcast-3.7.2
 disk0:asr9k-mpls-3.7.2
 disk0:asr9k-base-3.7.2
 disk0:asr9k-os-mpi-3.7.2

Node 0/6/CPU0 [LC] [SDR: Owner]
 Boot Device: bootflash:
 Inactive Packages:
 disk0:comp-asr9k-mini-3.7.2
 disk0:asr9k-infra-test-3.7.2
 disk0:asr9k-fpd-3.7.2
 disk0:asr9k-diags-3.7.2
```

## show install inactive

```

disk0:asr9k-mcast-3.7.2
disk0:asr9k-mpls-3.7.2
disk0:asr9k-base-3.7.2
disk0:asr9k-os-mpi-3.7.2

Node 0/RSP0/CPU0 [HRP] [SDR: Owner]
Boot Device: disk0:
Inactive Packages:
 disk0:comp-asr9k-mini-3.7.2
 disk0:asr9k-infra-test-3.7.2
 disk0:asr9k-fpd-3.7.2
 disk0:asr9k-doc-3.7.2
 disk0:asr9k-diags-3.7.2
 disk0:asr9k-mgbl-3.7.2
 disk0:asr9k-mcast-3.7.2
 disk0:asr9k-mpls-3.7.2
 disk0:asr9k-rout-3.7.2
 disk0:asr9k-base-3.7.2
 disk0:asr9k-os-mpi-3.7.2

```

The following example shows sample output from the **show install inactive** command with the **summary** keyword:

```
RP/0/RSP0/CPU0:router# show install inactive summary
```

```

Tue Feb 3 02:09:21.359 PST
Inactive Packages:
 disk0:comp-asr9k-mini-3.7.2
 disk0:asr9k-infra-test-3.7.2
 disk0:asr9k-fpd-3.7.2
 disk0:asr9k-doc-3.7.2
 disk0:asr9k-diags-3.7.2
 disk0:asr9k-mgbl-3.7.2
 disk0:asr9k-mcast-3.7.2
 disk0:asr9k-mpls-3.7.2
 disk0:asr9k-rout-3.7.2
 disk0:asr9k-base-3.7.2
 disk0:asr9k-os-mpi-3.7.2

```

The following example shows sample output from the **show install inactive** command with the **detail** and **location** keywords:

```
RP/0/RSP0/CPU0:router# show install inactive detail location 0/1/cpu0
```

```

Tue Feb 3 02:14:31.299 PST
Node 0/1/CPU0 [LC] [SDR: Owner]
Boot Device: bootflash:
Inactive Packages:
 disk0:comp-asr9k-mini-3.7.2
 disk0:asr9k-lc-3.7.2
 disk0:asr9k-fwgd-3.7.2
 disk0:asr9k-admin-3.7.2
 disk0:asr9k-base-3.7.2
 disk0:asr9k-os-mpi-3.7.2
 disk0:asr9k-infra-test-3.7.2
 disk0:asr9k-fpd-3.7.2
 disk0:asr9k-diags-3.7.2
 disk0:asr9k-mcast-3.7.2

```

```
disk0:asr9k-mpls-3.7.2
```

**Table 77: show install inactive Field Descriptions**

Field	Description
disk0:asr9k-mgbl-3.8.0	Storage device and the name of the package that is inactive.
asr9k-mgbl V3.8.0 Manageability Package	Name of the package that is inactive.
Vendor	Name of the manufacturer.
Desc	Name of the package.
Build	The date and time when the inactive package was built.
Source	The source directory where the inactive package was built.

### Related Topics

- [install deactivate](#), on page 931
- [show install package](#), on page 975
- [install deactivate \(IOS XR 64 bit\)](#), on page 937
- [show install pie-info](#), on page 978
- [show install which](#), on page 987

# show install issu inventory

To display the status of each node and the current status of ISSU, use the **show install issu inventory** command in administration EXEC mode.

**show install issu inventory**[{**detail** | **type** *ism-card-type*}]

Syntax Description	detail	Displays detailed information about the status of each card.
	<b>type</b> <i>ism-card-type</i>	displays information regarding a specific card type. <i>ism-card-type</i> values can be of the following: <ol style="list-style-type: none"> <li>1—Show inventory of all Active RPs in ndsc Racks</li> <li>2—Show inventory of all Standby RPs in ndsc Racks</li> <li>3—Show inventory of all Active DRPs (any rack)</li> <li>4—Show inventory of all Standby DRPs (any rack)</li> <li>5—Show inventory of the dSC node</li> <li>6—Show inventory of the Standby dSC node</li> <li>7—Show inventory of all Active Non-root SCs</li> <li>8—Show inventory of all Standby Non-root SCs</li> <li>9—Show inventory of the Root SC</li> <li>10—Show inventory of the Root SC backup</li> <li>11—Show inventory of all LCs (any rack)</li> <li>12—Show inventory of all Non-Fabric SPs. Eg:LC, Alarm, Fan Controller SPs</li> <li>13—Show inventory of all Fabric SPs</li> </ol>

**Command Default** Summary information is displayed

**Command Modes** Administration EXEC

Command History	Release	Modification
	Release 4.2.1	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **show install issu inventory** command displays output only when the ISSU process is running.

Task ID	Task ID	Operation
	pkg-mgmt	read

# show install issu stage

To display the current stage of the running ISSU process, use the **show install issu stage** command in administration EXEC mode.

**show install issu stage** [detail]

<b>Syntax Description</b>	<b>detail</b> Displays more information regarding the stage of the process.
---------------------------	-----------------------------------------------------------------------------

<b>Command Default</b>	Displays summary information about the ISSU stage on the router.
------------------------	------------------------------------------------------------------

<b>Command Modes</b>	Administration EXEC
----------------------	---------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 4.2.1	This command was introduced.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

The **show install issu stage** command displays output only when the ISSU process is running.

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	pkg-mgmt	read

This example displays output from the **show install issu stage** command during the load phase:

```
RP/0/RSP0/CPU0:router(admin)# show install issu stage

Thu Dec 8 16:09:48.397 UTC
Current State : LOAD phase done (Load phase done)
Status : 31% Completed
Participating nodes : 0
Nodes in progress : 0
```

# show install log

To display the details of installation requests, use the **show install log** command in EXEC or administration EXEC mode.

```
show install log [{install-id | from install-id}] [{detail | verbose}] [reverse]
```

Syntax Description	
<i>install-id</i>	(Optional) Identifier assigned to an installation operation.
<b>from</b> <i>install-id</i>	(Optional) Displays information for logs from the specified installation identifier and forward.
<b>detail</b>	(Optional) Displays details including impact to processes and nodes.
<b>verbose</b>	(Optional) Displays the information from the keyword, plus additional information about impacts to files, processes, and dynamic link libraries (DLLs).
<b>reverse</b>	(Optional) Displays the logs in reverse order.

**Command Default** None

**Command Modes** Administration EXEC  
EXEC

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** Enter the **show install log** command with no arguments to display a summary of all installation operations, including the changes to files and the processes impacted by each request. Specify the *install-id* argument to display details for a specific operation.

The *install-id* argument is listed beside each operation in the **show install log** summary and is attached to messages from that operation. For example, the third installation operation has “Install 3:” attached to all its status messages.

The **reverse** keyword displays the information from the latest install log to the oldest install log. Use the **from** keyword to limit the output to be from the specified installation identifier and later.

## Displaying Information for a Specific SDR

- To display information for a specific SDR from administration EXEC mode, use the **sdr sdr-name** keyword and argument.
- To display information for an SDR when logged into that SDR, enter the command in EXEC mode.

### Detailed and Verbose Information

Use the **detail** keyword to display detailed information for all previous installations, including impact to processes and nodes impacted. The detailed information is a subset of the information displayed with the **verbose** keyword.

Use the **verbose** keyword to display detailed information for all previous installations, information including files changes, impact to processes, and impact to dynamic link libraries (DLLs).

Task ID	Task ID	Operations
	pkg-mgmt	read

The following example shows a summary of all installation requests:

```
RP/0/RSP0/CPU0:router# admin
RP/0/RSP0/CPU0:router(admin)# show install log

Tue Jul 28 02:01:55.887 DST

Install operation 1 started by user 'user' via CLI at 14:14:19 DST Tue Jul
14 2009.
 (admin) install add /compactflash:asr9k-k9sec-p.pie-3.9.0.14I
/compactflash:asr9k-mcast-p.pie-3.9.0.14I
/compactflash:asr9k-mgbl-p.pie-3.9.0.14I
/compactflash:asr9k-mpis-p.pie-3.9.0.14I
/compactflash:asr9k-fpd.pie-3.9.0.14I
/compactflash:asr9k-diags-p.pie-3.9.0.14I
/compactflash:asr9k-adv-video-p.pie-3.9.0.14I activate
Install operation 1 completed successfully at 14:27:50 DST Tue Jul 14 2009.

Install operation 2 started by user 'user' via CLI at 14:28:16 DST Tue Jul
14 2009.
 (admin) install commit
Install operation 2 completed successfully at 14:28:18 DST Tue Jul 14 2009.

2 entries shown
```

The following example shows the details for a specific installation request. The **detail** keyword is used to display additional information about the impact of the operation to processes and nodes:

```
RP/0/RSP0/CPU0:router(admin)# show install log 2 detail

Tue Jul 28 02:09:08.628 DST

Install operation 2 started by user 'user_b' via CLI at 14:28:16 DST Tue Jul14 2009.
(admin) install commit
Install operation 2 completed successfully at 14:28:18 DST Tue Jul 14 2009.

Install logs:
 Install operation 2 '(admin) install commit' started by user 'user_b' via
 CLI at 14:28:16 DST Tue Jul 14 2009.
 Install operation 2 completed successfully at 14:28:18 DST Tue Jul 14 2009.
```

The following example shows information for the installation requests. The **verbose** keyword is used to display detailed information including file changes, impact to processes, and impact to DLLs.

```
RP/0/RSP0/CPU0:router(admin)# show install log 2 verbose
```

```
Tue Jul 28 02:21:49.011 DST
```

```
Install operation 1 started by user 'user_b' via CLI at 14:14:19 DST Tue Jul 14 2009.
```

```
(admin) install add /compactflash:asr9k-k9sec-p.pie-3.9.0.14I
/compactflash:asr9k-mcast-p.pie-3.9.0.14I
/compactflash:asr9k-mgbl-p.pie-3.9.0.14I
/compactflash:asr9k-mpls-p.pie-3.9.0.14I
/compactflash:asr9k-fpd.pie-3.9.0.14I
/compactflash:asr9k-diags-p.pie-3.9.0.14I
/compactflash:asr9k-adv-video-p.pie-3.9.0.14I activate
Install operation 1 completed successfully at 14:27:50 DST Tue Jul 14 2009.
```

```
Install logs:
```

```
Install operation 1 '(admin) install add
/compactflash:asr9k-k9sec-p.pie-3.9.0.14I
/compactflash:asr9k-mcast-p.pie-3.9.0.14I
/compactflash:asr9k-mgbl-p.pie-3.9.0.14I
/compactflash:asr9k-mpls-p.pie-3.9.0.14I
/compactflash:asr9k-fpd.pie-3.9.0.14I
/compactflash:asr9k-diags-p.pie-3.9.0.14I
/compactflash:asr9k-adv-video-p.pie-3.9.0.14I activate' started by
user 'user_b' via CLI at 14:14:19 DST Tue Jul 14 2009.
Part 1 of 2 (add software): Started
Warning: Skipped adding the following package as it was already present:
Warning: disk0:asr9k-diags-3.9.0.14I
Warning: Please check:
Warning: - the set of active packages using '(admin) show install
Warning: active'.
Warning: - the set of inactive packages using '(admin) show install
Warning: inactive'.
Info: The following packages are now available to be activated:
Info:
Info: disk0:asr9k-k9sec-3.9.0.14I
Info: disk0:asr9k-mcast-3.9.0.14I
Info: disk0:asr9k-mgbl-3.9.0.14I
Info: disk0:asr9k-mpls-3.9.0.14I
Info: disk0:asr9k-fpd-3.9.0.14I
Info: disk0:asr9k-diags-3.9.0.14I
Info: disk0:asr9k-adv-video-3.9.0.14I
Info:
Info: The packages can be activated across the entire router.
Info:
Part 1 of 2 (add software): Completed successfully (skipped adding one or
more packages because they were already present on the boot device)
Part 2 of 2 (activate software): Started
Info: Cannot activate the following package as it is already active on
Info: the router:
Info:
Info: disk0:asr9k-diags-3.9.0.14I
Info:
Info: The following sequence of sub-operations has been determined to
Info: minimize any impact:
```



```

Info:
Info: Sub-operation 1:
Info: Install Method: Parallel Process Restart
Info: asr9k-mpls-3.9.0.14I
Info:
Info: Sub-operation 2:
Info: Install Method: Parallel Process Restart
Info: asr9k-mcast-3.9.0.14I
Info:
Info: Sub-operation 3:
Info: Install Method: Parallel Process Restart
Info: asr9k-k9sec-3.9.0.14I
Info:
Info: Sub-operation 4:
Info: Install Method: Parallel Process Restart
Info: asr9k-fpd-3.9.0.14I
Info:
Info: Sub-operation 5:
Info: Install Method: Parallel Process Restart
Info: asr9k-mgbl-3.9.0.14I
Info:
Info: Sub-operation 6:
Info: Install Method: Parallel Process Restart
Info: asr9k-adv-video-3.9.0.14I
Info:
Info: The changes made to software configurations will not be
Info: persistent across system reloads. Use the command '(admin)
Info: install commit' to make changes persistent.
Info: Please verify that the system is consistent following the
Info: software change using the following commands:
Info: show system verify
Info: install verify packages
Part 2 of 2 (activate software): Completed successfully
Part 1 of 2 (add software): Completed successfully (skipped adding one or
more packages because they were already present on the boot device)
Part 2 of 2 (activate software): Completed successfully
Install operation 1 completed successfully at 14:27:50 DST Tue Jul 14 2009.

```

## Summary:

```

Sub-operation 1:
Install method: Parallel Process Restart
Summary of changes on node 0/RSP0/CPU0:
 Activated: asr9k-mpls-3.9.0.14I
 6 asr9k-mpls processes affected (0 updated, 6 added, 0 removed, 0 impacted)

Summary of changes on node 0/1/CPU0:
 Activated: asr9k-mpls-3.9.0.14I
 1 asr9k-mpls processes affected (0 updated, 1 added, 0 removed, 0 impacted)

Summary of changes on node 0/4/CPU0:
 Activated: asr9k-mpls-3.9.0.14I
 1 asr9k-mpls processes affected (0 updated, 1 added, 0 removed, 0 impacted)

Summary of changes on node 0/6/CPU0:
 Activated: asr9k-mpls-3.9.0.14I
 1 asr9k-mpls processes affected (0 updated, 1 added, 0 removed, 0 impacted)

Sub-operation 2:
Install method: Parallel Process Restart
Summary of changes on node 0/RSP0/CPU0:
 Activated: asr9k-mcast-3.9.0.14I
 16 asr9k-mcast processes affected (0 updated, 16 added, 0 removed, 0 impacted)

Summary of changes on node 0/1/CPU0:

```

```

Activated: asr9k-mcast-3.9.0.14I
 1 asr9k-base processes affected (1 updated, 0 added, 0 removed, 0 impacted)
 2 asr9k-mcast processes affected (0 updated, 2 added, 0 removed, 0 impacted)

Summary of changes on node 0/4/CPU0:
Activated: asr9k-mcast-3.9.0.14I
 1 asr9k-base processes affected (1 updated, 0 added, 0 removed, 0 impacted)
 2 asr9k-mcast processes affected (0 updated, 2 added, 0 removed, 0 impacted)

Summary of changes on node 0/6/CPU0:
Activated: asr9k-mcast-3.9.0.14I
 1 asr9k-base processes affected (1 updated, 0 added, 0 removed, 0 impacted)
--More--

```

The following example shows all installation requests in reverse order, such that the most recent requests are displayed first:

```

RP/0/RSP0/CPU0:router(admin)# show install log reverse

Install operation 2 started by user 'user_a' via CLI at 12:33:10 GMT Mon Oct 29 2008.
(admin) install add /tftp://xx-tftp/user_a/asr9k-fpd.pie
Install operation 2 completed successfully at 12:35:19 GMT Mon Oct 29 2008.

Install operation 1 started by user 'user_a' via CLI at 12:31:07 GMT Mon Oct 29 2007.
(admin) install add /tftp://xx-tftp/user_a/asr9k-mgbl.pie
Install operation 1 completed successfully at 12:32:12 GMT Mon Oct 29 2008.

```

### Related Topics

- [install activate](#), on page 907
- [install add](#), on page 918
- [install deactivate](#), on page 931
- [install remove](#), on page 942
- [install commit](#), on page 929
- [install rollback to](#), on page 945

# show install package

To display information about a package, use the **show install package** command in EXEC or administration EXEC mode.

```
show install package {device:package | all} [{brief | detail | verbose}]
```

Syntax Description	
<i>device : package</i>	Device and package, expressed in concatenated form (for example, disk0:asr9k-mgbl-3.8.0). For the <i>device:</i> argument, the value is a specified storage device, typically <b>disk0:</b> .
<b>all</b>	Displays all installed packages on the system or SDR.
<b>brief</b>	(Optional) Displays only the name and version of packages.
<b>detail</b>	(Optional) Displays detailed information including impact to processes and nodes, vendor information, card support, and component information.
<b>verbose</b>	(Optional) Displays the information included in the keyword, plus information about dynamic link libraries (DLLs).

**Command Default** None

**Command Modes** Administration EXEC  
EXEC

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** Use the **show install package** command with the **all** keyword to display a list of the packages on the router or SDR.

Use the **show install package** command with the **detail** keyword to display the version of the package, name of the manufacturer, name of the package, date and time when the package was built, and source directory where the package was built.

Use the **show install package** command with the **verbose** keyword to display the same information as the **detail** keyword, plus additional information about DLLs.



**Note** This command returns the same data in EXEC mode and administration EXEC mode. In EXEC mode, only the information for the current SDR is displayed.

For additional information about the status of installed software packages, use the **show install active** and **show install inactive** commands.

## show install package

Task ID	Task ID	Operations
	pkg-mgmt	read

The following sample output from the **show install package** command lists all packages that are available on the router:

```
RP/0/RSP0/CPU0:router(admin)# show install package all

Tue Jul 28 05:02:53.578 DST
disk0:asr9k-fpd-3.9.0.14I

disk0:asr9k-mgbl-3.9.0.14I

disk0:asr9k-mpis-3.9.0.14I

disk0:asr9k-k9sec-3.9.0.14I

disk0:asr9k-mcast-3.9.0.14I

disk0:asr9k-adv-video-3.9.0.14I

disk0:comp-asr9k-mini-3.9.0.14I
 disk0:asr9k-scfclient-3.9.0.14I
 disk0:asr9k-diags-3.9.0.14I
 disk0:asr9k-rout-3.9.0.14I
 disk0:asr9k-lc-3.9.0.14I
 disk0:asr9k-fwdg-3.9.0.14I
 disk0:asr9k-admin-3.9.0.14I
 disk0:asr9k-base-3.9.0.14I
 disk0:asr9k-os-mpi-3.9.0.14I
```

The following sample output from the **show install package** command lists all the packages contained in a composite package:

```
RP/0/RSP0/CPU0:router(admin)# show install package disk0:comp-asr9k-mini-3.8.0

Tue Feb 3 04:01:55.015 PST
disk0:comp-asr9k-mini-3.8.0
 disk0:asr9k-rout-3.8.0
 disk0:asr9k-lc-3.8.0
 disk0:asr9k-fwdg-3.8.0
 disk0:asr9k-admin-3.8.0
 disk0:asr9k-base-3.8.0
 disk0:asr9k-os-mpi-3.8.0
```

**Table 78: show install package Field Descriptions**

Field	Description
disk0:asr9k-rout-3.8.0	Storage device and the name of the package that has been installed.
asr9k-rout V3.8.0 Routing Package	Name of the package.
Vendor	Name of the manufacturer.
Desc	Name of the package.

Field	Description
Build	Date and time the package was built.
Source	Source directory where the package was built.
Card(s)	Card types supported by the package.
Restart information	Restart impact on processes or nodes.
Components in package	Components included in the package.

**Related Topics**

- [show install active](#), on page 955
- [show install inactive](#), on page 964
- [show install log](#), on page 970
- [show install](#), on page 952
- [show install pie-info](#), on page 978
- [show install which](#), on page 987

# show install pie-info

To display information about a package installation envelope (PIE) installation file, use the **show install pie-info** command in EXEC or administration EXEC mode.

```
show install pie-info device:package [{brief | detail | verbose}]
```

Syntax Description	
<i>device : package</i>	Device, directory path, and package, expressed in concatenated form.
<b>brief</b>	(Optional) Displays summary information.
<b>detail</b>	(Optional) Displays detailed information.
<b>verbose</b>	(Optional) Displays comprehensive information.

**Command Default** Displays summary information.

**Command Modes** EXEC  
Administration EXEC

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **install pie-info** command to display information about a specified PIE installation file.

Task ID	Task ID	Operations
	pkg-mgmt	read

The following example illustrates sample output from the **install pie-info** command. The default display shows the package name, expiration date, and file size:

```
RP/0/RSP0/CPU0:router(admin)# show install pie-info disk1:/
asr9k
-mgbl-p.pie-3.8.0

Contents of pie file '/disk1:/asr9k-mgbl-p.pie-3.8.0':
 Expiry date : Jan 19, 2007 02:55:56 UTC
 Uncompressed size : 17892613
 asr9k-mgbl-3.8.0
```

The following example illustrates sample output from the **install pie-info** command with the **detail** keyword. This command displays additional information including vendor, build date supported cards, and component information:

```
RP/0/RSP0/CPU0:router(admin)# show install pie-info disk1:/
asr9k
-mgbl-p.pie-3.8.0 detail
Contents of pie file '/disk1:/asr9k-mgbl-p.pie-3.8.0':
 Expiry date : Jan 19, 2007 02:55:56 UTC
 Uncompressed size : 17892613
 asr9k-mgbl-3.8.0
 asr9k-mgbl V3.8.0[00] Manageability Package
 Vendor : Cisco Systems
 Desc : Manageability Package
 Build : Built on Wed May 10 08:04:58 UTC 2006
 Source : By edde-bld1 in /vws/aga/production/3.8.0/asr9k/workspace for c28
 Card(s): RP
 Restart information:
 Default:
 parallel impacted processes restart
 Components in package asr9k-mgbl-3.8.0, package
asr9k-mgbl:
manageability-cwi V[r33x/2] Craft Web Interface related binaries ae
asr9k-feature-ipsla V[r33x/1] IPSLA time stamping feature
 doc-asr9k-mgbl V[r33x/2] Contains the
man page documentation for asr9ksemweb V[r33x/1]
Agranat/Virata Emweb embedded web server
generic-xmlagent V[r33x/1] Generic XML Agent
ipsla V[r33x/1] IP SLA Agent (formerly known as Service Assurance)
manageability-perf V[r33x/1] Performance Management Component for y
man-xml-alarm-ops V[r33x/1] The XML Operations Provider for alarms.
man-xml-cfgmgr-ops V[r33x/1] Handler for XML which contains CfgMgrs
man-xml-cli-ops V[r33x/1] Handler for XML which contains CLI reques
man-xml-infra V[r33x/1] Generic infrastructure for XML support
man-xml-mdm-ops V[r33x/1] Handler for XML which contains MDA reques
man-xml-ttyagent V[r33x/1] XML Telnet/SSH agent
cfg-sh-mgbl V[r33x/1] LR shared plane manageability config
package-compat V[r33x/1] This is to collect package^Mcompatibilitys
package-manage V[r33x/3] This is to collect package^Mcompatibilitye
snmp-assetmib V[r33x/1] CISCO ASSET Management Information Base (M)
snmp-bulkfilemib V[r33x/1] Bulk File Management Information Base ()
snmp-assetmib-enhi V[r33x/1] CISCO ENHANCED IMAGE MIB
snmp-disman-mib V[r33x/1] Event MIB Implementation
snmp--disman-mib V[r33x/1] EXPRESSION-MIB implementation
snmp-frucontrolmib V[r33x/1] CISCO-FRU-CONTROL MIB Implementation A
snmp-ftpclientmib V[r33x/1] FTP Client Management Information Base)
snmp-pingmib V[r33x/1] Ping Management Information Base (MIB)
snmp-sensormib V[r33x/1] Sensor Management Information Base (MIB)
```

**Table 79: show install pie-info Field Descriptions**

Field	Description
Contents of pie file	Storage device, directory, and name of the package.
Expiry date	Date when the package expires and can no longer be added to a router.
Uncompressed size	File size of the package after it is added to a local storage device.
asr9k-mgbl-3.4.0	Name of the package.

Field	Description
Vendor	Name of the manufacturer.
Desc	Name of the package.
Build	Date and time the package was built.
Source	Source directory where the package was built.
Card(s)	Card types supported by the package.
Restart information	Restart impact on processes or nodes.
Components in package	Components included in the package.

**Related Topics**

- [show install active](#), on page 955
- [show install inactive](#), on page 964
- [show install log](#), on page 970
- [show install package](#), on page 975
- [show install request](#), on page 981
- [show install which](#), on page 987



# show install request

To display the list of incomplete installation requests, running and queued, use the **show install request** command in EXEC or administration EXEC mode.

**show install request [detail]**

<b>Syntax Description</b>	<b>detail</b> (Optional) Displays detailed information.
---------------------------	---------------------------------------------------------

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Administration EXEC EXEC
----------------------	-----------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** Cisco IOS XR software processes only one installation request per secure domain router (SDR) at a time. The **show install request** command displays any incomplete request that is currently running.

Use the **show install request** command in administration EXEC or EXEC mode to display installation operations for the Owner SDR.



**Note** The default of installation commands is asynchronous mode, meaning that the command runs in the background and the EXEC prompt is returned as soon as possible. Performing a command in synchronous mode allows the installation process to finish before the prompt is returned.



**Tip** These requests cannot be stopped by pressing **Ctrl-C**. To stop a request, use the **install attach** command to attach to the operation, then press **Ctrl-C** and select the “abort” option.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	pkg-mgmt	read

The following example shows sample output from the **show install request** command:

```
RP/0/RSP0/CPU0:router# admin
RP/0/RSP0/CPU0:router(admin)# show install request

Install operation 17 'install add /tftp://172.31.255.255/dir/19mcast' started by user
'user_b' at 14:38:45 UTC Thu Mar 30 2006. The operation is 1% complete 2,017KB
```

downloaded The operation can still be aborted.

The following example shows sample output from the **show install request** command when no installation operations are running:

```
RP/0/RSP0/CPU0:router(admin)# show install request
```

```
There are no install requests in operation.
```

### Related Topics

- [install activate](#), on page 907
- [install add](#), on page 918
- [install deactivate](#), on page 931
- [install remove](#), on page 942
- [install rollback to](#), on page 945

# show install rollback

To display the software set associated with a saved installation point, use the **show install rollback** command in EXEC or administration EXEC mode.

## Administration EXEC Mode

```
show install rollback {point-idlabel} [{detail | summary}] [{sdr sdr-name | location node-id}]
```

## EXEC Mode

```
show install rollback {point-idlabel} [{detail | summary}] [location node-id]
```

Syntax Description	
<i>point-id</i>	Installation point ID number.
<i>label</i>	Label associated with an installation point ID.
<b>detail</b>	(Optional) Displays a detailed summary of information for a system, SDR, or node, including the packages contained in a composite package.
<b>summary</b>	(Optional) Displays a summary of information in a system or SDR.
<b>sdr sdr-name</b>	(Optional) Displays information for a specific secure domain router (SDR). The <i>sdr-name</i> argument is the name assigned to the SDR. This option is in administration EXEC mode only.
<b>location node-id</b>	(Optional) Displays information for a designated node. The <i>node-id</i> argument is expressed in <i>rack/slot/module</i> notation.

**Command Default** None

**Command Modes** EXEC  
Administration EXEC

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **show install rollback** command to display the software set associated with a saved installation point. To display the available rollback points, use the online help system. For example: **show install rollback ?**.



**Tip** This command can be used with the **install rollback to** command to verify the software set associated with a saved installation point before rolling back to the saved installation point.

### Displaying Information for a Specific SDR or All Nodes

- To display information for a specific SDR from administration EXEC mode, use the **sdr** *sdr-name* keyword and argument.
- To display information for an SDR when logged into that SDR, enter the command in EXEC mode.

### Displaying Information for a Specific Node

Use the **location** *node-id* keyword and argument to display information for a specific node. If you do not specify a location with the **location** *node-id* keyword and argument, this command displays information from all nodes.

### Summary, Detailed, and Verbose Information

Use the **summary** keyword to display a summary of the packages that are used by the **install rollback to** command. Use the **detail** keyword to display additional information, including the individual packages included in the composite packages.



**Tip** Use the **clear install rollback oldest** command to delete saved installation points from the installation buffer.

### Task ID

#### Task ID Operations

pkg-mgmt read

In the following example, the **show install rollback** command with the **?** option displays the available rollback points:

```
RP/0/RSP0/CPU0:router# admin
RP/0/RSP0/CPU0:router(admin)# show install rollback ?

 0 ID of the rollback point to show package information for
 2 ID of the rollback point to show package information for
```

In the following example, the **show install rollback** command displays the packages for a specific rollback point. This display summarizes the packages that are used by the **install rollback to** command:

```
RP/0/RSP0/CPU0:router(admin)# show install rollback 1

Tue Jul 28 00:37:19.004 DST
ID: 1, Label:
Timestamp: 14:26:57 DST Tue Jul 14 2009

Secure Domain Router: Owner

Node 0/RSP0/CPU0 [RP] [SDR: Owner]
 Boot Device: disk0:
 Boot Image: /disk0/asr9k-os-mpi-3.9.0.14I/mbiasr9k-rp.vm
 Rollback Packages:
 disk0:comp-asr9k-mini-3.9.0.14I
 disk0:asr9k-adv-video-3.9.0.14I
 disk0:asr9k-fpd-3.9.0.14I
 disk0:asr9k-k9sec-3.9.0.14I
```

```

disk0:asr9k-mgbl-3.9.0.14I
disk0:asr9k-mcast-3.9.0.14I
disk0:asr9k-mppls-3.9.0.14I

Node 0/1/CPU0 [LC] [SDR: Owner]
 Boot Device: mem:
 Boot Image: /disk0/asr9k-os-mbi-3.9.0.14I/lc/mbiasr9k-lc.vm
 Rollback Packages:
 disk0:comp-asr9k-mini-3.9.0.14I
 disk0:asr9k-adv-video-3.9.0.14I
 disk0:asr9k-fpd-3.9.0.14I
 disk0:asr9k-mcast-3.9.0.14I
 disk0:asr9k-mppls-3.9.0.14I

Node 0/4/CPU0 [LC] [SDR: Owner]
 Boot Device: mem:
 Boot Image: /disk0/asr9k-os-mbi-3.9.0.14I/lc/mbiasr9k-lc.vm
 Rollback Packages:
 disk0:comp-asr9k-mini-3.9.0.14I
 disk0:asr9k-adv-video-3.9.0.14I
 disk0:asr9k-fpd-3.9.0.14I
 disk0:asr9k-mcast-3.9.0.14I
 disk0:asr9k-mppls-3.9.0.14I

Node 0/6/CPU0 [LC] [SDR: Owner]
 Boot Device: mem:
 Boot Image: /disk0/asr9k-os-mbi-3.9.0.14I/lc/mbiasr9k-lc.vm
 Rollback Packages:
 disk0:comp-asr9k-mini-3.9.0.14I
 disk0:asr9k-adv-video-3.9.0.14I
 disk0:asr9k-fpd-3.9.0.14I
 disk0:asr9k-mcast-3.9.0.14I
 disk0:asr9k-mppls-3.9.0.14I

```

In the following example, the **show install rollback** command with the **detail** keyword displays additional information for the packages, including the individual packages included in the composite packages:

```

RP/0/RSP0/CPU0:router(admin)# show install rollback 1 detail

Tue Jul 28 00:40:06.294 DST
ID: 1, Label:
Timestamp: 14:26:57 DST Tue Jul 14 2009

Secure Domain Router: Owner

Node 0/RSP0/CPU0 [RP] [SDR: Owner]
 Boot Device: disk0:
 Boot Image: /disk0/asr9k-os-mbi-3.9.0.14I/mbiasr9k-rp.vm
 Rollback Packages:
 disk0:comp-asr9k-mini-3.9.0.14I
 disk0:asr9k-scfclient-3.9.0.14I
 disk0:asr9k-diags-3.9.0.14I
 disk0:asr9k-rout-3.9.0.14I
 disk0:asr9k-lc-3.9.0.14I
 disk0:asr9k-fwdg-3.9.0.14I
 disk0:asr9k-admin-3.9.0.14I
 disk0:asr9k-base-3.9.0.14I
 disk0:asr9k-os-mbi-3.9.0.14I
 disk0:asr9k-adv-video-3.9.0.14I
 disk0:asr9k-fpd-3.9.0.14I
 disk0:asr9k-k9sec-3.9.0.14I

```

```
disk0:asr9k-mgbl-3.9.0.14I
disk0:asr9k-mcast-3.9.0.14I
--More--
```

**Table 80: show install rollback Field Descriptions**

Field	Description
Boot Image	Minimum boot image (MBI) used to boot the node.
Rollback Packages	Packages that are rolled back.

### Related Topics

[clear install rollback oldest](#), on page 903

[install rollback to](#), on page 945

# show install which

To display the origin of a named process, component, or package, use the **show install which** command in EXEC or administration EXEC mode.

```
show install which {component name [verbose] | file filename} [{sdr sdr-name | location node-id}]
```

Syntax Description	
<b>component</b> <i>name</i>	Displays the package information for the component specified in the <i>name</i> argument.
<b>verbose</b>	(Optional) Displays summary, component, and file information for each component.
<b>file</b> <i>filename</i>	Displays the package information for the file specified in the <i>filename</i> argument.
<b>sdr</b> <i>sdr-name</i>	(Optional. Administration EXEC mode only.) Displays information for a specific secure domain router (SDR). The <i>sdr-name</i> argument is the name assigned to the SDR.
<b>location</b> <i>node-id</i>	(Optional) Displays information for the designated node. The <i>node-id</i> argument is expressed in <i>rack/slot/module</i> notation.

**Command Default** The default search is performed for the active software set.

**Command Modes** Administration EXEC  
EXEC

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **show install which** command to display information about a named process, component, or package. Information is shown for each node where the process, component, or package is located.

This command returns the same data in EXEC mode and administration EXEC mode.

## Displaying Information for a Specific SDR or All SDRs

- To display information for a specific SDR from administration EXEC mode, use the **sdr** *sdr-name* keyword and argument.
- To display information for an SDR when logged into that SDR, enter the command in EXEC mode.

## Displaying Information for a Specific Node

Use the **location** *node-id* keyword and argument to display information for a specific node. If you do not specify a location with the **location** *node-id* keyword and argument, this command displays information from all nodes.



**Note** If the process, component, or package is not located on that node, an error message is displayed.

### Verbose Information

Use the **verbose** keyword to display additional information, including component and file information for each package.

### Task ID

#### Task ID Operations

pkg-mgmt read

The following example shows cisco discovery protocol (CDP) information for a single node. The **show install which** command is entered with the **file** and **location** keywords specified:

```
RP/0/RSP0/CPU0:router(admin)# show install which file cdp location 0/1/cpu0

Tue Jul 28 05:59:49.091 DST
Node 0/1/CPU0 has file cdp for boot package /disk0/asr9k-os-mbi-3.9.0.14I/lc/mbiasr9k-lc.vm

 from asr9k-base
Package:
 asr9k-base
 asr9k-base V3.9.0.14I[DT_IMAGE] Base Package for ASR9K
 Vendor : Cisco Systems
 Desc : Base Package for ASR9K
 Build : Built on Mon Jul 13 08:14:52 DST 2009
 Source : By sjc-lds-208 in
/auto/ioxbuild7/production/3.9.0.14I.DT_IMAGE/asr9k/workspace
 for c4.2.1-p0
 Card(s): RP, RP-B, HRP, OC3-POS-4, OC12-POS, GE-3, OC12-POS-4, OC48-POS, E3-OC48-POS,
 E3-OC12-POS-4, E3-OC3-POS-16, E3-OC3-POS-8, E3-OC3-POS-4, E3-OC48-CH, E3-OC12-CH-4,
 E3-GE-4, E3-OC3-ATM-4, E3-OC12-ATM-4, E5-CEC, E5-CEC-v2, SE-SEC, NP24-4x10GE,
NP24-40x1GE,
 NP40-40x1GE, NP40-4x10GE, NP40-8x10GE, NP40-2_20_COMBO, NP80-8x10GE, LC, E3-OC12-CH-1,
 E7-CEC,
 A9K-SIP-700
 Restart information:
 Default:
 parallel impacted processes restart

Component:
 cdp V[ci-39/9] Cisco Discovery Protocol (CDP)

File:
 cdp
 Card(s) : RP, DRP, LC, SC
 File type : Server
 Remotely-hosted : No
 Local view : /pkg/bin/cdp
 Local install path : /disk0/asr9k-base-3.9.0.14I/bin/cdp
 Central install path : /disk0/asr9k-base-3.9.0.14I/bin/cdp
```



The following example shows the message displayed if the specified process, component, or package is not active on a node:

```
RP/0/RSP0/CPU0:router# show install which file cdp location 0/1/CPU0
File cdp not active on node 0/6/CPU0
```

**Table 81: show install which Field Descriptions**

Field	Description
Package:	Name of the package that contains the file or component being described.
asr9k-base V3.8.0	Name and release number of the package.
Vendor	Name of the manufacturer.
Desc	Name of the package.
Build	Date and time the package was built.
Source	Source directory where the package was built.
Card(s)	Card types supported by the package.
Restart information	Restart impact on processes or nodes.
Component:	Component name and version number.
File:	Name of the of the process or DLL file that information is being specified for.
Card(s)	Supported card types on which the file can be used.
Local view	Generic directory path used to access the file on the nodes where it is used.
Local install path	Local directory path where the file is stored.
Central install path	Directory path where the file is stored on RP and SC nodes.

### Related Topics

- [show install active](#), on page 955
- [show install inactive](#), on page 964
- [show install log](#), on page 970
- [show install package](#), on page 975
- [show install request](#), on page 981
- [show install](#), on page 952

## show issu-warm-reload control-protocol trace

To display control protocol trace data about the ongoing process of an in-service software upgrade (ISSU), use the **show issu-warm-reload control-protocol trace** command in EXEC mode.

```
show issu-warm-reload control-protocol trace data-type type{all | error | information | packet}
[hexdump] [last n] [reverse] [stats] [tailf] [unique][verbose] [wrapping][file filename original]
```

### Syntax Description

<i>data-type</i>	The type of data to display. Valid options are: <ul style="list-style-type: none"> <li>• <b>all</b>—Displays all trace data.</li> <li>• <b>chdlc</b>—Displays Cisco High-Level Data Link Control (cHDLC) Serial Line Address Resolution Protocol (SLARP) data.</li> <li>• <b>control-io</b>—Displays control input-output (I/O) data.</li> <li>• <b>ipv6nd</b>—Displays IPv6 ND data.</li> <li>• <b>lACP</b>—Displays Link Aggregation Control Protocol (LACP) data.</li> <li>• <b>platform</b>—Displays platform data.</li> <li>• <b>ppp</b>—Displays PPP data.</li> </ul> all, chdlc, control-io, ipv6nd, lACP,
<b>type</b>	Specifies the format of trace data to display.
<b>all</b>	Displays error, information and packet traces.
<b>error</b>	Displays error traces.
<b>information</b>	Displays information traces.
<b>packet</b>	Displays packet traces.
<b>hexdump</b>	(Optional) Displays traces in hexadecimal format.
<b>last</b> <i>n</i>	(Optional) Displays the last <i>n</i> number of traces only.
<b>reverse</b>	(Optional) Displays the most recent traces first.
<b>stats</b>	(Optional) Displays execution path statistics.
<b>tailf</b>	(Optional) Displays new traces as they are added.
<b>unique</b>	(Optional) Displays unique entries only, along with the count of the number of times this entry appears.
<b>verbose</b>	(Optional) Displays additional internal debugging information.

<b>wrapping</b>	(Optional) Displays wrapping entries.
<b>file <i>filename</i> original</b>	(Optional) Specifies the filename of the file to display. You can specify up to four trace files.

**Command Default** None.

**Command Modes** EXEC

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 4.2.1	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **show issu-warm-reload control-protocol trace** command only provides information while the ISSU process is running. After the installation is complete, no information is provided.

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	system	read

# show zapdisk locations

To display location information where zapdisk operation is supported, use the **show zapdisk locations** command in EXEC mode.

## show zapdisk locations

This command has no keywords or arguments.

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	EXEC mode
----------------------	-----------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.0.1	This command was introduced.

<b>Usage Guidelines</b>	No specific guidelines impact the use of this command.
-------------------------	--------------------------------------------------------

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	diag	read

The following example shows sample output from the **show zapdisk locations** command:


```
RP/0/RSP0/CPU0:router# show context

0/RSP1 Fully qualified location specification
0/7 Fully qualified location specification
0/4 Fully qualified location specification
all all locations
```

# zapdisk start location

To erase data from the disk memory of RSPs and line cards, use the **zapdisk start location** command in EXEC mode.

```
zapdisk start location node-id
```

<b>Syntax Description</b>	<b>location</b> { <i>node-id</i>   <b>all</b> }	Specify the location string obtained from the <b>show zapdisk location</b> command. Zapdisk can be executed for specific node location or all node locations.
<b>Command Default</b>	Disabled.	
<b>Command Modes</b>	EXEC mode	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.0.1	This command was introduced.
<b>Usage Guidelines</b>	After the command is executed, the card is shut down. Do not reload the card.	
		
<b>Caution</b>	This command should not be used during normal operation of the router. The command should be used only when you have planned to delete the data from the card during return material authorization (RMA).	
<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	diag	read, write

The following example shows how to erase data from the line card location 0/4:

```
Router# zapdisk start location 0/4
Action on designated location is in progress, more detail logs will be located in sysadmin
at
/misc/disk1/tftpboot/zapdisk.log once action is completed
```

■ zapdisk start location



## Terminal Services Commands

---

This chapter describes the Cisco IOS XR commands used for setting up physical and virtual terminal connections, managing terminals, and configuring virtual terminal line (vty) pools. It also includes commands for the managing the Craft Panel Interface.

For detailed information about configuring physical and virtual terminals, see the *Implementing Physical and Virtual Terminals on Cisco IOS XR Software* module in *System Management Configuration Guide for Cisco ASR 9000 Series Routers*.

- [absolute-timeout](#), on page 997
- [access-class](#), on page 999
- [autocommand](#), on page 1001
- [banner exec](#), on page 1004
- [banner incoming](#), on page 1006
- [banner login](#), on page 1008
- [banner motd](#), on page 1010
- [banner prompt-timeout](#), on page 1012
- [clear line](#), on page 1014
- [clear line vty](#), on page 1015
- [cli interactive syntax check](#), on page 1016
- [cli whitespace completion](#), on page 1017
- [databits](#), on page 1018
- [disconnect](#), on page 1020
- [disconnect-character](#), on page 1021
- [escape-character](#), on page 1022
- [exec-timeout](#), on page 1024
- [flowcontrol hardware](#), on page 1026
- [lcd alarm-category](#), on page 1027
- [lcd message](#) , on page 1028
- [lcd name](#), on page 1029
- [length](#), on page 1030
- [line](#), on page 1031
- [parity](#), on page 1032
- [resume](#), on page 1033
- [send](#), on page 1035
- [session-limit](#), on page 1037

- [session-timeout](#), on page 1038
- [show diag lcd-interface](#), on page 1039
- [show line](#), on page 1040
- [show sessions](#), on page 1043
- [show terminal](#), on page 1045
- [show users](#), on page 1047
- [stopbits](#), on page 1049
- [terminal exec prompt](#), on page 1051
- [terminal exec utility pager](#), on page 1053
- [terminal length](#), on page 1054
- [terminal width](#), on page 1056
- [timestamp disable](#), on page 1057
- [transport input](#), on page 1058
- [transport output](#), on page 1060
- [transport preferred](#), on page 1062
- [vty-pool](#), on page 1064
- [width \(display\)](#), on page 1066



# absolute-timeout

To set the absolute timeout for line disconnection, use the **absolute-timeout** command in line template configuration mode. To remove the **absolute-timeout** command from the configuration file and restore the system to its default condition, use the **no** form of this command.

**absolute-timeout** *minutes*  
**no absolute-timeout** *minutes*

<b>Syntax Description</b>	<i>minutes</i> Absolute timeout interval, in minutes. Range is from 10 to 10000.
---------------------------	----------------------------------------------------------------------------------

<b>Command Default</b>	<i>minutes</i> : 1440
------------------------	-----------------------

<b>Command Modes</b>	Line template configuration
----------------------	-----------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.
	Release 5.0.0	This command was introduced.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

Use the **absolute-timeout** command to terminate the connection after the specified time has elapsed, regardless of whether the connection is being used at the time of termination. You can specify an absolute-timeout value for each port. The user is notified 20 seconds before the session is terminated.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	tty-access	read, write

The following example shows how to set the session timeout value to 2880 minutes (2 days) for the default line template:

```
RP/0/RSP0/CPU0:router(config)# line default
RP/0/RSP0/CPU0:router(config-line)# absolute-timeout 2880
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<a href="#">banner incoming, on page 1006</a>	Sets the idle wait timeout interval for user input over a physical terminal connection.

Command	Description
<a href="#">session-timeout, on page 1038</a>	Sets the idle wait timeout interval for user input over a virtual terminal connection.

# access-class

To restrict incoming and outgoing connections using an IPv4 or IPv6 access list, use the **access-class** command in line template configuration mode. To remove the restriction, use the **no** form of this command.

```
access-class list-name {in | out}
no accessclass list-name {in | out}
```

Syntax Description	
<i>list-name</i>	IPv4 or IPv6 access list name.
<b>in</b>	Filters incoming connections.
<b>out</b>	Filters outgoing connections.

**Command Default** No access class is set.

**Command Modes** Line template configuration

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **access-class** command to restrict incoming or outgoing connections to addresses defined in an access list. Use the **ipv4 access-list** or **ipv6 access-list** command to define an access list by name.



**Note** To restrict access of incoming or outgoing connections over IPv4 and IPv6, the IPv4 access list and IPv6 access list must share the same name.

Task ID	Task ID	Operations
	tty-access	read, write

The following example shows how to specify an access class assigned to outgoing connections for the default line template:

```
RP/0/RSP0/CPU0:router(config)# line default
RP/0/RSP0/CPU0:router(config-line)# access-class vtyacl out
```

The following sample output from the **show ipv4 access-lists** command displays the IPv4 access list named vtyacl:

```
RP/0/RSP0/CPU0:router# show ipv4 access-lists vtyacl

ipv4 access-list vtyacl
 10 permit ip host 10.32.162.48 any
 20 permit ip host 10.20.49.170 any
 30 permit ip host 10.60.3.5 any
```

The following sample output from the **show ipv6 access-lists** command displays the IPv6 access list name vtyacl:

```
RP/0/RSP0/CPU0:router# show ipv6 access-lists vtyacl

ipv6 access-list vtyacl
 10 permit ipv6 host 2001:db8:2222:: any
 20 permit ipv6 host 2001:db8:0:4::2 any
```

#### Related Commands

Command	Description
<b>ipv4 access-list</b>	Defines an IPv4 access list by name.
<b>ipv6 access-list</b>	Defines an IPv6 access list by name.

# autocommand

To automatically run one or more commands after a user logs in to a vty terminal session, use the **autocommand** command in line default or line template configuration mode. To remove the **autocommand** command from the configuration file and restore the system to its default condition, use the **no** form of this command.

**autocommand** *command*  
**no autocommand** *command*

## Syntax Description

*command* Command or command alias to be executed on user login to a vty session.

## Command Default

No default behavior or values

## Command Modes

Line template configuration  
 Line default configuration

## Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	No modification.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **autocommand** command to automatically run a command or command alias when a user logs in to a vty session. To run multiple commands, use a command alias for the *command* argument. When the user logs in, the commands included in the alias are run sequentially.



### Note

The **autocommand** command is supported on vty connections only; it is not supported on console or aux line connections. Use this command to automatically run a command after user login.

## Task ID

Task ID	Operations
tty-access	read, write

The following example shows how to use the **autocommand** command to automatically run the **show ip interface brief** command when a user logs in to a default vty session:

```
RP/0/RSP0/CPU0:router# configure terminal
RP/0/RSP0/CPU0:router(config)# line default
RP/0/RSP0/CPU0:router(config-line)# autocommand show ip interface brief
RP/0/RSP0/CPU0:router(config-line)# end
```

```

Uncommitted changes found, commit them before exiting(yes/no/cancel)? [cancel]:yes

RP/0/RSP0/CPU0:router# exit

<Your 'TELNET' connection has terminated>

```

The following example shows how the **show ip interface brief** command is automatically run when the user logs on to a vty session:

```

User Access Verification

Username: lab
Password:

Executing Autocommand 'show ip interface brief'
RP/0/RSP0/CPU0:router# show ip interface brief

Interface IP-Address Status Protocol
MgmtEth0/RP0/CPU0/0 172.16.0.0 Up Up
POS0/0/0/0 unassigned Up Up
POS0/0/0/1 unassigned Up Up
POS0/0/0/2 unassigned Up Up
POS0/0/0/3 unassigned Up Up
POS0/3/0/0 unassigned Up Up
POS0/3/0/1 unassigned Up Up
POS0/3/0/2 unassigned Up Up
POS0/3/0/3 unassigned Up Up

```

The following example shows how to disable the feature using the **no** form of the **autocommand** command. In this example, the autocommand for the **show ip interface brief** command is disabled. When the user logs out, and logs back in, the **autocommand** command does not run.

```

RP/0/RSP0/CPU0:router# configure terminal
RP/0/RSP0/CPU0:router(config)# line default
RP/0/RSP0/CPU0:router(config-line)# no autocommand ?

LINE Appropriate EXEC command

RP/0/RSP0/CPU0:router(config-line)# no autocommand show ip interface brief
RP/0/RSP0/CPU0:router(config-line)# end

Uncommitted changes found, commit them before exiting(yes/no/cancel)? [cancel]:yes

RP/0/RSP0/CPU0:router# exit

<Your 'TELNET' connection has terminated>

User Access Verification

Username: lab
Password:
RP/0/RSP0/CPU0:router#

```

The following example shows how to use a command alias with the **autocommand** command to run more than one command when a user logs in to a default vty session. In this example, the alias “test” is created to include the **show ip interface brief** command and the **show users** command. The autocommand feature is then used to run the “test” alias when a user logs in to the vty terminal:

```

RP/0/RSP0/CPU0:router# configure terminal
RP/0/RSP0/CPU0:router(config)# alias test show ip interface brief; show users
RP/0/RSP0/CPU0:router(config)# line default
RP/0/RSP0/CPU0:router(config-line)# autocommand test
RP/0/RSP0/CPU0:router(config-line)# end

Uncommitted changes found, commit them before exiting(yes/no/cancel)? [cancel]:yes

RP/0/RSP0/CPU0:router# exit

<Your 'TELNET' connection has terminated>

User Access Verification

Username: lab
Password:

Executing Autocommand 'test'
RP/0/RSP0/CPU0:router# test

RP/0/RSP0/CPU0:router# show ip interface brief

Interface IP-Address Status Protocol
MgmtEth0/RP0/CPU0/0 172.16.0.0 Up Up
POS0/0/0/0 unassigned Up Up
POS0/0/0/1 unassigned Up Up
POS0/0/0/2 unassigned Up Up
POS0/0/0/3 unassigned Up Up
POS0/3/0/0 unassigned Up Up
POS0/3/0/1 unassigned Up Up
POS0/3/0/2 unassigned Up Up
POS0/3/0/3 unassigned Up Up

RP/0/RSP0/CPU0:router# show users

 Line User Service Conns Idle Location
* vty0 lab telnet 0 00:00:00 172.16.0.0

```

# banner exec

To create a message that is displayed when an EXEC process is created (an EXEC banner), use the **banner exec** command in Global Configuration mode. To delete the EXEC banner, use the **no** form of this command.

```
banner exec delimiter message delimiter
no banner exec
```

## Syntax Description

*delimiter* Delimiting character is (c).

*message* Message text. Text may include tokens in the form  $\$( token )$  in the message text. Tokens are replaced with the corresponding configuration variable. Tokens are described in [Table 82: banner exec Tokens, on page 1004](#).

## Command Default

No EXEC banner is displayed.

## Command Modes

Global Configuration mode

## Command History

### Release

### Modification

Release 3.7.2

This command was introduced.

Release 3.9.0

No modification.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **banner exec** command to specify a message that is displayed when an EXEC process is created (a line is activated or an incoming connection is made to a vty). Follow this command with one or more blank spaces and the delimiting character (c). After entering one or more lines of text, terminate the message with the delimiting character (c).

When a user connects to a router, the message-of-the-day (MOTD) banner appears first, followed by the login banner and prompts. After the user logs in to the router, the EXEC banner or incoming banner is displayed, depending on the type of connection. For a reverse Telnet login, the incoming banner is displayed. For all other connections, the router displays the EXEC banner.

Use tokens in the form  $\$( token )$  in the message text to customize the banner. Tokens display current configuration variables, such as the router hostname and IP address.

The tokens are described in this table.

**Table 82: banner exec Tokens**

Token	Information Displayed in the Banner
$\$(hostname)$	Displays the hostname for the router.
$\$(domain)$	Displays the domain name for the router.



Token	Information Displayed in the Banner
<b>\$(line)</b>	Displays the vty or tty (asynchronous) line number.

**Task ID****Task ID    Operations**

tty-access read,  
write

The following example shows how to set an EXEC banner that uses tokens:

```
RP/0/RSP0/CPU0:router(config)# banner exec c
Enter TEXT message. End with the character 'c'.
THIS IS AN EXEC BANNER
c
```

**Related Commands**

Command	Description
<a href="#">banner incoming, on page 1006</a>	Defines and enables a customized message that is displayed when there is an incoming connection to a terminal line from a host on the network.
<a href="#">banner login, on page 1008</a>	Defines and enables a customized banner that is displayed before the username and password login prompts.
<a href="#">banner motd, on page 1010</a>	Defines a customized MOTD banner.
<a href="#">banner prompt-timeout, on page 1012</a>	Defines a customized banner that is displayed when there is a login timeout.

# banner incoming

To create a banner that is displayed when there is an incoming connection to a terminal line from a host on the network, use the **banner incoming** command in Global Configuration mode. To delete the incoming connection banner, use the **no** form of this command.

**banner incoming** *delimiter message delimiter*  
**no banner incoming**

<b>Syntax Description</b>	<p><i>delimiter</i> Delimiting character is (c).</p> <hr/> <p><i>message</i> Message text. You can include tokens in the form \$( <i>token</i> ) in the message text. Tokens are replaced with the corresponding configuration variable. Tokens are described in <a href="#">Table 83: banner incoming Tokens, on page 1007</a>.</p>						
<b>Command Default</b>	No incoming banner is displayed.						
<b>Command Modes</b>	Global Configuration mode						
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 3.7.2</td> <td>This command was introduced.</td> </tr> <tr> <td>Release 3.9.0</td> <td>No modification.</td> </tr> </tbody> </table>	Release	Modification	Release 3.7.2	This command was introduced.	Release 3.9.0	No modification.
Release	Modification						
Release 3.7.2	This command was introduced.						
Release 3.9.0	No modification.						
<b>Usage Guidelines</b>	<p>To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.</p> <p>Follow the <b>banner incoming</b> command with one or more blank spaces and the delimiting character (c). After entering one or more lines of text, terminate the message with the second occurrence of the delimiting character (c).</p> <p>An <i>incoming connection</i> is one initiated from the network side of the router. Incoming connections are also called reverse Telnet sessions. These sessions can display message-of-the-day (MOTD) banners and incoming banners, but they do not display EXEC banners.</p> <p>When a user connects to a router, the MOTD banner (if configured) appears first, followed by the login banner and prompts. After the user logs in to the router, the EXEC banner or incoming banner is displayed, depending on the type of connection. For a reverse Telnet login, the incoming banner is displayed. For all other connections, the router displays the EXEC banner.</p> <p>Incoming banners cannot be suppressed. If you do not want the incoming banner to appear, you must delete it with the <b>no banner incoming</b> command.</p> <p>To customize the banner, use tokens in the form \$(<i>token</i>) in the message text. Tokens display current variables, such as the router hostname and IP address.</p>						

This table describes the tokens.

**Table 83: banner incoming Tokens**

Token	Information Displayed in the Banner
<b>\$(hostname)</b>	Displays the hostname for the router.
<b>\$(domain)</b>	Displays the domain name for the router.
<b>\$(line)</b>	Displays the vty or tty (asynchronous) line number.

### Task ID

#### Task ID Operations

tty-access read,  
write

The following example shows how to create an incoming connection banner:

```
RP/0/RSP0/CPU0:router(config)# banner incoming c
Enter TEXT message. End with the character ^c
THIS IS AN INCOMING BANNER.
c
```

### Related Commands

Command	Description
<a href="#">banner exec, on page 1004</a>	Defines a customized banner that is displayed whenever the EXEC process is initiated.
<a href="#">banner login, on page 1008</a>	Defines and enables a customized banner that is displayed before the username and password login prompts.
<a href="#">banner motd, on page 1010</a>	Defines a customized MOTD banner.
<a href="#">banner prompt-timeout, on page 1012</a>	Defines a customized banner that is displayed when there is a login timeout.

# banner login

To create a customized banner that is displayed before the username and password login prompts, use the **banner login** command in Global Configuration mode. To disable the login banner, use **no** form of this command.

**banner login** *delimiter message delimiter*  
**no banner login**

<b>Syntax Description</b>	<i>delimiter</i> Delimiting character is (c).
	<i>message</i> Message text. You can include tokens in the form \$( <i>token</i> ) in the message text. Tokens are replaced with the corresponding configuration variable. Tokens are described in <a href="#">Table 84: banner login Tokens, on page 1008</a> .

**Command Default** No login banner is displayed.

**Command Modes** Global Configuration mode

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Follow the **banner login** command with one or more blank spaces and the delimiting character (c). Then enter one or more lines of text, terminating the message with the second occurrence of the delimiting character (c).

When a user connects to the router, the message-of-the-day (MOTD) banner (if configured) appears first, followed by the login banner and prompts. After the user successfully logs in to the router, the EXEC banner or incoming banner is displayed, depending on the type of connection. For a reverse Telnet login, the incoming banner is displayed. For all other connections, the router displays the EXEC banner.

To customize the banner, use tokens in the form \$( *token* ) in the message text. Tokens display current configuration variables, such as the router hostname and IP address.

Tokens are described in the this table.

**Table 84: banner login Tokens**

<b>Token</b>	<b>Information Displayed in the Banner</b>
<b>\$(hostname)</b>	Displays the hostname for the router.
<b>\$(domain)</b>	Displays the domain name for the router.
<b>\$(line)</b>	Displays the vty or tty (asynchronous) line number.

Task ID	Task ID	Operations
	tty-access	read, write

The following example shows how to set a login banner:

```
RP/0/RSP0/CPU0:router(config)# banner login c
Enter TEXT message. End with the character 'c'.
THIS IS A LOGIN BANNER
c
```

Related Commands	Command	Description
	<a href="#">banner exec, on page 1004</a>	Defines a customized banner that is displayed whenever the EXEC process is initiated.
	<a href="#">banner incoming, on page 1006</a>	Defines and enables a customized message that is displayed when there is an incoming connection to a terminal line from a host on the network.
	<a href="#">banner motd, on page 1010</a>	Defines a customized MOTD banner.
	<a href="#">banner prompt-timeout, on page 1012</a>	Defines a customized banner that is displayed when there is a login timeout.

# banner motd

To create a message-of-the-day (MOTD) banner, use the **banner motd** command in Global Configuration mode. To delete the MOTD banner, use the **no** form of this command.

```
banner motd delimiter message delimiter
no banner motd
```

## Syntax Description

*delimiter* Delimiting character is (c).

*message* Message text. You can include tokens in the form \$( *token* ) in the message text. Tokens are replaced with the corresponding configuration variable.

## Command Default

No MOTD banner is displayed.

## Command Modes

Global Configuration mode

## Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	No modification.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Follow this command with one or more blank spaces and the delimiting character (c). Then enter one or more lines of text, terminating the message with the second occurrence of the delimiting character (c).

This MOTD banner is displayed to all terminals connected and is useful for sending messages that affect all users (such as impending system shutdowns). Use the **no banner motd** command to disable the MOTD banner on a line.

When a user connects to the router, the MOTD banner (if configured) appears first, followed by the login banner and prompts. After the user successfully logs in to the router, the EXEC banner or incoming banner is displayed, depending on the type of connection. For a reverse Telnet login, the incoming banner is displayed. For all other connections, the router displays the EXEC banner.

To customize the banner, use tokens in the form \$(token) in the message text. Tokens display current configuration variables, such as the router hostname and IP address.

Tokens are described in this table.

**Table 85: banner motd Tokens**

Token	Information Displayed in the Banner
\$(hostname)	Displays the hostname for the router.
\$(domain)	Displays the domain name for the router.

Token	Information Displayed in the Banner
\$(line)	Displays the vty or tty (asynchronous) line number.

**Task ID****Task ID Operations**

tty-access read,  
write

The following example shows how to configure an MOTD banner with a token:

```
RP/0/RSP0/CPU0:router(config)# banner motd c
```

```
Enter TEXT message. End with the character 'c'.
```

```
Notice: all routers in $(domain) will be upgraded beginning April 20
c
```

**Related Commands**

Command	Description
<a href="#">banner exec, on page 1004</a>	Defines and enables a customized banner that is displayed whenever the EXEC process is initiated.
<a href="#">banner incoming, on page 1006</a>	Defines and enables a customized message that is displayed when there is an incoming connection to a terminal line from a host on the network.
<a href="#">banner login, on page 1008</a>	Defines and enables a customized banner that is displayed before the username and password login prompts.
<a href="#">banner prompt-timeout, on page 1012</a>	Defines a customized banner that is displayed when there is a login timeout.

# banner prompt-timeout

To create a banner that is displayed when there is a login authentication timeout, use the **banner prompt-timeout** command in Global Configuration mode. To delete the prompt timeout banner, use the **no banner prompt-timeout** form of this command.

**banner prompt-timeout** *delimiter message delimiter*  
**no banner prompt-timeout**

## Syntax Description

*delimiter* Delimiting character is (c).

*message* Message text. You can include tokens in the form  $\$(token)$  in the message text. Tokens are replaced with the corresponding configuration variable.

## Command Default

No banner is displayed when there is a login authentication timeout.

## Command Modes

Global Configuration mode

## Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	No modification.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Follow this command with one or more blank spaces and the delimiting character (c). Then enter one or more lines of text, terminating the message with the second occurrence of the delimiting character (c).

This prompt-timeout banner is displayed when there is a login authentication timeout at the username and password prompt.

## Task ID

### Task ID Operations

tty-access read,  
write

The following example shows how to configure a prompt-timeout banner:

```
RP/0/RSP0/CPU0:router(config)# banner prompt-timeout c
Enter TEXT message. End with the character 'c'.
THIS IS A PROMPT TIMEOUT BANNER
c
```



**Related Commands**

Command	Description
<a href="#">banner exec, on page 1004</a>	Defines and enables a customized banner that is displayed whenever the EXEC process is initiated.
<a href="#">banner incoming, on page 1006</a>	Defines and enables a customized message that is displayed when there is an incoming connection to a terminal line from a host on the network.
<a href="#">banner login, on page 1008</a>	Defines and enables a customized banner that is displayed before the username and password login prompts.
<a href="#">banner motd, on page 1010</a>	Defines a customized MOTD banner.

# clear line

To clear an auxiliary or console line to an idle state, use the **clear line** command in EXEC mode.

```
clear line {aux | console} location node-id
```

Syntax Description	Parameter	Description
	<b>aux</b>	Clears the auxiliary line.
	<b>console</b>	Clears the console line.
	<b>location</b> <i>node-id</i>	Specifies the location of a route processor (RP) where the auxiliary or console line to be cleared resides. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.

**Command Default** None

**Command Modes** EXEC mode

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	tty-access	execute

The following example shows how to clear the console line, putting it in an idle state:

```
RP/0/RSP0/CPU0:router# clear line console location 0/RP1/CPU0
```

Related Commands	Command	Description
	<a href="#">show users, on page 1047</a>	Displays information about the active lines on the networking device.

# clear line vty

To clear a virtual terminal line (vty) to an idle state, use the **clear line vty** command in EXEC mode.

**clear line vty** *line-number*

<b>Syntax Description</b>	<i>line-number</i> Line number in the range from 0 to 99.
---------------------------	-----------------------------------------------------------

<b>Command Default</b>	No default behavior or values
------------------------	-------------------------------

<b>Command Modes</b>	EXEC mode
----------------------	-----------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.2	This command was introduced.
Release 3.9.0	No modification.	

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

Use the **show users** command to determine the origin of the connection and which lines to clear. When a line is cleared to an idle state, the user on the other end of the connection receives notice that the connection was closed by a foreign host.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	tty-access	execute

The following example shows how to reset vty 3 to the idle state:

```
RP/0/RSP0/CPU0:router# clear line vty 3
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<a href="#">show users, on page 1047</a>	Displays information about the active lines on the networking device.

# cli interactive syntax check

To enable interactive syntax checking, use the **cli interactive syntax check** command in the appropriate line configuration mode. To disable interactive syntax checking, use the **no** form of this command.

**cli interactive syntax check**  
**no cli interactive syntax check**

**Syntax Description** This command has no keywords or arguments.

**Command Default** Interactive syntax checking is disabled.

**Command Modes** Line console configuration  
 Line default configuration  
 Line template configuration

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **cli interactive syntax check** command to check command syntax as you type. You are not allowed to enter incorrect syntax.

Task ID	Task ID	Operations
	tty-access	read, write

The following example shows how to enable interactive syntax checking:

```
RP/0/RSP0/CPU0:router(config)# line console
RP/0/RSP0/CPU0:router(config-line)# cli interactive syntax check
```

## Related Commands

Command	Description
<a href="#">cli whitespace completion, on page 1017</a>	Enables completion of a command when you type the space key.

# cli whitespace completion

To enable completion of a command when you type the space key, use the **cli whitespace completion** command in the appropriate line configuration mode. To disable whitespace completion, use the **no** form of this command.

**cli whitespace completion**  
**no cli whitespace completion**

**Syntax Description** This command has no keywords or arguments.

**Command Default** Whitespace completion is disabled.

**Command Modes** Line console configuration  
 Line default configuration  
 Line template configuration

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **cli whitespace completion** command to complete the next word of the command syntax if you type the space key before completing the word. If more than one option is valid, all options are displayed for you to choose one.

Task ID	Task ID	Operations
	tty-access	read, write

The following example shows how to enable whitespace completion:

```
RP/0/RSP0/CPU0:router(config)# line console
RP/0/RSP0/CPU0:router(config-line)# cli whitespace completion
```

Related Commands	Command	Description
	<a href="#">cli interactive syntax check, on page 1016</a>	Enables interactive syntax checking.

# databits

To set the data bits per character for physical terminal connections, use the **databits** command in line console configuration mode. To restore the default value, use the **no** form of this command.

**databits** {**5** | **6** | **7** | **8**}  
**no databits**

## Syntax Description

- 5** Sets the data bits per character to 5.
- 6** Sets the data bits per character to 6.
- 7** Sets the data bits per character to 7.
- 8** Sets the data bits per character to 8.

## Command Default

Eight databits per character.

## Command Modes

Line console configuration

## Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	No modification.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **databits** command to set the data bits attributes for physical terminal connections. Physical terminal connections use either the console or auxiliary line template.

The **databits** command masks the high bit on input from devices that generate 7 data bits with parity. If parity is being generated, specify 7 data bits per character. If no parity generation is in effect, specify 8 data bits per character. The keywords **5** and **6** are supplied for compatibility with older devices and generally are not used.

## Task ID

Task ID	Operations
tty-access	read, write

The following example shows how to set the data bits per character for the console terminal template to 7:

```
RP/0/RSP0/CPU0:router(config)# line console
RP/0/RSP0/CPU0:router(config-line)# databits 7
```

**Related Commands**

Command	Description
<a href="#">show users, on page 1047</a>	Displays information about the active lines on the networking device.
<a href="#">stopbits, on page 1049</a>	Sets the number of stop bits.

# disconnect

To disconnect a network connection, use the **disconnect** command in EXEC mode.

**disconnect** [*connection-number* *network-name*]

Syntax Description	
<i>connection-number</i>	(Optional) Number of the line of the active network connection to be disconnected. Range is from 1 to 20.
<i>network-name</i>	(Optional) Name of the active network connection to be disconnected.

**Command Modes** EXEC mode

**Command Default** Disconnects the existing network connection if no arguments are provided.

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** Do not disconnect a line to end a session. Instead, log off the host before ending the session to clear the connection. If you cannot log out of an active session, disconnect the line.

Task ID	Task ID	Operations
	tty-access	read, write

The following example shows how to disconnect from a device (in this example “User1”) to return to the router:

```
User1% disconnect
Connection closed by remote host

RP/0/RSP0/CPU0:router#
```



# disconnect-character

To define a character to disconnect a session, use the **disconnect-character** command in line template configuration mode. To remove the **disconnect-character** command from the configuration file and restore the system to its default condition, use the **no** form of this command.

```
disconnect-character [{numbercharacter}]
no disconnect-character
```

<b>Syntax Description</b>	<i>number</i> (Optional) ASCII decimal equivalent of the disconnect character. Range is from 0 through 255.
	<i>character</i> (Optional) Disconnect character.

**Command Default** No disconnect character is defined.

**Command Modes** Line template configuration

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The break character is represented by 0; null cannot be represented.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	tty-access	read, write

The following example shows how to set the disconnect character for the default line template to the Esc character, which is the ASCII decimal equivalent 27:

```
RP/0/RSP0/CPU0:router(config)# line default
RP/0/RSP0/CPU0:router(config-line)# disconnect-character 27
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<a href="#">escape-character, on page 1022</a>	Defines an escape character.

# escape-character

To define a character to escape a session, use the **escape-character** command in line template configuration mode. To remove the **escape-character** command from the configuration file and restore the system to its default condition, use the **no** form of this command.

```
escape-character {breaknumbercharacter | default | none}
no escape-character
```

Syntax Description	
<b>break</b>	Sets the escape character to the Break key.
<i>number</i>	ASCII decimal equivalent of the escape character. Range is from 0 through 255.
<i>character</i>	Escape character.
<b>default</b>	Specifies the default escape character (^X).
<b>none</b>	Disables the escape function.

**Command Default** The default escape character is ^X.

**Command Modes** Line template configuration

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **escape-character** command to define an escape character sequence that is different from the default. Use the escape character to exit from an existing connection and return to the EXEC prompt.

The default escape key sequence is Ctrl-Shift-6, X (^X). The **escape-character** command with the **default** keyword sets the escape character to the Break key (the default setting for the Break key is Ctrl-C).

Task ID	Task ID	Operations
	tty-access	read, write

The following example shows how to set the escape character for the default line template to Ctrl-P, which is the ASCII decimal character 16:

```
RP/0/RSP0/CPU0:router(config)# line default
RP/0/RSP0/CPU0:router(config-line)# escape-character 16
```

**Related Commands**

Command	Description
<a href="#">disconnect-character, on page 1021</a>	Defines a disconnect character.

# exec-timeout

To set the interval that the EXEC command interpreter waits until user input is detected, use the **exec-timeout** command in the appropriate line configuration mode. To remove the **exec-timeout** command from the running configuration and restore the system to its default condition, use the **no** form of this command.

**exec-timeout** *minutes seconds*

**no exec-timeout** *minutes seconds*

<b>Syntax Description</b>	<i>minutes</i> Minutes for the wait interval. Range is from 0 to 35791.
	<i>seconds</i> Seconds for the wait interval. Range is from 0 to 2147483.

<b>Command Default</b>	<i>minutes</i> : 10
	<i>seconds</i> : 0

<b>Command Modes</b>	Line console configuration
	Line default configuration
	Line template configuration

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

If no input is detected during the interval, the EXEC facility resumes the current connection. If no connections exist, the EXEC facility returns the terminal to the idle state and disconnects the incoming session. To disable the EXEC timeout function so that the EXEC session never timeouts, enter the following command:

```
exec-timeout 00
```

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	tty-access	read, write

The following example shows how to set the timeout interval for the console line template to 60 minutes, 0 seconds:

```
RP/0/RSP0/CPU0:router(config)# line console
RP/0/RSP0/CPU0:router(config-line)# exec-timeout 60 0
```

**Related Commands**

<b>Command</b>	<b>Description</b>
<a href="#">absolute-timeout, on page 997</a>	Sets the absolute timeout for line disconnection.
<a href="#">session-timeout, on page 1038</a>	Sets the idle wait timeout interval for user input over a virtual terminal connection.

# flowcontrol hardware

To configure the hardware flow control setting for physical terminal connections, use the **flowcontrol hardware** command in line console configuration mode. To remove the attribute from the configuration file and restore the system to its default condition, use the **no** form of this command.

```
flowcontrol hardware {in | out | none}
no flowcontrol hardware {in | out | none}
```

<b>Syntax Description</b>	<b>in</b> Specifies inbound flow control.						
	<b>out</b> Specifies outbound flow control.						
	<b>none</b> Specifies no flow control.						
<b>Command Default</b>	None						
<b>Command Modes</b>	Line console configuration						
<b>Command History</b>	<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;">Release</th> <th style="text-align: left;">Modification</th> </tr> </thead> <tbody> <tr> <td>Release 3.7.2</td> <td>This command was introduced.</td> </tr> <tr> <td>Release 3.9.0</td> <td>No modification.</td> </tr> </tbody> </table>	Release	Modification	Release 3.7.2	This command was introduced.	Release 3.9.0	No modification.
Release	Modification						
Release 3.7.2	This command was introduced.						
Release 3.9.0	No modification.						
<b>Usage Guidelines</b>	<p>To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.</p> <p>Use the <b>flowcontrol hardware</b> command to set the flow control attribute for physical line connections. Physical line connections use either the console or auxiliary line template.</p>						
<b>Task ID</b>	<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;">Task ID</th> <th style="text-align: left;">Operations</th> </tr> </thead> <tbody> <tr> <td>tty-access</td> <td>read, write</td> </tr> </tbody> </table>	Task ID	Operations	tty-access	read, write		
Task ID	Operations						
tty-access	read, write						
<b>Related Commands</b>	<p>The following example shows how to restrict the hardware flow control to inbound for the console line template:</p> <pre>RP/0/RSP0/CPU0:router(config)# line console RP/0/RSP0/CPU0:router(config-line)# flowcontrol hardware in</pre> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;">Command</th> <th style="text-align: left;">Description</th> </tr> </thead> <tbody> <tr> <td><a href="#">show users, on page 1047</a></td> <td>Displays information about the active lines on the networking device.</td> </tr> </tbody> </table>	Command	Description	<a href="#">show users, on page 1047</a>	Displays information about the active lines on the networking device.		
Command	Description						
<a href="#">show users, on page 1047</a>	Displays information about the active lines on the networking device.						

# lcd alarm-category

To set the alarm-category (will get displayed on the LCD panel), use the **lcd alarm-category** command in the appropriate mode. To delete the set category, use the **no** form of the command.

**lcd alarm-category** *number*  
**no lcd alarm-category** *number*

<b>Syntax Description</b>	<p><i>number</i> Number to identify the alarm category. This lists indicates the numbers for classification:</p> <ul style="list-style-type: none"> <li>• 1 for critical</li> <li>• 2 for critical and major</li> <li>• 3 for critical, major and minor</li> <li>• 0 for other</li> </ul>
---------------------------	-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Global configuration
----------------------	----------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 6.1.2	This command was introduced.

<b>Usage Guidelines</b>	None
-------------------------	------

## Example

This example show how to use the **lcd alarm-category** command:

```
RP/0/RSP0/CPU0:router (config) # lcd alarm-category 2
```

# lcd message

To set administrative messages (will get displayed on the LCD panel), use the **lcd message** command in the appropriate mode. To delete the set message, use the **no** form of the command.

**lcd message** *message*

<b>Syntax Description</b>	<i>message</i> Administrative message for the operator. Limit is 512 alphanumeric characters.
---------------------------	-----------------------------------------------------------------------------------------------

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Global configuration
----------------------	----------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 6.1.2	This command was introduced.

<b>Usage Guidelines</b>	None
-------------------------	------

## Example

This example show how to use the **lcd message** command:

```
RP/0/RSP0/CPU0:router (config) # lcd message abcd
```



# lcd name

To set the rack-name (will get displayed on the LCD panel), use the **lcd name** command in the appropriate mode. To delete the set name, use the **no** form of the command.

**lcd name** *rack-name location*

<b>Syntax Description</b>	<i>rack-name</i>	The rack-name. Limit is 15 alphanumeric characters.
	<i>location</i>	The location of the rack (rack-id).

**Command Default** None

**Command Modes** Global configuration

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 6.1.2	This command was introduced.

**Usage Guidelines** None

## Example

This example show how to use the **lcd name** command:

```
RP/0/RSP0/CPU0:router (config) # lcd name lc1
```

# length

To set the number of lines that display at one time on the screen, use the **length** command in line template configuration mode. To remove the **length** command from the configuration file and restore the system to its default condition, use the **no** form of this command.

**length** *lines*  
**no length** *lines*

<b>Syntax Description</b>	<i>lines</i> Number of lines that displays on a screen. Range is from 0 through 512. 0 specifies no pausing. The default is 24.
---------------------------	---------------------------------------------------------------------------------------------------------------------------------

<b>Command Default</b>	<i>lines</i> : 24
------------------------	-------------------

<b>Command Modes</b>	Line template configuration
----------------------	-----------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

Use the **length** command to modify the default length setting for the specified line template. The length setting determines when the screen pauses during the display of multiple-screen output. Specifying a value of 0 for the lines argument prevents the router from pausing between screens of output.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	tty-access	read, write

The following example shows how to set the length of the default line template to 33 lines:

```
RP/0/RSP0/CPU0:router(config)# line default
RP/0/RSP0/CPU0:router(config-line)# length 33
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<a href="#">terminal length, on page 1054</a>	Sets the length of the display terminal for the current terminal session.

# line

To specify the console, the default, or a user-defined line template and enter line template configuration mode, use the **line** command in

global configuration

mode.

**line** {**console** | **default** | **template** *template-name*}

Syntax Description		
	<b>console</b>	Specifies the line template for the console line.
	<b>default</b>	Specifies the default line template.
	<b>template</b> <i>template-name</i>	Specifies a user-defined line template to be applied to a vty pool.

**Command Default** None

**Command Modes** Global configuration

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** Use the **line** command to specify a line template type and enter into line template configuration mode. Line templates are a collection of attributes used to configure and manage physical terminal line connections (the console and auxiliary ports) and vty connections. The following templates are available in Cisco IOS XR software:

- Default line template—The default line template that applies to a physical and virtual terminal lines.
- Console line template—The line template that applies to the console line.
- User-defined line templates—User-defined line templates that can be applied to a range of virtual terminal lines.

The following example shows how to enter line template configuration mode to allow configuration changes to be made to the default line template:

```
RP/0/RSP0/CPU0:router(config)# line default
RP/0/RSP0/CPU0:router(config-line)#
```

# parity

To set the parity bit for physical terminal connections, use the **parity** command in line console configuration mode. To specify no parity, use the **no** form of this command.

```
parity {even | none | odd}
no parity {even | none | odd}
```

## Syntax Description

**even** Specifies even parity.

**none** Specifies no parity.

**odd** Specifies odd parity.

## Command Default

No parity is set.

## Command Modes

Line console configuration

## Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	No modification.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Communication protocols provided by devices such as terminals and modems often require a specific parity bit setting.

Use the **parity** command for setting the parity attribute for physical terminal connections. Physical terminal connections use either the console or auxiliary line template.

## Task ID

### Task ID Operations

tty-access read,  
write

The following example shows how to set the line parity configuration to even for the console line template:

```
RP/0/RSP0/CPU0:router(config)# line console
RP/0/RSP0/CPU0:router(config-line)# parity even
```

## Related Commands

Command	Description
<a href="#">show users, on page 1047</a>	Displays information about the active lines on the networking device.

# resume

To switch to another active Secure Shell (SSH) or Telnet session, use the **resume** command in

EXEC

mode.

**resume** [*connection*]

## Syntax Description

*connection* (Optional) Name or number of the active network connection; the default is the most recent connection. Number range is from 1 to 20.

## Command Default

The most recent connection.

## Command Modes

EXEC

## Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	No modification.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

SSH and Telnet sessions can be established to another router or server.

When the network session is being established and without disconnecting the network session, you can resume the router console session by typing a special sequence of characters as shown. After switching back to the router console, the network connection can be resumed by specifying the number of the connection or the name of the connection.

You can have several concurrent sessions open and switch back and forth between them. The number of sessions that can be open is defined using the **session-limit** command.

You can switch between sessions by escaping one session and resuming a previously opened session, as follows:

1. Escape from the current session by pressing the escape sequence (Ctrl Shift-6, x [^^X]) to return to the EXEC prompt.
2. Enter the **show sessions** command to list the open sessions. All open sessions associated with the current terminal line are displayed.
3. Enter the **resume** command and the session number to make the connection.

You can also resume the previous session by pressing the **Return** key.

The ^^X and commands are available for all supported connection protocols.

Task ID	Task ID	Operations
	tty-access	read, write

The following example shows how to escape from one connection and resume another. You can omit the connection name and simply enter the connection number to resume that connection.

```
host1% ^^X
RP/0/RSP0/CPU0:router# resume 1

blg_router#
```

#### Related Commands

Command	Description
<a href="#">session-limit, on page 1037</a>	Sets the maximum number of outgoing terminal sessions from the current terminal.
<a href="#">show sessions, on page 1043</a>	Displays information about SSH and Telnet connections.
<b>telnet</b>	Logs in to a host that supports Telnet.

# send

To send messages to one or all terminal lines, use the **send** command in

EXEC

mode.

```
send {*line-number | aux 0 | console 0 | vty number}
```

## Syntax Description

<b>*</b>	Sends a message to all tty lines.
<i>line-number</i>	Line number to which the message is sent. A number from 0 to 101.
<b>aux 0</b>	Sends a message to the auxiliary line.
<b>console 0</b>	Sends a message to the console line.
<b>vty number</b>	Sends a message to a virtual terminal line (vty). Range is 0 to 99.

## Command Default

None

## Command Modes

EXEC

## Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	No modification.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The system prompts for the message, which can be up to 500 characters long. Enter **Ctrl-Z** to end the message. Enter **Ctrl-C** to abort this command.

## Task ID

Task ID	Operations
tty-access	read, write

The following example shows how to send a message to all lines:

```
RP/0/RSP0/CPU0:router# send *

Enter message, end with CTRL/Z; abort with CTRL/C:
The system will be shut down in 10 minutes for repairs.^Z
Send message? [confirm]
RP/0/RSP0/CPU0:router#
```

```


*** Message from tty to all terminals:

The system will be shut down in 10 minutes for repairs.
```



# session-limit

To set the maximum number of outgoing terminal sessions from the current terminal, use the **session-limit** command in the appropriate line configuration mode. To remove any specified session limit, use the **no** form of this command.

**session-limit** *connections*  
**no session-limit**

<b>Syntax Description</b>	<i>connections</i> Maximum number of outgoing connections. Range is from 0 through 20.
---------------------------	----------------------------------------------------------------------------------------

<b>Command Default</b>	<i>connections</i> : 6
------------------------	------------------------

<b>Command Modes</b>	Line console configuration Line default configuration Line template configuration
----------------------	-----------------------------------------------------------------------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	tty-access	read, write

The following example shows how to limit the number of active outgoing connections for the default line template to eight:

```
RP/0/RSP0/CPU0:router(config)# line default
RP/0/RSP0/CPU0:router(config-line)# session-limit 8
```

# session-timeout

To set the timeout interval for all outgoing connections from the current terminal, use the **session-timeout** command in the appropriate line configuration mode. To remove the **session-timeout** command from the configuration file and restore the system to its default condition, use the **no** form of this command.

**session-timeout** *minutes* [**output**]  
**no session-timeout** *minutes*

<b>Syntax Description</b>	<i>minutes</i> Timeout interval, in minutes. Range is 0 to 35791. The default is 10.						
	<b>output</b> (Optional) Specifies that when traffic is sent to an asynchronous line from the router (within the specified interval), the connection is retained.						
<b>Command Default</b>	<i>minutes</i> : 10						
<b>Command Modes</b>	Line console configuration Line default configuration Line template configuration						
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 3.7.2</td> <td>This command was introduced.</td> </tr> <tr> <td>Release 3.9.0</td> <td>No modification.</td> </tr> </tbody> </table>	Release	Modification	Release 3.7.2	This command was introduced.	Release 3.9.0	No modification.
Release	Modification						
Release 3.7.2	This command was introduced.						
Release 3.9.0	No modification.						
<b>Usage Guidelines</b>	<p>To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.</p> <p>Use the <b>session-timeout</b> command to set the interval that Cisco IOS XR software waits for traffic before closing the connection to a remote device and returning the terminal to an idle state. If the <b>output</b> keyword is not specified, the session timeout interval is based solely on detected input from the user. If the keyword is specified, the interval is based on input and output traffic.</p>						
<b>Task ID</b>	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operations</th> </tr> </thead> <tbody> <tr> <td>tty-access</td> <td>read, write</td> </tr> </tbody> </table>	Task ID	Operations	tty-access	read, write		
Task ID	Operations						
tty-access	read, write						

The following example shows how to set the session timeout value for the default line template to 120 minutes (2 hours):

```
RP/0/RSP0/CPU0:router(config)# line default
RP/0/RSP0/CPU0:router(config-line)# session-timeout 120
```

# show diag lcd-interface

To display details about the LCD interface (of the craft panel) , use the **show diag lcd-interface** command in the appropriate mode.

## show diag lcd-interface

**Syntax Description** This command has no keywords or arguments.

**Command Default** None

**Command Modes** EXEC

Command History	Release	Modification
	Release 5.2.1	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operation
	lcd	read

## Example

This example shows how to use the **show diag lcd-interface**

```
RP/0/RSP0/CPU0:router # show diag location 0/CI0
```

```
Diag Information For : 0/CI0
```

```
0/CI0-IDPROM Info
 Controller Family : 0084
 Controller Type : 0932
 PID : NCS4K-CRAFT
 Version Identifier : V00
 UDI Description : NCS 4000 Craft Panel
 CLEI Code : NOCLEICODE
 ECI Number : 11223344
 Top Assy. Part Number : 800-41609-01
 Top Assy. Revision : 12
 PCB Serial Number : SAL1818RL2G
 PCA Number : 73-14799-03
```

# show line

To display the parameters of terminal lines, use the **show line** command in

EXEC

mode.

**show line** [{aux location *node-id* | console location *node-id* | vty *number*}]

Syntax Description		
<b>aux</b>	(Optional) Displays the terminal line parameters for the auxiliary line.	
<b>location</b> <i>node-id</i>	(Optional) Specifies the location for the route processor (RP) on which the auxiliary or console port resides. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.	
<b>console</b>	(Optional) Displays the terminal line parameters for the console line.	
<b>vty</b> <i>number</i>	(Optional) Specifies a virtual terminal line (vty) number. Range is from 0 through 99.	

**Command Default** None

**Command Modes** EXEC

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	tty-access	read

The following example shows sample output from the **show line** command. The asterisk (*) indicates the current terminal session.

```
RP/0/RSP0/CPU0:router# show line

 Tty Speed Modem Uses Noise Overruns Acc I/O
 aux0_0_0 9600 - - - 0/0 -/-
 * con0_0_0 9600 - - - 0/0 -/-
 vty0 0/0 - - - 0/0 -/-
```

```

vty1 0/0 - - - 0/0 -/-
vty2 0/0 - - - 0/0 -/-
vty3 0/0 - - - 0/0 -/-
vty4 0/0 - - - 0/0 -/-
vty100 0/0 - - - 0/0 -/-
vty101 0/0 - - - 0/0 -/-
vty102 0/0 - - - 0/0 -/-
vty103 0/0 - - - 0/0 -/-
vty104 0/0 - - - 0/0 -/-
vty105 0/0 - - - 0/0 -/-

```

**Table 86: show line Field Descriptions**

Field	Description
Tty	Available ttys and vtys.
Speed	Baud rate that the inbound serial connection is using, in bps.
Modem	Not implemented.
Uses	Not implemented.
Noise	Not implemented.
Overruns	Hardware Universal Asynchronous Receiver/Transmitter (UART) overruns or software buffer overflows, both defined as the number of overruns or overflows that have occurred on the specified line since the system was restarted. Hardware overruns are buffer overruns; the UART chip has received bits from the software faster than it can process them. A software overflow occurs when the software has received bits from the hardware faster than it can process them.
Acc I/O	Not implemented.

The following example shows sample output from the **show line** command with the console line specified:

```

RP/0/RSP0/CPU0:router# show line console location 0/rp0/cpu0

 Tty Speed Overruns Acc I/O
con0/RP0/CPU0 9600 0/0 -/-

Line con0_RP0_CPU0, Location "0/RP0/CPU0", Type "Console"
Length: 24 lines, Width: 80 columns
Baud rate (TX/RX) is 9600, 1 parity, 2 stopbits, 8 databits
Template: console
Capabilities: Timestamp Disabled
Allowed transports are none.

```

**Table 87: show line location Field Descriptions**

Field	Description
Tty	Unique identifier of the tty; it contains the type of tty and, for physical ttys, it indicates the physical location of the tty.
Speed	Baud rate that the inbound serial connection is using in bps.

Field	Description
Overruns	Hardware UART overruns or software buffer overflows, both defined as the number of overruns or overflows that have occurred on the specified line since the system was restarted. Hardware overruns are buffer overruns; the UART chip has received bits from the software faster than it can process them. A software overflow occurs when the software has received bits from the hardware faster than it can process them.
Acc I/O	Not implemented.
Line	Unique identifier of the TTY. This field displays the type of TTY and the physical location of physical TTYs.
Location	Location of the line.
Type	Line type.
Length	Length of the terminal or screen display, in rows.
Width	Width of the terminal or screen display, in columns.
Baud rate (TX/RX)	Transmit rate/receive rate of the line, in bps.
parity	Parity bits value used for physical terminal connections.
stopbits	Stop bits value used for physical terminal connections.
databits	Data bits value used for physical terminal connections.
Template	Line template being sourced by the particular connection.
Config	Configuration applied to the tty. This field indicates the allowed incoming transports that can be used to access the router from this tty.
Allowed transports are	Incoming transport protocols that can be used by this tty to access the router.

# show sessions

To display information about suspended Secure Shell (SSH) and Telnet connections launched from the terminal session, use the **show sessions** command in

EXEC

mode.

## show sessions

**Syntax Description** This command has no keywords or arguments.

**Command Default** None

**Command Modes** EXEC

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **show sessions** command to display the hostname, remote connection service used by the router to access the host, idle time, and connection name.

Task ID	Task ID	Operations
	tty-access	read

The following example shows sample output from the **show sessions** command:

```
RP/0/RSP0/CPU0:router# show sessions

Conn Host Address Service Idle Conn Name
* 1 10.26.25.40 10.26.25.40 telnet 15 10.26.25.40
```

The asterisk (*) indicates the current terminal session.

**Table 88: show sessions Field Descriptions**

Field	Description
Conn	Identifier for the connection used for resuming and disconnecting suspended sessions. An asterisk (*) indicates the current terminal session.

Field	Description
Host	Remote host to which the router is connected. This field displays either the IP address or hostname of the remote host. If the IP address of the remote host is mapped to the hostname (that is, if Domain Name System [DNS] services are enabled) and the session is initiated with the hostname, the output for this field displays the hostname of the host rather than the IP address of the host.
Address	IP address of the remote host.
Service	Remote connection service used.
Idle	Interval (in seconds) since data was last sent on the line.
Conn Name	Equivalent to the “Host” field in Cisco IOS XR software.

**Related Commands**

Command	Description
<a href="#">disconnect, on page 1020</a>	Disconnects a network connection.
<a href="#">resume, on page 1033</a>	Switches to another active Telnet session.



# show terminal

To obtain information about the terminal configuration attribute settings for the current terminal line, use the **show terminal** command in

EXEC

mode.

**show terminal**

**Syntax Description** This command has no keywords or arguments.

**Command Default** None

**Command Modes** EXEC

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** None.

This example shows sample output from the **show terminal** command:

```
RP/0/RSP0/CPU0:router# show terminal

Line vty0, Location "10.56.249.67", Type "VTY"
Length: 24 lines, Width: 80 columns
Baud rate (TX/RX) is 0, 0 parity, 0 stopbits, 0 databits
Template: default
Capabilities: Timestamp Disabled
Allowed transports are telnet ssh.
```

**Table 89: show terminal Field Descriptions**

Field	Description
Line	Line that is currently being used.
Location	Location of the terminal accessing the router.
Type	Type of line.
Length	Length of the terminal or screen display, in rows.
Width	Width of the terminal or screen display, in columns.
Baud rate (TX/RX)	Transmit or receive rate of the line, in bps.

<b>Field</b>	<b>Description</b>
parity	Parity bits value used for physical terminal connections.
stopbits	Stop bits value used for physical terminal connections.
databits	Data bits value used for physical terminal connections.
Template	Line template being sourced by the particular connection.
Config	Configuration applied to the tty. This field indicates the allowed incoming transports that can be used to access the router from this tty.
Allowed transports are	Incoming transport protocols that can be used by this tty to access the router.

# show users

To display information about the active lines on the router, use the **show users** command in EXEC mode.

**show users**

**Syntax Description** This command has no keywords or arguments.

**Command Default** None

**Command Modes** EXEC

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **show users** command to display the line number, connection name, idle time, hosts, and terminal location. An asterisk (*) indicates the current terminal session.



**Note** To display all user groups and task IDs associated with the currently logged-in user, use the **show user** command in EXEC mode. See the *Authentication, Authorization, and Accounting Commands on Cisco IOS XR Software* module in *System Security Command Reference for Cisco ASR 9000 Series Routers*.

Task ID	Task ID	Operations
	tty-access	read

The following example shows sample output identifying an active vty terminal session:

```
RP/0/RSP0/CPU0:router# show users

 Line User Service Conns Idle Location
 con0_RP0_CPU0 cisco hardware 0 18:33:48
 vty0 cisco telnet 0 00:30:36 10.33.54.132
 * vty1 cisco telnet 0 00:00:00 10.33.54.132
```

**Table 90: show users Command Output Field Descriptions**

Field	Description
Line	All current connections. An asterisk (*) indicates the active connection.

Field	Description
User	Username of the user logged into the line.
Service	Physical or remote login service used.
Conns	Number of outgoing connections.
Idle	Interval (in hours:minutes:seconds) since last keystroke.
Location	IP address of remote login host. For local (physical) terminal connections, this field is blank.

**Related Commands**

Command	Description
<a href="#">show line, on page 1040</a>	Displays the parameters of a terminal line.
<b>show user</b>	Displays all user groups and task IDs associated with the currently logged-in user.

# stopbits

To set the stop bits used for physical terminal connections, use the **stopbits** command in line console configuration mode. To restore the default, use the **no** form of this command.

**stopbits** {1 | 2}  
**no stopbits**

## Syntax Description

- |          |                                               |
|----------|-----------------------------------------------|
| <b>1</b> | Specifies one stop bit.                       |
| <b>2</b> | Specifies two stop bits. This is the default. |

## Command Default

Two stop bits.

## Command Modes

Line console configuration

## Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	No modification.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **stopbits** command to set the data bits attributes for physical terminal connections. Physical terminal connections use either the console or auxiliary terminal templates.

Communication protocols provided by devices such as terminals and modems often require a specific stop-bit setting.



### Note

The number of stop bits configured on the router and a terminal server should be same. The default number of stop bits on the router is two stop-bits.

## Task ID

Task ID	Operations
tty-access	read, write

This example shows how to change the default from two stop bits to one for the console line template:

```
RP/0/RSP0/CPU0:router(config)# line console
RP/0/RSP0/CPU0:router(config-line)# stopbits 1
```

---

**Related Commands**

Command	Description
<a href="#">databits, on page 1018</a>	Sets the number of data bits.

# terminal exec prompt

To specify prompt attributes for the current terminal session, use the **terminal exec prompt** command in the appropriate mode.

```
terminal exec prompt {no-timestamp | timestamp}
```

Syntax Description	
<b>no-timestamp</b>	Disables the time-stamp printing before each command.
<b>timestamp</b>	Enables the time-stamp printing before each command.

**Command Default** None

**Command Modes** EXEC

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** Use the **terminal exec prompt** command with the **timestamp** keyword to show the time-stamp display after each command is entered. Use the **terminal exec** command with the **no-timestamp** keyword to disable the time-stamp display.



**Note** The **terminal** commands are active for the current terminal session only. To apply a setting to all sessions, use the **line** commands.

This example shows how to enable the time-stamp prompt. When enabled, the date and time are displayed after each command. In this example, the **show version** command is entered, and the date and time is displayed.

```
RP/0/RSP0/CPU0:router# terminal exec prompt timestamp
RP/0/RSP0/CPU0:router# show version

Thu Jan 14 06:39:50.926 PST

Cisco IOS XR Software, Version 3.9.1.15I[DT_IMAGE]
Copyright (c) 2010 by Cisco Systems, Inc.

ROM: System Bootstrap, Version 1.2(20090903:202931) [ASR9K ROMMON],

router uptime is 6 days, 14 hours, 47 minutes
System image file is "bootflash:disk0/asr9k-os-mpi-3.9.1.15I/mbiasr9k-rp.vm"

cisco ASR9K Series (MPC8641D) processor with 4194304K bytes of memory.
MPC8641D processor at 1333MHz, Revision 2.2

2 Management Ethernet
```

```
40 GigabitEthernet
12 TenGigE
219k bytes of non-volatile configuration memory.
975M bytes of compact flash card.
33994M bytes of hard disk.
1605616k bytes of disk0: (Sector size 512 bytes).
1605616k bytes of disk1: (Sector size 512 bytes).

Configuration register on node 0/RSP0/CPU0 is 0x102
Boot device on node 0/RSP0/CPU0 is disk0:
--More--
```

The following example shows how to disable the time-stamp prompt:

```
RP/0/RSP0/CPU0:router# terminal exec prompt no-timestamp
```



# terminal exec utility pager

To configure the terminal page display options, use the **terminal exec utility pager** command in the appropriate mode.

```
terminal exec utility pager {less | more | none}
```

Syntax Description	
<b>less</b>	Specifies to use unix-like "less" bidirectional paging for the terminal display.
<b>more</b>	Specifies to use unix-like "more" unidirectional paging for the terminal display.
<b>none</b>	Specifies that the display is not paginated.

**Command Default** No pagination is configured by default.

**Command Modes** EXEC

Command History	Release	Modification
	Release 3.7.2	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **terminal exec utility pager** command with the **more** keyword to scroll forward through command display one screen at a time. "--More--" is displayed at the end of each screen. Press the Space key to advance one screen. Press the Enter key to advance one line. Press the Esc key to exit the command display.

Task ID	Task ID	Operation
	tty-access	Read

This example shows how to limit command display to one screen at a time such that you can move forward through the display:

```
RP/0/RSP0/CPU0:router#terminal exec utility pager more
```

# terminal length

To set the number of lines that display at one time on the screen for the current terminal session, use the **terminal length** command in

EXEC  
mode.

**terminal length** *lines*

---

**Syntax Description**     *lines* Number of lines that display on a screen. Range is from 0 through 512.

---

**Command Default**     None

**Command Modes**     EXEC

---

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

---

**Usage Guidelines**     To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **terminal length** command to set the terminal length value for only the current terminal session and not save it to the running configuration. Exiting from the terminal session returns the terminal length value to the value configured with the **length** command.

Specifying a value of 0 for the *lines* argument prevents the router from pausing between screens of output.




---

**Note**     The **terminal** commands are active for the current terminal session only. To apply a setting to all sessions, use the **line** commands.

---



---

Task ID	Task ID	Operations
	tty-access	read, write

---

This example shows how to set the length for the current terminal session to 120 lines:

```
RP/0/RSP0/CPU0:router# terminal length 120
```

**Related Commands**

Command	Description
<a href="#">length, on page 1030</a>	Sets the length of the display terminal.

# terminal width

To set the width of the display terminal for the current terminal session, use the **terminal width** command in EXEC mode.

**terminal width** *characters*

**Syntax Description** *characters* Number of characters to display on a screen. Range is from 0 to 512.

**Command Default** None

**Command Modes** EXEC

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **terminal width** command to set the terminal width value for only the current terminal session and not save it to the running configuration. Exiting from the terminal session returns the terminal width value to the value configured with the **width** (display) command.

Task ID	Task ID	Operations
	tty-access	read, write

The following example shows how to set the terminal width for the current terminal session to 120 characters:

```
RP/0/RSP0/CPU0:router# terminal width 120
```

Related Commands	Command	Description
	<a href="#">width (display), on page 1066</a>	Sets the width of the display terminal.

# timestamp disable

To disable time-stamp recording at the top of each command output, use the **timestamp disable** command in the appropriate line configuration mode. To reenable time-stamp recording if disabled, use the **no** form of this command.

**timestamp disable**  
**no timestamp disable**

<b>Syntax Description</b>	This command has no keywords or arguments.
<b>Command Default</b>	Time-stamp recording at the top of each command output is enabled.
<b>Command Modes</b>	Line console configuration Line default configuration Line template configuration

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

By default, the time stamp is displayed at the top of any command output. The time stamp records the time at which the command was issued. You can use the **snmp-server view** command to disable this setting so that the time stamp does not appear at the top of the command output. This setting applies to all command outputs on any terminal line to which the current line template applies.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	tty-access	read, write

This example shows how to disable time-stamp recording for the console line template:

```
RP/0/RSP0/CPU0:router(config)# line console
RP/0/RSP0/CPU0:router(config-line)# timestamp disable
```

# transport input

To define the transport protocols that can be used to access the router, use the **transport input** command in the appropriate line configuration mode. To change or remove the protocol, use the **no** form of this command.

```
transport input {all | none | ssh | telnet}
no transport input {all | none | ssh | telnet}
```

## Syntax Description

<b>all</b>	Specifies the Secure Shell (SSH) and Telnet protocols.
<b>none</b>	Specifies that the router rejects incoming SSH and Telnet transport protocol connections.
<b>ssh</b>	Specifies the SSH transport protocol.
<b>telnet</b>	Specifies the Telnet transport protocol.

## Command Default

All protocols are allowed on the line.

## Command Modes

Line console configuration  
Line default configuration  
Line template configuration

## Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	No modification.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

To be accepted, incoming network connections to an asynchronous port (terminal line) must use a transport protocol specified with the **transport input** command. This command can be useful in limiting the acceptable transport protocols to include or exclude those used by different types of users, or to restrict a line to secure connections (SSH connections).

## Task ID

Task ID	Operations
tty-access	read, write

This example shows how to set the transport input setting for the default line template to SSH connections:

```
RP/0/RSP0/CPU0:router(config)# line default
RP/0/RSP0/CPU0:router(config-line)# transport input ssh
```

**Related Commands**

Command	Description
<a href="#">transport output, on page 1060</a>	Determines the protocols that can be used for outgoing connections from a line.
<a href="#">transport preferred, on page 1062</a>	Specifies the transport protocol that Cisco IOS XR software uses if the user does not specify one when initiating a connection.

# transport output

To specify the transport protocols that can be used for outgoing connections from a line, use the **transport output** command in the appropriate line configuration mode. To change or remove the protocol, use the **no** form of this command.

```
transport output {all | none | ssh | telnet}
no transport output {all | none | ssh | telnet}
```

Syntax Description	
<b>all</b>	Specifies the Secure Shell (SSH) and Telnet transport protocols.
<b>none</b>	Specifies that the router rejects outgoing SSH and Telnet transport protocol connections.
<b>ssh</b>	Specifies the SSH transport protocol.
<b>telnet</b>	Specifies the Telnet transport protocol.

**Command Default** All protocols are allowed on the line.

**Command Modes**

- Line console configuration
- Line default configuration
- Line template configuration

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Any settings made with the **transport output** command override settings made with the **transport preferred** command.

Task ID	Task ID	Operations
	tty-access	read, write

This example shows how to set the default line template to prevent any outgoing transport protocol connections:

```
RP/0/RSP0/CPU0:router(config)# line default
RP/0/RSP0/CPU0:router(config-line)# transport output none
```



**Related Commands**

Command	Description
<a href="#">transport input, on page 1058</a>	Defines which protocols to use to connect to a specific line of the router.
<a href="#">transport preferred, on page 1062</a>	Specifies the transport protocol that Cisco IOS XR software uses if the user does not specify one when initiating a connection.

# transport preferred

To specify the default outgoing transport protocol to be used for initiating network connections, use the **transport preferred** command in the appropriate line configuration mode. To change or remove the protocol, use the **no** form of this command.

```
transport preferred {none | ssh | telnet}
no transport preferred {none | ssh | telnet}
```

## Syntax Description

<b>none</b>	Disables the feature.
<b>ssh</b>	Specifies the Secure Shell (SSH) transport protocol.
<b>telnet</b>	Specifies the Telnet transport protocol.

## Command Default

No transport protocol is set as the default outgoing protocol.

## Command Modes

Line console configuration  
Line default configuration  
Line template configuration

## Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	No modification.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **transport preferred** command to provide a default transport protocol to use when initiating outgoing connections. The preferred outgoing transport protocol specified with the **transport preferred** command enables you to initiate an outgoing connection without explicitly specifying the transport protocol.

Cisco IOS XR software assumes that any unrecognized command is a hostname and the software attempts a connection. When the protocol is set to **none**, the system ignores unrecognized commands entered at the EXEC prompt, and does not attempt a connection.

The default setting, the same as using the **transport preferred** command with the **none** keyword, prevents errant connection attempts.

## Task ID

Task ID	Operations
tty-access	read, write

The following example shows how to set the preferred transport setting for the default line template to SSH:

```
RP/0/RSP0/CPU0:router(config)# line default
RP/0/RSP0/CPU0:router(config-line)# transport preferred ssh
```

**Related Commands**

Command	Description
<a href="#">transport input, on page 1058</a>	Defines which protocols to use to connect to a specific line of the router.
<a href="#">transport output, on page 1060</a>	Determines the protocols that can be used for outgoing connections from a line.

# vty-pool

To create or modify a virtual terminal line (vty) pool, use the **vty-pool** command in global configuration mode. To delete a vty pool, use the **no** form of this command.

```
vty-pool {default | eempool-name} first-vty last-vty [line-template {defaulttemplate-name}]
no vty-pool {default | eempool-name} first-vty last-vty [line-template {defaulttemplate-name}]
```

Syntax Description		
	<b>default</b>	Specifies the default vty pool.
	<b>eem</b>	Specifies the embedded event manager vty pool.
	<i>pool-name</i>	User-defined vty pool.
	<i>first-vty</i>	First vty line in the pool. <ul style="list-style-type: none"> <li>• For the default vty pool, you must specify 0 for the first vty line.</li> <li>• For a user-defined vty pool, the range is 5 to 99.</li> <li>• For the embedded event manager vty pool, you must specify 100 for the first vty line.</li> </ul>
	<i>last-vty</i>	Last vty line in the pool. <ul style="list-style-type: none"> <li>• The default vty pool must contain at least five vtys. Range is 4 to 99.</li> <li>• For a user-defined vty pool, the range is 5 to 99.</li> <li>• The embedded event manager vty pool must contain at least six vtys. Range is 105 to 199.</li> </ul>
	<b>line-template</b>	(Optional) Specifies the terminal template to be used in the configuration of virtual terminals in the vty pool.
	<b>default</b>	Specifies that the vty pool should reference the default template.
	<i>template-name</i>	User-defined template to be applied to the vtys in the vty pool.

**Command Default**

**default** *vty-pool* : 5 vtys (vty 0 through 4) referencing the default line template.  
**eem** *vty pool* : 6 vtys (vty 100 through 105) referencing the default line template.

**Command Modes** Global configuration

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** When creating or modifying vty pools, follow these usage guidelines:

- Before creating or modifying the vty pools, enable the Telnet server using the **telnet server** command in global configuration mode. See *IP Addresses and Services Configuration Guide for Cisco ASR 9000 Series Routers* and *IP Addresses and Services Command Reference for Cisco ASR 9000 Series Routers* for more information.
- The vty range for the default vty pool must start at vty 0 and must contain a minimum of five vtys.
- The vty range from 0 through 99 can reference the default vty pool.
- The vty range from 5 through 99 can reference a user-defined vty pool.
- The vty range from 100 is reserved for the embedded event manager vty pool.
- The vty range for embedded event manager vty pools must start at vty 100 and must contain a minimum of six vtys.
- A vty can be a member of only one vty pool. A vty pool configuration fails if the vty pool includes a vty that is already in another pool.

If you attempt to remove an active vty from the active vty pool when configuring a vty pool, the configuration for that vty pool fails.

This example shows how to configure a user-defined vty pool (test1) that contains vtys 10 through 14 and references the user-defined line template test2:

```
RP/0/RSP0/CPU0:router(config)# vty-pool test1 10 14 line-template test2
```

## width (display)

To set the width of the display terminal, use the **width** command in the appropriate line configuration mode. To remove the **width** command from the configuration file and restore the system to its default condition, use the **no** form of this command.

**width** *characters*  
**no width** *characters*

<b>Syntax Description</b>	<i>characters</i> Number of characters to display on a screen. Range is from 0 to 512.
---------------------------	----------------------------------------------------------------------------------------

<b>Command Default</b>	<i>characters</i> : 80
------------------------	------------------------

<b>Command Modes</b>	Line console configuration Line default configuration Line template configuration
----------------------	-----------------------------------------------------------------------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

Use the **width** command to modify the default width setting for the specified line template.

<b>Task ID</b>	<b>Task ID</b> <b>Operations</b>
	tty-access read, write

This example shows how to set the terminal width for the default line template to 99 characters:

```
RP/0/RSP0/CPU0:router(config)# line default
RP/0/RSP0/CPU0:router(config-line)# width 99
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<a href="#">terminal width</a> , on page 1056	Sets the width of the display terminal for the current terminal session.



## Utility Commands

---

This module describes the utility commands for Cisco IOS XR software. Utility commands provide CLI equivalents to common UNIX commands.



**Note** Keywords are entered using the displayed syntax, or with UNIX-equivalent syntax. The UNIX-equivalent syntax is displayed in parentheses () in the syntax description. For example, the **universal** keyword can also be entered using the UNIX-equivalent (**-u**). To display the UNIX-equivalent syntax online, enter the **usage** keyword.

---

- [utility bc, on page 1068](#)
- [utility cut, on page 1072](#)
- [utility date, on page 1076](#)
- [utility date set, on page 1079](#)
- [utility df, on page 1081](#)
- [utility du, on page 1085](#)
- [utility egrep, on page 1088](#)
- [utility fgrep, on page 1091](#)
- [utility find, on page 1093](#)
- [utility head, on page 1096](#)
- [utility less, on page 1098](#)
- [utility mv, on page 1100](#)
- [utility sort, on page 1102](#)
- [utility tail, on page 1105](#)
- [utility uniq, on page 1107](#)
- [utility wc, on page 1109](#)
- [utility which, on page 1111](#)
- [utility xargs, on page 1113](#)

## utility bc

To implement an arbitrary precision calculator, use the **utility bc** command in EXEC mode or administration EXEC mode.

**utility bc** [**file** *input-file*]



---

**Syntax Description**

**file** (Optional) Specifies the text file containing commands and function definitions to be interpreted by the bc utility.  
*input-file*

After all files have been read, the bc utility reads input from the standard input (keyboard). If no files are specified, then only the standard input (keyboard) is used.

The syntax of the *input-file* argument is as follows: *device* :[/ *directory-path*]/ *filename*

Possible values of the *device*: argument are:

**disk0:**

Uses a file from disk0: file system.

**disk0a:**

Uses a file from disk0a: file system partition.

**disk1:**

Uses a file from disk1: file system.

**disk1a:**

Uses a file from disk1a: file system partition.

**ftp:**

Uses a file from an FTP network server. The syntax is

**ftp:**[[[/*username*[:*password*][@]*location*]/*directory*]/*filename*

**harddisk:**

Uses a file from the hard disk drive file system (if present).

**harddiska:**

Uses a file from the hard disk partition (if present).

**nvrn:**

Uses a file from the nvrn: file system.

**ipv4**

Uses a file from an IPv4 access list or prefix list.

**ipv6**

Uses a file from an IPv6 access list or prefix list.

**rcp:**

Uses a file from a remote copy protocol (rcp) network server. The syntax is

**rcp:**[[[/*username*@]*location*]/*directory*]/*filename*

**tftp:**

Uses a file from a TFTP network server. The syntax is **tftp:**[[/*location*]/*directory*]/*filename*

Use the online help (?) function to display the available devices and network protocols.

---

**Command Default**

If an input file is not specified, the standard input (keyboard) is used.

**Command Modes**

EXEC

Administration EXEC

**Command History**

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.8.0	No modification.
Release 3.9.0	No modification.

**Usage Guidelines**

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **utility bc** command to use the interactive, programmable calculator that supports a complete set of control structures, including functions. The utility first processes any specified files, and then reads input from the keyboard (standard input).

Input files (and standard input) are ASCII text files containing sequences of bc statements to be executed.

**Note**

The bc utility uses the bc programming language, an arbitrary precision calculator language with syntax similar to the C programming language. The bc utility does not support character or string manipulation.

The bc utility supports:

- 26 functions
- 26 simple variables
- 26 array variables (up to 2048 elements per array).

The bc utility supports the following common programming language constructs:

- “if”, “while”, and “for” statements
- User-defined functions with parameters
- Local variables

**Information About Supported Network Protocols**

In the syntax for the **ftp:**, **rcp:**, and **tftp:** network protocols, the location is either an IP address or a hostname. The filename is specified relative to the directory used for file transfers.

When no device is specified, the current directory is used. To view the current directory, enter the **pwd** command.

*Table 91: Network Protocols Supported by Cisco IOS XR Software*

Prefix	Name	Description
<b>tftp:</b>	Trivial File Transfer Protocol	<i>TFTP</i> is a simplified version of FTP that allows files to be transferred from one computer to another over a network, usually without the use of client authentication (for example, username and password).

Prefix	Name	Description
<b>ftp:</b>	File Transfer Protocol	<i>FTP</i> is an application protocol, part of the TCP/IP protocol stack, and is used for transferring files between network nodes. FTP requires a username and password.
<b>rcp:</b>	remote copy protocol	<i>Rcp</i> is a protocol that allows users to copy files to and from a file system residing on a remote host or server on the network. Rcp uses TCP to ensure the reliable delivery of data. Rcp downloads require a username.

**Task ID****Task ID Operations**


---

 universal execute
 

---

In the following example, the **utility bc** command is used to execute the bc statements contained in the ASCII text file exp.txt:

```
RP/0/RSP0/CPU0:router# utility bc file disk0:/usr/exp.txt

50
15
25
3
17
```

# utility cut

To extract selected characters or fields from standard input or from a file, use the **utility cut** command in EXEC mode or administration EXEC mode.

**utility cut** {{**list** *character-list* | **fields** *field-list* [**nodelim**] [**delimiter** *delimiter-character*]*WORD*} [**file** *input-file*] | **usage**}

## Syntax Description

<b>list</b> <i>character-list</i>	(-c) Cuts out the characters that are located on each line as specified with the <i>character-list</i> argument.  The <i>character-list</i> argument specifies the character positions or range of the characters to be cut.  <ul style="list-style-type: none"> <li>Use a comma (,) to indicate more than one character. For example, <b>utility list 1,2,5</b> outputs the first, second, and fifth characters.</li> <li>Use a dash (-) to indicate a range. For example, <b>utility list 1-64</b> outputs the first 64 characters of each line, <b>utility list 5-</b> outputs the fifth character to the end of the line.</li> </ul> <p><b>Note</b> Lines are separated by a delimiter. The default delimiter is tab.</p>
<b>fields</b> <i>field-list</i>	(-f) Cuts out the fields (lines) as indicated with the <i>field-list</i> argument.  The <i>field-list</i> argument specifies the field numbers or ranges. For example, <b>utility field 2,9</b> outputs the second and ninth fields, <b>utility field 1-3</b> outputs the first three fields, <b>utility field -6</b> outputs the first six fields.  <p><b>Note</b> The fields indicated by the <i>field-list</i> argument are assumed to be separated in the file by a delimiter character. The default delimiter is tab. Use the <b>delimiter</b> <i>delimiter</i> option to specify a delimiter character. Lines without field delimiters are processed unless the <b>nodelim</b> keyword is specified.</p>
<b>nodelim</b>	(Optional) (-s) Ignores lines with no delimiter. Use this optional keyword when the <b>fields</b> <i>field-list</i> keyword and argument is specified.
<b>delimiter</b> <i>delimiter-character</i>	(Optional) (-d) Specifies an alternative delimiter to indicate the end of each field. Replace the <i>delimiter-character</i> argument with the character used as the delimiter.
<i>WORD</i>	(Optional) UNIX command-line option string. The maximum number of characters is 80.
<b>file</b> <i>input-file</i>	(Optional) Storage device and directory path of the text file used instead of the standard input (keyboard input).  The syntax of the <i>input-file</i> argument is: <i>device</i> :[/ <i>directory-path</i> ]/ <i>filename</i>  The <i>device</i> argument, followed by a colon, indicates the name of the device where the file is located. Use the online help (?) function to display the available storage devices and network protocols.

---

**usage** (Optional) Displays the UNIX options supported by this command.

---

**Command Default** If no file is specified, the keyboard input (standard input) is used.  
The delimiter is tab.

**Command Modes** EXEC  
Administration EXEC

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** The **utility cut** command cuts out columns, fields, or characters displayed from standard input or from a file. Use the **fields** *field-list* keyword and argument if the fields vary in length from line to line. (The lines must be separated by a delimiter character.) By default, the field delimiter character is the Tab key. Use the **delimiter** *delimiter-character* keyword and argument to specify a different delimiter.

Use the **list** *character-list* keyword and argument only if the fields are of a fixed length. Replace the *character-list* argument with the character positions to be extracted.

For the *character-list* argument, use a comma (,) to indicate more than one character, or use a dash (-) to indicate a range. For example, **utility list 1,2,5** outputs the first, second, and fifth characters, **utility list 1-64** outputs the first 64 characters of each line, **utility list 5-** outputs the fifth character to the end of the line.

You can also use the cut utility as a filter. If no files are specified, the keyboard input (standard input) is used.



**Note** Keywords are entered using the displayed syntax, or with UNIX-equivalent syntax. The UNIX-equivalent syntax is displayed in parentheses () in the syntax description. For example, the **fields** keyword can also be entered using the UNIX-equivalent (-f). To display the UNIX-equivalent syntax online, enter the **usage** keyword.

In the following example, the **utility cut** command is entered with the **list** *character-list* keyword and argument to display the first 10 characters in each line. The output is from the results of the **show version** command, which is entered with the pipe (|) character:

```
RP/0/RP0/CPU0:router# show version | utility cut list 1-10

Thu Jul 30 06:25:35.854 DST

Cisco IOS
Copyright

ROM: Syste

PE44_ASR-9
System ima

cisco ASR9
```

```

MPC8641D p

2 Manageme
12 TenGigE
40 Gigabit
219k bytes
975M bytes
33994M byt
1605616k b
1605616k b

Configurat
Boot devic
Package ac
asr9k-scfc
 Built
 By sjc

asr9k-adv-
 Built
 By sjc

asr9k-fpd,
 Built
 By sjc

asr9k-diag
 Built
 By sjc

asr9k-k9se
 Built
 By sjc

asr9k-mgbl
 Built
--More--

```

In the following example, the **utility cut** command is used to extract fields from a file:

```

RP/0/RSP0/CPU0:router# utility cut fields 1,5 delimiter : file disk0:/usr/passwd

root:Super-User
daemon:
bin:
sys:
adm:Admin
lp:Line Printer Admin
uucp:uucp Admin
nuucp:uucp Admin
listen:Network Admin
nobody:Nobody

```

In the following example, the **utility cut** command is used with the **delimiter** keyword to specify an alternative field delimiter:

```

RP/0/RSP0/CPU0:router# utility cut fields 1,4,5 delimiter : file disk0:/usr/passwd

root:1:Super-User
daemon:1:
bin:2:

```

```

sys:3:
adm:4:Admin
lp:8:Line Printer Admin
uucp:5:uucp Admin
nuucp:9:uucp Admin
listen:4:Network Admin

```

In the following example, a range of fields is specified:

```

RP/0/RSP0/CPU0:router# utility cut fields 1-4 delimiter : file disk0:/usr/passwd

root:x:0:1
daemon:x:1:1
bin:x:2:2
sys:x:3:3
adm:x:4:4
lp:x:71:8
uucp:x:5:5
nuucp:x:9:9
listen:x:37:4

```

In the following example, the **list** *character-list* keyword and argument are used to specify the character positions to be extracted:

```

RP/0/RSP0/CPU0:router# utility cut list 1-30 file disk0:/usr/passwd

root:x:0:1:Super-User:/:sbin/
daemon:x:1:1:::/:
bin:x:2:2::/usr/bin:
sys:x:3:3:::/:
adm:x:4:4:Admin:/var/adm:
lp:x:71:8:Line Printer Admin:/
uucp:x:5:5:uucp Admin:/usr/lib
nuucp:x:9:9:uucp Admin:/var/sp
listen:x:37:4:Network Admin:/u
nobody:x:60001:60001:Nobody:/:
noaccess:x:60002:60002:No Acce
nobody4:x:65534:65534:SunOS 4.

```

In the following example, the UNIX equivalent options are used directly. First, the **utility cut** command is entered with the **usage** keyword to display the possible options. Next, the **utility cut** command is entered with the options to extract the desired data.

```

RP/0/RSP0/CPU0:router# utility cut usage

cut -c list [file], cut -f list [-d delim] [-s] [file]

RP/0/RSP0/CPU0:router# utility cut -f 1,4 -d : disk0:/usr/passwd

root:1
daemon:1
bin:2
sys:3
adm:4
lp:8

```

# utility date

To display the date and time, use the **utility date** command in EXEC mode or administration EXEC mode.

**utility date** {**format** *word* | **universal** | **usage***WORD*}

<b>Syntax Description</b>	<b>format</b> <i>word</i> (Optional) (+) Specifies the format for the date display. Use the online help system to display the available format syntax for the <i>word</i> argument.
	<b>universal</b> (Optional) (-u) Displays the date in Coordinated Universal Time (UTC) instead of local time. UTC is the standard term for Greenwich Mean Time (GMT).
	<b>usage</b> (Optional) Displays the UNIX options supported by this command.
	<i>WORD</i> (Optional) UNIX command-line option string. The maximum number of characters is 80.

**Command Default** The date is displayed in local time.

**Command Modes** EXEC  
Administration EXEC

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **utility date** command displays the internal time and date for the router.

## Date Format

Use the **format** *word* option to specify the format and content of the displayed date and time. The format is composed of ASCII characters and field descriptors prefaced with %, in a manner similar to a C-language printf() format specifier. In the output, each field descriptor is replaced by its corresponding value; all other characters are copied to the output without change. The format is specified using the following characters:

**%C**

Century in 'CC' form. For example: 20

**%y**

Year in 'YY' form. For example: 06



**%m**

Month in 'MM' form. For example: 08

**%d**

Date in 'DD' form. For example: 28

**%H**

Hour in 'hh (24 hr.)' form. For example: 18

**%M**

Minutes in 'mm' form. For example: 55

**%S**

seconds in 'ss' form. For example: 24



**Note** Keywords are entered using the displayed syntax, or with UNIX-equivalent syntax. The UNIX-equivalent syntax is displayed in parentheses () in the syntax description. For example, the **universal** keyword can also be entered using the UNIX-equivalent (**-u**). To display the UNIX-equivalent syntax online, enter the **usage** keyword.

**Task ID****Task ID Operations**

universal execute

This example shows how to display the router date and time using the **utility date** command:

```
RP/0/RSP0/CPU0:router# utility date
Fri Aug 04 11:53:38 UTC 2006
```

This example shows how to display the router date and time using a variety of options with the **format** keyword:

```
RP/0/RSP0/CPU0:router# utility date format "%y%m%d"
060828
RP/0/RSP0/CPU0:router# utility date format "%y-%m-%d"
06-08-28
RP/0/RSP0/CPU0:router# utility date format "%C%y-%m-%d"
2006-08-28
RP/0/RSP0/CPU0:router# utility date format "%C%y-%m-%d:%H:%M:%S"
2006-08-28:02:09:58
RP/0/RSP0/CPU0:router# utility date format "DATE: %y-%m-%d %nTIME: %H:%M:%S"
```

```
DATE: 06-09-17
TIME: 12:42:24
```

---

**Related Commands**

Command	Description
<a href="#">utility date set, on page 1079</a>	Sets the internal date and time of the router.

# utility date set

To set the router time, use the **utility date set** command in administration EXEC mode.

**utility date set** *hh:mm:ss*

## Syntax Description

*hh* Specifies the hour in 2-digit numerical format. Range is 00 to 23.

*mm* Specifies the minutes in 2-digit numerical format. Range is 0 to 59.

*SS* Specifies the seconds in 2-digit numerical format. Range is 0 to 59.

## Command Default

None

## Command Modes

Administration EXEC

## Command History

### Release

### Modification

Release 3.7.2

This command was introduced.

Release 3.9.0

No modification.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

A colon (:) is required between the entry for hour, minutes, and seconds.



### Note

Generally, if the system is synchronized by a valid outside timing mechanism, such as a Network Time Protocol (NTP) clock source, or if you have a networking device with calendar capability, you need not set the software clock. Use the **date** command or the **clock set** command if no other time sources are available.



### Note

To manually copy the hardware clock (calendar) settings into the software clock, use the **clock read-calendar** command in EXEC mode.

By default, the system makes a “slow adjustment” if the new time is in the range of the following:

- -2.5 minutes + old time
- 5 minutes + old time

In a slow adjustment, the clock speed increases by less than 100 percent or decreases by less than 50 percent over a period of time from 1 second to 5 minutes until the clock catches up with the new time. This slow

adjustment does not cause major discontinuities in the time flow. Use the **-S0** option to disable the slow adjustment.

Task ID	Task ID	Operations
	universal	execute

The following example shows how to set the time using the **utility date set** command:

```
RP/0/RSP0/CPU0:router(admin)# utility date set 13:07:00
Fri Sep 15 13:07:00 UTC 2006
```

#### Related Commands

Command	Description
<a href="#">utility date, on page 1076</a>	Displays the internal date and time of the router.

# utility df

To display the amount of disk space available for a directory or file, use the **utility df** command in EXEC mode or administration EXEC

mode.

**utility df** [{*WORD*} [**kbytes**] [**mountinfo**] [**vsfStats**] [**file** *input-file*] | **usage**}]

## Syntax Description

<b>WORD</b>	(Optional) UNIX command-line option string. The maximum number of characters is 80.
<b>kbytes</b>	(Optional) ( <b>-k</b> ) Displays the sizes in 1-K blocks (1024-byte units) instead of the default of 512 byte blocks.
<b>mountinfo</b>	(Optional) ( <b>-n</b> ) Displays the file-system mountpoints and types only.
<b>vsfStats</b>	(Optional) ( <b>-g</b> ) Displays all statvfs() information.
<b>file</b> <i>input-file</i>	(Optional) Specifies the storage device and directory path of the device, directory, or file. When a directory or file is specified, the df utility displays the amount of space on the file system that contains the directory or file.  If no files are specified, then only the standard input (keyboard) is used.  The syntax of the <i>input-file</i> argument is as follows: <i>device</i> :[ <i> directory-path</i> ]/ <i>filename</i>  The <i>device</i> argument, followed by a colon, indicates the name of the device where the file is located. Use the online help (?) function to display the available storage devices and network protocols.
<b>usage</b>	(Optional) Displays the UNIX options supported by this command.

## Command Default

Information is displayed for all file systems.  
The results are displayed in 512-byte blocks.

## Command Modes

EXEC  
Administration EXEC

## Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	No modification.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the (disk free) **utility df** command to display the amount of disk space available for a device, directory, or file. Enter the command without keywords or arguments to display information for all mounted file systems.

Use the **vsfStats** keyword to invoke the `statvfs()` function, which provides additional details for all mounted file systems.



**Note** Keywords are entered using the displayed syntax, or with UNIX-equivalent syntax. The UNIX-equivalent syntax is displayed in parentheses () in the syntax description. For example, the **kbytes** keyword can also be entered using the UNIX-equivalent (**-k**). To display the UNIX-equivalent syntax online, enter the **usage** keyword.

## Task ID

### Task ID Operations

universal execute

In the following example, the (disk free) **utility df** command is entered without keywords or arguments to display information for all file systems:

```
RP/0/RSP0/CPU0:router (admin) # utility df

/dev/hd0t6 77987744 61592 77926152 1% /harddisk:/
/nvram: 4086 60 4026 2%
/dev/disk1t6 2001280 382720 1618560 20% /disk1:/
/dev/disk0t6 2001184 533568 1467616 27% /disk0:/
/dev/fs0p1 121856 68 121787 1% /bootflash:
```

See [Table 93: utility df Column Descriptions \(left to right\), on page 1084](#) for column descriptions.

In the following example, the **kbytes** keyword is used to display information in 1-K blocks (1024-byte units) instead of the default of 512-byte blocks:

```
RP/0/RSP0/CPU0:router (admin) # utility df kbytes

/dev/hd0t6 38993872 30796 38963076 1% /harddisk:/
/nvram: 2043 30 2013 2%
/dev/disk1t6 1000640 191360 809280 20% /disk1:/
/dev/disk0t6 1000592 266784 733808 27% /disk0:/
/dev/fs0p1 60928 34 60893 1% /bootflash:
```

See [Table 93: utility df Column Descriptions \(left to right\), on page 1084](#) for column descriptions.

In the following example, the **mountinfo** keyword is used to display file-system mountpoints and types only:

```
RP/0/RSP0/CPU0:router (admin) # utility df mountinfo

Filesystem Mounted on Type
/dev/hd0t6 /harddisk:/ dos (fat32)
/nvram:
/dev/disk1t6 /disk1:/ dos (fat16)
/dev/disk0t6 /disk0:/ dos (fat16)
/dev/fs0p1 /bootflash: flash
```

In the following example, the **vfsStats** keyword is used to invoke the `statvfs()` function, which provides additional details for all mounted file systems:

```
RP/0/RSP0/CPU0:router(admin)# utility df vfsStats

/dev/hd0t6 /harddisk:/
 Blocks: 9748468 total 9740769 avail [4096-byte blocks]
 Files : 0 total 0 avail
 Type : dos (fat32)
 Flags : 00000120 [32bit, noatime]

/nvram:
 Blocks: 2043 total 2013 avail [1024-byte blocks]
 Files : 0 total 0 avail
 Type :
 Flags : 00000000 []

/dev/disk1t6 /disk1:/
 Blocks: 62540 total 50580 avail [16384-byte blocks]
 Files : 0 total 0 avail
 Type : dos (fat16)
 Flags : 00000120 [32bit, noatime]

/dev/disk0t6 /disk0:/
 Blocks: 62537 total 45863 avail [16384-byte blocks]
 Files : 0 total 0 avail
 Type : dos (fat16)
 Flags : 00000120 [32bit, noatime]

/dev/fs0p1 /bootflash:
 Blocks: 62390272 total 62355240 avail [1-byte blocks]
 Files : 2 total 0 avail
 Type : flash
 Flags : 00000000 []
```

This table describes the significant fields shown in the display.

**Table 92: utility df Field Descriptions**

Field	Description
Files	Number of files in the file system.
Blocks	Amount of space available on the file system in 1-K blocks.
Total	Amount of disk space used by the directory or file.
Avail	Amount of space available for use by the directory or file on the file system.
Type	Type of file system.
Flags	Displays the file system properties.

In the following example, the **file source** keyword and argument are used to specify a directory:

```
RP/0/RSP0/CPU0:router(admin)# utility df file disk0:/usr
```

```

/dev/disk0t6 2001184 533568 1467616 27% /disk0:/

```

This table describes the significant fields shown in the display.

**Table 93: utility df Column Descriptions (left to right)**

Field	Description
Filesystem	File system for the displayed information.
1k-blocks	Amount of space available on the file system in 1-K blocks.
Used	Amount of disk space used by the directory or file.
Available	Amount of space available for use by the directory or file on the file system.
Use%	Percentage of space used on the file system.
Mounted on	Storage device where the file system is mounted.

#### Related Commands

Command	Description
<a href="#">utility du, on page 1085</a>	Displays the amount of disk space used by one or more directories or files.



# utility du

To display the amount of disk space used in a device, directory, or file, use the **utility du** command in EXEC mode or administration EXEC mode.

**utility du** [{**all** | **specified**}] [{**kbytes** | **bytes** | **local**}] [*WORD*] [**file** *source*] | **usage**}]

## Syntax Description

<b>all</b>	(Optional) ( <b>-a</b> ) Displays the disk space used for each file in the directory. By default, information is displayed only for the directory. Use the <b>all</b> keyword to display the total disk space used by all files in the directory, including the directory itself.
<b>specified</b>	(Optional) ( <b>-s</b> ) Displays the total disk space used for each specified file, rather than the totals for any subdirectories.
<b>kbytes</b>	(Optional) ( <b>-k</b> ) Displays the disk space used in 1-K blocks (1024-byte units) instead of the default of 512-byte blocks.
<b>bytes</b>	(Optional) ( <b>-p</b> ) Displays the disk space used in bytes (the default is 512-byte blocks). Also generates error messages for exiting files that cannot be displayed.
<b>local</b>	(Optional) ( <b>-x</b> ) Displays information for the local device only.
<i>WORD</i>	(Optional) UNIX command-line option string. The maximum number of characters is 80.
<b>file source</b>	(Optional) Displays the disk space used for a device, directory, or file. The syntax for the <i>source</i> argument is <i>device</i> : / <i>directory-path</i> [ / <i>filename</i> ] The <i>device</i> argument, followed by a colon, indicates the name of the device where the file is located. Use the online help (?) function to display the available storage devices and network protocols. Enter the <b>utility du</b> command without specifying a device, directory, or file to display information for the current directory, and subdirectories. (The command behaves as if the filename dot (.) is entered.)
<b>usage</b>	(Optional) Displays the UNIX options supported by this command.

## Command Default

Information for the current directory is displayed.

## Command Modes

EXEC

Administration EXEC

## Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	No modification.

**Usage Guidelines**

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Enter the **utility du** command without specifying a file to display information for the current directory. The command behaves as if the filename dot (.) is entered.

**Note**

Keywords are entered using the displayed syntax, or with UNIX-equivalent syntax. The UNIX-equivalent syntax is displayed in parentheses () in the syntax description. For example, the **kbytes** keyword can also be entered using the UNIX-equivalent (**-k**). To display the UNIX-equivalent syntax online, enter the **usage** keyword.

**Task ID****Task ID Operations**

universal	execute
-----------	---------

In the following example, the **utility du** command is used to display the disk space used for the subdirectories in the MPLS package directory:

```
RP/0/RSP0/CPU0:router# utility du file disk1:/asr9k-mpls-3.9.0.14I

Tue Jul 28 03:20:34.059 DST
 1607 /disk1:/asr9k-mpls-3.9.0.14I/schema
 83 /disk1:/asr9k-mpls-3.9.0.14I/lib/cerrno
 944 /disk1:/asr9k-mpls-3.9.0.14I/lib/mib
 3434 /disk1:/asr9k-mpls-3.9.0.14I/lib
15974 /disk1:/asr9k-mpls-3.9.0.14I/bin
 14 /disk1:/asr9k-mpls-3.9.0.14I/mib
 14 /disk1:/asr9k-mpls-3.9.0.14I/placement
 14 /disk1:/asr9k-mpls-3.9.0.14I/startup
1099 /disk1:/asr9k-mpls-3.9.0.14I/parser
 18 /disk1:/asr9k-mpls-3.9.0.14I/configs
 11 /disk1:/asr9k-mpls-3.9.0.14I/rules
 14 /disk1:/asr9k-mpls-3.9.0.14I/partitions
 156 /disk1:/asr9k-mpls-3.9.0.14I/etc/compat
 164 /disk1:/asr9k-mpls-3.9.0.14I/etc
 59 /disk1:/asr9k-mpls-3.9.0.14I/instdb_v
 147 /disk1:/asr9k-mpls-3.9.0.14I/lc/bin
 9 /disk1:/asr9k-mpls-3.9.0.14I/lc/startup
 164 /disk1:/asr9k-mpls-3.9.0.14I/lc
 103 /disk1:/asr9k-mpls-3.9.0.14I/instdb
22697 /disk1:/asr9k-mpls-3.9.0.14I
```

In the following example, the **utility du** command is used to display the disk space used for a subdirectories:

```
RP/0/RSP0/CPU0:router# utility du file disk0:/
asr9k
-mpls-3.8.0/configs37 /disk0:/asr9k-mpls-3.8.0/configs
```

In the following example, the **utility du** command is used to display the disk space used for the current working directory:

```
RP/0/RSP0/CPU0:router# cd disk0:/
asr9k
-mpls-3.8.0
RP/0/RSP0/CPU0:router# utility du

 160 ./schema
 104 ./lib/cerrno
 625 ./lib/mib
 2545 ./lib
 9658 ./bin
 39 ./startup
 840 ./parser
 37 ./configs
 35 ./mib
 35 ./rules
 34 ./partitions
 135 ./etc/compat
 167 ./etc
 66 ./instdb_v
 181 ./lc/bin
 33 ./lc/startup
 246 ./lc
 112 ./instdb
 14006 .
```

**Related Commands**

Command	Description
<a href="#">utility df, on page 1081</a>	Displays the amount of disk space available for a directory or file.

## utility egrep

To search a file or the results of standard input using full regular expressions, use the **utility egrep** command in

EXEC mode or administration EXEC

mode.

**utility egrep** {**expr** *expression* | **script** *expression-file*} [*WORD*] [**count**] [**linenum**] [**matchfile**] [**matchline**] [**nocase**] [**nofile**] [**reverse**] [**file** *search-file*]

**utility egrep** *expression* [*WORD*] [**count**] [**linenum**] [**matchfile**] [**matchline**] [**nocase**] [**nofile**] [**reverse**] [**file** *search-file*]

### utility egrep usage

#### Syntax Description

<b>expr</b> <i>expression</i>	(-e) A regular expression. This form is used when only one expression is specified on the command line. Any names specified after this option are treated as input files.
<b>script</b> <i>expression-file</i>	(-f) A file containing a set of regular expressions, each separated by a new line. The type of the expressions is determined by the -e and -f options. This form is used when more than one expression is specified. You can specify more than one -f option.  The syntax of the <i>expression-file</i> argument is: [ <i>device</i> :]/ <i>filename</i>
<i>WORD</i>	(Optional) UNIX command-line option string. The maximum number of characters is 20.
<b>count</b>	(Optional) (-c) Displays a count of selected lines.
<b>linenum</b>	(Optional) (-n) Before each output line, displays the line's line number.
<b>matchfile</b>	(Optional) (-l) ("e") Displays only the names of files containing the selected lines.
<b>matchline</b>	(Optional) (-x) Includes only input lines selected against an entire fixed string or regular expression.
<b>nocase</b>	(Optional) (-i) Ignores uppercase and lowercase distinctions during comparisons.
<b>nofile</b>	(Optional) (-h) Displays results without a filename prefix attached to the matched lines. This option applies only when more than one file is searched.
<b>reverse</b>	(Optional) (-v) Selects only those lines that don't match the specified patterns.
<b>file</b> <i>search-file</i>	(Optional) The file used for the search. Replace the <i>search-file</i> argument with the device and directory path of the file. The syntax for the <i>search-file</i> argument is: [ <i>device</i> :]/ <i>filename</i> .
<b>usage</b>	(Optional) Displays the UNIX options supported by this command.

#### Command Default

If no files are specified, the keyboard input (standard input) is used.

If more than one input file is specified, then the filename is displayed before each line.

### Command Modes

EXEC, Admin EXEC

### Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	No modification.

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The grep utility searches files for character patterns using regular expressions and returns all lines that contain that pattern. The **utility egrep** command uses full regular expressions (expressions using the full set of alphanumeric and special characters) to match the patterns.

The results are displayed to the standard output (terminal screen).



#### Note

The egrep utility options are entered using the displayed syntax, or with UNIX-equivalent syntax. The UNIX-equivalent syntax is displayed in parentheses () in the syntax description. For example, the **count** keyword can also be entered using the UNIX-equivalent (-c). To display the UNIX-equivalent syntax online, enter the **usage** keyword.

### Task ID

#### Task ID Operations

universal execute

In the following example, the **utility egrep** command is used to locate the regular expression “uptime”. The **linenum** keyword is also entered to display the line number before each line of output.

```
RP/0/RSP0/CPU0:router# show version | utility egrep expr uptime linenum
7:router uptime is 5 days, 19 hours, 27 minutes
```

In the following example, the **utility egrep** command is used to locate a regular expression in a file. In this example, all lines with “adm” are displayed. The * character is used as a wildcard.

```
RP/0/RSP0/CPU0:router# utility egrep expr Adm* nofile file disk0:/usr/passwd

adm:x:4:4:Admin:/var/adm:
lp:x:71:8:Line Printer Admin:/usr/spool/lp:
uucp:x:5:5:uucp Admin:/usr/lib/uucp:
nuucp:x:9:9:uucp Admin:/var/spool/uucppublic:/usr/lib/uucp/uucico
listen:x:37:4:Network Admin:/usr/net/nls:
ssadmin:x:901218:60001:Sun StorEdge(tm) Configuration Service Agent Admin:./bin/false
```

In the following example, the **nocase** keyword is used to ignore the character case:

```
RP/0/RSP0/CPU0:router# utility egrep expr Adm* nocase file disk0:/usr/passwd

adm:x:4:4:Admin:/var/adm:
lp:x:71:8:Line Printer Admin:/usr/spool/lp:
uucp:x:5:5:uucp Admin:/usr/lib/uucp:
nuucp:x:9:9:uucp Admin:/var/spool/uucppublic:/usr/lib/uucp/uucico
listen:x:37:4:Network Admin:/usr/net/nls:
ssadmin:x:901218:60001:Sun StorEdge(tm) Configuration Service Agent Admin:./bin/false
```

In the following example, the **linenum** keyword is used to append the line number to the beginning of each output line:

```
RP/0/RSP0/CPU0:router# utility egrep expr Adm* linenum file disk0:/usr/passwd

5:adm:x:4:4:Admin:/var/adm:
6:lp:x:71:8:Line Printer Admin:/usr/spool/lp:
7:uucp:x:5:5:uucp Admin:/usr/lib/uucp:
8:nuucp:x:9:9:uucp Admin:/var/spool/uucppublic:/usr/lib/uucp/uucico
9:listen:x:37:4:Network Admin:/usr/net/nls:
15:ssadmin:x:901218:60001:Sun StorEdge(tm) Configuration Service Agent Admin:./bin/false
```

#### Related Commands

Command	Description
<a href="#">utility fgrep, on page 1091</a>	Searches a file for a fixed character string.

# utility fgrep

To search a file for a fixed character string, use the **utility fgrep** command in EXEC mode or administration EXEC

mode.

```
utility fgrep {expr expression | script expression-file} [WORD] [count] [linenum] [matchfile]
[matchline] [nocase] [nofile] [reverse] [file search-file]
```

```
utility fgrep expression [WORD] [count] [linenum] [matchfile] [matchline] [nocase] [nofile]
[reverse] [file search-file]
```

## utility fgrep usage

Syntax	Description
<b>expr</b> <i>expression</i>	(-e) A regular expression, whose type is determined by the -e and -f options. This form is used when only one expression is specified on the command line. Any names specified after this option are treated as input files.
<b>script</b> <i>expression-file</i>	(-f) A file containing a set of regular expressions, each separated by a new line. The type of the expressions is determined by the -e and -f options. This form is used when more than one expression is specified. You can specify more than one -f option.  The syntax of the <i>expression-file</i> argument is: <i>device</i> :[/ <i>directory-path</i> ]/ <i>filename</i>
<i>WORD</i>	(Optional) UNIX command-line option string. The maximum number of characters is 20.
<b>count</b>	(Optional) (-c) Displays a count of selected lines.
<b>linenum</b>	(Optional) (-n) Before each output line, displays the line's line number.
<b>matchfile</b>	(Optional) (-l) ("el") Displays only the names of files containing the selected lines.
<b>matchline</b>	(Optional) (-x) Includes only input lines selected against an entire fixed string or regular expression.
<b>nocase</b>	(Optional) (-i) Ignores uppercase and lowercase distinctions during comparisons.
<b>nofile</b>	(Optional) (-h) Displays results without a filename prefix attached to the matched lines. This option applies only when more than one file is searched.
<b>reverse</b>	(Optional) (-v) Selects only those lines that don't match the specified patterns.
<b>file</b> <i>search-file</i>	(Optional) The file used for the search. Replace the <i>search-file</i> argument with the device and directory path of the file. The syntax for the <i>search-file</i> argument is: <i>device</i> :[/ <i>directory-path</i> ]/ <i>filename</i>
<b>usage</b>	(Optional) Displays the UNIX options supported by this command.

**Command Default** The keyboard input (standard input) is used if no files are specified.

If more than one input file is specified, then the filename is displayed before each line.

**Command Modes** EXEC, Admin EXEC

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **utility fgrep** command searches files for a fixed character string (as opposed to `grep` and `egrep`, which search for a pattern that matches an expression).

The results are displayed to the standard output (terminal screen).



**Note** The `fgrep` utility options are entered using the displayed syntax, or with UNIX-equivalent syntax. The UNIX-equivalent syntax is displayed in parentheses () in the syntax description. For example, the **count** keyword can also be entered using the UNIX-equivalent (**-c**). To display the UNIX-equivalent syntax online, enter the **usage** keyword.

**Task ID**

Task ID	Operations
universal	execute

The following example, the **utility fgrep** command is used with the **nocase** and **linenum** keywords:

```
RP/0/RSP0/CPU0:router# show version | utility fgrep expr uptime nocase linenum
7:router uptime is 5 days, 20 hours, 10 minutes
```

Related Commands	Command	Description
	<a href="#">utility egrep, on page 1088</a>	Searches a file using full regular expressions.



# utility find

To locate files within one or more directories, use the **utility find** command in EXEC mode or administration EXEC mode.

**utility find** {**path** *directory-path* [*LINE*] | **name** *filename-pattern* | **user** *user-id*} | **usage**}

## Syntax Description

<b>path</b> <i>directory-path</i>	Specifies the storage device and directory for the file search. The search is performed for the specified directory and all subdirectories in that directory tree.  If a directory path is not specified, then the search is performed in the current directory (a path of . [dot] is assumed).
<i>LINE</i>	(Optional) UNIX command-line expressions provided as a string.
<b>name</b> <i>filename-pattern</i>	(Optional) Searches for the name of the file. The <i>filename-pattern</i> argument is a regular expression string.
<b>user</b> <i>user-id</i>	(Optional) Searches for files belonging to a specific user. The <i>user-id</i> argument is the username of the file owner.
<b>usage</b>	(Optional) Displays the UNIX options supported by this command.

## Command Default

If a directory path is not specified, then the search is performed in the current directory.  
If a **name** *filename-pattern* is not specified, then the search return all files in the specified directory.  
If a user is not specified, then the search is performed for all users.

## Command Modes

EXEC, Admin EXEC

## Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	No modification.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **utility find** command to locate files within one or more directories. You can perform the search for a specific directory (and its subdirectories). If a directory is not specified, then the search is performed for the current directory.

To search for a regular expression string, use the **name** *filename-pattern* keyword and argument. Replace the *filename-pattern* argument with the regular expression string. If this option is not used, then all files within the specified directory are displayed.

To search for files belonging to a specific user, use the *user-id* argument. If this option is not used, then files belonging to all users are displayed.

---

**Task ID**


---

**Task ID Operations**


---

 universal execute
 

---

In the following example, the **utility find** command is used to locate the file named “asr9k-fwdg-3.8.0”. The path is the root directory of disk0:.

```
RP/0/RP0/CPU0:router# utility find path disk0: name asr9k-fwdg-3.8.0

disk0:/instdb/admin_pkgs_mdata/asr9k-fwdg-3.8.0
disk0:/asr9k-fwdg-3.8.0
```

In the following example, the **utility find** command is used to locate files matching a pattern. In this example, all files ending in “.txt” are displayed:

```
RP/0/RSP0/CPU0:router# utility find path disk0:/usr name *.txt

disk0:/usr/test2.txt
```

In the following example, the UNIX equivalent option is used to locate files matching a pattern. In this example, all files ending in “.txt” are displayed:

```
RP/0/RSP0/CPU0:router# utility find path disk0: -name *.txt

disk0:/asr9k-base-3.8.0/etc/vim/doc/editing.txt
disk0:/asr9k-base-3.8.0/etc/vim/doc/help.txt
disk0:/asr9k-base-3.8.0/etc/vim/doc/intro.txt
disk0:/asr9k-base-3.8.0/etc/vim/doc/uganda.txt
disk0:/usr/test2.txt
```

In the following example, the files belonging to a specific user are displayed:

```
RP/0/RSP0/CPU0:router# utility find path disk0:/usr user 0

disk0:/usr
disk0:/usr/passwd
disk0:/usr/test2.txt
```

In the following example, the UNIX equivalent option is used to display files belonging to a specific user:

```
RP/0/RSP0/CPU0:router# utility find path disk0:/usr -user 0

disk0:/usr
disk0:/usr/passwd
disk0:/usr/test2.txt
```

**Related Commands**

Command	Description
<a href="#">utility which, on page 1111</a>	Locates a program file.

# utility head

To copy bytes or lines at the beginning of a file or from the standard input, use the **utility head** command in EXEC mode or administration EXEC mode.

**utilityhead**[{*WORD* | [**bytes**] [**count number**][**file source**] | **usage**}]

## Syntax Description

<b>WORD</b>	(Optional) UNIX command-line option string. The maximum number of characters is 80.
<b>bytes</b>	(Optional) ( <b>-c</b> ) Copies the data in bytes from the beginning of each specified file. The default setting is to copy lines of data.
<b>count number</b>	(Optional) ( <b>-n</b> ) Specifies the number of lines (default) or bytes to be copied. The <i>number</i> argument is an unsigned decimal integer.  By default, the <b>utility head</b> command copies the first ten units (lines or bytes) of the file. Use the <b>count number</b> option to change the default.
<b>file source</b>	(Optional) Specifies the storage device, directory, and filename for the files.  If a file is not specified, the standard input is used.
<b>usage</b>	(Optional) Displays the UNIX options supported by this command.

## Command Default

If the **utility head** command is entered without keywords or arguments, the first ten lines of the file or standard output are copied.

If no file is specified, then the standard input is used.

## Command Modes

EXEC, Admin EXEC

## Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	No modification.

## Usage Guidelines

The **utility head** command copies the beginning bytes (default) or lines of one or more files to the standard output (usually the user interface display). Use the **bytes** or **lines** keywords to copy the data based on lines or bytes. Use the **count number** option to specify the number of bytes or lines to copy. By default, the **utility head** command copies the first 10 lines of each file.

If more than one file is selected, an identifying header is added before the output for each file. If no file is specified, then the standard input (keyboard) is used.



**Note** Keywords are entered using the displayed syntax, or with UNIX-equivalent syntax. The UNIX-equivalent syntax is displayed in parentheses () in the syntax description. To display the UNIX-equivalent syntax online, enter the **usage** keyword.

In the following example, the **utility head** command is used to display the first 15 lines from the output of the **show version** command:

```
RP/0/RSP0/CPU0:router# show version | utility head count 15

Tue Jul 28 06:15:44.736 DST

Cisco IOS XR Software, Version 3.9.0.14I[DT_IMAGE]
Copyright (c) 2009 by Cisco Systems, Inc.

ROM: System Bootstrap, Version 1.1(20090521:183759) [ASR9K ROMMON],

PE44_ASR-9010 uptime is 1 week, 6 days, 14 hours, 54 minutes
System image file is "bootflash:disk0/asr9k-os-mpi-3.9.0.14I/mbiasr9k-rp.vm"

cisco ASR9K Series (MPC8641D) processor with 4194304K bytes of memory.
MPC8641D processor at 1333MHz, Revision 2.2

2 Management Ethernet
12 TenGigE
40 GigabitEthernet
```

In the following example, the **utility head** command is entered with the **bytes** keyword. Only the first 15 bytes of output are displayed.

```
RP/0/RSP0/CPU0:router# show version | utility head count 15 bytes

Cisco IOS XR S

RP/0/RSP0/CPU0:router#
```

# utility less

To display a file page-by-page, use the **utility less** command in EXEC mode or administration EXEC mode.

**utility less** {[**exitEOF**] [*WORD*] | **nocase** | **position** *line-number* | **startat** *string*} [**file** *source-file*]

## Syntax Description

<b>exitEOF</b>	(Optional) (-E) Automatically exits the utility the first time an end-of-file is encountered.
<i>WORD</i>	(Optional) UNIX command-line option string. The maximum number of characters is 80.
<b>nocase</b>	(Optional) (-i) Ignores uppercase and lowercase distinctions during comparisons.
<b>position</b> <i>line-number</i>	(Optional) (-j) Uses the line at <i>line-number</i> on the screen to position matched lines during a pattern search.
<b>startat</b> <i>string</i>	(Optional) (-p) Starts at the first occurrence of the pattern specified by the <i>string</i> argument in the file.
<b>file</b> <i>source-file</i>	(Optional) Specifies the storage device and directory path for the text file to be displayed. The default is standard input. The syntax for the <i>source-file</i> argument is: <i>device</i> :[/ <i>directory-path</i> ]/ <i>filename</i>

## Command Default

If no text file is specified, standard input is assumed.

## Command Modes

EXEC  
Administration EXEC

## Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	No modification.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **utility less** command to display files page by page. You can specify regular expressions for pattern matching using the **startat** keyword. You can scroll up as well as down. When you enter the less mode, commands are similar to the “vi” editor.



**Note** Keywords are entered using the displayed syntax, or with UNIX-equivalent syntax. The UNIX-equivalent syntax is displayed in parentheses () in the syntax description. To display the UNIX-equivalent syntax online, enter the **usage** keyword.

---

**Task ID**

---

**Task ID Operations**

---

universal execute

---

The following example, the **utility less** command is used to display the file “config_store”. Only part of the file is shown here.

```
RP/0/RSP0/CPU0:router# utility less file disk0:/usr/config_store
```

```
Last configuration change at Tue Feb 20 18:34:02 2007 by xxx
!
hostname H1
line console
 exec-timeout 600 0
 session-timeout 600
!
line default
 exec-timeout 600 0
 session-timeout 600
!
.
.
.
```

# utility mv

To rename or move a file from one directory to another, use the **utility mv** command in EXEC mode or administration EXEC mode.

**utility mv** *WORD* [**force** | **interactive**] **source** *source-file* **target** *target-file* | **usage**

Syntax Description		
<i>WORD</i>	(Optional) UNIX command-line option string. The maximum number of characters is 80.	
<b>force</b>	(Optional) (-f) Forces an overwrite if the target file already exists. There is no confirmation prompt.	
<b>interactive</b>	(Optional) (-i) Specifies to prompt for confirmation before renaming a file.	
<b>source</b> <i>source-file</i>	Specifies the storage device, directory, and filename for the file to be moved.	
<b>target</b> <i>target-file</i>	Specifies the new storage device, directory, and filename for the file.	
<b>usage</b>	(Optional) Displays the UNIX options supported by this command.	

**Command Default** No default behavior or values

**Command Modes** EXEC, Admin EXEC

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.



**Note** Keywords are entered using the displayed syntax, or with UNIX-equivalent syntax. The UNIX-equivalent syntax is displayed in parentheses () in the syntax description. To display the UNIX-equivalent syntax online, enter the **usage** keyword.

Task ID	Task ID	Operations
	universal	execute



In the following example, the **utility mv** command is used to move the file “aaa” from disk0a: to disk1a:

```
RP/0/RSP0/CPU0:router# utility mv source disk0a:/aaa target disk1a:/aaa
```

**Related Commands**

Command	Description
<a href="#">utility cut, on page 1072</a>	Cuts characters or lines from the output displayed from standard input or a file.
<a href="#">utility sort, on page 1102</a>	Sorts, merges, or sequence-checks the output displayed from standard input or a file.
<a href="#">utility tail, on page 1105</a>	Copies the end portion of the output displayed from standard input or a file.

# utility sort

To sort, merge, or sequence-check the lines in one or more files, or from the standard input, use the **utility sort** command in

EXEC mode or administration EXEC

mode.

**utility sort** {{{*WORD*}} | [[**dict**] [**fieldSep** *character*] [**ignoreblank**] [**key** *key-definition*] [**lowercase**] [**merge**] [**numeric**] [**outfile** *filename*] [**printable**] [**reverse**] [**unique**]]}] [**file** *filename*] | **usage**}

## Syntax Description

<b>WORD</b>	(Optional) UNIX command-line option string. The maximum number of characters is 80.
<b>dict</b>	(Optional) ( <b>-d</b> ) Sorts in dictionary order. Uses only alphanumeric and blank characters in the sort operation.
<b>fieldSep</b> <i>character</i>	(Optional) ( <b>-t</b> ) Specifies a character as the field separator.
<b>ignoreblank</b>	(Optional) ( <b>-b</b> ) Ignores leading blank characters in field comparisons.
<b>key</b> <i>key-definition</i>	(Optional) ( <b>-k</b> ) Defines a key to be the sort key. The <i>key-definition</i> argument field is defined using the following syntax: <i>field_start</i> [ <i>type_string</i> ] [, <i>field_end</i> ] [ <i>type_string</i> ] <ul style="list-style-type: none"> <li><i>field_start</i> and <i>field_end</i>—Specifies the beginning and end of the key field.</li> <li><i>type_string</i>—Specifies attributes specific to the key.</li> </ul> <p>The <i>field_start</i> and <i>field_end</i> arguments are each specified by a pair of digits of the form <i>m.n</i>, where the <i>m</i> refers to the field starting after the <i>m</i>th field separator in a line. For <i>field_start</i>, the <i>.n</i> refers to the <i>n</i>th character of the specified field, and is taken as zero if not specified. For <i>field_end</i>, the <i>.n</i> refers to the <i>n</i>th character after the last character of the specified field, and is taken as zero if not specified.</p> <p>The <i>type_string</i> argument may be formed from the characters <i>bdfinr</i>, which apply their defined attributes to the determination of the key.</p> <p><b>Note</b> When ordering options appear independent of key field specifications, the requested field ordering rules are applied globally to all sort keys. When attached to a specific key, the specified ordering options override all global ordering options for that key.</p>
<b>lowercase</b>	(Optional) ( <b>-f</b> ) Folds uppercase letters into lowercase (ignores case and treats upper case characters the same as lowercase characters).
<b>merge</b>	(Optional) ( <b>-m</b> ) Merges sorted files. Assumes that the files are already sorted and so does not sort the files.
<b>numeric</b>	(Optional) ( <b>-n</b> ) Interprets the field as numeric and sorts in numeric order. Includes the sign and optional thousands separator. This keyword also ignores leading blank characters in field comparisons (implies the <b>ignoreblank</b> keyword).

<b>outfile</b> <i>filename</i>	(Optional) <b>(-o)</b> Writes the results to a file. The <i>filename</i> argument is the destination disk, directory, and filename. The <i>filename</i> argument can be the same as the source file.
<b>printable</b>	(Optional) <b>(-i)</b> Ignores all nonprintable characters.
<b>reverse</b>	(Optional) <b>(-r)</b> Reverses the sort order. The sort is ascending by default.
<b>unique</b>	(Optional) <b>(-u)</b> Suppresses all but one line in each set of lines having equal keys.
<b>file</b> <i>filename</i>	(Optional) Specifies a file to be sorted.
<b>usage</b>	(Optional) Displays the UNIX options supported by this command.

**Command Default**

If no file is specified, then the standard input (keyboard) is used.

If an **outfile** *filename* keyword and argument is not specified, then the standard output (display) is used.

The file is sorted in ascending order.

**Command Modes**

EXEC, Admin EXEC

**Command History**

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	No modification.

**Usage Guidelines**

**Note** Keywords are entered using the displayed syntax, or with UNIX-equivalent syntax. The UNIX-equivalent syntax is displayed in parentheses () in the syntax description. To display the UNIX-equivalent syntax online, enter the **usage** keyword.

In the following example, the **utility sort** command is used to sort the contents of the file “words.txt”:

```
RP/0/RSP0/CPU0:router# utility sort file disk0:/usr/words.txt

The
few
inquires
A
Code.
Date
Done
This
best-selling
bestseller
book
come
concerning
fiction,
have
```

```
its
list
muscled
of
onto
our
the
way
way
work
```

In the following example, only the unique characters in the file “words.txt” are displayed:

```
RP/0/RSP0/CPU0:router# utility sort unique file disk0:/usr/words.txt
```

```
Code.
Date
best-selling
book
concerning
have
list
of
our
way
work
```

# utility tail

To copy the end portion of a file or the standard input, use the **utility tail** command in EXEC mode or administration EXEC mode.

**utility tail** {{{*WORD* | [**bytes**] [**continuous**] [**count number**]}} [file *input-file*] | **usage**}

## Syntax Description

<b>WORD</b>	(Optional) UNIX command-line option string. The maximum number of characters is 80.
<b>bytes</b>	(Optional) ( <b>-c</b> ) Copies the end of the file measured in bytes. The default is lines.
<b>continuous</b>	(Optional) ( <b>-f</b> ) Continues to copy data from the end of the file after the last line is reached. The operation pauses for 1 second, and then resumes in a continuous loop.  The input file must be a regular file, not a terminal or a FIFO special file (a named pipe).
<b>count number</b>	(Optional) ( <b>-n</b> ) Copies the number of lines (default) or bytes specified with the <i>number</i> argument. The range is 0 to 4294967295. By default, the last 10 lines are copied.  The <i>number</i> argument is a decimal integer that defines the location in the file to begin copying: <ul style="list-style-type: none"> <li>• Include the plus (+) character to copy from the beginning of the file.</li> <li>• Include the minus (-) character to copy from the end of the file.</li> <li>• Do not include a character to copy from the end of the file.</li> </ul> <p><b>Note</b> Select the <b>bytes</b> keyword to copy the information measured in a count of bytes.</p>
<b>file input-file</b>	(Optional) Directory path and filename for the input file. If no file is specified, then the standard input is used.  The syntax for the <i>input-file</i> argument is: <i>device</i> :[/ <i>directory-path</i> ]/ <i>filename</i>  The <i>device</i> argument, followed by a colon, indicates the name of the device where the file is located. Use the online help (?) function to display the available storage devices and network protocols.
<b>usage</b>	(Optional) Displays the UNIX options supported by this command.

## Command Default

If the **utility tail** command is entered without keywords or arguments, the last 10 lines of the standard input are copied.

## Command Modes

EXEC, Admin EXEC

## Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	No modification.

**Usage Guidelines**

Use the **utility tail** command to copy data from the end of a file. By default, the last 10 lines are copied. Use the **bytes** keyword to copy the data measured in bytes. Use the **count** *number* option to define the number of lines or bytes to copy. Use the **file** *filename* option to specify an input file.

**Note**

Keywords are entered using the displayed syntax, or with UNIX-equivalent syntax. The UNIX-equivalent syntax is displayed in parentheses () in the syntax description. To display the UNIX-equivalent syntax online, enter the **usage** keyword.

In the following example, the **utility tail** command is used to display the last 10 lines of the output from the **show version** command:

```
RP/0/RSP0/CPU0:router# show version | utility tail count 10

Wed Feb 11 11:18:34.396 PST
 By sjc5-gf-016.cisco.com in /auto/ioxbuild5/production/3.8.0.25I.SIT_IMAGE/asr9k/workspace
 for c4.2.1-p0

asr9k-base, V 3.8.0.25I[SIT_IMAGE], Cisco Systems, at disk0:asr9k-base-3.8.0.25I
 Built on Thu Nov 27 05:50:08 PST 2008
 By sjc5-gf-016.cisco.com in /auto/ioxbuild5/production/3.8.0.25I.SIT_IMAGE/asr9k/workspace
 for c4.2.1-p0

asr9k-os-mpi, V 3.8.0.25I[SIT_IMAGE], Cisco Systems, at disk0:asr9k-os-mpi-3.8.0.25I
 Built on Thu Nov 27 05:26:17 PST 2008
 By sjc5-gf-016.cisco.com in /auto/ioxbuild5/production/3.8.0.25I.SIT_IMAGE/asr9k/workspace
 for c4.2.1-p0
```

In the following example, the **utility tail** command is used with the **bytes** keyword to display the last 10 bytes in the output:

```
RP/0/RSP0/CPU0:router# show version | utility tail count 10 bytes

.95.3-p8

RP/0/RSP0/CPU0:router#
```

# utility uniq

To display or remove repeated lines in a file, use the **utility uniq** command in EXEC mode or administration EXEC mode.

**utility uniq** [{{{*WORD*}}|[**afterChars** *number*] [**afterField** *number*] [**count**] [{**nonrepeating** | **repeating**}]}] [**infile** *input-file* **outfile** *output-file*]| **usage**}}

Syntax Description	
<b>WORD</b>	(Optional) UNIX command-line option string. The maximum number of characters is 80.
<b>afterChars</b> <i>number</i>	(Optional) ( <b>-s</b> ) Ignores the first characters on each line of the input file. Use the <i>number</i> argument to specify the number of characters. The range is 0 to 4294967295.
<b>afterField</b> <i>number</i>	(Optional) ( <b>-f</b> ) Ignores the first fields on each line of the input file. Use the <i>number</i> argument to specify the number of fields. The range is 0 to 4294967295.
<b>count</b>	(Optional) ( <b>-c</b> ) Displays the number of times the line appeared in the input file at the beginning of each output line.
<b>nonrepeating</b>	(Optional) ( <b>-u</b> ) Displays only the nonrepeating lines from the input file (repeating lines are not displayed).
<b>repeating</b>	(Optional) ( <b>-d</b> ) Displays only the repeating lines from the input file (nonrepeating lines are not displayed).
<b>infile</b> <i>input-file</i>	(Optional) Specifies an input file for processing. The <i>input-file</i> argument specifies the device, directory, and filename of the input file. If no input file is specified, then the standard input (keyboard) is used.  The syntax of the <i>input-file</i> argument is: <i>device</i> :[/ <i>directory-path</i> ]/ <i>filename</i> .  The <i>device</i> argument, followed by a colon, indicates the name of the device where the file is located. Use the online help (?) function to display the available storage devices and network protocols.
<b>outfile</b> <i>output-file</i>	(Optional) Specifies an output file. The <i>output-file</i> argument specifies the device, directory, and filename of the output file. If no file is specified, then the standard output (display) is used.  The syntax of the <i>output-file</i> argument is: <i>device</i> :[/ <i>directory-path</i> ]/ <i>filename</i> .  The <i>device</i> argument, followed by a colon, indicates the name of the device where the file is located. Use the online help (?) function to display the available storage devices and network protocols.
<b>usage</b>	(Optional) Displays the UNIX options supported by this command.

## Command Default

If no input file is specified, then the standard input is used.

If no output file is specified, then the standard output is used.

---

**Command Modes** EXEC, Admin EXEC

---

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

---



---

**Usage Guidelines** Use the **utility uniq** command to display only lines that are repeated in a file, or to display only lines that appear once. This utility compares only adjacent lines, so the file or standard input must be sorted.



**Note** Keywords are entered using the displayed syntax, or with UNIX-equivalent syntax. The UNIX-equivalent syntax is displayed in parentheses () in the syntax description. To display the UNIX-equivalent syntax online, enter the **usage** keyword.

---

In the following example, the **utility uniq** command is used to display the repeating lines in the output of the **show environment** command:

```
RP/0/RSP0/CPU0:router# show environment | utility uniq repeating
host 5V 4500,5500 4250,5750 4000,6000
fabricq 1.25V 1125,1375 1063,1438 1000,1500
fabricq 1.25V 1125,1375 1063,1438 1000,1500
ingress 1.25V 1125,1375 1063,1438 1000,1500
spa5 1.5V 1500,0 1575,1425 0,0
host 5V 4500,5500 4250,5750 4000,6000
fabricq 1.25V 1125,1375 1063,1438 1000,1500
fabricq 1.25V 1125,1375 1063,1438 1000,1500
ingress 1.25V 1125,1375 1063,1438 1000,1500
spa5 1.5V 1500,0 1575,1425 0,0
```



# utility wc

To count words, lines, or bytes in a file, use the **utility wc** command in EXEC mode or administration EXEC mode.

**utility wc** [{{{*WORD*}} | [**bytes**] [**lines**] [**words**]}] [**file** *input-file*] | **usage**}]

## Syntax Description

<b>WORD</b>	(Optional) UNIX command-line option string. The maximum number of characters is 80.
<b>bytes</b>	(Optional) ( <b>-c</b> ) Displays the number of bytes in each input file.
<b>lines</b>	(Optional) ( <b>-l</b> ) ( <b>-œel-?</b> ) Displays the number of lines in each input file.
<b>words</b>	(Optional) ( <b>-w</b> ) Displays the number of words in each input file.
<b>file</b> <i>input-file</i>	(Optional) Specifies the input file. The <i>input-file</i> argument specifies the device, directory, and filename of the input file. If no input file is specified, then the standard input (keyboard) is used.  The syntax of the <i>input-file</i> argument is: <i>device</i> :[/ <i>directory-path</i> ]/ <i>filename</i> .  The <i>device</i> argument, followed by a colon, indicates the name of the device where the file is located. Use the online help (?) function to display the available storage devices and network protocols.
<b>usage</b>	(Optional) Displays the UNIX options supported by this command.

## Command Default

Output is displayed in the order bytes, words, and lines, even if the options are entered in a different order.

## Command Modes

EXEC, Administration EXEC

## Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	No modification.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Output is displayed in the following order:

- When keywords are entered, the output appears in the order bytes, words, and lines.
- When no keyword is entered, the output appears in the order lines, words, and bytes.
- When any UNIX equivalent options are entered, the output appears in the order specified by the options. For example, if the command **utility wc -w -l -c** is entered, the output appears in the order words, lines, and bytes.



**Note** Keywords are entered using the displayed syntax, or with UNIX-equivalent syntax. The UNIX-equivalent syntax is displayed in parentheses () in the syntax description. To display the UNIX-equivalent syntax online, enter the **usage** keyword.

**Task ID****Task ID Operations**

universal execute

In the following example, the **utility wc** command is issued to display the number of lines, words, and bytes in the output of the **show version** command:

```
RP/0/RSP0/CPU0:router# show version | utility wc
 221 1160 10820
```

The output displays the following:

- 221 lines
- 1160 words
- 10820 bytes

In the following example, the **utility wc** command is entered with the **words** keyword to display the number of words in the output of the **show version** command:

```
RP/0/RSP0/CPU0:router# show version | utility wc words
 1160
```

# utility which

To locate a program file, use the **utility which** command in EXEC mode or administration EXEC mode.

**utility which** {{{*WORD*}} | [**all**] [**fullname**] [**long** [*link*]]} **program** *program-name* | **usage**}

<b>Syntax Description</b>	<i>WORD</i>	(Optional) UNIX command-line option string. The maximum number of characters is 80.
	<b>all</b>	(Optional) ( <b>-a</b> ) Displays all occurrences of the program specified by the <b>program</b> <i>pathname</i> keyword and argument.
	<b>fullname</b>	(Optional) ( <b>-f</b> ) Displays the full pathname of the program file.
	<b>long</b> [ <i>link</i> ]	(Optional) ( <b>-l</b> ) (“el”) Displays the long format for each program found, and also displays link information if the file is a symlink.
	<b>program</b> <i>program-name</i>	Specifies the name of the program file.
	<b>usage</b>	(Optional) Displays the UNIX options supported by this command.

**Command Default** None

**Command Modes** EXEC, Admin EXEC

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.



**Note** Keywords are entered using the displayed syntax, or with UNIX-equivalent syntax. The UNIX-equivalent syntax is displayed in parentheses () in the syntax description. To display the UNIX-equivalent syntax online, enter the **usage** keyword.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	universal	execute

In the following example, the **utility which** command is entered without keywords or arguments to display the location of the perl program:

```
RP/0/RSP0/CPU0:router# utility which program perl

/pkg/bin/perl
```

In the following example, the **utility which** command is entered with the **fullname** keyword to display the full directory path of the perl program:

```
RP/0/RSP0/CPU0:router# utility which fullname program perl

/disk0:/asr9k-base-3.8.0.1I/sbin/perl
```

In the following example, the **utility which** command is entered with the **long** keyword to display additional details about the perl program file:

```
RP/0/RSP0/CPU0:router# utility which long program perl

-rwxrwxrwx 1 0 0 19245 Jul 28 14:31 /pkg/bin/perl
```

#### Related Commands

Command	Description
<a href="#">utility find, on page 1093</a>	Locates a file.

# utility xargs

To run a program from one or more argument lists, use the **utility xargs** command in EXEC mode or administration EXEC mode.

**utility xargs** [{{{*WORD* | **trace**}}] [**program** [*program-name*] [*initial-arguments*]] | **usage**}]

Syntax Description		
	<i>WORD</i>	(Optional) UNIX command-line option string. The maximum number of characters is 80.
	<b>trace</b>	(Optional) (-t) Prints each program on standard error before executing.
	<b>program</b>	(Optional) Specifies the name of the program and initial arguments. If a program name is not specified, then the echo utility is used.
	<i>program-name</i>	(Optional) Specifies the name of the program. If a program name is not specified, then the echo utility is used.
	<i>initial-arguments</i>	(Optional) Specifies the initial arguments.
	<b>usage</b>	(Optional) Displays the UNIX options supported by this command.

**Command Default** If no program is specified, then the echo utility is used (the input lines are displayed).

**Command Modes** EXEC, Administration EXEC

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	No modification.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.



**Note** Keywords are entered using the displayed syntax, or with UNIX-equivalent syntax. The UNIX-equivalent syntax is displayed in parentheses () in the syntax description. To display the UNIX-equivalent syntax online, enter the **usage** keyword.

Task ID	Task ID	Operations
	universal	execute

In the following example, the **utility xargs** command is used to display the egress lines:

```
RP/0/RSP0/CPU0:router# more disk0:/usr/files | utility xargs program grep EGRESS

disk0:/usr/atm.cfg:service-policy output EGRESS-GigabitEthernet0-0-0-0-101
disk0:/usr/atm.cfg:service-policy output EGRESS-GigabitEthernet0-0-0-0-102
disk0:/usr/atm.cfg:service-policy output EGRESS-GigabitEthernet0-0-0-0-103
disk0:/usr/atm.cfg:service-policy output EGRESS-GigabitEthernet0-0-0-0-104
disk0:/usr/atm.cfg:service-policy output EGRESS-GigabitEthernet0-0-0-0-105
disk0:/usr/atm.cfg:service-policy output EGRESS-GigabitEthernet0-0-0-0-106
disk0:/usr/atm.cfg:service-policy output EGRESS-GigabitEthernet0-0-0-0-107
disk0:/usr/atm.cfg:service-policy output EGRESS-GigabitEthernet0-0-0-0-108
disk0:/usr/atm.cfg:service-policy output EGRESS-common
disk0:/usr/atm.cfg:service-policy output EGRESS-common
disk0:/usr/atm.cfg:service-policy output EGRESS-common
disk0:/usr/atm.cfg:service-policy output EGRESS-common
disk0:/usr/atm.cfg:service-policy output EGRESS-common
.....
```