



Cisco MDS 9000 Family NX-OS Fundamentals Configuration Guide

First Published: 2013-04-09

Last Modified: 2013-04-09

Americas Headquarters

Cisco Systems, Inc.
170 West Tasman Drive
San Jose, CA 95134-1706
USA
<http://www.cisco.com>
Tel: 408 526-4000
800 553-NETS (6387)
Fax: 408 527-0883

Text Part Number: OL-29291-02



CONTENTS

PREFACE

Preface	xiii
Audience	xiii
Document Conventions	xiii
Related Documentation	xiv
Communications, Services, and Additional Information	xvi

CHAPTER 1

New and Changed Information	1
New and Changed Information	1

CHAPTER 2

Overview	5
Software Compatibility	5
Modular Software Design	5
Serviceability	5
Switched Port Analyzer	6
Call Home	6
Online Diagnostics	6
Embedded Event Manager	6
Manageability	6
Simple Network Management Protocol	6
Role-Based Access Control	6
Cisco NX-OS Software Configuration	7
Tools for Software Configuration	7
CLI	7
NTP	7
Licensing	9
Quality of Service	9

CHAPTER 3	Using the Cisco NX-OS Setup Utility	11
	Information About the Cisco NX-OS Setup Utility	11
	Prerequisites for the Setup Utility	13
	Initial Setup Routine	13
	Configuring Out-of-Band Management	13
	Configuring In-Band Management	19
	Where to Go Next	25

CHAPTER 4	Using PowerOn Auto Provisioning	27
	Using Power On Auto Provisioning	27
	About Power On Auto Provisioning	27
	POAP Configuration Script	28
	Guidelines and Limitations for POAP Configuration	28
	Network Infrastructure Requirements for POAP	28
	Setting Up the Network Environment to use POAP	29
	The POAP Process	31
	The Power-Up Phase	32
	The USB Discovery Phase	32
	The DHCP Discovery Phase	33
	Script Execution Phase	34
	Post-Installation Reload Phase	34
	Configuring a Switch Using POAP	35
	Verifying the Device Configuration	35

CHAPTER 5	Understanding the Command-Line Interface	37
	Information About the CLI Prompt	37
	Command Modes	38
	EXEC Command Mode	38
	Global Configuration Command Mode	38
	Interface Configuration Command Mode	39
	Subinterface Configuration Command Mode	39
	Saving and Restoring a Command Mode	40
	Command Mode Summary	40

Special Characters	41
Keystroke Shortcuts	41
Abbreviating Commands	43
Completing a Partial Command Name	44
Identifying Your Location in the Command Hierarchy	44
Using the no Form of a Command	45
Configuring CLI Variables	46
About CLI Variables	46
Configuring CLI Session-Only Variables	47
Configuring Persistent CLI Variables	47
Command Aliases	48
About Command Aliases	48
Defining Command Aliases	49
Configuring Command Aliases for a User Session	49
Command Scripts	50
Running a Command Script	50
Echoing Information to the Terminal	50
Delaying Command Action	51
Context-Sensitive Help	52
Understanding Regular Expressions	53
Special Characters	53
Multiple-Character Patterns	54
Anchoring	54
Searching and Filtering show Command Output	55
Filtering and Searching Keywords	55
diff Utility	57
grep and egrep Utilities	57
less Utility	58
sed Utility	58
sort Utility	58
Redirecting show Command Output Using sscp	59
Searching and Filtering from the --More-- Prompt	59
Using the Command History	60
Recalling a Command	60

Configuring the CLI Edit Mode	61
Controlling CLI History Recall	61
Displaying the Command History	61
Enabling or Disabling the CLI Confirmation Prompts	62
Setting CLI Display Colors	62
Sending Commands to Modules	63
BIOS Loader Prompt	64
Examples Using the CLI	64
Defining Command Aliases	64
Using CLI Session Variables	64
Using the System-Defined Timestamp Variable	65
Running a Command Script	65
Using the sscp Utility to Redirect show Command Output	66

CHAPTER 6**Configuring Terminal Settings and Sessions 67**

Information About Terminal Settings and Sessions	67
Terminal Session Settings	67
Console Port	67
COM1 Port	68
Virtual Terminals	68
Modem Support	68
Configuring the Console Port	69
Configuring the COM1 Port	71
Configuring Virtual Terminals	72
Configuring the Inactive Session Timeout	72
Configuring the Session Limit	74
Configuring Modem Connections	75
Enabling a Modem Connection	75
Downloading the Default Initialization String	76
Configuring and Downloading a User-Specified Initialization String	77
Initializing a Modem for a Powered-Up Cisco NX-OS Device	78
Clearing Terminal Sessions	79
Displaying Terminal and Session Information	79
Default Settings for Terminal Display and Session Parameters	80

CHAPTER 7**Basic Device Management 83**

- Information About Basic Device Management 83
 - Device Hostname 83
 - Interface 83
 - Default Gateway 84
 - Message-of-the-Day Banner 84
 - Device Clock 84
 - Time Zone and Summer Time (Daylight Saving Time) 85
 - User Sessions 85
 - Telnet Server Connection 85
- Changing the Device Hostname 85
- Configuring the Management Interface 86
- Configuring the Default Gateway 87
- Configuring the MOTD Banner 88
- Configuring the Time Zone 89
- Configuring Summer Time (Daylight Saving Time) 90
- Manually Setting the Device Clock 91
- Managing Users 92
 - Displaying Information about the User Sessions 92
 - Sending a Message to Users 92
- Enabling or Disabling a Telnet Server Connection 93
- Verifying the Device Configuration 93
- Default Settings for Basic Device Parameters 94

CHAPTER 8**Using the Device File Systems, Directories, and Files 95**

- Information About Device File Systems, Directories, Files, and External Storage Devices 95
 - File Systems 95
 - Directories 96
 - Files 96
- Working with External Storage Devices 97
 - Formatting an External Flash Device 97
 - Mounting or Unmounting a USB Drive 97
 - External Storage Device Support Matrix 97

Working with Directories	98
Identifying the Current Directory	98
Changing the Current Directory	99
Creating a Directory	99
Displaying Directory Contents	99
Deleting a Directory	99
Accessing the Directories on a Standby Supervisor Module	100
Working with Files	100
Moving a File	100
Copying a File	101
Deleting a File	101
Displaying a File's Contents	101
Displaying a File's Checksums	102
Compressing and Uncompressing a File	102
Displaying the Last Lines in a File	103
Redirecting show Command Output to a File	103
Finding Files	103
Working with Archive Files	103
Creating an Archive File	103
Appending Files to an Archive File	104
Extracting Files from an Archive File	105
Displaying the Filenames in an Archive File	105
Examples of Using a File System	105
Accessing Directories on a Standby Supervisor Module	106
Performing ISSU or ISSD Using a USB Drive	106
<hr/>	
CHAPTER 9	Working with Configuration Files 107
	Information About Configuration Files 107
	Types of Configuration Files 107
	Managing Configuration Files 108
	Saving the Running Configuration to the Startup Configuration 108
	Copying a Configuration File to a Remote Server 108
	Downloading the Running Configuration From a Remote Server 109
	Downloading the Startup Configuration From a Remote Server 110

Copying Configuration Files to an External Flash Memory Device	111
Copying the Running Configuration from an External Flash Memory Device	112
Copying the Startup Configuration from an External Flash Memory Device	113
Copying Configuration Files to an Internal File System	114
Rolling Back to a Previous Configuration	115
Removing the Configuration for a Missing Module	116
Erasing a Configuration	116
Verifying the Device Configuration	117
Examples of Working with Configuration Files	118
Copying Configuration Files	118
Backing Up Configuration Files	118
Rolling Back to a Previous Configuration	118

CHAPTER 10**Configuring CDP 121**

Information About CDP	121
CDP Overview	121
High Availability for CDP	122
Configuring CDP	122
Enabling or Disabling CDP Globally	122
Enabling or Disabling CDP on an Interface	122
Configuring Optional CDP Parameters	123
Verifying the CDP Configuration	124
Clearing CDP Counters and Tables	124
CDP Example Configuration	125
Default Settings for CDP	125

CHAPTER 11**Configuring NTP 127**

Information About NTP	127
NTP	127
Prerequisites for NTP	128
Guidelines and Limitations for NTP	129
Configuring NTP	129
Enabling NTP	129
Disabling NTP	129

Configuring Authentication Keys	130
Enabling Authentication of Temporary, Symmetric, Broadcast, or Multicast NTP Associations	130
Disabling Authentication of Temporary, Symmetric, Broadcast, or Multicast NTP Associations	131
Enabling NTP Servers and Peers	131
Disabling NTP Servers and Peers	132
Enabling NTP Modes	132
Disabling NTP Modes	133
Enabling NTP Source Interface	133
Disabling NTP Source Interface	133
Enabling NTP Logging	134
Disabling NTP Logging	134
Configuring NTP Syslog Logging Level	134
Setting the Default NTP Syslog Severity Logging Level	135
Displaying and Clearing NTP Statistics	135
Resynchronizing NTP	136
Distributing the NTP Configuration Using CFS	136
Enabling NTP Configuration Distribution	136
Disabling NTP Configuration Distribution	137
Committing NTP Configuration Changes	137
Discarding NTP Configuration Changes	137
Forcing Termination of a Lost NTP Configuration Session	138
Verifying NTP	138
Troubleshooting NTP	139
Example: Configuring NTP	141
Default Settings for NTP	143

CHAPTER 12

Managing System Hardware	145
Displaying Switch Hardware Inventory	145
Running CompactFlash Tests	149
Displaying the Switch Serial Number	149
Displaying Power Usage Information	150
Power Supply Modes	151
Configuration Guidelines for Power Supplies	151
Configuring the Power Supply Mode	159

About Module Temperature Monitoring	159
Displaying Module Temperatures	160
About Fan Modules	162
Displaying Environment Information	163
Default Settings	165

CHAPTER 13
Managing Modules 167

About Modules	167
Supervisor Modules	168
Switching Modules	169
Services Modules	170
Maintaining Supervisor Modules	170
Replacing Supervisor Modules	170
Standby Supervisor Module Boot Variable Version	170
Standby Supervisor Module Bootflash Memory	170
Standby Supervisor Module Boot Alert	170
Verifying the Status of a Module	171
Checking the State of a Module	172
Connecting to a Module	172
Reloading Modules	173
Reloading a Switch	173
Power Cycling Modules	173
Reloading Switching Modules	174
Saving the Module Configuration	174
Purging Module Configurations	175
Powering Off Switching Modules	176
Identifying Module LEDs	177
EPLD Images	182
Upgrading EPLD Images	183
Displaying EPLD Image Versions	187
SSI Boot Images	188
Installing the SSI Boot Image	188
Upgrading or Downgrading the SSI Boot Image	190
SSI Boot Image Upgrade Considerations for the SSM	190

Verifying the SSI Boot Image	191
Using the install ssi Command	194
Managing SSMs and Supervisor Modules	197
Configuring SSM and MSM Global Upgrade Delay	197
Guidelines for Replacing SSMs and Supervisor Modules	197
Recovering an SSM After Replacing Corrupted CompactFlash Memory	198
Guidelines for Upgrading and Downgrading Cisco MDS NX-OS Releases	199
Default Settings	201



Preface

This preface describes the audience, organization, and conventions of the *Cisco MDS 9000 Family NX-OS Fundamentals Configuration Guide*. It also provides information on how to obtain related documentation.

- [Audience, on page xiii](#)
- [Document Conventions, on page xiii](#)
- [Related Documentation, on page xiv](#)
- [Communications, Services, and Additional Information, on page xvi](#)

Audience

This guide is for experienced network administrators who are responsible for configuring and maintaining the Cisco MDS 9000 Family of multilayer directors and fabric switches.

Document Conventions



Note

As part of our constant endeavor to remodel our documents to meet our customers' requirements, we have modified the manner in which we document configuration tasks. As a result of this, you may find a deviation in the style used to describe these tasks, with the newly included sections of the document following the new format.

Command descriptions use the following conventions:

Convention	Description
bold	Bold text indicates the commands and keywords that you enter literally as shown.
<i>Italic</i>	Italic text indicates arguments for which the user supplies the values.
[x]	Square brackets enclose an optional element (keyword or argument).
[x y]	Square brackets enclosing keywords or arguments separated by a vertical bar indicate an optional choice.

Convention	Description
{x y}	Braces enclosing keywords or arguments separated by a vertical bar indicate a required choice.
[x {y z}]	Nested set of square brackets or braces indicate optional or required choices within optional or required elements. Braces and a vertical bar within square brackets indicate a required choice within an optional element.
<i>variable</i>	Indicates a variable for which you supply values, in context where italics cannot be used.
string	A nonquoted set of characters. Do not use quotation marks around the string or the string will include the quotation marks.

Examples use the following conventions:

Convention	Description
<code>screen font</code>	Terminal sessions and information the switch displays are in screen font.
boldface screen font	Information you must enter is in boldface screen font.
<i>italic screen font</i>	Arguments for which you supply values are in italic screen font.
<>	Nonprinting characters, such as passwords, are in angle brackets.
[]	Default responses to system prompts are in square brackets.
!, #	An exclamation point (!) or a pound sign (#) at the beginning of a line of code indicates a comment line.

This document uses the following conventions:



Note

Means *reader take note*. Notes contain helpful suggestions or references to material not covered in the manual.



Caution

Means *reader be careful*. In this situation, you might do something that could result in equipment damage or loss of data.

Related Documentation

The documentation set for the Cisco MDS 9000 Series includes the following documents. To find a document online, use the Cisco MDS NX-OS Documentation Locator at:

http://www.cisco.com/en/US/docs/storage/san_switches/mds9000/roadmaps/doclocator.htm

Cisco DCNM documentation is available at the following URL:

http://www.cisco.com/en/US/products/ps9369/tsd_products_support_series_home.html

Release Notes

- *Cisco MDS 9000 Series Release Notes for Cisco MDS NX-OS Releases*
- *Cisco MDS 9000 Series Release Notes for MDS SAN-OS Releases*
- *Cisco MDS 9000 Series Release Notes for Storage Services Interface Images*
- *Cisco MDS 9000 Series Release Notes for Cisco MDS 9000 EPLD Images*
- *Cisco Data Center Network Manager Release Notes*

Regulatory Compliance and Safety Information

Regulatory Compliance and Safety Information for the Cisco MDS 9000 Series

Compatibility Information

- *Cisco Data Center Interoperability Support Matrix*
- *Cisco MDS 9000 NX-OS Hardware and Software Compatibility Information and Feature Lists*
- *Cisco MDS NX-OS Release Compatibility Matrix for Storage Service Interface Images*
- *Cisco MDS 9000 Series Switch-to-Switch Interoperability Configuration Guide*
- *Cisco MDS NX-OS Release Compatibility Matrix for IBM SAN Volume Controller Software for Cisco MDS 9000*

Hardware Installation

- *Cisco MDS 9700 Director Hardware Installation Guide*
- *Cisco MDS 9500 Series Hardware Installation Guide*
- *Cisco MDS 9250i Multiservice Switch Hardware Installation Guide*
- *Cisco MDS 9200 Series Hardware Installation Guide*

Software Installation and Upgrade

- *Cisco MDS 9000 Series Storage Services Interface Image Install and Upgrade Guide*
- *Cisco MDS 9000 Series Storage Services Module Software Installation and Upgrade Guide*
- *Cisco MDS 9000 NX-OS Release 4.1(x) and SAN-OS 3(x) Software Upgrade and Downgrade Guide*

Cisco NX-OS

- *Cisco MDS 9000 Series NX-OS Fundamentals Configuration Guide*
- *Cisco MDS 9000 Series NX-OS Licensing Guide*
- *Cisco MDS 9000 Series NX-OS System Management Configuration Guide*
- *Cisco MDS 9000 Series NX-OS Interfaces Configuration Guide*

- *Cisco MDS 9000 Series NX-OS Fabric Configuration Guide*
- *Cisco MDS 9000 Series NX-OS Quality of Service Configuration Guide*
- *Cisco MDS 9000 Series NX-OS Security Configuration Guide*
- *Cisco MDS 9000 Series NX-OS IP Services Configuration Guide*
- *Cisco MDS 9000 Series NX-OS Intelligent Storage Services Configuration Guide*
- *Cisco MDS 9000 Series NX-OS High Availability and Redundancy Configuration Guide*
- *Cisco MDS 9000 Series NX-OS Inter-VSAN Routing Configuration Guide*

Command-Line Interface

Cisco MDS 9000 Series Command Reference

Intelligent Storage Networking Services Configuration Guides

- *Cisco MDS 9000 I/O Acceleration Configuration Guide*
- *Cisco MDS 9000 Series SANTap Deployment Guide*
- *Cisco MDS 9000 Series Data Mobility Manager Configuration Guide*
- *Cisco MDS 9000 Series Storage Media Encryption Configuration Guide*
- *Cisco MDS 9000 Series Secure Erase Configuration Guide*
- *Cisco MDS 9000 Series Cookbook for Cisco MDS SAN-OS*

Troubleshooting and Reference

- *Cisco NX-OS System Messages Reference*
- *Cisco MDS 9000 Series NX-OS Troubleshooting Guide*
- *Cisco MDS 9000 Series NX-OS MIB Quick Reference*
- *Cisco MDS 9000 Series NX-OS SMI-S Programming Reference*
- *Cisco DCNM for SAN Database Schema Reference*

Communications, Services, and Additional Information

- To receive timely, relevant information from Cisco, sign up at [Cisco Profile Manager](#).
- To get the business impact you're looking for with the technologies that matter, visit [Cisco Services](#).
- To submit a service request, visit [Cisco Support](#).
- To discover and browse secure, validated enterprise-class apps, products, solutions and services, visit [Cisco Marketplace](#).
- To obtain general networking, training, and certification titles, visit [Cisco Press](#).

- To find warranty information for a specific product or product family, access [Cisco Warranty Finder](#).

Cisco Bug Search Tool

[Cisco Bug Search Tool](#) (BST) is a web-based tool that acts as a gateway to the Cisco bug tracking system that maintains a comprehensive list of defects and vulnerabilities in Cisco products and software. BST provides you with detailed defect information about your products and software.



CHAPTER 1

New and Changed Information

This chapter provides release-specific information for each new and changed feature in the *Cisco MDS 9000 Series NX-OS Fundamentals Configuration Guide*. The latest version of this document is available at the following Cisco website:

http://www.cisco.com/en/US/products/ps5989/products_installation_and_configuration_guides_list.html

- [New and Changed Information, on page 1](#)

New and Changed Information

As of Cisco MDS NX-OS Release 4.2(1), software configuration information is available in new feature-specific configuration guides for the following information:

- System management
- Interfaces
- Fabric
- Quality of service
- Security
- IP services
- High availability and redundancy

The information in these new guides previously existed in the *Cisco MDS 9000 Family CLI Configuration Guide* and in the *Cisco MDS 9000 Family Fabric Manager Configuration Guide*. Those configuration guides remain available on Cisco.com and should be used for all software releases prior to MDS NX-OS Release 4.2(1). Each guide addresses the features introduced in or available in a particular release. Select and view the configuration guide that pertains to the software installed in your switch.

To find additional information about Cisco NX-OS Release 6.2, see [Cisco MDS 9000 Series NX-OS Release Notes](#).

This table summarizes the new and changed features for the *Cisco MDS 9000 Series NX-OS Fundamentals Configuration Guide*, and tells you where they are documented.

Table 1: New and Changed Features for Release 6.2

Feature	Description	Changed in Release	Where Documented
POAP	PowerOn Auto Provisioning (POAP) automates the process of upgrading software images and installing configuration files on the Cisco MDS 9148, 9148S, and 9396S Multilayer Fabric Switches.	6.2(9)	Using PowerOn Auto Provisioning, on page 27
diff utility	Allows comparison of command outputs.	4.2(1)	Understanding the Command-Line Interface, on page 37
Command aliases	Can be used in show command searching and filtering. Allows command aliases for users sessions.	4.2(1)	Understanding the Command-Line Interface, on page 37
Streaming secure copy (scp)	Allows redirection of command output to SSH sessions on remote servers.	4.2(1)	Understanding the Command-Line Interface, on page 37
I/O module commands	Allows sending commands directly to a module from the supervisor module session.	4.2(1)	Understanding the Command-Line Interface, on page 37
Command history	Provides changes to the show cli history command.	4.2(1)	Understanding the Command-Line Interface, on page 37
Command modes	Allows saving and restoring of command modes.	4.2(1)	Understanding the Command-Line Interface, on page 37
Confirmation prompts	Allows enabling and disabling for command confirmation prompts.	4.2(1)	Understanding the Command-Line Interface, on page 37

Feature	Description	Changed in Release	Where Documented
Terminal colors	Allowed changes to the colors used for CLI elements in the terminal display.	4.2(1)	Understanding the Command-Line Interface, on page 37



CHAPTER 2

Overview

This chapter provides an overview of the Cisco NX-OS software.

- [Software Compatibility](#), on page 5
- [Serviceability](#), on page 5
- [Manageability](#), on page 6
- [Cisco NX-OS Software Configuration](#), on page 7
- [Licensing](#), on page 9
- [Quality of Service](#), on page 9

Software Compatibility

The Cisco NX-OS software interoperates with Cisco products that run any variant of the Cisco IOS software. The Cisco NX-OS software also interoperates with any networking operating system that conforms to the IEEE and RFC compliance standards.

Modular Software Design

The Cisco NX-OS software supports distributed multithreaded processing on symmetric multiprocessors (SMPs), multi-core CPUs, and distributed data module processors. The Cisco NX-OS software offloads computationally intensive tasks, such as hardware table programming, to dedicated processors distributed across the data modules. The modular processes are created on demand, each in a separate protected memory space. Processes are started and system resources are allocated only when you enable a feature. A real-time preemptive scheduler helps to ensure the timely processing of critical functions.

Serviceability

The Cisco NX-OS software has serviceability functions that allow the device to respond to network trends and events. These features help you with network planning and improving response times.

Switched Port Analyzer

The Switched Port Analyzer (SPAN) feature allows you to analyze all traffic between ports (called the SPAN source ports) by nonintrusively directing the SPAN session traffic to a SPAN destination port that has an external analyzer attached to it. For more information about SPAN, see the .

Call Home

The Call Home feature continuously monitors hardware and software components to provide e-mail-based notification of critical system events. A versatile range of message formats is available for optimal compatibility with pager services, standard e-mail, and XML-based automated parsing applications. It offers alert grouping capabilities and customizable destination profiles. You can use this feature, for example, to directly page a network support engineer, send an e-mail message to a network operations center (NOC), and employ Cisco AutoNotify services to directly generate a case with the Cisco Technical Assistance Center (TAC). For more information about Call Home, see the .

Online Diagnostics

Cisco generic online diagnostics (GOLD) verify that hardware and internal data paths are operating as designed. Boot-time diagnostics, continuous monitoring, and on-demand and scheduled tests are part of the Cisco GOLD feature set. GOLD allows rapid fault isolation and continuous system monitoring. For information about configuring GOLD, see the .

Embedded Event Manager

Cisco Embedded Event Manager (EEM) is a device and system management feature that helps you to customize behavior based on network events as they happen. For information about configuring EEM, see the .

Manageability

This section describes the manageability features in the Cisco NX-OS software.

Simple Network Management Protocol

The Cisco NX-OS software is compliant with Simple Network Management Protocol (SNMP) version 1, version 2, and version 3. A large number of MIBs is supported. For more information about SNMP, see the .

Role-Based Access Control

With role-based access control (RBAC), you can limit access to device operations by assigning roles to users. You can customize access and restrict it to the users who require it. For more information about RBAC, see the .

Cisco NX-OS Software Configuration

This section describes the tools you can use to configure Cisco NX-OS software, and provides an overview of the software configuration process with links to the appropriate chapters.


Tools for Software Configuration

You can use one of two configuration management tools to configure your SANs:

- The command-line interface (CLI) can manage Cisco MDS 9000 Family switches using Telnet, SSH, or a serial connection.
- The Cisco MDS 9000 Fabric Manager, a Java-based graphical user interface, can manage Cisco MDS 9000 Family switches using SNMP.

Figure 1: Tools for Configuring Cisco NX-OS Software

This figure shows the tools for configuring the Cisco NX-OS software.



CLI

With the CLI, you can type commands at the switch prompt, and the commands are executed when you press the **Enter** key. The CLI parser provides command help, command completion, and keyboard sequences that allow you to access previously executed commands from the buffer history.

Continue reading this document for more information on configuring the Cisco MDS switch using the CLI.

NTP

In a large enterprise network, having one time standard for all network devices is critical for management reporting and event logging functions when trying to correlate interacting events logged across multiple devices. Many enterprise customers with extremely mission-critical networks maintain their own stratum-1 NTP source.

Time synchronization occurs when several frames are exchanged between clients and servers. The switches in client mode know the address of one or more NTP servers. The servers act as the time source and receive client synchronization requests.

By configuring an IP address as a peer, the Cisco NX-OS device will obtain and provide time as required. The peer is capable of providing time on its own and is capable of having a server configured. If both of these


instances point to different time servers, your NTP service is more reliable. Even if the active server link is lost, you can still maintain the correct time due to the presence of the peer.

If an active server fails, a configured peer helps in providing the NTP time. To ensure backup support if the active server fails, provide a direct NTP server association and configure a peer.

If you only configure a peer, the most accurate peer takes on the role of the NTP server and the other peer acts as a peer. Both devices end at the correct time if they have the correct time source or if they point to the correct NTP source.

Figure 2: NTP Peer and Server Association

Not even a server down time will affect well-configured switches in the network. This figure displays a network with two NTP stratum 2 servers and two switches.



In this configuration, the switches were configured as follows:

- Stratum-2 Server-1
 - IPv4 address-10.10.10.10
- Stratum-2 Server-2
 - IPv4 address-10.10.10.9
- Switch-1 IPv4 address-10.10.10.1
- Switch-1 NTP configuration
 - NTP server 10.10.10.10
 - NTP peer 10.10.10.2
- Switch-2 IPv4 address-10.10.10.2
- Switch-2 NTP configuration
 - NTP server 10.10.10.9
 - NTP peer 10.10.10.1

Licensing

The Cisco NX-OS software licensing feature allows you to access premium features on the device after you install the appropriate license for that feature. Any feature not included in a license package is bundled with the Cisco NX-OS software and is provided to you at no extra charge.

You must purchase and install a license for each device.



Note can enable a feature without installing its license. The Cisco NX-OS software gives you a grace period that allows you to try a feature before purchasing its license. You must install the Advanced Services license package to enable the Cisco TrustSec feature.

For detailed information about Cisco NX-OS software licensing, see the .

For information about troubleshooting licensing issues, see the .

Quality of Service

The Cisco NX-OS software supports quality of service (QoS) functions for classification, marking, queuing, policing, and scheduling. Modular QoS CLI (MQC) supports all QoS features. You can use MQC to provide uniform configurations across various Cisco platforms. For more information, see the .



CHAPTER 3

Using the Cisco NX-OS Setup Utility

This chapter describes how to use the Cisco NX-OS setup utility.

- [Information About the Cisco NX-OS Setup Utility, on page 11](#)
- [Prerequisites for the Setup Utility, on page 13](#)
- [Initial Setup Routine, on page 13](#)
- [Where to Go Next, on page 25](#)

Information About the Cisco NX-OS Setup Utility


The Cisco NX-OS setup utility is an interactive command-line interface (CLI) mode that guides you through a basic (also called a startup) configuration of the system. The setup utility allows you to configure only enough connectivity for system management.

The setup utility allows you to build an initial configuration file using the System Configuration Dialog. The setup starts automatically when a device has no configuration file in NVRAM. The dialog guides you through initial configuration. After the file is created, you can use the CLI to perform additional configuration.

You can press **Ctrl-C** at any prompt to skip the remaining configuration options and proceed with what you have configured up to that point, except for the administrator password. If you want to skip answers to any questions, press **Enter**. If a default answer is not available (for example, the device hostname), the device uses what was previously configured and skips to the next question.

Figure 3: Setup Script Flow

This figure shows how to enter and exit the setup script.



You use the setup utility mainly for configuring the system initially, when no configuration is present. However, you can use the setup utility at any time for basic device configuration. The setup utility keeps the configured values when you skip steps in the script. For example, if you have already configured the mgmt0 interface, the setup utility does not change that configuration if you skip that step. However, if there is a default value for the step, the setup utility changes to the configuration using that default, not the configured value. Be sure to carefully check the configuration changes before you save the configuration.



Note Be sure to configure the IPv4 route, the default network IPv4 address, and the default gateway IPv4 address to enable SNMP access. If you enable IPv4 routing, the device uses the IPv4 route and the default network IPv4 address. If IPv4 routing is disabled, the device uses the default gateway IPv4 address.



Note The setup script only supports IPv4.

Prerequisites for the Setup Utility

The setup utility has the following prerequisites:

- Have a password strategy for your network environment.
- Connect the console port on the supervisor module to the network. If you have dual supervisor modules, connect the console ports on both supervisor modules to the network.
- Connect the Ethernet management port on the supervisor module to the network. If you have dual supervisor modules, connect the Ethernet management ports on both supervisor modules to the network.
- Enable the licensing grace period, if applicable. For detailed information about licensing, see the .

Initial Setup Routine

The first time that you access a switch in the Cisco MDS 9000 Family, it runs a setup program that prompts you for the IP address and other configuration information necessary for the switch to communicate over the supervisor module Ethernet interface. This information is required to configure and manage the switch.

The IP address can only be configured from the CLI. When you power up the switch for the first time assign the IP address. After you perform this step, the Cisco MDS 9000 Family Fabric Manager can reach the switch through the console port.

Configuring Out-of-Band Management

You can configure out-of-band management on the mgmt 0 interface.



Note You can configure both in-band and out-of-band configuration together by entering **Yes** in both Step 12c and Step 12d in the following procedure.

Step 1 Power on the switch. Switches in the Cisco MDS 9000 Family boot automatically.

Step 2 Enter **yes** (**yes** is the default) to enable secure password standard.

```
Do you want to enforce secure password standard (yes/no): yes
```

Note You can also enable secure password standard using the **password strength-check** command. A secure password should contain characters from at least three of the classes: lower case letters, upper case letters, digits, and special characters.

Step 3 Enter the new password for the administrator.

Enter the password for admin: *admin-password*
 Confirm the password for admin: *admin-password*

Tip If a password is trivial (short, easy-to-decipher), your password configuration is rejected. Be sure to configure a strong password as shown in the sample configuration. Passwords are case-sensitive.

Step 4 Enter **yes** to enter the setup mode.

This setup utility will guide you through the basic configuration of the system. Setup configures only enough connectivity for management of the system.

*Note: setup is mainly used for configuring the system initially, when no configuration is present. So setup always assumes system defaults and not the current system configuration values.

Press Enter at anytime to skip a dialog. Use ctrl-c at anytime to skip the remaining dialogs.

Would you like to enter the basic configuration dialog (yes/no): **yes**

The setup utility guides you through the basic configuration process. Press **Ctrl-C** at any prompt to end the configuration process.

Step 5 Enter **yes** (**no** is the default) if you do not wish to create additional accounts.

Create another login account (yes/no) [no]: **yes**

While configuring your initial setup, you can create an additional user account (in the network-admin role) besides the administrator's account.

Note User login IDs must contain non-numeric characters.

a) Enter the user login ID.

Enter the user login ID: *user_name*

b) Enter and confirm the user password.

Enter the password for *user_name*: *user-password*
 Confirm the password for *user_name*: *user-password*

c) Assign the user role **network-admin** (**network-operator** is the default).

Enter the user role [network-operator]: **network-admin**

Step 6 Configure the read-only or read-write SNMP community string.

- a) Enter **yes** (**no** is the default) to avoid configuring the read-only SNMP community string.

```
Configure read-only SNMP community string (yes/no) [n]: yes
```

- b) Enter the SNMP community string.

```
SNMP community string: snmp_community
```

Step 7 Enter a name for the switch.

Note The switch name is limited to 32 alphanumeric characters. The default is **switch**.

```
Enter the switch name: switch_name
```

Step 8 Enter **yes** (**yes** is the default) at the configuration prompt to configure out-of-band management.

```
Continue with Out-of-band (mgmt0) management configuration? [yes/no]: yes
```

- a) Enter the mgmt0 IPv4 address.

```
Mgmt0 IPv4 address: ip_address
```

- b) Enter the mgmt0 IPv4 subnet mask.

```
Mgmt0 IPv4 netmask: subnet_mask
```

Step 9 Enter **yes** (**yes** is the default) to configure the default gateway.

```
Configure the default-gateway: (yes/no) [y]: yes
```

- a) Enter the default gateway IP address.

```
IP address of the default gateway: default_gateway
```

Step 10 Enter **yes** (**no** is the default) to configure advanced IP options such as in-band management, static routes, default network, DNS, and domain name.

```
Configure Advanced IP options (yes/no)? [n]: yes
```

- a) Enter **no** (**no** is the default) at the in-band management configuration prompt.

```
Continue with in-band (VSAN1) management configuration? (yes/no) [no]: no
```

- b) Enter **yes** (**yes** is the default) to enable IPv4 routing capabilities.

Enable ip routing capabilities? (yes/no) [y]: **yes**

- c) Enter **yes** (**yes** is the default) to configure a static route.

Configure static route: (yes/no) [y]: **yes**

Enter the destination prefix.

Destination prefix: *dest_prefix*

Enter the destination prefix mask.

Destination prefix mask: *dest_mask*

Enter the next hop IP address.

Next hop ip address: *next_hop_address*

Note Be sure to configure the IP route, the default network IP address, and the default gateway IP address to enable SNMP access. If IP routing is enabled, the switch uses the IP route and the default network IP address. If IP routing is disabled, the switch uses the default gateway IP address.

- d) Enter **yes** (**yes** is the default) to configure the default network.

Configure the default-network: (yes/no) [y]: **yes**

Enter the default network IPv4 address.

Note The default network IPv4 address is the destination prefix provided in Step 10c.

Default network IP address [*dest_prefix*]: *dest_prefix*

- e) Enter **yes** (**yes** is the default) to configure the DNS IPv4 address.

Configure the DNS IP address? (yes/no) [y]: **yes**

Enter the DNS IP address.

DNS IP address: *name_server*

- f) Enter **yes** (**no** is the default) to skip the default domain name configuration.

Configure the default domain name? (yes/no) [n]: **yes**

Enter the default domain name.

Default domain name: *domain_name*

Step 11 Enter **yes** (**yes** is the default) to enable the SSH service.

Enabled SSH service? (yes/no) [n]: **yes**

Enter the SSH key type.

Type the SSH key you would like to generate (dsa/rsa)? **rsa**

Enter the number of key bits within the specified range.

Enter the number of key bits? (768-2048) [1024]: **2048**

Step 12 Enter **yes** (**no** is the default) to disable the Telnet service.

Enable the telnet service? (yes/no) [n]: **yes**

Step 13 Enter **yes** (**yes** is the default) to configure congestion or no_credit drop for FC interfaces.

Configure congestion or no_credit drop for fc interfaces? (yes/no) [q/quit] to quit [y]:**yes**

Step 14 Enter **con**(**con** is the default) to configure congestion or no_credit drop.

Enter the type of drop to configure congestion/no_credit drop? (con/no) [c]:**con**

Step 15 Enter a value from 100 to 1000 (**d** is the default) to calculate the number of milliseconds for congestion or no_credit drop.

Enter number of milliseconds for congestion/no_credit drop[100 - 1000] or [d/default] for default:**100**

Step 16 Enter a mode for congestion or no_credit drop.

Enter mode for congestion/no_credit drop[E/F]:

Step 17 Enter **yes** (**no** is the default) to configure the NTP server.

Configure NTP server? (yes/no) [n]: **yes**

Enter the NTP server IPv4 address.

NTP server IP address: *ntp_server_IP_address*

Step 18 Enter **shut** (**shut** is the default) to configure the default switch port interface to the shut (disabled) state.

Configure default switchport interface state (shut/noshut) [shut]: **shut**

Note The management Ethernet interface is not shut down at this point. Only the Fibre Channel, iSCSI, FCIP, and Gigabit Ethernet interfaces are shut down.

Step 19 Enter **on** (**off** is the default) to configure the switch port trunk mode.

```
Configure default switchport trunk mode (on/off/auto) [off]: on
```

Step 20 Enter **yes** (**yes** is the default) to configure the switchport mode F.

```
Configure default switchport mode F (yes/no) [n]: y
```

Step 21 Enter **on** (**off** is the default) to configure the PortChannel auto-create state.

```
Configure default port-channel auto-create state (on/off) [off]: on
```

Step 22 Enter **permit** (**deny** is the default) to deny a default zone policy configuration.

```
Configure default zone policy (permit/deny) [deny]: permit
```

Permits traffic flow to all members of the default zone.

Note If you are executing the setup script after issuing a **write erase** command, you must explicitly change the default zone policy to permit for VSAN 1 after finishing the script using the following commands:

```
switch# configure terminal
switch(config)# zone default-zone permit vsan 1
```

Step 23 Enter **yes** (**no** is the default) to disable a full zone set distribution.

```
Enable full zoneset distribution (yes/no) [n]: yes
```

Overrides the switch-wide default for the full zone set distribution feature.

You see the new configuration. Review and edit the configuration that you have just entered.

Note If you are executing the setup script after issuing a **write erase** command, you must explicitly change the default zone policy to permit for VSAN 1 after finishing the script using the following commands:

```
switch# configure terminal
switch(config)# zoneset distribute full vsan 1
```

Step 24 Enter **enhanced** (**basic** is the default) to configure default-zone mode as enhanced.

```
Configure default zone mode (basic/enhanced) [basic]: enhanced
```

Overrides the switch-wide default zone mode as enhanced.

Note If you are executing the setup script after issuing a **write erase** command, you must explicitly change the default zoning mode to enhanced for VSAN 1 after finishing the script using the following commands:

```
switch# configure terminal
switch(config)# zone mode enhanced vsan 1
```

Step 25 Enter **no** (**no** is the default) if you are satisfied with the configuration.

The following configuration will be applied:

```
username admin password admin_pass role network-admin
username user_name password user_pass role network-admin
snmp-server community snmp_community ro
switchname switch
interface mgmt0
  ip address ip_address subnet_mask
  no shutdown
ip routing
ip route dest_prefix dest_mask dest_address
ip default-network dest_prefix
ip default-gateway default_gateway
ip name-server name_server
ip domain-name domain_name
telnet server disable
ssh key rsa 2048 force
ssh server enable
ntp server ipaddr ntp_server
system default switchport shutdown
system default switchport trunk mode on
system default switchport mode F
system default port-channel auto-create
zone default-zone permit vsan 1-4093
zoneset distribute full vsan 1-4093
system default zone mode enhanced
Would you like to edit the configuration? (yes/no) [n]: n
```

Step 26 Enter **yes** (**yes** is default) to use and save this configuration.

```
Use this configuration and save it? (yes/no) [y]: yes
```

Caution If you do not save the configuration at this point, none of your changes are updated the next time the switch is rebooted. Type **yes** to save the new configuration. This ensures that the kickstart and system images are also automatically configured.

Configuring In-Band Management

The in-band management logical interface is VSAN 1. This management interface uses the Fibre Channel infrastructure to transport IP traffic. An interface for VSAN 1 is created on every switch in the fabric. Each switch should have its VSAN 1 interface configured with either an IPv4 address or an IPv6 address in the same subnetwork. A default route that points to the switch providing access to the IP network should be configured on every switch in the Fibre Channel fabric.



Note You can configure both in-band and out-of-band configuration together by entering **Yes** in both Step 10c and Step 10d in the following procedure.

SUMMARY STEPS

1. Power on the switch. Switches in the Cisco MDS 9000 Family boot automatically.
2. Enter the new password for the administrator.
3. Enter **yes** to enter the setup mode.
4. Enter **yes** (yes is the default) to enable secure password standard
5. Enter **no** (no is the default) if you do not wish to create additional accounts.
6. Configure the read-only or read-write SNMP community string.
7. Enter a name for the switch.
8. Enter **no** (yes is the default) at the configuration prompt to configure out-of-band management.
9. Enter **yes** (yes is the default) to configure the default gateway.
10. Enter **yes** (**no** is the default) to configure advanced IP options such as in-band management, static routes, default network, DNS, and domain name.
11. Enter **no** (**no** is the default) to disable the Telnet service.
12. Enter **yes** (**yes** is the default) to enable the SSH service.
13. Enter the SSH key type.
14. Enter the number of key bits within the specified range.
15. Enter **no** (**no** is the default) to configure the NTP server.
16. Enter **shut** (**shut** is the default) to configure the default switch port interface to the shut (disabled) state.
17. Enter **auto** (**off** is the default) to configure the switch port trunk mode.
18. Enter **yes** (**yes** is the default) to configure the switchport mode F.
19. Enter **off** (**off** is the default) to configure the PortChannel auto-create state.
20. Enter **deny** (**deny** is the default) to deny a default zone policy configuration.
21. Enter **no** (**no** is the default) to disable a full zone set distribution.
22. Enter **enhanced** (**basic** is the default) to configure default-zone mode as enhanced.
23. Enter **no** (**no** is the default) if you are satisfied with the configuration.
24. Enter **yes** (**yes** is default) to use and save this configuration.

DETAILED STEPS

Step 1 Power on the switch. Switches in the Cisco MDS 9000 Family boot automatically.

Step 2 Enter the new password for the administrator.

Enter the password for admin: **2004asdf*1kjh18**

Tip If a password is trivial (short, easy-to-decipher), your password configuration is rejected. Be sure to configure a strong password as shown in the sample configuration. Passwords are case-sensitive.

Step 3 Enter **yes** to enter the setup mode.

This setup utility will guide you through the basic configuration of the system. Setup configures only enough connectivity for management of the system.

*Note: setup is mainly used for configuring the system initially, when no configuration is present. So setup always assumes system defaults and not the current system configuration values.

Press Enter at anytime to skip a dialog. Use ctrl-c at anytime to skip the remaining dialogs.

Would you like to enter the basic configuration dialog (yes/no): **yes**

The setup utility guides you through the basic configuration process. Press **Ctrl-C** at any prompt to end the configuration process.

Step 4 Enter **yes** (yes is the default) to enable secure password standard

Do you want to enforce secure password standard (yes/no): **yes**

Note You can also enable secure password standard using the **password strength-check** command. A secure password should contain characters from at least three of the classes: lower case letters, upper case letters, digits, and special characters.

Step 5 Enter **no** (no is the default) if you do not wish to create additional accounts.

Create another login account (yes/no) [no]: **no**

Step 6 Configure the read-only or read-write SNMP community string.

a) Enter **no** (no is the default) to avoid configuring the read-only SNMP community string.

Configure read-only SNMP community string (yes/no) [n]: **no**

b) Enter **yes** (no is the default) to avoid configuring the read-write SNMP community string.

Configure read-write SNMP community string (yes/no) [n]: **yes**

c) Enter the SNMP community string.

SNMP community string: *snmp_community*

Step 7 Enter a name for the switch.

Note The switch name is limited to 32 alphanumeric characters. The default is **switch**.

Enter the switch name: *switch_name*

Step 8 Enter **no** (yes is the default) at the configuration prompt to configure out-of-band management.

```
Continue with Out-of-band (mgmt0) management configuration? [yes/no]: no
```

Step 9 Enter **yes** (yes is the default) to configure the default gateway.

```
Configure the default-gateway: (yes/no) [y]: yes
```

a) Enter the default gateway IP address.

```
IP address of the default gateway: default_gateway
```

Step 10 Enter **yes** (**no** is the default) to configure advanced IP options such as in-band management, static routes, default network, DNS, and domain name.

```
Configure Advanced IP options (yes/no)? [n]: yes
```

a) Enter **yes** (**no** is the default) at the in-band management configuration prompt.

```
Continue with in-band (VSAN1) management configuration? (yes/no) [no]: yes
```

Enter the VSAN 1 IPv4 address.

```
VSAN1 IPv4 address: ip_address
```

Enter the IPv4 subnet mask.

```
VSAN1 IPv4 net mask: subnet_mask
```

b) Enter **no** (**yes** is the default) to enable IPv4 routing capabilities.

```
Enable ip routing capabilities? (yes/no) [y]: no
```

c) Enter **no** (**yes** is the default) to configure a static route.

```
Configure static route: (yes/no) [y]: no
```

d) Enter **no** (**yes** is the default) to configure the default network

```
Configure the default-network: (yes/no) [y]: no
```

e) Enter **no** (**yes** is the default) to configure the DNS IPv4 address.

```
Configure the DNS IP address? (yes/no) [y]: no
```


f) Enter **no** (**no** is the default) to skip the default domain name configuration.

```
Configure the default domain name? (yes/no) [n]: no
```

Step 11 Enter **no** (**no** is the default) to disable the Telnet service.

```
Enable the telnet service? (yes/no) [y]: no
```

Step 12 Enter **yes** (**yes** is the default) to enable the SSH service.

```
Enabled SSH service? (yes/no) [n]: yes
```

Step 13 Enter the SSH key type.

```
Type the SSH key you would like to generate (dsa/rsa)? rsa
```

Step 14 Enter the number of key bits within the specified range.

```
Enter the number of key bits? (768 to 2048): 2048
```

Step 15 Enter **no** (**no** is the default) to configure the NTP server.

```
Configure NTP server? (yes/no) [n]: no
```

Step 16 Enter **shut** (**shut** is the default) to configure the default switch port interface to the shut (disabled) state.

```
Configure default switchport interface state (shut/noshut) [shut]: shut
```

Note The management Ethernet interface is not shut down at this point. Only the Fibre Channel, iSCSI, FCIP, and Gigabit Ethernet interfaces are shut down.

Step 17 Enter **auto** (**off** is the default) to configure the switch port trunk mode.

```
Configure default switchport trunk mode (on/off/auto) [off]: auto
```

Step 18 Enter **yes** (**yes** is the default) to configure the switchport mode F.

```
Configure default switchport mode F (yes/no) [n]: y
```

Step 19 Enter **off** (**off** is the default) to configure the PortChannel auto-create state.

```
Configure default port-channel auto-create state (on/off) [off]: off
```

Step 20 Enter **deny** (**deny** is the default) to deny a default zone policy configuration.

```
Configure default zone policy (permit/deny) [deny]: deny
```

Denies traffic flow to all members of the default zone.

Note If you are executing the setup script after issuing a **write erase** command, you must explicitly change the default zone policy to permit for VSAN 1 after finishing the script using the following commands:

```
switch# configure terminal
switch(config)# zone default-zone permit vsan 1
```

Step 21 Enter **no** (**no** is the default) to disable a full zone set distribution.

```
Enable full zoneset distribution (yes/no) [n]: no
```

Disables the switch-wide default for the full zone set distribution feature.

You see the new configuration. Review and edit the configuration that you have just entered.

Note If you are executing the setup script after issuing a **write erase** command, you must explicitly change the default zone policy to permit for VSAN 1 after finishing the script using the following commands:

```
switch# configure terminal
switch(config)# zoneset distribute full vsan 1
```

Step 22 Enter **enhanced** (**basic** is the default) to configure default-zone mode as enhanced.

```
Configure default zone mode (basic/enhanced) [basic]: enhanced
```

Overrides the switch-wide default zone mode as enhanced.

Note If you are executing the setup script after issuing a **write erase** command, you must explicitly change the default zoning mode to enhanced for VSAN 1 after finishing the script using the following commands:

```
switch# configure terminal
switch(config)# zone mode enhanced vsan 1
```

Note If you are executing the setup script after issuing a **write erase** command, you must explicitly change the default zone policy to permit for VSAN 1 after finishing the script using the following commands:

```
switch# configure terminal
switch(config)# zoneset distribute full vsan 1
```

Step 23 Enter **no** (**no** is the default) if you are satisfied with the configuration.

```
The following configuration will be applied:
username admin password admin_pass role network-admin
snmp-server community snmp_community rw
switchname switch
```

```
interface vsan1
  ip address ip_address subnet_mask
  no shutdown ip default-gateway default_gateway
no telnet server disable
ssh key rsa 2048 force ssh server enable system default switchport shutdown
system default switchport trunk mode
auto system default switchport mode F
no zone default-zone permit vsan 1-4093
no zoneset distribute full vsan 1-4093
system default zone mode enhanced
Would you like to edit the configuration? (yes/no) [n]: n
```

Step 24 Enter **yes** (**yes** is default) to use and save this configuration.

```
Use this configuration and save it? (yes/no) [y]: yes
```

Caution If you do not save the configuration at this point, none of your changes are updated the next time the switch is rebooted. Type **yes** to save the new configuration. This ensures that the kickstart and system images are also automatically configured.

Where to Go Next

To become more familiar with the CLI, continue to .



CHAPTER 4

Using PowerOn Auto Provisioning

This chapter describes how to deploy and use Power On Auto Provisioning (POAP) for Cisco MDS 9148 Multilayer Fabric Switch, Cisco MDS 9148S 16G Multilayer Fabric Switch, and Cisco MDS 9396S 16G Multilayer Fabric Switch.

This chapter contains the following sections:

- [Using Power On Auto Provisioning, on page 27](#)

Using Power On Auto Provisioning

This chapter describes how to deploy and use Power On Auto Provisioning (POAP) for Cisco MDS 9148 Multilayer Fabric Switch, Cisco MDS 9148S 16G Multilayer Fabric Switch, and Cisco MDS 9396S 16G Multilayer Fabric Switch.

About Power On Auto Provisioning

When a Cisco MDS Series switch with POAP feature boots and does not find the startup configuration, the switch enters POAP mode and checks for a USB device (containing the configuration script file) in USB port 1. If it finds a USB device, it checks the device to see if the device also contains the software image files and the switch configuration file.

If the switch does not find a USB device in USB port 1, or if the USB device does not contain the required software image files or the switch configuration file, the switch locates a DHCP server and bootstraps itself with the server's interface IP address, gateway, and DNS server IP addresses. The switch then obtains the IP address of a TFTP server or the URL of an HTTP server from where it downloads the necessary configuration files.



Note DHCP information is used during the POAP process only when POAP fails via USB because of the following reasons:

- USB is not present.
 - Script is not present or script is present with incorrect names.
 - Script execution fails.
-

POAP Configuration Script

The reference script supplied by Cisco supports the following functionalities:

- Retrieves switch-specific identifiers, for example, the serial number.
- Downloads the software images (system and kickstart images) if the files do not already exist on the switch.
- Installs the software image on the switch, which is then used at the next reboot.
- Schedules the downloaded configuration to be applied at the next switch reboot.
- Stores the configuration as startup configuration.

Guidelines and Limitations for POAP Configuration

The POAP configuration guidelines and limitations are as follows:

- Only FAT32 USB is supported. (The file system on the USB should be FAT32).
- The software image for the Cisco MDS 9000 Series Switches, including the Cisco MDS 9396S Multilayer Fabric Switch, must support POAP.
- POAP can be initiated on any switch by erasing the startup configuration and reloading the switch.
- POAP does not support provisioning of the switch after it has been configured and is operational. Only auto provisioning of a switch with no startup configuration is supported.
- Important POAP updates are logged in the syslog and are available from the serial console.
- Critical POAP errors are logged to the bootflash. The filename format is date-time_poap_PID_[init,1,2].log, where date-time is in the YYYYMMDD_hhmmss format and PID is the process ID.
- Script logs are saved in the bootflash directory. The filename format is date-time_poap_PID_script.log, where date-time is in the YYYYMMDD_hhmmss format and PID is the process ID.
- You can configure the format of the script log file. These formats are specified in the script. The template of the script log file has a default format. However, you can choose a different format for the script execution log file.
- USB script execution logs are saved in the bootflash directory. The filename format is poap.log_usb_MM_DD_HR_MIN, where MM is the current month, DD is the date, HR is the current hour, and MIN is the current minute.
- The POAP feature does not require a license, and is enabled by default.




Note POAP is not supported through Cisco Data Center Network Management (DCNM).

Network Infrastructure Requirements for POAP

When there is no USB device with the required installation files, or the configuration files are not present in the USB, POAP requires the following network infrastructure:

- A DHCP server to bootstrap the interface IP address, gateway address, and TFTP address.
- A TFTP and SCP server that contains the configuration script used to automate the software image installation and configuration process.
- One or more servers containing the necessary software images and configuration files.

Figure 4: POAP Network Infrastructure



Setting Up the Network Environment to use POAP

The network environment for POAP can be set up with either a USB or a DHCP server.

Using USB

Follow these guidelines when copying software images, the configuration file, and the configuration script into a USB when setting up the network environment for POAP:

- The POAP configuration script on the USB should be titled `poap_script.tcl`.
- The configuration file with the name `conf_<serialnum>.cfg` must be present in the USB. To obtain the serial number of the switch, run the **show sprom backplane 1** command:

```
switch# show sprom backplane 1
DISPLAY backplane sprom contents:
Common block:
Block Signature : 0xabab
Block Version   : 3
Block Length    : 160
Block Checksum  : 0x128e
EEPROM Size     : 512
Block Count     : 6
```

```

FRU Major Type   : 0x6003
FRU Minor Type   : 0x0
OEM String       : Cisco Systems, Inc.
Product Number   : DS-C9148S48PK9
Serial Number    : JAF17353076
Part Number      : 73-15809-01

```

- The names of the software images copied to the USB should have standard names and must match the names specified in the POAP script.

For example, to boot up a Cisco MDS 9148s switch with the m9100-s5ek9-kickstart-mz.7.3.0.D1.0.159.bin and m9100-s5ek9-mz.7.3.0.D1.0.159.bin images, ensure that the POAP configuration script (poap_script.tcl) has the following information:

- set m9148s_image_version 7.3.0.D1.0.159
- set m9148s_kickstart_image_src [format m9100-s5ek9-kickstart-mz.%.s.bin \$m9148s_image_version]
- set m9148s_system_image_src [format m9100-s5ek9-mz.%.s.bin \$m9148s_image_version]



Note Ensure that the POAP script identifies the switch.



-
- Note**
- Only FAT32 USB is supported. (The file system on the USB should be FAT32).
 - Both the software images and the configuration files should be present in the USB. If no configuration is required, create an empty file named conf_serialnumber.cfg. When the configuration file is empty, the switch reloads the images twice from the USB.
-

Using a DHCP Server

Step 1 Deploy a TFTP server to host the configuration script, software images, and configuration files.

Step 2 Deploy a DHCP server.

Step 3 Configure the following parameters in the DHCP server:

- Interface address
- Gateway address
- TFTP server's IP address
- Boot file name

The following example of dhcpd.conf on Linux, with bootfile name, TFTP server, and script file name:

```

option vlan-id code 132 = unsigned integer 32 ;
subnet 10.105.188.0 netmask 255.255.255.0 {
    max-lease-time 7200;
    class "cisco MDS" {
        match if substring(option vendor-class-identifier, 0, 15) = "cisco MDS - tcl";
        option bootfile-name "poap_script.tcl";
    }
}

```



```

        option subnet-mask 255.255.255.0;
    option domain-name "cisco.com";
}
option routers 10.105.188.1;
option tftp-server-name "10.105.188.159";
}

```

Step 4 To obtain the serial number of the switch, execute the **show sprom backplane 1** command.

Step 5 Create a separate directory for each switch in the base directory of the TFTP server. The name of each directory should be the same as the serial number of the switch. Creating a separate directory for each switch enables you to have separate software images or configuration files for different switches.

Note The base directory should contain the software images (kickstart and system images) and the server-list.cfg file. The file names of the software images should match poap_script.tcl and device-recipe.cfg.

In the newly created directory for each switch, maintain the device-recipe.cfg and the conf_*SN*.cfg file. (Replace *SN* with the exact serial number of the corresponding switch.)

The following is an example of device-recipe.cfg:

```

{"serial-number":"JAF1735307V","kick-start-image":{"image-name":"MDS9148S_boot","download-server":
"Default_SCP_Repository"},"system-image":{"image-name":"MDS9148S_isan","download-server":
"Default_SCP_Repository"},"startup-config":{"config-name":"conf_JAF1735307V.cfg","download-server":
"Default_SCP_Repository"}}

```

The following is an example of server-list.cfg:

```

{ "repositories": {"Default_SCP_Repository":{"url":"scp://server_IP/directory_path","username":
"user","password": "password","last-modified-time":"Mon Mar 24 00:22:33 PDT 2014"} }, "resources":{
}}

```

Note You can download all the sample files for the POAP process from the following link:

[https://software.cisco.com/download/release.html?mdfid=283453013&softwareid=282088132&release=6.2\(11\)&relind=AVAILABLE&relifecycle=&reltype=latest](https://software.cisco.com/download/release.html?mdfid=283453013&softwareid=282088132&release=6.2(11)&relind=AVAILABLE&relifecycle=&reltype=latest)

Note Ensure that you select the correct version of the Cisco MDS NX-OS release before downloading the sample files.

The POAP Process


The POAP process involves the following phases:

1. Power up
2. USB discovery
3. DHCP discovery
4. Script execution
5. Post-installation reload

Within these phases, other processes and decision points occur. The following illustration shows a POAP process flow:

See [Setting Up the Network Environment to use POAP, on page 29](#) for more information on the POAP process.

Figure 5: The POAP Process



33/40/23

The Power-Up Phase

When you power-up a switch for the first time, it loads the software image that is installed at manufacturing, and only tries to find a configuration file from which to boot. When a configuration file is not found, the POAP mode starts.

During startup, a prompt appears, asking if you want to abort POAP and continue with the normal setup. You can choose to exit or continue with POAP.



Note No user intervention is required for POAP to continue. The prompt that asks if you want to abort POAP remains available until the POAP process is complete.

If you exit the POAP mode, you enter a script. If you continue in the POAP mode, all the front-panel interfaces are set up in the default configuration.

The USB Discovery Phase

When the POAP process begins, the switch searches the root directory for the presence of accessible USB devices with the POAP configuration script file (poap_script.tcl), configuration files, and system and kickstart images.

If the configuration script file is found on a USB device, POAP begins to run the configuration script. If the configuration script file is not found on the USB device, POAP executes DHCP discovery. (When failures occur, the POAP process alternates between USB discovery and DHCP discovery until POAP succeeds or you manually abort the POAP process.)

If the software image and switch configuration files specified in the configuration script are present, POAP uses those files to install the software and configure the switch. If the software image and switch configuration files are not on the USB device, POAP performs a clean-up operation and starts the DHCP phase from the beginning.

The DHCP Discovery Phase

The switch sends out DHCP discover messages on the management interface that solicits DHCP offers from the DHCP server or servers. (See the following [Figure 6: DHCP Discovery Process, on page 34](#).) The DHCP client on the Cisco MDS switch uses the switch serial number in the client-identifier option to identify itself to the DHCP server. The DHCP server can use this identifier to send information, such as the IP address and script filename, back to the DHCP client.

The POAP process requires a minimum DHCP lease period of 3600 seconds (1 hour). POAP checks the DHCP lease period. If the DHCP lease period is set to less than 3600 seconds (1 hour), POAP does not complete DHCP negotiation, but enters the USB phase.



Note The POAP process has to be aborted manually.


The DHCP discover message also solicits the following options from the DHCP server:

- TFTP server name or TFTP server address—The DHCP server relays the TFTP server name or TFTP server address to the DHCP client, which uses this information to contact the TFTP server to obtain the script file.
- Bootfile name—The DHCP server relays the bootfile name to the DHCP client. The bootfile name includes the complete path to the bootfile on the TFTP server. The DHCP client uses this information to download the script file.

When multiple DHCP offers that meet the requirement are received, an offer is randomly chosen. The device completes the DHCP negotiation (request and acknowledgment) with the selected DHCP server, and the DHCP server assigns an IP address to the switch. If a failure occurs in any of the subsequent steps in the POAP process, the IP address is released back to the DHCP server.

If none of the DHCP offers meet the requirements, the switch does not complete the DHCP negotiation (request and acknowledgment), and no IP address is assigned. However, the POAP process is not aborted because the switch reverts to the USB phase.

Figure 6: DHCP Discovery Process



Script Execution Phase

After the device bootstraps itself using the information in the DHCP acknowledgment, the script file is downloaded from the TFTP server.

The switch runs the configuration script, which downloads and installs the software image and downloads a switch-specific configuration file.

However, the configuration file is not applied to the switch at this point, because the software image that currently runs on the switch might not support all the commands in the configuration file. After the switch reboots, it begins to run the new software image, if any. At that point, the configuration is applied to the switch.



Note If script execution fails, the DHCP discovery process restarts.

Post-Installation Reload Phase

The switch restarts and applies (replays) the configuration on the upgraded software image. Afterward, the switch copies the running configuration to the startup configuration.

Configuring a Switch Using POAP

Before you begin

Make sure that the requisite network environment is set up to use POAP. For more information, see the [Using USB, on page 29](#) section.

Step 1 Install the switch in the network.

Step 2 Power on the switch.

If no configuration file is found, the switch boots in the POAP mode and displays a prompt that asks if you want to abort POAP and continue with a normal setup.

No entry is required to continue booting in POAP mode.

Step 3 (Optional) To exit POAP mode and enter the normal interactive setup script, enter **y** (yes).

The switch boots, and the POAP process begins.

What to do next

Verify the configuration.

Verifying the Device Configuration

To verify the configuration after bootstrapping the device using POAP, use one of the following commands:

Command	Purpose
show running-config	Displays the running configuration.
show startup-config	Displays the startup configuration.

For detailed information about these commands, see the [Cisco MDS 9000 Family Command Reference](#).



CHAPTER 5

Understanding the Command-Line Interface

This chapter helps you understand the command-line interface.

- [Information About the CLI Prompt, on page 37](#)
- [Command Modes, on page 38](#)
- [Special Characters, on page 41](#)
- [Keystroke Shortcuts, on page 41](#)
- [Abbreviating Commands, on page 43](#)
- [Completing a Partial Command Name, on page 44](#)
- [Identifying Your Location in the Command Hierarchy, on page 44](#)
- [Using the no Form of a Command , on page 45](#)
- [Configuring CLI Variables, on page 46](#)
- [Command Aliases, on page 48](#)
- [Command Scripts, on page 50](#)
- [Context-Sensitive Help , on page 52](#)
- [Understanding Regular Expressions, on page 53](#)
- [Searching and Filtering show Command Output, on page 55](#)
- [Searching and Filtering from the --More-- Prompt, on page 59](#)
- [Using the Command History, on page 60](#)
- [Enabling or Disabling the CLI Confirmation Prompts, on page 62](#)
- [Setting CLI Display Colors, on page 62](#)
- [Sending Commands to Modules, on page 63](#)
- [BIOS Loader Prompt, on page 64](#)
- [Examples Using the CLI , on page 64](#)

Information About the CLI Prompt

Once you have successfully accessed the device, the CLI prompt displays in the terminal window of your console port or remote workstation as shown in this example:

```
User Access Verification
login: admin
Password:<password>
Cisco Nexus Operating System (NX-OS) Software
TAC support: http://www.cisco.com/tac
Copyright (c) 2002-2009, Cisco Systems, Inc. All rights reserved.
```

The copyrights to certain works contained in this software are owned by other third parties and used and distributed under license. Certain components of this software are licensed under the GNU General Public License (GPL) version 2.0 or the GNU Lesser General Public License (LGPL) Version 2.1. A copy of each such license is available at <http://www.opensource.org/licenses/gpl-2.0.php> and <http://www.opensource.org/licenses/lgpl-2.1.php>
switch#

You can change the default device hostname.

From the CLI prompt, you can do the following:

- Use CLI commands for configuring features
- Access the command history
- Use command parsing functions



Note In normal operation, usernames are case sensitive. However, when you are connected to the device through its console port, you can enter a login username in all uppercase letters regardless of how the username was defined. As long as you provide the correct password, the device logs you in.

Command Modes

This section describes command modes in the Cisco NX-OS CLI.

EXEC Command Mode

When you first log in, the Cisco NX-OS software places you in EXEC mode. The commands available in EXEC mode include the **show** commands that display the device status and configuration information, the **clear** commands, and other commands that perform actions that you do not save in the device configuration.

Global Configuration Command Mode

Global configuration mode provides access to the broadest range of commands. The term indicates characteristics or features that affect the device as a whole. You can enter commands in global configuration mode to configure your device globally or to enter more specific configuration modes to configure specific elements such as interfaces or protocols.

SUMMARY STEPS

1. **configure terminal**

DETAILED STEPS

	Command or Action	Purpose
Step 1	configure terminal	Enters global configuration mode.

	Command or Action	Purpose
	Example: <pre>switch# configure terminal switch(config)#</pre>	Note The CLI prompt changes to indicate that you are in global configuration mode.

Interface Configuration Command Mode

One example of a specific configuration mode that you enter from global configuration mode is interface configuration mode. To configure interfaces on your device, you must specify the interface and enter interface configuration mode.

You must enable many features on a per-interface basis. Interface configuration commands modify the operation of the interfaces on the device, such as Ethernet interfaces or management interfaces (mgmt 0).

For more information about configuring interfaces, see the Cisco Nexus interfaces guide for your device.

SUMMARY STEPS

1. **configure terminal**
2. **interface *type number***

DETAILED STEPS

	Command or Action	Purpose
Step 1	configure terminal Example: <pre>switch# configure terminal switch(config)#</pre>	Enters global configuration mode.
Step 2	interface <i>type number</i> Example: <pre>switch(config)# interface ethernet 2/2 switch(config-if)#</pre>	Specifies the interface that you want to configure. The CLI places you into interface configuration mode for the specified interface. Note The CLI prompt changes to indicate that you are in interface configuration mode.

Subinterface Configuration Command Mode

From global configuration mode, you can access a configuration submode for configuring VLAN interfaces called subinterfaces. In subinterface configuration mode, you can configure multiple virtual interfaces on a single physical interface. Subinterfaces appear to a protocol as distinct physical interfaces.

Subinterfaces also allow multiple encapsulations for a protocol on a single interface. For example, you can configure IEEE 802.1Q encapsulation to associate a subinterface with a VLAN.

For more information about configuring subinterfaces, see the Cisco Nexus interfaces guide for your device. For details about the subinterface commands, see the command reference guide for your device.

SUMMARY STEPS

1. **configure terminal**
2. **interface type number.subint**

DETAILED STEPS

	Command or Action	Purpose
Step 1	configure terminal Example: <pre>switch# configure terminal switch(config)#</pre>	Enters global configuration mode.
Step 2	interface type number.subint Example: <pre>switch(config)# interface ethernet 2/2.1 switch(config-subif)#</pre>	Specifies the VLAN interface to be configured. The CLI places you into a subinterface configuration mode for the specified VLAN interface. Note The CLI prompt changes to indicate that you are in global configuration mode.

Saving and Restoring a Command Mode

The Cisco NX-OS software allows you to save the current command mode, configure a feature, and then restore the previous command mode. The **push** command saves the command mode and the **pop** command restores the command mode.

This example shows how to save and restore a command mode:

```
switch# configure terminal
switch(config)# event manager applet test
switch(config-applet)# push
switch(config-applet)# configure terminal
switch(config)# username testuser password newtest
switch(config)# pop
switch(config-applet)#
```

Command Mode Summary

This table summarizes information about the main command modes.

Table 2: Command Mode Summary

Mode	Access Method	Prompt	Exit Method
EXEC	From the login prompt, enter your username and password.	switch#	To exit to the login prompt, use the exit command.
Global configuration	From EXEC mode, use the configure terminal command.	switch(config)#	To exit to EXEC mode, use the end or exit command or press Ctrl-Z .

Mode	Access Method	Prompt	Exit Method
Interface configuration	From global configuration mode, use an interface command and specify an interface with an interface command.	<code>switch(config-if) #</code>	To exit to global configuration mode, use the exit command. To exit to EXEC mode, use the exit command or press Ctrl-Z .
Subinterface configuration	From global configuration mode, specify a subinterface with an interface command.	<code>switch(config-subif) #</code>	To exit to global configuration mode, use the exit command. To exit to EXEC mode, use the end command or press Ctrl-Z .

Special Characters

This table lists the characters that have special meaning in Cisco NX-OS text strings and should be used only in regular expressions or other special contexts.

Table 3: Special Characters

Character	Description
%	Percent
#	Pound, hash, or number
...	Ellipsis
	Vertical bar
<>	Less than or greater than
[]	Brackets
{ }	Braces

Keystroke Shortcuts

This table lists command key combinations that can be used in both EXEC and configuration modes.

Table 4: Keystroke Shortcuts

Keystokes	Description
Ctrl-A	Moves the cursor to the beginning of the line.

Keystokes	Description
Ctrl-B	Moves the cursor one character to the left. When you enter a command that extends beyond a single line, you can press the Left Arrow or Ctrl-B keys repeatedly to scroll back toward the system prompt and verify the beginning of the command entry, or you can press the Ctrl-A key combination.
Ctrl-C	Cancels the command and returns to the command prompt.
Ctrl-D	Deletes the character at the cursor.
Ctrl-E	Moves the cursor to the end of the line.
Ctrl-F	Moves the cursor one character to the right.
Ctrl-G	Exits to the previous command mode without removing the command string.
Ctrl-K	Deletes all characters from the cursor to the end of the command line.
Ctrl-L	Redisplays the current command line.
Ctrl-N	Displays the next command in the command history.
Ctrl-O	Clears the terminal screen.
Ctrl-P	Displays the previous command in the command history.
Ctrl-R	Redisplays the current command line.
Ctrl-T	Transposes the character under the cursor with the character located to the right of the cursor. The cursor is then moved one character to the right.
Ctrl-U	Deletes all characters from the cursor to the beginning of the command line.
Ctrl-V	Removes any special meaning for the following keystroke. For example, press Ctrl-V before entering a question mark (?) in a regular expression.
Ctrl-W	Deletes the word to the left of the cursor.
Ctrl-X, H	Lists the history of commands you have entered. When using this key combination, press and release the Ctrl and X keys together before pressing H.
Ctrl-Y	Recalls the most recent entry in the buffer (press keys simultaneously).
Ctrl-Z	Ends a configuration session, and returns you to EXEC mode. When used at the end of a command line in which a valid command has been typed, the resulting configuration is first added to the running configuration file.
Up arrow key	Displays the previous command in the command history.
Down arrow key	Displays the next command in the command history.

Keystokes	Description
Right arrow key Left arrow key	Moves your cursor through the command string, either forward or backward, allowing you to edit the current command.
?	Displays a list of available commands.
Tab	<p>Completes the word for you after you enter the first characters of the word and then press the Tab key. All options that match are presented.</p> <p>Use tabs to complete the following items:</p> <ul style="list-style-type: none"> • Command names • Scheme names in the file system • Server names in the file system • Filenames in the file system <p>Example:</p> <pre>switch(config)# c<Tab> callhome class-map clock cts cdp cli control-plane switch(config)# cl<Tab> class-map cli clock switch(config)# cla<Tab> switch(config)# class-map</pre> <p>Example:</p> <pre>switch# cd bootflash:<Tab> bootflash: bootflash://sup-1/ bootflash:/// bootflash://sup-2/ bootflash://module-5/ bootflash://sup-active/ bootflash://module-6/ bootflash://sup-local/</pre> <p>Example:</p> <pre>switch# cd bootflash://mo<Tab> bootflash://module-5/ bootflash://module-6/cv switch# cd bootflash://module-</pre>

Abbreviating Commands

You can abbreviate commands and keywords by entering the first few characters of a command. The abbreviation must include sufficient characters to make it unique from other commands or keywords. If you are having trouble entering a command, check the system prompt and enter the question mark (?) for a list of available commands. You might be in the wrong command mode or using incorrect syntax.

This table lists examples of command abbreviations.

Table 5: Examples of Command Abbreviations

Command	Abbreviation
configure terminal	conf t
copy running-config startup-config	copy run start
interface ethernet 1/2	int e 1/2
show running-config	sh run

Completing a Partial Command Name

If you cannot remember a complete command name, or if you want to reduce the amount of typing you have to perform, enter the first few letters of the command, and then press the **Tab** key. The command line parser will complete the command if the string entered is unique to the command mode. If your keyboard does not have a **Tab** key, press **Ctrl-I** instead.

The CLI recognizes a command once you have entered enough characters to make the command unique. For example, if you enter **conf** in EXEC mode, the CLI will be able to associate your entry with the **configure** command, because only the **configure** command begins with **conf**.

In this example, the CLI recognizes the unique string for **conf** in EXEC mode when you press the **Tab** key:

```
switch# conf<Tab>
switch# configure
```

When you use the command completion feature the CLI displays the full command name. The CLI does not execute the command until you press the **Return** or **Enter** key. This feature allows you to modify the command if the full command was not what you intended by the abbreviation. If you enter a set of characters that could indicate more than one command, a list of matching commands displays.

For example, entering **co<Tab>** lists all commands available in EXEC mode beginning with **co**:

```
switch# co<Tab>
configure    copy
switch# co
```

Note that the characters you entered appear at the prompt again to allow you to complete the command entry.

Identifying Your Location in the Command Hierarchy

Some features have a configuration submode hierarchy nested more than one level. In these cases, you can display information about your present working context (PWC).

SUMMARY STEPS

1. where detail

DETAILED STEPS

	Command or Action	Purpose
Step 1	<p>where detail</p> <p>Example:</p> <pre>switch# configure terminal switch(config)# interface mgmt0 switch(config-if)# where detail mode: conf interface mgmt0 username: admin</pre>	Displays the PWC.

Using the no Form of a Command

Almost every configuration command has a **no** form that can be used to disable a feature, revert to a default value, or remove a configuration. The Cisco NX-OS command reference publications describe the function of the **no** form of the command whenever a **no** form is available.

This example shows how to disable a feature:

```
switch# configure terminal
switch(config)# feature tacacs+
switch(config)# no feature tacacs+
```

This example shows how to revert to the default value for a feature:

```
switch# configure terminal
switch(config)# banner motd #Welcome to the switch#
switch(config)# show banner motd
Welcome to the switch

switch(config)# no banner motd
switch(config)# show banner motd
User Access Verification
```

This example shows how to remove the configuration for a feature:

```
switch# configure terminal
switch(config)# radius-server host 10.10.2.2
switch(config)# show radius-server
retransmission count:0
timeout value:1
deadtime value:1
total number of servers:1

following RADIUS servers are configured:
 10.10.1.1:
    available for authentication on port:1812
    available for accounting on port:1813
 10.10.2.2:
    available for authentication on port:1812
    available for accounting on port:1813

switch(config)# no radius-server host 10.10.2.2
```

```
switch(config)# show radius-server
retransmission count:0
timeout value:1
deadtime value:1
total number of servers:1

following RADIUS servers are configured:
 10.10.1.1:
    available for authentication on port:1812
    available for accounting on port:1813
```

This example shows how to use the **no** form of a command in EXEC mode:

```
switch# cli var name testinterface ethernet1/2
switch# show cli variables
SWITCHNAME="switch"
TIMESTAMP="2009-05-12-13.43.13"
testinterface="ethernet1/2"

switch# cli no var name testinterface
switch# show cli variables
SWITCHNAME="switch"
TIMESTAMP="2009-05-12-13.43.13"
```

Configuring CLI Variables

This section describes CLI variables in the Cisco NX-OS CLI.

About CLI Variables

The Cisco NX-OS software supports the definition and use of variables in CLI commands.

You can refer to CLI variables in the following ways:

- Entered directly on the command line.
- Passed to a script initiated using the **run-script** command. The variables defined in the parent shell are available for use in the child **run-script** command process.

CLI variables have the following characteristics:

- Cannot have nested references through another variable
- Can persist across switch reloads or exist only for the current session

Cisco NX-OS supports one predefined variable: **TIMESTAMP**. This variable refers to the current time when the command executes in the format **YYYY-MM-DD-HH.MM.SS**.



Note The **TIMESTAMP** variable name is case sensitive. All letters must be uppercase.

Configuring CLI Session-Only Variables

You can define CLI session variables to persist only for the duration of your CLI session. These variables are useful for scripts that you execute periodically. You can reference the variable by enclosing the name in parentheses and preceding it with a dollar sign (\$), for example `$(variable-name)`.

SUMMARY STEPS

1. **cli var name** *variable-name variable-text*
2. (Optional) **show cli variables**

DETAILED STEPS

	Command or Action	Purpose
Step 1	cli var name <i>variable-name variable-text</i> Example: <pre>switch# cli var name testinterface ethernet 2/1</pre>	Configures the CLI session variable. The <i>variable-name</i> argument is alphanumeric, case sensitive, and has a maximum length of 31 characters. The <i>variable-text</i> argument is alphanumeric, case sensitive, can contain spaces, and has a maximum length of 200 characters.
Step 2	(Optional) show cli variables Example: <pre>switch# show cli variables</pre>	Displays the CLI variable configuration.

Configuring Persistent CLI Variables

You can configure CLI variables that persist across CLI sessions and device reloads.

SUMMARY STEPS

1. **configure terminal**
2. **cli var name** *variable-name variable-text*
3. **exit**
4. (Optional) **show cli variables**
5. (Optional) **copy running-config startup-config**

DETAILED STEPS

	Command or Action	Purpose
Step 1	configure terminal Example: <pre>switch# configure terminal switch(config)#</pre>	Enters global configuration mode.
Step 2	cli var name <i>variable-name variable-text</i> Example:	Configures the CLI persistent variable. The variable name is a case-sensitive, alphanumeric string and must begin with an alphabetic character. The maximum length is 31 characters.

	Command or Action	Purpose
	<code>switch(config)# cli var name testinterface ethernet 2/1</code>	
Step 3	exit Example: <code>switch(config)# exit</code> <code>switch#</code>	Exits global configuration mode.
Step 4	(Optional) show cli variables Example: <code>switch# show cli variables</code>	Displays the CLI variable configuration.
Step 5	(Optional) copy running-config startup-config Example: <code>switch(config)# copy running-config startup-config</code>	Copies the running configuration to the startup configuration.

Command Aliases

This section provides information about command aliases.

About Command Aliases

You can define command aliases to replace frequently used commands. The command aliases can represent all or part of the command syntax.

Command alias support has the following characteristics:

- Command aliases are global for all user sessions.
- Command aliases persist across reboots if you save them to the startup configuration.
- Command alias translation always takes precedence over any keyword in any configuration mode or submode.
- Command alias configuration takes effect for other user sessions immediately.
- The Cisco NX-OS software provides one default alias, **alias**, which is the equivalent to the **show cli alias** command that displays all user-defined aliases.
- You cannot delete or change the default command alias **alias**.
- You can nest aliases to a maximum depth of 1. One command alias can refer to another command alias that must refer to a valid command, not to another command alias.
- A command alias always replaces the first command keyword on the command line.
- You can define command aliases for commands in any command mode.
- If you reference a CLI variable in a command alias, the current value of the variable appears in the alias, not the variable reference.

- You can use command aliases for **show** command searching and filtering.

Defining Command Aliases

You can define command aliases for commonly used commands.

SUMMARY STEPS

1. **configure terminal**
2. **cli alias name** *alias-name alias-text*
3. **exit**
4. (Optional) **alias**
5. (Optional) **copy running-config startup-config**

DETAILED STEPS

	Command or Action	Purpose
Step 1	configure terminal Example: <pre>switch# configure terminal switch(config)#</pre>	Enters global configuration mode.
Step 2	cli alias name <i>alias-name alias-text</i> Example: <pre>switch(config)# cli alias name ethint interface ethernet</pre>	Configures the command alias. The alias name is an alphanumeric string that is not case sensitive and must begin with an alphabetic character. The maximum length is 30 characters.
Step 3	exit Example: <pre>switch(config)# exit switch#</pre>	Exits global configuration mode.
Step 4	(Optional) alias Example: <pre>switch# alias</pre>	Displays the command alias configuration.
Step 5	(Optional) copy running-config startup-config Example: <pre>switch# copy running-config startup-config</pre>	Copies the running configuration to the startup configuration.

Configuring Command Aliases for a User Session

You can create a command alias for the current user session that is not available to any other user on the Cisco NX-OS device. You can also save the command alias for future use by the current user account.

SUMMARY STEPS

1. `terminal alias [persist] alias-name command -string`

DETAILED STEPS

	Command or Action	Purpose
Step 1	terminal alias [persist] alias-name command -string Example: <pre>switch# terminal alias shintbr show interface brief</pre>	Configures a command alias for the current user session. Use the persist keyword to save the alias for future use by the user account. Note Do not abbreviate the persist keyword.

Command Scripts

This section describes how you can create scripts of commands to perform multiple tasks.

Running a Command Script

You can create a list of commands in a file and execute them from the CLI. You can use CLI variables in the command script.



Note You cannot create the script files at the CLI prompt. You can create the script file on a remote device and copy it to the `bootflash:`, `slot0:`, or `volatile:` directory on the Cisco NX-OS device.

SUMMARY STEPS

1. `run-script [bootflash: | slot0: | volatile:]filename`

DETAILED STEPS

	Command or Action	Purpose
Step 1	run-script [bootflash: slot0: volatile:]filename Example: <pre>switch# run-script testfile</pre>	Executes the commands in the file on the default directory.

Echoing Information to the Terminal

You can echo information to the terminal, which is particularly useful from a command script. You can reference CLI variables and use formatting options in the echoed text.

This table lists the formatting options that you can insert in the text.

Table 6: Formatting Options for the echo Command

Formatting Option	Description
\b	Inserts back spaces.
\c	Removes the new line character at the end of the text string.
\f	Inserts a form feed character.
\n	Inserts a new line character.
\r	Returns to the beginning of the text line.
\t	Inserts a horizontal tab character.
\v	Inserts a vertical tab character.
\\	Displays a backslash character.
\nnn	Displays the corresponding ASCII octal character.

SUMMARY STEPS

1. `echo [backslash-interpret] [text]`

DETAILED STEPS

	Command or Action	Purpose
Step 1	<code>echo [backslash-interpret] [text]</code> Example: <pre>switch# echo This is a test. This is a test.</pre>	The backslash-interpret keyword indicates that the text string contains formatting options. The <i>text</i> argument is alphanumeric, case sensitive, and can contain blanks. The maximum length is 200 characters. The default is a blank line.

Delaying Command Action

You can delay a command action for a period of time, which is particularly useful within a command script.

SUMMARY STEPS

1. `sleep seconds`

DETAILED STEPS

	Command or Action	Purpose
Step 1	<p><code>sleep seconds</code></p> <p>Example:</p> <pre>switch# sleep 30</pre>	Causes a delay for a number of seconds. The range is from 0 to 2147483647.

Context-Sensitive Help

The Cisco NX-OS software provides context-sensitive help in the CLI. You can use a question mark (?) at any point in a command to list the valid input options.

CLI uses the caret (^) symbol to isolate input errors. The ^ symbol appears at the point in the command string where you have entered an incorrect command, keyword, or argument.

This table shows example outputs of context sensitive help.

Table 7: Context-Sensitive Help Example

Example Outputs	Description
<pre>switch# clock ? set HH:MM:SS Current Time switch# clock</pre>	<p>Displays the command syntax for the clock command in EXEC mode.</p> <p>The switch output shows that the set keyword is required for using the clock command.</p>
<pre>switch# clock set ? WORD HH:MM:SS Current Time switch# clock set</pre>	<p>Displays the command syntax for setting the time.</p> <p>The help output shows that the current time is required for setting the clock and how to format the time.</p>
<pre>switch# clock set 13:32:00<CR> % Incomplete command switch#</pre>	<p>Adds the current time.</p> <p>The CLI indicates the command is incomplete.</p>
<pre>switch# <Ctrl-P> switch# clock set 13:32:00</pre>	Displays the previous command that you entered.
<pre>switch# clock set 13:32:00 ? <1-31> Day of the month switch# clock set 13:32:00</pre>	Displays the additional arguments for the clock set command.

Example Outputs	Description
<pre>switch# clock set 13:32:00 18 ? April Month of the year August Month of the year December Month of the year February Month of the year January Month of the year July Month of the year June Month of the year March Month of the year May Month of the year November Month of the year October Month of the year September Month of the year switch# clock set 13:32:00 18</pre>	Displays the additional arguments for the clock set command.
<pre>switch# clock set 13:32:00 18 April 08<CR> % Invalid input detected at '^' marker.</pre>	Adds the date to the clock setting. The CLI indicates an error with the caret symbol (^) at 08.
<pre>switch# clock set 13:32:00 18 April ? <2000-2030> Enter the year (no abbreviation) switch# clock set 13:32:00 18 April</pre>	Displays the correct arguments for the year.
<pre>switch# clock set 13:32:00 18 April 2008<CR> switch#</pre>	Enters the correct syntax for the clock set command.

Understanding Regular Expressions

The Cisco NX-OS software supports regular expressions for searching and filtering in CLI output, such as the **show** commands. Regular expressions are case sensitive and allow for complex matching requirements.

Special Characters

You can also use other keyboard characters (such as ! or ~) as single-character patterns, but certain keyboard characters have special meanings when used in regular expressions.

This table lists the keyboard characters that have special meanings.

Table 8: Special Characters with Special Meaning

Character	Special Meaning
.	Matches any single character, including white space.
*	Matches 0 or more sequences of the pattern.
+	Matches 1 or more sequences of the pattern.
?	Matches 0 or 1 occurrences of the pattern.

Character	Special Meaning
^	Matches the beginning of the string.
\$	Matches the end of the string.
_ (underscore)	Matches a comma (,), left brace ({), right brace (}), left parenthesis ((), right parenthesis ()), the beginning of the string, the end of the string, or a space.

To use these special characters as single-character patterns, remove the special meaning by preceding each character with a backslash (\). This example contains single-character patterns that match a dollar sign (\$), an underscore (_), and a plus sign (+), respectively:

```
\$ \_ \+
```

Multiple-Character Patterns

You can also specify a pattern that contains multiple characters by joining letters, digits, or keyboard characters that do not have special meanings. For example, `a4%` is a multiple-character regular expression.

With multiple-character patterns, the order is important. The regular expression `a4%` matches the character `a` followed by a `4` followed by a percent sign (`%`). If the string does not have `a4%`, in that order, pattern matching fails. The multiple-character regular expression `a.` (the character `a` followed by a period) uses the special meaning of the period character to match the letter `a` followed by any single character. With this example, the strings `ab`, `a!`, or `a2` are all valid matches for the regular expression.

You can remove the special meaning of a special character by inserting a backslash before it. For example, when the expression `a\.` is used in the command syntax, only the string `a.` will be matched.

Anchoring

You can match a regular expression pattern against the beginning or the end of the string by anchoring these regular expressions to a portion of the string using the special characters.

This table lists the special characters that you can use for anchoring.

Table 9: Special Characters Used for Anchoring

Character	Description
^	Matches the beginning of the string.
\$	Matches the end of the string.

For example, the regular expression `^con` matches any string that starts with `con`, and `sole$` matches any string that ends with `sole`.



Note The `^` symbol can also be used to indicate the logical function "not" when used in a bracketed range. For example, the expression `[^abcd]` indicates a range that matches any single letter, as long as it is not `a`, `b`, `c`, or `d`.

Searching and Filtering show Command Output

Often, the output from **show** commands can be lengthy and cumbersome. The Cisco NX-OS software provides the means to search and filter the output so that you can easily locate information. The searching and filtering options follow a pipe character (|) at the end of the **show** command. You can display the options using the CLI context-sensitive help facility:

```
switch# show running-config | ?
cut      Print selected parts of lines.
diff     Show difference between current and previous invocation (creates temp files:
         remove them with 'diff-clean' command and don't use it on commands with big
         outputs, like 'show tech!')
egrep    Egrep - print lines matching a pattern
grep     Grep - print lines matching a pattern
head     Display first lines
human    Output in human format
last     Display last lines
less     Filter for paging
no-more  Turn-off pagination for command output
perl     Use perl script to filter output
section  Show lines that include the pattern as well as the subsequent lines that are
         more indented than matching line
sed      Stream Editor
sort     Stream Sorter
sscp     Stream SCP (secure copy)
tr       Translate, squeeze, and/or delete characters
uniq     Discard all but one of successive identical lines
vsh      The shell that understands cli command
wc       Count words, lines, characters
begin    Begin with the line that matches
count    Count number of lines
end      End with the line that matches
exclude  Exclude lines that match
include  Include lines that match
```

Filtering and Searching Keywords

The Cisco NX-OS CLI provides a set of keywords that you can use with the **show** commands to search and filter the command output.

This table lists the keywords for filtering and searching the CLI output.

Table 10: Filtering and Searching Keywords

Keyword Syntax	Description
begin <i>string</i> Example: <code>show version begin Hardware</code>	Starts displaying at the line that contains the text that matches the search string. The search string is case sensitive.
count Example: <code>show running-config count</code>	Displays the number of lines in the command output.

Keyword Syntax	Description
cut [-d <i>character</i>] {-b -c -f -s} Example: <pre>show file testoutput cut -b 1-10</pre>	Displays only part of the output lines. You can display a number of bytes (-b), characters (-vcut [-d <i>character</i>] {-b -c -f -s}), or fields (-f). You can also use the -d keyword to define a field delimiter other than the tag character default. The -s keyword suppresses the display of the lines that do not contain the delimiter.
end <i>string</i> Example: <pre>show running-config end interface</pre>	Displays all lines up to the last occurrence of the search string.
exclude <i>string</i> Example: <pre>show interface brief exclude down</pre>	Displays all lines that do not include the search string. The search string is case sensitive.
head [<i>lines lines</i>] Example: <pre>show logging logfile head lines 50</pre>	Displays the beginning of the output for the number of lines specified. The default number of lines is 10.
include <i>string</i> Example: <pre>show interface brief include up</pre>	Displays all lines that include the search string. The search string is case sensitive.
last [<i>lines</i>] Example: <pre>show logging logfile last 50</pre>	Displays the end of the output for the number of lines specified. The default number of lines is 10.
no-more Example: <pre>show interface brief no-more</pre>	Displays all the output without stopping at the end of the screen with the --More-- prompt.
sscp <i>SSH-connection-name filename</i> Example: <pre>show version sscp MyConnection show_version_output</pre>	Redirects the output using streaming secure copy (sscp) to a named SSH connection. You can create the SSH named connection using the ssh name command.
wc [<i>bytes lines words</i>] Example: <pre>show file testoutput wc bytes</pre>	Displays counts of characters, lines, or words. The default is to display the number of lines, words, and characters.

diff Utility

You can compare the output from a **show** command with the output from the previous invocation of that command.

diff-clean [**all-session**] [**all-users**]

This table describes the keywords for the diff utility.

Keyword	Description
all-sessions	Removes diff temporary files from all sessions (past and present sessions) of the current user.
all-users	Removes diff temporary files from all sessions (past and present sessions) of all users.

The Cisco NX-OS software creates temporary files for the most current output for a **show** command for all current and previous users sessions. You can remove these temporary files using the **diff-clean** command.

diff-clean [**all-sessions** | **all-users**]

By default, the **diff-clean** command removes the temporary files for the current user's active session. The **all-sessions** keyword removes temporary files for all past and present sessions for the current user. The **all-users** keyword removes temporary files for all past and present sessions for the all users.

grep and egrep Utilities

You can use the Global Regular Expression Print (grep) and Extended grep (egrep) command-line utilities to filter the **show** command output.

The grep and egrep syntax is as follows:

```
{grep | egrep} [count] [ignore-case] [invert-match] [line-exp] [line-number] [next lines] [prev lines] [word-exp expression]
```

This table lists the **grep** and **egrep** parameters.

Table 11: grep and egrep Parameters

Parameter	Description
count	Displays only the total count of matched lines.
ignore-case	Specifies to ignore the case difference in matched lines.
invert-match	Displays lines that do not match the expression.
line-exp	Displays only lines that match a complete line.
line-number	Specifies to display the line number before each matched line.
next lines	Specifies the number of lines to display after a matched line. The default is 0. The range is from 1 to 999.
prev lines	Specifies the number of lines to display before a matched line. The default is 0. The range is from 1 to 999.

Parameter	Description
word-exp	Displays only lines that match a complete word.
<i>expression</i>	Specifies a regular expression for searching the output.

less Utility

You can use the less utility to display the contents of the **show** command output one screen at a time. You can enter **less** commands at the `:` prompt. To display all **less** commands you can use, enter **h** at the `:` prompt.

sed Utility

You can use the Stream Editor (sed) utility to filter and manipulate the **show** command output as follows:

sed command

The *command* argument contains sed utility commands.

sort Utility

You can use the sort utility to filter **show** command output.

The sort utility syntax is as follows:

sort [-M] [-b] [-d] [-f] [-g] [-i] [-k *field-number*[*.char-position*][*ordering*]] [-n] [-r] [-t *delimiter*] [-u]

This table describes the sort utility parameters.

Table 12: sort Utility Parameters

Parameter	Description
-M	Sorts by month.
-b	Ignores leading blanks (space characters). The default sort includes the leading blanks.
-d	Sorts by comparing only blanks and alphanumeric characters. The default sort includes all characters.
-f	Folds lowercase characters into uppercase characters.
-g	Sorts by comparing a general numeric value.
-i	Sorts only using printable characters. The default sort includes nonprintable characters.
-k <i>field-number</i> [<i>.char-position</i>][<i>ordering</i>]	Sorts according to a key value. There is no default key value.
-n	Sorts according to a numeric string value.

Parameter	Description
-r	Reverses order of the sort results. The default sort output is in ascending order.
-t delimiter	Sorts using a specified delimiter. The default delimiter is the space character.
-u	Removes duplicate lines from the sort results. The sort output displays the duplicate lines.

Redirecting show Command Output Using sscp

You can use the Streamed Secure Copy Protocol (sscp) to redirect the **show** command output to a file on a remote server.

sscp *connection-name destination-file*



Note You must create a named Secure Shell (SSH) connection before using sscp.

The following example shows how to copy **show** command output to a remote server using sscp:

```
switch# ssh name mybox testuser 172.23.152.34

                               WARNING!!!
                               READ THIS BEFORE ATTEMPTING TO LOGON

                               This System is for the use of authorized users only.  Individuals
                               using this computer without authority, or in excess of their
                               ...

testuser@172.23.152.34's password: Ctrl-C
switch# show running-config | sscp mybox /users/testuser/sscp_output
```

Searching and Filtering from the --More-- Prompt

You can search and filter output from --More-- prompts in the **show** command output.

This table describes the --More-- prompt commands.

Table 13: --More-- Prompt Commands

Commands	Description
[lines]<space>	Displays output lines for either the specified number of lines or the current screen size.
[lines]z	Displays output lines for either the specified number of lines or the current screen size. If you use the <i>lines</i> argument, that value becomes the new default screen size.

Commands	Description
[<i>lines</i>]<return>	Displays output lines for either the specified number of lines or the current default number of lines. The initial default is 1 line. If you use the optional <i>lines</i> argument, that value becomes the new default number of lines to display for this command.
[<i>lines</i>]d or [<i>lines</i>]Ctrl+shift+D	Scrolls through output lines for either the specified number of lines or the current default number of lines. The initial default is 11 lines. If you use the optional <i>lines</i> argument, that value becomes the new default number of lines to display for this command.
q or Q or Ctrl-C	Exits the --More-- prompt.
[<i>lines</i>]s	Skips forward in the output for either the specified number of lines or the current default number of lines and displays a screen of lines. The default is 1 line.
[<i>lines</i>]f	Skips forward in the output for either the specified number of screens or the current default number of screens and displays a screen of lines. The default is 1 screen.
=	Displays the current line number.
[<i>count</i>]/ <i>expression</i>	Skips to the line that matches the regular expression and displays a screen of output lines. Use the optional <i>count</i> argument to search for lines with multiple occurrences of the expression. This command sets the current regular expression that you can use in other commands.
[<i>count</i>]n	Skips to the next line that matches the current regular expression and displays a screen of output lines. Use the optional <i>count</i> argument to skip past matches.
{! :![<i>shell-cmd</i>]}	Executes the command specified in the <i>shell-cmd</i> argument in a subshell.
.	Repeats the previous command.

Using the Command History

The Cisco NX-OS software CLI allows you to access the command history for the current user session. You can recall and reissue commands, with or without modification. You can also clear the command history.

Recalling a Command

You can recall a command in the command history to optionally modify and enter again.

This example shows how to recall a command and reenter it:

```
switch(config)# show cli history
0 11:04:07 configure terminal
1 11:04:28 show interface ethernet 2/24
2 11:04:39 interface ethernet 2/24
3 11:05:13 no shutdown
4 11:05:19 exit
5 11:05:25 show cli history
```

```
switch(config)# !1
switch(config)# show interface ethernet 2/24
```

You can also use the **Ctrl-P** and **Ctrl-N** keystroke shortcuts to recall commands.

Configuring the CLI Edit Mode

You can recall commands from the CLI history using the **Ctrl-P** and **Ctrl-N** keystroke shortcuts and edit them before reissuing them. The default edit mode is emacs. You can change the edit mode to vi.

SUMMARY STEPS

1. **[no] terminal edit-mode vi [persist]**

DETAILED STEPS

	Command or Action	Purpose
Step 1	[no] terminal edit-mode vi [persist] Example: <pre>switch# terminal edit-mode vi</pre>	Changes the CLI edit mode to vi for the user session. The persist keyword makes the setting persistent across sessions for the current username. Use the no to revert to using emacs.

Controlling CLI History Recall

You can control the commands that you recall from the CLI history using the **Ctrl-P** and **Ctrl-N** keystroke shortcuts. Cisco NX-OS software recalls all commands from the current command mode and higher command modes. For example, if you are working in global configuration mode, the command recall keystroke shortcuts recall both EXEC mode and global configuration mode commands.

Displaying the Command History

You can display the command history using the **show cli history** command.

The **show cli history** command has the following syntax:

By default, the number of lines displayed is 12 and the output includes the command number and timestamp.

The example shows how to display default number of lines of the command history:

```
switch# show cli history
```

The example shows how to display 20 lines of the command history:

```
switch# show cli history 20
```

The example shows how to display only the commands in the command history without the command number and timestamp:

```
switch(config)# show cli history unformatted
```

Enabling or Disabling the CLI Confirmation Prompts

For many features, the Cisco NX-OS software displays prompts on the CLI that ask for confirmation before continuing. You can enable or disable these prompts. The default is enabled.

SUMMARY STEPS

1. `[no] terminal dont-ask [persist]`

DETAILED STEPS

	Command or Action	Purpose
Step 1	<code>[no] terminal dont-ask [persist]</code> Example: <pre>switch# terminal dont-ask</pre>	Disables the CLI confirmation prompt. The persist keyword makes the setting persistent across sessions for the current username. The default is enabled. Use the no form of the command to enable the CLI confirmation prompts.

Setting CLI Display Colors

You can change the CLI colors to display as follows:

- The prompt displays in green if the previous command succeeded.
- The prompt displays in red if the previous command failed.
- The user input displays in blue.
- The command output displays in the default color.

The default colors are those set by the terminal emulator software.

SUMMARY STEPS

1. `terminal color [evening] [persist]`

DETAILED STEPS

	Command or Action	Purpose
Step 1	<code>terminal color [evening] [persist]</code> Example: <pre>switch# terminal color</pre>	Sets the CLI display colors for the terminal session. The evening keyword is not supported. The persist keyword makes the setting persistent across sessions for the current username. The default setting is not persistent.

Sending Commands to Modules

You can send commands directly to modules from the supervisor module session using the **slot** command.

The **slot** has the following syntax:

```
slot slot-number [quoted] command-string
```

By default, the keyword and arguments in the *command-string* argument are separated by a space. To send more than one command to a module, separate the commands with a space character, a semicolon character (;), and a space character.

The **quoted** keyword indicates that the command string begins and ends with double quotation marks ("). Use this keyword when you want to redirect the module command output to a filtering utility, such as diff, that is supported only on the supervisor module session.

This example shows how to display and filter module information:

```
switch# slot 2 show version | grep lc
```

This example shows how to filter module information on the supervisor module session:

```
switch# slot 2 quoted "show version" | diff
switch# slot 4 quoted "show version" | diff -c
*** /volatile/vsh_diff_1_root_8430_slot__quoted_show_version.old      Wed Apr 29 20:10:41
    2009
--- -   Wed Apr 29 20:10:41 2009
*****
*** 1,5 ****
! RAM 1036860 kB
! lc2
   Software
     BIOS:      version 1.10.6
     system:    version 4.2(1) [build 4.2(0.202)]
--- 1,5 ----
! RAM 516692 kB
! lc4
   Software
     BIOS:      version 1.10.6
     system:    version 4.2(1) [build 4.2(0.202)]
*****
*** 12,16 ****
   Hardware
     bootflash: 0 blocks (block size 512b)

!   uptime is 0 days 1 hours 45 minute(s) 34 second(s)

--- 12,16 ----
   Hardware
     bootflash: 0 blocks (block size 512b)

!   uptime is 0 days 1 hours 45 minute(s) 42 second(s)
```

BIOS Loader Prompt

When the supervisor modules power up, a specialized BIOS image automatically loads and tries to locate a valid kickstart image for booting the system. If a valid kickstart image is not found, the following BIOS loader prompt displays:

```
loader>
```

For information on how to load the Cisco NX-OS software from the `<loader>` prompt, see the Cisco Nexus troubleshooting guide for your device.

Examples Using the CLI

This section includes examples of using the CLI.

Defining Command Aliases

This example shows how to define command aliases:

```
cli alias name ethint interface ethernet
cli alias name shintbr show interface brief
cli alias name shintupbr shintbr | include up | include ethernet
```

This example shows how to use a command alias:

```
switch# configure terminal
switch(config)# ethint 2/3
switch(config-if)#
```

Using CLI Session Variables

You can reference a variable using the syntax `$(variable-name)`.

This example shows how to reference a user-defined CLI session variable:

```
switch# show interface $(testinterface)
Ethernet2/1 is down (Administratively down)
  Hardware is 10/100/1000 Ethernet, address is 0000.0000.0000 (bia 0019.076c.4dac)
  MTU 1500 bytes, BW 1000000 Kbit, DLY 10 usec,
    reliability 255/255, txload 1/255, rxload 1/255
  Encapsulation ARPA
  auto-duplex, auto-speed
  Beacon is turned off
  Auto-Negotiation is turned on
  Input flow-control is off, output flow-control is off
  Auto-mdix is turned on
  Switchport monitor is off
  Last clearing of "show interface" counters never
  5 minute input rate 0 bytes/sec, 0 packets/sec
```

```

5 minute output rate 0 bytes/sec, 0 packets/sec
L3 in Switched:
  ucast: 0 pkts, 0 bytes - mcast: 0 pkts, 0 bytes
L3 out Switched:
  ucast: 0 pkts, 0 bytes - mcast: 0 pkts, 0 bytes
Rx
  0 input packets 0 unicast packets 0 multicast packets
  0 broadcast packets 0 jumbo packets 0 storm suppression packets
  0 bytes
Tx
  0 output packets 0 multicast packets
  0 broadcast packets 0 jumbo packets
  0 bytes
  0 input error 0 short frame 0 watchdog
  0 no buffer 0 runt 0 CRC 0 ecc
  0 overrun 0 underrun 0 ignored 0 bad etype drop
  0 bad proto drop 0 if down drop 0 input with dribble
  0 input discard
  0 output error 0 collision 0 deferred
  0 late collision 0 lost carrier 0 no carrier
  0 babble
  0 Rx pause 0 Tx pause 0 reset

```

Using the System-Defined Timestamp Variable

This example uses \$(TIMESTAMP) when redirecting **show** command output to a file:

```

switch# show running-config > rcfg.$(TIMESTAMP)
Preparing to copy....done
switch# dir
      12667      May 01 12:27:59 2008  rcfg.2008-05-01-12.27.59

Usage for bootflash://sup-local
8192 bytes used
20963328 bytes free
20971520 bytes total

```

Running a Command Script

This example displays the CLI commands specified in the script file:

```

switch# show file testfile
configure terminal
interface ethernet 2/1
no shutdown
end
show interface ethernet 2/1

```

This example displays the **run-script** command execution output:

```

switch# run-script testfile
`configure terminal`
`interface ethernet 2/1`
`no shutdown`
`end`
`show interface ethernet 2/1 `
Ethernet2/1 is down (Link not connected)

```

```

Hardware is 10/100/1000 Ethernet, address is 0019.076c.4dac (bia 0019.076c.4dac)
MTU 1500 bytes, BW 1000000 Kbit, DLY 10 usec,
    reliability 255/255, txload 1/255, rxload 1/255
Encapsulation ARPA
Port mode is trunk
auto-duplex, auto-speed
Beacon is turned off
Auto-Negotiation is turned on
Input flow-control is off, output flow-control is off
Auto-mdix is turned on
Switchport monitor is off
Last clearing of "show interface" counters 1d26.2uh
5 minute input rate 0 bytes/sec, 0 packets/sec
5 minute output rate 0 bytes/sec, 0 packets/sec
Rx
  0 input packets 0 unicast packets 0 multicast packets
  0 broadcast packets 0 jumbo packets 0 storm suppression packets
  0 bytes
Tx
  0 output packets 0 multicast packets
  0 broadcast packets 0 jumbo packets
  0 bytes
  0 input error 0 short frame 0 watchdog
  0 no buffer 0 runt 0 CRC 0 ecc
  0 overrun 0 underrun 0 ignored 0 bad etype drop
  0 bad proto drop 0 if down drop 0 input with dribble
  0 input discard
  0 output error 0 collision 0 deferred
  0 late collision 0 lost carrier 0 no carrier
  0 babble
  0 Rx pause 0 Tx pause 0 reset

```

Using the sscp Utility to Redirect show Command Output

This example shows how to redirect **show** command output using the sscp utility:

```
switch# ssh name MyConnection MyId 172.28.255.18
```

```

WARNING!!!
READ THIS BEFORE ATTEMPTING TO LOGON

```

```

This System is for the use of authorized users only. Individuals
using this computer without authority, or in excess of their
authority, are subject to having all of their activities on this
system monitored and recorded by system personnel. In the course
of monitoring individuals improperly using this system, or in the
course of system maintenance, the activities of authorized users
may also be monitored. Anyone using this system expressly
consents to such monitoring and is advised that if such
monitoring reveals possible criminal activity, system personnel
may provide the evidence of such monitoring to law enforcement
officials.

```

```

MyId@172.28.255.18's password:
switch# show version | sscp MyConnection show_version_output
switch#

```



CHAPTER 6

Configuring Terminal Settings and Sessions

This chapter describes how to configure terminal settings and sessions.

- [Information About Terminal Settings and Sessions, on page 67](#)
- [Configuring the Console Port, on page 69](#)
- [Configuring the COM1 Port, on page 71](#)
- [Configuring Virtual Terminals, on page 72](#)
- [Configuring Modem Connections, on page 75](#)
- [Clearing Terminal Sessions, on page 79](#)
- [Displaying Terminal and Session Information, on page 79](#)
- [Default Settings for Terminal Display and Session Parameters, on page 80](#)

Information About Terminal Settings and Sessions

This section includes information about terminal settings and sessions.

Terminal Session Settings

The Cisco NX-OS software features allow you to manage the following characteristics of terminals:

Terminal type

Name used by Telnet when communicating with remote hosts

Length

Number of lines of command output displayed before pausing

Width

Number of characters displayed before wrapping the line

Inactive session timeout

Number of minutes that a session remains inactive before the device terminates it

Console Port

The console port is an asynchronous serial port that allows you to connect to the device for initial configuration through a standard RS-232 port with an RJ-45 connector. Any device connected to this port must be capable of asynchronous transmission. You can configure the following parameters for the console port:

Data bits

Specifies the number of bits in an 8-bit byte that is used for data.

Inactive session timeout

Specifies the number of minutes a session can be inactive before it is terminated.

Parity

Specifies the odd or even parity for error detection.

Speed

Specifies the transmission speed for the connection.

Stop bits

Specifies the stop bits for an asynchronous line.

Configure your terminal emulator with 9600 baud, 8 data bits, 1 stop bit, and no parity.

COM1 Port

A COM1 port is an RS-232 port with a DB-9 interface that enables you to connect to an external serial communication device such as a modem. You can configure the following parameters for the COM1 port:

Data bits

Specifies the number of bits in an 8-bit byte that is used for data.

Hardware flowcontrol

Enables the flow-control hardware.

Parity

Specifies the odd or even parity for error detection.

Speed

Specifies the transmission speed for the connection.

Stop bits

Specifies the stop bits for an asynchronous line.

Configure your terminal emulator with 9600 baud, 8 data bits, 1 stop bit, and no parity.

Virtual Terminals

You can use virtual terminal lines to connect to your Cisco NX-OS device. Secure Shell (SSH) and Telnet create virtual terminal sessions. You can configure an inactive session timeout and a maximum sessions limit for virtual terminals.

Modem Support

You can connect a modem to the COM1 or console ports only on the supervisor 1 module. The following modems were tested on devices running the Cisco NX-OS software:

- MultiTech MT2834BA (http://www.multitech.com/en_us/support/families/multimodemii/)
- Hayes Accura V.92 (http://www.zoom.com/products/dial_up_external_serial.html#hayes)

**Note**

Do not connect a modem when the device is booting. Only connect the modem when the device is powered up.

The Cisco NX-OS software has the default initialization string (ATE0Q1&D2&C1S0=1\015) to detect connected modems. The default string is defined as follows:

AT
Attention

E0 (required)
No echo

Q1
Result code on

&D2
Normal data terminal ready (DTR) option

&C1
Enable tracking the state of the data carrier

S0=1
Pick up after one ring

\015 (required)
Carriage return in octal

Configuring the Console Port

You can set the following characteristics for the console port:

- Data bits
- Inactive session timeout
- Parity
- Speed
- Stop bits

Before you begin

Log in to the console port.

SUMMARY STEPS

1. **configure terminal**
2. **line console**
3. **databits** *bits*
4. **exec-timeout** *minutes*
5. **parity** {*even* | *none* | *odd*}
6. **speed** {*300* | *1200* | *2400* | *4800* | *9600* | *38400* | *57600* | *115200*}
7. **stopbits** {*1* | *2*}
8. **exit**
9. (Optional) **show line console**
10. (Optional) **copy running-config startup-config**

DETAILED STEPS

	Command or Action	Purpose
Step 1	configure terminal Example: switch# configure terminal switch(config)#	Enters global configuration mode.
Step 2	line console Example: switch# line console switch(config-console)#	Enters console configuration mode.
Step 3	databits <i>bits</i> Example: switch(config-console)# databits 7	Configures the number of data bits per byte. The range is from 5 to 8. The default is 8.
Step 4	exec-timeout <i>minutes</i> Example: switch(config-console)# exec-timeout 30	Configures the timeout for an inactive session. The range is from 0 to 525600 minutes (8760 hours). A value of 0 minutes disables the session timeout. The default is 30 minutes.
Step 5	parity {even none odd} Example: switch(config-console)# parity even	Configures the parity. The default is none .
Step 6	speed {300 1200 2400 4800 9600 38400 57600 115200} Example: switch(config-console)# speed 115200	Configures the transmit and receive speed. The default is 9600 .
Step 7	stopbits {1 2} Example: switch(config-console)# stopbits 2	Configures the stop bits. The default is 1 .
Step 8	exit Example: switch(config-console)# exit switch(config)#	Exits console configuration mode.
Step 9	(Optional) show line console Example: switch(config)# show line console	Displays the console settings.
Step 10	(Optional) copy running-config startup-config Example: switch(config)# copy running-config startup-config	Copies the running configuration to the startup configuration.

Configuring the COM1 Port

You can set the following characteristics for the COM1 port:

- Data bits
- Flow control on the hardware
- Parity
- Speed
- Stop bits

Before you begin

Log in to the console port or COM1 port.

SUMMARY STEPS

1. **configure terminal**
2. **line com1**
3. **databits *bits***
4. **flowcontrol hardware**
5. **parity {even | none | odd}**
6. **speed {300 | 1200 | 2400 | 4800 | 9600 | 38400 | 57600 | 115200}**
7. **stopbits {1 | 2}**
8. **exit**
9. (Optional) **show line com1**
10. (Optional) **copy running-config startup-config**

DETAILED STEPS

	Command or Action	Purpose
Step 1	configure terminal Example: <pre>switch# configure terminal switch(config)#</pre>	Enters global configuration mode.
Step 2	line com1 Example: <pre>switch# line com1 switch(config-com1)#</pre>	Enters COM1 configuration mode.
Step 3	databits <i>bits</i> Example: <pre>switch(config-com1)# databits 7</pre>	Configures the number of data bits per byte. The range is from 5 to 8. The default is 8.

	Command or Action	Purpose
Step 4	flowcontrol hardware Example: <code>switch(config-com1)# flowcontrol hardware</code>	Enables flow control on the hardware. The default is enabled. Use the no flowcontrol hardware command to disable flow control on the hardware.
Step 5	parity {even none odd} Example: <code>switch(config-com1)# parity even</code>	Configures the parity. The default is none .
Step 6	speed {300 1200 2400 4800 9600 38400 57600 115200} Example: <code>switch(config-com1)# speed 115200</code>	Configures the transmit and receive speed. The default is 9600 .
Step 7	stopbits {1 2} Example: <code>switch(config-com1)# stopbits 2</code>	Configures the stop bits. The default is 1 .
Step 8	exit Example: <code>switch(config-com1)# exit</code> <code>switch(config)#</code>	Exits COM1 configuration mode.
Step 9	(Optional) show line com1 Example: <code>switch(config)# show line com1</code>	Displays the COM1 port settings.
Step 10	(Optional) copy running-config startup-config Example: <code>switch(config)# copy running-config startup-config</code>	Copies the running configuration to the startup configuration.

Configuring Virtual Terminals

This section describes how to configure virtual terminals on Cisco NX-OS devices.

Configuring the Inactive Session Timeout

You can configure a timeout for inactive virtual terminal sessions on a Cisco NX-OS device.

SUMMARY STEPS

1. **configure terminal**
2. **line vty**
3. • **exec-timeout** *minutes*

- **absolute-timeout** *minutes*

4. **exit**
5. (Optional) **show running-config all | begin vty**
6. (Optional) **copy running-config startup-config**

DETAILED STEPS

	Command or Action	Purpose
Step 1	configure terminal Example: <pre>switch# configure terminal switch(config)#</pre>	Enters global configuration mode.
Step 2	line vty Example: <pre>switch# line vty switch(config-line)#</pre>	Enters line configuration mode.
Step 3	<ul style="list-style-type: none"> • exec-timeout <i>minutes</i> • absolute-timeout <i>minutes</i> Example: <pre>switch(config-line)# exec-timeout 30</pre> Example: <pre>switch(config-line)# absolute-timeout 30</pre>	<p>Configures the inactive session timeout. The range is from 0 to 525600 minutes (8760 hours). A value of 0 minutes disables the timeout. The default value is 30.</p> <p>Sets a timeout interval on a virtual terminal (vty) line. The range is from 0 to 10000.</p> <p>The absolute-timeout command terminates the connection after the specified time period has elapsed, regardless of whether the connection is being used at the time of termination. You can specify an absolute-timeout value for each port. The user is given 20 seconds notice before the session is terminated. You can use this command along with the logout-warning command, which notifies the user of an impending logout.</p>
Step 4	exit Example: <pre>switch(config-line)# exit switch(config)#</pre>	Exits line configuration mode.
Step 5	(Optional) show running-config all begin vty Example: <pre>switch(config)# show running-config all begin vty</pre>	Displays the virtual terminal configuration.
Step 6	(Optional) copy running-config startup-config Example: <pre>switch(config)# copy running-config startup-config</pre>	Copies the running configuration to the startup configuration.

Configuring the Session Limit

You can limit the number of virtual terminal sessions on your Cisco NX-OS device.

SUMMARY STEPS

1. **configure terminal**
2. **line vty**
3. **session-limit *sessions***
4. **exit**
5. (Optional) **show running-config all | being vty**
6. (Optional) **copy running-config startup-config**

DETAILED STEPS

	Command or Action	Purpose
Step 1	configure terminal Example: <pre>switch# configure terminal switch(config)#</pre>	Enters global configuration mode.
Step 2	line vty Example: <pre>switch# line vty switch(config-line)#</pre>	Enters line configuration mode.
Step 3	session-limit <i>sessions</i> Example: <pre>switch(config-line)# session-limit 10</pre>	Configures the maximum number of virtual sessions for the Cisco NX-OS device. The range is from 1 to 60. The default is 32.
Step 4	exit Example: <pre>switch(config-line)# exit switch(config)#</pre>	Exits line configuration mode.
Step 5	(Optional) show running-config all being vty Example: <pre>switch(config)# show running-config all begin vty</pre>	Displays the virtual terminal configuration.
Step 6	(Optional) copy running-config startup-config Example: <pre>switch(config)# copy running-config startup-config</pre>	Copies the running configuration to the startup configuration.

Configuring Modem Connections

You can connect a modem to either the COM1 port or the console port.

We recommend that you use the COM1 port to connect the modem.

Enabling a Modem Connection

You must enable the modem connection on the port before you can use the modem.

Before you begin

Log in to the console port.

SUMMARY STEPS

1. **configure terminal**
2. Enter one of the following commands:
3. **modem in**
4. **exit**
5. (Optional) **show line**
6. (Optional) **copy running-config startup-config**

DETAILED STEPS

	Command or Action	Purpose						
Step 1	configure terminal Example: <pre>switch# configure terminal switch(config)#</pre>	Enters global configuration mode.						
Step 2	Enter one of the following commands:	Enters COM1 configuration mode or console configuration mode.						
	<table border="1"> <thead> <tr> <th>Command</th> <th>Purpose</th> </tr> </thead> <tbody> <tr> <td>line com1</td> <td>Enters COM1 configuration mode.</td> </tr> <tr> <td>line console</td> <td>Enters console configuration mode.</td> </tr> </tbody> </table>		Command	Purpose	line com1	Enters COM1 configuration mode.	line console	Enters console configuration mode.
	Command		Purpose					
line com1	Enters COM1 configuration mode.							
line console	Enters console configuration mode.							
Example: <pre>switch# line com1 switch(config-com1)#</pre>								
Step 3	modem in Example: <pre>switch(config-com1)# modem in</pre>	Enables modem input on the COM1 or console port.						

	Command or Action	Purpose
Step 4	exit Example: <pre>switch(config-com1) # exit switch(config) #</pre>	Exits COM1 or console configuration mode.
Step 5	(Optional) show line Example: <pre>switch(config) # show line</pre>	Displays the console and COM1 settings.
Step 6	(Optional) copy running-config startup-config Example: <pre>switch(config) # copy running-config startup-config</pre>	Copies the running configuration to the startup configuration.

Downloading the Default Initialization String

The Cisco NX-OS software provides a default initialization string that you can download for connecting with the modem. The default initialization string is ATE0Q1&D2&C1S0=1\015.

Before you begin

Log in to the console port.

SUMMARY STEPS

1. **configure terminal**
2. Enter one of the following commands:
3. **modem init-string default**
4. **exit**
5. (Optional) **show line**
6. (Optional) **copy running-config startup-config**

DETAILED STEPS

	Command or Action	Purpose						
Step 1	configure terminal Example: <pre>switch# configure terminal switch(config) #</pre>	Enters global configuration mode.						
Step 2	Enter one of the following commands: <table border="1" data-bbox="224 1669 852 1816"> <thead> <tr> <th>Option</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>line com1</td> <td>Enters COM1 configuration mode.</td> </tr> <tr> <td>line console</td> <td>Enters console configuration mode.</td> </tr> </tbody> </table>	Option	Description	line com1	Enters COM1 configuration mode.	line console	Enters console configuration mode.	
Option	Description							
line com1	Enters COM1 configuration mode.							
line console	Enters console configuration mode.							

	Command or Action	Purpose
	Example: switch# line com1 switch(config-com1)#	
Step 3	modem init-string default Example: switch(config-com1)# modem init-string default	Writes the default initialization string to the modem.
Step 4	exit Example: switch(config-com1)# exit switch(config)#	Exits COM1 or console configuration mode.
Step 5	(Optional) show line Example: switch(config)# show line	Displays the COM1 and console settings.
Step 6	(Optional) copy running-config startup-config Example: switch(config)# copy running-config startup-config	Copies the running configuration to the startup configuration.

Configuring and Downloading a User-Specified Initialization String

You can configure and download your own initialization when the default initialization string is not compatible with your modem.

Before you begin

Log in to the console port.

SUMMARY STEPS

1. **configure terminal**
2. Enter one of the following commands:
3. **modem set-string user-input *string***
4. **modem init-string user-input**
5. **exit**
6. (Optional) **show line**
7. (Optional) **copy running-config startup-config**

DETAILED STEPS

	Command or Action	Purpose
Step 1	configure terminal Example:	Enters global configuration mode.

	Command or Action	Purpose						
	<pre>switch# configure terminal switch(config)#</pre>							
Step 2	Enter one of the following commands:							
	<table border="1"> <thead> <tr> <th>Option</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>line com1</td> <td>Enters COM1 configuration mode.</td> </tr> <tr> <td>line console</td> <td>Enters console configuration mode.</td> </tr> </tbody> </table>		Option	Description	line com1	Enters COM1 configuration mode.	line console	Enters console configuration mode.
	Option		Description					
	line com1		Enters COM1 configuration mode.					
line console	Enters console configuration mode.							
Example:								
<pre>switch# line com1 switch(config-com1)#</pre>								
Step 3	<p>modem set-string user-input <i>string</i></p> <p>Example:</p> <pre>switch(config-com1)# modem set-string user-input ATE0Q1&D2&C1S0=3\015</pre>	<p>Sets the user-specified initialization string for the COM1 or console port. The initialization string is alphanumeric and case sensitive, can contain special characters, and has a maximum of 100 characters.</p> <p>Note You must first set the user-input string before initializing the string.</p>						
Step 4	<p>modem init-string user-input</p> <p>Example:</p> <pre>switch(config-com1)# modem init-string user-input</pre>	Writes the user-specified initialization string to the modem connected to the COM1 or console port.						
Step 5	<p>exit</p> <p>Example:</p> <pre>switch(config-com1)# exit switch(config)#</pre>	Exits COM1 or console configuration mode.						
Step 6	<p>(Optional) show line</p> <p>Example:</p> <pre>switch(config)# show line</pre>	Displays the COM1 and console settings.						
Step 7	<p>(Optional) copy running-config startup-config</p> <p>Example:</p> <pre>switch(config)# copy running-config startup-config</pre>	Copies the running configuration to the startup configuration.						

Initializing a Modem for a Powered-Up Cisco NX-OS Device

If you connect a modem to a powered-up physical device, you must initialize the modem before you can use it.

Before you begin

After waiting until the Cisco NX-OS device has completed the boot sequence and the system image is running, connect the modem to either the COM1 port or the console port on the device.

Enable the modem connection on the port.

SUMMARY STEPS

1. **modem connect line {com1 | console}**

DETAILED STEPS

	Command or Action	Purpose
Step 1	modem connect line {com1 console} Example: switch# modem connect line com1	Initializes the modem connected to the device.

Related Topics

[Enabling a Modem Connection](#), on page 75

Clearing Terminal Sessions

You can clear terminal sessions on the Cisco NX-OS device.

SUMMARY STEPS

1. (Optional) **show users**
2. **clear line name**

DETAILED STEPS

	Command or Action	Purpose
Step 1	(Optional) show users Example: switch# show users	Displays the user sessions on the device.
Step 2	clear line name Example: switch# clear line pts/0	Clears a terminal session on a specific line. The line name is case sensitive.

Displaying Terminal and Session Information

To display terminal and session information, perform one of the following tasks:

Command	Purpose
show terminal	Displays terminal settings.
show line	Displays the COM1 and console ports settings.
show users	Displays virtual terminal sessions.
show running-config [all]	Displays the user account configuration in the running configuration. The all keyword displays the default values for the user accounts.

For detailed information about the fields in the output from these commands, see the Cisco Nexus command reference guide for your device.

Default Settings for Terminal Display and Session Parameters

This table lists the default settings for terminal displays and session parameters.

Table 14: Default Terminal Display and Session Parameter Settings

Parameters	Default
Terminal type	ansi
Terminal length	0 lines for console sessions 31 lines for virtual terminal sessions
Terminal width	80 columns
Terminal inactive session timeout	Disabled (0 minutes)
Console session data bits	8
Console inactive session timeout	Disabled (0 minutes)
Console session parity	none
Console session speed	11520 bps
Console session stop bits	1
COM1 session data bits	8
COM1 hardware flow control	Enabled
COM1 session parity	none
COM1 session speed	9600 bps
COM1 session stop bits	1
Virtual terminal inactive session timeout	Disabled (0 minutes)

Parameters	Default
Virtual terminal sessions limit	32
Modem default initialization string	ATE0Q1&D2&C1S0=1\015



CHAPTER 7

Basic Device Management

This chapter describes how to configure, manage, and verify the basic setting on your Cisco NX-OS device.

- [Information About Basic Device Management, on page 83](#)
- [Changing the Device Hostname, on page 85](#)
- [Configuring the Management Interface, on page 86](#)
- [Configuring the Default Gateway, on page 87](#)
- [Configuring the MOTD Banner, on page 88](#)
- [Configuring the Time Zone, on page 89](#)
- [Configuring Summer Time \(Daylight Saving Time\), on page 90](#)
- [Manually Setting the Device Clock, on page 91](#)
- [Managing Users, on page 92](#)
- [Enabling or Disabling a Telnet Server Connection, on page 93](#)
- [Verifying the Device Configuration, on page 93](#)
- [Default Settings for Basic Device Parameters, on page 94](#)

Information About Basic Device Management

This section provides information about basic device management.

Device Hostname

You can change the device hostname displayed in the command prompt from the default (switch) to another character string. When you give the device a unique hostname, you can easily identify the device from the command-line interface (CLI) prompt.

Interface



Note If the management 10/100 Ethernet port (mgmt0) interface of the Cisco MDS 9700 Series switches has a preconfigured /0 IPv6 address that cannot be removed, use the **write erase boot** command to clear the complete configuration of the device and reload it. Perform this process before commissioning the device into production as this process is disruptive to user traffic if it is applied to the active supervisor of a system. Ensure an active console connection to the supervisor as this process will remove the IPv4 address of the mgmt0 interface.

The management interface allows multiple simultaneous Telnet or SNMP sessions. You can remotely configure the device through the management interface (mgmt0), but first you must configure some IP parameters so that the switch is reachable. You can manually configure the management interface from the CLI. You can configure the mgmt 0 interface with either IPv4 address parameters or an IPv6 address.


On devices with dual supervisor modules, a single IP address is used to manage the switch. The active supervisor module's mgmt0 interface uses this IP address. The mgmt0 interface on the standby supervisor module remains in an inactive state and cannot be accessed until a switchover happens. After a switchover, the mgmt0 interface on the standby supervisor module becomes active and assumes the same IP address as the previously active supervisor module.

The management port (mgmt0) is autosensing and operates in full duplex mode at a speed of 10/100/1000 Mbps. Autosensing supports both the speed and the duplex mode.

Default Gateway

Figure 7: Default Gateway

The supervisor module sends IP packets with unresolved destination IPv4 addresses to the default gateway.



Message-of-the-Day Banner

The message-of-the-day (MOTD) banner displays before the user login prompt on the device. This message can contain any information that you want to display for users of the device.

Device Clock

If you do not synchronize your device with a valid outside timing mechanism, such as an NTP clock source, you can manually set the clock time when your device boots.

Time Zone and Summer Time (Daylight Saving Time)

You can configure the time zone and summer time (daylight saving time) setting for your device. These values offset the clock time from Coordinated Universal Time (UTC). UTC is International Atomic Time (TAI) with leap seconds added periodically to compensate for the Earth's slowing rotation. UTC was formerly called Greenwich Mean Time (GMT).

User Sessions

You can display the active user session on your device. You can also send messages to the user sessions. For more information about managing user sessions and accounts, see the Cisco Nexus security configuration guide for your device.

Telnet Server Connection

The Telnet server is disabled by default on all switches in the Cisco MDS 9000 Family. You can enable the Telnet server if you do not require a secure SSH connection. However, if you require a secure SSH connection, you need to disable the default Telnet connection and then enable the SSH connection.



Note For information on connecting a terminal to the supervisor module console port, refer to the [Cisco MDS 9200 Series Hardware Installation Guide](#) or the [Cisco MDS 9500 Series Hardware Installation Guide](#).



Note The Cisco NX-OS software allows a maximum of 16 sessions on any switch in the Cisco MDS 9500 Series or the Cisco MDS 9200 Series.

Changing the Device Hostname

You can change the device hostname displayed in the command prompt from the default (switch) to another character string.

SUMMARY STEPS

1. **configure terminal**
2. **{ hostname | switchname } name**
3. **exit**
4. (Optional) **copy running-config startup-config**

DETAILED STEPS

	Command or Action	Purpose
Step 1	configure terminal Example:	Enters global configuration mode.

	Command or Action	Purpose
	<pre>switch# configure terminal switch(config)#</pre>	
Step 2	<p>{ hostname switchname } <i>name</i></p> <p>Example:</p> <p>Using the hostname command:</p> <pre>switch(config)# hostname Engineering1 Engineering1(config)#</pre> <p>Using the switchname command:</p> <pre>Engineering1(config)# switchname Engineering2 Engineering2(config)#</pre>	<p>Changes the device hostname. The <i>name</i> argument is alphanumeric, case sensitive, and has a maximum length of 32 characters. The default name is switch.</p> <p>Note The switchname command performs the same function as the hostname command.</p>
Step 3	<p>exit</p> <p>Example:</p> <pre>Engineering2(config)# exit Engineering2#</pre>	Exits global configuration mode.
Step 4	<p>(Optional) copy running-config startup-config</p> <p>Example:</p> <pre>Engineering2# copy running-config startup-config</pre>	Copies the running configuration to the startup configuration.

Configuring the Management Interface

You can manually configure the management interface from the CLI. You can configure the mgmt 0 interface with either IPv4 address parameters or an IPv6 address.



Note You only need to configure the mgmt0 interface on the active supervisor module. When a supervisor module switchover occurs, the new active supervisor module uses the same configuration for the mgmt0 interface.

Before you begin

Establish a connection on the console port.

SUMMARY STEPS

1. **configure terminal**
2. **interface mgmt 0**
3. **ip address** { *ipv4-address subnet-mask* | *ipv6-address* }
4. **exit**
5. (Optional) **show interface mgmt 0**
6. (Optional) **copy running-config startup-config**

DETAILED STEPS

	Command or Action	Purpose
Step 1	configure terminal Example: <pre>switch# configure terminal switch(config)#</pre>	Enters global configuration mode.
Step 2	interface mgmt 0 Example: <pre>switch(config)# interface mgmt 0 switch(config-if)#</pre>	Specifies the mgmt0 interface and enters the interface configuration mode.
Step 3	ip address {ipv4-address subnet-mask ipv6-address} Example: <pre>switch(config-if)# ip address 1.1.1.0 255.255.255.0</pre>	Configures the IPv4 or IPv6 address on the mgmt 0 interface.
Step 4	exit Example: <pre>switch(config-if)# exit switch(config)#</pre>	Returns to global configuration mode.
Step 5	(Optional) show interface mgmt 0 Example: <pre>switch(config)# show interface mgmt 0</pre>	Displays the mgmt 0 interface information.
Step 6	(Optional) copy running-config startup-config Example: <pre>switch(config)# copy running-config startup-config</pre>	Copies the running configuration to the startup configuration.

Configuring the Default Gateway

You can manually configure the management interface from the CLI. You can configure the mgmt 0 interface with either IPv4 address parameters or an IPv6 address.

Before you begin

Establish a connection on the console port.

SUMMARY STEPS

1. **configure terminal**
2. **ip default gateway *ipv4-address***
3. (Optional) **show ip route**
4. (Optional) **copy running-config startup-config**

DETAILED STEPS

	Command or Action	Purpose
Step 1	configure terminal Example: switch# configure terminal switch(config)#	Enters global configuration mode.
Step 2	ip default gateway ipv4-address Example: switch(config)# ip default-gateway 172.16.1.1	Configures the IPv4 address for the default gateway.
Step 3	(Optional) show ip route Example: switch(config)# show ip route	Displays the default gateway configuration.
Step 4	(Optional) copy running-config startup-config Example: switch(config)# copy running-config startup-config	Configures the IPv4 or IPv6 address on the mgmt 0 interface.

Configuring the MOTD Banner

You can configure the MOTD to display before the login prompt on the terminal when a user logs in. The MOTD banner has the following characteristics:

- Maximum of 254 characters per line
- Maximum of 40 lines

SUMMARY STEPS

1. **configure terminal**
2. **banner motd *delimiting-character message delimiting-character***
3. **exit**
4. (Optional) **show banner motd**
5. (Optional) **copy running-config startup-config**

DETAILED STEPS

	Command or Action	Purpose
Step 1	configure terminal Example: switch# configure terminal switch(config)#	Enters global configuration mode.

	Command or Action	Purpose
Step 2	banner motd <i>delimiting-character message delimiting-character</i> Example: <pre>switch(config)# banner motd #Welcome to the Switch# switch(config)#</pre>	Configures the MOTD banner. Do not use the <i>delimiting-character</i> in the <i>message</i> text. Note Do not use " or % as a delimiting character.
Step 3	exit Example: <pre>switch(config)# exit switch#</pre>	Exits global configuration mode.
Step 4	(Optional) show banner motd Example: <pre>switch# show banner motd</pre>	Displays the configured MOTD banner.
Step 5	(Optional) copy running-config startup-config Example: <pre>switch# copy running-config startup-config</pre>	Copies the running configuration to the startup configuration.

Configuring the Time Zone

You can configure the time zone to offset the device clock time from UTC.

SUMMARY STEPS

1. **configure terminal**
2. **clock timezone** *zone-name offset-hours offset-minutes*
3. **exit**
4. (Optional) **show clock**
5. (Optional) **copy running-config startup-config**

DETAILED STEPS

	Command or Action	Purpose
Step 1	configure terminal Example: <pre>switch# configure terminal switch(config)#</pre>	Enters global configuration mode.
Step 2	clock timezone <i>zone-name offset-hours offset-minutes</i> Example: <pre>switch(config)# clock timezone EST -5 0</pre>	Configures the time zone. The <i>zone-name</i> argument is a 3-character string for the time zone acronym (for example, PST or EST). The <i>offset-hours</i> argument is the offset from the UTC and the range is from –23 to 23 hours. The range for the <i>offset-minutes</i> argument is from 0 to 59 minutes.

	Command or Action	Purpose
Step 3	exit Example: switch(config)# exit switch#	Exits global configuration mode.
Step 4	(Optional) show clock Example: switch# show clock	Displays the time and time zone.
Step 5	(Optional) copy running-config startup-config Example: switch# copy running-config startup-config	Copies the running configuration to the startup configuration.

Configuring Summer Time (Daylight Saving Time)

You can configure when summer time, or daylight saving time, is in effect for the device and the offset in minutes.

SUMMARY STEPS

1. **configure terminal**
2. **clock summer-time** *zone-name start-week start-day start-month start-time end-week end-day end-month end-time offset-minutes*
3. **exit**
4. (Optional) **show clock detail**
5. (Optional) **copy running-config startup-config**

DETAILED STEPS

	Command or Action	Purpose
Step 1	configure terminal Example: switch# configure terminal switch(config)#	Enters global configuration mode.
Step 2	clock summer-time <i>zone-name start-week start-day start-month start-time end-week end-day end-month end-time offset-minutes</i> Example: switch(config)# clock summer-time PDT 1 Sunday March 02:00 1 Sunday November 02:00 60	Configures summer time or daylight saving time. The <i>zone-name</i> argument is a three character string for the time zone acronym (for example, PST and EST). The values for the <i>start-day</i> and <i>end-day</i> arguments are Monday, Tuesday, Wednesday, Thursday, Friday, Saturday, and Sunday .

	Command or Action	Purpose
		<p>The values for the <i>start-month</i> and <i>end-month</i> arguments are January, February, March, April, May, June, July, August, September, October, November, and December.</p> <p>The value for the <i>start-time</i> and <i>end-time</i> arguments are in the format <i>hh:mm</i>.</p> <p>The range for the <i>offset-minutes</i> argument is from 0 to 1440 minutes.</p>
Step 3	<p>exit</p> <p>Example:</p> <pre>switch(config)# exit switch#</pre>	Exits global configuration mode.
Step 4	<p>(Optional) show clock detail</p> <p>Example:</p> <pre>switch(config)# show clock detail</pre>	Displays the configured MOTD banner.
Step 5	<p>(Optional) copy running-config startup-config</p> <p>Example:</p> <pre>switch# copy running-config startup-config</pre>	Copies the running configuration to the startup configuration.

Manually Setting the Device Clock

You can set the clock manually if your device cannot access a remote time source.

Before you begin

Configure the time zone.

SUMMARY STEPS

1. **clock set** *time day month year*
2. (Optional) **show clock**

DETAILED STEPS

	Command or Action	Purpose
Step 1	<p>clock set <i>time day month year</i></p> <p>Example:</p> <pre>switch# clock set 15:00:00 30 May 2008 Fri May 30 15:14:00 PDT 2008</pre>	<p>Configures the device clock.</p> <p>The format for the <i>time</i> argument is <i>hh:mm:ss</i>.</p> <p>The range for the <i>day</i> argument is from 1 to 31.</p> <p>The values for the <i>month</i> argument are January, February, March, April, May, June, July, August, September, October, November, and December.</p>

	Command or Action	Purpose
		The range for the <i>year</i> argument is from 2000 to 2030.
Step 2	(Optional) show clock Example: switch(config)# show clock	Displays the current clock value.

Related Topics

[Configuring the Time Zone](#), on page 89

Managing Users

You can display information about users logged into the device and send messages to those users.

Displaying Information about the User Sessions

You can display information about the user session on the device.

SUMMARY STEPS

1. **show users**

DETAILED STEPS

	Command or Action	Purpose
Step 1	show users Example: switch# show users	Displays the user sessions.

Sending a Message to Users

You can send a message to active users currently using the device CLI.

SUMMARY STEPS

1. (Optional) **show users**
2. **send [session line] message-text**

DETAILED STEPS

	Command or Action	Purpose
Step 1	(Optional) show users Example: switch# show users	Displays the active user sessions.

	Command or Action	Purpose
Step 2	send [session line] message-text Example: switch# send Reloading the device is 10 minutes!	Sends a message to all active users or to a specific user. The message can be up to 80 alphanumeric characters and is case sensitive.

Enabling or Disabling a Telnet Server Connection

You can enable or disable the Telnet server connection.

SUMMARY STEPS

1. **configure terminal**
2. **[no] feature telnet**
3. (Optional) **show telnet server**
4. (Optional) **copy running-config startup-config**

DETAILED STEPS

	Command or Action	Purpose
Step 1	configure terminal Example: switch# configure terminal switch(config)#	Enters global configuration mode.
Step 2	[no] feature telnet Example: switch(config)# feature telnet	Enables the Telnet server connection. Use the no form of the command to disable the Telnet server connection. The default is disabled.
Step 3	(Optional) show telnet server Example: switch(config)# show telnet server	Displays the Telnet server configuration.
Step 4	(Optional) copy running-config startup-config Example: switch(config)# copy running-config startup-config	Copies the running configuration to the startup configuration.

Verifying the Device Configuration

To verify the configuration after bootstrapping the device using POAP, use one of the following commands:

Command	Purpose
show running-config	Displays the running configuration.

Command	Purpose
<code>show startup-config</code>	Displays the startup configuration.

For detailed information about the fields in the output from these commands, see the Cisco Nexus command reference for your device.

Default Settings for Basic Device Parameters

This table lists the default settings for basic device parameters.

Table 15: Default Basic Device Parameters

Parameters	Default
MOTD banner text	User Access Verification
Clock time zone	UTC



CHAPTER 8

Using the Device File Systems, Directories, and Files

This chapter describes how to use your device file systems, directories, and files.

- [Information About Device File Systems, Directories, Files, and External Storage Devices, on page 95](#)
- [Working with External Storage Devices, on page 97](#)
- [Working with Directories, on page 98](#)
- [Working with Files, on page 100](#)
- [Working with Archive Files, on page 103](#)
- [Examples of Using a File System, on page 105](#)

Information About Device File Systems, Directories, Files, and External Storage Devices

This section describes the file systems, directories, files, and support provided to the external storage devices on devices.

File Systems

This topic provides information about the file system components supported on a Cisco MDS device. (The syntax for specifying a local file system is `filesystem:[//modules/]`.)



Note The default `filesystem` parameter is `bootflash:`.

This table describes the file system components that you can use on a Cisco MDS device.

Table 16: File System Components

File System Name	Module	Description
bootflash	sup-active sup-local	Internal CompactFlash memory located on an active supervisor module. Used for storing image files, configuration files, and other miscellaneous files. The initial default directory is bootflash.
	sup-standby sup-remote	Internal CompactFlash memory located on a standby supervisor module. Used for storing image files, configuration files, and other miscellaneous files.
volatile	—	Volatile random-access memory (VRAM) located on a supervisor module. Used for temporary or pending changes.
log	—	Memory on an active supervisor module. Used for storing file statistics logs.
system	—	Memory on a supervisor module. Used for storing the running configuration file.
debug	—	Memory on a supervisor module. Used for storing the debug logs.

Directories

You can create directories on bootflash: and external flash memory (slot0:, usb1:, and usb2:). You can create, store, and access files from directories.

Files

You can create and access files from bootflash:, volatile:, slot0:, usb1:, and usb2: file systems. You can only access files from the system: file system. Use the debug: file system to store the debug log files specified using the **debug logfile** command.

You can download files, such as system image files, from remote servers using FTP, Secure Copy Protocol (SCP), Secure File Transfer Protocol (SFTP), and TFTP. You can also copy files from an external server to your device because your device can act as an SCP server.

Working with External Storage Devices

This section describes formatting, mounting, and unmounting of external storage devices on devices.

Formatting an External Flash Device

Insert the external flash device into the active supervisor module in a Cisco MDS device.

To format an external flash device, run the following command:

```
format {slot0: | usb1: | usb2:}
```

Example:

```
switch# format slot0:
```



Note You can format an external flash device to erase its contents and restore the device to its factory-shipped state. For information about recovering corrupted bootflash using formatting, see the .

Mounting or Unmounting a USB Drive

Mount or unmount a USB drive automatically by plugging or unplugging the drive from a Cisco MDS device. You can also use the **mount** or **unmount** command in either the user EXEC mode or the privileged EXEC mode to mount or unmount the device, respectively.

- To mount a USB drive on a Cisco MDS device, run the following command:

```
mount {usb1: | usb2:}
```

Example:

```
switch# mount usb1:
```

- To unmount a USB drive from a Cisco MDS device, run the following command:

```
unmount {usb1: | usb2:}
```

Example:

```
switch# unmount usb1:
```

External Storage Device Support Matrix

This section provides information about hardware and software support for external storage device ports on each type of Cisco MDS platform.

Cisco MDS switches support devices formatted with the FAT32 file system.

Platform	PCMCIA	USB ¹			
	slot0	First supported	slot0	usb1	usb2
Cisco MDS 9700 Series Multilayer Director	No hardware port	Cisco MDS NX-OS Release 6.2(1)	Enabled	Enabled	No hardware port
Cisco MDS 9500 Series Multilayer Director	Enabled	Cisco MDS NX-OS Release 6.2(1)	No hardware port	Enabled	Enabled
Cisco MDS 9396S 16G Multilayer Fabric Switch	No hardware port	Cisco MDS NX-OS Release 6.2(13)	No hardware port	Enabled	No hardware port
Cisco MDS 9250i Multiservice Fabric Switch	No hardware port	Cisco MDS NX-OS Release 6.2(15)	No hardware port	Enabled	No hardware port
Cisco MDS 9222i Multiservice Modular Switch	No hardware port	—	No hardware port	No hardware port	No hardware port
Cisco MDS 9148S 16G Multilayer Fabric Switch	No hardware port	Cisco MDS NX-OS Release 6.2(15)	No hardware port	Enabled	No hardware port
Cisco MDS 9148 Multilayer Fabric Switch	No hardware port	—	No hardware port	No hardware port	No hardware port
Cisco MDS 8Gb Fabric Switch for HP BladeSystem c-Class	No hardware port	—	No hardware port	No hardware port	No hardware port

¹USB 2.0 or higher devices supported.

Working with Directories

Identifying the Current Directory

To display the name of the current directory, run the following command:

```
pwd
```

Example:

```
switch# pwd
```

Changing the Current Directory

You can change the current directory for file system operations. The default directory is bootflash:.



Note The file system, module, and directory names are case sensitive.

To change to a new directory, run the following command:

```
cd {directory | filesystem:[//module/][directory]}
```

Example:

```
switch# cd slot0:
```

Creating a Directory

You can create directories in the bootflash: and flash device file systems.



Note

- The file system, module, and directory names are case sensitive.
- The *filesystem* argument is case sensitive. The *directory* argument is alphanumeric, case sensitive, and can have a maximum of 64 characters.

To create a new directory, run the following command:

```
mkdir [filesystem:[//module/]]directory
```

Example:

```
switch# mkdir test
```

Displaying Directory Contents

To display the contents of a directory, run the following command:

```
dir [directory | filesystem:[//module/]][directory]
```

Example:

```
switch# dir bootflash:
```

Deleting a Directory

You can remove directories from the file systems on a Cisco MDS device.



Note

- Ensure that the directory is empty before you delete it. If the directory is not empty, you must delete all the files before you delete the directory.
- The file system and directory names are case sensitive.

To delete a directory, run the following command:

```
rmdir [filesystem :[/module/]]directory
```

Example:

```
switch# rmdir test
```

Accessing the Directories on a Standby Supervisor Module

You can access all the file systems on a standby supervisor module (remote) from a session on an active supervisor module. This feature is useful when copying files to the active supervisor module that requires similar files to exist, as in the standby supervisor module.

To access the file systems on the standby supervisor module from a session on the active supervisor module, specify the standby supervisor module in the path to the file using either the `filesystem://sup-remote/` command, or the `filesystem://sup-standby/` command.

Working with Files

Moving a File

Files can be moved from one directory to another directory.

You can use the **move** command to rename a file by moving the file within the same directory or to another directory.



Note The file system, module, and directory names are case sensitive.

To move a file from one directory to another directory, run the following command:

```
move [filesystem:[/module/][directory /] | directory/]source-filename { {filesystem:[/module/][directory /] | directory/}[target-filename] | target-filename}
```

Example:

```
switch# move test old_tests/test1
```



Note The *target-filename* argument is alphanumeric, case sensitive, and can have a maximum of 64 characters. If the *target-filename* argument is not specified, the filename defaults to the *source-filename* argument value.



Caution When you try to move a file from one directory to another, if a file with the same name already exists in the destination directory, that file is overwritten by the moved file.

Copying a File

You can make copies of files, either within the same directory or in another directory.

**Note**

- Use the **dir** command to ensure that enough space is available in the target file system. If enough space is not available, use the **delete** command to remove the files that are no longer required.
- The file system, module, and directory names are case sensitive.

To copy a file, run the following command:

```
copy [filesystem:[//module/][directory/] | directory/]source-filename | {filesystem:[//module/][directory/] | directory/}[target-filename]
```

Example:

```
switch# copy test old_tests/test1
```

**Note**

- The *source-filename* argument is alphanumeric, case sensitive, and can have a maximum of 64 characters. If the *target-filename* argument is not specified, the filename defaults to the *source-filename* argument value.
- The **copy** command supports FTP, SCP, SFTP, TFTP, and HTTP protocols.

Deleting a File

**Caution**

If you specify a directory, the **delete** command deletes the entire directory and all of its contents.

**Note**

The file system name, directory name, and *source-filename* argument are case sensitive.

To delete a file, run the following command:

```
delete {filesystem:[//module/][directory/] | directory/}filename
```

Example:

```
switch# delete test old_tests/test1
```

Displaying a File's Contents

To display a file's contents, run the following command:

```
show file [filesystem:[//module/][directory/]filename
```

Example:

```
switch# show file bootflash:test-results
```

Displaying a File's Checksums

You can use checksums to verify a file's integrity.

To display the checksum or MD5 checksum of a file, run the following command:

```
show file [filesystem:[//module/]][directory/]filename {cksum | md5sum}
```

Example:

```
switch# show file bootflash:trunks2.cfg cksum
```

Compressing and Uncompressing a File

You can compress and uncompress the files on a device using Lempel-Ziv 77 (LZ77) coding.



Note The file system and directory names are case sensitive.

- To compress a file, run the following command:

```
gzip [filesystem:[//module/]][directory/] | directory/filename
```

Example:

```
switch# gzip show_tech
```



Note After a file is compressed, it has a .gz suffix.

- To uncompress a file, run the following command:

```
gunzip [filesystem:[//module/]][directory/] | directory/filename .gz
```

Example:

```
switch# gunzip show_tech.gz
```



Note The file that has been uncompressed must have the .gz suffix. After the file is uncompressed, it does not have the .gz suffix.

- To display the contents of the current directory, run the following command:

```
dir [filesystem:[//module/]][directory/]
```

Example:

```
switch# dir bootflash:
```


Displaying the Last Lines in a File



Note The default number of lines is 10. The range is from 0 to 80 lines.

To display the last lines in a file, run the following command:

```
tail [filesystem:[//module/]][directory/]filename [lines]
```

Example:

```
switch# tail ospf-gr.conf
```

Redirecting show Command Output to a File

You can redirect the **show** command output to a file on bootflash:, slot0:, volatile:, or on a remote server.

To redirect the output from a **show** command to a file, run the following command:

```
show command > [filesystem:[//module/]][directory] | [directory /]filename
```

Example:

```
switch# show tech-support > bootflash:techinfo
```

Finding Files

You can find files that have names beginning with a specific character string in the current working directory and its subdirectories.

To find all the files beginning with the filename prefix in the default directory and in its subdirectories, run the following command:

```
find filename-prefix
```

Example:

```
switch# find bgp_script
```



Note The filename prefix is case sensitive.

Working with Archive Files

Creating an Archive File

You can create an archive file and add files to it. You can specify the following compression types:

- bzip2
- gzip

- Uncompressed

The default compression type is gzip.



Note The filename is alphanumeric, not case sensitive, and can have a maximum of 240 characters.

To create an archive file and add files to it, run the following command:

```
tar create {bootflash: | volatile:}archive-filename [absolute] [bz2-compress] [gz-compress] [remove]
[uncompressed] [verbose]filename-list
```

This example shows how to create a gzip compressed archive file:

```
switch# tar create bootflash:config-archive gz-compress bootflash:config-file
```

The **absolute** keyword specifies that the leading backslash characters (\) should not be removed from the names of the files added to the archive file. By default, the leading backslash characters are removed.

The **bz2-compress**, **gz-compress**, and **uncompressed** keywords determine the compression utility to use when files are added or later appended to the archive, and the decompression utility to use when extracting the files. If you do not specify an extension for the archive file, the default extensions are as follows:

- For **bz2-compress**, the extension is `.tar.bz2`.
- For **gz-compress**, the extension is `.tar.gz`.
- For **uncompressed**, the extension is `.tar`.

The **remove** keyword specifies that the software should delete the files from the file system after adding them to the archive. By default, the files are not deleted.

The **verbose** keyword specifies that the software should list the files as they are added to the archive. By default, the files are listed as they are added.

Appending Files to an Archive File

You can append files to an existing archive file on a device.



Note The archive filename is not case sensitive.

To add files to an existing archive file, run the following command:

```
tar append {bootflash: | volatile:}archive-filename [absolute] [remove] [verbose]filename-list
```

Example:

```
switch# tar append bootflash:config-archive.tar.gz bootflash:new-config
```

The **absolute** keyword specifies that the leading backslash characters (\) should not be removed from the names of the files added to the archive file. By default, the leading backslash characters are removed.

The **remove** keyword specifies that the software should delete the files from the file system after adding them to the archive. By default, the files are not deleted.

The **verbose** keyword specifies that the software should list the files as they are added to the archive. By default, the files are listed as they are added.

Extracting Files from an Archive File

You can extract files from an existing archive file on a device.



Note The archive filename is not case sensitive.

To extract files from an existing archive file, run the following command:

```
tar extract {bootflash: | volatile:}archive-filename [keep-old] [screen] [to {bootflash: | volatile:}[/directory-name]] [verbose]
```

Example:

```
switch# tar extract bootflash:config-archive.tar.gz
```

The **keep-old** keyword indicates that the software should not overwrite files with the same name as the files being extracted.

The **screen** keyword specifies that the software should display the contents of the extracted files to the terminal screen.

The **to** keyword specifies the target file system. You can include a directory name. The directory name is alphanumeric, case sensitive, and can have a maximum of 240 characters.

The **verbose** keyword specifies that the software should display the names of the files as they are extracted.

Displaying the Filenames in an Archive File



Note The archive filename is not case sensitive.

To display the file names in an archive file, run the following command:

```
tar list {bootflash: | volatile:}archive-filename
```

Example:

```
switch# tar list bootflash:config-archive.tar.gz  
config-file  
new-config
```

Examples of Using a File System

This section includes examples of using a file system on a device.

Accessing Directories on a Standby Supervisor Module

This example shows how to list the files on a standby supervisor module:

```
switch# dir bootflash://sup-remote
 12198912   Aug 27 16:29:18 2003  m9500-sflek9-kickstart-mzg.1.3.0.39a.bin
  1864931   Apr 29 12:41:59 2003  dplug2
    12288   Apr 18 20:23:11 2003  lost+found/
 12097024   Nov 21 16:34:18 2003  m9500-sflek9-kickstart-mz.1.3.1.1.bin
 41574014   Nov 21 16:34:47 2003  m9500-sflek9-mz.1.3.1.1.bin

Usage for bootflash://sup-remote
 67747169 bytes used
116812447 bytes free
184559616 bytes total
```

This example shows how to delete a file on a standby supervisor module:

```
switch# delete bootflash://sup-remote/aOldConfig.txt
```

Performing ISSU or ISSD Using a USB Drive

This example shows how to perform an In-Service Software Upgrade (ISSU) or In-Service Software Downgrade (ISSD) using a system image or kickstart image from a USB drive:

```
switch# install all system usb1:m9300-slek9-mzg.6.2.13.FM.0.65.bin.S0 kickstart
usb1:m9300-slek9-kickstart-mzg.6.2.13.FM.0.65.bin.S0
```



CHAPTER 9

Working with Configuration Files

This chapter describes how to work with your device configuration files.

- [Information About Configuration Files, on page 107](#)
- [Managing Configuration Files, on page 108](#)
- [Verifying the Device Configuration, on page 117](#)
- [Examples of Working with Configuration Files, on page 118](#)

Information About Configuration Files

Configuration files contain the Cisco NX-OS software commands used to configure the features on a Cisco NX-OS device. Commands are parsed (translated and executed) by the Cisco NX-OS software when the system is booted (from the startup-config file) or when you enter commands at the CLI in a configuration mode.

To change the startup configuration file, you can either save the running-configuration file to the startup configuration using the **copy running-config startup-config** command or copy a configuration file from a file server to the startup configuration.

Types of Configuration Files

The Cisco NX-OS software has two types of configuration files, running configuration and startup configuration. The device uses the startup configuration (startup-config) during device startup to configure the software features. The running configuration (running-config) contains the current changes that you make to the startup-configuration file. The two configuration files can be different. You might want to change the device configuration for a short time period rather than permanently. In this case, you would change the running configuration by using commands in global configuration mode but not save the changes to the startup configuration.

To change the running configuration, use the **configure terminal** command to enter global configuration mode. As you use the Cisco NX-OS configuration modes, commands generally are executed immediately and are saved to the running configuration file either immediately after you enter them or when you exit a configuration mode.

To change the startup-configuration file, you can either save the running configuration file to the startup configuration or download a configuration file from a file server to the startup configuration.

Related Topics

[About Command Modes](#)

[Saving the Running Configuration to the Startup Configuration](#), on page 108

[Downloading the Startup Configuration From a Remote Server](#), on page 110

Managing Configuration Files

This section describes how to manage configuration files.

Saving the Running Configuration to the Startup Configuration

You can save the running configuration to the startup configuration to save your changes for the next time you that reload the device.

SUMMARY STEPS

1. (Optional) **show running-config**
2. **copy running-config startup-config**

DETAILED STEPS

	Command or Action	Purpose
Step 1	(Optional) show running-config Example: switch# show running-config	Displays the running configuration.
Step 2	copy running-config startup-config Example: switch# copy running-config startup-config	Copies the running configuration to the startup configuration.

Copying a Configuration File to a Remote Server

You can copy a configuration file stored in the internal memory to a remote server as a backup or to use for configuring other Cisco NX-OS devices.

SUMMARY STEPS

1. **copy running-config *scheme://server/[url /]filename***
2. **copy startup-config *scheme://server/[url /]filename***

DETAILED STEPS

	Command or Action	Purpose
Step 1	copy running-config <i>scheme://server/[url /]filename</i> Example: switch# copy running-config tftp://10.10.1.1/sw1-run-config.bak	Copies the running-configuration file to a remote server. For the <i>scheme</i> argument, you can enter tftp: , ftp: , scp: , or sftp: . The <i>server</i> argument is the address or name of the

	Command or Action	Purpose
		remote server, and the <i>url</i> argument is the path to the source file on the remote server. The <i>server</i> , <i>url</i> , and <i>filename</i> arguments are case sensitive.
Step 2	copy startup-config <i>scheme://server/[url /]filename</i> Example: <pre>switch# copy startup-config tftp://10.10.1.1/sw1-start-config.bak</pre>	Copies the startup-configuration file to a remote server. For the <i>scheme</i> argument, you can enter tftp: , ftp: , scp: , or sftp: . The <i>server</i> argument is the address or name of the remote server, and the <i>url</i> argument is the path to the source file on the remote server. The <i>server</i> , <i>url</i> , and <i>filename</i> arguments are case sensitive.

Example

Downloading the Running Configuration From a Remote Server

You can configure your Cisco NX-OS device by using configuration files that you created on another Cisco NX-OS device and uploaded to a remote server. You then download the file from the remote server to your device using TFTP, FTP, Secure Copy (SCP), or Secure Shell FTP (SFTP) to the running configuration.

Before you begin

Ensure that the configuration file that you want to download is in the correct directory on the remote server.

Ensure that the permissions on the file are set correctly. Permissions on the file should be set to world-read.

Ensure that your Cisco NX-OS device has a route to the remote server. The Cisco NX-OS device and the remote server must be in the same subnetwork if you do not have a router or a default gateway to route traffic between subnets.

Check connectivity to the remote server using the **ping** or **ping6** command.

SUMMARY STEPS

1. **copy *scheme://server/[url/]filename* running-config**
2. (Optional) **show running-config**
3. (Optional) **copy running-config startup-config**
4. (Optional) **show startup-config**

DETAILED STEPS

	Command or Action	Purpose
Step 1	copy <i>scheme://server/[url/]filename</i> running-config Example: <pre>switch# copy tftp://10.10.1.1/my-config running-config</pre>	Downloads the running-configuration file from a remote server. For the <i>scheme</i> argument, you can enter tftp: , ftp: , scp: , or sftp: . The <i>server</i> argument is the address or name of the

	Command or Action	Purpose
		remote server, and the <i>url</i> argument is the path to the source file on the remote server. The <i>server</i> , <i>url</i> , and <i>filename</i> arguments are case sensitive.
Step 2	(Optional) show running-config Example: switch# show running-config	Displays the running configuration.
Step 3	(Optional) copy running-config startup-config Example: switch# copy running-config startup-config	Copies the running configuration to the startup configuration.
Step 4	(Optional) show startup-config Example: switch# show startup-config	Displays the startup configuration.

Related Topics[Copying Files](#)

Downloading the Startup Configuration From a Remote Server

You can configure your Cisco NX-OS device by using configuration files that you created on another Cisco NX-OS device and uploaded to a remote server. You then download the file from the remote server to your device using TFTP, FTP, Secure Copy (SCP), or Secure Shell FTP (SFTP) to the startup configuration.

**Caution**

This procedure disrupts all traffic on the Cisco NX-OS device.

Before you begin

Log in to a session on the console port.

Ensure that the configuration file that you want to download is in the correct directory on the remote server.

Ensure that the permissions on the file are set correctly. Permissions on the file should be set to world-read.

Ensure that your Cisco NX-OS device has a route to the remote server. The Cisco NX-OS device and the remote server must be in the same subnet if you do not have a router or a default gateway to route traffic between subnets.

Check connectivity to the remote server using the **ping** or **ping6** command.

SUMMARY STEPS

1. **write erase**
2. **reload**
3. **copy *scheme://server/[url /]filename* running-config**
4. **copy running-config startup-config**

5. (Optional) **show startup-config**

DETAILED STEPS

	Command or Action	Purpose
Step 1	write erase Example: <pre>switch# write erase</pre>	Erases the startup configuration file.
Step 2	reload Example: <pre>switch# reload This command will reboot the system. (y/n)? [n] y ... Enter the password for "admin": <password> Confirm the password for "admin": <password> ... Would you like to enter the basic configuration dialog (yes/no): n switch#</pre>	Reloads the Cisco NX-OS device. Note Do not use the setup utility to configure the device.
Step 3	copy <i>scheme://server[/url /]filename running-config</i> Example: <pre>switch# copy tftp://10.10.1.1/my-config running-config</pre>	Downloads the running configuration file from a remote server. For the <i>scheme</i> argument, you can enter tftp: , ftp: , scp: , or sftp: . The <i>server</i> argument is the address or name of the remote server, and the <i>url</i> argument is the path to the source file on the remote server. The <i>server</i> , <i>url</i> , and <i>filename</i> arguments are case sensitive.
Step 4	copy running-config startup-config Example: <pre>switch# copy running-config startup-config</pre>	Saves the running configuration file to the startup configuration file.
Step 5	(Optional) show startup-config Example: <pre>switch# show startup-config</pre>	Displays the running configuration.

Related Topics

[Copying Files](#)

Copying Configuration Files to an External Flash Memory Device

You can copy configuration files to an external flash memory device as a backup for later use.

Before you begin

Insert the external Flash memory device into the active supervisor module.

SUMMARY STEPS

1. (Optional) **dir** {slot0: | usb1: | usb2:}[*directory/*]
2. **copy running-config** {slot0: | usb1: | usb2:}[*directory/*]*filename*
3. **copy startup-config** {slot0: | usb1: | usb2:}[*directory/*]*filename*

DETAILED STEPS

	Command or Action	Purpose
Step 1	(Optional) dir {slot0: usb1: usb2:}[<i>directory/</i>] Example: switch# dir slot0:	Displays the files on the external flash memory device.
Step 2	copy running-config {slot0: usb1: usb2:}[<i>directory/</i>] <i>filename</i> Example: switch# copy running-config slot0:dsn-running-config.cfg	Copies the running configuration to an external flash memory device. The <i>filename</i> argument is case sensitive.
Step 3	copy startup-config {slot0: usb1: usb2:}[<i>directory/</i>] <i>filename</i> Example: switch# copy startup-config slot0:dsn-startup-config.cfg	Copies the startup configuration to an external flash memory device. The <i>filename</i> argument is case sensitive.

Related Topics

[Copying Files](#)

Copying the Running Configuration from an External Flash Memory Device

You can configure your Cisco NX-OS device by copying configuration files created on another Cisco NX-OS device and saved to an external flash memory device.

Before you begin

Insert the external flash memory device into the active supervisor module.

SUMMARY STEPS

1. (Optional) **dir** {slot0: | usb1: | usb2:}[*directory/*]
2. **copy** {slot0: | usb1: | usb2:}[*directory/*]*filename* **running-config**
3. (Optional) **show running-config**
4. (Optional) **copy running-config startup-config**
5. (Optional) **show startup-config**

DETAILED STEPS

	Command or Action	Purpose
Step 1	(Optional) dir {slot0: usb1: usb2:}[directory/] Example: switch# dir slot0:	Displays the files on the external flash memory device.
Step 2	copy {slot0: usb1: usb2:}[directory/]filename running-config Example: switch# copy slot0:dsn-config.cfg running-config	Copies the running configuration from an external flash memory device. The <i>filename</i> argument is case sensitive.
Step 3	(Optional) show running-config Example: switch# show running-config	Displays the running configuration.
Step 4	(Optional) copy running-config startup-config Example: switch# copy running-config startup-config	Copies the running configuration to the startup configuration.
Step 5	(Optional) show startup-config Example: switch# show startup-config	Displays the startup configuration.

Related Topics

[Copying Files](#)

Copying the Startup Configuration from an External Flash Memory Device

You can recover the startup configuration on your Cisco NX-OS device by downloading a new startup configuration file saved on an external flash memory device.

Before you begin

Insert the external flash memory device into the active supervisor module.

SUMMARY STEPS

1. (Optional) **dir** {slot0: | usb1: | usb2:}[directory/]
2. **copy** {slot0: | usb1: | usb2:}[directory/]filename **startup-config**
3. (Optional) **show startup-config**

DETAILED STEPS

	Command or Action	Purpose
Step 1	(Optional) <code>dir {slot0: usb1: usb2:}[directory/]</code> Example: switch# dir slot0:	Displays the files on the external flash memory device.
Step 2	<code>copy {slot0: usb1: usb2:}[directory /]filename startup-config</code> Example: switch# copy slot0:dsn-config.cfg startup-config	Copies the startup configuration from an external flash memory device. The <i>filename</i> argument is case sensitive.
Step 3	(Optional) <code>show startup-config</code> Example: switch# show startup-config	Displays the startup configuration.

Related Topics

[Copying Files](#)

Copying Configuration Files to an Internal File System

You can copy configuration files to the internal memory as a backup for later use.

SUMMARY STEPS

1. `copy running-config [filesystem:][directory/] | [directory/]filename`
2. `copy startup-config [filesystem:][directory/] | [directory/]filename`

DETAILED STEPS

	Command or Action	Purpose
Step 1	<code>copy running-config [filesystem:][directory/] [directory/]filename</code> Example: switch# copy running-config bootflash:sw1-run-config.bak	Copies the running-configuration file to internal memory. The <i>filesystem</i> , <i>directory</i> , and <i>filename</i> arguments are case sensitive.
Step 2	<code>copy startup-config [filesystem:][directory/] [directory/]filename</code> Example: switch# copy startup-config bootflash:sw1-start-config.bak	Copies the startup-configuration file to internal memory. The <i>filesystem</i> , <i>directory</i> , and <i>filename</i> arguments are case sensitive.

Related Topics

[Copying Files](#)

Rolling Back to a Previous Configuration

Problems, such as memory corruption, can occur that make it necessary for you to recover your configuration from a backed up version.



Note Each time that you enter a **copy running-config startup-config** command, a binary file is created and the ASCII file is updated. A valid binary configuration file reduces the overall boot time significantly. A binary file cannot be uploaded, but its contents can be used to overwrite the existing startup configuration. The **write erase** command clears the binary file.

SUMMARY STEPS

1. **write erase**
2. **reload**
3. **copy *configuration_file* running-configuration**
4. **copy running-config startup-config**

DETAILED STEPS

	Command or Action	Purpose
Step 1	write erase Example: <pre>switch# write erase</pre>	Clears the current configuration of the switch.
Step 2	reload Example: <pre>switch# reload</pre>	Restarts the device. You will be prompted to provide a kickstart and system image file for the device to boot and run. Note By default, the reload command reloads the device from a binary version of the startup configuration. Beginning with Cisco NX-OS 6.2(2), you can use the reload ascii command to copy an ASCII version of the configuration to the start up configuration when reloading the device.
Step 3	copy <i>configuration_file</i> running-configuration Example: <pre>switch# copy bootflash:start-config.bak running-configuration</pre>	Copies a previously saved configuration file to the running configuration. Note The <i>configuration_file</i> filename argument is case sensitive.
Step 4	copy running-config startup-config Example: <pre>switch# copy running-config startup-config</pre>	Copies the running configuration to the start-up configuration.

Removing the Configuration for a Missing Module

When you remove an I/O module from the chassis, you can also remove the configuration for that module from the running configuration.



Note You can only remove the configuration for an empty slot in the chassis.

Before you begin

Remove the I/O module from the chassis.

SUMMARY STEPS

1. (Optional) **show hardware**
2. **purge module *slot* running-config**
3. (Optional) **copy running-config startup-config**

DETAILED STEPS

	Command or Action	Purpose
Step 1	(Optional) show hardware Example: switch# show hardware	Displays the installed hardware for the device.
Step 2	purge module <i>slot</i> running-config Example: switch# purge module 3 running-config	Removes the configuration for a missing module from the running configuration.
Step 3	(Optional) copy running-config startup-config Example: switch# copy running-config startup-config	Copies the running configuration to the startup configuration.

Erasing a Configuration

You can erase the configuration on your device to return to the factory defaults.

You can erase the following configuration files saved in the persistent memory on the device:

- Startup
- Boot
- Debug

The **write erase** command erases the entire startup configuration, except for the following:

- Boot variable definitions
- The IPv4 configuration on the mgmt0 interface, including the following:

- Address
- Subnet mask

To remove the boot variable definitions follow step-1 and step-2.

To remove the boot variables, running configuration, and the IP configuration on the management interface follow step-3 to step-5.

SUMMARY STEPS

1. write erase boot
2. reload
3. write erase
4. write erase boot
5. reload

DETAILED STEPS

	Command or Action	Purpose
Step 1	write erase boot Example: <pre>switch# write erase boot</pre>	Erases the boot variable definitions.
Step 2	reload Example: <pre>switch# reload</pre>	Restarts the device. You will be prompted to provide a kickstart and system image file for the device to boot and run. By default, the reload command reloads the device from a binary version of the startup configuration.
Step 3	write erase Example: <pre>switch# write erase</pre>	Erases the boot variable definitions.
Step 4	write erase boot Example: <pre>switch# write erase boot</pre>	Erases the boot variable definitions and the IPv4 configuration on the management interface.
Step 5	reload Example: <pre>switch# reload</pre>	Restarts the device. You will be prompted to provide a kickstart and system image file for the device to boot and run. By default, the reload command reloads the device from a binary version of the startup configuration.

Verifying the Device Configuration

To verify the configuration after bootstrapping the device using POAP, use one of the following commands:

Command	Purpose
<code>show running-config</code>	Displays the running configuration.
<code>show startup-config</code>	Displays the startup configuration.

For detailed information about the fields in the output from these commands, see the Cisco Nexus command reference for your device.

Examples of Working with Configuration Files

This section includes examples of working with configuration files.

Copying Configuration Files

This example shows how to copy a running configuration to the bootflash: file system:

Backing Up Configuration Files

This example shows how to back up the startup configuration to the bootflash: file system (ASCII file):

```
switch# copy startup-config bootflash:my-config
```

This example shows how to back up the startup configuration to the TFTP server (ASCII file):

```
switch# copy startup-config tftp://172.16.10.100/my-config
```

This example shows how to back up the running configuration to the bootflash: file system (ASCII file):

```
switch# copy running-config bootflash:my-config
```

Rolling Back to a Previous Configuration

To roll back your configuration to a snapshot copy of a previously saved configuration, you need to perform the following steps:

1. Clear the current running image with the **write erase** command.
2. Restart the device with the **reload** command.



Note

By default, the **reload** command reloads the device from a binary version of the startup configuration.

Beginning with Cisco NX-OS 6.2(2), you can use the **reload ascii** command to copy an ASCII version of the configuration to the start up configuration when reloading the device.

3. Copy the previously saved configuration file to the running configuration with the **copy configuration_file running-configuration** command.

4. Copy the running configuration to the start-up configuration with the **copy running-config startup-config** command.



CHAPTER 10

Configuring CDP

This chapter describes how to configure the Cisco Discovery Protocol (CDP) on Cisco MDS 9000 Family switches.

- [Information About CDP, on page 121](#)
- [Configuring CDP, on page 122](#)
- [Verifying the CDP Configuration, on page 124](#)
- [Clearing CDP Counters and Tables, on page 124](#)
- [CDP Example Configuration, on page 125](#)
- [Default Settings for CDP, on page 125](#)

Information About CDP

This section includes information about CDP.

CDP Overview

The Cisco Discovery Protocol (CDP) is an advertisement protocol used by Cisco devices to advertise itself to other Cisco devices in the same network. CDP runs on the data link layer and is independent of Layer 3 protocols. Cisco devices that receive the CDP packets cache the information to make it accessible through the CLI and SNMP.

The Cisco NX-OS software supports CDP on the management Ethernet (mgmt0) interface on the supervisor module and the Gigabit Ethernet interfaces on the IP Storage Services (IPS) and 14/2-port Multiprotocol Services (MPS-14/2) modules. The CDP daemon is restartable and switchable. The running and startup configurations are available across restarts and switchovers.

CDP version 1 (v1) and version 2 (v2) are supported in Cisco MDS 9000 Family switches. CDP packets with any other version number are silently discarded when received.

When the interface link is established, CDP is enabled by default and three CDP packets are sent at 1-second intervals. Following this action, the CDP frames are sent at the globally configured refresh interval.

High Availability for CDP

The Cisco NX-OS software supports stateless restarts for CDP. After a reboot or a supervisor module switchover, the Cisco NX-OS software applies the running configuration. For more information on high availability, see the .

Configuring CDP

This section describes how to configure CDP.

Enabling or Disabling CDP Globally

CDP is enabled by default. You can disable CDP and then reenabling it.

CDP must be enabled on the device before you enable CDP on any interfaces. If CDP is disabled globally and you enable CDP on specified interfaces, CDP will not be active on those interfaces. The system does not return an error message when this occurs.

SUMMARY STEPS

1. **configure terminal**
2. **cdp enable**
3. (Optional) **copy running-config startup-config**

DETAILED STEPS

	Command or Action	Purpose
Step 1	configure terminal Example: switch# configure terminal switch(config)#	Enters configuration mode.
Step 2	cdp enable Example: switch(config)# cdp enable	Enables the CDP feature on the entire device. This is enabled by default .
Step 3	(Optional) copy running-config startup-config Example: switch(config)# copy running-config startup-config	Saves this configuration change.

Enabling or Disabling CDP on an Interface

CDP is enabled by default on an interface. You can disable CDP on an interface.

If CDP is disabled globally and you enable CDP on specified interfaces, CDP will not be active on those interfaces. The system does not return an error message when this occurs.

Before you begin

Ensure that CDP is enabled on the device.

SUMMARY STEPS

1. **configure terminal**
2. **interface** *interface-type slot/port*
3. **cdp enable**
4. (Optional) **show cdp interface** *interface-type slot/port*
5. (Optional) **copy running-config startup-config**

DETAILED STEPS

	Command or Action	Purpose
Step 1	configure terminal Example: switch# configure terminal switch(config)#	Enters configuration mode.
Step 2	interface <i>interface-type slot/port</i> Example: switch(config)# interface ethernet 1/2 switch(config-if)#	Enters interface configuration mode.
Step 3	cdp enable Example: switch(config-if)# cdp enable	Enables CDP on this interface. This is enabled by default.
Step 4	(Optional) show cdp interface <i>interface-type slot/port</i> Example: switch(config-if)# show cdp interface ethernet 1/2	Displays CDP information for an interface.
Step 5	(Optional) copy running-config startup-config Example: switch(config-if)# copy running-config startup-config	Saves this configuration change.

Configuring Optional CDP Parameters

You can use the following optional commands in global configuration mode to modify CDP:

Command	Purpose
cdp advertise {v1 v2} Example: switch(config)# cdp advertise v1	Sets the CDP version supported by the device. The default is v2.

Command	Purpose
cdp format device-id {mac-address serial-number system-name} Example: <pre>switch(config)# cdp format device-id mac-address</pre>	Sets the CDP device ID. The options are as follows: <ul style="list-style-type: none"> • mac-address—MAC address of the chassis. • serial-number—Chassis serial number or Organizationally Unique Identifier (OUI). • system-name—System name or fully qualified domain name (FQDN). The default is system-name .
cdp holdtime seconds Example: <pre>switch(config)# cdp holdtime 150</pre>	Sets the time that CDP holds onto neighbor information before discarding it. The range is from 10 to 255 seconds. The default is 180 seconds.
cdp timer seconds Example: <pre>switch(config)# cdp timer 50</pre>	Sets the refresh time when CDP sends advertisements to neighbors. The range is from 5 to 254 seconds. The default is 60 seconds.

Verifying the CDP Configuration

Use the following commands to verify the CDP configuration:

Command	Purpose
show cdp all	Displays all interfaces that have CDP enabled.
show cdp entry {all name entry-name}	Displays the CDP database entries.
show cdp global	Displays the CDP global parameters.
show cdp interface interface-type slot/port	Displays the CDP interface status.
show cdp neighbors {device-id interface interface-type slot/port} [detail]	Displays the CDP neighbor status.
show cdp traffic interface interface-type slot/port	Displays the CDP traffic statistics on an interface.

Clearing CDP Counters and Tables

Use the **clear cdp counters** command to clear CDP traffic counters for all interfaces. You can issue this command for a specified interface or for all interfaces (management and Gigabit Ethernet interfaces).

```
switch# clear cdp counters
```

Use the **clear cdp table** command to clear neighboring CDP entries for all interfaces. You can issue this command for a specified interface or for all interfaces (management and Gigabit Ethernet interfaces).

```
switch# clear cdp table interface gigabitethernet 4/1
```

CDP Example Configuration

This example enables the CDP feature and configures the refresh and hold timers:

```
configure terminal
 cdp enable
 cdp timer 50
 cdp holdtime 100
```

Default Settings for CDP

This table lists the CDP default settings.

Table 17: CDP Default Settings

Parameters	Default
CDP	Enabled globally and on all interfaces
CDP version	Version 2
CDP device ID	Serial number
CDP timer	60 seconds
CDP hold timer	180 seconds



CHAPTER 11

Configuring NTP

This chapter describes how to configure the Network Time Protocol (NTP) on Cisco MDS 9000 Series switches.

- [Information About NTP, on page 127](#)
- [Prerequisites for NTP , on page 128](#)
- [Guidelines and Limitations for NTP, on page 129](#)
- [Configuring NTP, on page 129](#)
- [Verifying NTP, on page 138](#)
- [Troubleshooting NTP, on page 139](#)
- [Example: Configuring NTP, on page 141](#)
- [Default Settings for NTP, on page 143](#)

Information About NTP

This section describes information about NTP.

NTP

In a large enterprise network, having one time standard for all network devices is critical for management reporting and event logging functions when trying to correlate interacting events logged across multiple devices. Many enterprise customers with extremely mission-critical networks maintain their own stratum-1 NTP source.

Time synchronization occurs when several frames are exchanged between clients and servers. The switches in client mode know the address of one or more NTP servers. The servers act as the time source and receive client synchronization requests.


By configuring an IP address as a peer, the Cisco NX-OS device will obtain and provide time as required. The peer is capable of providing time on its own and is capable of having a server configured. If both of these instances point to different time servers, your NTP service is more reliable. Even if the active server link is lost, you can still maintain the correct time due to the presence of the peer.

If an active server fails, a configured peer helps in providing the NTP time. To ensure backup support if the active server fails, provide a direct NTP server association and configure a peer.

If you only configure a peer, the most accurate peer takes on the role of the NTP server and the other peer acts as a peer. Both devices end at the correct time if they have the correct time source or if they point to the correct NTP source.

Figure 8: NTP Peer and Server Association

Not even a server down time will affect well-configured switches in the network. This figure displays a network with two NTP stratum 2 servers and two switches.



In this configuration, the switches were configured as follows:

- Stratum-2 Server-1
 - IPv4 address-10.10.10.10
- Stratum-2 Server-2
 - IPv4 address-10.10.10.9
- Switch-1 IPv4 address-10.10.10.1
- Switch-1 NTP configuration
 - NTP server 10.10.10.10
 - NTP peer 10.10.10.2
- Switch-2 IPv4 address-10.10.10.2
- Switch-2 NTP configuration
 - NTP server 10.10.10.9
 - NTP peer 10.10.10.1

Prerequisites for NTP

NTP has the following prerequisite:

- The switch should have IP connectivity to other NTP-enabled devices.

Guidelines and Limitations for NTP

NTP has the following configuration guidelines and limitations:

- You should allow a peer association with another device only when you are sure that the switch's clock is reliable (either it has a high quality local clock or the switch is itself a client of a reliable NTP server).
- A peer configured alone takes on the role of a server and should be used as a backup. If you have two servers, you can configure several devices to point to one server and the remaining devices to point to the other server. You can then configure a peer association between these two servers to create a more reliable NTP configuration.
- If you only have one server, you should configure all the devices as clients to that server.
- You can configure up to 64 NTP entities (servers and peers).

Configuring NTP

This section describes how to configure NTP.

Enabling NTP

To enable NTP on a switch:



Note NTP is enabled by default.

Step 1 Enter configuration mode:
switch# **configure terminal**

Step 2 Enable NTP:
switch(config)# **feature ntp**

Disabling NTP

To disable NTP on a switch:

Step 1 Enter configuration mode:
switch# **configure terminal**

- Step 2** Disable NTP:
switch(config)# **no feature ntp**
-

Configuring Authentication Keys

The **ntp trusted-key** command provides protection against accidentally synchronizing the device to a time source that is not trusted. To synchronize a server device time zone with a client device time zone, the NTP authentication feature can be enabled only on the server device. To synchronize a client device time zone with a server device time zone, the NTP authentication feature must be enabled on both devices and the keys specified on the client device must be one of the keys specified on the server device. If the keys specified on the server device and the client device are different, then only the server device time zone can be synchronized with the client device time zone.

To configure the keys to be used to authenticate NTP associations, perform these steps:

Before you begin

Make sure that you configured the NTP server with the authentication keys that you plan to specify in this procedure.

- Step 1** Enter configuration mode:
switch# **configure terminal**
- Step 2** Define an authentication key:
switch(config)# **ntp authentication-key id md5 key [0 | 7]**
The range for key *id* is from 1 to 65535. For the *key*, you can enter up to eight alphanumeric characters.
- Step 3** Specify one or more keys that a time source must provide in its NTP packets in order for the device to synchronize to it:
switch(config)# **ntp trusted-key id**
The range for key *id* is from 1 to 65535.
-

What to do next

[Enabling Authentication of Temporary, Symmetric, Broadcast, or Multicast NTP Associations, on page 130.](#)

Enabling Authentication of Temporary, Symmetric, Broadcast, or Multicast NTP Associations

Temporary, symmetric, broadcast, or multicast updates (as opposed to server or peer updates) should be authenticated to prevent untrusted sources from injecting updates to devices.

To enable authentication of these types of NTP associations, perform these steps:

-
- Step 1** Enter configuration mode:
switch# **configure terminal**
- Step 2** Enable NTP authentication of packets from new temporary, symmetric, broadcast, or multicast associations with remote network hosts (this does not authenticate peer associations that are created using the **ntp server** or **ntp peer** commands.):
switch# **ntp authenticate**
-

Disabling Authentication of Temporary, Symmetric, Broadcast, or Multicast NTP Associations

To disable authentication of these types of NTP associations, perform these steps:

-
- Step 1** Enter configuration mode:
switch# **configure terminal**
- Step 2** Disable NTP authentication of packets from new temporary, symmetric, broadcast, or multicast associations with remote network hosts (this does not authenticate peer associations that are created using the **ntp server** or **ntp peer** commands.):
switch(config)# **no ntp authenticate**
NTP authentication is disabled by default.
-

Enabling NTP Servers and Peers

An NTP server is an authoritative source of NTP updates. The local device will follow the time of a server, but the server will not update from the local device's time. NTP peers send out updates and also adjust to incoming peer updates so that all peers converge to the same time. A device may have associations with multiple servers or peers.

NTP implements authentication through keys. Use NTP keys to filter exchanges to only trusted devices. This avoids trusting NTP updates from misconfigured or malicious sources.

To enable NTP server and peers, perform these steps:

Before you begin

Make sure that you know the IP address or Domain Name System (DNS) names of your NTP server and its peers.

-
- Step 1** Enter configuration mode:
switch# **configure terminal**
- Step 2** Form an association with a server:

```
switch(config)# ntp server {ip-address | ipv6-address | dns-name} [key id] [prefer] [maxpoll interval] [minpoll interval]
```

You can specify multiple server associations.

Use the **key** keyword to enable authentication with the named server using the specified key. The range for the *id* argument is from 1 to 65535.

Use the **prefer** keyword to make this server the preferred NTP server for the device.

Use the **maxpoll** and **minpoll** keywords to configure the maximum and minimum intervals in which to poll a server. The range for the *interval* is from 4 to 16 seconds, and the default values are 6 for maxpoll and 4 for minpoll.

Note If you configure a key to be used while communicating with the NTP server, make sure that the key exists as a trusted key on the device.

Step 3 Form an association with a peer:

```
switch(config)# ntp peer {ip-address | ipv6-address | dns-name} [key id] [prefer] [maxpoll interval] [minpoll interval]
```

You can specify multiple peer associations.

Use the **key** keyword to enable authentication with the named server using the specified key. The range for the *id* argument is from 1 to 65535.

Use the **prefer** keyword to make this peer the preferred NTP peer for the device.

Use the **maxpoll** and **minpoll** keywords to configure the maximum and minimum intervals in which to poll a peer. The range for the interval is from 4 to 17 seconds, and the default values are 6 for maxpoll and 4 for minpoll.

Note If you configure a key to be used while communicating with the NTP peer, make sure that the key exists as a trusted key on the device.

Disabling NTP Servers and Peers

To disable NTP server and peers, perform these steps:

Step 1 Enter configuration mode:

```
switch# configure terminal
```

Step 2 Disable an NTP server:

```
switch(config)# no ntp server {ip-address | ipv6-address | dns-name}
```

Step 3 Disable an NTP peer:

```
switch(config)# no ntp peer {ip-address | ipv6-address | dns-name}
```

Enabling NTP Modes

To enable processing of NTP control mode and private mode packets, perform these steps:

Step 1 Enter configuration mode:

```
switch# configure terminal
```

Step 2 Enable the processing of control mode and private mode packets:

```
switch(config)# ntp allow {private | control [rate-limit seconds]}
```

The default time duration is 3 seconds, which means that a control mode packet is processed or responded every 3 seconds. Range is from 1 to 65535.

Disabling NTP Modes

To disable processing of NTP control mode and private mode packets, perform these steps:

Step 1 Enter configuration mode:

```
switch# configure terminal
```

Step 2 Disable the processing of control mode and private mode packets:

```
switch(config)# no ntp allow {private | control [rate-limit seconds]}
```

Enabling NTP Source Interface

To override the default source address of NTP packets sent from the switch, perform these steps:

Step 1 Enter configuration mode:

```
switch# configure terminal
```

Step 2 Override the default source address of NTP packets sent from the switch:

```
switch(config)# ntp source-interface {ethernet slot/port.sub-interface | mgmt number | port-channel number}
```

Only a single **ntp source-interface** command can be specified. All NTP packets sent through all interfaces will use the address specified by this command as the source address.

Disabling NTP Source Interface

To restore the default source address of NTP packets, perform these steps:

Step 1 Enter configuration mode:

```
switch# configure terminal
```

Step 2 Restore the default source address of NTP packets:

```
switch(config)# no ntp source-interface {ethernet slot/port.sub-interface | mgmt number | port-channel number}
```

Enabling NTP Logging

To enable logging of NTP message to syslog, perform these steps:

Step 1 Enter configuration mode:

```
switch# configure terminal
```

Step 2 Enable NTP logging:

```
switch(config)# ntp logging
```

Disabling NTP Logging

To disable logging of NTP message to syslog, perform these steps:

Step 1 Enter configuration mode:

```
switch# configure terminal
```

Step 2 Disable NTP logging:

```
switch(config)# no ntp logging
```

Configuring NTP Syslog Logging Level

To configure the severity threshold of NTP syslog messages, perform these steps:

Step 1 Enter configuration mode:

```
switch# configure terminal
```

Step 2 Configure the severity threshold of NTP syslog messages:

```
switch(config)# logging level ntp {0 | 1 | 2 | 3 | 4 | 5 | 6 | 7}
```

The following keywords specify the severity levels:

- **0**—Specifies to log emergency messages.

- **1**—Specifies to log alert messages.
- **2**—Specifies to log critical messages.
- **3**—Specifies to log error messages.
- **4**—Specifies to log warning messages.
- **5**—Specifies to log notification messages.
- **6**—Specifies to log informational messages.
- **7**—Specifies to log debugging messages.

Setting the Default NTP Syslog Severity Logging Level

To return to the default NTP syslog severity logging level, perform these steps:

Step 1 Enter configuration mode:

```
switch# configure terminal
```

Step 2 Return to the default NTP syslog severity logging level:

```
switch(config)# no logging level ntp {0 | 1 | 2 | 3 | 4 | 5 | 6 | 7}
```

Displaying and Clearing NTP Statistics

NTP generates statistics that you can display and clear as needed.

To display and clear NTP statistics, perform these steps:

Step 1 Display NTP statistics:

```
switch# show ntp statistics {peers | io | local | memory}
```

You can display the following NTP statistics:

- **peer**—NTP statistics per peer.
- **io**—Statistics of NTP packet handling.
- **local**—Statistics of NTP packet types.
- **memory**—Statistics of memory usage by NTP.

Step 2 Clear NTP statistics:

```
switch# clear ntp statistics {peer | io | local | memory}
```

Resynchronizing NTP

If the NTP client on a switch has lost synchronization with servers or peers, you may need to restart the NTP client. This will restart the synchronization process with all NTP servers and peers configured on the local switch. To check the status of NTP servers and clients, see the [Troubleshooting NTP](#).

To restart the NTP client on the switch, perform the following steps:

Retry synchronization:

```
switch# ntp sync-retry
```

Distributing the NTP Configuration Using CFS

You can distribute local NTP configuration to other switches in the fabric using CFS.



Note Only NTP server and peer configuration is distributed through CFS.

Enabling NTP Configuration Distribution

To enable CFS distribution of NTP configuration, perform these steps:

Before you begin

- Ensure that CFS is enabled. For more information, see the "Verifying CFS Distribution Status" section in the "[Cisco MDS 9000 Series System Management Configuration Guide](#)."
 - Ensure that NTP is enabled. For more information, see "[Verifying NTP, on page 138](#)."
-

Step 1 Enter configuration mode:

```
switch# configure terminal
```

Step 2 Enable NTP configuration distribution to all switches in a fabric:

```
switch(config)# ntp distribute
```

This command acquires a fabric lock and stores all future configuration changes in the pending database.

Disabling NTP Configuration Distribution

To disable CFS distribution of NTP configuration, perform these steps:

-
- Step 1** Enter configuration mode:
switch# **configure terminal**
- Step 2** Disable NTP configuration distribution:
switch(config)# **no ntp distribute**
-

Committing NTP Configuration Changes

When you commit the NTP configuration changes, the Cisco NX-OS software applies the pending changes to the running configuration on the local Cisco MDS switch and to all the Cisco MDS switches in a fabric that can receive NTP configuration distributions.

To apply pending NTP configuration to an NTP CFS enabled peers in a fabric, perform these steps:

Before you begin

Enable NTP configuration distribution on other Cisco MDS switches in a fabric.

-
- Step 1** Enter configuration mode:
switch# **configure terminal**
- Step 2** Distribute the pending NTP configuration to an NTP CFS enabled peers in the fabric:
switch(config)# **ntp commit**
-

Discarding NTP Configuration Changes

In NTP distribution mode, configuration changes are buffered until committed by the user. You can discard the changes before they are committed with the **abort** command.

To abort and unlock the existing NTP CFS distribution session on a switch, perform these steps:

-
- Step 1** Enter configuration mode:
switch# **configure terminal**
- Step 2** Abort and unlock the existing NTP CFS distribution session on a switch:
switch(config)# **ntp abort**
-

Forcing Termination of a Lost NTP Configuration Session

When a user starts making NTP configuration changes in distribute mode, a session is created and CFS creates a fabric wide session lock. The session lock is to prevent other users from simultaneously creating sessions and making NTP configuration changes. If the user does not commit or cancel the changes, further NTP configuration sessions will be prevented until the lock is cleared. In this case, the session lock can be released by another user and this action causes all pending NTP configuration changes in the session to be discarded and the lock to be released. Releasing the session lock can be performed from any switch in the fabric. If the administrator performs this task, pending configuration changes are discarded and the fabric lock is released.

To use administrative privileges and release the locked NTP session, perform this step:

Release the locked NTP session:

```
switch# clear ntp session
```

Verifying NTP

Use the following commands to verify NTP:

This example shows how to verify if NTP is enabled:

```
switch(config)# show running-config all | include "feature ntp"
feature ntp
```

This example shows how to display the current NTP configuration:

```
switch# show running-config ntp

!Command: show running-config ntp
!Time: Fri Jan 1 1:23:45 2018

version 8.2(1)
logging level ntp 6
ntp peer 192.168.12.34
ntp server 192.168.86.42
ntp authentication-key 1 md5 fewhg12345 7
ntp logging
```

This example shows the uncommitted (pending) NTP configuration for the current session:

```
switch# configure terminal
switch(config)# ntp distribute
switch(config)# ntp peer 192.168.12.34
switch(config)# show ntp pending peers

ntp peer 192.168.12.34

switch(config)# ntp commit
switch(config)# show ntp pending peers
```

This example shows the difference between the pending CFS database and the current NTP configuration:

```
switch# show ntp pending-diff
```

This example shows if the time stamp check is enabled using the **time-stamp** command:

```
switch# show ntp timestamp status
Linecard 3 does not support Timestamp check.
```

Troubleshooting NTP

Use the following information for troubleshooting NTP:

This example shows the NTP CFS status:

```
switch# show ntp status
Distribution : Disabled
Last operational state: No session
```

This example shows how to verify to which switches NTP configuration changes will be distributed to:

```
switch1# show cfs peers name ntp

Scope : Physical-fc-ip
-----
Switch                WWN IP Address
-----
20:00:8c:60:4f:0d:2b:b0 192.168.12.34 [Local]
                        [switch1]
20:00:8c:60:4f:0d:32:d0 192.168.56.78 [Merged]
                        [switch2.mydomain.com]

Total number of entries = 2
```

This example shows the NTP session information:

```
switch# show ntp session status
Last Action Time Stamp : None
Last Action            : None
Last Action Result     : None
Last Action Failure Reason : none
```

This example shows all the NTP peers:

```
switch# show ntp peers
-----
Peer IP Address          Serv/Peer
-----
10.105.194.169          Server (configured)
```

This example shows the difference between **show ntp pending peers** and **show ntp pending-diff** commands. The outputs are similar when adding NTP servers or peers.

```

switch1# configure terminal
switch1(config)# ntp authenticate
switch1(config)# ntp authentication-key 1 md5 aNiceKey
switch1(config)# ntp server 192.168.12.34 key 1
switch1(config)# ntp authentication-key 2 md5 goodTime
switch1(config)# ntp peer 192.168.56.78 key 2
switch1(config)# show ntp pending peers

ntp server 192.168.12.34

ntp peer 192.168.56.78

switch1(config)# show ntp pending-diff
+ntp peer 192.168.56.78
+ntp server 192.168.12.34
switch1(config)# ntp commit
switch1(config)# show ntp pending peers
switch1(config)# show ntp pending-diff

```

**Caution**

Only the server and peer commands are distributed to the NTP peer switches. Other parameters such as enabling authentication and configuring authentication keys must be configured on each switch.

Continuing the example on switch1, the outputs differ when deleting servers or peers:

```

switch1(config)# no ntp peer 192.168.56.78
switch1(config)# show ntp pending peers

ntp server 192.168.12.34

switch1(config)# show ntp pending-diff
-ntp peer 192.168.56.78
switch1(config)# ntp commit
switch1(config)# show ntp pending peers
switch1(config)# show ntp pending-diff
switch1(config)# end

```

This example shows the status of a peer. Information about each peer is displayed in the table, one peer per line. The first character of each line is a status flag. A legend above the table shows the meaning of this flag. NTP servers and peers that are in synchronization and used for local time updates have an equal (=) flag. There must be at least one device with this flag for the time on the local switch to be updated. Passive peers are peers that are currently unsynchronized. This means the local switch will not use time updates from these peers. The *remote* column shows the source IP address of the peer. The accuracy of the peer's source clock, or stratum, is shown in the *st* column. The higher the stratum value, the lower the accuracy of the peer's clock source, 16 being the lowest accuracy. The polling interval, in seconds, is shown in the *poll* column. The reachability field in the *reach* column is a circular bit map of the last 8 transactions with that peer, '1' indicating success and '0' indicating failure, the most recent transaction in the lowest significant bit. This peer has not lost any of the last 6 poll messages. The round trip time between the local switch and peer, in seconds, is shown in the *delay* column.

```

switch# show ntp peer-status
Total peers : 1
* - selected for sync, + - peer mode(active),
- - peer mode(passive), = - polled in client mode

```

```

      remote          local    st    poll    reach delay
-----
*10.105.194.169     0.0.0.0    4     16     77    0.00099

```

This example shows the detailed NTP information for a single server or peer.

The *time last received* parameter will return to zero each time frame is received from that server or peer. Consequently, this parameter will steadily increment if the peer is unreachable or not sending to the local switch NTP client.

```

switch# show ntp statistics peer ipaddr 10.105.194.169
remote host:          10.105.194.169
local interface:      Unresolved
time last received:   9s
time until next send: 54s
reachability change:  54705s
packets sent:         3251
packets received:     3247
bad authentication:   0
bogus origin:         0
duplicate:            0
bad dispersion:       0
bad reference time:   0
candidate order:      6

```

This example shows the counters maintained by the local NTP client on the switch:

```

switch# show ntp statistics local
system uptime:        24286
time since reset:     24286
old version packets:  13
new version packets:  0
unknown version number: 0
bad packet format:    0
packets processed:    13
bad authentication:   0

```

Example: Configuring NTP

This example displays how to enable the NTP protocol:

```

switch# configure terminal
switch(config)# feature ntp

```

This example displays how to disable the NTP protocol:

```

switch# configure terminal
switch(config)# no feature ntp

```

This example displays how to configure an NTP server:

```

switch# configure terminal

```

```
switch(config)# ntp server 192.0.2.10
```

This example displays how to configure an NTP peer:

```
switch# configure terminal
switch(config)# ntp peer 2001:0db8::4101
```

This example displays how to configure NTP authentication:

```
switch# configure terminal
switch(config)# ntp authentication-key 42 md5 key1_12
switch(config)# ntp trusted-key 42
switch(config)# ntp authenticate
```

This example displays how to enable the processing of private mode packets:

```
switch# configure terminal
switch(config)# ntp allow private
```

This example displays how to enable the processing of control mode packets with a rate-limit of 10 seconds:

```
switch# configure terminal
switch(config)# ntp allow control rate-limit 10
```

This example displays how to configure an NTP source interface:

```
switch# configure terminal
switch(config)# ntp source-interface ethernet 2/2
```

This example enables logging of NTP messages to syslog and changes the syslog logging threshold to 'information':

```
switch# configure terminal
switch(config)# ntp logging
switch(config)# logging logfile messages 6
switch(config)# end
switch# show logging | include "logfile:" next 1
Logging logfile: enabled
Name - messages: Severity - information Size - 4194304
switch# show logging logfile | include %NTP
2017 Jan 1 1:02:03 switch %NTP-6-NTP_SYSLOG_LOGGING: : Peer 192.168.12.34 is reachable
2017 Jan 1 2:34:56 switch %NTP-6-NTP_SYSLOG_LOGGING: : System clock has been updated,
offset= sec
```

This example displays how to disable NTP logging:

```
switch# configure terminal
switch(config)# no ntp logging
```


Default Settings for NTP

This table lists the default settings for NTP parameters.

Table 18: Default NTP Settings

NTP	Disabled
NTP Modes	Disabled
NTP Source Interface	mgmt0
NTP Logging	Disabled
NTP Distribution	Disabled



CHAPTER 12

Managing System Hardware

This chapter provides details on how to manage system hardware other than services and switching modules and how to monitor the health of the switch.

- [Displaying Switch Hardware Inventory, on page 145](#)
- [Running CompactFlash Tests, on page 149](#)
- [Displaying the Switch Serial Number, on page 149](#)
- [Displaying Power Usage Information, on page 150](#)
- [Power Supply Modes, on page 151](#)
- [About Module Temperature Monitoring, on page 159](#)
- [About Fan Modules, on page 162](#)
- [Displaying Environment Information, on page 163](#)
- [Default Settings, on page 165](#)

Displaying Switch Hardware Inventory

Use the **show inventory** command to view information on the field replaceable units (FRUs) in the switch, including product IDs, serial numbers, and version IDs. The following example shows the **show inventory** command output:

```
switch# show inventory
NAME: "Chassis", DESCR: "MDS 9710 (10 Slot) Chassis "
PID: DS-C9710 , VID: V00 , SN: JAF1647AQTL

NAME: "Slot 2", DESCR: "2/4/8/10/16 Gbps Advanced FC Module"
PID: DS-X9448-768K9 , VID: V02 , SN: JAE192008U7

NAME: "Slot 3", DESCR: "4/8/16/32 Gbps Advanced FC Module"
PID: DS-X9648-1536K9 , VID: V01 , SN: JAE203901Z0

NAME: "Slot 5", DESCR: "Supervisor Module-3"
PID: DS-X97-SF1-K9 , VID: V02 , SN: JAE17360E6B

NAME: "Slot 6", DESCR: "Supervisor Module-3"
PID: DS-X97-SF1-K9 , VID: , SN: JAE164300E8

NAME: "Slot 7", DESCR: "1/10/40G IPS,2/4/8/10/16G FC Module"
PID: DS-X9334-K9 , VID: V00 , SN: JAE195001TJ

NAME: "Slot 8", DESCR: "4/8/16/32 Gbps Advanced FC Module"
PID: DS-X9648-1536K9 , VID: V01 , SN: JAE203901ZJ
```

```

NAME: "Slot 10",  DESCR: "1/10 Gbps Ethernet Module"
PID: DS-X9848-480K9      ,  VID: V01 ,  SN: JAE172603Q9

NAME: "Slot 11",  DESCR: "Fabric card module"
PID: DS-X9710-FAB1     ,  VID: V01 ,  SN: JAE18040A1N

NAME: "Slot 12",  DESCR: "Fabric card module"
PID: DS-X9710-FAB      ,  VID: V01 ,  SN: JAE164705RF

NAME: "Slot 13",  DESCR: "Fabric card module"
PID: DS-X9710-FAB1     ,  VID: V01 ,  SN: JAE18040A22

NAME: "Slot 14",  DESCR: "Fabric card module"
PID: DS-X9710-FAB1     ,  VID: V01 ,  SN: JAE1640085T

NAME: "Slot 15",  DESCR: "Fabric card module"
PID: DS-X9710-FAB      ,  VID: V01 ,  SN: JAE16410AR4

NAME: "Slot 16",  DESCR: "Fabric card module"
PID: DS-X9710-FAB1     ,  VID: V00 ,  SN: JAE19500864

NAME: "Slot 33",  DESCR: "MDS 9710 (10 Slot) Chassis Power Supply"
PID: DS-CAC97-3KW      ,  VID: V01 ,  SN: DTM1649022W

NAME: "Slot 34",  DESCR: "MDS 9710 (10 Slot) Chassis Power Supply"
PID: DS-CAC97-3KW      ,  VID: V01 ,  SN: DTM16490239

NAME: "Slot 35",  DESCR: "MDS 9710 (10 Slot) Chassis Power Supply"
PID: DS-CAC97-3KW      ,  VID: V01 ,  SN: DTM164602ZP

NAME: "Slot 40",  DESCR: "MDS 9710 (10 Slot) Chassis Power Supply"
PID: DS-CAC97-3KW      ,  VID: V01 ,  SN: DTM164602XH

NAME: "Slot 41",  DESCR: "MDS 9710 (10 Slot) Chassis Fan Module"
PID: DS-C9710-FAN      ,  VID: V00 ,  SN: JAF1647ADCN

NAME: "Slot 42",  DESCR: "MDS 9710 (10 Slot) Chassis Fan Module"
PID: DS-C9710-FAN      ,  VID: V00 ,  SN: JAF1647ACHH

NAME: "Slot 43",  DESCR: "MDS 9710 (10 Slot) Chassis Fan Module"
PID: DS-C9710-FAN      ,  VID: V00 ,  SN: JAF1647ADCE

```

Use the **show hardware** command to display switch hardware inventory details. The following example shows the **show hardware** command output:

```

switch# show hardware
Cisco Nexus Operating System (NX-OS) Software
TAC support: http://www.cisco.com/tac
Documents: http://www.cisco.com/en/US/products/ps9372/tsd_products_support_series_home.html
Copyright (c) 2002-2017, Cisco Systems, Inc. All rights reserved.
The copyrights to certain works contained in this software are
owned by other third parties and used and distributed under
license. Certain components of this software are licensed under
the GNU General Public License (GPL) version 2.0 or the GNU
Lesser General Public License (LGPL) Version 2.1. A copy of each
such license is available at
http://www.opensource.org/licenses/gpl-2.0.php and
http://www.opensource.org/licenses/lgpl-2.1.php

Software
  BIOS:          version 3.1.0

```

```

kickstart: version 8.2(1)
system:    version 8.2(1)
BIOS compile time:    02/27/2013
kickstart image file is: bootflash:///m9700-sf3ek9-kickstart-mz.8.2.1.bin.S46
kickstart compile time: 8/30/2017 23:00:00 [09/27/2017 12:00:46]
system image file is:   bootflash:///m9700-sf3ek9-mz.8.2.1.bin.S46
system compile time:   8/30/2017 23:00:00 [09/27/2017 14:57:51]

```

Hardware

```

cisco MDS 9710 (10 Slot) Chassis ("Supervisor Module-3")
Intel(R) Xeon(R) CPU          with 8167860 kB of memory.
Processor Board ID JAE17360E6B

```

```

Device name: sw-9710-101
bootflash:   3915776 kB
slot0:       0 kB (expansion flash)

```

Kernel uptime is 0 day(s), 2 hour(s), 25 minute(s), 2 second(s)

Last reset at 969755 usecs after Wed Nov 8 06:28:35 2017

```

Reason: Reset Requested by CLI command reload
System version: 8.2(1)
Service:

```

plugin

```

Core Plugin, Ethernet Plugin
-----

```

Switch hardware ID information

```

-----
Switch is booted up
Switch type is : MDS 9710 (10 Slot) Chassis
Model number is DS-C9710
H/W version is 0.2
Part Number is 73-14586-02
Part Revision is 02
Manufacture Date is Year 16 Week 47
Serial number is JAF1647AQTL
CLEI code is 0

```

```

-----
Chassis has 10 Module slots and 6 Fabric slots
-----

```

Module1 empty

```

Module2 powered-dn
Module type is : 2/4/8/10/16 Gbps Advanced FC Module
0 submodules are present
Model number is DS-X9448-768K9
H/W version is 1.3
Part Number is 73-15110-04
Part Revision is A0
Manufacture Date is Year 19 Week 20
Serial number is JAE192008U7
CLEI code is CMUIAHUCAC

```

```

.
.
.

```

```

Module10 ok
Module type is : 1/10 Gbps Ethernet Module
0 submodules are present

```

```

Model number is DS-X9848-480K9
H/W version is 1.0
Part Number is 73-15258-05
Part Revision is A0
Manufacture Date is Year 17 Week 26
Serial number is JAE172603Q9
CLEI code is CMUCAD5BAA

```

```

Xbar1 ok
Module type is : Fabric card module
0 submodules are present
Model number is DS-X9710-FAB1
H/W version is 1.2
Part Number is 73-15234-02
Part Revision is C0
Manufacture Date is Year 18 Week 4
Serial number is JAE18040A1N
CLEI code is CMUCAD1BA

```

```

.
.
.

```

```

Xbar6 powered-dn
Module type is : Fabric card module
0 submodules are present
Model number is DS-X9710-FAB1
H/W version is 1.0
Part Number is 73-100994-01
Part Revision is 03
Manufacture Date is Year 19 Week 50
Serial number is JAE19500864
CLEI code is CLEI987656

```

```

-----
Chassis has 8 PowerSupply Slots
-----

```

```

PS1 ok
Power supply type is: 3000.00W 220v AC
Model number is DS-CAC97-3KW
H/W version is 1.0
Part Number is 341-0428-01
Part Revision is A0
Manufacture Date is Year 16 Week 49
Serial number is DTM1649022W
CLEI code is CMUPABRCAA

```

```

.
.
.

```

```

PS8 ok
Power supply type is: 3000.00W 220v AC
Model number is DS-CAC97-3KW
H/W version is 1.0
Part Number is 341-0428-01
Part Revision is A0
Manufacture Date is Year 16 Week 46
Serial number is DTM164602XH
CLEI code is CMUPABRCAA

```

```

-----
Chassis has 3 Fan slots
-----

```

```

Fan1(sys_fan1) ok
Model number is DS-C9710-FAN

```

```
H/W version is 0.2
Part Number is 73-15236-02
Part Revision is 02
Manufacture Date is Year 16 Week 47
Serial number is JAF1647ADCN
CLEI code is

Fan2(sys_fan2) ok
Model number is DS-C9710-FAN
H/W version is 0.2
Part Number is 73-15236-02
Part Revision is 02
Manufacture Date is Year 16 Week 47
Serial number is JAF1647ACHH
CLEI code is

Fan3(sys_fan3) ok
Model number is DS-C9710-FAN
H/W version is 0.2
Part Number is 73-15236-02
Part Revision is 02
Manufacture Date is Year 16 Week 47
Serial number is JAF1647ADCE
CLEI code is
```

Running CompactFlash Tests

Displaying the Switch Serial Number

You can display the serial number of your Cisco MDS 9000 Series switch by looking at the serial number label on the back of the chassis (next to the power supply), or by using the **show sprom backplane 1** command.

```
switch# show sprom backplane 1
DISPLAY backplane sprom contents:
Common block :
Block Signature : 0xabab
Block Version   : 3
Block Length    : 160
Block Checksum  : 0x134f
EEPROM Size     : 65535
Block Count     : 5
FRU Major Type  : 0x6001
FRU Minor Type  : 0x0
OEM String      : Cisco Systems, Inc.
Product Number  : DS-C9710
Serial Number   : JAF1647AQTL
Part Number     : 73-14586-02
Part Revision   : 02
Mfg Deviation   : 0
H/W Version     : 0.2
Mfg Bits        : 0
Engineer Use    : 0
snmpOID        : 0.0.0.0.0.0.0.0
Power Consump   : 0
RMA Code        : 0-0-0-0
CLEI Code       : 0
VID            : V00
Chassis specific block:
```

.

.

.



Note If you are installing a new license, use the **show license host-id** command to obtain the switch serial number. For more information, see the [Cisco MDS 9000 Series NX-OS Software Licensing Guide](#).

Displaying Power Usage Information

Use the **show environment power** command to display the actual power usage information for the entire switch. In response to this command, power supply capacity and consumption information is displayed for each module.



Note In a Cisco MDS 9700 Series switch, power usage is reserved for both supervisors regardless of whether one or both supervisor modules are present.

```
switch# show environment power
```

```
Power Supply:
Voltage: 50 Volts
```

Power Supply	Model	Actual Output	Total Capacity	Status
1	DS-CAC97-3KW	549 W	3000 W	Ok
2	DS-CAC97-3KW	535 W	3000 W	Ok
3	DS-CAC97-3KW	539 W	3000 W	Ok
4	DS-CAC97-3KW	535 W	3000 W	Ok
5	-----	0 W	0 W	Absent
6	-----	0 W	0 W	Absent
7	-----	0 W	0 W	Absent
8	-----	0 W	0 W	Absent

Module	Model	Actual Draw	Power Allocated	Status
2	DS-X9448-768K9	N/A	0 W	Powered-Dn
3	DS-X9648-1536K9	265 W	750 W	Powered-Up
5	DS-X97-SF1-K9	113 W	190 W	Powered-Up
6	DS-X97-SF1-K9	106 W	190 W	Powered-Up
7	DS-X9334-K9	441 W	480 W	Powered-Up
8	DS-X9648-1536K9	252 W	750 W	Powered-Up
10	DS-X9848-480K9	363 W	500 W	Powered-Up
Xb1	DS-X9710-FAB1	95 W	150 W	Powered-Up
Xb2	DS-X9710-FAB	91 W	150 W	Powered-Up
Xb3	DS-X9710-FAB1	94 W	150 W	Powered-Up
Xb4	DS-X9710-FAB1	90 W	150 W	Powered-Up
Xb5	DS-X9710-FAB	98 W	150 W	Powered-Up
Xb6	DS-X9710-FAB1	N/A	150 W	Powered-Dn
fan1	DS-C9710-FAN	50 W	600 W	Powered-Up
fan2	DS-C9710-FAN	40 W	600 W	Powered-Up
fan3	DS-C9710-FAN	45 W	600 W	Powered-Up

N/A - Per module power not available

Power Usage Summary:

Power Supply redundancy mode (configured)	Redundant
Power Supply redundancy mode (operational)	Redundant
Total Power Capacity (based on configured mode)	6000 W
Total Power of all Inputs (cumulative)	12000 W
Total Power Output (actual draw)	2158 W
Total Power Allocated (budget)	5560 W
Total Power Available for additional modules	440 W

Power Supply Modes

Cisco MDS 9000 Series Multilayer Switches support different number and capabilities of power supplies. This section describes the power modes that are available on Cisco MDS 9000 Series Multilayer Switches.

You can configure one of the following power modes to use the combined power provided by the installed power supply units (no power redundancy) or to provide power redundancy when there is power loss. We recommend that you configure the full redundancy power mode on your switch for optimal performance.

- **Combined mode**—This mode uses the combined capacity of all the power supplies. In case of power supply failure, the entire switch can be shut down (depending on the power used) causing traffic disruption. This mode is seldom used, except in cases when the switch requires more power.
- **Input Source (grid) redundancy mode**—This mode allocates half of the power supplies to the available category and the other half to the reserve category. You must use different power supplies for the available and reserve categories so that if the power supplies used for the active power fails, the power supplies used for the reserve power can provide power to the switch. If the grid-redundancy mode is lost, the power mode reverts to combined mode.
- **Power-supply (N+1) redundancy mode**—This mode allocates one power supply as reserve to provide power to the switch in case an active power supply fails. The remaining power supplies are allocated for the available category. The reserve power supply must be at least as powerful as each of the power supplies used for the active power.
- **Full-redundancy mode**—This mode is a combination of input-source (grid) and power-supply (N+1) redundancy modes. Similar to the input-source redundancy mode, this mode allocates half of the power supplies to the available category and the remaining power supplies to reserve category. One of the reserve power supplies can alternatively be used to provide power if a power supply used for the active power fails.

For more information on the power supply modes supported on your switch, see the *Hardware Installation Guide* corresponding to your switch.

Configuration Guidelines for Power Supplies

For information that is specific to the power supplies supported on your switch, see the *Hardware Installation Guide* corresponding to your switch.

**Note**

- Some Cisco MDS switches support DC and high-voltage DC (HVDC) power supplies. HVDC power supplies support 440 V (higher voltage), whereas DC power supplies support up to 110 or 220 V. Also, HVDC power supplies are efficient in transmitting power over a long distance.
- The Cisco MDS 9250i switch has three power supplies whose power supply mode is configured to N+1 mode. Cisco MDS 9250i switch can also be operated with only two power supplies when 1+1 grid redundancy is required. All the other Cisco MDS 9000 switches (excluding Directors) have a nonconfigurable power supply mode set to 1+1 grid redundancy.

A Cisco MDS 9700 Series switch ships with enough power supplies to power a fully populated chassis in the grid-redundant (N+N) mode. For example, depending on your switch's configuration, Cisco MDS 9710 switch may ship with six power supplies, by default, and can power a fully populated chassis in the grid-redundant power-configuration (N+N) mode. All the power supplies are always powering the chassis. However, for managing, reporting, and budgeting the power supplies, Cisco MDS NX-OS supports various configurable power supply modes. One of the features of the power supply modes is to make assumptions, especially in grid configuration, to identify power supplies that are connected to grid A and grid B power whips. For information on connecting power supplies, see the "Product Overview" section in the [Cisco MDS 9700 Series Hardware Installation Guide](#).

The following table provides information about the power supply bays with respect to grid configurations:

Table 19: Cisco MDS 9700 Grid-Slot Location

Cisco MDS Switch	Grid A	Grid B
Cisco MDS 9718	PSU1, PSU2, PSU5, PSU6, PSU9, PSU10, PSU13, PSU14	PSU3, PSU4, PSU7, PSU8, PSU11, PSU12, PSU15, PSU16
Cisco MDS 9710	PSU1, PSU2, PSU5, PSU6	PSU3, PSU4, PSU7, PSU8
Cisco MDS 9706	PSU1, PSU2	PSU3, PSU4

The following is a list of power supply modes supported on Cisco MDS switches:

**Note**

Changing between power modes is non disruptive and is possible only if there is enough power available in the target mode. If enough power is not available, MDS NX-OS rejects the command with "Insufficient capacity" message.

- Ps-redundant mode—The default power supply mode is the ps-redundant mode, which is equivalent to the N+1 redundant mode because this mode is flexible enough to cover the deployments in the most diverse environments. In this mode, N functioning power supplies are used for budgeting, alerting, reporting, and monitoring, and one power supply is used as reserve. The total available power is the sum of capacities of the N power supplies.

In the ps-redundant mode, there is no restriction for the placement of power supplies in the chassis slots. The power supplies need not be placed in grid A or grid B as recommended. Even if the power supplies are placed as recommended in grid A or grid B, MDS NX-OS will not support budgeting, alerting, reporting, and monitoring as per a grid configuration because of the N+1 redundancy mode.

Table 20: ps-redundant Mode

Scenario	Grid A			Grid B			Available Capacity (Watts)	Power Supply Operational Mode
	Power Supply 1 (Watts)	Power Supply 2 (Watts)	Power Supply 5 (Watts)	Power Supply 3 (Watts)	Power Supply 4 (Watts)	Power Supply 7 (Watts)		
1	3000	3000	3000	3000	3000	3000	15000	N+1 redundant mode. Available power capacity is the sum of power capacities of all the operational power supply units (PSUs), except one, which is used as reserve.
2	3000	3000	3000	3000	3000	Off	12000	
3	3000	3000	3000	3000	Off	Off	9000	
4	3000	3000	3000	Off	Off	Off	6000	

- insrc-redundant mode—If a grid (N+N) mode is required in a chassis for proper budgeting, alerting, reporting, and monitoring purposes, power supplies must be configured, as shown in [Table 20: ps-redundant Mode, on page 153](#) and then the ps-redundant mode should be changed to the insrc-redundant mode.

After the insrc-redundant mode is configured, and if a power supply fails, the power supply mode is changed to combined (nonredundant) mode in relation to the least-populated grid.

When the insrc-redundant mode is configured and a grid fails, the insrc-redundant mode is disabled until the grid is back online. In the meantime, the operational power supply mode is changed to combined (nonredundant) mode and power is used from all the power supplies for budgeting, alerting, reporting, and monitoring.

Table 21: insrc-redundant Mode

Scenario	Grid A			Grid B			Available Capacity (Watts)	Power Supply Operational Mode
	Power Supply 1 (Watts)	Power Supply 2 (Watts)	Power Supply 5 (Watts)	Power Supply 3 (Watts)	Power Supply 4 (Watts)	Power Supply 7 (Watts)		

Scenario	Grid A			Grid B			Available Capacity (Watts)	Power Supply Operational Mode
1	3000	3000	3000	3000	3000	3000	9000	3+3 redundant mode. Available capacity is the sum of power capacities of three PSUs, which are used as reserve.
2	3000	3000	3000	3000	3000	Off	6000	Combined (nonredundant) mode because of uneven distribution of PSUs in grids. Available capacity is the sum of power capacities of PSUs of the least populated grid.
3	3000	3000	3000	3000	Off	Off	3000	Combined (nonredundant) mode because of uneven distribution of PSUs in grids. Available capacity is the sum of power capacities of PSUs of the least populated grid.
4	3000	3000	3000	Off	Off	Off	9000	Combined (nonredundant) mode because of the grid B failure.

- Redundant mode—Redundant mode is a combination of grid (N+N) and ps-redundant (N+1) modes. If the MDS NX-OS power supply mode is set to redundant mode and if there are an equal number of functioning power supplies in each grid location (grid A and grid B), the operational power supply mode

is set to the grid (insrc-redundant) mode. If a grid fails, the operational power supply mode is changed to ps-redundant (N+1) mode. The ps-redundant mode is different from the insrc-redundant mode because a grid failure in insrc-redundant mode defaults to combined (nonredundant) mode.

When configured in redundant mode and if a power supply fails, the power supply mode is changed to combined (nonredundant) mode in relation to the least-populated grid.

Table 22: Redundant Mode

Scenario	Grid A			Grid B			Available Capacity (Watts)	Power Supply Operational Mode
	Power Supply 1 (Watts)	Power Supply 2 (Watts)	Power Supply 5 (Watts)	Power Supply 3 (Watts)	Power Supply 4 (Watts)	Power Supply 7 (Watts)		
1	3000	3000	3000	3000	3000	3000	9000	3+3 redundant mode with three PSUs in each grid.
2	3000	3000	3000	3000	3000	Off	6000	Combined (non redundant) mode because of uneven distribution of PSUs in grids. Available capacity is the sum of PSUs of the least populated grid.

Scenario	Grid A			Grid B			Available Capacity (Watts)	Power Supply Operational Mode
3	3000	3000	3000	3000	Off	Off	3000	Combined (non redundant) mode because of uneven distribution of PSUs in grids. Available capacity is the sum of PSUs of the least populated grid.
4	3000	3000	3000	Off	Off	Off	6000	Power supply mode switched to ps-redundant (N+1) mode because of grid B failure.



Note When the insrc-redundant or redundant mode is configured, the grid power supply with an unbalanced configuration (that is, 2+4, and so on) results in the power supply mode to change to combined (nonredundant) operational mode and insufficient power may be budgeted. We recommend that you do not use a grid power supply with an unbalanced configuration when the insrc-redundant or redundant mode is configured.

- Combined (nonredundant) mode—This has no restrictions on how external power sources are connected to a Cisco MDS 9710 switch. The power that is available to the switch is the sum of all the working power supplies in the chassis. You can change from other power modes to the combined mode without disrupting the traffic.

Table 23: Combined (Nonredundant) Mode

Scenario	Grid A			Grid B			Available Capacity (Watts)	Power Supply Operational Mode
	Power Supply 1 (Watts)	Power Supply 2 (Watts)	Power Supply 5 (Watts)	Power Supply 3 (Watts)	Power Supply 4 (Watts)	Power Supply 7 (Watts)		
1	3000	3000	3000	3000	3000	3000	18000	In the combined (non redundant) mode, the position of PSUs do not matter. All PSUs are available for budgeting.
2	3000	3000	3000	3000	3000	Off	15000	
3	3000	3000	3000	3000	Off	Off	12000	
4	3000	3000	3000	Off	Off	Off	9000	

The following table provides information about moving from combined (nonredundant) mode to other power supply modes:

Table 24: Moving from Combined (Nonredundant) Mode to Other Power Supply Modes

Scenario	Grid A			Grid B			Current Usage (Watts)	Current Mode	New Mode	Capacity (Watts)	Power Supply Operational Mode
	Power Supply 1 (Watts)	Power Supply 2 (Watts)	Power Supply 5 (Watts)	Power Supply 3 (Watts)	Power Supply 4 (Watts)	Power Supply 7 (Watts)					
1	3000	3000	3000	3000	3000	3000	6500	Combined	NA	18000	Combined mode.
	3000	3000	3000	3000	3000	3000	6500	NA	Redundant or insrc-redundant	9000	The new capacity has changed to redundant mode.

Scenario	Grid A			Grid B			Current Usage (Watts)	Current Mode	New Mode	Capacity (Watts)	Power Supply Operational Mode
2	3000	3000	3000	3000	3000	Off	6500	Combined	NA	15000	Combined mode.
	3000	3000	3000	3000	3000	Off	6500	NA	Redundant or insrc-redundant	NA	Rejected due to insufficient capacity. Power supply mode reverts to the combined (non redundant) mode, because the power availability in one grid is less than the current usage.
3	3000	3000	3000	3000	3000	Off	5500	Combined	NA	15000	Combined mode.
	3000	3000	3000	3000	3000	Off	5500	NA	Redundant or insrc-redundant	6000	The new capacity has changed to redundant mode.
4	3000	3000	3000	3000	3000	Off	6500	Combined	NA	15000	Combined mode.
	3000	3000	3000	3000	3000	Off	6500	NA	Ps-redundant	12000	The new capacity has changed to ps-redundant mode.

Configuring the Power Supply Mode

You can configure power supply modes.

SUMMARY STEPS

1. **configure terminal**
2. **power redundancy-mode {combined | insrc-redundant | ps-redundant | redundant}**
3. (Optional) **show environment power**
4. (Optional) **copy running-config startup-config**

DETAILED STEPS

	Command or Action	Purpose
Step 1	configure terminal Example: <pre>switch# configure terminal switch(config)#</pre>	Enters global configuration mode.
Step 2	power redundancy-mode {combined insrc-redundant ps-redundant redundant} Example: <pre>switch(config)# power redundancy-mode combined</pre>	Configures the power supply mode. The default is redundant .
Step 3	(Optional) show environment power Example: <pre>switch(config)# show environment power</pre>	Displays the power mode configuration.
Step 4	(Optional) copy running-config startup-config Example: <pre>switch(config)# copy running-config startup-config</pre>	Copies the running configuration to the startup configuration.

About Module Temperature Monitoring

Built-in automatic sensors are provided in all switches in the Cisco MDS 9000 Family to monitor your switch at all times.

Each module (switching and supervisor) has four sensors: 1 (outlet sensor), 2 (intake sensor), and 3 (onboard sensor). Each sensor has two thresholds (in degrees Celsius): minor and major.



Note A threshold value of -127 indicates that no thresholds are configured or applicable.

- Minor threshold—When a minor threshold is exceeded, a minor alarm occurs and the following action is taken for all four sensors:

- System messages are displayed.
 - Call Home alerts are sent (if configured).
 - SNMP notifications are sent (if configured).
- Major threshold—When a major threshold is exceeded, a major alarm occurs and the following action is taken:
 - For sensors 1 and 3 (outlet and onboard sensors):
 - System messages are displayed.
 - Call Home alerts are sent (if configured).
 - SNMP notifications are sent (if configured).
 - For sensor 2 (intake sensor):
 - If the threshold is exceeded in a switching module, only that module is shut down.
 - If the threshold is exceeded in an active supervisor module with HA-standby or standby present, only that supervisor module is shut down and the standby supervisor module takes over.
 - If you do not have a standby supervisor module in your switch, you have an interval of 2 minutes to decrease the temperature. During this interval the software monitors the temperature every five (5) seconds and continuously sends system messages as configured.



Tip To realize the benefits of these built-in automatic sensors on any switch in the Cisco MDS 9700 Series, we highly recommend that you install dual supervisor modules. If you are using a Cisco MDS 9000 Series switch without dual supervisor modules, we recommend that you immediately replace the fan module if even one fan is not working.

Displaying Module Temperatures

Use the **show environment temperature** command to display temperature sensors for each module.

This example shows the temperature information.

```
switch# show environment temperature
Temperature:
-----
```

Module	Sensor	MajorThresh (Celsius)	MinorThres (Celsius)	CurTemp (Celsius)	Status
3	Crossbar0 (s1)	125	115	46	Ok
3	Crossbar1 (s2)	125	115	54	Ok
3	Arb-mux (s3)	125	105	48	Ok
3	CPU (s4)	125	105	48	Ok
3	PCISW (s5)	125	105	66	Ok
3	IOSlice0 (s6)	125	115	38	Ok
3	IOSlice1 (s7)	125	115	39	Ok
3	IOSlice2 (s8)	125	115	40	Ok
5	Inlet (s1)	60	42	23	Ok

5	Crossbar (s2)	125	115	71	Ok
5	Arbiter (s3)	125	105	51	Ok
5	L2L3Dev1 (s4)	125	110	41	Ok
5	CPU1CORE1 (s5)	85	75	35	Ok
5	CPU1CORE2 (s6)	85	75	28	Ok
5	CPU1CORE3 (s7)	85	75	35	Ok
5	CPU1CORE4 (s8)	85	75	31	Ok
5	DDR3DIMM1 (s9)	95	85	31	Ok
6	Inlet (s1)	60	42	25	Ok
6	Crossbar (s2)	125	115	70	Ok
6	Arbiter (s3)	125	105	52	Ok
6	L2L3Dev1 (s4)	125	110	41	Ok
6	CPU1CORE1 (s5)	85	70	36	Ok
6	CPU1CORE2 (s6)	85	70	34	Ok
6	CPU1CORE3 (s7)	85	70	36	Ok
6	CPU1CORE4 (s8)	85	70	33	Ok
6	DDR3DIMM1 (s9)	95	85	31	Ok
7	Crossbar0 (s1)	125	115	83	Ok
7	Crossbar1 (s2)	125	115	82	Ok
7	Arb-mux (s3)	125	115	52	Ok
7	CPU (s4)	125	115	53	Ok
7	L2L3Dev0 (s5)	125	115	66	Ok
7	IOSlice0 (s6)	125	115	56	Ok
7	IOSlice1 (s7)	125	115	56	Ok
7	IOSlice2 (s8)	125	115	57	Ok
7	FC-IP 0 (s9)	95	85	55	Ok
7	FC-IP 1 (s10)	95	85	56	Ok
8	Crossbar0 (s1)	125	115	52	Ok
8	Crossbar1 (s2)	125	115	52	Ok
8	Arb-mux (s3)	125	105	50	Ok
8	CPU (s4)	125	105	47	Ok
8	PCISW (s5)	125	105	56	Ok
8	IOSlice0 (s6)	125	115	40	Ok
8	IOSlice1 (s7)	125	115	41	Ok
8	IOSlice2 (s8)	125	115	42	Ok
10	Crossbar1 (s1)	125	115	79	Ok
10	Crossbar2 (s2)	125	115	78	Ok
10	Arb-mux (s3)	125	105	56	Ok
10	L2L3Dev1 (s5)	125	110	61	Ok
10	L2L3Dev2 (s6)	125	110	61	Ok
10	L2L3Dev3 (s7)	125	110	57	Ok
10	L2L3Dev4 (s8)	125	110	56	Ok
10	L2L3Dev5 (s9)	125	110	61	Ok
10	L2L3Dev6 (s10)	125	110	52	Ok
10	L2L3Dev7 (s11)	125	110	58	Ok
10	L2L3Dev8 (s12)	125	110	66	Ok
10	L2L3Dev9 (s13)	125	110	57	Ok
10	L2L3Dev10 (s14)	125	110	58	Ok
10	L2L3Dev11 (s15)	125	110	66	Ok
10	L2L3Dev12 (s16)	125	110	61	Ok
xbar-1	Crossbar1 (s1)	125	115	49	Ok
xbar-1	Crossbar2 (s2)	125	115	54	Ok
xbar-2	Crossbar1 (s1)	125	115	56	Ok
xbar-2	Crossbar2 (s2)	125	115	63	Ok
xbar-3	Crossbar1 (s1)	125	115	51	Ok
xbar-3	Crossbar2 (s2)	125	115	64	Ok
xbar-4	Crossbar1 (s1)	125	115	59	Ok
xbar-4	Crossbar2 (s2)	125	115	67	Ok
xbar-5	Crossbar1 (s1)	125	115	61	Ok
xbar-5	Crossbar2 (s2)	125	115	68	Ok

About Fan Modules

Hot-swappable fan modules (fan trays) are provided in all switches in the Cisco MDS 9000 Series to manage airflow and cooling for the entire switch. Each fan module contains multiple fans to provide redundancy. The switch can continue functioning in the following situations:

- One or more fans fail within a fan module—Even with multiple fan failures, switches in the Cisco MDS 9000 Series can continue functioning. When a fan fails within a module, the functioning fans in the module increase their speed to compensate for the failed fan(s).
- The fan module is removed for replacement—The fan module is designed to be removed and replaced while the system is operating without presenting an electrical hazard or damage to the system. When replacing a failed fan module in a running switch, be sure to replace the new fan module within five minutes.



Note If one or more fans fail within a fan module, the Fan Status LED turns red. A fan failure could lead to temperature alarms if not corrected immediately.

The fan status is continuously monitored by the Cisco MDS NX-OS software. In case of a fan failure, the following action is taken:

- System messages are displayed.
- Call Home alerts are sent (if configured).
- SNMP notifications are sent (if configured).

Use the **show environment fan** command to display the fan module status.

This example shows the chassis fan information.

```
switch# show environment fan
Fan:
-----
Fan          Model                Hw          Status
-----
Fan1 (sys_fan1) DS-C9710-FAN        0.2        Ok
Fan2 (sys_fan2) DS-C9710-FAN        0.2        Ok
Fan3 (sys_fan3) DS-C9710-FAN        0.2        Ok
Fan_in_PS1    --                   --          Ok
Fan_in_PS2    --                   --          Ok
Fan_in_PS3    --                   --          Ok
Fan_in_PS4    --                   --          Absent
Fan_in_PS5    --                   --          Absent
Fan_in_PS6    --                   --          Absent
Fan_in_PS7    --                   --          Absent
Fan_in_PS8    --                   --          Ok
Fan Zone Speed % (Hex) : Zone 1: 40.78 (0x68)
```

The possible Status field values for a fan module on the Cisco MDS 9700 Series switches are as follows:

- If the fan module is operating properly, the status is ok.
- If the fan is physically absent, the status is absent.

- If the fan is physically present but not working properly, the status is failure.

Displaying Environment Information

Use the **show environment** command to display all environment-related switch information.

```
switch# show environment
Power Supply:
Voltage: 50 Volts
Power
Supply      Model                Actual      Total
            Model                Output      Capacity  Status
-----
1           DS-CAC97-3KW          548 W      3000 W    Ok
2           DS-CAC97-3KW          535 W      3000 W    Ok
3           DS-CAC97-3KW          535 W      3000 W    Ok
4           -----              0 W        0 W       Absent
5           -----              0 W        0 W       Absent
6           -----              0 W        0 W       Absent
7           -----              0 W        0 W       Absent
8           DS-CAC97-3KW          535 W      3000 W    Ok
```

```

Module      Model                Actual      Power
            Model                Draw        Allocated  Status
-----
2           DS-X9448-768K9        N/A         0 W       Powered-Dn
3           DS-X9648-1536K9      265 W       350 W     Powered-Up
5           DS-X97-SF1-K9        107 W       190 W     Powered-Up
6           DS-X97-SF1-K9        106 W       190 W     Powered-Up
7           DS-X9334-K9          441 W       480 W     Powered-Up
8           DS-X9648-1536K9      252 W       750 W     Powered-Up
10          DS-X9848-480K9       363 W       500 W     Powered-Up
Xb1         DS-X9710-FAB1         95 W        150 W     Powered-Up
Xb2         DS-X9710-FAB1         94 W        150 W     Powered-Up
Xb3         DS-X9710-FAB1         91 W        150 W     Powered-Up
Xb          DS-X9710-FAB1         N/A         150 W     Powered-Dn
fan1        DS-C9710-FAN          45 W        600 W     Powered-Up
fan2        DS-C9710-FAN          45 W        600 W     Powered-Up
fan3        DS-C9710-FAN          50 W        600 W     Powered-Up
```

N/A - Per module power not available

```
Power Usage Summary:
-----
Power Supply redundancy mode (configured)      Redundant
Power Supply redundancy mode (operational)     Redundant

Total Power Capacity (based on configured mode) 6000 W
Total Power of all Inputs (cumulative)          12000 W
Total Power Output (actual draw)                2153 W
Total Power Allocated (budget)                  5560 W
Total Power Available for additional modules     440 W
```

```
Clock:
-----
Clock      Model                Hw          Status
-----
A           Clock Module         --          NotSupported/None
B           Clock Module         --          NotSupported/None
```

Fan:

Fan	Model	Hw	Status
Fan1(sys_fan1)	DS-C9710-FAN	0.2	Ok
Fan2(sys_fan2)	DS-C9710-FAN	0.2	Ok
Fan3(sys_fan3)	DS-C9710-FAN	0.2	Ok
Fan_in_PS1	--	--	Ok
Fan_in_PS2	--	--	Ok
Fan_in_PS3	--	--	Ok
Fan_in_PS4	--	--	Absent
Fan_in_PS5	--	--	Absent
Fan_in_PS6	--	--	Absent
Fan_in_PS7	--	--	Absent
Fan_in_PS8	--	--	Ok

Fan Zone Speed % (Hex): Zone 1: 40.78 (0x68)

Temperature:

Module	Sensor	MajorThresh (Celsius)	MinorThres (Celsius)	CurTemp (Celsius)	Status
3	Crossbar0 (s1)	125	115	46	Ok
3	Crossbar1 (s2)	125	115	54	Ok
3	Arb-mux (s3)	125	105	49	Ok
3	CPU (s4)	125	105	48	Ok
3	PCISW (s5)	125	105	66	Ok
3	IOSlice0 (s6)	125	115	38	Ok
3	IOSlice1 (s7)	125	115	39	Ok
3	IOSlice2 (s8)	125	115	40	Ok
5	Inlet (s1)	60	42	24	Ok
5	Crossbar(s2)	125	115	71	Ok
5	Arbiter (s3)	125	105	51	Ok
5	L2L3Dev1(s4)	125	110	42	Ok
5	CPU1CORE1(s5)	85	75	35	Ok
5	CPU1CORE2(s6)	85	75	29	Ok
5	CPU1CORE3(s7)	85	75	35	Ok
5	CPU1CORE4(s8)	85	75	30	Ok
5	DDR3DIMM1(s9)	95	85	31	Ok
6	Inlet (s1)	60	42	26	Ok
6	Crossbar(s2)	125	115	70	Ok
6	Arbiter (s3)	125	105	52	Ok
6	L2L3Dev1(s4)	125	110	41	Ok
6	CPU1CORE1(s5)	85	70	36	Ok
6	CPU1CORE2(s6)	85	70	34	Ok
6	CPU1CORE3(s7)	85	70	36	Ok
6	CPU1CORE4(s8)	85	70	33	Ok
6	DDR3DIMM1(s9)	95	85	31	Ok
7	Crossbar0 (s1)	125	115	83	Ok
7	Crossbar1 (s2)	125	115	82	Ok
7	Arb-mux (s3)	125	115	52	Ok
7	CPU (s4)	125	115	53	Ok
7	L2L3Dev0 (s5)	125	115	66	Ok
7	IOSlice0 (s6)	125	115	56	Ok
7	IOSlice1 (s7)	125	115	57	Ok
7	IOSlice2 (s8)	125	115	57	Ok
7	FC-IP 0 (s9)	95	85	56	Ok
7	FC-IP 1 (s10)	95	85	56	Ok
8	Crossbar0 (s1)	125	115	52	Ok
8	Crossbar1 (s2)	125	115	52	Ok
8	Arb-mux (s3)	125	105	50	Ok

8	CPU	(s4)	125	105	47	Ok
8	PCISW	(s5)	125	105	56	Ok
8	IOSlice0	(s6)	125	115	40	Ok
8	IOSlice1	(s7)	125	115	41	Ok
8	IOSlice2	(s8)	125	115	42	Ok
10	Crossbar1	(s1)	125	115	79	Ok
10	Crossbar2	(s2)	125	115	79	Ok
10	Arb-mux	(s3)	125	105	56	Ok
10	L2L3Dev1	(s5)	125	110	61	Ok
10	L2L3Dev2	(s6)	125	110	61	Ok
10	L2L3Dev3	(s7)	125	110	57	Ok
10	L2L3Dev4	(s8)	125	110	56	Ok
10	L2L3Dev5	(s9)	125	110	61	Ok
10	L2L3Dev6	(s10)	125	110	52	Ok
10	L2L3Dev7	(s11)	125	110	58	Ok
10	L2L3Dev8	(s12)	125	110	66	Ok
10	L2L3Dev9	(s13)	125	110	57	Ok
10	L2L3Dev10	(s14)	125	110	59	Ok
10	L2L3Dev11	(s15)	125	110	66	Ok
10	L2L3Dev12	(s16)	125	110	62	Ok
xbar-1	Crossbar1	(s1)	125	115	49	Ok
xbar-1	Crossbar2	(s2)	125	115	54	Ok
xbar-2	Crossbar1	(s1)	125	115	56	Ok
xbar-2	Crossbar2	(s2)	125	115	63	Ok
xbar-3	Crossbar1	(s1)	125	115	51	Ok
xbar-3	Crossbar2	(s2)	125	115	64	Ok
xbar-4	Crossbar1	(s1)	125	115	59	Ok
xbar-4	Crossbar2	(s2)	125	115	67	Ok
xbar-5	Crossbar1	(s1)	125	115	61	Ok
xbar-5	Crossbar2	(s2)	125	115	68	Ok

Default Settings

This table lists the default hardware settings

Table 25: Default Hardware Parameter Settings

Parameter	Default Setting
Power supply mode	PS redundant mode.



CHAPTER 13

Managing Modules

This chapter describes how to manage switching and services modules (also known as line cards) and provides information on monitoring module states.

- [About Modules, on page 167](#)
- [Maintaining Supervisor Modules, on page 170](#)
- [Verifying the Status of a Module, on page 171](#)
- [Checking the State of a Module, on page 172](#)
- [Connecting to a Module, on page 172](#)
- [Reloading Modules, on page 173](#)
- [Saving the Module Configuration, on page 174](#)
- [Purging Module Configurations, on page 175](#)
- [Powering Off Switching Modules, on page 176](#)
- [Identifying Module LEDs, on page 177](#)
- [EPLD Images, on page 182](#)
- [SSI Boot Images, on page 188](#)
- [Managing SSMs and Supervisor Modules, on page 197](#)
- [Default Settings, on page 201](#)

About Modules

This table describes the supervisor module options for switches in the Cisco MDS 9000 Family.

Table 26: Supervisor Module Options

Product	Number of Supervisor Modules	Supervisor Module Slot Number	Switching and Services Module Features
Cisco MDS 9513	Two modules	7 and 8	13-slot chassis allows any switching or services module in the other eleven slots.
Cisco MDS 9509	Two modules	5 and 6	9-slot chassis allows any switching or services module in the other seven slots.

Product	Number of Supervisor Modules	Supervisor Module Slot Number	Switching and Services Module Features
Cisco MDS 9506	Two modules	5 and 6	6-slot chassis allows any switching or services module in the other four slots.
Cisco MDS 9216	One module	1	2-slot chassis allows one optional switching or services module in the other slot.
Cisco MDS 9216A	One module	1	2-slot chassis allows one optional switching or services module in the other slot.
Cisco MDS 9216i	One module	1	2-slot chassis allows one optional switching or services module in the other slot.

Supervisor Modules

Supervisor modules are automatically powered up and started with the switch. The Cisco MDS Family switches have the following supervisor module configurations:

- Cisco MDS 9513 Directors—Two supervisor modules, one in slot 7 (sup-1) and one in slot 8 (sup-2). When the switch powers up and both supervisor modules come up together, the active module is the one that comes up first. The standby module constantly monitors the active module. If the active module fails, the standby module takes over without any impact to user traffic.
- Cisco MDS 9506 and Cisco MDS 9509 Directors—Two supervisor modules, one in slot 5 (sup-1) and one in slot 6 (sup-2). When the switch powers up and both supervisor modules come up together, the active module is the one that comes up first. The standby module constantly monitors the active module. If the active module fails, the standby module takes over without any impact to user traffic.
- Cisco MDS 9216i switches—One supervisor module that includes an integrated switching module with 14 Fibre Channel ports and two Gigabit Ethernet ports.
- Cisco MDS 9200 Series switches—One supervisor module that includes an integrated 16-port switching module.

Module Terms	Fixed or Relative	Usage
module-7 and module-8	Fixed usage for the Cisco MDS 9513 Director	module-7 always refers to the supervisor module in slot 7 and module-8 always refers to the supervisor module in slot 8.

Module Terms	Fixed or Relative	Usage
module-5 and module-6	Fixed usage for the Cisco MDS 9509 and Cisco MDS 9506 Directors	module-5 always refers to the supervisor module in slot 5 and module-6 always refers to the supervisor module in slot 6.
module-1	Fixed usage for the Cisco MDS 9200 Series switches	module-1 always refers to the supervisor module in slot 1.
sup-1 and sup-2	Fixed usage	On the Cisco MDS 9506 and MDS 9509 switches, sup-1 always refers to the supervisor module in slot 5 and sup-2 always refers to the supervisor module in slot 6. On the Cisco MDS 9513 Directors, sup-1 always refers to the supervisor module in slot 7 and sup-2 always refers to the supervisor module in slot 8.
sup-active and sup-standby	Relative usage	sup-active refers to the active supervisor module-relative to the slot that contains the active supervisor module. sup-standby refers to the standby supervisor module-relative to the slot that contains the standby supervisor module.
sup-local and sup-remote	Relative usage	If you are logged into the active supervisor, sup-local refers to the active supervisor module and sup-remote refers to the standby supervisor module. If you are logged into the standby supervisor, sup-local refers to the standby supervisor module (the one you are logged into.) There is no sup-remote available from the standby supervisor module (you cannot access a file system on the active sup).

Switching Modules

Cisco MDS 9000 Family switches support any switching module in any non-supervisor slot. These modules obtain their image from the supervisor module.

Services Modules

Cisco MDS 9000 Family switches support any services module in any non-supervisor slot.

Refer to the [Cisco MDS 9000 Series SAN Volume Controller Configuration Guide](#) for more information on Cisco MDS 9000 Caching Services Modules (CSMs).

Maintaining Supervisor Modules

This section includes general information about replacing and using supervisor modules effectively.

Replacing Supervisor Modules

To avoid packet loss when removing a supervisor module from a Cisco MDS 9500 Series Director, take the supervisor modules out of service before removing the supervisor module.

Use the **out-of-service** command before removing the supervisor module.

out-of-service module slot

Where *slot* indicates the chassis slot number in which the supervisor module resides.



Note You must remove and reinsert or replace the supervisor module to bring it into service.

Standby Supervisor Module Boot Variable Version

If the standby supervisor module boot variable images are not the same version as those running on the active supervisor module, the software forces the standby supervisor module to run the same version as the active supervisor module.

If you specifically set the boot variables of the standby supervisor module to a different version and reboot the standby supervisor module, the standby supervisor module will only load the specified boot variable if the same version is also running on the active supervisor module. At this point, the standby supervisor module is not running the images set in the boot variables.

Standby Supervisor Module Bootflash Memory

When updating software images on the standby supervisor module, verify that there is enough space available for the image using the **dir bootflash://sup-standby/** command. It is a good practice to remove older versions of Cisco MDS NX-OS images and kickstart images.

Standby Supervisor Module Boot Alert

If a standby supervisor module fails to boot, the active supervisor module detects that condition and generates a Call Home event and a system message and reboots the standby supervisor module approximately 3 to 6 minutes after the standby supervisor module moves to the loader> prompt.

The following system message is issued:

```
%DAEMON-2-SYSTEM_MSG:Standby supervisor failed to boot up.
```

This error message is also generated if one of the following situations apply:

- You remain at the loader> prompt for an extended period of time.
- You have not set the boot variables appropriately.

Verifying the Status of a Module

Before you begin configuring the switch, you need to ensure that the modules in the chassis are functioning as designed. To verify the status of a module at any time, issue the **show module** command. The interfaces in each module are ready to be configured when the ok status is displayed in the **show module** command output. A sample screenshot output of the **show module** command follows:

```
switch# show module
Mod  Ports  Module-Type                               Model                               Status
---  -
2    8      IP Storage Services Module              DS-X9308-SMIP                       ok
4    0      Caching Services Module                 DS-X9560-SMAP                       ok
5    0      Supervisor/Fabric-1                     DS-X9530-SF1-K9                     active *
6    0      Supervisor/Fabric-1                     DS-X9530-SF1-K9                     ha-standby
8    0      Caching Services Module                 DS-X9560-SMAP                       ok
9    32     1/2 Gbps FC Module                      DS-X9032                             ok

Mod  Sw          Hw          World-Wide-Name(s) (WWN)
---  -
2    1.3(0.106a) 0.206      20:41:00:05:30:00:00:00 to 20:48:00:05:30:00:00:00
5    1.3(0.106a) 0.602      --
6    1.3(0.106a) 0.602      -- <----- New running version in module 6
8    1.3(0.106a) 0.702      --
9    1.3(0.106a) 0.3        22:01:00:05:30:00:00:00 to 22:20:00:05:30:00:00:00

Mod  MAC-Address(es)                               Serial-Num
---  -
2    00-05-30-00-9d-d2 to 00-05-30-00-9d-de  JAB064605a2
5    00-05-30-00-64-be to 00-05-30-00-64-c2
6    00-d0-97-38-b3-f9 to 00-d0-97-38-b3-fd  JAB06350B1R
8    00-05-30-01-37-7a to 00-05-30-01-37-fe  JAB072705ja
9    00-05-30-00-2d-e2 to 00-05-30-00-2d-e6  JAB06280ae9

* this terminal session
```

The Status column in the output should display an ok status for switching modules and an active or standby (or HA-standby) status for supervisor modules. If the status is either ok or active, you can continue with your configuration.



Note A standby supervisor module reflects the HA-standby status if the HA switchover mechanism is enabled. If the warm switchover mechanism is enabled, the standby supervisor module reflects the standby status.

Checking the State of a Module

If your chassis has more than one switching module (also known as line card), you can check the progress by issuing the **show module** command several times and viewing the Status column each time. The switching module goes through a testing and an initializing stage before displaying an ok status.

This table describes the module states listed in the **show module** command output.

Table 27: Module States

Module Status Output	Description
powered up	The hardware has electrical power. When the hardware is powered up, the software begins booting.
testing	The switching module has established connection with the supervisor module and the switching module is performing bootup diagnostics.
initializing	The diagnostics have completed successfully and the configuration is being downloaded.
failure	The switch detects a switching module failure upon initialization and automatically attempts to power-cycle the module three times. After the third attempt it continues to display a failed state.
ok	The switch is ready to be configured.
power-denied	The switch detects insufficient power for a switching module to power up.
active	This module is the active supervisor module and the switch is ready to be configured.
HA-standby	The HA switchover mechanism is enabled on the standby supervisor module.
standby	The warm switchover mechanism is enabled on the standby supervisor module.

Connecting to a Module

At any time, you can connect to any module using the **attach module** command. Once you are at the module prompt, you can obtain further details about the module using module-specific commands.

You can also use the **attach module** command as follows:

- To display the standby supervisor module information. You cannot configure the standby supervisor module using this command.

- To display the switching module portion of the Cisco MDS 9200 Series supervisor module which resides in slot 1.

SUMMARY STEPS

1. **attach module** *slot*
2. **exit**

DETAILED STEPS

	Command or Action	Purpose
Step 1	attach module <i>slot</i> Example: <pre>switch# attach module 4 Attaching to module 4 ... To exit type 'exit', to abort type '\$.' module-4#</pre>	Provides direct access to the module in the specified slot.
Step 2	exit Example: <pre>module-4# exit rlogin: connection closed. switch#</pre>	Exits module access configuration mode.

Reloading Modules

You can reload the entire switch, reset specific modules in the switch, or reload the image on specific modules in the switch.

Reloading a Switch

To reload the switch, issue the **reload** command without any options. When you issue this command, you reboot the switch (see the [Cisco MDS 9000 NX-OS Release 4.1\(x\) and SAN-OS 3\(x\) Software Upgrade and Downgrade Guide](#)).

Power Cycling Modules

You can power cycle any module in a chassis. Power cycling reinitializes the module.

SUMMARY STEPS

1. Identify the module that needs to be reset.
2. Issue the **reload module** command to reset the identified module. This command power cycles the selected module.

DETAILED STEPS

Step 1 Identify the module that needs to be reset.

Step 2 Issue the **reload module** command to reset the identified module. This command power cycles the selected module.

reload module *number*

number indicates the slot in which the identified module resides.

```
switch# reload module 2
```

Caution Reloading a module disrupts traffic through the module.

Reloading Switching Modules

Switching modules automatically download their images from the supervisor module and do not need a forced download. This procedure is provided for reference if a new image is required.

SUMMARY STEPS

1. Identify the switching module that requires the new image.
2. Issue the **reload module** command to update the image on the switching module.

DETAILED STEPS

Step 1 Identify the switching module that requires the new image.

Step 2 Issue the **reload module** command to update the image on the switching module.

reload module *number* **force-dnld**

number indicates the slot in which the identified module resides. In this example, the identified module resides in slot 9:

```
switch# reload module 9 force-dnld
Jan 1 00:00:46 switch %LC-2-MSG: SLOT9 LOG_LC-2-IMG_DNLD_COMPLETE: COMPLETED
downloading of linecard image. Download successful...
```

Saving the Module Configuration

Issue the **copy running-config startup-config** command to save the new configuration into nonvolatile storage. Once this command is issued, the running and the startup copies of the configuration are identical.

This table displays various scenarios when module configurations are preserved or lost.

Table 28: Switching Module Configuration Status

Scenario	Consequence
You remove a switching module and issue the copy running-config startup-config command.	The configured module information is lost.
You remove a switching module and reinsert the same switching module before issuing the copy running-config startup-config command.	The configured module information is saved.
You remove a switching module, insert the same type switching module in the same slot, and issue a reload module number command.	The configured module information is saved.
You enter a reload module number command to reload a switching module.	The configured module information is preserved.
<p>You remove a switching module and insert a different type of switching module in the slot. For example, you replace a 16-port switching module with a 32-port switching module.</p> <p>Sample scenario:</p> <ol style="list-style-type: none"> 1. The switch currently has a 16-port switching module and the startup and running configuration files are the same. 2. You replace the 16-port switching module in the switch with a 32-port switching module. 3. Next, you remove the 32-port switching module and replace it with the same 16-port switching module referred to in Step 1. 4. You enter the reload command to reload the switch. 	<p>The configured module information is lost from the running configuration. The default configuration is applied.</p> <p>The configured module information remains in startup configuration until a copy running-config startup-config command is issued again.</p> <p>Sample response:</p> <ol style="list-style-type: none"> 1. The switch uses the 16-port switching module and the present configuration is saved in nonvolatile storage. 2. The factory default configuration is applied. 3. The factory default configuration is applied. 4. The configuration saved in nonvolatile storage referred to in Step 1 is applied.

Purging Module Configurations

Enter the **purge module slot running-config** command to delete the configuration in a specific module. Once you enter this command, the Cisco NX-OS software clears the running configuration for the specified slot. This command does not work on supervisor modules or on any slot that currently has a module. This command only works on an empty slot (where the specified module once resided).

The **purge module** command clears the configuration for any module that previously existed in a slot and has since been removed. While the module was in that slot, some parts of the configuration may have been stored in the running configuration and cannot be reused (for example, IP addresses), unless you clear it from the running configuration.

For example, suppose you create an IP storage configuration with an IPS module in slot 3 in Switch A. This module uses IP address 10.1.5.500. You decide to remove this IPS module and move it to Switch B, and you no longer need the IP address 10.1.5.500. If you try to configure this unused IP address, you will receive an error message that prevents you from proceeding with the configuration. In this case, you must enter the **purge module 3 running-config** command to clear the old configuration on Switch A before proceeding with using this IP address.

Powering Off Switching Modules

You can power off a switching module from the command-line interface (CLI). By default, all switching modules are in the power up state when the chassis loads or you insert the module into the chassis.

SUMMARY STEPS

1. **configure terminal**
2. **[no] poweroff module slot**

DETAILED STEPS

	Command or Action	Purpose
Step 1	configure terminal Example: <pre>switch# configure terminal switch(config)#</pre>	Enters global configuration mode.
Step 2	[no] poweroff module slot Example: <pre>switch(config)# poweroff module 2</pre>	Powers off the specified module. Use the no form of the command to power on a module.

Identifying Module LEDs

This table describes the LEDs for the Cisco MDS 9200 Series integrated supervisor modules.

Table 29: LEDs for the Cisco MDS 9200 Series Supervisor Modules

LED	Status	Description
Status	Green	All diagnostics pass. The module is operational (normal initialization sequence).
	Orange	The module is booting or running diagnostics (normal initialization sequence). or The inlet air temperature of the system has exceeded the maximum system operating temperature limit (a minor environmental warning). To ensure maximum product life, you should immediately correct the environmental temperature and restore the system to normal operation.
	Red	The diagnostic test failed. The module is not operational because a fault occurred during the initialization sequence. or The inlet air temperature of the system has exceeded the safe operating temperature limits of the card (a major environmental warning). The card has been shut down to prevent permanent damage. The system will be shut down after two minutes if this condition is not cleared.
Speed	On	2-Gbps mode and beacon mode disabled.
	Off	1-Gbps mode and beacon mode disabled.
	Flashing	Beacon mode enabled.

LED	Status	Description
Link	Solid green	Link is up.
	Solid yellow	Link is disabled by software.
	Flashing yellow	A fault condition exists.
	Off	No link.

This table describes the LEDs for the Cisco MDS 9200 Series interface module.

Table 30: LEDs on the Cisco MDS 9200 Series Interface Module

LED	Status	Description
Status	Green	All diagnostics pass. The module is operational (normal initialization sequence).
	Orange	The module is booting or running diagnostics (normal initialization sequence). or The inlet air temperature of the system has exceeded the maximum system operating temperature limit (a minor environmental warning). To ensure maximum product life, you should immediately correct the environmental temperature and restore the system to normal operation.
	Red	The diagnostic test failed. The module is not operational because a fault occurred during the initialization sequence. or The inlet air temperature of the system has exceeded the safe operating temperature limits of the card (a major environmental warning). The card has been shut down to prevent permanent damage.

LED	Status	Description
System	Green	All chassis environmental monitors are reporting OK.
	Orange	The power supply failed or the power supply fan failed. or Incompatible power supplies are installed. or The redundant clock failed.
	Red	The temperature of the supervisor module exceeded the major threshold.
MGMT 10/100 Ethernet Link LED	Green	Link is up.
	Off	No link.
MGMT 10/100 Ethernet Activity LED	Green	Traffic is flowing through port.
	Off	No link or no traffic.

This table describes the LEDs for the 16-port and 32-port switching modules, and the 4-port, 12-port, 24-port, and 48-port Generation 2 switching modules.

Table 31: LEDs for the Cisco MDS 9000 Family Fibre Channel Switching Modules

LED	Status	Description
Status	Green	All diagnostics pass. The module is operational (normal initialization sequence).
	Red	The module is booting or running diagnostics (normal initialization sequence). or The inlet air temperature of the system has exceeded the maximum system operating temperature limit (a minor environmental warning). To ensure maximum product life, you should immediately correct the environmental temperature and restore the system to normal operation.
	Orange	The diagnostic test failed. The module is not operational because a fault occurred during the initialization sequence. or The inlet air temperature of the system has exceeded the safe operating temperature limits of the card (a major environmental warning). The card has been shut down to prevent permanent damage.
Speed	On	2-Gbps mode.
	Off	1-Gbps mode.

LED	Status	Description
Link	Solid green	Link is up.
	Steady flashing green	Link is up (beacon used to identify port).
	Intermittent flashing green	Link is up (traffic on port).
	Solid yellow	Link is disabled by software.
	Flashing yellow	A fault condition exists.
	Off	No link.

The LEDs on the supervisor module indicate the status of the supervisor module, power supplies, and the fan module.

This table provides more information about these LEDs.

Table 32: LEDs for the Cisco MDS 9500 Series Supervisor Modules

LED	Status	Description
Status	Green	All diagnostics pass. The module is operational (normal initialization sequence).
	Orange	The module is booting or running diagnostics (normal initialization sequence). or An over temperature condition has occurred (a minor threshold has been exceeded during environmental monitoring).
	Red	The diagnostic test failed. The module is not operational because a fault occurred during the initialization sequence. or An over temperature condition occurred (a major threshold was exceeded during environmental monitoring).

LED	Status	Description
System Note The System and Pwr Mgmt LEDs on a redundant supervisor module are synchronized to the active supervisor module.	Green	All chassis environmental monitors are reporting OK.
	Orange	The power supply has failed or the power supply fan has failed. or Incompatible power supplies are installed. or The redundant clock has failed.
	Red	The temperature of the supervisor module major threshold has been exceeded.
Active	Green	The supervisor module is operational and active.
	Orange	The supervisor module is in standby mode.
Pwr Mgmt ¹	Green	Sufficient power is available for all modules.
	Orange	Sufficient power is not available for all modules.
MGMT 10/100 Ethernet Link LED	Green	Link is up.
	Off	No link.
MGMT 10/100 Ethernet Activity LED	Green	Traffic is flowing through port.
	Off	No link or no traffic.
Compact Flash	Green	The external CompactFlash card is being accessed.
	Off	No activity.

EPLD Images

Switches and directors in the Cisco MDS 9000 Family contain several electrical programmable logical devices (EPLDs) that provide hardware functionalities in all modules. EPLD image upgrades are periodically provided to include enhanced hardware functionality or to resolve known issues.



Tip Refer to the Cisco MDS NX-OS Release Notes to verify if the EPLD has changed for the Cisco NX-OS image version being used.

Upgrading EPLD Images

You can upgrade the EPLD images on the modules.



Note The same procedure used to upgrade the EPLD images on a module can be used to downgrade the EPLD images.

SUMMARY STEPS

1. Log into the switch through the console port, an SSH session, or a Telnet session.
2. Enter the **show version** command to verify the Cisco MDS NX-OS software release running on the MDS switch.
3. If necessary, upgrade the Cisco MDS NX-OS software running on your switch (see the [Cisco MDS 9000 NX-OS Release 4.1\(x\) and SAN-OS 3\(x\) Software Upgrade and Downgrade Guide](#)).
4. Issue the **dir bootflash:** or **dir slot0:** command to verify that the EPLD software image file corresponding to your Cisco MDS NX-OS release is present on the active supervisor module. For example, if your switch is running Cisco MDS SAN-OS Release 2.1(2), you must have m9000-epld-2.1.2.img in bootflash: or slot0: on the active supervisor module.
5. If you need to obtain the appropriate EPLD software image file, follow these steps:
6. Use the **install module number epld url** command on the active supervisor module to upgrade EPLD images for a module.

DETAILED STEPS

Step 1 Log into the switch through the console port, an SSH session, or a Telnet session.

Step 2 Enter the **show version** command to verify the Cisco MDS NX-OS software release running on the MDS switch.

```
switch# show version
Cisco Nexus Operating System (NX-OS) Software
TAC support: http://www.cisco.com/tac
Copyright (c) 2002-2006, Cisco Systems, Inc. All rights reserved.
The copyrights to certain works contained herein are owned by
other third parties and are used and distributed under license.
Some parts of this software may be covered under the GNU Public
License or the GNU Lesser General Public License. A copy of
each such license is available at
http://www.gnu.org/licenses/gpl.html and
http://www.gnu.org/licenses/lgpl.html

Software
  BIOS:          version 1.0.8
  loader:        version unavailable [last: 1.0(0.267c)]
  kickstart:     version 2.1(2) [build 2.1(2.47)] [gdb]
  system:        version 2.1(2) [build 2.1(2.47)] [gdb]
```

...

Step 3 If necessary, upgrade the Cisco MDS NX-OS software running on your switch (see the [Cisco MDS 9000 NX-OS Release 4.1\(x\) and SAN-OS 3\(x\) Software Upgrade and Downgrade Guide](#)).

Step 4 Issue the **dir bootflash:** or **dir slot0:** command to verify that the EPLD software image file corresponding to your Cisco MDS NX-OS release is present on the active supervisor module. For example, if your switch is running Cisco MDS SAN-OS Release 2.1(2), you must have m9000-epld-2.1.2.img in bootflash: or slot0: on the active supervisor module.

```
switch# dir bootflash:
 12288 Jan 01 00:01:07 1980 lost+found/
2337571 May 31 13:43:02 2005 m9000-epld-2.1.2.img
...
```

You can find the EPLD images at the following URL:

<http://www.cisco.com/cgi-bin/tablebuild.pl/mds-epld>

Step 5 If you need to obtain the appropriate EPLD software image file, follow these steps:

1. Download the EPLD software image file from Cisco.com to your FTP server.
2. Verify that you have enough free space available on the active and standby supervisor memory devices that you plan to use, either bootflash: or slot0:. The download site on Cisco.com shows the size of the EPLD image file in bytes.

The following example shows how to display the available memory for the bootflash: devices on the active and standby supervisors:

```
switch# dir bootflash:
 12288 Jan 01 00:01:06 1980 lost+found/
14765056 Mar 21 15:35:06 2005 m9500-sflek9-kickstart-mz.2.1.1.bin
15944704 Apr 06 16:46:04 2005 m9500-sflek9-kickstart-mz.2.1.1a.bin
48063243 Mar 21 15:34:46 2005 m9500-sflek9-mz.2.1.1.bin
48036239 Apr 06 16:45:41 2005 m9500-sflek9-mz.2.1.1a.bin
```

```
Usage for bootflash://sup-local
141066240 bytes used
 43493376 bytes free
184559616 bytes total
```

```
switch# show module
Mod  Ports  Module-Type                Model                Status
---  ---  -
2    32     Storage Services Module   DS-X9032-SSM        ok
5     0      Supervisor/Fabric-1       DS-X9530-SF1-K9     active *
6     0      Supervisor/Fabric-1       DS-X9530-SF1-K9     ha-standby
...
```

The **show module** command output shows that the standby supervisor is in slot 6. Use the **attach** command to access the supervisor module.

```
switch# attach module 6
...
switch(standby)# dir bootflash:
 12288 Jan 01 00:01:06 1980 lost+found/
14765056 Mar 21 15:35:06 2005 m9500-sflek9-kickstart-mz.2.1.1.bin
15944704 Apr 06 16:46:04 2005 m9500-sflek9-kickstart-mz.2.1.1a.bin
```

```
48063243 Mar 21 15:34:46 2005 m9500-sflek9-mz.2.1.1.bin
48036239 Apr 06 16:45:41 2005 m9500-sflek9-mz.2.1.1a.bin
```

```
Usage for bootflash://sup-local
141066240 bytes used
 43493376 bytes free
184559616 bytes total
```

```
switch(standby)# exit
switch#
```

The following example shows how to display the available memory for the slot0: devices on the active and standby supervisors:

```
switch# dir slot0:
 12288 Jan 01 00:01:06 1980 lost+found/
14765056 Mar 21 15:35:06 2005 m9500-sflek9-kickstart-mz.2.1.1.bin
15944704 Apr 06 16:46:04 2005 m9500-sflek9-kickstart-mz.2.1.1a.bin
48063243 Mar 21 15:34:46 2005 m9500-sflek9-mz.2.1.1.bin
48036239 Apr 06 16:45:41 2005 m9500-sflek9-mz.2.1.1a.bin
```

```
Usage for slot:
141066240 bytes used
 43493376 bytes free
184559616 bytes total
```

```
switch# show module
```

Mod	Ports	Module-Type	Model	Status
2	32	Storage Services Module	DS-X9032-SSM	ok
5	0	Supervisor/Fabric-1	DS-X9530-SF1-K9	active *
6	0	Supervisor/Fabric-1	DS-X9530-SF1-K9	ha-standby
...				

The **show module** command output shows that the standby supervisor is in slot 6. Use the **attach** command to access the supervisor module.

```
switch# attach module 6
...
switch(standby)# dir slot0:
 12288 Jan 01 00:01:06 1980 lost+found/
14765056 Mar 21 15:35:06 2005 m9500-sflek9-kickstart-mz.2.1.1.bin
15944704 Apr 06 16:46:04 2005 m9500-sflek9-kickstart-mz.2.1.1a.bin
48063243 Mar 21 15:34:46 2005 m9500-sflek9-mz.2.1.1.bin
48036239 Apr 06 16:45:41 2005 m9500-sflek9-mz.2.1.1a.bin

Usage for slot0:
141066240 bytes used
 43493376 bytes free
184559616 bytes total

switch(standby)# exit
switch#
```

3. If there is not enough space, delete unneeded files.

```
switch# delete bootflash:m9500-sflek9-kickstart-mz.2.1.1.bin
```

The **show module** command output shows that the standby supervisor is in slot 6. Use the **attach** command to access the supervisor module.

```
switch# attach module 6
switch(standby)# delete bootflash:m9500-sflek9-kickstart-mz.2.1.1.bin
switch(standby)# exit
switch#
```

4. Copy the EPLD image file from the FTP server to the bootflash: or slot0: device in the active supervisor module. The following example shows how to copy to bootflash:

```
switch# copy ftp://10.1.7.2/m9000-epld-2.1.2.img bootflash:m9000-epld-2.1.2.img
```

Note The system will automatically synchronize the EPLD image to the standby supervisor if automatic copying is enabled.

```
switch# configure terminal
switch(config)# boot auto-copy
```

Step 6 Use the **install module number epld url** command on the active supervisor module to upgrade EPLD images for a module.

```
switch# install module 2 epld bootflash:m9000-epld-2.1.2.img

EPLD                               Curr Ver   New Ver
-----
XBUS IO                             0x07       0x07
UD Flow Control                      0x05       0x05
PCI ASIC I/F                         0x05       0x05
PCI Bridge                           0x05       0x07
WARNING: Upgrade process could take upto 15 minutes.

Module 2 will be powered down now!!
Do you want to continue (y/n) ? y
\ <-----progress twirl
Module 2 EPLD upgrade is successful
```

If you forcefully upgrade a module that is not online, all EPLDs are forcefully upgraded. If the module is not present in the switch, an error is returned. If the module is present, the command process continues. To upgrade a module that is not online but is present in the chassis, use the same command. The switch software prompts you to continue after reporting the module state. When you confirm your intention to continue, the upgrade continues.

```
switch# install module 2 epld bootflash:m9000-epld-2.1.2.img
\ <-----progress twirl
Module 2 EPLD upgrade is successful
```

Note When you upgrade the EPLD module on Cisco MDS 9100 Series switches, you receive the following message:

```
Data traffic on the switch will stop now!!
Do you want to continue (y/n) ?
```

Displaying EPLD Image Versions

Use the **show version module *number* epld** command to view all current EPLD versions on a specified module.

```
switch# show version module 2 epld
EPLD Device                Version
-----
Power Manager              0x07
XBUS IO                    0x07
UD Flow Control            0x05
PCI ASIC I/F              0x05
PCI Bridge                 0x07
```

Use the **show version module epld *url*** command to view the available EPLD versions.

```
switch# show version epld bootflash:m9000-epld-2.1.1a.img
MDS series EPLD image, built on Wed May  4 09:52:37 2005

Module Type                EPLD Device                Version
-----
MDS 9500 Supervisor 1     XBUS 1 IO                  0x09
                          XBUS 2 IO                  0x0c
                          UD Flow Control            0x05
                          PCI ASIC I/F              0x04

1/2 Gbps FC Module (16 Port)  XBUS IO                    0x07
                          UD Flow Control            0x05
                          PCI ASIC I/F              0x05

1/2 Gbps FC Module (32 Port)  XBUS IO                    0x07
                          UD Flow Control            0x05
                          PCI ASIC I/F              0x05

Advanced Services Module    XBUS IO                    0x07
                          UD Flow Control            0x05
                          PCI ASIC I/F              0x05
                          PCI Bridge                 0x07

IP Storage Services Module (8 Port)  Power Manager              0x07
                          XBUS IO                    0x03
                          UD Flow Control            0x05
                          PCI ASIC I/F              0x05
                          Service Module I/F        0x0a
                          IPS DB I/F                 0x1a

IP Storage Services Module (4 Port)  Power Manager              0x07
                          XBUS IO                    0x03
                          UD Flow Control            0x05
                          PCI ASIC I/F              0x05
```

	Service Module I/F	0x1a
Caching Services Module	Power Manager	0x08
	XBUS IO	0x03
	UD Flow Control	0x05
	PCI ASIC I/F	0x05
	Service Module I/F	0x72
	Memory Decoder 0	0x02
	Memory Decoder 1	0x02
MDS 9100 Series Fabric Switch	XBUS IO	0x03
	PCI ASIC I/F	0x40000003
2x1GE IPS, 14x1/2Gbps FC Module	Power Manager	0x07
	XBUS IO	0x05
	UD Flow Control	0x05
	PCI ASIC I/F	0x07
	IPS DB I/F	0x1a

SSI Boot Images

As of Cisco SAN-OS Release 2.0(2b), you can specify the SSI boot image for a Storage Services Module (SSM) to configure Fibre Channel switching and Intelligent Storage Services (see [Cisco MDS 9000 Series NX-OS Intelligent Storage Services Configuration Guide](#) and the [Cisco MDS 9000 Series SAnTap Deployment Guide](#)). Once you set the SSI image boot variable, you do not need to reset it for upgrades or downgrades to any Cisco MDS NX-OS or SAN-OS release that supports the SSI image.



Note

- If your switch is running Cisco MDS SAN-OS Release 2.1(2) or later, a newly installed SSM initially operates in Fibre Channel switching mode by default.
- If you downgrade to a Cisco MDS SAN-OS release that does not support the SSM, you must power down the module. The boot variables for the SSM are lost.

Installing the SSI Boot Image

You can install the SSI boot image on the following modules:

- Storage Services Module (SSM)
- MSM-18+4 Multiservice Module
- MDS 9222i Module-1 Module

The SSM supports normal Fibre Channel switching and Intelligent Storage Services. To use Fibre Channel switching and Intelligent Storage Services, you must install an SSI boot image on the SSM.



Note

A newly installed SSM initially operates in Fibre Channel switching mode by default.

SUMMARY STEPS

1. Log into the switch through the console port, an SSH session, or a Telnet session.
2. Enter the **dir modflash://slot-1/** command to verify that the SSI boot image file corresponding to your Cisco MDS NX-OS release is present on the active supervisor module.
3. If the file is not present in bootflash: or the modflash:, follow these steps:
4. Enter the **install ssi** command to install the SSI boot image on the SSM.
5. Enter the **show module** command to verify the status of the SSM.

DETAILED STEPS

Step 1 Log into the switch through the console port, an SSH session, or a Telnet session.

Step 2 Enter the **dir modflash://slot-1/** command to verify that the SSI boot image file corresponding to your Cisco MDS NX-OS release is present on the active supervisor module.

For example, if your switch is running Cisco NX-OS Release 4.1(1b), you must have m9000-ek9-ssi-mz.4.1.1b.bin in modflash: on the SSM. To determine the correct SSI boot image to use, refer to the [Cisco MDS NX-OS Release Compatibility Matrix for Storage Service Interface Images](#).

You can find the SSI images at the following URL:

<http://www.cisco.com/pcgi-bin/tablebuild.pl/mds9000-ssi-3des>

Step 3 If the file is not present in bootflash: or the modflash:, follow these steps:

1. Enter the **dir modflash://slot-1/** command to ensure that there is enough free space for the SSI image file. If necessary, enter the **delete modflash://slot-1/filename** command to remove files.
2. Download the appropriate SSI boot image file to your FTP server and copy it from an FTP server to modflash: on the SSM:

```
switch# copy ftp://10.1.7.2/m9000-ek9-ssi-mz.4.1.1b.bin
modflash://4-1/m9000-ek9-ssi-mz.4.1.1b.bin
```

Step 4 Enter the **install ssi** command to install the SSI boot image on the SSM.

Note As of Cisco SAN-OS Release 3.0(2), if the SSI boot image is located on bootflash: the **install ssi** command copies the SSI boot image to the modflash: on the SSM.

```
switch# install ssi modflash://4-1/m9000-ek9-ssi-mz.4.1.1b.bin
```

Step 5 Enter the **show module** command to verify the status of the SSM.

```
switch# show module
Mod Ports Module-Type                               Model                               Status
-----
4    32    Storage Services Module                          DS-X9032-SSM                       ok
...
Mod      Application Image Description          Application Image Version
-----
4        SSI linecard image                    4.1(1b)
```

...

Upgrading or Downgrading the SSI Boot Image

You can upgrade the SSI boot image.

SUMMARY STEPS

1. Verify that the correct SSI boot image is present on your switch
2. Update the SSI boot image using one of the following methods:

DETAILED STEPS

Step 1 Verify that the correct SSI boot image is present on your switch

Step 2 Update the SSI boot image using one of the following methods:

- If your switch is running Cisco MDS SAN-OS Release 2.0(1a) through Release 2.1(1a), configure the SSI boot variable to upgrade or downgrade the SSI boot image on the module.
- Use the **install ssi** command to upgrade or downgrade the SSI boot image on the module.

SSI Boot Image Upgrade Considerations for the SSM

When you upgrade, or downgrade, the SSI boot image on an SSM, you might disrupt traffic through the module.



Note SANTap is not supported in Cisco MDS NX-OS Release 7.3(x) and above releases.

This table describes how updating the SSI boot image affects SSM traffic.

Table 33: SSI Boot Image Upgrading Effects on SSM Traffic

Cisco MDS SAN-OS Release	Traffic Type	Disrupts Traffic?
2.0(2b) through 2.1(1a)	All	Yes

Cisco MDS SAN-OS Release	Traffic Type	Disrupts Traffic?
2.1(2) and later	Layer 2 Fiber Channel switching only	No Note Requires EPLD version 2.1(2).
	Both Layer 2 Fiber Channel switching and Layer 3 Intelligent Storage Services (such as FCWA, NASB, SANTap, ISAPI virtualization)	Yes
	Layer 3 Intelligent Storage Services (such as FCWA, NASB, SANTap, ISAPI virtualization) only	Yes



Note Updating the SSI boot image disrupts Layer 3 Intelligent Storage Services traffic. If you have configured Layer 3 Intelligent Storage Services on your SSM, we recommend that you shut down these services before upgrading the SSI boot image. You can use dual fabric configuration to minimize the impact of shutting down Layer 3 services.

Verifying the SSI Boot Image

You can verify the Cisco MDS NX-OS release and SSI boot image on your switch.

SUMMARY STEPS

1. Log into the switch through the console port, an SSH session, or a Telnet session.
2. Enter the **show version** command to ensure that your switch is running Cisco MDS SAN-OS Release 2.1(1a) or later system and kickstart images.
3. If necessary, upgrade the Cisco MDS SAN-OS or NX-OS software running on your switch (see the [Cisco MDS 9000 NX-OS Release 4.1\(x\) and SAN-OS 3\(x\) Software Upgrade and Downgrade Guide](#)).
4. Issue the **dir bootflash:** or **dir slot0:** command to verify that the SSI software image file corresponding to your Cisco MDS SAN-OS release is present on the active supervisor module. For example, if your switch is running Cisco MDS NX-OS Release 4.1(1b), you must have m9000-ek9-ssi-mz.4.1.1b.bin in bootflash: or slot0: on the active supervisor module. See to the [Cisco MDS NX-OS Release Compatibility Matrix for Storage Service Interface Images](#).
5. If you need to obtain the appropriate SSI software image file, perform the following steps:

DETAILED STEPS

- Step 1** Log into the switch through the console port, an SSH session, or a Telnet session.
- Step 2** Enter the **show version** command to ensure that your switch is running Cisco MDS SAN-OS Release 2.1(1a) or later system and kickstart images.

```
switch# show version
Cisco Nexus Operating System (NX-OS) Software
```

```
TAC support: http://www.cisco.com/tac
Copyright (c) 2002-2009, Cisco Systems, Inc. All rights reserved.
The copyrights to certain works contained herein are owned by
other third parties and are used and distributed under license.
Some parts of this software may be covered under the GNU Public
License or the GNU Lesser General Public License. A copy of
each such license is available at
http://www.gnu.org/licenses/gpl.html and
http://www.gnu.org/licenses/lgpl.html
```

```
Software
  BIOS:      version 1.0.8
  loader:    version unavailable [last: 1.0(0.267c)]
  kickstart: version 2.1(2) [build 2.1(2.47)] [gdb]
  system:    version 2.1(2) [build 2.1(2.47)] [gdb]
```

...

Step 3 If necessary, upgrade the Cisco MDS SAN-OS or NX-OS software running on your switch (see the [Cisco MDS 9000 NX-OS Release 4.1\(x\) and SAN-OS 3\(x\) Software Upgrade and Downgrade Guide](#)).

Step 4 Issue the **dir bootflash:** or **dir slot0:** command to verify that the SSI software image file corresponding to your Cisco MDS SAN-OS release is present on the active supervisor module. For example, if your switch is running Cisco MDS NX-OS Release 4.1(1b), you must have m9000-ek9-ssi-mz.4.1.1b.bin in bootflash: or slot0: on the active supervisor module. See to the [Cisco MDS NX-OS Release Compatibility Matrix for Storage Service Interface Images](#).

Note As of Cisco MDS SAN-OS Release 2.1(2), we recommend that you use modflash: on the SSM. You can check for the presence of the SSI software image using the **dir modflash://slot-1/** command.

```
switch# dir bootflash:
 12288 Jan 01 00:01:07 1980 lost+found/
3821032 May 10 13:43:02 2005 m9000-ek9-ssi-mz.2.1.2.bin
...
```

You can find the SSI images at the following URL:

<http://www.cisco.com/cgi-bin/tablebuild.pl/mds9000-ssi-3des>

Step 5 If you need to obtain the appropriate SSI software image file, perform the following steps:

1. Download the SSI software image file from Cisco.com to your FTP server.
2. Verify that you have enough free space available on the active and standby supervisor memory devices which you plan to use, either bootflash: or slot0:. The download site on Cisco.com shows the size of the boot image file in bytes.

Note As of Cisco MDS SAN-OS Release 2.1(2), we recommend that you use modflash: on the SSM. You can check the available space using the **dir modflash://slot-1/** command.

The following example shows how to display the available memory for the bootflash: devices on the active and standby supervisors:

```
switch# dir bootflash:
 12288 Jan 01 00:01:06 1980 lost+found/
14765056 Mar 21 15:35:06 2005 m9500-sf1ek9-kickstart-mz.2.1.1.bin
15944704 Apr 06 16:46:04 2005 m9500-sf1ek9-kickstart-mz.2.1.1a.bin
48063243 Mar 21 15:34:46 2005 m9500-sf1ek9-mz.2.1.1.bin
48036239 Apr 06 16:45:41 2005 m9500-sf1ek9-mz.2.1.1a.bin
```

```
Usage for bootflash://sup-local
141066240 bytes used
 43493376 bytes free
184559616 bytes total
```

```
switch# show module
Mod  Ports  Module-Type                      Model                      Status
---  -
4    32     Storage Services Module         DS-X9032-SSM              ok
5    0      Supervisor/Fabric-1             DS-X9530-SF1-K9          active *
6    0      Supervisor/Fabric-1             DS-X9530-SF1-K9          ha-standby
...
```

The **show module** command output shows that the standby supervisor is in slot 6. Use the **attach** command to access the supervisor module.

```
switch# attach module 6
...
switch(standby)# dir bootflash:
 12288 Jan 01 00:01:06 1980 lost+found/
14765056 Mar 21 15:35:06 2005 m9500-sflek9-kickstart-mz.2.1.1.bin
15944704 Apr 06 16:46:04 2005 m9500-sflek9-kickstart-mz.2.1.1a.bin
48063243 Mar 21 15:34:46 2005 m9500-sflek9-mz.2.1.1.bin
48036239 Apr 06 16:45:41 2005 m9500-sflek9-mz.2.1.1a.bin

Usage for bootflash://sup-local
141066240 bytes used
 43493376 bytes free
184559616 bytes total

switch(standby)# exit
switch#
```

The following example shows how to display the available memory for the slot0: devices on the active and standby supervisors.

```
switch# dir slot0:
 12288 Jan 01 00:01:06 1980 lost+found/
14765056 Mar 21 15:35:06 2005 m9500-sflek9-kickstart-mz.2.1.1.bin
15944704 Apr 06 16:46:04 2005 m9500-sflek9-kickstart-mz.2.1.1a.bin
48063243 Mar 21 15:34:46 2005 m9500-sflek9-mz.2.1.1.bin
48036239 Apr 06 16:45:41 2005 m9500-sflek9-mz.2.1.1a.bin

Usage for slot:
141066240 bytes used
 43493376 bytes free
184559616 bytes total
```

```
switch# show module
Mod  Ports  Module-Type                      Model                      Status
---  -
4    32     Storage Services Module         DS-X9032-SSM              ok
5    0      Supervisor/Fabric-1             DS-X9530-SF1-K9          active *
6    0      Supervisor/Fabric-1             DS-X9530-SF1-K9          ha-standby
...
```

The **show module** command output shows that the standby supervisor is in slot 6. Use the **attach** command to access the supervisor module.

```

switch# attach module 6
...
switch(standby)# dir slot0:
 12288 Jan 01 00:01:06 1980 lost+found/
14765056 Mar 21 15:35:06 2005 m9500-sflek9-kickstart-mz.2.1.1.bin
15944704 Apr 06 16:46:04 2005 m9500-sflek9-kickstart-mz.2.1.1a.bin
48063243 Mar 21 15:34:46 2005 m9500-sflek9-mz.2.1.1.bin
48036239 Apr 06 16:45:41 2005 m9500-sflek9-mz.2.1.1a.bin

Usage for slot0:
141066240 bytes used
 43493376 bytes free
184559616 bytes total

switch(standby)# exit
switch#

```

3. If there is not enough space, delete unneeded files.

```
switch# delete bootflash:m9500-sflek9-kickstart-mz.2.1.1.bin
```

The **show module** command output shows that the standby supervisor is in slot 6. Use the **attach** command to access the supervisor module.

```

switch# attach module 6
switch(standby)# delete bootflash:m9500-sflek9-kickstart-mz.2.1.1.bin
switch(standby)# exit
switch#

```

4. Copy the EPLD image file from the FTP server to the bootflash: or slot0: device in the active supervisor module. The following example shows how to copy to bootflash:

```
switch# copy ftp://10.1.7.2/m9000-epld-4.1.1b.img bootflash:m9000-epld-4.1.1b.img
```

Note The system will automatically synchronize the ELPD image to the standby supervisor if automatic copying is enabled.

```

switch# configure terminal
switch(config)# boot auto-copy

```

Using the install ssi Command

You can use the **install ssi** command to update the boot image on an SSM. If the SSM is performing Fibre Channel switching and no Intelligent Storage Services are provisioned on the module, this operation does not disrupt traffic through the module. If the SSM is configured for Intelligent Storage Services, a warning is displayed at the command prompt indicating that the operation will disrupt traffic and asking if you wish to continue.



Note The SSM must be running EPLD version 2.1(2) to use the `install ssi` command. You must install the SSM on a Cisco MDS 9500 Series switch to update the EPLD.

SUMMARY STEPS

1. Log into the switch through the console port, an SSH session, or a Telnet session.
2. Verify that the SSM is physically installed in the switch. If the module is not physically installed, insert it into the desired slot. Issue a `show module` command to verify the status of the module.
3. Verify the Cisco MDS NX-OS release running on the switch and the location and name of the SSI boot image on the switch.
4. Install the SSI image on the SSM.
5. Issue the `show boot` command to display the current contents of the image boot variable for the SSM.
6. Save the new boot variable configuration so the new boot image is used when the switch reboots.
7. Issue the `show module` command to verify the status of the SSM.

DETAILED STEPS

Step 1 Log into the switch through the console port, an SSH session, or a Telnet session.

Step 2 Verify that the SSM is physically installed in the switch. If the module is not physically installed, insert it into the desired slot. Issue a `show module` command to verify the status of the module.

```
switch# show module
Mod  Ports  Module-Type                Model                Status
---  -
4    32     Storage Services Module    DS-X9032-SSM        ok
5     0      Supervisor/Fabric-1        DS-X9530-SF1-K9     active *
6     0      Supervisor/Fabric-1        DS-X9530-SF1-K9     ha-standby
...
```

Note the slot number for later reference.

Step 3 Verify the Cisco MDS NX-OS release running on the switch and the location and name of the SSI boot image on the switch.

Step 4 Install the SSI image on the SSM.

Note If the SSI boot image is located on bootflash: the `install ssi` command copies the SSI boot image to modflash: on the SSM.

```
switch# install ssi modflash://4-1/m9000-ek9-ssi-mz.4.1.1b.bin module 4
```

Note If the SSM is configured for Layer 3 Fibre Channel switching or Intelligent Storage Services, a warning will be displayed at the command prompt indicating that the operation will disrupt traffic and you will be asked if you wish to continue.

Note We recommend that you reference the SSI boot image on modflash: on the SSM. Use the **install ssi modflash://slot-1/filename module alor** command to install the SSI image.

Step 5 Issue the **show boot** command to display the current contents of the image boot variable for the SSM.

```
switch# show boot
sup-1
kickstart variable = bootflash:/boot-2-0-1-9
system variable =
bootflash:/isan-2-0-1-9;bootflash:/isan-2-0-0-181b;bootflash:/isan-2-0-0-181b
sup-2
kickstart variable = bootflash:/boot-2-0-1-9
system variable =
bootflash:/isan-2-0-1-9;bootflash:/isan-2-0-0-181b;bootflash:/isan-2-0-0-181b
Module 4
ssi variable = modflash://4-1/m9000-ek9-ssi-mz.4.1.1b.bin
```

Step 6 Save the new boot variable configuration so the new boot image is used when the switch reboots.

```
switch# copy running-config startup-config
```

Note If you do not save this configuration, it is lost on a switch reboot. In addition, the SSM comes up in Fibre Channel switching mode. You must perform this procedure again to recover the SSI image boot variable configuration.

Step 7 Issue the **show module** command to verify the status of the SSM.

```
switch# show module

Mod  Ports  Module-Type                Model                Status
---  ---  -
4    32    Storage Services Module    DS-X9032-SSM        ok
5    0     Supervisor/Fabric-1        DS-X9530-SF1-K9     active *
6    0     Supervisor/Fabric-1        DS-X9530-SF1-K9     ha-standby

Mod  Sw          Hw          World-Wide-Name(s) (WWN)
---  ---  ---  -
4    2.1(2)     0.30        20:c1:00:05:30:00:06:de to 20:e0:00:05:30:00:06:de
5    2.1(2)     4.0         --
6    2.1(2)     4.0         --

Mod      Application Image Description                Application Image Version
-----  -
4        SSI linecard image                4.1 (1b)

Mod  MAC-Address(es)                Serial-Num
---  -
4    00-05-30-00-9e-b2 to 00-05-30-00-9e-b6    JAB06480590
5    00-0e-38-c6-2c-6c to 00-0e-38-c6-2c-70    JAB082504Mq
6    00-0f-34-94-4d-34 to 00-0f-34-94-4d-38    JAB083407D3

* this terminal session
```

Managing SSMs and Supervisor Modules

This section describes the guidelines for replacing SSMs and supervisor modules and for upgrading and downgrading Cisco MDS NX-OS and SAN-OS releases.

Configuring SSM and MSM Global Upgrade Delay

When there are multiple SSMs or MSMs in the same chassis, you can set the amount of time to delay between upgrading the SSMs or MSMs in a rolling SSI upgrade.

SUMMARY STEPS

1. **configure terminal**
2. **[no] ssm upgrade delay *seconds***
3. (Optional) **copy running-config startup-config**

DETAILED STEPS

	Command or Action	Purpose
Step 1	configure terminal Example: <pre>switch# configure terminal switch(config)#</pre>	Enters global configuration mode.
Step 2	[no] ssm upgrade delay <i>seconds</i> Example: <pre>switch(config)# ssm upgrade delay 30</pre>	Delays the SSI upgrade between SSMs or MSMs by the specified number of seconds. The range is from 1 to 600 seconds. The default is 0 seconds. Use the no form of the command to clear the delay timer.
Step 3	(Optional) copy running-config startup-config Example: <pre>switch(config)# copy running-config startup-config</pre>	Copies the running configuration to the startup configuration.

Guidelines for Replacing SSMs and Supervisor Modules

If you replace an SSM or supervisor module, consider the following guidelines:

- If you replace an SSM with another SSM and the SSM boot image is on bootflash:, you can leave the boot image installed on the active supervisor module.
- If you replace an SSM with another SSM and the SSI boot image is on the modflash:, the SSM might not initialize.
- If you replace an SSM with any other type of module, you can leave the SSM boot image installed on the active supervisor module or remove it. The active supervisor module detects the module type and boots the module appropriately.

- If you replace a supervisor module in a switch with active and standby supervisor modules, no action is required because the boot image is automatically synchronized to the new supervisor module.
- If you replace a supervisor module in a switch with no standby supervisor module, you need to reimplement the configuration on the new supervisor module.

Recovering an SSM After Replacing Corrupted CompactFlash Memory

As of Cisco MDS NX-OS Release 4.1(1a) and SAN-OS Release 2.1(2), you can use the CompactFlash memory (modflash:) on the SSM to store the SSI image. If the modflash: on the SSM is replaced, the SSM might not initialize.

SUMMARY STEPS

1. Log into the switch through the console port, an SSH session, or a Telnet session.
2. Display the values assigned to the SSI image boot variable for each module and note the values for later reference.
3. Clear the values assigned to the SSI image boot variable.
4. Reload the SSM to initialize in Fibre Channel switching mode.
5. After the SSM initializes, upgrade the SSI boot image.
6. Reassign the SSI boot variables cleared in Step 3.

DETAILED STEPS

Step 1 Log into the switch through the console port, an SSH session, or a Telnet session.

Step 2 Display the values assigned to the SSI image boot variable for each module and note the values for later reference.

```
switch# show boot module
Module 2
ssi variable = modflash://2-1/m9000-ek9-ssi-mz.2.1.2.bin
Module 4
ssi variable = modflash://4-1/m9000-ek9-ssi-mz.2.1.2.bin
```

Step 3 Clear the values assigned to the SSI image boot variable.

```
switch# configure terminal
switch(config)# no boot ssi
```

Step 4 Reload the SSM to initialize in Fibre Channel switching mode.

```
switch# reload module 4
reloading module 4 ...
```

Step 5 After the SSM initializes, upgrade the SSI boot image.

Step 6 Reassign the SSI boot variables cleared in Step 3.

```
switch# configure terminal
```



```
switch(config)# boot ssi modflash://2-1/m9000-ek9-ssi-mz.2.1.2.bin module 2
```

Guidelines for Upgrading and Downgrading Cisco MDS NX-OS Releases

Consider the following guidelines when upgrading and downgrading the Cisco MDS NX-OS software on a switch containing an SSM:

- Once you set the SSI image boot variable, you do not need to reset it for upgrades or downgrades to any Cisco MDS NX-OS release that supports boot images. You can use the **install all** command or Fabric Manager GUI to upgrade SSMs once it has been installed.
- If you downgrade to a Cisco MDS NX-OS release that does not support the SSM, you must power down the module. The boot variables for the module are lost.
- The SSM cannot be configured for both the SSI and any other third-party software on the module such as VSFN.

The following example shows successful **install all** command output including an SSI image upgrade.



Note

The SSI boot variable setting is included in the **install all** output. Also, if the SSI boot image is located on bootflash: the **install all** command copies the SSI boot image to the modflash: on the SSMs.

```
Switch# install all system bootflash:isan-2-1-1a kickstart bootflash:boot-2-1-1a
ssi bootflash:ssi-2.1.1a
```

```
Copying image from bootflash:ssi-2.1.1a to modflash://2-1/ssi-2.1.1a.
[#####] 100% -- SUCCESS
```

```
Verifying image bootflash:/ssi-2.1.1a
[#####] 100% -- SUCCESS
```

```
Verifying image bootflash:/boot-2-1-1a
[#####] 100% -- SUCCESS
```

```
Verifying image bootflash:/isan-2-1-1a
[#####] 100% -- SUCCESS
```

```
Extracting "slc" version from image bootflash:/isan-2-1-1a.
[#####] 100% -- SUCCESS
```

```
Extracting "ips4" version from image bootflash:/isan-2-1-1a.
[#####] 100% -- SUCCESS
```

```
Extracting "system" version from image bootflash:/isan-2-1-1a.
[#####] 100% -- SUCCESS
```

```
Extracting "kickstart" version from image bootflash:/boot-2-1-1a.
[#####] 100% -- SUCCESS
```

```
Extracting "loader" version from image bootflash:/boot-2-1-1a.
[#####] 100% -- SUCCESS
```

```
Compatibility check is done:
```

```

Module bootable Impact Install-type Reason
-----
2 yes non-disruptive rolling
3 yes disruptive rolling Hitless upgrade is not supported
4 yes disruptive rolling Hitless upgrade is not supported
5 yes non-disruptive reset

```

Images will be upgraded according to following table:

Module	Image	Running-Version	New-Version	Upg-Required
2	slc	2.0(3)	2.1(1a)	yes
2	bios	v1.1.0(10/24/03)	v1.1.0(10/24/03)	no
3	slc	2.0(3)	2.1(1a)	yes
3	SSI	2.0(3)	2.1(1a)	yes
3	bios	v1.0.8(08/07/03)	v1.1.0(10/24/03)	yes
4	ips4	2.0(3)	2.1(1a)	yes
4	bios	v1.1.0(10/24/03)	v1.1.0(10/24/03)	no
5	system	2.0(3)	2.1(1a)	yes
5	kickstart	2.0(3)	2.1(1a)	yes
5	bios	v1.1.0(10/24/03)	v1.1.0(10/24/03)	no
5	loader	1.2(2)	1.2(2)	no

Do you want to continue with the installation (y/n)? [n] **y**

Install is in progress, please wait.

Module 6:Force downloading.
-- SUCCESS

Syncing image bootflash:/SSI-2.1.1a to standby.
[#####] 100% -- SUCCESS

Syncing image bootflash:/boot-2-1-1a to standby.
[#####] 100% -- SUCCESS

Syncing image bootflash:/isan-2-1-1a to standby.
[#####] 100% -- SUCCESS

Setting boot variables.
[#####] 100% -- SUCCESS

Performing configuration copy.
[#####] 100% -- SUCCESS

Module 3:Upgrading Bios/loader/bootrom.
[#####] 100% -- SUCCESS

Module 6:Waiting for module online.
-- SUCCESS

"Switching over onto standby".

Default Settings

This table lists the default settings for the supervisor module.

Table 34: Default Supervisor Module Settings

Parameter	Default
Administrative connection	Serial connection.
Global switch information	<ul style="list-style-type: none"> • No value for system name. • No value for system contact. • No value for location.
System clock	No value for system clock time.
In-band (VSAN 1) interface	IP address, subnet mask, and broadcast address assigned to the VSAN are set to 0.0.0.0.

This table lists the default settings for the SSM.

Table 35: Default Supervisor Module Settings

Parameter	Default
Initial state when installed	<ul style="list-style-type: none"> • Power-down state on switches with Cisco MDS SAN-OS Release 2.1(1a) and earlier installed. • Fibre Channel switching mode on switches with Cisco MDS SAN-OS Release 2.1(2) and NX-OS Release 4.1(1b), or later installed and SSMs with EPLD version 2.0(2) and later installed.



INDEX

- More-- prompt [59](#)
 - filtering output [59](#)
 - searching output [59](#)

A

- aliases, *See* command aliases
- archive files [103, 104, 105](#)
 - appending files [104](#)
 - creating [103](#)
 - displaying the contents to the screen [105](#)
 - extracting files [105](#)
 - listing archived filenames [105](#)

B

- banners, *See* MOTD banners
- BIOS [64](#)
 - loader> prompt [64](#)
- boot variables [116](#)
 - erasing configuration [116](#)

C

- Call Home [6](#)
 - description [6](#)
- CDP [121, 123, 124, 125](#)
 - clearing cache [124](#)
 - clearing counters [124](#)
 - clearing statistics [124](#)
 - clearing tables [124](#)
 - configuring timers, example [125](#)
 - default settings [125](#)
 - description [121](#)
 - optional parameters [123](#)
 - verifying configuration [124](#)
- characters [41](#)
 - special [41](#)
- Cisco Embedded Event Manager, *See* EEM
- Cisco MDS 9200 Series interfaces modules [177](#)
 - LED description [177](#)
- Cisco MDS 9200 Series supervisor modules [177](#)
 - LED description [177](#)

- Cisco MDS 9200 Series switching modules [177](#)
 - LED description [177](#)
- CLI [37, 38, 44, 60, 61, 62, 64](#)
 - command history [60](#)
 - command modes [38](#)
 - command name completion [44](#)
 - command prompt [37](#)
 - configuring the edit mode [61](#)
 - disabling confirmation prompts [62](#)
 - enabling confirmation prompts [62](#)
 - examples [64](#)
 - setting display colors [62](#)
- CLI history [61](#)
 - controlling command recall [61](#)
- CLI prompt [37](#)
 - description [37](#)
- CLI variables [46, 47, 64, 65](#)
 - characteristics [46](#)
 - description [46](#)
 - examples [64](#)
 - persistent [47](#)
 - referencing [46](#)
 - session-only [47](#)
 - system-defined variables [65](#)
- clock modules [28, 32](#)
 - description [28, 32](#)
 - displaying information [28, 32](#)
- clocks [84, 91, 94](#)
 - default settings [94](#)
 - description [84](#)
 - setting manually [91](#)
- COM1 port [68](#)
 - settings [68](#)
- COM1 ports [71, 75, 80](#)
 - configuring settings [71](#)
 - default settings [80](#)
 - enabling modem connections [75](#)
- command aliases [48, 49, 64](#)
 - characteristics [48](#)
 - defining [49](#)
 - description [48](#)
 - examples [64](#)
 - user session only [49](#)
- command history [60, 61](#)
 - description [60](#)

- command history (*continued*)
 - displaying [61](#)
- command modes [38, 39, 40](#)
 - description [38](#)
 - EXEC [38](#)
 - global configuration [38](#)
 - interface [39](#)
 - restoring [40](#)
 - saving [40](#)
 - subinterface [39](#)
 - summary (table) [40](#)
- command scripts [50, 51, 65](#)
 - delaying command actions [51](#)
 - description [50](#)
 - echoing text to terminals [50](#)
 - examples [65](#)
- commands [43, 45, 60](#)
 - abbreviations [43](#)
 - no form [45](#)
 - recalling [60](#)
- commands scripts [50](#)
 - running [50](#)
- CompactFlash [149](#)
 - running tests [149](#)
- compatibility [5](#)
 - software [5](#)
- configuration [35, 93, 117](#)
 - displaying [35, 93, 117](#)
- configuration files [107, 108, 111, 114, 115, 116, 118](#)
 - copying from remote servers [108](#)
 - copying to external memory [111](#)
 - copying to internal file systems [114](#)
 - description [107](#)
 - erasing [116](#)
 - example backup [118](#)
 - example copy [118](#)
 - example roll back [118](#)
 - rolling back to previous configurations [115](#)
 - types [107](#)
- configuration prompts [62](#)
 - disabling [62](#)
 - enabling [62](#)
- configuring devices [31, 32, 33, 34, 35](#)
 - POAP process [31, 32, 33, 34](#)
 - DHCP phase [33](#)
 - post-installation reload phase [34](#)
 - power up phase [32](#)
 - script execution phase [34](#)
 - using POAP [35](#)
- console ports [67, 69, 75, 80](#)
 - configuring settings [69](#)
 - default settings [80](#)
 - enabling modem connections [75](#)
 - settings [67](#)
- context-sensitive help [52](#)
 - syntax checking [52](#)

D

- daylight savings time, *See* summer time
- default gateway [84](#)
 - description [84](#)
- default settings [80, 94, 125, 143, 165](#)
 - CDP [125](#)
 - clocks [94](#)
 - COM1 ports [80](#)
 - console ports [80](#)
 - modems [80](#)
 - MOTD banners [94](#)
 - NTP [143](#)
 - system hardware [165](#)
 - Telnet servers [94](#)
 - terminals [80](#)
 - virtual terminals [80](#)
- diagnostics., *See* online diagnostics
- diff utility [57](#)
 - description [57](#)
- directories [96, 98, 99](#)
 - changing current directories [99](#)
 - creating [99](#)
 - description [96](#)
 - displaying contents [99](#)
 - displaying current directory [98](#)
 - working with [98](#)
- downgrading [199](#)
 - guidelines [199](#)

E

- EDLD images [183](#)
 - downgrading [183](#)
- EEM [6](#)
 - description [6](#)
- egrep utility [57](#)
 - filtering show command output [57](#)
 - searching show command output [57](#)
- EPLD images [182, 183, 187](#)
 - description [182](#)
 - displaying versions [187](#)
 - upgrading [183](#)
- examples [106, 118](#)
 - accessing directories on standby supervisor modules [106](#)
 - backing up configuration files [118](#)
 - copying configuration files [118](#)
 - rolling back to a previous configuration [118](#)
- EXEC command mode [38](#)
 - description [38](#)

F

- fan modules [162](#)
 - description [162](#)

- file systems [95, 99, 100](#)
 - accessing standby supervisor modules [100](#)
 - changing current directories [99](#)
 - description [95](#)
 - specifying [95](#)
- files [96, 100, 101, 102, 103](#)
 - compressing [102](#)
 - copying [101](#)
 - deleting [101](#)
 - description [96](#)
 - displaying checksums [102](#)
 - displaying contents [101](#)
 - displaying last lines [103](#)
 - finding [103](#)
 - moving [100](#)
 - redirecting command output [103](#)
 - renaming [100](#)
 - tar files [103](#)
 - uncompressing [102](#)
- files systems [98](#)
 - displaying current directory [98](#)
- filtering [55, 57, 58, 59](#)
 - More-- prompt [59](#)
 - diff utility [57](#)
 - egrep utility [57](#)
 - grep utility [57](#)
 - keywords [55](#)
 - less utility [58](#)
 - sed utility [58](#)
 - show command output [55](#)

G

- global configuration command mode [38](#)
 - description [38](#)
- global configuration mode [40](#)
 - summary [40](#)
- grep utility [57](#)
 - searching show command output [57](#)
- grep utility filtering show command output [57](#)
- guidelines and limitations [28](#)
 - POAP [28](#)

H

- hardware [145](#)
 - displaying inventory [145](#)
- high availability [122](#)
 - CDP [122](#)
 - NTP [122](#)
- hostname [83, 85](#)
 - configuring [85](#)
 - description [83](#)

I

- install all command [194](#)
 - SSI boot images [194](#)
- Interface configuration command mode [39](#)
 - description [39](#)
- interface configuration mode [40](#)
 - summary [40](#)

K

- keystrokes [41](#)
 - shortcuts [41](#)

L

- LEDs [177](#)
 - descriptions [177](#)
- less utility [58](#)
 - filtering show command output [58](#)
 - searching show command output [58](#)
- licensing [9](#)
 - support [9](#)
- loader> prompt [64](#)
 - description [64](#)

M

- manageability [6](#)
 - description [6](#)
- management [19](#)
 - configuring in-band management [19](#)
- management interface [86](#)
 - configuring [86](#)
- message-of-the-day banners. *See* MOTD banners
- modems [68, 75, 76, 77, 78, 80](#)
 - configuring connections [75](#)
 - configuring user-specific initialization strings [77](#)
 - default settings [80](#)
 - downloading initialization string [76](#)
 - enabling connections [75](#)
 - initializing connection [78](#)
 - settings [68](#)
- modes. *See* command modes
- module temperature monitoring [159](#)
 - description [159](#)
- modules [63, 116, 159, 167, 168, 169, 170, 171, 172, 173, 174, 175](#)
 - checking states [172](#)
 - connecting to with CLI [172](#)
 - description [167](#)
 - monitoring temperatures [159](#)
 - power cycling [173](#)
 - purging configurations [175](#)
 - reloading [173](#)
 - removing configuration after removal [116](#)

modules (*continued*)

- saving configurations 174
- sending commands from the supervisor module session 63
- services modules 170
- supervisor modules 168
- switching modules 169
- verifying status 171

MOTD banner 88

- configuring 88

MOTD banners 84, 94

- default settings 94
- description 84

MSMs 197

- configuring global delay timers 197

N

NTP 7, 122, 127, 128, 129, 135, 138, 141, 143

- clearing a session 138
- clearing statistics 135, 138
- configuring a server, example 141
- default settings 143
- description 7, 127
- displaying statistics 135
- guidelines 129
- high availability 122
- limitations 129
- prerequisites 128
- verifying configuration 138

NTP configuration distribution 136

- enabling 136

NTP configuration distribution 137, 138

- committing changes 137
- discarding changes 137
- releasing the fabric session lock 138

O

online diagnostics 6

- description 6

P

POAP 28, 31, 33, 34, 35

- DHCP discovery phase 33
- guidelines and limitations 28
- post-installation reload phase 34
- process 31
- using to configure a switch 35

power 150

- displaying usage information 150

power cycling 173

- modules 173

Power On Auto Provisioning 32

- power up phase 32

Power On Auto Provisioning (*continued*)

- provisioning devices 32

POAP process 32

- power up phase 32

power supply mode 151

- description 151

power supply modes 151, 159

- configuration guidelines 151
- configuring 159

PowerOn Auto Provisioning 33, 34

- script execution phase 34

privileged EXEC mode 40

- summary 40

prompts, *See* confirmation prompts

provisioning devices 31, 33, 34

- POAP process 31, 33, 34

DHCP phase 33

post-installation reload phase 34

- script execution phase 34

Q

QoS 9

- description 9

Quality of Service, *See* QoS

R

RBAC 6

- description 6

regular expressions 53, 54

- anchoring 54
- filtering CLI output 53
- multiple-character patterns 54
- special characters 53

role-based access control, *See* RBAC

running configuration 35, 93, 117

- displaying 35, 93, 117

running configurations 108, 109, 112, 114, 115, 116, 118

- copying from external memory devices 112

copying to internal file systems 114

downloading from remote servers 109

example backup 118

example copy 118

example roll back 118

removing configuration for missing modules 116

rolling back to previous configurations 115

saving to startup configurations 108

S

scripts, *See* command scripts

searching 55, 57, 58, 59

- More-- prompt 59

diff utility 57

- searching (*continued*)
 - egrep utility [57](#)
 - grep utility [57](#)
 - keywords [55](#)
 - less utility [58](#)
 - sed utility [58](#)
 - show command output [55](#)
 - sed utility [58](#)
 - filtering show command output [58](#)
 - searching show command output [58](#)
 - serial number [149](#)
 - displaying [149](#)
 - serviceability [5](#)
 - description [5](#)
 - services modules [170](#)
 - description [170](#)
 - setup utility [11, 13](#)
 - description [11](#)
 - prerequisites [13](#)
 - shortcuts [41](#)
 - keystrokes [41](#)
 - show commands [55](#)
 - filtering output [55](#)
 - searching output [55](#)
 - Simple Network Management Protocol. , *See* SNMP
 - SNMP [6](#)
 - description [6](#)
 - software compatibility [5](#)
 - description [5](#)
 - sort utility [58](#)
 - description [58](#)
 - SPAN [6](#)
 - description [6](#)
 - special characters [41](#)
 - description [41](#)
 - sscp [55, 59, 66](#)
 - example [66](#)
 - redirecting show command output [55, 59](#)
 - SSI boot images [188, 190, 191, 194](#)
 - description [188](#)
 - downgrading [190](#)
 - installing [188](#)
 - upgrading [190](#)
 - Using install all command [194](#)
 - verifying [191](#)
 - SSMs [197, 198, 201](#)
 - configuring global delay timers [197](#)
 - default settings [201](#)
 - downgrading software, guidelines [197](#)
 - recovering after replacing corrupted Compact Flash [198](#)
 - replacing, guidelines [197](#)
 - replacing, guidelines [197](#)
 - upgrading software, guidelines [197](#)
 - standby supervisor modules [100, 106](#)
 - accessing directories, examples [106](#)
 - accessing file systems [100](#)
 - startup configuration [35, 93, 116, 117](#)
 - displaying [35, 93, 117](#)
 - erasing [116](#)
 - startup configurations [108, 110, 113, 114, 115, 118](#)
 - copying from external memory devices [113](#)
 - copying from running configurations [108](#)
 - copying to internal file systems [114](#)
 - downloading from remote servers [110](#)
 - example backup [118](#)
 - example copy [118](#)
 - example roll back [118](#)
 - rolling back to previous configurations [115](#)
 - storage [97](#)
 - device operation [97](#)
 - streaming secure copy, *See* sscp
 - subinterface configuration command mode [39](#)
 - description [39](#)
 - subinterface configuration mode [40](#)
 - summary [40](#)
 - summer time [85, 90](#)
 - configuring [90](#)
 - description [85](#)
 - supervisor modules [168, 197, 201](#)
 - default settings [201](#)
 - description [168](#)
 - downgrading, guidelines [197](#)
 - replacing, guidelines [197](#)
 - upgrading, guidelines [197](#)
 - Switched Port Analyzer. , *See* SPAN
 - switches [173](#)
 - reloading [173](#)
 - switching module [174](#)
 - reloading [174](#)
 - switching modules [169, 176](#)
 - description [169](#)
 - powering off [176](#)
 - switchname [83, 85](#)
 - configuring [85](#)
 - syntax checking, *See* context-sensitive help
 - system hardware [165](#)
 - default settings [165](#)
- ## T
- Telnet servers [85, 93, 94](#)
 - connections [85](#)
 - default settings [94](#)
 - disabling connection [93](#)
 - enabling connection [93](#)
 - terminal sessions [67, 79](#)
 - clearing [79](#)
 - displaying information [79](#)
 - settings [67](#)
 - terminals [80](#)
 - default settings [80](#)

time zones [85, 89](#)
 configuring [89](#)
 description [85](#)

U

upgrading [199](#)
 guidelines [199](#)
user sessions [85, 92](#)
 description [85](#)
 sending messages [92](#)
users [92](#)
 managing [92](#)

users sessions [92](#)
 displaying information [92](#)

V

variables, *See* CLI variables
virtual terminals [68, 72, 74, 80](#)
 configuring [72](#)
 configuring session limits [74](#)
 default settings [80](#)
 settings [68](#)