



***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***



## **Cisco Nexus 1000V Security Configuration Guide, Release 4.2(1)SV1(5.1)**

April 12, 2013

### **Americas Headquarters**

Cisco Systems, Inc.  
170 West Tasman Drive  
San Jose, CA 95134-1706  
USA  
<http://www.cisco.com>  
Tel: 408 526-4000  
800 553-NETS (6387)  
Fax: 408 527-0883

Text Part Number: OL-25384-01

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: [www.cisco.com/go/trademarks](http://www.cisco.com/go/trademarks). Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1110R)

Any Internet Protocol (IP) addresses used in this document are not intended to be actual addresses. Any examples, command display output, and figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses in illustrative content is unintentional and coincidental.

*Cisco Nexus 1000V Security Configuration Guide, Release 4.2(1)SV1(5.1)*  
© 2009-2012 Cisco Systems, Inc. All rights reserved.



## CONTENTS

### **New and Changed Information** xv

#### **Preface** xvii

Audience xvii

Document Organization xvii

Document Conventions xviii

Related Documentation xix

xx

Obtaining Documentation and Submitting a Service Request xx

xx

### **Security Overview** 1-1

User Accounts 1-1

Virtual Service Domain 1-1

Authentication, Authorization, and Accounting (AAA) 1-2

RADIUS Security Protocol 1-2

TACACS+ Security Protocol 1-2

SSH 1-3

Telnet 1-3

Access Control Lists (ACLs) 1-3

Port Security 1-3

DHCP Snooping 1-3

Dynamic ARP Inspection 1-4

IP Source Guard 1-4

### **Managing User Accounts** 2-1

Information About User Accounts 2-1

Role 2-1

User Name 2-3

Password 2-3

Check of Password Strength 2-3

Expiration Date 2-4

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

Guidelines and Limitations	2-4
Default Settings	2-4
Configuring User Access	2-4
Enabling the Check of Password Strength	2-5
Disabling the Check of Password Strength	2-6
Creating a User Account	2-6
Creating a Role	2-8
Creating a Feature Group	2-10
Configuring Interface Access	2-12
Configuring VLAN Access	2-13
Verifying the User Access Configuration	2-15
Example Configuration	2-15
Additional References	2-16
Related Documents	2-16
Standards	2-16
MIBs	2-16
Feature History for User Accounts	2-16
<b>Configuring VSD</b>	<b>3-1</b>
Information About Virtual Service Domain	3-1
Service Virtual Machine	3-1
Port Profiles	3-2
Guidelines and Limitations	3-3
Default Settings	3-3
Configuring VSD	3-4
Configuring an Inside or Outside VSD Port Profile	3-4
Configuring a Member VSD Port Profile	3-7
Verifying the Configuration	3-8
Configuration Example	3-10
Additional References	3-10
Related Documents	3-11
Standards	3-11
Feature History	3-11
<b>Configuring AAA</b>	<b>4-1</b>
Information About AAA	4-1

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

AAA Security Services	4-1
Authentication	4-2
Authorization	4-3
Accounting	4-3
AAA Server Groups	4-4
Prerequisites for AAA	4-4
AAA Guidelines and Limitations	4-4
Default Settings	4-4
Configuring AAA	4-4
Configuring a Login Authentication Method	4-6
Enabling Login Authentication Failure Messages	4-7
Verifying AAA Configuration	4-8
Example AAA Configuration	4-9
Additional References	4-9
Related Documents	4-9
Standards	4-9
Feature History for AAA	4-10
<b>Configuring RADIUS</b>	<b>5-1</b>
Information About RADIUS	5-1
RADIUS Network Environments	5-1
RADIUS Operation	5-2
RADIUS Server Monitoring	5-2
Vendor-Specific Attributes	5-3
Prerequisites for RADIUS	5-4
Guidelines and Limitations	5-4
Default Settings	5-5
Configuring RADIUS Servers	5-5
Configuring RADIUS Server Hosts	5-6
Configuring the Global RADIUS Key	5-7
Configuring a RADIUS Server Key	5-8
Configuring RADIUS Server Groups	5-9
Enabling RADIUS Server Directed Requests	5-10
Setting the Global Timeout for All RADIUS Servers	5-12
Configuring a Global Retry Count for All RADIUS Servers	5-13
Setting the Timeout Interval for a Single RADIUS Server	5-14
Configuring Retries for a Single RADIUS Server	5-15

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

Configuring a RADIUS Accounting Server	5-16
Configuring a RADIUS Authentication Server	5-17
Configuring Periodic RADIUS Server Monitoring	5-18
Configuring the Global Dead-Time Interval	5-20
Manually Monitoring RADIUS Servers or Groups	5-21
Verifying RADIUS Configuration	5-22
Displaying RADIUS Server Statistics	5-22
Example RADIUS Configuration	5-22
Additional References	5-22
Related Documents	5-22
Standards	5-23
Feature History for RADIUS	5-23
<b>Configuring TACACS+</b>	<b>6-1</b>
Information About TACACS+	6-1
TACACS+ Operation for User Login	6-2
Default TACACS+ Server Encryption Type and Preshared Key	6-2
TACACS+ Server Monitoring	6-3
Vendor-Specific Attributes	6-3
Cisco VSA Format	6-3
Prerequisites for TACACS+	6-4
Guidelines and Limitations	6-4
Default Settings	6-4
Configuring TACACS+	6-5
Enabling or Disabling TACACS+	6-8
Configuring Shared Keys	6-9
Configuring a TACACS+ Server Host	6-11
Configuring a TACACS+ Server Group	6-12
Enabling TACACS+ Server Directed Requests	6-15
Setting the TACACS+ Global Timeout Interval	6-16
Setting a Timeout Interval for an Individual TACACS+ Host	6-17
Configuring the TCP Port for a TACACS+ Host	6-18
Configuring Monitoring for a TACACS+ Host	6-20
Configuring the TACACS+ Global Dead-Time Interval	6-21
Displaying Statistics for a TACACS+ Host	6-22
Example TACACS+ Configuration	6-23

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

Feature History for TACACS+	6-23
Additional References	6-24
Related Documents	6-24
Standards	6-24
<b>Configuring SSH</b>	<b>7-1</b>
Information About SSH	7-1
SSH Server	7-1
SSH Client	7-2
SSH Server Keys	7-2
Prerequisites for SSH	7-2
Guidelines and Limitations	7-2
Default Settings	7-3
Configuring SSH	7-3
Generating SSH Server Keys	7-3
Configuring a User Account with a Public Key	7-5
Configuring an OpenSSH Key	7-5
Configuring IETF or PEM Keys	7-7
Starting SSH Sessions	7-8
Clearing SSH Hosts	7-9
Disabling the SSH Server	7-9
Deleting SSH Server Keys	7-10
Clearing SSH Sessions	7-12
Verifying the SSH Configuration	7-13
SSH Example Configuration	7-14
Additional References	7-15
Related Documents	7-15
Standards	7-15
Feature History for SSH	7-15
<b>Configuring Telnet</b>	<b>8-1</b>
Information About the Telnet Server	8-1
Prerequisites for Telnet	8-1
Guidelines and Limitations	8-2
Default Setting	8-2
Configuring Telnet	8-2

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

Enabling the Telnet Server	8-2
Starting an IP Telnet Session to a Remote Device	8-3
Clearing Telnet Sessions	8-4
Verifying the Telnet Configuration	8-5
Additional References	8-5
Related Documents	8-5
Standards	8-6
Feature History for Telnet	8-6
<b>Configuring an IP ACL</b>	<b>9-1</b>
Information About ACLs	9-1
ACL Types and Applications	9-2
Order of ACL Application	9-2
About Rules	9-2
Source and Destination	9-2
Protocols	9-3
Implicit Rules	9-3
Additional Filtering Options	9-3
Sequence Numbers	9-4
Statistics	9-4
ACL Logging	9-5
ACL Flows	9-5
Syslog Messages	9-6
Prerequisites for IP ACLs	9-7
Guidelines and Limitations	9-7
Default Settings	9-7
Configuring IP ACLs	9-7
Creating an IP ACL	9-8
Changing an IP ACL	9-9
Removing an IP ACL	9-11
Changing Sequence Numbers in an IP ACL	9-12
Applying an IP ACL as a Port ACL	9-13
Adding an IP ACL to a Port Profile	9-14
Applying an IP ACL to the Management Interface	9-15
Configuring ACL Logging	9-16
Disabling ACL Logging	9-16
Configuring a Time Interval for Accumulating Packet Counters	9-17



***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

Configuring Flows	9-17
Configuring Syslog Server Severity Levels	9-19
Verifying the IP ACL Configuration	9-20
Monitoring IP ACL	9-20
Example Configurations for IP ACL	9-21
Additional References	9-21
Related Documents	9-22
Standards	9-22
Feature History for IP ACL	9-22
<b>Configuring a MAC ACL</b>	<b>10-1</b>
Information About MAC ACLs	10-1
Prerequisites for MAC ACLs	10-1
Guidelines and Limitations	10-2
Default Settings	10-2
Configuring MAC ACLs	10-2
Creating a MAC ACL	10-2
Changing a MAC ACL	10-4
Removing a MAC ACL	10-5
Changing Sequence Numbers in a MAC ACL	10-6
Applying a MAC ACL as a Port ACL	10-7
Adding a MAC ACL to a Port Profile	10-8
Verifying MAC ACL Configurations	10-9
Monitoring MAC ACLs	10-10
Example Configurations for MAC ACLs	10-11
Additional References	10-11
Related Documents	10-12
Standards	10-12
Feature History for MAC ACL	10-12
<b>Configuring Port Security</b>	<b>11-1</b>
Information About Port Security	11-1
Secure MAC Address Learning	11-1
Static Method	11-2
Dynamic Method	11-2
Sticky Method	11-2

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

Dynamic Address Aging	11-2
Secure MAC Address Maximums	11-3
Interface Secure MAC Addresses	11-3
Security Violations and Actions	11-4
Port Security and Port Types	11-5
Result of Changing an Access Port to a Trunk Port	11-5
Result of Changing a Trunk Port to an Access Port	11-5
Guidelines and Limitations	11-5
Default Settings	11-6
Configuring Port Security	11-6
Enabling or Disabling Port Security on a Layer 2 Interface	11-7
Enabling or Disabling Sticky MAC Address Learning	11-8
Adding a Static Secure MAC Address on an Interface	11-9
Removing a Static or a Sticky Secure MAC Address from an Interface	11-10
Removing a Dynamic Secure MAC Address	11-11
Configuring a Maximum Number of MAC Addresses	11-12
Configuring an Address Aging Type and Time	11-14
Configuring a Security Violation Action	11-15
Recovering Ports Disabled for Port Security Violations	11-17
Verifying the Port Security Configuration	11-18
Displaying Secure MAC Addresses	11-18
Example Configuration for Port Security	11-18
Additional References	11-19
Related Documents	11-19
Standards	11-19
Feature History for Port Security	11-19
<b>Configuring DHCP Snooping</b>	<b>12-1</b>
Information About DHCP Snooping	12-1
Overview	12-1
Trusted and Untrusted Sources	12-2
DHCP Snooping Binding Database	12-2
Relay Agent Information Option	12-3
High Availability	12-3
Prerequisites for DHCP Snooping	12-3
Guidelines and Limitations	12-4
Default Settings	12-4

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

Configuring DHCP Snooping	12-4
Minimum DHCP Snooping Configuration	12-5
Enabling or Disabling the DHCP Feature	12-5
Enabling or Disabling DHCP Snooping Globally	12-6
Enabling or Disabling DHCP Snooping on a VLAN	12-7
Enabling or Disabling DHCP Snooping MAC Address Verification	12-8
Configuring an Interface as Trusted or Untrusted	12-9
Configuring the Rate Limit for DHCP Packets	12-10
Detecting Ports Disabled for DHCP Rate Limit Violation	12-11
Recovering Ports Disabled for DHCP Rate Limit Violations	12-12
Clearing the DHCP Snooping Binding Database	12-13
Clearing All Binding Entries	12-13
Clearing Binding Entries for an Interface	12-14
Relaying Switch and Circuit Information in DHCP	12-15
Verifying the DHCP Snooping Configuration	12-16
Monitoring DHCP Snooping	12-16
Example Configuration for DHCP Snooping	12-16
Additional References	12-17
Related Documents	12-17
Standards	12-17
Feature History for DHCP Snooping	12-17
<b>Configuring Dynamic ARP Inspection</b>	<b>13-1</b>
Information About DAI	13-1
About ARP	13-1
About ARP Spoofing Attacks	13-2
About DAI and ARP Spoofing	13-2
Interface Trust and Network Security	13-3
Prerequisites for DAI	13-4
Guidelines and Limitations	13-4
Default Settings	13-5
Configuring DAI	13-5
Configuring a VLAN for DAI	13-6
Configuring a Trusted vEthernet Interface	13-6
Resetting a vEthernet Interface to Untrusted	13-8
Configuring DAI Rate Limits	13-9
Resetting DAI Rate Limits to Default Values	13-11

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

Detecting and Recovering Error-Disabled Interfaces	13-12
Validating ARP Packets	13-13
Verifying the DAI Configuration	13-14
Monitoring DAI	13-15
Example DAI Configuration	13-15
Additional References	13-17
Related Documents	13-17
Standards	13-17
Feature History for DAI	13-18
<b>Configuring IP Source Guard</b>	<b>14-1</b>
Information About IP Source Guard	14-1
Prerequisites for IP Source Guard	14-2
Guidelines and Limitations	14-2
Default Settings	14-2
Configuring IP Source Guard	14-2
Enabling or Disabling IP Source Guard on a Layer 2 Interface	14-3
Adding or Removing a Static IP Source Entry	14-4
Verifying the IP Source Guard Configuration	14-5
Displaying IP Source Guard Bindings	14-5
Example Configuration for IP Source Guard	14-5
Additional References	14-5
Related Documents	14-5
Standards	14-6
Feature History for IP Source Guard	14-6
<b>Disabling HTTP Server</b>	<b>15-1</b>
Information About the HTTP Server	15-1
Guidelines and Limitations	15-1
Default Setting	15-2
Disabling HTTP Server	15-2
Verifying the HTTP Configuration	15-3
Additional References	15-3
Related Documents	15-4
Standards	15-4

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

Feature History for Disabling the HTTP Server 15-4

**Blocking Unknown Unicast Flooding 16-1**

Information About UUFB 16-1

Guidelines and Limitations 16-1

Default Settings 16-2

Configuring UUFB 16-2

    Blocking Unknown Unicast Flooding Globally on the Switch 16-2

    Configuring an Interface to Allow Unknown Unicast Flooding 16-3

    Configuring a Port Profile to Allow Unknown Unicast Flooding 16-5

Verifying the UUFB Configuration 16-6

UUFB Example Configurations 16-7

Additional References 16-8

    Related Documents 16-8

    Standards 16-8

Feature History for UUFB 16-8

**Security Configuration Limits 17-1**

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***



## New and Changed Information

This chapter lists the information that is new or was changed in this document per release, and where it is located.

Feature	Description	Changed in release	Where Documented
ACL Logging	You can log statistics for flows that match the ACL permit or deny conditions to monitor the flows.	4.2(1)SV1 (5.1)	<a href="#">Chapter 9, “Configuring an IP ACL”</a>
UUFB	You can block unknown unicast packets from flooding the forwarding path.	4.2(1)SV1(4a)	<a href="#">Chapter 16, “Blocking Unknown Unicast Flooding”</a>
DHCP Snooping Relay Agent (Option 82)	You can configure DHCP to relay VSM MAC and port information in DHCP packets.	4.2(1)SV1(4)	<a href="#">Chapter 12, “Configuring DHCP Snooping”</a>
DHCP Snooping binding table	You can clear DHCP snooping binding table entries for an interface.	4.2(1)SV1(4)	<a href="#">Chapter 12, “Configuring DHCP Snooping”</a>
Enable DHCP	You can enable or disable DHCP globally using the <b>feature DHCP</b> command.	4.2(1)SV1(4)	<a href="#">Chapter 12, “Configuring DHCP Snooping”</a>
Enable SSH server	You can enable or disable the SSH server using the <b>feature DHCP</b> command.	4.2(1)SV1(4)	<a href="#">Chapter 7, “Configuring SSH”</a>
Enable Telnet server	You can enable or disable the Telnet server using the <b>feature DHCP</b> command.	4.2(1)SV1(4)	<a href="#">Chapter 8, “Configuring Telnet”</a>
Disable HTTP Server	Disabling the HTTP server for security purposes.	4.2(1)SV1(4)	<a href="#">Chapter 15, “Disabling HTTP Server”</a>
VSD	Virtual service domains (VSDs) allow you to classify and separate traffic for network services.	4.0(4)SV1(2)	<a href="#">Chapter 3, “Configuring VSD”</a>
DHCP Snooping	Dynamic Host Configuration Protocol (DHCP) snooping acts like a firewall between untrusted hosts and trusted DHCP servers.	4.0(4)SV1(2)	<a href="#">Chapter 12, “Configuring DHCP Snooping”</a>

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

<b>Feature</b>	<b>Description</b>	<b>Changed in release</b>	<b>Where Documented</b>
Dynamic ARP Inspection (DAI)	Dynamic ARP inspection (DAI) provides IP communication within a Layer 2 broadcast domain by mapping an IP address to a MAC address.	4.0(4)SV1(2)	<a href="#">Chapter 13, “Configuring Dynamic ARP Inspection”</a>
IP Source Guard	IP Source Guard is a per-interface traffic permit filter for IP and MAC addresses.	4.0(4)SV1(2)	<a href="#">Chapter 14, “Configuring IP Source Guard”</a>





## Preface

---

The Security Configuration document provides procedures for configuring security features, such as AAA, VSD, SSH, and so forth.

This preface describes the following aspects of this document:

- [Audience, page xvii](#)
- [Document Organization, page xvii](#)
- [Document Conventions, page xviii](#)
- [Obtaining Documentation and Submitting a Service Request, page xx](#)
- [Obtaining Documentation and Submitting a Service Request, page xx](#)

## Audience

This guide is for experienced network system users.

## Document Organization

This document is organized into the following chapters:

Chapter and Title	Description
<a href="#">Chapter 1, “Security Overview”</a>	Describes the security features.
<a href="#">Chapter 2, “Managing User Accounts”</a>	Describes how to configure user accounts.
<a href="#">Chapter 3, “Configuring VSD”</a>	Describes how to configure VSD.
<a href="#">Chapter 4, “Configuring AAA”</a>	Describes how to configure AAA.
<a href="#">Chapter 5, “Configuring RADIUS”</a>	Describes how to configure RADIUS.
<a href="#">Chapter 6, “Configuring TACACS+”</a>	Describes how to configure TACACS+.
<a href="#">Chapter 7, “Configuring SSH”</a>	Describes how to configure SSH.
<a href="#">Chapter 8, “Configuring Telnet”</a>	Describes how to configure Telnet.
<a href="#">Chapter 9, “Configuring an IP ACL”</a>	Describes how to configure IP access control lists (ACLs) for filtering traffic.

**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**

Chapter and Title	Description
<a href="#">Chapter 10, “Configuring a MAC ACL”</a>	Describes how to configure MAC access control lists (ACLs) for filtering traffic.
<a href="#">Chapter 11, “Configuring Port Security”</a>	Describes how to configure port security.
<a href="#">Chapter 12, “Configuring DHCP Snooping”</a>	Describes how to configure DHCP snooping.
<a href="#">Chapter 13, “Configuring Dynamic ARP Inspection”</a>	Describes how to configure Dynamic ARP Inspection.
<a href="#">Chapter 14, “Configuring IP Source Guard”</a>	Describes how to configure IP Source Guard.
<a href="#">Chapter 15, “Disabling HTTP Server”</a>	Describes how to disable HTTP server.
<a href="#">Chapter 16, “Blocking Unknown Unicast Flooding”</a>	Describes how to block unknown unicast packet flooding (UUF) in the forwarding path.
<a href="#">Chapter 17, “Security Configuration Limits”</a>	Describes configuration limits for security features.

## Document Conventions

Command descriptions use these conventions:

<b>boldface font</b>	Commands and keywords are in boldface.
<i>italic font</i>	Arguments for which you supply values are in italics.
{ }	Elements in braces are required choices.
[ ]	Elements in square brackets are optional.
x   y   z	Alternative, mutually exclusive elements are separated by vertical bars.
string	A nonquoted set of characters. Do not use quotation marks around the string or the string will include the quotation marks.

Screen examples use these conventions:

<code>screen font</code>	Terminal sessions and information the device displays are in screen font.
<b><code>boldface screen font</code></b>	Information you must enter is in boldface screen font.
<i><code>italic screen font</code></i>	Arguments for which you supply values are in italic screen font.
< >	Nonprinting characters, such as passwords, are in angle brackets.
[ ]	Default responses to system prompts are in square brackets.
!, #	An exclamation point (!) or a pound sign (#) at the beginning of a line of code indicates a comment line.

This document uses the following conventions for notes and cautions:



### Note

Means reader *take note*. Notes contain helpful suggestions or references to material not covered in the manual.

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

**Caution**

Means *reader be careful*. In this situation, you might do something that could result in equipment damage or loss of data.

## Related Documentation

This section lists the documents used with the Cisco Nexus 1000 and available on [Cisco.com](http://www.cisco.com) at the following URL:

[http://www.cisco.com/en/US/products/ps9902/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/ps9902/tsd_products_support_series_home.html)

### General Information

*Cisco Nexus 1000V Documentation Roadmap, Release 4.2(1)SVI(5.1)*

*Cisco Nexus 1000V Release Notes, Release 4.2(1)SVI(5.1)*

*Cisco Nexus 1000V Compatibility Information, Release 4.2(1)SVI(5.1)*

*Cisco Nexus 1010 Management Software Release Notes, Release 4.2(1)SP1(3)*

### Install and Upgrade

*Cisco Nexus 1000V Installation and Upgrade Guide, Release 4.2(1)SVI(5.1)*

*Cisco Nexus 1010 Virtual Services Appliance Hardware Installation Guide*

*Cisco Nexus 1010 Software Installation and Upgrade Guide, Release 4.2(1)SP1(3)*

### Configuration Guides

*Cisco Nexus 1000V High Availability and Redundancy Configuration Guide, Release 4.2(1)SVI(5.1)*

*Cisco Nexus 1000V Interface Configuration Guide, Release 4.2(1)SVI(5.1)*

*Cisco Nexus 1000V Layer 2 Switching Configuration Guide, Release 4.2(1)SVI(5.1)*

*Cisco Nexus 1000V License Configuration Guide, Release 4.2(1)SVI(5.1)*

*Cisco Nexus 1000V Network Segmentation Manager Configuration Guide, Release 4.2(1)SVI(5.1)*

*Cisco Nexus 1000V Port Profile Configuration Guide, Release 4.2(1)SVI(5.1)*

*Cisco Nexus 1000V Quality of Service Configuration Guide, Release 4.2(1)SVI(5.1)*

*Cisco Nexus 1000V Security Configuration Guide, Release 4.2(1)SVI(5.1)*

*Cisco Nexus 1000V System Management Configuration Guide, Release 4.2(1)SVI(5.1)*

*Cisco Nexus 1000V VXLAN Configuration Guide, Release 4.2(1)SVI(5.1)*

*Cisco Nexus 1010 Software Configuration Guide, Release 4.2(1)SP1(3)*

### Programming Guide

*Cisco Nexus 1000V XML API User Guide, Release 4.2(1)SVI(5.1)*

### Reference Guides

*Cisco Nexus 1000V Command Reference, Release 4.2(1)SVI(5.1)*

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

*Cisco Nexus 1000V MIB Quick Reference*

*Cisco Nexus 1010 Command Reference, Release 4.2(1)SP1(3)*

### **Troubleshooting and Alerts**

*Cisco Nexus 1000V Troubleshooting Guide, Release 4.2(1)SV1(5.1)*

*Cisco Nexus 1000V Password Recovery Guide*

*Cisco NX-OS System Messages Reference*

### **Virtual Security Gateway Documentation**

*Cisco Virtual Security Gateway for Nexus 1000V Series Switch*

### **Virtual Network Management Center**

*Cisco Virtual Network Management Center*

### **Virtual Wide Area Application Services (vWAAS)**

*Cisco Virtual Wide Area Application Services (vWAAS)*

### **Network Analysis Module Documentation**

*Cisco Prime Network Analysis Module Software Documentation Guide, 5.1*

*Cisco Prime Network Analysis Module (NAM) for Nexus 1010 Installation and Configuration Guide, 5.1*

*Cisco Prime Network Analysis Module Command Reference Guide 5.1*

*Cisco Prime Network Analysis Module Software 5.1 Release Notes*

*Cisco Prime Network Analysis Module Software 5.1 User Guide*

## **Obtaining Documentation and Submitting a Service Request**

For information on obtaining documentation, submitting a service request, and gathering additional information, see the monthly *What's New in Cisco Product Documentation*, which also lists all new and revised Cisco technical documentation, at:

<http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html>

Subscribe to the *What's New in Cisco Product Documentation* as a Really Simple Syndication (RSS) feed and set content to be delivered directly to your desktop using a reader application. The RSS feeds are a free service and Cisco currently supports RSS Version 2.0.



# CHAPTER 1

## Security Overview

---

This chapter provides an overview of the following security features used with the Cisco Nexus 1000V:

- [User Accounts](#), page 1-1
- [Virtual Service Domain](#), page 1-1
- [Authentication, Authorization, and Accounting \(AAA\)](#), page 1-2
- [RADIUS Security Protocol](#), page 1-2
- [TACACS+ Security Protocol](#), page 1-2
- [SSH](#), page 1-3
- [Telnet](#), page 1-3
- [Access Control Lists \(ACLs\)](#), page 1-3
- [Port Security](#), page 1-3
- [DHCP Snooping](#), page 1-3
- [Dynamic ARP Inspection](#), page 1-4
- [IP Source Guard](#), page 1-4

## User Accounts

Access to the Cisco Nexus 1000V is accomplished by setting up user accounts that define the specific actions permitted by each user. You can create up to 256 user accounts. For each user account, you define a role, user name, password, and expiration date. For information about configuring and managing user accounts, see [Chapter 2, “Managing User Accounts.”](#)

## Virtual Service Domain

A virtual service domain (VSD) allows you to classify and separate traffic for network services, such as firewalls, traffic monitoring, and those in support of compliance goals such as Sarbanes Oxley. For information about configuring and managing VSD, see [Chapter 3, “Configuring VSD.”](#)

*Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).*

## Authentication, Authorization, and Accounting (AAA)

AAA, called Triple A, is an architectural framework for configuring a set of three independent, consistent, and modular security functions.

- **Authentication**—Provides the method of identifying users, including login and password dialog, challenge and response, messaging support, and, depending on the security protocol that you select, encryption. Authentication is the way a user is identified prior to being allowed access to the network and network services. You configure AAA authentication by defining a named list of authentication methods and then applying that list to various interfaces.
- **Authorization**—Provides the method for remote access control, including one-time authorization or authorization for each service, per-user account list and profile, user group support, and support of IP, IPX, ARA, and Telnet.

Remote security servers, such as RADIUS and TACACS+, authorize users for specific rights by associating attribute-value (AV) pairs, which define those rights, with the appropriate user. AAA authorization works by assembling a set of attributes that describe what the user is authorized to perform. These attributes are compared with the information contained in a database for a given user, and the result is returned to AAA to determine the user's actual capabilities and restrictions.

- **Accounting**—Provides the method for collecting and sending security server information used for billing, auditing, and reporting, such as user identities, start and stop times, executed commands (such as PPP), number of packets, and number of bytes. Accounting enables you to track the services that users are accessing, as well as the amount of network resources that they are consuming.



### Note

You can configure authentication outside of AAA. However, you must configure AAA if you want to use RADIUS or TACACS+, or if you want to configure a backup authentication method.

For information about configuring AAA, see [Chapter 4, “Configuring AAA.”](#)

## RADIUS Security Protocol

AAA establishes communication between your network access server and your RADIUS security server.

RADIUS is a distributed client/server system implemented through AAA that secures networks against unauthorized access. In the Cisco implementation, RADIUS clients run on Cisco routers and send authentication requests to a central RADIUS server that contains all user authentication and network service access information.

For information about configuring RADIUS, see [Chapter 5, “Configuring RADIUS.”](#)

## TACACS+ Security Protocol

AAA establishes communication between your network access server and your TACACS+ security server.

TACACS+ is a security application implemented through AAA that provides a centralized validation of users who are attempting to gain access to a router or network access server. TACACS+ services are maintained in a database on a TACACS+ daemon that usually runs on a UNIX or Windows NT workstation. TACACS+ provides separate and modular authentication, authorization, and accounting facilities.

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

For information about configuring TACACS+, see [Chapter 6, “Configuring TACACS+.”](#)

## SSH

You can use the Secure Shell (SSH) server to enable an SSH client to make a secure, encrypted connection to a device. SSH uses strong encryption for authentication. The SSH server can operate with publicly and commercially available SSH clients.

The SSH client works with publicly and commercially available SSH servers.

For information, see the [Chapter 7, “Configuring SSH.”](#)

## Telnet

You can use the Telnet protocol to set up TCP/IP connections to a host. Telnet allows a person at one site to establish a TCP connection to a login server at another site and then passes the keystrokes from one device to the other. Telnet can accept either an IP address or a domain name as the remote device address. For information, see the [Chapter 8, “Configuring Telnet.”](#)

## Access Control Lists (ACLs)

An ACL is an ordered set of rules for filtering traffic. When the device determines that an ACL applies to a packet, it tests the packet against the rules. The first matching rule determines whether the packet is permitted or denied. If there is no match, the device applies a default rule. The device processes packets that are permitted and drops packets that are denied.

ACLs protect networks and specific hosts from unnecessary or unwanted traffic. For example, ACLs can disallow HTTP traffic from a high-security network to the Internet. ACLs also allow HTTP traffic but only to specific sites, using the IP address of the site to identify it in an IP ACL.

For more information, see the following:

- [Chapter 9, “Configuring an IP ACL”](#)
- [Chapter 10, “Configuring a MAC ACL”](#)

## Port Security

Port security lets you configure Layer 2 interfaces permitting inbound traffic from a restricted and secured set of MAC addresses. Traffic from a secured MAC address is not allowed on another interface within the same VLAN. The number of MAC addresses that can be secured is configured per interface.

For more information, see [Chapter 11, “Configuring Port Security.”](#)

## DHCP Snooping

DHCP snooping provides a mechanism to prevent a malicious host masquerading as a DHCP server from assigning IP addresses (and related configuration) to DHCP clients. In addition, DHCP snooping prevents certain denial of service attacks on the DHCP server.

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

DHCP snooping requires you to configure a trust setting for ports, which is used to differentiate between trusted and untrusted DHCP servers.

In addition, DHCP snooping learns IP addresses assigned by the DHCP server, so that other security features (for example, Dynamic ARP inspection and IP source guard) can function when DHCP is used to assign IP addresses to interfaces.

For more information, see [Chapter 12, “Configuring DHCP Snooping.”](#)

## Dynamic ARP Inspection

Dynamic ARP Inspection (DAI) ensures that only valid ARP requests and responses are relayed by intercepting all ARP requests and responses on untrusted ports and verifying that each of these intercepted packets has a valid IP-to-MAC address binding before updating the local ARP cache or before forwarding the packet to the appropriate destination. When this feature is enabled, invalid ARP packets are dropped.

For more information, see [Chapter 13, “Configuring Dynamic ARP Inspection.”](#)

## IP Source Guard

IP Source Guard is a per-interface traffic filter that permits IP traffic only when the packet IP address and MAC address match one of the following:

- The IP address and MAC address in the DHCP snooping binding
- The static IP source entries that you configure

For more information, see [Chapter 14, “Configuring IP Source Guard.”](#)





# CHAPTER 2

## Managing User Accounts

---

This chapter describes how to configure user accounts and includes the following topics:

- [Information About User Accounts, page 2-1](#)
- [Guidelines and Limitations, page 2-4](#)
- [Default Settings, page 2-4](#)
- [Configuring User Access, page 2-4](#)
- [Example Configuration, page 2-15](#)
- [Additional References, page 2-16](#)
- [Feature History for User Accounts, page 2-16](#)

### Information About User Accounts

Access to the Cisco Nexus 1000V is accomplished by setting up user accounts that define the specific actions permitted by each user. You can create up to 256 user accounts. Each user account includes the following criteria:

- [Role, page 2-1](#)
- [User Name, page 2-3](#)
- [Password, page 2-3](#)
- [Expiration Date, page 2-4](#)

### Role

A role is a collection of rules that define the specific actions that can be shared by a group of users. The following broadly defined roles, for example, can be assigned to user accounts. These roles are predefined in the Cisco Nexus 1000V and cannot be modified:

```

role: network-admin
  description: Predefined network admin role has access to all commands
               on the switch
-----
Rule      Perm   Type      Scope      Entity
-----
1         permit read-write

role: network-operator

```

## Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).

description: Predefined network operator role has access to all read commands on the switch

```
-----
Rule    Perm    Type    Scope    Entity
-----
1       permit read
```

You can create an additional 64 roles that define access for users.

Each user account must be assigned at least one role and can be assigned up to 64 roles.

You can create roles that, by default, permit access to the following commands only. You must add rules to allow users to configure features.

- **show**
- **exit**
- **end**
- **configure terminal**

Table 2-1 describes the components that make up a role.

**Table 2-1 Role Components**

Component	Description
Rule	<p>One of the defined role criteria, such as a command that is permitted or denied. You can add up to 256 rules to each role.</p> <p>The following are the rules for the predefined roles:</p> <ul style="list-style-type: none"> <li>• <b>role: network-admin</b></li> </ul> <pre>----- Rule    Perm    Type    Scope    Entity ----- 1       permit read-write</pre> <ul style="list-style-type: none"> <li>• <b>role: network-operator</b></li> </ul> <pre>----- Rule    Perm    Type    Scope    Entity ----- 1       permit read-only</pre>
Feature	An individual feature, such as syslog or TACACS+, whose access can be defined in a rule. To see a list of available features, use the <b>show role feature</b> command.
Feature Group	A grouping of features whose access can be defined in a rule. You can create up to 64 such groupings. To see a list of available feature groups, use the <b>show role feature-group</b> command.
Command	<p>A single command, or group of commands collected in a regular expression, whose access can be defined in a rule.</p> <p>A role permitting access to a command takes precedence over a role that denies access to the command. For example, if a user is assigned a role that denies access to the configuration command, but is also assigned a role that permits access to this command, then access is permitted.</p>

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

## User Name

A user name identifies an individual user by a unique character string, such as daveGreen. User names are case sensitive and can consist of up to 28 alphanumeric characters. A user name consisting of all numerals is not allowed. If an all numeric user name exists on an AAA server and is entered during login, the user is not logged in.

## Password

A password is a case-sensitive character string that enables access by a specific user and helps prevent unauthorized access. You can add a user without a password, but they may not be able to access the device. Passwords should be strong so that they cannot be easily guessed for unauthorized access.

The following characters are not permitted in clear text passwords:

- dollar signs (\$)
- spaces

The following special characters are not permitted at the beginning of the password:

- quotation marks (" or ')
- vertical bars (|)
- right angle brackets (>)

Table 2-2 lists the characteristics of strong passwords.

**Table 2-2**      **Characteristics of strong passwords**

<b>Strong passwords have:</b>	<b>Strong passwords do not have:</b>
<ul style="list-style-type: none"> <li>• At least eight characters</li> <li>• Uppercase letters</li> <li>• Lowercase letters</li> <li>• Numbers</li> <li>• Special characters</li> </ul>	<ul style="list-style-type: none"> <li>• Consecutive characters, such as “abcd”</li> <li>• Repeating characters, such as “aaabbb”</li> <li>• Dictionary words</li> <li>• Proper names</li> </ul>

The following are examples of strong passwords:

- If2CoM18
- 2004AsdfLkj30
- Cb1955S21

## Check of Password Strength

The device checks password strength automatically by default. When you add a user name and password, the strength of the password is evaluated. If it is a weak password, then the error message below displays to notify you.

```
n1000v# config t
n1000v(config)# username daveGreen password davey
password is weak
Password should contain characters from at least three of the classes:
```

## Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).

lower case letters, upper case letters, digits, and special characters

Password strength-checking can be disabled.

## Expiration Date

By default, a user account does not expire. You can, however, explicitly configure an expiration date on which the account will be disabled.

## Guidelines and Limitations

User access has the following configuration guidelines and limitations:

- You can create up to 64 roles in addition to the two predefined user roles.
- You can create up to 256 rules in a user role.
- You can create up to 64 feature groups.
- You can add up to 256 users.
- You can assign a maximum of 64 user roles to a user account.
- If you have a user account that has the same name as a remote user account on an AAA server, the user roles for the local user account are applied to the remote user, not the user roles configured on the AAA server.

## Default Settings

Table 2-3 lists the default settings for user access.

**Table 2-3** User Access Defaults

Parameters	Default
User account password	Undefined
User account expiration date.	None
User account role	Network-operator
Interface policy	All interfaces are accessible.
VLAN policy	All VLANs are accessible.

## Configuring User Access

This section includes the following topics:

- [Enabling the Check of Password Strength, page 2-5](#)
- [Disabling the Check of Password Strength, page 2-6](#)
- [Creating a User Account, page 2-6](#)
- [Creating a Role, page 2-8](#)

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

- [Creating a Feature Group, page 2-10](#)
- [Configuring Interface Access, page 2-12](#)
- [Configuring VLAN Access, page 2-13](#)

## Enabling the Check of Password Strength

Use this procedure to enable the Cisco Nexus 1000V to check the strength of passwords to avoid creating weak passwords for user accounts.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following.

- You are logged in to the CLI in EXEC mode.
- Checking password strength is enabled by default. This procedure can be used to enable it again should it become disabled.

### SUMMARY STEPS

1. `config t`
2. `password strength-check`
3. `show password strength-check`
4. `copy running-config startup-config`

### DETAILED STEPS

	Command	Purpose
Step 1	<code>config t</code>  <b>Example:</b> n1000v# <code>config t</code> n1000v(config)#	Places you into the CLI Global Configuration mode.
Step 2	<code>password strength-check</code>  <b>Example:</b> n1000v(config)# <code>password strength-check</code>	Enables password-strength checking. The default is enabled.  You can disable the checking of password strength by using the <b>no</b> form of this command.
Step 3	<code>show password strength-check</code>  <b>Example:</b> n1000v# <code>show password strength-check</code> Password strength check enabled n1000v(config)#	(Optional) Displays the configuration for checking password strength.
Step 4	<code>copy running-config startup-config</code>  <b>Example:</b> n1000v# <code>copy running-config startup-config</code>	(Optional) Saves the running configuration persistently through reboots and restarts by copying it to the startup configuration.

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

## Disabling the Check of Password Strength

Use this procedure to disable the check of password strength.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following.

- You are logged in to the CLI in EXEC mode.
- Checking password strength is enabled by default. This procedure can be used to disable it.

### SUMMARY STEPS

1. **config t**
2. **no password strength-check**
3. **show password strength-check**
4. **copy running-config startup-config**

### DETAILED STEPS

	Command	Purpose
Step 1	<b>config t</b>  <b>Example:</b> n1000v# config t n1000v(config)#	Places you into the CLI Global Configuration mode.
Step 2	<b>no password strength-check</b>  <b>Example:</b> n1000v(config)# no password strength-check n1000v(config)#	Disables password-strength checking.  The default is enabled.
Step 3	<b>show password strength-check</b>  <b>Example:</b> n1000v# show password strength-check Password strength check not enabled n1000v(config)#	(Optional) Displays the configuration for checking password strength.
Step 4	<b>copy running-config startup-config</b>  <b>Example:</b> n1000v# copy running-config startup-config	(Optional) Saves the running configuration persistently through reboots and restarts by copying it to the startup configuration.

## Creating a User Account

Use this procedure to create and configure a user account, defining access to the Cisco Nexus 1000V.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following.

- You are logged in to the CLI in EXEC mode.

## Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).

- You can add up to 256 user accounts.
- Changes to user accounts do not take effect until the user logs in and creates a new session.
- Do not use the following words in user accounts. These words are reserved for other purposes.

adm	gdm	mtsuser	rpcuser
bin	gopher	news	shutdown
daemon	haltlp	nobody	sync
ftp	mail	nscd	sys
ftpuser	mailnull	operator	uucp
games	man	rpc	xf

- You can add a user password as either clear text or encrypted.
  - Clear text passwords are encrypted before they are saved to the running configuration.
  - Encrypted passwords are saved to the running configuration without further encryption.
- A user account can have up to 64 roles, but must have at least one role. For more information about roles, see the [“Role” section on page 2-1](#).
- If you do not specify a password, the user might not be able to log in.
- For information about using SSH public keys instead of passwords, see the [“Configuring a User Account with a Public Key” section on page 7-5](#).

### SUMMARY STEPS

- config t**
- show role**
- username *user-name* [password [0 | 5]*password*] [expire *date*] [role *role-name*]**
- show user-account *user-name***
- copy running-config startup-config**

### DETAILED STEPS

	Command	Purpose
Step 1	<b>config t</b>  <b>Example:</b> n1000v# config t n1000v(config)#	Places you into the CLI Global Configuration mode.
Step 2	<b>show role</b>  <b>Example:</b> n1000v(config)# show role	(Optional) Displays the available roles that can be assigned to users.  You can create a new user role with the <a href="#">“Creating a Role” procedure on page 2-8</a> )

**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**

	Command	Purpose
Step 3	<p><b>username</b> <i>name</i> [<b>password</b> [0   5] <i>password</i>] [expire date] [role <i>role-name</i>]</p> <p><b>Example:</b>  n1000v(config)# username NewUser password 4Ty18Rnt</p>	<p>Creates a user account.</p> <ul style="list-style-type: none"> <li>• <b>name:</b> A case-sensitive, alphanumeric character string of up to 28 characters in length.</li> <li>• <b>password:</b> The default password is undefined. <ul style="list-style-type: none"> <li>– <b>0</b> = (the default) Specifies that the password you are entering is in clear text. The Cisco Nexus 1000V encrypts the clear text password before saving it in the running configuration.</li> </ul> <p>In the example shown, the password <b>4Ty18Rnt</b> is encrypted in your running configuration in password 5 format.</p> <li>– <b>5</b> = Specifies that the password you are entering is already in encrypted format. The Cisco Nexus 1000V does not encrypt the password before saving it in the running configuration.</li> </li></ul> <p>User passwords are not displayed in the configuration files.</p> <ul style="list-style-type: none"> <li>• <b>expire date:</b> YYYY-MM-DD. The default is no expiration date.</li> <li>• <b>role:</b> You must assign at least one role. You can assign up to 64 roles. The default role is <b>network-operator</b>.</li> </ul>
Step 4	<p><b>show user-account</b> <i>username</i></p> <p><b>Example:</b>  n1000v(config)# show user-account NewUser  user:NewUser  this user account has no expiry date  roles:network-operator network-admin  n1000v(config)#</p>	<p>Displays the new user account configuration.</p>
Step 5	<p><b>copy running-config startup-config</b></p> <p><b>Example:</b>  n1000v# copy running-config startup-config</p>	<p>(Optional) Saves the running configuration persistently through reboots and restarts by copying it to the startup configuration.</p>

## Creating a Role

Use this procedure to create a role defining a set of specific actions that are permitted or denied. This role will be assigned to users whose access requirements match the actions defined.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.
- You can configure up to 64 user roles.



## Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).

- You can configure up to up to 256 rules for each role.
- You can assign a single role to more that one user.
- The rule number specifies the order in which it is applied, in descending order. For example, if a role has three rules, rule 3 is applied first, rule 2 is applied next, and rule 1 is applied last.
- By default, the user roles that you create allow access only to the **show**, **exit**, **end**, and **configure terminal** commands. You must add rules to allow users to configure features.

### SUMMARY STEPS

1. **config t**
2. **role name** *role-name*
3. (Optional) **description** *string*
4. **rule** *number* {deny | permit} **command** *command-string*  
**rule** *number* {deny | permit} {read | read-write}  
**rule** *number* {deny | permit} {read | read-write} **feature** *feature-name*  
**rule** *number* {deny | permit} {read | read-write} **feature-group** *group-name*
5. Repeat Step 4 to create all needed rules for this role.
6. **show role**
7. **copy running-config startup-config**

### DETAILED STEPS

	Command	Purpose
Step 1	<b>config t</b>  <b>Example:</b> n1000v# config t n1000v(config)#	Places you into the CLI Global Configuration mode.
Step 2	<b>role name</b> <i>role-name</i>  <b>Example:</b> n1000v(config)# role name UserA n1000v(config-role)#	Names a user role and places you in Role Configuration mode for that role.  The name is a case-sensitive, alphanumeric string of up to 16 characters.
Step 3	<b>description</b> <i>description-string</i>  <b>Example:</b> n1000v(config-role)# description Prohibits use of clear commands	(Optional) Configures the role description, which can include spaces.

**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**

	Command	Purpose
Step 4	<pre>rule number {deny   permit} command command-string</pre> <p><b>Example:</b>  n1000v(config-role)# rule 1 deny command  clear users</p>	<p>Creates a rule to permit or deny a specific command.</p> <p>The command you specify can contain spaces and regular expressions. For example, “interface ethernet *” permits/denies access to all Ethernet interfaces.</p> <p>This example rule denies access to the <b>clear users</b> command.</p>
	<pre>rule number {deny   permit} {read   read-write}</pre> <p><b>Example:</b>  n1000v(config-role)# rule 2 deny  read-write</p>	<p>Creates a blanket rule to permit or deny all operations.</p> <p>This example rule permits read-only access for any operation.</p>
	<pre>rule number {deny   permit} {read   read-write} feature feature-name</pre> <p><b>Example:</b>  n1000v(config-role)# rule 3 permit read  feature eth-port-sec</p>	<p>Creates a rule for feature access.</p> <p>Use the <b>show role feature</b> command to display a list of available features.</p> <p>This example rule permits users read-only access to the Ethernet port security feature.</p>
	<pre>rule number {deny   permit} {read   read-write} feature-group group-name</pre> <p><b>Example:</b>  n1000v(config-role)# rule 4 deny  read-write feature-group eth-port-sec</p>	<p>Creates a rule for feature group access.</p> <p>Use the <b>show role feature-group</b> command to display a list of feature groups.</p> <p>This example configures a rule denying access to a feature group.</p>
Step 5	Repeat <a href="#">Step 4</a> to create all needed rules for the specified role.	
Step 6	<pre>show role</pre> <p><b>Example:</b>  n1000v(config)# show role</p>	(Optional) Displays the user role configuration.
Step 7	<pre>copy running-config startup-config</pre> <p><b>Example:</b>  n1000v(config)# copy running-config  startup-config</p>	(Optional) Saves the running configuration persistently through reboots and restarts by copying it to the startup configuration.

## Creating a Feature Group

Use this procedure to create and configure a feature group.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.
- You can create up to 64 custom feature groups.

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

## SUMMARY STEPS

1. `config t`
2. `role feature-group name group-name`
3. `show role feature`
4. `feature feature-name`
5. Repeat 4 for all features to be added to the feature group.
6. `show role feature-group`
7. `copy running-config startup-config`

## DETAILED STEPS

	Command	Purpose
Step 1	<p><code>config t</code></p> <p><b>Example:</b>  n1000v# <code>config t</code>  n1000v(config)#</p>	Places you into the CLI Global Configuration mode.
Step 2	<p><code>role feature-group name <i>group-name</i></code></p> <p><b>Example:</b>  n1000v(config)# <code>role feature-group name</code>  GroupA  n1000v(config-role-featuregrp)#</p>	Places you into the Role Feature Group Configuration mode for the named group. <ul style="list-style-type: none"> <li>• <b>group-name:</b> A case-sensitive, alphanumeric string of up to 32 characters in length.</li> </ul>
Step 3	<p><code>show role feature</code></p> <p><b>Example:</b>  n1000v(config-role-featuregrp)# <code>show role feature</code>  feature: aaa  feature: access-list  feature: cdp  feature: install  . . .  n1000v(config-role-featuregrp)#</p>	Displays a list of available features for use in defining the feature group.
Step 4	<p><code>feature <i>feature-name</i></code></p> <p><b>Example:</b>  n1000v(config-role-featuregrp)# <code>feature</code>  syslog  n1000v(config-role-featuregrp)#</p>	Adds a feature to the feature group.
Step 5	Repeat Step 6 for all features to be added to the feature group.	

**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**

	Command	Purpose
Step 6	<b>show role feature-group</b>  <b>Example:</b> n1000v(config-role-featuregrp)# show role feature-group feature group: GroupA feature: syslog feature: snmp feature: ping n1000v(config-role-featuregrp)#	(Optional) Displays the feature group configuration.
Step 7	<b>copy running-config startup-config</b>  <b>Example:</b> n1000v(config-role-featuregrp)# copy running-config startup-config	(Optional) Saves the running configuration persistently through reboots and restarts by copying it to the startup configuration.

## Configuring Interface Access

Use this procedure to configure interface access for a specific role.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.
- You have already created one or more user roles using the “[Creating a Role](#)” procedure on page 2-8. In this procedure, you will be modifying a role you have already created.
- By default, a role allows access to all interfaces. In this procedure you will, first, deny access to all interfaces and then permit access to selected interfaces.

### SUMMARY STEPS

1. **config t**
2. **role name** *role-name*
3. **interface policy deny**
4. **permit interface** *interface-list*
5. **show role**
6. **copy running-config startup-config**

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

## DETAILED STEPS

	Command	Purpose
Step 1	<pre>config t</pre> <p><b>Example:</b> n1000v# config t n1000v(config)#</p>	Places you into the CLI Global Configuration mode.
Step 2	<pre>role name role-name</pre> <p><b>Example:</b> n1000v(config)# role name network-observer n1000v(config-role)#</p>	Specifies a user role and enters Role Configuration mode for the named role.
Step 3	<pre>interface policy deny</pre> <p><b>Example:</b> n1000v(config-role)# interface policy deny n1000v(config-role-interface)#</p>	Enters the Interface Configuration mode, and denies all interface access for the role.  Access to any interface must now be explicitly defined for this role using the <b>permit interface</b> command.
Step 4	<pre>permit interface interface-list</pre> <p><b>Example:</b> n1000v(config-role-interface)# permit interface ethernet 2/1-4</p>	Specifies the interface(s) that users assigned to this role can access.  Repeat this command to specify all interface lists that users assigned to this role are permitted to access.
Step 5	<pre>show role role-name</pre> <p><b>Example:</b> n1000v(config-role-interface)# show role name network-observer</p> <pre>role: network-observer description: temp Vlan policy: permit (default) Interface policy: deny Permitted interfaces: Ethernet2/1-4</pre>	(Optional) Displays the role configuration.
Step 6	<pre>copy running-config startup-config</pre> <p><b>Example:</b> n1000v(config-role-featuregrp)# copy running-config startup-config</p>	(Optional) Saves the running configuration persistently through reboots and restarts by copying it to the startup configuration.

## Configuring VLAN Access

Use this procedure to define the VLAN access for a role.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.
- You have already created one or more user roles using the [“Creating a Role” procedure on page 2-8](#). In this procedure, you will be modifying a role you have already created.

**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**

- By default, access is allowed to all VLANs. In this procedure you will, first, deny access to all VLANs and then permit access to selected VLANs.

**SUMMARY STEPS**

1. **config t**
2. **role name *role-name***
3. **vlan policy deny**
4. **permit vlan *vlan-range***
5. **exit**
6. **show role**
7. **copy running-config startup-config**

**DETAILED STEPS**

	Command	Purpose
Step 1	<b>config t</b>  <b>Example:</b> n1000v# config t n1000v(config)#	Places you into the CLI Global Configuration mode.
Step 2	<b>role name <i>role-name</i></b>  <b>Example:</b> n1000v(config)# role name network-observer n1000v(config-role)#	Specifies a user role and enters role configuration mode.
Step 3	<b>vlan policy deny</b>  <b>Example:</b> n1000v(config-role)# vlan policy deny n1000v(config-role-vlan)#	Enters the VLAN Configuration mode, and denies all VLAN access for the role.  Access to any VLAN must now be explicitly defined for this role using the <b>permit vlan</b> command.
Step 4	<b>permit vlan <i>vlan-list</i></b>  <b>Example:</b> n1000v(config-role-vlan)# permit vlan 1-4	Specifies the VLAN(s) that users assigned to this role can access.  Repeat this command to specify all VLANs that users assigned to this role are permitted to access.

**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**

	Command	Purpose
Step 5	<b>show role</b> <i>role-name</i>  <b>Example:</b> n1000v(config-role)# show role network-observer  role: network-observer description: temp Vlan policy: deny Permitted vlans: vlan 1-4 Interface policy: deny Permitted interfaces: Ethernet2/1-4	(Optional) Displays the role configuration.
Step 6	<b>copy running-config startup-config</b>  <b>Example:</b> n1000v(config-role)# copy running-config startup-config	(Optional) Saves the running configuration persistently through reboots and restarts by copying it to the startup configuration.

## Verifying the User Access Configuration

To display user account and RBAC configuration information, perform one of the following tasks:

Command	Purpose
<b>show role</b>	Displays the available user roles and their rules.
<b>show role feature</b>	Displays a list of available features.
<b>show role feature-group</b>	Displays a list of available feature groups.
<b>show startup-config security</b>	Displays the user account configuration in the startup configuration.
<b>show running-config security [all]</b>	Displays the user account configuration in the running configuration. The <b>all</b> keyword displays the default values for the user accounts.
<b>show user-account</b>	Displays user account information.

## Example Configuration

The following example shows how to configure a role:

```
role name UserA
  rule 3 permit read feature snmp
  rule 2 permit read feature dot1x
  rule 1 deny command clear *
```

The following example shows how to configure a feature group:

```
role feature-group name Security-features
  feature radius
  feature tacacs
  feature dot1x
  feature aaa
  feature snmp
  feature acl
  feature access-list
```

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

## Additional References

For additional information related to implementing RBAC, see the following sections:

- [Related Documents, page 2-16](#)
- [Standards, page 2-16](#)
- [MIBs, page 2-16](#)

## Related Documents

Related Topic	Document Title
User access commands	<i>Cisco Nexus 1000V Command Reference, Release 4.2(1)SV1(5.1)</i>
Managing users on the switch	<i>Cisco Nexus 1000V Installation and Upgrade Guide, Release 4.2(1)SV1(5.1)</i>

## Standards

Standards	Title
No new or modified standards are supported by this feature, and support for existing standards has not been modified by this feature.	—

## MIBs

MIBs	MIBs Link
<ul style="list-style-type: none"> <li>• CISCO-COMMON-MGMT-MIB</li> </ul>	To locate and download MIBs, go to the following URL: <a href="http://www.cisco.com/public/sw-center/netmgmt/cmtk/mibs.shtml">http://www.cisco.com/public/sw-center/netmgmt/cmtk/mibs.shtml</a>

## Feature History for User Accounts

This section provides the user accounts release history.

Feature Name	Releases	Feature Information
User Accounts	4.0(4)SV1(1)	This feature was introduced.





# CHAPTER 3

## Configuring VSD

---

This chapter describes how to configure VSD and includes the following topics:

- [Information About Virtual Service Domain, page 3-1](#)
- [Guidelines and Limitations, page 3-3](#)
- [Default Settings, page 3-3](#)
- [Configuring VSD, page 3-4](#)
- [Verifying the Configuration, page 3-8](#)
- [Configuration Example, page 3-10](#)
- [Additional References, page 3-10](#)
- [Feature History, page 3-11](#)

## Information About Virtual Service Domain

A virtual service domain (VSD) allows you to classify and separate traffic for network services, such as firewalls, traffic monitoring, and those in support of compliance goals such as Sarbanes Oxley.

### Service Virtual Machine

A service VM (SVM) provides the specialized service like firewall, deep packet inspection (application aware networking), or monitoring. Each Service VM has three virtual interfaces:

Interface	Description
Management	A regular interface that manages the SVM Should have Layer 2 or Layer 3 connectivity, depending on its use.
Incoming	Guards the traffic coming into the VSD Any packet coming into the VSD must go through this interface.
Outgoing	Guards the traffic going out of the VSD. Any packet that originates in the VSD and goes out must go through the SVM and out through the outgoing interface.

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

There is no source MAC learning on these interfaces. Each SVM creates a secure VSD. Interfaces within the VSD are shielded by the SVM.

## Port Profiles

A VSD is the collection of interfaces that are guarded by the SVM providing the security service. Any traffic coming into the VSD or going out of the VSD has to go through the SVM.

Traffic that both originates and terminates within the same VSD need not be routed through the SVM as it is considered to be safe.

A VSD is formed by creating the following port profiles:


Port Profile	Description
Inside	Traffic originating from a VSD member goes into the service VM (SVM) through the inside port and comes out of the outside port before it is forwarded to its destination.
Outside	Traffic destined for a VSD member goes into the SVM through the outside port and comes out of the inside port before it is forwarded to its destination.
Member	Location for individual inside VMs.

In [Figure 3-1](#), a single VEM takes the place of vswitches; the SVMs define the following VSDs;

VSD	SVM (guard)	Inside Port Profile	Outside Port Profile	Member Port Profile(s)
DB VSD	SVM_db	SVM_db_inside	SVM_db_outside	vEth_db1 vEth_db2
Web VSD	SVM_web	SVM_web_inside	SVM_web_outside	vEth_web
Internet VSD	SVM_Internet	SVM_internet_inside	SVM_internet_outside	
Default		SVM VSD		vEth Email

**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**

**Figure 3-1 Virtual Service Domain (VSD) Example**



## Guidelines and Limitations

Virtual Service Domain has the following configuration guidelines and limitations:

- To prevent traffic latency, VSD should only be used for securing traffic.
- Up to 6 VSDs can be configured per host and up to 64 on the VSM.
- Up to 214 interfaces per VSD are supported on a single host, and 2048 interfaces on the VSM.
- Vmotion is not supported for the SVM and should be disabled.
- To avoid network loops following a VSM reload or a network disruption, control and packet VLANs must be disabled in all port profiles of the Service VMs.
- If a port profile without a service port is configured on an SVM, it will flood the network with packets.
- When configuring a port profile on an SVM, first bring the SVM down. This prevents a port-profile that is mistakenly configured without a service port from flooding the network with packets. The SVM can be returned to service after the configuration is complete and verified.
- VShield 4.1 does not support VSD. VSD feature will not function as expected if used with VShield 4.1.

## Default Settings

The following table lists the Telnet defaults.

Parameters	Default
service-port default-action	Forward.
switchport trunk allowed vlan	All

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

## Configuring VSD

This section includes the following procedures:

- [Configuring an Inside or Outside VSD Port Profile, page 3-4](#)
- [Configuring a Member VSD Port Profile, page 3-7](#)

### Configuring an Inside or Outside VSD Port Profile

Use this procedure to configure the port-profiles that define the connections going into and out of the SVM.

#### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.
- You have taken the SVM out of service to prevent any configuration errors from flooding the network. Once the configuration is complete and verified, you can bring the SVM back into service.
- If you do not configure a service-port, the SVM will come up as a regular VM, flooding the network with packets.
- Selected VLAN filtering is not supported in this configuration. The default should be used instead, which allows all VLANs on the port.

#### SUMMARY STEPS

1. **config t**
2. **port-profile** *name*
3. **switchport mode trunk**
4. **switchport trunk allowed vlan** *vlanID*
5. **virtual-service-domain** *name*
6. **no shut**
7. **vmware port-group** *pg-name*
8. **service-port** {inside | outside} [default-action {drop | forward}]
9. **state enabled**
10. **show virtual-service-domain** *name*
11. **copy running-config startup-config**

**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**

## DETAILED STEPS

	Command	Purpose
Step 1	<b>config t</b>  <b>Example:</b> n1000v# config t n1000v(config)#	Places you in the CLI Global Configuration mode.
Step 2	<b>port-profile name</b>  <b>Example:</b> n1000v(config)# port-profile webserver-inside n1000v(config-port-profile)#	Creates a port profile and places you into Port Profile Configuration mode for the named port profile.  The port profile name can be up to 80 characters and must be unique for each port profile on the Cisco Nexus 1000V.
Step 3	<b>switchport mode trunk</b>  <b>Example:</b> n1000v(config-port-profile)# switchport mode trunk n1000v(config-port-profile)#	Designates that the interfaces are switch trunk ports.
Step 4	<b>switchport trunk allowed vlan vlanID</b>  <b>Example:</b> n1000v(config-port-profile)# switchport trunk allowed vlan all n1000v(config-port-profile)#	Allows all VLANs on the port.
Step 5	<b>virtual-service-domain name</b>  <b>Example:</b> n1000v(config-port-profile)# virtual-service-domain vsd1-webserver n1000v(config-port-profile)#	Adds a VSD name to this port profile.
Step 6	<b>no shutdown</b>  <b>Example:</b> n1000v(config-port-prof)# no shutdown n1000v(config-port-prof)#	Administratively enables all ports in the profile.
Step 7	<b>vmware port-group pg-name</b>  <b>Example:</b> n1000v(config-port-prof)# vmware port-group webservers-inside-protected n1000v(config-port-prof)#	Designates the port-profile as a VMware port-group.  The port profile is mapped to a VMware port group of the same name. When a vCenter Server connection is established, the port group created in Cisco Nexus 1000V is then distributed to the virtual switch on the vCenter Server.  <b>name:</b> Port group name. If you do not specify a pg-name, then the port group name will be the same as the port profile name. If you want to map the port profile to a different port group name, use the pg-name option followed by the alternate name.

**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**

	Command	Purpose												
Step 8	<b>service-port {inside   outside}</b> <b>[default-action {drop   forward}]</b>	Configures the interface as either inside or outside and designates (default-action) whether packets should be forwarded or dropped if the service port is down.  If you do not specify a default-action, then the <b>forward</b> setting is used by default.												
	<b>Example:</b> <pre>n1000v(config-port-prof)# service-port inside default-action forward n1000v(config-port-prof)#</pre>	This example configures an inside VSD that forwards packets if the service port is down.												
	<b>Example:</b> <pre>n1000v(config-port-prof)# service-port outside default-action forward n1000v(config-port-prof)#</pre>	This example configures an outside VSD that forwards packets if the service port is down.												
Step 9	<b>state enabled</b>	Enables the VSD port profile.												
	<b>Example:</b> <pre>n1000v(config-port-prof)# state enabled n1000v(config-port-prof)#</pre>	The configuration for this port profile is applied to the assigned ports, and the port group is created in the VMware vSwitch on the vCenter Server.												
Step 10	<b>show virtual-service-domain <i>name</i></b>	(Optional) Displays the configuration for this VSD port profile. Use this to verify that the port-profile was configured as expected.												
	<b>Example:</b> <pre>n1000v(config-port-prof)# show virtual-service-domain vsdl-webserver Default Action: forward</pre> <table border="1"> <thead> <tr> <th>Interface</th> <th>Type</th> </tr> </thead> <tbody> <tr> <td>Vethernet1</td> <td>Member</td> </tr> <tr> <td>Vethernet2</td> <td>Member</td> </tr> <tr> <td>Vethernet3</td> <td>Member</td> </tr> <tr> <td>Vethernet7</td> <td>Inside</td> </tr> <tr> <td>Vethernet8</td> <td>Outside</td> </tr> </tbody> </table> <pre>n1000v(config-port-prof)#</pre>	Interface	Type	Vethernet1	Member	Vethernet2	Member	Vethernet3	Member	Vethernet7	Inside	Vethernet8	Outside	
Interface	Type													
Vethernet1	Member													
Vethernet2	Member													
Vethernet3	Member													
Vethernet7	Inside													
Vethernet8	Outside													
Step 11	<b>copy running-config startup-config</b>	(Optional) Saves the running configuration persistently through reboots and restarts by copying it to the startup configuration.												
	<b>Example:</b> <pre>n1000v(config-port-prof)# copy running-config startup-config [##### #] 100% n1000v(config-port-prof)#</pre>													

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

## Configuring a Member VSD Port Profile

Use this procedure to configure the VSD port profile where individual members reside.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.
- Do not configure a member VSD port profile on an SVM.

A member VSD port profile does not have a service port, and will flood the network with packets if configured on an SVM.

### SUMMARY STEPS

1. **config t**
2. **port-profile *name***
3. **switchport access vlan *vlanID***
4. **switchport trunk allowed vlan *vlanID***
5. **virtual-service-domain *name***
6. **no shut**
7. **state enabled**
8. **show virtual-service-domain *name***
9. **copy running-config startup-config**

### DETAILED STEPS

	Command	Purpose
Step 1	<b>config t</b>  <b>Example:</b> n1000v# config t n1000v(config)#	Places you in the CLI Global Configuration mode.
Step 1	<b>port-profile <i>name</i></b>  <b>Example:</b> n1000v(config)# port-profile vsd1-member n1000v(config-port-profile)#	Creates a port profile and places you into Port Profile Configuration mode for the named port profile.  The port profile name can be up to 80 characters and must be unique for each port profile on the Cisco Nexus 1000V.
Step 2	<b>switchport access vlan <i>vlanID</i></b>  <b>Example:</b> n1000v(config-port-profile)# switchport access vlan 315 n1000v(config-port-profile)#	Assigns a VLAN ID to the access port for this port profile.

**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**

	Command	Purpose														
Step 3	<b>virtual-service-domain</b> <i>name</i>  <b>Example:</b> n1000v(config-port-profile)# virtual-service-domain vsdl-webserver n1000v(config-port-profile)#	Assigns a VSD name to this port profile.														
Step 4	<b>no shutdown</b>  <b>Example:</b> n1000v(config-port-prof)# no shutdown n1000v(config-port-prof)#	Administratively enables all ports in the profile.														
Step 5	<b>state enabled</b>  <b>Example:</b> n1000v(config-port-prof)# state enabled n1000v(config-port-prof)#	Enables the VSD port profile.  The configuration for this port profile is applied to the assigned ports, and the port group is created in the VMware vSwitch on the vCenter Server.														
Step 6	<b>show virtual-service-domain</b> <i>name</i>  <b>Example:</b> n1000v(config-port-prof)# show virtual-service-domain vsdl-webserver Default Action: forward  <table border="1"> <thead> <tr> <th>Interface</th> <th>Type</th> </tr> </thead> <tbody> <tr><td>Vethernet1</td><td>Member</td></tr> <tr><td>Vethernet2</td><td>Member</td></tr> <tr><td>Vethernet3</td><td>Member</td></tr> <tr><td>Vethernet6</td><td>Member</td></tr> <tr><td>Vethernet7</td><td>Inside</td></tr> <tr><td>Vethernet8</td><td>Outside</td></tr> </tbody> </table> n1000v(config-port-prof)#	Interface	Type	Vethernet1	Member	Vethernet2	Member	Vethernet3	Member	Vethernet6	Member	Vethernet7	Inside	Vethernet8	Outside	(Optional) Displays the configuration for this VSD port profile. Use this to verify that the port-profile was configured as expected.
Interface	Type															
Vethernet1	Member															
Vethernet2	Member															
Vethernet3	Member															
Vethernet6	Member															
Vethernet7	Inside															
Vethernet8	Outside															
Step 7	<b>copy running-config startup-config</b>  <b>Example:</b> n1000v(config-port-prof)# copy running-config startup-config [##### #] 100% n1000v(config-port-prof)#	(Optional) Saves the running configuration persistently through reboots and restarts by copying it to the startup configuration.														

## Verifying the Configuration

To display the VSD configuration, use the following commands:

Command	Purpose
<b>show virtual-service-domain</b> <i>name</i> <i>vsd-name</i>	Displays a specific VSD configuration. See <a href="#">Example 3-1 on page 3-9</a> .
<b>show virtual-service-domain</b> <b>brief</b>	Displays a summary of all VSD configurations. See <a href="#">Example 3-2 on page 3-9</a> .



**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**

Command	Purpose
<b>show virtual-service-domain interface</b>	Displays the interface configuration for all VSDs. See <a href="#">Example 3-3 on page 3-9</a> .
<b>module vem <i>module_number</i> execute vemcmd show vsd</b>	Displays the VEM VSD configuration by sending the command to the VEM from the remote Cisco Nexus 1000V. See <a href="#">Example 3-4 on page 3-10</a> .
<b>module vem <i>module_number</i> execute vemcmd show vsd ports</b>	Displays the VEM VSD ports configuration by sending the command to the VEM from the remote Cisco Nexus 1000V. See <a href="#">Example 3-5 on page 3-10</a> .

For detailed information about command output for these commands, see the *Cisco Nexus 1000V Command Reference, Release 4.2(1)SV1(5.1)*.

**Example 3-1 show virtual-service-domain name *vsd\_name***

```
n1000v## show virtual-service-domain name vsd1
Default Action: drop
```

Interface	Type
Vethernet1	Member
Vethernet2	Member
Vethernet3	Member
Vethernet6	Member
Vethernet7	Inside
Vethernet8	Outside

```
n1000v#
```

**Example 3-2 show virtual-service-domain brief**

```
n1000v# show virtual-service-domain brief
Name vsd-id default action in-ports out-ports mem-ports Modules with
VSD Enabled
zone 1 forward 1 1 2 4
n1000v#
```

**Example 3-3 show virtual-service-domain interface**

```
n1000v# sho virtual-service-domain interface
-----
Name Interface Type Status
-----
vsd1 Vethernet1 Member Active
vsd1 Vethernet2 Member Active
vsd1 Vethernet3 Member Active
vsd1 Vethernet6 Member Active
vsd1 Vethernet7 Inside Active
vsd1 Vethernet8 Outside Active
vsd2 Vethernet9 Inside Active
vsd2 Vethernet10 Outside Active
```

**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**

**Example 3-4** *module module\_number execute vemcmd show vsd*

```
n1000v# module vem 4 execute vemcmd show vsd
ID Def_Act ILTL OLTL NMLTL State Member LTLs
1 FRWD 51 50 1 ENA 49
n1000v#
```

**Example 3-5** *module module\_number execute vemcmd show vsd ports*

```
n1000v# module vem 4 execute vemcmd show vsd ports
LTL IfIndex VSD_ID VSD_PORT_TYPE
49 1c000010 1 REGULAR
50 1c000040 1 OUTSIDE
51 1c000030 1 INSIDE
n1000v#
```

## Configuration Example

The following example shows how to configure VSD.

```
port-profile vsd1_member
  vmware port-group
  switchport access vlan 315
  virtual-service-domain vsd1
  no shutdown
  state enabled
port-profile svm_vsd1_in
  vmware port-group
  switchport mode trunk
  switchport trunk allowed vlan 310-319
  virtual-service-domain vsd1
  service-port inside default-action drop
  no shutdown
  state enabled
port-profile svm_vsd1_out
  vmware port-group
  switchport mode trunk
  switchport trunk allowed vlan 310-319
  virtual-service-domain vsd1
  service-port outside default-action drop
  no shutdown
```

## Additional References

For additional information related to VSD configuration, see the following:

- [Related Documents, page 3-11](#)
- [Standards, page 3-11](#)

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

## Related Documents

Related Topic	Document Title
Port Profiles	<i>Cisco Nexus 1000V Port Profile Configuration Guide, Release 4.2(1)SV1(5.1)</i>
CLI	<i>Cisco Nexus 1000V Installation and Upgrade Guide, Release 4.2(1)SV1(5.1)</i> <i>Cisco Nexus 1000V Command Reference, Release 4.2(1)SV1(5.1)</i>

## Standards

Standards	Title
No new or modified standards are supported by this feature, and support for existing standards has not been modified by this feature.	—

## Feature History

This section provides the VSD release history.

Feature Name	Releases	Feature Information
VSD	4.0(4)SV1(2)	This feature was introduced.

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***



## CHAPTER 4

# Configuring AAA

---

This chapter describes how to configure authentication, authorization, and accounting (AAA) and includes the following sections:

- [Information About AAA, page 4-1](#)
- [Prerequisites for AAA, page 4-4](#)
- [AAA Guidelines and Limitations, page 4-4](#)
- [Default Settings, page 4-4](#)
- [Configuring AAA, page 4-4](#)
- [Verifying AAA Configuration, page 4-8](#)
- [Example AAA Configuration, page 4-9](#)
- [Additional References, page 4-9](#)
- [Feature History for AAA, page 4-10](#)

## Information About AAA

This section includes the following topics:

- [AAA Security Services, page 4-1](#)
- [AAA Server Groups, page 4-4](#)

## AAA Security Services

Based on a user ID and password combination, AAA is used to authenticate and authorize users. A key secures communication with AAA servers.

In many circumstances, AAA uses protocols such as RADIUS or TACACS+, to administer its security functions. If your router or access server is acting as a network access server, AAA is the means through which you establish communication between your network access server and your RADIUS or TACACS+, security server.

Although AAA is the primary (and recommended) method for access control, additional features for simple access control are available outside the scope of AAA, such as local username authentication, line password authentication, and enable password authentication. However, these features do not provide the same degree of access control that is possible by using AAA.

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

Separate AAA configurations are made for the following services:

- User Telnet or Secure Shell (SSH) login authentication
- Console login authentication
- User management session accounting

Table 4-1 shows the related CLI command for configuring an AAA service.

**Table 4-1 AAA Service Configuration Commands**

AAA Service Configuration Option	Related Command
Telnet or SSH login	<b>aaa authentication login default</b>
Console login	<b>aaa authentication login console</b>

AAA secures the following:

- [Authentication, page 4-2](#)
- [Authorization, page 4-3](#)
- [Accounting, page 4-3](#)

## Authentication


Authentication identifies users with a login and password, messaging, and encryption.

Authentication is accomplished as follows:

Authentication Method	Description
Local database	Authenticates the following with a local lookup database of user names or passwords. <ul style="list-style-type: none"> <li>• Console login authentication</li> <li>• User login authentication</li> <li>• User management session accounting</li> </ul>
Remote RADIUS or TACACS+ server	Authenticates the following using a remote server lookup database of user names and passwords. <ul style="list-style-type: none"> <li>• Console login authentication</li> <li>• User login authentication</li> <li>• User management session accounting</li> </ul>
None	Authenticates the following with only a username. <ul style="list-style-type: none"> <li>• Console login authentication</li> <li>• User login authentication</li> <li>• User management session accounting</li> </ul>

**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**

**Figure 4-1 Authenticating User Log In**



272799

## Authorization

Authorization restricts the actions that a user is allowed to perform.

## Accounting

Accounting tracks and maintains a log of every SVS management session. You can use this information to generate reports for troubleshooting and auditing purposes. You can store accounting logs locally or send them to remote AAA servers.

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

## AAA Server Groups

Remote AAA server groups can provide fail-over in case one remote AAA server fails to respond. If the first server in the group fails, the next server in the group is tried until a server responds. Multiple server groups can provide fail-over for each other in this same way.

If all remote server groups fail, the local database is used for authentication.

## Prerequisites for AAA

Authentication using remote AAA servers requires that the following be in place:

- At least one TACACS+ or RADIUS server is IP reachable
- The VSM is configured as an AAA server client.
- A shared secret key is configured on the VSM and the remote AAA server.

See the [“Configuring Shared Keys” procedure on page 6-9](#).

## AAA Guidelines and Limitations

The Cisco Nexus 1000V does not support user names made up of all numeric characters and does not create local user names made up of all numeric characters. If a username made up of all numeric characters exists on an AAA server and is entered during login, the Cisco Nexus 1000V does not authenticate the user.

## Default Settings

The following table lists the AAA defaults.

Parameters	Default
Console authentication method	<b>local</b>
Default authentication method	<b>local</b>
Login authentication failure messages	Disabled

## Configuring AAA

This section includes the following topics:


- [Configuring a Login Authentication Method, page 4-6](#)
- [Enabling Login Authentication Failure Messages, page 4-7](#)



***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

Use the following flow chart to configure AAA.

**Flow Chart: Configuring AAA**



**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**

## Configuring a Login Authentication Method

Use this procedure to configure the login authentication method.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.
- If authentication is to be done with TACACS+ server group(s), you have already added the group(s). For more information, see [Configuring a TACACS+ Server Group, page 6-12](#).

### SUMMARY STEPS

1. **config t**
2. **aaa authentication login {console | default} {group group-list [none] | local | none}**
3. **exit**
4. **show aaa authentication**
5. **copy running-config start-config**

### DETAILED STEPS

	Command	Purpose
Step 1	<b>config t</b>  <b>Example:</b> n1000v# config t n1000v(config)#	Places you into the CLI Global Configuration mode.
Step 2	<b>aaa authentication login {console   default} {group group-list [none]   local   none}</b>  <b>Example:</b> n1000v(config)# aaa authentication login console group tacgroup	Configures the console or default login authentication method. <ul style="list-style-type: none"> <li>• <b>group:</b> Authentication is done by server group(s).               <ul style="list-style-type: none"> <li>– <b>group-list:</b> List server group names separated by spaces; or none for no authentication.</li> </ul> </li> <li>• <b>local:</b> The local database is used for authentication.</li> </ul> <p><b>Note</b> Local is the default and is used when no methods are configured or when all the configured methods fail to respond.</p> <ul style="list-style-type: none"> <li>• <b>none:</b> Authentication is done by username.</li> </ul>
Step 3	<b>exit</b>  <b>Example:</b> n1000v(config)# exit n1000v#	Exits the CLI Global Configuration mode and returns you to EXEC mode.

**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**

	Command	Purpose
Step 4	<b>show aaa authentication</b>  <b>Example:</b> n1000v# show aaa authentication default: group tacgroup console: group tacgroup n1000v#	(Optional) Displays the configured login authentication method.
Step 5	<b>copy running-config startup-config</b>  <b>Example:</b> n1000v# copy running-config startup-config	(Optional) Copies the running configuration to the startup configuration.

## Enabling Login Authentication Failure Messages

Use this procedure to enable the login authentication failure message to displays if the remote AAA servers do not respond.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.
- The following is the Login Authentication Failure message:

```
Remote AAA servers unreachable; local authentication done.
Remote AAA servers unreachable; local authentication failed.
```

### SUMMARY STEPS

- config t**
- aaa authentication login error-enable**
- exit**
- show aaa authentication login error-enable**
- copy running-config start-config**

### DETAILED STEPS

	Command	Purpose
Step 1	<b>config t</b>  <b>Example:</b> n1000v# config t n1000v(config)#	Places you in CLI Global Configuration mode.
Step 2	<b>aaa authentication login error-enable</b>  <b>Example:</b> n1000v(config)# aaa authentication login error-enable n1000v(config)#	Enables login authentication failure messages. The default is disabled.

**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**

	Command	Purpose
Step 3	<b>exit</b>  <b>Example:</b> n1000v(config)# exit n1000v#	Exits CLI Global Configuration mode and returns you to EXEC mode.
Step 4	<b>show aaa authentication login error-enable</b>  <b>Example:</b> n1000v# show aaa authentication login error-enable enabled n1000v#	(Optional) Displays the login failure message configuration.
Step 5	<b>copy running-config startup-config</b>  <b>Example:</b> n1000v# copy running-config startup-config	(Optional) Copies the running configuration to the startup configuration.

## Verifying AAA Configuration

To display AAA configuration information, perform one of the following tasks:

Command	Purpose
<b>show aaa authentication [login {error-enable   mschap}]</b>	Displays AAA authentication information. See <a href="#">Example 4-1 on page 4-8</a>
<b>show aaa groups</b>	Displays the AAA server group configuration.
<b>show running-config aaa [all]</b>	Displays the AAA configuration in the running configuration. See <a href="#">Example 4-2 on page 4-8</a>
<b>show startup-config aaa</b>	Displays the AAA configuration in the startup configuration. See <a href="#">Example 4-3 on page 4-9</a>

### Example 4-1 show aaa authentication

```
n1000v# show aaa authentication login error-enable
disabled
```

### Example 4-2 show running config aaa

```
n1000v# show running-config aaa all
version 4.0(1)
aaa authentication login default local
aaa accounting default local
no aaa authentication login error-enable
no aaa authentication login mschap enable
no radius-server directed-request
no snmp-server enable traps aaa server-state-change
```

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

```
no tacacs-server directed-request
n1000v#
```

**Example 4-3** show startup-config aaa

```
n1000v# show startup-config aaa
version 4.0(1)svs#
```

## Example AAA Configuration

The following is an AAA configuration example:

```
aaa authentication login default group tacacs
aaa authentication login console group tacacs
```

## Additional References

For additional information related to implementing AAA, see the following sections:

- [Related Documents, page 4-9](#)
- [Standards, page 4-9](#)

## Related Documents

Related Topic	Document Title
System Management	<i>Cisco Nexus 1000V System Management Configuration Guide, Release 4.2(1)SV1(5.1)</i>
CLI	<i>Cisco Nexus 1000V Installation and Upgrade Guide, Release 4.2(1)SV1(5.1)</i>
TACACS+ Security protocol	<a href="#">Chapter 6, “Configuring TACACS+”</a>

## Standards

Standards	Title
No new or modified standards are supported by this feature, and support for existing standards has not been modified by this feature.	—

*Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).*

## Feature History for AAA

This section provides the AAA release history.

Feature Name	Releases	Feature Information
AAA	4.0(4)SV1(1)	This feature was introduced.



## CHAPTER 5

# Configuring RADIUS

---

This chapter describes how to configure RADIUS protocol on Cisco NX-OS devices.

This chapter includes the following sections:

- [Information About RADIUS, page 5-1](#)
- [Prerequisites for RADIUS, page 5-4](#)
- [Guidelines and Limitations, page 5-4](#)
- [Default Settings, page 5-5](#)
- [Configuring RADIUS Servers, page 5-5](#)
- [Verifying RADIUS Configuration, page 5-22](#)
- [Displaying RADIUS Server Statistics, page 5-22](#)
- [Example RADIUS Configuration, page 5-22](#)
- [Additional References, page 5-22](#)
- [Feature History for RADIUS, page 5-23](#)

## Information About RADIUS

The RADIUS distributed client/server system allows you to secure networks against unauthorized access. In the Cisco implementation, RADIUS clients run on Cisco NX-OS devices and send authentication and accounting requests to a central RADIUS server that contains all user authentication and network service access information.

This section includes the following topics:

- [RADIUS Network Environments, page 5-1](#)
- [RADIUS Operation, page 5-2](#)
- [Vendor-Specific Attributes, page 5-3](#)

## RADIUS Network Environments

RADIUS can be implemented in a variety of network environments that require high levels of security while maintaining network access for remote users.

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

You can use RADIUS in the following network environments that require access security:

- Networks with multiple-vendor network devices, each supporting RADIUS. For example, network devices from several vendors can use a single RADIUS server-based security database.
- Networks already using RADIUS. You can add a Cisco NX-OS device with RADIUS to the network. This action might be the first step when you make a transition to a AAA server.
- Networks that require resource accounting. You can use RADIUS accounting independent of RADIUS authentication or authorization. The RADIUS accounting functions allow data to be sent at the start and end of services, indicating the amount of resources (such as time, packets, bytes, and so on) used during the session. An Internet service provider (ISP) might use a freeware-based version of the RADIUS access control and accounting software to meet special security and billing needs.
- Networks that support authentication profiles. Using the RADIUS server in your network, you can configure AAA authentication and set up per-user profiles. Per-user profiles enable the NX-OS device to better manage ports using their existing RADIUS solutions and to efficiently manage shared resources to offer different service-level agreements.

## RADIUS Operation

When a user attempts to log in to the and authenticate to an NX-OS device using RADIUS, the following happens:

1. The user is prompted for and enters a username and password.
2. The username and encrypted password are sent over the network to the RADIUS server.
3. The user receives one of the following responses from the RADIUS server:
  - ACCEPT—The user is authenticated.
  - REJECT—The user is not authenticated and is prompted to reenter the username and password, or access is denied.
  - CHALLENGE—A challenge is issued by the RADIUS server. The challenge collects additional data from the user.
  - CHANGE PASSWORD—A request is issued by the RADIUS server, asking the user to select a new password.

The ACCEPT or REJECT response is bundled with additional data that is used for EXEC or network authorization. You must first complete RADIUS authentication before using RADIUS authorization. The additional data included with the ACCEPT or REJECT packets consists of the following:

- Services that the user can access, including Telnet, rlogin, or local-area transport (LAT) connections, and Point-to-Point Protocol (PPP), Serial Line Internet Protocol (SLIP), or EXEC services.
- Connection parameters, including the host or client IPv4 address, access list, and user timeouts.

## RADIUS Server Monitoring


An unresponsive RADIUS server can cause a delay in processing AAA requests. You can periodically monitor a RADIUS server to check whether it is responding (or alive) to save time in processing AAA requests. Unresponsive RADIUS servers are marked as dead and are not sent AAA requests. Dead RADIUS servers are periodically monitored and returned to the alive state once they respond. This monitoring process verifies that a RADIUS server is in a working state before real AAA requests are



**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**

sent its way. Whenever a RADIUS server changes to the dead or alive state, a Simple Network Management Protocol (SNMP) trap is generated and an error message is displayed indicating that a failure is taking place. See [Figure 5-1](#).

**Figure 5-1 RADIUS Server States**



**Note**

The monitoring interval for alive servers and dead servers are different and can be configured by the user. The RADIUS server monitoring is performed by sending a test authentication request to the RADIUS server.

## Vendor-Specific Attributes

The Internet Engineering Task Force (IETF) draft standard specifies a method for communicating VSAs between the network access server and the RADIUS server. The IETF uses attribute 26. VSAs allow vendors to support their own extended attributes that are not suitable for general use. The Cisco RADIUS implementation supports one vendor-specific option using the format recommended in the specification. The Cisco vendor ID is 9, and the supported option is vendor type 1, which is named `cisco-av-pair`. The value is a string with the following format:

```
protocol : attribute separator value *
```

The protocol is a Cisco attribute for a particular type of authorization, separator is = (equal sign) for mandatory attributes, and \* (asterisk) indicates optional attributes.

When you use RADIUS servers for authentication, the RADIUS protocol directs the RADIUS server to return user attributes, such as authorization information, along with authentication results. This authorization information is specified through VSAs.

The following are supported VSA protocol options:

- Shell—Protocol used in access-accept packets to provide user profile information.
- Accounting—Protocol used in accounting-request packets. If a value contains any white spaces, you should enclose the value within double quotation marks.

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

The following are supported attributes:

- **roles**—Lists all the roles to which the user belongs. The value field is a string that lists the role names delimited by white space. For example, if the user belongs to roles `network-operator` and `vdc-admin`, the value field would be “`network-operator vdc-admin`.” This attribute, which the RADIUS server sends in the VSA portion of the Access-Accept frames, can only be used with the shell protocol value. The following examples show the roles attribute as supported by Cisco ACS:

```
shell:roles="network-operator vdc-admin"
```

```
shell:roles*"network-operator vdc-admin"
```

The following examples show the roles attribute as supported by FreeRADIUS:

```
Cisco-AVPair = "shell:roles=\"network-operator vdc-admin\""
```

```
Cisco-AVPair = "shell:roles*\"network-operator vdc-admin\""
```

If you are using Cisco ACS and intend to use the same ACS group for both Cisco Nexus 1000V and Cisco UCS authentication, use the following roles attribute:

```
cisco-av-pair*shell:roles="network-admin admin"
```



**Note**

When you specify a VSA as `shell:roles*"network-operator vdc-admin"` or `"shell:roles*\"network-operator vdc-admin\""`, this VSA is flagged as an optional attribute and other Cisco devices ignore this attribute.

- **accountinginfo**—Stores accounting information in addition to the attributes covered by a standard RADIUS accounting protocol. This attribute is sent only in the VSA portion of the Account-Request frames from the RADIUS client on the switch. It can be used only with the accounting protocol data units (PDUs).

## Prerequisites for RADIUS

RADIUS has the following prerequisites:

- You already know the RADIUS server IP addresses or hostnames.
- You already know the key(s) used to secure RADIUS communication in your network.
- The device is already configured as a RADIUS client of the AAA servers.

## Guidelines and Limitations

RADIUS has the following guidelines and limitations:

- You can configure a maximum of 64 RADIUS servers.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

## Default Settings

Table 5-1 lists the RADIUS default settings.

**Table 5-1** Default RADIUS Parameters

Parameters	Default
Server roles	Authentication and accounting
Dead timer interval	0 minutes
Retransmission count	1
Retransmission timer interval	5 seconds
Idle timer interval	0 minutes
Periodic server monitoring username	test
Periodic server monitoring password	test

## Configuring RADIUS Servers

This section includes the following topics:

- [Configuring RADIUS Server Hosts, page 5-6](#)
- [Configuring the Global RADIUS Key, page 5-7](#)
- [Configuring a RADIUS Server Key, page 5-8](#)
- [Configuring RADIUS Server Groups, page 5-9](#)
- [Enabling RADIUS Server Directed Requests, page 5-10](#)
- [Setting the Global Timeout for All RADIUS Servers, page 5-12](#)
- [Configuring a Global Retry Count for All RADIUS Servers, page 5-13](#)
- [Setting the Timeout Interval for a Single RADIUS Server, page 5-14](#)
- [Configuring Retries for a Single RADIUS Server, page 5-15](#)
- [Configuring a RADIUS Accounting Server, page 5-16](#)
- [Configuring a RADIUS Authentication Server, page 5-17](#)
- [Configuring Periodic RADIUS Server Monitoring, page 5-18](#)
- [Configuring the Global Dead-Time Interval, page 5-20](#)
- [Manually Monitoring RADIUS Servers or Groups, page 5-21](#)



### Note

Be aware that the Cisco NX-OS commands for this feature may differ from those used in Cisco IOS.

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

## Configuring RADIUS Server Hosts

Use this procedure to configure the IP address or the hostname for each RADIUS server to be used for authentication.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.
- You can configure up to 64 RADIUS servers.
- All RADIUS server hosts are automatically added to the default RADIUS server group.

### SUMMARY STEPS

1. **config t**
2. **radius-server host {ipv4-address | host-name}**
3. **exit**
4. **show radius-server**
5. **copy running-config startup-config**

### DETAILED STEPS

	Command	Purpose
Step 1	<b>config t</b>  <b>Example:</b> n1000v# config t n1000v(config)#	Places you into the CLI Global Configuration mode.
Step 2	<b>radius-server host {ipv4-address   host-name}</b>  <b>Example:</b> n1000v(config)# radius-server host 10.10.1.1	Defines the IP address or hostname for the RADIUS server.
Step 3	<b>exit</b>  <b>Example:</b> n1000v(config)# exit n1000v#	Returns you to the CLI EXEC mode.
Step 4	<b>show radius-server</b>  <b>Example:</b> n1000v# show radius-server	(Optional) Displays the RADIUS server configuration.
Step 5	<b>copy running-config startup-config</b>  <b>Example:</b> n1000v# copy running-config startup-config	(Optional) Saves this change in the running configuration to the startup configuration.

*Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).*

## Configuring the Global RADIUS Key

Use this procedure to configure the key that is used by all RADIUS servers to authenticate with the Cisco Nexus 1000V.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.
- You know the global key that is used for RADIUS server authentication.

### SUMMARY STEPS

1. `config t`
2. `radius-server key [0 | 7] key-value`
3. `exit`
4. `show radius-server`
5. `copy running-config startup-config`

### DETAILED STEPS

To configure a global preshared key, follow these steps:

	Command	Purpose
Step 1	<code>config t</code>  <b>Example:</b> n1000v# config t n1000v(config)#	Places you into the CLI Global Configuration mode.
Step 2	<code>radius-server key [0   7] key-value</code>  <b>Example:</b> n1000v(config)# radius-server key 0 QsEfThUkO	Specifies a preshared key for all RADIUS servers. You can specify a clear text (0) or encrypted (7) preshared key. The default format is clear text. The maximum length is 63 characters.  By default, no preshared key is configured.
Step 3	<code>exit</code>  <b>Example:</b> n1000v(config)# exit n1000v#	Returns you to the CLI EXEC mode.
Step 4	<code>show radius-server</code>  <b>Example:</b> n1000v# show radius-server	(Optional) Displays the RADIUS server configuration.  <b>Note</b> The preshared keys are saved in encrypted form in the running configuration. Use the <b>show running-config</b> command to display the encrypted preshared keys.
Step 5	<code>copy running-config startup-config</code>  <b>Example:</b> n1000v# copy running-config startup-config	(Optional) Saves this change in the running configuration to the startup configuration.

**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**

## Configuring a RADIUS Server Key

Use this procedure to configure a key for a single RADIUS server host.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.
- You have the key to be used for the remote RADIUS host.

### SUMMARY STEPS

1. **config t**
2. **radius-server host** {ipv4-address | host-name} **key** key-value
3. **exit**
4. **show radius-server**
5. **copy running-config startup-config**

### DETAILED STEPS

	Command	Purpose
Step 1	<b>config t</b>  <b>Example:</b> n1000v# config t n1000v(config)#	Places you into the CLI Global Configuration mode.
Step 2	<b>radius-server host</b> {ipv4-address   host-name} <b>key</b> [0   7] key-value  <b>Example:</b> n1000v(config)# radius-server host 10.10.1.1 key 0 PlIjUhYg	Specifies a preshared key for a specific RADIUS server. You can specify a clear text (0) or encrypted (7) preshared key. The default format is clear text. The maximum length is 63 characters.  This preshared key is used instead of the global preshared key.
Step 3	<b>exit</b>  <b>Example:</b> n1000v(config)# exit n1000v#	Returns you to the CLI EXEC mode.
Step 4	<b>show radius-server</b>  <b>Example:</b> n1000v# show radius-server	(Optional) Displays the RADIUS server configuration.  <b>Note</b> The preshared keys are saved in encrypted form in the running configuration. Use the <b>show running-config</b> command to display the encrypted preshared keys.
Step 5	<b>copy running-config startup-config</b>  <b>Example:</b> n1000v# copy running-config startup-config	(Optional) Saves this change in the running configuration to the startup configuration.

**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**

## Configuring RADIUS Server Groups

Use this procedure to configure a RADIUS server group whose member servers share authentication functions.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.
- All servers in a RADIUS server group must belong to the RADIUS protocol.
- The servers in the group are tried in the same order in which you configure them.

### SUMMARY STEPS

1. `config t`
2. `aaa group server radius group-name`
3. `server {ipv4-address | server-name}`
4. `deadtime minutes`
5. `use-vrf vrf-name`
6. (Optional) `source-interface {interface-type} {interface-number}`
7. (Optional) `show radius-server groups [group-name]`
8. (Optional) `copy running-config startup-config`

### DETAILED STEPS

	Command	Purpose
Step 1	<code>config t</code>  <b>Example:</b> n1000v# config t n1000v(config)#	Places you into the CLI Global Configuration mode.
Step 2	<code>aaa group server radius group-name</code>  <b>Example:</b> n1000v(config)# aaa group server radius RadServer n1000v(config-radius)#	Creates a RADIUS server group and enters the RADIUS server group configuration mode for that group. The <i>group-name</i> argument is a case-sensitive alphanumeric string with a maximum length of 127 characters.
Step 3	<code>server {ipv4-address   server-name}</code>  <b>Example:</b> n1000v(config-radius)# server 10.10.1.1	Configures the RADIUS server as a member of the RADIUS server group.  <b>Tip</b> If the specified RADIUS server is not found, configure it using the <b>radius-server host</b> command and retry this command.

**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**

	Command	Purpose
Step 4	<b>deadtime</b> <i>minutes</i>  <b>Example:</b> n1000v(config-radius)# deadtime 30	(Optional) Configures the monitoring dead time. The default is 0 minutes. The range is from 1 through 1440.  <b>Note</b> If the dead-time interval for a RADIUS server group is greater than zero (0), that value takes precedence over the global dead-time value (see the “Configuring the Global Dead-Time Interval” section on page 5-20).
Step 5	<b>use-vrf</b> <i>vrf-name</i>  <b>Example:</b> n1000v(config-radius)# use-vrf vrf1	(Optional) Specifies the VRF to use to contact the servers in the server group.
Step 6	<b>source-interface</b> { <i>interface-type</i> } { <i>interface-number</i> }  <b>Example:</b> n1000v(config-radius)# source-interface mgmt0 n1000v(config-radius)#	(Optional) Specifies a source interface to be used to reach the RADIUS server. <ul style="list-style-type: none"> <li>• loopback = Virtual interface number from 0 to 1023</li> <li>• mgmt = Management interface 0</li> <li>• null = Null interface 0</li> <li>• port-channel = Port channel number from 1 to 4096</li> </ul>
Step 7	<b>show radius-server groups</b> [ <i>group-name</i> ]  <b>Example:</b> n1000v(config-radius)# show radius-server group total number of groups:2  following RADIUS server groups are configured: group Radservers: server: 10.10.1.1 deadtime is 30 group test: deadtime is 30	(Optional) Displays the RADIUS server group configuration.
Step 8	<b>copy running-config startup-config</b>  <b>Example:</b> n1000v(config-radius)# copy running-config startup-config	(Optional) Saves this change in the running configuration to the startup configuration.

## Enabling RADIUS Server Directed Requests

Use this procedure to let users designate the RADIUS server to send their authentication request to. This is called a directed-request.

If you enable this option, a user can log in as *username@vrfname:hostname*, where *vrfname* is the VRF to use and *hostname* is the name of a configured RADIUS server.



### Note

User-specified logins are supported only for Telnet sessions.



***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

## BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.
- Directed requests are disabled by default.

## SUMMARY STEPS

1. **config t**
2. **radius-server directed-request**
3. **exit**
4. **show radius-server directed-request**
5. **copy running-config startup-config**

## DETAILED STEPS

	Command	Purpose
Step 1	<b>config t</b>  <b>Example:</b> n1000v# config t n1000v(config)#	Places you into the CLI Global Configuration mode.
Step 2	n1000v(config)# radius-server directed-request  <b>Example:</b> n1000v(config)# radius-server directed-request	Enables directed requests. The default is disabled.
Step 3	<b>exit</b>  <b>Example:</b> n1000v(config)# exit n1000v#	Returns you to the CLI EXEC mode.
Step 4	<b>show radius-server directed-request</b>  <b>Example:</b> n1000v# show radius-server directed-request	(Optional) Displays the directed request configuration.
Step 5	<b>copy running-config startup-config</b>  <b>Example:</b> n1000v# copy running-config startup-config	(Optional) Copies the running configuration to the startup configuration.

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

## Setting the Global Timeout for All RADIUS Servers

Use this procedure to configure the global timeout interval specifying how long to wait for a response from a RADIUS server before declaring a timeout failure.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.
- The timeout specified in the [“Setting the Timeout Interval for a Single RADIUS Server”](#) procedure on page 5-14 overrides the global RADIUS timeout.

### SUMMARY STEPS

- config t**
- radius-server timeout *seconds***
- exit**
- show radius-server**
- copy running-config startup-config**

### DETAILED STEPS

	Command	Purpose
Step 1	<b>config t</b>  <b>Example:</b> n1000v# config t n1000v(config)#	Places you into the CLI Global Configuration mode.
Step 2	<b>radius-server timeout <i>seconds</i></b>  <b>Example:</b> n1000v(config)# radius-server timeout 10	Specifies the transmission timeout interval for RADIUS servers. The default timeout interval is 5 seconds and the allowable range is from 1 to 60 seconds.
Step 3	<b>exit</b>  <b>Example:</b> n1000v(config)# exit n1000v#	Returns you to the CLI EXEC mode.
Step 4	<b>show radius-server</b>  <b>Example:</b> n1000v# show radius-server	(Optional) Displays the RADIUS server configuration.
Step 5	<b>copy running-config startup-config</b>  <b>Example:</b> n1000v# copy running-config startup-config	(Optional) Saves this change in the running configuration to the startup configuration.

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

## Configuring a Global Retry Count for All RADIUS Servers

Use this procedure to configure the maximum number of times to retry transmitting to a RADIUS server before reverting to local authentication. This setting is applied to all RADIUS servers.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.
- By default, retransmission to a RADIUS server is only tried once before reverting to local authentication.
- You can increase the number of retries up to a maximum of five.
- The retry count specified for a single RADIUS server in the [“Configuring Retries for a Single RADIUS Server”](#) procedure on page 5-15, overrides this global setting.

### SUMMARY STEPS

1. **config t**
2. **radius-server retransmission *count***
3. **radius-server timeout *seconds***
4. **exit**
5. **show radius-server**
6. **copy running-config startup-config**

### DETAILED STEPS

	Command	Purpose
Step 1	<b>config t</b>  <b>Example:</b> n1000v# config t n1000v(config)#	Places you into the CLI Global Configuration mode.
Step 2	<b>radius-server retransmit <i>count</i></b>  <b>Example:</b> n1000v(config)# radius-server retransmit 3	Defines the number of retransmits allowed before reverting to local authentication. This is a global setting that applies to all RADIUS servers. The default number of retransmits is 1 and the range is from 0 to 5.
Step 3	<b>exit</b>  <b>Example:</b> n1000v(config)# exit n1000v#	Returns you to the CLI EXEC mode.

**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**

	Command	Purpose
Step 4	<b>show radius-server</b>  <b>Example:</b> n1000v# show radius-server	(Optional) Displays the RADIUS server configuration.
Step 5	<b>copy running-config startup-config</b>  <b>Example:</b> n1000v# copy running-config startup-config	(Optional) Saves this change in the running configuration to the startup configuration.

## Setting the Timeout Interval for a Single RADIUS Server

Use this procedure to configure how long to wait for a response from a RADIUS server before declaring a timeout failure.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.
- The timeout specified for a single RADIUS server overrides the timeout defined in the [“Setting the Global Timeout for All RADIUS Servers”](#) procedure on page 5-12.

### SUMMARY STEPS

- config t**
- radius-server host** {*ipv4-address* | *host-name*} **timeout** *seconds*
- exit**
- show radius-server**
- copy running-config startup-config**

### DETAILED STEPS

	Command	Purpose
Step 1	<b>config t</b>  <b>Example:</b> n1000v# config t n1000v(config)#	Places you into the CLI Global Configuration mode.
Step 2	<b>radius-server host</b> { <i>ipv4-address</i>   <i>host-name</i> } <b>timeout</b> <i>seconds</i>  <b>Example:</b> n1000v(config)# radius-server host server1 timeout 10	Specifies the timeout interval for the specified server. The default timeout interval is 5 seconds and the allowable range is from 1 to 60 seconds.  <b>Note</b> The timeout specified for a single RADIUS server overrides the global RADIUS timeout.

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

	Command	Purpose
Step 3	<b>exit</b>  <b>Example:</b> n1000v(config)# exit n1000v#	Returns you to the CLI EXEC mode.
Step 4	<b>show radius-server</b>  <b>Example:</b> n1000v# show radius-server	(Optional) Displays the RADIUS server configuration.
Step 5	<b>copy running-config startup-config</b>  <b>Example:</b> n1000v# copy running-config startup-config	(Optional) Saves this change in the running configuration to the startup configuration.

## Configuring Retries for a Single RADIUS Server

Use this procedure to configure the maximum number of times to retry transmitting to a RADIUS server before reverting to local authentication. This setting is applied to a single RADIUS server and takes precedence over the global retry count.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.
- By default, retransmission to a RADIUS server is only tried once before reverting to local authentication.
- You can increase the number of retries up to a maximum of five.
- The retry count specified for a single RADIUS server overrides the global setting made for all RADIUS servers.

### SUMMARY STEPS

1. **config t**
2. **radius-server host {ipv4-address | host-name} retransmit count**
3. **exit**
4. **show radius-server**
5. **copy running-config startup-config**

**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**

## DETAILED STEPS

	Command	Purpose
Step 1	<b>config t</b>  <b>Example:</b> n1000v# config t n1000v(config)#	Places you into the CLI Global Configuration mode.
Step 2	<b>radius-server host</b> { <i>ipv4-address</i>   <i>host-name</i> } <b>retransmit</b> <i>count</i>  <b>Example:</b> n1000v(config)# radius-server host server1 retransmit 3	Specifies the retransmission count for a specific server. The default is the global value.  <b>Note</b> This retransmit count for a single RADIUS server overrides the global setting for all RADIUS servers.
Step 3	<b>exit</b>  <b>Example:</b> n1000v(config)# exit n1000v#	Returns you to the CLI EXEC mode.
Step 4	<b>show radius-server</b>  <b>Example:</b> n1000v# show radius-server	(Optional) Displays the RADIUS server configuration.
Step 5	<b>copy running-config startup-config</b>  <b>Example:</b> n1000v# copy running-config startup-config	(Optional) Saves this change in the running configuration to the startup configuration.

## Configuring a RADIUS Accounting Server

Use this procedure to configure a server to perform accounting functions.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.
- By default, RADIUS servers are used for both accounting and authentication.
- You know the destination UDP port number for RADIUS accounting messages.

### SUMMARY STEPS

1. **config t**
2. **radius-server host** {*ipv4-address* | *host-name*} **acct-port** *udp-port*
3. **radius-server host** {*ipv4-address* | *host-name*} **accounting**
4. **exit**
5. **show radius-server**
6. **copy running-config startup-config**

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

## DETAILED STEPS

To configure the authentication and accounting attributes for RADIUS servers, follow these steps:

	Command	Purpose
Step 1	<b>config t</b>  <b>Example:</b> n1000v# config t n1000v(config)#	Places you into the CLI Global Configuration mode.
Step 2	<b>radius-server host</b> { <i>ipv4-address</i>   <i>host-name</i> } <b>acct-port</b> <i>udp-port</i>  <b>Example:</b> n1000v(config)# radius-server host 10.10.1.1 acct-port 2004	(Optional) Associates a specific host with the UDP port that receives RADIUS accounting messages. The default UDP port is 1812. The range is from 0 to 65535.
Step 3	<b>radius-server host</b> { <i>ipv4-address</i>   <i>host-name</i> } <b>accounting</b>  <b>Example:</b> n1000v(config)# radius-server host 10.10.1.1 accounting	(Optional) Designates the specific RADIUS host as an accounting server. The default is both accounting and authentication.
Step 4	<b>exit</b>  <b>Example:</b> n1000v(config)# exit n1000v#	Returns you to the CLI EXEC mode.
Step 5	<b>show radius-server</b>  <b>Example:</b> n1000v(config)# show radius-server	(Optional) Displays the RADIUS server configuration.
Step 6	<b>copy running-config startup-config</b>  <b>Example:</b> n1000v# copy running-config startup-config	(Optional) Saves this change in the running configuration to the startup configuration.

## Configuring a RADIUS Authentication Server

Use this procedure to configure a server to perform authentication functions.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.
- By default, RADIUS servers are used for both accounting and authentication.
- You know the destination UDP port number for RADIUS authentication messages.

### SUMMARY STEPS

1. **config t**
2. **radius-server host** {*ipv4-address* | *host-name*} **auth-port** *udp-port*
3. **radius-server host** {*ipv4-address* | *host-name*} **authentication**

**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**

4. **exit**
5. **show radius-server**
6. **copy running-config startup-config**

## DETAILED STEPS

To configure the authentication and accounting attributes for RADIUS servers, follow these steps:

	Command	Purpose
Step 1	<b>config t</b>  <b>Example:</b> n1000v# config t n1000v(config)#	Places you into the CLI Global Configuration mode.
Step 2	<b>radius-server host</b> { <i>ipv4-address</i>   <i>host-name</i> } <b>auth-port</b> <i>udp-port</i>  <b>Example:</b> n1000v(config)# radius-server host 10.10.2.2 auth-port 2005	(Optional) Associates a specific host with the UDP port that receives RADIUS authentication messages. The default UDP port is 1812. The range is from 0 to 65535.
Step 3	<b>radius-server host</b> { <i>ipv4-address</i>   <i>host-name</i> } <b>authentication</b>  <b>Example:</b> n1000v(config)# radius-server host 10.10.2.2 authentication	(Optional) Designates the specific RADIUS host as an authentication server. The default is both accounting and authentication.
Step 4	<b>exit</b>  <b>Example:</b> n1000v(config)# exit n1000v#	Returns you to the CLI EXEC mode.
Step 5	<b>show radius-server</b>  <b>Example:</b> n1000v(config)# show radius-server	(Optional) Displays the RADIUS server configuration.
Step 6	<b>copy running-config startup-config</b>  <b>Example:</b> n1000v# copy running-config startup-config	(Optional) Saves this change in the running configuration to the startup configuration.

## Configuring Periodic RADIUS Server Monitoring

Use this procedure to configure the monitoring of RADIUS servers.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.
- The test idle timer specifies the interval of time that elapses before a test packet is sent to a nonresponsive RADIUS server.



**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**



**Note** For security reasons, do not configure a username that is in the RADIUS database as a test username.



**Note** The default idle timer value is 0 minutes. When the idle time interval is 0 minutes, the NX-OS device does not perform periodic RADIUS server monitoring.

## SUMMARY STEPS

1. `config t`
2. `radius-server host {ipv4-address | host-name} test {idle-time minutes | password password [idle-time minutes] | username name [password password [idle-time minutes]]}`
3. `radius-server dead-time minutes`
4. `exit`
5. `show radius-server`
6. `copy running-config startup-config`

## DETAILED STEPS

	Command	Purpose
Step 1	<pre>config t</pre> <p><b>Example:</b> n1000v# config t n1000v(config)#</p>	Places you into the CLI Global Configuration mode.
Step 2	<pre>radius-server host {ipv4-address   host-name} test {idle-time minutes   password password [idle-time minutes]   username name [password password [idle-time minutes]]}</pre> <p><b>Example:</b> n1000v(config)# radius-server host 10.10.1.1 test username user1 password Ur2Gd2BH idle-time 3</p>	<p>Specifies parameters for server monitoring. The default username is test and the default password is test. The default value for the idle timer is 0 minutes. The valid range is 0 to 1440 minutes.</p> <p><b>Note</b> For periodic RADIUS server monitoring, you must set the idle timer to a value greater than 0.</p>
Step 3	<pre>radius-server dead-time minutes</pre> <p><b>Example:</b> n1000v(config)# radius-server dead-time 5</p>	Specifies the number of minutes to wait before sending a test packet to a RADIUS server that was declared dead. The default value is 0 minutes. The valid range is 1 to 1440 minutes.
Step 4	<pre>exit</pre> <p><b>Example:</b> n1000v(config)# exit n1000v#</p>	Returns you to the CLI EXEC mode.

**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**

	Command	Purpose
Step 5	<b>show radius-server</b>  <b>Example:</b> n1000v# show radius-server	(Optional) Displays the RADIUS server configuration.
Step 6	<b>copy running-config startup-config</b>  <b>Example:</b> n1000v# copy running-config startup-config	(Optional) Saves this change in the running configuration to the startup configuration.

## Configuring the Global Dead-Time Interval

Use this procedure to configure the dead-time interval for all RADIUS servers. The dead-time interval specifies the time to wait after declaring a RADIUS server dead, before sending out a test packet to determine if the server is now alive. The default value is 0 minutes.



### Note

When the dead-time interval is 0 minutes, RADIUS servers are not marked as dead even if they are not responding. You can configure the dead-time interval for a RADIUS server group (see the “[Configuring RADIUS Server Groups](#)” section on page 5-9).

## BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.

## SUMMARY STEPS

- config t**
- radius-server deadtime *minutes***
- exit**
- show radius-server**
- copy running-config startup-config**

## DETAILED STEPS

To configure the RADIUS dead-time interval, follow these steps:

	Command	Purpose
Step 1	<b>config t</b>  <b>Example:</b> n1000v# config t n1000v(config)#	Places you into the CLI Global Configuration mode.
Step 2	n1000v(config)# <b>radius-server deadtime <i>minutes</i></b>  <b>Example:</b> n1000v(config)# radius-server deadtime 5	Configures the dead-time interval. The default value is 0 minutes. The range is from 1 to 1440 minutes.

**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**

	Command	Purpose
Step 3	<b>exit</b>  <b>Example:</b> n1000v(config)# exit n1000v#	Returns you to the CLI EXEC mode.
Step 4	<b>show radius-server</b>  <b>Example:</b> n1000v# show radius-server	(Optional) Displays the RADIUS server configuration.
Step 5	<b>copy running-config startup-config</b>  <b>Example:</b> n1000v# copy running-config startup-config	(Optional) Saves this change in the running configuration to the startup configuration.

## Manually Monitoring RADIUS Servers or Groups

Use this procedure to manually send a test message to a RADIUS server or to a server group.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.

### SUMMARY STEPS

- test aaa server radius** {*ipv4-address* | *host-name*} [**vrf** *vrf-name*] *username password*
- test aaa group** *group-name username password*

### DETAILED STEPS

	Command	Purpose
Step 1	<b>test aaa server radius</b> { <i>ipv4-address</i>   <i>server-name</i> } [ <b>vrf</b> <i>vrf-name</i> ] <i>username password</i>  <b>Example:</b> n1000v# test aaa server radius 10.10.1.1 user1 Ur2Gd2BH	Sends a test message to a RADIUS server to confirm availability.
Step 1	<b>test aaa group</b> <i>group-name username password</i>  <b>Example:</b> n1000v# test aaa group RadGroup user2 As3He3CI	Sends a test message to a RADIUS server group to confirm availability.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

## Verifying RADIUS Configuration

Use the commands in this section to verify the RADIUS configuration. For detailed information about show command output, see the *Cisco Nexus 1000V Command Reference, Release 4.2(1)SV1(5.1)*.

Command	Purpose
<code>show running-config radius [all]</code>	Displays the RADIUS configuration in the running configuration.
<code>show startup-config radius</code>	Displays the RADIUS configuration in the startup configuration.
<code>show radius-server [server-name   ipv4-address] [directed-request   groups   sorted   statistics]</code>	Displays all configured RADIUS server parameters.

## Displaying RADIUS Server Statistics

Use the following command to display statistics for RADIUS server activity.

```
show radius-server statistics {hostname | ipv4-address }
```

## Example RADIUS Configuration

The following example shows how to configure RADIUS:

```
radius-server key 7 "ToIkLhPpG"
radius-server host 10.10.1.1 key 7 "ShMoMhTl" authentication accounting
aaa group server radius RadServer
    server 10.10.1.1
```

## Additional References

For additional information related to implementing RADIUS, see the following sections:

- [Related Documents, page 5-22](#)
- [Standards, page 5-23](#)

## Related Documents

Related Topic	Document Title
Command reference	<i>Cisco Nexus 1000V Command Reference, Release 4.2(1)SV1(5.1)</i>

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

## Standards

Standards	Title
No new or modified standards are supported by this feature, and support for existing standards has not been modified by this feature.	—

## Feature History for RADIUS

This section provides the RADIUS release history.

Feature Name	Releases	Feature Information
RADIUS	4.0(4)SV1(1)	This feature was introduced.

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***



## CHAPTER 6

# Configuring TACACS+

---

This chapter describes how to configure the Terminal Access Controller Access Control System Plus (TACACS+) protocol.

This chapter includes the following sections:

- [Information About TACACS+](#), page 6-1
- [Prerequisites for TACACS+](#), page 6-4
- [Guidelines and Limitations](#), page 6-4
- [Default Settings](#), page 6-4
- [Configuring TACACS+](#), page 6-5
- [Displaying Statistics for a TACACS+ Host](#), page 6-22
- [Example TACACS+ Configuration](#), page 6-23
- [Additional References](#), page 6-24
- [Feature History for TACACS+](#), page 6-23

## Information About TACACS+

You can use TACACS+ to provide centralized validation of users attempting to gain access to a device. TACACS+ services are maintained in a database on a TACACS+ daemon running, typically, on a UNIX or Windows NT workstation. You must have access to and must configure a TACACS+ server before the configured TACACS+ features on your device are available.

The TACACS+ security protocol provides centralized validation of users attempting to gain access to a device. TACACS+ services are maintained in a database on a TACACS+ daemon running, typically, on a UNIX or Windows NT workstation. You must have access to and must configure a TACACS+ server before the configured TACACS+ features on your device are available.

TACACS+ provides for separate authentication, authorization, and accounting services. The TACACS+ daemon provides each service independently. Each service can be tied into its own database to take advantage of other services available on that server or on the network, depending on the capabilities of the daemon.

The TACACS+ client/server protocol uses TCP (TCP port 49) for transport requirements. Centralized authentication is provided using the TACACS+ protocol.

This section includes the following topics:

- [TACACS+ Operation for User Login](#), page 6-2

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

- Default TACACS+ Server Encryption Type and Preshared Key, page 6-2
- TACACS+ Server Monitoring, page 6-3
- Vendor-Specific Attributes, page 6-3

## TACACS+ Operation for User Login

The following sequence of events take place when you attempt to login to a TACACS+ server using Password Authentication Protocol (PAP):

1. When a connection is established, the TACACS+ daemon is contacted to obtain the username and password.




---

**Note** TACACS+ allows an arbitrary conversation between the daemon and the user until the daemon receives enough information to authenticate the user. This action is usually done by prompting for a username and password combination, but may include prompts for additional information, such as mother's maiden name.

---

2. The TACACS+ daemon provides one of the following responses:
  - a. ACCEPT—User authentication succeeds and service begins. If user authorization is needed, authorization begins.
  - b. REJECT—User authentication failed. The TACACS+ daemon either denies further access to the user or prompts the user to retry the login sequence.
  - c. ERROR—An error occurred at some time during authentication either at the daemon or in the network connection. If an ERROR response is received, the device tries to use an alternative method for authenticating the user.

If further authorization is required after authentication, the user also undergoes an additional authorization phase. Users must first successfully complete TACACS+ authentication before proceeding to TACACS+ authorization.

3. If TACACS+ authorization is required, the TACACS+ daemon is contacted and it returns an ACCEPT or REJECT authorization response. An ACCEPT response contains attributes that are used to direct the EXEC or NETWORK session for that user and determines the services that the user can access.

Services include the following:

- Telnet, rlogin, Point-to-Point Protocol (PPP), Serial Line Internet Protocol (SLIP), or EXEC services
- Connection parameters, including the host or client IP address, access list, and user timeouts

## Default TACACS+ Server Encryption Type and Preshared Key

You must configure the TACACS+ preshared key to authenticate to the TACACS+ server. A preshared key is a secret text string shared between the device and the TACACS+ server host. The length of the key is restricted to 63 characters and can include any printable ASCII characters (white spaces are not allowed). You can configure a global preshared secret key for all TACACS+ server configurations.

You can override the global preshared key assignment by explicitly using the **key** option when configuring and individual TACACS+ server.




[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

## TACACS+ Server Monitoring

Unresponsive TACACS+ servers are marked as dead and are not sent AAA requests. Dead TACACS+ servers are periodically monitored and brought back alive once they respond. This process confirms that a TACACS+ server is in a working state before real AAA requests are sent its way. The following figure shows how a TACACS+ server state change generates a Simple Network Management Protocol (SNMP) trap and an error message showing the failure before it impacts performance.

**Figure 6-1 TACACS+ Server States**



### Note

The monitoring interval for alive servers and dead servers are different and can be configured by the user. The TACACS+ server monitoring is performed by sending a test authentication request to the TACACS+ server.

## Vendor-Specific Attributes

The Internet Engineering Task Force (IETF) draft standard specifies a method for communicating vendor-specific attributes (VSAs) between the network access server and the TACACS+ server. The IETF uses attribute 26. VSAs allow vendors to support their own extended attributes that are not suitable for general use.

### Cisco VSA Format

The Cisco TACACS+ implementation supports one vendor-specific option using the format recommended in the IETF specification. The Cisco vendor ID is 9, and the supported option is vendor type 1, which is named `cisco-av-pair`. The value is a string with the following format:

```
protocol : attribute separator value *
```

The protocol is a Cisco attribute for a particular type of authorization, separator is = (equal sign) for mandatory attributes, and \* (asterisk) indicates optional attributes.

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

When you use TACACS+ servers for authentication, the TACACS+ protocol directs the TACACS+ server to return user attributes, such as authorization information, along with authentication results. This authorization information is specified through VSAs.

The following are supported VSA protocol options:

- Shell—Protocol used in access-accept packets to provide user profile information.
- Accounting—Protocol used in accounting-request packets. If a value contains any white spaces, you should enclose the value within double quotation marks.

The following are other supported attributes:

- roles—Lists all the roles to which the user belongs. The value consists of a string listing the role names delimited by white space. This subattribute, which the TACACS+ server sends in the VSA portion of the Access-Accept frames, can only be used with the shell protocol value.
- accountinginfo—Stores accounting information in addition to the attributes covered by a standard TACACS+ accounting protocol. This attribute is sent only in the VSA portion of the Account-Request frames from the TACACS+ client on the switch. It can be used only with the accounting protocol data units (PDUs).

## Prerequisites for TACACS+

TACACS+ has the following prerequisites:

- Obtain the IP addresses or hostnames for the TACACS+ servers.
- Obtain the preshared keys from the TACACS+ servers, if any.
- Ensure that the Cisco Nexus 1000V is configured as a TACACS+ client of the AAA servers.
- You have already configured AAA, including remote TACACS+ authentication using the following procedures:
  - [Configuring a Login Authentication Method, page 4-6](#)
  - [Configuring AAA, page 4-4](#)

## Guidelines and Limitations

TACACS+ has the following guidelines and limitations:

- You can configure a maximum of 64 TACACS+ servers.
- The logging level for TACACS + must be set to 5.

## Default Settings

The following table lists the TACACS+ defaults.

Parameters	Default
TACACS+	Disabled
Dead timer interval	0 minutes

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

Parameters	Default
Timeout interval	5 seconds
Idle timer interval	0 minutes
Periodic server monitoring username	test
Periodic server monitoring password	test

## Configuring TACACS+

This section includes the following topics:

- [Flow Chart: Configuring TACACS+, page 6-6](#)
- [Configuring a TACACS+ Server Host, page 6-11](#)
- [Configuring a TACACS+ Server Host, page 6-11](#)
- [Configuring Shared Keys, page 6-9](#)
- [Configuring a TACACS+ Server Group, page 6-12](#)
- [Enabling TACACS+ Server Directed Requests, page 6-15](#)
- [Setting the TACACS+ Global Timeout Interval, page 6-16](#)
- [Setting a Timeout Interval for an Individual TACACS+ Host, page 6-17](#)
- [Configuring the TCP Port for a TACACS+ Host, page 6-18](#)
- [Configuring Monitoring for a TACACS+ Host, page 6-20](#)
- [Configuring the TACACS+ Global Dead-Time Interval, page 6-21](#)




### Note

Be aware that the Cisco Nexus 1000V commands may differ from the Cisco IOS commands.

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***


Use the following flow chart to configure TACACS+.

**Flow Chart: Configuring TACACS+**




***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

Flow Chart: Configuring TACACS+ (Continued)



***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

Flow Chart: Configuring TACACS+ (Continued)



## Enabling or Disabling TACACS+

Use this procedure to either enable or disable TACACS+.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following.

- You are logged in to the CLI in EXEC mode.
- By default, TACACS+ is disabled. You must explicitly enable the TACACS+ feature to access the configuration and verification commands that support TACACS+ authentication.

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

**Caution**

When you disable TACACS+, all related configurations are automatically discarded.

**SUMMARY STEPS**

1. **config t**
2. **[no] tacacs+ enable**
3. **exit**
4. **copy running-config startup-config**

**DETAILED STEPS**

	<b>Command</b>	<b>Purpose</b>
<b>Step 1</b>	<b>config t</b>  <b>Example:</b> n1000v# config t n1000v(config)#	Places you in the CLI Global Configuration mode.
<b>Step 2</b>	<b>[no] tacacs+ enable</b>  <b>Example:</b> n1000v(config)# tacacs+ enable n1000v(config)#  <b>Example:</b> n1000v(config)# no tacacs+ enable n1000v(config)#	Enables or disables TACACS+.
<b>Step 3</b>	<b>exit</b>  <b>Example:</b> n1000v(config)# exit n1000v#	Exits the CLI Global Configuration mode and returns you to EXEC mode.
<b>Step 4</b>	<b>copy running-config startup-config</b>  <b>Example:</b> n1000v# copy running-config startup-config	(Optional) Copies the changes you made to the startup configuration.

## Configuring Shared Keys

Use this procedure to configure the following:

- The global key, or a secret text string shared between the Cisco Nexus 1000V and all TACACS+ server hosts
- The key, or secret text string shared between the Cisco Nexus 1000V and a single TACACS+ server host

**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**

## BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.
- You have already enabled TACACS+ for authentication. See the “[Enabling or Disabling TACACS+](#)” procedure on page 6-8.
- You know the key for the TACACS+ server host(s).
- By default, no global key is configured.

## SUMMARY STEPS

1. **config t**
2. **tacacs-server key [0 | 7] global\_key**
3. **exit**
4. **show tacacs-server**
5. **copy running-config startup-config**

## DETAILED STEPS

	Command	Purpose
Step 1	<b>config t</b>  <b>Example:</b> n1000v# config t n1000v(config)#	Places you in the CLI Global Configuration mode.
Step 2	Do one of the following: <ul style="list-style-type: none"> <li>• To configure a global key for all TACACS+ server hosts, continue with the next step.</li> <li>• To configure a key for a single TACACS+ server host, go to <a href="#">Step 5</a>.</li> </ul>	
Step 3	<b>tacacs-server key [0   7] global_key</b>  <b>Example:</b> n1000v(config)# tacacs-server key 0 QsEftkI# n1000v(config)#	Designates the global key shared between the Cisco Nexus 1000V and the TACACS+ server hosts. <b>0:</b> Specifies a clear text string (key) to follow. [the default] <b>7:</b> Specifies an encrypted string (key) to follow. <b>global_key:</b> A string of up to 63 characters. By default, no global key is configured.
Step 4	Go to <a href="#">Step 6</a> .	
Step 5	<b>tacacs-server host {ipv4-address   host-name} key [0   7] shared_key</b>  <b>Example:</b> n1000v(config)# tacacs-server host 10.10.1.1 key 0 PlIjUhYg n1000v(config)#	Designates the key shared between the Cisco Nexus 1000V and this specific TACACS+ server host. <b>0:</b> Specifies a clear text string (key) to follow. [the default] <b>7:</b> Specifies an encrypted string (key) to follow. <b>global_key:</b> A string of up to 63 characters. This shared key is used instead of the global shared key.



**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**

	Command	Purpose
Step 6	<b>exit</b>  <b>Example:</b> n1000v(config)# exit n1000v#	Exits the CLI Global Configuration mode and returns you to EXEC mode.
Step 7	<b>show tacacs-server</b>  <b>Example:</b> n1000v# show tacacs-server Global TACACS+ shared secret:***** timeout value:5 deadtime value:0 total number of servers:1  following TACACS+ servers are configured: 10.10.2.2: available on port:49	(Optional) Displays the TACACS+ server configuration.  <b>Note</b> The global shared key is saved in encrypted form in the running configuration. To display the key, use the <b>show running-config</b> command.
Step 8	<b>copy running-config startup-config</b>  <b>Example:</b> n1000v# copy running-config startup-config	(Optional) Copies these changes in the running configuration to the startup configuration.

## Configuring a TACACS+ Server Host

Use this procedure to configure a TACACS+ server as a TACACS+ host.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.
- You have already enabled TACACS+ for authentication.  
See the [“Enabling or Disabling TACACS+” procedure on page 6-8](#).
- You have already configured the shared key, using the following:  
[“Configuring Shared Keys” procedure on page 6-9](#)
- You know the IP addresses or the hostnames for the remote TACACS+ server hosts.
- All TACACS+ server hosts are added to the default TACACS+ server group.

### SUMMARY STEPS

1. **config t**
2. **tacacs-server host {ipv4-address | host-name}**
3. **exit**
4. **show tacacs-server**
5. **copy running-config startup-config**

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

## DETAILED STEPS

	Command	Purpose
Step 1	<b>config t</b>  <b>Example:</b> n1000v# config t n1000v(config)#	Places you in the CLI Global Configuration mode.
Step 2	<b>tacacs-server host</b> { <i>ipv4-address</i>   <i>host-name</i> }  <b>Example:</b> n1000v(config)# tacacs-server host 10.10.2.2	Configures the server IP address or hostname as a TACACS+ server host.
Step 3	<b>exit</b>  <b>Example:</b> n1000v(config)# exit n1000v#	Exits the CLI Global Configuration mode and returns you to EXEC mode.
Step 4	<b>show tacacs-server</b>  <b>Example:</b> n1000v# <b>show tacacs-server</b> timeout value:5 deadtime value:0 total number of servers:1  following TACACS+ servers are configured: 10.10.2.2: available on port:49 n1000v#	(Optional) Displays the TACACS+ server configuration.
Step 5	<b>copy running-config startup-config</b>  <b>Example:</b> n1000v# copy running-config startup-config	(Optional) Copies these changes in the running configuration to the startup configuration.

## Configuring a TACACS+ Server Group

Use this procedure to configure a TACACS+ server group whose member servers share authentication functions.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.
- All servers added to a TACACS+ server group must use the TACACS+ protocol.
- Once the TACACS+ server group is configured, the server members are tried in the same order in which you configured them.
- You have already enabled TACACS+ for authentication.  
See the [“Enabling or Disabling TACACS+” procedure on page 6-8](#).

## Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).

- You have already configured the preshared keys, using the following:  
[“Configuring Shared Keys” procedure on page 6-9](#)
- A TACACS+ server group can provide fail-over in case one server fails to respond. If the first server in the group fails, the next server in the group is tried until a server responds. Multiple server groups can provide fail-over for each other in this same way.

### SUMMARY STEPS

- `config t`
- `aaa group server tacacs+ group-name`
- `server {ipv4-address | host-name}`
- `deadtime minutes`
- `use-vrf vrf-name`
- (Optional) `source-interface {interface-type} {interface-number}`
- (Optional) `show tacacs-server groups`
- (Optional) `copy running-config startup-config`

### DETAILED STEPS

	Command	Purpose
Step 1	<b>config t</b>  <b>Example:</b> n1000v# config t n1000v(config)#	Places you in the CLI Global Configuration mode.
Step 2	<b>aaa group server tacacs+ group-name</b>  <b>Example:</b> n1000v(config)# aaa group server tacacs+ TacServer n1000v(config-tacacs)#	Creates a TACACS+ server group with the specified name and places you into the TACACS+ configuration mode for that group.
Step 3	<b>server {ipv4-address   host-name}</b>  <b>Example:</b> n1000v(config-tacacs)# server 10.10.2.2 n1000v(config-tacacs)#	Configures the TACACS+ server host-name or IP address as a member of the TACACS+ server group.  <b>Tip</b> If the specified TACACS+ server is not found, configure it using the <b>tacacs-server host</b> command and retry this command.
Step 4	<b>deadtime minutes</b>  <b>Example:</b> n1000v(config-tacacs)# deadtime 30 n1000v(config-tacacs)#	(Optional) Configures the monitoring dead time for this TACACS+ group. The default is 0 minutes. The range is from 0 through 1440.  <b>Note</b> If the dead-time interval for a TACACS+ server group is greater than zero (0), that value takes precedence over the global dead-time value (see the <a href="#">“Configuring the TACACS+ Global Dead-Time Interval” procedure on page 6-21</a> ).

**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**

	Command	Purpose
Step 5	<b>use-vrf</b> <i>vrf-name</i>  <b>Example:</b> n1000v(config-tacacs+)# use-vrf management n1000v(config-tacacs+)#	(Optional) Specifies the virtual routing and forwarding instance (VRF) to use to contact this server group.
Step 6	<b>source-interface</b> { <i>interface-type</i> } { <i>interface-number</i> }  <b>Example:</b> n1000v(config-tacacs+)# source-interface mgmt0 n1000v(config-tacacs+)#	(Optional) Specifies a source interface to be used to reach the TACACS+ server. <ul style="list-style-type: none"> <li>• loopback = Virtual interface number from 0 to 1023</li> <li>• mgmt = Management interface 0</li> <li>• null = Null interface 0</li> <li>• port-channel = Port channel number from 1 to 4096</li> </ul>
Step 7	<b>show tacacs-server groups</b>  <b>Example:</b> n1000v(config-tacacs+)# show tacacs-server groups total number of groups:1  following TACACS+ server groups are configured: group TacServer: server 10.10.2.2 on port 49 deadtime is 30 vrf is management n1000v(config-tacacs+)#	(Optional) Displays the TACACS+ server group configuration.
Step 8	<b>copy running-config startup-config</b>  <b>Example:</b> n1000v(config-tacacs+)# copy running-config startup-config	(Optional) Copies these changes made in the running configuration to the startup configuration.

**Example:**  
 n1000v(config)# **aaa group server tacacs+ TacServer**  
 n1000v(config-tacacs+)# **server 10.10.2.2**  
 n1000v(config-tacacs+)# **deadtime 30**  
 n1000v(config-tacacs+)# **use-vrf management**  
 n1000v(config-tacacs+)# **show tacacs-server groups**  
 total number of groups:1  
  
 following TACACS+ server groups are configured:  
     group TacServer:  
         server 10.10.2.2 on port 49  
         deadtime is 30  
         vrf is management  
 n1000v(config-tacacs+)#

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

## Enabling TACACS+ Server Directed Requests

Use this procedure to let users designate the TACACS+ server to send their authentication request to. This is called a directed-request.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.
- You have already enabled TACACS+ for authentication.  
See the [“Enabling or Disabling TACACS+” procedure on page 6-8](#).



#### Note

User-specified logins are only supported for Telnet sessions.

- When directed requests are enabled, the user can log in as *username@vrfname:hostname*, where *vrfname* is the VRF to use and *hostname* is the name of a configured TACACS+ server.

### SUMMARY STEPS

1. `config t`
2. `tacacs-server directed-request`
3. `exit`
4. `show tacacs-server directed-request`
5. `copy running-config startup-config`

### DETAILED STEPS

	Command	Purpose
Step 1	<code>config t</code>  <b>Example:</b> n1000v# <code>config t</code> n1000v(config)#	Places you in the CLI Global Configuration mode.
Step 2	<code>tacacs-server directed-request</code>  <b>Example:</b> n1000v(config)# <code>tacacs-server directed-request</code> n1000v(config)#	Enables use of directed requests for specifying the TACACS+ server to send an authentication request to when logging in. The default is disabled.
Step 3	<code>exit</code>  <b>Example:</b> n1000v(config)# <code>exit</code> n1000v#	Exits the CLI Global Configuration mode and returns you to EXEC mode.

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

	Command	Purpose
Step 4	<b>show tacacs-server directed-request</b>  <b>Example:</b> n1000v# show tacacs-server directed-request enabled n1000v#	(Optional) Displays the TACACS+ directed request configuration.
Step 5	<b>copy running-config startup-config</b>  <b>Example:</b> n1000v# copy running-config startup-config	(Optional) Copies the running configuration to the startup configuration.

## Setting the TACACS+ Global Timeout Interval

Use this procedure to set the interval in seconds that the Cisco Nexus 1000V waits for a response from any TACACS+ server before declaring a timeout.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.
- You have already enabled TACACS+ for authentication.  
See the [“Enabling or Disabling TACACS+” procedure on page 6-8](#).
- The timeout specified for an individual TACACS+ server overrides the global timeout interval. To set the timeout for an individual server, see the [“Setting a Timeout Interval for an Individual TACACS+ Host” procedure on page 6-17](#).

### SUMMARY STEPS

1. **config t**
2. **tacacs-server timeout *seconds***
3. **exit**
4. **show tacacs-server**
5. **copy running-config startup-config**

**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**

## DETAILED STEPS

	Command	Purpose
Step 1	<b>config t</b>  <b>Example:</b> n1000v# config t n1000v(config)#	Places you in the CLI Global Configuration mode.
Step 2	<b>tacacs-server timeout seconds</b>  <b>Example:</b> n1000v(config)# tacacs-server timeout 10	Specifies the interval in seconds that the Cisco Nexus 1000V waits for a response from a server. The default timeout interval is 5 seconds. The range is from 1 to 60 seconds.
Step 3	<b>exit</b>  <b>Example:</b> n1000v(config)# exit n1000v#	Exits the CLI Global Configuration mode and returns you to EXEC mode.
Step 4	<b>show tacacs-server</b>  <b>Example:</b> n1000v# show tacacs-server Global TACACS+ shared secret:***** timeout value:10 deadtime value:0 total number of servers:1  following TACACS+ servers are configured: 10.10.2.2: available on port:49 n1000v#	(Optional) Displays the TACACS+ server configuration.
Step 5	<b>copy running-config startup-config</b>  <b>Example:</b> n1000v# copy running-config startup-config	(Optional) Copies these changes made in the running configuration to the startup configuration.

## Setting a Timeout Interval for an Individual TACACS+ Host

Use this procedure to set the interval in seconds that the Cisco Nexus 1000V waits for a response from a specific TACACS+ server before declaring a timeout. This setting is configured per TACACS+ host.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.
- You have already enabled TACACS+ for authentication.  
See the [“Enabling or Disabling TACACS+” procedure on page 6-8](#).
- The timeout setting for an individual TACACS+ server overrides the global timeout interval.

### SUMMARY STEPS

1. **config t**
2. **tacacs-server host {ipv4-address | host-name} timeout seconds**

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

3. `exit`
4. `show tacacs-server`
5. `copy running-config startup-config`

## DETAILED STEPS

	Command	Purpose
Step 1	<code>config t</code>  <b>Example:</b> n1000v# <code>config t</code> n1000v(config)#	Places you in the CLI Global Configuration mode.
Step 2	<code>tacacs-server host {ipv4-address   host-name} timeout seconds</code>  <b>Example:</b> n1000v(config)# <code>tacacs-server host 10.10.2.2 timeout 10</code> n1000v(config)#	Specifies the timeout interval for a specific server. The default is the global timeout interval.  For more information, see the <a href="#">“Setting the TACACS+ Global Timeout Interval” procedure on page 6-16</a> .
Step 3	<code>exit</code>  <b>Example:</b> n1000v(config)# <code>exit</code> n1000v#	Exits the CLI Global Configuration mode and returns you to EXEC mode.
Step 4	<code>show tacacs-server</code>  <b>Example:</b> n1000v# <code>show tacacs-server</code> Global TACACS+ shared secret:***** timeout value:10 deadtime value:0 total number of servers:1  following TACACS+ servers are configured: 10.10.2.2: available on port:49 timeout:10 n1000v#	(Optional) Displays the TACACS+ server configuration.
Step 5	<code>copy running-config startup-config</code>  <b>Example:</b> n1000v# <code>copy running-config startup-config</code>	(Optional) Copies these changes made in the running configuration to the startup configuration.

## Configuring the TCP Port for a TACACS+ Host

Use this procedure to configure a TCP port other than port 49 (the default for TACACS+ requests).

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.
- You have already enabled TACACS+ for authentication.  
See the [“Enabling or Disabling TACACS+” procedure on page 6-8](#).



## Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).

- You have configured the TACACS+ server using the “Configuring a TACACS+ Server Host” procedure on page 6-11.

### SUMMARY STEPS

- config t**
- tacacs-server host {ipv4-address | host-name} port tcp-port**
- exit**
- show tacacs-server**
- copy running-config startup-config**

### DETAILED STEPS

	Command	Purpose
Step 1	<b>config t</b>  <b>Example:</b> n1000v# config t n1000v(config)#	Places you in the CLI Global Configuration mode.
Step 2	<b>tacacs-server host {ipv4-address   host-name} port tcp-port</b>  <b>Example:</b> n1000v(config)# tacacs-server host 10.10.2.2 port 2 n1000v(config)#	Specifies the TCP port to use. allowable range: 1 to 65535 default: 49
Step 3	<b>exit</b>  <b>Example:</b> n1000v(config)# exit n1000v#	Exits the CLI Global Configuration mode and returns you to EXEC mode.
Step 4	<b>show tacacs-server</b>  <b>Example:</b> n1000v# show tacacs-server Global TACACS+ shared secret:***** timeout value:10 deadtime value:0 total number of servers:1  following TACACS+ servers are configured: 10.10.2.2: available on port:2 timeout:10 n1000v#	(Optional) Displays the TACACS+ server configuration.
Step 5	<b>copy running-config startup-config</b>  <b>Example:</b> n1000v# copy running-config startup-config	(Optional) Copies the running configuration to the startup configuration.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

## Configuring Monitoring for a TACACS+ Host

Use this procedure to configure periodic monitoring of a TACACS+ host.

### BEFORE YOU BEGIN

Before starting this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.
- You have already enabled TACACS+ for authentication.  
See the “[Enabling or Disabling TACACS+](#)” procedure on page 6-8.
- You have configured the TACACS+ server.  
See the “[Configuring a TACACS+ Server Host](#)” procedure on page 6-11.
- The idle timer specifies how long a TACACS+ server should remain idle (receiving no requests) before sending it a test packet.
- The default idle timer value is 0 minutes. When the idle time interval is 0 minutes, periodic TACACS+ server monitoring is not done.

### SUMMARY STEPS

1. **config t**
2. **tacacs-server host** {*ipv4-address* | *host-name*} **test** {*idle-time minutes* | **password** *password* [*idle-time minutes*] | **username** *name* [**password** *password* [*idle-time minutes*]]}
3. **tacacs-server dead-time** *minutes*
4. **exit**
5. **show tacacs-server**
6. **copy running-config startup-config**

### DETAILED STEPS

	Command	Purpose
Step 1	<b>config t</b>  <b>Example:</b> n1000v# config t n1000v(config)#	Places you in the CLI Global Configuration mode.
Step 2	<b>tacacs-server host</b> { <i>ipv4-address</i>   <i>host-name</i> } <b>test</b> { <i>idle-time minutes</i>   <b>password</b> <i>password</i> [ <i>idle-time minutes</i> ]   <b>username</b> <i>name</i> [ <b>password</b> <i>password</i> [ <i>idle-time minutes</i> ]]}  <b>Example:</b> n1000v(config)# tacacs-server host 10.10.2.2 test username pvk2 password a3z9yjz7 idle-time 3	Configures server monitoring.  <b>username:</b> The default is test.  <b>Note</b> To protect network security, we recommend assigning a username that is not already in the TACACS+ database.  <b>password:</b> The default is test.  <b>idle-time:</b> The default is 0 minutes. The valid range is from 0 to 1440 minutes.  <b>Note</b> For periodic TACACS+ server monitoring, the idle timer value must be greater than 0.

**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**

	Command	Purpose
Step 3	<b>tacacs-server dead-time</b> <i>minutes</i>  <b>Example:</b> n1000v(config)# tacacs-server dead-time 5	Specifies the duration of time in minutes before checking a TACACS+ server that was previously unresponsive. The default value is 0 minutes and the valid range is from 0 to 1440 minutes.
Step 4	<b>exit</b>  <b>Example:</b> n1000v(config)# exit n1000v#	Exits the CLI Global Configuration mode and returns you to EXEC mode.
Step 5	<b>show tacacs-server</b>  <b>Example:</b> n1000v# show tacacs-server Global TACACS+ shared secret:***** timeout value:10 deadtime value:0 total number of servers:1  following TACACS+ servers are configured: 10.10.2.2: available on port:2 timeout:10 n1000v#	(Optional) Displays the TACACS+ server configuration.
Step 6	<b>copy running-config startup-config</b>  <b>Example:</b> n1000v# copy running-config startup-config	(Optional) Copies these changes made to the running configuration to the startup configuration.

## Configuring the TACACS+ Global Dead-Time Interval

Use this procedure to configure the interval to wait before sending a test packet to a previously unresponsive server.

### BEFORE YOU BEGIN

Before starting this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.
- You have already enabled TACACS+ for authentication.  
See the [“Enabling or Disabling TACACS+” procedure on page 6-8](#).
- You have configured the TACACS+ server.  
See the [“Configuring a TACACS+ Server Host” procedure on page 6-11](#).
- When the dead-timer interval is 0 minutes, TACACS+ servers are not marked as dead even if they are not responding. You can configure the dead-timer per group (see the [“Configuring a TACACS+ Server Group” procedure on page 6-12](#)).

### SUMMARY STEPS

1. **config t**
2. **tacacs-server deadtime** *minutes*
3. **exit**

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

4. `show tacacs-server`
5. `copy running-config startup-config`

## DETAILED STEPS

	Command	Purpose
Step 1	<code>config t</code>  <b>Example:</b> n1000v# <code>config t</code> n1000v(config)#	Places you in the CLI Global Configuration mode.
Step 2	<code>tacacs-server deadtime minutes</code>  <b>Example:</b> n1000v(config)# <code>tacacs-server deadtime 5</code>	Configures the global dead-time interval. The default value is 0 minutes. The range is from 1 to 1440 minutes
Step 3	<code>exit</code>  <b>Example:</b> n1000v(config)# <code>exit</code> n1000v#	Exits the CLI Global Configuration mode and returns you to EXEC mode.
Step 4	<code>show tacacs-server</code>  <b>Example:</b> n1000v# <code>show tacacs-server</code>	(Optional) Displays the TACACS+ server configuration.
Step 5	<code>copy running-config startup-config</code>  <b>Example:</b> n1000v# <code>copy running-config startup-config</code>	(Optional) Copies the running configuration to the startup configuration.

## Displaying Statistics for a TACACS+ Host

Use this procedure to display the statistics for TACACS+ host.

### BEFORE YOU BEGIN

Before starting this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.
- You have already enabled TACACS+ for authentication.  
See the [“Enabling or Disabling TACACS+” procedure on page 6-8](#).
- You have configured the TACACS+ server.  
See the [“Configuring a TACACS+ Server Host” procedure on page 6-11](#).

### SUMMARY STEPS

1. `show tacacs-server statistics {hostname | ipv4-address}`

**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**

## DETAILED STEPS

	Command	Purpose
Step 1	<code>show tacacs-server statistics {hostname   ipv4-address}</code>	Displays statistics for a TACACS+ host.

**Example:**

```
n1000v# show tacacs-server statistics 10.10.1.1
Server is not monitored
```

```
Authentication Statistics
  failed transactions: 9
  successful transactions: 2
  requests sent: 2
  requests timed out: 0
  responses with no matching requests: 0
  responses not processed: 0
  responses containing errors: 0
```

```
Authorization Statistics
  failed transactions: 1
  successful transactions: 0
  requests sent: 0
  requests timed out: 0
  responses with no matching requests: 0
  responses not processed: 0
  responses containing errors: 0
```

```
Accounting Statistics
  failed transactions: 0
  successful transactions: 0
  requests sent: 0
  requests timed out: 0
  responses with no matching requests: 0
  responses not processed: 0
  responses containing errors: 0
```

## Example TACACS+ Configuration

The following example shows a TACACS+ configuration:

```
feature tacacs+
tacacs-server key 7 "ToIkLhPpG"
tacacs-server host 10.10.2.2 key 7 "ShMoMhTl"
aaa group server tacacs+ TacServer
server 10.10.2.2
```

## Feature History for TACACS+

This section provides the TACACS+ release history.

Feature Name	Releases	Feature Information
TACACS+	4.0(4)SV1(1)	This feature was introduced.

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

## Additional References

For additional information related to implementing TACACS+, see the following sections:

- [Related Documents, page 6-24](#)
- [Standards, page 6-24](#)

## Related Documents

Related Topic	Document Title
CLI	<i>Cisco Nexus 1000V Command Reference, Release 4.2(1)SV1(5.1)</i>
System Management	<i>Cisco Nexus 1000V System Management Configuration Guide, Release 4.2(1)SV1(5.1)</i>

## Standards

Standards	Title
No new or modified standards are supported by this feature, and support for existing standards has not been modified by this feature.	—



## CHAPTER 7

# Configuring SSH

---

This chapter describes how to configure Secure Shell Protocol (SSH).

This chapter includes the following sections:

- [Information About SSH, page 7-1](#)
- [Prerequisites for SSH, page 7-2](#)
- [Guidelines and Limitations, page 7-2](#)
- [Default Settings, page 7-3](#)
- [Configuring SSH, page 7-3](#)
- [Verifying the SSH Configuration, page 7-13](#)
- [SSH Example Configuration, page 7-14](#)
- [Additional References, page 7-15](#)
- [Feature History for SSH, page 7-15](#)

## Information About SSH

This section includes the following topics:

- [SSH Server, page 7-1](#)
- [SSH Client, page 7-2](#)
- [SSH Server Keys, page 7-2](#)

## SSH Server

You can use the SSH server to enable an SSH client to make a secure, encrypted connection. SSH uses strong encryption for authentication. The SSH server can operate with publicly and commercially available SSH clients.

TACACS+ user authentication and locally stored user names and passwords is supported for SSH.

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

## SSH Client

The SSH client feature is an application that runs over the SSH protocol to provide device authentication and encryption. The SSH client enables a secure, encrypted connection to any device that runs the SSH server. This connection provides an encrypted outbound connection. With authentication and encryption, the SSH client produces secure communication over an insecure network.

The SSH client works with publicly and commercially available SSH servers.

## SSH Server Keys

SSH requires server keys for secure communication. You can use SSH server keys for the following SSH options:

- SSH version 2 using Rivest, Shamir, and Adelman (RSA) public-key cryptography
- SSH version 2 using the Digital System Algorithm (DSA)

Be sure to have an SSH server key-pair with the correct version before enabling the SSH service. Generate the SSH server key-pair according to the SSH client version used. The SSH service accepts two types of key-pairs for use by SSH version 2:

- The **dsa** option generates the DSA key-pair for the SSH version 2 protocol.
- The **rsa** option generates the RSA key-pair for the SSH version 2 protocol.

By default, an RSA key using 1024 bits is generated.

SSH supports the following public key formats:

- OpenSSH
- IETF Secure Shell (SECSH)
- Public Key Certificate in Privacy-Enhanced Mail (PEM)



**Caution**

---

If you delete all of the SSH keys, you cannot start the SSH services.

---

## Prerequisites for SSH

SSH has the following prerequisite:

- You have configured IP on a Layer 3 interface, out-of-band on the mgmt 0 interface, or inband on an Ethernet interface.
- Before enabling the SSH server, obtain the SSH key.

## Guidelines and Limitations

- Only SSH version 2 (SSHv2) is supported.
- SSH is enabled by default.
- Cisco NX-OS commands might differ from the Cisco IOS commands.



*Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).*

## Default Settings

The following table lists the default settings for SSH.

Parameters	Default
SSH server	Enabled.
SSH server key	RSA key generated with 1024 bits.
RSA key bits for generation	1024.

## Configuring SSH

This section includes the following topics:

- [Generating SSH Server Keys, page 7-3](#)
- [Configuring a User Account with a Public Key, page 7-5](#)
- [Starting SSH Sessions, page 7-8](#)
- [Clearing SSH Hosts, page 7-9](#)
- [Disabling the SSH Server, page 7-9](#)
- [Deleting SSH Server Keys, page 7-10](#)
- [Clearing SSH Sessions, page 7-12](#)

## Generating SSH Server Keys

Use this procedure to generate an SSH server key based on your security requirements.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.
- The default SSH server key is an RSA key that is generated using 1024 bits.

### SUMMARY STEPS

1. **config t**
2. **no feature ssh**
3. **ssh key {dsa [force] | rsa [bits [force]]}**
4. **feature ssh**
5. **exit**
6. **show ssh key**
7. **copy running-config startup-config**

**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**

## DETAILED STEPS

	Command	Purpose
Step 1	<b>config t</b>  <b>Example:</b> n1000v# config t n1000v(config)#	Places you in the CLI Global Configuration mode.
Step 2	<b>no feature ssh</b>  <b>Example:</b> n1000v(config)# no feature ssh	Disables SSH.
Step 3	<b>ssh key {dsa [force]   rsa [bits [force]]}</b>  <b>Example:</b> n1000v(config)# ssh key dsa force	Generates the SSH server key.  The <i>bits</i> argument is the number of bits used to generate the key. The range is from 768 to 2048 and the default value is 1024.  Use the <b>force</b> keyword to replace an existing key.
Step 4	<b>feature ssh</b>  <b>Example:</b> n1000v(config)# feature ssh	Enables SSH.
Step 5	<b>show ssh key</b>  <b>Example:</b> n1000v# show ssh key	(Optional) Displays the SSH server keys.
Step 6	<b>copy running-config startup-config</b>  <b>Example:</b> n1000v# copy running-config startup-config	(Optional) Copies the running configuration to the startup configuration.

```

Example:
n1000v# config t
n1000v(config)# no feature ssh
XML interface to system may become unavailable since ssh is disabled
n1000v(config)# ssh key dsa force
generating dsa key(1024 bits).....
.
generated dsa key
n1000v(config)# feature ssh
n1000v(config)# show ssh key
*****
rsa Keys generated:Sun Jul 27 15:18:46 2008

ssh-rsa AAAAB3NzaC1yc2EAAAABIwAAAQEAyKcb7Nv9Ki100Id9/tDHHa/ngQujlvK5mXyL/n+DeOXX
fVhHbX2a+V0cm7CCLUkBh+BvZRmpmOVTmU/5awfVhVxMKXMiPOPbc+A6/n3FVroyRwupMki6mWom6Uwa
GID5gsVPqFjFNSgMwtbhjo97XVKhgjFW+wOvt8QoAcrEtnwEfsnQk1EIr/0XIP1mqTsrqTsmjZ2vLk+f
FzTGYAxMvYZI+BrN47aoH2yws7CpnODjCDXJuDYSPbc3PA8t0ghU/60m9R+s6AZPuljVQbGfxPrahEu4
GVc6sMJNU1JxmQDJkdhMARB4Umzj7E3Rdby/ZWx/clTYiXQR1X1VFhQ==

bitcount:2048
fingerprint:
fd:ca:48:73:b9:ee:e7:86:9e:1e:40:46:f1:50:1d:44
*****
dsa Keys generated:Sun Jul 27 15:20:12 2008

ssh-dss AAAAB3NzaC1kc3MAAACBALpdXlXNS/jcCNY+F1QZV9HegxBEB0DMUm9bSq2N+KAcvH1lEh

```

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

```
GnaiHhqar0lcEKqhLbIbuqtKTCvfa+YlhBIAhWVjg1UR3/M22jqxnfhnxL5YRc1Q7fcesFax0myayAIU
nXrk05iww9XHTu+EIInRc4kJ0XrG9SxtLmDe/fi2ZAAAFQDbRabAjZa6GfDpwjXw5smRhrElJwAAAEIA
r50yi3hHawNnb5qgYLXhN+KA8XJF753eCWhtMw7NR8fz6fjQ1R2J97UjjGuQ8DvwpGeNQ5S+AuIo0rGq
svdg7TTecBcbgBOnR7Fs2+W5HiSVEGbvj1xaeK8fkNE6kaJumBB343b8Rgj0G97MP/os1GfkEqmX9g1B
0IOM2mgHHyoAAACAFRir27hHy+fw8CxPlsK0R6cFhxYyd/qYYogXFKYIOPxpLoYrjqODEOfThU7TJuBz
aS97eXiruzbfFHwzUGfXgmQT5o9IMZRTC1WPA/5Ju4O9YABYHccUghf0W+QtgGOT6FOSvBh8uOV0kcHC
GMJAP8omphauZJlc+wgFxnkyh4=
```

```
bitcount:1024
fingerprint:
44:91:32:1f:7a:d1:83:3c:f3:5e:db:53:0a:2d:ce:69
*****
```

## Configuring a User Account with a Public Key

Use this procedure to configure an SSH public key to log in using the SSH client without being prompted for a password. You can specify the SSH public key in one of three different formats:

- OpenSSH format
- IETF SECSH format
- Public Key Certificate in PEM format

### Configuring an OpenSSH Key

Use this procedure to specify the SSH public keys in OpenSSH format for user accounts.

#### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.
- You have already generated an SSH public key in OpenSSH format.
- The user account already exists.

#### SUMMARY STEPS

1. **config t**
2. **username *username* sshkey *ssh-key***
3. **exit**
4. **show user-account**
5. **copy running-config startup-config**

**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**

## DETAILED STEPS

	Command	Purpose
Step 1	<b>config t</b>  <b>Example:</b> n1000v# config t n1000v(config)#	Places you in the CLI Global Configuration mode.
Step 2	<b>username username sshkey ssh-key</b>  <b>Example:</b> n1000v(config)# username user1 sshkey ssh-rsa AAAAB3NzaC1yc2EAAAABIwAAAQEAYKcb7Nv9Ki100Id9/tDHHa/ngQujlvK5mXyL/n+DeOXXfVhHbX2a+V0cm7CCLUkHh+BvZRmpmOVTmU/5awfVhVxMKXMiPOPbc+A6/n3FVroyRwupMki6mWoM6UwaGID5gsVPqFjFNSgMWtbhj097XVKhgjFW+wOVt8QoAcrEtnwEfsnQk1EIr/0XIP1mqTsrqTsmjZ2vLk+fFzTGYAxMvYZI+BrN47aoH2ywS7CpnODjCDXJuDYSPbc3PA8t0ghU/60m9R+s6AZPuljVQbGfxPrahEu4GVc6sMJNU1JxmQDJkdhMARObB4Umzj7E3Rdby/ZWx/clTYiXQR1X1VfhQ==	Configures the SSH public key in OpenSSH format with an existing user account.  To create a user account use the following command:  <b>username name password pwd</b>
Step 3	<b>exit</b>  <b>Example:</b> n1000v(config)# exit n1000v#	Exits Global Configuration mode and returns you to EXEC mode.
Step 4	<b>show user-account</b>  <b>Example:</b> n1000v# <b>show user-account</b> user:admin this user account has no expiry date roles:network-admin user:user1 this user account has no expiry date roles:network-operator ssh public key: ssh-rsa AAAAB3NzaC1yc2EAAAABIwAAAQEAYKcb7Nv9Ki100Id9/tDHHa/ngQujlvK5mXyL/n+DeOXXfVhHbX2a+V0cm7CCLUkHh+BvZRmpmOVTmU/5awfVhVxMKXMiPOPbc+A6/n3FVroyRwupMki6mWoM6UwaGID5gsVPqFjFNSgMWtbhj097XVKhgjFW+wOVt8QoAcrEtnwEfsnQk1EIr/0XIP1mqTsrqTsmjZ2vLk+fFzTGYAxMvYZI+BrN47aoH2ywS7CpnODjCDXJuDYSPbc3PA8t0ghU/60m9R+s6AZPuljVQbGfxPrahEu4GVc6sMJNU1JxmQDJkdhMARObB4Umzj7E3Rdby/ZWx/clTYiXQR1X1VfhQ==	(Optional) Displays the user account configuration.
Step 5	<b>copy running-config startup-config</b>  <b>Example:</b> n1000v# copy running-config startup-config	(Optional) Copies the running configuration to the startup configuration.

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

## Configuring IETF or PEM Keys

Use this procedure to specify the SSH public keys in IETF SECSH or PEM format for user accounts.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.
- You have already generated an SSH public key in one of the following formats:
  - IETF SECSH format
  - Public Key Certificate in PEM format

### SUMMARY STEPS

1. **copy** *server-file* **bootflash:***filename*
2. **config t**
3. **username** *username* **sshkey file** **bootflash:***filename*
4. **exit**
5. **show user-account**
6. **copy running-config startup-config**

### DETAILED STEPS

	Command	Purpose
Step 1	<b>copy</b> <i>server-file</i> <b>bootflash:</b> <i>filename</i>	Downloads the file containing the SSH key from a server. The server can be FTP, secure copy (SCP), secure FTP (SFTP), or TFTP.
	<b>Example:</b> n1000v# copy tftp://10.78.1.10/secsh_file.pub bootflash:secsh_file.pub vrf management Trying to connect to tftp server..... Connection to server Established.   TFTP get operation was successful n1000v#	
Step 2	<b>config t</b>	Places you in the CLI Global Configuration mode.
	<b>Example:</b> n1000v# config t n1000v(config)#	
Step 3	<b>username</b> <i>username</i> <b>sshkey file</b> <b>bootflash:</b> <i>filename</i>	Configures the SSH public key.
	<b>Example:</b> n1000v(config)# username User1 sshkey file bootflash:secsh_file.pub	
Step 4	<b>exit</b>	Exits Global Configuration mode and returns you to EXEC mode.
	<b>Example:</b> n1000v(config)# exit n1000v#	

**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**

	Command	Purpose
Step 5	<b>show user-account</b>	(Optional) Displays the user account configuration.
	<b>Example:</b> <pre>n1000v# show user-account user:admin     this user account has no expiry date     roles:network-admin user:user2     this user account has no expiry date     roles:network-operator     ssh public key: ssh-rsa AAAAB3NzaC1yc2EAAAABIwAAAQEAYKcb7Nv9Ki100Id9/tddHhA/ngQujlvK5mXyL/n+DeOxKfVhHbX2a+V0cm7CC LUkWh+BvZRmpmOVTmU/5awfVhVxMKXMiPOPbc+A6/n3FVroyRwupMki6 mWoM6UwaGID5gsVPqFjFNSgMwtbhjo97XVKhgjFW+wOVt8QoAcrEtnwEfsnQk1EIr/OXIP1mqTsrqTsmjZ2vLk+f FzTGYAxMvYZI+BrN47aoH2yws7CpnODjCDXJuDYSPbc3PA8t0ghU/60m9R+s6AZPuljVQbGfxPrahEu4GVc6sMJN U1JxmQDJkdhMArObB4Umzj7E3Rdby/ZWx/clTYiXQR1X1VfhQ==</pre>	
Step 6	<b>copy running-config startup-config</b>	(Optional) Copies the running configuration to the startup configuration.
	<b>Example:</b> <pre>n1000v# copy running-config startup-config</pre>	

## Starting SSH Sessions

Use this procedure to start SSH sessions using IP to connect to remote devices.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.
- You have already obtained the hostname and, if needed, the username, for the remote device.
- The SSH server is already enabled on the remote device.

### SUMMARY STEPS

1. **ssh** [*username@*]{*hostname | username@hostname*} [**vrf** *vrf-name*]  
**ssh6** [*username@*]{*hostname | username@hostname*} [**vrf** *vrf-name*]

### DETAILED STEPS

	Command	Purpose
Step 1	<b>ssh</b> [ <i>root@</i> ]{ <i>ip address   hostname</i> } [ <b>vrf</b> <i>vrf-name</i> ]	Creates an SSH IP session to a remote device using IP. The default VRF is the default VRF.
	<b>Example:</b> <pre>n1000v(config)# ssh root@172.28.30.77 root@172.28.30.77's password: Last login: Sat Jul 26 11:07:23 2008 from 171.70.209.64</pre>	

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

## Clearing SSH Hosts

Use this procedure to clear from your account the list of trusted SSH servers that were added when you downloaded a file from a server using SCP or SFTP, or when you started an SSH session to a remote host.

### BSUMMARY STEPS

1. `clear ssh hosts`

### DETAILED STEPS

	Command	Purpose
Step 1	<code>clear ssh hosts</code>  <b>Example:</b> n1000v# <code>clear ssh hosts</code>	Clears the SSH host sessions.

## Disabling the SSH Server

Use this procedure to disable the SSH server to prevent SSH access to the switch. By default, the SSH server is enabled.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.
- If you disable SSH, to enable it again you must first generate an SSH server key.  
See the [“Generating SSH Server Keys” procedure on page 7-3](#).

### SUMMARY STEPS

1. `config t`
2. `no feature ssh`
3. `show ssh server`
4. `copy running-config startup-config`

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

## DETAILED STEPS

	Command	Purpose
Step 1	<b>config t</b>  <b>Example:</b> n1000v# config t n1000v(config)#	Places you in the CLI Global Configuration mode.
Step 2	<b>no feature ssh</b>  <b>Example:</b> n1000v(config)# no feature ssh XML interface to system may become unavailable since ssh is disabled n1000v(config)#	Disables the SSH server. The default is enabled.
Step 3	<b>show ssh server</b>  <b>Example:</b> n1000v(config)# show ssh server ssh is not enabled n1000v(config)#	(Optional) Displays the SSH server configuration.
Step 4	<b>copy running-config startup-config</b>  <b>Example:</b> n1000v(config)# copy running-config startup-config	(Optional) Copies the running configuration to the startup configuration.

## Deleting SSH Server Keys

Use this procedure to delete SSH server keys after you disable the SSH server.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.
- If you disable SSH, to enable it again you must first generate an SSH server key.  
See the [“Generating SSH Server Keys” procedure on page 7-3](#).

### SUMMARY STEPS

1. **config t**
2. **no feature ssh**
3. **no ssh key [dsa | rsa]**
4. **show ssh key**
5. **copy running-config startup-config**



**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**

## DETAILED STEPS

	Command	Purpose
Step 1	<b>config t</b>  <b>Example:</b> n1000v# config t n1000v(config)#	Places you in the CLI Global Configuration mode.
Step 2	<b>no feature ssh</b>  <b>Example:</b> n1000v(config)# no feature ssh	Disables the SSH server.
Step 3	<b>no ssh key [dsa   rsa]</b>  <b>Example:</b> n1000v(config)# no ssh key rsa	Deletes the SSH server key.  The default is to delete all the SSH keys.
Step 4	<b>show ssh key</b>  <b>Example:</b> n1000v(config)# show ssh key	(Optional) Displays the SSH server key configuration.
Step 5	<b>copy running-config startup-config</b>  <b>Example:</b> n1000v(config)# copy running-config startup-config	(Optional) Copies the running configuration to the startup configuration.

**Example:**

```
n1000v# config t
n1000v(config)# no feature ssh
n1000v(config)# no ssh key rsa
n1000v(config)# show ssh key
*****
rsa Keys generated:Sun Jul 27 15:18:46 2008

ssh-rsa AAAAB3NzaC1yc2EAAAABIwAAAQEAyKcb7Nv9Ki100Id9/tDHhA/ngQujlvK5mXyL/n+DeOXX
fVhHbX2a+V0cm7CCLUkBh+BvZRmpmOVTmU/5awfVhVxMKXMiPOPbc+A6/n3FVroyRwupMki6mWoM6Uwa
GID5gsVPqFjFNSgMWtbhjo97XVKhgjFW+wOVt8QoAcrEtnwEfsnQk1EIr/0XIP1mqTsrqTsmjZ2vLk+f
FzTGYAxMvYZI+BrN47aoH2ywS7CpnODjCDXJuDYSPbc3PA8t0ghU/60m9R+s6AZPuljVQbGfxPrahEu4
GVc6sMJNU1JxmQDJk0dhMAR0bB4Umzj7E3Rdby/ZWx/clTYiXQR1X1VfhQ==

bitcount:2048
fingerprint:
fd:ca:48:73:b9:ee:e7:86:9e:1e:40:46:f1:50:1d:44
*****
dsa Keys generated:Sun Jul 27 15:20:12 2008

ssh-dss AAAAB3NzaC1kc3MAAACBALpdxLjXNS/jcNY+F1QZV9HegxBEB0DMUm9bSq2N+KAcvHl1Eh
GnaiHhgar0lcEKqLbIbuqtKTCvfa+YlhBIAhWVjg1UR3/M22jqxnfhnxL5YRc1Q7fcesFax0myayAIU
nXrK05iWv9XHTu+EIInRc4kJ0XrG9SxtLmDe/fi2ZAAAFQDbRabAjZa6GfDpwjXw5smRhrElJwAAIEA
r50yi3hHawNnb5ggYLXhN+KA8XJF753eCWHtMw7NR8fz6fjQ1R2J97UjjGuQ8DvwpGeNQ5S+AuIo0rGg
svdg7TTecBcbgBOnR7Fs2+W5HiSVEGbvjlxaeK8fkNE6kaJumBB343b8Rgj0G97MP/os1GfkEqmX9g1B
0IOM2mgHHyoAAACAFRir27hHy+fw8CxPlsK0R6cFhxYyd/qYYogXFYIOPxpLoYrjqODEOfThU7TJuBz
aS97eXiruzbfHwzUGfXgmQT5o9IMZRTC1WPA/5Ju409YABYHccUghf0W+QtgGOT6FOSvBh8uOV0kcHC
GMJAP8omphauZJlc+wgFxnkyh4=

bitcount:1024
fingerprint:
44:91:32:1f:7a:d1:83:3c:f3:5e:db:53:0a:2d:ce:69
```

**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**

```

*****
mcs-srvr43(config)# no ssh key rsa
mcs-srvr43(config)# show ssh key
*****
could not retrieve rsa key information
*****
dsa Keys generated:Sun Jul 27 15:20:12 2008

ssh-dss AAAAB3NzaC1kc3MAAACBALpdxLjXNS/jcCNY+F1QZV9HegxBEB0DMUmq9bSq2N+KAcvH1lEh
GnaiHhqrOlCEKqhlbIbuqtKTCvfa+Y1hBIAhWVjg1UR3/M22jqxfhnxL5YRc1Q7fcesFax0myayAIU
nXrkO5iWv9XHTu+ElRc4kJOXrG9SxtLmDe/fi2ZAAAFQDbRabAjZa6GfDpwjXw5smRhrElJwAAIEA
r50yi3hHawNnb5qgYLXhN+KA8XJF753eCWHTMw7NR8fz6fjQ1R2J97UjjGuQ8DvwpGeNQ5S+AuIo0rGg
svdg7TTecBcbgBOnR7Fs2+W5HiSVEGbvjlxaeK8fkNE6kaJumBB343b8Rgj0G97MP/os1GfkEqmX9glB
0IOM2mgHHyoAAACAFrir27hHy+fw8CxPlsK0R6cFhxYyd/qYYogXFKYIOPxpLoYrjq0DeOfThU7TJuBz
aS97eXiruzbfffHwzUGfXgmQT5o9IMZRTClWPA/5Ju409YABYHccUghf0W+QtgGOT6FOSvBh8uOV0kcHC
GMJAP8omphauZJlc+wgFxnkyh4=

bitcount:1024
fingerprint:
44:91:32:1f:7a:d1:83:3c:f3:5e:db:53:0a:2d:ce:69
*****
mcs-srvr43(config)# no ssh key dsa
mcs-srvr43(config)# show ssh key
*****
could not retrieve rsa key information
*****
could not retrieve dsa key information
*****
no ssh keys present. you will have to generate them
*****
n1000v#

```

## Clearing SSH Sessions

Use this procedure to clear SSH sessions from the device.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.

### SUMMARY STEPS

1. **show users**
2. **clear line vty-line**
3. **show users**

**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**

## DETAILED STEPS

	Command	Purpose
Step 1	<b>show users</b>  <b>Example:</b> n1000v# show users	Displays user session information.
Step 2	<b>clear line vty-line</b>  <b>Example:</b> n1000v# clear line 0	Clears a user SSH session.
Step 3	<b>show users</b>  <b>Example:</b> n1000v# show users	Displays user session information.

```

Example:
n1000v# show users
NAME      LINE      TIME          IDLE          PID COMMENT
admin    tty1      Jul 25 19:13  old          2867
admin    pts/0     Jul 28 09:49  00:02       28556 (10.21.148.122)
admin    pts/1     Jul 28 09:46  .           28437 (::ffff:10.21.148.122)*
n1000v# clear line 0
n1000v# show users
NAME      LINE      TIME          IDLE          PID COMMENT
admin    tty1      Jul 25 19:13  old          2867
admin    pts/1     Jul 28 09:46  .           28437 (::ffff:10.21.148.122)*
mcs-srvr43(config)#

```

## Verifying the SSH Configuration

To display the SSH configuration information, use one of the following commands:

Command	Purpose
<b>show ssh key [dsa   rsa]</b>	Displays SSH server key-pair information.
<b>show running-config security [all]</b>	Displays the SSH and user account configuration in the running configuration. The <b>all</b> keyword displays the default values for the SSH and user accounts.
<b>show ssh server</b>	Displays the SSH server configuration.

```

Example:
n1000v# show ssh key rsa
*****
rsa Keys generated:Mon Jul 28 09:49:18 2008

ssh-rsa
AAAAB3NzaC1yc2EAAAABIwAAAGEAv0a4p6VulQMw4AMgoPFApB2KegF3QTojCzed51iVQnEkNglNm7A/oEIZAt1VLY
k/PEzt+ED7lPal/8pomaqjgRxHSeK2gw1cJKSDBCyH5na8uox1Hr50eK0q2+ZfvMqV

bitcount:768
fingerprint:

```

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

```
76:6c:a0:5c:79:a6:ae:3d:cb:27:a1:86:62:fa:09:df
*****
```

## SSH Example Configuration

To configure SSH with an OpenSSH key, follow these steps:

**Step 1** Disable the SSH server.

```
n1000v# config t
n1000v(config)# no feature ssh
```

**Step 2** Generate an SSH server key.

```
n1000v(config)# ssh key rsa
generating rsa key(1024 bits).....
.generated rsa key
```

**Step 3** Enable the SSH server.

```
n1000v(config)# feature ssh
```

**Step 4** Display the SSH server key.

```
n1000v(config)# show ssh key
rsa Keys generated:Sat Sep 29 00:10:39 2007
```

```
ssh-rsa AAAAB3NzaC1yc2EAAAABIwAAAIEAvWhEBsF55oaPHNDBnpXOTw6+/OdHoLJZKr+MZm99n2U0
ChzZG4svRWmHuJY4PeDWl0e5yE3g3EO3pjDDmt923siNiv5aSga60K361r39HmXL6VgprVn1XQFiBwn4
na+H1d3Q0hDt+uWEA0tka2uOtXlDhliEmm4HVXOjGhFhoNE=
```

```
bitcount:1024
fingerprint:
51:6d:de:1c:c3:29:50:88:df:cc:95:f0:15:5d:9a:df
*****
could not retrieve dsa key information
*****
```

**Step 5** Specify the SSH public key in OpenSSH format.

```
n1000v(config)# username User1 sshkey ssh-rsa
AAAAB3NzaC1yc2EAAAABIwAAAIEAy19oF6QaZl9G+3f1XswK30iW4H7YyUyuA50rv7gsEPjhOBYmsi6PAVKuInIf/
DQhum+1JNqJP/eLowb7ubO+1VKRXYF/G+1JNIQW3g9igG30c6k6+XVn+NjnI1B7ihvpVh7dLddMOXwOnXHYshXmSiH
3UD/vKyzIEh5S4Tplx8=
```

**Step 6** Save the configuration.

```
n1000v(config)# copy running-config startup-config
```

### Example:

```
n1000v# config t
n1000v(config)# no feature ssh
n1000v(config)# ssh key rsa
generating rsa key(1024 bits).....
n1000v(config)# feature ssh
n1000v(config)# show ssh key
rsa Keys generated:Sat Sep 29 00:10:39 2007
ssh-rsa AAAAB3NzaC1yc2EAAAABIwAAAIEAvWhEBsF55oaPHNDBnpXOTw6+/OdHoLJZKr+MZm99n2U0
ChzZG4svRWmHuJY4PeDWl0e5yE3g3EO3pjDDmt923siNiv5aSga60K361r39HmXL6VgprVn1XQFiBwn4
```

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

```
na+H1d3Q0hDt+uWEA0tka2uOtXlDhliEmn4HVXOjGhPhoNE=
bitcount:1024
fingerprint:
51:6d:de:1c:c3:29:50:88:df:cc:95:f0:15:5d:9a:df
*****
could not retrieve dsa key information
*****

n1000v(config)# username User1 sshkey ssh-rsa
AAAAB3NzaC1yc2EAAAABIwAAAIEAy19oF6QaZl9G+3f1XswK3Oiw4H7YyUyuA50rv7gsEPjhOBYmsi6PAVKui1nIf/
DQhum+1JNqJP/eLowb7ubO+1VKRXFY/G+1JNIQW3g9igG30c6k6+XVn+NjnI1B7ihvpVh7dLddMOXwOnXHYshXmSiH
3UD/vKyziEh5S4Tplx8=
n1000v(config)# copy running-config startup-config
[#####] 100%
n1000v(config)#
```

## Additional References

For additional information related to implementing RBAC, see the following sections:

- [Related Documents, page 7-15](#)
- [Standards, page 7-15](#)

## Related Documents

Related Topic	Document Title
CLI	<i>Cisco Nexus 1000V Installation and Upgrade Guide, Release 4.2(1)SV1(5.1)</i>
Telnet	<a href="#">Chapter 8, “Configuring Telnet”</a>

## Standards

Standards	Title
No new or modified standards are supported by this feature, and support for existing standards has not been modified by this feature.	—

## Feature History for SSH

This section provides the SSH release history.

Feature Name	Releases	Feature Information
SSH	4.0(4)SV1(1)	This feature was introduced.

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***



## CHAPTER 8

# Configuring Telnet

---

This chapter describes how to configure Telnet and includes the following topics:

- [Information About the Telnet Server, page 8-1](#)
- [Prerequisites for Telnet, page 8-1](#)
- [Guidelines and Limitations, page 8-2](#)
- [Default Setting, page 8-2](#)
- [Configuring Telnet, page 8-2](#)
- [Verifying the Telnet Configuration, page 8-5](#)
- [Additional References, page 8-5](#)
- [Feature History for Telnet, page 8-6](#)

## Information About the Telnet Server

The Telnet protocol enables you to set up TCP/IP connections to a host. Telnet allows a person at one site to establish a TCP connection to a login server at another site and then passes the keystrokes from one device to the other. Telnet can accept either an IP address or a domain name as the remote device address.

## Prerequisites for Telnet

Telnet has the following prerequisites:

- You have configured IP on a Layer 3 interface, out-of-band on the mgmt 0 interface, or inband on an Ethernet interface.

*Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).*

## Guidelines and Limitations

- The Telnet server is enabled by default.
- Cisco NX-OS commands may differ from Cisco IOS commands.

## Default Setting

The following table lists the default setting for Telnet.

Parameters	Default
Telnet server	Enabled.

## Configuring Telnet

This section includes the following topics:

- [Enabling the Telnet Server, page 8-2](#)
- [Starting an IP Telnet Session to a Remote Device, page 8-3](#)
- [Clearing Telnet Sessions, page 8-4](#)

## Enabling the Telnet Server

Use this procedure to enable the Telnet server. The Telnet server is enabled by default, but you can use this procedure to re-enable it if necessary.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.
- By default, the Telnet server is enabled.

### SUMMARY STEPS

1. **config t**
2. **feature telnet**
3. **exit**
4. **show telnet server**
5. **copy running-config startup-config**



***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

## DETAILED STEPS

	Command	Purpose
Step 1	<code>config t</code>  <b>Example:</b> n1000v# config t n1000v(config)#	Places you into CLI Global Configuration mode.
Step 2	<code>feature telnet</code>  <b>Example:</b> n1000v(config)# feature telnet n1000v(config)#	Enables the Telnet server.
Step 3	<code>show telnet server</code>  <b>Example:</b> n1000v(config)# show telnet server telnet service enabled n1000v(config)#	(Optional) Displays the Telnet server configuration.
Step 4	<code>copy running-config startup-config</code>  <b>Example:</b> n1000v(config)# copy running-config startup-config	(Optional) Copies these changes made in the running configuration to the startup configuration.

## Starting an IP Telnet Session to a Remote Device

Use this procedure to start a Telnet session to a remote device.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following.

- You are logged in to the CLI in EXEC mode.
- You have verified that the Telnet server is enabled on the remote device.
- You have already obtained the hostname for the remote device and, if needed, the username on the remote device.
- You have already verified that the Telnet server is enabled. If not you have enabled it using the [“Enabling the Telnet Server” procedure on page 8-2](#). By default, the Telnet server is enabled.

### SUMMARY STEPS

1. `telnet {ip address | hostname} [port-number] [vrf vrf-name]`

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

## DETAILED STEPS

	Command	Purpose
Step 1	<pre>telnet {ip address   host-name} [port-number] [vrf vrf-name]</pre> <p><b>Example:</b> n1000v# telnet 10.10.1.1</p>	<p>Creates an IP Telnet session to the specified destination.</p> <p><b>port-number:</b> The port number, from 1 to 65535, to use for this session. The default port number is 23.</p> <p><b>vrf-name:</b> The default VRF is the default VRF.</p>

## Clearing Telnet Sessions

Use this procedure to clear Telnet sessions.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following.

- You are logged in to the CLI in EXEC mode.

### SUMMARY STEPS

- show users
- clear line *vtty-line*

### DETAILED STEPS

	Command	Purpose
Step 1	<pre>show users</pre> <p><b>Example:</b> n1000v# show users</p>	Displays user session information.
Step 2	<pre>clear line vty-line</pre> <p><b>Example:</b> n1000v# clear line 1</p>	Clears a user Telnet session.
Step 3	<pre>show users</pre> <p><b>Example:</b> n1000v# show users</p>	Displays user session information.

**Example:**

```
n1000v# show users
NAME      LINE      TIME          IDLE          PID COMMENT
admin     tty1      Jul 25 19:13  old          2867
admin     pts/1     Jul 28 14:04  .            31453 (::ffff:171.70.209.8)
admin     pts/2     Jul 28 14:04  .            31475 (171.70.209.8)*
n1000v# clear line 1
n1000v# show users
NAME      LINE      TIME          IDLE          PID COMMENT
admin     tty1      Jul 25 19:13  old          2867
admin     pts/2     Jul 28 14:04  .            31475 (171.70.209.8)*
n1000v#
```

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

## Verifying the Telnet Configuration

To display the Telnet configuration information, use one of the following commands:

Command	Purpose
<code>show running-config security [all]</code>	Displays the user account configuration in the running configuration. The <b>all</b> keyword displays the default values for the user accounts.
<code>show telnet server</code>	Displays the telnet server configuration.
<code>show hosts</code>	Displays the configuration details for current hosts.
<code>show tcp connection</code>	Displays connection information.

### Example:

```
n1000v# show running-config security all
version 4.0(1)
username admin password 5 $1$xMw2Q/1S$ZEWrvyAxAJAFV0weuSPvg1 role network-admin
username user2 password 5 $1$byNNnnSP$xfXVKje5UEScvriwX3Kyj0 role network-operator
username user2 sshkey ssh-rsa
AAAAB3NzaC1yc2EAAAABIwAAAQEAyKcb7Nv9Ki100Id9/tdHhA/ngQujlvK5mXyL/n+DeOXXfVhHbX2a+V0cm7CCLU
kBh+BvZRmpmOVTmU/5awfVhVxMKXMiPOPbc+A6/n3FVroyRwupMki6mW
oM6UwaGID5gsVPqFjFNSgMwtbhjo97XVKhgjFW+wOVt8QoAcrEtnwEfsnQk1EIr/0XIP1mqTsrqTsmjZ2vLk+fFzTG
YAxMvYZI+BrN47aoh2yws7CpnODjCDXJuDYSPbc3PA8t0ghU/60m9R+s6AZPuljVQbGfxPrahEu4GVc6sMJNU1
JxmQDJkodhMARObB4Umzj7E3Rdby/ZWx/clTYiXQR1X1VfhQ==
telnet server enable

banner motd # User Access Verification #

ssh key rsa 1024 force
no ssh key dsa force
ssh server enable
```

## Additional References

For additional information related to implementing Telnet, see the following sections:

- [Related Documents, page 8-5](#)
- [Standards, page 8-6](#)

## Related Documents

Related Topic	Document Title
SSH	<a href="#">Chapter 7, “Configuring SSH”</a>
CLI	<i>Cisco Nexus 1000V Installation and Upgrade Guide, Release 4.2(1)SV1(5.1)</i>

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

## Standards

Standards	Title
No new or modified standards are supported by this feature, and support for existing standards has not been modified by this feature.	—

## Feature History for Telnet

This section provides the Telnet release history.

Feature Name	Releases	Feature Information
Telnet	4.0(4)SV1(1)	This feature was introduced.



## CHAPTER 9

# Configuring an IP ACL

---

This chapter describes how to configure IP access control lists (ACLs).

This chapter includes the following sections:

- [Information About ACLs, page 9-1](#)
- [Prerequisites for IP ACLs, page 9-7](#)
- [Guidelines and Limitations, page 9-7](#)
- [Default Settings, page 9-7](#)
- [Configuring IP ACLs, page 9-7](#)
- [Verifying the IP ACL Configuration, page 9-20](#)
- [Monitoring IP ACL, page 9-20](#)
- [Example Configurations for IP ACL, page 9-21](#)
- [Additional References, page 9-21](#)
- [Feature History for IP ACL, page 9-22](#)

## Information About ACLs

An ACL is an ordered set of rules for filtering traffic. When the device determines that an ACL applies to a packet, it tests the packet against the rules. The first matching rule determines whether the packet is permitted or denied. If there is no match, the device applies a default rule. The device processes packets that are permitted and drops packets that are denied. For more information, see the [“Implicit Rules” section on page 9-3](#).

You can use ACLs to protect networks and specific hosts from unnecessary or unwanted traffic. For example, you could use ACLs to disallow HTTP traffic from a high-security network to the Internet. You could also use ACLs to allow HTTP traffic but only to specific sites, using the IP address of the site to identify it in an IP ACL.

This section includes the following topics:

- [ACL Types and Applications, page 9-2](#)
- [Order of ACL Application, page 9-2](#)
- [About Rules, page 9-2](#)
- [Statistics, page 9-4](#)
- [ACL Logging, page 9-5](#)

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

## ACL Types and Applications

When a port ACL is applied to a trunk port, the ACL filters traffic on all VLANs on the trunk port.

The following types of port ACLs are supported for filtering Layer 2 traffic:

- IP ACLs—The device applies IPv4 ACLs only to IP traffic.
- MAC ACLs—The device applies MAC ACLs only to non-IP traffic.

## Order of ACL Application

ACLs are applied in the following order:

1. Incoming Port ACL
2. Outgoing Port ACL

## About Rules

Rules are what you create, modify, and remove when you configure how an ACL filters network traffic. Rules appear in the running configuration. When you apply an ACL to an interface or change a rule within an ACL that is already applied to an interface, the supervisor module creates ACL entries from the rules in the running configuration and sends those ACL entries to the applicable I/O module.

You can create rules in ACLs in access-list configuration mode by using the **permit** or **deny** command. The device allows traffic that matches the criteria in a permit rule and blocks traffic that matches the criteria in a deny rule. You have many options for configuring the criteria that traffic must meet in order to match the rule.

This section describes some of the options that you can use when you configure a rule. For information about every option, see the applicable **permit** and **deny** commands in the *Cisco Nexus 1000V Command Reference, Release 4.2(1)SV1(5.1)*.

This section includes the following topics:

- [Source and Destination, page 9-2](#)
- [Protocols, page 9-3](#)
- [Implicit Rules, page 9-3](#)
- [Additional Filtering Options, page 9-3](#)
- [Sequence Numbers, page 9-4](#)
- [Statistics, page 9-4](#)
- [Statistics, page 9-4](#)

## Source and Destination

In each rule, you specify the source and the destination of the traffic that matches the rule. You can specify both the source and destination as a specific host, a network or group of hosts, or any host. How you specify the source and destination depends on whether you are configuring IP or MAC ACLs. For information about specifying source and destination, see the applicable **permit** and **deny** commands in the *Cisco Nexus 1000V Command Reference, Release 4.2(1)SV1(5.1)*.

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

## Protocols

IP and MAC ACLs let you to identify traffic by protocol. You can specify some protocols by name. For example, in an IP ACL, you can specify ICMP by name.

You can specify any protocol by number. In MAC ACLs, you can specify protocols by the Ethertype number of the protocol, which is a hexadecimal number. For example, you can use 0x0800 to specify IP traffic in a MAC ACL rule.

In IP ACLs, you can specify protocols by the integer that represents the Internet protocol number. For example, you can use 115 to specify Layer 2 Tunneling Protocol (L2TP) traffic.

For a list of the protocols that each type of ACL supports by name, see the applicable **permit** and **deny** commands in the *Cisco Nexus 1000V Command Reference, Release 4.2(1)SV1(5.1)*.

## Implicit Rules

IP and MAC ACLs have implicit rules, which means that although these rules do not appear in the running configuration, the device applies them to traffic when no other rules in an ACL match. When you configure the device to maintain per-rule statistics for an ACL, the device does not maintain statistics for implicit rules.

All IP ACLs include the following implicit rule that denies unmatched IP traffic:

```
deny ip any any
```

All MAC ACLs include the following implicit rule:

```
deny any any
```

This implicit rule ensures that unmatched traffic is denied, regardless of the protocol specified in the Layer 2 header of the traffic.

## Additional Filtering Options

You can identify traffic by using additional options. These options differ by ACL type. The following list includes most but not all additional filtering options:

- IP ACLs support the following additional filtering options:
  - Layer 4 protocol
  - TCP and UDP ports
  - ICMP types and codes
  - IGMP types
  - Precedence level
  - Differentiated Services Code Point (DSCP) value
  - TCP packets with the ACK, FIN, PSH, RST, SYN, or URG bit set
- MAC ACLs support the following additional filtering options:
  - Layer 3 protocol
  - VLAN ID
  - Class of Service (CoS)

For information about all filtering options available in rules, see the applicable **permit** and **deny** commands in the *Cisco Nexus 1000V Command Reference, Release 4.2(1)SV1(5.1)*.

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

## Sequence Numbers

The device supports sequence numbers for rules. Every rule that you enter receives a sequence number, either assigned by you or assigned automatically by the device. Sequence numbers simplify the following ACL tasks:

- Adding new rules between existing rules—By specifying the sequence number, you specify where in the ACL a new rule should be positioned. For example, if you need to insert a rule between rules numbered 100 and 110, you could assign a sequence number of 105 to the new rule.
- Removing a rule—Without using a sequence number, removing a rule requires that you enter the whole rule, as follows:

```
n1000v(config-acl)# no permit tcp 10.0.0.0/8 any
```

However, if the same rule had a sequence number of 101, removing the rule requires only the following command:

```
n1000v(config-acl)# no 101
```

- Moving a rule—With sequence numbers, if you need to move a rule to a different position within an ACL, you can add a second instance of the rule using the sequence number that positions it correctly, and then you can remove the original instance of the rule. This action allows you to move the rule without disrupting traffic.

If you enter a rule without a sequence number, the device adds the rule to the end of the ACL and assigns a sequence number that is 10 greater than the sequence number of the preceding rule to the rule. For example, if the last rule in an ACL has a sequence number of 225 and you add a rule without a sequence number, the device assigns the sequence number 235 to the new rule.

In addition, you can reassign sequence numbers to rules in an ACL. Resequencing is useful when an ACL has rules numbered contiguously, such as 100 and 101, and you need to insert one or more rules between those rules.

## Statistics

The device can maintain global statistics for each rule that you configure in IPv4 and MAC ACLs. If an ACL is applied to multiple interfaces, the maintained rule statistics are the sum of packet matches (hits) on all the interfaces on which that ACL is applied.



### Note

The device does not support interface-level ACL statistics.

For each ACL that you configure, you can specify whether the device maintains statistics for that ACL, which allows you to turn ACL statistics on or off as needed to monitor traffic filtered by an ACL or to help troubleshoot the configuration of an ACL.

The device does not maintain statistics for implicit rules in an ACL. For example, the device does not maintain a count of packets that match the implicit **deny ip any any** rule at the end of all IPv4 ACLs. If you want to maintain statistics for implicit rules, you must explicitly configure the ACL with rules that are identical to the implicit rules. For more information, see the [“Implicit Rules” section on page 9-3](#).



***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

## ACL Logging

You can use access control list (ACL) logging to monitor flows that affect specific ACLs. The ACLs can be configured with the optional **log** keyword in each of the access control entries (ACEs). When you configure an option, statistics for each flow that match the ACL permit or deny conditions that you enter are logged in the software.

You can apply the log option to any ACL by entering the following commands:

```
(config)# ip access-list [name]
(config-acl)# permit tcp any 156.10.3.44/24 log
```

An implicit deny rule is the default action for ACLs. To log any packets that match the implicit deny rule, you must create an explicit deny rule and add the **log** keyword.

ACL logging is only applicable to ACLs that are configured with the **ip access-list** command. Other traffic such as the Virtual Supervisor Module (VSM) management interface or the selectors (aaa authen match, qos match, and so on) are not logged.

Statistics and logging are provided for each flow. A flow is defined by the following IP flows:

- VSM ID
- Virtual Ethernet Module (VEM) ID
- Source interface
- Protocol
- Source IP address
- Source port
- Destination IP address
- Destination port

Scalability is provided through the following functionality:

- Each Cisco Nexus 1000V switch can support up to 64 VEMs.
- Each VEM can support up to 5000 permits and 5000 denies flows. The maximum number of permit/deny flows is a configurable option.
- The flow reporting interval can be set from 5 up to 86,400 seconds (1 day).
- The configuration flow syslog level can be from 0 to 7.
- Up to three syslog servers are supported.

For information about troubleshooting ACL logging, see to the *Cisco Nexus 1000V Troubleshooting Guide, Release 4.2(1)SVI(5.1)*.

## ACL Flows

An ACL flow as it pertains to ACL logging has the following characteristics:

- It represents a stream of IPv4 packets with the same packet headers (SrcIP, DstIP, Protocol, SrcPort, DstPort) for which an identical ACL action is enforced. Each flow entry tracks the count of packets that match the flow.
- It is created only if logging is enabled on the corresponding ingress/egress ACL policy. Ingress and egress flows are tracked separately.

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

- Each VEM tracks a maximum of 10,000 ACL flows; a flow space is shared between permit/deny flows; each has a configurable maximum of 5000.
- Each flow entry contains the following:
  - Packet tuple
  - ACL action
  - Direction
  - Packet count
- The ACL flow life cycle is as follows:
  - A flow is created when the first packet of a unidirectional stream matches a Layer 3 ACL policy. A new flow notification is sent to the syslog server.
  - For all subsequent packets with a tuple that matches the flow-tuple, the per flow packet counter is incremented.
  - Each flow is tracked periodically based on the configured reporting interval. Within each periodic report, all the active flows and the corresponding packet count seen since the last periodic report are reported to the syslog server.
  - If no packets matches a flow for one full periodic interval, the flow entry is purged. This is the only flow-aging scheme.
  - A flow is not stateful. There is no connection tracking for TCP flows.
- The flow reporting process occurs in the following manner:
  - For each flow created, a new flow notification message is sent to the syslog server.
  - A periodic report for each active flow comes next. A flow is active if packets that match the flow are seen since the last periodic report.
  - The flow information is exported to the syslog server and contains the following: packet tuple, ACL action, direction, VEM-ID, VSM-ID, packet count.
  - The periodic time can be as low as 5 seconds with the default setting of 5 minutes. A new user space ACL-Logging thread handles the periodic poll and report functionality.
  - Syslog messages that identify the flow space usage are sent at 75 percent, 90 percent, and 100 percent of the threshold maximum to the syslog server once during each interval.

## Syslog Messages

Syslog message characteristics are as follows:

- Syslog messages that contain flow information are exported from each VEM.
- The syslog client functionality is RFC-5424 compliant and communicates to servers over a UDP port (514).
- The host must be configured with a vmknfc interface that can reach the remote syslog server.
- On an ESXi-5.0 host, syslog messages are blocked by a firewall. The Cisco Nexus 1000V has installation scripts that open the firewall for port 514.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

## Prerequisites for IP ACLs

IP ACLs have the following prerequisites:

- You must be familiar with IP addressing and protocols to configure IP ACLs.
- You must be familiar with the interface types that you want to configure with ACLs.

## Guidelines and Limitations

IP ACLs have the following configuration guidelines and limitations:

- In most cases, ACL processing for IP packets are processed on the I/O modules. Management interface traffic is always processed on the supervisor module, which is slower.
- ACLs are not supported in port channels.

## Default Settings

Table 9-1 lists the default settings for IP ACL parameters.

**Table 9-1** Default IP ACL Parameters

Parameters	Default
IP ACLs	No IP ACLs exist by default
ACL rules	Implicit rules apply to all ACLs (see the “Implicit Rules” section on page 9-3)

## Configuring IP ACLs

This section includes the following topics:

- [Creating an IP ACL, page 9-8](#)
- [Changing an IP ACL, page 9-9](#)
- [Removing an IP ACL, page 9-11](#)
- [Changing Sequence Numbers in an IP ACL, page 9-12](#)
- [Applying an IP ACL as a Port ACL, page 9-13](#)
- [Applying an IP ACL to the Management Interface, page 9-15](#)
- [Configuring ACL Logging, page 9-16](#)

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

## Creating an IP ACL

You can create an IPv4 ACL on the device and add rules to it.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.

### SUMMARY STEPS

- config t**
- [no] ip access-list** *{name | match-local-traffic}*
- [sequence-number] {permit | deny} protocol source destination*
- statistics per-entry**
- show ip access-lists** *name*
- copy running-config startup-config**

### DETAILED STEPS

	Command	Purpose
Step 1	<b>config t</b>  <b>Example:</b> n1000v# config t n1000v(config)#	Places you into CLI Global Configuration mode.
Step 2	<b>[no] ip access-list</b> <i>{name   match-local-traffic}</i>  <b>Example:</b> n1000v(config)# ip access-list acl-01 n1000v(config-acl)#  <b>Example:</b> n1000v(config)# ip access-list match-local-traffic n1000v(config-acl)#	Creates the named IP ACL (up to 64 characters in length) and enters IP ACL configuration mode.  The <b>match-local-traffic</b> option enables matching for locally-generated traffic.  The <b>no</b> option removes the specified access list.

**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**

	Command	Purpose
Step 3	<pre>[sequence-number] {permit   deny} protocol source destination</pre> <p><b>Example:</b>  n1000v(config-acl)# permit ip 192.168.2.0/24 any</p>	<p>Creates a rule in the IP ACL. You can create many rules. The <i>sequence-number</i> argument can be a whole number between 1 and 4294967295.</p> <p>The <b>permit</b> and <b>deny</b> commands support many ways of identifying traffic. For more information, see the <i>Cisco Nexus 1000V Command Reference, Release 4.2(1)SV1(5.1)</i>.</p>
Step 4	<pre>statistics per-entry</pre> <p><b>Example:</b>  n1000v(config-acl)# statistics per-entry</p>	(Optional) Specifies that the device maintains global statistics for packets that match the rules in the ACL.
Step 5	<pre>show ip access-lists name</pre> <p><b>Example:</b>  n1000v(config-acl)# show ip access-lists acl-01</p>	(Optional) Displays the IP ACL configuration.
Step 6	<pre>copy running-config startup-config</pre> <p><b>Example:</b>  n1000v(config-acl)# copy running-config startup-config</p>	(Optional) Copies the running configuration to the startup configuration.

## Changing an IP ACL

You can add and remove rules in an existing IPv4 ACL. You cannot change existing rules. Instead, to change a rule, you can remove it and recreate it with the desired changes.

If you need to add more rules between existing rules than the current sequence numbering allows, you can use the **resequence** command to reassign sequence numbers. For more information, see the “[Changing Sequence Numbers in an IP ACL](#)” section on page 9-12.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.

### SUMMARY STEPS

- config t**
- ip access-list name**
- [sequence-number] {permit | deny} protocol source destination**
- no {sequence-number | {permit | deny} protocol source destination}**
- [no] statistics per-entry**
- show ip access-list name**
- copy running-config startup-config**

**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**

## DETAILED STEPS

	Command	Purpose
Step 1	<pre>config t</pre> <p><b>Example:</b>  n1000v# config t  n1000v(config)#</p>	Places you into CLI Global Configuration mode.
Step 2	<pre>ip access-list name</pre> <p><b>Example:</b>  n1000v(config)# ip access-list acl-01  n1000v(config-acl)#</p>	Places you into IP ACL configuration mode for the specified ACL.
Step 3	<pre>[sequence-number] {permit   deny} protocol source destination</pre> <p><b>Example:</b>  n1000v(config-acl)# 100 permit ip  192.168.2.0/24 any</p>	<p>(Optional) Creates a rule in the IP ACL. Using a sequence number allows you to specify a position for the rule in the ACL. Without a sequence number, the rule is added to the end of the rules. The <i>sequence-number</i> argument can be a whole number between 1 and 4294967295.</p> <p>The <b>permit</b> and <b>deny</b> commands support many ways of identifying traffic. For more information, see the <i>Cisco Nexus 1000V Command Reference, Release 4.2(1)SVI(5.1)</i></p>
Step 4	<pre>no {sequence-number   {permit   deny} protocol source destination}</pre> <p><b>Example:</b>  n1000v(config-acl)# no 80</p>	<p>(Optional) Removes the rule that you specified from the IP ACL.</p> <p>The <b>permit</b> and <b>deny</b> commands support many ways of identifying traffic. For more information, see the <i>Cisco Nexus 1000V Command Reference, Release 4.2(1)SVI(5.1)</i>.</p>
Step 5	<pre>[no] statistics per-entry</pre> <p><b>Example:</b>  n1000v(config-acl)# statistics per-entry</p>	<p>(Optional) Specifies that the device maintains global statistics for packets that match the rules in the ACL.</p> <p>The <b>no</b> option stops the device from maintaining global statistics for the ACL.</p>
Step 6	<pre>show ip access-lists name</pre> <p><b>Example:</b>  n1000v(config-acl)# show ip access-lists  acl-01</p>	(Optional) Displays the IP ACL configuration.
Step 7	<pre>copy running-config startup-config</pre> <p><b>Example:</b>  n1000v(config-acl)# copy running-config  startup-config</p>	(Optional) Copies the running configuration to the startup configuration.

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

## Removing an IP ACL

You can remove an IP ACL from the device.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.
- Make sure that you know whether the ACL is applied to an interface.
- Removing an ACL does not affect the configuration of the interfaces where applied. Instead, the device considers the removed ACL to be empty.

### SUMMARY STEPS

1. **config t**
2. **[no] ip access-list *name***
3. **show ip access-list *name* summary**
4. **copy running-config startup-config**

### DETAILED STEPS

	Command	Purpose
Step 1	<b>config t</b>  <b>Example:</b> n1000v# config t n1000v(config)#	Places you into CLI Global Configuration mode.
Step 2	<b>no ip access-list <i>name</i></b>  <b>Example:</b> n1000v(config)# no ip access-list acl-01	Removes the IP ACL that you specified by name from the running configuration.
Step 3	<b>show ip access-list <i>name</i> summary</b>  <b>Example:</b> n1000v(config)# show ip access-lists acl-01 summary	(Optional) Displays the IP ACL configuration. If the ACL remains applied to an interface, the command lists the interfaces.
Step 4	<b>copy running-config startup-config</b>  <b>Example:</b> n1000v(config)# copy running-config startup-config	(Optional) Copies the running configuration to the startup configuration.

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

## Changing Sequence Numbers in an IP ACL

You can change all the sequence numbers assigned to the rules in an IP ACL.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.

### SUMMARY STEPS

- config t**
- resequence ip access-list** *name starting-sequence-number increment*
- show ip access-lists** *name*
- copy running-config startup-config**

### DETAILED STEPS

	Command	Purpose
Step 1	<b>config t</b>  <b>Example:</b> n1000v# config t n1000v(config)#	Places you into CLI Global Configuration mode.
Step 2	<b>resequence ip access-list</b> <i>name starting-sequence-number increment</i>  <b>Example:</b> n1000v(config)# resequence access-list ip acl-01 100 10	Assigns sequence numbers to the rules contained in the ACL, where the first rule receives the starting sequence number that you specify. Each subsequent rule receives a number larger than the preceding rule. The difference in numbers is determined by the increment that you specify. The <i>starting-sequence-number</i> argument and the <i>increment</i> argument can be a whole number between 1 and 4294967295.
Step 3	<b>show ip access-lists</b> <i>name</i>  <b>Example:</b> n1000v(config)# show ip access-lists acl-01	(Optional) Displays the IP ACL configuration.
Step 4	<b>copy running-config startup-config</b>  <b>Example:</b> n1000v(config)# copy running-config startup-config	(Optional) Copies the running configuration to the startup configuration.



***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

## Applying an IP ACL as a Port ACL

Use this procedure to configure a port ACL by applying an IPv4 or ACL to a Layer 2 interface physical port.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.
- You can apply one port ACL to an interface.
- Make sure that the ACL you want to apply exists and that it is configured to filter traffic in the manner that you need for this application. For more information, see the “Creating an IP ACL” section on page 9-8 or the “Changing an IP ACL” section on page 9-9.
- An IP ACL can also be configured in a port profile. For more information, see the “Adding an IP ACL to a Port Profile” procedure on page 9-14.

### SUMMARY STEPS

1. **config t**
2. **interface vethernet *port***
3. **ip port access-group *access-list* [in | out]**
4. **show running-config aclmgr**
5. **copy running-config startup-config**

### DETAILED STEPS

	Command	Purpose
Step 1	<b>config t</b>  <b>Example:</b> n1000v# config t n1000v(config)#	Places you into CLI Global Configuration mode.
Step 2	<b>interface vethernet <i>port</i></b>  <b>Example:</b> n1000v(config)# interface vethernet 40 n1000v(config-if)#	Places you into Interface Configuration mode for the specified vEthernet interface.
Step 3	<b>ip port access-group <i>access-list</i> [in   out]</b>  <b>Example:</b> n1000v(config-if)# ip port access-group acl-l2-marketing-group in	Applies an inbound or outbound IPv4 ACL to the interface. You can apply one port ACL to an interface.
Step 4	<b>show running-config aclmgr</b>  <b>Example:</b> n1000v(config-if)# show running-config aclmgr	(Optional) Displays the ACL configuration.

**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**

	Command	Purpose
Step 5	<pre>copy running-config startup-config</pre> <p><b>Example:</b>  <pre>n1000v(config-if)# copy running-config startup-config</pre></p>	(Optional) Copies the running configuration to the startup configuration.

## Adding an IP ACL to a Port Profile

You can use this procedure to add an IP ACL to a port profile:

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.
- You have already created the IP ACL to add to this port profile using the [“Creating an IP ACL” procedure on page 9-8](#); and you know its name.
- If using an existing port profile, you have already created it and you know its name.
- If creating a new port profile, you know the interface type (Ethernet or vEthernet) and the name you want to give the profile.
- For more information about port profiles, see the *Cisco Nexus 1000V Port Profile Configuration Guide, Release 4.2(1)SV1(5.1)*;
- You know the name of the IP access control list that you want to configure for this port profile.
- You know the direction of packet flow for the access list.

### SUMMARY STEPS

1. **config t**
2. **port-profile [type {ethernet | vethernet}] profile-name**
3. **ip port access-group name {in | out}**
4. **show port-profile [brief | expand-interface | usage] [name profile-name]**
5. **copy running-config startup-config**

**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**

## DETAILED STEPS

	Command	Description
Step 1	<code>config t</code>  <b>Example:</b> n1000v# config t n1000v(config)#	Enters global configuration mode.
Step 2	<code>port-profile [type {ethernet   vethernet}] name</code>  <b>Example:</b> n1000v(config)# port-profile AccessProf n1000v(config-port-prof)#	Enters port profile configuration mode for the named port profile.
Step 3	<code>ip port access-group name {in   out}</code>  <b>Example:</b> n1000v(config-port-prof)# ip port access-group allaccess4 out	Adds the named ACL to the port profile for either inbound or outbound traffic.
Step 4	<code>show port-profile name profile-name</code>  <b>Example:</b> n1000v(config-port-prof)# show port-profile name AccessProf	(Optional) Displays the configuration for verification.
Step 5	<code>copy running-config startup-config</code>  <b>Example:</b> n1000v(config-port-prof)# copy running-config startup-config	(Optional) Saves the running configuration persistently through reboots and restarts by copying it to the startup configuration.

## Applying an IP ACL to the Management Interface

Use this procedure to applying an IPv4 or ACL to the Management interface, mgmt0.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.
- Make sure that the ACL you want to apply exists and that it is configured to filter traffic in the manner that you need for this application. For more information, see the [“Creating an IP ACL” section on page 9-8](#) or the [“Changing an IP ACL” section on page 9-9](#).

### SUMMARY STEPS

1. `config t`
2. `interface mgmt0`
3. `[no] ip access-group access-list [in | out]`
4. `show ip access-lists access-list`
5. `copy running-config startup-config`

**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**

## DETAILED STEPS

	Command	Purpose
Step 1	<b>config t</b>  <b>Example:</b> n1000v# config t n1000v(config)#	Places you into CLI global configuration mode.
Step 2	<b>interface mgmt0</b>  <b>Example:</b> n1000v(config)# interface mgmt0 n1000v(config-if)#	Places you into interface configuration mode for the management interface.
Step 3	<b>[no] ip access-group access-list</b> <b>[in   out]</b>  <b>Example:</b> n1000v(config-if)# ip access-group telnet in n1000v(config-if)#	Applies a specified inbound or outbound IPv4 ACL to the interface.  The no option removes the specified configuration.
Step 4	<b>show ip access-lists access-list</b>  <b>Example:</b> n1000v(config-if)# show ip access-lists telnet summary IP access list telnet statistics per-entry Total ACEs Configured:2  Configured on interfaces: mgmt0 - ingress (Router ACL)  Active on interfaces: mgmt0 - ingress (Router ACL)	(Optional) Displays the ACL configuration.
Step 5	<b>copy running-config startup-config</b>  <b>Example:</b> n1000v(config-if)# copy running-config startup-config	(Optional) Copies the running configuration to the startup configuration.

## Configuring ACL Logging

ACL logging is enabled by default on all Virtual Ethernet Modules (VEMs). In addition, the following also apply to ACL logging configuration:

- Any rule can be enabled for logging by adding the **log** keyword.
- Only packets that have a rule with the **log** keyword enabled are logged.

## Disabling ACL Logging

You can disable ACL logging on a VEM by entering the following command:

Command	Purpose
<b>[no] logging ip access-list cache module vem</b>	Disables ACL logging on the specified VEM.

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

## Configuring a Time Interval for Accumulating Packet Counters

You can configure the time interval for accumulating packet counters before they are reported to the syslog servers. You enter the time range in seconds from 5 to 86,400 seconds (1 day). The default is 300 seconds (5 minutes).

You can configure the amount of time to accumulate packet counters by entering one of the following commands:

Command	Purpose
<b>logging ip access-list cache interval secs</b>	Sets the time interval in seconds to accumulate packet counters before they are reported to the syslog servers, where <i>num</i> is the number of seconds.
<b>[no] logging ip access-list cache interval secs</b>	Reverts the configuration to the default time interval configuration 300 seconds (5 minutes), where <i>num</i> is the number of seconds.

### EXAMPLES

These examples show the time interval syslog message format that is sent periodically when the time interval expires:

```
ACL-LOGGING-6-PERMIT-FLOW-INTERVAL <VSM-id> <VEM-id> <protocol> <source-interface>
<source-ip/source-port> <destination-ip/destination-port> Hit-count = <nnn>
```

```
ACL-LOGGING-6-DENY-FLOW-INTERVAL <VSM-id> <VEM-id> <protocol> <source-interface>
<source-ip/source-port> <destination-ip/destination-port> Hit-count = <nnn>
```

These examples show the time interval syslog message format that is sent when the time interval conditions are met:

```
ACL-LOGGING-6-MAX-PERMIT-FLOW-REACHED: The number of ACL log permit-flows has reached 75%
limit (<n>)
```

```
ACL-LOGGING-6-MAX-PERMIT-FLOW-REACHED: The number of ACL log permit-flows has reached 90%
limit (<n>)
```

```
ACL-LOGGING-6-MAX-PERMIT-FLOW-REACHED: The number of ACL log permit-flows has reached 100%
limit (<n>)
```

```
ACL-LOGGING-6-MAX-DENY-FLOW-REACHED: The number of ACL log deny-flows has reached 75%
limit (<n>)
```

```
ACL-LOGGING-6-MAX-DENY-FLOW-REACHED: The number of ACL log deny-flows has reached 90%
limit (<n>)
```

```
ACL-LOGGING-6-MAX-DENY-FLOW-REACHED: The number of ACL log deny-flows has reached 100%
limit (<n>)
```

## Configuring Flows

You can configure the number of deny and permit flows per VEM. The range is from 0 to 5000 flows. The default is 3000. A syslog message is sent when the flow is near the maximum threshold. The first message is sent when the number of flows has reached 75 percent of the maximum threshold and the next message is sent when the number of flows has reached 90 percent of the maximum threshold. The last message is sent when the number of flows reaches the maximum threshold 100 percent.

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

## Configuring Permit Flows

You can configure permit flows by entering one of the following commands:

Command	Purpose
<b>logging ip access-list cache max-permit-flows</b> <i>num</i>	Sets the number of permit flows where <i>num</i> is the number of flows.
<b>[no] logging ip access-list cache max-permit-flows</b>	Reverts the configuration to the default permit flow value 3000.

## EXAMPLES

These examples show permit flow syslog messages:

- New flow notification message

```
- Aug 28 04:17:19 fish-231-157.cisco.com 1 2011-08-28T11:14:23 - n1k-ecology -
ACLLOG-PERMIT-FLOW-CREATE VSM ID: 172.23.231.150, VEM ID:
86d04494-79e2-11df-a573-d0d0fd093c68, Source IP: 192.168.231.22, Destination IP:
192.168.231.21, Source Port: 42196, Destination Port: 8029, Source Interface: Veth2,
Protocol: "TCP" (6), Hit-count = 1
```

- Periodic flow reporting message

```
- Aug 28 04:17:20 sfish-231-157.cisco.com 1 2011-08-28T11:14:23 - n1k-acllog -
ACLLOG-PERMIT-FLOW-INTERVAL VSM ID: 172.23.231.150, VEM ID:
86d04494-79e2-11df-a573-d0d0fd093c68, Source IP: 192.168.231.22, Destination IP:
192.168.231.21, Source Port: 42196, Destination Port: 8029, Source Interface: Veth2,
Protocol: "TCP" (6), Hit-count = 1245
```

- Threshold crossing alarm messages

```
- Aug 28 04:17:22 sfish-231-157.cisco.com 1 2011-08-28T11:14:24 - n1k-acllog -
ACLLOG-MAX-PERMIT-FLOW-REACHED The number of ACL log permit-flows has reached 75 percent
limit (3969)
- Aug 28 04:17:26 sfish-231-157.cisco.com 1 2011-08-28T11:14:26 - n1k-acllog -
ACLLOG-MAX-PERMIT-FLOW-REACHED The number of ACL log permit-flows has reached 90 percent
limit (4969)
- Aug 28 04:17:27 sfish-231-157.cisco.com 1 2011-08-28T11:14:31 - n1k-acllog -
ACLLOG-MAX-PERMIT-FLOW-REACHED The number of ACL log permit-flows has reached 100 percent
limit (5000)
```

## Configuring Deny Flows

You can configure deny flows by entering one of the following commands:

Command	Purpose
<b>logging ip access-list cache max-deny-flows</b> <i>num</i>	Sets the number of deny flows, where <i>num</i> is the number of flows
<b>[no] logging ip access-list cache max-deny-flows</b>	Reverts the configuration back to the default deny flow value 3000.

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

## EXAMPLES

These examples show deny flow syslog messages:

- New flow notification message

```
- Aug 28 04:17:19 sfish-231-157.cisco.com 1 2011-08-28T11:14:23 - n1k-aclog -
ACLOG-DENY-FLOW-CREATE VSM ID: 172.23.231.150, VEM ID:
86d04494-79e2-11df-a573-d0d0fd093c68, Source IP: 192.168.231.22, Destination IP:
192.168.231.100, Source Port: 48528, Destination Port: 8029, Source Interface: Veth2,
Protocol: "TCP"(6), Hit-count = 1
```

- Periodic flow reporting message

```
- Aug 28 04:17:20 sfish-231-157.cisco.com 1 2011-08-28T11:14:23 - n1k-aclog -
ACLOG-DENY-FLOW-INTERVAL VSM ID: 172.23.231.150, VEM ID:
86d04494-79e2-11df-a573-d0d0fd093c68, Source IP: 192.168.231.22, Destination
IP:192.168.231.100, Source Port: 47164, Destination Port: 8029, Source Interface: Veth2,
Protocol: "TCP"(6), Hit-count = 1245
```

- Threshold crossing alarm messages

```
- Aug 28 04:17:27 sfish-231-157.cisco.com 1 2011-08-28T11:14:31 - n1k-aclog -
ACLOG-MAX-DENY-FLOW-REACHED The number of ACL log deny-flows has reached 75 percent limit
(4330)
- Aug 28 04:18:27 sfish-231-157.cisco.com 1 2011-08-28T11:15:31 - n1k-aclog -
ACLOG-MAX-DENY-FLOW-REACHED The number of ACL log deny-flows has reached 90 percent limit
(4630)
- Aug 28 04:20:17 sfish-231-157.cisco.com 1 2011-08-28T11:17:20 - n1k-aclog -
ACLOG-MAX-PERMIT-FLOW-REACHED The number of ACL log permit-flows has reached 100 percent
limit (5000)
```

## Configuring Syslog Server Severity Levels

You can configure severity levels of the ACL logging syslog messages for up to three remote syslog servers. The range is from 0 up to 7. The default severity level is 6. See the [“Configuring Flows” section on page 9-17](#) for examples. [Table 9-2](#) lists the severity code, the severity level, and the description of each severity level.

**Table 9-2**      **Severity Levels**

Severity code	Severity level	Description
0	Emergency	System is unusable
1	Alert	Action must be taken immediately
2	Critical	Critical conditions
3	Error	Error conditions
4	Warning	Warning conditions
5	Notice	Normal but significant condition
6	Informational	Informational messages.
7	Debug	Debug-level messages

You can set the severity level of a syslog message and the server to which you want the message to be sent by entering one of the following commands:

**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**

Command	Purpose
<code>aclog match-log-level <i>level</i></code>	Sets the severity level at which syslog messages are sent, where <i>level</i> is the severity code from 0 to 7.
<code>[no] logging ip access-list cache max-deny-flows</code>	Reverts the configuration back to the default severity level 6.
<code>logging server <i>A.B.C.D 0-7</i></code>	Specifies the syslog server on which you want to set a severity level, where <i>A.B.C.D</i> is the syslog server IP address and <i>0-7</i> are the severity levels you can choose.

## Verifying the IP ACL Configuration

To display IP ACL configuration information, use the following commands:

Command	Purpose
<code>show running-config aclmgr</code>	Displays the ACL configuration, including IP ACL configuration and interfaces that IP ACLs are applied to.
<code>show ip access-lists [<i>name</i>]</code>	Displays all IPv4 access control lists (ACLs) or a named IPv4 ACL.
<code>show ip access-list [<i>name</i>] summary</code>	Displays a summary of all configured IPv4 ACLs or a named IPv4 ACL.
<code>show running-config interface</code>	Displays the configuration of an interface to which you have applied an ACL.
<code>show logging ip access-list status</code>	Displays the ACL logging configuration for a VSM
<code>vemcmd show aclog config</code>	Displays the VEM ACL logging configuration

## Monitoring IP ACL

Use the following commands for IP ACL monitoring:

Command	Purpose
<code>show ip access-lists</code>	Displays IPv4 ACL configuration. If the IPv4 ACL includes the <b>statistics per-entry</b> command, then the <code>show ip access-lists</code> command output includes the number of packets that have matched each rule.
<code>clear ip access-list counters</code>	Clears statistics for all IPv4 ACLs or for a specific IPv4 ACL.



*Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).*

## Example Configurations for IP ACL

This example shows how to create an IPv4 ACL named acl-01 and apply it as a port ACL to vEthernet interface 40:

```
ip access-list acl-01
  permit ip 192.168.2.0/24 any
interface vethernet 40
ip port access-group acl-01 in
```

This example shows how to enable access list matching for locally-generated traffic:

```
ip access-list match-local-traffic
```

This example shows how to verify VSM ACL logging configuration:

```
vsm# show logging ip access-list status
Max deny flows    = 3000
Max permit flows  = 3000
Alert interval    = 300
Match log level   = 6
VSM IP = 192.168.1.1
Syslog IP = 10.1.1.1
Syslog IP = 0.0.0.0
Syslog IP = 0.0.0.0

ACL Logging enabled on module(s):
 4  5  6  7  8  9 10 11 12 13 14 15 16 17 18 19
20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35
36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51
52 53 54 55 56 57 58 59 60 61 62 63 64 65 66

ACL Logging disabled on module(s):
 3
```

This example shows how to verify VEM ACL logging configuration:

```
vem# vemcmd show acllog config
ACL-Log Config:
Status:                enabled
Reporting Interval:    300
Max Permit Flows:      3000
Max Deny Flows:        3000
Syslog Facility :      4
Syslog Severity:       6
Syslog Srvr 1:         10.1.1.1
Syslog Srvr 2:         0.0.0.0
Syslog Srvr 3:         0.0.0.0
VSM:                   192.168.1.1
```

## Additional References

For additional information related to implementing IP ACLs, see the following sections:

- [Related Documents, page 9-22](#)
- [Standards, page 9-22](#)

**[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)**

## Related Documents

Related Topic	Document Title
ACL concepts.	<i>Information About ACLs, page 9-1</i>
Configuring interfaces.	<i>Cisco Nexus 1000V Interface Configuration Guide, Release 4.2(1)SV1(5.1)</i>
Configuring port profiles.	<i>Cisco Nexus 1000V Port Profile Configuration Guide, Release 4.2(1)SV1(5.1)</i>
Complete command syntax, command modes, command history, defaults, usage guidelines, and examples for Cisco Nexus 1000V commands.	<i>Cisco Nexus 1000V Command Reference, Release 4.2(1)SV1(5.1)</i>

## Standards

Standards	Title
No new or modified standards are supported by this feature, and support for existing standards has not been modified by this feature.	—

## Feature History for IP ACL

This section provides the IP ACL release history.

Feature Name	Releases	Feature Information
IP ACL for mgmt0 interface	4.2(1) SV1(4)	
IP ACL	4.0(4)SV1(1)	This feature was introduced.



# CHAPTER 10

## Configuring a MAC ACL

---

This chapter describes how to configure MAC access control lists (ACLs), and includes the following sections:

- [Information About MAC ACLs, page 10-1](#)
- [Prerequisites for MAC ACLs, page 10-1\](#)
- [Guidelines and Limitations, page 10-2](#)
- [Default Settings, page 10-2](#)
- [Configuring MAC ACLs, page 10-2](#)
- [Verifying MAC ACL Configurations, page 10-9](#)
- [Monitoring MAC ACLs, page 10-10](#)
- [Example Configurations for MAC ACLs, page 10-11](#)
- [Additional References, page 10-11](#)
- [Feature History for MAC ACL, page 10-12](#)

### Information About MAC ACLs

MAC ACLs are ACLs that filter traffic using information in the Layer 2 header of each packet.

### Prerequisites for MAC ACLs

MAC ACLs have the following prerequisites:

- You are familiar with MAC addressing and non-IP protocols to configure MAC ACLs.
- You are familiar with the concepts in the [“Information About ACLs” section on page 9-1](#).

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

## Guidelines and Limitations

MAC ACLs have the following configuration guidelines and limitations:

- In most cases, ACL processing for IP packets are processed on the I/O modules. Management interface traffic is always processed on the supervisor module, which is slower.
- ACLs are not supported in port channels.

## Default Settings

Table 10-1 lists MAC ACL defaults.

**Table 10-1** Default MAC ACLs Parameters

Parameters	Default
MAC ACLs	No MAC ACLs exist by default
ACL rules	Implicit rules apply to all ACLs (see the <a href="#">“Implicit Rules” section on page 9-3</a> )

## Configuring MAC ACLs

This section includes the following topics:

- [Creating a MAC ACL, page 10-2](#)
- [Changing a MAC ACL, page 10-4](#)
- [Removing a MAC ACL, page 10-5](#)
- [Changing Sequence Numbers in a MAC ACL, page 10-6](#)
- [Applying a MAC ACL as a Port ACL, page 10-7](#)
- [Adding a MAC ACL to a Port Profile, page 10-8](#)

## Creating a MAC ACL

Use this procedure to create a MAC ACL and add rules to it. You can also use this procedure to add the ACL to a port profile.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.
- You have a name to assign to the ACL you are creating.
- If you want to also add the ACL to a port-profile, you must know or do the following:
  - If using an existing port profile, you have already created it using the *Cisco Nexus 1000V Port Profile Configuration Guide, Release 4.2(1)SV1(5.1)*; and you know its name.

**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**

- If creating a new port profile, you know the interface type (Ethernet or vEthernet) and the name you want to give the profile.
- You know the direction of packet flow for the access list.

## SUMMARY STEPS

1. `config t`
2. `mac access-list name`
3. `{permit | deny} source destination protocol`
4. `statistics per-entry`
5. `show mac access-lists name`
6. `copy running-config startup-config`

## DETAILED STEPS

	Command	Purpose
Step 1	<code>config t</code>  <b>Example:</b> n1000v# config t n1000v(config)#	Places you into CLI Global Configuration mode.
Step 2	<code>mac access-list name</code>  <b>Example:</b> n1000v(config)# mac access-list acl-mac-01 n1000v(config-mac-acl)#	Creates the MAC ACL and enters ACL configuration mode.
Step 3	<code>{permit   deny} source destination protocol</code>  <b>Example:</b> n1000v(config-mac-acl)# permit 00c0.4f00.0000 0000.00ff.ffff any	Creates a rule in the MAC ACL.  The <b>permit</b> and <b>deny</b> commands support many ways of identifying traffic. For more information, see the <i>Cisco Nexus 1000V Command Reference, Release 4.2(1)SV1(5.1)</i> .
Step 4	<code>statistics per-entry</code>  <b>Example:</b> n1000v(config-mac-acl)# statistics per-entry	(Optional) Specifies that the device maintains global statistics for packets that match the rules in the ACL.
Step 5	<code>show mac access-lists name</code>  <b>Example:</b> n1000v(config-mac-acl)# show mac access-lists acl-mac-01	(Optional) Displays the MAC ACL configuration for verification.
Step 6	<code>copy running-config startup-config</code>  <b>Example:</b> n1000v(config-mac-acl)# copy running-config startup-config	(Optional) Copies the running configuration to the startup configuration.

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

## Changing a MAC ACL

Use this procedure to change an existing MAC ACL, for example, to add or remove rules.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.
- In an existing MAC ACL, you cannot change existing rules.
- In an existing MAC ACL, you can add and remove rules.
- Use the **resequence** command to reassign sequence numbers, such as when adding rules between existing sequence numbers.

### SUMMARY STEPS

1. **config t**
2. **mac access-list name**
3. *[sequence-number] {permit | deny} source destination protocol*
4. **no {sequence-number | {permit | deny} source destination protocol}**
5. **[no] statistics per-entry**
6. **show mac access-lists name**
7. **copy running-config startup-config**

### DETAILED STEPS

	Command	Purpose
Step 1	<b>config t</b>  <b>Example:</b> n1000v# config t n1000v(config)#	Places you into CLI Global Configuration mode.
Step 2	<b>mac access-list name</b>  <b>Example:</b> n1000v(config)# mac access-list acl-mac-01 n1000v(config-mac-acl)#	Places you in ACL configuration mode for the ACL that you specify by name.
Step 3	<i>[sequence-number] {permit   deny} source destination protocol</i>  <b>Example:</b> n1000v(config-mac-acl)# 100 permit mac 00c0.4f00.00 0000.00ff.ffff any	(Optional) Creates a rule in the MAC ACL. Using a sequence number allows you to specify a position for the rule in the ACL. Without a sequence number, the rule is added to the end of the rules.  The <b>permit</b> and <b>deny</b> commands support many ways of identifying traffic. For more information, see the <i>Cisco Nexus 1000V Command Reference, Release 4.2(1)SV1(5.1)</i> .

**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**

	Command	Purpose
Step 4	<pre>no {sequence-number   {permit   deny} source destination protocol}</pre> <p><b>Example:</b> n1000v(config-mac-acl)# no 80</p>	<p>(Optional) Removes the rule that you specify from the MAC ACL.</p> <p>The <b>permit</b> and <b>deny</b> commands support many ways of identifying traffic. For more information, see the <i>Cisco Nexus 1000V Command Reference, Release 4.2(1)SV1(5.1)</i>.</p>
Step 5	<pre>[no] statistics per-entry</pre> <p><b>Example:</b> n1000v(config-mac-acl)# statistics per-entry</p>	<p>(Optional) Specifies that the device maintains global statistics for packets that match the rules in the ACL.</p> <p>The <b>no</b> option stops the device from maintaining global statistics for the ACL.</p>
Step 6	<pre>show mac access-lists name</pre> <p><b>Example:</b> n1000v(config-mac-acl)# show mac access-lists acl-mac-01</p>	<p>(Optional) Displays the MAC ACL configuration.</p>
Step 7	<pre>copy running-config startup-config</pre> <p><b>Example:</b> n1000v(config-mac-acl)# copy running-config startup-config</p>	<p>(Optional) Copies the running configuration to the startup configuration.</p>

## Removing a MAC ACL

Use this procedure to remove a MAC ACL.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.
- Make sure that you know whether the ACL is applied to an interface.
- You can remove ACLs that are currently applied. Removing an ACL does not affect the configuration of interfaces where you have applied the ACL. Instead, removed ACLs are considered empty.
- To find the interfaces that a MAC ACL is configured on, use the **show mac access-lists** command with the **summary** keyword.

### SUMMARY STEPS

1. **config t**
2. **no mac access-list name**
3. **show mac access-lists name summary**
4. **copy running-config startup-config**

**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**

## DETAILED STEPS

	Command	Purpose
Step 1	<b>config t</b>  <b>Example:</b> n1000v# config t n1000v(config)#	Places you into CLI Global Configuration mode.
Step 2	<b>no mac access-list name</b>  <b>Example:</b> n1000v(config)# no mac access-list acl-mac-01 n1000v(config)#	Removes the specified MAC ACL from the running configuration.
Step 3	<b>show mac access-lists name summary</b>  <b>Example:</b> n1000v(config)# show mac access-lists acl-mac-01 summary	(Optional) Displays the MAC ACL configuration. If the ACL remains applied to an interface, the command lists the interfaces.
Step 4	<b>copy running-config startup-config</b>  <b>Example:</b> n1000v(config)# copy running-config startup-config	(Optional) Copies the running configuration to the startup configuration.

## Changing Sequence Numbers in a MAC ACL

Use this procedure to change sequence numbers assigned to rules in a MAC ACL. Resequencing is useful when you need to insert rules into an ACL and there are not enough available sequence numbers. For more information, see the [“Changing Sequence Numbers in a MAC ACL”](#) section on page 10-6.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.

### SUMMARY STEPS

- config t**
- resequence mac access-list name starting-sequence-number increment**
- show mac access-lists name**
- copy running-config startup-config**



**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**

## DETAILED STEPS

	Command	Purpose
Step 1	<code>config t</code>  <b>Example:</b> n1000v# config t n1000v(config)#	Places you into CLI Global Configuration mode.
Step 2	<code>resequence mac access-list name starting-sequence-number increment</code>  <b>Example:</b> n1000v(config)# resequence mac access-list acl-mac-01 100 10	Assigns sequence numbers to the rules contained in the ACL, where the first rule receives the number specified by the starting-sequence number that you specify. Each subsequent rule receives a number larger than the preceding rule. The difference in numbers is determined by the increment number that you specify.
Step 3	<code>show mac access-lists name</code>  <b>Example:</b> n1000v(config)# show mac access-lists acl-mac-01	(Optional) Displays the MAC ACL configuration.
Step 4	<code>copy running-config startup-config</code>  <b>Example:</b> n1000v(config)# copy running-config startup-config	(Optional) Copies the running configuration to the startup configuration.

## Applying a MAC ACL as a Port ACL

Use this procedure to apply a MAC ACL as a port ACL.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.
- Make sure that the ACL that you want to apply exists and is configured to filter traffic in the manner that you need for this application. For more information about configuring MAC ACLs, see the [“Configuring MAC ACLs” section on page 10-2](#).
- A MAC ACL can also be applied to a port using a port profile. For information about port profiles, see the *Cisco Nexus 1000V Port Profile Configuration Guide, Release 4.2(1)SV1(5.1)*.

### SUMMARY STEPS

1. `config t`
2. `interface vethernet port`
3. `mac port access-group access-list [in | out]`
4. `show running-config aclmgr`
5. `copy running-config startup-config`

**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**

## DETAILED STEPS

	Command	Purpose
Step 1	<code>config t</code>  <b>Example:</b> n1000v# config t n1000v(config)#	Places you into CLI Global Configuration mode.
Step 2	<code>interface vethernet port</code>  <b>Example:</b> n1000v(config)# interface vethernet 35 n1000v(config-if)#	Places you into Interface Configuration mode for the specified interface.
Step 3	<code>mac port access-group access-list [in   out]</code>  <b>Example:</b> n1000v(config-if)# mac port access-group acl-01 in	Applies a MAC ACL to the interface.
Step 4	<code>show running-config aclmgr</code>  <b>Example:</b> n1000v(config-if)# show running-config aclmgr	(Optional) Displays ACL configuration.
Step 5	<code>copy running-config startup-config</code>  <b>Example:</b> n1000v(config-if)# copy running-config startup-config	(Optional) Copies the running configuration to the startup configuration.

## Adding a MAC ACL to a Port Profile

You can use this procedure to add a MAC ACL to a port profile:

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.
- You have already created the MAC ACL to add to this port profile using the [“Creating a MAC ACL” procedure on page 10-2](#); and you know its name.
- If using an existing port profile, you have already created it and you know its name.
- If creating a new port profile, you know the interface type (Ethernet or vEthernet) and the name you want to give the profile.
- For more information about port profiles, see the *Cisco Nexus 1000V Port Profile Configuration Guide, Release 4.2(1)SV1(5.1)*;
- You know the direction of packet flow for the access list.

### SUMMARY STEPS

1. `config t`

**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**

2. `port-profile [type {ethernet | vethernet}] profile-name`
3. `mac port access-group name {in | out}`
4. `show port-profile [brief | expand-interface | usage] [name profile-name]`
5. `copy running-config startup-config`

## DETAILED STEPS

	Command	Description
Step 1	<code>config t</code>  <b>Example:</b> n1000v# <code>config t</code> n1000v(config)#	Enters global configuration mode.
Step 2	<code>port-profile [type {ethernet   vethernet}] name</code>  <b>Example:</b> n1000v(config)# <code>port-profile AccessProf</code> n1000v(config-port-prof)#	Enters port profile configuration mode for the named port profile.
Step 3	<code>mac port access-group name {in   out}</code>  <b>Example:</b> n1000v(config-port-prof)# <code>mac port access-group allaccess4 out</code>	Adds the named ACL to the port profile for either inbound or outbound traffic.
Step 4	<code>show port-profile name profile-name</code>  <b>Example:</b> n1000v(config-port-prof)# <code>show port-profile name AccessProf</code>	(Optional) Displays the configuration for verification.
Step 5	<code>copy running-config startup-config</code>  <b>Example:</b> n1000v(config-port-prof)# <code>copy running-config startup-config</code>	(Optional) Saves the running configuration persistently through reboots and restarts by copying it to the startup configuration.

## Verifying MAC ACL Configurations

You can use the following commands to verify the MAC ACL configuration:

Command	Purpose
<code>show mac access-lists</code>	Displays the MAC ACL configuration. See <a href="#">Example 10-1 on page 10-10</a> .
<code>show running-config aclmgr</code>	Displays the ACL configuration, including MAC ACLs and the interfaces they are applied to. See <a href="#">Example 10-2 on page 10-10</a> .
<code>show running-config interface</code>	Displays the configuration of the interface to which you applied the ACL. See <a href="#">Example 10-3 on page 10-10</a> .

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

**Example 10-1 show mac access-list**

```
n1000v# show mac access-list

MAC access list acl-mac-01
    10 permit 00c0.4f00.0000 0000.00ff.ffff any
n1000v#
```

**Example 10-2 show running-config aclmgr**

```
n1000v# show running-config aclmgr

!Command: show running-config aclmgr
!Time: Mon Jan  3 15:53:50 2011

version 4.2(1)SV1(4)
mac access-list acl-mac-01
    10 permit 00c0.4f00.0000 0000.00ff.ffff any

interface Vethernet35
    mac port access-group acl-mac-01 in
n1000v#
```

**Example 10-3 show running-config interface**

```
n1000v# show running-config interface

!Command: show running-config interface
!Time: Mon Jan  3 15:58:25 2011

version 4.2(1)SV1(4)

interface mgmt0
    ip address 172.23.180.75/24

interface Vethernet35
    mac port access-group acl-mac-01 in

interface Vethernet1998

interface control0
    ip address 10.2.10.10/24

n1000v#
```

## Monitoring MAC ACLs

Use the following commands for MAC ACL monitoring.

**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**

Command	Purpose
<code>show mac access-lists</code>	Displays the MAC ACL configuration. If the MAC ACL includes the <b>statistics per-entry</b> command, the <b>show mac access-lists</b> command output includes the number of packets that have matched each rule.
<code>clear mac access-list counters</code>	Clears statistics for all MAC ACLs or for a specific MAC ACL.

## Example Configurations for MAC ACLs

This example shows how to create MAC ACL `acl-mac-01` to permit MAC `00c0.4f00.0000.00ff.ffff` for any protocol, and apply the ACL as a port ACL for outbound traffic on vEthernet interface 35.

```
config t
mac access-list acl-mac-01
    permit 00c0.4f00.0000 0000.00ff.ffff any
interface vethernet 35
mac port access-group acl-mac-01 out
```

This example shows how to add the MAC ACL `allaccess4` to the port profile `AccessProf`:

```
config t
port-profile AccessProf
mac port access-group allaccess4 out
show port-profile name AccessProf
port-profile AccessProf
    description: allaccess4
    type: vethernet
    status: disabled
    capability l3control: no
    pinning control-vlan: -
    pinning packet-vlan: -
    system vlans: none
    port-group:
    max ports: 32
    inherit:
    config attributes:
        mac port access-group allaccess4 out
    evaluated config attributes:
        mac port access-group allaccess4 out
    assigned interfaces:
```

## Additional References

For additional information related to implementing MAC ACLs, see the following sections:

- [Related Documents, page 10-12](#)
- [Standards, page 10-12](#)

**[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)**

## Related Documents

Related Topic	Document Title
ACL concepts.	<a href="#">Information About ACLs, page 9-1</a>
Configuring interfaces.	<i>Cisco Nexus 1000V Interface Configuration Guide, Release 4.2(1)SV1(5.1)</i>
Configuring port profiles.	<i>Cisco Nexus 1000V Port Profile Configuration Guide, Release 4.2(1)SV1(5.1)</i>
Complete command syntax, command modes, command history, defaults, usage guidelines, and examples for all Cisco Nexus 1000V commands.	<i>Cisco Nexus 1000V Command Reference, Release 4.2(1)SV1(5.1)</i>

## Standards

Standards	Title
No new or modified standards are supported by this feature, and support for existing standards has not been modified by this feature.	—

## Feature History for MAC ACL

This section provides the MAC ACL release history.

Feature Name	Releases	Feature Information
MAC ACL	4.0(4)SV1(1)	This feature was introduced.



## CHAPTER 11

# Configuring Port Security

---

This chapter describes how to configure port security and includes the following sections:

- [Information About Port Security](#), page 11-1
- [Guidelines and Limitations](#), page 11-5
- [Additional References](#), page 11-19
- [Configuring Port Security](#), page 11-6
- [Verifying the Port Security Configuration](#), page 11-18
- [Displaying Secure MAC Addresses](#), page 11-18
- [Example Configuration for Port Security](#), page 11-18
- [Additional References](#), page 11-19
- [Feature History for Port Security](#), page 11-19

## Information About Port Security

Port security lets you configure Layer 2 interfaces permitting inbound traffic from a restricted, secured set of MAC addresses. Traffic from secured MAC addresses is not allowed on another interface within the same VLAN. The number of MAC addresses that can be secured is configured per interface.

This section includes the following topics:

- [Secure MAC Address Learning](#), page 11-1
- [Dynamic Address Aging](#), page 11-2
- [Secure MAC Address Maximums](#), page 11-3
- [Security Violations and Actions](#), page 11-4
- [Port Security and Port Types](#), page 11-5

## Secure MAC Address Learning

The process of securing a MAC address is called learning. The number of addresses that can be learned is restricted, as described in the [“Secure MAC Address Maximums” section on page 11-3](#). Address learning can be accomplished using the following methods on any interface where port security is enabled:

- [Static Method](#), page 11-2

## ***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

- [Dynamic Method, page 11-2](#) (the default method)
- [Sticky Method, page 11-2](#)

### **Static Method**

The static learning method lets you manually add or remove secure MAC addresses in the configuration of an interface.

A static secure MAC address entry remains in the configuration of an interface until you explicitly remove it. For more information, see the [“Removing a Static or a Sticky Secure MAC Address from an Interface” section on page 11-10](#).

Adding secure addresses by the static method is not affected by whether dynamic or sticky address learning is enabled.

### **Dynamic Method**

By default, when you enable port security on an interface, you enable the dynamic learning method. With this method, the device secures MAC addresses as ingress traffic passes through the interface. If the address is not yet secured and the device has not reached any applicable maximum, it secures the address and allows the traffic.

Dynamic addresses are aged and dropped once the age limit is reached, as described in the [“Dynamic Address Aging” section on page 11-2](#).

Dynamic addresses do not persist through restarts.

To remove a specific address learned by the dynamic method or to remove all addresses learned by the dynamic method on a specific interface, see the [“Removing a Dynamic Secure MAC Address” section on page 11-11](#).

### **Sticky Method**

If you enable the sticky method, the device secures MAC addresses in the same manner as dynamic address learning. These addresses can be made persistent through a reboot by copying the running-configuration to the startup-configuration, **copy run start**.

Dynamic and sticky address learning are mutually exclusive. When you enable sticky learning on an interface, dynamic learning is stopped and sticky learning is used instead. If you disable sticky learning, dynamic learning is resumed.

Sticky secure MAC addresses are not aged.

To remove a specific address learned by the sticky method, see the [“Removing a Static or a Sticky Secure MAC Address from an Interface” section on page 11-10](#).

### **Dynamic Address Aging**

MAC addresses learned by the dynamic method are aged and dropped when reaching the age limit. You can configure the age limit on each interface. The range is from 0 to 1440 minutes, where 0 disables aging.

There are two methods of determining address age:



***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***


- Inactivity—The length of time after the device last received a packet from the address on the applicable interface.
- Absolute—The length of time after the device learned the address. This is the default aging method; however, the default aging time is 0 minutes, which disables aging.

## Secure MAC Address Maximums

The secure MAC addresses on a secure port are inserted in the same MAC address table as other regular MACs. If a MAC table has reached its limit, then it will not learn any new secure MACs for that VLAN.

Figure 11-1 shows that each VLAN in a VEM has a forwarding table that can store a maximum number of secure MAC addresses. For current MAC address maximums, see [Security Configuration Limits, page 17-1](#).

**Figure 11-1** Secure MAC Addresses per VEM



## Interface Secure MAC Addresses

By default, an interface can have only one secure MAC address. You can configure the maximum number of MAC addresses permitted per interface or per VLAN on an interface. Maximums apply to secure MAC addresses learned by any method: dynamic, sticky, or static.



### Tip

To make use of the full bandwidth of the port, set the maximum number of addresses to one and configure the MAC address of the attached device.

The following limits can determine how many secure MAC address are permitted on an interface:

- Device maximum—The device has a nonconfigurable limit of 8192 secure MAC addresses. If learning a new address would violate the device maximum, the device does not permit the new address to be learned, even if the interface or VLAN maximum has not been reached.

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

- **Interface maximum**—You can configure a maximum number of secure MAC addresses for each interface protected by port security. The default interface maximum is one address. Interface maximums cannot exceed the device maximum.
- **VLAN maximum**—You can configure the maximum number of secure MAC addresses per VLAN for each interface protected by port security. A VLAN maximum cannot exceed the interface maximum. VLAN maximums are useful only for trunk ports. There are no default VLAN maximums.

For an example of how VLAN and interface maximums interact, see the [“Security Violations and Actions” section on page 11-4](#).

You can configure VLAN and interface maximums per interface, as needed; however, when the new limit is less than the applicable number of secure addresses, you must reduce the number of secure MAC addresses first. To remove dynamically learned addresses, see the [“Removing a Dynamic Secure MAC Address” section on page 11-11](#). To remove addresses learned by the sticky or static methods, see the [“Removing a Static or a Sticky Secure MAC Address from an Interface” section on page 11-10](#).

## Security Violations and Actions

Port security triggers a security violation when either of the following occurs:

- Ingress traffic arrives at an interface from a nonsecure MAC address and learning the address would exceed the applicable maximum number of secure MAC addresses.

When an interface has both a VLAN maximum and an interface maximum configured, a violation occurs when either maximum is exceeded. For example, consider the following on a single interface configured with port security:

- VLAN 1 has a maximum of 5 addresses
- The interface has a maximum of 10 addresses

A violation is detected when either of the following occurs:

- Five addresses are learned for VLAN 1 and inbound traffic from a sixth address arrives at the interface in VLAN 1.
- Ten addresses are learned on the interface and inbound traffic from an 11th address arrives at the interface.
- Ingress traffic from a secure MAC address arrives at a different interface in the same VLAN as the interface on which the address is secured.




---

**Note** After a secure MAC address is configured or learned on one secure port, the sequence of events that occurs when port security detects that secure MAC address on a different port in the same VLAN is known as a MAC move violation.

---

When a security violation occurs on an interface, the action specified in its port security configuration is applied. The possible actions that the device can take are as follows:

- **Shutdown**—Shuts down the interface that received the packet triggering the violation. The interface is error disabled. This action is the default. After you reenables the interface, it retains its port security configuration, including its secure MAC addresses.

You can use the **errdisable** global configuration command to configure the device to reenables the interface automatically if a shutdown occurs, or you can manually reenables the interface by entering the **shutdown** and **no shut down** interface configuration commands.

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

**Example:**

```
n1000v(config)# errdisable recovery cause psecure-violation
n1000v(config)# copy running-config startup-config (Optional)
```

- **Protect**—Prevents violations from occurring. Address learning continues until the maximum number of MAC addresses on the interface is reached, after which the device disables learning on the interface and drops all ingress traffic from nonsecure MAC addresses.

If a violation occurs because ingress traffic from a secure MAC address arrives at a different interface than the interface on which the address is secure, the action is applied on the interface that received the traffic. A MAC Move Violation is triggered on the port seeing the MAC which is already secured on another interface.

## Port Security and Port Types

You can configure port security only on Layer 2 interfaces. Details about port security and different types of interfaces or ports are as follows:

- **Access ports**—You can configure port security on interfaces that you have configured as Layer 2 access ports. On an access port, port security applies only to the access VLAN.
- **Trunk ports**—You can configure port security on interfaces that you have configured as Layer 2 trunk ports. VLAN maximums are not useful for access ports. The device allows VLAN maximums only for VLANs associated with the trunk port.
- **SPAN ports**—You can configure port security on SPAN source ports but not on SPAN destination ports.
- **Ethernet Ports**—Port security is not supported on Ethernet ports.
- **Ethernet Port Channels**—Port security is not supported on Ethernet port channels.

### Result of Changing an Access Port to a Trunk Port

When you change an access port to a trunk port on a Layer 2 interface configured with port security, all secure addresses learned by the dynamic method are dropped. The device moves the addresses learned by the static or sticky method to the native trunk VLAN.

### Result of Changing a Trunk Port to an Access Port

When you change a trunk port to an access port on a Layer 2 interface configured with port security, all secure addresses learned by the dynamic method are dropped. All configured and sticky MAC addresses are dropped if they are not on the native trunk VLAN and do not match the access VLAN configured for the access port they are moving to.

## Guidelines and Limitations

When configuring port security, follow these guidelines:

- Port security is not supported on the following:
  - Ethernet interfaces
  - Ethernet port-channel interfaces

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

- Switched port analyzer (SPAN) destination ports
- The port security feature cannot be applied for the Control, Management, and AIPC interfaces of the VSM.
- Port security does not depend upon other features.
- Port security does not support 802.1X.
- Port Security cannot be configured on interfaces with existing static MACs.
- Port Security cannot be enabled on interfaces whose VLANs have an existing static MAC even if it is programmed on a different interface.

## Default Settings

Table 11-1 lists the default settings for port security parameters.

**Table 11-1**      **Default Port Security Parameters**

Parameters	Default
Interface	Disabled
MAC address learning method	Dynamic
Interface maximum number of secure MAC addresses	1
Security violation action	Shutdown

## Configuring Port Security

This section includes the following topics:

- [Enabling or Disabling Port Security on a Layer 2 Interface, page 11-7](#)
- [Enabling or Disabling Sticky MAC Address Learning, page 11-8](#)
- [Adding a Static Secure MAC Address on an Interface, page 11-9](#)
- [Removing a Static or a Sticky Secure MAC Address from an Interface, page 11-10](#)
- [Removing a Dynamic Secure MAC Address, page 11-11](#)
- [Configuring a Maximum Number of MAC Addresses, page 11-12](#)
- [Configuring an Address Aging Type and Time, page 11-14](#)
- [Configuring a Security Violation Action, page 11-15](#)
- [Recovering Ports Disabled for Port Security Violations, page 11-17](#)

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

## Enabling or Disabling Port Security on a Layer 2 Interface

Use this procedure to enable or disable port security on a Layer 2 interface. For more information about dynamic learning of MAC addresses, see the [“Secure MAC Address Learning”](#) section on page 11-1.



Note You cannot enable port security on a routed interface.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.
- By default, port security is disabled on all interfaces.
- Enabling port security on an interface also enables dynamic MAC address learning. If you want to enable sticky MAC address learning, you must also complete the steps in the [“Enabling or Disabling Sticky MAC Address Learning”](#) section on page 11-8.

### SUMMARY STEPS

1. **config t**
2. **interface** *type number*
3. **[no] switchport port-security**
4. **show running-config port-security**
5. **copy running-config startup-config**

### DETAILED STEPS

	Command	Purpose
Step 1	<b>config t</b>  <b>Example:</b> n1000v# config t n1000v(config)#	Places you into CLI Global Configuration mode.

**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**

	Command	Purpose
Step 2	<b>interface</b> <i>type number</i>  <b>Example:</b> n1000v(config)# interface vethernet 36 n1000v(config-if)#	Places you into Interface Configuration mode for the specified interface.
Step 3	[no] <b>switchport port-security</b>  <b>Example:</b> n1000v(config-if)# switchport port-security	Enables port security on the interface.  Using the <b>no</b> option disables port security on the interface.
Step 4	<b>show running-config port-security</b>  <b>Example:</b> n1000v(config-if)# show running-config port-security	Displays the port security configuration.
Step 5	<b>copy running-config startup-config</b>  <b>Example:</b> n1000v(config-if)# copy running-config startup-config	(Optional) Copies the running configuration to the startup configuration.

## Enabling or Disabling Sticky MAC Address Learning

Use this procedure to disable or enable sticky MAC address learning on an interface.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.
- Dynamic MAC address learning is the default on an interface.
- By default, sticky MAC address learning is disabled.
- Make sure that port security is enabled on the interface that you are configuring.
  - To verify the configuration, see the “[Verifying the Port Security Configuration](#)” section on [page 11-18](#).
  - To enable port security on the interface, see the “[Enabling or Disabling Port Security on a Layer 2 Interface](#)” section on [page 11-7](#).

### SUMMARY STEPS

1. **config t**
2. **interface** *type number*
3. [no] **switchport port-security mac-address sticky**
4. **show running-config port-security**
5. **copy running-config startup-config**

**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**

## DETAILED STEPS

	Command	Purpose
Step 1	<code>config t</code>  <b>Example:</b> n1000v# config t n1000v(config)#	Places you into CLI Global Configuration mode.
Step 2	<code>interface type number</code>  <b>Example:</b> n1000v(config)# interface vethernet 36 n1000v(config-if)#	Places you into Interface Configuration mode for the specified interface.
Step 3	<code>[no] switchport port-security mac-address sticky</code>  <b>Example:</b> n1000v(config-if)# switchport port-security mac-address sticky	Enables sticky MAC address learning on the interface.  Using the <b>no</b> option disables sticky MAC address learning.
Step 4	<code>show running-config port-security</code>  <b>Example:</b> n1000v(config-if)# show running-config port-security	Displays the port security configuration.
Step 5	<code>copy running-config startup-config</code>  <b>Example:</b> n1000v(config-if)# copy running-config startup-config	(Optional) Copies the running configuration to the startup configuration.

## Adding a Static Secure MAC Address on an Interface

Use this procedure to add a static secure MAC address on a Layer 2 interface.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.
- By default, no static secure MAC addresses are configured on an interface.
- Determine if the interface maximum has been reached for secure MAC addresses (use the **show port-security** command).
- If needed, you can remove a secure MAC address. See one of the following:
  - “Removing a Static or a Sticky Secure MAC Address from an Interface” section on page 11-10
  - “Removing a Dynamic Secure MAC Address” section on page 11-11)
  - “Configuring a Maximum Number of MAC Addresses” section on page 11-12).
- Make sure that port security is enabled on the interface that you are configuring.
  - To verify the configuration, see the “Verifying the Port Security Configuration” section on page 11-18.

## Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).

- To enable port security on the interface, see the “Enabling or Disabling Port Security on a Layer 2 Interface” section on page 11-7.

### SUMMARY STEPS

1. **config t**
2. **interface** *type number*
3. **[no] switchport port-security mac-address** *address* [**vlan** *vlan-ID*]
4. **show running-config port-security**
5. **copy running-config startup-config**

### DETAILED STEPS

	Command	Purpose
Step 1	<b>config t</b>  <b>Example:</b> n1000v# config t n1000v(config)#	Places you into CLI Global Configuration mode.
Step 2	<b>interface</b> <i>type number</i>  <b>Example:</b> n1000v(config)# interface vethernet 36 n1000v(config-if)#	Places you into Interface Configuration mode for the specified interface.
Step 3	<b>[no] switchport port-security mac-address</b> <i>address</i> [ <b>vlan</b> <i>vlan-ID</i> ]  <b>Example:</b> n1000v(config-if)# switchport port-security mac-address 0019.D2D0.00AE	Configures a static MAC address for port security on the current interface. Use the <b>vlan</b> keyword if you want to specify the VLAN that traffic from the address is allowed on.
Step 4	<b>show running-config port-security</b>  <b>Example:</b> n1000v(config-if)# show running-config port-security	Displays the port security configuration.
Step 5	<b>copy running-config startup-config</b>  <b>Example:</b> n1000v(config-if)# copy running-config startup-config	(Optional) Copies the running configuration to the startup configuration.

## Removing a Static or a Sticky Secure MAC Address from an Interface

Use this procedure to remove a static or a sticky secure MAC address from a Layer 2 interface.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.
- Make sure that port security is enabled on the interface that you are configuring.



***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

- To verify the configuration, see the “Verifying the Port Security Configuration” section on page 11-18.
- To enable port security on the interface, see the “Enabling or Disabling Port Security on a Layer 2 Interface” section on page 11-7.

## SUMMARY STEPS

1. **config t**
2. **interface** *type number*
3. **no switchport port-security mac-address** *address* [**vlan** *vlan-ID*]
4. **show running-config port-security**
5. **copy running-config startup-config**

## DETAILED STEPS

	Command	Purpose
Step 1	<b>config t</b>  <b>Example:</b> n1000v# config t n1000v(config)#	Places you into CLI Global Configuration mode.
Step 2	<b>interface</b> <i>type number</i>  <b>Example:</b> n1000v(config)# interface vethernet 36 n1000v(config-if)#	Places you into Interface Configuration mode for the specified interface.
Step 3	<b>no switchport port-security mac-address</b> <i>address</i>  <b>Example:</b> n1000v(config-if)# no switchport port-security mac-address 0019.D2D0.00AE	Removes the MAC address from port security on the current interface.
Step 4	<b>show running-config port-security</b>  <b>Example:</b> n1000v(config-if)# show running-config port-security	Displays the port security configuration.
Step 5	<b>copy running-config startup-config</b>  <b>Example:</b> n1000v(config-if)# copy running-config startup-config	(Optional) Copies the running configuration to the startup configuration.

## Removing a Dynamic Secure MAC Address

Use this procedure to remove a dynamically learned, secure MAC address.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**

- You are logged in to the CLI in EXEC mode.

## SUMMARY STEPS

- `config t`
- `clear port-security dynamic {interface vethernet number | address address} [vlan vlan-ID]`
- `show port-security address`

## DETAILED STEPS

	Command	Purpose
Step 1	<code>config t</code>  <b>Example:</b> n1000v# config t n1000v(config)#	Places you into CLI Global Configuration mode.
Step 2	<code>clear port-security dynamic {interface vethernet <i>number</i>   address <i>address</i>} [vlan <i>vlan-ID</i>]</code>  <b>Example:</b> n1000v(config)# clear port-security dynamic interface vethernet 36	Removes dynamically learned, secure MAC addresses, as specified.  If you use the <b>interface</b> keyword, you remove all dynamically learned addresses on the interface that you specify.  If you use the <b>address</b> keyword, you remove the single, dynamically learned address that you specify.  Use the <b>vlan</b> keyword if you want to further limit the command to removing an address or addresses on a particular VLAN.
Step 3	<code>show port-security address</code>  <b>Example:</b> n1000v(config)# show port-security address	Displays secure MAC addresses.

## Configuring a Maximum Number of MAC Addresses

Use this procedure to configure the maximum number of MAC addresses that can be learned or statically configured on a Layer 2 interface. You can also configure a maximum number of MAC addresses per VLAN on a Layer 2 interface. The largest maximum number of addresses that you can configure is 4096 addresses.



### Note

When you specify a maximum number of addresses that is less than the number of addresses already learned or statically configured on the interface, the command is rejected.

To reduce the number of addresses learned by the sticky or static methods, see the [“Removing a Static or a Sticky Secure MAC Address from an Interface”](#) section on page 11-10.

To remove all addresses learned by the dynamic method, use the **shutdown** and **no shutdown** commands to restart the interface.

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

## BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.
- The Secure MACs share the L2 Forwarding Table (L2FT). The forwarding table for each VLAN can hold up to 1024 entries.
- By default, an interface has a maximum of one secure MAC address.
- VLANs have no default maximum number of secure MAC addresses.
- Make sure that port security is enabled on the interface that you are configuring.
  - To verify the configuration, see the “[Verifying the Port Security Configuration](#)” section on page 11-18.
  - To enable port security on the interface, see the “[Enabling or Disabling Port Security on a Layer 2 Interface](#)” section on page 11-7.

## SUMMARY STEPS

1. **config t**
2. **interface *type number***
3. **[no] switchport port-security maximum *number* [vlan *vlan-ID*]**
4. **show running-config port-security**
5. **copy running-config startup-config**

## DETAILED STEPS

	Command	Purpose
Step 1	<b>config t</b>  <b>Example:</b> n1000v# config t n1000v(config)#	Places you into CLI Global Configuration mode.
Step 2	<b>interface <i>type number</i></b>  <b>Example:</b> n1000v(config)# interface vethernet 36 n1000v(config-if)#	Places you into Interface Configuration mode for the specified interface.
Step 3	<b>[no] switchport port-security maximum <i>number</i> [vlan <i>vlan-ID</i>]</b>  <b>Example:</b> n1000v(config-if)# switchport port-security maximum 425	Configures the maximum number of MAC addresses that can be learned or statically configured for the current interface. The highest valid <i>number</i> is 4096. The <b>no</b> option resets the maximum number of MAC addresses to the default, which is 1.  If you want to specify the VLAN that the maximum applies to, use the <b>vlan</b> keyword.

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

	Command	Purpose
Step 4	<b>show running-config port-security</b>  <b>Example:</b> n1000v(config-if)# show running-config port-security	Displays the port security configuration.
Step 5	<b>copy running-config startup-config</b>  <b>Example:</b> n1000v(config-if)# copy running-config startup-config	(Optional) Copies the running configuration to the startup configuration.

## Configuring an Address Aging Type and Time

Use this procedure to configure the MAC address aging type and the length of time used to determine when MAC addresses learned by the dynamic method have reached their age limit.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.
- By default, the aging time is 0 minutes, which disables aging.
- Absolute aging is the default aging type.
- Make sure that port security is enabled on the interface that you are configuring.
  - To verify the configuration, see the “[Verifying the Port Security Configuration](#)” section on [page 11-18](#).
  - To enable port security on the interface, see the “[Enabling or Disabling Port Security on a Layer 2 Interface](#)” section on [page 11-7](#).

### SUMMARY STEPS

1. **config t**
2. **interface *type number***
3. **[no] switchport port-security aging type {absolute | inactivity}**
4. **[no] switchport port-security aging time *minutes***
5. **show running-config port-security**
6. **copy running-config startup-config**

**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**

## DETAILED STEPS

	Command	Purpose
Step 1	<code>config t</code>  <b>Example:</b> n1000v# config t n1000v(config)#	Places you into CLI Global Configuration mode.
Step 2	<code>interface type number</code>  <b>Example:</b> n1000v(config)# interface vethernet 36 n1000v(config-if)#	Places you into Interface Configuration mode for the specified interface.
Step 3	<code>[no] switchport port-security aging type {absolute   inactivity}</code>  <b>Example:</b> n1000v(config-if)# switchport port-security aging type inactivity	Configures the type of aging that the device applies to dynamically learned MAC addresses. The <b>no</b> option resets the aging type to the default, which is absolute aging.
Step 4	<code>[no] switchport port-security aging time minutes</code>  <b>Example:</b> n1000v(config-if)# switchport port-security aging time 120	Configures the number of minutes that a dynamically learned MAC address must age before the address is dropped. The maximum valid <i>minutes</i> is 1440. The <b>no</b> option resets the aging time to the default, which is 0 minutes (no aging).
Step 5	<code>show running-config port-security</code>  <b>Example:</b> n1000v(config-if)# show running-config port-security	Displays the port security configuration.
Step 6	<code>copy running-config startup-config</code>  <b>Example:</b> n1000v(config-if)# copy running-config startup-config	(Optional) Copies the running configuration to the startup configuration.

## Configuring a Security Violation Action

Use this procedure to configure how an interface responds to a security violation.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.
- The default security action is to shut down the port on which the security violation occurs.
- You can configure the following interface responses to security violations:
  - protect—Drops packets with unknown source addresses until you remove a sufficient number of secure MAC addresses to drop below the maximum value.
  - restrict—Drops packets with unknown source addresses until you remove a sufficient number of secure MAC addresses to drop below the maximum value and causes the SecurityViolation counter to increment.

## Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).

- shutdown—(the default) Puts the interface into the error-disabled state immediately and sends an SNMP trap notification.

For more information, see the “[Security Violations and Actions](#)” section on page 11-4.

- Make sure that port security is enabled on the interface that you are configuring.
  - To verify the configuration, see the “[Verifying the Port Security Configuration](#)” section on page 11-18.
  - To enable port security on the interface, see the “[Enabling or Disabling Port Security on a Layer 2 Interface](#)” section on page 11-7.

### SUMMARY STEPS

1. `config t`
2. `interface type number`
3. `[no] switchport port-security violation {protect | restrict | shutdown}`
4. `show running-config port-security`
5. `copy running-config startup-config`

### DETAILED STEPS

	Command	Purpose
Step 1	<pre>config t</pre> <p><b>Example:</b>  <pre>n1000v# config t n1000v(config)#</pre></p>	Places you into CLI Global Configuration mode.
Step 2	<pre>interface type number</pre> <p><b>Example:</b>  <pre>n1000v(config)# interface vethernet 36 n1000v(config-if)#</pre></p>	Places you into Interface Configuration mode for the specified interface.
Step 3	<pre>[no] switchport port-security violation {protect   restrict   shutdown}</pre> <p><b>Example:</b>  <pre>n1000v(config-if)# switchport port-security violation protect</pre></p>	<p>Configures the security violation action for port security on the current interface. The <b>no</b> option resets the violation action to the default, which is to shut down the interface.</p> <ul style="list-style-type: none"> <li>• <b>protect:</b> Drops packets with unknown source addresses until you remove a sufficient number of secure MAC addresses to drop below the maximum value.</li> <li>• <b>restrict:</b> Drops packets with unknown source addresses until you remove a sufficient number of secure MAC addresses to drop below the maximum value and increments the SecurityViolation counter.</li> <li>• <b>shutdown:</b> (the default) Puts the interface into the error-disabled state immediately and sends an SNMP trap notification.</li> </ul>

**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**

	Command	Purpose
Step 4	<b>show running-config port-security</b>  <b>Example:</b> n1000v(config-if)# show running-config port-security	Displays the port security configuration.
Step 5	<b>copy running-config startup-config</b>  <b>Example:</b> n1000v(config-if)# copy running-config startup-config	(Optional) Copies the running configuration to the startup configuration.

## Recovering Ports Disabled for Port Security Violations

Use this procedure to automatically recover an interface disabled for port security violations.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.
- To recover an interface manually from the error-disabled state, you must enter the **shutdown** command and then the **no shutdown** command.
- For more information, see the “Security Violations and Actions” section on page 11-4.

### SUMMARY STEPS

1. **config t**
2. **interface** *type number*
3. **errdisable recovery cause psecure-violation**
4. **errdisable recovery interval** *seconds*
5. **show interface** *type number*

### DETAILED STEPS

	Command	Purpose
Step 1	<b>config t</b>  <b>Example:</b> n1000v# config t n1000v(config)#	Places you into CLI Global Configuration mode.
Step 2	<b>interface</b> <i>type number</i>  <b>Example:</b> n1000v(config)# interface vethernet 36 n1000v(config-if)#	Places you into Interface Configuration mode for the specified interface.

**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**

	Command	Purpose
Step 3	<b>errdisable recovery cause psecure-violation</b>  <b>Example:</b> n1000v(config-if)# errdisable recovery cause psecure-violation	Enables timed automatic recovery of the specified port that is disabled for port security violation.
Step 4	<b>errdisable recovery interval <i>seconds</i></b>  <b>Example:</b> n1000v(config-if)# errdisable recovery interval 30	Configures a timer recovery interval in seconds from 30 to 65535 seconds.
Step 5	<b>show interface <i>type number</i></b>  <b>Example:</b> n1000v(config-if)# show running-config port-security	Displays the interface state for verification.

## Verifying the Port Security Configuration

Use the following commands to display the port security configuration information:

Command	Purpose
<b>show running-config port-security</b>	Displays the port security configuration
<b>show port-security</b>	Displays the port security status.

For detailed information about the fields in the output from this command, see the *Cisco Nexus 1000V Command Reference, Release 4.2(1)SV1(5.1)*.

## Displaying Secure MAC Addresses

Use the **show port-security address** command to display secure MAC addresses. For detailed information about the fields in the output from this command, see the *Cisco Nexus 1000V Command Reference, Release 4.2(1)SV1(5.1)*.

## Example Configuration for Port Security

The following example shows a port security configuration for vEthernet 36 interface with VLAN and interface maximums for secure addresses. In this example, the interface is a trunk port. Additionally, the violation action is set to Protect.

```
interface vethernet 36
switchport port-security
  switchport port-security maximum 10
  switchport port-security maximum 7 vlan 10
  switchport port-security maximum 3 vlan 20
  switchport port-security violation protect
```



***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

## Additional References

For additional information related to implementing port security, see the following sections:

- [Related Documents, page 11-19](#)
- [Standards, page 11-19](#)

## Related Documents

Related Topic	Document Title
Layer 2 switching	<i>Cisco Nexus 1000V Layer 2 Switching Configuration Guide, Release 4.2(1)SV1(5.1)</i>
Port security commands: complete command syntax, command modes, command history, defaults, usage guidelines, and examples	<i>Cisco Nexus 1000V Command Reference, Release 4.2(1)SV1(5.1)</i>

## Standards

Standards	Title
No new or modified standards are supported by this feature, and support for existing standards has not been modified by this feature.	—

## Feature History for Port Security

This section provides the port security feature release history.

Feature Name	Releases	Feature Information
Port Security	4.0(4)SV1(1)	This feature was introduced.

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***



## CHAPTER 12

# Configuring DHCP Snooping

---

This chapter describes how to configure Dynamic Host Configuration Protocol (DHCP) snooping and includes the following sections:

- [Information About DHCP Snooping, page 12-1](#)
- [Prerequisites for DHCP Snooping, page 12-3](#)
- [Guidelines and Limitations, page 12-4](#)
- [Default Settings, page 12-4](#)
- [Configuring DHCP Snooping, page 12-4](#)
- [Verifying the DHCP Snooping Configuration, page 12-16](#)
- [Monitoring DHCP Snooping, page 12-16](#)
- [Example Configuration for DHCP Snooping, page 12-16](#)
- [Additional References, page 12-17](#)
- [Feature History for DHCP Snooping, page 12-17](#)

## Information About DHCP Snooping

This section includes the following topics:

- [Overview, page 12-1](#)
- [Trusted and Untrusted Sources, page 12-2](#)
- [DHCP Snooping Binding Database, page 12-2](#)

## Overview

DHCP snooping acts like a firewall between untrusted hosts and trusted DHCP servers by doing the following:

- Validates DHCP messages received from untrusted sources and filters out invalid response messages from DHCP servers.
- Builds and maintains the DHCP snooping binding database, which contains information about untrusted hosts with leased IP addresses.
- Uses the DHCP snooping binding database to validate subsequent requests from untrusted hosts.

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

Dynamic ARP inspection (DAI) and IP Source Guard also use information stored in the DHCP snooping binding database. For more information about these features, see [Chapter 13, “Configuring Dynamic ARP Inspection”](#) and [Chapter 14, “Configuring IP Source Guard.”](#)

DHCP snooping is enabled globally and per VLAN. By default, DHCP snooping is inactive on all VLANs. You can enable the feature on a single VLAN or a range of VLANs.

## Trusted and Untrusted Sources

DHCP snooping identifies ports as trusted or untrusted. When you enable DHCP snooping, by default all vEthernet ports are untrusted and all ethernet ports (uplinks), port channels, special vEthernet ports (used by other features, such as VSD, for their operation) are trusted. You can configure whether DHCP trusts traffic sources.

In an enterprise network, a trusted source is a device that is under your administrative control. Any device beyond the firewall or outside the network is an untrusted source. Generally, host ports are treated as untrusted sources.

In a service provider environment, any device that is not in the service provider network is an untrusted source (such as a customer switch). Host ports are untrusted sources.

In the Cisco Nexus 1000V, you indicate that a source is trusted by configuring the trust state of its connecting interface. Uplink ports, as defined with the uplink capability on port profiles, are trusted and cannot be configured to be untrusted. This restriction prevents the uplink from being shut down for not conforming to rate limits or DHCP responses.

You can also configure other interfaces as trusted if they connect to devices (such as switches or routers) inside your network or if the administrator is running the DHCP server in a VM. You usually do not configure host port interfaces as trusted.

**Note**

---

For DHCP snooping to function properly, all DHCP servers must be connected to the device through trusted interfaces.

---

## DHCP Snooping Binding Database

Using information extracted from intercepted DHCP messages, DHCP snooping dynamically builds and maintains a database on each VEM. The database contains an entry for each untrusted host with a leased IP address if the host is associated with a VLAN that has DHCP snooping enabled. The database does not contain entries for hosts connected through trusted interfaces.

**Note**

---

The DHCP snooping binding database is also referred to as the DHCP snooping binding table.

---

DHCP snooping updates the database when the device receives specific DHCP messages. For example, the feature adds an entry to the database when the device receives a DHCPACK message from the server. The feature removes the entry in the database when the IP address lease expires or the device receives a DHCPRELEASE or DHCP DECLINE from the DHCP client or a DHCPNACK from the DHCP server.

Each entry in the DHCP snooping binding database includes the MAC address of the host, the leased IP address, the lease time, the binding type, and the VLAN number and interface information associated with the host.

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

You can remove dynamically added entries from the binding database by using the **clear ip dhcp snooping binding** command. For more information, see the “[Clearing the DHCP Snooping Binding Database](#)” section on page 12-13.

## Relay Agent Information Option

You can configure DHCP to add the VSM MAC address and vEthernet port in the DHCP packet. This is called the DHCP Relay Agent Information Option, or Option 82, and is inserted by the DHCP relay agent when forwarding DHCP packets. Server administrators may use the information to implement IP address assignment policies.

The relay agent identifies the following:

Information Option	Description
circuit ID	vEthernet port name
remote ID	VSM MAC address

For detailed information about the Relay Agent Information Option, see [RFC-3046, DHCP Relay Agent Information Option](#).

To configure the relay agent, see the “[Relaying Switch and Circuit Information in DHCP](#)” procedure on page 12-15.

## High Availability

The DHCP snooping binding table and all database entries created on the VEM are exported to the VSM and are persistent across VSM reboots.

## Prerequisites for DHCP Snooping

DHCP snooping has the following prerequisites:

- You must be familiar with DHCP to configure DHCP snooping.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

## Guidelines and Limitations

DHCP snooping has the following configuration guidelines and limitations:

- A DHCP snooping database is stored on each VEM and can contain up to 1024 bindings.
- For seamless DHCP snooping, Virtual Service Domain (VSD) service VM ports are trusted ports by default. If you configure these ports as untrusted, this setting is ignored.
- If the VSM uses the VEM for connectivity (that is, the VSM has its VSM AIPC, management, and inband ports on a particular VEM), these virtual Ethernet interfaces must be configured as trusted interfaces.
- The connecting interfaces on a device upstream from the Cisco Nexus 1000V must be configured as trusted if DHCP snooping is enabled on the device.
- If you are configuring more than 128 ACLs (MAC and IP ACLs combined) then make sure the VSM RAM is set to be 3GB (3072 Mb). The procedure to change the RAM to 3GB is explained at [Setting the VSM RAM size to 3072 Mb \(hyperlink\)](#).

## Default Settings

Table 12-1 lists the defaults for DHCP snooping.

**Table 12-1** Default DHCP Snooping Parameters

Parameters	Default
DHCP feature	Disabled
DHCP snooping global	Disabled
DHCP snooping VLAN	Disabled
DHCP snooping MAC address verification	Enabled
DHCP snooping trust	Trusted for Ethernet interfaces, vEthernet interfaces, and port channels, in the VSD feature. Untrusted for vEthernet interfaces not participating in the VSD feature.

## Configuring DHCP Snooping

This section includes the following topics:

- [Minimum DHCP Snooping Configuration, page 12-5](#)
- [Enabling or Disabling the DHCP Feature, page 12-5](#)
- [Enabling or Disabling DHCP Snooping Globally, page 12-6](#)
- [Enabling or Disabling DHCP Snooping on a VLAN, page 12-7](#)
- [Enabling or Disabling DHCP Snooping MAC Address Verification, page 12-8](#)
- [Configuring an Interface as Trusted or Untrusted, page 12-9](#)
- [Configuring the Rate Limit for DHCP Packets, page 12-10](#)
- [Detecting Ports Disabled for DHCP Rate Limit Violation, page 12-11](#)

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

- [Recovering Ports Disabled for DHCP Rate Limit Violations](#), page 12-12
- [Clearing the DHCP Snooping Binding Database](#), page 12-13
- [Relaying Switch and Circuit Information in DHCP](#), page 12-15

## Minimum DHCP Snooping Configuration

The minimum configuration for DHCP snooping is as follows:

- 
- |               |  |
|---------------|--|
| <b>Step 1</b> | Enable the DHCP feature. For more information, see the <a href="#">“Enabling or Disabling the DHCP Feature” section on page 12-5</a> .   |
| <b>Step 2</b> | Enable DHCP snooping globally. For more information, see the <a href="#">“Enabling or Disabling DHCP Snooping Globally” section on page 12-6</a> .   |
| <b>Step 3</b> | Enable DHCP snooping on at least one VLAN. For more information, see the <a href="#">“Enabling or Disabling DHCP Snooping on a VLAN” section on page 12-7</a> .<br>By default, DHCP snooping is disabled on all VLANs. |
| <b>Step 4</b> | Ensure that the DHCP server is connected to the device using a trusted interface. For more information, see the <a href="#">“Configuring an Interface as Trusted or Untrusted” section on page 12-9</a> .              |
- 

## Enabling or Disabling the DHCP Feature

Use this procedure to globally enable or disable the DHCP feature.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.
- By default, DHCP is disabled.

### SUMMARY STEPS

1. **config t**
2. **feature dhcp**
3. **show feature**
4. **copy running-config startup-config**

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

## DETAILED STEPS

	Command	Purpose
Step 1	<b>config t</b>  <b>Example:</b> n1000v# config t n1000v(config)#	Enters global configuration mode.
Step 2	<b>feature dhcp</b>  <b>Example:</b> n1000v(config)# feature dhcp  <b>Example:</b> n1000v(config)# no feature dhcp	Enables DHCP snooping globally. The <b>no</b> option disables DHCP snooping but preserves an existing DHCP snooping configuration.
Step 3	<b>show feature</b>  <b>Example:</b> n1000v(config)# show feature Feature Name            Instance    State ----- dhcp-snooping            1            enabled http-server              1            enabled lcp                        1            enabled netflow                   1            disabled port-profile-roles       1            enabled private-vlan             1            disabled sshServer                1            enabled tacacs                    1            enabled telnetServer             1            enabled n1000v(config)#	Shows the state (enabled or disabled) of each available feature.
Step 4	<b>copy running-config startup-config</b>  <b>Example:</b> n1000v(config)# copy running-config startup-config	(Optional) Saves the running configuration persistently through reboots and restarts by copying it to the startup configuration.

## Enabling or Disabling DHCP Snooping Globally

Use this procedure to globally enable or disable the DHCP snooping.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- By default, DHCP snooping is globally disabled.
- If DHCP snooping is globally disabled, all DHCP snooping stops and no DHCP messages are relayed.
- If you configure DHCP snooping and then globally disable it, the remaining configuration is preserved.

### SUMMARY STEPS

1. **config t**



***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

2. `[no] ip dhcp snooping`
3. `show running-config dhcp`
4. `copy running-config startup-config`

## DETAILED STEPS

	Command	Purpose
Step 1	<code>config t</code>  <b>Example:</b> n1000v# <code>config t</code> n1000v(config)#	Enters global configuration mode.
Step 2	<code>[no] ip dhcp snooping</code>  <b>Example:</b> n1000v(config)# <code>ip dhcp snooping</code>	Enables DHCP snooping globally. The <b>no</b> option disables DHCP snooping but preserves an existing DHCP snooping configuration.
Step 3	<code>show running-config dhcp</code>  <b>Example:</b> n1000v(config)# <code>show running-config dhcp</code>	Shows the DHCP snooping configuration.
Step 4	<code>copy running-config startup-config</code>  <b>Example:</b> n1000v(config)# <code>copy running-config startup-config</code>	(Optional) Saves the running configuration persistently through reboots and restarts by copying it to the startup configuration.

## Enabling or Disabling DHCP Snooping on a VLAN

Use this procedure to enable or disable DHCP snooping on one or more VLANs.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.
- By default, DHCP snooping is disabled on all VLANs.

### SUMMARY STEPS

1. `config t`
2. `[no] ip dhcp snooping vlan vlan-list`
3. `show running-config dhcp`
4. `copy running-config startup-config`

**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**

## DETAILED STEPS

	Command	Purpose
Step 1	<b>config t</b>  <b>Example:</b> n1000v# config t n1000v(config)#	Enters global configuration mode.
Step 2	[no] ip dhcp snooping vlan <i>vlan-list</i>  <b>Example:</b> n1000v(config)# ip dhcp snooping vlan 100,200,250-252	Enables DHCP snooping on the VLANs specified by <i>vlan-list</i> . The <b>no</b> option disables DHCP snooping on the VLANs specified.
Step 3	<b>show running-config dhcp</b>  <b>Example:</b> n1000v(config)# show running-config dhcp	Shows the DHCP snooping configuration.
Step 4	<b>copy running-config startup-config</b>  <b>Example:</b> n1000v(config)# copy running-config startup-config	(Optional) Saves the running configuration persistently through reboots and restarts by copying it to the startup configuration.

## Enabling or Disabling DHCP Snooping MAC Address Verification

Use this procedure to enable or disable DHCP snooping MAC address verification. If the device receives a packet on an untrusted interface and the source MAC address and the DHCP client hardware address do not match, address verification causes the device to drop the packet.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.
- MAC address verification is enabled by default.

### SUMMARY STEPS

1. **config t**
2. [no] **ip dhcp snooping verify mac-address**
3. **show running-config dhcp**
4. **copy running-config startup-config**

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

## DETAILED STEPS

	Command	Purpose
Step 1	<code>config t</code>  <b>Example:</b> n1000v# config t n1000v(config)#	Enters global configuration mode.
Step 2	<code>[no] ip dhcp snooping verify mac-address</code>  <b>Example:</b> n1000v(config)# ip dhcp snooping verify mac-address	Enables DHCP snooping MAC address verification. The <b>no</b> option disables MAC address verification.
Step 3	<code>show running-config dhcp</code>  <b>Example:</b> n1000v(config)# show running-config dhcp	Shows the DHCP snooping configuration.
Step 4	<code>copy running-config startup-config</code>  <b>Example:</b> n1000v(config)# copy running-config startup-config	(Optional) Saves the running configuration persistently through reboots and restarts by copying it to the startup configuration.

## Configuring an Interface as Trusted or Untrusted

Use this procedure to configure whether a virtual interface is a trusted or untrusted source of DHCP messages. You can configure DHCP trust on the following:

- Layer 2 vEthernet interfaces
- Port Profiles for Layer 2 vEthernet interfaces

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.
- By default, vEthernet interfaces are untrusted. The only exception is the special vEthernet ports used by other features such as VSD which are trusted
- Ensure that the vEthernet interface is configured as a Layer 2 interface.
- For seamless DHCP snooping, DAI, and IP Source Guard, Virtual Service Domain (VSD) service VM ports are trusted ports by default. If you configure these ports as untrusted, this setting is ignored.

### SUMMARY STEPS

1. `config t`
2. `interface vethernet interface-number`  
`port-profile profilename`
3. `[no] ip dhcp snooping trust`
4. `show running-config dhcp`

**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**

5. `copy running-config startup-config`

## DETAILED STEPS

	Command	Purpose
Step 1	<code>config t</code>  <b>Example:</b> n1000v# <code>config t</code> n1000v(config)#	Enters global configuration mode.
Step 2	<code>interface vethernet interface-number</code>  <b>Example:</b> n1000v(config)# <code>interface vethernet 3</code> n1000v(config-if)#  <code>port-profile profilename</code>  <b>Example:</b> n1000v(config)# <code>port-profile vm-data</code> n1000v(config-port-prof)#	Enters interface configuration mode, where <i>interface-number</i> is the vEthernet interface that you want to configure as trusted or untrusted for DHCP snooping.  Enters port profile configuration mode for the specified port profile, where <i>profilename</i> is a unique name of up to 80 characters.
Step 3	<code>[no] ip dhcp snooping trust</code>  <b>Example:</b> n1000v(config-if)# <code>ip dhcp snooping trust</code>	Configures the interface as a trusted interface for DHCP snooping. The <b>no</b> option configures the port as an untrusted interface.
Step 4	<code>show running-config dhcp</code>  <b>Example:</b> n1000v(config-if)# <code>show running-config dhcp</code>	Shows the DHCP snooping configuration.
Step 5	<code>copy running-config startup-config</code>  <b>Example:</b> n1000v(config-if)# <code>copy running-config startup-config</code>	(Optional) Saves the running configuration persistently through reboots and restarts by copying it to the startup configuration.

## Configuring the Rate Limit for DHCP Packets

Use this procedure to configure a limit for the rate of DHCP packets per second received on each port.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.
- Ports are put into an errdisabled state if they exceed the limit you set in this procedure for rate of DHCP packets per second.
- You can configure the rate limit on either the interface or port profile.

### SUMMARY STEPS

1. `config t`
2. `interface vethernet interface-number`

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

- ```
port-profile profilename
```
3. **[no] ip dhcp snooping limit rate *rate***
  4. **show running-config dhcp**
  5. **copy running-config startup-config**

## DETAILED STEPS

|        | Command                                                                                                                                                                                                                                                                            | Purpose                                                                                                                                                          |
|--------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <b>config t</b><br><br><b>Example:</b><br>n1000v# config t<br>n1000v(config)#                                                                                                                                                                                                      | Enters global configuration mode.                                                                                                                                |
| Step 2 | <b>interface vethernet <i>interface-number</i></b><br><br><b>Example:</b><br>n1000v(config)# interface vethernet 3<br>n1000v(config-if)#<br><br><b>port-profile <i>profilename</i></b><br><br><b>Example:</b><br>n1000v(config)# port-profile vm-data<br>n1000v(config-port-prof)# | Enters interface configuration mode, where <i>interface-number</i> is the vEthernet interface for which you want to configure the DHCP packets per second limit. |
| Step 3 | <b>[no] ip dhcp snooping limit rate <i>rate</i></b><br><br><b>Example:</b><br>n1000v(config-port-prof)# ip dhcp snooping<br>limit rate 30                                                                                                                                          | Configures the limit for the rate of DHCP packets per second (1 - 2048). The <b>no</b> option removes the rate limit.                                            |
| Step 4 | <b>show running-config dhcp</b><br><br><b>Example:</b><br>n1000v(config-if)# show running-config<br>dhcp                                                                                                                                                                           | Shows the DHCP snooping configuration.                                                                                                                           |
| Step 5 | <b>copy running-config startup-config</b><br><br><b>Example:</b><br>n1000v(config-if)# copy running-config<br>startup-config                                                                                                                                                       | (Optional) Saves the running configuration persistently through reboots and restarts by copying it to the startup configuration.                                 |

## Detecting Ports Disabled for DHCP Rate Limit Violation

Use this procedure to globally configure detection of ports disabled for exceeding the DHCP rate limit.

### BEFORE YOU BEGIN

Before beginning this procedures, you must know or do the following:

- You are logged in to the CLI in EXEC mode.
- A failure to conform to the set rate causes the port to be put into an errdisable state.
- You must enter the **shutdown** command and then the **no shutdown** command to recover an interface manually from the error-disabled state.

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

## SUMMARY STEPS

1. `config t`
2. `[no] errdisable detect cause dhcp-rate-limit`
3. `show running-config dhcp`
4. `copy running-config startup-config`

## DETAILED STEPS

|        | Command                                                                                                                                                  | Purpose                                                                                                                          |
|--------|----------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>config t</code><br><br><b>Example:</b><br><code>n1000v# config t</code><br><code>n1000v(config)#</code>                                            | Enters global configuration mode.                                                                                                |
| Step 2 | <code>[no] errdisable detect cause dhcp-rate-limit</code><br><br><b>Example:</b><br><code>n1000v(config)# errdisable detect cause dhcp-rate-limit</code> | Enables DHCP error-disabled detection. The <b>no</b> option disables DHCP error-disabled detection.                              |
| Step 3 | <code>show running-config dhcp</code><br><br><b>Example:</b><br><code>n1000v(config)# show running-config dhcp</code>                                    | Shows the DHCP snooping configuration.                                                                                           |
| Step 4 | <code>copy running-config startup-config</code><br><br><b>Example:</b><br><code>n1000v(config)# copy running-config startup-config</code>                | (Optional) Saves the running configuration persistently through reboots and restarts by copying it to the startup configuration. |

## Recovering Ports Disabled for DHCP Rate Limit Violations

Use this procedure to globally configure automatic recovery of ports disabled for violating the DHCP rate limit.

### BEFORE YOU BEGIN

Before beginning this procedures, you must know or do the following:

- You are logged in to the CLI in EXEC mode.
- Ports that rate causes the port to be put into an errdisable state.
- You must enter the **shutdown** command and then the **no shutdown** command to recover an interface manually from the error-disabled state.

## SUMMARY STEPS

1. `config t`
2. `[no] errdisable recovery cause dhcp-rate-limit`
3. `errdisable recovery interval timer-interval`

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

4. `show running-config dhcp`
5. `copy running-config startup-config`

## DETAILED STEPS

|        | Command                                                                                                                                                    | Purpose                                                                                                                          |
|--------|------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>config t</code><br><br><b>Example:</b><br><code>n1000v# config t</code><br><code>n1000v(config)#</code>                                              | Enters global configuration mode.                                                                                                |
| Step 2 | <code>[no] errdisable recovery cause dhcp-rate-limit</code><br><br><b>Example:</b><br><code>n1000v(config)# errdisable detect cause dhcp-rate-limit</code> | Enables DHCP error-disabled recovery. The <b>no</b> option disables DHCP error-recovery.                                         |
| Step 3 | <code>errdisable recovery interval timer-interval</code><br><br><b>Example:</b><br><code>n1000v(config)# errdisable recovery interval 30</code>            | Sets the DHCP error-disabled recovery interval, where <i>timer-interval</i> is the number of seconds (30-65535).                 |
| Step 4 | <code>show running-config dhcp</code><br><br><b>Example:</b><br><code>n1000v(config)# show running-config dhcp</code>                                      | Shows the DHCP snooping configuration.                                                                                           |
| Step 5 | <code>copy running-config startup-config</code><br><br><b>Example:</b><br><code>n1000v(config)# copy running-config startup-config</code>                  | (Optional) Saves the running configuration persistently through reboots and restarts by copying it to the startup configuration. |

## Clearing the DHCP Snooping Binding Database

This section includes the following procedures:

- [Clearing All Binding Entries, page 12-13](#)
- [Clearing Binding Entries for an Interface, page 12-14](#)

### Clearing All Binding Entries

Use this procedure to remove all entries from the DHCP snooping binding database.

#### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.

#### SUMMARY STEPS

1. `clear ip dhcp snooping binding`

**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**

## 2. show ip dhcp snooping binding

### DETAILED STEPS

|        | Command                                                                                                | Purpose                                                                   |
|--------|--------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------|
| Step 1 | <b>clear ip dhcp snooping binding</b><br><br><b>Example:</b><br>n1000v# clear ip dhcp snooping binding | Clears dynamically added entries from the DHCP snooping binding database. |
| Step 2 | <b>show ip dhcp snooping binding</b><br><br><b>Example:</b><br>n1000v# show ip dhcp snooping binding   | Displays the DHCP snooping binding database.                              |

## Clearing Binding Entries for an Interface

Use this procedure to remove binding entries for an interface from the DHCP snooping database.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.
- You have the following information for the interface:
  - VLAN ID
  - IP address
  - MAC address

### SUMMARY STEPS

1. **clear ip dhcp snooping binding** [{vlan *vlan-id* mac *mac-addr* ip *ip-addr* interface *interface-id*} | vlan *vlan-id1* | interface *interface-id1*]
2. **show ip dhcp snooping binding**

### DETAILED STEPS

|        | Command                                                                                                                                                                                                                                                                                                                           | Purpose                                                                                    |
|--------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------|
| Step 1 | <b>clear ip dhcp snooping binding</b> [{vlan <i>vlan-id</i> mac <i>mac-addr</i> ip <i>ip-addr</i> interface <i>interface-id</i> }   vlan <i>vlan-id1</i>   interface <i>interface-id1</i> ]<br><br><b>Example:</b><br>n1000v# clear ip dhcp snooping binding<br>vlan 10 mac EEEE.EEEE.EEEE ip 10.10.10.1<br>interface vethernet 1 | Clears dynamically added entries for an interface from the DHCP snooping binding database. |
| Step 2 | <b>show ip dhcp snooping binding</b><br><br><b>Example:</b><br>n1000v# show ip dhcp snooping binding                                                                                                                                                                                                                              | Displays the DHCP snooping binding database.                                               |



***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

## Relaying Switch and Circuit Information in DHCP

Use this procedure to globally configure relaying of the VSM MAC address and vEthernet port information in DHCP packets. This is also called Option 82 and Relay Agent Information Option.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.
- For more information, see the following:
  - “Relay Agent Information Option” section on page 12-3
  - *RFC-3046, DHCP Relay Agent Information Option*.

### SUMMARY STEPS

1. **config t**
2. **[no] ip dhcp snooping information option**
3. **show runing-config dhcp**
4. **copy running-config startup-config**

### DETAILED STEPS

|        | Command                                                                                                                                                                                                                                                                                                                                        | Purpose                                                                                                                                                    |
|--------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <b>config t</b><br><br><b>Example:</b><br>n1000v# config t<br>n1000v(config)#                                                                                                                                                                                                                                                                  | Enters global configuration mode.                                                                                                                          |
| Step 2 | <b>[no] ip dhcp snooping information option</b><br><br><b>Example:</b><br>n1000v(config)# ip dhcp snooping<br>information option<br>n1000v(config)#                                                                                                                                                                                            | Configures DHCP to relay the VSM MAC address and vEthernet port information in DHCP packets.<br><br>Use the <b>no</b> option to remove this configuration. |
| Step 3 | <b>show running-config dhcp</b><br><br><b>Example:</b><br>n1000v(config)# show running-config dhcp<br><br>!Command: show running-config dhcp<br>!Time: Fri Dec 17 11:30:22 2010<br><br>version 4.2(1)SV1(4)<br>ip dhcp snooping information option<br>service dhcp<br>ip dhcp relay<br>ip dhcp relay information option<br><br>n1000v(config)# | (Optional) Displays the DHCP snooping configuration for verification.                                                                                      |

**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**

|        | Command                                                                                                                                 | Purpose                                                                                                                          |
|--------|-----------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------|
| Step 4 | <pre>copy running-config startup-config</pre> <p><b>Example:</b><br/> <pre>n1000v(config)# copy running-config startup-config</pre></p> | (Optional) Saves the running configuration persistently through reboots and restarts by copying it to the startup configuration. |

## Verifying the DHCP Snooping Configuration

To verify the DHCP snooping configuration, use the following commands:

| Command                                    | Purpose                                                                      |
|--------------------------------------------|------------------------------------------------------------------------------|
| <code>show running-config dhcp</code>      | Displays the DHCP snooping configuration                                     |
| <code>show ip dhcp snooping</code>         | Displays general information about DHCP snooping.                            |
| <code>show ip dhcp snooping binding</code> | Display the contents of the DHCP snooping binding table.                     |
| <code>show feature</code>                  | Displays the features available, such as DHCP, and whether they are enabled. |

For detailed information about these commands, see the *Cisco Nexus 1000V Command Reference, Release 4.2(1)SV1(5.1)*.

## Monitoring DHCP Snooping

Use the `show ip dhcp snooping statistics` command to monitor DHCP snooping statistics. For detailed information about this command, see the *Cisco Nexus 1000V Command Reference, Release 4.2(1)SV1(5.1)*.

## Example Configuration for DHCP Snooping

This example shows how to enable DHCP snooping on two VLANs, with vEthernet interface 5 trusted because the DHCP server is connected to that interface:

```
feature dhcp

interface vethernet 5
ip dhcp snooping trust
ip dhcp snooping vlan 1, 50
```

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

## Additional References

For additional information related to implementing DHCP snooping, see the following sections:

- [Related Documents, page 12-17](#)
- [Standards, page 12-17](#)

## Related Documents

| Related Topic                                                                                                             | Document Title                                                                                                                  |
|---------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------|
| IP Source Guard                                                                                                           | <i>Cisco Nexus 1000V Security Configuration Guide, Release 4.2(1)SV1(5.1), Chapter 14, “Configuring IP Source Guard”</i>        |
| Dynamic ARP Inspection                                                                                                    | <i>Cisco Nexus 1000V Security Configuration Guide, Release 4.2(1)SV1(5.1), Chapter 13, “Configuring Dynamic ARP Inspection”</i> |
| DHCP snooping commands: complete command syntax, command modes, command history, defaults, usage guidelines, and examples | <i>Cisco Nexus 1000V Command Reference, Release 4.2(1)SV1(5.1)</i>                                                              |

## Standards

| Standards | Title                                                                                                                                 |
|-----------|---------------------------------------------------------------------------------------------------------------------------------------|
| RFC-2131  | <i>Dynamic Host Configuration Protocol</i><br>( <a href="http://tools.ietf.org/html/rfc2131">http://tools.ietf.org/html/rfc2131</a> ) |
| RFC-3046  | <i>DHCP Relay Agent Information Option</i><br>( <a href="http://tools.ietf.org/html/rfc3046">http://tools.ietf.org/html/rfc3046</a> ) |

## Feature History for DHCP Snooping

[Table 12-2](#) lists the release history for this feature.

**Table 12-2** Feature History for DHCP Snooping

| Feature Name                | Releases     | Feature Information                                                         |
|-----------------------------|--------------|-----------------------------------------------------------------------------|
| Relay Agent (Option 82)     | 4.2(1)SV1(4) | You can configure relaying of VSM MAC and port information in DHCP packets. |
| <b>feature dhcp</b> command | 4.2(1)SV1(4) | Command added for enabling DHCP feature globally.                           |
| DHCP snooping               | 4.0(4)SV1(2) | This feature was introduced.                                                |

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***



## CHAPTER 13

# Configuring Dynamic ARP Inspection

---

This chapter describes how to configure dynamic Address Resolution Protocol (ARP) inspection (DAI).

This chapter includes the following sections:

- [Information About DAI, page 13-1](#)
- [Prerequisites for DAI, page 13-4](#)
- [Guidelines and Limitations, page 13-4](#)
- [Default Settings, page 13-5](#)
- [Configuring DAI, page 13-5](#)
- [Verifying the DAI Configuration, page 13-14](#)
- [Monitoring DAI, page 13-15](#)
- [Example DAI Configuration, page 13-15](#)
- [Additional References, page 13-17](#)
- [Feature History for DAI, page 13-18](#)

## Information About DAI

This section includes the following topics:

- [About ARP, page 13-1](#)
- [About ARP Spoofing Attacks, page 13-2](#)
- [About DAI and ARP Spoofing, page 13-2](#)
- [Interface Trust and Network Security, page 13-3](#)

## About ARP

ARP provides IP communication within a Layer 2 broadcast domain by mapping an IP address to a MAC address. For example, host B wants to send information to host A but does not have the MAC address of host A in its ARP cache. In ARP terms, host B is the sender and host A is the target.

To get the MAC address of host A, host B generates a broadcast message for all hosts within the broadcast domain to obtain the MAC address associated with the IP address of host A. All hosts within the broadcast domain receive the ARP request, and host A responds with its MAC address.


[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

## About ARP Spoofing Attacks

In an ARP spoofing attack, a host allows an unsolicited ARP response to update its cache so that traffic is directed through the attacker until it is discovered and the information in the ARP cache is corrected.

An ARP spoofing attack can affect hosts, switches, and routers connected to your Layer 2 network by sending false information to their ARP caches. [Figure 13-1](#) shows an example of ARP cache poisoning.

**Figure 13-1** ARP Cache Poisoning



In [Figure 13-1](#), hosts A, B, and C are connected to the device on interfaces A, B, and C, all of which are on the same subnet. Their IP and MAC addresses are shown in parentheses. For example, host A uses IP address IA and MAC address MA.

When host A needs to send IP data to host B, it broadcasts an ARP request for the MAC address associated with IP address IB. When the device and host B receive the ARP request, they add a binding to their ARP caches for a host with the IP address IA and a MAC address MA.

When host B responds, the device and host A update their ARP caches with a binding for a host with the IP address IB and the MAC address MB.

Host C can spoof host A and B by broadcasting the following forged ARP responses:

- one for a host with an IP address of IA and a MAC address of MC
- one for a host with the IP address of IB and a MAC address of MC.

Host B then uses MC as the destination MAC address for traffic that was intended for IA, which means that host C intercepts that traffic. Likewise, host A and the device use MC as the destination MAC address for traffic intended for IB.

Because host C knows the authentic MAC addresses for IA and IB, it can forward the intercepted traffic.

## About DAI and ARP Spoofing

DAI is used to validate ARP requests and responses as follows:

- Intercepts all ARP requests and responses on untrusted ports.
- Verifies that a packet has a valid IP-to-MAC address binding before updating the ARP cache or forwarding the packet.
- Drops invalid ARP packets.

DAI can determine the validity of an ARP packet based on valid IP-to-MAC address bindings stored in a Dynamic Host Configuration Protocol (DHCP) snooping binding database. This database is built by DHCP snooping when it is enabled on the VLANs and on the device. It may also contain static entries that you have created.

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

If an ARP packet is received on a trusted interface, the device forwards the packet without any checks. On untrusted interfaces, the device forwards the packet only if it is valid. For more information about trusted interfaces, see the [Interface Trust and Network Security](#), page 13-3.

You can enable or disable validation of ARP packets for destination MAC address, source MAC address, and IP address. For more information, see the [“Validating ARP Packets”](#) section on page 13-13.

## Interface Trust and Network Security

DAI identifies interfaces as trusted or untrusted.

In a typical network, interfaces are configured as follows:

- Untrusted—Interfaces that are connected to hosts  
Packets are validated by DAI.
- Trusted—Interfaces that are connected to devices  
Packets bypass all DAI validation checks.

With this configuration, all ARP packets that enter the network from a device bypass the security check. No other validation is needed at any other place in the VLAN or in the network. For information about configuring a trusted interface, see the [“Configuring a Trusted vEthernet Interface”](#) section on page 13-6.




### Caution

Use the trust state configuration carefully. Configuring interfaces as untrusted when they should be trusted can result in a loss of connectivity.

In [Figure 13-2](#), assume that both device A and device B are running DAI on the VLAN that includes host 1 and host 2. If host 1 and host 2 acquire their IP addresses from the DHCP server connected to device A, only device A binds the IP-to-MAC address of host 1. If the interface between device A and device B is untrusted, the ARP packets from host 1 are dropped by device B and connectivity between host 1 and host 2 is lost.

**Figure 13-2 ARP Packet Validation on a VLAN Enabled for DAI**



***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

If you configure interfaces as trusted when they should be untrusted, you may open a security hole in a network. If device A is not running DAI, host 1 can easily poison the ARP cache of device B (and host 2, if you configured the link between the devices as trusted). This condition can occur even though device B is running DAI.

DAI ensures that hosts (on untrusted interfaces) connected to a device that runs DAI do not poison the ARP caches of other hosts in the network; however, DAI does not prevent hosts in other portions of the network from poisoning the caches of the hosts that are connected to a device that runs DAI.

**Note**

Depending on your network setup, you may not be able to validate a given ARP packet on all devices in the VLAN.

## Prerequisites for DAI

The following are prerequisite to configuring DAI.

- You are familiar with the following:

- ARP

For more information, see IETF Standard RFC-826, *An Ethernet Address Resolution Protocol* (<http://tools.ietf.org/html/rfc826>).

- DHCP Snooping

For more information, see [Configuring DHCP Snooping, page 12-1](#).

- The software running on your Cisco Nexus 1000V supports DAI.
- The VEM feature level is updated to a release that supports DAI.

For more information about setting the VEM feature level, see the *Cisco Nexus 1000V Software Upgrade Guide, Release 4.2(1)SV1(5.1)*.

## Guidelines and Limitations

DAI has the following configuration guidelines and limitations:

- DAI is an ingress security feature and does not perform any egress checking.
- DAI is not effective when the host is connected to a device that does not support DAI or that does not have DAI enabled. To prevent attacks that are limited to a single Layer 2 broadcast domain, you should separate a domain with DAI from those without DAI. This separation secures the ARP caches of hosts in the domain with DAI.
- DAI verifies IP-to-MAC address bindings in incoming ARP requests and ARP responses. If you have not configured static entries, then DHCP snooping must be enabled on the same VLANs on which you configure DAI. For more information, see the [“Configuring DHCP Snooping” section on page 12-4](#).



***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

- DAI is supported on vEthernet interfaces and private VLAN ports.
- If you want DAI to use dynamic IP-MAC address bindings to determine if ARP packets are valid, ensure that DHCP snooping is configured. For more information, see the “[Configuring DHCP Snooping](#)” section on page 12-4).
- Virtual Service Domain (VSD) service VM ports are trusted ports by default. Even if you configure VSD ports as untrusted, they still appear as trusted ports to DAI.

## Default Settings

Table 13-1 lists the DAI defaults.

**Table 13-1**      **Default DAI Settings**

| Parameters                                              | Default                                                  |
|---------------------------------------------------------|----------------------------------------------------------|
| VLAN                                                    | VLANs are not configured for DAI.                        |
| Trust state of vEthernet interfaces not in a VSD        | Untrusted                                                |
| Trust state of vEthernet Interfaces in a VSD            | Trusted                                                  |
| Trust state of Ethernet port channels                   | Trusted                                                  |
| Incoming ARP packet rate limit for untrusted interfaces | 15 packets per second (pps)                              |
| Incoming ARP packet rate limit for trusted interfaces   | Unlimited                                                |
| Rate limit burst interval                               | 1 second                                                 |
| Detecting and Recovering DAI error-disabled interfaces  | Error-disabled detection and recovery is not configured. |
| Validation checks                                       | No checks are performed.                                 |
| VLAN statistics                                         | ARP request and response statistics.                     |

## Configuring DAI

This section includes the following topics:

- [Configuring a VLAN for DAI, page 13-6](#)
- [Configuring a Trusted vEthernet Interface, page 13-6](#)
- [Resetting a vEthernet Interface to Untrusted, page 13-8](#)
- [Configuring DAI Rate Limits, page 13-9](#)
- [Resetting DAI Rate Limits to Default Values, page 13-11](#)
- [Detecting and Recovering Error-Disabled Interfaces, page 13-12](#)
- [Validating ARP Packets, page 13-13](#)

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

## Configuring a VLAN for DAI

Use this procedure to configure a VLAN or a list of VLANs for DAI.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.
- By default, VLANs are not configured for DAI.
- You have already enabled DHCP snooping. For more information, see the [“Enabling or Disabling the DHCP Feature”](#) section on page 12-5.
- You know which VLANs you want to configure for DAI and they have already been created.

### SUMMARY STEPS

1. **config t**
2. **[no] ip arp inspection vlan list**
3. **show ip arp inspection vlan list**
4. **copy running-config startup-config**

### DETAILED STEPS

|        | Command                                                                                                                      | Purpose                                                                                                                          |
|--------|------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <b>config t</b><br><br><b>Example:</b><br>switch# config t<br>switch(config)#                                                | Places you into the CLI Global Configuration mode.                                                                               |
| Step 2 | <b>ip arp inspection vlan list</b><br><br><b>Example:</b><br>switch(config)# ip arp inspection vlan 13                       | Configures the specified VLAN or list of VLANs for DAI.                                                                          |
| Step 3 | <b>show ip arp inspection vlan list</b><br><br><b>Example:</b><br>switch(config)# show ip arp inspection<br>vlan 13          | (Optional) Shows the DAI status for the specified list of VLANs.                                                                 |
| Step 4 | <b>copy running-config startup-config</b><br><br><b>Example:</b><br>switch(config-if)# copy running-config<br>startup-config | (Optional) Saves the running configuration persistently through reboots and restarts by copying it to the startup configuration. |

## Configuring a Trusted vEthernet Interface

Use this procedure to configure a trusted vEthernet interface.

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

## BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.
- By default, vEthernet interfaces are untrusted, unless they are part of a VSD.
- If an interface is untrusted, all ARP requests and responses are verified for a valid IP-MAC address binding before the local cache is updated and the packet forwarded. If a packet has an invalid IP-MAC address binding, it is dropped.
- ARP packets received on a trusted interface are forwarded but not checked.
- You can configure a trusted interface on either of the following:
  - the interface, itself
  - the existing port profile that the interface is assigned to

If configuring a trusted interface on the port profile, it has already been created and you know its name.

## SUMMARY STEPS

1. **config t**
2. **interface vethernet *interface-number***  
**port-profile *profilename***
3. **[no] ip arp inspection trust**
4. **show ip arp inspection interface *type slotnumber***  
**show port-profile *profilename***
5. **copy running-config startup-config**

## DETAILED STEPS

|        | Command                                                                                                                                  | Purpose                                                                                      |
|--------|------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------|
| Step 1 | <b>config t</b><br><br><b>Example:</b><br>switch# config t<br>switch(config)#                                                            | Places you into the CLI Global Configuration mode.                                           |
| Step 2 | <b>interface vethernet <i>interface-number</i></b><br><br><b>Example:</b><br>switch(config)# interface vethernet 3<br>switch(config-if)# | Places you into the CLI Interface Configuration mode, for the specified vEthernet interface. |
|        | <b>port-profile <i>profilename</i></b><br><br><b>Example:</b><br>switch(config)# port-profile vm-data<br>switch(config-port-prof)#       | Places you into the CLI Port Profile Configuration mode for the specified port profile.      |
| Step 3 | <b>ip arp inspection trust</b><br><br><b>Example:</b><br>switch(config-if)# ip arp inspection trust                                      | Configures the interface as a trusted ARP interface.                                         |

**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**

|               | Command                                                                                                                                                             | Purpose                                                                                                                          |
|---------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------|
|               | <b>ip arp inspection trust</b><br><br><b>Example:</b><br>switch(config-port-prof)# ip arp inspection trust                                                          | Configures the interfaces assigned to the port profile as trusted ARP interfaces.                                                |
| <b>Step 4</b> | <b>show ip arp inspection interface vethernet <i>interface-number</i></b><br><br><b>Example:</b><br>switch(config-if)# show ip arp inspection interface vethernet 2 | (Optional) Displays the trusted state and the ARP packet rate for the specified interface.                                       |
|               | <b>show port-profile <i>profilename</i></b><br><br><b>Example:</b><br>switch(config)# show port-profile vm-data                                                     | (Optional) Displays the port profile configuration including the ARP trusted state.                                              |
| <b>Step 5</b> | <b>copy running-config startup-config</b><br><br><b>Example:</b><br>switch(config-if)# copy running-config startup-config                                           | (Optional) Saves the running configuration persistently through reboots and restarts by copying it to the startup configuration. |

## Resetting a vEthernet Interface to Untrusted

Use this procedure to remove a trusted designation from a vEthernet interface, returning it to the default untrusted designation.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.
- By default, vEthernet interfaces are untrusted, unless they are part of a VSD.
- If an interface is untrusted, all ARP requests and responses are verified for a valid IP-MAC address binding before the local cache is updated and the packet forwarded. If a packet has an invalid IP-MAC address binding, it is dropped.

### SUMMARY STEPS

1. **config t**
2. **interface vethernet *interface-number***
3. **default ip arp inspection trust**
4. **show ip arp inspection interface *type slotnumber***
5. **copy running-config startup-config**

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

## DETAILED STEPS

|        | Command                                                                                                                                                             | Purpose                                                                                                                          |
|--------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <b>config t</b><br><br><b>Example:</b><br>switch# config t<br>switch(config)#                                                                                       | Places you into the CLI Global Configuration mode.                                                                               |
| Step 2 | <b>interface vethernet <i>interface-number</i></b><br><br><b>Example:</b><br>switch(config)# interface vethernet 3<br>switch(config-if)#                            | Places you into the CLI Interface Configuration mode, for the specified vEthernet interface.                                     |
| Step 3 | <b>default ip arp inspection trust</b><br><br><b>Example:</b><br>switch(config-if)# default ip arp inspection trust                                                 | Removes the trusted designation from the interface and returns it to the default untrusted state.                                |
| Step 4 | <b>show ip arp inspection interface vethernet <i>interface-number</i></b><br><br><b>Example:</b><br>switch(config-if)# show ip arp inspection interface vethernet 3 | (Optional) Displays the trusted state and the ARP packet rate for the specified interface.                                       |
| Step 5 | <b>copy running-config startup-config</b><br><br><b>Example:</b><br>switch(config-if)# copy running-config startup-config                                           | (Optional) Saves the running configuration persistently through reboots and restarts by copying it to the startup configuration. |

## Configuring DAI Rate Limits

Use this procedure to set the rate limit of ARP requests and responses.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.
- Because of their aggregation, trunk ports should be configured with higher rate limit.
- Once the rate of incoming packets exceeds the configured rate, the interface is automatically put into an errdisable state.
- The default DAI rate limits are as follows:
  - Untrusted interfaces = 15 packets per second
  - Trusted interfaces = unlimited
  - Burst interval = 1 second
- You can configure the rate limits for an interface on either of the following:
  - the interface, itself
  - the existing port profile that the interface is assigned to

If configuring the port profile, it has already been created and you know its name.

**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**

## SUMMARY STEPS

1. **config t**
2. **interface vethernet *interface-number***  
**port-profile *profilename***
3. **ip arp inspection limit {rate *pps* [burst interval *bint*] | none}**
4. **show running-config dhcp**
5. **copy running-config startup-config**

## DETAILED STEPS

|        | Command                                                                                                                                                                                                                                                 | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
|--------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <b>config t</b><br><br><b>Example:</b><br>switch# config t<br>switch(config)#                                                                                                                                                                           | Places you into the CLI Global Configuration mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| Step 2 | <b>interface vethernet <i>interface-number</i></b><br><br><b>Example:</b><br>switch(config)# interface vethernet 3<br>switch(config-if)#                                                                                                                | Places you into the CLI Interface Configuration mode, for the specified vEthernet interface.                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
|        | <b>port-profile <i>profilename</i></b><br><br><b>Example:</b><br>switch(config)# port-profile vm-data<br>switch(config-port-prof)#                                                                                                                      | Places you into the CLI Port Profile configuration mode for the specified port profile.                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| Step 3 | <b>ip arp inspection limit {rate <i>pps</i> [burst interval <i>bint</i>]   none}</b><br><br><b>Example:</b><br>switch(config-if)# ip arp inspection limit<br>rate 30<br><b>Example:</b><br>switch(config-port-prof)# ip arp<br>inspection limit rate 30 | Configures the specified ARP inspection limit on the interface or the port profile as follows: <ul style="list-style-type: none"> <li>• <b>rate:</b> allowable values are between 1 and 2048 packets per second (pps) <ul style="list-style-type: none"> <li>– Untrusted interface default = 15 packets per second</li> <li>– Trusted interface default = unlimited</li> </ul> </li> <li>• <b>burst interval:</b> allowable values are between 1 and 15 seconds (default = 1 second).</li> <li>• <b>none:</b> unlimited number of packets per second</li> </ul> |
| Step 4 | <b>show running-config dhcp</b><br><br><b>Example:</b><br>switch(config)# show running-config dhcp                                                                                                                                                      | (Optional) Displays the DHCP snooping configuration, including the DAI configuration.                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| Step 5 | <b>copy running-config startup-config</b><br><br><b>Example:</b><br>switch(config)# copy running-config<br>startup-config                                                                                                                               | (Optional) Saves the running configuration persistently through reboots and restarts by copying it to the startup configuration.                                                                                                                                                                                                                                                                                                                                                                                                                                |

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

## Resetting DAI Rate Limits to Default Values

Use this procedure to set the rate limit of ARP requests and responses to the defaults, removing any configured values.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.
- The default DAI rate limits are as follows:
  - Untrusted interfaces = 15 packets per second
  - Trusted interfaces = unlimited
  - Burst interval = 1 second
- You can configure the rate limits for an interface on either of the following:
  - the interface, itself
  - the existing port profile that the interface is assigned to

If configuring the port profile, it has already been created and you know its name.

### SUMMARY STEPS

1. **config t**
2. **interface vethernet *interface-number***
3. **default ip arp inspection limit {rate *pps* [*burst interval bint*] | none }**
4. **show running-config dhcp**
5. **copy running-config startup-config**

### DETAILED STEPS

|        | Command                                                                                                                                  | Purpose                                                                                      |
|--------|------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------|
| Step 1 | <b>config t</b><br><br><b>Example:</b><br>switch# config t<br>switch(config)#                                                            | Places you into the CLI Global Configuration mode.                                           |
| Step 2 | <b>interface vethernet <i>interface-number</i></b><br><br><b>Example:</b><br>switch(config)# interface vethernet 3<br>switch(config-if)# | Places you into the CLI Interface Configuration mode, for the specified vEthernet interface. |

**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**

|        | Command                                                                                                                                                                                    | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                          |
|--------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 3 | <b>default ip arp inspection limit { rate <i>pps</i> [burst interval <i>bint</i>]   none}</b><br><br><b>Example:</b><br><pre>switch(config-if)# default ip arp inspection limit rate</pre> | Removes the configured DAI rate limits from the interface and returns them to the default values. <ul style="list-style-type: none"> <li>• <b>rate:</b> <ul style="list-style-type: none"> <li>– Untrusted interface default = 15 packets per second</li> <li>– Trusted interface default = unlimited</li> </ul> </li> <li>• <b>burst interval:</b> default = 1 second</li> <li>• <b>none:</b> unlimited number of packets per second</li> </ul> |
| Step 4 | <b>show running-config dhcp</b><br><br><b>Example:</b><br><pre>switch(config)# show running-config dhcp</pre>                                                                              | (Optional) Displays the DHCP snooping configuration, including the DAI rate limits.                                                                                                                                                                                                                                                                                                                                                              |
| Step 5 | <b>copy running-config startup-config</b><br><br><b>Example:</b><br><pre>switch(config)# copy running-config startup-config</pre>                                                          | (Optional) Saves the running configuration persistently through reboots and restarts by copying it to the startup configuration.                                                                                                                                                                                                                                                                                                                 |

## Detecting and Recovering Error-Disabled Interfaces

Use this procedure to configure the detection and recovery of error-disabled interfaces.

### BEFORE YOU BEGIN

Before beginning this procedures, you must know or do the following:

- You are logged in to the CLI in EXEC mode.
- By default, interfaces are not configured for DAI error-disabled recovery.
- To manually recover an interface from the error-disabled state, use the following command sequence.
  1. **shutdown**
  2. **no shutdown**

### SUMMARY STEPS

1. **config t**
2. **[no] errdisable detect cause arp-inspection**
3. **[no] errdisable recovery cause arp-inspection**
4. **errdisable recovery interval *timer-interval***
5. **show running-config | include errdisable**
6. **copy running-config startup-config**



***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

## DETAILED STEPS

|        | Command                                                                                                                            | Purpose                                                                                                                                                                           |
|--------|------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <b>config t</b><br><br><b>Example:</b><br>switch# config t<br>switch(config)#                                                      | Places you into the CLI Global Configuration mode.                                                                                                                                |
| Step 2 | <b>errdisable detect cause arp-inspection</b><br><br><b>Example:</b><br>switch(config)# errdisable detect cause arp-inspection     | Configures the detection of interfaces that have been error-disabled by ARP inspection.<br><br>The <b>no</b> option disables the detection.                                       |
| Step 3 | <b>errdisable recovery cause arp-inspection</b><br><br><b>Example:</b><br>switch(config)# errdisable recovery cause arp-inspection | Configures the recovery of interfaces that have been error-disabled by ARP inspection.                                                                                            |
| Step 4 | <b>errdisable recovery interval timer-interval</b><br><br><b>Example:</b><br>switch(config)# errdisable recovery interval 30       | Configures the recovery interval for interfaces that have been error-disabled by ARP inspection.<br><br><b>timer-interval:</b> allowable values are between 30 and 65535 seconds. |
| Step 5 | <b>show running-config   include errdisable</b><br><br><b>Example:</b><br>switch(config)# show running-config   include errdisable | (Optional) Displays the errdisable configuration.                                                                                                                                 |
| Step 6 | <b>copy running-config startup-config</b><br><br><b>Example:</b><br>switch(config-if)# copy running-config startup-config          | (Optional) Saves the running configuration persistently through reboots and restarts by copying it to the startup configuration.                                                  |

## Validating ARP Packets

Use this procedure to configure the validation of ARP packets.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.
- You can enable validation of the following, which are disabled by default:

- Destination MAC address

Checks the destination MAC address in the Ethernet header against the target MAC address in the ARP body, and drops packets with an invalid MAC address.

- IP address

Checks the ARP body for invalid and unexpected IP addresses, including 0.0.0.0, 255.255.255.255, and any IP multicast address. Sender IP addresses are checked in both ARP requests and responses. Target IP addresses are checked only in ARP responses.

- Source MAC address

**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**

Checks the source MAC address in the Ethernet header against the sender MAC address in the ARP body for ARP requests and responses, and drops packets with invalid MAC addresses.

- Whenever you configure a validation, any previous validation configuration is overwritten.

## SUMMARY STEPS

1. **config t**
2. **[no] ip arp inspection validate {[src-mac] [dst-mac] [ip]}**
3. **show running-config dhcp**
4. **copy running-config startup-config**

## DETAILED STEPS

|        | Command                                                                                                                                              | Purpose                                                                                                                                                                                                                                                                                                                                               |
|--------|------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <b>config t</b><br><br><b>Example:</b><br>switch# config t<br>switch(config)#                                                                        | Places you into the CLI Global Configuration mode.                                                                                                                                                                                                                                                                                                    |
| Step 2 | <b>ip arp inspection validate {[src-mac] [dst-mac] [ip]}</b><br><br><b>Example:</b><br>switch(config)# ip arp inspection validate src-mac dst-mac ip | Enables the specified validation and overwrites any existing validation that was previously saved: <ul style="list-style-type: none"> <li>• Source MAC</li> <li>• Destination MAC</li> <li>• IP</li> </ul> <p>You can specify all three of these validations but you must specify at least one.</p> <p>Use the no option to disable a validation.</p> |
| Step 3 | <b>show running-config dhcp</b><br><br><b>Example:</b><br>switch(config)# show running-config dhcp                                                   | (Optional) Displays the DHCP snooping configuration, including the DAI configuration.                                                                                                                                                                                                                                                                 |
| Step 4 | <b>copy running-config startup-config</b><br><br><b>Example:</b><br>switch(config)# copy running-config startup-config                               | (Optional) Saves the running configuration persistently through reboots and restarts by copying it to the startup configuration.                                                                                                                                                                                                                      |

## Verifying the DAI Configuration

To display and verify the DAI configuration, use the following commands:

| Command                         | Purpose                         |
|---------------------------------|---------------------------------|
| <b>show running-config dhcp</b> | Displays the DAI configuration. |
| <b>show ip arp inspection</b>   | Displays the status of DAI.     |

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

| Command                                                                      | Purpose                                                                |
|------------------------------------------------------------------------------|------------------------------------------------------------------------|
| <b>show ip arp inspection interface vethernet</b><br><i>interface-number</i> | Displays the trust state and ARP packet rate for a specific interface. |
| <b>show ip arp inspection vlan</b> <i>vlan-ID</i>                            | Displays the DAI configuration for a specific VLAN.                    |

For detailed information about command output, see the *Cisco Nexus 1000V Command Reference, Release 4.2(1)SV1(5.1)*.

## Monitoring DAI

To monitor DAI, use the following commands:

| Command                                       | Purpose                                       |
|-----------------------------------------------|-----------------------------------------------|
| <b>show ip arp inspection statistics</b>      | Displays DAI statistics.                      |
| <b>show ip arp inspection statistics vlan</b> | Displays DAI statistics for a specified VLAN. |
| <b>clear ip arp inspection statistics</b>     | Clears DAI statistics.                        |

For detailed information about command output, see the *Cisco Nexus 1000V Command Reference, Release 4.2(1)SV1(5.1)*.

## Example DAI Configuration

This example shows how to configure DAI in a network with two VEMs:

- One VEM is hosting an authentic web server and a DHCP server.
- The other VEM is hosting a client virtual machine (VM 1) and a virtual machine (VM 2) with a rogue web server. VM 1 is connected to vEthernet interface 3, which is untrusted by default, and belongs to VLAN 1. VM 2 is connected to vEthernet 10 and VLAN 1.

Without DAI enabled, VM 2 can spoof the ARP cache in VM 1 by sending a packet even though an ARP request was not generated. In this case, the packet directs VM 1 to send its traffic to the VM 2 web server instead of the authentic web server.

If DAI is enabled when VM2 attempts to spoof the ARP cache in VM1, the unsolicited ARP packet sent by VM 2 is dropped because DAI detects the invalid IP-to-MAC address binding. The attempt to spoof the ARP cache fails, and VM 1 connects to the authentic web server.



### Note

DAI depends on the DHCP snooping database to verify IP-to-MAC address bindings in incoming ARP requests and ARP responses. Make sure to enable DHCP snooping to permit ARP packets that have dynamically-assigned IP addresses. For configuration information, see [Chapter 12, “Configuring DHCP Snooping.”](#)

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

The following steps are used to configure DAI for this example:

**Step 1** Enable DAI on VLAN 1 and verify the configuration.

```
n1000v# config t
n1000v(config)# ip arp inspection vlan 1
n1000v(config)# show ip arp inspection vlan 1

Source Mac Validation      : Disabled
Destination Mac Validation : Disabled
IP Address Validation      : Disabled

Vlan : 1
-----
Configuration      : Enabled
Operation State     : Active
n1000v(config)#
```

**Step 2** Check the statistics before and after DAI processes any packets.

```
n1000v# show ip arp inspection statistics vlan 1

Vlan : 1
-----
ARP Req Forwarded = 0
ARP Res Forwarded = 0
ARP Req Dropped   = 0
ARP Res Dropped   = 0
DHCP Drops        = 0
DHCP Permits      = 0
SMAC Fails-ARP Req = 0
SMAC Fails-ARP Res = 0
DMAC Fails-ARP Res = 0
IP Fails-ARP Req   = 0
IP Fails-ARP Res   = 0
n1000v#
```

If VM 1 sends out two ARP requests with an IP address of 10.0.0.1 and a MAC address of 0002.0002.0002, both requests are permitted, as shown in the following command output:

```
n1000v# show ip arp inspection statistics vlan 1

Vlan : 1
-----
ARP Req Forwarded = 2
ARP Res Forwarded = 0
ARP Req Dropped   = 0
ARP Res Dropped   = 0
DHCP Drops        = 0
DHCP Permits      = 2
SMAC Fails-ARP Req = 0
SMAC Fails-ARP Res = 0
DMAC Fails-ARP Res = 0
IP Fails-ARP Req   = 0
IP Fails-ARP Res   = 0
```

If VM 2 tries to send an ARP request with an IP address of 10.0.0.3, the packet is dropped and an error message is logged.

```
00:12:08: %SW_DAI-4-DHCP_SNOOPING_DENY: 2 Invalid ARPs (Req) on vEthernet3, vlan
1. ([0002.0002.0002/10.0.0.3/0000.0000.0000/0.0.0.0/02:42:35 UTC Fri Jul 13 2008])
```

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

The statistics display as follows:

```
n1000v# show ip arp inspection statistics vlan 1
n1000v#

Vlan : 1
-----
ARP Req Forwarded = 2
ARP Res Forwarded = 0
ARP Req Dropped   = 2
ARP Res Dropped   = 0
DHCP Drops        = 2
DHCP Permits      = 2
SMAC Fails-ARP Req = 0
SMAC Fails-ARP Res = 0
DMAC Fails-ARP Res = 0
IP Fails-ARP Req   = 0
IP Fails-ARP Res   = 0
n1000v#
```

## Additional References

For additional information related to implementing DAI, see the following sections:

- [Related Documents, page 13-17](#)
- [Standards, page 13-17](#)

## Related Documents

| Related Topic                                                                                                            | Document Title                                                     |
|--------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------|
| DHCP snooping                                                                                                            | <a href="#">Configuring DHCP Snooping, page 12-1</a>               |
| DAI and DHCP commands: complete command syntax, command modes, command history, defaults, usage guidelines, and examples | <i>Cisco Nexus 1000V Command Reference, Release 4.2(1)SV1(5.1)</i> |

## Standards

| Standards | Title                                                                                                                                   |
|-----------|-----------------------------------------------------------------------------------------------------------------------------------------|
| RFC-826   | <i>An Ethernet Address Resolution Protocol</i><br>( <a href="http://tools.ietf.org/html/rfc826">http://tools.ietf.org/html/rfc826</a> ) |

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

## Feature History for DAI

Table 13-2 lists the release history for the DAI feature.

**Table 13-2**      *Feature History for DAI*

| Feature Name | Releases     | Feature Information          |
|--------------|--------------|------------------------------|
| DAI          | 4.0(4)SV1(2) | This feature was introduced. |



## CHAPTER 14

# Configuring IP Source Guard

---

This chapter describes how to configure IP Source Guard on Cisco Nexus 1000Vs.

This chapter includes the following sections:

- [Information About IP Source Guard, page 14-1](#)
- [Prerequisites for IP Source Guard, page 14-2](#)
- [Guidelines and Limitations, page 14-2](#)
- [Default Settings, page 14-2](#)
- [Configuring IP Source Guard, page 14-2](#)
- [Verifying the IP Source Guard Configuration, page 14-5](#)
- [Displaying IP Source Guard Bindings, page 14-5](#)
- [Example Configuration for IP Source Guard, page 14-5](#)
- [Additional References, page 14-5](#)
- [Feature History for IP Source Guard, page 14-6](#)

## Information About IP Source Guard

IP Source Guard is a per-interface traffic filter that permits IP traffic only when the IP address and MAC address of each packet matches the IP and MAC address bindings of dynamic or static IP source entries in the Dynamic Host Configuration Protocol (DHCP) snooping binding table.

You can enable IP Source Guard on Layer 2 interfaces that are not trusted by DHCP snooping. IP Source Guard supports interfaces that are configured to operate in access mode and trunk mode. When you initially enable IP Source Guard, all inbound IP traffic on the interface is blocked except for the following:

- DHCP packets, which DHCP snooping inspects and then forwards or drops, depending upon the results of inspecting the packet.
- IP traffic from static IP source entries that you have configured in the Cisco Nexus 1000V.

The device permits the IP traffic when DHCP snooping adds a binding table entry for the IP address and MAC address of an IP packet or when you have configured a static IP source entry.

The device drops IP packets when the IP address and MAC address of the packet do not have a binding table entry or a static IP source entry. For example, assume that the **show ip dhcp snooping binding** command displays the following binding table entry:

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

| MacAddress        | IpAddress | LeaseSec | Type          | VLAN | Interface  |
|-------------------|-----------|----------|---------------|------|------------|
| 00:02:B3:3F:3B:99 | 10.5.5.2  | 6943     | dhcp-snooping | 10   | vEthernet3 |

If the device receives an IP packet with an IP address of 10.5.5.2, IP Source Guard forward the packet only if the MAC address of the packet is 00:02:B3:3F:3B:99.

## Prerequisites for IP Source Guard

IP Source Guard has the following prerequisites:

- You should be familiar with DHCP snooping before you configure IP Source Guard.
- DHCP snooping is enabled (see the “[Configuring DHCP Snooping](#)” section on page 12-4).

## Guidelines and Limitations

IP Source Guard has the following configuration guidelines and limitations:

- IP Source Guard limits IP traffic on an interface to only those sources that have an IP-MAC address binding table entry or static IP source entry. When you first enable IP Source Guard on an interface, you may experience disruption in IP traffic until the hosts on the interface receive a new IP address from a DHCP server.
- IP Source Guard is dependent upon DHCP snooping to build and maintain the IP-MAC address binding table or upon manual maintenance of static IP source entries. For more information on DHCP snooping, see [Chapter 12, “Configuring DHCP Snooping.”](#)
- For seamless IP Source Guard, Virtual Service Domain (VSD) service VM ports are trusted ports by default. If you configure these ports as untrusted, this setting is ignored.

## Default Settings

[Table 14-1](#) lists IP Source Guard defaults.

**Table 14-1** Default IP Source Guard Parameters

| Parameters        | Default                                                        |
|-------------------|----------------------------------------------------------------|
| IP Source Guard   | Disabled on each interface.                                    |
| IP source entries | None. No static or default IP source entries exist by default. |

## Configuring IP Source Guard

This section includes the following topics:

- [Enabling or Disabling IP Source Guard on a Layer 2 Interface, page 14-3](#)
- [Adding or Removing a Static IP Source Entry, page 14-4](#)



***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

## Enabling or Disabling IP Source Guard on a Layer 2 Interface

Use this procedure to enable or disable IP Source Guard on a Layer 2 interface.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- By default, IP Source Guard is disabled on all interfaces.
- Ensure that DHCP snooping is enabled. For more information, see the “[Enabling or Disabling the DHCP Feature](#)” section on page 12-5.

### SUMMARY STEPS

1. **config t**
2. **interface vethernet** *interface-number*  
**port-profile** *profilename*
3. **[no] ip verify source dhcp-snooping-vlan**
4. **show running-config dhcp**
5. **copy running-config startup-config**

### DETAILED STEPS

|        | Command                                                                                                                                                                                                                                                                            | Purpose                                                                                                                                                                                                                                                                                                             |
|--------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <b>config t</b><br><br><b>Example:</b><br>switch# config t<br>switch(config)#                                                                                                                                                                                                      | Enters global configuration mode.                                                                                                                                                                                                                                                                                   |
| Step 2 | <b>interface vethernet</b> <i>interface-number</i><br><br><b>Example:</b><br>switch(config)# interface vethernet 3<br>switch(config-if)#<br><br><b>port-profile</b> <i>profilename</i><br><br><b>Example:</b><br>switch(config)# port-profile vm-data<br>switch(config-port-prof)# | Enters interface configuration mode, where <i>interface-number</i> is the vEthernet interface that you want to configure as trusted or untrusted for DHCP snooping.<br><br>Enters port profile configuration mode for the specified port profile, where <i>profilename</i> is a unique name of up to 80 characters. |
| Step 3 | <b>[no] ip verify source dhcp-snooping-vlan</b><br><br><b>Example:</b><br>switch(config-if)# ip verify source<br>dhcp-snooping vlan                                                                                                                                                | Enables IP Source Guard on the interface. The <b>no</b> option disables IP Source Guard on the interface.                                                                                                                                                                                                           |
| Step 4 | <b>show running-config dhcp</b><br><br><b>Example:</b><br>switch(config-if)# show running-config<br>dhcp                                                                                                                                                                           | (Optional) Displays the running configuration for DHCP snooping, including the IP Source Guard configuration.                                                                                                                                                                                                       |

**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**

|        | Command                                                                                                                   | Purpose                                                                   |
|--------|---------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------|
| Step 5 | <b>copy running-config startup-config</b><br><br><b>Example:</b><br>switch(config-if)# copy running-config startup-config | (Optional) Copies the running configuration to the startup configuration. |

## Adding or Removing a Static IP Source Entry

Use this procedure to add or remove a static IP source entry on a device.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- By default, there are no static IP source entries on a device.

### SUMMARY STEPS

1. **config t**
2. **[no] ip source binding** *IP-address MAC-address* **vlan** *vlan-ID* **interface vethernet** *interface-number*
3. **show ip dhcp snooping binding** [**interface vethernet** *interface-number*]
4. **copy running-config startup-config**

### DETAILED STEPS

|        | Command                                                                                                                                                                                                                                                       | Purpose                                                                                                                                                                       |
|--------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <b>config t</b><br><br><b>Example:</b><br>switch# config t<br>switch(config)#                                                                                                                                                                                 | Enters global configuration mode.                                                                                                                                             |
| Step 2 | <b>[no] ip source binding</b> <i>IP-address MAC-address</i> <b>vlan</b> <i>vlan-ID</i> <b>interface vethernet</b> <i>interface-number</i><br><br><b>Example:</b><br>switch(config)# ip source binding 10.5.22.17 001f.28bd.0013 vlan 100 interface ethernet 3 | Creates a static IP source entry for the current interface, or if you use the <b>no</b> option, removes a static IP source entry.                                             |
| Step 3 | <b>show ip dhcp snooping binding</b> [ <b>interface vethernet</b> <i>interface-number</i> ]<br><br><b>Example:</b><br>switch(config)# show ip dhcp snooping binding interface ethernet 3                                                                      | (Optional) Displays IP-MAC address bindings for the interface specified, including static IP source entries. Static entries appear with the term “static” in the Type column. |
| Step 4 | <b>copy running-config startup-config</b><br><br><b>Example:</b><br>switch(config)# copy running-config startup-config                                                                                                                                        | (Optional) Copies the running configuration to the startup configuration.                                                                                                     |

**[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)**

## Verifying the IP Source Guard Configuration

To display IP Source Guard configuration information, use one of the following commands:

| Command                               | Purpose                                                                            |
|---------------------------------------|------------------------------------------------------------------------------------|
| <code>show running-config dhcp</code> | Displays DHCP snooping configuration, including the IP Source Guard configuration. |
| <code>show ip verify source</code>    | Displays IP-MAC address bindings.                                                  |

For detailed information about command output, see the *Cisco Nexus 1000V Command Reference, Release 4.2(1)SV1(5.1)*.

## Displaying IP Source Guard Bindings

Use the `show ip verify source` command to display IP-MAC address bindings.

## Example Configuration for IP Source Guard

The following example shows how to create a static IP source entry and then how to enable IP Source Guard on an interface:

```
ip source binding 10.5.22.17 001f.28bd.0013 vlan 100 interface vethernet 3
interface ethernet 2/3
  no shutdown
  ip verify source dhcp-snooping-vlan
```

## Additional References

For additional information related to implementing IP Source Guard, see the following sections:

- [Related Documents, page 14-5](#)
- [Standards, page 14-6](#)

## Related Documents

| Related Topic                                                                                                               | Document Title                                                                                                         |
|-----------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------|
| <a href="#">Information About DHCP Snooping, page 12-1</a>                                                                  | <i>Cisco Nexus 1000V Security Configuration Guide, Release 4.2(1)SV1(5.1), Chapter 12, “Configuring DHCP Snooping”</i> |
| IP Source Guard commands: complete command syntax, command modes, command history, defaults, usage guidelines, and examples | <i>Cisco Nexus 1000V Command Reference, Release 4.2(1)SV1(5.1)</i>                                                     |
| DHCP snooping commands: complete command syntax, command modes, command history, defaults, usage guidelines, and examples   | <i>Cisco Nexus 1000V Command Reference, Release 4.2(1)SV1(5.1)</i>                                                     |

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

## Standards

| Standards                                                                                                                             | Title |
|---------------------------------------------------------------------------------------------------------------------------------------|-------|
| No new or modified standards are supported by this feature, and support for existing standards has not been modified by this feature. | —     |

## Feature History for IP Source Guard

[Table 14-2](#) lists the release history for this feature.

**Table 14-2**     *Feature History for IP Source Guard*

| Feature Name    | Releases     | Feature Information          |
|-----------------|--------------|------------------------------|
| IP Source Guard | 4.0(4)SV1(2) | This feature was introduced. |



## CHAPTER 15

# Disabling HTTP Server

---

This chapter describes how to disable the HTTP server and includes the following topics:

- [Information About the HTTP Server, page 15-1](#)
- [Guidelines and Limitations, page 15-1](#)
- [Default Setting, page 15-2](#)
- [Disabling HTTP Server, page 15-2](#)
- [Verifying the HTTP Configuration, page 15-3](#)
- [Additional References, page 15-3](#)
- [Feature History for Disabling the HTTP Server, page 15-4](#)

## Information About the HTTP Server

An HTTP server, which can be turned off from the CLI to address security concerns, is embedded in the Virtual Supervisor Module (VSM).

If you want to turn off the HTTP server, see the following “[Guidelines and Limitations](#)”.

## Guidelines and Limitations

- The HTTP server is enabled by default.
- VUM will not install VEMs if the HTTP server is disabled. During VEM installation, VUM talks directly to the HTTP server to extract required module information from the VSM. To install VEMs, you must do one of the following:
  - Use VUM by enabling the HTTP server during VEM installation, and then disabling it after the VEMs are installed.
  - Install VEMs manually without using VUM.
- The HTTP server must be enabled in order to get the Cisco Nexus 1000V XML plugin from the VSM.
- To change the security certificate for the HTTP server, use the **install http-certificate bootflash:** `<cert_path>` command. After executing this command, the Webserver begins using the security certificate. The certificate that is being installed must be a server certificate containing both a public and a private key.

*Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).*

## Default Setting

The HTTP server is enabled by default.

## Disabling HTTP Server

Use this procedure to disable the HTTP server.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.
- By default, the HTTP server is enabled.

### SUMMARY STEPS

1. **config t**
2. **no feature http-server**
3. **show http-server**
4. **copy running-config startup-config**

### DETAILED STEPS

|        | Command                                                                                                                                                         | Purpose                                                                                                                          |
|--------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <b>config t</b><br><br><b>Example:</b><br>n1000v# config t<br>n1000v(config)#                                                                                   | Enters CLI global configuration mode.                                                                                            |
| Step 2 | <b>no feature http-server</b><br><br><b>Example:</b><br>n1000v(config)# no feature http-server<br>n1000v(config)#                                               | Disables the HTTP server.                                                                                                        |
| Step 3 | <b>show http-server</b><br><br><b>Example:</b><br>n1000v(config)# show http-server<br>http-server disabled                                                      | (Optional) Displays the HTTP server configuration (enabled or disabled).                                                         |
| Step 4 | <b>copy running-config startup-config</b><br><br><b>Example:</b><br>n1000v(config)# copy running-config<br>startup-config<br>[#####]<br>100%<br>n1000v(config)# | (Optional) Saves the running configuration persistently through reboots and restarts by copying it to the startup configuration. |

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

**Example:**  
 config t  
 no feature http-server

## Verifying the HTTP Configuration

To display the HTTP configuration, use the following commands:

| Command                       | Purpose                                                                                                          |
|-------------------------------|------------------------------------------------------------------------------------------------------------------|
| <code>show http-server</code> | Displays the HTTP server configuration.<br>See <a href="#">Example 15-1</a>                                      |
| <code>show feature</code>     | Displays the features available, such as LACP, and whether they are enabled.<br>See <a href="#">Example 15-2</a> |

### **Example 15-1** `show http-server`

```
n1000v(config)# show http-server
http-server enabled
n1000v(config)#
```

### **Example 15-2** `show feature`

```
n1000v(config)# show feature
Feature Name      Instance  State
-----
dhcp-snooping    1        disabled
http-server      1        disabled
ippool           1        disabled
lACP              1        disabled
netflow          1        disabled
private-vlan     1        disabled
sshServer        1        enabled
tacacs           1        disabled
telnetServer     1        disabled
n1000v(config)#
```

## Additional References

For additional information related to implementing Telnet, see the following sections:

- [Related Documents, page 15-4](#)
- [Standards, page 15-4](#)

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

## Related Documents

| Related Topic                                                                                     | Document Title                                                     |
|---------------------------------------------------------------------------------------------------|--------------------------------------------------------------------|
| Complete command syntax, command modes, command history, defaults, usage guidelines, and examples | <i>Cisco Nexus 1000V Command Reference, Release 4.2(1)SV1(5.1)</i> |

## Standards

| Standards                                                                                                                             | Title |
|---------------------------------------------------------------------------------------------------------------------------------------|-------|
| No new or modified standards are supported by this feature, and support for existing standards has not been modified by this feature. | —     |

## Feature History for Disabling the HTTP Server

This section provides the release history for disabling the HTTP server.

| Feature Name        | Releases     | Feature Information          |
|---------------------|--------------|------------------------------|
| Disable HTTP server | 4.2(1)SV1(4) | This feature was introduced. |





## CHAPTER 16

# Blocking Unknown Unicast Flooding

---

This chapter describes how to block unknown unicast packet flooding (UUFb) in the forwarding path and includes the following sections:

- [Information About UUFb, page 16-1](#)
- [Guidelines and Limitations, page 16-1](#)
- [Default Settings, page 16-2](#)
- [Configuring UUFb, page 16-2](#)
- [Verifying the UUFb Configuration, page 16-6](#)
- [UUFb Example Configurations, page 16-7](#)
- [Additional References, page 16-8](#)
- [Feature History for UUFb, page 16-8](#)

## Information About UUFb

UUFb limits unknown unicast flooding in the forwarding path to prevent the security risk of unwanted traffic reaching the VMs. UUFb prevents packets received on both vEthernet and Ethernet interfaces destined to unknown unicast addresses from flooding the VLAN. When UUFb is applied, VEMs drop unknown unicast packets coming in on the uplink ports.

After you disable unknown unicast packets globally, you can then allow unicast flooding on either a single interface or all interfaces in a port profile.

You can also configure an interface or a port profile to never allow unknown unicasts to be blocked.

## Guidelines and Limitations

UUFb configuration has the following guideline.

- Before configuring UUFb, make sure the VSM HA pair and all VEMs have been upgraded to Release 4.2(1)SV1(5.1) by entering the **show module** command.
- You must explicitly disable UUFb on virtual service domain (VSD) ports. This can be done in the VSD port profiles. For more information, see the [Chapter 16, “Configuring a Port Profile to Allow Unknown Unicast Flooding”](#).

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

- You must explicitly disable UUFb on the ports of an application or VM using MAC addresses other than the one given by VMware.
- You can configure an interface to make sure that an unknown unicast is never blocked using the “[Configuring an Interface to Allow Unknown Unicast Flooding](#)” procedure on page 16-3.
- Unknown Unicast packets will be dropped by UCS-Fabric Interconnect when Unified Computing and Servers (UCS) is running in End-Host-Mode.
- On Microsoft Network Load Balancing (MS-NLB) enabled vEthernet interfaces ( no mac auto-static-learn), UUFb does not block MS-NLB related packets. In these scenarios, UUFb can be used to limit flooding of MS-NLB packets to non-MS-NLB ports within a VLAN.

## Default Settings

The following table lists the UUFb default settings.

| Parameters                           | Default  |
|--------------------------------------|----------|
| <code>uufb enable</code>             | disabled |
| <code>switchport uufb disable</code> | disabled |

## Configuring UUFb

This section includes the following procedures:

- [Blocking Unknown Unicast Flooding Globally on the Switch, page 16-2](#)
- [Configuring an Interface to Allow Unknown Unicast Flooding, page 16-3](#)
- [Configuring a Port Profile to Allow Unknown Unicast Flooding, page 16-5](#)

## Blocking Unknown Unicast Flooding Globally on the Switch

Use this procedure to globally block unknown unicast packets from flooding the forwarding path for the switch.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.

### SUMMARY STEPS

1. `config t`
2. `[no] uufb enable`
3. `show uufb status`
4. `copy running-config startup-config`

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

## DETAILED STEPS

|        | Command                                                                                                                                                               | Purpose                                                                                                                          |
|--------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>config t</code><br><br><b>Example:</b><br>n1000v# config t<br>n1000v(config)#                                                                                   | Enters CLI global configuration mode.                                                                                            |
| Step 2 | <code>[no] uufb enable</code><br><br><b>Example:</b><br>n1000v(config)# uufb enable<br>n1000v(config)#                                                                | Configures UUFB globally for the VSM.                                                                                            |
| Step 3 | <code>show uufb status</code><br><br><b>Example:</b><br>n1000v(config)# show uufb status<br>UUFB Status: Enabled<br>n1000v(config)#                                   | (Optional) Displays the UUFB global setting for the VSM.                                                                         |
| Step 4 | <code>copy running-config startup-config</code><br><br><b>Example:</b><br>n1000v(config)# copy running-config<br>startup-config<br>[#####]<br>100%<br>n1000v(config)# | (Optional) Saves the running configuration persistently through reboots and restarts by copying it to the startup configuration. |

## Configuring an Interface to Allow Unknown Unicast Flooding

Use this procedure to allow unknown unicast packets to flood a vEthernet interface if you have blocked flooding globally for the VSM.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.
- You can use this procedure to make sure unknown unicasts are never blocked on a specific interface, regardless of the global setting.
- If you have previously blocked unknown unicast packets globally, you can then allow unicast flooding on either a single interface or all interfaces in a port profile.

To allow unicast flooding on all interfaces in a port profile, see the [“Configuring a Port Profile to Allow Unknown Unicast Flooding”](#) procedure on page 16-5.

### SUMMARY STEPS

1. `config t`
2. `interface vethernet interface-number`
3. `[no] switchport uufb disable`
4. `show running-config vethernet interface-number`

**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**

### 5. copy running-config startup-config

#### DETAILED STEPS

|        | Command                                                                                                                                                                                                                                                                                                                                                                                                        | Purpose                                                                                                                          |
|--------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <b>config t</b><br><br><b>Example:</b><br>n1000v# config t<br>n1000v(config)#                                                                                                                                                                                                                                                                                                                                  | Enters CLI global configuration mode.                                                                                            |
| Step 2 | <b>interface vethernet interface-number</b><br><br><b>Example:</b><br>n1000v(config)# interface vethernet 100<br>n1000v(config-if)#                                                                                                                                                                                                                                                                            | Enters CLI interface configuration mode for the specified interface.                                                             |
| Step 3 | <b>[no] switchport uufb disable</b><br><br><b>Example:</b><br>n1000v(config-if)# switchport uufb disable<br>n1000v(config-if)#                                                                                                                                                                                                                                                                                 | Disables blocking of unicast packet flooding for the named interface.                                                            |
| Step 4 | <b>show running-config vethernet interface-number</b><br><br><b>Example:</b><br>n1000v(config-if)# show running-config interface veth100<br><br>!Command: show running-config interface Vethernet100<br>!Time: Fri Jun 10 12:43:53 2011<br><br>version 4.2(1)SV1(4a)<br><br>interface Vethernet100<br>description accessvlan<br>switchport access vlan 30<br>switchport uufb disable<br><br>n1000v(config-if)# | (Optional) Displays the running configuration for the interface for verification.                                                |
| Step 5 | <b>copy running-config startup-config</b><br><br><b>Example:</b><br>n1000v(config-if)# copy running-config startup-config<br>[#####]<br>100%<br>n1000v(config-if)#                                                                                                                                                                                                                                             | (Optional) Saves the running configuration persistently through reboots and restarts by copying it to the startup configuration. |

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

## Configuring a Port Profile to Allow Unknown Unicast Flooding

Use this procedure to allow unknown unicast packets to flood the interfaces in an existing vEthernet port profile if you have disabled unicast flooding globally for the VSM.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.
- You can use this procedure to make sure unknown unicasts are never blocked on a specific port profile, regardless of the global setting.
- If you have previously blocked unknown unicast packets globally, you can then allow unicast flooding on either a single interface or all interfaces in a port profile.

To allow unicast flooding on a single interface, see the [“Configuring an Interface to Allow Unknown Unicast Flooding” procedure on page 16-3](#).

- You have previously configured the vEthernet port profile that you want to allow flooding for.

### SUMMARY STEPS

1. **config t**
2. **port-profile *profile-name***
3. **[no] switchport uufb disable**
4. **show running-config port-profile *profile-name***
5. **copy running-config startup-config**

### DETAILED STEPS

|        | Command                                                                                                                                         | Purpose                                                                                    |
|--------|-------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------|
| Step 1 | <b>config t</b><br><br><b>Example:</b><br>n1000v# config t<br>n1000v(config)#                                                                   | Enters CLI global configuration mode.                                                      |
| Step 1 | <b>port-profile <i>profile-name</i></b><br><br><b>Example:</b><br>n1000v(config)# port-profile accessprof<br>n1000v(config-port-prof)#          | Enters configuration mode for the named port profile.                                      |
| Step 2 | <b>[no] switchport uufb disable</b><br><br><b>Example:</b><br>n1000v(config-port-prof)# switchport uufb<br>disable<br>n1000v(config-port-prof)# | Disables blocking of unicast packet flooding for all interfaces in the named port profile. |

**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**

|        | Command                                                                                                                                                                                                                                                                                                                                                                                                                                                             | Purpose                                                                                                                          |
|--------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------|
| Step 3 | <pre>show running-config port-profile profile-name  Example: n1000v(config-port-prof)# show running-config port-profile accessprof  !Command: show running-config port-profile accessprof !Time: Fri Jun 10 12:06:38 2011  version 4.2(1)SV1(4a) port-profile type vethernet accessprof   vmware port-group   switchport mode access   switchport access vlan 300   switchport uufb disable   no shutdown   description all_access  n1000v(config-port-prof)#</pre> | (Optional) Displays the configuration for the named port profile for verification.                                               |
| Step 4 | <pre>copy running-config startup-config  Example: n1000v(config-port-prof)# copy running-config startup-config [#####] 100% n1000v(config-port-prof)#</pre>                                                                                                                                                                                                                                                                                                         | (Optional) Saves the running configuration persistently through reboots and restarts by copying it to the startup configuration. |

## Verifying the UUF B Configuration

You can use the following commands to verify the UUF B configuration:

| Command                                                                                      | Purpose                                                         |
|----------------------------------------------------------------------------------------------|-----------------------------------------------------------------|
| <code>show uufb status</code>                                                                | Displays the UUF B global setting for the VSM.                  |
| <code>show running-config port-profile</code><br><i>profile-name</i>                         | Displays the running configuration for a specific port profile. |
| <code>show running-config interface</code><br><code>vethernet</code> <i>interface-number</i> | Displays the running configuration for a specific interface.    |
| <code>vemcmd show port uufb-override</code>                                                  | Displays UUF B disable state for each port.                     |

*Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).*

## UUFb Example Configurations

The following example shows how to block unknown unicast packets from flooding the forwarding path globally for the VSM.

**Example:**

```
n1000v# config t
n1000v(config)# uufb enable
n1000v(config)# show uufb status
UUFb Status: Enabled
n1000v(config)# copy running-config startup-config
[#####] 100%
n1000v(config)#
```

The following example shows how to allow unknown unicast packets to flood vEthernet interface 100 if you have disabled UUFb globally for the VSM.

**Example:**

```
n1000v# config t
n1000v(config)# interface vethernet 100
n1000v(config-if)# switchport uufb disable
n1000v(config-if)# show running-config interface veth100

!Command: show running-config interface Vethernet100
!Time: Fri Jun 10 12:43:53 2011

version 4.2(1)SV1(4a)

interface Vethernet100
  description accessvlan
  switchport access vlan 30
  switchport uufb disable

n1000v(config-if)#
```

The following example shows how to allow unknown unicast packets to flood the interfaces in an existing port profile if you have disabled UUFb globally for the VSM.

**Example:**

```
n1000v# config t
n1000v(config)# port-profile accessprof
n1000v(config-port-prof)# switchport uufb disable
n1000v(config-port-prof)# show running-config port-profile accessprof

!Command: show running-config port-profile accessprof
!Time: Fri Jun 10 12:06:38 2011

version 4.2(1)SV1(4a)
port-profile type vethernet accessprof
  vmware port-group
  switchport mode access
  switchport access vlan 300
  switchport uufb disable
  no shutdown
  description all_access

n1000v(config-port-prof)#
```

**[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)**

## Additional References

For additional information related to UUFb, see the following sections:

- [Related Documents, page 16-8](#)
- [Standards, page 16-8](#)

## Related Documents

| Related Topic                                                                                     | Document Title                                                                         |
|---------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------|
| Complete command syntax, command modes, command history, defaults, usage guidelines, and examples | <i>Cisco Nexus 1000V Command Reference, Release 4.2(1)SV1(5.1)</i>                     |
| Interface configuration                                                                           | <i>Cisco Nexus 1000V Interface Configuration Guide, Release 4.2(1)SV1(5.1)</i>         |
| Port Profile configuration                                                                        | <i>Cisco Nexus 1000V Port Profile Configuration Guide, Release 4.2(1)SV1(5.1)</i>      |
| Layer 2 switching configuration                                                                   | <i>Cisco Nexus 1000V Layer 2 Switching Configuration Guide, Release 4.2(1)SV1(5.1)</i> |

## Standards

| Standards                                                                                                                             | Title |
|---------------------------------------------------------------------------------------------------------------------------------------|-------|
| No new or modified standards are supported by this feature, and support for existing standards has not been modified by this feature. | —     |

## Feature History for UUFb

This section provides the UUFb release history.

| Feature Name | Releases      | Feature Information          |
|--------------|---------------|------------------------------|
| UUFb         | 4.2(1)SV1(4a) | This feature was introduced. |





# CHAPTER 17

## Security Configuration Limits

Table 17-1 shows the maximum configuration limits for Security features.

**Table 17-1 Security Maximum Configuration Limits**

| Security Feature                     | Maximum Limit |                  |
|--------------------------------------|---------------|------------------|
| Active VLANs across all VEMs         | 2048          |                  |
| MAC addresses over VLAN within a VEM | 32000         |                  |
| MAC addresses per VLAN within a VEM  | 4000          |                  |
| Secure vEths per VSM                 | 2000          |                  |
| Secure MACs per VSM                  | 8000          |                  |
| Secure MACs per vEths                | 1025          |                  |
|                                      | Per DVS       | Per Host         |
| ACLs                                 | 128           | 16 <sup>2</sup>  |
| ACEs per ACL                         | 128           | 128 <sup>2</sup> |
| ACL Interfaces                       | 2048          | 256              |
| NetFlow Policies                     | 32            | 8                |
| NetFlow Interfaces                   | 256           | 32               |
| SPAN/ERSPAN Sessions                 | 64            | 64               |
| Port Security                        | 2048          | 216              |
| Multicast Groups                     | 512           | 512              |
| Virtual Service Domains (VSD)        | 64            | 6                |
| VSD Interfaces                       | 2048          | 216              |

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***



## INDEX

---

### A

#### AAA

- default settings [4-4](#)
- description [4-1 to 4-4](#)
- example configuration [4-9](#)
- guidelines [4-4](#)
- limitations [4-4](#)
- monitoring TACACS+ servers [6-3](#)
- prerequisites [4-4](#)
- server groups description [4-4](#)
- services [4-1](#)
- standards [4-9](#)
- TACACS+ server groups [6-12](#)
- verifying configurations [4-8](#)

aaa authentication command [4-6](#)

#### AAA servers

- FreeRADIUS VSA format [5-4](#)

#### access control lists

- order of application [9-2](#)
- See ACLs.
- types of [9-2](#)

#### accounting

- default [4-4](#)
- description [4-3](#)

#### ACL flows [9-5](#)

#### ACL logging [9-5](#)

- disabling [9-16](#)
- packet counters [9-17](#)
- severity levels [9-19](#)
- syslog message [9-19](#)
- time interval [9-17](#)
- verifying configuration [9-20](#)

#### ACLs

- configuring in port profiles [9-14, 10-8](#)

#### ARP inspection

- See dynamic ARP inspection

#### authentication

- console default [4-4](#)
- description [4-2](#)
- method default [4-4](#)

authentication, authorization, and accounting. See AAA

authorization, description [4-3](#)

av pair [6-3](#)

---

### C

#### Cisco

- vendor ID [5-3, 6-3](#)

class-map limits [17-1](#)

clear a Telnet session [8-4](#)

configuration limits [17-1](#)

#### console

- authentication default [4-4](#)
- configure login authentication [4-6](#)

---

### D

#### defaults

- user access [2-4](#)

#### default settings

- AAA [4-4](#)
- HTTP [15-2](#)
- SSH [7-3](#)
- TACACS+ [6-4](#)
- Telnet [3-3, 8-2](#)

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

- unknown unicast flooding [16-2](#)
- deny flows [9-6](#)
- deny flows, configuring [9-18](#)
- detection, DAI error-disabled interface [13-12](#)
- DHCP binding database
  - See DHCP snooping binding database
- DHCP feature
  - enabling [12-5](#)
- DHCP snooping
  - binding database
    - See DHCP snooping binding database
  - displaying DHCP bindings [12-16](#)
  - enabling globally [12-6](#)
  - enabling on a VLAN [12-7](#)
  - error-disable detection [11-17, 12-11, 12-12, 13-12](#)
  - guidelines and limitations [12-4](#)
  - information about [12-1](#)
    - binding database [12-2](#)
    - high availability [12-3](#)
    - Relay Agent [12-3](#)
    - trusted sources [12-2](#)
  - MAC address verification [12-8](#)
  - minimum configuration [12-5](#)
  - overview [12-1](#)
  - rate limiting DHCP packets [12-10](#)
  - relay agent, option 82 data, relaying switch and circuit information, DHCP snooping [12-15](#)
  - trusted and untrusted interfaces [12-9](#)
- DHCP snooping binding database
  - described [12-2](#)
  - entries [12-2](#)
- disable
  - HTTP [15-2](#)
  - Telnet [8-2](#)
- documentation
  - additional publications [1-xix](#)
- dynamic ARP inspection
  - additional validation [13-13](#)
  - ARP requests [13-1](#)

- ARP spoofing attack [13-2](#)
- configuring trust state [13-6, 13-8](#)
- configuring VLANs [13-6](#)
- description [13-1](#)
- DHCP snooping binding database [13-2](#)
- error-disabled detection and recovery [13-12](#)
- function of [13-2](#)
- network security and trusted interfaces [13-3](#)
- rate limits [13-14](#)
- Dynamic Host Configuration Protocol snooping
  - See DHCP snooping

---

## E

- enable
  - authentication failure messages [4-7](#)
  - port profile [3-6, 3-8](#)
  - Telnet [8-2](#)
- error-disabled interface, DAI [13-12](#)
- example configuration
  - AAA [4-9](#)
  - blocking unknown unicasts (UUFB) [16-7](#)
  - Secure Shell (SSH) [7-14](#)
  - TACACS+ [6-23](#)
  - user access [2-15](#)
- expiration date
  - information about [2-4](#)

---

## F

- feature groups
  - creating [2-10](#)
- flow chart
  - configuring AAA [4-5](#)
  - configuring TACACS+ [6-6](#)
- flow definition [9-5](#)
- flows
  - configuring permit and deny [9-17](#)

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

permit deny 9-6

FreeRADIUS

VSA format for role attributes 5-4

---

## H

HTTP 15-1

default setting 15-2

disable 15-2

guidelines and limitations 15-1

information about 15-1

---

## I

IDs

Cisco vendor ID 5-3

inside port profile, VSD, outside port profile, VSD 3-4, 3-7

interfaces, VSD 3-1

IP ACLs

changing an IP ACL 9-9

configuring 9-7 to ??

creating an IP ACL 9-8

default settings 9-7

description 9-1

guidelines 9-7, 10-2

limitations 9-7, 10-2

prerequisites 9-7

removing an IP ACL 9-11

verifying configuration 9-20

IP Source Guard

description 14-1

enabling 14-3

static IP source entries 14-4

---

## L

limits, configuration 17-1

logging ACL 9-5

login AAA, about 4-1

login authentication

configuring console methods 4-6

---

## M

MAC ACLs

changing a MAC ACL 10-4

creating a MAC ACL 10-2

description 10-1

removing a MAC ACL 10-5

mac port access-group command 9-15, 10-9

match criteria limit 17-1

---

## O

option 82, DHCP snooping 12-15

---

## P

password

checking strength 2-5, 2-6

passwords

information about 2-3

permit flows

about 9-6

configuring 9-18

policy map limits 17-1

port ACLs

applying 9-13, 9-15

port-profile command 3-5

port profiles

ACL 9-14, 10-8

port security

description 11-1

enabling on an interface 11-7

MAC move 11-4

static MAC address 11-9

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

violations [11-4](#)  
 preshared keys  
     TACACS+ [6-2](#)  
 prohibited words [2-7](#)

---

## R

### RADIUS

configuring servers [5-5 to 5-20](#)  
 configuring the global key [5-7](#)  
 configuring transmission retries [5-13](#)  
 default settings [5-5](#)  
 description [5-1 to 5-4](#)  
 example configurations [5-22](#)  
 network environments [5-1](#)  
 operation [5-2](#)  
 prerequisites [5-4](#)  
 specifying server at login [5-10](#)  
 verifying configuration [5-22](#)  
 VSAs [5-3](#)

### RADIUS server groups

configuring [5-9](#)

### RADIUS Servers

retries to a single server [5-15](#)

### RADIUS servers

configuring accounting attributes [5-16, 5-17](#)  
 configuring a timeout interval [5-14](#)  
 configuring authentication attributes [5-16, 5-17](#)  
 configuring dead-time intervals [5-20](#)  
 configuring hosts [5-6](#)  
 configuring keys [5-8](#)  
 configuring periodic monitoring [5-18](#)  
 displaying statistics [5-22](#)  
 example configurations [5-22](#)  
 manually monitoring [5-21](#)  
 monitoring [5-2](#)  
 verifying configuration [5-22](#)

recovery, DAI error-disabled interface [13-12](#)

related documents [1-xix, 1-xx](#)

relay agent, DHCP snooping [12-15](#)  
 remote session, Telnet IPv4 [8-3](#)  
 roles  
     example configuration [2-15](#)  
     information about [2-1](#)  
     interface access [2-12](#)  
     limitations [2-4](#)  
     verifying [2-15](#)  
 VLAN access [2-13](#)

---

## S

### Secure Shell

default settings [7-3](#)  
 security services, about [4-1](#)  
 server groups, description [4-4](#)  
 service policy limits [17-1](#)  
 service-port command [3-6](#)  
 services, AAA, about [4-1](#)  
 session, clearing Telnet [8-3, 8-4](#)  
 session, starting IPv4 Telnet [8-3](#)  
 show HTTP server command [15-3](#)  
 show Telnet server command [8-5](#)  
 show virtual -service-domain command [3-8](#)

### SSH

default settings [7-3](#)  
 generating server key-pairs [1-3, 7-1](#)  
 state enabled command [3-6, 3-8](#)  
 statistics  
     RADIUS servers [5-22](#)  
     TACACS+ [6-22](#)  
 switchport access vlan command [3-7](#)  
 switchport mode trunk command [3-5](#)  
 syslog messages [9-6](#)  
 syslog server severity levels [9-19](#)

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

---

## T

### TACACS+

- configuring [6-5 to ??](#)
- configuring global timeout interval [6-16](#)
- configuring shared keys [6-9](#)
- default settings [6-4](#)
- description [6-1 to ??](#)
- disabling [6-8](#)
- displaying statistics [6-22](#)
- enabling [6-8](#)
- example configurations [6-23](#)
- global preshared keys [6-2](#)
- guidelines [6-4](#)
- limitations [6-4](#)
- prerequisites [6-4](#)
- preshared key [6-2](#)
- specifying TACACS+ servers at login [6-15](#)
- user login operation [6-2](#)
- VSAs [6-3](#)

### TACACS+ servers

- configuration overview [6-6](#)
- configuring dead-time interval [6-21](#)
- configuring hosts [6-11](#)
- configuring periodic monitoring [6-20](#)
- configuring server groups [6-12](#)
- configuring TCP ports [6-18](#)
- displaying statistics [6-22](#)
- monitoring [6-3](#)

### TCP ports

- TACACS+ servers [6-18](#)

### Telnet [3-1, 8-1](#)

- clearing a session [8-4](#)
- clear session [8-3](#)
- default setting [3-3, 8-2](#)
- enable, disable [8-2](#)
- information about [8-1](#)
- prerequisites for [8-1](#)
- start IPv4 session [8-3](#)

- Telnet command [8-4](#)
- time interval, ACL logging [9-17](#)
- timeout
  - TACACS+ [6-16](#)

---

## U

### unknown unicast flooding

- default settings [16-2](#)

### user access

- defaults [2-4](#)
- example configuration [2-15](#)
- verifying [2-15](#)

### user account

- prohibited words [2-7](#)

### user accounts

- configuring [2-6](#)
- guidelines [2-4](#)
- information about [2-1](#)
- limitations roles
  - guidelines [2-4](#)

### user names

- information about [2-3](#)

### user roles

- creating [2-8](#)
- creating feature groups [2-10](#)

### UUFB

- default settings [16-2](#)
- verifying UUFB [16-6](#)

---

## V

### vendor ID, Cisco [6-3](#)

### vendor-specific attributes (VSAs) [6-3](#)

### verifying

- ACL logging configuration [9-20](#)
- unknown unicast flooding [16-6](#)

### virtual service domain

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

create [3-8](#)

display [3-8](#)

interfaces [3-1](#)

port profile

    inside or outside [3-4](#)

    member [3-7](#)

virtual -service-domain command [3-8](#)

virtual-service-domain command [3-5](#)

vmware port-group command [3-5](#)

VSAs

    protocol options [5-3](#)