



CHAPTER 33

Configuring ANCP Client

This chapter describes ANCP Client on Catalyst 4500 series switches. It includes the following sections:

- [Overview, page 33-1](#)
- [Enabling and Configuring ANCP Client, page 33-2](#)



Note

For complete syntax and usage information for the switch commands used in this chapter, look at the *Cisco Catalyst 4500 Series Switch Command Reference* and related publications at this location:

<http://www.cisco.com/en/US/products/hw/switches/ps4324/index.html>

If the command is not found in the Catalyst 4500 Command Reference, it will be found in the larger Cisco IOS library. Refer to the *Catalyst 4500 Series Switch Cisco IOS Command Reference* and related publications at this location:

<http://www.cisco.com/en/US/products/ps6350/index.html>

Overview

ANCP multicast enables you to control multicast traffic on a Catalyst 4500 series switch using either ANCP (rather than IGMP) or direct static configuration on the CLI. You can configure the switch as an ANCP client that connects to a remote ANCP server with multicast enabled. You can then initiate join and leave requests from that server. So, you can use the switch in a system in which a subscriber requests that a digital right management (DRM) server receive a given channel (multicast) potentially through any private protocol mechanism.



Note

The ANCP client does not allow more than four multicast streams per port per VLAN. If a fifth join request arrives, it is rejected.

If the DRM server determines that a subscriber is allowed to receive a multicast, it requests that the ANCP server send an ANCP join command to the ANCP client (Catalyst 4500 series switch) for the port to which the subscriber is connected.

**Note**

You must enable IGMP snooping on an ANCP Client (Catalyst 4500 series switch) in order to process multicast commands (join, leave, leave all requests, and request for active flows report) from the ANCP server. For information on enabling IGMP snooping, refer to [Chapter 22, “Configuring IGMP Snooping and Filtering.”](#)

The ANCP protocol must be able to identify the port on which you must add multicast. (You can identify this port through either the identifier configured on the CLI or the DHCP option 82 inserted by the switch when the subscriber received an IP address with DHCP. Either way, the administrator should be consistent in identifying a given port.

Enabling and Configuring ANCP Client

**Note**

If you intend to use DHCP option 82 rather than CLI mapping (with the **anpc client port identif** command) you must enter the **ip dhcp snooping** command before configuring the ANCP client.

You can identify a port by using the **anpc mode client** command or with DHCP option 82.

This section includes the following topics:

- [Enabling ANCP Client on a Port, page 33-2](#)
- [Enabling DHCP Option 82 on a Port, page 33-4](#)

Enabling ANCP Client on a Port

To make the Catalyst 4500 series switch operate as an ANCP client and to build and initialize its relevant data, enter the **anpc mode client** command. The **no** version of this command disables ANCP. This command disconnects the ANCP client from the ANCP server, and terminates any existing multicast streams that you enabled with ANCP.

To configure a switch to communicate with a single ANCP server, use the [**no**] **anpc client server interface** command. This command directs the ANCP client to initiate a TCP connection to the remote ANCP server identified with the IP address. If the TCP connection fails, it times out and retries the connection every 120 seconds until it succeeds. The **interface** command specifies the interface from which the local ANCP client obtains its IP address. The **no** version of the command terminates the TCP connection to the ANCP server but retains any existing ANCP-activated multicast stream.

By using separate commands to enable the ANCP client and to configure the IP address of the ANCP server, you can reconfigure the IP address of the remote ANCP server without losing existing ANCP-activated multicast streams.

Step 1 Enable ANCP:

```
Switch(config)> anpc mode client
```

Step 2 Configure the IP address of the remote server as the interface to acquire the source IP address:

```
Switch(config)> anpc client server ipaddress of server interface interface
```

The interface might be a loopback, which allows the client to reach the server through the interface.

- Step 3** (Optional) Enable the ANCP multicast client to identify this VLAN interface using the port-identifier as opposed to the Option 82 circuit-id:

```
Switch(config)> ancp client port identifier port-identifier vlan number interface
```

The **no** version of this command prompts a warning message if any multicast stream is activated by ANCP using the port-identifier on a port:

```
Switch(config)# no ancp client port identifier bbb vlan 10 interface GigabitEthernet3/5
Warning: Multicast flows seems to exist for this port, remove mapping and delete flows
anyway?[confirm]y
Switch(config)#

```

The ANCP client tries to connect to the server. If it fails, it tries again 10 seconds later. If it fails again, it tries again 20 seconds later and so on until it reaches the 120-second timeout. It remains timed out until it reconnects.



Note

If the connection is made and then fails again and the client attempts to reconnect again and it fails, the wait time returns to 10 seconds (and so on).

To determine whether the ANCP client is successfully connected to the server, enter the **show ancp status** command, which displays the status of the ANCP TCP connection with the remote ANCP server.

```
Switch# show ancp status
ANCP enabled on following interfaces

Et0/0
  ANCP end point(s) on this interface:
  =====

  ANCP state ESTAB
  Neighbor 10.1.1.1 Neighbor port 6068
  Hello interval 100 Sender instance 1 Sender name 372F61C
  Sender port 0 Partition ID 0 TCB 36E27E8
  Capabilities negotiated: Transactional Multicast

Switch#
```

In the preceding example, only one capability is negotiated (supported): transactional multicast. This is the only capability that the ANCP client supports. Therefore, the server also supports this capability and the two entities can now communicate.

The server can send ANCP multicast commands (join, leave, leave all requests, and request for active flows report) as defined in the multicast portion of the ANCP protocol. At any time, an administrator can use the **show ancp multicast [interface vlan] [group | source]** command to see the information the ANCP client has obtained about the current multicast flows.

Example 1

```
ANCP_Client# show ancp multicast group 239.6.6.6
ANCP Multicast Streams
ClientID          VLAN   Interface        Joined on
Group 239.6.6.6
0x0106000700130103    19    Gi1/3           15:06:23 UTC Tue Aug 26 2008
ANCP_Client#
```

Example 2

```
ANCP_Client# show ancp multicast interface Fa2/3 vlan 19
ANCP Multicast Streams
Interface FastEthernet2/3
  Group           Source
  239.5.6.7      -
VLAN 19: client ID 0x0106000700130203
  Joined on
  15:03:14 UTC Tue Aug 26 2008
ANCP_Client#
```



Note Specifying the **show ancp multicast** command without parameters or keywords lists all available data.

Enabling DHCP Option 82 on a Port



Note To use DHCP option 82, you need to enable DHCP and DHCP snooping.

If you identify the port with DHCP option 82 and intend to insert DHCP option 82, you need to configure the Catalyst 4500 series switch as a DHCP relay. This action adds a tag in the DHCP packet from the DHCP client so that the DHCP server can detect the switch port that the DHCP client is connected to. The DHCP server can then map the IP address it is providing to the client with the DHCP option 82 it received from the switch. The DHCP server only needs to look up the DHCP option 82 associated with a given IP address and provide it to the ANCP server. This allows the ANCP client on the switch to identify the proper port using an identifier the switch has knowledge of. To configure DHCP snooping on the Catalyst 4500 series switch, use the following commands:

```
Switch(config)# ip dhcp snooping
Switch(config)# ip dhcp snooping vlan vlan-range
```

By default, DHCP option 82 is inserted when DHCP snooping is activated. Turning this default off could cause ANCP to function improperly with the DHCP circuit-id; it must remain active. To activate it, enter the command:

```
Switch(config)# ip dhcp snooping information option
```



Note The DHCP option 82 circuit-ID is inserted into the Active-Flow report (when queried for all multicast flows) even if a configured circuit-ID exists.

ANCP allows a remote server to request the list of active flows from the ANCP client (Catalyst 4500 series switch is the ANCP client). This list is very similar to the output from the **show ancp multicast** command except that it follows the ANCP protocol packet format (see IETF.org). Observe that the **show ancp multicast** command provides the flows that have been activated with the **ancp port client identifier** command even though the ANCP active flow request only reports the client ID in DHCP option 82 circuit-ID format, regardless of the activation mechanism.

Guidelines and Restrictions

Follow these guidelines when applying ANCP functionality:

- Entering a **shut** command on a port removes ANCP activated multicast streams from the port. They must be reactivated by the ANCP server.
- Entering a **suspend** or **shut** command on a VLAN removes ANCP-activated multicast streams from the VLAN.
- Deleting a VLAN removes ANCP-activated multicast streams from the VLAN.
- If a port enters the errdisable or blocked state, ANCP-activated multicast streams are removed from the port.
- Disabling IGMP snooping globally or on one VLAN might disrupt ANCP client functionality.
- An ANCP client does not account for the Layer 3 interface state changes (if PIM interface at Layer 3 shuts down, ANCP does not remove the streams). When a PIM interface is running again, multicast streams are received by subscribers.

■ Guidelines and Restrictions