



## **Cisco UCS C-Series Integrated Management Controller CLI Configuration Guide for C3X60 Servers**

**First Published:** 2015-09-17

**Last Modified:** 2016-09-16

### **Americas Headquarters**

Cisco Systems, Inc.  
170 West Tasman Drive  
San Jose, CA 95134-1706  
USA  
<http://www.cisco.com>  
Tel: 408 526-4000  
800 553-NETS (6387)  
Fax: 408 527-0883

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NON-INFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: <http://www.cisco.com/go/trademarks>. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1110R)

© 2015-2016 Cisco Systems, Inc. All rights reserved.



## CONTENTS

---

### Preface

#### Preface **xiii**

Audience **xiii**

Conventions **xiii**

Related Cisco UCS Documentation **xv**

---

### CHAPTER 1

#### Overview **1**

Overview of the Cisco UCS C-Series Rack-Mount Server **1**

Overview of the Server Software **2**

Cisco Integrated Management Controller **2**

Cisco IMC CLI **4**

Command Modes **4**

Command Mode Table **5**

Complete a Command **8**

Command History **9**

Committing, Discarding, and Viewing Pending Commands **9**

Command Output Formats **9**

Online Help for the CLI **10**

Logging In to Cisco IMC **10**

---

### CHAPTER 2

#### Installing the Server OS **13**

OS Installation Methods **13**

KVM Console **13**

Installing an OS Using the KVM Console **14**

PXE Installation Servers **14**

Installing an OS Using a PXE Installation Server **15**

Booting an Operating System from a USB Port **15**

---

**CHAPTER 3****Managing Chassis and Dynamic Storage 17**

- Viewing Chassis Properties 17
  - Viewing Chassis Summary 17
  - Viewing CMC Firmware Versions 18
  - Viewing LED Details 18
  - Viewing the Details of the Servers on the Chassis 19
  - Viewing Physical Drive Properties 19
  - Viewing Cisco VIC Adapter Properties 21
  - Viewing Power Supply Properties 22
- Chassis Management Tasks 23
  - Toggling the Front Locator LED for the Chassis 23
  - Updating Firmware on Server Components 23
  - Time Zone 24
    - Selecting a Time Zone 24
    - Setting a Time Zone 24
- Managing Dynamic Storage 27
  - Dynamic Storage Support 27
  - Viewing SAS Expander Properties 28
  - Viewing Dynamic Storage and Physical Drive Details 29
  - Managing Physical Drives 31
    - Assigning Physical Drives to Servers 31
    - Unassigning Physical Drives to Servers 31
    - Assigning Physical Drives as Chassis Wide Hot Spare 32
    - Sharing Physical Drives with Servers 32
  - Managing SAS Expander and HDD Firmware 33
    - Updating and Activating SAS Expander Firmware 33
    - Updating HDD Firmware 34

---

**CHAPTER 4****Managing the Server 37**

- Toggling the Server Locator LED 37
- Toggling the Locator LED for a Hard Drive 38
- Managing the Server Boot Order 39
  - Server Boot Order 39
  - Viewing the Boot Device Detail 40

Configuring the Precision Boot Order	41
Modifying the Attributes of a Boot Device	43
Rearranging Device Boot Order	44
Reapplying Boot Order Configuration	44
Deleting an Existing Boot Device	45
Overview to UEFI Secure Boot	46
Enabling or Disabling UEFI Secure Boot Mode	47
Viewing the Actual Server Boot Order	48
Managing Server Power	49
Powering On the Server	49
Powering Off the Server	50
Powering Cycling the Server	51
Configuring the Power Restore Policy	51
Power Characterization	53
Power Profiles	53
Enabling Chassis Global Power Capping	54
Enabling Auto Balance Profile	55
Disabling Auto Balance Power Profile	56
Enabling Custom Profile on Server	57
Disabling Custom Profile on Server	58
Enabling Thermal Profile on Server	59
Disabling Thermal Profile on Server	60
Viewing Power Cap Configuration Details	61
Viewing Power Monitoring Details	62
Viewing CUPS Utilization Details	62
Resetting the Server	63
Shutting Down the Server	64
Configuring DIMM Black Listing	65
DIMM Black Listing	65
Enabling DIMM Black Listing	65
Configuring BIOS Settings	66
Viewing BIOS Status	66
Configuring Main BIOS Settings	67
Configuring Advanced BIOS Settings	67
Configuring Server Management BIOS Settings	68

Restoring BIOS Defaults	69
Entering BIOS Setup	69
Restoring BIOS Manufacturing Custom Defaults	70
Viewing Product ID (PID) Catalog Details	71
Uploading and Activating PID Catalog	72

---

**CHAPTER 5****Viewing Server Properties 75**

Viewing Server Properties	75
Viewing CMC Properties	76
Viewing Server CPU Details	77
Viewing Memory Properties	77
Viewing PCI Adapter Properties for a Server	78
Viewing HDD Details for a Server	79
Viewing Storage Adapter Properties for a Server	80
Viewing TPM Properties	80

---

**CHAPTER 6****Viewing Sensors 83**

Viewing Chassis Sensors	83
Viewing Power Supply Sensors	83
Viewing Fan Sensors	84
Viewing Current Sensors	85
Viewing Voltage Sensors	86
Viewing Temperature Sensors	87
Viewing LED Sensor	88
Viewing Server Sensors	88
Viewing Storage Sensors	88
Viewing Current Sensors	89
Viewing LED Sensors	89
Viewing Temperature Sensors	90
Viewing Voltage Sensors	91

---

**CHAPTER 7****Managing Remote Presence 93**

Managing the Virtual KVM	93
KVM Console	93
Enabling the Virtual KVM	94

Disabling the Virtual KVM	95
Configuring the Virtual KVM	95
Configuring Virtual Media	96
Configuring a Cisco IMC-Mapped vMedia Volume	98
Viewing Cisco IMC-Mapped vMedia Volume Properties	99
Managing Serial over LAN	100
Serial Over LAN	100
Guidelines and Restrictions for Serial Over LAN	100
Configuring Serial Over LAN	100

---

**CHAPTER 8**

<b>Managing User Accounts</b>	<b>103</b>
Configuring Local Users	103
Disabling Strong Password	105
LDAP Servers	106
Configuring the LDAP Server	106
Configuring LDAP in Cisco IMC	107
Configuring LDAP Groups in Cisco IMC	109
Configuring Nested Group Search Depth in LDAP Groups	110
LDAP Certificates Overview	111
Exporting LDAP CA Certificate	111
Downloading LDAP CA Certificate Content by Copying Content	112
Downloading LDAP CA Certificate Using Remote Server	114
Testing LDAP Binding	115
Deleting LDAP CA Certificate	116
Viewing User Sessions	116
Terminating a User Session	117

---

**CHAPTER 9**

<b>Configuring Network-Related Settings</b>	<b>119</b>
Server NIC Configuration	119
Server NICs	119
Configuring NICs	120
Common Properties Configuration	121
Overview to Common Properties Configuration	121
Configuring Common Properties	122
Configuring IPv4	123

Configuring IPv6	125
Configuring VLAN	129
Connecting to a Port Profile	131
Configuring Interface Properties	132
Network Security Configuration	133
Network Security	133
Configuring Network Security	133
Network Time Protocol Configuration	135
Configuring Network Time Protocol Settings	135
Pinging an IP address	136

---

**CHAPTER 10**

<b>Managing Network Adapters</b>	<b>139</b>
Overview of the Cisco UCS C-Series Network Adapters	139
Viewing Network Adapter Properties	142
Configuring Network Adapter Properties	143
Managing vHBAs	144
Guidelines for Managing vHBAs	144
Viewing vHBA Properties	145
Modifying vHBA Properties	145
Creating a vHBA	150
Deleting a vHBA	151
vHBA Boot Table	151
Viewing the Boot Table	152
Creating a Boot Table Entry	152
Deleting a Boot Table Entry	153
vHBA Persistent Binding	154
Enabling Persistent Binding	154
Disabling Persistent Binding	155
Rebuilding Persistent Binding	156
Managing vNICs	156
Guidelines for Managing vNICs	156
Viewing vNIC Properties	157
Modifying vNIC Properties	159
Enabling or Disabling Link Training on External Ethernet Interfaces	164
Creating a vNIC	165



Deleting a vNIC	166
Creating Cisco usNIC Using the Cisco IMC CLI	167
Modifying a Cisco usNIC value using the Cisco IMC CLI	169
Viewing usNIC Properties	171
Deleting Cisco usNIC from a vNIC	171
Configuring iSCSI Boot Capability	172
Configuring iSCSI Boot Capability for vNICs	172
Configuring iSCSI Boot Capability on a vNIC	173
Deleting an iSCSI Boot Configuration for a vNIC	174
Managing VM FEX	175
Virtual Machine Fabric Extender	175
Viewing VM FEX Properties	175
VM FEX Settings	177
Backing Up and Restoring the Adapter Configuration	180
Exporting the Adapter Configuration	180
Importing the Adapter Configuration	181
Restoring Adapter Defaults	182
Managing Adapter Firmware	183
Adapter Firmware	183
Installing Adapter Firmware	183
Activating Adapter Firmware	184

---

**CHAPTER 11**
**Managing Storage Adapters 185**

Creating Virtual Drives from Unused Physical Drives	186
Creating Virtual Drive from an Existing Drive Group	188
Setting a Virtual Drive as Transport Ready	190
Clearing a Virtual Drive as Transport Ready	191
Importing Foreign Configuration	193
Clearing Foreign Configuration	193
Enabling and Disabling JBOD	194
Clearing a Boot Drive	195
Retrieving Storage Firmware Logs for a Controller	196
Deleting a Virtual Drive	196
Initializing a Virtual Drive	197
Set as Boot Drive	198

Editing a Virtual Drive	199
Modifying Attributes of a Virtual Drive	200
Making a Dedicated Hot Spare	201
Making a Global Hot Spare	202
Preparing a Drive for Removal	202
Toggling Physical Drive Status	203
Setting a Physical Drive as a Controller Boot Drive	204
Removing a Drive from Hot Spare Pools	206
Undo Preparing a Drive for Removal	206
Enabling Auto Learn Cycles for the Battery Backup Unit	207
Disabling Auto Learn Cycles for the Battery Backup Unit	208
Starting a Learn Cycle for a Battery Backup Unit	208
Toggling the Locator LED for a Physical Drive	209
Viewing Storage Controller Logs	210

---

**CHAPTER 12****Configuring Communication Services 211**

Configuring HTTP	211
Configuring SSH	212
Configuring XML API	213
XML API for Cisco IMC	213
Enabling XML API	213
Configuring IPMI	214
IPMI Over LAN	214
Configuring IPMI over LAN for Cisco IMC	214
Configuring IPMI over LAN for CMCs	215
Configuring SNMP	217
SNMP	217
Configuring SNMP Properties	217
Configuring SNMP Trap Settings	219
Sending a Test SNMP Trap Message	220
Configuring SNMPv3 Users	220

---

**CHAPTER 13****Managing Certificates 223**

Managing the Server Certificate	223
Generating a Certificate Signing Request	224

Creating an Untrusted CA-Signed Certificate 226

Uploading a Server Certificate 228

---

**CHAPTER 14****Cisco IMC Firmware Management 231**

Overview of Firmware 231

Obtaining Firmware from Cisco 232

Installing Cisco IMC Firmware from a Remote Server 234

Activating Installed Cisco IMC Firmware 235

Installing BIOS Firmware from a Remote Server 237

Activating Installed BIOS Firmware 238

Installing CMC Firmware from a Remote Server 240

Activating Installed CMC Firmware 241

---

**CHAPTER 15****Viewing Faults and Logs 243**

Fault Summary 243

Viewing the Faults and Logs Summary 243

Fault History 244

Viewing the Fault History 244

Cisco IMC Log 244

Viewing Cisco IMC Log 244

Clearing Trace Logs 245

Configuring the Cisco IMC Log Threshold 245

Sending the Cisco IMC Log to a Remote Server 247

System Event Log 248

Viewing the System Event Log 248

Viewing the System Event Log for Servers 249

Clearing the System Event Log 250

Logging Controls 250

Configuring the Cisco IMC Log Threshold 250

Sending the Cisco IMC Log to a Remote Server 252

Sending a Test Cisco IMC Log to a Remote Server 253

---

**CHAPTER 16****Server Utilities 255**

Exporting Technical Support Data 255

Rebooting the Cisco IMC 257

Clearing the BIOS CMOS	258
Resetting the BMC to factory Defaults	258
Resetting CMCs to Factory Defaults	259
Exporting and Importing the Cisco IMC and BMC Configuration	260
Importing a CMC Configuration	260
Importing BMC Configuration	261
Exporting the BMC Configuration	263
Exporting the CMC Configuration	264
Generating Non-Maskable Interrupts to the Host	265
Adding Cisco IMC Banner	266

---

**APPENDIX A****BIOS Parameters by Server Model 267**

C3X60 Servers	267
Main BIOS Parameters for C3260 Servers	267
Advanced BIOS Parameters for C3260 Servers	268
Server Management BIOS Parameters for C3260 Servers	285
Main BIOS Parameters for C3X60 M4 Servers	286
Advanced BIOS Parameters for C3X60 M4 Servers	287
Server Management BIOS Parameters for C3X60 M4 Servers	306

---

**APPENDIX B****BIOS Token Name Comparison for Multiple Interfaces 309**

BIOS Token Name Comparison for Multiple Interfaces	309
--	-----



# Preface

---

- [Audience, page xiii](#)
- [Conventions, page xiii](#)
- [Related Cisco UCS Documentation, page xv](#)

## Audience

This guide is intended primarily for data center administrators with responsibilities and expertise in one or more of the following:

- Server administration
- Storage administration
- Network administration
- Network security

## Conventions

Text Type	Indication
GUI elements	GUI elements such as tab titles, area names, and field labels appear in <b>this font</b> . Main titles such as window, dialog box, and wizard titles appear in <b>this font</b> .
Document titles	Document titles appear in <i>this font</i> .
TUI elements	In a Text-based User Interface, text the system displays appears in <i>this font</i> .
System output	Terminal sessions and information that the system displays appear in <i>this font</i> .
CLI commands	CLI command keywords appear in <b>this font</b> . Variables in a CLI command appear in <i>this font</i> .

Text Type	Indication
[ ]	Elements in square brackets are optional.
{x   y   z}	Required alternative keywords are grouped in braces and separated by vertical bars.
[x   y   z]	Optional alternative keywords are grouped in brackets and separated by vertical bars.
string	A nonquoted set of characters. Do not use quotation marks around the string or the string will include the quotation marks.
< >	Nonprinting characters such as passwords are in angle brackets.
[ ]	Default responses to system prompts are in square brackets.
!, #	An exclamation point (!) or a pound sign (#) at the beginning of a line of code indicates a comment line.

**Note**

Means *reader take note*. Notes contain helpful suggestions or references to material not covered in the document.

**Tip**

Means *the following information will help you solve a problem*. The tips information might not be troubleshooting or even an action, but could be useful information, similar to a Timesaver.

**Timesaver**

Means *the described action saves time*. You can save time by performing the action described in the paragraph.

**Caution**

Means *reader be careful*. In this situation, you might perform an action that could result in equipment damage or loss of data.

**Warning****IMPORTANT SAFETY INSTRUCTIONS**

This warning symbol means danger. You are in a situation that could cause bodily injury. Before you work on any equipment, be aware of the hazards involved with electrical circuitry and be familiar with standard practices for preventing accidents. Use the statement number provided at the end of each warning to locate its translation in the translated safety warnings that accompanied this device.

SAVE THESE INSTRUCTIONS

# Related Cisco UCS Documentation

## Documentation Roadmaps

For a complete list of all B-Series documentation, see the *Cisco UCS B-Series Servers Documentation Roadmap* available at the following URL: <http://www.cisco.com/go/unifiedcomputing/b-series-doc>.

For a complete list of all C-Series documentation, see the *Cisco UCS C-Series Servers Documentation Roadmap* available at the following URL: <http://www.cisco.com/go/unifiedcomputing/c-series-doc>.

For information on supported firmware versions and supported UCS Manager versions for the rack servers that are integrated with the UCS Manager for management, refer to [Release Bundle Contents for Cisco UCS Software](#).

## Other Documentation Resources

Follow [Cisco UCS Docs on Twitter](#) to receive document update notifications.







## Overview

---

This chapter includes the following sections:

- [Overview of the Cisco UCS C-Series Rack-Mount Server, page 1](#)
- [Overview of the Server Software, page 2](#)
- [Cisco Integrated Management Controller, page 2](#)
- [Cisco IMC CLI, page 4](#)

## Overview of the Cisco UCS C-Series Rack-Mount Server

The Cisco UCS C3260 is a modular, dense storage server with dual M3 or M4 server nodes, optimized for large datasets used in environments such as big data, cloud, object storage, and content delivery.

The UCS C3260 chassis is a modular architecture consisting of the following modules:

- Base chassis: contains four redundant, hot-pluggable power supplies, eight redundant, hot-pluggable fans, and a rail kit.
- Server Node: one or two M3 or M4 server nodes, each with two CPUs, 128, 256, or 512 GB of DIMM memory, and a pass-through controller or a RAID card with a 1 GB or 4 GB cache.
- System I/O Controller (SIOC): one or two System I/O Controllers, each of which includes an integrated 1300-series virtual interface capability.
- Optional Drive Expansion Node: Large Form Factor (LFF) 3.5-inch drives in a choice of capacities.
- Hard Drives: Up to 56 top-loading Large Form Factor (LFF) HDDs of 4TB, 6TB, 8TB and 10TB capacities.
- Solid State Drives: Optionally up to 28 solid-state disks (SSDs) of 400GB, 800 GB, 1.6TB, and 3.2 TB capacities.
- Solid-State Boot Drives: up to two SSDs per M3 or M4 server node.
- I/O Expander: provides two PCIe expansion slots and accommodates up to two NVMe SSDs.

The enterprise-class UCS C3260 storage server extends the capabilities of Cisco's Unified Computing System portfolio in a 4U form factor that delivers the best combination of performance, flexibility, and efficiency gains.



---

**Note** An M3 Server Node has Intel E5-2600 V2 CPUs and DDR-3 DIMMs. An M4 Server Node has Intel E5-2600 v4 CPUs and DDR-4 DIMMs

---

## Overview of the Server Software

The Cisco UCS C-Series Rack-Mount Server ships with the Cisco IMC firmware.

### Cisco IMC Firmware

Cisco IMC is a separate management module built into the motherboard. A dedicated ARM-based processor, separate from the main server CPU, runs the Cisco IMC firmware. The system ships with a running version of the Cisco IMC firmware. You can update the Cisco IMC firmware, but no initial installation is needed.

### Server OS

The Cisco UCS C-Series rack servers support operating systems such as Windows, Linux, Oracle and so on. For more information on supported operating systems, see the *Hardware and Software Interoperability for Standalone C-series servers* at [http://www.cisco.com/en/US/products/ps10477/prod\\_technical\\_reference\\_list.html](http://www.cisco.com/en/US/products/ps10477/prod_technical_reference_list.html). You can use Cisco IMC to install an OS on the server using the KVM console and vMedia.



---

**Note** You can access the available OS installation documentation from the *Cisco UCS C-Series Servers Documentation Roadmap* at <http://www.cisco.com/go/unifiedcomputing/c-series-doc>.

---

## Cisco Integrated Management Controller

The Cisco IMC is the management service for the C-Series servers. Cisco IMC runs within the server.



---

**Note** The Cisco IMC management service is used only when the server is operating in Standalone Mode. If your C-Series server is integrated into a UCS system, you must manage it using UCS Manager. For information about using UCS Manager, see the configuration guides listed in the *Cisco UCS B-Series Servers Documentation Roadmap* at <http://www.cisco.com/go/unifiedcomputing/b-series-doc>.

---

### Management Interfaces

You can use a web-based GUI or SSH-based CLI or an XML-based API to access, configure, administer, and monitor the server. Almost all tasks can be performed in either interface, and the results of tasks performed in one interface are displayed in another. However, you cannot do the following:

- Use Cisco IMC GUI to invoke Cisco IMC CLI

- View a command that has been invoked through Cisco IMC CLI in Cisco IMC GUI
- Generate Cisco IMC CLI output from Cisco IMC GUI

### Tasks You Can Perform in Cisco IMC

You can use Cisco IMC to perform the following server management tasks:

- Power on, power off, power cycle, reset and shut down the server
- Toggle the locator LED
- Configure the server boot order
- View server properties and sensors
- Manage remote presence
- Create and manage local user accounts, and enable remote user authentication through Active Directory
- Configure network-related settings, including NIC properties, IPv4, VLANs, and network security
- Configure communication services, including HTTP, SSH, IPMI Over LAN, and SNMP.
- Manage certificates
- Configure platform event filters
- Update Cisco IMC firmware
- Monitor faults, alarms, and server status
- Set time zone and view local time
- Install and activate Cisco IMC firmware
- Install and activate BIOS firmware
- Install and activate CMC firmware

### No Operating System or Application Provisioning or Management

Cisco IMC provisions servers, and as a result, exists below the operating system on a server. Therefore, you cannot use it to provision or manage operating systems or applications on servers. For example, you cannot do the following:

- Deploy an OS, such as Windows or Linux
- Deploy patches for software, such as an OS or an application
- Install base software components, such as anti-virus software, monitoring agents, or backup clients
- Install software applications, such as databases, application server software, or web servers
- Perform operator actions, including restarting an Oracle database, restarting printer queues, or handling non-Cisco IMC user accounts
- Configure or manage external storage on the SAN or NAS storage

# Cisco IMC CLI

The Cisco IMC CLI is a command-line management interface for Cisco UCS C-Series servers. You can launch the Cisco IMC CLI and manage the server over the network by SSH or Telnet.

A user of the CLI will be one of three roles: admin, user (can control, cannot configure), and read-only.



---

**Note** To recover from a lost admin password, see the Cisco UCS C-Series server installation and service guide for your platform.

---

## Command Modes

The CLI is organized into a hierarchy of command modes, with the EXEC mode being the highest-level mode of the hierarchy. Higher-level modes branch into lower-level modes. You use the **scope** command to move from higher-level modes to modes in the next lower level, and the **exit** command to move up one level in the mode hierarchy. The **top** command returns to the EXEC mode.



---

**Note** Most command modes are associated with managed objects. The **scope** command does not create managed objects and can only access modes for which managed objects already exist.

---

Each mode contains a set of commands that can be entered in that mode. Most of the commands available in each mode pertain to the associated managed object. Depending on your assigned role, you may have access to only a subset of the commands available in a mode; commands to which you do not have access are hidden.

The CLI prompt for each mode shows the full path down the mode hierarchy to the current mode. This helps you to determine where you are in the command mode hierarchy and can be an invaluable tool when you need to navigate through the hierarchy.

## Command Mode Table

The following table lists the first four levels of command modes, the commands used to access each mode, and the CLI prompt associated with each mode.

Mode Name	Command to Access	Mode Prompt
EXEC	<b>top</b> command from any mode	#
server	<b>scope server</b> <i>index</i> command from EXEC mode	/server #
bios	<b>scope bios</b> command from server mode	/server/bios #
advanced	<b>scope advanced</b> command from bios mode	/server/bios/advanced #
main	<b>scope main</b> command from bios mode	/server/bios/main #
server-management	<b>scope server-management</b> command from bios mode	/server/bios/server-management #
boot-device	<b>scope boot-device</b> command from bios mode	/server/bios/boot-device #
bmc	<b>scope bmc</b> command from server mode	/server/bmc #
firmware	<b>scope firmware</b> command from bmc mode	/server/bios/bmc #
import-export	<b>scope import-export</b> command from bmc mode	/server/bios/import-export #
network	<b>scope network</b> command from bmc mode	/server/bios/network #
power-restore-policy	<b>scope power-restore-policy</b> command from bmc mode	/server/bios/power-restore-policy #
kvm	<b>scope kvm</b> command from server mode	/server/kvm #
ipmi	<b>scope ipmi</b> command from server mode	/server/ipmi #
dimmi-blacklisting	<b>scope dimmi-blacklisting</b> command from server mode	/server/dimmi-blacklisting #

Mode Name	Command to Access	Mode Prompt
reset-ecc	<b>scope reset-ecc</b> command from server mode	/server/reset-ecc #
sel	<b>scope sel</b> command from server mode	/server/sel #
sol	<b>scope sol</b> command from server mode	/server/sol #
vmedia	<b>scope vmedia</b> command from server mode	/server/vmedia #
certificate	<b>scope certificate</b> command from EXEC mode	/certificate #
fault	<b>scope fault</b> command from EXEC mode	/fault #
http	<b>scope http</b> command from EXEC mode	/http #
ldap	<b>scope ldap</b> command from EXEC mode	/ldap #
binding	<b>scope binding</b> command from ldap mode	/ldap/binding #
dns-search	<b>scope dns-search</b> command from ldap mode	/ldap/dns-search #
ldap-group-rule	<b>scope ldap-group-rule</b> command from ldap mode	/ldap/ldap-group-rule #
ldap-server	<b>scope ldap-server</b> command from ldap mode	/ldap/ldap-server #
role-group	<b>scope role-group</b> command from ldap mode	/ldap/role-group #
network	<b>scope network</b> command from EXEC mode	/network #
ipblocking	<b>scope ipblocking</b> command from network mode	/network/ipblocking #
chassis	<b>scope chassis</b> command from EXEC mode	/chassis #
adapter		/chassis/adapter #

Mode Name	Command to Access	Mode Prompt
	<b>scope adapter</b> <i>index</i> command from chassis mode	
host-eth-if	<b>scope host-eth-if</b> command from adapter mode	/chassis/adapter/host-eth-if #
host-fc-if	<b>scope host-fc-if</b> command from adapter mode	/chassis/adapter/host-fc-if #
port-profiles	<b>scope port-profiles</b> command from adapter mode	/chassis/adapter/port-profiles #
vmfex	<b>scope vmfex</b> <i>index</i> command from adapter mode	/chassis/adapter/vmfex #
cmc	<b>scope cmc</b> <i>index</i> command from chassis mode	/chassis/cmc #
ipmi	<b>scope ipmi</b> command from cmc mode	/chassis/cmc/ipmi #
network	<b>scope network</b> command from cmc mode	/chassis/cmc/network #
firmware	<b>scope firmware</b> command from chassis mode	/chassis/firmware #
import-export	<b>scope import-export</b> command from chassis mode	/chassis/import-export #
log	<b>scope log</b> command from chassis mode	/chassis/log #
server	<b>scope server</b> command from log mode	/chassis/log/server #
sas-expander	<b>scope sas-expander</b> <i>index</i> command from chassis mode	/chassis/sas-expander #
phy-stats	<b>scope phy-stats</b> command from sas-expander mode	/chassis/sas-expander/phy-stats #
server	<b>scope server</b> <i>index</i> command from chassis mode	/chassis/server #
storageadapter	<b>scope storageadapter</b> command from server mode	/chassis/server/storageadapter #
dim-summary		/chassis/server/dimm-summary #

Mode Name	Command to Access	Mode Prompt
	<b>scope dimm-summary</b> command from server mode	
tech-support	<b>scope tech-support</b> command from chassis mode	/chassis/tech-support #
sensor	<b>scope sensor</b> command from EXEC mode	/sensor #
snmp	<b>scope snmp</b> command from EXEC mode	/snmp #
trap-destinations	<b>scope trap-destinations</b> command from snmp mode	/snmp/trap-destinations #
v3users	<b>scope v3users</b> command from snmp mode	/snmp/v3users #
ssh	<b>scope ssh</b> command from EXEC mode	/ssh #
time	<b>scope time</b> command from EXEC mode	/time #
ntp	<b>scope ntp</b> command from time mode	/time/ntp #
user	<b>scope user</b> <i>user-number</i> command from EXEC mode	/user #
user-policy	<b>scope user-policy</b> command from EXEC mode	/user-policy #
user-session	<b>scope user-session</b> <i>session-number</i> command from EXEC mode	/user-session #
xmlapi	<b>scope xmlapi</b> command from EXEC mode	/xmlapi #

## Complete a Command

You can use the Tab key in any mode to complete a command. Partially typing a command name and pressing Tab causes the command to be displayed in full or to the point where another keyword must be chosen or an argument value must be entered.



## Command History

The CLI stores all commands used in the current session. You can step through the previously used commands by using the Up Arrow or Down Arrow keys. The Up Arrow key steps to the previous command in the history, and the Down Arrow key steps to the next command in the history. If you get to the end of the history, pressing the Down Arrow key does nothing.

All commands in the history can be entered again by simply stepping through the history to recall the desired command and pressing Enter. The command is entered as if you had manually typed it. You can also recall a command and change it before you press Enter.

## Committing, Discarding, and Viewing Pending Commands

When you enter a configuration command in the CLI, the command is not applied until you enter the **commit** command. Until committed, a configuration command is pending and can be discarded by entering a **discard** command. When any command is pending, an asterisk (\*) appears before the command prompt. The asterisk disappears when you enter the **commit** command, as shown in this example:

```
Server# scope chassis
Server /chassis # set locator-led off
Server /chassis *# commit
Server /chassis #
```

You can accumulate pending changes in multiple command modes and apply them together with a single **commit** command. You can view the pending commands by entering the **show configuration pending** command in any command mode.

**Note**

---

Committing multiple commands together is not an atomic operation. If any command fails, the successful commands are applied despite the failure. Failed commands are reported in an error message.

---

## Command Output Formats

Most CLI **show** commands accept an optional **detail** keyword that causes the output information to be displayed as a list rather than a table. You can configure either of two presentation formats for displaying the output information when the **detail** keyword is used. The format choices are as follows:

- **Default**—For easy viewing, the command output is presented in a compact list.

This example shows command output in the default format:

```
Server /chassis # set cli output default
Server /chassis # show hdd detail
Name HDD_01_STATUS:
  Status : present
Name HDD_02_STATUS:
  Status : present
Name HDD_03_STATUS:
  Status : present
Name HDD_04_STATUS:
  Status : present

Server /chassis #
```

- **YAML**—For easy parsing by scripts, the command output is presented in the YAML (YAML Ain't Markup Language) data serialization language, delimited by defined character strings.

This example shows command output in the YAML format:

```
Server /chassis # set cli output yaml
Server /chassis # show hdd detail
---
  name: HDD_01_STATUS
  hdd-status: present
---
  name: HDD_02_STATUS
  hdd-status: present
---
  name: HDD_03_STATUS
  hdd-status: present
---
  name: HDD_04_STATUS
  hdd-status: present
...
Server /chassis #
```

For detailed information about YAML, see <http://www.yaml.org/about.html>.

In most CLI command modes, you can enter **set cli output default** to configure the default format, or **set cli output yaml** to configure the YAML format.

## Online Help for the CLI

At any time, you can type the ? character to display the options available at the current state of the command syntax.

If you have not typed anything at the prompt, typing ? lists all available commands for the mode you are in. If you have partially typed a command, typing ? lists all available keywords and arguments available at your current position in the command syntax.

## Logging In to Cisco IMC

### Procedure

- 
- Step 1** Connect to the console port.
- Step 2** When logging in to an unconfigured system for the first time, use **admin** as the username and **password** as the password.

The following situations occur when you login to the CLI for the first time:

- You cannot perform any operation until you change default admin credentials on the Cisco IMC web UI or CLI.

**Note** After an upgrade from Cisco IMC version 1.5(x) or 2.0(1) to the latest version, or when you do a factory reset, during first login Cisco IMC prompts for a password change. You cannot choose the word 'password' as your new password. If this creates problems for any scripts you may be running, you could change it to password by logging back into the user management options, but this is ENTIRELY at your own risk. It is not recommended by Cisco.

---

The following example shows how to login in to Cisco IMC first time:

```
Login as # admin
admin10.101.255.255's password # password

*****WARNING*****
Default credentials were used for login.
Administration passwords needs to be changed for security purpose.
*****

Enter current password # abcxyz
Re-enter new password # abcxyz
Updating password...
Password updated successfully.
Server #
```





## Installing the Server OS

---

This chapter includes the following sections:

- [OS Installation Methods, page 13](#)
- [KVM Console, page 13](#)
- [PXE Installation Servers, page 14](#)
- [Booting an Operating System from a USB Port, page 15](#)

### OS Installation Methods

C-Series servers support several operating systems. Regardless of the OS being installed, you can install it on your server using one of the following tools:

- KVM console
- PXE installation server

### KVM Console

The KVM console is an interface accessible from Cisco IMC that emulates a direct keyboard, video, and mouse (KVM) connection to the server. The KVM console allows you to connect to the server from a remote location.

Instead of using CD/DVD or floppy drives physically connected to the server, the KVM console uses virtual media, which are actual disk drives or disk image files that are mapped to virtual CD/DVD or floppy drives. You can map any of the following to a virtual drive:

- CD/DVD or floppy drive on your computer
- Disk image files (ISO or IMG files) on your computer
- USB flash drive on your computer
- CD/DVD or floppy drive on the network
- Disk image files (ISO or IMG files) on the network

- USB flash drive on the network

You can use the KVM console to install an OS on the server.



**Note** To configure the KVM console successfully for the Cisco UCS C3260 server, you need to configure IP addresses for the Cisco IMC, CMC, and BMC components. You can configure the IP addresses for these components using the CLI interface or Web UI. For the CLI, use the command **scope network**, or view the setting using **scope <chassis/server1/2><cmc/bmc><network>**.

To configure IP addresses for network components on the web interface, see the steps described in the section **Configuring Network-Related Settings**.



**Note** The KVM Console is operated only through the GUI. To launch the KVM Console, see the instructions in the *Cisco UCS C-Series Servers Integrated Management Controller GUI Configuration Guide*.

## Installing an OS Using the KVM Console

Because the KVM console is operated only through the GUI, you cannot install a server OS using the CLI. To install an OS using the KVM console, follow the instructions in the "Installing an OS Using the KVM Console" section of the *Cisco UCS C-Series Servers Integrated Management Controller GUI Configuration Guide*.



**Note** Detailed guides for installing Linux, VMware, and Windows can be found at this URL: [http://www.cisco.com/en/US/products/ps10493/products\\_installation\\_and\\_configuration\\_guides\\_list.html](http://www.cisco.com/en/US/products/ps10493/products_installation_and_configuration_guides_list.html).

## PXE Installation Servers

A Preboot Execution Environment (PXE) installation server allows a client to boot and install an OS from a remote location. To use this method, a PXE environment must be configured and available on your VLAN, typically a dedicated provisioning VLAN. Additionally, the server must be set to boot from the network. When the server boots, it sends a PXE request across the network. The PXE installation server acknowledges the request, and starts a sequence of events that installs the OS on the server.

PXE servers can use installation disks, disk images, or scripts to install an OS. Proprietary disk images can also be used to install an OS, additional components, or applications.



**Note** PXE installation is an efficient method for installing an OS on a large number of servers. However, considering that this method requires setting up a PXE environment, it might be easier to use another installation method.

## Installing an OS Using a PXE Installation Server

### Before You Begin

- Verify that the server can be reached over a VLAN.
- You must log in as a user with admin privileges to install an OS.

### Procedure

---

**Step 1** Set the boot order to **PXE** first.

**Step 2** Reboot the server.

If a PXE install server is available on the VLAN, the installation process begins when the server reboots. PXE installations are typically automated and require no additional user input. Refer to the installation guide for the OS being installed to guide you through the rest of the installation process.

---

### What to Do Next

After the OS installation is complete, reset the LAN boot order to its original setting.

## Booting an Operating System from a USB Port

All Cisco UCS C-series servers support booting an operating system from any USB port on the server. However, there are a few guidelines that you must keep in mind, prior to booting an OS from a USB port.

- To maintain the boot order configuration, it is recommended that you use an internal USB port for booting an OS.
- The USB port must be enabled prior to booting an OS from it.

By default, the USB ports are enabled. If you have disabled a USB port, you must enable it prior to booting an OS from it. For information on enabling a disabled USB ports, see topic *Enabling or Disabling the Internal USB Port* in the server-specific installation and service guide available at the following link:

[http://www.cisco.com/en/US/products/ps10493/prod\\_installation\\_guides\\_list.html](http://www.cisco.com/en/US/products/ps10493/prod_installation_guides_list.html).

- After you boot the OS from the USB port, you must set the second-level boot order so that the server boots from that USB source every time.







# Managing Chassis and Dynamic Storage

This chapter includes the following sections:

- [Viewing Chassis Properties, page 17](#)
- [Chassis Management Tasks, page 23](#)
- [Managing Dynamic Storage, page 27](#)

## Viewing Chassis Properties

### Viewing Chassis Summary

#### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>show detail</b>	Displays the chassis' properties.

This example displays the chassis' properties:

```
Server# scope chassis
Server /chassis # show detail
Chassis:
  Serial Number: FOX1843G9EM
  Product Name: UCS C3260
  PID : UCSC-C3X60-BASE
  Front Panel Locator LED: on
  Description:
  CMC-1 State: Active
  CMC-2 State: Standby

Server /chassis #
```

## Viewing CMC Firmware Versions

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>show cmc</b>	Displays the CMC firmware versions.

This example displays the CMC firmware versions.:

```
Server# scope chassis
Server /chassis # show cmc
ID      Name      Serial Number Update Stage Update Progress Current FW Version
-----
1       CMC1          NONE          100          2.0 (6.79)
2       CMC2          NONE          100          2.0 (6.79)

Server /chassis #
```

## Viewing LED Details

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>show led</b>	Displays the LED details at the chassis level.

This example the LED details at the chassis level:

```
Server# scope chassis
Server /chassis # show led
LED Name      LED State LED Color
-----
CHS_FP_LED_ID FAST BLINK BLUE
LED_HLTH_STATUS ON GREEN
LED_PSU_STATUS ON GREEN
LED_TEMP_STATUS ON GREEN
LED_FAN_STATUS ON GREEN
SERVER1_FP_ID_LED OFF BLUE
SERVER2_FP_ID_LED OFF BLUE
OVERALL_DIMM_STATUS ON GREEN

Server /chassis #
```

## Viewing the Details of the Servers on the Chassis

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>show server</b>	Displays the high level details of the servers on the chassis.

This example displays the high level details of the servers on the chassis:

```

Server# scope chassis
Server /chassis # show server
Server ID Power Serial Number Product Name PID UID
-----
-----
1 on FCH1848794D UCS C3160 UCSC-C3X60-SVRNB
60974271-A514-484C-BAE3-A5EE4FD16E06
2 on FCH183978RD UCS C3160 UCSC-C3X60-SVRNB
207BD0D4-C589-40C1-A73E-EF6E7F773198

Server /chassis #
    
```

## Viewing Physical Drive Properties

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope dynamic-storage</b>	Enters the dynamic storage command mode.
<b>Step 3</b>	Server /chassis/dynamic-storage # <b>scope physical-drive drive number</b>	Enters the physical drive command mode.
<b>Step 4</b>	Server /chassis/dynamic-storage/physical-drive # <b>show detail</b>	Displays the details of the physical drive.
<b>Step 5</b>	Server /chassis/dynamic-storage/physical-drive # <b>exit</b>	Exits to the dynamic storage command mode.
<b>Step 6</b>	Server /chassis/dynamic-storage # <b>scope physical-drive-fw drive number</b>	Enters the physical drive firmware command mode.
<b>Step 7</b>	Server /chassis/dynamic-storage/physical-drive-fw # <b>show detail</b>	Displays the firmware details of the physical drive.

	Command or Action	Purpose
<b>Step 8</b>	Server /chassis/dynamic-storage/physical-drive-fw # <b>exit</b>	Exits to the dynamic storage command mode.
<b>Step 9</b>	Server /chassis/dynamic-storage # <b>scope physical-drive-link drive number</b>	Enters the physical drive link command mode.
<b>Step 10</b>	Server /chassis/dynamic-storage/physical-drive-link # <b>show detail</b>	Displays the link details of the physical drive.
<b>Step 11</b>	Server /chassis/dynamic-storage/physical-drive-link # <b>exit</b>	Exits to the dynamic storage command mode.
<b>Step 12</b>	Server /chassis/dynamic-storage # <b>scope physical-slot-owner drive number</b>	Enters the physical slot ownership command mode.
<b>Step 13</b>	Server /chassis/dynamic-storage/physical-slot-owner # <b>show detail</b>	Displays details about which server the physical drive is assigned to.

This example displays the physical drive properties:

#### Viewing Physical Drive Properties

```
Server# scope chassis
Server /chassis # scope dynamic-storage
Server /chassis/dynamic-storage # scope physical-drive 1
Server /chassis/dynamic-storage/physical-drive # show detail
Slot 1:
  Ownership: server1
  Health: good
  Vendor: TOSHIBA
  Product ID: MG03SCA400
  Product Rev Level: 5702
  Size: 3.63 TB
  Serial Number: 94E0A0T9FVU4
svbu-huu-sanity-col2-1-vcmc /chassis/dynamic-storage/physical-drive #
```

#### Viewing Firmware Details

```
Server /chassis/dynamic-storage/physical-drive # exit
Server /chassis/dynamic-storage # scope physical-drive-fw 1
Server /chassis/dynamic-storage/physical-drive-fw # show detail

Slot 1:
  Vendor: TOSHIBA
  Product ID: MG03SCA400
  Current_FW: 5702
  Update_Stage: NONE
  Update_Progress: 0
Server /chassis/dynamic-storage/physical-drive-fw #
```

#### Viewing Link Details

```
Server /chassis/dynamic-storage/physical-drive # exit
Server /chassis/dynamic-storage # scope physical-drive-link 1
Server /chassis/dynamic-storage/physical-drive-link # show detail
Slot 1:
  Ownership: server1
  EX1 Link: 6.0 Gb
  EX2 Link: 6.0 Gb
```

```

SAS Address 1: 50000395c8d2a1fe
SAS Address 2: 50000395c8d2a1ff
Server /chassis/dynamic-storage/physical-drive-link #
Viewing the slot ownership
Server /chassis/dynamic-storage/physical-drive-link # exit
Server /chassis/dynamic-storage # scope physical-slot-owner 1
Server /chassis/dynamic-storage/physical-drive-link # show detailSlot 1:
  Ownership: server1
Server /chassis/dynamic-storage/physical-slot-owner #
    
```

## Viewing Cisco VIC Adapter Properties

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>show adapter</b>	Displays the high level details of the servers on the chassis.
<b>Step 3</b>	Server /chassis # <b>show adapter detail</b>	Displays the high level details of the servers on the chassis.

This example displays the high level details of the Cisco Virtual Interface Card properties:

```

Server# scope chassis
Server /chassis # show adapter
Server ID Power Serial Number Product Name PID UUID
-----
1 on FCH1848794D UCS C3160 UCSC-C3X60-SVRNB
60974271-A514-484C-BAE3-A5EE4FD16E06
2 on FCH183978RD UCS C3160 UCSC-C3X60-SVRNB
207BD0D4-C589-40C1-A73E-EF6E7F773198
Server /chassis # show adapter detail
SIOC Slot 1:
  Product Name: UCSC-C3260-SIOC
  Serial Number: FCH18467P0U
  Product ID: UCSC-C3260-SIOC
  Adapter Hardware Revision:
  Current FW Version: 4.0(300.76)
  VNTAG: Disabled
  FIP: Enabled
  LLDP: Enabled
  Configuration Pending: no
  Cisco IMC Management Enabled: yes
  VID: V00
  Vendor: Cisco Systems Inc
  Description:
  Bootloader Version: 4.0(300.76)
  FW Image 1 Version: 4.0(300.76)
  FW Image 1 State: RUNNING ACTIVATED
  FW Image 2 Version: 4.0(300.71)
  FW Image 2 State: BACKUP INACTIVATED
  FW Update Status: Idle
  FW Update Error: No error
  FW Update Stage: No operation (0%)
  FW Update Overall Progress: 0%
SIOC Slot 2:
    
```

```

Product Name: UCSC-C3260-SIOC
Serial Number: FCH18467P16
Product ID: UCSC-C3260-SIOC
Adapter Hardware Revision:
Current FW Version: 4.0(300.61)
VNTAG: Disabled
FIP: Enabled
LLDP: Enabled
Configuration Pending: no
Cisco IMC Management Enabled: yes
VID: V00
Vendor: Cisco Systems Inc
Description:
Bootloader Version: 4.0(300.61)
FW Image 1 Version: 4.0(300.61)
FW Image 1 State: RUNNING ACTIVATED
FW Image 2 Version: 4.0(300.51)
FW Image 2 State: BACKUP INACTIVATED
FW Update Status: Idle
FW Update Error: No error
FW Update Stage: No operation (0%)
FW Update Overall Progress: 0%
Server /chassis #

```

## Viewing Power Supply Properties

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>show psu</b>	Displays the properties of each power supply on the chassis.
<b>Step 3</b>	Server /chassis # <b>show psu detail</b>	Displays the properties of each power supply on the chassis.

This example displays the properties of each power supply on the chassis:

```

Server# scope chassis
Server /chassis # show psu
Name          In. Power (Watts)  Out. Power (Watts)  Firmware  Status  Product ID
-----
PSU1          101                79                  10062012  Present UCSC-PSU1-1050W
PSU2          89                 73                  10062012  Present UCSC-PSU1-1050W
PSU3          96                 79                  10062012  Present UCSC-PSU1-1050W
PSU4          92                 82                  10062012  Present UCSC-PSU1-1050W
Server /chassis # show psu detail
Name PSU1:
  In. Power (Watts): 100
  Out. Power (Watts): 77
  Firmware : 10062012
  Status : Present
  Product ID : UCSC-PSU1-1050W
Name PSU2:
  In. Power (Watts): 89
  Out. Power (Watts): 75
  Firmware : 10062012
  Status : Present
  Product ID : UCSC-PSU1-1050W
Name PSU3:

```

```

In. Power (Watts): 96
Out. Power (Watts): 81
Firmware : 10062012
Status : Present
Product ID : UCSC-PSU1-1050W
Name PSU4:
In. Power (Watts): 91
Out. Power (Watts): 77
Firmware : 10062012
Status : Present
Product ID : UCSC-PSU1-1050W

Server /chassis #
    
```

## Chassis Management Tasks

### Toggleing the Front Locator LED for the Chassis

#### Before You Begin

You must log in with user or admin privileges to perform this task.

#### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>set front-locator-led {on   off}</b>	Enables or disables the chassis locator LED.
<b>Step 3</b>	Server /chassis # <b>commit</b>	Commits the transaction to the system configuration.

This example disables the chassis locator LED and commits the transaction:

```

Server# scope chassis
Server /chassis # set front-locator-led off
Server /chassis *# commit

Server /chassis #
    
```

### Updating Firmware on Server Components



#### Important

If any firmware or BIOS updates are in progress, do not reset the server until those tasks are complete.

#### Before You Begin

You must log in with user or admin privileges to perform this task.

Server must be powered off.

**Procedure**

	<b>Command or Action</b>	<b>Purpose</b>
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope firmware</b>	Enters firmware command mode.
<b>Step 3</b>	Server /chassis/firmware # <b>show detail</b>	Displays the firmware update required on some components message.
<b>Step 4</b>	Server /chassis/firmware # <b>update-all</b>	Updates the firmware on the server components.

This example resets the server:

```
Server# scope chassis
Server /chassis # scope firmware
Server /chassis / firmware # show detail
```

```
Firmware update required on some components,
please run update-all (under chassis/firmware scope).
```

```
Server /chassis / firmware # update-all
```

## Time Zone

### Selecting a Time Zone

Selecting a time zone helps you choose a local time zone so that you can view the local time rather than the default machine time. Cisco IMC Web UI and the CLI provide you options to choose and set a time zone of your choice.

Setting the time zone to your local time will apply the time zone variable to all the services that utilize the system timing. This impacts the logging information and is utilized in the following applications of the Cisco IMC:

- Fault summary and fault history logs
- Cisco IMC log
- rsyslog

When you set a local time, the timestamp on the applications that you can view are updated with the local time that you have chosen.

### Setting a Time Zone

#### Before You Begin

You must log in with user or admin privileges to perform this task.



**Procedure**

	<b>Command or Action</b>	<b>Purpose</b>
<b>Step 1</b>	Server # <b>scope time</b>	Enters time command mode.
<b>Step 2</b>	Server /time # <b>timezone-select</b>	Displays a list of continents and oceans.
<b>Step 3</b>	Enter the number corresponding to your continent or ocean.	A list of all the countries or regions of the chosen continent or ocean displays.
<b>Step 4</b>	Enter the number corresponding to the country or region that you want to set as your time zone.	If a country or a region has more than one time zones, a list of time zones in that country or region displays.
<b>Step 5</b>	Enter the number corresponding to time zone.	<b>Is the above information OK?</b> message appears.
<b>Step 6</b>	Enter <b>1</b> .	<b>Continue?[y/N]</b> : prompt appears.
<b>Step 7</b>	Enter <b>y</b> if you want to set the chosen time zone.	The chosen time zone is set as the time zone for your Cisco IMC server.

This example sets the time zone:

```
Server# scope time
Server /time # timezone-select
```

Please identify a location so that time zone rules can be set correctly.  
Please select a continent or ocean.

- 1) Africa
- 2) Americas
- 3) Antarctica
- 4) Arctic Ocean
- 5) Asia
- 6) Atlantic Ocean
- 7) Australia
- 8) Europe
- 9) Indian Ocean
- 10) Pacific Ocean

#? 2

Please select a country whose clocks agree with yours.

- 1) Anguilla
- 2) Antigua & Barbuda
- 3) Argentina
- 4) Aruba
- 5) Bahamas
- 6) Barbados
- 7) Belize
- 8) Bolivia
- 9) Brazil
- 10) Canada
- 11) Caribbean Netherlands
- 12) Cayman Islands
- 13) Chile
- 14) Colombia
- 15) Costa Rica
- 16) Cuba
- 17) Curacao
- 18) Dominica
- 19) Dominican Republic
- 20) Ecuador
- 21) El Salvador
- 22) French Guiana

- 23) Greenland
- 24) Grenada
- 25) Guadeloupe
- 26) Guatemala
- 27) Guyana
- 28) Haiti
- 29) Honduras
- 30) Jamaica
- 31) Martinique
- 32) Mexico
- 33) Montserrat
- 34) Nicaragua
- 35) Panama
- 36) Paraguay
- 37) Peru
- 38) Puerto Rico
- 39) St Barthelemy
- 40) St Kitts & Nevis
- 41) St Lucia
- 42) St Maarten (Dutch part)
- 43) St Martin (French part)
- 44) St Pierre & Miquelon
- 45) St Vincent
- 46) Suriname
- 47) Trinidad & Tobago
- 48) Turks & Caicos Is
- 49) United States
- 50) Uruguay
- 51) Venezuela
- 52) Virgin Islands (UK)
- 53) Virgin Islands (US)

#? 49

Please select one of the following time zone regions.

- 1) Eastern Time
- 2) Eastern Time - Michigan - most locations
- 3) Eastern Time - Kentucky - Louisville area
- 4) Eastern Time - Kentucky - Wayne County
- 5) Eastern Time - Indiana - most locations
- 6) Eastern Time - Indiana - Daviess, Dubois, Knox & Martin Counties
- 7) Eastern Time - Indiana - Pulaski County
- 8) Eastern Time - Indiana - Crawford County
- 9) Eastern Time - Indiana - Pike County
- 10) Eastern Time - Indiana - Switzerland County
- 11) Central Time
- 12) Central Time - Indiana - Perry County
- 13) Central Time - Indiana - Starke County
- 14) Central Time - Michigan - Dickinson, Gogebic, Iron & Menominee Counties
- 15) Central Time - North Dakota - Oliver County
- 16) Central Time - North Dakota - Morton County (except Mandan area)
- 17) Central Time - North Dakota - Mercer County
- 18) Mountain Time
- 19) Mountain Time - south Idaho & east Oregon
- 20) Mountain Standard Time - Arizona (except Navajo)
- 21) Pacific Time
- 22) Alaska Time
- 23) Alaska Time - Alaska panhandle
- 24) Alaska Time - southeast Alaska panhandle
- 25) Alaska Time - Alaska panhandle neck
- 26) Alaska Time - west Alaska
- 27) Aleutian Islands
- 28) Metlakatla Time - Annette Island
- 29) Hawaii

#? 8

The following information has been given:

United States  
Eastern Time - Indiana - Crawford County

Is the above information OK?

- 1) Yes
- 2) No

#? 1

```
You have chosen to set timezone settings to:

        America/Indiana/Marengo

Continue?[y|N]: y
Timezone has been updated.
The local time now is: Wed Jul 1 02:21:15 2015 EST

Server /time #
```

# Managing Dynamic Storage

## Dynamic Storage Support

Effective with this release, The Cisco UCS C-Series rack-mount servers support dynamic storage of Serial Attached SCSI (SAS) drives in the Cisco Management Controller (CMC). This dynamic storage support is provided by the SAS fabric manager located in the CMC.

The fabric manager interacts with the PMC SAS expanders over an Out-of-Band ethernet connection. SAS Expanders allow you to maximize the storage capability of an SAS controller card. Using these expanders, you can employ SAS controllers support up to 60 hard drives. In CMC, an active SIOC configures the expander zoning, where you can assign the drives to the server nodes through the Web UI, command line interface or Cisco UCS Manager. The standby CMC is updated with the current state, so during a CMC fail-over standby, the CMC can take over the zoning responsibilities. Once the drives are visible to a particular server node, you can manage these using RAID controller.

**Note**

---

The SAS controller support 56 hard disk drives (HDD) by default. There is also a provision to replace Server node 2 with an additional four HDDs on Server 2. In that case the total number of HDDs shown in the Zoning page is 60. However, CMC would not support zoning for the additional HDDs 57, 58, 59, 60.

---

The SAS fabric manager provides an API library for other processes to configure and monitor the expanders and drives. Configuration of the fabric involves zoning the drives, updating the firmware for expanders and drives.

Dynamic Storage supports the following options:

- Assigning physical disks to server 1 and server 2
- Chassis Wide Hot Spare (supported only on RAID controllers)
- Shared mode (supported only in HBAs)
- Unassigning physical disks

## Viewing SAS Expander Properties

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>show sas-expander</b>	Displays the SAS expander properties.
<b>Step 3</b>	Server /chassis # <b>show sas-expander detail</b>	Displays detailed SAS expander properties.
<b>Step 4</b>	Server /chassis # <b>scope sas-expander sas expander ID</b>	Enters SAS expander mode.
<b>Step 5</b>	Server /chassis/sas-expander # <b>show detail</b>	Displays the properties of the chosen SAS expander.

This example displays the SAS expander properties:

```

Server# scope chassis
Server /chassis # show sas-expander
ID      Name      Update Stage Update Progress Current FW Version
-----
1       SASEXP1    NONE          100           04.08.01_B055
2       SASEXP2    NONE          100           04.08.01_B055

Server /chassis # show sas-expander detail
Firmware Image Information:
  ID: 1
  Name: SASEXP1
  Update Stage: NONE
  Update Progress: 100
  Current FW Version: 04.08.01_B056
  FW Image 1 Version: 04.08.01_B056
  FW Image 1 State: RUNNING ACTIVATED
  FW Image 2 Version: 04.08.01_B056
  FW Image 2 State: BACKUP INACTIVATED
Firmware Image Information:
  ID: 2
  Name: SASEXP2
  Update Stage: NONE
  Update Progress: 100
  Current FW Version: 04.08.01_B056
  FW Image 1 Version: 04.08.01_B056
  FW Image 1 State: RUNNING ACTIVATED
  FW Image 2 Version: 04.08.01_B056
  FW Image 2 State: BACKUP INACTIVATED

Server /chassis # scope sas-expander 1
Server /chassis/sas-expander # show detail
Firmware Image Information:
  ID: 1
  Name: SASEXP1
  Update Stage: NONE
  Update Progress: 100
  Current FW Version: 04.08.01_B056
  FW Image 1 Version: 04.08.01_B056
  FW Image 1 State: RUNNING ACTIVATED
  FW Image 2 Version: 04.08.01_B056
  FW Image 2 State: BACKUP INACTIVATED

```

```
Server /chassis/sas-expander #
```

## Viewing Dynamic Storage and Physical Drive Details

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>show dynamic-storage</b>	Displays the physical drives and the servers they are assigned to.
<b>Step 3</b>	Server /chassis/dynamic-storage # <b>scope dynamic-storage</b>	Enters dynamic storage command mode.
<b>Step 4</b>	Server /chassis/dynamic-storage # <b>show physical-drive</b>	Displays the physical drive properties.
<b>Step 5</b>	Server /chassis/dynamic-storage # <b>show physical-drive-fw</b>	Displays the firmware of the physical drives.
<b>Step 6</b>	Server /chassis/dynamic-storage # <b>show physical-drive-link</b>	Displays the links of the physical drives.
<b>Step 7</b>	Server /chassis/dynamic-storage # <b>show physical-slot-owner</b>	Displays the physical drives association with the servers.

This example displays the dynamic storage properties:

```
Server# scope chassis
Server /chassis # show dynamic-storage
Slot Ownership
-----
1    server1
2    server1
3    server1
4    server1
5    server1
6    server1
7    server1
8    server1
9    server1
.
.
Server /chassis # scope dynamic-storage
Server /chassis/dynamic-storage # show detail
Slot 1:
  Ownership: server1
Slot 2:
  Ownership: server1
Slot 3:
  Ownership: server1
Slot 4:
  Ownership: server1
Slot 5:
  Ownership: server1
Slot 6:
  Ownership: server1
```

## Viewing Dynamic Storage and Physical Drive Details

```
Slot 7:
  Ownership: server1
Slot 8:
.
.
.
```

```
Server /chassis/dynamic-storage # show physical-drive
-----
```

Slot	Ownership	Health	Vendor	Product ID	Size	Serial Number
1	server1	good	TOSHIBA	MG03SCA400	3.63 TB	94E0A0T9FVU4
2	server1	good	TOSHIBA	MG03SCA400	3.63 TB	94D0A0F7FVU4
3	server1	good	TOSHIBA	MG03SCA400	3.63 TB	94B0A12YFVU4
4	server1	good	TOSHIBA	MG03SCA400	3.63 TB	94B0A131FVU4
5	server1	good	TOSHIBA	MG03SCA400	3.63 TB	94C0A0I9FVU4
6	server1	good	TOSHIBA	MG03SCA400	3.63 TB	94B0A12ZFVU4
7	server1	good	TOSHIBA	MG03SCA400	3.63 TB	94B0A02AFVU4
8	server1	good	TOSHIBA	MG03SCA400	3.63 TB	94B0A00LFVU4
9	server1	good	TOSHIBA	MG03SCA400	3.63 TB	94B0A00WFVU4
10	server1	good	TOSHIBA	MG03SCA400	3.63 TB	94B0A00QFVU4
11	server1	good	TOSHIBA	MG03SCA400	3.63 TB	94B0A00MFVU4
12	server1	good	TOSHIBA	MG03SCA400	3.63 TB	94B0A00NFVU4
13	server1	good	TOSHIBA	MG03SCA400	3.63 TB	94B0A130FVU4
14	server1	good	TOSHIBA	MG03SCA400	3.63 TB	94B0A000FVU4

```
Server /chassis/dynamic-storage # show physical-drive-fw
-----
```

Slot	Vendor	Product ID	Current_FW	Update Stage	Update Progress
1	TOSHIBA	MG03SCA400	5702	NONE	0
2	TOSHIBA	MG03SCA400	5702	NONE	0
3	TOSHIBA	MG03SCA400	5702	NONE	0
4	TOSHIBA	MG03SCA400	5702	NONE	0
5	TOSHIBA	MG03SCA400	5702	NONE	0
6	TOSHIBA	MG03SCA400	5702	NONE	0
7	TOSHIBA	MG03SCA400	5702	NONE	0
8	TOSHIBA	MG03SCA400	5702	NONE	0
9	TOSHIBA	MG03SCA400	5702	NONE	0
10	TOSHIBA	MG03SCA400	5702	NONE	0
11	TOSHIBA	MG03SCA400	5702	NONE	0
12	TOSHIBA	MG03SCA400	5702	NONE	0
13	TOSHIBA	MG03SCA400	5702	NONE	0
14	TOSHIBA	MG03SCA400	5702	NONE	0

```
Server /chassis/dynamic-storage # show physical-drive-link
-----
```

Slot	Ownership	EX1 Link	EX2 Link	SAS Address 1	SAS Address 2
1	server1	6.0 Gb	6.0 Gb	50000395c8d2a1fe	50000395c8d2a1ff
2	server1	6.0 Gb	6.0 Gb	50000395c8d1f6de	50000395c8d1f6df
3	server1	6.0 Gb	6.0 Gb	50000395c8d0e93a	50000395c8d0e93b
4	server1	6.0 Gb	6.0 Gb	50000395c8d0e946	50000395c8d0e947
5	server1	6.0 Gb	6.0 Gb	50000395c8d17d2e	50000395c8d17d2f
6	server1	6.0 Gb	6.0 Gb	50000395c8d0e93e	50000395c8d0e93f
7	server1	6.0 Gb	6.0 Gb	50000395c8d09ace	50000395c8d09acf
8	server1	6.0 Gb	6.0 Gb	50000395c8d099ce	50000395c8d099cf
9	server1	6.0 Gb	6.0 Gb	50000395c8d099fa	50000395c8d099fb
10	server1	6.0 Gb	6.0 Gb	50000395c8d099e2	50000395c8d099e3
11	server1	6.0 Gb	6.0 Gb	50000395c8d099d2	50000395c8d099d3
12	server1	6.0 Gb	6.0 Gb	50000395c8d099d6	50000395c8d099d7
13	server1	6.0 Gb	6.0 Gb	50000395c8d0e942	50000395c8d0e943
14	server1	6.0 Gb	6.0 Gb	50000395c8d099da	50000395c8d099db

```
Server /chassis/dynamic-storage # show physical-slot-owner
-----
```

Slot	Ownership
1	server1
2	server1
3	server1
4	server1
5	hotspare
6	server1
7	server1
8	server1

```

9     server1
10    server1
.
.
.
Server /chassis/dynamic-storage #
    
```

## Managing Physical Drives

### Assigning Physical Drives to Servers

#### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis/dynamic-storage # <b>scope dynamic-storage</b>	Enters dynamic storage command mode.
<b>Step 3</b>	Server /chassis/dynamic-storage # <b>assign-drive server ID&lt;drive-slotid-list&gt;</b>	Assigns the chosen physical drive to the server.

Example for assigning a physical drive to the servers:

```

Server# scope chassis
Server /chassis # scope dynamic-storage
svbu-huu-sanity-col2-1-vcmc /chassis/dynamic-storage # assign-drive server2 27
Are you sure you want to assign drives 27 to server2
Enter 'yes' to confirm -> yes
assign-drive operation successful.

Server /chassis/dynamic-storage #
    
```

### Unassigning Physical Drives to Servers

#### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>show dynamic-storage</b>	Displays the physical drives and the servers they are assigned to servers.
<b>Step 3</b>	Server /chassis/dynamic-storage # <b>scope dynamic-storage</b>	Enters dynamic storage command mode.
<b>Step 4</b>	Server /chassis/dynamic-storage # <b>unassign-drive &lt;drive-slotid-list&gt;</b>	Unassign the chosen physical drive.

This example unassigning a physical drive:

```
Server# scope chassis
Server /chassis # scope dynamic-storage
Server /chassis/dynamic-storage # unassign-drive 27
Are you sure you want to unassign drives 27
Host will loose access to drive(s). Enter 'yes' to confirm -> yes
unassign-drive operation successful.

Server /chassis/dynamic-storage #
```

## Assigning Physical Drives as Chassis Wide Hot Spare

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis/dynamic-storage # <b>scope dynamic-storage</b>	Enters dynamic storage command mode.
<b>Step 3</b>	Server /chassis/dynamic-storage # <b>assign-drive hotspare &lt;drive-slotid-list&gt;</b>	Assigns the physical drive as a global hotspare at the chassis level.

Example for assigning a physical drive as a global hotspare at the chassis level:

```
Server# scope chassis
Server /chassis # scope dynamic-storage
Server /chassis/dynamic-storage # assign-drive hotspare 5
Are you sure you want to assign drives 5 as hotspare
Enter 'yes' to confirm -> yes
assign-drive operation successful.

Server /chassis/dynamic-storage #
```

## Sharing Physical Drives with Servers

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis/dynamic-storage # <b>scope dynamic-storage</b>	Enters dynamic storage command mode.
<b>Step 3</b>	Server /chassis/dynamic-storage # <b>assign-drive shared &lt;drive-slotid-list&gt;</b>	Assigns the chosen physical drive for both the servers.



Example for assigning the same physical drive for both the servers:

```
Server# scope chassis
Server /chassis # scope dynamic-storage
svbu-huu-sanity-col2-1-vcmc /chassis/dynamic-storage # assign-drive shared 4
Are you sure you want to assign drives 4 as shared
Enter 'yes' to confirm -> yes
assign-drive operation successful.

Server /chassis/dynamic-storage #
```

## Managing SAS Expander and HDD Firmware

### Updating and Activating SAS Expander Firmware

**Procedure**

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope sas-expandersas expander ID</b>	Enters SAS expander mode.
<b>Step 3</b>	Server /chassis/sas-expander # <b>update protocol IP Address path</b>	<p>Initiates the firmware update by specifying the protocol, IP address of the remote server, and the file path to the firmware file on the server. The protocol can be one of the following:</p> <ul style="list-style-type: none"> <li>• TFTP</li> <li>• FTP</li> <li>• SFTP</li> <li>• SCP</li> <li>• HTTP</li> </ul> <p><b>Note</b> The Cisco UCS C-Series server now supports fingerprint confirmation of the server when you update firmware through a remote server. This option is available only if you choose SCP or SFTP as the remote server type.</p> <p>If you chose SCP or SFTP as the remote server type while performing this action, a prompt with the message Server (RSA) key fingerprint is &lt;server_finger_print_ID&gt; Do you wish to continue? Click y or n depending on the authenticity of the server fingerprint.</p> <p>The fingerprint is based on the host's public key and helps you to identify or verify the host you are connecting to.</p>

	Command or Action	Purpose
<b>Step 4</b>	Server /chassis/sas-expander # <b>show detail</b>	(Optional) Displays the status of the firmware upgrade.

This example shows how to update and activate the SAS expander firmware:

```
Server# scope chassis
Server /chassis # scope sas-expander 1
Updating the firmware
Server /chassis/sas-expander# update tftp 10.10.10.10 /tftpboot/skasargo/<firmware file>
updating the firmware.
Checking the status of the upgrade
Server /chassis/sas-expander# show detail
Firmware Image Information:
  ID: 1
  Name: SASEXP1
  Update Stage: In Progress
  Update Progress: 25
  Current FW Version: 04.08.01_B056
  FW Image 1 Version: 04.08.01_B056
  FW Image 1 State: RUNNING ACTIVATED
  FW Image 2 Version: 04.08.01_B056
  FW Image 2 State: BACKUP INACTIVATED

Activating the firmware
svbu-huu-sanity-col2-1-vmc /chassis/sas-expander # activate
This operation will activate backup firmware and reboot the SAS-Expander.
Continue?[y|N]y

Server /chassis/sas-expander #
```

## Updating HDD Firmware

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis/dynamic-storage # <b>scope dynamic-storage</b>	Enters dynamic storage command mode.
<b>Step 3</b>	Server /chassis/dynamic-storage # <b>update-drive protocol IP</b> <i>Address path HDD slot-ids</i>	Specifies the protocol, IP address of the remote server, and the file path to the firmware file on the server. The protocol can be one of the following: <ul style="list-style-type: none"> <li>• TFTP</li> <li>• FTP</li> <li>• SFTP</li> <li>• SCP</li> <li>• HTTP</li> </ul>

	Command or Action	Purpose
		<p><b>Note</b> The Cisco UCS C-Series server now supports fingerprint confirmation of the server when you update firmware through a remote server. This option is available only if you choose SCP or SFTP as the remote server type.</p> <p>If you chose SCP or SFTP as the remote server type while performing this action, a prompt with the message Server (RSA) key fingerprint is &lt;server_finger_print_ID&gt; Do you wish to continue? Click y or n depending on the authenticity of the server fingerprint.</p> <p>The fingerprint is based on the host's public key and helps you to identify or verify the host you are connecting to.</p> <p><b>Note</b> You can update firmware for multiple servers from the same vendor.</p>
<b>Step 4</b>	Server /chassis/dynamic-storage # <b>show physical-drive-fw</b>	(Optional) Displays the status of the firmware upgrade.

This example provides steps to update the HDD firmware:

```

Server# scope chassis
Server /chassis # scope dynamic-storage
Updating for a single HDD
Server /chassis/dynamic-storage #update-drive tftp 10.10.10.10 /tftpboot/skasargo/sg4.1od
14
updating FW for slot 1 HDD
Updating for Multiple HDD
Server /chassis/dynamic-storage#update-drive tftp 10.10.10.10 /tftpboot/skasargo/sg4.1od
1-14
updating fw for multiple HDDs
Viewing the Status of the Upgrade
Server /chassis/dynamic-storage# show physical-drive-fw

Slot  Vendor      Product ID      Current_FW  Update Stage  Update Progress
-----
1      TOSHIBA      MG03SCA400     5702       Progress     25
2      TOSHIBA      MG03SCA400     5702       NONE         0
3      TOSHIBA      MG03SCA400     5702       NONE         0
4      TOSHIBA      MG03SCA400     5702       NONE         0
5      TOSHIBA      MG03SCA400     5702       NONE         0
6      TOSHIBA      MG03SCA400     5702       NONE         0
7      TOSHIBA      MG03SCA400     5702       NONE         0
8      TOSHIBA      MG03SCA400     5702       NONE         0
9      TOSHIBA      MG03SCA400     5702       NONE         0
10     TOSHIBA      MG03SCA400     5702       NONE         0
11     TOSHIBA      MG03SCA400     5702       NONE         0
12     TOSHIBA      MG03SCA400     5702       NONE         0
13     TOSHIBA      MG03SCA400     5702       NONE         0
14     TOSHIBA      MG03SCA400     5702       NONE         0
Server /chassis/dynamic-storage #
    
```





# CHAPTER 4

## Managing the Server

This chapter includes the following sections:

- [Toggling the Server Locator LED, page 37](#)
- [Toggling the Locator LED for a Hard Drive, page 38](#)
- [Managing the Server Boot Order, page 39](#)
- [Managing Server Power, page 49](#)
- [Resetting the Server, page 63](#)
- [Shutting Down the Server, page 64](#)
- [Configuring DIMM Black Listing, page 65](#)
- [Configuring BIOS Settings, page 66](#)
- [Viewing Product ID \(PID\) Catalog Details, page 71](#)
- [Uploading and Activating PID Catalog, page 72](#)

## Toggling the Server Locator LED

### Before You Begin

You must log in with user or admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server server ID</b>	Enters server command mode.
<b>Step 2</b>	Server /server # <b>set locator-led {on   off}</b>	Enables or disables the server locator LED.
<b>Step 3</b>	Server /server # <b>commit</b>	Commits the transaction to the system configuration.

This example disables the server locator LED and commits the transaction:

```
Server# scope server 1
Server /server # set locator-led off
Server /server *# commit

Server /server #
```

## Toggling the Locator LED for a Hard Drive

### Before You Begin

You must log in with user or admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /server # <b>scope sensor</b>	Enters sensor command.
<b>Step 3</b>	Server /server/sensor # <b>scope hdd</b>	Enters hard disk drive (HDD) command mode.
<b>Step 4</b>	Server /server/sensor/hdd # <b>set locateHDD</b> <i>drivenum</i> {1   2}	Where <i>drivenum</i> is the number of the hard drive whose locator LED you want to set. A value of 1 turns the LED on while a value of 2 turns the LED off.

This example turns on the locator LED on HDD 2:

```
Server# scope server 1
Server /server # scope sensor
Server /server/sensor # scope hdd
Server /server/sensor/hdd # locateHDD 2 1
HDD Locate LED Status changed to 1
Server /server/sensor/hdd # show
Name                               Status                               LocateLEDStatus
-----
HDD1_STATUS                         present                             TurnOFF
HDD2_STATUS                         present                             TurnON
HDD3_STATUS                         absent                              TurnOFF
HDD4_STATUS                         absent                              TurnOFF

Server /server/sensor/hdd #
```

# Managing the Server Boot Order

## Server Boot Order

Using Cisco IMC, you can configure the order in which the server attempts to boot from available boot device types. In the legacy boot order configuration, Cisco IMC allows you to reorder the device types but not the devices within the device types. With the precision boot order configuration, you can have a linear ordering of the devices. In the web UI or CLI you can change the boot order and boot mode, add multiple devices under each device types, rearrange the boot order, set parameters for each device type.

When you change the boot order configuration, Cisco IMC sends the configured boot order to BIOS the next time that server is rebooted. To implement the new boot order, reboot the server after you make the configuration change. The new boot order takes effect on any subsequent reboot. The configured boot order remains until the configuration is changed again in Cisco IMC or in the BIOS setup.

**Note**

The actual boot order differs from the configured boot order if either of the following conditions occur:

- BIOS encounters issues while trying to boot using the configured boot order.
- A user changes the boot order directly through BIOS.
- BIOS appends devices that are seen by the host but are not configured from the user.

**Note**

When you create a new policy using the configure boot order feature, BIOS tries to map this new policy to the devices in the system. It displays the actual device name and the policy name to which it is mapped in the **Actual Boot Order** area. If BIOS cannot map any device to a particular policy in Cisco IMC, the actual device name is stated as **NonPolicyTarget** in the **Actual Boot Order** area.

**Note**

When you upgrade Cisco IMC to the latest version 2.0(x) for the first time, the legacy boot order is migrated to the precision boot order. During this process, previous boot order configuration is erased and all device types configured before updating to 2.0 version are converted to corresponding precision boot device types and some dummy devices are created for the same device types. you can view these devices in the **Configured Boot Order** area in the web UI. To view these devices in the CLI, enter **show boot-device** command. During this the server's actual boot order is retained and it can be viewed under actual boot order option in web UI and CLI.

When you downgrade Cisco IMC prior to 2.0(x) version the server's last legacy boot order is retained, and the same can be viewed under **Actual Boot Order** area. For example:

- If you configured the server in a legacy boot order in 2.0(x) version, upon downgrade a legacy boot order configuration is retained.
- If you configured the server in a precision boot order in 2.0(x), upon downgrade the last configured legacy boot order is retained.

**Important**

- C3260 M4 servers support both Legacy and Precision Boot order configuration through Web UI and CLI.
- Boot order configuration prior to 2.0(x) is referred as legacy boot order. If your running version is 2.0(x), then you cannot configure legacy boot order through web UI, but you can configure through CLI and XML API. In the CLI, you can configure it by using **set boot-order HDD,PXE** command. Even though, you can configure legacy boot order through CLI or XML API, in the web UI this configured boot order is not displayed.
- Legacy and precision boot order features are mutually exclusive. You can configure either legacy or precision boot order. If you configure legacy boot order, it disables all the precision boot devices configured. If you configure precision boot order, then it erases legacy boot order configuration.

## Viewing the Boot Device Detail

**Note**

Do not change the boot order while the host is performing BIOS power-on self test (POST).

### Before You Begin

You must log in with user or admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /server# <b>scope bios</b>	Enters BIOS command mode.
<b>Step 3</b>	Server /serve/bios # <b>show boot-device [detail]</b> .	Displays the detailed information of the boot devices.

This example displays the details of the created bootable devices:

```
Server# scope server 1
Server /server # scope bios
Server /server/bios # show boot-device
Boot Device          Device Type  Device State  Device Order
-----
TestUSB              USB         Enabled       1
TestPXE              PXE         Enabled       2
Server /server/bios # show boot-device detail
Boot Device TestSAN:
  Device Type: SAN
  Device State: Enabled
  Device Order: 1
  Slot Id:
  Lun Id:
Boot Device TestUSB:
  Device Type: USB
  Device State: Enabled
```



```

Device Order: 2
Sub Type: HDD
Boot Device TestPXE:
Device Type: PXE
Device State: Enabled
Device Order: 3
Slot Id: L
Port Number: 1
    
```

## Configuring the Precision Boot Order



**Note** Do not change the boot order while the host is performing BIOS power-on self test (POST).

### Before You Begin

You must log in with user or admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /server# <b>scope bios</b>	Enters BIOS command mode.
<b>Step 3</b>	Server /server/bios # <b>create-boot-device</b> [ <i>device name</i> ] [ <i>device type</i> ].	Creates a bootable device that BIOS chooses to boot. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>HDD</b>—Hard disk drive</li> <li>• <b>PXE</b>—PXE boot</li> <li>• <b>SAN</b> boot</li> <li>• <b>iSCSI</b> boot</li> <li>• <b>USB</b></li> <li>• <b>Virtual Media</b></li> <li>• <b>PCHStorage</b></li> <li>• <b>UEFISHELL</b></li> </ul>
<b>Step 4</b>	Server /server/bios # <b>scope boot-device</b> <i>created boot device name</i> .	Enters the management of the created bootable devices.
<b>Step 5</b>	Server /server/bios/boot-device # <b>set values</b>	Specifies the property values for particular bootable device. You can set one or more of the following: <ul style="list-style-type: none"> <li>• <b>cli</b>— CLI options</li> <li>• <b>state</b>— Whether the device will be visible by BIOS. By default the device is disabled.</li> </ul>

	Command or Action	Purpose
		<p><b>Note</b> If enabled, the device will overwrite the legacy boot order configuration.</p> <ul style="list-style-type: none"> <li>• slot— Slot id where the device is plugged in.</li> <li>• port— Port of the slot in which the device is present.</li> <li>• LUN— Logical unit in a slot where the device is present.</li> <li>• sub-type—Sub device type under a certain device type.</li> <li>• order—The order of the device in the available list of devices.</li> </ul>
<b>Step 6</b>	Server /server/bios /boot-device # <b>commit</b>	Commits the transaction to the system configuration.

This example configures the boot order, creates a boot device, set the attributes of the new device and commit the transaction:

```

Server# scope server 1
Server /server # scope bios
Server /server/bios # create boot-device TestPXE PXE
Server /server/bios # scope boot-device TestPXE
Server /server/bios /boot-device # set state Enabled
Server /server/bios /boot-device # set slot L
Server /server/bios /boot-device # set port 1
Server /server/server/bios /boot-device # set order 1
Server /bios /boot-device # commit
Enabling boot device will overwrite Legacy Boot Order configuration
Continue?[y|N]y
Server /server/bios /boot-device # y
Committing device configuration
Server /server/bios/boot-device # show detail
BBIOS:
  BIOS Version: C3X60M3.2.0.7c.0.071620151216
  Backup BIOS Version: C3X60M3.2.0.7c.0.071620151216
  Boot Order: (none)
  Boot Override Priority:
  FW Update/Recovery Status: None, OK
  UEFI Secure Boot: disabled
  Configured Boot Mode: Legacy
  Actual Boot Mode: Legacy
  Last Configured Boot Order Source: CIMC

Server /server/bios/boot-device # show boot-device detail
Boot Device TestPXE:
  Device Type: PXE
  Device State: Enabled
  Device Order: 1
  Slot Id: L
  Port Number: 1

```

## What to Do Next

Reboot the server to boot with your new boot order.

# Modifying the Attributes of a Boot Device



**Note** Do not change the boot order while the host is performing BIOS power-on self test (POST).

### Before You Begin

You must log in with user or admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /server# <b>scope bios</b>	Enters BIOS command mode.
<b>Step 3</b>	Server /server/bios # <b>scope boot-device</b> <i>created boot device name</i> .	Enters the management of the created bootable devices.
<b>Step 4</b>	Server /server/bios /boot-device # <b>set state</b> { <i>Enabled</i>   <i>Disabled</i> }.	Enables or disables the device. The default state is disabled. <b>Note</b> If enabled, the device will overwrite the legacy boot order configuration.
<b>Step 5</b>	Server /server/bios /boot-device* # <b>set order</b> { <i>Index</i>   1-50}.	Specifies the order of booting for particular device in the device list. Enter a number between 1 and 50 based on the total number of created device. <b>Note</b> When you set the boot device order individually, it is not assured that the order appears in the way it was set. So, it is recommended that to set the order for multiple devices in a single execution, use <b>re-arrange-boot-device</b> command.
<b>Step 6</b>	Server /server/bios /boot-device* # <b>set port</b> { <i>value</i>   1-255}.	Specifies the port of the slot in which the device is present. Enter a number between 1 and 255.
<b>Step 7</b>	Server /server/bios /boot-device* # <b>commit</b>	Commits the transaction to the system configuration.

This example modifies the attributes of an existing device:

```
Server# scope server 1
Server /server # scope bios
Server /server/bios *# scope boot-device scu-device-hdd
Server /server/bios/boot-device # set status enabled
Server /server/bios/boot-device *# set order 2
Server /server/bios/boot-device *# set port 1
Server /server/bios/boot-device *# commit
Enabling boot device will overwrite boot order Level 1 configuration
Continue?[y|N]y
Server /server/bios/boot-device #
```

## Rearranging Device Boot Order



**Note** Do not change the boot order while the host is performing BIOS power-on self test (POST).

### Before You Begin

You must log in with user or admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /server# <b>scope bios</b>	Enters BIOS command mode.
<b>Step 3</b>	Server /server/bios # <b>rearrange boot-device</b> [ <i>device name</i> ]:[ <i>position</i> ].	Rearranges the selected boot devices in a single execution.

This example rearranges the selected boot devices:

```
Server# scope server 1
Server /server # scope bios
Server /server/bios # rearrange-boot-device TestPXE:1,TestUSB:2
Server /server/bios # show boot-device
-----
Boot Device          Device Type  Device State  Device Order
-----
TestPXE              PXE         Disabled      1
TestUSB              USB         Disabled      2
-----
Server /server/bios #
```

## Reapplying Boot Order Configuration



**Note** Do not change the boot order while the host is performing BIOS power-on self test (POST).

### Before You Begin

You must log in with user or admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.

	Command or Action	Purpose
<b>Step 2</b>	Server /server# <b>scope bios</b>	Enters BIOS command mode.
<b>Step 3</b>	Server /server/bios # <b>re-apply</b> .	Re-applies the boot order to BIOS, if the last configured boot order source is BIOS..

This example reapplies the boot order to BIOS:

```
Server# scope server 1
Server /server # scope bios
Server /server/bios # re-apply
Server /server/bios #
```

**What to Do Next**

Reboot the host after reapplying the boot order to BIOS.

## Deleting an Existing Boot Device



**Note** Do not change the boot order while the host is performing BIOS power-on self test (POST).

**Before You Begin**

You must log in with user or admin privileges to perform this task.

**Procedure**

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server {1   2}</b>	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /server# <b>scope bios</b>	Enters BIOS command mode.
<b>Step 3</b>	Server /server/bios # <b>remove-boot-device</b> <i>device name</i>	Deletes the particular device from the boot order.

This example deletes the selected device from the device list:

```
Server# scope server 1
Server /server # scope bios
Server /server/bios # remove-boot-device scu-device-hdd
Server /server/bios #
```

## Overview to UEFI Secure Boot

You can use Unified Extensible Firmware Interface (UEFI) secure boot to ensure that all the EFI drivers, EFI applications, option ROM or operating systems prior to loading and execution are signed and verified for authenticity and integrity, before you load and execute the operating system. You can enable this option using either web UI or CLI. When you enable UEFI secure boot mode, the boot mode is set to UEFI mode and you cannot modify the configured boot mode until the UEFI boot mode is disabled.



### Note

If you enable UEFI secure boot on a nonsupported OS, on the next reboot, you cannot boot from that particular OS. If you try to boot from the previous OS, an error is reported and recorded the under system software event in the web UI. You must disable the UEFI secure boot option using Cisco IMC to boot from your previous OS.



### Important

Also, if you use an unsupported adapter, an error log event in Cisco IMC SEL is recorded. The error messages is displayed that says:

System Software event: Post sensor, System Firmware error. EFI Load Image Security Violation. [0x5302] was asserted .

UEFI secure boot is supported on the following components:

Components	Types
Supported OS	<ul style="list-style-type: none"> <li>• Windows Server 2012</li> <li>• Windows Server 2012 R2</li> </ul>
QLogic PCI adapters	<ul style="list-style-type: none"> <li>• 8362 dual port adapter</li> <li>• 2672 dual port adapter</li> </ul>
Fusion-io	

Components	Types
LSI	<ul style="list-style-type: none"> <li>• LSI MegaRAID SAS 9240-8i</li> <li>• LSI MegaRAID SAS 9220-8i</li> <li>• LSI MegaRAID SAS 9265CV-8i</li> <li>• LSI MegaRAID SAS 9285CV-8e</li> <li>• LSI MegaRAID SAS 9285CV-8e</li> <li>• LSI MegaRAID SAS 9266-8i</li> <li>• LSI SAS2008-8i mezz</li> <li>• LSI Nytro card</li> <li>• RAID controller for UCS C3X60 Storage (SLOT-MEZZ)</li> <li>• Host Bus Adapter (HBA)</li> </ul>

## Enabling or Disabling UEFI Secure Boot Mode

### Before You Begin

You must be logged in as admin to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /server# <b>scope bios</b>	Enters BIOS command mode.
<b>Step 3</b>	Server /server/bios # <b>set secure-boot</b> { <b>enable</b>   <b>disable</b> }	Enables or disables UEFI secure boot.  <b>Note</b> If enabled, the boot mode is set to UEFI secure mode. You cannot modify configure boot mode until UEFI secure boot mode is disabled.
<b>Step 4</b>	Server /server/bios # <b>show detail</b>	(Optional) Displays the details of the BIOS settings.

The following examples show how to enable or disable secure boot and commit the transaction:

```
Server# scope server 1
Server /server # scope bios
Server /server/bios # set secure-boot enable
Setting Value : enable
Commit Pending.
```

```

Server /server/bios *# commit
UEFI Secure boot state changed successfully. Execute 'show detail' command to check the
current status
Server /server/bios # show detail
BIOS:
  BIOS Version: C3X60M3.2.0.7c.0.071620151216
  Backup BIOS Version: C3X60M3.2.0.8.0.071620152203
  Boot Order: (none)
  Boot Override Priority:
  FW Update/Recovery Status: None, OK
  UEFI Secure Boot: enabled
  Configured Boot Mode: Legacy
  Actual Boot Mode: Legacy
  Last Configured Boot Order Source: CIMC
Server /server/bios #
Server /server/bios #
erver# scope server 1
Server /server # scope bios
Server /server/bios # set secure-boot disable
Setting Value : disable
Commit Pending.
Server /server/bios *# commit
UEFI Secure boot state changed successfully. Execute 'show detail' command to check the
current status
Server /server/bios # show detail
BIOS:
  BIOS Version: C3X60M3.2.0.7c.0.071620151216
  Backup BIOS Version: C3X60M3.2.0.8.0.071620152203
  Boot Order: (none)
  Boot Override Priority:
  FW Update/Recovery Status: None, OK
  UEFI Secure Boot: disabled
  Configured Boot Mode: Legacy
  Actual Boot Mode: Legacy
  Last Configured Boot Order Source: CIMC
Server /server/bios #

```

### What to Do Next

Reboot the server to have your configuration boot mode settings take place.

## Viewing the Actual Server Boot Order

The actual server boot order is the boot order actually used by the BIOS when the server last booted. The actual boot order can differ from the boot order configured in Cisco IMC.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /server# <b>scope bios</b>	Enters BIOS command mode.
<b>Step 3</b>	Server /server/bios # <b>show actual-boot-order [detail]</b>	Displays the boot order actually used by the BIOS when the server last booted.

This example displays the actual boot order of the legacy boot order from the last boot:

```

Server# scope server 1
Server /server # scope bios
Server /server/bios # show actual-boot-order

```



```

Boot Order  Boot Device                                     Device Type  Boot Policy
-----
1           Cisco CIMC-Mapped vDVD1.22                          VMEDIA      NIHUUCIMCDVD
2           Cisco vKVM-Mapped vDVD1.22                          VMEDIA      dvd
3           Cisco vKVM-Mapped vHDD1.22                          VMEDIA      dvd2
4           Cisco CIMC-Mapped vHDD1.22                          VMEDIA      dvd3
5           (Bus 14 Dev 00) PCI RAID Adapter                    HDD         NonPolicyTarget
6           "P1: INTEL SSDSC2BB120G4 " "                          PCHSTORAGE NonPolicyTarget
7           "UEFI: Built-in EFI Shell " "                       EFI         NonPolicyTarget
8           "P0: INTEL SSDSC2BB120G4 " "                          PCHSTORAGE NonPolicyTarget
9           Cisco vKVM-Mapped vFDD1.22                      VMEDIA      NonPolicyTarget

Server /server/bios #
    
```

# Managing Server Power

## Powering On the Server



**Note** If the server was powered off other than through the Cisco IMC, the server will not become active immediately when powered on. In this case, the server will enter standby mode until the Cisco IMC completes initialization.



**Important** If any firmware or BIOS updates are in progress, do not change the server power until those tasks are complete.

### Before You Begin

You must log in with user or admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server {1   2}</b>	Enters server command mode of server 1 or 2.
<b>Step 3</b>	Server /chassis/server # <b>power on</b>	Powers on the server.
<b>Step 4</b>	At the prompt, enter y to confirm.	Power on the server.

This example shows how to power on the server:

```

Server# scope chassis
Server# /chassis scope server 1
Server /chassis/server # power on
This operation will change the server's power state.
Do you want to continue with power control for Server 1 ?[y|N] y
    
```

```

Server /chassis/server # show
Server ID Power Serial Number Product Name PID UUID
-----
1 On FCH1848794D UCS C3160 UCSC-C3X60-SVRNB
60974271-A514-484C-BAE3-A5EE4FD16E06

Server /chassis/server#

```

## Powering Off the Server



**Important** If any firmware or BIOS updates are in progress, do not change the server power until those tasks are complete.

### Before You Begin

You must log in with user or admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server 1</b>	Enters the server command mode.
<b>Step 3</b>	Server /chassis/server # <b>power off</b>	Powers off the server.
<b>Step 4</b>	At the prompt, enter y to confirm.	Power off the server.

This example shows how to power off the server:

```

Server# scope chassis
Server# /chassis scope server 1
Server /chassis/server # power off
This operation will change the server's power state.
Do you want to continue with power control for Server 1 ?[y|N] y

Server /chassis/server # show
Server ID Power Serial Number Product Name PID UUID
-----
1 Off FCH1848794D UCS C3x60 UCSC-C3X60-SVRNB
60974271-A514-484C-BAE3-A5EE4FD16E06

Server /chassis/server#

```

# Powering Cycling the Server



**Important** If any firmware or BIOS updates are in progress, do not change the server power until those tasks are complete.

### Before You Begin

You must log in with user or admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server 1</b>	Enters the server command mode.
<b>Step 3</b>	Server /chassis/server # <b>power cycle</b>	Power off and then powers on the server.
<b>Step 4</b>	At the prompt, enter <b>y</b> to confirm.	Power off and then powers on the server.

This example shows how to power cycle the server:

```
Server# scope chassis
Server# /chassis scope server 1
Server /chassis/server # power cycle
This operation will change the server's power state.
Do you want to continue with power control for Server 1 ?[y|N] y

Server /chassis/server # show
Server ID Power Serial Number Product Name PID UUID
-----
-----
1 On FCH1848794D UCS C3x60 UCSC-C3X60-SVRNB
60974271-A514-484C-BAE3-A5EE4FD16E06

Server /chassis/server#
```

# Configuring the Power Restore Policy

The power restore policy determines how power is restored to the server after a chassis power loss.

### Before You Begin

You must log in with admin privileges to perform this task.

## Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server /server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	server /server # <b>scope bmc</b>	Enters bmc command mode.
<b>Step 3</b>	Server /server/bmc # <b>scope power-restore-policy</b>	Enters the power restore policy command mode.
<b>Step 4</b>	Server /server/bmc/power-restore-policy # <b>set policy</b> { <b>power-off</b>   <b>power-on</b>   <b>restore-last-state</b> }	Specifies the action to be taken when chassis power is restored. Select one of the following: <ul style="list-style-type: none"> <li>• <b>power-off</b>—Server power will remain off until manually turned on. This is the default action.</li> <li>• <b>power-on</b>—Server power will be turned on when chassis power is restored.</li> <li>• <b>restore-last-state</b>—Server power will return to the state before chassis power was lost.</li> </ul> <p>When the selected action is <b>power-on</b>, you can select a delay in the restoration of power to the server.</p>
<b>Step 5</b>	Server /server/bmc/power-restore-policy # <b>set delay</b> { <b>fixed</b>   <b>random</b> }	(Optional) Specifies whether server power will be restored after a fixed or random time. The default is <b>fixed</b> . This command is accepted only if the power restore action is <b>power-on</b> .
<b>Step 6</b>	Server /server/bmc/power-restore-policy # <b>set delay-value</b> <i>delay</i>	(Optional) Specifies the delay time in seconds. The range is 0 to 240; the default is 0.
<b>Step 7</b>	Server /CIMC/power-restore-policy # <b>commit</b>	Commits the transaction to the system configuration.

This example sets the power restore policy to power-on with a fixed delay of 180 seconds (3 minutes) and commits the transaction:

```
Server# scope CIMC
Server /CIMC # Scope power-restore-policy
Server /server/bmc/power-restore-policy # set policy power-on
Server /server/bmc/power-restore-policy *# commit
Server /server/bmc/power-restore-policy # set delay fixed
Server /server/bmc/power-restore-policy *# set delay-value 180
Server /server/bmc/power-restore-policy *# commit
Server /server/bmc/power-restore-policy # show detail
Power Restore Policy:
  Power Restore Policy: power-on
  Power Delay Type: fixed
  Power Delay Value(sec): 180

Server /server/bmc/power-restore-policy #
```

## Power Characterization

The chassis power characterization range is calculated and derived from individual server node power characterization status, and from the power requirements of all the unmanageable components of the chassis.

This range varies for each configuration, so you need to run the power characterization every time a configuration changes.

To help you use the power characterization range appropriately for the different power profiles, the system represents the chassis' minimum power as auto profile minimum and custom profile minimum. However, custom power profile minimum is the actual minimum power requirement of the current chassis configuration. For more information see the section Run Power Characterization.

## Power Profiles

**Note**

---

Power Management is available only on some C-series servers.

---

Power capping determines how server power consumption is actively managed. When you enable power capping option, the system monitors power consumption and maintains the power below the allocated power limit. If the server cannot maintain the power limit or cannot bring the platform power back to the specified power limit within the correction time, power capping performs actions that you specify in the Action field under the Power Profile area.

You can configure multiple profiles with the following combinations: automatic and thermal profiles; and custom and thermal profiles. These profiles are configured by using either the web user interface, command line interface, or XML API. In the web UI, the profiles are listed under the Power Capping area. In the CLI, the profiles are configured when you enter the **power-cap-config** command. You can configure the following power profiles for power capping feature:

- Automatic Power Limiting Profile
- Custom Power Limiting Profile
- Thermal Power Limiting Profile

Automatic power limiting profile sets the power limit of the individual server boards based on server priority selected by you, or as detected by the system, based on the server utilization sensor (which is known as manual or dynamic priority selection). The limiting values are calculated within the manageable chassis power budget and applied to the individual server, and the priority server is allocated with its maximum power limiting value, while the other server with the remaining of the manageable power budget. Power limiting occurs at each server board platform level that affects the overall chassis power consumption.

Custom power limiting profile allows you to set an individual server board's power limit from the Web UI or command line interface within the chassis power budget. In this scenario you can specify an individual server power limit.

Thermal power profile allows you to enable thermal failure power capping, which means you can set a specific platform temperature threshold and it sets P (min-x) as the power limit to be applied on the temperature threshold.

## Enabling Chassis Global Power Capping

### Before You Begin

You must log in as a user with admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope power-cap-config</b>	Enters power cap configuration command mode.
<b>Step 3</b>	Server /chassis/power-cap-config # <b>set pow-cap-enable {yes   no}</b>	Enables or disables the power configuration.
<b>Step 4</b>	Server /chassis/power-cap-config *# <b>set chassis-budget</b> <i>power limit</i>	Sets the chassis power limit.
<b>Step 5</b>	Server /chassis/power-cap-config *# <b>commit</b>	Commits the transaction to the system.
<b>Step 6</b>	Server /chassis/power-cap-config # <b>show detail</b>	(Optional) Displays the chassis power configuration details.

The following example shows how to enable chassis global power capping:

```

Server # scope chassis
Server /chassis # scope power-cap-config
Server /chassis/power-cap-config # set pow-cap-enable yes
Server /chassis/power-cap-config *# set chassis-budget 1000
Server /chassis/power-cap-config *# commit
Server /chassis/power-cap-config # show detail
Chassis :
  Power Capping: yes
  Power Characterization Status: Completed
  Chassis Minimum (W): 756
  Chassis Maximum (W): 1089
  Chassis Budget (W): 1000
  Chassis Manageable Power Budget (W): 530
  Auto Balance Minimum Power Budget (W) : 966
Server 1 :
  Power Characterization Status: Completed
  Platform Minimum (W): 163
  Platform Maximum (W): 362
  Memory Minimum (W): 1
  Memory Maximum (W): 0
  CPU Minimum (W): 95
  CPU Maximum (W): 241
Server 2 :
  Power Characterization Status: Completed
  Platform Minimum (W): 136
  Platform Maximum (W): 253
  Memory Minimum (W): 1
  Memory Maximum (W): 0
  CPU Minimum (W): 57
  CPU Maximum (W): 139
Server /chassis/power-cap-config #

```

## Enabling Auto Balance Profile

### Before You Begin

You must log in as a user with admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope power-cap-config</b>	Enters power cap configuration command mode.
<b>Step 3</b>	Server /chassis/power-cap-config # <b>scope power-profile auto_balance</b>	Enters auto balance power profile command mode.
<b>Step 4</b>	Server /chassis/power-cap-config/power-profile # <b>set enabled {yes   no}</b>	Enables or disables the power profile.
<b>Step 5</b>	Server /chassis/power-cap-config/power-profile *# <b>set priority-selection {dynamic   manual}</b>	Sets the priority type to the chosen value.
<b>Step 6</b>	Server /chassis/power-cap-config/power-profile *# <b>set priority-server-id {1   2}</b>	Assigns priority to the chosen server.
<b>Step 7</b>	Server /chassis/power-cap-config/power-profile *# <b>set corr-time</b> <i>Value</i>	Sets the correction time in which the platform power should be brought back to the specified power limit before taking the action specified in the <b>Action</b> mode.  The range is from 1 and 600 seconds. The default is 1 seconds.
<b>Step 8</b>	Server /chassis/power-cap-config/power-profile *# <b>set allow-throttle {yes   no}</b>	Enables or disables the system to maintain the power limit by forcing the processor to use the throttling state (T-state) and memory throttle.
<b>Step 9</b>	Server /chassis /power-cap-config# <b>set susp-pd</b> { <i>h:m-h:m</i>   <i>ll,Mo,Tu,We,Th,Fr,Sa,Su.</i> }	Specifies the time period that the power capping profile will not be active.
<b>Step 10</b>	Server /chassis/power-cap-config/power-profile *# <b>commit</b>	Commits the transaction to the system configuration.
<b>Step 11</b>	Server /chassis/power-cap-config/power-profile # <b>show detail</b>	(Optional) Displays the auto balance power profile details.

The following example shows how to enable auto balance profile and setting the priority selection:

#### Setting Priority Using Dynamic Option

```
Server # scope chassis
Server /chassis # scope power-cap-config
Server /chassis/power-cap-config # scope power-profile auto_balance
Server /chassis/power-cap-config/power-profile # set enabled yes
Server /chassis/power-cap-config/power-profile *# set priority-selection dynamic
Server /chassis/power-cap-config/power-profile *# set corr-time 1
Server /chassis/power-cap-config/power-profile *# set allow-throttle yes
Server /chassis/power-cap-config/power-profile *# set susp-pd "2:0-4:30|All"
Server /chassis/power-cap-config/power-profile *# commit
Server /chassis/power-cap-config/power-profile # show detail
Profile Name : auto_balance
  Enabled: yes
  Priority Selection: dynamic
  Priority Server: 2
  Server1 Power Limit: 362
  Server2 Power Limit: 253
  Suspend Period: 2:0-4:30|All
  Exception Action: alert
  Correction Time: 1
  Throttling: no
Server /chassis/power-cap-config/power-profile #
```

#### Setting Priority Using the Manual Option

```
Server # scope chassis
Server /chassis # scope power-cap-config
Server /chassis/power-cap-config # scope power-profile auto_balance
Server /chassis/power-cap-config/power-profile # set enabled yes
Server /chassis/power-cap-config/power-profile *# set priority-selection manual
Server /chassis/power-cap-config/power-profile *# set priority-server-id 1
Server /chassis/power-cap-config/power-profile *# set corr-time 1
Server /chassis/power-cap-config/power-profile *# set allow-throttle yes
Server /chassis/power-cap-config/power-profile *# set susp-pd "2:0-4:30|All"
Server /chassis/power-cap-config/power-profile *# commit
Server /chassis/power-cap-config/power-profile # show detail
Profile Name : auto_balance
  Enabled: yes
  Priority Selection: manual
  Priority Server: 1
  Server1 Power Limit: 362
  Server2 Power Limit: 253
  Suspend Period: 2:0-4:30|All
  Exception Action: alert
  Correction Time: 1
  Throttling: no
Server /chassis/power-cap-config/power-profile #
```

## Disabling Auto Balance Power Profile

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # scope chassis	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # scope power-cap-config	Enters the power cap configuration mode.
<b>Step 3</b>	Server /chassis/power-cap-config # scope power-profile auto_balance	Enters the auto balance power profile mode.



	Command or Action	Purpose
<b>Step 4</b>	Server /chassis/power-cap-config/power-profile # <b>set enabled no</b>	Disables the auto balance power profile.
<b>Step 5</b>	Server /chassis/power-cap-config/power-profile # <b>commit</b>	Commits the transaction to the system configuration.

This example shows how to disable the auto balance profile:

```
Server # scope chassis
Server /chassis # scope power-cap-config
Server /chassis/power-cap-config # scope power-profile auto_balance
Server /chassis/power-cap-config/power-profile # set enabled no
Server /chassis/power-cap-config/power-profile *# commit
```

## Enabling Custom Profile on Server

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope power-cap-config</b>	Enters the power cap configuration mode.
<b>Step 3</b>	Server /chassis/power-cap-config # <b>scope power-profile custom</b>	Enters the custom power profile mode.
<b>Step 4</b>	Server /chassis/power-cap-config/power-profile # <b>set enabled yes</b>	Enables the custom power profile.
<b>Step 5</b>	Server /chassis/power-cap-config/power-profile *# <b>set power-limit value</b>	Specifies the power limit. Enter a value within the specified range.
<b>Step 6</b>	Server /chassis/power-cap-config/power-profile *# <b>set corr-time value</b>	Sets the correction time in which the platform power should be brought back to the specified power limit before taking the action specified in the <b>Action</b> mode.  The range is from 1 and 600 seconds. The default is 1 seconds
<b>Step 7</b>	Server /chassis/power-cap-config/power-profile *# <b>set allow-throttle yes</b>	Enables the system to maintain the power limit by forcing the processor to use the throttling state (T-state) and memory throttle.
<b>Step 8</b>	Server /chassis/power-cap-config/power-profile *# <b>commit</b>	Commits the transaction to the system configuration.

	Command or Action	Purpose
<b>Step 9</b>	At the prompt, enter the server ID for which you want to apply the custom power profile.	
<b>Step 10</b>	Server /chassis/power-cap-config/power-profile # <b>show detail</b>	Displays the power profile details.

This example shows how to enable the custom profile on any server node:

```

Server # scope chassis
Server /chassis # scope power-cap-config
Server /chassis/power-cap-config # scope power-profile custom
Server /chassis/power-cap-config/power-profile # set enabled yes
Server /chassis/power-cap-config/power-profile *# set power-limit 253
Server /chassis/power-cap-config/power-profile *# set corr-time 1
Server /chassis/power-cap-config/power-profile *# set allow-throttle no
Server /chassis/power-cap-config/power-profile *# commit
Please enter server Id for which 'custom' power profile setting needs to be done
[1|2]?2
Server /chassis/power-cap-config/power-profile # show detail
Profile Name : custom
Server Id 1:
  Enabled: no
  Power Limit: N/A
  Suspend Period:
  Exception Action: alert
  Correction Time: 1
  Throttling: no
Server Id 2:
  Enabled: yes
  Power Limit: 253
  Suspend Period:
  Exception Action: alert
  Correction Time: 1
  Throttling: yes

```

## Disabling Custom Profile on Server

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope power-cap-config</b>	Enters the power cap configuration mode.
<b>Step 3</b>	Server /chassis/power-cap-config # <b>scope power-profile custom</b>	Enters the custom power profile mode.
<b>Step 4</b>	Server /chassis/power-cap-config/power-profile # <b>set enabled no</b>	Disables the custom power profile.

	Command or Action	Purpose
<b>Step 5</b>	Server /chassis/power-cap-config/power-profile *# <b>commit</b>	Commits the transaction to the system configuration.
<b>Step 6</b>	At the prompt, enter the server ID for which you want to disable the custom power profile.	
<b>Step 7</b>	Server /chassis/power-cap-config/power-profile # <b>show detail</b>	Displays the power profile details.

This example shows how to disable the custom profile on any server node:

```

Server # scope chassis
Server /chassis # scope power-cap-config
Server /chassis/power-cap-config # scope power-profile custom
Server /chassis/power-cap-config/power-profile # set enabled no
Server /chassis/power-cap-config/power-profile *# commit
Please enter server Id for which 'custom' power profile setting needs to be done
[1|2]?2
Server /chassis/power-cap-config/power-profile # show detail
Profile Name : custom
Server Id 1:
  Enabled: no
  Power Limit: N/A
  Suspend Period:
  Exception Action: alert
  Correction Time: 1
  Throttling: no
Server Id 2:
  Enabled: no
  Power Limit: 253
  Suspend Period:
  Exception Action: alert
  Correction Time: 1
  Throttling: yes
    
```

## Enabling Thermal Profile on Server

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope power-cap-config</b>	Enters the power cap configuration mode.
<b>Step 3</b>	Server /chassis/power-cap-config # <b>scope power-profile thermal</b>	Enters the thermal power profile mode.
<b>Step 4</b>	Server /chassis/power-cap-config/power-profile # <b>set enabled yes</b>	Enables or disables the thermal power profile.

	Command or Action	Purpose
<b>Step 5</b>	Server /chassis/power-cap-config/power-profile *# <b>set temperature value</b>	Enter power in watts within the range specified. Enter the temperature in Celsius.
<b>Step 6</b>	Server /chassis/power-cap-config/power-profile *# <b>commit</b>	Commits the transaction to the system configuration.
<b>Step 7</b>	At the prompt, enter the server ID for which you want to enable the thermal power profile.	
<b>Step 8</b>	Server /chassis/power-cap-config/power-profile # <b>show detail</b>	Displays the power profile details.

This example shows how to enable the thermal profile on any server node:

```

Server # scope chassis
Server /chassis # scope power-cap-config
Server /chassis/power-cap-config # scope power-profile thermal
Server /chassis/power-cap-config/power-profile # set enabled yes
Server /chassis/power-cap-config/power-profile *# set temperature 26
Server /chassis/power-cap-config/power-profile *# commit
Please enter server Id for which 'thermal' power profile setting needs to be done
[1|2]?1
Server /chassis/power-cap-config/power-profile # show detail
Profile Name : thermal
Server Id 1:
  Enabled: yes
  Temperature Threshold (deg C): 26
  Power Limit: 163

```

## Disabling Thermal Profile on Server

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope power-cap-config</b>	Enters the power cap configuration mode.
<b>Step 3</b>	Server /chassis/power-cap-config # <b>scope power-profile thermal</b>	Enters the thermal power profile mode.
<b>Step 4</b>	Server /chassis/power-cap-config/power-profile # <b>set enabled no</b>	Disables the thermal power profile.
<b>Step 5</b>	Server /chassis/power-cap-config/power-profile *# <b>commit</b>	Commits the transaction to the system configuration.
<b>Step 6</b>	At the prompt, enter the server ID for which you want to disable the thermal power profile.	

	Command or Action	Purpose
<b>Step 7</b>	Server /chassis/power-cap-config/power-profile # <b>show detail</b>	Displays the power profile details.

This example shows how to disable the thermal profile on any server node:

```

Server # scope chassis
Server /chassis # scope power-cap-config
Server /chassis/power-cap-config # scope power-profile thermal
Server /chassis/power-cap-config/power-profile # set enabled no
Server /chassis/power-cap-config/power-profile *# commit
Please enter server Id for which 'thermal' power profile setting needs to be done
[1|2]?1
Server /chassis/power-cap-config/power-profile # show detail
Profile Name : thermal
Server Id 1:
    Enabled: no
    Temperature Threshold (deg C): 26
    Power Limit: 163
Server Id 2:
    Enabled: no
    Temperature Threshold (deg C): 0
    Power Limit: N/A
Server /chassis/power-cap-config/power-profile #
    
```

## Viewing Power Cap Configuration Details

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope power-cap-config</b>	Enters the power cap configuration mode.
<b>Step 3</b>	Server /chassis/power-cap-config # <b>show detail</b>	Displays the power characterization status of the chassis and servers.

This example shows how to view power cap configuration details:

```

Server # scope chassis
Server /chassis # scope power-cap-config
Server /chassis/power-cap-config # show detail
Chassis :
    Power Capping: yes
    Power Characterization Status: Completed
    Chassis Minimum (W): 756
    Chassis Maximum (W): 1089
    Chassis Budget (W): 1000
    Chassis Manageable Power Budget (W): 530
    Auto Balance Minimum Power Budget (W) : 966
Server 1 :
    Power Characterization Status: Completed
    Platform Minimum (W): 163
    
```

```

Platform Maximum (W): 362
Memory Minimum (W): 1
Memory Maximum (W): 0
CPU Minimum (W): 95
CPU Maximum (W): 241
Server 2 :
Power Characterization Status: Completed
Platform Minimum (W): 136
Platform Maximum (W): 253
Memory Minimum (W): 1
Memory Maximum (W): 0
CPU Minimum (W): 57
CPU Maximum (W): 139

```

## Viewing Power Monitoring Details

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>show power-monitoring</b>	Displays the power monitoring details.

This example shows how to view power monitoring details:

```

Server # scope chassis
Server /chassis # show power-monitoring
Chassis :
Current (W)  Minimum (W)  Maximum (W)  Average (W)  Period
-----
408          311          471          392          0days 9:5...
Server 1 :
Domain      Current (W)  Minimum (W)  Maximum (W)  Average (W)  Period
-----
Platform    68           61           178          68           0days 21:...
CPU         30           28           133          30           0days 21:...
Memory      1            0            1            1            0days 21:...
Server 2 :
Domain      Current (W)  Minimum (W)  Maximum (W)  Average (W)  Period
-----
Platform    97           62           200          100          1days 7:1:2
CPU         46           16           140          48           1days 7:1:2
Memory      1            0            1            1            1days 7:1:2
Server /chassis/server/pid-catalog #

```

## Viewing CUPS Utilization Details

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters the chassis command mode.

	Command or Action	Purpose
<b>Step 2</b>	Server /chassis # <b>show cups-utilization</b>	Displays the server utilization value on all the available CPUs.

This example shows how to view CUPS utilization details:

```
Server # scope chassis
Server /chassis # show cups-utilization
Server 1 :
CPU Utilization (%) Memory Utilization (%) I/O Utilization (%) Overall Utilization (%)
-----
0 0 0 0
Server 2 :
CPU Utilization (%) Memory Utilization (%) I/O Utilization (%) Overall Utilization (%)
-----
7 0 0 8
```

# Resetting the Server



**Important** If any firmware or BIOS updates are in progress, do not change the server power until those tasks are complete.

## Before You Begin

You must log in with user or admin privileges to perform this task.

## Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server 1</b>	Enters the server command mode.
<b>Step 3</b>	Server /chassis/server # <b>power hard-reset</b>	Reset the server, this is equivalent to pressing the reset button on the front panel or IPMI reset.
<b>Step 4</b>	At the prompt, enter y to confirm.	Reset the server, this is equivalent to pressing the reset button on the front panel or IPMI reset.

This example shows how to power hard reset the server:

```
Server# scope chassis
Server# /chassis scope server 1
Server /chassis/server # power hard-reset
This operation will change the server's power state.
Do you want to continue with power control for Server 1 ?[y|N] y

Server /chassis/server # show
Server ID Power Serial Number Product Name PID UUID
```

```

-----
1          Off    FCH1848794D   UCS C3260      UCSC-C3X60-SVRNB
60974271-A514-484C-BAE3-A5EE4FD16E06

Server /chassis/server#

```

## Shutting Down the Server



**Important** If any firmware or BIOS updates are in progress, do not change the server power until those tasks are complete.

### Before You Begin

You must log in with user or admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server 1</b>	Enters the server command mode.
<b>Step 3</b>	Server /chassis/server # <b>power shutdown</b>	Shuts down the host OS and powers off the server.
<b>Step 4</b>	At the prompt, enter y to confirm.	Shuts down the host OS and powers off the server.

This example shows how to shutdown the server:

```

Server# scope chassis
Server# /chassis scope server 1
Server /chassis/server # power shutdown
This operation will change the server's power state.
Do you want to continue with power control for Server 1 ?[y|N] y

Server /chassis/server # show
Server ID Power Serial Number Product Name PID UUID
-----
1          Off    FCH1848794D   UCS C3260      UCSC-C3X60-SVRNB
60974271-A514-484C-BAE3-A5EE4FD16E06

Server /chassis/server#

```



# Configuring DIMM Black Listing

## DIMM Black Listing

In Cisco IMC, the state of the Dual In-line Memory Module (DIMM) is based on SEL event records. A DIMM is marked bad if the BIOS encounters a non-correctable memory error or correctable memory error with 16000 error counts during memory test execution during BIOS post. If a DIMM is marked bad, it is considered a non-functional device.

If you enable DIMM blacklisting, Cisco IMC monitors the memory test execution messages and blacklists any DIMM that encounters memory errors at any given point of time in the DIMM SPD data. This allows the host to map out those DIMMs.

DIMMs are mapped out or blacklisted only when Uncorrectable errors occur. When a DIMM gets blacklisted, other DIMMs in the same channel are ignored or disabled, which means that the DIMM is no longer considered bad.



**Note**

DIMMs do not get mapped out or blacklisted for 16000 Correctable errors.

## Enabling DIMM Black Listing

### Before You Begin

You must be logged in as an administrator.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /server # <b>scope dimm-blacklisting</b> /	Enters the DIMM blacklisting mode.
<b>Step 3</b>	Server /server/dimm-blacklisting # <b>set enabled</b> {yes   no}	Enables or disables DIMM blacklisting.
<b>Step 4</b>	Server /server/dimm-blacklisting* # <b>commit</b>	Commits the transaction to the system configuration.

The following example shows how to enable DIMM blacklisting:

```
Server # scope server 1
Server /server # scope dimm-blacklisting
Server /server/dimm-blacklisting # set enabled yes
Server /server/dimm-blacklisting* # commit
Server /server/dimm-blacklisting #
Server /server/dimm-blacklisting # show detail
```

```
DIMM Blacklisting:
  Enabled: yes
Server /server/dimm-blacklisting #
```

# Configuring BIOS Settings

## Viewing BIOS Status

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /sever # <b>scope bios</b>	Enters the BIOS command mode.
<b>Step 3</b>	Server /sever/bios # <b>show detail</b>	Displays details of the BIOS status.

The BIOS status information contains the following fields:

Name	Description
BIOS Version	The version string of the running BIOS.
Backup BIOS Version	The backup version string of the BIOS.
Boot Order	The legacy boot order of bootable target types that the server will attempt to use.
Boot Override Priority	This can be None, or HV.
FW Update/Recovery Status	The status of any pending firmware update or recovery action.
UEFI Secure Boot	Enables or Disables UEFI secure boot.
Configured Boot Mode	The boot mode in which h BIOS will try to boot the devices.
Actual Boot Mode	The actual boot mode in which BIOS booted the devices.
Last Configured Boot Order Source	The last configured boot order source by BIOS.

This example displays the BIOS status:

```
Server# scope server 1
Server /sever # scope bios
```

```
Server /server/bios # show detail
Server /server/bios # show detail
BIOS:
  BIOS Version: C3X60M3.2.0.7c.0.071620151216
  Backup BIOS Version: C3X60M3.2.0.7c.0.071620151216
  Boot Order: (none)
  Boot Override Priority:
  FW Update/Recovery Status: None, OK
  UEFI Secure Boot: disabled
  Configured Boot Mode: Legacy
  Actual Boot Mode: Legacy
  Last Configured Boot Order Source: CIMC
Server /server/bios #
```

## Configuring Main BIOS Settings

### Before You Begin

You must log in with admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /server # <b>scope bios</b>	Enters the BIOS command mode.
<b>Step 3</b>	Server /server /bios # <b>scope main</b>	Enters the main BIOS settings command mode.
<b>Step 4</b>	Server /server /bios # <b>set TPMAdminCtrl</b> {Disbaled   Enabled}	Enables or disables TPM support.
<b>Step 5</b>	Server /server /bios/main # <b>commit</b>	Commits the transaction to the system configuration.  Changes are applied on the next server reboot. If server power is on, you are prompted to choose whether to reboot now.

This example configures the main BIOS parameter and commits the transaction:

```
Server /server # scope server 1
Server/server # scope bios
Server /server/bios # scope main
Server /server/bios/main # set TPMAdminCtrl Enabled
Server /server/bios/main *# commit
Changes to BIOS set-up parameters will require a reboot.
Do you want to reboot the system?[y|N] n
Changes will be applied on next reboot.
Server /server/bios/main #
```

## Configuring Advanced BIOS Settings

### Before You Begin

You must log in with admin privileges to perform this task.

**Procedure**

	<b>Command or Action</b>	<b>Purpose</b>
<b>Step 1</b>	Server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /sever # <b>scope bios</b>	Enters the BIOS command mode.
<b>Step 3</b>	Server /sever/bios # <b>scope advanced</b>	Enters the advanced BIOS settings command mode.
<b>Step 4</b>	Configure the BIOS settings.	<a href="#">BIOS Parameters by Server Model, on page 267</a>
<b>Step 5</b>	Server /sever/bios/advanced # <b>commit</b>	Commits the transaction to the system configuration. Changes are applied on the next server reboot. If server power is on, you are prompted to choose whether to reboot now.

This example enables all the USB drives and commits the transaction:

```
Server# scope server 1
Server/sever # scope bios
Server /sever/bios # scope advanced
Server /sever/bios/advanced # set AllUsbDevices Enabled
Server /sever/bios/advanced *# commit
Changes to BIOS set-up parameters will require a reboot.
Do you want to reboot the system?[y|N] n
Changes will be applied on next reboot.
Server /sever/bios/advanced #
```

## Configuring Server Management BIOS Settings

**Before You Begin**

You must log in with admin privileges to perform this task.

**Procedure**

	<b>Command or Action</b>	<b>Purpose</b>
<b>Step 1</b>	Server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /sever # <b>scope bios</b>	Enters the BIOS command mode.
<b>Step 3</b>	Server /sever/bios # <b>scope server-management</b>	Enters the server management BIOS settings command mode.
<b>Step 4</b>	Configure the BIOS settings.	<a href="#">BIOS Parameters by Server Model, on page 267</a>
<b>Step 5</b>	Server /sever/bios/server-management # <b>commit</b>	Commits the transaction to the system configuration. Changes are applied on the next server reboot. If server power is on, you are prompted to choose whether to reboot now.

	Command or Action	Purpose
--	-------------------	---------

This example enables the OS watchdog timer and commits the transaction:

```
Server# scope bios
Server /sever # scope bios
Server /sever/bios # scope server-management
Server /sever/bios/server-management # set OSBootWatchdogTimer Enabled
Server /sever/bios/server-management *# commit
Changes to BIOS set-up parameters will require a reboot.
Do you want to reboot the system?[y|N] n
Changes will be applied on next reboot.
Server /sever/bios/server-management #
```

## Restoring BIOS Defaults

### Before You Begin

You must log in as a user with admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # scope server {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /sever # scope bios	Enters the BIOS command mode.
<b>Step 3</b>	Server /sever/bios # bios-setup-default	Restores BIOS default settings. This command initiates a reboot.

This example restores BIOS default settings:

```
Server# scope bios
Server/sever # scope bios
Server /sever/bios # bios-setup-default
This operation will reset the BIOS set-up tokens to factory defaults.
All your configuration will be lost.
Changes to BIOS set-up parameters will initiate a reboot.
Continue?[y|N]y
```

## Entering BIOS Setup

### Before You Begin

- The server must be powered on.
- You must log in as a user with admin privileges to perform this task.

**Procedure**

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /sever # <b>scope bios</b>	Enters the BIOS command mode.
<b>Step 3</b>	Server /sever/bios # <b>enter-bios-setup</b>	Enters BIOS setup on reboot.

This example enables you to enter BIOS setup:

```
Server# scope server 1
Server /sever # scope bios
Server /sever/bios # enter-bios-setup
This operation will enable Enter BIOS Setup option.
Host must be rebooted for this option to be enabled.
Continue?[y|N]y
```

## Restoring BIOS Manufacturing Custom Defaults

In instances where the components of the BIOS no longer function as desired, you can restore the BIOS set up tokens to the manufacturing default values.

**Before You Begin**

- You must log in with admin privileges to perform this task.
- The server must be powered off.

**Procedure**

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /sever # <b>scope bios</b>	Enters the BIOS command mode.
<b>Step 3</b>	Server /sever/bios # <b>restore-mfg-defaults</b>	Restores the set up tokens to the manufacturing default values.

This example shows how to restore the BIOS set up tokens to the manufacturing default values:

```
Server # scope bios
Server /sever/bios # restore-mfg-defaults
This operation will reset the BIOS set-up tokens to manufacturing defaults.
The system will be powered on.
Continue? [y|n] y
Server /sever/bios #
```

# Viewing Product ID (PID) Catalog Details

## Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server {1   2}</b>	Enters server command mode of server 1 or 2.
<b>Step 3</b>	Server /chassis/server # <b>show cpu-pid</b>	Displays the CPU PID details.
<b>Step 4</b>	Server /chassis/server # <b>show dimm-pid</b>	Displays the memory PID details.
<b>Step 5</b>	Server /chassis/server # <b>show pciadapter-pid</b>	Displays the PCI adapters PID details.
<b>Step 6</b>	Server /chassis/server # <b>show hdd-pid</b>	Displays the HDD PID details.

This example shows how to create view PID details

```

Server # scope chassis
Server /chassis # scope server 1
Viewing CPU PID details
Server /chassis/server # show cpu-pid
Socket Product ID Model
-----
CPU1 UCS-CPU-E52660B Intel(R) Xeon(R) CPU E5-2660 v2 @ 2.2...
CPU2 UCS-CPU-E52660B Intel(R) Xeon(R) CPU E5-2660 v2 @ 2.2...
Viewing memory PID details
Server /chassis/server # show dimm-pid
Name Product ID Vendor ID Capacity Speed
-----
DIMM_A1 UNKNOWN NA Failed NA
DIMM_A2 UNKNOWN NA Ignore... NA
DIMM_B1 UCS-MR-1X162RZ-A 0xCE00 16384 MB 1866
DIMM_B2 UCS-MR-1X162RZ-A 0xCE00 16384 MB 1866
DIMM_C1 UCS-MR-1X162RZ-A 0xCE00 16384 MB 1866
DIMM_C2 UCS-MR-1X162RZ-A 0xCE00 16384 MB 1866
DIMM_D1 UCS-MR-1X162RZ-A 0xCE00 16384 MB 1866
DIMM_D2 UCS-MR-1X162RZ-A 0xCE00 16384 MB 1866
DIMM_E1 UCS-MR-1X162RZ-A 0xCE00 16384 MB 1866
DIMM_E2 UCS-MR-1X162RZ-A 0xCE00 16384 MB 1866
DIMM_F1 UCS-MR-1X162RZ-A 0xCE00 16384 MB 1866
DIMM_F2 UCS-MR-1X162RZ-A 0xCE00 16384 MB 1866
DIMM_G1 UCS-MR-1X162RZ-A 0xCE00 16384 MB 1866
DIMM_G2 UCS-MR-1X162RZ-A 0xCE00 16384 MB 1866
DIMM_H1 UCS-MR-1X162RZ-A 0xCE00 16384 MB 1866
DIMM_H2 UCS-MR-1X162RZ-A 0xCE00 16384 MB 1866
Viewing PCI adapters PID details
Server /chassis/server # show pciadapter-pid
Slot Product ID Vendor ID Device ID SubVendor ID SubDevice ID
-----
1 UCSC-MLOM-CSC-02 0x1137 0x0042 0x1137 0x012e
Viewing HDD PID details
Server /chassis/server # show hdd-pid
Disk Controller Product ID Vendor Model
-----
1 SBMezz1 UCSC-C3X60-HD6TB SEAGATE ST6000NM0014
2 SBMezz1 UCSC-C3X60-HD6TB SEAGATE ST6000NM0014
3 SBMezz1 UCSC-C3X60-HD6TB SEAGATE ST6000NM0014
    
```

```

4   SBMezz1   UCSC-C3X60-HD6TB   SEAGATE   ST6000NM0014
5   SBMezz1   UCSC-C3X60-HD6TB   SEAGATE   ST6000NM0014
6   SBMezz1   UCSC-C3X60-HD6TB   SEAGATE   ST6000NM0014
7   SBMezz1   UCSC-C3X60-HD6TB   SEAGATE   ST6000NM0014
8   SBMezz1   UCSC-C3X60-HD6TB   SEAGATE   ST6000NM0014
9   SBMezz1   UCSC-C3X60-HD6TB   SEAGATE   ST6000NM0014
10  SBMezz1   UCSC-C3X60-HD6TB   SEAGATE   ST6000NM0014
11  SBMezz1   UCSC-C3X60-HD6TB   SEAGATE   ST6000NM0014
12  SBMezz1   UCSC-C3X60-HD6TB   SEAGATE   ST6000NM0014
13  SBMezz1   UCSC-C3X60-HD6TB   SEAGATE   ST6000NM0014
14  SBMezz1   UCSC-C3X60-HD6TB   SEAGATE   ST6000NM0014
201 SBMezz1   UCSC-C3X60-12SSD   ATA       INTEL SSD...
202 SBMezz1   UCSC-C3X60-12SSD   ATA       INTEL SSD...

```

```
Server /chassis/server #
```

## Uploading and Activating PID Catalog

### Before You Begin

You must log in as a user with admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope pid-catalog</b>	Enters the server PID catalog command mode.
<b>Step 3</b>	Server /chassis/pid-catalog # <b>upload-pid-catalog</b> <i>remote-protocol IP address PID</i> <i>Catalog file</i>	<p>Specifies the protocol to connect to the remote server. It can be one of the following types:</p> <ul style="list-style-type: none"> <li>• TFTP</li> <li>• FTP</li> <li>• SFTP</li> <li>• SCP</li> <li>• HTTP</li> </ul> <p><b>Note</b> The Cisco UCS C-Series server now supports fingerprint confirmation of the server when you update firmware through a remote server. This option is available only if you choose SCP or SFTP as the remote server type.</p> <p>If you chose SCP or SFTP as the remote server type while performing this action, a prompt with the message Server (RSA) key fingerprint is &lt;server_finger_print_ID&gt; Do you wish to continue? Click y or n depending on the authenticity of the server fingerprint.</p> <p>The fingerprint is based on the host's public key and helps you to identify or verify the host you are connecting to.</p>



	Command or Action	Purpose
		Initiates the upload of the PID catalog.
<b>Step 4</b>	Server /chassis/pid-catalog # <b>show detail</b>	(Optional) Displays the status of the upload.
<b>Step 5</b>	Server /chassis/pid-catalog # <b>exit</b>	Returns to the chassis command mode.
<b>Step 6</b>	Server /chassis # <b>scope server {1   2}</b>	Enters server command mode of server 1 or 2.
<b>Step 7</b>	Server /chassis/server # <b>scope pid-catalog</b>	Enters server PID catalog command mode.
<b>Step 8</b>	Server /chassis/server/pid-catalog # <b>activate</b>	Activates the uploaded PID catalog.
<b>Step 9</b>	Server /chassis/server/pid-catalog # <b>show detail</b>	(Optional) Displays the status of the activation.

This example shows how to upload and activate PID catalog:

```

Server # scope chassis
Server /chassis # scope pid-catalog
Uploading PID catalog
Server /chassis/pid-catalog # upload-pid-catalog tftp 172.22.141.66
pid-ctlg-2_0_12_78_01.tar.gz
upload-pid-catalog initialized.
Please check the status using "show detail".
Server /chassis/pid-catalog # show detail
    Upload Status: Upload Successful
Activating the uploaded PID catalog
Server /chassis/pid-catalog # exit
Server /chassis # scope server 2
Server /chassis/server # scope pid-catalog
Server /chassis/server/pid-catalog # activate
Successfully activated PID catalog
Server /chassis/server/pid-catalog # show detail
    Upload Status:
    Activation Status: Activation Successful
    Current Activated Version: 2.0(12.78).01
Server /chassis/server/pid-catalog #
    
```





# Viewing Server Properties

This chapter includes the following sections:

- [Viewing Server Properties, page 75](#)
- [Viewing CMC Properties, page 76](#)
- [Viewing Server CPU Details, page 77](#)
- [Viewing Memory Properties, page 77](#)
- [Viewing PCI Adapter Properties for a Server, page 78](#)
- [Viewing HDD Details for a Server, page 79](#)
- [Viewing Storage Adapter Properties for a Server, page 80](#)
- [Viewing TPM Properties, page 80](#)

## Viewing Server Properties

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server {1   2}</b>	Enters server command mode of server 1 or 2.
<b>Step 3</b>	Server /chassis /server # <b>show detail</b>	Displays server properties.

This example displays server properties:

```
Server# scope chassis
Server /chassis #scope server 1
Server /chassis /Server #show
Server ID Power Serial Number Product Name PID UUID
```

```

-----
2          on      FCH183978RD  UCS C3260      UCSC-C3X60-SVRNB
207BD0D4-C589-40C1-A73E-EF6E7F773198

Server /chassis /Server #show detail
Server ID 1:
  Power: off
  Serial Number: FCH1848794D
  Product Name: UCS C3260
  PID: UCSC-C3X60-SVRNB
  UUID: 60974271-A514-484C-BAE3-A5EE4FD16E06
Server /chassis /Server #

```

## Viewing CMC Properties

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	server /chassis # <b>scope cmc</b> / 2	Enters CMC on the chosen SIOC controller command mode.
<b>Step 3</b>	server /chassis/cmc # <b>show detail</b>	Displays the CMC details for the chosen SIOC controller.

This example shows how to view the CMC details:

```

server # scope chassis
server /chassis # scope cmc 1
server /chassis/cmc # show detail
CMC Firmware update initialized.
Please check the status using "show detail"
Server /chassis/cmc # show detail
Firmware Image Information:
  ID: 1
  Name: CMC1
  Serial Number: FCH19117MTU
  Update Stage: NONE
  Update Progress: 100
  Current FW Version: 2.0(10.97)
  FW Image 1 Version: 2.0(10.97)
  FW Image 1 State: RUNNING ACTIVATED
  FW Image 2 Version: 2.0(10.87)
  FW Image 2 State: BACKUP INACTIVATED
  Reset Reason: not-applicable (This provides the reason for the last Cisco IMC reboot.)
server /chassis/cmc #

```

# Viewing Server CPU Details

## Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server {1   2}</b>	Enters server command mode of server 1 or 2.
<b>Step 3</b>	Server /chassis /server # <b>show cpu</b>	Displays CPU details for the server.
<b>Step 4</b>	Server# <b>show cpu-pid</b>	Displays the CPU product IDs .

This example displays the CPU details for the server:

```
Server# scope chassis
Server /chassis #scope server 1
Server /chassis /Server #show cpu
Name          Cores    Version
-----
CPU1          6        Intel(R) Xeon(R) CPU E5-2620 v2 @ 2.10GHz
CPU2          6        Intel(R) Xeon(R) CPU E5-2620 v2 @ 2.10GHz

Server /chassis /Server #show cpu-pid
Socket Product ID      Model
-----
CPU1   UCS-CPU-E52620B      Intel(R) Xeon(R) CPU E5-2620 v2 @ 2.1...
CPU2   UCS-CPU-E52620B      Intel(R) Xeon(R) CPU E5-2620 v2 @ 2.1...

Server /chassis /Server #
```

# Viewing Memory Properties

## Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server {1   2}</b>	Enters server command mode of server 1 or 2.
<b>Step 3</b>	Server /chassis /server # <b>show dimm</b>	Displays DIMM details for the server.
<b>Step 4</b>	Server# <b>show dimm-pid</b>	Displays the DIMM product IDs.
<b>Step 5</b>	Server# <b>show dimm-summary</b>	Displays the DIMM summary information .

This example displays the DIMM details for the server.:

```
Server# scope chassis
Server /chassis #scope server 1
```

```

Server /chassis /Server #show dimm
Name                               Capacity           Channel Speed (MHz) Channel Type
-----
DIMM_A1                            16384 MB           1866                DDR3
DIMM_A2                            16384 MB           1866                DDR3
DIMM_B1                            16384 MB           1866                DDR3
DIMM_B2                            16384 MB           1866                DDR3
DIMM_C1                            16384 MB           1866                DDR3
DIMM_C2                            16384 MB           1866                DDR3
DIMM_D1                            16384 MB           1866                DDR3
DIMM_D2                            16384 MB           1866                DDR3
DIMM_E1                            16384 MB           1866                DDR3
DIMM_E2                            16384 MB           1866                DDR3
DIMM_F1                            16384 MB           1866                DDR3
DIMM_F2                            16384 MB           1866                DDR3
DIMM_G1                            16384 MB           1866                DDR3
DIMM_G2                            16384 MB           1866                DDR3
DIMM_H1                            16384 MB           1866                DDR3
DIMM_H2                            16384 MB           1866                DDR3

```

```

Server /chassis /Server #show dimm-pid
Name                               Product ID         Vendor ID           Capacity           Speed
-----
DIMM_A1                            UCS-MR-1X162RZ-A  0xCE00             16384 MB           1866
DIMM_A2                            UCS-MR-1X162RZ-A  0xCE00             16384 MB           1866
DIMM_B1                            UCS-MR-1X162RZ-A  0xCE00             16384 MB           1866
DIMM_B2                            UCS-MR-1X162RZ-A  0xCE00             16384 MB           1866
DIMM_C1                            UCS-MR-1X162RZ-A  0xCE00             16384 MB           1866
DIMM_C2                            UCS-MR-1X162RZ-A  0xCE00             16384 MB           1866
DIMM_D1                            UCS-MR-1X162RZ-A  0xCE00             16384 MB           1866
DIMM_D2                            UCS-MR-1X162RZ-A  0xCE00             16384 MB           1866
DIMM_E1                            UCS-MR-1X162RZ-A  0xCE00             16384 MB           1866
DIMM_E2                            UCS-MR-1X162RZ-A  0xCE00             16384 MB           1866
DIMM_F1                            UCS-MR-1X162RZ-A  0xCE00             16384 MB           1866
DIMM_F2                            UCS-MR-1X162RZ-A  0xCE00             16384 MB           1866
DIMM_G1                            UCS-MR-1X162RZ-A  0xCE00             16384 MB           1866
DIMM_G2                            UCS-MR-1X162RZ-A  0xCE00             16384 MB           1866
DIMM_H1                            UCS-MR-1X162RZ-A  0xCE00             16384 MB           1866
DIMM_H2                            UCS-MR-1X162RZ-A  0xCE00             16384 MB           1866

```

```

Server /chassis /Server #show dimm-summary
DIMM Summary:
Memory Speed: 1600 MHz
Total Memory: 262144 MB
Effective Memory: 262144 MB
Redundant Memory: 0 MB
Failed Memory: 0 MB
Ignored Memory: 0 MB
Number of Ignored Dimms: 0
Number of Failed Dimms: 0
Memory RAS possible: Independent Mirroring Lockstep
Memory Configuration: Independent

```

```
Server /chassis /Server #
```

## Viewing PCI Adapter Properties for a Server

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # scope chassis	Enters chassis command mode.

	Command or Action	Purpose
<b>Step 2</b>	Server /chassis # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 3</b>	Server /chassis /server # <b>show pci-adapter</b>	Displays PCI adapter details for the server.
<b>Step 4</b>	Server# <b>show pciadapter-pid</b>	Displays the PCI adapter product IDs.

This example displays the PCI adapter details for the server.:

```
Server# scope chassis
Server /chassis #scope server 1
Server /chassis /Server #show pci-adapter
Slot          Vendor ID  Device ID  SubVendor ID  SubDevice ID  Firmware Version  Product Name
-----
1             0x1137    0x0042     0x1137        0x0157        4.0 (300.71)      UCSC-C3260-SIOC
M             0x1000    0x005d     0x1137        0x012d        24.7.3-0006      Cisco RAID
controller ...

Server /chassis /Server #show pciadapter-pid
Slot  Product ID          Vendor ID  Device ID  SubVendor ID  SubDevice ID
-----
1     UNKNOWN            0x1137    0x0042     0x1137        0x0157
M     UCSC-C3X60-RAID    0x1000    0x005d     0x1137        0x012d

Server /chassis /Server #
```

## Viewing HDD Details for a Server

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 3</b>	Server /chassis /server # <b>show hdd-pid</b>	Displays HDD details for the server.

This example displays the HDD details for the server:

```
Server# scope chassis
Server /chassis #scope server 1
Server /chassis /Server #show hdd-pid
Disk Controller  Product ID          Vendor      Model
-----
1  SLOT-MEZZ      UCS-HD4T7KS3-E     TOSHIBA    MG03SCA400
2  SLOT-MEZZ      UCS-HD4T7KS3-E     TOSHIBA    MG03SCA400
3  SLOT-MEZZ      UCS-HD4T7KS3-E     TOSHIBA    MG03SCA400
4  SLOT-MEZZ      UCS-HD4T7KS3-E     TOSHIBA    MG03SCA400
5  SLOT-MEZZ      UCS-HD4T7KS3-E     TOSHIBA    MG03SCA400
6  SLOT-MEZZ      UCS-HD4T7KS3-E     TOSHIBA    MG03SCA400
7  SLOT-MEZZ      UCS-HD4T7KS3-E     TOSHIBA    MG03SCA400
```

```

8   SLOT-MEZZ   UCS-HD4T7KS3-E   TOSHIBA   MG03SCA400
9   SLOT-MEZZ   UCS-HD4T7KS3-E   TOSHIBA   MG03SCA400
10  SLOT-MEZZ   UCS-HD4T7KS3-E   TOSHIBA   MG03SCA400
11  SLOT-MEZZ   UCS-HD4T7KS3-E   TOSHIBA   MG03SCA400
12  SLOT-MEZZ   UCS-HD4T7KS3-E   TOSHIBA   MG03SCA400
13  SLOT-MEZZ   UCS-HD4T7KS3-E   TOSHIBA   MG03SCA400
14  SLOT-MEZZ   UCS-HD4T7KS3-E   TOSHIBA   MG03SCA400

```

```
Server /chassis /Server#
```

## Viewing Storage Adapter Properties for a Server

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server {1   2}</b>	Enters server command mode of server 1 or 2.
<b>Step 3</b>	Server /chassis /server # <b>show storageadapter</b>	Displays storage adapter details for the server.

This example displays the storage adapter details for the server.:

```

Server# scope chassis
Server /chassis #scope server 1
Server /chassis /Server #show storageadapter
PCI Slot      Health          Controller Status  ROC Temperature  Product Name
-----
SLOT-MEZZ     Good            Optimal            48 degrees C    RAID controller for UCS C3X60
S...

Serial Number  Firmware Package Build  Product ID  D Battery Status  Cache Memory Size
-----
FCH184972F5   24.7.3-0006             LSI Logic   Optimal           3534 MB

Boot Drive    Boot Drive is PD
-----
0             false
Server /chassis /Server #

```

## Viewing TPM Properties

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.



	Command or Action	Purpose
<b>Step 2</b>	Server /chassis # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 3</b>	Server /chassis/server # <b>show tpm-inventory</b>	Displays TPM properties for the server.

This example displays the TPM properties for the server:

```

Server# scope chassis
Server /chassis #scope server 1
Server /chassis /Server #show tpm-inventory
Version      Presence      Enabled-Status      Active-Status      Ownership Revision
-----
NA           empty         unknown             unknown            unknown   NA
Model          Vendor          Serial
-----

Server chassis /Server#

```





# CHAPTER 6

## Viewing Sensors

This chapter includes the following sections:

- [Viewing Chassis Sensors, page 83](#)
- [Viewing Server Sensors, page 88](#)

## Viewing Chassis Sensors

## Viewing Power Supply Sensors

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope sensor</b>	Enters sensor command mode.
<b>Step 2</b>	Server /sensor # <b>show psu</b>	Displays power supply sensor statistics for the server.
<b>Step 3</b>	Server /sensor # <b>show psu-redundancy</b>	Displays power supply redundancy sensor status for the server.

This example displays power supply sensor statistics:

```
Server# scope sensor
Server /sensor # show psu
Name           Sensor Status  Reading  Units  Min. Warning  Max. Warning  Min. Failure  Max.
Failure
-----
SU1_PIN
1098          Normal         102     Watts  N/A           882           N/A
PSU2_PIN
1098          Normal          96     Watts  N/A           882           N/A
PSU3_PIN
1098          Normal         102     Watts  N/A           882           N/A
```

```

PSU4_PIN           Normal      96      Watts    N/A      882      N/A
1098
PSU1_POUT          Normal      78      Watts    N/A      798      N/A
996
PSU2_POUT          Normal      78      Watts    N/A      798      N/A
996
PSU3_POUT          Normal      84      Watts    N/A      798      N/A
996
PSU4_POUT          Normal      84      Watts    N/A      798      N/A
996
POWER_USAGE        Normal      406     Watts    N/A      N/A      N/A
2674
PSU1_DC_OK         Normal      good
PSU2_DC_OK         Normal      good
PSU3_DC_OK         Normal      good
PSU4_DC_OK         Normal      good
PSU1_AC_OK         Normal      good
PSU2_AC_OK         Normal      good
PSU3_AC_OK         Normal      good
PSU4_AC_OK         Normal      good
PSU1_STATUS        Normal      present
PSU2_STATUS        Normal      present
PSU3_STATUS        Normal      present
PSU4_STATUS        Normal      present

Server /sensor # show psu-redundancy
Name              Reading          Sensor Status
-----
PS_RDNDNT_MODE    full            Normal

Server /sensor #

```

## Viewing Fan Sensors

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope sensor</b>	Enters sensor command mode.
<b>Step 2</b>	Server /sensor # <b>show fan [detail]</b>	Displays fan sensor statistics for the server.

This example displays fan sensor statistics:

```

Server# scope sensor
Server /sensor # show fan
Name              Sensor Status  Reading  Units  Min. Warning  Max. Warning  Min. Failure
Max. Failure
-----
PSU1_FAN_SPEED    Normal         5160    RPM    1118          N/A            946
N/A
PSU2_FAN_SPEED    Normal         6106    RPM    1118          N/A            946

```

```

N/A
PSU3_FAN_SPEED Normal 5762 RPM 1118 N/A 946
N/A
PSU4_FAN_SPEED Normal 4988 RPM 1118 N/A 946
N/A
FAN1_SPEED Normal 6600 RPM 2040 N/A 1800
N/A
FAN2_SPEED Normal 6660 RPM 2040 N/A 1800
N/A
FAN3_SPEED Normal 6600 RPM 2040 N/A 1800
N/A
FAN4_SPEED Normal 6660 RPM 2040 N/A 1800
N/A
FAN5_SPEED Normal 6660 RPM 2040 N/A 1800
N/A
FAN6_SPEED Normal 6660 RPM 2040 N/A 1800
N/A
FAN7_SPEED Normal 6660 RPM 2040 N/A 1800
N/A
FAN8_SPEED Normal 6660 RPM 2040 N/A 1800
N/A
Server /sensor #

```

## Viewing Current Sensors

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope sensor</b>	Enters sensor command mode.
<b>Step 2</b>	Server /sensor # <b>show current</b>	Displays current sensor statistics.

This example displays current sensor statistics:

```

Server# scope sensor
Server /sensor # show current
Name           Sensor Status Reading  Units  Min. Warning Max. Warning Min. Failure Max.
Failure
-----
PSU1_IOUT Normal 6.00 AMP N/A 78.00 N/A
87.00
PSU2_IOUT Normal 6.00 AMP N/A 78.00 N/A
87.00
PSU3_IOUT Normal 7.00 AMP N/A 78.00 N/A
87.00
PSU4_IOUT Normal 7.00 AMP N/A 78.00 N/A
87.00
Server /sensor #

```

## Viewing Voltage Sensors

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope sensor</b>	Enters sensor command mode.
<b>Step 2</b>	Server /sensor # <b>show voltage</b>	Displays voltage sensor statistics.

This example displays voltage sensor statistics:

```

Server# scope sensor
Server /sensor # show voltage
Name           Sensor Status  Reading    Units  Min. Warning Max. Warning Min. Failure
Max. Failure
-----
SIOC_P1V0      Normal         1.000     V      N/A       N/A       0.944
 1.064
SIOC_P1V2      Normal         1.208     V      N/A       N/A       1.128
 1.272
SIOC_P1V5      Normal         1.500     V      N/A       N/A       1.410
 1.590
SIOC_P2V5      Normal         2.478     V      N/A       N/A       2.338
 2.646
SIOC_P3V3      Normal         3.320     V      N/A       N/A       3.100
 3.500
SIOC_P12V_STBY Normal         12.060    V      N/A       N/A      11.280
 12.720
SIOC_P3V3_STBY Normal         3.360     V      N/A       N/A       3.140
 3.460
PSU1_VIN       Normal        228.000   V      N/A       N/A       N/A
 264.000
PSU2_VIN       Normal        228.000   V      N/A       N/A       N/A
 264.000
PSU3_VIN       Normal        228.000   V      N/A       N/A       N/A
 264.000
PSU4_VIN       Normal        228.000   V      N/A       N/A       N/A
 264.000
P5V_1          Normal         5.010     V      N/A       N/A       4.500
 5.640
P5V_2          Normal         5.010     V      N/A       N/A       4.500
 5.640
P5V_3          Normal         5.010     V      N/A       N/A       4.500
 5.640
P5V_4          Normal         5.010     V      N/A       N/A       4.500
 5.640
P0V9_EXP1_VCORE Normal         0.872     V      N/A       N/A       0.836
 0.976
P0V9_EXP2_VCORE Normal         0.872     V      N/A       N/A       0.836
 0.976
P0V9_EXP1_AVD  Normal         0.888     V      N/A       N/A       0.836
 0.976
P0V9_EXP2_AVD  Normal         0.904     V      N/A       N/A       0.836
 0.976
PSU1_VOUT      Normal        12.000    V      N/A       N/A       N/A
 12.600
PSU2_VOUT      Normal        12.000    V      N/A       N/A       N/A
 12.600
PSU3_VOUT      Normal        12.000    V      N/A       N/A       N/A
 12.600
PSU4_VOUT      Normal        12.000    V      N/A
Server /sensor #

```

## Viewing Temperature Sensors

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope sensor</b>	Enters sensor command mode.
<b>Step 2</b>	Server /sensor # <b>show temperature</b>	Displays temperature sensor statistics.

This example displays temperature sensor statistics:

```

Server# scope sensor
Server /sensor # show temperature
Name                Sensor Status  Reading Units   Min. Warning Max. Warning Min. Failure
Max. Failure
-----
SIOC1_BACK_TEMP    Normal         37.0   C           N/A         70.0         N/A
 80.0
SIOC1_FRONT_TEMP   Normal         42.0   C           N/A         70.0         N/A
 80.0
SIOC1_MID_TEMP     Normal         41.0   C           N/A         70.0         N/A
 80.0
SIOC1_VIC_TEMP     Normal         44.0   C           N/A         70.0         N/A
 80.0
SIOC2_VIC_TEMP     Normal         44.0   C           N/A         70.0         N/A
 80.0
MOBO_R_BOT_TEMP    Normal         30.0   C           N/A         70.0         N/A
 80.0
MOBO_L_BOT_TEMP    Normal         31.0   C           N/A         70.0         N/A
 80.0
MOBO_R_MID_TEMP    Normal         25.0   C           N/A         50.0         N/A
 55.0
MOBO_R_IN_TEMP     Normal         24.0   C           N/A         50.0         N/A
 55.0
MOBO_L_IN_TEMP     Normal         26.0   C           N/A         50.0         N/A
 55.0
MOBO_L_MID_TEMP    Normal         26.0   C           N/A         50.0         N/A
 55.0
MOBO_R_OUT_TEMP    Normal         29.0   C           N/A         47.0         N/A
 52.0
MOBO_L_OUT_TEMP    Normal         29.0   C           N/A         46.0         N/A
 51.0
PSU1_TEMP          Normal         24.0   C           N/A         55.0         N/A
 60.0
PSU2_TEMP          Normal         27.0   C           N/A         55.0         N/A
 60.0
PSU3_TEMP          Normal         27.0   C           N/A         55.0         N/A
 60.0
PSU4_TEMP          Normal         25.0   C           N/A         55.0         N/A
 60.0
SIOC1_CMC_TEMP     Normal         51.0   C           N/A         75.0         N/A
 85.0
MOBO_R_EXP_TEMP    Normal         37.0   C           N/A         80.0         N/A
 90.0
MOBO_L_EXP_TEMP    Normal         40.0   C           N/A         80.0         N/A
 90.0
SIOC2_BACK_TEMP    Normal         36.0   C           N/A         70.0         N/A
 80.0
SIOC2_FRONT_TEMP   Normal         36.0   C           N/A         70.0         N/A
 80.0
SIOC2_MID_TEMP     Normal         36.0   C           N/A         70.0         N/A
 80.0

```

```

SIOC2_CMC_TEMP      Normal      36.0      C      N/A      75.0      N/A
  85.0
Server /sensor #

```

## Viewing LED Sensor

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope sensor</b>	Enters sensor command mode.
<b>Step 2</b>	Server /sensor # <b>show led</b>	Displays LED sensor statistics.

This example displays LED sensor statistics:

```

Server# scope sensor
Server /sensor # show led
LED Name                LED State  LED Color
-----
LED_FAN12_FAULT         OFF        AMBER
LED_FAN34_FAULT         OFF        AMBER
LED_FAN56_FAULT         OFF        AMBER
LED_FAN78_FAULT         OFF        AMBER
CHS_FP_LED_ID           OFF        BLUE
LED_HLTH_STATUS         ON         GREEN
LED_PSU_STATUS          ON         GREEN
LED_TEMP_STATUS         ON         GREEN
LED_FAN_STATUS          ON         GREEN
SERVER1_FP_ID_LED       OFF        BLUE
SERVER2_FP_ID_LED       OFF        BLUE
OVERALL_DIMM_STATUS     ON         GREEN
Server /sensor #

```

## Viewing Server Sensors

### Viewing Storage Sensors

#### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server {1   2}</b>	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /server # <b>scope sensor</b>	Enters sensor command.
<b>Step 3</b>	Server /server /sensor # <b>show hdd</b>	Displays the storage sensors for the server.



This example displays the storage sensors for the server:

```
Server# scope server 1
Server /server #scope sensor
Server /server /sensor #show hdd
Name                               Status
-----
SSD1_PRS                           inserted
SSD2_PRS                           inserted

Server server /sensor #
```

## Viewing Current Sensors

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /server # <b>scope sensor</b>	Enters sensor command.
<b>Step 3</b>	Server /server /sensor # <b>show current</b>	Displays the current sensors for the server.

This example displays the current sensors for the server:

```
Server# scope server 1
Server /server #scope sensor
Server /server /sensor #show current
Name                               Sensor Status Reading Units Min. Warning Max. Warning Min. Failure Max.
Failure
-----
P12V_CUR_SENS Normal           5.84 AMP N/A N/A N/A
56.90
Server server /sensor #
```

## Viewing LED Sensors

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /server # <b>scope sensor</b>	Enters sensor command.
<b>Step 3</b>	Server /server /sensor # <b>show led</b>	Displays the LED sensors for the server.

This example displays the LED sensors for the server:

```

Server# scope server 1
Server /server #scope sensor
Server /server /sensor #show led
LED Name                               LED State LED Color
-----
FP_ID_LED                               FAST BLINK BLUE
P1_DIMM_A1_LED                           OFF        AMBER
P1_DIMM_A2_LED                           OFF        AMBER
P1_DIMM_B1_LED                           OFF        AMBER
P1_DIMM_B2_LED                           OFF        AMBER
P1_DIMM_C1_LED                           OFF        AMBER
P1_DIMM_C2_LED                           OFF        AMBER
P1_DIMM_D1_LED                           OFF        AMBER
P1_DIMM_D2_LED                           OFF        AMBER
P2_DIMM_E1_LED                           OFF        AMBER
P2_DIMM_E2_LED                           OFF        AMBER
P2_DIMM_F1_LED                           OFF        AMBER
P2_DIMM_F2_LED                           OFF        AMBER
P2_DIMM_G1_LED                           OFF        AMBER
P2_DIMM_G2_LED                           OFF        AMBER
P2_DIMM_H1_LED                           OFF        AMBER
P2_DIMM_H2_LED                           OFF        AMBER
LED_HLTH_STATUS                          ON         GREEN
LED_TEMP_STATUS                          ON         GREEN
OVERALL_DIMM_STATUS                      ON         GREEN

Server server /sensor #

```

## Viewing Temperature Sensors

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /server # <b>scope sensor</b>	Enters sensor command.
<b>Step 3</b>	Server /server /sensor # <b>show temperature</b>	Displays the temperature sensors for the server.

This example displays the temperature sensors for the server:

```

Server# scope server 1
Server /server #scope sensor
Server /server /sensor #show temperature
Name           Sensor Status Reading Units   Min. Warning Max. Warning Min. Failure
Max. Failure
-----
TEMP_SENS_FRONT Normal      24.0   C      N/A      60.0      N/A
  70.0
TEMP_SENS_REAR Normal      25.0   C      N/A      80.0      N/A
  85.0
P1_TEMP_SENS Normal      21.0   C      N/A      74.0      N/A
  79.0
P2_TEMP_SENS Normal      23.5   C      N/A      74.0      N/A
  79.0
DDR3_P1_A1_TEMP Normal      23.0   C      N/A      65.0      N/A

```

```

      85.0
DDR3_P1_A2_TEMP Normal      23.0      C      N/A      65.0      N/A
      85.0
DDR3_P1_B1_TEMP Normal      23.0      C      N/A      65.0      N/A
      85.0
DDR3_P1_B2_TEMP Normal      23.0      C      N/A      65.0      N/A
      85.0
DDR3_P1_C1_TEMP Normal      24.0      C      N/A      65.0      N/A
      85.0
DDR3_P1_C2_TEMP Normal      24.0      C      N/A      65.0      N/A
      85.0
DDR3_P1_D1_TEMP Normal      24.0      C      N/A      65.0      N/A
      85.0
DDR3_P1_D2_TEMP Normal      23.0      C      N/A      65.0      N/A
      85.0
DDR3_P2_E1_TEMP Normal      23.0      C      N/A      65.0      N/A
      85.0
DDR3_P2_E2_TEMP Normal      23.0      C      N/A      65.0      N/A
      85.0
DDR3_P2_F1_TEMP Normal      22.0      C      N/A      65.0      N/A
      85.0

Server server /sensor #

```

## Viewing Voltage Sensors

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server {1   2}</b>	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /server # <b>scope sensor</b>	Enters sensor command.
<b>Step 3</b>	Server /server /sensor # <b>show voltage</b>	Displays the voltage sensors for the server.

This example displays the voltage sensors for the server:

```

Server# scope server 1
Server /server #scope sensor
Server /server /sensor #show voltage
Name           Sensor Status Reading Units   Min. Warning Max. Warning Min. Failure
Max. Failure
-----
P3V_BAT_SCALED Normal      2.973      V      N/A      N/A      2.154
 3.418
P5V_STBY       Normal      4.909      V      N/A      N/A      4.555
 5.452
P3V3_STBY      Normal      3.302      V      N/A      N/A      3.018
 3.602
P1V1_SSB_STBY Normal      1.088      V      N/A      N/A      1.000
 1.205
P1V8_STBY      Normal      1.784      V      N/A      N/A      1.627
 1.980
P1V0_STBY      Normal      0.990      V      N/A      N/A      0.911
 1.088
P1V5_STBY      Normal      1.490      V      N/A      N/A      1.372
 1.637
P0V75_STBY     Normal      0.725      V      N/A      N/A      0.686
 0.823
P2V5_STBY      Normal      2.484      V      N/A      N/A      2.279

```

2.734							
P12V	Normal	11.977	V	N/A	N/A	11.210	
12.803							
P5V	Normal	5.031	V	N/A	N/A	4.680	
5.335							
P3V3	Normal	3.276	V	N/A	N/A	3.089	
3.526							
P1V5_SSB	Normal	1.482	V	N/A	N/A	1.412	
1.607							
P1V1_SSB	Normal	1.084	V	N/A	N/A	1.037	
1.178							
PVTT_P1	Normal	0.991	V	N/A	N/A	0.944	
1.061							
PVTT_P2	Normal	0.975	V	N/A	N/A	0.944	
1.061							
PVSA_P1	Normal	0.959	V	N/A	N/A	0.593	
1.170							

Server server /sensor #



## Managing Remote Presence

---

This chapter includes the following sections:

- [Managing the Virtual KVM, page 93](#)
- [Configuring Virtual Media, page 96](#)
- [Managing Serial over LAN, page 100](#)

### Managing the Virtual KVM

#### KVM Console

The KVM console is an interface accessible from Cisco IMC that emulates a direct keyboard, video, and mouse (KVM) connection to the server. The KVM console allows you to connect to the server from a remote location.

Instead of using CD/DVD or floppy drives physically connected to the server, the KVM console uses virtual media, which are actual disk drives or disk image files that are mapped to virtual CD/DVD or floppy drives. You can map any of the following to a virtual drive:

- CD/DVD or floppy drive on your computer
- Disk image files (ISO or IMG files) on your computer
- USB flash drive on your computer
- CD/DVD or floppy drive on the network
- Disk image files (ISO or IMG files) on the network
- USB flash drive on the network

You can use the KVM console to install an OS on the server.

**Note**

To configure the KVM console successfully for the Cisco UCS C3260 server, you need to configure IP addresses for the Cisco IMC, CMC, and BMC components. You can configure the IP addresses for these components using the CLI interface or Web UI. For the CLI, use the command **scope network**, or view the setting using **scope <chassis/server1/2><cmc/bmc><network>**.

To configure IP addresses for network components on the web interface, see the steps described in the section **Configuring Network-Related Settings**.

**Note**

The KVM Console is operated only through the GUI. To launch the KVM Console, see the instructions in the *Cisco UCS C-Series Servers Integrated Management Controller GUI Configuration Guide*.

## Enabling the Virtual KVM

### Before You Begin

You must log in as a user with admin privileges to enable the virtual KVM.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /server # <b>scope kvm</b>	Enters KVM command mode.
<b>Step 3</b>	Server /server/kvm # <b>set enabled yes</b>	Enables the virtual KVM.
<b>Step 4</b>	Server /server/kvm # <b>commit</b>	Commits the transaction to the system configuration.
<b>Step 5</b>	Server /server/kvm # <b>show [detail]</b>	(Optional) Displays the virtual KVM configuration.

This example enables the virtual KVM:

```
Server# scope server 1
Server /server # scope kvm
Server /server/kvm # set enabled yes
Server /server/kvm *# commit
Server /server/kvm # show detail
KVM Settings:
  Encryption Enabled: yes
  Max Sessions: 4
  Local Video: yes
  Active Sessions: 1
  Enabled: yes
  KVM Port: 2068

Server /server/kvm #
```

## Disabling the Virtual KVM

### Before You Begin

You must log in as a user with admin privileges to enable the virtual KVM.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /server # <b>scope kvm</b>	Enters KVM command mode.
<b>Step 3</b>	Server /server /kvm # <b>set enabled no</b>	Disables the virtual KVM.  <b>Note</b> Disabling the virtual KVM disables access to the virtual media feature, but does not detach the virtual media devices if virtual media is enabled.
<b>Step 4</b>	Server /server/kvm # <b>commit</b>	Commits the transaction to the system configuration.
<b>Step 5</b>	Server /server/kvm # <b>show [detail]</b>	(Optional) Displays the virtual KVM configuration.

This example enables the virtual KVM:

```
Server# scope server 1
Server /server # scope kvm
Server /server/kvm # set enabled no
Server /server/kvm *# commit
Server /server/kvm # show detail
KVM Settings:
  Encryption Enabled: yes
  Max Sessions: 4
  Local Video: yes
  Active Sessions: 0
  Enabled: no
  KVM Port: 2068

Server /server/kvm #
```

## Configuring the Virtual KVM

### Before You Begin

You must log in as a user with admin privileges to configure the virtual KVM.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.

	Command or Action	Purpose
<b>Step 2</b>	Server /server# <b>scope kvm</b>	Enters KVM command mode.
<b>Step 3</b>	Server /server/kvm # <b>set enabled {yes   no}</b>	Enables or disables the virtual KVM.
<b>Step 4</b>	Server /server/kvm # <b>set encrypted {yes   no}</b>	If encryption is enabled, the server encrypts all video information sent through the KVM.
<b>Step 5</b>	Server /server/kvm # <b>set kvm-port port</b>	Specifies the port used for KVM communication.
<b>Step 6</b>	Server /server/kvm # <b>set local-video {yes   no}</b>	If local video is <b>yes</b> , the KVM session is also displayed on any monitor attached to the server.
<b>Step 7</b>	Server /server/kvm # <b>set max-sessions sessions</b>	Specifies the maximum number of concurrent KVM sessions allowed. The <i>sessions</i> argument is an integer between 1 and 4.
<b>Step 8</b>	Server /server/kvm # <b>commit</b>	Commits the transaction to the system configuration.
<b>Step 9</b>	Server /server/kvm # <b>show [detail]</b>	(Optional) Displays the virtual KVM configuration.

This example configures the virtual KVM and displays the configuration:

```
Server# scope server 1
Server /server # scope kvm
Server /server/kvm # set enabled yes
Server /server/kvm *# set encrypted no
Server /server/kvm *# set kvm-port 2068
Server /server/kvm *# set max-sessions 4
Server /server/kvm *# set local-video yes
Server /server/kvm *# commit
Server /server/kvm # show detail
KVM Settings:
  Encryption Enabled: no
  Max Sessions: 4
  Local Video: yes
  Active Sessions: 0
  Enabled: yes
  KVM Port: 2068

Server /server/kvm #
```

### What to Do Next

Launch the virtual KVM from the GUI.

## Configuring Virtual Media

### Before You Begin

You must log in as a user with admin privileges to configure virtual media.



**Procedure**

	<b>Command or Action</b>	<b>Purpose</b>
<b>Step 1</b>	Server# <b>scope vmedia</b>	Enters virtual media command mode.
<b>Step 2</b>	Server /vmedia # <b>set enabled</b> {yes   no}	Enables or disables virtual media. By default, virtual media is disabled.  <b>Note</b> Disabling virtual media detaches the virtual CD, virtual floppy, and virtual HDD devices from the host.
<b>Step 3</b>	Server /vmedia # <b>set encryption</b> {yes   no}	Enables or disables virtual media encryption.
<b>Step 4</b>	Server /vmedia # <b>set low-power-usb-enabled</b> {yes   no}	Enables or disables low power USB.  <b>Note</b> While mapping an ISO to a server which has a UCS VIC P81E card and the NIC is in Cisco Card mode: <ul style="list-style-type: none"> <li>• If the low power USB is enabled, after mapping the ISO and rebooting the host the card resets and ISO mapping is lost. The virtual drives are not visible on the boot selection menu.</li> <li>• If the low power USB is disabled, after mapping the ISO, and rebooting the host and the Cisco IMC, the virtual drivers appear on the boot selection menu as expected.</li> </ul>
<b>Step 5</b>	Server /vmedia # <b>commit</b>	Commits the transaction to the system configuration.
<b>Step 6</b>	Server /vmedia # <b>show [detail]</b>	(Optional) Displays the virtual media configuration.

This example configures virtual media encryption:

```
Server# scope vmedia
Server /vmedia # set enabled yes
Server /vmedia *# set encryption yes
Server /vmedia *# set low-power-use-enabled no
Server /vmedia *# commit
Server /vmedia # show detail
vMedia Settings:
  Encryption Enabled: yes
  Enabled: yes
  Max Sessions: 1
  Active Sessions: 0
  Low Power USB Enabled: no

Server /vmedia #
```

**What to Do Next**

Use the KVM to attach virtual media devices to a host.

## Configuring a Cisco IMC-Mapped vMedia Volume

### Before You Begin

You must log in with admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /server# <b>scope vmedia</b>	Enters the virtual media command mode.
<b>Step 3</b>	Server /server/vmedia # <b>map-cifs</b> { <b>volume-name</b>   <b>remote-share</b>   <b>remote-file-path</b> [ <i>mount options</i> ]	Maps a CIFS file for vMedia. You must specify the following: <ul style="list-style-type: none"> <li>• Name of the volume to create</li> <li>• Remote share including IP address and the exported directory</li> <li>• Path of the remote file corresponding to the exported directory.</li> <li>• (Optional) Mapping options</li> <li>• Username and password to connect to the server</li> </ul>
<b>Step 4</b>	Server /server/vmedia # <b>map-nfs</b> { <b>volume-name</b>   <b>remote-share</b>   <b>remote-file-path</b> } [ <i>mount options</i> ]	Maps an NFS file for vMedia. You must specify the following: <ul style="list-style-type: none"> <li>• Name of the volume to create</li> <li>• Remote share including IP address and the exported directory</li> <li>• Path of the remote file corresponding to the exported directory.</li> <li>• (Optional) Mapping options</li> </ul>
<b>Step 5</b>	Server /server/vmedia # <b>map-www</b> { <b>volume-name</b>   <b>remote-share</b>   <b>remote-file-path</b> [ <i>mount options</i> ]	Maps an HTTPS file for vMedia. You must specify the following: <ul style="list-style-type: none"> <li>• Name of the volume to create</li> <li>• Remote share including IP address and the exported directory</li> <li>• Path of the remote file corresponding to the exported directory.</li> <li>• (Optional) Mapping options</li> <li>• Username and password to connect to the server</li> </ul>

	Command or Action	Purpose
--	-------------------	---------

This example shows how to create a CIFS Cisco IMC-mapped vmedia settings:

```
Server # scope server 1
Server /server #scope vmedia
Server /server/vmedia # map-cifs sample-volume //10.10.10.10/project /test/sample
Server username:
Server password: ****
Confirm password: ****

Server /server/vmedia #
```

## Viewing Cisco IMC-Mapped vMedia Volume Properties

### Before You Begin

You must log in with admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server {1   2}</b>	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /server # <b>scope vmedia</b>	Enters the virtual media command mode.
<b>Step 3</b>	Server /server/vmedia # <b>show mappings detail</b>	Displays information on all the vmedia mapping that are configured.

This example shows how to view the properties of all the configured vmedia mapping:

```
Server # scope server 1
Server /server #scope vmedia
Server /server/vmedia # show mappings
```

Volume	Map-status	Drive-type	remote-share	remote-file	mount-type
Huu	OK	removable	http://10.104.236.99/	rhel-server-6.1-x86_6.iso	www
Rhel	OK	CD	http://10.104.236.99/	rhel-server-6.1-x86_6.iso	www

```
Server /server/vmedia #
```

# Managing Serial over LAN

## Serial Over LAN

Serial over LAN (SoL) is a mechanism that enables the input and output of the serial port of a managed system to be redirected via an SSH session over IP. SoL provides a means of reaching the host console via Cisco IMC.

### Guidelines and Restrictions for Serial Over LAN

For redirection to SoL, the server console must have the following configuration:

- console redirection to serial port A
- no flow control
- baud rate the same as configured for SoL
- VT-100 terminal type
- legacy OS redirection disabled

The SoL session will display line-oriented information such as boot messages, and character-oriented screen menus such as BIOS setup menus. If the server boots an operating system or application with a bitmap-oriented display, such as Windows, the SoL session will no longer display. If the server boots a command-line-oriented operating system (OS), such as Linux, you may need to perform additional configuration of the OS in order to properly display in an SoL session.

In the SoL session, your keystrokes are transmitted to the console except for the function key F2. To send an F2 to the console, press the Escape key, then press 2.

## Configuring Serial Over LAN

### Before You Begin

You must log in as a user with admin privileges to configure serial over LAN (SoL).

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /server# <b>scope sol</b>	Enters SoL command mode.
<b>Step 3</b>	Server /server/sol # <b>set enabled</b> {yes   no}	Enables or disables SoL on this server.
<b>Step 4</b>	Server /server/sol # <b>set baud-rate</b> {9600   19200   38400   57600   115200}	Sets the serial baud rate the system uses for SoL communication. <b>Note</b> The baud rate must match the baud rate configured in the server serial console.

	Command or Action	Purpose
<b>Step 5</b>	Server /server/sol # <b>set comport {com0   com1}</b>	<p>(Optional) Sets the serial port through which the system routes SoL communications.</p> <p><b>Note</b> This field is only available on some C-Series servers. If it is not available, the server always uses COM port 0 for SoL communication.</p> <p>You can specify:</p> <ul style="list-style-type: none"> <li>• <b>com0</b>—SoL communication is routed through COM port 0, an externally accessible serial port that supports either a physical RJ45 connection to an external device or a virtual SoL connection to a network device.</li> </ul> <p>If you select this option, the system enables SoL and disables the RJ45 connection, which means that the server can no longer support an external serial device.</p> <ul style="list-style-type: none"> <li>• <b>com1</b>—SoL communication is routed through COM port 1, an internal port accessible only through SoL.</li> </ul> <p>If you select this option, you can use SoL on COM port 1 and the physical RJ45 connection on COM port 0.</p> <p><b>Note</b> Changing the comport setting disconnects any existing SoL sessions.</p>
<b>Step 6</b>	Server /sol # <b>commit</b>	Commits the transaction to the system configuration.
<b>Step 7</b>	Server /sol # <b>show [detail]</b>	(Optional) Displays the SoL settings.

This example configures SoL:

```

Server# scope server 1
Server /server #scope sol
Server /server/sol # set enabled yes
Server /server/sol *# set baud-rate 115200
Server /server/sol *# set comport com1
Server /server/sol *# commit
Server /server/sol # show
Enabled Baud Rate(bps) Com Port
-----
yes      115200          com1
Server /sol # show detail
Serial Over LAN:
  Enabled: yes
  Baud Rate(bps): 115200
  Com Port: com1
Server /server/sol #
    
```





# CHAPTER 8

## Managing User Accounts

This chapter includes the following sections:

- [Configuring Local Users, page 103](#)
- [Disabling Strong Password, page 105](#)
- [LDAP Servers, page 106](#)
- [Configuring the LDAP Server, page 106](#)
- [Configuring LDAP in Cisco IMC, page 107](#)
- [Configuring LDAP Groups in Cisco IMC, page 109](#)
- [Configuring Nested Group Search Depth in LDAP Groups, page 110](#)
- [LDAP Certificates Overview, page 111](#)
- [Viewing User Sessions, page 116](#)
- [Terminating a User Session, page 117](#)

## Configuring Local Users

### Before You Begin

You must log in as a user with admin privileges to configure or modify local user accounts.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope user</b> <i>usernumber</i>	Enters user command mode for user number <i>usernumber</i> .
<b>Step 2</b>	Server /user # <b>set enabled</b> { <b>yes</b>   <b>no</b> }	Enables or disables the user account on the Cisco IMC.

	Command or Action	Purpose
<b>Step 3</b>	Server /user # <b>set name</b> <i>username</i>	Specifies the username for the user.
<b>Step 4</b>	Server /user # <b>set password</b>	<p>You are prompted to enter the password twice.</p> <p><b>Note</b> When strong password is enabled, you must follow these guidelines while setting a password:</p> <ul style="list-style-type: none"> <li>• The password must have a minimum of 8 and a maximum of 14 characters.</li> <li>• The password must not contain the User's Name.</li> <li>• The password must contain characters from three of the following four categories: <ul style="list-style-type: none"> <li>◦ English uppercase characters (A through Z)</li> <li>◦ English lowercase characters (a through z)</li> <li>◦ Base 10 digits (0 through 9)</li> <li>◦ Non-alphabetic characters (!, @, #, \$, %, ^, &amp;, *, -, _, +, =)</li> </ul> </li> </ul> <p>when strong password is disabled, you can set a password using characters of your choice (alphanumeric, special characters, or integers) within the range 1-20.</p>
<b>Step 5</b>	Server /user # <b>set role</b> { <b>readonly</b>   <b>user</b>   <b>admin</b> }	<p>Specifies the role assigned to the user. The roles are as follows:</p> <ul style="list-style-type: none"> <li>• <b>readonly</b>—This user can view information but cannot make any changes.</li> <li>• <b>user</b>—This user can do the following: <ul style="list-style-type: none"> <li>• View all information</li> <li>• Manage the power control options such as power on, power cycle, and power off</li> <li>• Launch the KVM console and virtual media</li> <li>• Clear all logs</li> <li>• Toggle the locator LED</li> <li>• Set the time zone</li> <li>• Ping an IP address</li> </ul> </li> <li>• <b>admin</b>—This user can perform all actions available through the GUI, CLI, and IPMI.</li> </ul>
<b>Step 6</b>	Server /user # <b>commit</b>	Commits the transaction to the system configuration.



This example configures user 5 as an admin:

```
Server# scope user 5
Server /user # set enabled yes
Server /user *# set name john
Server /user *# set password
Warning:
Strong Password Policy is enabled!
```

For CIMC protection your password must meet the following requirements:  
 The password must have a minimum of 8 and a maximum of 14 characters.  
 The password must not contain the User's Name.  
 The password must contain characters from three of the following four categories.  
 English uppercase characters (A through Z)  
 English lowercase characters (a through z)  
 Base 10 digits (0 through 9)

```
Please enter password:
Please confirm password:
Server /user *# set role readonly
Server /user *# commit
Server /user # show
User  Name          Role      Enabled
-----
5     john             readonly yes
```

## Disabling Strong Password

The Cisco IMC now implements a strong password policy wherein you are required to follow guidelines and set a strong password when you first log on to the server for the first time. The Cisco IMC CLI provides you option which allows you to disable the strong password policy and set a password of your choice by ignoring the guidelines. Once you disable the strong password, an Enable Strong Password button is displayed. By default, the strong password policy is enabled.

### Before You Begin

You must log in as a user with admin privileges to perform this action.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope user-policy</b>	Enters user policy command mode.
<b>Step 2</b>	Server /user-policy # <b>set password-policy {enabled   disabled}</b>	At the confirmation prompt, enter y to complete the action or n to cancel the action. Enables or disables the strong password.
<b>Step 3</b>	Server /user-policy # <b>commit</b>	Commits the transaction to the system configuration.

This example shows how to disable strong password:

```
Server# scope user-policy
Server /user-policy # set password-policy disabled
Warning: Strong password policy is being disabled.
Do you wish to continue? [y/N] y
```

```
Server /user-policy *# commit
Server /user-policy #
```

## LDAP Servers

Cisco IMC supports directory services that organize information in a directory, and manage access to this information. Cisco IMC supports Lightweight Directory Access Protocol (LDAP), which stores and maintains directory information in a network. In addition, Cisco IMC supports Microsoft Active Directory (AD). Active Directory is a technology that provides a variety of network services including LDAP-like directory services, Kerberos-based authentication, and DNS-based naming. The Cisco IMC utilizes the Kerberos-based authentication service of LDAP.

When LDAP is enabled in the Cisco IMC, user authentication and role authorization is performed by the LDAP server for user accounts not found in the local user database. The LDAP user authentication format is `username@domain.com`.

By enabling encryption in the configuration of Active Directory on the server, you can require the server to encrypt data sent to the LDAP server.

## Configuring the LDAP Server

The Cisco IMC can be configured to use LDAP for user authentication and authorization. To use LDAP, configure users with an attribute that holds the user role and locale information for the Cisco IMC. You can use an existing LDAP attribute that is mapped to the Cisco IMC user roles and locales or you can modify the LDAP schema to add a new custom attribute, such as the `CiscoAVPair` attribute, which has an attribute ID of 1.3.6.1.4.1.9.287247.1.



### Important

For more information about altering the schema, see the article at <http://technet.microsoft.com/en-us/library/bb727064.aspx>.



### Note

This example creates a custom attribute named `CiscoAVPair`, but you can also use an existing LDAP attribute that is mapped to the Cisco IMC user roles and locales.

The following steps must be performed on the LDAP server.

### Procedure

**Step 1** Ensure that the LDAP schema snap-in is installed.

**Step 2** Using the schema snap-in, add a new attribute with the following properties:

Properties	Value
Common Name	CiscoAVPair
LDAP Display Name	CiscoAVPair

Properties	Value
Unique X500 Object ID	1.3.6.1.4.1.9.287247.1
Description	CiscoAVPair
Syntax	Case Sensitive String

**Step 3** Add the CiscoAVPair attribute to the user class using the snap-in:

- a) Expand the **Classes** node in the left pane and type U to select the user class.
- b) Click the **Attributes** tab and click **Add**.
- c) Type C to select the CiscoAVPair attribute.
- d) Click **OK**.

**Step 4** Add the following user role values to the CiscoAVPair attribute, for the users that you want to have access to Cisco IMC:

Role	CiscoAVPair Attribute Value
admin	shell:roles="admin"
user	shell:roles="user"
read-only	shell:roles="read-only"

**Note** For more information about adding values to attributes, see the article at <http://technet.microsoft.com/en-us/library/bb727064.aspx>.

### What to Do Next

Use the Cisco IMC to configure the LDAP server.

## Configuring LDAP in Cisco IMC

Configure LDAP in Cisco IMC when you want to use an LDAP server for local user authentication and authorization.

### Before You Begin

You must log in as a user with admin privileges to perform this task.

**Procedure**

	<b>Command or Action</b>	<b>Purpose</b>
<b>Step 1</b>	Server# <b>scope ldap</b>	Enters the LDAP command mode.
<b>Step 2</b>	Server /ldap # <b>set enabled</b> {yes   no}	Enables or disables LDAP security. When enabled, user authentication and role authorization is performed by LDAP for user accounts not found in the local user database.
<b>Step 3</b>	Server /ldap # <b>set domain</b> <i>LDAP domain name</i>	Specifies an LDAP domain name.
<b>Step 4</b>	Server /ldap # <b>set timeout</b> <i>seconds</i>	Specifies the number of seconds the Cisco IMC waits until the LDAP search operation times out. The value must be between 0 and 1800 seconds.
<b>Step 5</b>	Server /ldap # <b>set encrypted</b> {yes   no}	If encryption is enabled, the server encrypts all information sent to AD.
<b>Step 6</b>	Server /ldap # <b>set base-dn</b> <i>domain-name</i>	Specifies the Base DN that is searched on the LDAP server.
<b>Step 7</b>	Server /ldap # <b>set attribute</b> <i>name</i>	<p>Specify an LDAP attribute that contains the role and locale information for the user. This property is always a name-value pair. The system queries the user record for the value that matches this attribute name.</p> <p>You can use an existing LDAP attribute that is mapped to the Cisco IMC user roles and locales or you can create a custom attribute, such as the CiscoAVPair attribute, which has the following attribute ID:</p> <p>1.3.6.1.4.1.9.287247.1</p> <p><b>Note</b> If you do not specify this property, user access is denied.</p>
<b>Step 8</b>	Server /ldap # <b>set filter-attribute</b>	Specifies the account name attribute. If Active Directory is used, then specify <b>sAMAccountName</b> for this field.
<b>Step 9</b>	Server /ldap # <b>commit</b>	Commits the transaction to the system configuration.
<b>Step 10</b>	Server /ldap # <b>show [detail]</b>	(Optional) Displays the LDAP configuration.

This example configures LDAP using the CiscoAVPair attribute:

```
Server# scope ldap
Server /ldap # set enabled yes
Server /ldap *# set domain sample-domain
Server /ldap *# set timeout 60
Server /ldap *# set encrypted yes
Server /ldap *# set base-dn example.com
Server /ldap *# set attribute CiscoAVPair
Server /ldap *# set filter-attribute sAMAccountName
Server /ldap *# commit
Server /ldap # show detail
```

```
LDAP Settings:
  Enabled: yes
  Encrypted: yes
  Domain: sample-domain
  BaseDN: example.com
  Timeout: 60
  Filter-Attribute: sAMAccountName
  Attribute: CiscoAvPair
Server /ldap #
```

**What to Do Next**

If you want to use LDAP groups for group authorization, see *Configuring LDAP Groups in Cisco IMC*.

# Configuring LDAP Groups in Cisco IMC



**Note**

When Active Directory (AD) group authorization is enabled and configured, user authentication is also done on the group level for users that are not found in the local user database or who are not individually authorized to use Cisco IMC in the Active Directory.

**Before You Begin**

- You must log in as a user with admin privileges to perform this task.
- Active Directory (or LDAP) must be enabled and configured.

**Procedure**

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope ldap</b>	Enters the LDAP command mode for AD configuration.
<b>Step 2</b>	Server /ldap# <b>scope ldap-group-rule</b>	Enters the LDAP group rules command mode for AD configuration.
<b>Step 3</b>	Server /ldap/ldap-group-rule # <b>set group-auth {yes   no}</b>	Enables or disables LDAP group authorization.
<b>Step 4</b>	Server /ldap # <b>scope role-group index</b>	Selects one of the available group profiles for configuration, where <i>index</i> is a number between 1 and 28.
<b>Step 5</b>	Server /ldap/role-group # <b>set name group-name</b>	Specifies the name of the group in the AD database that is authorized to access the server.
<b>Step 6</b>	Server /ldap/role-group # <b>set domain domain-name</b>	Specifies the AD domain the group must reside in.
<b>Step 7</b>	Server /ldap/role-group # <b>set role {admin   user   readonly}</b>	Specifies the permission level (role) assigned to all users in this AD group. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>admin</b>—The user can perform all actions available.</li> <li>• <b>user</b>—The user can perform the following tasks:               <ul style="list-style-type: none"> <li>◦ View all information</li> </ul> </li> </ul>

	Command or Action	Purpose
		<ul style="list-style-type: none"> <li>◦ Manage the power control options such as power on, power cycle, and power off</li> <li>◦ Launch the KVM console and virtual media</li> <li>◦ Clear all logs</li> <li>◦ Toggle the locator LED</li> </ul> <ul style="list-style-type: none"> <li>• <b>readonly</b>—The user can view information but cannot make any changes.</li> </ul>
<b>Step 8</b>	Server /ldap/role-group # <b>commit</b>	Commits the transaction to the system configuration.

This example shows how to configure LDAP group authorization:

```
Server# scope ldap
Server /ldap # scope ldap-group-rule
Server /ldap/ldap-group-rule # set group-auth yes
Server /ldap *# scope role-group 5
Server /ldap/role-group # set name Training
Server /ldap/role-group* # set domain example.com
Server /ldap/role-group* # set role readonly
Server /ldap/role-group* # commit
ucs-c250-M2 /ldap # show role-group
Group  Group Name          Domain Name          Assigned Role
-----
1      (n/a)                   (n/a)               admin
2      (n/a)                   (n/a)               user
3      (n/a)                   (n/a)               readonly
4      (n/a)                   (n/a)               (n/a)
5      Training                example.com         readonly

Server /ldap/role-group #
```

## Configuring Nested Group Search Depth in LDAP Groups

You can search for an LDAP group nested within another defined group in an LDAP group map.

- You must log in as a user with admin privileges to perform this task.
- Active Directory (or LDAP) must be enabled and configured.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope ldap</b>	Enters the LDAP command mode for AD configuration.

	Command or Action	Purpose
<b>Step 2</b>	Server /ldap# <b>scope ldap-group-rule</b>	Enters the LDAP group rules command mode for AD configuration.
<b>Step 3</b>	Server /ldap/ldap-group-rule # <b>set group-search-depth value</b>	Enables search for a nested LDAP group.
<b>Step 4</b>	Server /ldap/role-group-rule # <b>commit</b>	Commits the transaction to the system configuration.

This example shows how to search for run a search for an LDAP group nested within another defined group.

```
Server# scope ldap
Server /ldap # scope ldap-group-rule
Server /ldap/ldap-group-rule # set group-search-depth 10
Server /ldap/role-group-rule* # commit
Server /ldap/role-group-rule # show detail
Group rules for LDAP:
  Group search attribute: memberOf
  Enable Group Authorization: yes
  Nested group search depth: 10
Server/ldap/ldap-group-rule #
```

## LDAP Certificates Overview

Cisco C-series servers allow an LDAP client to validate a directory server certificate against an installed CA certificate or chained CA certificate during an LDAP binding step. This feature is introduced in the event where anyone can duplicate a directory server for user authentication and cause a security breach due to the inability to enter a trusted point or chained certificate into the Cisco IMC for remote user authentication.

An LDAP client needs a new configuration option to validate the directory server certificate during the encrypted TLS/SSL communication.

## Exporting LDAP CA Certificate

### Before You Begin

You must log in as a user with admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope ldap</b>	Enters the LDAP command mode.
<b>Step 2</b>	Server# /ldap <b>scope binding-certificate</b>	Enters the LDAP CA certificate binding command mode.

	Command or Action	Purpose
<b>Step 3</b>	<pre>Server /ldap/binding-certificate # export-ca-certificate remote-protocol IP Address LDAP CA Certificate file</pre>	<p>Specifies the protocol to connect to the remote server. It can be of the following types:</p> <ul style="list-style-type: none"> <li>• TFTP</li> <li>• FTP</li> <li>• SFTP</li> <li>• SCP</li> <li>• HTTP</li> </ul> <p><b>Note</b> The Cisco UCS C-Series server now supports fingerprint confirmation of the server when you update firmware through a remote server. This option is available only if you choose SCP or SFTP as the remote server type.</p> <p>If you chose SCP or SFTP as the remote server type while performing this action, a prompt with the message Server (RSA) key fingerprint is &lt;server_finger_print_ID&gt; Do you wish to continue? Click y or n depending on the authenticity of the server fingerprint.</p> <p>The fingerprint is based on the host's public key and helps you to identify or verify the host you are connecting to.</p> <p>Initiates the export of the certificate.</p>

This example exports the LDAP certificate:

```
Server # scope ldap
Server /ldap # scope binding-certificate
Server /ldap/binding-certificate # export-ca-certificate tftp 172.22.141.66 test.csv
Initiating Export
% Total      % Received % Xferd  Average Speed   Time    Time     Time  Current
   Dload  Upload   Total   Spent    Left     Speed
100 1262    0     0  100 1262      0  1244  0:00:01  0:00:01  --:--:-- 1653
100 1262    0     0  100 1262      0  1237  0:00:01  0:00:01  --:--:-- 1237
LDAP CA Certificate is exported successfully
Server /ldap/binding-certificate #
```

## Downloading LDAP CA Certificate Content by Copying Content

### Before You Begin

You must log in as a user with admin privileges to perform this task.



**Procedure**

	<b>Command or Action</b>	<b>Purpose</b>
<b>Step 1</b>	Server# <b>scope ldap</b>	Enters the LDAP command mode.
<b>Step 2</b>	Server# /ldap <b>scope binding-certificate</b>	Enters the LDAP CA certificate binding command mode.
<b>Step 3</b>	Server# /ldap/binding-certificate <b>set enabled {yes   no}</b>	Enables or disables LDAP CA certificate binding.
<b>Step 4</b>	Server /ldap/binding-certificate* # <b>commit</b>	Commits the transaction to the system configuration.
<b>Step 5</b>	Server /ldap/binding-certificate # <b>paste-ca-certificate</b>	Prompts you to paste the certificate content.
<b>Step 6</b>	Paste the certificate content and press <b>CTRL+D</b> .	Confirmation prompt appears.
<b>Step 7</b>	At the confirmation prompt, enter <b>y</b> .	This begins the download of the LDAP CA certificate.

This example downloads the LDAP certificate:

```

Server # scope ldap
Server /ldap # scope binding-certificate
Server /ldap/binding-certificate # set enabled yes
Server /ldap/binding-certificate *# commit
Server /ldap/binding-certificate # show detail
LDAP binding with Certificate:
  Enabled: yes
Server /ldap/binding-certificate # paste-ca-certificate
  Please paste your certificate here, when finished, press CTRL+D.
-----BEGIN CERTIFICATE-----
MIIDdzCCAl+gAwIBAgIQV06yJcJPAYNO8Cp+FYQttjANBgkqhkiG9w0BAQsFADBO
MRIwEAYKCZImiZPyLGBGRYCaW4xGzAZBgoJkiaJk/IsZAEZFgsOT0JKUkEySkhC
UTEbMBkGA1UEAxMSV01OLTRPQkpSQTJKSEJRLUNBMB4XDTE2MDIyNTE3MDCzNlOx
DTIwMDIyNTE3MTCzNlOwTjESMBAGCgMSJomT8ixkARKWAmLUrSwGQYKCZImiZPy
LGBGRYLnE9CSlJBMkpIQlExGzAZBgNVBAMTEldJTi00T0JKUkEySkhCUS1DQTC
ASiWdQYJKoZIhvcNAQEBBQADggEPADCCAQoCggEBAMM2cdgmrPTkZe4K2zI+EbeZ
mfQnjfiUz8OIY97w8lC/2S4qK46T+fnX13rXe8vvVHAO5wgPDVQTGS4nlF46A6Ba
FK+krKcIgfRQB1gnF74qs/ln1YtKHNbjrv5KyeWFrA7So6Mi2XEw8w/zMPL0d8T
b+LM1YnhnuXA9G8gVCJ/iUhXfMpB20L8sv30Mek7bw8x2cxJYTuJAviViRjSwU5j
fO3WKttRuyFpeOIi00weklpF0+8D3Z9mBinoTbL2pl0U32am6wTI+8WmtJ+8W68v
jH4Y8YBY/kzMHdpwjdZkC5pE9BcM0rL9xKoLu6X0kSNEssoGnepFyNaH3t8vnmC
AwEAAaNRME8wCwYDVR0PBAQDAgGMA8GA1UdEwEB/wQFMAMBAf8wHQYDVR0OBBYE
FBAUulHTAWBT1OBz8IgaEzXsfccsMBAGCSsGAQQBgjcVAQQDAgEAMA0GCSqGSIb3
DQEBChUAA4IBAQAazUMZr+0rldWkVfFNBd7lu8tQbAEJf/A7PIKnJGNoUq8moAGS4
pMndoxdpNGZhyCWDWX3GWdeF1HqZHhb38gQ9y1u0pIK7tgQufZmeCBH6T7Tzq/w
Dq+TMFGIjXF84xW3N665y4ePgUcUI7e/6aBGcGkGeUYodBPTExe28tQyeyYwD4Zj
nLuZKkT+I4PAYygVCqxDGsvfRHDpGneb3R+GeonOf4ED/0tn5PLSL9khh9qkHu/V
do3/HmKVzUhl0TDBuAMq/wES2WZAWHGr3hBc4nWQNjZWEMOKDpYZVK/GhBmNF+xi
eRcFqgh64oEmH9qAp0caGS1e7UyYan+LtPRE
-----END CERTIFICATE-----
CTRL+D
You are going to overwrite the LDAP CA Certificate.
Are you sure you want to proceed and overwrite the LDAP CA Certificate? [y|N]
y
Server /ldap/binding-certificate #
    
```

## Downloading LDAP CA Certificate Using Remote Server

### Before You Begin

You must log in as a user with admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope ldap</b>	Enters the LDAP command mode.
<b>Step 2</b>	Server# /ldap <b>scope binding-certificate</b>	Enters the LDAP CA certificate binding command mode.
<b>Step 3</b>	Server# /ldap/binding-certificate <b>set enabled {yes   no}</b>	Enables or disables LDAP CA certificate binding.
<b>Step 4</b>	Server /ldap/binding-certificate* # <b>commit</b>	Commits the transaction to the system configuration.
<b>Step 5</b>	Server /ldap/binding-certificate # <b>download-ca-certificate</b> <i>remote-protocol IP Address LDAP CA Certificate file</i>	<p>Specifies the protocol to connect to the remote server. It can be of the following types:</p> <ul style="list-style-type: none"> <li>• TFTP</li> <li>• FTP</li> <li>• SFTP</li> <li>• SCP</li> <li>• HTTP</li> </ul> <p><b>Note</b> The Cisco UCS C-Series server now supports fingerprint confirmation of the server when you update firmware through a remote server. This option is available only if you choose SCP or SFTP as the remote server type.</p> <p>If you chose SCP or SFTP as the remote server type while performing this action, a prompt with the message Server (RSA) key fingerprint is &lt;server_finger_print_ID&gt; Do you wish to continue? Click y or n depending on the authenticity of the server fingerprint.</p> <p>The fingerprint is based on the host's public key and helps you to identify or verify the host you are connecting to.</p>
<b>Step 6</b>	At the confirmation prompt, enter <b>y</b> .	This begins the download of the LDAP CA certificate.

This example downloads the LDAP certificate:

```

Server # scope ldap
Server /ldap # scope binding-certificate
Server /ldap/binding-certificate # set enabled yes
Server /ldap/binding-certificate *# commit
Server /ldap/binding-certificate # show detail
LDAP binding with Certificate:
    Enabled: yes
Server /ldap/binding-certificate # download-ca-certificate tftp 172.22.141.66
new_com_chain.cer
% Total      % Received % Xferd  Average Speed   Time    Time       Time  Current
   Dload  Upload  Total   Spent    Left     Speed
100 1282  100 1282    0     0  1247      0  0:00:01  0:00:01  --:--:-- 1635
100 1282  100 1282    0     0  1239      0  0:00:01  0:00:01  --:--:-- 1239
You are going to overwrite the LDAP CA Certificate.
Are you sure you want to proceed and overwrite the LDAP CA Certificate? [y|N]y
LDAP CA Certificate is downloaded successfully
Server /ldap/binding-certificate #
    
```

## Testing LDAP Binding

### Before You Begin

You must log in as a user with admin privileges to perform this task.



**Note**

If you checked the **Enable Encryption** and the **Enable Binding CA Certificate** check boxes, enter the fully qualified domain name (FQDN) of the LDAP server in the LDAP Server field. To resolve the FQDN of the LDAP server, configure the preferred DNS of Cisco IMC network with the appropriate DNS IP address.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope ldap</b>	Enters the LDAP command mode.
<b>Step 2</b>	Server# /ldap <b>scope binding-certificate</b>	Enters the LDAP CA certificate binding command mode.
<b>Step 3</b>	Server /ldap/binding-certificate # <b>test-ldap-binding username</b>	Password prompt appears.
<b>Step 4</b>	Enter the corresponding password.	Authenticates the user.

This example tests the LDAP user binding:

```

Server # scope ldap
Server /ldap # scope binding-certificate
Server /ldap/binding-certificate # test-ldap-binding user
Password:
diagldapbinding: Authenticated by LDAP
User user authenticated successfully.
Server /ldap/binding-certificate #
    
```

## Deleting LDAP CA Certificate

### Before You Begin

You must log in as a user with admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope ldap</b>	Enters the LDAP command mode.
<b>Step 2</b>	Server# /ldap <b>scope binding-certificate</b>	Enters the LDAP CA certificate binding command mode.
<b>Step 3</b>	Server /ldap/binding-certificate # <b>delete-ca-certificate</b>	Confirmation prompt appears.
<b>Step 4</b>	At the confirmation prompt, enter <b>y</b> .	This deletes the LDAP CA certificate.

This example deletes the LDAP certificate:

```
Server # scope ldap
Server /ldap # scope binding-certificate
Server /ldap/binding-certificate # delete-ca-certificate
You are going to delete the LDAP CA Certificate.
Are you sure you want to proceed and delete the LDAP CA Certificate? [y|N]y
LDAP CA Certificate is deleted successfully
Server /ldap/binding-certificate #
```

## Viewing User Sessions

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>show user-session</b>	Displays information about current user sessions.

The command output displays the following information about current user sessions:

Name	Description
<b>Terminate Session</b> button	If your user account is assigned the <b>admin</b> user role, this option enables you to force the associated user session to end. <b>Note</b> You cannot terminate your current session from this tab.
<b>Session ID</b> column	The unique identifier for the session.

Name	Description
User name column	The username for the user.
IP Address column	The IP address from which the user accessed the server. If this is a serial connection, it displays N/A.
Type column	The type of session the user chose to access the server. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>webgui</b>— indicates the user is connected to the server using the web UI.</li> <li>• <b>CLI</b>— indicates the user is connected to the server using CLI.</li> <li>• <b>serial</b>— indicates the user is connected to the server using the serial port.</li> </ul>

This example displays information about current user sessions:

```
Server# show user-session
ID      Name      IP Address      Type      Killable
-----
15      admin     10.20.30.138   CLI      yes
Server /user #
```

# Terminating a User Session

## Before You Begin

You must log in as a user with admin privileges to terminate a user session.

## Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>show user-session</b>	Displays information about current user sessions. The user session to be terminated must be eligible to be terminated (killable) and must not be your own session.
<b>Step 2</b>	Server /user-session # <b>scope user-session session-number</b>	Enters user session command mode for the numbered user session that you want to terminate.
<b>Step 3</b>	Server /user-session # <b>terminate</b>	Terminates the user session.

This example shows how the admin at user session 10 terminates user session 15:

```
Server# show user-session
ID      Name      IP Address      Type      Killable
-----
10      admin     10.20.41.234   CLI      yes
```

```
15      admin          10.20.30.138      CLI          yes
Server# scope user-session 15
Server /user-session # terminate
User session 15 terminated.

Server /user-session #
```



# CHAPTER 9

## Configuring Network-Related Settings

---

This chapter includes the following sections:

- [Server NIC Configuration, page 119](#)
- [Common Properties Configuration, page 121](#)
- [Configuring IPv4, page 123](#)
- [Configuring IPv6, page 125](#)
- [Configuring VLAN, page 129](#)
- [Connecting to a Port Profile, page 131](#)
- [Configuring Interface Properties, page 132](#)
- [Network Security Configuration, page 133](#)
- [Network Time Protocol Configuration, page 135](#)
- [Pinging an IP address, page 136](#)

## Server NIC Configuration

### Server NICs

#### NIC Mode

The NIC mode setting determines which ports can reach the Cisco IMC. The following network mode options are available, depending on your platform:

- **Dedicated**—The management port that is used to access the Cisco IMC.
- **Cisco Card**—Any port on the adapter card that can be used to access the Cisco IMC. The Cisco adapter card has to be installed in a slot with Network the Communications Services Interface protocol support (NCSI).

## NIC Redundancy

The following NIC redundancy options are available, depending on the selected NIC mode and your platform:

- **active-active**—If supported, all ports that are associated with the configured NIC mode operate simultaneously. This feature increases throughput and provides multiple paths to the Cisco IMC.
- **active-standby**—If a port that is associated with the configured NIC mode fails, traffic fails over to one of the other ports associated with the NIC mode.



**Note** If you choose this option, make sure that all ports associated with the configured NIC mode are connected to the same subnet to ensure that traffic is secure regardless of which port is used.

The available redundancy modes vary depending on the selected network mode and your platform. For the available modes, see the *Hardware Installation Guide* (HIG) for the type of server you are using. The C-Series HIGs are available at the following URL: [http://www.cisco.com/en/US/products/ps10493/prod\\_installation\\_guides\\_list.html](http://www.cisco.com/en/US/products/ps10493/prod_installation_guides_list.html)

## Configuring NICs

Configure a server NIC when you want to set the NIC mode and NIC redundancy.

### Before You Begin

You must log in as a user with admin privileges to configure the NIC.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope network</b>	Enters the Cisco IMC network command mode.
<b>Step 2</b>	Server /network # <b>set mode</b> { <b>dedicated</b>   <b>cisco_card</b> }	Sets the NIC mode to one of the following: <ul style="list-style-type: none"> <li>• <b>Dedicated</b>—The management Ethernet port is used to access the Cisco IMC.</li> <li>• <b>Cisco card</b>—The ports on the adapter card are used to access the Cisco IMC.</li> </ul>
<b>Step 3</b>	Server /network # <b>set redundancy</b> { <b>none</b>   <b>active-active</b>   <b>active-standby</b> }	Sets the NIC redundancy mode when the NIC mode is Shared LOM. The redundancy mode can be one of the following: <ul style="list-style-type: none"> <li>• <b>none</b>—The LOM Ethernet ports operate independently and do not fail over if there is a problem.</li> <li>• <b>active-active</b>—If supported, all LOM Ethernet ports are utilized.</li> <li>• <b>active-standby</b>—If one LOM Ethernet port fails, traffic fails over to another LOM port.</li> </ul>



	Command or Action	Purpose
<b>Step 4</b>	Server /network # <b>commit</b>	Commits the transaction to the system configuration.  <b>Note</b> The available NIC mode and NIC redundancy mode options may vary depending on your platform. If you select a mode not supported by your server, an error message displays when you save your changes.
<b>Step 5</b>	At the prompt, enter y to confirm.	Configures the server NIC.

This example configures the Cisco IMC network interface:

```
Server # scope network
Server /network # set mode cisco_card
Server /network *# set redundancy <active-active>
Server /network *# commit
Changes to the network settings will be applied immediately.
You may lose connectivity to the Cisco IMC and may have to log in again.
Do you wish to continue? [y/N] y
Server /network #
```

## Common Properties Configuration

### Overview to Common Properties Configuration

#### Hostname

The Dynamic Host Configuration Protocol (DHCP) enhancement is available with the addition of the hostname to the DHCP packet, which can either be interpreted or displayed at the DHCP server side. The hostname, which is now added to the options field of the DHCP packet, sent in the DHCP DISCOVER packet that was initially sent to the DHCP server.

The default hostname of the server is changed from ucs-c2XX to CXXX-YYYYYY, where XXX is the model number and YYYYYY is the serial number of the server. This unique string acts as a client identifier, allows you to track and map the IP addresses that are leased out to Cisco IMC from the DHCP server. The default serial number is provided by the manufacturer as a sticker or label on the server to help you identify the server.

#### Dynamic DNS

Dynamic DNS (DDNS) is used to add or update the resource records on the DNS server from Cisco IMC. You can enable Dynamic DNS by using either the web UI or CLI. When you enable the DDNS option, the DDNS service records the current hostname, domain name, and the management IP address and updates the resource records in the DNS server from Cisco IMC.

**Note**

The DDNS server deletes the prior resource records (if any) and adds the new resource records to the DNS server if any one of the following DNS configuration is changed:

- Hostname
- Domain name in the LDAP settings
- When DDNS and DHCP are enabled, if the DHCP gets a new IP address or DNS IP or domain name due to a change in a network or a subnet.
- When DHCP is disabled and if you set the static IP address by using CLI or web UI.
- When you enter the **dns-use-dhcp** command.

**Dynamic DNS Update Domain**— You can specify the domain. The domain could be either main domain or any sub-domain. This domain name is appended to the hostname of the Cisco IMC for the DDNS update.

## Configuring Common Properties

Use common properties to describe your server.

### Before You Begin

You must log in as a user with admin privileges to configure common properties.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope network</b>	Enters the Cisco IMC network command mode.
<b>Step 2</b>	Server /network # <b>set hostname-bmc1 hostname-bmc2hostname-cmc1hostname-cmc2host-name</b>	<p>Specifies the name of the host for the following components:</p> <ul style="list-style-type: none"> <li>• <b>BMC 1</b></li> <li>• <b>BMC 2</b></li> <li>• <b>CMC 1</b></li> <li>• <b>CMC 2</b></li> </ul> <p>When you modify the hostname, you are prompted to confirm whether you want to create a new self-signed certificate with Common Name (CN) as the new hostname.</p> <p>If you enter <b>y</b> at the prompt, a new self-signed certificate is created with CN as the new hostname.</p>

	Command or Action	Purpose
		If you enter <b>n</b> at the prompt, only the hostname is changed and no certificate will be generated.
<b>Step 3</b>	Server /network # <b>set ddns-enabled</b>	(Optional) Enables the DDNS service for Cisco IMC
<b>Step 4</b>	Server /network # <b>set ddns-update-domain</b> <i>value</i>	(Optional) Updates the selected domain or its subdomain.
<b>Step 5</b>	Server /network # <b>commit</b>	Commits the transaction to the system configuration.
<b>Step 6</b>	At the prompt, enter y to confirm.	Configures common properties.

This example shows how to configure the common properties:

```
Server # scope network
Server /network # set hostname-cmcl cmcl
Server /network *# set ddns-enabled
Server /network *# set ddns-update-domain 1.2.3.4
Server /network *# commit
Changes to the network settings will be applied immediately.
You may lose connectivity to the Cisco IMC and may have to log in again.
Do you wish to continue? [y/N] y
Server /network #
```

### What to Do Next

Changes to the network are applied immediately. You might lose connectivity to Cisco IMC and have to log in again. Because of the new SSH session created, you may be prompted to confirm the host key.

## Configuring IPv4

### Before You Begin

You must log in as a user with admin privileges to configure IPv4 network settings.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope network</b>	Enters the Cisco IMC network command mode.

	Command or Action	Purpose
<b>Step 2</b>	Server /network # <b>set dhcp-enabled</b> {yes   no}	Selects whether the Cisco IMC uses DHCP. <b>Note</b> If DHCP is enabled, we recommend that the DHCP server be configured to reserve a single IP address for the Cisco IMC. If the Cisco IMC is reachable through multiple ports on the server, the single IP address must be reserved for the full range of MAC addresses of those ports.
<b>Step 3</b>	Server /network # <b>set v4-addr</b> <i>ipv4-address</i>	Specifies the IP address for the Cisco IMC.
<b>Step 4</b>	Server /network # <b>set v4-netmask</b> <i>ipv4-netmask</i>	Specifies the subnet mask for the IP address.
<b>Step 5</b>	Server /network # <b>set v4-gateway</b> <i>gateway-ipv4-address</i>	Specifies the gateway for the IP address.
<b>Step 6</b>	Server /network # <b>set dns-use-dhcp</b> {yes   no}	Selects whether the Cisco IMC retrieves the DNS server addresses from DHCP.
<b>Step 7</b>	Server /network # <b>set preferred-dns-server</b> <i>dns1-ipv4-address</i>	Specifies the IP address of the primary DNS server.
<b>Step 8</b>	Server /network # <b>set alternate-dns-server</b> <i>dns2-ipv4-address</i>	Specifies the IP address of the secondary DNS server.
<b>Step 9</b>	Server /network # <b>commit</b>	Commits the transaction to the system configuration.
<b>Step 10</b>	At the prompt, enter y to confirm.	Configures IPv4.
<b>Step 11</b>	Server /network # <b>show [detail]</b>	(Optional) Displays the IPv4 network settings.

This example configures and displays the IPv4 network settings:

```

Server # scope network
Server /network # set dhcp-enabled yes
Server /network *# set v4-addr 10.20.30.11
Server /network *# set v4-netmask 255.255.248.0
Server /network *# set v4-gateway 10.20.30.1
Server /network *# set dns-use-dhcp-enabled no
Server /network *# set preferred-dns-server 192.168.30.31
Server /network *# set alternate-dns-server 192.168.30.32
Server /network *# commit
Changes to the network settings will be applied immediately.
You may lose connectivity to the Cisco IMC and may have to log in again.
Do you wish to continue? [y/N] y
Server /network # show detail
Network Setting:
  IPv4 Enabled: yes
  IPv4 Netmask: 255.255.248.0
  IPv4 Gateway: 10.20.30.1
  DHCP Enabled: no
  DDNS Enabled: yes
  DDNS Update Domain:
  Obtain DNS Server by DHCP: no
  Preferred DNS: 192.168.30.31

```

```

Alternate DNS: 192.168.30.32
IPv6 Enabled: no
IPv6 Prefix: 64
IPv6 Gateway: ::
IPv6 DHCP Enabled: no
IPv6 Obtain DNS Server by DHCP: no
IPv6 Preferred DNS: ::
IPv6 Alternate DNS: ::
VLAN Enabled: no
VLAN ID: 1
VLAN Priority: 0
Port Profile: abcde12345
NIC Mode: dedicated
NIC Redundancy: none
SIOC Slot: 1
Management IPv4 Address: 10.106.145.202
Management IPv6 Address: ::
Management Hostname: C3260-FCH18207WF3
Network Speed: 100Mbps
Duplex: full
Auto Negotiate: yes
Admin Network Speed: auto
Admin Duplex: auto
Operational Network Speed: 1Gbps
Operational Duplex: full
CMC 1 Network Setting:
IPv4 Address CMC 1: 10.20.30.11
IPv6 Address CMC 1: ::
IPv6 Link Local CMC 1: ::
IPv6 SLAAC Address CMC 1: ::
Hostname CMC 1: UCS-C3260-FCH181772ZP-1
MAC Address CMC 1: F4:CF:E2:77:7F:D2
CMC 2 Network Setting:
IPv4 Address CMC 2: 10.20.30.11
IPv6 Address CMC 2: ::
IPv6 Link Local CMC 2: ::
IPv6 SLAAC Address CMC 2: ::
Hostname CMC 2: UCS-C3260--2
MAC Address CMC 2: F4:CF:E2:77:80:83
BMC 1 Network Setting:
IPv4 Address BMC 1: 10.20.30.11
IPv6 Address BMC 1: ::
IPv6 Link Local BMC 1: ::
IPv6 SLAAC Address BMC 1: ::
Hostname BMC 1: C3160-FCH1827K9YT
MAC Address BMC 1: 7C:0E:CE:5A:EF:26
BMC 2 Network Setting:
IPv4 Address BMC 2: 10.20.30.11
IPv6 Address BMC 2: ::
IPv6 Link Local BMC 2: ::
IPv6 SLAAC Address BMC 2: ::
Hostname BMC 2: C3160-FCH18407MYD
MAC Address BMC 2: A0:EC:F9:85:90:3F

```

```
Server /network #
```

## Configuring IPv6

### Before You Begin

You must log in as a user with admin privileges to configure IPv6 network settings.

## Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope network</b>	Enters the Cisco IMC network command mode.
<b>Step 2</b>	Server /network # <b>set v6-enabled {yes   no}</b>	Enables IPv6.
<b>Step 3</b>	Server /network # <b>set v6-dhcp-enabled {yes   no}</b>	Selects whether the Cisco IMC uses DHCP. <b>Note</b> If DHCP is enabled, we recommend that the DHCP server be configured to reserve a single IPv6 address for the Cisco IMC. If the Cisco IMC is reachable through multiple ports on the server, the single IPv6 address must be reserved for the full range of MAC addresses of those ports.
<b>Step 4</b>	Server /network # <b>set v6-addr-bmc1v6-addr-bmc2v6-addr-cmc1v6-addr-cmc2v6-addr-mgmtip6-address</b>	Specifies the IP address for the following components: <ul style="list-style-type: none"> <li>• BMC1 IPv6 Address</li> <li>• BMC2 IPv6 Address</li> <li>• CMC1 IPv6 Address</li> <li>• CMC2 IPv6 Address</li> <li>• Management IPv6 Address</li> </ul>
<b>Step 5</b>	Server /network # <b>set v6-prefix ipv6-prefix-length</b>	Specifies the prefix length for the IP address.
<b>Step 6</b>	Server /network # <b>set v6-gateway gateway-ipv6-address</b>	Specifies the gateway for the IP address.
<b>Step 7</b>	Server /network # <b>set v6-dns-use-dhcp {yes   no}</b>	Selects whether the Cisco IMC retrieves the DNS server addresses from DHCP. <b>Note</b> You can use this option only when DHCP enabled.
<b>Step 8</b>	Server /network # <b>set v6-preferred-dns-server dns1-ipv6-address</b>	Specifies the IP address of the primary DNS server.
<b>Step 9</b>	Server /network # <b>set v6-alternate-dns-server dns2-ipv6-address</b>	Specifies the IP address of the secondary DNS server.

	Command or Action	Purpose
<b>Step 10</b>	Server /network # <b>commit</b>	Commits the transaction to the system configuration.
<b>Step 11</b>	At the prompt, enter y to confirm.	Configures IPv6.
<b>Step 12</b>	Server /network # <b>show [detail]</b>	(Optional) Displays the IPv6 network settings.

This example enables static IPv6 and displays the IPv6 network settings:

```

Server # scope network
Server /network # set v6-enabled yes
Server /network *# set v6-addr-bmc1 2010:201::279
Server /network *# set v6-gateway 2010:201::1
Server /network *# set v6-prefix 64
Server /network *# set v6-dns-use-dhcp no
Server /network *# set v6-preferred-dns-server 2010:201::100
Server /network *# set v6-alternate-dns-server 2010:201::101
Changes to the network settings will be applied immediately.
You may lose connectivity to the Cisco IMC and may have to log in again.
Server /network *# commit
Changes to the network settings will be applied immediately.
You may lose connectivity to the Cisco IMC and may have to log in again.
Do you wish to continue? [y/N] y
Server /network # show detail
Network Setting:
  IPv4 Enabled: yes
  IPv4 Netmask: 255.255.255.0
  IPv4 Gateway: 10.106.145.1
  DHCP Enabled: no
  DDNS Enabled: yes
  DDNS Update Domain:
  Obtain DNS Server by DHCP: no
  Preferred DNS: 171.70.168.183
  Alternate DNS: 0.0.0.0
  IPv6 Enabled: no
  IPv6 Prefix: 64
  IPv6 Gateway: 2010:201::1
  IPV6 DHCP Enabled: no
  IPV6 Obtain DNS Server by DHCP: no
  IPV6 Preferred DNS: 2010:201::100
  IPV6 Alternate DNS: 2010:201::101
  VLAN Enabled: no
  VLAN ID: 1
  VLAN Priority: 0
  Port Profile: abcde12345
  NIC Mode: dedicated
  NIC Redundancy: none
  SIOC Slot: 1
  Management IPv4 Address: 10.106.145.202
  Management IPv6 Address: ::
  Management Hostname: C3260-FCH18207WF3
  Network Speed: 100Mbps
  Duplex: full
  Auto Negotiate: yes
  Admin Network Speed: auto
  Admin Duplex: auto
  Operational Network Speed: 1Gbps
  Operational Duplex: full
CMC 1 Network Setting:
  IPv4 Address CMC 1: 10.106.145.135
  IPv6 Address CMC 1: ::
  IPv6 Link Local CMC 1: ::
  IPv6 SLAAC Address CMC 1: ::
    
```

```

      Hostname CMC 1: UCS-C3260-FCH181772ZP-1
      MAC Address CMC 1: F4:CF:E2:77:7F:D2
CMC 2 Network Setting:
      IPv4 Address CMC 2: 10.106.145.248
      IPv6 Address CMC 2:  ::
      IPv6 Link Local CMC 2:  ::
      IPv6 SLAAC Address CMC 2:  ::
      Hostname CMC 2: UCS-C3260--2
      MAC Address CMC 2: F4:CF:E2:77:80:83
BMC 1 Network Setting:
      IPv4 Address BMC 1: 10.106.145.41
      IPv6 Address BMC 1: 2010:201::279
      IPv6 Link Local BMC 1:  ::
      IPv6 SLAAC Address BMC 1:  ::
      Hostname BMC 1: C3160-FCH1827K9YT
      MAC Address BMC 1: 7C:0E:CE:5A:EF:26
BMC 2 Network Setting:
      IPv4 Address BMC 2: 10.106.145.39
      IPv6 Address BMC 2:  ::
      IPv6 Link Local BMC 2:  ::
      IPv6 SLAAC Address BMC 2:  ::
      Hostname BMC 2: C3160-FCH18407MYD
      MAC Address BMC 2: A0:EC:F9:85:90:3F

```

```
Server /network #
```

This example enables DHCP for IPv6 and displays the IPv6 network settings:

```

Server # scope network
Server /network # set v6-enabled yes
Server /network *# set v6-dhcp-enabled yes
Changes to the network settings will be applied immediately.
You may lose connectivity to the Cisco IMC and may have to log in again.
Server /network *# commit
Changes to the network settings will be applied immediately.
You may lose connectivity to the Cisco IMC and may have to log in again.
Do you wish to continue? [y/N] y
Server /network # show detail
Network Setting:
  IPv4 Enabled: yes
  IPv4 Address: 10.106.145.76
  IPv4 Netmask: 255.255.255.0
  IPv4 Gateway: 10.106.145.1
  DHCP Enabled: yes
  DDNS Enabled: yes
  DDNS Update Domain: example.com
  Obtain DNS Server by DHCP: no
  Preferred DNS: 171.70.168.183
  Alternate DNS: 0.0.0.0
  IPv6 Enabled: yes
  IPv6 Address: 2010:201::253
  IPv6 Prefix: 64
  IPv6 Gateway: fe80::222:ddf:fec2:8000
  IPv6 Link Local: fe80::523d:e5ff:fe9d:395d
  IPv6 SLAAC Address: 2010:201::523d:e5ff:fe9d:395d
  IPV6 DHCP Enabled: yes
  IPV6 Obtain DNS Server by DHCP: no
  IPV6 Preferred DNS: ::
  IPV6 Alternate DNS: ::
  VLAN Enabled: no
  VLAN ID: 1
  VLAN Priority: 0
  Port Profile:
  Hostname: CIMC_C220
  MAC Address: 50:3D:E5:9D:39:5C
  NIC Mode: dedicated
  NIC Redundancy: none
  Network Speed: 100Mbps
  Duplex: full
  Auto Negotiate: no
  Admin Network Speed: auto
  Admin Duplex: auto
  Operational Network Speed: 1Gbps

```



```

Operational Duplex: full
CMC 1 Network Setting:
IPv4 Address CMC 1: 10.106.145.135
IPv6 Address CMC 1: ::
IPv6 Link Local CMC 1: ::
IPv6 SLAAC Address CMC 1: ::
Hostname CMC 1: UCS-C3260-FCH181772ZP-1
MAC Address CMC 1: F4:CF:E2:77:7F:D2
CMC 2 Network Setting:
IPv4 Address CMC 2: 10.106.145.248
IPv6 Address CMC 2: ::
IPv6 Link Local CMC 2: ::
IPv6 SLAAC Address CMC 2: ::
Hostname CMC 2: UCS-C3260--2
MAC Address CMC 2: F4:CF:E2:77:80:83
BMC 1 Network Setting:
IPv4 Address BMC 1: 10.106.145.41
IPv6 Address BMC 1: ::
IPv6 Link Local BMC 1: ::
IPv6 SLAAC Address BMC 1: ::
Hostname BMC 1: C3160-FCH1827K9YT
MAC Address BMC 1: 7C:0E:CE:5A:EF:26
BMC 2 Network Setting:
IPv4 Address BMC 2: 10.106.145.39
IPv6 Address BMC 2: ::
IPv6 Link Local BMC 2: ::
IPv6 SLAAC Address BMC 2: ::
Hostname BMC 2: C3160-FCH18407MYD
MAC Address BMC 2: A0:EC:F9:85:90:3F

```

```
Server /network #
```

## Configuring VLAN

### Before You Begin

You must be logged in as admin to configure the server VLAN.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope network</b>	Enters the Cisco IMC network command mode.
<b>Step 2</b>	Server /network # <b>set vlan-enabled {yes   no}</b>	Selects whether the Cisco IMC is connected to a VLAN.
<b>Step 3</b>	Server /network # <b>set vlan-id <i>id</i></b>	Specifies the VLAN number.
<b>Step 4</b>	Server /network # <b>set vlan-priority <i>priority</i></b>	Specifies the priority of this system on the VLAN.
<b>Step 5</b>	Server /network # <b>commit</b>	Commits the transaction to the system configuration.
<b>Step 6</b>	At the prompt, enter y to confirm.	Configures the server LAN.
<b>Step 7</b>	Server /network # <b>show [detail]</b>	(Optional) Displays the network settings.

This example configures the VLAN:

```

Server # scope network
Server /network # set vlan-enabled yes
Server /network *# set vlan-id 5
Server /network *# set vlan-priority 7
Server /network *# commit
Changes to the network settings will be applied immediately.
You may lose connectivity to the Cisco IMC and may have to log in again.
Do you wish to continue? [y/N] y
Server /network # show detail
Network Setting:
  IPv4 Enabled: yes
  IPv4 Netmask: 255.255.255.0
  IPv4 Gateway: 10.106.145.1
  DHCP Enabled: no
  DDNS Enabled: yes
  DDNS Update Domain:
  Obtain DNS Server by DHCP: no
  Preferred DNS: 171.70.168.183
  Alternate DNS: 0.0.0.0
  IPv6 Enabled: no
  IPv6 Prefix: 64
  IPv6 Gateway: ::
  IPV6 DHCP Enabled: no
  IPV6 Obtain DNS Server by DHCP: no
  IPV6 Preferred DNS: ::
  IPV6 Alternate DNS: ::
VLAN Enabled: yes
VLAN ID: 2
VLAN Priority: 7
  Port Profile: abcde12345
  NIC Mode: dedicated
  NIC Redundancy: none
  SIOC Slot: 1
  Management IPv4 Address: 10.106.145.202
  Management IPv6 Address: ::
  Management Hostname: C3260-FCH18207WF3
  Network Speed: 100Mbps
  Duplex: full
  Auto Negotiate: yes
  Admin Network Speed: auto
  Admin Duplex: auto
  Operational Network Speed: 1Gbps
  Operational Duplex: full
CMC 1 Network Setting:
  IPv4 Address CMC 1: 10.106.145.135
  IPv6 Address CMC 1: ::
  IPv6 Link Local CMC 1: ::
  IPv6 SLAAC Address CMC 1: ::
  Hostname CMC 1: UCS-C3260-FCH181772ZP-1
  MAC Address CMC 1: F4:CF:E2:77:7F:D2
CMC 2 Network Setting:
  IPv4 Address CMC 2: 10.106.145.248
  IPv6 Address CMC 2: ::
  IPv6 Link Local CMC 2: ::
  IPv6 SLAAC Address CMC 2: ::
  Hostname CMC 2: UCS-C3260--2
  MAC Address CMC 2: F4:CF:E2:77:80:83
BMC 1 Network Setting:
  IPv4 Address BMC 1: 10.106.145.41
  IPv6 Address BMC 1: ::
  IPv6 Link Local BMC 1: ::
  IPv6 SLAAC Address BMC 1: ::
  Hostname BMC 1: C3160-FCH1827K9YT
  MAC Address BMC 1: 7C:0E:CE:5A:EF:26
BMC 2 Network Setting:
  IPv4 Address BMC 2: 10.106.145.39
  IPv6 Address BMC 2: ::
  IPv6 Link Local BMC 2: ::
  IPv6 SLAAC Address BMC 2: ::

```

```

Hostname BMC 2: C3160-FCH18407MYD
MAC Address BMC 2: A0:EC:F9:85:90:3F

Server /network #
    
```

# Connecting to a Port Profile



**Note** You can configure a port profile or a VLAN, but you cannot use both. If you want to use a port profile, make sure the **set vlan-enabled** command is set to **no**.

## Before You Begin

You must be logged in as admin to connect to a port profile.

## Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope network</b>	Enters the Cisco IMC network command mode.
<b>Step 2</b>	Server /network # <b>set port-profile port_profile_name</b>	Specifies the port profile Cisco IMC should use to configure the management interface, the virtual Ethernet, and the VIF on supported adapter cards such as the Cisco UCS VIC 1225 Virtual Interface Card.  Enter up to 80 alphanumeric characters. You cannot use spaces or other special characters except for - (hyphen) and _ (underscore). In addition, the port profile name cannot begin with a hyphen.  <b>Note</b> The port profile must be defined on the switch to which this server is connected.
<b>Step 3</b>	Server /network # <b>commit</b>	Commits the transaction to the system configuration.
<b>Step 4</b>	At the prompt, enter y to confirm.	Connects to a port profile.
<b>Step 5</b>	Server /network # <b>show [detail]</b>	(Optional) Displays the network settings.

This example connects to port profile abcde12345:

```

Server # scope network
Server /network # set port-profile abcde12345
Server /network *# commit
Changes to the network settings will be applied immediately.
You may lose connectivity to the Cisco IMC and may have to log in again.
Do you wish to continue? [y/N] y
Server /network # show detail
Network Setting:
  IPv4 Enabled: yes
  IPv4 Netmask: 255.255.255.0
  IPv4 Gateway: 10.106.145.1
    
```

```

DHCP Enabled: no
DDNS Enabled: yes
DDNS Update Domain:
Obtain DNS Server by DHCP: no
Preferred DNS: 171.70.168.183
Alternate DNS: 0.0.0.0
IPv6 Enabled: no
IPv6 Prefix: 64
IPv6 Gateway: ::
IPV6 DHCP Enabled: no
IPV6 Obtain DNS Server by DHCP: no
IPV6 Preferred DNS: ::
IPV6 Alternate DNS: ::
VLAN Enabled: no
VLAN ID: 1
VLAN Priority: 0
Port Profile: abcde12345
NIC Mode: dedicated
NIC Redundancy: none
SIOC Slot: 1
Management IPv4 Address: 10.106.145.202
Management IPv6 Address: ::
Management Hostname: C3260-FCH18207WF3
Network Speed: 100Mbps
Duplex: full
Auto Negotiate: yes
Admin Network Speed: auto
Admin Duplex: auto
Operational Network Speed: 1Gbps
Operational Duplex: full
CMC 1 Network Setting:
IPv4 Address CMC 1: 10.106.145.135
IPv6 Address CMC 1: ::
IPv6 Link Local CMC 1: ::
IPv6 SLAAC Address CMC 1: ::
Hostname CMC 1: UCS-C3260-FCH181772ZP-1
MAC Address CMC 1: F4:CF:E2:77:7F:D2
CMC 2 Network Setting:
IPv4 Address CMC 2: 10.106.145.248
IPv6 Address CMC 2: ::
IPv6 Link Local CMC 2: ::
IPv6 SLAAC Address CMC 2: ::
Hostname CMC 2: UCS-C3260--2
MAC Address CMC 2: F4:CF:E2:77:80:83
BMC 1 Network Setting:
IPv4 Address BMC 1: 10.106.145.41
IPv6 Address BMC 1: ::
IPv6 Link Local BMC 1: ::
IPv6 SLAAC Address BMC 1: ::
Hostname BMC 1: C3160-FCH1827K9YT
MAC Address BMC 1: 7C:0E:CE:5A:EF:26
BMC 2 Network Setting:
IPv4 Address BMC 2: 10.106.145.39
IPv6 Address BMC 2: ::
IPv6 Link Local BMC 2: ::
IPv6 SLAAC Address BMC 2: ::
Hostname BMC 2: C3160-FCH18407MYD
MAC Address BMC 2: A0:EC:F9:85:90:3F

Server /network #

```

## Configuring Interface Properties

The settings on the switch must match with the Cisco IMC settings to avoid any speed or duplex mismatch.

**Procedure**

	<b>Command or Action</b>	<b>Purpose</b>
<b>Step 1</b>	Server # <b>scope network</b>	Enters the network command mode.
<b>Step 2</b>	Server /network* # <b>set mode dedicated</b>	Enters dedicated command mode.
<b>Step 3</b>	Server /network* # <b>set auto-negotiate {yes   no}</b>	Enables or disables auto negotiation command mode. <ul style="list-style-type: none"> <li>• If you enter <b>yes</b>, the setting for duplex will be ignored by the system. The Cisco IMC retains the speed at which the switch is configured.</li> <li>• If you enter <b>no</b>, you can set duplex. Else, a default speed of 100 Mbps will be applied, and duplex will retain its previous value.</li> </ul>
<b>Step 4</b>	Server /network* # <b>set duplex {full   half}</b>	Sets specified duplex mode type. By default, the duplex mode is set to <b>Full</b>

This example shows how to configure the interface properties and commit the transaction:

```

Server # scope network
Server /network* # set mode dedicated
Server /network* # set auto-negotiate no
Warning: You have chosen to set auto negotiate to no
        If speed and duplex are not set then a default speed of 100Mbps will be applied
        Duplex will retain its previous value
Server /network* # commit
Server /network # set duplex full
Server /network* # commit
Changes to the network settings will be applied immediately.
You may lose connectivity to the Cisco IMC and may have to log in again.
Do you wish to continue? [y/N] y
Server /network #

```

## Network Security Configuration

### Network Security

The Cisco IMC uses IP blocking as network security. IP blocking prevents the connection between a server or website and certain IP addresses or ranges of addresses. IP blocking effectively bans undesired connections from those computers to a website, mail server, or other Internet servers.

IP banning is commonly used to protect against denial of service (DoS) attacks. Cisco IMC bans IP addresses by setting up an IP blocking fail count.

### Configuring Network Security

Configure network security if you want to set up an IP blocking fail count.

### Before You Begin

You must log in as a user with admin privileges to configure network security.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope network</b>	Enters the Cisco IMC network command mode.
<b>Step 2</b>	Server /network # <b>scope ipblocking</b>	Enters the IP blocking command mode.
<b>Step 3</b>	Server /network/ipblocking # <b>set enabled {yes   no}</b>	Enables or disables IP blocking.
<b>Step 4</b>	Server /cimc/network/ipblocking # <b>set fail-count fail-count</b>	Sets the number of times a user can attempt to log in unsuccessfully before the system locks that user out for a specified length of time.  The number of unsuccessful login attempts must occur within the time frame specified in the IP Blocking Fail Window field.  Enter an integer between 3 and 10.
<b>Step 5</b>	Server /network/ipblocking # <b>set fail-window fail-seconds</b>	Sets the length of time, in seconds, in which the unsuccessful login attempts must occur in order for the user to be locked out.  Enter an integer between 60 and 120.
<b>Step 6</b>	Server /network/ipblocking # <b>set penalty-time penalty-seconds</b>	Sets the number of seconds the user remains locked out if they exceed the maximum number of login attempts within the specified time window.  Enter an integer between 300 and 900.
<b>Step 7</b>	Server /network/ipblocking # <b>commit</b>	Commits the transaction to the system configuration.

This example configures IP blocking:

```
Server # scope network
Server /network # scope ipblocking
Server /network/ipblocking # set enabled yes
Server /network/ipblocking *# set fail-count 5
Server /network/ipblocking *# set fail-window 90
Server /network/ipblocking *# set penalty-time 600
Server /network/ipblocking *# commit
Server /network/ipblocking #
```

# Network Time Protocol Configuration

## Configuring Network Time Protocol Settings

By default, when Cisco IMC is reset, it synchronizes the time with the host. With the introduction of the NTP service, you can configure Cisco IMC to synchronize the time with an NTP server. The NTP server does not run in Cisco IMC by default. You must enable and configure the NTP service by specifying the IP/DNS address of at least one server or a maximum of four servers that function as NTP servers or time source servers. When you enable the NTP service, Cisco IMC synchronizes the time with the configured NTP server. The NTP service can be modified only through Cisco IMC.



**Note** To enable the NTP service, it is preferable to specify the IP address of a server rather than the DNS address.

### Before You Begin

You must log in with admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope time</b>	Enters time command mode.
<b>Step 2</b>	Server /time # <b>scope ntp</b>	Enters NTP service command mode.
<b>Step 3</b>	Server /time/ntp # <b>set enabled yes</b>	Enables the NTP service on the server.
<b>Step 4</b>	Server /time/ntp* # <b>commit</b>	Commits the transaction.
<b>Step 5</b>	Server /time/ntp # <b>set server-1 10.120.33.44</b>	Specifies the IP/DNS address of one of the four servers that act as an NTP server or the time source server.
<b>Step 6</b>	Server /time/ntp # <b>set server-2 10.120.34.45</b>	Specifies the IP/DNS address of one of the four servers that act as an NTP server or the time source server.
<b>Step 7</b>	Server /time/ntp # <b>set server-3 10.120.35.46</b>	Specifies the IP/DNS address of one of the four servers that act as an NTP server or the time source server.
<b>Step 8</b>	Server /time/ntp # <b>set server-4 10.120.36.48</b>	Specifies the IP/DNS address of one of the four servers that act as an NTP server or the time source server.
<b>Step 9</b>	Server /time/ntp # <b>commit</b>	Commits the transaction.
<b>Step 10</b>	Server /time/ntp # <b>show detail</b>	Displays the NTP configuration details.

This example shows how to configure the NTP service:

```
Server # scope time
Server /time # scope ntp
Server /time/ntp # set enabled yes
Warning: IPMI Set SEL Time Command will be
disabled if NTP is enabled.
Do you wish to continue? [y|N]
y
Server /time/ntp* # commit
Server /time/ntp # set server-1 10.120.33.44
Server /time/ntp* # set server-2 10.120.34.45
Server /time/ntp* # set server-3 10.120.35.46
Server /time/ntp* # set server-4 10.120.36.48
Server /time/ntp* # commit
Server /time/ntp # show details
NTP Service Settings:
  NTP Enabled: yes
  NTP Server 1: 10.120.33.44
  NTP Server 2: 10.120.34.45
  NTP Server 3: 10.120.35.46
  NTP Server 4: 10.120.36.48
  Status: NTP service enabled
```

## Pinging an IP address

Ping an IP address when you want to validate network connectivity with the IP address in the Cisco IMC.

### Before You Begin

You must log in as a user with administration privileges to ping an IP address.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope network</b>	Enters the network command mode.
<b>Step 2</b>	Server /network# <b>ping IP address   retriesnumber   timeoutseconds</b>	<p>Pings the IP address or host name for a specified number of times until timeout.</p> <ul style="list-style-type: none"> <li>• <b>IP address/hostname</b> - The IP address or the host name of the server.</li> <li>• <b>Number of retries</b> - The number of times the system tries to connect to the server. Default value is 3. Valid range is from 1 to 10.</li> <li>• <b>Timeout</b> - The number of seconds the system waits before it stops pinging. Default maximum value is 20 seconds. Valid range is from 1 to 20 seconds.</li> <li>• <b>Component</b> - The controller that you can ping.</li> </ul>
<b>Step 3</b>	Server /network # <b>commit</b>	Commits the transaction to the system configuration.
<b>Step 4</b>	At the prompt, enter y to confirm.	Pings the IP address.



This example pings an IP address:

```
Server # scope network
Server /network # ping 10.10.10.10
PING 10.10.10.10 (10.10.10.10): 56 data bytes
64 bytes from 10.10.10.10: seq=0 ttl=238 time=146.343 ms
64 bytes from 10.10.10.10: seq=1 ttl=238 time=146.140 ms
64 bytes from 10.10.10.10: seq=2 ttl=238 time=146.238 ms

--- 10.10.10.10 ping statistics ---
3 packets transmitted, 3 packets received, 0% packet loss
round-trip min/avg/max = 146.140/146.240/146.343 ms
Server /cimc/network #
```





## Managing Network Adapters

---

This chapter includes the following sections:

- [Overview of the Cisco UCS C-Series Network Adapters, page 139](#)
- [Viewing Network Adapter Properties, page 142](#)
- [Configuring Network Adapter Properties, page 143](#)
- [Managing vHBAs, page 144](#)
- [Managing vNICs, page 156](#)
- [Managing VM FEX, page 175](#)
- [Backing Up and Restoring the Adapter Configuration, page 180](#)
- [Managing Adapter Firmware, page 183](#)

## Overview of the Cisco UCS C-Series Network Adapters



**Note**

The procedures in this chapter are available only when a Cisco UCS C-Series network adapter is installed in the chassis.

A Cisco UCS C-Series network adapter can be installed to provide options for I/O consolidation and virtualization support. The following adapters are available:

- Cisco UCS P81E Virtual Interface Card
- Cisco UCS VIC 1225 Virtual Interface Card
- Cisco UCS VIC 1385 Virtual Interface Card
- Cisco UCS VIC 1227T Virtual Interface Card
- Cisco UCS VIC 1387 Virtual Interface Card

The interactive *UCS Hardware and Software Interoperability Utility* lets you view the supported components and configurations for a selected server model and software release. The utility is available at the following URL: <http://www.cisco.com/web/techdoc/ucs/interoperability/matrix/matrix.html>

### Cisco UCS P81E Virtual Interface Card

The Cisco UCS P81E Virtual Interface Card is optimized for virtualized environments, for organizations that seek increased mobility in their physical environments, and for data centers that want reduced costs through NIC, HBA, cabling, and switch reduction and reduced management overhead. This Fibre Channel over Ethernet (FCoE) PCIe card offers the following benefits:

- Allows up to 16 virtual Fibre Channel and 16 virtual Ethernet adapters to be provisioned in virtualized or nonvirtualized environments using just-in-time provisioning, providing tremendous system flexibility and allowing consolidation of multiple physical adapters.
- Delivers uncompromising virtualization support, including hardware-based implementation of Cisco VN-Link technology and pass-through switching.
- Improves system security and manageability by providing visibility and portability of network policies and security all the way to the virtual machine.

The virtual interface card makes Cisco VN-Link connections to the parent fabric interconnects, which allows virtual links to connect virtual NICs in virtual machines to virtual interfaces in the interconnect. In a Cisco Unified Computing System environment, virtual links then can be managed, network profiles applied, and interfaces dynamically reprovisioned as virtual machines move between servers in the system.

### Cisco UCS VIC 1225 Virtual Interface Card

The Cisco UCS VIC 1225 Virtual Interface Card is a high-performance, converged network adapter that provides acceleration for the various new operational modes introduced by server virtualization. It brings superior flexibility, performance, and bandwidth to the new generation of Cisco UCS C-Series Rack-Mount Servers.

The Cisco UCS VIC 1225 implements the Cisco Virtual Machine Fabric Extender (VM-FEX), which unifies virtual and physical networking into a single infrastructure. It provides virtual-machine visibility from the physical network and a consistent network operations model for physical and virtual servers. In virtualized environments, this highly configurable and self-virtualized adapter provides integrated, modular LAN interfaces on Cisco UCS C-Series Rack-Mount Servers. Additional features and capabilities include:

- Supports up to 256 PCIe virtual devices, either virtual network interface cards (vNICs) or virtual host bus adapters (vHBAs), with high I/O operations per second (IOPS), support for lossless Ethernet, and 20 Gbps to servers.
- PCIe Gen2 x16 helps assure optimal bandwidth to the host for network-intensive applications with a redundant path to the fabric interconnect.
- Half-height design reserves full-height slots in servers for Cisco certified third-party adapters.
- Centrally managed by Cisco UCS Manager with support for Microsoft Windows, Red Hat Enterprise Linux, SUSE Linux, VMware vSphere, and Citrix XenServer.

### Cisco UCS VIC 1385 Virtual Interface Card

The Cisco UCS VIC 1385 Virtual Interface Card is a dual-port Enhanced Quad Small Form-Factor Pluggable (QSFP) 40 Gigabit Ethernet and Fibre Channel over Ethernet (FCoE)-capable half-height PCI Express (PCIe) card designed exclusively for Cisco UCS C-Series Rack Servers. It incorporates Cisco's next-generation

converged network adapter (CNA) technology, with a comprehensive feature set, providing investment protection for future feature software releases. The card enables a policy-based, stateless, agile server infrastructure that can present over 256 PCIe standards-compliant interfaces to the host that can be dynamically configured as either network interface cards (NICs) or host bus adapters (HBAs). In addition, the Cisco UCS VIC 1385 card supports Cisco Data Center Virtual Machine Fabric Extender (VM-FEX) technology, which extends the Cisco UCS fabric interconnect ports to virtual machines, simplifying server virtualization deployment.

The personality of the card is determined dynamically at boot time using the service profile associated with the server. The number, type (NIC or HBA), identity (MAC address and World Wide Name [WWN]), failover policy, bandwidth, and quality-of-service (QoS) policies of the PCIe interfaces are all determined using the service profile. The capability to define, create, and use interfaces on demand provides a stateless and agile server infrastructure. Additional features and capabilities include:

- Each PCIe interface created on the VIC is associated with an interface on the Cisco UCS fabric interconnect, providing complete network separation for each virtual cable between a PCIe device on the VIC and the interface on the fabric interconnect
- The Cisco UCS VIC 1385 Virtual Interface Card provides high network performance and low latency for the most demanding applications such as SMB-Direct, VMQ, DPDK, and Cisco NetFlow

### Cisco UCS VIC 1227T Virtual Interface Card

The Cisco UCS VIC 1227T Virtual Interface Card is a dual-port 10GBASE-T (RJ-45) 10-Gbps Ethernet and Fibre Channel over Ethernet (FCoE)-capable PCI Express (PCIe) modular LAN-on-motherboard (mLOM) adapter designed exclusively for Cisco UCS C-Series Rack Servers. New to Cisco rack servers, the mLOM slot can be used to install a Cisco VIC without consuming a PCIe slot, which provides greater I/O expandability. It incorporates next-generation converged network adapter (CNA) technology from Cisco, providing Fibre Channel connectivity over low-cost twisted pair cabling with a bit error rate (BER) of 10 to 15 up to 30 meters and investment protection for future feature releases. The mLOM card enables a policy-based, stateless, agile server infrastructure that can present up to 256 PCIe standards-compliant interfaces to the host that can be dynamically configured as either network interface cards (NICs) or host bus adapters (HBAs). In addition, the Cisco UCS VIC 1227T Virtual Interface Card supports Cisco Data Center Virtual Machine Fabric Extender (VM-FEX) technology, which extends the Cisco UCS fabric interconnect ports to virtual machines, simplifying server virtualization deployment. Additional features and capabilities include:

- Stateless and agile design - The personality of the card is determined dynamically at boot time using the service profile associated with the server. The number, type (NIC or HBA), identity (MAC address and World Wide Name [WWN]), failover policy, bandwidth, and quality-of-service (QoS) policies of the PCIe interfaces are all determined using the service profile. The capability to define, create, and use interfaces on demand provides a stateless and agile server infrastructure.
- Each PCIe interface created on the VIC is associated with an interface on the Cisco UCS fabric interconnect, providing complete network separation for each virtual cable between a PCIe device on the VIC and the interface on the fabric interconnect.
- Cisco SingleConnect technology provides an exceptionally easy, intelligent, and efficient way to connect and manage computing in the data center. Cisco SingleConnect technology dramatically simplifies the way that data centers connect to rack and blade servers, physical servers, virtual machines, LANs, SANs, and management networks.

### Cisco UCS VIC 1387 Virtual Interface Card

The Cisco UCS VIC 1387 Virtual Interface Card is a dual-port Enhanced Quad Small Form-Factor Pluggable (QSFP) 40 Gigabit Ethernet and Fibre Channel over Ethernet (FCoE)-capable half-height PCI Express (PCIe) card designed exclusively for Cisco UCS C-Series Rack Servers. It incorporates Cisco's next-generation converged network adapter (CNA) technology, with a comprehensive feature set, providing investment protection for future feature software releases. The card enables a policy-based, stateless, agile server infrastructure that can present over 256 PCIe standards-compliant interfaces to the host that can be dynamically configured as either network interface cards (NICs) or host bus adapters (HBAs). In addition, the Cisco UCS VIC 1387 card supports Cisco Data Center Virtual Machine Fabric Extender (VM-FEX) technology, which extends the Cisco UCS fabric interconnect ports to virtual machines, simplifying server virtualization deployment.

The personality of the card is determined dynamically at boot time using the service profile associated with the server. The number, type (NIC or HBA), identity (MAC address and World Wide Name [WWN]), failover policy, bandwidth, and quality-of-service (QoS) policies of the PCIe interfaces are all determined using the service profile. The capability to define, create, and use interfaces on demand provides a stateless and agile server infrastructure. Additional features and capabilities include:

- Each PCIe interface created on the VIC is associated with an interface on the Cisco UCS fabric interconnect, providing complete network separation for each virtual cable between a PCIe device on the VIC and the interface on the fabric interconnect
- The Cisco UCS VIC 1387 Virtual Interface Card provides high network performance and low latency for the most demanding applications such as SMB-Direct, VMQ, DPDK, and Cisco NetFlow

## Viewing Network Adapter Properties

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>show adapter</b> [ <i>index</i> ] [ <i>detail</i> ]	Displays adapter properties. To display the properties of a single adapter, specify the PCI slot number as the <i>index</i> argument.

This example displays the properties of adapter 2:

```
Server# scope chassis
Server /chassis # show adapter
PCI Slot Product Name   Serial Number   Product ID      Vendor
-----
1         UCS VIC 1225      FCH1613796C    UCSC-PCIE-C... Cisco Systems Inc

Server /chassis # show adapter 2 detail
PCI Slot 2:
  Product Name: UCS VIC 1225
  Serial Number: FCH1613796C
  Product ID: UCSC-PCIE-CSC-02
  Adapter Hardware Revision: 4
  Current FW Version: 2.1(0.291)
  NIV: Disabled
```

```
FIP: Enabled
Configuration Pending: no
CIMC Management Enabled : no
VID: V00
Vendor: Cisco Systems Inc
Description:
Bootloader Version: 2.1(0.291)
FW Image 1 Version: 2.1(0.291)
FW Image 1 State: RUNNING ACTIVATED
FW Image 2 Version: 1.6(0.547)
FW Image 2 State: BACKUP INACTIVATED
FW Update Status: Idle
FW Update Error: No error
FW Update Stage: No operation (0%)
FW Update Overall Progress: 0%
```

Server /chassis #

## Configuring Network Adapter Properties

### Before You Begin

- You must log in with admin privileges to perform this task.
- A supported Virtual Interface Card (VIC) must be installed in the chassis and the server must be powered on.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>show adapter</b>	(Optional) Displays the available adapter devices.
<b>Step 3</b>	Server /chassis # <b>scope adapter index</b>	Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> .  <b>Note</b> The server must be powered on before you can view or change adapter settings.
<b>Step 4</b>	Server /chassis/adapter # <b>set fip-mode {disable   enable}</b>	Enables or disables FCoE Initialization Protocol (FIP) on the adapter card. FIP is enabled by default.  <b>Note</b> We recommend that you disable this option only when explicitly directed to do so by a technical support representative.
<b>Step 5</b>	Server /chassis/adapter # <b>set lldp {disable   enable}</b>	Enables or disables Link Layer Discovery Protocol (LLDP) on the adapter card. LLDP is enabled by default.  <b>Note</b> We recommend that you do not disable LLDP option, as it disables all the Data Center Bridging Capability Exchange protocol (DCBX) functionality.
<b>Step 6</b>	Server /chassis/adapter # <b>set niv-mode {disable   enable}</b>	Enables or disables Network Interface Virtualization (NIV) on the adapter card. NIV is disabled by default.  If NIV mode is enabled, vNICs:

	Command or Action	Purpose
		<ul style="list-style-type: none"> <li>• Can be assigned to a specific channel</li> <li>• Can be associated with a port profile</li> <li>• Can fail over to another vNIC if there are communication problems</li> </ul>
<b>Step 7</b>	Server /chassis/adapter # <b>configure-vmfex</b> <i>port-count</i>	If NIV mode is enabled, <i>port-count</i> specifies the number of VM FEX interfaces you want Cisco IMC to create, from 0 to 112.
<b>Step 8</b>	Server /chassis/adapter # <b>commit</b>	Commits the transaction to the system configuration.

This example configures the properties of adapter 1:

```
Server# scope chassis
Server /chassis # scope adapter 1
Server /chassis/adapter # set fip-mode enable
Server /chassis/adapter *# commit
Server /chassis/adapter #
```

## Managing vHBAs

### Guidelines for Managing vHBAs

When managing vHBAs, consider the following guidelines and restrictions:

- The Cisco UCS P81E Virtual Interface Card and Cisco UCS VIC 1225 Virtual Interface Card provide two vHBAs (fc0 and fc1). You can create up to 16 additional vHBAs on these adapter cards.



**Note** If Network Interface Virtualization (NIV) mode is enabled for the adapter, you must assign a channel number to a vHBA when you create it.

- When using the Cisco UCS P81E Virtual Interface Card or Cisco UCS VIC 1225 Virtual Interface Card in an FCoE application, you must associate the vHBA with the FCoE VLAN. Follow the instructions in the **Modifying vHBA Properties** section to assign the VLAN.
- After making configuration changes, you must reboot the host for settings to take effect.



## Viewing vHBA Properties

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope adapter</b> <i>index</i>	Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> .  <b>Note</b> The server must be powered on before you can view or change adapter settings.
<b>Step 3</b>	Server /chassis/adapter # <b>show host-fc-if</b> [ <b>fc0</b>   <b>fc1</b>   <i>name</i> ] [ <b>detail</b> ]	Displays properties of a single vHBA, if specified, or all vHBAs.

This example displays all vHBAs on adapter card 1 and the detailed properties of fc0:

```
Server# scope chassis
Server /chassis # scope adapter 1
Server /chassis/adapter # show host-fc-if
Name      World Wide Port Name      FC SAN Boot Uplink Port
-----
fc0       20:00:00:22:BD:D6:5C:35    Disabled    0
fc1       20:00:00:22:BD:D6:5C:36    Disabled    1

Server /chassis/adapter # show host-fc-if fc0 detail
Name fc0:
World Wide Node Name: 10:00:00:22:BD:D6:5C:35
World Wide Port Name: 20:00:00:22:BD:D6:5C:35
FC SAN Boot: Disabled
Persistent LUN Binding: Disabled
Uplink Port: 0
MAC Address: 00:22:BD:D6:5C:35
CoS: 3
VLAN: NONE
Rate Limiting: OFF
PCIe Device Order: ANY
EDTOV: 2000
RATOV: 10000
Maximum Data Field Size: 2112
Channel Number: 3
Port Profile:

Server /chassis/adapter #
```

## Modifying vHBA Properties

### Before You Begin

You must log in with admin privileges to perform this task.

## Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>show adapter</b>	(Optional) Displays the available adapter devices.
<b>Step 3</b>	Server /chassis # <b>scope adapter</b> <i>index</i>	Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> .  <b>Note</b> The server must be powered on before you can view or change adapter settings.
<b>Step 4</b>	Server /chassis/adapter # <b>scope host-fc-if</b> { <b>fc0</b>   <b>fc1</b>   <i>name</i> }	Enters the host Fibre Channel interface command mode for the specified vHBA.
<b>Step 5</b>	Server /chassis/adapter/host-fc-if # <b>set wwnn</b> <i>wwnn</i>	Specifies a unique World Wide Node Name (WWNN) for the adapter in the form hh:hh:hh:hh:hh:hh:hh:hh. Unless specified by this command, the WWNN is generated automatically by the system.
<b>Step 6</b>	Server /chassis/adapter/host-fc-if # <b>set wwpn</b> <i>wwpn</i>	Specifies a unique World Wide Port Name (WWPN) for the adapter in the form hh:hh:hh:hh:hh:hh:hh:hh. Unless specified by this command, the WWPN is generated automatically by the system.
<b>Step 7</b>	Server /chassis/adapter/host-fc-if # <b>set boot</b> { <b>disable</b>   <b>enable</b> }	Enables or disables FC SAN boot. The default is disable.
<b>Step 8</b>	Server /chassis/adapter/host-fc-if # <b>set persistent-lun-binding</b> { <b>disable</b>   <b>enable</b> }	Enables or disables persistent LUN binding. The default is disable.
<b>Step 9</b>	Server /chassis/adapter/host-fc-if # <b>set mac-addr</b> <i>mac-addr</i>	Specifies a MAC address for the vHBA.
<b>Step 10</b>	Server /chassis/adapter/host-fc-if # <b>set vlan</b> { <b>none</b>   <i>vlan-id</i> }	Specifies the default VLAN for this vHBA. Valid VLAN numbers are 1 to 4094; the default is none.
<b>Step 11</b>	Server /chassis/adapter/host-fc-if # <b>set cos</b> <i>cos-value</i>	Specifies the class of service (CoS) value to be marked on received packets unless the vHBA is configured to trust host CoS. Valid CoS values are 0 to 6; the default is 0. Higher values indicate more important traffic.  This setting is not functional in NIV mode.
<b>Step 12</b>	Server /chassis/adapter/host-fc-if # <b>set rate-limit</b> { <b>off</b>   <i>rate</i> }	Specifies a maximum data rate for the vHBA. The range is 1 to 10000 Mbps; the default is off.  This setting is not functional in NIV mode.
<b>Step 13</b>	Server /chassis/adapter/host-fc-if # <b>set order</b> { <b>any</b>   <i>0-99</i> }	Specifies the relative order of this device for PCIe bus device number assignment; the default is any.

	Command or Action	Purpose
<b>Step 14</b>	Server /chassis/adapter/host-fc-if # <b>set error-detect-timeout</b> <i>msec</i>	Specifies the error detect timeout value (EDTOV), the number of milliseconds to wait before the system assumes that an error has occurred. The range is 1000 to 100000; the default is 2000 milliseconds.
<b>Step 15</b>	Server /chassis/adapter/host-fc-if # <b>set resource-allocation-timeout</b> <i>msec</i>	Specifies the resource allocation timeout value (RATOV), the number of milliseconds to wait before the system assumes that a resource cannot be properly allocated. The range is 5000 to 100000; the default is 10000 milliseconds.
<b>Step 16</b>	Server /chassis/adapter/host-fc-if # <b>set max-field-size</b> <i>size</i>	Specifies the maximum size of the Fibre Channel frame payload (in bytes) that the vHBA supports. The range is 1 to 2112; the default is 2112 bytes.
<b>Step 17</b>	Server /chassis/adapter/host-fc-if # <b>scope error-recovery</b>	Enters the Fibre Channel error recovery command mode.
<b>Step 18</b>	Server /chassis/adapter/host-fc-if/error-recovery # <b>set fcp-error-recovery</b> { <b>disable</b>   <b>enable</b> }	Enables or disables FCP Error Recovery. The default is disable.
<b>Step 19</b>	Server /chassis/adapter/host-fc-if/error-recovery # <b>set link-down-timeout</b> <i>msec</i>	Specifies the link down timeout value, the number of milliseconds the uplink port should be offline before it informs the system that the uplink port is down and fabric connectivity has been lost. The range is 0 to 240000; the default is 30000 milliseconds.
<b>Step 20</b>	Server /chassis/adapter/host-fc-if/error-recovery # <b>set port-down-io-retry-count</b> <i>count</i>	Specifies the port down I/O retries value, the number of times an I/O request to a port is returned because the port is busy before the system decides the port is unavailable. The range is 0 to 255; the default is 8 retries.
<b>Step 21</b>	Server /chassis/adapter/host-fc-if/error-recovery # <b>set port-down-timeout</b> <i>msec</i>	Specifies the port down timeout value, the number of milliseconds a remote Fibre Channel port should be offline before informing the SCSI upper layer that the port is unavailable. The range is 0 to 240000; the default is 10000 milliseconds.
<b>Step 22</b>	Server /chassis/adapter/host-fc-if/error-recovery # <b>exit</b>	Exits to the host Fibre Channel interface command mode.
<b>Step 23</b>	Server /chassis/adapter/host-fc-if # <b>scope interrupt</b>	Enters the interrupt command mode.
<b>Step 24</b>	Server /chassis/adapter/host-fc-if/interrupt # <b>set interrupt-mode</b> { <b>intx</b>   <b>msi</b>   <b>msix</b> }	Specifies the Fibre Channel interrupt mode. The modes are as follows: <ul style="list-style-type: none"> <li>• <b>intx</b> —Line-based interrupt (INTx)</li> </ul>

	Command or Action	Purpose
		<ul style="list-style-type: none"> <li>• <b>msi</b> —Message-Signaled Interrupt (MSI)</li> <li>• <b>msix</b> —Message Signaled Interrupts with the optional extension (MSIx). This is the recommended and default option.</li> </ul>
<b>Step 25</b>	Server /chassis/adapter/host-fc-if/interrupt # <b>exit</b>	Exits to the host Fibre Channel interface command mode.
<b>Step 26</b>	Server /chassis/adapter/host-fc-if # <b>scope port</b>	Enters the Fibre Channel port command mode.
<b>Step 27</b>	Server /chassis/adapter/host-fc-if/port # <b>set outstanding-io-count count</b>	Specifies the I/O throttle count, the number of I/O operations that can be pending in the vHBA at one time. The range is 1 to 1024; the default is 512 operations.
<b>Step 28</b>	Server /chassis/adapter/host-fc-if/port # <b>set max-target-luns count</b>	Specifies the maximum logical unit numbers (LUNs) per target, the maximum number of LUNs that the driver will discover. This is usually an operating system platform limitation. The range is 1 to 1024; the default is 256 LUNs.
<b>Step 29</b>	Server /chassis/adapter/host-fc-if/port # <b>exit</b>	Exits to the host Fibre Channel interface command mode.
<b>Step 30</b>	Server /chassis/adapter/host-fc-if # <b>scope port-f-logic</b>	Enters the Fibre Channel fabric login command mode.
<b>Step 31</b>	Server /chassis/adapter/host-fc-if/port-f-logic # <b>set flogi-retries {infinite   count}</b>	Specifies the fabric login (FLOGI) retries value, the number of times that the system tries to log in to the fabric after the first failure. Enter a number between 0 and 4294967295 or enter <b>infinite</b> ; the default is infinite retries.
<b>Step 32</b>	Server /chassis/adapter/host-fc-if/port-f-logic # <b>set flogi-timeout msec</b>	Specifies the fabric login (FLOGI) timeout value, the number of milliseconds that the system waits before it tries to log in again. The range is 1 to 255000; the default is 2000 milliseconds.
<b>Step 33</b>	Server /chassis/adapter/host-fc-if/port-f-logic # <b>exit</b>	Exits to the host Fibre Channel interface command mode.
<b>Step 34</b>	Server /chassis/adapter/host-fc-if # <b>scope port-p-logic</b>	Enters the Fibre Channel port login command mode.
<b>Step 35</b>	Server /chassis/adapter/host-fc-if/port-p-logic # <b>set plogi-retries count</b>	Specifies the port login (PLOGI) retries value, the number of times that the system tries to log in to the fabric after the first failure. The range is 0 and 255; the default is 8 retries.

	Command or Action	Purpose
<b>Step 36</b>	Server /chassis/adapter/host-fc-if/port-p-logic # <b>set plogi-timeout msec</b>	Specifies the port login (PLOGI) timeout value, the number of milliseconds that the system waits before it tries to log in again. The range is 1 to 255000; the default is 2000 milliseconds.
<b>Step 37</b>	Server /chassis/adapter/host-fc-if/port-p-logic # <b>exit</b>	Exits to the host Fibre Channel interface command mode.
<b>Step 38</b>	Server /chassis/adapter/host-fc-if# <b>scope scsi-io</b>	Enters the SCSI I/O command mode.
<b>Step 39</b>	Server /chassis/adapter/host-fc-if/scsi-io # <b>set cdb-wq-count count</b>	The number of command descriptor block (CDB) transmit queue resources to allocate. The range is 1 to 8; the default is 1.
<b>Step 40</b>	Server /chassis/adapter/host-fc-if/scsi-io # <b>set cdb-wq-ring-size size</b>	The number of descriptors in the command descriptor block (CDB) transmit queue. The range is 64 to 512; the default is 512.
<b>Step 41</b>	Server /chassis/adapter/host-fc-if/scsi-io # <b>exit</b>	Exits to the host Fibre Channel interface command mode.
<b>Step 42</b>	Server /chassis/adapter/host-fc-if# <b>scope trans-queue</b>	Enters the Fibre Channel transmit queue command mode.
<b>Step 43</b>	Server /chassis/adapter/host-fc-if/trans-queue # <b>set fc-wq-ring-size size</b>	The number of descriptors in the Fibre Channel transmit queue. The range is 64 to 128; the default is 64.
<b>Step 44</b>	Server /chassis/adapter/host-fc-if/trans-queue # <b>exit</b>	Exits to the host Fibre Channel interface command mode.
<b>Step 45</b>	Server /chassis/adapter/host-fc-if# <b>scope recv-queue</b>	Enters the Fibre Channel receive queue command mode.
<b>Step 46</b>	Server /chassis/adapter/host-fc-if/recv-queue # <b>set fc-rq-ring-size size</b>	The number of descriptors in the Fibre Channel receive queue. The range is 64 to 128; the default is 64.
<b>Step 47</b>	Server /chassis/adapter/host-fc-if/recv-queue # <b>exit</b>	Exits to the host Fibre Channel interface command mode.
<b>Step 48</b>	Server /chassis/adapter/host-fc-if # <b>commit</b>	Commits the transaction to the system configuration. <b>Note</b> The changes will take effect upon the next server reboot.

This example configures the properties of a vHBA:

```
Server# scope chassis
Server /chassis # show adapter
-----
PCI Slot Product Name      Serial Number  Product ID      Vendor
-----
1         UCS VIC P81E      QCI1417A0QK   N2XX-ACPCI01   Cisco Systems Inc

Server /chassis # scope adapter 1
Server /chassis/adapter # scope host-fc-if fc1
Server /chassis/adapter/host-fc-if # set boot enable
Server /chassis/adapter/host-fc-if *# scope scsi-io
Server /chassis/adapter/host-fc-if/scsi-io *# set cdb-wq-count 2
Server /chassis/adapter/host-fc-if/scsi-io *# exit
Server /chassis/adapter/host-fc-if *# commit
Server /chassis/adapter/host-fc-if #
```

### What to Do Next

Reboot the server to apply the changes.

## Creating a vHBA

The adapter provides two permanent vHBAs. If NIV mode is enabled, you can create up to 16 additional vHBAs.

### Before You Begin

You must log in with user or admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope adapter</b> <i>index</i>	Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> .  <b>Note</b> The server must be powered on before you can view or change adapter settings.
<b>Step 3</b>	Server /chassis/adapter # <b>create</b> <b>host-fc-if</b> <i>name</i>	Creates a vHBA and enters the host Fibre Channel interface command mode. The <i>name</i> argument can be up to 32 ASCII characters.
<b>Step 4</b>	Server /chassis/adapter/host-fc-if # <b>set channel-number</b> <i>number</i>	(Optional) If NIV mode is enabled for the adapter, you must assign a channel number to this vHBA. The range is 1 to 1000.
<b>Step 5</b>	Server /chassis/adapter/host-fc-if # <b>commit</b>	Commits the transaction to the system configuration.  <b>Note</b> The changes will take effect upon the next server reboot.

This example creates a vHBA on adapter 1:

```
Server# scope chassis
Server /chassis # scope adapter 1
Server /chassis/adapter # create host-fc-if Vhba5
Server /chassis/adapter/host-fc-if *# commit
New host-fc-if settings will take effect upon the next server reset
Server /chassis/adapter/host-fc-if #
```

### What to Do Next

- Reboot the server to create the vHBA.
- If configuration changes are required, configure the new vHBA as described in [Modifying vHBA Properties](#), on page 145.

## Deleting a vHBA

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope adapter</b> <i>index</i>	Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> .  <b>Note</b> The server must be powered on before you can view or change adapter settings.
<b>Step 3</b>	Server /chassis/adapter # <b>delete</b> <b>host-fc-if</b> <i>name</i>	Deletes the specified vHBA.  <b>Note</b> You cannot delete either of the two default vHBAs, fc0 or fc1.
<b>Step 4</b>	Server /chassis/adapter # <b>commit</b>	Commits the transaction to the system configuration.  <b>Note</b> The changes will take effect upon the next server reboot.

This example deletes a vHBA on adapter 1:

```
Server# scope chassis
Server /chassis # scope adapter 1
Server /chassis/adapter # delete host-fc-if Vhba5
Server /chassis/adapter *# commit
Server /chassis/adapter #
```

## vHBA Boot Table

In the vHBA boot table, you can specify up to four LUNs from which the server can boot.

## Viewing the Boot Table

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope adapter</b> <i>index</i>	Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> .  <b>Note</b> The server must be powered on before you can view or change adapter settings.
<b>Step 3</b>	Server /chassis/adapter # <b>scope host-fc-if</b> { <b>fc0</b>   <b>fc1</b>   <i>name</i> }	Enters the host Fibre Channel interface command mode for the specified vHBA.
<b>Step 4</b>	Server /chassis/adapter/host-fc-if # <b>show boot</b>	Displays the boot table of the Fibre Channel interface.

This example displays the boot table for a vHBA:

```
Server# scope chassis
Server /chassis # scope adapter 1
Server /chassis/adapter # scope host-fc-if fc1
Server /chassis/adapter/host-fc-if # show boot
Boot Table Entry  Boot Target WWPN                Boot LUN ID
-----
0                  20:00:00:11:22:33:44:55          3
1                  20:00:00:11:22:33:44:56          5
Server /chassis/adapter/host-fc-if #
```

## Creating a Boot Table Entry

You can create up to four boot table entries.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope adapter</b> <i>index</i>	Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> .  <b>Note</b> The server must be powered on before you can view or change adapter settings.
<b>Step 3</b>	Server /chassis/adapter # <b>scope host-fc-if</b> { <b>fc0</b>   <b>fc1</b>   <i>name</i> }	Enters the host Fibre Channel interface command mode for the specified vHBA.



	Command or Action	Purpose
<b>Step 4</b>	Server /chassis/adapter/host-fc-if # <b>create-boot-entry</b> <i>wwpn lun-id</i>	Creates a boot table entry. <ul style="list-style-type: none"> <li>• <i>wwpn</i> — The World Wide Port Name (WWPN) for the boot target in the form hh:hh:hh:hh:hh:hh:hh:hh.</li> <li>• <i>lun-id</i> —The LUN ID of the boot LUN. The range is 0 to 255.</li> </ul>
<b>Step 5</b>	Server /chassis/adapter/host-fc-if # <b>commit</b>	Commits the transaction to the system configuration. <p><b>Note</b> The changes will take effect upon the next server reboot.</p>

This example creates a boot table entry for vHBA fc1:

```
Server# scope chassis
Server /chassis # scope adapter 1
Server /chassis/adapter # scope host-fc-if fc1
Server /chassis/adapter/host-fc-if # create-boot-entry 20:00:00:11:22:33:44:55 3
Server /chassis/adapter/host-fc-if *# commit
New boot table entry will take effect upon the next server reset
Server /chassis/adapter/host-fc-if #
```

## Deleting a Boot Table Entry

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope adapter</b> <i>index</i>	Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> . <p><b>Note</b> The server must be powered on before you can view or change adapter settings.</p>
<b>Step 3</b>	Server /chassis/adapter # <b>scope</b> <b>host-fc-if</b> { <i>fc0</i>   <i>fc1</i>   <i>name</i> }	Enters the host Fibre Channel interface command mode for the specified vHBA.
<b>Step 4</b>	Server /chassis/adapter/host-fc-if # <b>show boot</b>	Displays the boot table. From the Boot Table Entry field, locate the number of the entry to be deleted.
<b>Step 5</b>	Server /chassis/adapter/host-fc-if # <b>delete boot</b> <i>entry</i>	Deletes the boot table entry at the specified position in the table. The range of <i>entry</i> is 0 to 3. The change will take effect upon the next server reset.
<b>Step 6</b>	Server /chassis/adapter/host-fc-if # <b>commit</b>	Commits the transaction to the system configuration. <p><b>Note</b> The changes will take effect upon the next server reboot.</p>

This example deletes boot table entry number 1 for the vHBA fc1:

```
Server# scope chassis
Server /chassis # scope adapter 1
Server /chassis/adapter # scope host-fc-if fc1
Server /chassis/adapter/host-fc-if # show boot
-----
Boot Table Entry  Boot Target WWPN          Boot LUN ID
-----
0                 20:00:00:11:22:33:44:55      3
1                 20:00:00:11:22:33:44:56      5

Server /chassis/adapter/host-fc-if # delete boot 1
Server /chassis/adapter/host-fc-if *# commit
New host-fc-if settings will take effect upon the next server reset
Server /chassis/adapter/host-fc-if # show boot
-----
Boot Table Entry  Boot Target WWPN          Boot LUN ID
-----
0                 20:00:00:11:22:33:44:55      3

Server /chassis/adapter/host-fc-if #
```

### What to Do Next

Reboot the server to apply the changes.

## vHBA Persistent Binding

Persistent binding ensures that the system-assigned mapping of Fibre Channel targets is maintained after a reboot.

## Enabling Persistent Binding

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope adapter</b> <i>index</i>	Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> . <b>Note</b> The server must be powered on before you can view or change adapter settings.
<b>Step 3</b>	Server /chassis/adapter # <b>scope host-fc-if</b> { <b>fc0</b>   <b>fc1</b>   <i>name</i> }	Enters the host Fibre Channel interface command mode for the specified vHBA.
<b>Step 4</b>	Server /chassis/adapter/host-fc-if # <b>scope perbi</b>	Enters the persistent binding command mode for the vHBA.
<b>Step 5</b>	Server /chassis/adapter/host-fc-if/perbi # <b>set persistent-lun-binding enable</b>	Enables persistent binding for the vHBA.

	Command or Action	Purpose
<b>Step 6</b>	Server /chassis/adapter/host-fc-if/perbi # <b>commit</b>	Commits the transaction to the system configuration.

This example enables persistent binding for a vHBA:

```
Server# scope chassis
Server /chassis # scope adapter 4
Server /chassis/adapter # scope host-fc-if fc1
Server /chassis/adapter/host-fc-if # scope perbi
Server /chassis/adapter/host-fc-if/perbi # set persistent-lun-binding enable
Server /chassis/adapter/host-fc-if/perbi *# commit
Server /chassis/adapter/host-fc-if/perbi #
```

## Disabling Persistent Binding

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope adapter</b> <i>index</i>	Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> .  <b>Note</b> The server must be powered on before you can view or change adapter settings.
<b>Step 3</b>	Server /chassis/adapter # <b>scope host-fc-if</b> {fc0   fc1   <i>name</i> }	Enters the host Fibre Channel interface command mode for the specified vHBA.
<b>Step 4</b>	Server /chassis/adapter/host-fc-if # <b>scope perbi</b>	Enters the persistent binding command mode for the vHBA.
<b>Step 5</b>	Server /chassis/adapter/host-fc-if/perbi # <b>set persistent-lun-binding disable</b>	Disables persistent binding for the vHBA.
<b>Step 6</b>	Server /chassis/adapter/host-fc-if/perbi # <b>commit</b>	Commits the transaction to the system configuration.

This example disables persistent binding for a vHBA:

```
Server# scope chassis
Server /chassis # scope adapter 4
Server /chassis/adapter # scope host-fc-if fc1
Server /chassis/adapter/host-fc-if # scope perbi
Server /chassis/adapter/host-fc-if/perbi # set persistent-lun-binding disable
Server /chassis/adapter/host-fc-if/perbi *# commit
Server /chassis/adapter/host-fc-if/perbi #
```

## Rebuilding Persistent Binding

### Before You Begin

Persistent binding must be enabled in the vHBA properties.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope adapter</b> <i>index</i>	Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> .  <b>Note</b> The server must be powered on before you can view or change adapter settings.
<b>Step 3</b>	Server /chassis/adapter # <b>scope host-fc-if</b> { <b>fc0</b>   <b>fc1</b>   <i>name</i> }	Enters the host Fibre Channel interface command mode for the specified vHBA.
<b>Step 4</b>	Server /chassis/adapter/host-fc-if # <b>scope perbi</b>	Enters the persistent binding command mode for the vHBA.
<b>Step 5</b>	Server /chassis/adapter/host-fc-if/perbi # <b>rebuild</b>	Rebuilds the persistent binding table for the vHBA.

This example rebuilds the persistent binding table for a vHBA:

```
Server# scope chassis
Server /chassis # scope adapter 4
Server /chassis/adapter # scope host-fc-if fc1
Server /chassis/adapter/host-fc-if # scope perbi
Server /chassis/adapter/host-fc-if/perbi # rebuild

Server /chassis/adapter/host-fc-if/perbi #
```

## Managing vNICs

### Guidelines for Managing vNICs

When managing vNICs, consider the following guidelines and restrictions:

- The Cisco UCS P81E Virtual Interface Card and Cisco UCS VIC 1225 Virtual Interface Card provide two default vNICs (eth0 and eth1). You can create up to 16 additional vNICs on these adapter cards.



**Note** If Network Interface Virtualization (NIV) mode is enabled for the adapter, you must assign a channel number to a vNIC when you create it.

- After making configuration changes, you must reboot the host for settings to take effect.

Cisco C-series servers use Remote Direct Memory Access (RDMA) over Converged Ethernet (RoCE) for packet transfers. RoCE defines the mechanism of performing RDMA over ethernet, based on the similar mechanism of RDMA over Infiniband. However, RoCE, with its performance oriented characteristics, delivers a superior performance compared to traditional network socket implementation because of the lower latency, lower CPU utilization and higher utilization of network bandwidth. RoCE meets the requirement of moving large amount of data across networks very efficiently.

The RoCE firmware requires the following configuration parameters provided by Cisco UCS Manager for better vNIC performance:

- Queue Pairs
- Memory Regions
- Resource Groups

## Viewing vNIC Properties

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope adapter</b> <i>index</i>	Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> .  <b>Note</b> The server must be powered on before you can view or change adapter settings.
<b>Step 3</b>	Server /chassis/adapter # <b>show host-eth-if</b> [ <b>eth0</b>   <b>eth1</b>   <i>name</i> ] [ <b>detail</b> ]	Displays properties of a single vNIC, if specified, or all vNICs.
<b>Step 4</b>	Server /chassis/adapter # <b>show ext-eth-if</b> [ <b>detail</b> ]	Displays the external ethernet interfaces' details.

Following examples display the brief properties of all vNICs and the detailed properties of eth0 and the external interfaces:

```
Server# scope chassis
Server /chassis # scope adapter 1
Server /chassis/adapter # show host-eth-if
Name      MTU  Uplink Port  MAC Address      CoS  VLAN  PXE  Boot  iSCSI  Boot  usNIC
-----
eth0      1500 0           74:A2:E6:28:C6:AE N/A  N/A   disabled disabled 0
eth1      1500 1           74:A2:E6:28:C6:AF N/A  N/A   disabled disabled 0
srg       1500 0           74:A2:E6:28:C6:B2 N/A  N/A   disabled disabled 64
hhh       1500 0           74:A2:E6:28:C6:B3 N/A  N/A   disabled disabled 0

Server /chassis/adapter # show host-eth-if eth0 detail
Name eth0:
  MTU: 1500
  Uplink Port: 0
  MAC Address: 00:22:BD:D6:5C:33
  CoS: 0
```

```

Trust Host CoS: disabled
PCI Link: 0
PCI Order: ANY
VLAN: NONE
VLAN Mode: TRUNK
Rate Limiting: OFF
PXE Boot: disabled
iSCSI Boot: disabled
usNIC: 0
Channel Number: N/A
Port Profile: N/A
Uplink Failover: disabled
Uplink Failback Timeout: 5
aRFS: disabled
VMQ: disabled
NVGRE: disabled
VXLAN: disabled
RDMA Queue Pairs: 1
RDMA Memory Regions: 4096
RDMA Resource Groups: 1
CDN Name: VIC-1-eth0

```

```

Server# scope chassis
Server /chassis # scope adapter 1
Server /chassis/adapter # show ext-eth-if

```

Port	MAC Address	Link State	Encap..	Mode	Admin Speed	Oper..Speed	Link Training
0	74:A2:E6:28:C6:A2	Link	CE		40Gbps	40Gbps	N/A
Yes	Yes						
1	74:A2:E6:28:C6:A3	Link	CE		40Gbps	40Gbps	N/A
Yes	Yes						

```

Server /chassis/adapter # show ext-eth-if detail

```

```

C220-FCH1834V23X /chassis/adapter # show ext-eth-if detail
Port 0:

```

```

MAC Address: 74:A2:E6:28:C6:A2
Link State: Link
Encapsulation Mode: CE
Admin Speed: 40Gbps
Operating Speed: 40Gbps
Link Training: N/A
Connector Present: Yes
Connector Supported: Yes
Connector Type: QSFP_XCVR_CR4
Connector Vendor: CISCO
Connector Part Number: 2231254-3
Connector Part Revision: B

```

```

Port 1:

```

```

MAC Address: 74:A2:E6:28:C6:A3
Link State: Link
Encapsulation Mode: CE
Admin Speed: 40Gbps
Operating Speed: 40Gbps
Link Training: N/A
Connector Present: Yes
Connector Supported: Yes
Connector Type: QSFP_XCVR_CR4
Connector Vendor: CISCO
Connector Part Number: 2231254-3
Connector Part Revision: B

```

```

Server /chassis/adapter #

```

## Modifying vNIC Properties

### Before You Begin

You must log in with admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>show adapter</b>	(Optional) Displays the available adapter devices.
<b>Step 3</b>	Server /chassis # <b>scope adapter</b> <i>index</i>	Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> . <b>Note</b> The server must be powered on before you can view or change adapter settings.
<b>Step 4</b>	Server /chassis/adapter # <b>scope host-eth-if</b> { <b>eth0</b>   <b>eth1</b>   <i>name</i> }	Enters the host Ethernet interface command mode for the specified vNIC.
<b>Step 5</b>	Server /chassis/adapter/host-eth-if # <b>set mtu</b> <i>mtu-value</i>	Specifies the maximum transmission unit (MTU) or packet size that the vNIC accepts. Valid MTU values are 1500 to 9000 bytes; the default is 1500.
<b>Step 6</b>	Server /chassis/adapter/host-eth-if # <b>set uplink</b> { <b>0</b>   <b>1</b> }	Specifies the uplink port associated with this vNIC. All traffic for this vNIC goes through this uplink port.
<b>Step 7</b>	Server /chassis/adapter/host-eth-if # <b>set mac-addr</b> <i>mac-addr</i>	Specifies a MAC address for the vNIC in the form hh:hh:hh:hh:hh:hh or hhhh:hhhh:hhhh.
<b>Step 8</b>	Server /chassis/adapter/host-eth-if # <b>set cos</b> <i>cos-value</i>	Specifies the class of service (CoS) value to be marked on received packets unless the vNIC is configured to trust host CoS. Valid CoS values are 0 to 6; the default is 0. Higher values indicate more important traffic. <b>Note</b> If NIV is enabled, this setting is determined by the switch, and the command is ignored.
<b>Step 9</b>	Server /chassis/adapter/host-eth-if # <b>set trust-host-cos</b> { <b>disable</b>   <b>enable</b> }	Specifies whether the vNIC will trust host CoS or will remark packets. The behavior is as follows: <ul style="list-style-type: none"> <li>• <b>disable</b> —Received packets are remarked with the configured CoS. This is the default.</li> <li>• <b>enable</b> —The existing CoS value of received packets (host CoS) is preserved.</li> </ul>
<b>Step 10</b>	Server /chassis/adapter/host-eth-if # <b>set order</b> { <b>any</b>   <i>0-99</i> }	Specifies the relative order of this device for PCI bus device number assignment; the default is any.
<b>Step 11</b>	Server /chassis/adapter/host-eth-if # <b>set vlan</b> { <b>none</b>   <i>vlan-id</i> }	Specifies the default VLAN for this vNIC. Valid VLAN numbers are 1 to 4094; the default is none.

	Command or Action	Purpose
		<b>Note</b> If NIV is enabled, this setting is determined by the switch, and the command is ignored.
<b>Step 12</b>	Server /chassis/adapter/host-eth-if # <b>set vlan-mode</b> {access   trunk}	<p>Specifies the VLAN mode for the vNIC. The modes are as follows:</p> <ul style="list-style-type: none"> <li>• <b>access</b> —The vNIC belongs to only one VLAN. When the VLAN is set to access mode, any frame received from the specified default VLAN (1-4094) that is received from the switch with a TAG removes that TAG when it is sent to the host OS through the vNIC.</li> <li>• <b>trunk</b> —The vNIC can belong to more than one VLAN. This is the default.</li> </ul> <p><b>Note</b> If NIV is enabled, this setting is determined by the switch, and the command is ignored.</p>
<b>Step 13</b>	Server /chassis/adapter/host-eth-if # <b>set rate-limit</b> {off   rate}	<p>Specifies a maximum data rate for the vNIC. The range is 1 to 10000 Mbps; the default is off.</p> <p><b>Note</b> If NIV is enabled, this setting is determined by the switch, and the command is ignored.</p>
<b>Step 14</b>	Server /chassis/adapter/host-eth-if # <b>set boot</b> {disable   enable}	Specifies whether the vNIC can be used to perform a PXE boot. The default is enable for the two default vNICs, and disable for user-created vNICs.
<b>Step 15</b>	Server /chassis/adapter/host-eth-if # <b>set channel-number</b> <i>number</i>	If NIV mode is enabled for the adapter, select the channel number that will be assigned to this vNIC. The range is 1 to 1000.
<b>Step 16</b>	Server /chassis/adapter/host-eth-if # <b>set port-profile</b> <i>name</i>	<p>If NIV mode is enabled for the adapter, select the port profile that should be associated with the vNIC.</p> <p><b>Note</b> The <i>name</i> must be a port profile defined on the switch to which this server is connected.</p>
<b>Step 17</b>	Server /chassis/adapter/host-eth-if # <b>set uplink-failover</b> {disable   enable}	If NIV mode is enabled for the adapter, enable this setting if traffic on this vNIC should fail over to the secondary interface if there are communication problems.
<b>Step 18</b>	Server /chassis/adapter/host-eth-if # <b>set uplink-failback-timeout</b> <i>seconds</i>	<p>After a vNIC has started using its secondary interface, this setting controls how long the primary interface must be available before the system resumes using the primary interface for the vNIC.</p> <p>Enter a number of <i>seconds</i> between 0 and 600.</p>
<b>Step 19</b>	Server /chassis/adapter/host-eth-if # <b>set vmq</b> {disable   enable}	<p>Enables or disables Virtual Machine Queue (VMQ) for this adapter.</p> <p><b>Note</b> Ensure that VMQ is not enabled when SR-IOV or netflow is enabled on the adapter.</p>



	Command or Action	Purpose
<b>Step 20</b>	Server /chassis/adapter/host-eth-if # <b>set arfs</b> { <b>disable</b>   <b>enable</b> }	Enables or disables Accelerated Receive Flow steering (aRFS) for this adapter.
<b>Step 21</b>	Server /chassis/adapter/host-eth-if # <b>scope interrupt</b>	Enters the interrupt command mode.
<b>Step 22</b>	Server /chassis/adapter/host-eth-if/interrupt # <b>set interrupt-count</b> <i>count</i>	Specifies the number of interrupt resources. The range is 1 to 514; the default is 8. In general, you should allocate one interrupt resource for each completion queue.
<b>Step 23</b>	Server /chassis/adapter/host-eth-if/interrupt # <b>set coalescing-time</b> <i>usec</i>	The time to wait between interrupts or the idle period that must be encountered before an interrupt is sent. The range is 1 to 65535 microseconds; the default is 125. To turn off coalescing, enter 0 (zero).
<b>Step 24</b>	Server /chassis/adapter/host-eth-if/interrupt # <b>set coalescing-type</b> { <b>idle</b>   <b>min</b> }	The coalescing types are as follows: <ul style="list-style-type: none"> <li>• <b>idle</b> —The system does not send an interrupt until there is a period of no activity lasting as long as the time specified in the coalescing time configuration.</li> <li>• <b>min</b> —The system waits for the time specified in the coalescing time configuration before sending another interrupt event. This is the default.</li> </ul>
<b>Step 25</b>	Server /chassis/adapter/host-eth-if/interrupt # <b>set interrupt-mode</b> { <b>intx</b>   <b>msi</b>   <b>msix</b> }	Specifies the Ethernet interrupt mode. The modes are as follows: <ul style="list-style-type: none"> <li>• <b>intx</b> —Line-based interrupt (PCI INTx)</li> <li>• <b>msi</b> —Message-Signaled Interrupt (MSI)</li> <li>• <b>msix</b> —Message Signaled Interrupts with the optional extension (MSI-X). This is the recommended and default option.</li> </ul>
<b>Step 26</b>	Server /chassis/adapter/host-eth-if/interrupt # <b>exit</b>	Exits to the host Ethernet interface command mode.
<b>Step 27</b>	Server /chassis/adapter/host-eth-if # <b>scope rcv-queue</b>	Enters receive queue command mode.
<b>Step 28</b>	Server /chassis/adapter/host-eth-if/rcv-queue # <b>set rq-count</b> <i>count</i>	The number of receive queue resources to allocate. The range is 1 to 256; the default is 4.
<b>Step 29</b>	Server /chassis/adapter/host-eth-if/rcv-queue # <b>set rq-ring-size</b> <i>size</i>	The number of descriptors in the receive queue. The range is 64 to 4094; the default is 512.

	Command or Action	Purpose
<b>Step 30</b>	Server /chassis/adapter/host-eth-if/recv-queue # <b>exit</b>	Exits to the host Ethernet interface command mode.
<b>Step 31</b>	Server /chassis/adapter/host-eth-if # <b>scope trans-queue</b>	Enters transmit queue command mode.
<b>Step 32</b>	Server /chassis/adapter/host-eth-if/trans-queue # <b>set wq-count</b> <i>count</i>	The number of transmit queue resources to allocate. The range is 1 to 256; the default is 1.
<b>Step 33</b>	Server /chassis/adapter/host-eth-if/trans-queue # <b>set wq-ring-size</b> <i>size</i>	The number of descriptors in the transmit queue. The range is 64 to 4094; the default is 256.
<b>Step 34</b>	Server /chassis/adapter/host-eth-if/trans-queue # <b>exit</b>	Exits to the host Ethernet interface command mode.
<b>Step 35</b>	Server /chassis/adapter/host-eth-if # <b>scope comp-queue</b>	Enters completion queue command mode.
<b>Step 36</b>	Server /chassis/adapter/host-eth-if/comp-queue # <b>set cq-count</b> <i>count</i>	The number of completion queue resources to allocate. The range is 1 to 512; the default is 5.  In general, the number of completion queues equals the number of transmit queues plus the number of receive queues.
<b>Step 37</b>	Server /chassis/adapter/host-eth-if/comp-queue # <b>exit</b>	Exits to the host Ethernet interface command mode.
<b>Step 38</b>	Server /chassis/adapter/host-eth-if/ # <b>set rdma_mrnumber</b>	Sets the number of memory regions to be used per adapter. The values range from 4096 to 524288.
<b>Step 39</b>	Server /chassis/adapter/host-eth-if/ # <b>set rdma_qpnumber</b>	Sets the number of queue pairs to be used per adapter. The values range from 1-8192 queue pairs.
<b>Step 40</b>	Server /chassis/adapter/host-eth-if/ # <b>set rdma_resgrpnumber</b>	Sets the number of resource groups to be used. The values range from 1-128 resource groups.  <b>Note</b> After committing the RoCE details, you are required to reboot the server for the changes to take place.
<b>Step 41</b>	Server /chassis/adapter/host-eth-if # <b>scope offload</b>	Enters TCP offload command mode.
<b>Step 42</b>	Server /chassis/adapter/host-eth-if/offload # <b>set tcp-segment-offload</b> { <b>disable</b>   <b>enable</b> }	Enables or disables TCP Segmentation Offload as follows: <ul style="list-style-type: none"> <li>• <b>disable</b> —The CPU segments large TCP packets.</li> <li>• <b>enable</b> —The CPU sends large TCP packets to the hardware to be segmented. This option may</li> </ul>

	Command or Action	Purpose
		<p>reduce CPU overhead and increase throughput rate. This is the default.</p> <p><b>Note</b> This option is also known as Large Send Offload (LSO).</p>
<b>Step 43</b>	<pre>Server /chassis/adapter/host-eth-if/offload # set tcp-rx-checksum-offload {disable   enable}</pre>	<p>Enables or disables TCP Receive Offload Checksum Validation as follows:</p> <ul style="list-style-type: none"> <li>• <b>disable</b> —The CPU validates all packet checksums.</li> <li>• <b>enable</b> —The CPU sends all packet checksums to the hardware for validation. This option may reduce CPU overhead. This is the default.</li> </ul>
<b>Step 44</b>	<pre>Server /chassis/adapter/host-eth-if/offload # set tcp-tx-checksum-offload {disable   enable}</pre>	<p>Enables or disables TCP Transmit Offload Checksum Validation as follows:</p> <ul style="list-style-type: none"> <li>• <b>disable</b> —The CPU validates all packet checksums.</li> <li>• <b>enable</b> —The CPU sends all packet checksums to the hardware for validation. This option may reduce CPU overhead. This is the default.</li> </ul>
<b>Step 45</b>	<pre>Server /chassis/adapter/host-eth-if/offload # set tcp-large-receive-offload {disable   enable}</pre>	<p>Enables or disables TCP Large Packet Receive Offload as follows:</p> <ul style="list-style-type: none"> <li>• <b>disable</b> —The CPU processes all large packets.</li> <li>• <b>enable</b> —The hardware reassembles all segmented packets before sending them to the CPU. This option may reduce CPU utilization and increase inbound throughput. This is the default.</li> </ul>
<b>Step 46</b>	<pre>Server /chassis/adapter/host-eth-if/offload # exit</pre>	Exits to the host Ethernet interface command mode.
<b>Step 47</b>	<pre>Server /chassis/adapter/host-eth-if # scope rss</pre>	Enters Receive-side Scaling (RSS) command mode.
<b>Step 48</b>	<pre>Server /chassis/adapter/host-eth-if/rss # set rss {disable   enable}</pre>	Enables or disables RSS, which allows the efficient distribution of network receive processing across multiple CPUs in multiprocessor systems. The default is enable for the two default vNICs, and disable for user-created vNICs.
<b>Step 49</b>	<pre>Server /chassis/adapter/host-eth-if/rss # set rss-hash-ipv4 {disable   enable}</pre>	Enables or disables IPv4 RSS. The default is enable.

	Command or Action	Purpose
<b>Step 50</b>	Server /chassis/adapter/host-eth-if/rss # <b>set rss-hash-tcp-ipv4 {disable   enable}</b>	Enables or disables TCP/IPv4 RSS. The default is enable.
<b>Step 51</b>	Server /chassis/adapter/host-eth-if/rss # <b>set rss-hash-ipv6 {disable   enable}</b>	Enables or disables IPv6 RSS. The default is enable.
<b>Step 52</b>	Server /chassis/adapter/host-eth-if/rss # <b>set rss-hash-tcp-ipv6 {disable   enable}</b>	Enables or disables TCP/IPv6 RSS. The default is enable.
<b>Step 53</b>	Server /chassis/adapter/host-eth-if/rss # <b>set rss-hash-ipv6-ex {disable   enable}</b>	Enables or disables IPv6 Extension RSS. The default is disable.
<b>Step 54</b>	Server /chassis/adapter/host-eth-if/rss # <b>set rss-hash-tcp-ipv6-ex {disable   enable}</b>	Enables or disables TCP/IPv6 Extension RSS. The default is disable.
<b>Step 55</b>	Server /chassis/adapter/host-eth-if/rss # <b>exit</b>	Exits to the host Ethernet interface command mode.
<b>Step 56</b>	Server /chassis/adapter/host-eth-if # <b>commit</b>	Commits the transaction to the system configuration. <b>Note</b> The changes will take effect upon the next server reboot.

This example configures the properties of a vNIC:

```
Server# scope chassis
Server /chassis # show adapter
-----
PCI Slot Product Name Serial Number Product ID Vendor
-----
1 UCS VIC P81E QCI1417A0QK N2XX-ACPCI01 Cisco Systems Inc

Server /chassis # scope adapter 1
Server /chassis/adapter # scope host-eth-if Test1
Server /chassis/adapter/host-eth-if # set uplink 1
Server /chassis/adapter/host-eth-if # enable vmq
Server /chassis/adapter/host-eth-if # enable arfs
Server /chassis/adapter/host-eth-if *# scope offload
Server /chassis/adapter/host-eth-if/offload *# set tcp-segment-offload enable
Server /chassis/adapter/host-eth-if/offload *# exit
Server /chassis/adapter/host-eth-if *# commit
Server /chassis/adapter/host-eth-if #
```

### What to Do Next

Reboot the server to apply the changes.

## Enabling or Disabling Link Training on External Ethernet Interfaces

Link training for the port profile on the external ethernet interfaces of the specified vNIC can be enabled or disabled.

## Before You Begin

You must log in with admin privileges to perform this task.

## Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>show adapter</b>	(Optional) Displays the available adapter devices.
<b>Step 3</b>	Server /chassis # <b>scope adapter</b> <i>index</i>	Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> . <b>Note</b> The server must be powered on before you can view or change adapter settings.
<b>Step 4</b>	Server /chassis / adapter # <b>scope</b> <b>ext-eth-if</b> 0   1 <i>name</i>	Enters the external ethernet interface command mode for the specified vNIC.
<b>Step 5</b>	Server /chassis / adapter / ext-eth-if # <b>set link-training</b> on   off	Enables or disables the link training for the specified vNIC.
<b>Step 6</b>	Server /chassis / adapter / ext-eth-if * # <b>commit</b>	Commits the transaction to the system configuration.

This example shows how to enable or disable link training on the external ethernet interface.

```
Server# scope chassis
Server /chassis # scope adapter 1
Server /chassis/adapter # scope ext-eth-if 1
Server /chassis/adapter/ext-eth-if* # set link-training on
Server /chassis/adapter/ext-eth-if# commit
You may lose connectivity to the Cisco IMC and may have to log in again.
Do you wish to continue? [y/N] y
Port 1:
  MAC Address: 74:A2:E6:28:C6:A3
  Link State: Link
  Encapsulation Mode: CE
  Admin Speed: 40Gbps
  Operating Speed: -
  Link Training: N/A
  Connector Present: Yes
  Connector Supported: Yes
  Connector Type: QSFP_XCVR_CR4
  Connector Vendor: CISCO
  Connector Part Number: 2231254-3
  Connector Part Revision: B
```

## Creating a vNIC

The adapter provides two permanent vNICs. You can create up to 16 additional vNICs.

### Before You Begin

You must log in with user or admin privileges to perform this task.

**Procedure**

	<b>Command or Action</b>	<b>Purpose</b>
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope adapter</b> <i>index</i>	Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> .  <b>Note</b> The server must be powered on before you can view or change adapter settings.
<b>Step 3</b>	Server /chassis/adapter # <b>create host-eth-if</b> <i>name</i>	Creates a vNIC and enters the host Ethernet interface command mode. The <i>name</i> argument can be up to 32 ASCII characters.
<b>Step 4</b>	Server /chassis/adapter/host-eth-if # <b>set channel-number</b> <i>number</i>	(Optional) If NIV mode is enabled for the adapter, you must assign a channel number to this vNIC. The range is 1 to 1000.
<b>Step 5</b>	Server /chassis/adapter/host-eth-if # <b>commit</b>	Commits the transaction to the system configuration.  <b>Note</b> The changes will take effect upon the next server reboot.

This example creates a vNIC on adapter 1:

```
Server# scope chassis
Server /chassis # scope adapter 1
Server /chassis/adapter # create host-eth-if Vnic5
Server /chassis/adapter/host-eth-if *# commit
New host-eth-if settings will take effect upon the next server reset
Server /chassis/adapter/host-eth-if #
```

## Deleting a vNIC

**Procedure**

	<b>Command or Action</b>	<b>Purpose</b>
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope adapter</b> <i>index</i>	Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> .  <b>Note</b> The server must be powered on before you can view or change adapter settings.
<b>Step 3</b>	Server /chassis/adapter # <b>delete host-eth-if</b> <i>name</i>	Deletes the specified vNIC.  <b>Note</b> You cannot delete either of the two default vNICs, eth0 or eth1.
<b>Step 4</b>	Server /chassis/adapter # <b>commit</b>	Commits the transaction to the system configuration.

	Command or Action	Purpose
		<b>Note</b> The changes will take effect upon the next server reboot.

This example deletes a vNIC on adapter 1:

```
Server# scope chassis
Server /chassis # scope adapter 1
Server /chassis/adapter # delete host-eth-if Vnic5
Server /chassis/adapter *# commit
Server /chassis/adapter #
```

## Creating Cisco usNIC Using the Cisco IMC CLI



**Note** Even though several properties are listed for Cisco usNIC in the usNIC properties dialog box, you must configure only the following properties because the other properties are not currently being used.

- cq-count
- rq-count
- tq-count
- usnic-count

### Before You Begin

You must log in to the Cisco IMC CLI with administrator privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	server# <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	server/chassis# <b>scope adapter</b> <i>index</i>	Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> .  <b>Note</b> Make sure that the server is powered on before you attempt to view or change adapter settings. To view the index of the adapters configured on your server, use the <b>show adapter</b> command.
<b>Step 3</b>	server/chassis/adapter# <b>scope host-eth-if</b> { <b>eth0</b>   <b>eth1</b> }	Enters the command mode for the vNIC. Specify the Ethernet ID based on the number of vNICs that you have configured in your environment. For example, specify <b>eth0</b> if you configured only one vNIC.

	Command or Action	Purpose
<b>Step 4</b>	server/chassis/adapter/host-eth-if# <b>create usnic-config 0</b>	Creates a usNIC config and enters its command mode. Make sure that you always set the index value to 0.  <b>Note</b> To create a Cisco usNIC for the first time for a given vNIC using the Cisco IMC CLI, you must first create a <b>usnic-config</b> . Subsequently, you only need to scope into the <b>usnic-config</b> and modify the properties for Cisco usNIC. For more information about modifying Cisco usNIC properties, see <a href="#">Modifying a Cisco usNIC value using the Cisco IMC CLI</a> , on page 169.
<b>Step 5</b>	server/chassis/adapter/host-eth-if/usnic-config# <b>set cq-count count</b>	Specifies the number of completion queue resources to allocate. We recommend that you set this value to 6.  The number of completion queues equals the number of transmit queues plus the number of receive queues.
<b>Step 6</b>	server/chassis/adapter/host-eth-if/usnic-config# <b>set rq-count count</b>	Specifies the number of receive queue resources to allocate. We recommend that you set this value to 6.
<b>Step 7</b>	server/chassis/adapter/host-eth-if/usnic-config# <b>set tq-count count</b>	Specifies the number of transmit queue resources to allocate. We recommend that you set this value to 6.
<b>Step 8</b>	server/chassis/adapter/host-eth-if/usnic-config# <b>set usnic-count number of usNICs .</b>	Specifies the number of Cisco usNICs to create. Each MPI process that is running on the server requires a dedicated Cisco usNIC. Therefore, you might need to create up to 64 Cisco usNICs to sustain 64 MPI processes running simultaneously. We recommend that you create at least as many Cisco usNICs, per Cisco usNIC-enabled vNIC, as the number of physical cores on your server. For example, if you have 8 physical cores on your server, create 8 Cisco usNICs.
<b>Step 9</b>	server/chassis/adapter/host-eth-if/usnic-config# <b>commit</b>	Commits the transaction to the system configuration.  <b>Note</b> The changes take effect when the server is rebooted.
<b>Step 10</b>	server/chassis/adapter/host-eth-if/usnic-config# <b>exit</b>	Exits to host Ethernet interface command mode.
<b>Step 11</b>	server/chassis/adapter/host-eth-if# <b>exit</b>	Exits to adapter interface command mode.



	Command or Action	Purpose
<b>Step 12</b>	server/chassis/adapter# <b>exit</b>	Exits to chassis interface command mode.
<b>Step 13</b>	server/chassis# <b>exit</b>	Exits to server interface command mode.
<b>Step 14</b>	server# <b>scope bios</b>	Enters Bios command mode.
<b>Step 15</b>	server/bios# <b>scope advanced</b>	Enters the advanced settings of BIOS command mode.
<b>Step 16</b>	server/bios/advanced# <b>set IntelVTD Enabled</b>	Enables the Intel Virtualization Technology.
<b>Step 17</b>	server/bios/advanced# <b>set ATS Enabled</b>	Enables the Intel VT-d Address Translation Services (ATS) support for the processor.
<b>Step 18</b>	server/bios/advanced# <b>set CoherencySupport Enabled</b>	Enables Intel VT-d coherency support for the processor.
<b>Step 19</b>	server /bios/advanced# <b>commit</b>	Commits the transaction to the system configuration.  <b>Note</b> The changes take effect when the server is rebooted.

This example shows how to configure Cisco usNIC properties:

```

Server # scope chassis
server /chassis # show adapter
server /chassis # scope adapter 2
server /chassis/adapter # scope host-eth-if eth0
server /chassis/adapter/host-eth-if # create usnic-config 0
server /chassis/adapter/host-eth-if/usnic-config *# set usnic-count 64
server /chassis/adapter/host-eth-if/usnic-config *# set cq-count 6
server /chassis/adapter/host-eth-if/usnic-config *# set rq-count 6
server /chassis/adapter/host-eth-if/usnic-config *# set tq-count 6
server /chassis/adapter/host-eth-if/usnic-config *# commit
Committed settings will take effect upon the next server reset
server /chassis/adapter/host-eth-if/usnic-config # exit
server /chassis/adapter/host-eth-if # exit
server /chassis/adapter # exit
server /chassis # exit
server # exit
server# scope bios
server /bios # scope advanced
server /bios/advanced # set IntelVTD Enabled
server /bios/advanced *# set ATS Enabled*
server /bios/advanced *# set CoherencySupport Enabled
server /bios/advanced *# commit
Changes to BIOS set-up parameters will require a reboot.
Do you want to reboot the system?[y|N]y
A system reboot has been initiated.
    
```

## Modifying a Cisco usNIC value using the Cisco IMC CLI

### Before You Begin

You must log in to the Cisco IMC GUI with administrator privileges to perform this task.

## Procedure

	Command or Action	Purpose
<b>Step 1</b>	server# <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	server/chassis# <b>scope adapter</b> <i>index</i>	Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> .  <b>Note</b> Make sure that the server is powered on before you attempt to view or change adapter settings. To view the index of the adapters configured on your server, use the <b>show adapter</b> command.
<b>Step 3</b>	server/chassis/adapter# <b>scope host-eth-if</b> { <b>eth0</b>   <b>eth1</b> }	Enters the command mode for the vNIC. Specify the Ethernet ID based on the number of vNICs that you have configured in your environment. For example, specify <b>eth0</b> if you configured only one vNIC.
<b>Step 4</b>	server/chassis/adapter/host-eth-if# <b>scope usnic-config 0</b>	Enters the command mode for the usNIC. Make sure that you always set the index value as 0 to configure a Cisco usNIC.
<b>Step 5</b>	server/chassis/adapter/host-eth-if/usnic-config# <b>set usnic-count</b> <i>number of usNICs</i> .	Specifies the number of Cisco usNICs to create. Each MPI process running on the server requires a dedicated Cisco usNIC. Therefore, you might need to create up to 64 Cisco usNIC to sustain 64 MPI processes running simultaneously. We recommend that you create at least as many Cisco usNIC, per Cisco usNIC-enabled vNIC, as the number of physical cores on your server. For example, if you have 8 physical cores on your server, create 8 usNICs.
<b>Step 6</b>	server /chassis/adapter/host-eth-if/usnic-config# <b>commit</b>	Commits the transaction to the system configuration.  <b>Note</b> The changes take effect when the server is rebooted.
<b>Step 7</b>	server/chassis/adapter/host-eth-if/usnic-config# <b>exit</b>	Exits to host Ethernet interface command mode.
<b>Step 8</b>	server/chassis/adapter/host-eth-if# <b>exit</b>	Exits to adapter interface command mode.
<b>Step 9</b>	server/chassis/adapter# <b>exit</b>	Exits to chassis interface command mode.
<b>Step 10</b>	server/chassis# <b>exit</b>	Exits to server interface command mode.

This example shows how to configure Cisco usNIC properties:

```
server # scope chassis
server /chassis # show adapter
```

```

server /chassis # scope adapter 2
server /chassis/adapter # scope host-eth-if eth0
server /chassis/adapter/host-eth-if # scope usnic-config 0
server /chassis/adapter/host-eth-if/usnic-config # set usnic-count 32
server /chassis/adapter/host-eth-if/usnic-config # commit
Committed settings will take effect upon the next server reset
server /chassis/adapter/host-eth-if/usnic-config # exit
server /chassis/adapter/host-eth-if # exit
server /chassis/adapter # exit
server /chassis # exit
server # exit
    
```

## Viewing usNIC Properties

### Before You Begin

You must log in with admin privileges to perform this task.

usNIC must be configured on a vNIC.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope adapter</b> <i>index</i>	Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> .  <b>Note</b> The server must be powered on before you can view or change adapter settings.
<b>Step 3</b>	Server /chassis/adapter # <b>scope host-eth-if</b> { <b>eth0</b>   <b>eth1</b>   <i>name</i> }	Enters the host Ethernet interface command mode for the specified vNIC.
<b>Step 4</b>	Server /chassis/adapter/host-eth-if # <b>show usnic-config</b> <i>index</i>	Displays the usNIC properties for a vNIC.

This example displays the usNIC properties for a vNIC:

```

Server # scope chassis
Server /chassis # scope adapter 1
Server /chassis/adapter # scope host-eth-if eth0
Server /chassis/adapter/host-eth-if # show usnic-config 0
Idx usNIC Count TQ Count RQ Count CQ Count TQ Ring Size RQ Ring Size Interrupt Count
-----
0 113 2 2 4 256 512 4
Server /chassis/adapter/host-eth-if #
    
```

## Deleting Cisco usNIC from a vNIC

### Before You Begin

You must log in to Cisco IMC CLI with admin privileges to perform this task.

**Procedure**

	<b>Command or Action</b>	<b>Purpose</b>
<b>Step 1</b>	<code>server# scope chassis</code>	Enters chassis command mode.
<b>Step 2</b>	<code>server/chassis# scope adapter index</code>	Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> .  <b>Note</b> Make sure that the server is powered on before you attempt to view or change adapter settings. To view the index of the adapters configured on your server, use the <b>show adapter</b> command.
<b>Step 3</b>	<code>server/chassis/adapter# scope host-eth-if {eth0   eth1}</code>	Enters the command mode for the vNIC. Specify the Ethernet ID based on the number of vNICs that you have configured in your environment. For example, specify <b>eth0</b> if you configured only one vNIC.
<b>Step 4</b>	<code>Server/chassis/adapter/host-eth-if# delete usnic-config 0</code>	Deletes the Cisco usNIC configuration for the vNIC.
<b>Step 5</b>	<code>Server/chassis/adapter/host-eth-if# commit</code>	Commits the transaction to the system configuration  <b>Note</b> The changes take effect when the server is rebooted.

This example shows how to delete the Cisco usNIC configuration for a vNIC:

```
server # scope chassis
server/chassis # show adapter
server/chassis # scope adapter 1
server/chassis/adapter # scope host-eth-if eth0
server/chassis/adapter/host-eth-if # delete usnic-config 0
server/chassis/host-eth-if/iscsi-boot *# commit
New host-eth-if settings will take effect upon the next adapter reboot

server/chassis/host-eth-if/usnic-config #
```

## Configuring iSCSI Boot Capability

### Configuring iSCSI Boot Capability for vNICs

When the rack-servers are configured in a standalone mode, and when the VIC adapters are directly attached to the Nexus 5000 and Nexus 6000 family of switches, you can configure these VIC adapters to boot the servers remotely from iSCSI storage targets. You can configure Ethernet vNICs to enable a rack server to load the host OS image from remote iSCSI target devices.

To configure the iSCSI boot capability on a vNIC:

- You must log in with admin privileges to perform this task.
- To configure a vNIC to boot a server remotely from an iSCSI storage target, you must enable the PXE boot option on the vNIC.



**Note** You can configure a maximum of 2 iSCSI vNICs for each host.

## Configuring iSCSI Boot Capability on a vNIC

You can configure a maximum of 2 iSCSI vNICs for each host.

### Before You Begin

- To configure a vNIC to boot a server remotely from an iSCSI storage target, you must enable the PXE boot option on the vNIC.
- You must log in with admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope adapter</b> <i>index</i>	Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> . <b>Note</b> The server must be powered on before you can view or change adapter settings.
<b>Step 3</b>	Server /chassis/adapter # <b>scope host-eth-if</b> { <i>eth0</i>   <i>eth1</i>   <i>name</i> }	Enters the host Ethernet interface command mode for the specified vNIC.
<b>Step 4</b>	Server /chassis/adapter/host-eth-if # <b>create iscsi-boot</b> <i>index</i>	Creates the iSCSI boot index for the vNIC. At this moment, only 0 is allowed as the index.
<b>Step 5</b>	Server /chassis/adapter/host-eth-if/iscsi-boot* # <b>create iscsi-target</b> <i>index</i>	Creates an iSCSI target for the vNIC. The value can either be 0 or 1.
<b>Step 6</b>	Server /chassis/adapter/host-eth-if/iscsi-boot* # <b>set dhcp-net-settings enabled</b>	Enables the DHCP network settings for the iSCSI boot.
<b>Step 7</b>	Server /chassis/adapter/host-eth-if/iscsi-boot* # <b>set initiator-name</b> <i>string</i>	Sets the initiator name. It cannot be more than 223 characters.
<b>Step 8</b>	Server /chassis/adapter/host-eth-if/iscsi-boot* # <b>set dhcp-iscsi-settings enabled</b>	Enables the DHCP iSCSI settings.
<b>Step 9</b>	Server /chassis/adapter/host-eth-if/iscsi-boot* # <b>commit</b>	Commits the transaction to the system configuration. <b>Note</b> The changes will take effect upon the next server reboot.

This example shows how to configure the iSCSI boot capability for a vNIC:

```
Server # scope chassis
Server /chassis # scope adapter 1
Server /chassis/adapter # scope host-eth-if eth0
Server /chassis/adapter/host-eth-if # create iscsi-boot 0
Server /adapter/host-eth-if/iscsi-boot *# set dhcp-net-settings enabled
Server /adapter/host-eth-if/iscsi-boot *# set initiator-name iqn.2012-01.com.adser:abcde
Server /adapter/host-eth-if/iscsi-boot *# set dhcp-iscsi-settings enabled
Server /adapter/host-eth-if/iscsi-boot *# commit
```

New host-eth-if settings will take effect upon the next server reset  
Server /adapter/host-eth-if/iscsi-boot #

## Deleting an iSCSI Boot Configuration for a vNIC

### Before You Begin

You must log in with admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope adapter</b> <i>index</i>	Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> . <b>Note</b> The server must be powered on before you can view or change adapter settings.
<b>Step 3</b>	Server /chassis/adapter # <b>scope host-eth-if</b> { <b>eth0</b>   <b>eth1</b>   <i>name</i> }	Enters the host Ethernet interface command mode for the specified vNIC.
<b>Step 4</b>	Server /chassis/adapter/host-eth-if # <b>delete iscsi-boot 0</b>	Deletes the iSCSI boot capability for the vNIC.
<b>Step 5</b>	Server /chassis/adapter/host-eth-if* # <b>commit</b>	Commits the transaction to the system configuration. <b>Note</b> The changes will take effect upon the next server reboot.

This example shows how to delete the iSCSI boot capability for a vNIC:

```
Server # scope chassis
Server /chassis # scope adapter 1
Server /chassis/adapter # scope host-eth-if eth0
Server /chassis/adapter/host-eth-if # delete iscsi-boot 0
Server /adapter/host-eth-if/iscsi-boot *# commit
New host-eth-if settings will take effect upon the next server reset
Server /adapter/host-eth-if/iscsi-boot #
```

# Managing VM FEX

## Virtual Machine Fabric Extender

Cisco Virtual Machine Fabric Extender (VM FEX) extends the (prestandard) IEEE 802.1Qbh port extender architecture to virtual machines. In this architecture, each VM interface is provided with a virtual Peripheral Component Interconnect Express (PCIe) device and a virtual port on a switch.

For this release, VM FEX supports the following cards and Operating systems:

Cards - Cisco UCS 1225 Virtual Interface Card

Operating Systems:

- VMware ESXi 5.1 Update 2
- VMware ESXi 5.5

VM FEX is not supported on Microsoft Hyper-V and Red Hat KVM for this release.

## Viewing VM FEX Properties

### Before You Begin

- The server must be powered on, or the properties will not display.
- A supported Virtual Interface Card (VIC) must be installed in the chassis and the server must be powered on.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope adapter</b> <i>index</i>	Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> .  <b>Note</b> The server must be powered on before you can view or change adapter settings.
<b>Step 3</b>	Server /chassis/adapter # <b>show vmfex</b> [detail]	Displays the general VM FEX properties. For field descriptions, see <a href="#">General Properties Settings</a> , on page 177.
<b>Step 4</b>	Server /chassis/adapter # <b>scope vmfex</b> <i>name</i>	Enters the command mode for the specified VM FEX interface.

	Command or Action	Purpose
<b>Step 5</b>	Server /chassis/adapter/vmfex # <b>show interrupt [detail]</b>	Displays Ethernet interrupt settings. For field descriptions, see <a href="#">Ethernet Interrupt Settings</a> , on page 178.
<b>Step 6</b>	Server /chassis/adapter/vmfex # <b>show rcv-queue [detail]</b>	Displays Ethernet receive queue settings. For field descriptions, see <a href="#">Ethernet Receive Queue Settings</a> , on page 178.
<b>Step 7</b>	Server /chassis/adapter/vmfex # <b>show trans-queue [detail]</b>	Displays Ethernet transmit queue settings. For field descriptions, see <a href="#">Ethernet Transmit Queue Settings</a> , on page 179.
<b>Step 8</b>	Server /chassis/adapter/vmfex # <b>show comp-queue [detail]</b>	Displays completion queue settings. For field descriptions, see <a href="#">Completion Queue Settings</a> , on page 179.
<b>Step 9</b>	Server /chassis/adapter/vmfex # <b>show offload [detail]</b>	Displays TCP offload settings. For field descriptions, see <a href="#">TCP Offload Settings</a> , on page 179.
<b>Step 10</b>	Server /chassis/adapter/vmfex # <b>show rss [detail]</b>	Displays RSS settings. For field descriptions, see <a href="#">Receive Side Scaling Settings</a> , on page 180.

This example displays the VM FEX properties:

```

Server /chassis/adapter # show vmfex detail
Name pts0:
  MTU: 1500
  Uplink Port: 0
  MAC Address: 00:00:00:00:00:00
  CoS: N/A
  Trust Host CoS:
  PCI Order:
  VLAN: N/A
  VLAN Mode: N/A
  Rate Limiting:
  PXE Boot: disabled
  Channel Number: 0
  Port Profile:
  Uplink Failover: Enabled
  Uplink Failback Timeout: 5

Server /chassis/adapter # scope vmfex pts0

Server /chassis/adapter/vmfex # show interrupt
Interrupt Count Coalescing Time (us) Coalescing Type Interrupt Mode
-----
6                125                    MIN                MSI

Server /chassis/adapter/vmfex # show rcv-queue
Receive Queue Count Receive Queue Ring Size
-----
4                    512

Server /chassis/adapter/vmfex # show trans-queue
Transmit Queue Count Transmit Queue Ring Size
-----
1                    256

```



```

Server /chassis/adapter/vmfex # show comp-queue
Completion Queue Count      Completion Queue Ring Size
-----
5                            1

Server /chassis/adapter/vmfex # show offload
TCP Segment Offload  TCP Rx Checksum  TCP Tx Checksum  Large Receive
-----
enabled              enabled          enabled          enabled

Server /chassis/adapter/vmfex # show rss
TCP Rx Side Scaling
-----
enabled

Server /chassis/adapter/vmfex #
    
```

## VM FEX Settings

The following tables describe the VM FEX settings that you can view.

### General Properties Settings

Name	Description
<b>Name</b>	A user-defined name for the VM FEX.
<b>MTU</b>	The maximum transmission unit, or packet size, that this VM FEX accepts.
<b>Uplink Port</b>	The uplink port associated with this VM FEX. All traffic for this VM FEX goes through this uplink port.
<b>MAC Address</b>	The MAC address associated with the VM FEX.
<b>Class of Service</b>	The class of service to associate with traffic from this VM FEX.
<b>Trust Host CoS</b>	Whether the VM FEX can use the class of service provided by the host operating system.
<b>PCI Order</b>	The order in which this VM FEX will be used.
<b>Default VLAN</b>	The default VLAN for this VM FEX.
<b>VLAN Mode</b>	Whether VLAN trunking or access is configured.
<b>Rate Limit</b>	If rate limiting is configured, the maximum rate.
<b>Enable PXE Boot</b>	Whether the VM FEX can be used to perform a PXE boot.
<b>Channel Number</b>	If NIV mode is enabled for the adapter, the channel number assigned to this VM FEX.

Name	Description
<b>Port Profile</b>	If NIV mode is enabled for the adapter, the port profile associated with the VM FEX.  <b>Note</b> This field displays the port profiles defined on the switch to which this server is connected.
<b>Enable Uplink Failover</b>	If NIV mode is enabled for the adapter, whether traffic on this VM FEX should fail over to the secondary interface if there are communication problems.
<b>Failback Timeout</b>	After a VM FEX has started using its secondary interface, this setting controls how long the primary interface must be available before the system resumes using the primary interface for the VM FEX.

### Ethernet Interrupt Settings

Name	Description
<b>Interrupt Count</b> field	The number of interrupt resources allocated to this VM FEX.
<b>Coalescing Time</b> field	The time Cisco IMC waits between interrupts or the idle period that must be encountered before an interrupt is sent.
<b>Coalescing Type</b> field	This can be one of the following: <ul style="list-style-type: none"> <li>• <b>MIN</b>—The system waits for the time specified in the <b>Coalescing Time</b> field before sending another interrupt event.</li> <li>• <b>IDLE</b>—The system does not send an interrupt until there is a period of no activity lasting as least as long as the time specified in the <b>Coalescing Time</b> field.</li> </ul>
<b>Interrupt Mode</b> field	The preferred driver interrupt mode. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>MSIx</b>—Message Signaled Interrupts (MSI) with the optional extension.</li> <li>• <b>MSI</b>—MSI only.</li> <li>• <b>INTx</b>—PCI INTx interrupts.</li> </ul>

### Ethernet Receive Queue Settings

Name	Description
<b>Receive Queue Count</b> field	The number of receive queue resources allocated to this VM FEX.
<b>Receive Queue Ring Size</b> field	The number of descriptors in each receive queue.

**Ethernet Transmit Queue Settings**

Name	Description
<b>Transmit Queue Count</b> field	The number of transmit queue resources allocated to this VM FEX.
<b>Transmit Queue Ring Size</b> field	The number of descriptors in each transmit queue.

**Completion Queue Settings**

Name	Description
<b>Completion Queue Count</b> field	The number of completion queue resources allocated to this VM FEX.
<b>Completion Queue Ring Size</b> field	The number of descriptors in each completion queue.

**TCP Offload Settings**

Name	Description
<b>Enable TCP Segmentation Offload</b> field	If enabled, the CPU sends large TCP packets to the hardware to be segmented. If disabled, the CPU segments large packets. <b>Note</b> This option is also known as Large Send Offload (LSO).
<b>Enable TCP Rx Offload Checksum Validation</b> field	If enabled, the CPU sends all packet checksums to the hardware for validation. If disabled, the CPU validates all packet checksums.
<b>Enable TCP Tx Offload Checksum Generation</b> field	If enabled, the CPU sends all packets to the hardware so that the checksum can be calculated. If disabled, the CPU calculates all packet checksums.
<b>Enable Large Receive</b> field	If enabled, the hardware reassembles all segmented packets before sending them to the CPU. If disabled, the CPU processes all large packets.

**Receive Side Scaling Settings**

Name	Description
<b>Enable TCP Receive Side Scaling</b> field	Receive Side Scaling (RSS) distributes network receive processing across multiple CPUs in multiprocessor systems.  If enabled, network receive processing is shared across processors whenever possible. If disabled, network receive processing is always handled by a single processor even if additional processors are available.
<b>Enable IPv4 RSS</b> field	If enabled, RSS is enabled on IPv4 networks.
<b>Enable TCP-IPv4 RSS</b> field	If enabled, RSS is enabled for TCP transmissions across IPv4 networks.
<b>Enable IPv6 RSS</b> field	If enabled, RSS is enabled on IPv6 networks.
<b>Enable TCP-IPv6 RSS</b> field	If enabled, RSS is enabled for TCP transmissions across IPv6 networks.
<b>Enable IPv6 Extension RSS</b> field	If enabled, RSS is enabled for IPv6 extensions.
<b>Enable TCP-IPv6 Extension RSS</b> field	If enabled, RSS is enabled for TCP transmissions across IPv6 networks.

# Backing Up and Restoring the Adapter Configuration

## Exporting the Adapter Configuration

The adapter configuration can be exported as an XML file to a TFTP server.



**Important** If any firmware or BIOS updates are in progress, do not export the adapter configuration until those tasks are complete.

**Before You Begin**

A supported Virtual Interface Card (VIC) must be installed in the chassis and the server must be powered on. Obtain the TFTP server IP address.

**Procedure**

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope adapter index</b>	Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> .

	Command or Action	Purpose
		<p><b>Note</b> The server must be powered on before you can view or change adapter settings.</p>
<b>Step 3</b>	<p>Server /chassis/adapter # <b>export-vnic protocol remote server IP address</b></p>	<p>Starts the export operation. The adapter configuration file will be stored at the specified path and filename on the remote server at the specified IP address. The protocol can be one of the following:</p> <ul style="list-style-type: none"> <li>• TFTP</li> <li>• FTP</li> <li>• SFTP</li> <li>• SCP</li> <li>• HTTP</li> </ul> <p><b>Note</b> The Cisco UCS C-Series server now supports fingerprint confirmation of the server when you update firmware through a remote server. This option is available only if you choose SCP or SFTP as the remote server type.</p> <p>If you chose SCP or SFTP as the remote server type while performing this action, a prompt with the message Server (RSA) key fingerprint is &lt;server_finger_print_ID&gt; Do you wish to continue? Click y or n depending on the authenticity of the server fingerprint.</p> <p>The fingerprint is based on the host's public key and helps you to identify or verify the host you are connecting to.</p>

This example exports the configuration of adapter 1:

```
Server# scope chassis
Server /chassis # scope adapter 1
Server /chassis/adapter # export-vnic ftp 192.0.20.34 //test/dnld-ucs-k9-bundle.1.0.2h.bin
Server /chassis/adapter #
```

## Importing the Adapter Configuration



**Important** If any firmware or BIOS updates are in progress, do not import the adapter configuration until those tasks are complete.

### Before You Begin

You must log in with admin privileges to perform this task.

**Procedure**

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope adapter</b> <i>index</i>	Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> .  <b>Note</b> The server must be powered on before you can view or change adapter settings.
<b>Step 3</b>	Server /chassis/adapter # <b>import-vnic</b> <i>tftp-ip-address path-and-filename</i>	Starts the import operation. The adapter downloads the configuration file from the specified path on the TFTP server at the specified IP address. The configuration will be installed during the next server reboot.

This example imports a configuration for the adapter in PCI slot 1:

```
Server# scope chassis
Server /chassis # scope adapter 1
Server /chassis/adapter # import-vnic 192.0.2.34 /ucs/backups/adapter4.xml
Import succeeded.
New VNIC adapter settings will take effect upon the next server reset.
Server /chassis/adapter #
```

**What to Do Next**

Reboot the server to apply the imported configuration.

## Restoring Adapter Defaults

**Before You Begin**

You must log in with admin privileges to perform this task.

**Procedure**

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>adapter-reset-defaults</b> <i>index</i>	Restores factory default settings for the adapter at the PCI slot number specified by the <i>index</i> argument.  <b>Note</b> Resetting the adapter to default settings sets the port speed to 4 X 10 Gbps. Choose 40 Gbps as the port speed only if you are using a 40 Gbps switch.

This example restores the default configuration of the adapter in PCI slot 1:

```
Server# scope chassis
Server /chassis # adapter-reset-defaults 1
```

```

This operation will reset the adapter to factory default.
All your configuration will be lost.
Continue?[y|N] y
Server /chassis #

```

# Managing Adapter Firmware

## Adapter Firmware

A Cisco UCS C-Series network adapter contains the following firmware components:

- Adapter firmware —The main operating firmware, consisting of an active and a backup image, can be installed from the Cisco IMC GUI or CLI interface or from the Host Upgrade Utility (HUU). You can upload a firmware image from either a local file system or a TFTP server.
- Bootloader firmware—The bootloader firmware cannot be installed from the Cisco IMC. You can install this firmware using the Host Upgrade Utility.

## Installing Adapter Firmware



### Important

If any firmware or BIOS updates are in progress, do not install the adapter firmware until those tasks are complete.

### Before You Begin

You must log in with admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>update-adapter-fw</b> <i>tftp-ip-address path-and-filename</i> { <b>activate</b>   <b>no-activate</b> } [ <i>pci-slot</i> ] [ <i>pci-slot</i> ]	Downloads the specified adapter firmware file from the TFTP server, then installs the firmware as the backup image on one or two specified adapters or, if no adapter is specified, on all adapters. If the <b>activate</b> keyword is specified, the new firmware is activated after installation.
<b>Step 3</b>	Server /chassis # <b>recover-adapter-update</b> [ <i>pci-slot</i> ] [ <i>pci-slot</i> ]	(Optional) Clears an incomplete firmware update condition on one or two specified adapters or, if no adapter is specified, on all adapters.

This example begins an adapter firmware upgrade on the adapter in PCI slot 1:

```
Server# scope chassis
Server /chassis # update-adapter-fw 192.0.2.34 /ucs/adapters/adapter4.bin activate 1
Server /chassis #
```

### What to Do Next

To activate the new firmware, see [Activating Adapter Firmware](#), on page 184.

## Activating Adapter Firmware



### Important

While the activation is in progress, do not:

- Reset, power off, or shut down the server.
- Reboot or reset Cisco IMC.
- Activate any other firmware.
- Export technical support or configuration data.

### Before You Begin

You must log in with admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis# <b>activate-adapter-fw</b> <i>pci-slot</i> { <b>1</b>   <b>2</b> }	Activates adapter firmware image 1 or 2 on the adapter in the specified PCI slot.  <b>Note</b> The changes will take effect upon the next server reboot.

This example activates adapter firmware image 2 on the adapter in PCI slot 1:

```
Server# scope chassis
Server /chassis # activate-adapter-fw 1 2
Firmware image activation succeeded
Please reset the server to run the activated image
Server /chassis #
```

### What to Do Next

Reboot the server to apply the changes.





## Managing Storage Adapters

---

This chapter includes the following sections:

- [Creating Virtual Drives from Unused Physical Drives, page 186](#)
- [Creating Virtual Drive from an Existing Drive Group, page 188](#)
- [Setting a Virtual Drive as Transport Ready, page 190](#)
- [Clearing a Virtual Drive as Transport Ready, page 191](#)
- [Importing Foreign Configuration, page 193](#)
- [Clearing Foreign Configuration, page 193](#)
- [Enabling and Disabling JBOD, page 194](#)
- [Clearing a Boot Drive, page 195](#)
- [Retrieving Storage Firmware Logs for a Controller , page 196](#)
- [Deleting a Virtual Drive, page 196](#)
- [Initializing a Virtual Drive, page 197](#)
- [Set as Boot Drive, page 198](#)
- [Editing a Virtual Drive, page 199](#)
- [Modifying Attributes of a Virtual Drive, page 200](#)
- [Making a Dedicated Hot Spare, page 201](#)
- [Making a Global Hot Spare, page 202](#)
- [Preparing a Drive for Removal, page 202](#)
- [Toggling Physical Drive Status, page 203](#)
- [Setting a Physical Drive as a Controller Boot Drive, page 204](#)
- [Removing a Drive from Hot Spare Pools, page 206](#)
- [Undo Preparing a Drive for Removal, page 206](#)
- [Enabling Auto Learn Cycles for the Battery Backup Unit, page 207](#)

- [Disabling Auto Learn Cycles for the Battery Backup Unit, page 208](#)
- [Starting a Learn Cycle for a Battery Backup Unit, page 208](#)
- [Toggling the Locator LED for a Physical Drive, page 209](#)
- [Viewing Storage Controller Logs, page 210](#)

## Creating Virtual Drives from Unused Physical Drives

### Before You Begin

You must log in with admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 3</b>	Server /chassis/server # <b>scope storageadapter Slot-ID</b>	Enters storage adapter command mode.
<b>Step 4</b>	Server /chassis/server/storageadapter # <b>create virtual-drive</b>	At this point, you are prompted to enter information corresponding to the RAID level, the physical drives to be used, the size and the write policy for the new virtual drive. Enter the appropriate information at each prompt.  When you have finished specifying the virtual drive information, you are prompted to confirm that the information is correct. Enter <b>y</b> (yes) to confirm, or <b>n</b> (no) to cancel the operation.
<b>Step 5</b>	Server /chassis/storageadapter # <b>show virtual-drive</b>	Displays the existing virtual drives.

This example shows how to create a new virtual drive that spans two unused physical drives.

```
Server # scope chassis
Server /chassis # scope server 1
Server /chassis/server # scope storageadapter SLOT-3
Server /chassis/server/storageadapter # create-virtual-drive
Please enter RAID level
0, 1, 5, 10, 50 --> 1
```

Please choose from the following 10 unused physical drives:

ID	Size (MB)	Model	Interface	Type
1	571776	SEAGATE	SAS	HDD
2	571776	SEAGATE	SAS	HDD
4	571776	SEAGATE	SAS	HDD
5	428672	SEAGATE	SAS	HDD
6	571776	SEAGATE	SAS	HDD
7	571776	SEAGATE	SAS	HDD
8	571776	SEAGATE	SAS	HDD

```

    9 428672      SEAGATE      SAS      HDD
   10 571776      SEAGATE      SAS      HDD
   11 953344      SEAGATE      SAS      HDD

```

```

Specify physical disks for span 0:
Enter comma-separated PDs from above list--> 1,2
Please enter Virtual Drive name (15 characters maximum)--> test_v_drive
Please enter Virtual Drive size in MB, GB, or TB
Example format: '400 GB' --> 10 GB

Optional attribute:

stripsize: defaults to 64K Bytes

    0: 8K Bytes
    1: 16K Bytes
    2: 32K Bytes
    3: 64K Bytes
    4: 128K Bytes
    5: 256K Bytes
    6: 512K Bytes
    7: 1024K Bytes
Choose number from above options or hit return to pick default--> 2
stripsize will be set to 32K Bytes (6 and 'strip-size\:32k')

Disk Cache Policy: defaults to Unchanged

    0: Unchanged
    1: Enabled
    2: Disabled
Choose number from above options or hit return to pick default--> 0
Disk Cache Policy will be set to Unchanged (0 and 'disk-cache-policy\:unchanged')

)

Read Policy: defaults to No Read Ahead

    0: No Read Ahead
    1: Always
Choose number from above options or hit return to pick default--> 0
Read Policy will be set to No Read Ahead (0 and 'read-policy\:no-read-ahead')

Write Policy: defaults to Write Through

    0: Write Through
    1: Write Back Good BBU
    2: Always Write Back
Choose number from above options or hit return to pick default--> 0
Write Policy will be set to Write Through (0 and 'write-policy\:write-through')

IO Policy: defaults to Direct I/O

    0: Direct I/O
    1: Cached I/O
Choose number from above options or hit return to pick default--> 0
IO Policy will be set to Direct I/O (0 and 'io-policy\:direct-io')

Access Policy: defaults to Read Write

    0: Read Write
    1: Read Only
    2: Blocked
Choose number from above options or hit return to pick default--> 0
Access Policy will be set to Read Write (0 and 'access-policy\:read-write')

New virtual drive will have the following characteristics:
- Spans: '[1.2]'
- RAID level: '1'
- Name: 'test_v_drive'
- Size: 10 GB
- stripsize: 32K Bytes
- Disk Cache Policy: Unchanged

```

- Read Policy: No Read Ahead
- Write Policy: Write Through
- IO Policy: Direct I/O
- Access Policy: Read Write

OK? (y or n)--> **y**

```
Server /chassis/server/storageadapter # show virtual-drive
Virtual Drive Health      Status      Name          Size      RAID Level
Boot Drive
-----
0                          Good       Optimal      150528 MB RAID 0
false
1                          Good       Optimal      20480 MB  RAID 0
true
2                          Good       Optimal      114140 MB RAID 0
false
3                          Good       Optimal      test_v_drive 10000 MB  RAID 1
false
4                          Good       Optimal      new_from_test 500 MB    RAID 1
false

Server /chassis/storageadapter #
```

## Creating Virtual Drive from an Existing Drive Group

### Before You Begin

You must log in with admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 3</b>	Server /chassis/server # <b>scope storageadapter</b> <i>Slot-ID</i>	Enters storage adapter command mode.
<b>Step 4</b>	Server /chassis/storageadapter # <b>carve-virtual-drive</b>	At this point, you are prompted to enter information corresponding to the virtual drives to be used, and the size and the write policy for the new virtual drive. Enter the appropriate information at each prompt.  When you have finished specifying the virtual drive information, you are prompted to confirm that the information is correct. Enter <b>y</b> (yes) to confirm, or <b>n</b> (no) to cancel the operation.
<b>Step 5</b>	Server /chassis/server/storageadapter # <b>show virtual-drive</b>	Displays the existing virtual drives.

This example shows how to carve a new virtual drive out of unused space in an existing RAID 1 drive group:

```

Server# scope chassis
Server /chassis # scope server 1
Server /chassis/server # scope storageadapter SLOT-3
Server /chassis/server/storageadapter # carve-virtual-drive
  < Fetching virtual drives...>

ID  Name          RL  VDSize      MaxPossibleSize PD(s)
-----
0   RAID0_12      0   100 MB      Unknown        1,2

Please choose from the above list the virtual drive number
whose space the new virtual drive will share--> 0
New virtual drive will share space with VD 0

Please enter Virtual Drive name (15 characters maximum)--> test_v_drive
Please enter Virtual Drive size in MB, GB, or TB (maximum: Unknown)
  Example format: '400 GB' --> 10 GB

Optional attributes:

  stripsize: defaults to 64K Bytes
    0: 8K Bytes
    1: 16K Bytes
    2: 32K Bytes
    3: 64K Bytes
    4: 128K Bytes
    5: 256K Bytes
    6: 512K Bytes
    7: 1024K Bytes
  Choose number from above options or hit return to pick default--> 0
  stripsize will be set to 8K Bytes (4 and 'strip-size\:8k')

  Disk Cache Policy: defaults to Unchanged
    0: Unchanged
    1: Enabled
    2: Disabled
  Choose number from above options or hit return to pick default--> 0
  Disk Cache Policy will be set to Unchanged (0 and 'disk-cache-policy\:unchanged')

  Read Policy: defaults to No Read Ahead
    0: No Read Ahead
    1: Always
  Choose number from above options or hit return to pick default--> 0
  Read Policy will be set to No Read Ahead (0 and 'read-policy\:no-read-ahead')

  Write Policy: defaults to Write Through
    0: Write Through
    1: Write Back Good BBU
    2: Always Write Back
  Choose number from above options or hit return to pick default--> 0
  Write Policy will be set to Write Through (0 and 'write-policy\:write-through')

  IO Policy: defaults to Direct I/O
    0: Direct I/O
    1: Cached I/O
  Choose number from above options or hit return to pick default--> 0
  IO Policy will be set to Direct I/O (0 and 'io-policy\:direct-io')

  Access Policy: defaults to Read Write
    0: Read Write
    1: Read Only
    2: Blocked
  Choose number from above options or hit return to pick default--> 0
  Access Policy will be set to Read Write (0 and 'access-policy\:read-write')

New virtual drive will have the following characteristics:
- It will share space with virtual drive 0
- Name: 'amit'
- Size: 10 GB
- stripsize: 8K Bytes

```

- Disk Cache Policy: Unchanged
- Read Policy: No Read Ahead
- Write Policy: Write Through
- IO Policy: Direct I/O
- Access Policy: Read Write

OK? (y or n)--> **y**

Server /chassis/storageadapter # **show virtual-drive**

Virtual Drive	Health	Status	Name	Size	RAID Level
0	Good	Optimal		150528 MB	RAID 0
1	Good	Optimal		20480 MB	RAID 0
2	Good	Optimal		114140 MB	RAID 0
3	Good	Optimal	test_v_drive	10000 MB	RAID 1
4	Good	Optimal	new_from_test	500 MB	RAID 1

Server /chassis/server/storageadapter #

## Setting a Virtual Drive as Transport Ready

### Before You Begin

- You must log in with admin privileges to perform this task.
- The virtual drive must be in optimal state to enable transport ready.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 3</b>	Server /chassis/server # <b>scope storageadapter</b> <i>slot ID</i>	Enters the command mode for an installed storage card.
<b>Step 4</b>	Server /chassis/server/storageadapter # <b>scope virtual-drive</b> <i>drive-number</i>	Enters the command mode for the specified virtual drive.
<b>Step 5</b>	Server /chassis/server/storageadapter/virtual-drive # <b>set-transport-ready</b> { <i>include-all</i>   <i>exclude-all</i>   <i>include-dhsp</i> }	Enter the initialization type using which you can set the selected virtual drive as transport ready. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>exclude-all</b>— Excludes all the dedicated hot spare drives.</li> <li>• <b>include-all</b>— Includes any exclusively available or shared dedicated hot spare drives.</li> <li>• <b>include-dhsp</b>— Includes exclusive dedicated hot spare drives.</li> </ul>

	Command or Action	Purpose
		<p>Sets the virtual drive to transport ready and assigns the chosen properties.</p> <p>When you are prompted to confirm the action. Enter y to confirm.</p> <p><b>Note</b> When you set a virtual drive to transport ready all the physical drives associated with it are displayed as Ready to remove.</p>
<b>Step 6</b>	<pre>Server /chassis/server/storageadapter/virtual-drive # show detail</pre>	<p>(Optional)</p> <p>Display the virtual drive properties with the change.</p>

This example shows how to set virtual drive 5 to transport ready:

```
Server # scope chassis
Server /chassis # scope server 1
Server /chassis/server # scope storageadapter SLOT-HBA
Server /chassis/server/storageadapter # scope virtual-drive 5
Server /chassis/storageadapter/virtual-drive # set-transport-ready exclude-all
Since they belong to same drive group, all these virtual drives will be set to Transport
Ready - 0
Are you sure you want to proceed?[y|N]y
Server /chassis/storageadapter/virtual-drive # show detail
Virtual Drive 0:
  Health: Good
  Status: Optimal
  Visibility : Visible
  Name: RAID0_124_RHEL
  Size: 2858160 MB
  Physical Drives: 1, 2, 4
  RAID Level: RAID 0
  Boot Drive: false
  FDE Capable: 0
  FDE Enabled: 0
  Target ID: 0
  Strip Size: 64 KB
  Drives Per Span: 3
  Span Depth: 1
  Access Policy: Transport Ready
  Cache Policy: Direct
  Read Ahead Policy: None
  Requested Write Cache Policy: Write Through
  Current Write Cache Policy: Write Through
  Disk Cache Policy: Unchanged
  Auto Snapshot: false
  Auto Delete Oldest: true
  Allow Background Init: true
Server /chassis/server/storageadapter/virtual-drive #
```

## Clearing a Virtual Drive as Transport Ready

### Before You Begin

You must log in with admin privileges to perform this task.

**Procedure**

	<b>Command or Action</b>	<b>Purpose</b>
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server {1   2}</b>	Enters server command mode of server 1 or 2.
<b>Step 3</b>	Server /chassis/server # <b>scope storageadapter slot ID</b>	Enters the command mode for an installed storage card.
<b>Step 4</b>	Server /chassis/server/storageadapter # <b>scope virtual-drive drive-number</b>	Enters the command mode for the specified virtual drive.
<b>Step 5</b>	Server /chassis/server/storageadapter/virtual-drive # <b>clear-transport-ready</b>	This reverts the selected transport ready virtual drive to its original state.  When you are prompted to confirm the action. Enter y to confirm.
<b>Step 6</b>	Server /chassis/server/storageadapter/virtual-drive # <b>show detail</b>	(Optional) Display the virtual drive properties with the change.

This example shows how to revert the selected transport ready virtual drive to its original state:

```

Server # scope chassis
Server /chassis # scope server 1
Server /chassis/server # scope storageadapter SLOT-HBA
Server /chassis/server/storageadapter # scope virtual-drive 5
Server /chassis/storageadapter/virtual-drive # clear-transport-ready
Since they belong to same drive group, all these virtual drives will be moved out of Transport
Ready - 0
Are you sure you want to proceed?[y|N]y
Server /chassis/storageadapter/virtual-drive # show detail
Virtual Drive 0:
  Health: Good
  Status: Optimal
  Visibility : Visible
  Name: RAID0 124 RHEL
  Size: 2858160 MB
  Physical Drives: 1, 2, 4
  RAID Level: RAID 0
  Boot Drive: false
  FDE Capable: 0
  FDE Enabled: 0
  Target ID: 0
  Strip Size: 64 KB
  Drives Per Span: 3
  Span Depth: 1
  Access Policy: Read-Write
  Cache Policy: Direct
  Read Ahead Policy: None
  Requested Write Cache Policy: Write Through
  Current Write Cache Policy: Write Through
  Disk Cache Policy: Unchanged
  Auto Snapshot: false
  Auto Delete Oldest: true
  Allow Background Init: true
Server /chassis/server/storageadapter/virtual-drive #

```



## Importing Foreign Configuration

When one or more physical drives that have previously been configured with a different controller are inserted into a server, they are identified as foreign configurations. You can import these foreign configurations to a controller.

### Before You Begin

You must log in with admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server {1   2}</b>	Enters server command mode of server 1 or 2.
<b>Step 3</b>	Server /chassis/server # <b>scope storageadapter Slot-ID</b>	Enters storage adapter command mode.
<b>Step 4</b>	Server /chassis/server/storageadapter # <b>import-foreign-config</b>	You are prompted to confirm the action. Enter <b>yes</b> to confirm.  <b>Note</b> If you do not enter <b>yes</b> , the action is aborted.

This example shows how to import all foreign configurations on the MegaRAID controller in slot 3:

```
Server# scope chassis
Server /chassis/server # scope storageadapter SLOT-3
Server /chassis/server/storageadapter # import-foreign-config
Are you sure you want to import all foreign configurations on this controller?
Enter 'yes' to confirm -> yes
Server /chassis/server/storageadapter #
```

## Clearing Foreign Configuration



### Important

This task clears all foreign configuration on the controller. Also, all configuration information from all physical drives hosting foreign configuration is deleted. This action cannot be reverted.

### Before You Begin

You must log in with admin privileges to perform this task.

**Procedure**

	<b>Command or Action</b>	<b>Purpose</b>
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server {1   2}</b>	Enters server command mode of server 1 or 2.
<b>Step 3</b>	Server /chassis/server # <b>scope storageadapter Slot-ID</b>	Enters storage adapter command mode.
<b>Step 4</b>	Server /chassis/server/storageadapter # <b>clear-foreign-config</b>	You are prompted to confirm the action. Enter <b>yes</b> to confirm.  <b>Note</b> If you do not enter <b>yes</b> , the action is aborted.

This example shows how to clear all foreign configurations on the MegaRAID controller in slot 3:

```
Server# scope chassis
Server /chassis # scope server 1
Server /chassis/server # scope storageadapter SLOT-3
Server /chassis/server/storageadapter # clear-foreign-config
Are you sure you want to clear all foreign configurations on this controller?
All data on the drive(s) will be lost.
Enter 'yes' to confirm -> yes
Server /chassis/server/storageadapter #
```

## Enabling and Disabling JBOD

**Procedure**

	<b>Command or Action</b>	<b>Purpose</b>
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server {1   2}</b>	Enters server command mode of server 1 or 2.
<b>Step 3</b>	Server /chassis/server # <b>scope storageadapter Slot-ID</b>	Enters storage adapter command mode.
<b>Step 4</b>	Server /chassis/server/storageadapter # <b>enable-jbod-mode</b>	Enables the JBOD Mode for the selected controller
<b>Step 5</b>	Server /chassis/server/storageadapter # <b>disable-jbod-mode</b>	Disables the JBOD Mode for the selected controller

This example enables and disables the JBOD mode for the selected controller:

```
Server# scope chassis
Server /chassis # scope server 1
Server /chassis/server # scope storageadapter SLOT-3
```

**Enabling JBOD**

```
Server /chassis/server/storageadapter # enable-jbod-mode
Are you sure you want to enable JBOD mode?
Enter 'yes' to confirm -> yes
Server/chassis/server/storageadapter # show settings
PCI Slot SLOT-3:
  Info Valid: Yes
  Enable JBOD Mode: true
```

**Disabling JBOD**

```
Server /chassis/server/storageadapter # disable-jbod-mode
Are you sure you want to disable JBOD mode?
Enter 'yes' to confirm -> yes
Server/chassis/server/storageadapter # show settings
PCI Slot SLOT-3:
  Info Valid: Yes
  Enable JBOD Mode: false
```

**What to Do Next**

.

# Clearing a Boot Drive



**Important** This task clears the boot drive configuration on the controller. This action cannot be reverted.

**Before You Begin**

You must log in with admin privileges to perform this task.

**Procedure**

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 3</b>	Server /chassis/server # <b>scope storageadapter</b> <i>Slot-ID</i>	Enters storage adapter command mode.
<b>Step 4</b>	Server /chassis/server/storageadapter # <b>clear-boot-drive</b>	You are prompted to confirm the action. Enter <b>yes</b> to confirm.  <b>Note</b> If you do not enter <b>yes</b> , the action is aborted.

This example shows how to clear the boot drive configuration on the MegaRAID controller in slot 3:

```
Server# scope chassis
Server/chassis # scope server 1
Server /chassis/server # scope storageadapter SLOT-3
Server /chassis/server/storageadapter # clear-boot-drive
Are you sure you want to clear the controller's boot drive?
Enter 'yes' to confirm -> yes
Server /chassis/server/storageadapter #
```

# Retrieving Storage Firmware Logs for a Controller

This task retrieves the firmware logs for the controller and places it in the `/var/log` location. This ensures that this log data is available when Technical Support Data is requested.

## Before You Begin

You must log in with admin privileges to perform this task

## Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope storageadapter</b> <i>slot</i>	Enters the command mode for an installed storage card.
<b>Step 3</b>	Server /chassis/storageadapter # <b>get-storage-fw-log</b>	Retrieves the storage firmware log file to the specified controller.
<b>Step 4</b>	At the prompt, enter yes.	Begins download of the storage firmware log files.

This example shows how to view the download status of the retrieved storage firmware log files:

```
Server # scope chassis
Server /chassis # scope storageadapter SLOT-HBA
Server /chassis/storageadapter # get-storage-fw-log
```

You are initiating the retrieval of the storage firmware log to Cisco IMC. This task will take a few minutes to complete. You may monitor the status of the retrieval by running the 'get-storage-fw-log-download-progress' command. When the download is finished, the 'Storage Firmware Log Status' value will be 'Complete', along with the size of the logfile. You may then download the log file using the Technical Support facility, accessible from /cimc/tech-support scope, or the WebUI's Utilities page.

```
Do you want to proceed?
Enter 'yes' to confirm -> yes
Server /chassis/storageadapter # get-storage-fw-log-download-progress
Storage Firmware Log Status: Complete (total size 61906 bytes)
```

# Deleting a Virtual Drive



## Important

This task deletes a virtual drive, including the drives that run the booted operating system. So back up any data that you want to retain before you delete a virtual drive.

## Before You Begin

You must log in with admin privileges to perform this task.

**Procedure**

	<b>Command or Action</b>	<b>Purpose</b>
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 3</b>	Server /chassis/server # <b>scope storageadapter</b> <i>Slot-ID</i>	Enters storage adapter command mode.
<b>Step 4</b>	Server /chassis/server/storageadapter # <b>scope virtual-drive</b> <i>drive-number</i>	Enters command mode for the specified virtual drive.
<b>Step 5</b>	Server /chassis/server/storageadapter/virtual-drive # <b>delete-virtual-drive</b>	You are prompted to confirm the action. Enter <b>yes</b> to confirm.  <b>Note</b> If you do not enter <b>yes</b> , the action is aborted.

This example shows how to delete virtual drive 3.

```
Server# scope chassis
Server /chassis # scope server 1
Server /chassis/server # scope storageadapter SLOT-3
Server /chassis/server/storageadapter # scope virtual-drive 3
Server /chassis/server/storageadapter/virtual-drive # delete-virtual-drive
Are you sure you want to delete virtual drive 3?
All data on the drive will be lost. Enter 'yes' to confirm -> yes
Server /chassis/server/storageadapter/virtual-drive #
```

## Initializing a Virtual Drive

All data on a virtual drive is lost when you initialize the drive. Before you run an initialization, back up any data on the virtual drive that you want to save.

**Before You Begin**

You must log in with admin privileges to perform this task.

**Procedure**

	<b>Command or Action</b>	<b>Purpose</b>
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 3</b>	Server /chassis/server # <b>scope storageadapter</b> <i>Slot-ID</i>	Enters storage adapter command mode.

	Command or Action	Purpose
<b>Step 4</b>	Server /chassis/server/storageadapter # <b>scope virtual-drive drive-number</b>	Enters command mode for the specified virtual drive.
<b>Step 5</b>	Server /chassis/server/storageadapter/virtual-drive # <b>start-initialization</b>	Initializes the specified virtual drive.
<b>Step 6</b>	Server /chassis/server/storageadapter/virtual-drive # <b>cancel-initialization</b>	(Optional) Cancels the initialization of the specified virtual drive.
<b>Step 7</b>	Server /chassis/server/storageadapter/physical-drive # <b>get-operation-status</b>	Displays the status of the task that is in progress on the drive.

This example shows how to initialize virtual drive 3 using fast initialization:

```
Server# scope chassis
Server /chassis/server # scope storageadapter SLOT-3
Server /chassis/storageadapter # scope virtual-drive 3
Server /chassis/server/storageadapter/virtual-drive # start-initialization
Are you sure you want to initialize virtual drive 3?
All data on the drive will be lost. Enter 'yes' to confirm -> yes
Fast (0) or full (1) initialization? -> 0
Server /chassis/server/storageadapter/virtual-drive # get-operation-status

progress-percent: 20%
elapsed -seconds: 30
operation-in-progress: initializing virtual drive

Server /chassis/server/storageadapter/virtual-drive #
```

## Set as Boot Drive

### Before You Begin

You must log in with admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server {1   2}</b>	Enters server command mode of server 1 or 2.
<b>Step 3</b>	Server /chassis/server # <b>scope storageadapter Slot-ID</b>	Enters storage adapter command mode.

	Command or Action	Purpose
<b>Step 4</b>	Server /chassis/server/storageadapter # <b>scope virtual-drive</b> <i>drive-number</i>	Enters command mode for the specified virtual drive.
<b>Step 5</b>	Server /chassis/server/storageadapter # <b>set-boot-drive</b>	Specifies the controller to boot from this virtual drive.

This example shows how to specify the controller to boot from virtual drive 3:

```
Server# scope chassis
Server /chassis # scope server 1
Server /chassis/server # scope storageadapter SLOT-3
Server /chassis/server/storageadapter # scope virtual-drive 3
Server /chassis/server/storageadapter/virtual-drive # set-boot-drive
Are you sure you want to set virtual drive 3 as the boot drive?
Enter 'yes' to confirm -> yes
Server /chassis/server/storageadapter/virtual-drive #
```

## Editing a Virtual Drive

### Before You Begin

You must log in with admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 3</b>	Server /chassis/server # <b>scope storageadapter</b> <i>Slot-ID</i>	Enters storage adapter command mode.
<b>Step 4</b>	Server chassis/server/storageadapter # <b>scope virtual-drive</b> <i>drive number</i>	Enters command mode for the specified virtual drive.
<b>Step 5</b>	Server chassis/server/storageadapter /virtual-drive # <b>modify-attributes</b>	Prompts you to select a different current policy.
<b>Step 6</b>	Server chassis/server/storageadapter/virtual-drive# <b>set raid-level</b> <i>value</i>	Specifies the RAID level for the specified virtual drive.
<b>Step 7</b>	Server chassis/server/storageadapter/virtual-drive# <b>set physical-drive</b> <i>value</i>	Specifies the physical drive for the specified virtual drive.

This example shows to edit a virtual drive:

```
Server# scope chassis
Server /chassis # scope chassis
Server /chassis/server # scope storageadapter slot-3
Server /chassis/server/storageadapter # scope virtual-drive 3
Server /chassis/server/storageadapter/virtual-drive #set raid-level 1
Server /chassis/server/storageadapter/virtual-drive *# physical-drive 1
Server /chassis/server/storageadapter/virtual-drive* #commit
Server /chassis/server/storageadapter /virtual-drive # modify-attribute
Current write policy: Write Back Good BBU

    0: Write Through
    1: Write Back Good BBU
    2: Always Write Back
Choose number from above options--> 0
The following attribute will be modified:
- Write Policy: Write Through

OK? (y or n)--> y
Server /chassis/server/storageadapter/virtual-drive #
```

## Modifying Attributes of a Virtual Drive

### Before You Begin

You must log in with admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 3</b>	Server /chassis/server # <b>scope storageadapter</b> <i>Slot-ID</i>	Enters storage adapter command mode.
<b>Step 4</b>	Server /chassis/server/storageadapter # <b>scope virtual-drive</b> 3	Enters the command mode for the virtual drive.
<b>Step 5</b>	Server /chassis/server/storageadapter/virtual-drive # <b>modify-attributes</b>	Prompts you to select a different current policy.

This example shows how to carve a new virtual drive out of unused space in an existing RAID 1 drive group:

```
Server# scope chassis
Server /chassis # scope server 1
Server /chassis/server # scope storageadapter SLOT-3
Server /chassis/server/storageadapter # scope virtual-drive
Server /chassis/server/storageadapter/virtual-drive # modify-attributes

Current write policy: Write Back

    0: Write Through
    1: Write Back
```



```

2: Write Back even if Bad BBU
Choose number from above options --> 0
The following attribute will be modified:
- Write policy: Write Through
OK? (y or n) --> y
operation in progress.
Server /chassis/server/storageadapter/virtual-drive #
    
```

# Making a Dedicated Hot Spare

## Before You Begin

You must log in with admin privileges to perform this task.

## Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server {1   2}</b>	Enters server command mode of server 1 or 2.
<b>Step 3</b>	Server /chassis/server # <b>scope storageadapter Slot-ID</b>	Enters storage adapter command mode.
<b>Step 4</b>	Server /chassis/server/storageadapter # <b>scope physical-drive drive-number</b>	Enters command mode for the specified physical drive.
<b>Step 5</b>	Server /chassis/server/storageadapter/physical-drive # <b>make-dedicated-hot-spare</b>	You are prompted to choose a virtual drive for which the dedicated hot spare is being created.

This example shows how to make physical drive 3 a dedicated hot spare for virtual drive 6:

```

Server# scope chassis
Server /chassis # scope server 1
Server /chassis/server # scope storageadapter SLOT-3
Server /chassis/server/storageadapter # scope physical-drive 3
Server /chassis/server/storageadapter/physical-drive # make-dedicated-hot-spare
 5: VD_OS_1, RAID 0, 102400 MB, physical disks: 1
 6: VD_OS_2, RAID 0, 12288 MB, physical disks: 1
 7: VD_OS_3, RAID 0, 12288 MB, physical disks: 1
 8: VD_DATA_1, RAID 0, 12512 MB, physical disks: 1
 9: RAID1_2358, RAID 1, 40000 MB, physical disks: 2,3,5,8
11: JFB_RAID1_67, RAID 1, 20000 MB, physical disks: 6,7
12: JFB_Crv_R1_40, RAID 1, 40000 MB, physical disks: 6,7
13: JFB_R1_10GB, RAID 1, 10000 MB, physical disks: 6,7

Please choose from the above 8 virtual drives-->6
Server /chassis/server/storageadapter/physical-drive #
    
```

# Making a Global Hot Spare

## Before You Begin

You must log in with admin privileges to perform this task.

## Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server {1   2}</b>	Enters server command mode of server 1 or 2.
<b>Step 3</b>	Server /chassis/server # <b>scope storageadapter Slot-ID</b>	Enters storage adapter command mode.
<b>Step 4</b>	Server /chassis/server/storageadapter # <b>scope physical-drive drive-number</b>	Enters command mode for the specified physical drive.
<b>Step 5</b>	Server /chassis/server/storageadapter/physical-drive # <b>make-global-hot-spare</b>	
<b>Step 6</b>	Server /chassis/server/storageadapter/physical-drive # <b>get-operation-status</b>	Displays the status of the task that is in progress on the drive.

This example shows how to make physical drive 3 a global hot spare:

```
Server# scope chassis
Server /chassis # scope server 1
Server /chassis/server # scope storageadapter SLOT-3
Server /chassis/server/storageadapter # scope physical-drive 3
Server /chassis/server/storageadapter/physical-drive # make-global-hot-spare
Server /chassis/server/storageadapter/physical-drive #
```

# Preparing a Drive for Removal

You can confirm this task only on physical drives that display the **Unconfigured Good** status.

## Before You Begin

You must log in with admin privileges to perform this task.

## Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.

	Command or Action	Purpose
<b>Step 2</b>	Server /chassis # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 3</b>	Server /chassis/server # <b>scope storageadapter</b> <i>Slot-ID</i>	Enters storage adapter command mode.
<b>Step 4</b>	Server /chassis/server/storageadapter # <b>scope physical-drive</b> <i>drive-number</i>	Enters command mode for the specified physical drive.
<b>Step 5</b>	Server /chassis/server/storageadapter/physical-drive # <b>prepare-for-removal</b>	

This example shows how to prepare physical drive 3 for removal.

```
Server# scope chassis
Server /chassis # scope server 1
Server /chassis/server # scope storageadapter SLOT-3
Server /chassis/server/storageadapter # scope physical-drive 3
Server /chassis/server/storageadapter/physical-drive # prepare-for-removal
Server /chassis/server/storageadapter/physical-drive #
```

## Toggling Physical Drive Status

### Before You Begin

- You must log in with admin privileges to perform this task.
- The controller must support the JBOD mode and the JBOD mode must be enabled.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 3</b>	Server /chassis/server # <b>scope storageadapter</b> <i>Slot-ID</i>	Enters storage adapter command mode.
<b>Step 4</b>	Server /chassis/server/storageadapter # <b>scope physical-drive 4</b>	Enters command mode for the physical drive.
<b>Step 5</b>	Server /chassis/server/storageadapter/physical-drive # <b>make-unconfigured-good</b>	Modifies the status of the drive to Unconfigured good.

	Command or Action	Purpose
<b>Step 6</b>	Server /chassis/server/storageadapter/physical-drive # <b>make-jbod</b>	Enables the JBOD mode on the physical drive.

This example shows how to toggle between the status of the physical drive:

```

Server# scope chassis
Server /chassis # scope chassis
Server /chassis/server # scope storageadapter SLOT-3
Server /chassis/server/storageadapter # scope physical-drive 4
Server /chassis/server/storageadapter/physical-drive # show detail
Physical Drive Number 4:
  Controller: SLOT-4
  Health: Good
  Status: JBOD
  Boot Drive: true
  Manufacturer: ATA
  Model: ST500NM0011
  Predictive Failure Count: 0
  Drive Firmware: CC02
  Coerced Size: 476416 MB
  Type: HDD
Server /chassis/server/storageadapter/physical-drive # make-unconfigured-good
Server /chassis/server/storageadapter/physical-drive # show detail
Physical Drive Number 4:
  Controller: SLOT-4
  Health: Good
  Status: Unconfigured Good
  Boot Drive: true
  Manufacturer: ATA
  Model: ST500NM0011
  Predictive Failure Count: 0
  Drive Firmware: CC02
  Coerced Size: 476416 MB
  Type: HDD
Server /chassis/server/storageadapter/physical-drive # make-jbod
Server /chassis/server/storageadapter/physical-drive # show detail
Physical Drive Number 4:
  Controller: SLOT-4
  Health: Good
  Status: JBOD
  Boot Drive: true
  Manufacturer: ATA
  Model: ST500NM0011
  Predictive Failure Count: 0
  Drive Firmware: CC02
  Coerced Size: 476416 MB
  Type: HDD

```

## Setting a Physical Drive as a Controller Boot Drive

### Before You Begin

- You must log in with admin privileges to perform this task.
- The controller must support the JBOD mode and the JBOD mode must be enabled.

**Procedure**

	<b>Command or Action</b>	<b>Purpose</b>
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server {1   2}</b>	Enters server command mode of server 1 or 2.
<b>Step 3</b>	Server /chassis/server # <b>scope storageadapter Slot-ID</b>	Enters storage adapter command mode.
<b>Step 4</b>	Server /chassis/server/storageadapter # <b>scope physical-drive 4</b>	Enters command mode for the physical drive.
<b>Step 5</b>	Server /chassis/server/storageadapter/physical-drive # <b>set-boot-drive</b>	You are prompted to confirm the action. Enter <b>yes</b> to confirm.  <b>Note</b> If you do not enter <b>yes</b> , the action is aborted.

This example shows how to set a physical drive as a boot drive for a controller:

```

Server# scope chassis
Server/chassis # scope server 1
Server /chassis/server # scope storageadapter SLOT-3
Server /chassis/server/storageadapter # show detail
PCI Slot SLOT-4:
  Health: Good
  Controller Status: Optimal
  ROC Temperature: Not Supported
  Product Name: MegaRAID 9240-8i (RAID 0,1,10,5)
  Serial Number: SP23807413
  Firmware Package Build: 20.11.1-0159
  Product ID: LSI Logic
  Battery Status: no battery
  Cache Memory Size: 0 MB
  Boot Drive: none
  Boot Drive is PD: false
  TTY Log Status: Not Downloaded
Server /chassis/server/storageadapter # scope physical-drive 4
Server /chassis/server/storageadapter/physical-drive # set-boot-drive
Are you sure you want to set physical drive 4 as the boot drive?
Enter 'yes' to confirm -> yes
Server /chassis/server/storageadapter/physical-drive # exit
Server /chassis/server/storageadapter # show detail
PCI Slot SLOT-4:
  Health: Good
  Controller Status: Optimal
  ROC Temperature: Not Supported
  Product Name: MegaRAID 9240-8i (RAID 0,1,10,5)
  Serial Number: SP23807413
  Firmware Package Build: 20.11.1-0159
  Product ID: LSI Logic
  Battery Status: no battery
  Cache Memory Size: 0 MB
  Boot Drive: 4
  Boot Drive is PD: true
  TTY Log Status: Not Downloaded
    
```

# Removing a Drive from Hot Spare Pools

## Before You Begin

You must log in with admin privileges to perform this task.

## Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 3</b>	Server /chassis/server # <b>scope storageadapter</b> <i>Slot-ID</i>	Enters storage adapter command mode.
<b>Step 4</b>	Server /chassis/server/storageadapter # <b>scope physical-drive</b> <i>drive-number</i>	Enters command mode for the specified physical drive.
<b>Step 5</b>	Server /chassis/server/storageadapter/physical-drive # <b>remove-hot-spare</b>	Removes a drive from the host spare pool.

This example shows how to remove physical drive 3 from the hot spare pools:

```
Server# scope chassis
Server /chassis # scope server 1
Server /chassis/server # scope storageadapter SLOT-3
Server /chassis/server/storageadapter # scope physical-drive 3
Server /chassis/server/storageadapter/physical-drive # remove-hot-spare
Server /chassis/server/storageadapter/physical-drive #
```

# Undo Preparing a Drive for Removal

## Before You Begin

You must log in with admin privileges to perform this task.

## Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 3</b>	Server /chassis/server # <b>scope storageadapter</b> <i>Slot-ID</i>	Enters storage adapter command mode.

	Command or Action	Purpose
<b>Step 4</b>	Server /chassis/server/storageadapter # <b>scope physical-drive drive-number</b>	Enters command mode for the specified physical drive.
<b>Step 5</b>	Server /chassis/server/storageadapter/physical-drive # <b>undo-prepare-for-removal</b>	

This example shows how to respin physical drive 3 after preparing the drive for removal.

```
Server# scope chassis
Server /chassis # scope server 1
Server /chassis/server # scope storageadapter SLOT-3
Server /chassis/server/storageadapter # scope physical-drive 3
Server /chassis/server/storageadapter/physical-drive # undo-prepare-for-removal
Server /chassis/server/storageadapter/physical-drive #
```

## Enabling Auto Learn Cycles for the Battery Backup Unit

### Before You Begin

You must log in with admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server {1   2}</b>	Enters server command mode of server 1 or 2.
<b>Step 3</b>	Server /chassis/server # <b>scope storageadapter Slot-ID</b>	Enters storage adapter command mode.
<b>Step 4</b>	Server /chassis/server/storageadapter # <b>scope bbu</b>	Enter the battery backup unit command mode.
<b>Step 5</b>	Server /chassis/server/storageadapter # <b>enable-auto-learn</b>	Enables the battery auto-learn cycles

This example shows how to enable the battery auto-learn cycles:

```
Server # scope chassis
Server /chassis # scope server 1
Server /chassis/server # scope storageadapter SLOT-2
Server /chassis/server/storageadapter # scope bbu
Server /chassis/server/storageadapter/bbu # enable-auto-learn
Automatic BBU learn cycles will occur without notice if enabled.
Are you sure? [y/n] --> y
enable-auto-learn initiated
Server /chassis/server/storageadapter/bbu #
```

# Disabling Auto Learn Cycles for the Battery Backup Unit

## Before You Begin

You must log in with admin privileges to perform this task.

## Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server {1   2}</b>	Enters server command mode of server 1 or 2.
<b>Step 3</b>	Server /chassis/server # <b>scope storageadapter Slot-ID</b>	Enters storage adapter command mode.
<b>Step 4</b>	Server /chassis/server/storageadapter # <b>scope bbu</b>	Enter the battery backup unit command mode.
<b>Step 5</b>	Server /chassis/server/storageadapter # <b>disable-auto-learn</b>	Disables the battery auto-learn cycles

This example shows how to disables the battery auto-learn cycles:

```
Server # scope chassis
Server /chassis # scope server 1
Server /chassis/server # scope storageadapter SLOT-2
Server /chassis/server/storageadapter # scope bbu
Server /chassis/server/storageadapter/bbu # disable-auto-learn
Automatic BBU learn cycles will no longer occur if disabled.
Are you sure? [y/n] --> y
disable-auto-learn initiated

Server /chassis/server/storageadapter/bbu #
```

# Starting a Learn Cycle for a Battery Backup Unit

## Before You Begin

You must be logged in as an admin to use this command.

## Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server {1   2}</b>	Enters server command mode of server 1 or 2.



	Command or Action	Purpose
<b>Step 3</b>	Server /chassis/server # <b>scope storageadapter</b> <i>Slot-ID</i>	Enters storage adapter command mode.
<b>Step 4</b>	Server /chassis/server/storageadapter # <b>scope</b> <b>bbu</b>	Enter the battery backup unit command mode.
<b>Step 5</b>	Server /chassis/server/storageadapter # <b>start-learn-cycle</b>	Starts the learn cycle for the battery.

This example shows how to initiate the learn cycles for a battery:

```
Server # scope chassis
Server /chassis # scope server 1
Server /chassis/server # scope storageadapter SLOT-2
Server /chassis/server/storageadapter # scope bbu
Server /chassis/server/storageadapter/bbu # start-learn-cycle
Server /chassis/server/storageadapter/bbu #
```

## Toggling the Locator LED for a Physical Drive

### Before You Begin

You must be logged in as an admin to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 3</b>	Server /chassis/server # <b>scope storageadapter</b> <i>Slot-ID</i>	Enters storage adapter command mode.
<b>Step 4</b>	Server /chassis/server/storageadapter # <b>scope</b> <b>physical-drive 3</b>	Enters the physical drive command mode.
<b>Step 5</b>	Server /chassis/server/storageadapter/physical-drive # <b>locator-led</b> {on   off}	Enables or disables the physical drive locator LED.

This example shows how to enable the locator LED for physical drive 3:

```
Server # scope chassis
Server /chassis # scope server 1
Server /chassis/server # scope storageadapter SLOT-2
Server /chassis/server/storageadapter # scope physical-drive 3
Server /chassis/server/storageadapter/physical-drive # locator-led on
Server /chassis/server/storageadapter/physical-drive* # commit
Server /chassis/server/storageadapter/physical-drive #
```

# Viewing Storage Controller Logs

## Before You Begin

You must log in with admin privileges to perform this task.

## Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server {1   2}</b>	Enters server command mode of server 1 or 2.
<b>Step 3</b>	Server /chassis/server # <b>scope storageadapter Slot-ID</b>	Enters storage adapter command mode.
<b>Step 4</b>	Server /chassis/server/storageadapter # <b>show log</b>	Displays the storage controller logs.

This example shows how to display storage controller logs:

```
Server # scope chassis
Server /chassis # scope server 1
Server /chassis/server # scope storageadapter SLOT-3
Server /chassis/server/storageadapter # show log
```

Time	Severity	Description
-----	-----	-----
Fri March 1 09:52:19 2015	Warning	Predictive Failure
Fri March 1 07:50:19 2015	Info	Battery charge complete
Fri March 1 07:50:19 2015	Info	Battery charge started
Fri March 1 07:48:19 2015	Info	Battery relearn complete
Fri March 1 07:47:19 2015	Info	Battery is discharging
Fri March 1 07:45:19 2015	Info	Battery relearn started

```
Server /chassis/server/storageadapter #
```



# CHAPTER 12

## Configuring Communication Services

This chapter includes the following sections:

- [Configuring HTTP, page 211](#)
- [Configuring SSH, page 212](#)
- [Configuring XML API, page 213](#)
- [Configuring IPMI, page 214](#)
- [Configuring SNMP, page 217](#)

### Configuring HTTP

#### Before You Begin

You must log in as a user with admin privileges to configure HTTP.

#### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope http</b>	Enters the HTTP command mode.
<b>Step 2</b>	Server /http # <b>set enabled {yes   no}</b>	Enables or disables HTTP and HTTPS service on the Cisco IMC.
<b>Step 3</b>	Server /http # <b>set http-port number</b>	Sets the port to use for HTTP communication. The default is 80.
<b>Step 4</b>	Server /http # <b>set https-port number</b>	Sets the port to use for HTTPS communication. The default is 443.
<b>Step 5</b>	Server /http # <b>set http-redirect {yes   no}</b>	Enables or disables the redirection of an HTTP request to HTTPS.

	Command or Action	Purpose
<b>Step 6</b>	Server /http # <b>set timeout</b> <i>seconds</i>	Sets the number of seconds to wait between HTTP requests before the Cisco IMC times out and terminates the session.  Enter an integer between 60 and 10,800. The default is 1,800 seconds.
<b>Step 7</b>	Server /http # <b>commit</b>	Commits the transaction to the system configuration.

This example configures HTTP for the Cisco IMC:

```
Server# scope http
Server /http # set enabled yes
Server /http *# set http-port 80
Server /http *# set https-port 443
Server /http *# set http-redirect yes
Server /http *# set timeout 1800
Server /http *# commit
Server /http # show
-----
HTTP Port  HTTPS Port  Timeout  Active Sessions  Enabled  HTTP Redirected
-----
80          443           1800     0                 yes     yes
-----
Server /http #
```

## Configuring SSH

### Before You Begin

You must log in as a user with admin privileges to configure SSH.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope ssh</b>	Enters the SSH command mode.
<b>Step 2</b>	Server /ssh # <b>set enabled</b> {yes   no}	Enables or disables SSH on the Cisco IMC.
<b>Step 3</b>	Server /ssh # <b>set ssh-port</b> <i>number</i>	Sets the port to use for secure shell access. The default is 22.
<b>Step 4</b>	Server /ssh # <b>set timeout</b> <i>seconds</i>	Sets the number of seconds to wait before the system considers an SSH request to have timed out.  Enter an integer between 60 and 10,800. The default is 300 seconds.
<b>Step 5</b>	Server /ssh # <b>commit</b>	Commits the transaction to the system configuration.
<b>Step 6</b>	Server /ssh # <b>show</b> [detail]	(Optional) Displays the SSH configuration.

This example configures SSH for the Cisco IMC:

```
Server# scope ssh
Server /ssh # set enabled yes
Server /ssh *# set ssh-port 22
Server /ssh *# set timeout 600
Server /ssh *# commit
Server /ssh # show
-----
SSH Port      Timeout    Active Sessions  Enabled
-----
22            600       1                 yes
Server /ssh #
```

## Configuring XML API

### XML API for Cisco IMC

The Cisco Cisco IMC XML application programming interface (API) is a programmatic interface to Cisco IMC for a C-Series Rack-Mount Server. The API accepts XML documents through HTTP or HTTPS.

For detailed information about the XML API, see *Cisco UCS Rack-Mount Servers Cisco IMC XML API Programmer's Guide*.

### Enabling XML API

#### Before You Begin

You must log in as a user with admin privileges to perform this task.

#### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope xmlapi</b>	Enters XML API command mode.
<b>Step 2</b>	Server /xmlapi # <b>set enabled {yes   no}</b>	Enables or disables XML API control of Cisco IMC.
<b>Step 3</b>	Server /xmlapi # <b>commit</b>	Commits the transaction to the system configuration.

This example enables XML API control of Cisco IMC and commits the transaction:

```
Server# scope xmlapi
Server /xmlapi # set enabled yes
Server /xmlapi *# commit
Server /xmlapi # show detail
XMLAPI Settings:
  Enabled: yes
  Active Sessions: 0
  Max Sessions: 4
Server /xmlapi #
```

# Configuring IPMI

## IPMI Over LAN

Intelligent Platform Management Interface (IPMI) defines the protocols for interfacing with a service processor embedded in a server platform. This service processor is called a Baseboard Management Controller (BMC) and resides on the server motherboard. The BMC links to a main processor and other on-board elements using a simple serial bus.

During normal operations, IPMI lets a server operating system obtain information about system health and control system hardware. For example, IPMI enables the monitoring of sensors, such as temperature, fan speeds and voltages, for proactive problem detection. If server temperature rises above specified levels, the server operating system can direct the BMC to increase fan speed or reduce processor speed to address the problem.

## Configuring IPMI over LAN for Cisco IMC

Configure IPMI over LAN when you want to manage the Cisco IMC with IPMI messages.

### Before You Begin

You must log in with admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /server # <b>scope ipmi</b>	Enters the IPMI command mode.
<b>Step 3</b>	Server /server/ipmi # <b>set enabled</b> {yes   no}	Enables or disables IPMI access on this server.
<b>Step 4</b>	Server /server/ipmi # <b>set privilege-level</b> {readonly   user   admin}	<p>Specifies the highest privilege level that can be assigned to an IPMI session on this server. This can be:</p> <ul style="list-style-type: none"> <li>• <b>readonly</b> — IPMI users can view information but cannot make any changes. If you select this option, IPMI users with the "Administrator", "Operator", or "User" user roles can only create read-only IPMI sessions, regardless of their other IPMI privileges.</li> <li>• <b>user</b> — IPMI users can perform some functions but cannot perform administrative tasks. If you select this option, IPMI users with the "Administrator" or "Operator" user role can create user and read-only sessions on this server.</li> <li>• <b>admin</b> — IPMI users can perform all available actions. If you select this option, IPMI users with the</li> </ul>

	Command or Action	Purpose
		"Administrator" user role can create admin, user, and read-only sessions on this server.
<b>Step 5</b>	Server /server/ipmi # <b>set encryption-key</b> <i>key</i>	Sets the IPMI encryption key to use for IPMI communications. The key value must be 40 hexadecimal numbers.
<b>Step 6</b>	Server /server/ipmi # <b>commit</b>	Commits the transaction to the system configuration.
<b>Step 7</b>	Server /server/ipmi # <b>randomise-key</b>	Sets the IPMI encryption key to a random value. <b>Note</b> You can perform the Step 6 action instead of Steps 4 and 5.
<b>Step 8</b>	At the prompt, enter y to randomize the encryption key.	Sets the IPMI encryption key to a random value.

This example configures IPMI over LAN for the Cisco IMC:

```

Server # scope server 1
Server /server # scope ipmi
Server /server/ipmi # set enabled yes
Server /server/ipmi *# set privilege-level admin
Server /server/ipmi *# set encryption-key abcdef01234567890abcdef01234567890abcdef
Server /server/ipmi *# commit
Server /server/ipmi *# show
Enabled Encryption Key                               Privilege Level Limit
-----
yes          ABCDEF01234567890ABCDEF01234567890ABCDEF admin

Server /server/ipmi # randomise-key
This operation will change the IPMI Encryption Key to a random value
Continue?[y|N]y
Setting IPMI Encryption Key to a random value...

Server /server/ipmi # show
Enabled Encryption Key                               Privilege Level Limit
-----
yes          abcdef01234567890abcdef01234567890abcdef admin

Server /server/ipmi #
    
```

## Configuring IPMI over LAN for CMCs

Configure IPMI over LAN when you want to manage the CMC with IPMI messages.

### Before You Begin

You must log in with admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters server command mode of server 1 or 2.

	Command or Action	Purpose
<b>Step 2</b>	Server /chassis # <b>scope cmc</b> {1   2}	Enters CMC command mode.
<b>Step 3</b>	Server /server # <b>scope ipmi</b>	Enters the IPMI command mode.
<b>Step 4</b>	Server /chassis/cmc/ipmi # <b>set enabled</b> {yes   no}	Enables or disables IPMI access on this server.
<b>Step 5</b>	Server /chassis/cmc/ipmi # <b>set privilege-level</b> {readonly   user   admin}	Specifies the highest privilege level that can be assigned to an IPMI session on this server. This can be: <ul style="list-style-type: none"> <li>• <b>readonly</b> — IPMI users can view information but cannot make any changes. If you select this option, IPMI users with the "Administrator", "Operator", or "User" user roles can only create read-only IPMI sessions, regardless of their other IPMI privileges.</li> <li>• <b>user</b> — IPMI users can perform some functions but cannot perform administrative tasks. If you select this option, IPMI users with the "Administrator" or "Operator" user role can create user and read-only sessions on this server.</li> <li>• <b>admin</b> — IPMI users can perform all available actions. If you select this option, IPMI users with the "Administrator" user role can create admin, user, and read-only sessions on this server.</li> </ul>
<b>Step 6</b>	Server /chassis/cmc/ipmi # <b>set encryption-key</b> <i>key</i>	Sets the IPMI encryption key to use for IPMI communications. The key value must be 40 hexadecimal numbers.
<b>Step 7</b>	Server /chassis/cmc/ipmi # <b>commit</b>	Commits the transaction to the system configuration.
<b>Step 8</b>	Server /chassis/cmc/ipmi # <b>randomise-key</b>	Sets the IPMI encryption key to a random value. <b>Note</b> You can perform the Step 6 action instead of Steps 4 and 5.
<b>Step 9</b>	At the prompt, enter y to randomize the encryption key.	Sets the IPMI encryption key to a random value.

This example configures IPMI over LAN for the CMC 1:

```

Server # scope chassis
Server # scope cmc 1
Server /chassis # scope ipmi
Server /chassis/cmc/ipmi # set enabled yes
Server /chassis/cmc/ipmi *# set privilege-level admin
Server /chassis/cmc/ipmi *# set encryption-key abcdef01234567890abcdef01234567890abcdef
Server /chassis/cmcipmi *# commit
Server /chassis/cmc/ipmi *# show
Enabled Encryption Key                                     Privilege Level Limit
-----

```



```

yes      ABCDEF01234567890ABCDEF01234567890ABCDEF admin

Server /chassis/cmc/ipmi # randomise-key
This operation will change the IPMI Encryption Key to a random value
Continue?[y|N]y
Setting IPMI Encryption Key to a random value...

Server /chassis/cmc/ipmi # show
Enabled Encryption Key                               Privilege Level Limit
-----
yes      abcdef01234567890abcdef01234567890abcdef admin

Server /chassis/cmc/ipmi #

```

## Configuring SNMP

### SNMP

The Cisco UCS C-Series Rack-Mount Servers support the Simple Network Management Protocol (SNMP) for viewing server configuration and status and for sending fault and alert information by SNMP traps. For information on Management Information Base (MIB) files supported by Cisco IMC, see the *MIB Quick Reference for Cisco UCS* at this URL: [http://www.cisco.com/c/en/us/td/docs/unified\\_computing/ucs/sw/mib/b-series/b\\_UCS\\_MIBRef.html](http://www.cisco.com/c/en/us/td/docs/unified_computing/ucs/sw/mib/b-series/b_UCS_MIBRef.html).

## Configuring SNMP Properties

### Before You Begin

You must log in as a user with admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope snmp</b>	Enters SNMP command mode.
<b>Step 2</b>	Server /snmp# <b>set enabled {yes   no}</b>	Enables or disables SNMP. <b>Note</b> SNMP must be enabled and saved before additional SNMP configuration commands are accepted.
<b>Step 3</b>	Server /snmp# <b>commit</b>	Commits the transaction to the system configuration.
<b>Step 4</b>	Server /snmp# <b>set enable-serial-num {yes   no}</b>	Prefixes the traps with the serial number of the server.
<b>Step 5</b>	Server /snmp# <b>set snmp-port port number</b>	Sets the port number on which the SNMP agent runs. You can choose a number within the range 1 to 65535. The default port number is 161. <b>Note</b> The port numbers that are reserved for system calls, such as 22,23,80,123,443,623,389,636,3268,3269 and 2068, cannot be used as an SNMP port.

	Command or Action	Purpose
<b>Step 6</b>	Server /snmp # <b>set community-str</b> <i>community</i>	Specifies the default SNMP v1 or v2c community name that Cisco IMC includes on any trap messages it sends to the SNMP host. The name can be up to 18 characters.
<b>Step 7</b>	Server /snmp # <b>set community-access</b>	This can be one of the following : Disabled, Limited, or Full.
<b>Step 8</b>	Server /snmp # <b>set trap-community-str</b>	Specifies the SNMP community group to which trap information should be sent. The name can be up to 18 characters
<b>Step 9</b>	Server /snmp # <b>set sys-contact</b> <i>contact</i>	Specifies the system contact person responsible for the SNMP implementation. The contact information can be up to 254 characters, such as an email address or a name and telephone number. To enter a value that contains spaces, you must enclose the entry with quotation marks.
<b>Step 10</b>	Server /snmp # <b>set sys-location</b> <i>location</i>	Specifies the location of the host on which the SNMP agent (server) runs. The location information can be up to 254 characters. To enter a value that contains spaces, you must enclose the entry with quotation marks.
<b>Step 11</b>	Server /snmp # <b>commit</b>	Commits the transaction to the system configuration.

This example configures the SNMP properties and commits the transaction:

```
Server# scope snmp
Server /snmp # set enabled yes
Server /snmp *# commit
Server /snmp *# set enable-serial-num yes
Server /snmp *# set snmp-port 20000
Server /snmp *# set community-str cimcpbublic
Server /snmp *# set community-access Full
Server /snmp *# set trap-community-str public
Server /snmp *# set sys-contact "User Name <username@example.com> +1-408-555-1212"
Server /snmp *# set sys-location "San Jose, California"
Server /snmp *# commit
Server /snmp # show detail
SNMP Settings:
  SNMP Port: 20000
  System Contact: User Name <username@example.com> +1-408-555-1212
  System Location: San Jose, California
  SNMP Community: cimcpbublic
  SNMP Trap Community: public
  SNMP Community access: Full
  Enabled: yes
  Serial Number Enabled: yes

Server /snmp #
```

### What to Do Next

Configure SNMP trap settings as described in [Configuring SNMP Trap Settings](#), on page 219.

## Configuring SNMP Trap Settings

### Before You Begin

- You must log in with admin privileges to perform this task.
- SNMP must be enabled and saved before trap settings can be configured.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope snmp</b>	Enters the SNMP command mode.
<b>Step 2</b>	Server /snmp # <b>scope trap-destinations</b> <i>number</i>	Enters the SNMP trap destination command mode for the specified destination. Four SNMP trap destinations are available. The destination <i>number</i> is an integer between 1 and 15.
<b>Step 3</b>	Server /snmp/trap-destinations # <b>set enabled</b> {yes   no}	Enables or disables the SNMP trap destination.
<b>Step 4</b>	Server /snmp/trap-destinations # <b>set version</b> { 2   3 }	Specify the desired SNMP version of the trap message. <b>Note</b> SNMPv3 traps will be delivered only to locations where the SNMPv3 user and key values are configured correctly.
<b>Step 5</b>	Server /snmp/trap-destinations # <b>set type</b> {trap   inform}	Specifies whether SNMP notification messages are sent as simple traps or as inform requests requiring acknowledgment by the receiver. <b>Note</b> The inform option can be chosen only for V2 users.
<b>Step 6</b>	Server /snmp/trap-destinations # <b>set user</b> <i>user</i>	
<b>Step 7</b>	Server /snmp/trap-destination # <b>set trap-addr</b> <i>trap destination address</i>	Specifies the trap destination address to which the trap information is sent. You can set an IPv4 or IPv6 address or a domain name as the trap destination. <b>Note</b> When IPv6 is enabled, the SNMP Trap destination source address can either be the SLAAC IPv6 address (if available) or a user assigned IPv6 address. Both these are valid SNMP IPv6 destination addresses that uniquely identify the server.
<b>Step 8</b>	Server /snmp/trap-destinations # <b>set trap-port</b> <i>trap destination port</i>	Sets the port number the server uses to communicate with the trap destination. You can choose a number within the range 1 to 65535.
<b>Step 9</b>	Server /snmp/trap-destination # <b>commit</b>	Commits the transaction to the system configuration.

This example configures general SNMP trap settings and trap destination number 1 and commits the transaction:

```
Server# scope snmp
Server /snmp # Scope trap-destinations 1
Server /snmp/trap-destination *# set enabled yes
Server /snmp/trap-destination *# set version 2
Server /snmp/trap-destination *# set type inform
Server /snmp/trap-destination *# set user user1
Server /snmp/trap-destination *# set trap-addr www.cisco.com
Server /snmp/trap-destination *# set trap-port 10000
Server /snmp/trap-destination *# commit
Server /snmp/trap-destination # show detail
Trap Destination 1:
  Enabled: yes
  SNMP version: 2
  Trap type: inform
  SNMP user: user1
  Trap Address: www.cisco.com
  Trap Port: 10000
  Delete Trap: no
Server /snmp/trap-destination #
```

## Sending a Test SNMP Trap Message

### Before You Begin

You must log in with admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope snmp</b>	Enters the SNMP command mode.
<b>Step 2</b>	Server /snmp # <b>send-test-trap</b>	Sends an SNMP test trap to the configured SNMP trap destination that are enabled.  <b>Note</b> The trap must be configured and enabled in order to send a test message.

This example sends a test message to all the enabled SNMP trap destinations:

```
Server# scope snmp
Server /snmp # send-test-trap
SNMP Test Trap sent to the destination.
Server /snmp #
```

## Configuring SNMPv3 Users

### Before You Begin

- You must log in as a user with admin privileges to perform this task.
- SNMP must be enabled and saved before these configuration commands are accepted.

## Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope snmp</b>	Enters the SNMP command mode.
<b>Step 2</b>	Server /snmp # <b>scope v3users</b> <i>number</i>	Enters the SNMPv3 users command mode for the specified user number.
<b>Step 3</b>	Server /snmp/v3users # <b>set v3add</b> { <b>yes</b>   <b>no</b> }	<p>Adds or deletes an SNMPv3 user. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>yes</b>—This user is enabled as an SNMPv3 user and is allowed to access the SNMP OID tree.</li> </ul> <p><b>Note</b> The security name and security level must also be configured at this time or the user addition will fail.</p> <ul style="list-style-type: none"> <li>• <b>no</b>—This user configuration is deleted.</li> </ul>
<b>Step 4</b>	Server /snmp/v3users # <b>set v3security-name</b> <i>security-name</i>	Enter an SNMP username for this user.
<b>Step 5</b>	Server /snmp/v3users # <b>set v3security-level</b> { <b>noauthnopriv</b>   <b>authnopriv</b>   <b>authpriv</b> }	<p>Select a security level for this user. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>noauthnopriv</b>—The user does not require an authorization or privacy password.</li> <li>• <b>authnopriv</b>—The user requires an authorization password but not a privacy password. If you select this option, you must configure an authentication key.</li> <li>• <b>authpriv</b>—The user requires both an authorization password and a privacy password. If you select this option, you must configure an authentication key and a private encryption key.</li> </ul>
<b>Step 6</b>	Server /snmp/v3users # <b>set v3proto</b> { <b>MD5</b>   <b>SHA</b> }	Select an authentication protocol for this user.
<b>Step 7</b>	Server /snmp/v3users # <b>set v3auth-key</b> <i>auth-key</i>	Enter an authorization password for this user.
<b>Step 8</b>	Server /snmp/v3users # <b>set v3priv-proto</b> { <b>DES</b>   <b>AES</b> }	Select an encryption protocol for this user.
<b>Step 9</b>	Server /snmp/v3users # <b>set v3priv-auth-key</b> <i>priv-auth-key</i>	Enter a private encryption key (privacy password) for this user.
<b>Step 10</b>	Server /snmp/v3users # <b>commit</b>	Commits the transaction to the system configuration.

This example configures SNMPv3 user number 2 and commits the transaction:

```
Server# scope snmp
Server /snmp # scope v3users 2
Server /snmp/v3users # set v3add yes
Server /snmp/v3users *# set v3security-name ucsSNMPV3user
Server /snmp/v3users *# set v3security-level authpriv
Server /snmp/v3users *# set v3proto SHA
Server /snmp/v3users *# set v3auth-key
Please enter v3auth-key:ex4mplek3y
Please confirm v3auth-key:ex4mplek3y
Server /snmp/v3users *# set v3priv-prot0 AES
Server /snmp/v3users *# set v3priv-auth-key
Please enter v3priv-auth-key:!1@2#3$4%5^6&7*8
Please confirm v3priv-auth-key:!1@2#3$4%5^6&7*8
Server /snmp/v3users *# commit
Settings are being applied ... allow a few minutes for the process to complete
Server /snmp/v3users # show detail
User 2:
  Add User: yes
  Security Name: ucsSNMPV3user
  Security Level: authpriv
  Auth Type: SHA
  Auth Key: *****
  Encryption: AES
  Private Key: *****

Server /snmp/v3users #
```



## Managing Certificates

---

This chapter includes the following sections:

- [Managing the Server Certificate, page 223](#)
- [Generating a Certificate Signing Request, page 224](#)
- [Creating an Untrusted CA-Signed Certificate, page 226](#)
- [Uploading a Server Certificate, page 228](#)

### Managing the Server Certificate

You can generate a certificate signing request (CSR) to obtain a new certificate, and you can upload the new certificate to the Cisco IMC to replace the current server certificate. The server certificate may be signed either by a public Certificate Authority (CA), such as Verisign, or by your own certificate authority. The generated certificate key length is 2048 bits.



---

**Note** Before performing any of the following tasks in this chapter, ensure that the Cisco IMC time is set to the current time.

---

#### Procedure

---

- Step 1** Generate the CSR from the Cisco IMC.
- Step 2** Submit the CSR file to a certificate authority that will issue and sign your certificate. If your organization generates its own self-signed certificates, you can use the CSR file to generate a self-signed certificate.
- Step 3** Upload the new certificate to the Cisco IMC.
- Note** The uploaded certificate must be created from a CSR generated by the Cisco IMC. Do not upload a certificate that was not created by this method.
-

# Generating a Certificate Signing Request

You can either generate a self-signed certificate manually using the **generate-csr** command, or automatically when you change the hostname. For information on changing the hostname and auto generation of the self-signed certificate, see [Configuring Common Properties, on page 122](#).

To manually generate a certificate signing request, follow these steps:

## Before You Begin

- You must log in as a user with admin privileges to configure certificates.
- Ensure that the Cisco IMC time is set to the current time.

## Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope certificate</b>	Enters the certificate command mode.
<b>Step 2</b>	Server /certificate # <b>generate-csr</b>	Launches a dialog for the generation of a certificate signing request (CSR).

You will be prompted to enter the following information for the certificate signing request:

Name	Description
<b>Common Name</b> field	The fully qualified name of the Cisco IMC. By default the CN of the servers appears in CXXX-YYYYYY format, where XXX is the model number and YYYYYY is the serial number of the server. When you upgrade to latest version, CN is retained as is.
<b>Organization Name</b> field	The organization requesting the certificate.
<b>Organization Unit</b> field	The organizational unit.
<b>Locality</b> field	The city or town in which the company requesting the certificate is headquartered.
<b>State Name</b> field	The state or province in which the company requesting the certificate is headquartered.
<b>Country Code</b> drop-down list	The country in which the company resides.
<b>Email</b> field	The email contact at the company.



After you have entered the requested information, the system will generate and display a certificate signing request in the console output. A CSR file will not be created, but you can copy the CSR information from the console output and paste the information into a text file.

This example generates a certificate signing request:

```
Server# scope certificate
Server /certificate # generate-csr
Common Name (CN): test.example.com
Organization Name (O): Example, Inc.
Organization Unit (OU): Test Department
Locality (L): San Jose
StateName (S): CA
Country Code (CC): US
Email: user@example.com
Continue to generate CSR? [y|N]y

-----BEGIN CERTIFICATE REQUEST-----
MIIB/zCCAWgCAQAwgZkxCzAJBgNVBAYTA1VTMQswCQYDVQQIEwJDQTEVMBMGA1UE
BxMMU2FuIEpvc2UsIENBMRUwEwYDVQQKEwxFeGFtcGx1IEluYy4xEzARBgNVBAst
ClRlc3QgR3JvdXAxGTAXBgNVBAMTEHRlc3QuZXhhbXBsZS5jb20xHzAdBgkqhkiG
9w0BCQEWEHVzZXJAZXhhbXBsZS5jb20wgZ8wDQYJKoZIhvcNAQEBBQADgY0AMIGJ
AocGBAMZw4nTepNIDhVzb0j7Z2Je4xAG56zmSHRMQeOGHemdh66u2/XAoLx7YccYU
ZgAMivYCsKgb/6CjQtsofvzxmC/eAehuK3/SINv7wd6Vv2pBt6ZpXgD4VBNKOND1
GMbkPayVlQjbG4MD2dx2+H8EH3LMtdZrgKvPxPTE+bF5wzVNAgMBAAGgJTAjBgkq
hkiG9w0BCQcxFhMUQSBjaGFsbGVuZ2UgcGFzc3dvcmQwDQYJKoZIhvcNAQEFBQAD
gYEAG6lCaJoJaVMhzCl903O6Mg51zq1zXcz75+VFj2I6rH9asckCl3mkOVx5gJU
Ptt5CVQpNgNLdvbDPSsXretysOhqHmp9+CLv8FDuy1CDYfuaLtv1VwfvhevskV0j6
mK3Ku+YiORnv6DhxrOoqau8r/hyI/L4317IPN1HhOi3oha4=
-----END CERTIFICATE REQUEST-----
```

Copy everything from "-----BEGIN ..." to "END CERTIFICATE REQUEST-----",  
paste to a file, send to your chosen CA for signing,  
and finally upload the signed certificate via upload command.

---OR---

Continue to self sign CSR and overwrite the current certificate?  
All HTTPS and SSH sessions will be disconnected. [y|N]N

## What to Do Next

Perform one of the following tasks:

- If you do not want to obtain a certificate from a public certificate authority, and if your organization does not operate its own certificate authority, you can allow Cisco IMC to internally generate a self-signed certificate from the CSR and upload it immediately to the server. Type **y** after the final prompt in the example to perform this action.
- If your organization operates its own certificate server for generating self-signed certificates, copy the command output from "-----BEGIN ..." to "END CERTIFICATE REQUEST-----" and paste to a file named `csr.txt`. Input the CSR file to your certificate server to generate a self-signed certificate.
- If you will obtain a certificate from a public certificate authority, copy the command output from "-----BEGIN ..." to "END CERTIFICATE REQUEST-----" and paste to a file named `csr.txt`. Submit the CSR file to the certificate authority to obtain a signed certificate.
- Ensure that the certificate is of type **Server**.

If you did not use the first option, in which Cisco IMC internally generates and uploads a self-signed certificate, you must upload the new certificate using the **upload** command in certificate command mode.

# Creating an Untrusted CA-Signed Certificate

As an alternative to using a public Certificate Authority (CA) to generate and sign a server certificate, you can operate your own CA and sign your own certificates. This section shows commands for creating a CA and generating a server certificate using the OpenSSL certificate server running on Linux. For detailed information about OpenSSL, see <http://www.openssl.org>.



## Note

These commands are to be entered on a Linux server with the OpenSSL package, not in the Cisco IMC.

## Before You Begin

- Obtain and install a certificate server software package on a server within your organization.
- Ensure that the Cisco IMC time is set to the current time.

## Procedure

	Command or Action	Purpose
<b>Step 1</b>	<b>openssl genrsa -out CA_keyfilename keysize</b>  <b>Example:</b> <pre># openssl genrsa -out ca.key 2048</pre>	This command generates an RSA private key that will be used by the CA.  <b>Note</b> To allow the CA to access the key without user input, do not use the <code>-des3</code> option for this command.  The specified file name contains an RSA key of the specified key size.
<b>Step 2</b>	<b>openssl req -new -x509 -days numdays -key CA_keyfilename -out CA_certfilename</b>  <b>Example:</b> <pre># openssl req -new -x509 -days 365 -key ca.key -out ca.crt</pre>	This command generates a new self-signed certificate for the CA using the specified key. The certificate is valid for the specified period. The command prompts the user for additional certificate information.  The certificate server is an active CA.
<b>Step 3</b>	<b>echo "nsCertType = server" &gt; openssl.conf</b>  <b>Example:</b> <pre># echo "nsCertType = server" &gt; openssl.conf</pre>	This command adds a line to the OpenSSL configuration file to designate the certificate as a server-only certificate. This designation is a defense against a man-in-the-middle attack, in which an authorized client attempts to impersonate the server.  The OpenSSL configuration file <code>openssl.conf</code> contains the statement <code>"nsCertType = server"</code> .
<b>Step 4</b>	<b>openssl x509 -req -days numdays -in CSR_filename -CA CA_certfilename -set_serial 04 -CAkey CA_keyfilename -out server_certfilename -extfile openssl.conf</b>	This command directs the CA to use your CSR file to generate a server certificate.  Your server certificate is contained in the output file.

	Command or Action	Purpose
	<p><b>Example:</b>  <pre># openssl x509 -req -days 365 -in csr.txt -CA ca.crt -set_serial 04 -CAkey ca.key -out myserver05.crt -extfile openssl.conf</pre></p>	
<b>Step 5</b>	<p><b>openssl x509 -noout -text -purpose -in &lt;cert file&gt;</b></p> <p><b>Example:</b>  <pre>openssl x509 -noout -text -purpose -in &lt;cert file&gt;</pre></p>	<p>Verifies if the generated certificate is of type <b>Server</b>.</p> <p><b>Note</b> If the values of the fields <b>Server SSL</b> and <b>Netscape SSL</b> server are not yes, ensure that openssl.conf is configured to generate certificates of type server.</p>
<b>Step 6</b>	<p>If the generated certificate does not have the correct validity dates, ensure the Cisco IMC time is set to the current time, and regenerate the certificate by repeating steps 1 through 5.</p>	<p>(Optional)  Certificate with the correct validity dates is created.</p>

This example shows how to create a CA and to generate a server certificate signed by the new CA. These commands are entered on a Linux server running OpenSSL.

```
# /usr/bin/openssl genrsa -out ca.key 2048
Generating RSA private key, 2048 bit long modulus
.....+++++
.....+++++
e is 65537 (0x10001)
# /usr/bin/openssl req -new -x509 -days 365 -key ca.key -out ca.crt
You are about to be asked to enter information that will be incorporated
into your certificate request.
What you are about to enter is what is called a Distinguished Name or a
DN.
There are quite a few fields but you can leave some blank
For some fields there will be a default value,
If you enter '.', the field will be left blank.
-----
Country Name (2 letter code) [GB]:US
State or Province Name (full name) [Berkshire]:California
Locality Name (eg, city) [Newbury]:San Jose
Organization Name (eg, company) [My Company Ltd]:Example Incorporated
Organizational Unit Name (eg, section) []:Unit A
Common Name (eg, your name or your server's hostname) []:example.com
Email Address []:admin@example.com
# echo "nsCertType = server" > openssl.conf
# /usr/bin/openssl x509 -req -days 365 -in csr.txt -CA ca.crt -set_serial 01 -CAkey ca.key -out server.crt
-extfile openssl.conf
Signature ok
subject=/C=US/ST=California/L=San Jose/O=Example Inc./OU=Unit
A/CN=example.com/emailAddress=john@example.com
Getting CA Private Key
#
```

### What to Do Next

Upload the new certificate to the Cisco IMC.

## Uploading a Server Certificate

### Before You Begin

- You must log in as a user with admin privileges to upload a certificate.
- The certificate to be uploaded must be available as readable text. During the upload procedure, you will copy the certificate text and paste it into the CLI.
- Ensure that the generated certificate is of type **Server**.



#### Note

You must first generate a CSR using the Cisco IMC certificate management CSR generation procedure, and you must use that CSR to obtain the certificate for uploading. Do not upload a certificate that was not obtained by this method.



#### Note

All current HTTPS and SSH sessions are disconnected when the new server certificate is uploaded.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope certificate</b>	Enters the certificate command mode.
<b>Step 2</b>	Server /certificate # <b>upload</b>	Launches a dialog for entering and uploading the new server certificate.

Copy the certificate text, paste it into the console when prompted, and type CTRL+D to upload the certificate.

This example uploads a new certificate to the server:

```
Server# scope certificate
Server /certificate # upload
Please paste your certificate here, when finished, press CTRL+D.
-----BEGIN CERTIFICATE-----
MIIB/zCCAWgCAQAwZkxkCzAJBgNVBAYTA1VMTQswCQYDVQQLIEwJRDQTEVMBMGA1UE
BxMMU2FuIEpvc2UsIENBMRUwEwYDVQQKEwxFeGFtcGx1IEluYy4xEzARBgNVBASt
ClRlc3QgR3JvdXAxGTAXBgNVBAMTEHRlc3QuZXhhbXBsZS5jb20xHzAdBgkqhkiG
9w0BCQEWEHVzZXJAZXhhbXBsZS5jb20wgZ8wDQYJKoZIhvcNAQEBBQADgY0AMIGJ
AoGBAMZw4nTepNIDhVzb0j7Z2Je4xAG56zmSHRMQeOGHemdh66u2/XAoLx7YCcYU
ZgAMiVyCsKgb/6CjQtsofvzxmc/eAehuK3/SINv7wd6Vv2pBt6ZpXgD4VBKOND1
GMbkPayV1Qjbg4MD2dx2+H8EH3lMtdZrgKvPxPTE+bf5wZVNAgMBAAGgJTAjBgkq
hkiG9w0BCQcxFhMUQSBjaGFsbGVuZ2UgcGFzc3dvcmQwDQYJKoZIhvcNAQEFBQAD
gYEA61CaJoJavMhzC190306Mg51zq1zXcz75+VFj2I6rH9ascKClD3mkOVx5gJU
Ptt5CVQpNgNLdvbDPSsXretysOhqHmp9+CLv8FDuy1CDYfuaLtv1LWvfhevskV0j6
mK3Ku+YiORnv6DhxrOoqau8r/hyI/L4317IPN1HhOi3oha4=
-----END CERTIFICATE-----
```

<CTRL+D>





## Cisco IMC Firmware Management

---

This chapter includes the following sections:

- [Overview of Firmware, page 231](#)
- [Obtaining Firmware from Cisco, page 232](#)
- [Installing Cisco IMC Firmware from a Remote Server, page 234](#)
- [Activating Installed Cisco IMC Firmware, page 235](#)
- [Installing BIOS Firmware from a Remote Server, page 237](#)
- [Activating Installed BIOS Firmware, page 238](#)
- [Installing CMC Firmware from a Remote Server, page 240](#)
- [Activating Installed CMC Firmware, page 241](#)

### Overview of Firmware

C-Series servers use Cisco-certified firmware that is specific to the C-Series server model that you are using. You can download new releases of the firmware for all supported server models from Cisco.com.



#### Caution

When you install the new BIOS firmware, it must be from the same software release as the Cisco IMC firmware that is running on the server. Do not install the new BIOS firmware until after you have activated the matching Cisco IMC firmware or the server will not boot.

To avoid potential problems, we strongly recommend that you use the Cisco Host Upgrade Utility (HUU), which upgrades the BIOS, Cisco IMC, and other firmware to compatible levels. For detailed information about this utility, see the *Cisco Host Upgrade Utility Guide* for the version of the HUU that goes with the Cisco IMC software release that you want to install. The HUU guides are available at the following URL: [http://www.cisco.com/en/US/products/ps10493/products\\_user\\_guide\\_list.html](http://www.cisco.com/en/US/products/ps10493/products_user_guide_list.html).

If you want to update the firmware manually, you must update the Cisco IMC firmware first. The Cisco IMC firmware update process is divided into the following stages to minimize the amount of time that the server is offline:

- **Installation**—During this stage, Cisco IMC installs the selected Cisco IMC firmware in the nonactive, or backup, slot on the server.
- **Activation**—During this stage, Cisco IMC sets the nonactive firmware version as active, causing a disruption in service. When the server reboots, the firmware in the new active slot becomes the running version.

After you activate the Cisco IMC firmware, you can update the BIOS firmware.



#### Note

- You can either upgrade an older firmware version to a newer one, or downgrade a newer firmware version to an older one.
- This procedure only applies to the Cisco UCS C-Series server running on Stand-Alone mode. Contact Cisco Technical Assistance Center to upgrade firmware for UCS C-Series running on Cisco UCS Manager integrated mode.

Cisco IMC in a secure mode ensures that all the firmware images prior to loading and execution are digitally signed and are verified for authenticity and integrity to protect the device from running tampered software.

## Obtaining Firmware from Cisco

### Procedure

- Step 1** Navigate to <http://www.cisco.com/>.
- Step 2** If you are not already logged in, click **Log In** at the top right-hand edge of the page and log in using your Cisco.com credentials.
- Step 3** In the menu bar at the top, click **Support**.
- Step 4** Click **All Downloads** in the roll down menu.
- Step 5** If your server model is listed in the **Recently Used Products** list, click the server name. Otherwise, do the following:
  - a) In the left-hand box, click **Products**.
  - b) In the center box, click **Unified Computing and Servers**.
  - c) In the right-hand box, click **Cisco UCS C-Series Rack-Mount Standalone Server Software**.
  - d) In the right-hand box, click the server model whose software you want to download.
- Step 6** Click the **Unified Computing System (UCS) Server Firmware** link.
- Step 7** (Optional) Select a prior release from the menu bar on the left-hand side of the page.
- Step 8** Click the **Download** button associated with the Cisco Host Upgrade Utility ISO for the selected release.
- Step 9** Click **Accept License Agreement**.
- Step 10** Save the ISO file to a local drive.  
We recommend you upgrade the Cisco IMC and BIOS firmware on your server using this ISO file, which contains the Cisco Host Upgrade Utility. For detailed information about this utility, see the *Cisco Host Upgrade Utility Guide* for the version of the HUU that goes with the Cisco IMC software release that you want to install. The HUU guides are available at the following URL: [http://www.cisco.com/en/US/products/ps10493/products\\_user\\_guide\\_list.html](http://www.cisco.com/en/US/products/ps10493/products_user_guide_list.html).



**Step 11** (Optional) If you plan to upgrade the Cisco IMC and BIOS firmware manually, do the following:

- a) From the ISO file, open the ZIP file containing the firmware installation files.  
The ZIP file is on the top-level of the ISO file, and its name follows the format *ServerModel\_ReleaseNumber.ZIP*.  
For example, *C240M3\_1.4.4A.ZIP*.  
You do not need to extract all of the files contained in this ZIP file. Instead, you only need to open it so that you can access the BIOS firmware installation CAP file and the ZIP file containing the Cisco IMC firmware installation BIN file.
- b) From the *ServerModel\_ReleaseNumber.ZIP* file, extract the BIOS firmware installation CAP file and save it to your local drive.  
The CAP file is in the *ReleaseNumber/bios/cisco imc* folder, and its name follows the format *Server-BIOS-Release-Number.CAP*.  
For example, *1.4.4a/bios/cisco imc/C240-BIOS-1-4-4c-0.CAP*.
- c) From the *ServerModel\_ReleaseNumber.ZIP* file, open the ZIP file containing the Cisco IMC firmware installation files.  
The ZIP file is in the *ReleaseNumber/cisco imc* folder and its name follows the format *server-model-cisco imc-release.zip*.  
For example, *1.4.4a/cisco imc/c240-m3-cisco imc.1.4.4a.zip*.  
You do not need to extract all of the files contained in this zip file. Instead, you only need to open it so that you can access the Cisco IMC firmware installation BIN file.
- d) From the *server-model-cisco imc-release.zip* file, extract the full Cisco IMC firmware installation BIN file and save it to your local drive.  
The BIN file is in the *server-model-cisco imc-release* folder and its name follows the format *upd-pkg-server-model-cisco imc.full.release.bin*.  
For example, *c240-m3-cisco imc.1.4.4a/upd-pkg-c240-m3-cisco imc.full.1.4.4a.bin*.

**Step 12** (Optional) If you plan to install the firmware from a remote server, copy the BIOS installation CAP file and the Cisco IMC installation BIN file to the remote server you want to use.  
The remote server can be one of the following:

- TFTP
- FTP
- SFTP
- SCP
- HTTP

The server must have read permission for the destination folder on the remote server.

**Note** The Cisco UCS C-Series server now supports fingerprint confirmation of the server when you update firmware through a remote server. This option is available only if you choose SCP or SFTP as the remote server type.

If you chose SCP or SFTP as the remote server type while performing this action, a prompt with the message Server (RSA) key fingerprint is <server\_finger\_print\_ID> Do you wish to continue? Click y or n depending on the authenticity of the server fingerprint.

The fingerprint is based on the host's public key and helps you to identify or verify the host you are connecting to.

### What to Do Next

Use the Cisco Host Upgrade Utility to upgrade all firmware on the server or manually install the Cisco IMC firmware on the server.

## Installing Cisco IMC Firmware from a Remote Server

### Before You Begin

- Log in to the Cisco IMC as a user with admin privileges.
- Activate the Cisco IMC firmware that goes with the BIOS version you want to install, as described in the **Activating Installed Cisco IMC Firmware** section.
- Power off the server.



#### Note

You must not initiate a Cisco IMC update when another Cisco IMC update is already in progress.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server /server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	server /server # <b>scope bmc</b>	Enters bmc command mode.
<b>Step 3</b>	server /server/bmc # <b>scope firmware</b>	Enters the firmware command mode.
<b>Step 4</b>	server /server/bmc/firmware # <b>update protocol IP Address path</b>	Specifies the protocol, IP address of the remote server, and the file path to the firmware file on the server. The protocol can be one of the following: <ul style="list-style-type: none"> <li>• TFTP</li> <li>• FTP</li> <li>• SFTP</li> </ul>

	Command or Action	Purpose
		<ul style="list-style-type: none"> <li>• SCP</li> <li>• HTTP</li> </ul> <p><b>Note</b> The Cisco UCS C-Series server now supports fingerprint confirmation of the server when you update firmware through a remote server. This option is available only if you choose SCP or SFTP as the remote server type.</p> <p>If you chose SCP or SFTP as the remote server type while performing this action, a prompt with the message Server (RSA) key fingerprint is &lt;server_finger_print_ID&gt; Do you wish to continue? Click y or n depending on the authenticity of the server fingerprint.</p> <p>The fingerprint is based on the host's public key and helps you to identify or verify the host you are connecting to.</p>
<b>Step 5</b>	server /server/bmc/firmware # <b>show detail</b>	(Optional) Displays the progress of the firmware update.

This example shows how to update the Cisco IMC firmware:

```
server# scope server 1
server /server # scope bmc
server /server/bmc # scope firmware
server /server/bmc/firmware # update ftp 192.0.20.34 //test/dnld-ucs-k9-bundle.1.0.2h.bin
Firmware update has started.
Please check the status using "show detail"
server /server/bmc/firmware # show detail
Firmware Image Information:
  Update Stage: NONE
  Update Progress: 5
  Current FW Version: 2.0(6.56)
  FW Image 1 Version: 2.0(6.56)
  FW Image 1 State: RUNNING ACTIVATED
  FW Image 2 Version: 2.0(6.55)
  FW Image 2 State: BACKUP INACTIVATED
  Boot-loader Version: 2.0(6.56).36
  Secure Boot: ENABLED

server /server/bmc/firmware #
```

### What to Do Next

Activate the new firmware.

## Activating Installed Cisco IMC Firmware

### Before You Begin

Install the Cisco IMC firmware on the server.

**Important**

- While the activation is in progress, do not:
- Reset, power off, or shut down the server.
  - Reboot or reset Cisco IMC.
  - Activate any other firmware.
  - Export technical support or configuration data.

**Procedure**

	Command or Action	Purpose
<b>Step 1</b>	Server /server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	server /server # <b>scope bmc</b>	Enters bmc command mode.
<b>Step 3</b>	server /server/bmc # <b>scope firmware</b>	Enters the firmware command mode.
<b>Step 4</b>	Server /server/bmc # <b>show detail</b>	Displays the available firmware images and status.
<b>Step 5</b>	Server /server/bmc # <b>activate</b>	Activates the selected image. If no image number is specified, the server activates the currently inactive image.
<b>Step 6</b>	At the prompt, enter y to activate the selected firmware image.	The BMC reboots, terminating all CLI and GUI sessions until the reboot completes.
<b>Step 7</b>	Log back into the CLI and repeat steps 1–4 to verify the activation.	(Optional)

This example activates firmware image 2 and then verifies the activation after the BMC reboots:

```
Server# scope server 1
Server/server# scope bmc
Server /server/bmc # scope firmware
Server /server/bmc # show detail
Firmware Image Information:
  Update Stage: NONE
  Update Progress: 100
  Current FW Version: 2.0(6.55)
  FW Image 1 Version: 2.0(6.56)
  FW Image 1 State: BACKUP INACTIVATED
  FW Image 2 Version: 2.0(6.55)
  FW Image 2 State: RUNNING ACTIVATED
  Boot-loader Version: 2.0(6.55).36
  Secure Boot: ENABLED

Server /server/bmc # activate
This operation will activate firmware 2 and reboot the BMC.
Continue?[y|N]y
:
```

```

-- BMC reboot --
.
-- Log into CLI as Admin --

Server# scope server 1
Server/server# scope bmc
Server /server/bmc # scope firmware
Server /server/bmc # show detail
Firmware Image Information:
  Update Stage: NONE
  Update Progress: 100
  Current FW Version: 2.0(6.55)
  FW Image 1 Version: 2.0(6.56)
  FW Image 1 State: BACKUP INACTIVATED
  FW Image 2 Version: 2.0(6.55)
  FW Image 2 State: RUNNING ACTIVATED
  Boot-loader Version: 2.0(6.55).36
  Secure Boot: ENABLED

```

## Installing BIOS Firmware from a Remote Server

### Before You Begin

- Log in to the Cisco IMC as a user with admin privileges.
- Activate the Cisco IMC firmware that goes with the BIOS version you want to install, as described in the **Activating Installed BIOS Firmware** section.
- Power off the server.



#### Note

You must not initiate a BIOS update while another BIOS update is already in progress.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server /server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	server /server # <b>scope bios</b>	Enters BIOS command mode.
<b>Step 3</b>	server /server/bios # <b>update</b> <i>protocol IP Address pathrecovery</i>	Specifies the protocol, IP address of the remote server, and the file path to the firmware file on the server. The protocol can be one of the following: <ul style="list-style-type: none"> <li>• TFTP</li> <li>• FTP</li> <li>• SFTP</li> <li>• SCP</li> <li>• HTTP</li> </ul>

	Command or Action	Purpose
		<p><b>Note</b> The Cisco UCS C-Series server now supports fingerprint confirmation of the server when you update firmware through a remote server. This option is available only if you choose SCP or SFTP as the remote server type.</p> <p>If you chose SCP or SFTP as the remote server type while performing this action, a prompt with the message Server (RSA) key fingerprint is &lt;server_finger_print_ID&gt; Do you wish to continue? Click y or n depending on the authenticity of the server fingerprint.</p> <p>The fingerprint is based on the host's public key and helps you to identify or verify the host you are connecting to.</p>
<b>Step 4</b>	server /server/bios # <b>show detail</b>	(Optional) Displays the progress of the firmware update.

This example updates the BIOS firmware to Cisco IMC software release 2.0(7c):

```
Server# scope server 1
Server /server# scope bios
Server /server/bios# show detail
BIOS:
  BIOS Version: C3X60M3.2.0.7c.0.071620151216
  Backup BIOS Version: C3X60M3.2.0.7c.0.071620151216
  Boot Order: (none)
  Boot Override Priority:
  FW Update/Recovery Status: None, OK
  UEFI Secure Boot: disabled
  Configured Boot Mode: Legacy
  Actual Boot Mode: Legacy
  Last Configured Boot Order Source: CIMC
Server /server/bios # update ftp 192.0.20.34 //upgrade_bios_files/C3620-BIOS-2-0-7c-0.CAP
<CR> Press Enter key
Firmware update has started.
Check the status using "show detail"
Server /bios #
```

## Activating Installed BIOS Firmware

### Before You Begin

- Install the BIOS firmware on the server.
- Power off the host.

**Important**

While the activation is in progress, do not:

- Reset, power off, or shut down the server.
- Reboot or reset Cisco IMC.
- Activate any other firmware.
- Export technical support or configuration data.

**Procedure**

	Command or Action	Purpose
<b>Step 1</b>	Server /server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	server /server # <b>scope bios</b>	Enters BIOS command mode.
<b>Step 3</b>	Server /server/bios # <b>activate</b>	Activates the currently inactive image.
<b>Step 4</b>	At the prompt, enter y to activate the selected firmware image.	Initiates the activation.

This example activates firmware and then verifies the activation:

```

Server# scope server 1
Server /server# scope bios
Server /server/bios# show detail
BIOS:
  BIOS Version: C3X60M3.2.0.7c.0.071620151216
  Backup BIOS Version: C3X60M3.2.0.7c.0.071620151216
  Boot Order: (none)
  Boot Override Priority:
  FW Update/Recovery Status: None, OK
  UEFI Secure Boot: disabled
  Configured Boot Mode: Legacy
  Actual Boot Mode: Legacy
  Last Configured Boot Order Source: CIMC

Server /server/bios # activate
This operation will activate "C240M4.2.0.2.66.071820142034" after next host power off
Continue?[y|N]

Server# scope server 1
Server /server# scope bios
Server /server/bios# show detail
BIOS:
  BIOS Version: C3X60M3.2.0.7c.0.071620151216
  Backup BIOS Version: C3X60M3.2.0.7c.0.071620151216
  Boot Order: (none)
  Boot Override Priority:
  FW Update/Recovery Status: None, OK
  UEFI Secure Boot: disabled
  Configured Boot Mode: Legacy
  Actual Boot Mode: Legacy
  Last Configured Boot Order Source: CIMC

```

# Installing CMC Firmware from a Remote Server



**Note** You must not initiate a CMC update while another CMC update is already in progress.

## Before You Begin

- Log in to the Cisco IMC as a user with admin privileges.
- Obtain the Cisco Host Upgrade Utility ISO file from Cisco.com and extract the firmware installation files as described in [Obtaining Firmware from Cisco](#), on page 232.

## Procedure

	Command or Action	Purpose
<b>Step 1</b>	server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	server /chassis # <b>scope cmc</b> I 2	Enters CMC on the chosen SIOC controller command mode.
<b>Step 3</b>	server /chassis/cmc # <b>update protocol IP</b> <i>Address path</i>	<p>Specifies the protocol, IP address of the remote server, and the file path to the firmware file on the server. The protocol can be one of the following:</p> <ul style="list-style-type: none"> <li>• TFTP</li> <li>• FTP</li> <li>• SFTP</li> <li>• SCP</li> <li>• HTTP</li> </ul> <p><b>Note</b> The Cisco UCS C-Series server now supports fingerprint confirmation of the server when you update firmware through a remote server. This option is available only if you choose SCP or SFTP as the remote server type.</p> <p>If you chose SCP or SFTP as the remote server type while performing this action, a prompt with the message Server (RSA) key fingerprint is &lt;server_finger_print_ID&gt; Do you wish to continue? Click y or n depending on the authenticity of the server fingerprint.</p> <p>The fingerprint is based on the host's public key and helps you to identify or verify the host you are connecting to.</p>
<b>Step 4</b>	server /chassis/cmc # <b>show detail</b>	(Optional) Displays the progress of the firmware update.



This example shows how to update the CMC firmware:

```
server # scope chassis
server /chassis # scope cmc 1
server /chassis/cmc # update http 10.104.236.99 colusa2_cmc.2.0.7a.img
CMC Firmware update initialized.
Please check the status using "show detail"
Server /chassis/cmc # show detail
Firmware Image Information:
  Name: CMc1
  Update Stage: DOWNLOAD
  Update Progress: 25
  Current FW Version: 2.0 (7a)
  FW Image 1 Version: 2.0 (7a)
  FW Image 1 State: RUNNING ACTIVATED
  FW Image 2 Version: 2.0 (7a)
  FW Image 2 State: BACKUP INACTIVATED
server /chassis/cmc #
```

### What to Do Next

Activate the new firmware.

## Activating Installed CMC Firmware



**Note** CMCs are configured to have one in an active state while other acts as a backup, when you activate the backup CMC the previously active CMC changes to backup CMC activating the other.

### Before You Begin

Install the CMC firmware on the server.



**Important** While the activation is in progress, do not:

- Reset, power off, or shut down the server.
- Reboot or reset Cisco IMC.
- Activate any other firmware.
- Export technical support or configuration data.

- CMC-1 activation interrupts Cisco IMC network connectivity.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server# <b>scope cmc</b> /2	Enters the CMC of the chosen SIOC slot command mode.

	Command or Action	Purpose
<b>Step 3</b>	Server /cmc # <b>activate</b>	Activates the selected image for the chosen CMC.
<b>Step 4</b>	At the prompt, enter y to activate the selected firmware image.	The CMC-1 reboots, terminating all CLI and GUI sessions until the reboot completes, but CMC-2 reboot will not affect any active sessions.

This example activates CMC firmware on the SIOC slot 1:

```

Server # scope chassis
Server /chassis # scope cmc 1
Server /chassis/cmc # activate
Warning: The CMC will be rebooted immediately to complete the activation.
The network may go down temporarily till CMC boots up again
Continue?[y|N]y

```



## Viewing Faults and Logs

This chapter includes the following sections:

- [Fault Summary, page 243](#)
- [Fault History, page 244](#)
- [Cisco IMC Log, page 244](#)
- [System Event Log, page 248](#)
- [Logging Controls, page 250](#)

### Fault Summary

#### Viewing the Faults and Logs Summary

##### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <code>scope fault</code>	Enters fault command mode.
<b>Step 2</b>	Server # <code>show fault-entries</code>	Displays a log of all the faults.

This example displays a summary of faults:

```
Server # scope fault
Server /fault # show fault-entries

Time                Severity          Distinguished Name (DN)
-----
2015-08-18T06:44:02 major            sys/chassis-1/server-2/board/memarray-1/mem-2
2015-08-18T06:43:48 major            sys/chassis-1/server-2/board/memarray-1/mem-1

Description
-----
"DDR3_P1_A2_ECC: DIMM 2 is inoperable : Check or replace DIMM"
```

```
"DDR3_P1_A1_ECC: DIMM 1 is inoperable : Check or replace DIMM"
Server /fault #
```

## Fault History

### Viewing the Fault History

#### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope fault</b>	Enters fault command mode.
<b>Step 2</b>	Server # <b>show fault-history</b>	Displays the faults' history.

This example displays the faults' history:

```
Server # scope fault
Server /fault # show fault-history
Time                Severity  Source  Cause                Description
-----
-----
2014 Feb 6 23:24:49 error      %CIMC   PSU_REDUNDANCY-FAIL
"[F0743][major][psu-redundancy-fail]....
2014 Feb 6 23:24:49 error      %CIMC   EQUIPMENT_INOPERABLE
"[F0374][major][equipment-inoperable]...
2014 Feb 6 23:24:19 debug      %CIMC   2014 Feb 6 23      "24:19:7:%CIMC::: SEL INIT DONE"

Server /fault #
```

## Cisco IMC Log

### Viewing Cisco IMC Log

#### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope log</b>	Enters log command mode.
<b>Step 3</b>	Server /chassis/log # <b>show entries detail</b>	Displays the CMC trace log details.

This example displays the CMC trace log details:

```

Server# scope chassis
Server /chassis # scope log
Server /chassis/log # show entries detail
Trace Log:
  Time: 2015 Jul 26 06:35:15
  Severity: Notice
  Source: CMC:dropbear:19566
  Description: PAM password auth succeeded for 'cli' from 10.127.148.234:53791
  Order: 0
Trace Log:
  Time: 2015 Jul 26 06:35:15
  Severity: Notice
  Source: CMC:AUDIT:19566
  Description: Session open (user:admin, ip:10.127.148.234, id:6, type:CLI)
  Order: 1
Trace Log:
  Time: 2015 Jul 26 06:35:15
  Severity: Informational
  Source: CMC:dropbear:19566
  Description: " pam_session_manager(sshd:session): session (6) opened for user admin
from 10.127.148.234 by (uid=0) "
  Order: 2
Trace Log:
  Time: 2015 Jul 26 06:35:15
  Severity: Notice
  Source: CMC:AUDIT:1779
.
.
.
Server /chassis/log #

```

## Clearing Trace Logs

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope log</b>	Enters the log command mode.
<b>Step 3</b>	Server /chassis/log # <b>clear</b>	Clears the trace log.

The following example clears the log of trace logs:

```

Server# scope chassis
Server /chassis # scope log
Server /chassis/log # clear

Server /chassis/log #

```

## Configuring the Cisco IMC Log Threshold

You can specify the lowest level of messages that will be included in the syslog log.

## Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope log</b>	Enters log command mode.
<b>Step 3</b>	Server /chassis/log # <b>set local-syslog-severity level</b>	<p>The severity <i>level</i> can be one of the following, in decreasing order of severity:</p> <ul style="list-style-type: none"> <li>• emergency</li> <li>• alert</li> <li>• critical</li> <li>• error</li> <li>• warning</li> <li>• notice</li> <li>• informational</li> <li>• debug</li> </ul> <p><b>Note</b> Cisco IMC does not log any messages with a severity below the selected severity. For example, if you select <b>error</b>, then the Cisco IMC log will contain all messages with the severity Emergency, Alert, Critical, or Error. It will not show Warning, Notice, Informational, or Debug messages.</p>
<b>Step 4</b>	Server /chassis/log # <b>set remote-syslog-severity level</b>	<p>The severity <i>level</i> can be one of the following, in decreasing order of severity:</p> <ul style="list-style-type: none"> <li>• emergency</li> <li>• alert</li> <li>• critical</li> <li>• error</li> <li>• warning</li> <li>• notice</li> <li>• informational</li> <li>• debug</li> </ul> <p><b>Note</b> Cisco IMC does not log any messages with a severity below the selected severity. For example, if you select <b>error</b>, then the Cisco IMC log will contain all messages with the severity Emergency, Alert, Critical, or Error. It will not show Warning, Notice, Informational, or Debug messages.</p>

	Command or Action	Purpose
<b>Step 5</b>	Server /chassis/log # <b>commit</b>	Commits the transaction to the system configuration.
<b>Step 6</b>	Server /chassis/log # <b>show</b>	(Optional) Displays the configured severity level.

This example shows how to configure the logging of messages with a minimum severity of Debug for the local syslogs and error for the remote syslog:

```
Server# scope chassis
Server /chassis # scope log
Server /chassis/log # set local-syslog-severity debug
Server /chassis/log # set remote-syslog-severity error
Server /chassis/log *# commit
Server /chassis/log # show
Local Syslog Severity  Remote Syslog Severity
-----
debug                  error
Server /chassis/log #
```

## Sending the Cisco IMC Log to a Remote Server

You can configure profiles for one or two remote syslog servers to receive system log entries.

### Before You Begin

- The remote syslog server must be configured to receive logs from a remote host.
- The remote syslog server must be configured to receive all types of logs, including authentication-related logs.
- The remote syslog server's firewall must be configured to allow syslog messages to reach the syslog server.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope log</b>	Enters log command mode.
<b>Step 3</b>	Server /chassis/log # <b>scope server {1   2}</b>	Selects one of the two remote syslog server profiles and enters the command mode for configuring the profile.
<b>Step 4</b>	Server /chassis/log/server # <b>set server-ip</b> <i>ipv4 or ipv6 address or domain name</i>	Specifies the remote syslog server address. <b>Note</b> You can set an IPv4 or IPv6 address or a domain name as the remote server address.

	Command or Action	Purpose
<b>Step 5</b>	Server /chassis/log/server # <b>set server-port</b> <i>port number</i>	Sets the destination port number of the remote syslog server.
<b>Step 6</b>	Server /chassis/log/server # <b>set enabled</b> {yes   no}	Enables the sending of system log entries to this syslog server.
<b>Step 7</b>	Server /chassis/log/server # <b>commit</b>	Commits the transaction to the system configuration.
<b>Step 8</b>	Server /chassis/log/server # <b>exit</b>	Exits to the log command mode.
<b>Step 9</b>	Server /chassis/log/server # <b>showserver</b>	Exits to the log command mode.

This example shows how to configure a remote syslog server profile and enable the sending of system log entries:

## System Event Log

### Viewing the System Event Log

#### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope sel</b>	Enters the system event log (SEL) command mode.
<b>Step 2</b>	Server /sel # <b>show entries</b> [detail]	For system events, displays timestamp, the severity of the event, and a description of the event. The <b>detail</b> keyword displays the information in a list format instead of a table format.

This example displays the system event log:

```
Server# scope sel
Server /sel # show entries
Time                Severity          Description
-----
[System Boot]      Informational " LED_PSU_STATUS: Platform sensor, OFF event was asserted"

[System Boot]      Informational " LED_HLTH_STATUS: Platform sensor, GREEN was asserted"
[System Boot]      Normal           " PSU_REDUNDANCY: PS Redundancy sensor, Fully Redundant
was asserted"
[System Boot]      Normal           " PSU2 PSU2_STATUS: Power Supply sensor for PSU2, Power
Supply input lost (AC/DC) was deasserted"
[System Boot]      Informational " LED_PSU_STATUS: Platform sensor, ON event was asserted"

[System Boot]      Informational " LED_HLTH_STATUS: Platform sensor, AMBER was asserted"
[System Boot]      Critical         " PSU_REDUNDANCY: PS Redundancy sensor, Redundancy Lost
was asserted"
```



```

[System Boot]      Critical      " PSU2 PSU2_STATUS: Power Supply sensor for PSU2, Power
Supply input lost (AC/DC) was asserted"
[System Boot]      Normal       " HDD_01_STATUS: Drive Slot sensor, Drive Presence was
asserted"
[System Boot]      Critical      " HDD_01_STATUS: Drive Slot sensor, Drive Presence was
deasserted"
[System Boot]      Informational " DDR3_P2_D1_INFO: Memory sensor, OFF event was asserted"

2001-01-01 08:30:16 Warning      " PSU2 PSU2_VOUT: Voltage sensor for PSU2, failure event
was deasserted"
2001-01-01 08:30:16 Critical     " PSU2 PSU2_VOUT: Voltage sensor for PSU2, non-recoverable
event was deasserted"
2001-01-01 08:30:15 Informational " LED_PSU_STATUS: Platform sensor, ON event was asserted"

2001-01-01 08:30:15 Informational " LED_HLTH_STATUS: Platform sensor, AMBER was asserted"
2001-01-01 08:30:15 Informational " LED_HLTH_STATUS: Platform sensor, FAST BLINK event was
asserted"
2001-01-01 08:30:14 Non-Recoverable " PSU2 PSU2_VOUT: Voltage sensor for PSU2, non-recoverable
event was asserted"
2001-01-01 08:30:14 Critical     " PSU2 PSU2_VOUT: Voltage sensor for PSU2, failure event
was asserted"
--More--

```

## Viewing the System Event Log for Servers

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope server</b> {1   2 }	Enters the server mode for server 1 or 2.
<b>Step 2</b>	Server /server # <b>scope sel</b>	Enters the system event log (SEL) command mode.
<b>Step 3</b>	Server /server/sel # <b>show entries</b> [detail]	For system events, displays timestamp, the severity of the event, and a description of the event. The <b>detail</b> keyword displays the information in a list format instead of a table format.

This example displays the system event log:

```

Server # scope server 1
Server/server # scope sel
Server /server/sel # show entries
Time          Severity  Description
-----
2015-08-18 08:46:03 Normal    "BIOS_POST_CMPLT: Presence sensor, Device Inserted / Device
Present was asserted"
2015-08-18 08:46:00 Normal    "System Software event: System Event sensor, OEM System Boot
Event was asserted"
2010-03-21 00:17:42 Normal    "System Software event: System Event sensor, Timestamp Clock
Synch (second of pair) was asserted"
2015-08-18 08:44:34 Normal    "System Software event: System Event sensor, Timestamp Clock
Synch (first of pair) was asserted"
2015-08-18 08:44:00 Normal    "BIOS_POST_CMPLT: Presence sensor, Device Removed / Device
Absent was asserted"
2015-08-18 08:44:00 Normal    "MAIN_POWER_PRS: Presence sensor, Device Inserted / Device
Present was asserted"
2015-08-18 08:43:39 Normal    "MAIN_POWER_PRS: Presence sensor, Device Removed / Device
Absent was asserted"
2015-08-18 08:16:18 Normal    "BIOS_POST_CMPLT: Presence sensor, Device Inserted / Device
Present was asserted"

```

```

2015-08-18 08:16:16 Normal    "System Software event: System Event sensor, OEM System Boot
Event was asserted"
2010-03-20 23:47:59 Normal    "System Software event: System Event sensor, Timestamp Clock
Synch (second of pair) was asserted"
2015-08-18 08:14:50 Normal    "System Software event: System Event sensor, Timestamp Clock
Synch (first of pair) was asserted"
2015-08-18 08:14:20 Normal    "BIOS_POST_CMPLT: Presence sensor, Device Removed / Device
Absent was asserted"
2015-08-18 08:14:20 Normal    "MAIN_POWER_PRS: Presence sensor, Device Inserted / Device
Present was asserted"
2015-08-18 08:13:44 Normal    "MAIN_POWER_PRS: Presence sensor, Device Removed / Device
Absent was asserted"
2015-08-18 08:12:57 Normal    "FRU_RAM_SEL_FULLNESS: Event Log sensor for FRU_RAM, Log Area
Reset/Cleared was asserted"

```

## Clearing the System Event Log

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope sel</b>	Enters the system event log command mode.
<b>Step 2</b>	Server /sel # <b>clear</b>	You are prompted to confirm the action. If you enter <b>y</b> at the prompt, the system event log is cleared.

This example clears the system event log:

```

Server# scope sel
Server /sel # clear
This operation will clear the whole sel.
Continue?[y|N]y

```

## Logging Controls

### Configuring the Cisco IMC Log Threshold

You can specify the lowest level of messages that will be included in the syslog log.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope log</b>	Enters log command mode.
<b>Step 3</b>	Server /chassis/log # <b>set local-syslog-severity level</b>	The severity <i>level</i> can be one of the following, in decreasing order of severity:

	Command or Action	Purpose
		<ul style="list-style-type: none"> <li>• emergency</li> <li>• alert</li> <li>• critical</li> <li>• error</li> <li>• warning</li> <li>• notice</li> <li>• informational</li> <li>• debug</li> </ul> <p><b>Note</b> Cisco IMC does not log any messages with a severity below the selected severity. For example, if you select <b>error</b>, then the Cisco IMC log will contain all messages with the severity Emergency, Alert, Critical, or Error. It will not show Warning, Notice, Informational, or Debug messages.</p>
<b>Step 4</b>	Server /chassis/log # <b>set remote-syslog-severity level</b>	<p>The severity <i>level</i> can be one of the following, in decreasing order of severity:</p> <ul style="list-style-type: none"> <li>• emergency</li> <li>• alert</li> <li>• critical</li> <li>• error</li> <li>• warning</li> <li>• notice</li> <li>• informational</li> <li>• debug</li> </ul> <p><b>Note</b> Cisco IMC does not log any messages with a severity below the selected severity. For example, if you select <b>error</b>, then the Cisco IMC log will contain all messages with the severity Emergency, Alert, Critical, or Error. It will not show Warning, Notice, Informational, or Debug messages.</p>
<b>Step 5</b>	Server /chassis/log # <b>commit</b>	Commits the transaction to the system configuration.
<b>Step 6</b>	Server /chassis/log # <b>show</b>	(Optional) Displays the configured severity level.

This example shows how to configure the logging of messages with a minimum severity of Debug for the local syslogs and error for the remote syslog:

```
Server# scope chassis
Server /chassis # scope log
Server /chassis/log # set local-syslog-severity debug
Server /chassis/log # set remote-syslog-severity error
Server /chassis/log *# commit
Server /chassis/log # show
Local Syslog Severity  Remote Syslog Severity
-----
debug                  error

Server /chassis/log #
```

## Sending the Cisco IMC Log to a Remote Server

You can configure profiles for one or two remote syslog servers to receive system log entries.

### Before You Begin

- The remote syslog server must be configured to receive logs from a remote host.
- The remote syslog server must be configured to receive all types of logs, including authentication-related logs.
- The remote syslog server's firewall must be configured to allow syslog messages to reach the syslog server.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope log</b>	Enters log command mode.
<b>Step 3</b>	Server /chassis/log # <b>scope server {1   2}</b>	Selects one of the two remote syslog server profiles and enters the command mode for configuring the profile.
<b>Step 4</b>	Server /chassis/log/server # <b>set server-ip</b> <i>ipv4 or ipv6 address or domain name</i>	Specifies the remote syslog server address. <b>Note</b> You can set an IPv4 or IPv6 address or a domain name as the remote server address.
<b>Step 5</b>	Server /chassis/log/server # <b>set server-port</b> <i>port number</i>	Sets the destination port number of the remote syslog server.
<b>Step 6</b>	Server /chassis/log/server # <b>set enabled</b> <i>{yes   no}</i>	Enables the sending of system log entries to this syslog server.
<b>Step 7</b>	Server /chassis/log/server # <b>commit</b>	Commits the transaction to the system configuration.

	Command or Action	Purpose
<b>Step 8</b>	Server /chassis/log/server # <b>exit</b>	Exits to the log command mode.
<b>Step 9</b>	Server /chassis/log/server # <b>showserver</b>	Exits to the log command mode.

This example shows how to configure a remote syslog server profile and enable the sending of system log entries:

## Sending a Test Cisco IMC Log to a Remote Server

### Before You Begin

- The remote syslog server must be configured to receive logs from a remote host.
- The remote syslog server must be configured to receive all types of logs, including authentication-related logs.
- The remote syslog server's firewall must be configured to allow syslog messages to reach the syslog server.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope log</b>	Enters log command mode.
<b>Step 3</b>	Server /chassis/log # <b>send-test-syslog</b>	Sends a test log to the remote server.

This example shows how send a test log to a remote server:





## Server Utilities

This chapter includes the following sections:

- [Exporting Technical Support Data, page 255](#)
- [Rebooting the Cisco IMC, page 257](#)
- [Clearing the BIOS CMOS, page 258](#)
- [Resetting the BMC to factory Defaults, page 258](#)
- [Resetting CMCs to Factory Defaults, page 259](#)
- [Exporting and Importing the Cisco IMC and BMC Configuration, page 260](#)
- [Generating Non-Maskable Interrupts to the Host, page 265](#)
- [Adding Cisco IMC Banner, page 266](#)

## Exporting Technical Support Data

Perform this task when requested by the Cisco Technical Assistance Center (TAC). This utility creates a summary report containing configuration information, logs and diagnostic data that will help TAC in troubleshooting and resolving a technical issue.



### Important

If any firmware or BIOS updates are in progress, do not export the technical support data until those tasks are complete.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope tech-support</b>	Enters the tech-support command mode.

	Command or Action	Purpose
<b>Step 3</b>	Server /chassis/tech-support # <b>set collect-from</b> {all   cmc   peercmc   bmc1   bmc2}	Specifies the component for which the technical support data has to be exported.
<b>Step 4</b>	Server /chassis/tech-support # <b>set remote-ip</b> <i>ip-address</i>	Specifies the IP address of the remote server on which the technical support data file should be stored.
<b>Step 5</b>	Server /chassis/tech-support # <b>set remote-path</b> <i>path/filename</i>	Specifies the file name in which the support data should be stored on the remote server. When you enter this name, include the relative path for the file from the top of the server tree to the desired location.  <b>Tip</b> To have the system auto-generate the file name, enter the file name as default.tar.gz.
<b>Step 6</b>	Server /chassis/tech-support # <b>set remote-protocol</b> <i>protocol</i>	Specifies the protocol to connect to the remote server. It can be of the following types: <ul style="list-style-type: none"> <li>• TFTP</li> <li>• FTP</li> <li>• SFTP</li> <li>• SCP</li> <li>• HTTP</li> </ul> <b>Note</b> The Cisco UCS C-Series server now supports fingerprint confirmation of the server when you update firmware through a remote server. This option is available only if you choose SCP or SFTP as the remote server type.  If you chose SCP or SFTP as the remote server type while performing this action, a prompt with the message Server (RSA) key fingerprint is <server_finger_print_ID> Do you wish to continue? Click y or n depending on the authenticity of the server fingerprint.  The fingerprint is based on the host's public key and helps you to identify or verify the host you are connecting to.
<b>Step 7</b>	Server /chassis/tech-support # <b>set remote-username</b> <i>name</i>	Specifies the user name on the remote server on which the technical support data file should be stored. This field does not apply if the protocol is TFTP or HTTP.
<b>Step 8</b>	Server /chassis/tech-support # <b>set remote-password</b> <i>password</i>	Specifies the password on the remote server on which the technical support data file should be stored. This field does not apply if the protocol is TFTP or HTTP.
<b>Step 9</b>	Server /chassis/tech-support # <b>commit</b>	Commits the transaction to the system configuration.



	Command or Action	Purpose
<b>Step 10</b>	Server /chassis/tech-support # <b>start</b>	Begins the transfer of the data file to the remote server.
<b>Step 11</b>	Server /chassis/tech-support # <b>show detail</b>	(Optional) Displays the progress of the transfer of the data file to the remote server.
<b>Step 12</b>	Server /chassis/tech-support # <b>cancel</b>	(Optional) Cancels the transfer of the data file to the remote server.

This example creates a technical support data file and transfers the file to a TFTP server:

```
Server# scope chassis
Server /chassis # scope tech-support
Server /chassis/tech-support # set collect-from all
Server /chassis/tech-support* # set remote-ip 192.0.20.41
Server /chassis/tech-support* # set remote-protocol tftp
Server /chassis/tech-support *# set remote-path /user/user1/default.tar.gz
Server /chassis/tech-support *# commit
Server /chassis/tech-support # start
Tech Support upload started.

Server /chassis/tech-support # show detail

Tech Support:
  Server Address: 192.0.20.41
    Path('default' for auto-naming): default.tar.gz
    Protocol: tftp
    Username:
    Password: *****
    Collect from: all
    Progress(%): 100
    Status: COMPLETED

Server /chassis/tech-support #
```

### What to Do Next

Provide the generated report file to Cisco TAC.

## Rebooting the Cisco IMC

On rare occasions, such as an issue with the current running firmware, troubleshooting a server may require you to reboot the Cisco IMC. This procedure is not part of the normal maintenance of a server. After you reboot the Cisco IMC, you are logged off and the Cisco IMC will be unavailable for a few minutes.



### Note

If you reboot the Cisco IMC while the server is performing power-on self test (POST) or is operating in the Extensible Firmware Interface (EFI) shell, the server will be powered down until the Cisco IMC reboot is complete.

**Procedure**

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /server # <b>scope bmc</b>	Enters bmc command mode.
<b>Step 3</b>	Server /server/bmc # <b>reboot</b>	The Cisco IMC reboots.

This example reboots the Cisco IMC:

```
Server# scope server 1
Server /server # scope bmc
Server /server/bmc # reboot
```

## Clearing the BIOS CMOS

On rare occasions, troubleshooting a server may require you to clear the server's BIOS CMOS memory. This procedure is not part of the normal maintenance of a server.

**Procedure**

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /server # <b>scope bios</b>	Enters the bios command mode.
<b>Step 3</b>	Server /server/bios # <b>clear-cmos</b>	After a prompt to confirm, clears the CMOS memory.

This example clears the BIOS CMOS memory:

```
Server# scope server 2
Server /server # scope bios
Server /server/bios # clear-cmos
```

This operation will clear the BIOS CMOS.  
 Note: Server should be in powered off state to clear CMOS.  
 Continue?[y|n] **y**

```
Server /server/bios #
```

## Resetting the BMC to factory Defaults

On rare occasions, such as an issue with the current running firmware, troubleshooting a server may require you to reset the BMC to the factory default. When this happens, all user-configurable settings are reset.

This procedure is not part of the normal server maintenance. After you reset the BMC, you are logged off and must log in again. You may also lose connectivity and may need to reconfigure the network settings.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /server # <b>scope bmc</b>	Enters bmc command mode. <b>Note</b> Depending on the server number you have chosen, enters the BMC1 or BMC2 mode.
<b>Step 3</b>	Server /server/bmc # <b>factory-default</b>	After a prompt to confirm, the BMC resets to factory defaults. All your BMC configuration is lost and some of the inventory information may not be available until the server is powered on or power cycled.

This example resets BMC1 to factory defaults:

```
Server# scope server 1
Server /server # scope bmc
Server /server/bmc # factory-default
This operation will reset the Server BMC configuration to factory default.
All your configuration will be lost. Some inventory information may
not be available until the server is powered on or power cycled.
Continue?[y|N] y
```

## Resetting CMCs to Factory Defaults

On rare occasions, such as an issue with the current running firmware, troubleshooting a server may require you to reset the CMCs to the factory default. When this happens, all user-configurable settings are reset.

This procedure is not part of the normal server maintenance. After you reset the CMC, you are logged off and must log in again. You may also lose connectivity and may need to reconfigure the network settings.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>factory-default</b>	After a prompt to confirm, the CMCs resets to factory defaults. All your CMC configuration is lost and the network configuration mode is set to <b>Cisco Card</b> mode by default.

The CMCs factory defaults include the following conditions:

- SSH is enabled for access to the Cisco IMC CLI. Telnet is disabled.

- HTTPS is enabled for access to the Cisco IMC GUI.
- A single user account exists (user name is **admin** , password is **password** ).
- DHCP is enabled on the management port.
- The previous actual boot order is retained.
- KVM and vMedia are enabled.
- USB is enabled.
- SoL is disabled.

This example resets the CMCs to factory defaults:

```
Server# scope chassis
Server /chassis # factory-default
This operation will reset the CMC configuration to factory default.
All your configuration will be lost.
Continue?[y|N]
```

# Exporting and Importing the Cisco IMC and BMC Configuration

## Importing a CMC Configuration



**Important** If any firmware or BIOS updates are in progress, do not import the Cisco IMC configuration until those tasks are complete.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope import-export</b>	Enters the import-export command mode.
<b>Step 3</b>	Server /chassis/import-export # <b>import-config protocol ip-address path-and-filename</b>	The configuration file at the specified path and file name on the remote server at the specified IPv4 or IPv6 address or a hostname will be imported. The remote server can be one of the following: <ul style="list-style-type: none"> <li>• TFTP</li> <li>• FTP</li> <li>• SFTP</li> <li>• SCP</li> <li>• HTTP</li> </ul>

	Command or Action	Purpose
		<p><b>Note</b> The Cisco UCS C-Series server now supports fingerprint confirmation of the server when you update firmware through a remote server. This option is available only if you choose SCP or SFTP as the remote server type.</p> <p>If you chose SCP or SFTP as the remote server type while performing this action, a prompt with the message Server (RSA) key fingerprint is &lt;server_finger_print_ID&gt; Do you wish to continue? Click y or n depending on the authenticity of the server fingerprint.</p> <p>The fingerprint is based on the host's public key and helps you to identify or verify the host you are connecting to.</p>
<b>Step 4</b>	Enter the Username, Password and Pass Phrase.	Sets the username, password and the pass phrase for the file being imported. Starts the import operation.

To determine whether the import operation has completed successfully, use the **show detail** command. To abort the operation, type CTRL+C.

This example shows how to import a Cisco IMC configuration:

```

Server# scope chassis
Server /chassis # scope import-export
Server /chassis/import-export # import-config tftp 192.0.2.34 /ucs/backups/cimc5.xml
Username:pynj
Password:****
Passphrase:***
Import config started. Please check the status using "show detail".
Server /chassis/import-export # show detail
Import Export:
  Operation: Import
  Status: COMPLETED
  Error Code: 100 (No Error)
  Diagnostic Message: NONE
Server /chassis/import-export #

```

## Importing BMC Configuration



### Important

If any firmware or BIOS updates are in progress, do not import the Cisco IMC configuration until those tasks are complete.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /server # <b>scope bmc</b>	Enters bmc command mode.

	Command or Action	Purpose
<b>Step 3</b>	Server /server/bmc # <b>scope import-export</b>	Enters the import-export command mode.
<b>Step 4</b>	Server /server/bmc/import-export # <b>import-config</b> <i>protocol</i> <i>ip-address path-and-filename</i>	<p>The configuration file at the specified path and file name on the remote server at the specified IPv4 or IPv6 address or a hostname will be imported. The remote server can be one of the following:</p> <ul style="list-style-type: none"> <li>• TFTP</li> <li>• FTP</li> <li>• SFTP</li> <li>• SCP</li> <li>• HTTP</li> </ul> <p><b>Note</b> The Cisco UCS C-Series server now supports fingerprint confirmation of the server when you update firmware through a remote server. This option is available only if you choose SCP or SFTP as the remote server type.</p> <p>If you chose SCP or SFTP as the remote server type while performing this action, a prompt with the message Server (RSA) key fingerprint is &lt;server_finger_print_ID&gt; Do you wish to continue? Click y or n depending on the authenticity of the server fingerprint.</p> <p>The fingerprint is based on the host's public key and helps you to identify or verify the host you are connecting to.</p>
<b>Step 5</b>	Enter the Username and Password.	Sets the username and password for the file being imported. Starts the import operation.

To determine whether the import operation has completed successfully, use the **show detail** command. To abort the operation, type CTRL+C.

This example shows how to import a Cisco IMC configuration:

```

Server# scope server 2
Server /server# scope bmc
Server /server/bmc # scope import-export
Server /server/bmc/import-export # import-config tftp 192.0.2.34 /ucs/backups/cimc5.xml
Username:pynj
Password:****
Import config started. Please check the status using "show detail".
Server /chassis/import-export # show detail
Import Export:
  Operation: Import
  Status: COMPLETED
  Error Code: 100 (No Error)
  Diagnostic Message: NONE
Server /server/bmc/import-export #

```

## Exporting the BMC Configuration



**Note** For security reasons, this operation does not export user accounts or the server certificate.



**Important** If any firmware or BIOS updates are in progress, do not export the Cisco IMC configuration until those tasks are complete.

### Before You Begin

Obtain the backup remote server IP address.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /server # <b>scope bmc</b>	Enters bmc command mode.
<b>Step 3</b>	Server /server/bmc # <b>scope import-export</b>	Enters the import-export command mode.
<b>Step 4</b>	Server /server/bmc/import-export # <b>export-config protocol ip-address path-and-filename</b>	<p>The configuration file will be stored at the specified path and file name on a remote server at the specified IPv4 or IPv6 address or a hostname. The remote server could be one of the following types:</p> <ul style="list-style-type: none"> <li>• TFTP</li> <li>• FTP</li> <li>• SFTP</li> <li>• SCP</li> <li>• HTTP</li> </ul> <p><b>Note</b> The Cisco UCS C-Series server now supports fingerprint confirmation of the server when you update firmware through a remote server. This option is available only if you choose SCP or SFTP as the remote server type.</p> <p>If you chose SCP or SFTP as the remote server type while performing this action, a prompt with the message Server (RSA) key fingerprint is &lt;server_finger_print_ID&gt; Do you wish to continue? Click y or n depending on the authenticity of the server fingerprint.</p> <p>The fingerprint is based on the host's public key and helps you to identify or verify the host you are connecting to.</p>

	Command or Action	Purpose
<b>Step 5</b>	Enter the Username and Password.	Sets the username, password and the pass phrase for the file being exported. Starts the backup operation.

To determine whether the export operation has completed successfully, use the **show detail** command. To abort the operation, type CTRL+C.

This example shows how to back up the Cisco IMC configuration:

```
Server# scope server 2
Server /server# scope bmc
Server /server/bmc # scope import-export
Server /server/bmc/import-export # export-config tftp 192.0.2.34 /ucs/backups/cimc5.xml
Username:pynj
Password:****
Export config started. Please check the status using "show detail".
Server /cimc/import-export # show detail
Import Export:
  Operation: EXPORT
  Status: COMPLETED
  Error Code: 100 (No Error)
  Diagnostic Message: NONE

Server /server/bmc/import-export #
```

## Exporting the CMC Configuration



**Note** For security reasons, this operation does not export user accounts or the server certificate.



**Important** If any firmware or BIOS updates are in progress, do not export the Cisco IMC configuration until those tasks are complete.

### Before You Begin

Obtain the backup remote server IP address.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope import-export</b>	Enters the import-export command mode.
<b>Step 3</b>	Server /chassis/import-export # <b>export-config protocol ip-address path-and-filename</b>	The configuration file will be stored at the specified path and file name on a remote server at the specified IPv4 or IPv6 address or a hostname. The remote server could be one of the following types: <ul style="list-style-type: none"> <li>• TFTP</li> </ul>



	Command or Action	Purpose
		<ul style="list-style-type: none"> <li>• FTP</li> <li>• SFTP</li> <li>• SCP</li> <li>• HTTP</li> </ul> <p><b>Note</b> The Cisco UCS C-Series server now supports fingerprint confirmation of the server when you update firmware through a remote server. This option is available only if you choose SCP or SFTP as the remote server type.</p> <p>If you chose SCP or SFTP as the remote server type while performing this action, a prompt with the message Server (RSA) key fingerprint is &lt;server_finger_print_ID&gt; Do you wish to continue? Click y or n depending on the authenticity of the server fingerprint.</p> <p>The fingerprint is based on the host's public key and helps you to identify or verify the host you are connecting to.</p>
<b>Step 4</b>	Enter the Username, Password and Pass Phrase.	Sets the username, password and the pass phrase for the file being exported. Starts the backup operation.

To determine whether the export operation has completed successfully, use the **show detail** command. To abort the operation, type CTRL+C.

This example shows how to back up the Cisco IMC configuration:

```

Server# scope chassis
Server /chassis # scope import-export
Server /chassis/import-export # export-config tftp 192.0.2.34 /ucs/backups/cimc5.xml
Username:pynj
Password:****
Passphrase:***
Export config started. Please check the status using "show detail".
Server /chassis/import-export # show detail
Import Export:
  Operation: EXPORT
  Status: COMPLETED
  Error Code: 100 (No Error)
  Diagnostic Message: NONE

Server /chassis/import-export #

```

## Generating Non-Maskable Interrupts to the Host

In some situations, the server might hang and not respond to traditional debug mechanisms. By generating a non maskable interrupt (NMI) to the host, you can create and send a crash dump file of the server and use it to debug the server.

Depending on the type of operating system associated with the server, this task might restart the OS.

**Procedure**

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server {1   2}</b>	Enters server command mode of server 1 or 2.
<b>Step 3</b>	Server /chassis/server # <b>generate-nmi</b>	Generates the crash dump file for the server.  To use this command, the server must be powered on, and you must be logged in as an administrator.

This example shows how to generate NMI signals to the host:

```
Server # scope chassis
Server /chassis # scope server 2
Server /chassis/server # generate-nmi
This operation will send NMI to host and may cause reboot of OS
OS reboot depends on it's NMI configuration
Do you want to continue? [y|N] y
Server /chassis/server #
```

## Adding Cisco IMC Banner

**Procedure**

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>upload-banner</b>	A prompt to enter the banner displays.
<b>Step 3</b>	Enter the banner and press CTRL+D.	At the prompt, enter y. This results in a loss of the current session, when you log back on again, the new banner appears.
<b>Step 4</b>	Server /chassis # <b>show-banner</b>	(Optional) The banner that you have added displays.

This example shows how to add the Cisco IMC banner:

```
Server # scope chassis
Server /chassis # upload-banner
Please paste your custom banner here, when finished, press enter and CTRL+D.
hello world
This will terminate all open SSH session to take an immediate action.
Do you wish to continue? [y/N] yy
Server /chassis # show-banner
hello world
Server /chassis #
```



## BIOS Parameters by Server Model

This appendix contains the following sections:

- [C3X60 Servers, page 267](#)

### C3X60 Servers

#### Main BIOS Parameters for C3260 Servers

##### Main BIOS Parameters

Name	Description
TPM Support set TPMAdminCtrl	<p>TPM (Trusted Platform Module) is a microchip designed to provide basic security-related functions primarily involving encryption keys. This option allows you to control the TPM Security Device support for the system. It can be one of the following:</p> <ul style="list-style-type: none"><li>• <b>Disabled</b>—The server does not use the TPM.</li><li>• <b>Enabled</b>—The server uses the TPM.</li></ul> <p><b>Note</b> We recommend that you contact your operating system vendor to make sure the operating system supports this feature.</p>

## Advanced BIOS Parameters for C3260 Servers

### Processor Configuration Parameters

Name	Description
<b>Intel Hyper-Threading Technology</b> <b>set IntelHyperThread</b>	<p>Whether the processor uses Intel Hyper-Threading Technology, which allows multithreaded software applications to execute threads in parallel within each processor. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not permit hyperthreading.</li> <li>• <b>Enabled</b>—The processor allows for the parallel execution of multiple threads.</li> </ul> <p>We recommend that you contact your operating system vendor to make sure the operating system supports this feature.</p>
<b>Number of Enabled Cores</b> <b>set CoreMultiProcessing</b>	<p>Allows you to disable one or more of the physical cores on the server. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>All</b>—Enables all physical cores. This also enables Hyper Threading on the associated logical processor cores.</li> <li>• <b>1 through <i>n</i></b>—Specifies the number of physical processor cores that can run on the server. Each physical core has an associated logical core.</li> </ul> <p>We recommend that you contact your operating system vendor to make sure the operating system supports this feature.</p>
<b>Execute Disable</b> <b>set ExecuteDisable</b>	<p>Classifies memory areas on the server to specify where application code can execute. As a result of this classification, the processor disables code execution if a malicious worm attempts to insert code in the buffer. This setting helps to prevent damage, worm propagation, and certain classes of malicious buffer overflow attacks. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not classify memory areas.</li> <li>• <b>Enabled</b>—The processor classifies memory areas.</li> </ul> <p>We recommend that you contact your operating system vendor to make sure the operating system supports this feature.</p>

Name	Description
<b>Intel VT</b> <b>set IntelVT</b>	<p>Whether the processor uses Intel Virtualization Technology (VT), which allows a platform to run multiple operating systems and applications in independent partitions. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not permit virtualization.</li> <li>• <b>Enabled</b>—The processor allows multiple operating systems in independent partitions.</li> </ul> <p><b>Note</b> If you change this option, you must power cycle the server before the setting takes effect.</p>
<b>Intel VT-d</b> <b>set IntelVTD</b>	<p>Whether the processor uses Intel Virtualization Technology for Directed I/O (VT-d). This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not use virtualization technology.</li> <li>• <b>Enabled</b>—The processor uses virtualization technology.</li> </ul>
<b>Intel VT-d Coherency Support</b> <b>set CoherencySupport</b>	<p>Whether the processor supports Intel VT-d Coherency. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not support coherency.</li> <li>• <b>Enabled</b>—The processor uses VT-d Coherency as required.</li> </ul>
<b>Intel VT-d ATS Support</b> <b>set ATS</b>	<p>Whether the processor supports Intel VT-d Address Translation Services (ATS). This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not support ATS.</li> <li>• <b>Enabled</b>—The processor uses VT-d ATS as required.</li> </ul>

Name	Description
<b>CPU Performance</b> <b>set CPUPerformance</b>	Sets the CPU performance profile for the server. The performance profile consists of the following options: <ul style="list-style-type: none"> <li>• DCU Streamer Prefetcher</li> <li>• DCU IP Prefetcher</li> <li>• Hardware Prefetcher</li> <li>• Adjacent Cache-Line Prefetch</li> </ul> This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Enterprise</b>—All options are enabled.</li> <li>• <b>High_Throughput</b>—Only the DCU IP Prefetcher is enabled. The rest of the options are disabled.</li> <li>• <b>HPC</b>—All options are enabled. This setting is also known as high performance computing.</li> <li>• <b>Custom</b>—All performance profile options can be configured from the BIOS setup on the server. In addition, the Hardware Prefetcher and Adjacent Cache-Line Prefetch options can be configured in the fields below.</li> </ul>
<b>Hardware Prefetcher</b> <b>set HardwarePrefetch</b>	Whether the processor allows the Intel hardware prefetcher to fetch streams of data and instruction from memory into the unified second-level cache when necessary. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The hardware prefetcher is not used.</li> <li>• <b>Enabled</b>—The processor uses the hardware prefetcher when cache issues are detected.</li> </ul>
<b>Adjacent Cache Line Prefetcher</b> <b>set AdjacentCacheLinePrefetch</b>	Whether the processor fetches cache lines in even/odd pairs instead of fetching just the required line. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor only fetches the required line.</li> <li>• <b>Enabled</b>— The processor fetches both the required line and its paired line.</li> </ul>

Name	Description
<b>DCU Streamer Prefetch</b> <b>set DcuStreamerPrefetch</b>	Whether the processor uses the DCU IP Prefetch mechanism to analyze historical cache access patterns and preload the most relevant lines in the L1 cache. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not try to anticipate cache read requirements and only fetches explicitly requested lines.</li> <li>• <b>Enabled</b>—The DCU prefetcher analyzes the cache read pattern and prefetches the next line in the cache if it determines that it may be needed.</li> </ul>
<b>DCU IP Prefetcher</b> <b>set DcuIpPrefetch</b>	Whether the processor uses the DCU IP Prefetch mechanism to analyze historical cache access patterns and preload the most relevant lines in the L1 cache. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not preload any cache data.</li> <li>• <b>Enabled</b>—The DCU IP prefetcher preloads the L1 cache with the data it determines to be the most relevant.</li> </ul>
<b>Direct Cache Access Support</b> <b>set DirectCacheAccess</b>	Allows processors to increase I/O performance by placing data from I/O devices directly into the processor cache. This setting helps to reduce cache misses. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Data from I/O devices is not placed directly into the processor cache.</li> <li>• <b>Enabled</b>—Data from I/O devices is placed directly into the processor cache.</li> </ul>

Name	Description
<p><b>Power Technology</b> set <b>CPUPowerManagement</b></p>	<p>Enables you to configure the CPU power management settings for the following options:</p> <ul style="list-style-type: none"> <li>• Enhanced Intel Speedstep Technology</li> <li>• Intel Turbo Boost Technology</li> <li>• Processor Power State C6</li> </ul> <p>Power Technology can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Custom</b>—The server uses the individual settings for the BIOS parameters mentioned above. You must select this option if you want to change any of these BIOS parameters.</li> <li>• <b>Disabled</b>—The server does not perform any CPU power management and any settings for the BIOS parameters mentioned above are ignored.</li> <li>• <b>Energy_Efficient</b>—The server determines the best settings for the BIOS parameters mentioned above and ignores the individual settings for these parameters.</li> </ul>
<p><b>Enhanced Intel Speedstep Technology</b> set <b>EnhancedIntelSpeedStep</b></p>	<p>Whether the processor uses Enhanced Intel SpeedStep Technology, which allows the system to dynamically adjust processor voltage and core frequency. This technology can result in decreased average power consumption and decreased average heat production. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor never dynamically adjusts its voltage or frequency.</li> <li>• <b>Enabled</b>—The processor utilizes Enhanced Intel SpeedStep Technology and enables all supported processor sleep states to further conserve power.</li> </ul> <p>We recommend that you contact your operating system vendor to make sure the operating system supports this feature.</p> <p><b>Note</b> <b>CPUPowerManagement</b> must be set to <b>Custom</b> or the server ignores the setting for this parameter.</p>



Name	Description
<b>Intel Turbo Boost Technology</b> <b>set IntelTurboBoostTech</b>	<p>Whether the processor uses Intel Turbo Boost Technology, which allows the processor to automatically increase its frequency if it is running below power, temperature, or voltage specifications. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not increase its frequency automatically.</li> <li>• <b>Enabled</b>—The processor utilizes Turbo Boost Technology if required.</li> </ul> <p><b>Note</b> <b>CPUPowerManagement</b> must be set to <b>Custom</b> or the server ignores the setting for this parameter.</p>
<b>Processor Power State C6</b> <b>set ProcessorC6Report</b>	<p>Whether the BIOS sends the C6 report to the operating system. When the OS receives the report, it can transition the processor into the lower C6 power state to decrease energy usage while maintaining optimal processor performance. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The BIOS does not send the C6 report.</li> <li>• <b>Enabled</b>—The BIOS sends the C6 report, allowing the OS to transition the processor to the C6 low power state.</li> </ul> <p><b>Note</b> <b>CPUPowerManagement</b> must be set to <b>Custom</b> or the server ignores the setting for this parameter.</p>
<b>Processor Power State C1 Enhanced</b> <b>set ProcessorC1EReport</b>	<p>Whether the CPU transitions to its minimum frequency when entering the C1 state. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The CPU continues to run at its maximum frequency in C1 state.</li> <li>• <b>Enabled</b>—The CPU transitions to its minimum frequency. This option saves the maximum amount of power in C1 state.</li> </ul>
<b>Frequency Floor Override</b> <b>set CpuFreqFloor</b>	<p>Whether the CPU is allowed to drop below the maximum non-turbo frequency when idle. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>— The CPU can drop below the maximum non-turbo frequency when idle. This option decreases power consumption but may reduce system performance.</li> <li>• <b>Enabled</b>— The CPU cannot drop below the maximum non-turbo frequency when idle. This option improves system performance but may increase power consumption.</li> </ul>

Name	Description
<p><b>P-STATE Coordination</b> set PsdCoordType</p>	<p>Allows you to define how BIOS communicates the P-state support model to the operating system. There are 3 models as defined by the Advanced Configuration and Power Interface (ACPI) specification.</p> <ul style="list-style-type: none"> <li>• <b>HW_ALL</b>—The processor hardware is responsible for coordinating the P-state among logical processors with dependencies (all logical processors in a package).</li> <li>• <b>SW_ALL</b>—The OS Power Manager (OSPM) is responsible for coordinating the P-state among logical processors with dependencies (all logical processors in a physical package), and must initiate the transition on all of the logical processors.</li> <li>• <b>SW_ANY</b>—The OS Power Manager (OSPM) is responsible for coordinating the P-state among logical processors with dependencies (all logical processors in a package), and may initiate the transition on any of the logical processors in the domain.</li> </ul> <p><b>Note</b> <b>CPUPowerManagement</b> must be set to <b>Custom</b> or the server ignores the setting for this parameter.</p>
<p><b>Energy Performance</b> set CpuEngPerfBias</p>	<p>Allows you to determine whether system performance or energy efficiency is more important on this server. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Balanced_Energy</b></li> <li>• <b>Balanced_Performance</b></li> <li>• <b>Energy_Efficient</b></li> <li>• <b>Performance</b></li> </ul>

## Memory Configuration Parameters

Name	Description
<b>Select Memory RAS</b> <b>set SelectMemoryRAS</b>	<p>How the memory reliability, availability, and serviceability (RAS) is configured for the server. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Maximum_Performance</b>—System performance is optimized.</li> <li>• <b>Mirroring</b>—System reliability is optimized by using half the system memory as backup.</li> <li>• <b>Lockstep</b>—If the DIMM pairs in the server have an identical type, size, and organization and are populated across the SMI channels, you can enable lockstep mode to minimize memory access latency and provide better performance. This option offers better system performance than Mirroring and better reliability than Maximum Performance but lower reliability than Mirroring and lower system performance than Maximum Performance.</li> </ul>
<b>DRAM Clock Throttling</b> <b>set DRAMClockThrottling</b>	<p>Allows you to tune the system settings between the memory bandwidth and power consumption. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Balanced</b>— DRAM clock throttling is reduced, providing a balance between performance and power.</li> <li>• <b>Performance</b>—DRAM clock throttling is disabled, providing increased memory bandwidth at the cost of additional power.</li> <li>• <b>Energy_Efficient</b>—DRAM clock throttling is increased to improve energy efficiency.</li> </ul>
<b>NUMA</b> <b>set NUMAOptimize</b>	<p>Whether the BIOS supports Non-Uniform Memory Access (NUMA). This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The BIOS does not support NUMA.</li> <li>• <b>Enabled</b>—The BIOS includes the ACPI tables that are required for NUMA-aware operating systems. If you enable this option, the system must disable Inter-Socket Memory interleaving on some platforms.</li> </ul>

Name	Description
<b>Low Voltage DDR Mode</b> set LvDDRMode	Whether the system prioritizes low voltage or high frequency memory operations. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Power_Saving_Mode</b>—The system prioritizes low voltage memory operations over high frequency memory operations. This mode may lower memory frequency in order to keep the voltage low.</li> <li>• <b>Performance_Mode</b>—The system prioritizes high frequency operations over low voltage operations.</li> </ul>
<b>DRAM Refresh rate</b> set DramRefreshRate	Allows you to set the rate at which the DRAM cells are refreshed. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>1x</b>—DRAM cells are refreshed every 64ms.</li> <li>• <b>2x</b>—DRAM cells are refreshed every 32ms.</li> <li>• <b>3x</b>—DRAM cells are refreshed every 21ms.</li> <li>• <b>4x</b>—DRAM cells are refreshed every 16ms.</li> <li>• <b>Auto</b>—DRAM cells refresh rate is automatically chosen by the BIOS based on the system configuration. This is the recommended setting for this parameter.</li> </ul>
<b>Channel Interleaving</b> set ChannelInterLeave	Whether the CPU divides memory blocks and spreads contiguous portions of data across interleaved channels to enable simultaneous read operations. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Auto</b>—The CPU determines what interleaving is done.</li> <li>• <b>1_Way</b>—Some channel interleaving is used.</li> <li>• <b>2_Way</b></li> <li>• <b>3_Way</b></li> <li>• <b>4_Way</b>—The maximum amount of channel interleaving is used.</li> </ul>

Name	Description
<b>Rank Interleaving</b> <b>set RankInterLeave</b>	<p>Whether the CPU interleaves physical ranks of memory so that one rank can be accessed while another is being refreshed. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Auto</b>—The CPU determines what interleaving is done.</li> <li>• <b>1_Way</b>—Some rank interleaving is used.</li> <li>• <b>2_Way</b></li> <li>• <b>4_Way</b></li> <li>• <b>8_Way</b>—The maximum amount of rank interleaving is used.</li> </ul>
<b>Patrol Scrub</b> <b>set PatrolScrub</b>	<p>Whether the system actively searches for, and corrects, single bit memory errors even in unused portions of the memory on the server. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The system checks for memory ECC errors only when the CPU reads or writes a memory address.</li> <li>• <b>Enabled</b>—The system periodically reads and writes memory searching for ECC errors. If any errors are found, the system attempts to fix them. This option may correct single bit errors before they become multi-bit errors, but it may adversely affect performance when the patrol scrub is running.</li> </ul>
<b>Demand Scrub</b> <b>set DemandScrub</b>	<p>Whether the system corrects single bit memory errors encountered when the CPU or I/O makes a demand read. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>— Single bit memory errors are not corrected.</li> <li>• <b>Enabled</b>— Single bit memory errors are corrected in memory and the corrected data is set in response to the demand read.</li> </ul>

Name	Description
<b>Altitude</b> set Altitude	The approximate number of meters above sea level at which the physical server is installed. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Auto</b>—The CPU determines the physical elevation.</li> <li>• <b>300_M</b>—The server is approximately 300 meters above sea level.</li> <li>• <b>900_M</b>—The server is approximately 900 meters above sea level.</li> <li>• <b>1500_M</b>—The server is approximately 1500 meters above sea level.</li> <li>• <b>3000_M</b>—The server is approximately 3000 meters above sea level.</li> </ul>

#### QPI Configuration Parameters

Name	Description
<b>QPI Link Frequency Select</b> set QPILinkFrequency	The Intel QuickPath Interconnect (QPI) link frequency, in gigatransfers per second (GT/s). This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Auto</b>—The CPU determines the QPI link frequency.</li> <li>• <b>6.4_GT/s</b></li> <li>• <b>7.2_GT/s</b></li> <li>• <b>8.0_GT/s</b></li> </ul>

#### SATA Configuration Parameters

Name	Description
<b>SATA Mode</b> set SataMode	Mode of operation of Serial Advanced Technology Attachment (SATA) Solid State Drives (SSD). <ul style="list-style-type: none"> <li>• <b>Disabled</b>— All SATA ports is disabled, and drivers are not enumerated.</li> <li>• <b>AHCI Mode</b>—The default mode. Drives operate according to newer standard of Advance Host Controller Interface(AHCI).</li> </ul>

## USB Configuration Parameters

Name	Description
<b>Legacy USB Support</b> <b>set LegacyUSBSupport</b>	Whether the system supports legacy USB devices. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—USB devices are only available to EFI applications.</li> <li>• <b>Enabled</b>—Legacy USB support is always available.</li> <li>• <b>Auto</b>—Disables legacy USB support if no USB devices are connected.</li> </ul>
<b>Port 60/64 Emulation</b> <b>set UsbEmul6064</b>	Whether the system supports 60h/64h emulation for complete USB keyboard legacy support. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—60h/64 emulation is not supported.</li> <li>• <b>Enabled</b>—60h/64 emulation is supported.</li> </ul> You should select this option if you are using a non-USB aware operating system on the server.
<b>All USB Devices</b> <b>set AllUsbDevices</b>	Whether all physical and virtual USB devices are enabled or disabled. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—All USB devices are disabled.</li> <li>• <b>Enabled</b>—All USB devices are enabled.</li> </ul>
<b>USB Port: Rear</b> <b>set UsbPortRear</b>	Whether the rear panel USB devices are enabled or disabled. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Disables the rear panel USB ports. Devices connected to these ports are not detected by the BIOS and operating system.</li> <li>• <b>Enabled</b>—Enables the rear panel USB ports. Devices connected to these ports are detected by the BIOS and operating system.</li> </ul>
<b>USB Port: Internal</b> <b>set UsbPortInt</b>	Whether the internal USB devices are enabled or disabled. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Disables the internal USB ports. Devices connected to these ports are not detected by the BIOS and operating system.</li> <li>• <b>Enabled</b>—Enables the internal USB ports. Devices connected to these ports are detected by the BIOS and operating system.</li> </ul>

Name	Description
<b>USB Port: KVM</b> set <code>UsbPortKVM</code>	Whether the KVM ports are enabled or disabled. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Disables the KVM keyboard and/or mouse devices. Keyboard and/or mouse will not work in the KVM window.</li> <li>• <b>Enabled</b>—Enables the KVM keyboard and/or mouse devices.</li> </ul>
<b>USB Port: vMedia</b> set <code>UsbPortVMedia</code>	Whether the virtual media devices are enabled or disabled. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Disables the vMedia devices.</li> <li>• <b>Enabled</b>—Enables the vMedia devices.</li> </ul>

### PCI Configuration Parameters

Name	Description
<b>PCI ROM CLP</b> set <code>PciRomClp</code>	PCI ROM Command Line Protocol (CLP) controls the execution of different Option ROMs such as PxE and iSCSI that are present in the card. By default, it is disabled. <ul style="list-style-type: none"> <li>• <b>Enabled</b>— Enables you to configure execution of different option ROMs such as PxE and iSCSI for an individual ports separately.</li> <li>• <b>Disabled</b>—The default option. You cannot choose different option ROMs. A default option ROM is executed during PCI enumeration.</li> </ul>
<b>ASPM Support</b> set <code>ASPMSupport</code>	Allows you to set the level of ASPM (Active Power State Management) support in the BIOS. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—ASPM support is disabled in the BIOS.</li> <li>• <b>Force L0s</b>—Force all links to L0 standby (L0s) state.</li> <li>• <b>Auto</b>—The CPU determines the power state.</li> </ul>



## Serial Configuration Parameters

Name	Description
<b>Out-of-Band Mgmt Port</b> <b>set comSpcrEnable</b>	<p>Allows you to configure the COM port 0 that can be used for Windows Emergency Management services. ACPI SPCR table is reported based on this setup option. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Configures the COM port 0 as a general purpose port for use with the Windows Operating System.</li> <li>• <b>Enabled</b>—Configures the COM port 0 as a remote management port for Windows Emergency Management services.</li> </ul>
<b>Console Redirection</b> <b>set ConsoleRedir</b>	<p>Allows a serial port to be used for console redirection during POST and BIOS booting. After the BIOS has booted and the operating system is responsible for the server, console redirection is irrelevant and has no effect. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—No console redirection occurs during POST.</li> <li>• <b>COM_0</b>—Enables console redirection on COM port 0 during POST.</li> <li>• <b>COM_1</b>—Enables console redirection on COM port 1 during POST.</li> </ul>
<b>Terminal Type</b> <b>set TerminalType</b>	<p>What type of character formatting is used for console redirection. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>PC-ANSI</b>—The PC-ANSI terminal font is used.</li> <li>• <b>VT100</b>—A supported vt100 video terminal and its character set are used.</li> <li>• <b>VT100+</b>—A supported vt100-plus video terminal and its character set are used.</li> <li>• <b>VT-UTF8</b>—A video terminal with the UTF-8 character set is used.</li> </ul> <p><b>Note</b> This setting must match the setting on the remote terminal application.</p>

Name	Description
<b>Bits per second</b> <b>set BaudRate</b>	<p>What BAUD rate is used for the serial port transmission speed. If you disable Console Redirection, this option is not available. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>9600</b>—A 9,600 BAUD rate is used.</li> <li>• <b>19200</b>—A 19,200 BAUD rate is used.</li> <li>• <b>38400</b>—A 38,400 BAUD rate is used.</li> <li>• <b>57600</b>—A 57,600 BAUD rate is used.</li> <li>• <b>115200</b>—A 115,200 BAUD rate is used.</li> </ul> <p><b>Note</b> This setting must match the setting on the remote terminal application.</p>
<b>Flow Control</b> <b>set FlowCtrl</b>	<p>Whether a handshake protocol is used for flow control. Request to Send / Clear to Send (RTS/CTS) helps to reduce frame collisions that can be introduced by a hidden terminal problem. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>None</b>—No flow control is used.</li> <li>• <b>Hardware_RTS/CTS</b>—RTS/CTS is used for flow control.</li> </ul> <p><b>Note</b> This setting must match the setting on the remote terminal application.</p>
<b>Putty KeyPad</b> <b>set PuttyFunctionKeyPad</b>	<p>Allows you to change the action of the PuTTY function keys and the top row of the numeric keypad. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>VT100</b>—The function keys generate ESC OP through ESC O[.</li> <li>• <b>LINUX</b>—Mimics the Linux virtual console. Function keys F6 to F12 behave like the default mode, but F1 to F5 generate ESC [[A through ESC [[E.</li> <li>• <b>XTERMR6</b>—Function keys F5 to F12 behave like the default mode. Function keys F1 to F4 generate <b>ESC OP</b> through <b>ESC OS</b>, which are the sequences produced by the top row of the keypad on Digital terminals.</li> <li>• <b>SCO</b>—The function keys F1 to F12 generate ESC [M through ESC [X. The function and shift keys generate ESC [Y through ESC [j. The control and function keys generate ESC [k through ESC [v. The shift, control and function keys generate ESC [w through ESC [{.</li> <li>• <b>ESCN</b>—The default mode. The function keys match the general behavior of Digital terminals. The function keys generate sequences such as ESC [11~ and ESC [12~.</li> <li>• <b>VT400</b>—The function keys behave like the default mode. The top row of the numeric keypad generates ESC OP through ESC OS.</li> </ul>

Name	Description
<b>Redirection After BIOS POST</b> set <code>RedirectionAfterPOST</code>	<p>Whether BIOS console redirection should be active after BIOS POST is complete and control given to the OS bootloader. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Always_Enabled</b>—BIOS Legacy console redirection is active during the OS boot and run time.</li> <li>• <b>Bootloader</b>—BIOS Legacy console redirection is disabled before giving control to the OS boot loader.</li> </ul>

### LOM and PCIe Slots Configuration Parameters

Name	Description
<b>CDN Support for VIC</b> set <code>CdnEnable</code>	<p>Whether the Ethernet Network naming convention is according to Consistent Device Naming (CDN) or the traditional way of naming conventions. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>— CDN support for VIC cards is disabled.</li> <li>• <b>Enabled</b>— CDN support is enabled for VIC cards.</li> </ul> <p><b>Note</b>    CDN support for VIC cards work with Windows 2012 or the latest OS only.</p>
<b>All PCIe Slots OptionROM</b> set <code>PcieOptionROMs</code>	<p>Whether the server can use Option ROM present in the PCIe Cards. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The Option ROM for all PCIe slots are not available.</li> <li>• <b>Enabled</b>—The Option ROMs for all the PCIe slots are available.</li> <li>• <b>UEFI_Only</b>—The Option ROMs for slot <i>n</i> are available for UEFI only.</li> <li>• <b>Legacy_Only</b>—The Option ROM for slot <i>n</i> are available for legacy only.</li> </ul>
<b>PCIe Slot:<i>n</i> OptionROM</b> set <code>PcieSlot<i>n</i>OptionROM</code>	<p>Whether the server can use the Option ROMs present in the PCIe Cards. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The Option ROM for slot <i>n</i> is not available.</li> <li>• <b>Enabled</b>—The Option ROM for slot <i>n</i> is available.</li> <li>• <b>UEFI_Only</b>—The Option ROM for slot <i>n</i> is available for UEFI only.</li> <li>• <b>Legacy_Only</b>—The Option ROM for slot <i>n</i> is available for legacy only.</li> </ul>

Name	Description
<b>PCIe Mezzanine OptionROM</b> <b>set PcieMezzOptionROM</b>	Whether the PCIe mezzanine slot expansion ROM is available to the server. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>— The Option ROM for slot <i>M</i> is not available.</li> <li>• <b>Enabled</b>— The Option ROM for slot <i>M</i> is available.</li> <li>• <b>UEFI_Only</b>—The Option ROM for slot <i>M</i> is available for UEFI only.</li> <li>• <b>Legacy_Only</b>—The expansion slot for slot <i>M</i> is available for legacy only.</li> </ul>
<b>SIOC1 Link Speed</b> <b>Set PcieSlot1LinkSpeed</b>	System IO Controller 1 (SIOC1) add-on slot 1 link speed. <ul style="list-style-type: none"> <li>• <b>GEN1</b> — Link speed can reach up to first generation.</li> <li>• <b>GEN2</b> — Link speed can reach up to second generation.</li> <li>• <b>GEN3</b>— The default link speed. Link speed can reach up to third generation.</li> <li>• <b>Disabled</b> — Slot is disabled, and the card is not enumerated.</li> </ul>
<b>SIOC2 Link Speed</b> <b>set PcieSlot2LinkSpeed</b>	System IO Controller 2 (SIOC2) add-on slot 2 link speed. <ul style="list-style-type: none"> <li>• <b>GEN1</b> — Link speed can reach up to first generation.</li> <li>• <b>GEN2</b> — Link speed can reach up to second generation.</li> <li>• <b>GEN3</b>— The default link speed. Link speed can reach up to third generation.</li> <li>• <b>Disabled</b> — Slot is disabled, and the card is not enumerated.</li> </ul>
<b>Mezz Link Speed</b> <b>set PcieSlotMLinkSpeed</b>	Mezz link speed. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>GEN 1</b>— Link speed can reach up to first generation.</li> <li>• <b>GEN 2</b>— Link speed can reach up to second generation.</li> <li>• <b>GEN 3</b>—The default link speed. Link speed can reach up to third generation.</li> <li>• <b>Disabled</b>—Slot is disabled, and the card is not enumerated.</li> </ul>

## Server Management BIOS Parameters for C3260 Servers

### Server Management BIOS Parameters

Name	Description
<b>FRB-2 Timer</b> <b>set FRB-2</b>	Whether the FRB2 timer is used by Cisco IMC to recover the system if it hangs during POST. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The FRB2 timer is not used.</li> <li>• <b>Enabled</b>—The FRB2 timer is started during POST and used to recover the system if necessary.</li> </ul>
<b>OS Watchdog Timer</b> <b>set OSBootWatchdogTimer</b>	Whether the BIOS programs the watchdog timer with a specified timeout value. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The watchdog timer is not used to track how long the server takes to boot.</li> <li>• <b>Enabled</b>—The watchdog timer tracks how long the server takes to boot. If the server does not boot within the length of time specified by the <b>set OSBootWatchdogTimerTimeout</b> command, the Cisco IMC logs an error and takes the action specified by the <b>set OSBootWatchdogTimerPolicy</b> command.</li> </ul>
<b>OS Watchdog Timer Timeout</b> <b>set OSBootWatchdogTimerTimeOut</b>	If OS does not boot within the specified time, OS watchdog timer expires and system takes action according to timer policy. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>5_Minutes</b>—The OS watchdog timer expires 5 minutes after it begins to boot.</li> <li>• <b>10_Minutes</b>—The OS watchdog timer expires 10 minutes after it begins to boot.</li> <li>• <b>15_Minutes</b>—The OS watchdog timer expires 15 minutes after it begins to boot.</li> <li>• <b>20_Minutes</b>—The OS watchdog timer expires 20 minutes after it begins to boot.</li> </ul> <p><b>Note</b> This option is only applicable if you enable the OS Boot Watchdog Timer.</p>

Name	Description
<b>OS Watchdog Timer Policy</b> set OSBootWatchdogTimerPolicy	What action the system takes if the watchdog timer expires. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Do_Nothing</b>—The server takes no action if the watchdog timer expires during OS boot.</li> <li>• <b>Power_Down</b>—The server is powered off if the watchdog timer expires during OS boot.</li> <li>• <b>Reset</b>—The server is reset if the watchdog timer expires during OS boot.</li> </ul> <p><b>Note</b> This option is only applicable if you enable the OS Boot Watchdog Timer.</p>

## Main BIOS Parameters for C3X60 M4 Servers

### Main BIOS Parameters

Name	Description
<b>Reboot Host Immediately</b> checkbox	Upon checking, reboots the host server immediately. You must check the checkbox after saving changes.
<b>TPM Support</b>	TPM (Trusted Platform Module) is a microchip designed to provide basic security-related functions primarily involving encryption keys. This option allows you to control the TPM Security Device support for the system. It can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The server does not use the TPM.</li> <li>• <b>Enabled</b>—The server uses the TPM.</li> </ul> <p><b>Note</b> We recommend that you contact your operating system vendor to make sure the operating system supports this feature.</p>

## Advanced BIOS Parameters for C3X60 M4 Servers

### Processor Configuration Parameters

Name	Description
<b>Intel Hyper-Threading Technology</b> <b>set IntelHyperThread</b>	<p>Whether the processor uses Intel Hyper-Threading Technology, which allows multithreaded software applications to execute threads in parallel within each processor. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not permit hyperthreading.</li> <li>• <b>Enabled</b>—The processor allows for the parallel execution of multiple threads.</li> </ul> <p>We recommend that you contact your operating system vendor to make sure the operating system supports this feature.</p>
<b>Number of Enabled Cores</b> <b>set CoreMultiProcessing</b>	<p>Allows you to disable one or more of the physical cores on the server. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>All</b>—Enables all physical cores. This also enables Hyper Threading on the associated logical processor cores.</li> <li>• <b>1 through n</b>—Specifies the number of physical processor cores that can run on the server. Each physical core has an associated logical core.</li> </ul> <p>We recommend that you contact your operating system vendor to make sure the operating system supports this feature.</p>
<b>Execute Disable</b> <b>set ExecuteDisable</b>	<p>Classifies memory areas on the server to specify where application code can execute. As a result of this classification, the processor disables code execution if a malicious worm attempts to insert code in the buffer. This setting helps to prevent damage, worm propagation, and certain classes of malicious buffer overflow attacks. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not classify memory areas.</li> <li>• <b>Enabled</b>—The processor classifies memory areas.</li> </ul> <p>We recommend that you contact your operating system vendor to make sure the operating system supports this feature.</p>

Name	Description
<b>Intel VT</b> <b>set IntelVT</b>	Whether the processor uses Intel Virtualization Technology (VT), which allows a platform to run multiple operating systems and applications in independent partitions. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not permit virtualization.</li> <li>• <b>Enabled</b>—The processor allows multiple operating systems in independent partitions.</li> </ul> <p><b>Note</b> If you change this option, you must power cycle the server before the setting takes effect.</p>
<b>Intel VT-d</b> <b>set IntelVTD</b>	Whether the processor uses Intel Virtualization Technology for Directed I/O (VT-d). This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not use virtualization technology.</li> <li>• <b>Enabled</b>—The processor uses virtualization technology.</li> </ul>
<b>Intel VT-d Interrupt Remapping</b> <b>set InterruptRemap</b>	Whether the processor supports Intel VT-d Interrupt Remapping. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not support remapping.</li> <li>• <b>Enabled</b>—The processor uses VT-d Interrupt Remapping as required.</li> </ul>
<b>Intel VT-d PassThrough DMA</b> <b>set PassThroughDMA</b>	Whether the processor supports Intel VT-d Pass-through DMA. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not support pass-through DMA.</li> <li>• <b>Enabled</b>—The processor uses VT-d Pass-through DMA as required.</li> </ul>
<b>Intel VT-d Coherency Support</b> <b>set CoherencySupport</b>	Whether the processor supports Intel VT-d Coherency. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not support coherency.</li> <li>• <b>Enabled</b>—The processor uses VT-d Coherency as required.</li> </ul>
<b>Intel VT-d ATS Support</b> <b>set ATS</b>	Whether the processor supports Intel VT-d Address Translation Services (ATS). This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not support ATS.</li> <li>• <b>Enabled</b>—The processor uses VT-d ATS as required.</li> </ul>



Name	Description
<b>CPU Performance</b> <b>set CPUPerformance</b>	<p>Sets the CPU performance profile for the server. The performance profile consists of the following options:</p> <ul style="list-style-type: none"> <li>• DCU Streamer Prefetcher</li> <li>• DCU IP Prefetcher</li> <li>• Hardware Prefetcher</li> <li>• Adjacent Cache-Line Prefetch</li> </ul> <p>This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Enterprise</b>—All options are enabled.</li> <li>• <b>High_Throughput</b>—Only the DCU IP Prefetcher is enabled. The rest of the options are disabled.</li> <li>• <b>HPC</b>—All options are enabled. This setting is also known as high performance computing.</li> <li>• <b>Custom</b>—All performance profile options can be configured from the BIOS setup on the server. In addition, the Hardware Prefetcher and Adjacent Cache-Line Prefetch options can be configured in the fields below.</li> </ul>
<b>Hardware Prefetcher</b> <b>set HardwarePrefetch</b>	<p>Whether the processor allows the Intel hardware prefetcher to fetch streams of data and instruction from memory into the unified second-level cache when necessary. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The hardware prefetcher is not used.</li> <li>• <b>Enabled</b>—The processor uses the hardware prefetcher when cache issues are detected.</li> </ul>
<b>Adjacent Cache Line Prefetcher</b> <b>set AdjacentCacheLinePrefetch</b>	<p>Whether the processor fetches cache lines in even/odd pairs instead of fetching just the required line. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor only fetches the required line.</li> <li>• <b>Enabled</b>—The processor fetches both the required line and its paired line.</li> </ul>

Name	Description
<b>DCU Streamer Prefetch</b> <b>set DcuStreamerPrefetch</b>	<p>Whether the processor uses the DCU IP Prefetch mechanism to analyze historical cache access patterns and preload the most relevant lines in the L1 cache. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not try to anticipate cache read requirements and only fetches explicitly requested lines.</li> <li>• <b>Enabled</b>—The DCU prefetcher analyzes the cache read pattern and prefetches the next line in the cache if it determines that it may be needed.</li> </ul>
<b>DCU IP Prefetcher</b> <b>set DcuIpPrefetch</b>	<p>Whether the processor uses the DCU IP Prefetch mechanism to analyze historical cache access patterns and preload the most relevant lines in the L1 cache. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not preload any cache data.</li> <li>• <b>Enabled</b>—The DCU IP prefetcher preloads the L1 cache with the data it determines to be the most relevant.</li> </ul>
<b>Direct Cache Access Support</b> <b>set DirectCacheAccess</b>	<p>Allows processors to increase I/O performance by placing data from I/O devices directly into the processor cache. This setting helps to reduce cache misses. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Data from I/O devices is not placed directly into the processor cache.</li> <li>• <b>Enabled</b>—Data from I/O devices is placed directly into the processor cache.</li> </ul>

Name	Description
<p><b>Power Technology</b> set <b>CPUPowerManagement</b></p>	<p>Enables you to configure the CPU power management settings for the following options:</p> <ul style="list-style-type: none"> <li>• Enhanced Intel Speedstep Technology</li> <li>• Intel Turbo Boost Technology</li> <li>• Processor Power State C6</li> </ul> <p>Power Technology can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Custom</b>—The server uses the individual settings for the BIOS parameters mentioned above. You must select this option if you want to change any of these BIOS parameters.</li> <li>• <b>Disabled</b>—The server does not perform any CPU power management and any settings for the BIOS parameters mentioned above are ignored.</li> <li>• <b>Energy_Efficient</b>—The server determines the best settings for the BIOS parameters mentioned above and ignores the individual settings for these parameters.</li> </ul>
<p><b>Enhanced Intel Speedstep Technology</b> set <b>EnhancedIntelSpeedStep</b></p>	<p>Whether the processor uses Enhanced Intel SpeedStep Technology, which allows the system to dynamically adjust processor voltage and core frequency. This technology can result in decreased average power consumption and decreased average heat production. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor never dynamically adjusts its voltage or frequency.</li> <li>• <b>Enabled</b>—The processor utilizes Enhanced Intel SpeedStep Technology and enables all supported processor sleep states to further conserve power.</li> </ul> <p>We recommend that you contact your operating system vendor to make sure the operating system supports this feature.</p> <p><b>Note</b>    <b>CPUPowerManagement</b> must be set to <b>Custom</b> or the server ignores the setting for this parameter.</p>

Name	Description
<b>Intel Turbo Boost Technology</b> <b>set IntelTurboBoostTech</b>	<p>Whether the processor uses Intel Turbo Boost Technology, which allows the processor to automatically increase its frequency if it is running below power, temperature, or voltage specifications. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not increase its frequency automatically.</li> <li>• <b>Enabled</b>—The processor utilizes Turbo Boost Technology if required.</li> </ul> <p><b>Note</b> <b>CPUPowerManagement</b> must be set to <b>Custom</b> or the server ignores the setting for this parameter.</p>
<b>Processor C3 Report</b> <b>set ProcessorC3Report</b>	<p>Whether the BIOS sends the C3 report to the operating system. When the OS receives the report, it can transition the processor into the lower C3 power state to decrease energy usage while maintaining optimal processor performance. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—BIOS does not send C3 report.</li> <li>• <b>Enabled</b>—BIOS sends the C3 report, allowing the OS to transition the processor to the C3 low power state.</li> </ul> <p><b>Note</b> <b>CPUPowerManagement</b> must be set to <b>Custom</b> or the server ignores the setting for this parameter.</p>
<b>Processor C6 Report</b> <b>set ProcessorC6Report</b>	<p>Whether the BIOS sends the C6 report to the operating system. When the OS receives the report, it can transition the processor into the lower C6 power state to decrease energy usage while maintaining optimal processor performance. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The BIOS does not send the C6 report.</li> <li>• <b>Enabled</b>—The BIOS sends the C6 report, allowing the OS to transition the processor to the C6 low power state.</li> </ul> <p><b>Note</b> <b>CPUPowerManagement</b> must be set to <b>Custom</b> or the server ignores the setting for this parameter.</p>
<b>Processor Power State C1 Enhanced</b> <b>set ProcessorC1EReport</b>	<p>Whether the CPU transitions to its minimum frequency when entering the C1 state. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The CPU continues to run at its maximum frequency in C1 state.</li> <li>• <b>Enabled</b>—The CPU transitions to its minimum frequency. This option saves the maximum amount of power in C1 state.</li> </ul>

Name	Description
<b>P-STATE Coordination</b> <b>set PsdCoordType</b>	<p>Allows you to define how BIOS communicates the P-state support model to the operating system. There are 3 models as defined by the Advanced Configuration and Power Interface (ACPI) specification.</p> <ul style="list-style-type: none"> <li>• <b>HW_ALL</b>—The processor hardware is responsible for coordinating the P-state among logical processors with dependencies (all logical processors in a package).</li> <li>• <b>SW_ALL</b>—The OS Power Manager (OSPM) is responsible for coordinating the P-state among logical processors with dependencies (all logical processors in a physical package), and must initiate the transition on all of the logical processors.</li> <li>• <b>SW_ANY</b>—The OS Power Manager (OSPM) is responsible for coordinating the P-state among logical processors with dependencies (all logical processors in a package), and may initiate the transition on any of the logical processors in the domain.</li> </ul> <p><b>Note</b> <b>CPUPowerManagement</b> must be set to <b>Custom</b> or the server ignores the setting for this parameter.</p>
<b>Energy Performance Tuning</b> <b>set PwrPerfTuning</b>	<p>Allows you to choose BIOS or Operating System for energy performance bias tuning. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>OS</b>— Chooses OS for energy performance tuning.</li> <li>• <b>BIOS</b>— Chooses BIOS for energy performance tuning.</li> </ul>
<b>Energy Performance</b> <b>set CpuEngPerfBias</b>	<p>Allows you to determine whether system performance or energy efficiency is more important on this server. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Balanced_Energy</b></li> <li>• <b>Balanced_Performance</b></li> <li>• <b>Energy_Efficient</b></li> <li>• <b>Performance</b></li> </ul>

Name	Description
<p><b>Package C State Limit</b> set PackageCStateLimit</p>	<p>The amount of power available to the server components when they are idle. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>C0_state</b>—The server provides all server components with full power at all times. This option maintains the highest level of performance and requires the greatest amount of power.</li> <li>• <b>C1_state</b>—When the CPU is idle, the system slightly reduces the power consumption. This option requires less power than C0 and allows the server to return quickly to high performance mode.</li> <li>• <b>C3_state</b>—When the CPU is idle, the system reduces the power consumption further than with the C1 option. This requires less power than C1 or C0, but it takes the server slightly longer to return to high performance mode.</li> <li>• <b>C6_state</b>—When the CPU is idle, the system reduces the power consumption further than with the C3 option. This option saves more power than C0, C1, or C3, but there may be performance issues until the server returns to full power.</li> <li>• <b>C7_state</b>—When the CPU is idle, the server makes a minimal amount of power available to the components. This option saves the maximum amount of power but it also requires the longest time for the server to return to high performance mode.</li> <li>• <b>No_Limit</b>—The server may enter any available C state.</li> </ul>
<p><b>Extended APIC</b> set LocalX2Apic</p>	<p>Allows you to enable or disable extended APIC support. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>XAPIC</b>—Enables APIC support.</li> <li>• <b>X2APIC</b>—Enables APIC and also enables Intel VT-d and Interrupt Remapping .</li> </ul>
<p><b>Workload Configuration</b> set WorkLdConfig</p>	<p>Allows you to set a parameter to optimize workload characterization. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Balanced</b>— Chooses balanced option for optimization.</li> <li>• <b>I/O Sensitive</b>— Chooses I/O sensitive option for optimization.</li> </ul> <p><b>Note</b> We recommend you to set the workload configuration to <b>Balanced</b>.</p>

## Memory Configuration Parameters

Name	Description
<b>Select Memory RAS</b> <b>set SelectMemoryRAS</b>	<p>How the memory reliability, availability, and serviceability (RAS) is configured for the server. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Maximum_Performance</b>—System performance is optimized.</li> <li>• <b>Mirroring</b>—System reliability is optimized by using half the system memory as backup.</li> <li>• <b>Lockstep</b>—If the DIMM pairs in the server have an identical type, size, and organization and are populated across the SMI channels, you can enable lockstep mode to minimize memory access latency and provide better performance. This option offers better system performance than Mirroring and better reliability than Maximum Performance but lower reliability than Mirroring and lower system performance than Maximum Performance.</li> </ul>
<b>NUMA</b> <b>set NUMAOptimize</b>	<p>Whether the BIOS supports Non-Uniform Memory Access (NUMA). This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The BIOS does not support NUMA.</li> <li>• <b>Enabled</b>—The BIOS includes the ACPI tables that are required for NUMA-aware operating systems. If you enable this option, the system must disable Inter-Socket Memory interleaving on some platforms.</li> </ul>
<b>Channel Interleaving</b> <b>set ChannelInterLeave</b>	<p>Whether the CPU divides memory blocks and spreads contiguous portions of data across interleaved channels to enable simultaneous read operations. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Auto</b>—The CPU determines what interleaving is done.</li> <li>• <b>1_Way</b>—Some channel interleaving is used.</li> <li>• <b>2_Way</b></li> <li>• <b>3_Way</b></li> <li>• <b>4_Way</b>—The maximum amount of channel interleaving is used.</li> </ul>

Name	Description
<b>Rank Interleaving</b> set RankInterLeave	Whether the CPU interleaves physical ranks of memory so that one rank can be accessed while another is being refreshed. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Auto</b>—The CPU determines what interleaving is done.</li> <li>• <b>1_Way</b>—Some rank interleaving is used.</li> <li>• <b>2_Way</b></li> <li>• <b>4_Way</b></li> <li>• <b>8_Way</b>—The maximum amount of rank interleaving is used.</li> </ul>
<b>Patrol Scrub</b> set PatrolScrub	Whether the system actively searches for, and corrects, single bit memory errors even in unused portions of the memory on the server. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The system checks for memory ECC errors only when the CPU reads or writes a memory address.</li> <li>• <b>Enabled</b>—The system periodically reads and writes memory searching for ECC errors. If any errors are found, the system attempts to fix them. This option may correct single bit errors before they become multi-bit errors, but it may adversely affect performance when the patrol scrub is running.</li> </ul>
<b>Demand Scrub</b> set DemandScrub	Whether the system corrects single bit memory errors encountered when the CPU or I/O makes a demand read. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>— Single bit memory errors are not corrected.</li> <li>• <b>Enabled</b>— Single bit memory errors are corrected in memory and the corrected data is set in response to the demand read.</li> </ul>



Name	Description
<b>Altitude</b> <b>set Altitude</b>	<p>The approximate number of meters above sea level at which the physical server is installed. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Auto</b>—The CPU determines the physical elevation.</li> <li>• <b>300_M</b>—The server is approximately 300 meters above sea level.</li> <li>• <b>900_M</b>—The server is approximately 900 meters above sea level.</li> <li>• <b>1500_M</b>—The server is approximately 1500 meters above sea level.</li> <li>• <b>3000_M</b>—The server is approximately 3000 meters above sea level.</li> </ul>

#### QPI Configuration Parameters

Name	Description
<b>QPI Link Frequency Select</b> <b>set QPILinkFrequency</b>	<p>The Intel QuickPath Interconnect (QPI) link frequency, in gigatransfers per second (GT/s). This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Auto</b>—The CPU determines the QPI link frequency.</li> <li>• <b>6.4_GT/s</b></li> <li>• <b>7.2_GT/s</b></li> <li>• <b>8.0_GT/s</b></li> </ul>
<b>QPI Snoop Mode</b> <b>set QpiSnoopMode</b>	<p>The Intel QuickPath Interconnect (QPI) snoop mode. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Home Snoop</b>—The snoop is always spawned by the home agent (centralized ring stop) for the memory controller. This mode has a higher local latency than early snoop, but it provides extra resources for a larger number of outstanding transactions.</li> <li>• <b>Cluster on Die</b>—Enables Cluster On Die. When enabled LLC is split into two parts with an independent caching agent for each. This helps increase the performance in some workloads. This mode is available only for processors that have 10 or more cores. It is the best mode for highly NUMA optimized workloads.</li> <li>• <b>Early Snoop</b>—The distributed cache ring stops can send a snoop probe or a request to another caching agent directly. This mode has lower latency and it is best for workloads that have shared data sets across threads and can benefit from a cache-to-cache transfer, or for workloads that are not NUMA optimized.</li> </ul>

## USB Configuration Parameters

Name	Description
<b>Legacy USB Support</b> set LegacyUSBSupport	Whether the system supports legacy USB devices. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—USB devices are only available to EFI applications.</li> <li>• <b>Enabled</b>—Legacy USB support is always available.</li> <li>• <b>Auto</b>—Disables legacy USB support if no USB devices are connected.</li> </ul>
<b>Port 60/64 Emulation</b> set UsbEmul6064	Whether the system supports 60h/64h emulation for complete USB keyboard legacy support. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—60h/64 emulation is not supported.</li> <li>• <b>Enabled</b>—60h/64 emulation is supported.</li> </ul> <p>You should select this option if you are using a non-USB aware operating system on the server.</p>
<b>xHCI Mode</b> set PchUsb30Mode	Whether the xHCI controller legacy support is enabled or disabled. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Disables the xHCI controller legacy support.</li> <li>• <b>Enabled</b>—Enables the xHCI controller legacy support.</li> </ul>

## PCI Configuration Parameters

Name	Description
<b>Memory Mapped I/O Above 4GB</b> set MemoryMappedIOAbove4GB	Whether to enable or disable MMIO above 4GB or not. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The server does not map I/O of 64-bit PCI devices to 4GB or greater address space.</li> <li>• <b>Enabled</b>—The server maps I/O of 64-bit PCI devices to 4GB or greater address space.</li> </ul> <p><b>Note</b> PCI devices that are 64-bit compliant but use a legacy option ROM may not function correctly with this setting enabled.</p>

Name	Description
<b>SrIov</b> <b>set SrIov</b>	Whether SR-IOV (Single Root I/O Virtualization) is enabled or disabled on the server. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—SR-IOV is disabled.</li> <li>• <b>Enabled</b>—SR-IOV is enabled.</li> </ul>

### Serial Configuration Parameters

Name	Description
<b>Out-of-Band Mgmt Port</b> <b>set comSpcrEnable</b>	Allows you to configure the COM port 0 that can be used for Windows Emergency Management services. ACPI SPCR table is reported based on this setup option. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Configures the COM port 0 as a general purpose port for use with the Windows Operating System.</li> <li>• <b>Enabled</b>—Configures the COM port 0 as a remote management port for Windows Emergency Management services.</li> </ul>
<b>Console Redirection</b> <b>set ConsoleRedir</b>	Allows a serial port to be used for console redirection during POST and BIOS booting. After the BIOS has booted and the operating system is responsible for the server, console redirection is irrelevant and has no effect. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—No console redirection occurs during POST.</li> <li>• <b>COM_0</b>—Enables console redirection on COM port 0 during POST.</li> <li>• <b>COM_1</b>—Enables console redirection on COM port 1 during POST.</li> </ul>
<b>Terminal Type</b> <b>set TerminalType</b>	What type of character formatting is used for console redirection. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>PC-ANSI</b>—The PC-ANSI terminal font is used.</li> <li>• <b>VT100</b>—A supported vt100 video terminal and its character set are used.</li> <li>• <b>VT100+</b>—A supported vt100-plus video terminal and its character set are used.</li> <li>• <b>VT-UTF8</b>—A video terminal with the UTF-8 character set is used.</li> </ul> <p><b>Note</b> This setting must match the setting on the remote terminal application.</p>

Name	Description
<b>Bits per second</b> <b>set BaudRate</b>	<p>What BAUD rate is used for the serial port transmission speed. If you disable Console Redirection, this option is not available. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>9600</b>—A 9,600 BAUD rate is used.</li> <li>• <b>19200</b>—A 19,200 BAUD rate is used.</li> <li>• <b>38400</b>—A 38,400 BAUD rate is used.</li> <li>• <b>57600</b>—A 57,600 BAUD rate is used.</li> <li>• <b>115200</b>—A 115,200 BAUD rate is used.</li> </ul> <p><b>Note</b> This setting must match the setting on the remote terminal application.</p>
<b>Flow Control</b> <b>set FlowCtrl</b>	<p>Whether a handshake protocol is used for flow control. Request to Send / Clear to Send (RTS/CTS) helps to reduce frame collisions that can be introduced by a hidden terminal problem. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>None</b>—No flow control is used.</li> <li>• <b>Hardware_RTS/CTS</b>—RTS/CTS is used for flow control.</li> </ul> <p><b>Note</b> This setting must match the setting on the remote terminal application.</p>
<b>Putty KeyPad</b> <b>set PuttyFunctionKeyPad</b>	<p>Allows you to change the action of the PuTTY function keys and the top row of the numeric keypad. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>VT100</b>—The function keys generate ESC OP through ESC O[.</li> <li>• <b>LINUX</b>—Mimics the Linux virtual console. Function keys F6 to F12 behave like the default mode, but F1 to F5 generate ESC [[A through ESC [[E.</li> <li>• <b>XTERMR6</b>—Function keys F5 to F12 behave like the default mode. Function keys F1 to F4 generate <b>ESC OP</b> through <b>ESC OS</b>, which are the sequences produced by the top row of the keypad on Digital terminals.</li> <li>• <b>SCO</b>—The function keys F1 to F12 generate ESC [M through ESC [X. The function and shift keys generate ESC [Y through ESC [j. The control and function keys generate ESC [k through ESC [v. The shift, control and function keys generate ESC [w through ESC [{.</li> <li>• <b>ESCN</b>—The default mode. The function keys match the general behavior of Digital terminals. The function keys generate sequences such as ESC [11~ and ESC [12~.</li> <li>• <b>VT400</b>—The function keys behave like the default mode. The top row of the numeric keypad generates ESC OP through ESC OS.</li> </ul>

Name	Description
<b>Redirection After BIOS POST</b> set <code>RedirectionAfterPOST</code>	<p>Whether BIOS console redirection should be active after BIOS POST is complete and control given to the OS bootloader. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Always_Enable</b>—BIOS Legacy console redirection is active during the OS boot and run time.</li> <li>• <b>Bootloader</b>—BIOS Legacy console redirection is disabled before giving control to the OS boot loader.</li> </ul>

### LOM and PCIe Slots Configuration Parameters

Name	Description
<b>CDN Support for VIC</b> set <code>CdnEnable</code>	<p>Whether the Ethernet Network naming convention is according to Consistent Device Naming (CDN) or the traditional way of naming conventions. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>— CDN support for VIC cards is disabled.</li> <li>• <b>Enabled</b>— CDN support is enabled for VIC cards.</li> </ul> <p><b>Note</b>    CDN support for VIC cards work with Windows 2012 or the latest OS only.</p>
<b>PCI ROM CLP</b> set <code>PciRomClp</code>	<p>PCI ROM Command Line Protocol (CLP) controls the execution of different Option ROMs such as PxE and iSCSI that are present in the card. By default, it is disabled.</p> <ul style="list-style-type: none"> <li>• <b>Enabled</b>— Enables you to configure execution of different option ROMs such as PxE and iSCSI for an individual ports separately.</li> <li>• <b>Disabled</b>—The default option. You cannot choose different option ROMs. A default option ROM is executed during PCI enumeration.</li> </ul>
<b>All PCIe Slots OptionROM</b> set <code>PcieOptionROMs</code>	<p>Whether the server can use Option ROM present in the PCIe Cards. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The Option ROM for slot <i>n</i> is not available.</li> <li>• <b>Enabled</b>—The Option ROM for slot <i>n</i> is available.</li> <li>• <b>UEFI_Only</b>—The Option ROM for slot <i>n</i> is available for UEFI only.</li> <li>• <b>Legacy_Only</b>—The Option ROM for slot <i>n</i> is available for legacy only.</li> </ul>

Name	Description
<b>SBNVMe1 OptionROM</b> <b>set SBNVMe1OptionROM</b>	Whether the server can use Option ROM present in SBNVMe1 controller. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The Option ROM for SBNVMe1 controllers is not available.</li> <li>• <b>Enabled</b>—The Option ROMs for SBNVMe1 controller is available.</li> <li>• <b>UEFI_Only</b>—The Option ROMs for slot are available for UEFI only.</li> <li>• <b>Legacy_Only</b>—The Option ROM for slot are available for legacy only.</li> </ul>
<b>SIOC1 OptionROM</b> <b>set SIOC1OptionROM</b>	Whether the server can use Option ROM present in System IO Controller 1 (SIOC1). This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The Option ROM for System IO Controller 1 (SIOC1) is not available.</li> <li>• <b>Enabled</b>—The Option ROMs for System IO Controller 1 (SIOC1) is available.</li> <li>• <b>UEFI_Only</b>—The Option ROMs for slot are available for UEFI only.</li> <li>• <b>Legacy_Only</b>—The Option ROM for slot are available for legacy only.</li> </ul>
<b>SIOC2 OptionROM</b> <b>set</b> <b>SIOC2OptionROM</b> <b>set SIOC2OptionROM</b>	Whether the server can use Option ROM present in System IO Controller 2 (SIOC2). This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The Option ROM for System IO Controller 2 (SIOC2) is not available.</li> <li>• <b>Enabled</b>—The Option ROMs for System IO Controller 2 (SIOC2) is available.</li> <li>• <b>UEFI_Only</b>—The Option ROMs for slot are available for UEFI only.</li> <li>• <b>Legacy_Only</b>—The Option ROM for slot are available for legacy only.</li> </ul>

Name	Description
<b>SBMezz1 OptionROM</b> set SBMezz1OptionROM	Whether the server can use Option ROM present in SBMezz1 controller. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The Option ROM for SBMezz1 controllers is not available.</li> <li>• <b>Enabled</b>—The Option ROMs for SBMezz1 controller is available.</li> <li>• <b>UEFI_Only</b>—The Option ROMs for slot are available for UEFI only.</li> <li>• <b>Legacy_Only</b>—The Option ROM for slot are available for legacy only.</li> </ul>
<b>IOESlot1 OptionROM</b> set IOESlot1OptionROM	Whether option ROM is enabled on the IOE slot 1. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>— Option ROM is disabled.</li> <li>• <b>Enabled</b>— Default value. Option ROM is enabled.</li> <li>• <b>UEFI Only</b>— slot 1 option ROM is available for UEFI only.</li> <li>• <b>Legacy Only</b>— slot 1 option ROM is available for legacy only.</li> </ul>
<b>IOEMezz1 OptionROM</b> set IOEMezz1OptionROM	Whether option ROM is enabled on the IOE Mezz1. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>— Option ROM is disabled.</li> <li>• <b>Enabled</b>— Default value. Option ROM is enabled.</li> <li>• <b>UEFI Only</b>— Mezz1 option ROM is available for UEFI only.</li> <li>• <b>Legacy Only</b>— Mezz1 option ROM is available for legacy only.</li> </ul>
<b>IOESlot2 OptionROM</b> set IOESlot2OptionROM	Whether option ROM is enabled on the IOE slot 2. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>— Option ROM is disabled.</li> <li>• <b>Enabled</b>— Default value. Option ROM is enabled.</li> <li>• <b>UEFI Only</b>— slot 2 option ROM is available for UEFI only.</li> <li>• <b>Legacy Only</b>— slot 2 option ROM is available for legacy only.</li> </ul>

Name	Description
<b>IOENVMe1 OptionROM</b> <b>set IOENVMe1OptionROM</b>	Whether option ROM is enabled on the IOE NVMe1. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>— Option ROM is disabled.</li> <li>• <b>Enabled</b>— Default value. Option ROM is enabled.</li> <li>• <b>UEFI Only</b>— Mezz1 option ROM is available for UEFI only.</li> <li>• <b>Legacy Only</b>— Mezz1 option ROM is available for legacy only.</li> </ul>
<b>IOENVMe2 OptionROM</b> <b>set IOENVMe2OptionROM</b>	Whether option ROM is enabled on the IOE NVMe2. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>— Option ROM is disabled.</li> <li>• <b>Enabled</b>— Default value. Option ROM is enabled.</li> <li>• <b>UEFI Only</b>— Mezz1 option ROM is available for UEFI only.</li> <li>• <b>Legacy Only</b>— Mezz1 option ROM is available for legacy only.</li> </ul>
<b>SBNVMe1 Link Speed</b> <b>Set SBNVMe1LinkSpeed</b>	SBNVMe1 add-on slot 1 link speed. <ul style="list-style-type: none"> <li>• <b>Auto</b>—Link speed is automatically assigned.</li> <li>• <b>GEN1</b>— Link speed can reach up to first generation.</li> <li>• <b>GEN2</b>—The default link speed. Link speed can reach up to second generation.</li> <li>• <b>GEN3</b>— Link speed can reach up to third generation.</li> <li>• <b>Disabled</b>—Slot is disabled, and the card is not enumerated.</li> </ul>
<b>SIOC1 Link Speed</b> <b>Set PcieSlot1LinkSpeed</b>	System IO Controller 1 (SIOC1) add-on slot 1 link speed. <ul style="list-style-type: none"> <li>• <b>GEN1</b> — Link speed can reach up to first generation.</li> <li>• <b>GEN2</b> — Link speed can reach up to second generation.</li> <li>• <b>GEN3</b>— The default link speed. Link speed can reach up to third generation.</li> <li>• <b>Disabled</b> — Slot is disabled, and the card is not enumerated.</li> </ul>



Name	Description
<b>SIOC2 Link Speed</b> <b>set PcieSlot2LinkSpeed</b>	System IO Controller 2 (SIOC2) add-on slot 2 link speed. <ul style="list-style-type: none"> <li>• <b>GEN1</b> — Link speed can reach up to first generation.</li> <li>• <b>GEN2</b> — Link speed can reach up to second generation.</li> <li>• <b>GEN3</b>— The default link speed. Link speed can reach up to third generation.</li> <li>• <b>Disabled</b> — Slot is disabled, and the card is not enumerated.</li> </ul>
<b>SBMezz1 Link Speed</b> <b>Set SBMezz1LinkSpeed</b>	SBMezz1 add-on slot 1 link speed. <ul style="list-style-type: none"> <li>• <b>Auto</b>—Link speed is automatically assigned.</li> <li>• <b>GEN1</b>— Link speed can reach up to first generation.</li> <li>• <b>GEN2</b>—The default link speed. Link speed can reach up to second generation.</li> <li>• <b>GEN3</b>— Link speed can reach up to third generation.</li> <li>• <b>Disabled</b>—Slot is disabled, and the card is not enumerated.</li> </ul>
<b>IOESlot1 Link Speed</b> <b>set IOESlot1LinkSpeed</b>	Slot 1 link speed. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Auto</b>— Default value. Slot is enabled.</li> <li>• <b>GEN 1</b>— Link speed can reach up to first generation.</li> <li>• <b>GEN 2</b>— Link speed can reach up to second generation.</li> <li>• <b>GEN 3</b>— Link speed can reach up to third generation.</li> <li>• <b>Disabled</b>—Slot is disabled, and the card is not enumerated.</li> </ul>
<b>IOEMezz1 Link Speed</b> <b>set IOEMezz1LinkSpeed</b>	Mezz1 link speed. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Auto</b>— Default value. Slot is enabled.</li> <li>• <b>GEN 1</b>— Link speed can reach up to first generation.</li> <li>• <b>GEN 2</b>— Link speed can reach up to second generation.</li> <li>• <b>GEN 3</b>— Link speed can reach up to third generation.</li> <li>• <b>Disabled</b>—Slot is disabled, and the card is not enumerated.</li> </ul>

Name	Description
<b>IOESlot2 Link Speed</b> set IOESlot2LinkSpeed	Slot 2 link speed. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Auto</b>— Default value. Slot is enabled.</li> <li>• <b>GEN 1</b>— Link speed can reach up to first generation.</li> <li>• <b>GEN 2</b>— Link speed can reach up to second generation.</li> <li>• <b>GEN 3</b>— Link speed can reach up to third generation.</li> <li>• <b>Disabled</b>—Slot is disabled, and the card is not enumerated.</li> </ul>
<b>IOENVMe1 Link Speed</b> set IOENVMe1LinkSpeed	NVMe1 link speed. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Auto</b>— Default value. Slot is enabled.</li> <li>• <b>GEN 1</b>— Link speed can reach up to first generation.</li> <li>• <b>GEN 2</b>— Link speed can reach up to second generation.</li> <li>• <b>GEN 3</b>— Link speed can reach up to third generation.</li> <li>• <b>Disabled</b>—Slot is disabled, and the card is not enumerated.</li> </ul>
<b>IOENVMe2 Link Speed</b> set IOENVMe2LinkSpeed	NVMe2 link speed. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Auto</b>— Default value. Slot is enabled.</li> <li>• <b>GEN 1</b>— Link speed can reach up to first generation.</li> <li>• <b>GEN 2</b>— Link speed can reach up to second generation.</li> <li>• <b>GEN 3</b>— Link speed can reach up to third generation.</li> <li>• <b>Disabled</b>—Slot is disabled, and the card is not enumerated.</li> </ul>

## Server Management BIOS Parameters for C3X60 M4 Servers

### Server Management BIOS Parameters

Name	Description
<b>FRB-2 Timer</b> set FRB-2	Whether the FRB2 timer is used by Cisco IMC to recover the system if it hangs during POST. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The FRB2 timer is not used.</li> <li>• <b>Enabled</b>—The FRB2 timer is started during POST and used to recover the system if necessary.</li> </ul>

Name	Description
<b>OS Watchdog Timer</b> <b>set OSBootWatchdogTimer</b>	Whether the BIOS programs the watchdog timer with a specified timeout value. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The watchdog timer is not used to track how long the server takes to boot.</li> <li>• <b>Enabled</b>—The watchdog timer tracks how long the server takes to boot. If the server does not boot within the length of time specified by the <b>set OSBootWatchdogTimerTimeout</b> command, the Cisco IMC logs an error and takes the action specified by the <b>set OSBootWatchdogTimerPolicy</b> command.</li> </ul>
<b>OS Watchdog Timer Timeout</b> <b>set OSBootWatchdogTimerTimeOut</b>	If OS does not boot within the specified time, OS watchdog timer expires and system takes action according to timer policy. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>5_Minutes</b>—The OS watchdog timer expires 5 minutes after it begins to boot.</li> <li>• <b>10_Minutes</b>—The OS watchdog timer expires 10 minutes after it begins to boot.</li> <li>• <b>15_Minutes</b>—The OS watchdog timer expires 15 minutes after it begins to boot.</li> <li>• <b>20_Minutes</b>—The OS watchdog timer expires 20 minutes after it begins to boot.</li> </ul> <p><b>Note</b> This option is only applicable if you enable the OS Boot Watchdog Timer.</p>
<b>OS Watchdog Timer Policy</b> <b>set OSBootWatchdogTimerPolicy</b>	What action the system takes if the watchdog timer expires. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Do_Nothing</b>—The server takes no action if the watchdog timer expires during OS boot.</li> <li>• <b>Power_Down</b>—The server is powered off if the watchdog timer expires during OS boot.</li> <li>• <b>Reset</b>—The server is reset if the watchdog timer expires during OS boot.</li> </ul> <p><b>Note</b> This option is only applicable if you enable the OS Boot Watchdog Timer.</p>





## BIOS Token Name Comparison for Multiple Interfaces

This appendix contains the following section:

- [BIOS Token Name Comparison for Multiple Interfaces](#), page 309

### BIOS Token Name Comparison for Multiple Interfaces

The following table lists the BIOS token names used in the XML, CLI and Web GUI interfaces. You can use this list to map the names across these interfaces.

**Note**

The parameters that are available depend on the type of Cisco UCS server you are using.

BIOS Token Group	BIOS Token Name	XML Object	CLI and Web GUI Object
Main	TPM Support	biosVfTPMSupport/ vpTPMSupport	TPMAdminCtrl
Process Configuration	Intel(R) Hyper-Threading Technology	biosVfIntelHyperThreadingTech/ vpIntelHyperThreadingTech	IntelHyperThread
	Number of Enable Cores	biosVfCoreMultiProcessing/ vpCoreMultiProcessing	CoreMultiProcessing
	Execute Disable	biosVfExecuteDisableBit/ vpExecuteDisableBit	ExecuteDisable
	Intel(R) VT	biosVfIntelVirtualizationTechnology/ vpIntelVirtualizationTechnology	IntelVT

BIOS Token Group	BIOS Token Name	XML Object	CLI and Web GUI Object
	Intel(R) VT-d	biosVfIntelVTForDirectedIO/ vpIntelVTForDirectedIO	IntelVTD
	Intel(R) VT-d Coherency Support	biosVfIntelVTForDirectedIO/ vpIntelVTDCoherencySupport	CoherencySupport
	Intel(R) VT-d ATS Support	biosVfIntelVTForDirectedIO/ vpIntelVTDATSSupport	ATS
	CPU Performance	biosVfCPUPerformance/ vpCPUPerformance	CpuPerformanceProfile
	Hardware Prefetcher	biosVfHardwarePrefetch/ vpHardwarePrefetch	HardwarePrefetch
	Adjacent Cache Line Prefetcher	biosVfAdjacentCacheLinePrefetch/ vpAdjacentCacheLinePrefetch	AdjacentCacheLinePrefetch
	DCU Streamer Prefetch	biosVfDCUPrefetch/ vvpStreamerPrefetch	DcuStreamerPrefetch
	DCU IP Prefetcher	biosVfDCUPrefetch/ vpIPPrefetch	DcuIpPrefetch
	Direct Cache Access Support	biosVfDirectCacheAccess/ vpDirectCacheAccess	DirectCacheAccess
	Power Technology	biosVfCPUPowerManagement/ vpCPUPowerManagement	CPUPowerManagement
	Enhanced Intel Speedstep(R) Technology	biosVfEnhancedIntelSpeedStepTech/ vpEnhancedIntelSpeedStepTech	EnhancedIntelSpeedStep
	Intel(R) Turbo Boost Technology	biosVfIntelTurboBoostTech/ vpIntelTurboBoostTech	IntelTurboBoostTech
	Processor Power state C6	biosVfProcessorCState/ vpProcessorCState	ProcessorC6Report

BIOS Token Group	BIOS Token Name	XML Object	CLI and Web GUI Object
	Processor Power state C1 Enhanced	biosVfProcessorC1E/ vpProcessorC1E	ProcessorC1E
	Frequency Floor Override	biosVfCPUFrequencyFloor/ vpCPUFrequencyFloor	CpuFreqFloor
	P-STATE Coordination	biosVfPStateCoordType/ vpPStateCoordType	PsdCoordType
	Energy Performance	biosVfCPUEnergyPerformance/ vpCPUEnergyPerformance	CpuEngPerfBias
<b>Memory Configuration</b>	Select Memory RAS	biosVfSelectMemoryRASConfiguration/ vpSelectMemoryRASConfiguration	SelectMemoryRAS
	DRAM Clock Throttling	biosVfDRAMClockThrottling/ vpDRAMClockThrottling	DRAMClockThrottling
	NUMA	biosVfNUMAOptimized/ vpNUMAOptimized	NUMAOptimize
	Low Voltage DDR Mode	biosVfLvDIMMSupport/ vpNUMAOptimized	LvDDRMode
	DRAM Refresh rate	biosVfDramRefreshRate/ vpDramRefreshRate	DramRefreshRate
	Channel Interleaving	biosVfMemoryInterleave/ vpChannelInterLeave	ChannelInterLeave
	Rank Interleaving	biosVfMemoryInterleave/ vpRankInterLeave	RankInterLeave
	Patrol Scrub	biosVfPatrolScrub/ vpPatrolScrub	PatrolScrub
	Demand Scrub	biosVfDemandScrub/ vpDemandScrub	DemandScrub
	Altitude	biosVfAltitude/ vpAltitude	Altitude

<b>BIOS Token Group</b>	<b>BIOS Token Name</b>	<b>XML Object</b>	<b>CLI and Web GUI Object</b>
<b>QPI Configuration</b>	QPI Link Frequency Select	biosVfQPIConfig/ vpQPILinkFrequency	QPILinkFrequency
	Cluster on Die	biosVfCODEnable/ vpCODEnable	CODEnable
	Snoop Mode	biosVfEarlySnoop/ vpEarlySnoop	EarlySnoop
<b>SATA Configuration</b>	SATA Mode	Not supported	SATAMode
<b>Onboard Storage</b>	Onboard SCU Storage Support	biosVfOnboardStorage/ vpOnboardSCUStorageSupport	DisableSCU
	Onboard SCU Storage SW Stack	biosVfOnboardStorageSWStack vpOnboardSCUStorageSWStack	PchScuOromSelect
<b>USB Configuration</b>	Legacy USB Support	biosVfLegacyUSBSupport/ vpLegacyUSBSupport	LegacyUSBSupport
	Port 60/64 Emulation	biosVfUSBEmulation/ vpUSBEmul6064	UsbEmul6064
	All USB Devices	biosVfUSBPortsConfig/ vpAllUsbDevices	AllUsbDevices
	USB Port:Rear	biosVfUSBPortsConfig/ vpUsbPortRear	UsbPortRear
	USB Port:Front	biosVfUSBPortsConfig/ vpUsbPortFront	UsbPortFront
	USB Port:Internal	biosVfUSBPortsConfig/ vpUsbPortInternal	UsbPortInt
	USB Port:KVM	biosVfUSBPortsConfig/ vpUsbPortKVM	UsbPortKVM
	USB Port:Vmedia	biosVfUSBPortsConfig/ vpUsbPortVMedia	UsbPortVMedia



BIOS Token Group	BIOS Token Name	XML Object	CLI and Web GUI Object
	USB Port:SD Card	biosVfUSBPortsConfig/ vpUsbPortSDCard	UsbPortSdCard
	xHCI Mode	biosVfPchUsb30Mode/ vpPchUsb30Mode	PchUsb30Mode
<b>PCI Configuration</b>	PCI ROM CLP	Not Supported	PciRomClp
	MMIO above 4GB	biosVfMemoryMappedIOAbove4GB/ vpMemoryMappedIOAbove4GB	MemoryMappedIOAbove4GB
	ASPM Support	biosVfASPMSupport/ vpASPMSupport	ASPMSupport
	VGA Priority	biosVfVgaPriority/ vpVgaPriority	VgaPriority
<b>Serial Configuration</b>	Console Redirection	biosVfConsoleRedirection/ vpConsoleRedirection	ConsoleRedir
	Terminal Type	biosVfConsoleRedirection/ vpTerminalType	TerminalType
	Bits per second	biosVfConsoleRedirection/ vpBaudRate	BaudRate
	Flow Control	biosVfConsoleRedirection/ vpFlowControl	FlowCtrl
	Putty KeyPad	biosVfConsoleRedirection/ vpPuttyKeyPad	PuttyFunctionKeyPad
	Redirection After BIOS POST	biosVfConsoleRedirection/ vpLegacyOSRedirection	RedirectionAfterPOST
<b>LOM and PCIe Slots Configuration</b>	PCH SATA Mode	biosVfSataModeSelect/ vpSataModeSelect	SataModeSelect
	All Onboard LOM Ports	biosVfSataModeSelect/ vpSataModeSelect	AllLomPortControl

BIOS Token Group	BIOS Token Name	XML Object	CLI and Web GUI Object
	LOM Port 0 OptionROM	biosVfLOMPortOptionROM/ vpLOMPort0State	LomOpromControlPort0
	LOM Port 1 OptionROM	biosVfLOMPortOptionROM/ vpLOMPort1State	LomOpromControlPort1
	All PCIe Slots OptionROM	biosVfPCIOptionROMs/ vpPCIOptionROMs	PcieOptionROMs
	PCIe Slot: <i>n</i> OptionROM	biosVfPCISlotOptionROMEnable/ vpSlot <i>n</i> State	PcieSlot <i>n</i> OptionROM
	PCIe Mezzanine OptionROM	biosVfPCISlotOptionROMEnable/ vpSlotMezzState	PcieMezzOptionROM
	PCIe Slot:1 Link Speed or SIOC1 Link Speed	biosVfPCISlotOptionROMEnable/ vpSlot1LinkSpeed	PcieSlot1LinkSpeed
	PCIe Slot:2 Link Speed or SIOC2 Link Speed	biosVfPCISlotOptionROMEnable/ vpSlot2LinkSpeed	PcieSlot2LinkSpeed
	PCIe Slot:MLOM OptionROM	biosVfPCISlotOptionROMEnable/ vpSlotMLOMState	PcieSlotMLOMOptionROM
	PCIe Slot:HBA OptionROM	biosVfPCISlotOptionROMEnable/ vpSlotHBAState	PcieSlotHBAOptionROM
	PCIe Slot:N1 OptionROM	biosVfPCISlotOptionROMEnable/ vpSlotN1State	PcieSlotN1OptionROM
	PCIe Slot:N2 OptionROM	biosVfPCISlotOptionROMEnable/ vpSlotN2State	PcieSlotN2OptionROM
Server Management	FRB-2 Timer	biosVfFRB2Enable/ vpFRB2Enable	FRB-2

<b>BIOS Token Group</b>	<b>BIOS Token Name</b>	<b>XML Object</b>	<b>CLI and Web GUI Object</b>
	OS Watchdog Timer	biosVfOSBootWatchdogTimer/ vpOSBootWatchdogTimer	OSBootWatchdogTimer
	OS Watchdog Timer Timeout	biosVfOSBootWatchdogTimerPolicy/ vpOSBootWatchdogTimerPolicy	OSBootWatchdogTimerTimeout
	OS Watchdog Timer Policy	biosVfOSBootWatchdogTimerTimeOut/ vpOSBootWatchdogTimerPolicy	OSBootWatchdogTimerPolicy
	Boot Order Rules	biosVfUCSMBootOrderRuleControl/ vpUCSMBootOrderRule	UCSMBootOrderRule





## INDEX

### A

- Active Directory [109](#)
  - configuring groups [109](#)
- adapter [142, 143, 180, 181, 182, 183, 184](#)
  - activating firmware [184](#)
  - configuring properties [143](#)
  - exporting the configuration [180](#)
  - importing the configuration [181](#)
  - installing firmware [183](#)
  - network [142](#)
  - restoring default configuration [182](#)
  - viewing properties [142](#)
- adapters [139](#)
  - overview [139](#)
- add banner [266](#)
- advanced BIOS parameters [268](#)
- Assigning physical drives [31](#)
- auto balance power profile [56](#)

### B

- backing up [263, 264](#)
  - configuration [263, 264](#)
- BIOS [232, 237, 238](#)
  - activating firmware [238](#)
  - installing from remote server [237](#)
  - obtaining firmware from Cisco [232](#)
- BIOS settings [39, 67, 68, 69](#)
  - advanced [67](#)
  - main [67](#)
  - restoring defaults [69](#)
  - server boot order [39](#)
  - server management [68](#)
- BIOS setup [69](#)
  - entering [69](#)
- BIOS status [66](#)
  - viewing [66](#)
- blacklisting [65](#)
- boot drive [195](#)
  - clearing [195](#)

- boot order [39, 48](#)
  - about [39](#)
  - viewing [48](#)
- boot table [151, 152, 153](#)
  - creating entry [152](#)
  - deleting entry [152, 153](#)
  - description [151](#)

### C

- certificate management [228](#)
  - uploading a certificate [228](#)
- Chassis [17, 18, 19, 21, 22, 28, 29, 31, 32, 33, 34, 244, 245](#)
  - clearing log [245](#)
  - Dynamic Storage [19, 28, 29, 31, 32, 33, 34](#)
- chassis current sensors [85](#)
- chassis LED sensors [88](#)
- chassis temperature sensors [87](#)
- chassis voltage sensors [86](#)
- Cisco IMC [183, 234, 235, 245, 250](#)
  - activating firmware [235](#)
  - configuring log threshold [245, 250](#)
  - firmware [183](#)
  - installing firmware from remote server [234](#)
- Cisco VIC Adapter Details [21](#)
- Clearing BIOS CMOS [258](#)
- clearing foreign configuration [193](#)
- CLI [4](#)
- CMC [240, 241, 259](#)
  - activating firmware [241](#)
  - installing firmware from remote server [240](#)
  - resetting to factory defaults [259](#)
- CMC Firmware [18](#)
- common properties [122](#)
- communication services properties [211, 212, 214, 215](#)
  - HTTP properties [211](#)
  - IPMI over LAN properties [214](#)
  - IPMI over LAN properties for CMC [215](#)
  - SSH properties [212](#)
- configuration [260, 261, 263, 264](#)
  - backing up [263, 264](#)

configuration (*continued*)  
 importing 260, 261  
 create virtual drive 186  
 Create Virtual Drive 188  
 CUPS utilization 62  
 custom profile 57, 58

## D

delete virtual drive 196  
 Deleting boot device 45  
 DIMM 65  
 disabling 56, 58, 60  
 disabling KVM 95  
 disabling-auto-learn 208  
 Dynamic Storage 27  
   SAS Expanders 27  
   Zoning 27

## E

edit virtual drive 199  
 enabling 57, 59  
 enabling JBOD 194  
 enabling KVM 94, 95  
 Enabling secure boot 47  
 enabling-auto-learn 207  
 encrypting virtual media 96  
 event log, system 248, 249, 250  
   clearing 250  
   viewing 248, 249  
 exporting 263, 264  
   configuration 263, 264

## F

fan sensors 84  
 fault summary 243  
   viewing 243  
 faults 244  
 faults, logs 243  
   viewing summary 243  
 FEX 175  
   description 175  
   viewing properties 175  
 FIP mode 143  
   enabling 143  
 firmware 231, 232, 234, 235, 238, 240, 241  
   about 231  
   activating 235, 238, 241

firmware (*continued*)  
   installing from remote server 234, 240  
   obtaining from Cisco 232  
 firmware overview 231  
 floppy disk emulation 96  
 foreign configuration 193  
   importing 193  
 front locator LED 23  
   chassis 23

## G

generate NMI 265

## H

hard drive locator LED 38  
 hard reset 63  
 hot spare 201, 202, 206  
   dedicated 201  
   global 202, 206  
 HTTP properties 211

## I

importing 260, 261  
   configuration 260, 261  
 initializing virtual drive 197  
 IP address 136  
 IP blocking 133  
 IPMI over LAN 214  
   description 214  
 IPMI over LAN properties 214, 215  
 IPv4 properties 123  
 IPv6 properties 125  
 iscsi-boot 172  
   vNIC 172

## K

KVM 94, 95  
   configuring 95  
   disabling 95  
   enabling 94, 95  
 KVM console 13, 93

**L**

- LDAP [106, 107](#)
  - See also [Active Directory](#)
  - configuring in Cisco IMC [107](#)
    - See also [Active Directory](#)
- LDAP Server [106](#)
- LED Details [18](#)
- local users [103](#)
- locator LED [38](#)
  - hard drive [38](#)
- Locator LED [37](#)
  - server [37](#)
- locator-led [209](#)
  - bbu [209](#)
- Logs [244](#)

**M**

- main BIOS parameters [267](#)
  - C3260 servers [267](#)
- making a dedicated hot spare [201](#)
- making a global hot spare [202, 206](#)
- mapped vmedia volume [98, 99](#)
  - cifs [98](#)
  - nfs [98](#)
  - viewing properties [99](#)
  - www [98](#)
- Modifying Boot Order [43](#)

**N**

- network adapter [142](#)
  - viewing properties [142](#)
- network properties [120, 122, 123, 125, 129, 131](#)
  - common properties [122](#)
  - IPv4 properties [123](#)
  - IPv6 properties [125](#)
  - NIC properties [120](#)
  - port profile properties [131](#)
  - VLAN properties [129](#)
- network security [133](#)
- NIC properties [120](#)
- NIV mode [143](#)
  - enabling [143](#)
- NTP settings [135](#)

**O**

- obtaining firmware from Cisco [232](#)

- OS boot [15](#)
  - USB port [15](#)
- OS installation [13, 15](#)
  - methods [13](#)
  - PXE [15](#)
- Overview [2](#)

**P**

- persistent binding [154, 155, 156](#)
  - description [154](#)
  - disabling [155](#)
  - enabling [154](#)
  - rebuilding [156](#)
- physical drive status [203](#)
  - toggling [203](#)
- pinging [136](#)
- port profile properties [131](#)
- power characterization [53](#)
- power cycling the server [51](#)
- power restore policy [51](#)
- Power Supply Properties [22](#)
- power supply sensors [83](#)
- powering off the server [50](#)
- powering on the server [49](#)
- Precision Boot Order [41](#)
- prepare for removal [202](#)
- PXE installation [14](#)

**R**

- Reapplying Boot Order [44](#)
- Rearranging boot order [44](#)
- Rebooting the Cisco IMC [257](#)
- remote presence [94, 95, 96, 100](#)
  - configuring serial over LAN [100](#)
  - virtual KVM [94, 95](#)
  - virtual media [96](#)
- Resetting Cisco IMC factory defaults [258](#)
- restore BIOS manufacturing custom defaults [70](#)
- retrieving [196](#)

**S**

- SAS Expander [28](#)
- self-signed certificate [226](#)
- sensors [83, 84](#)
  - fan [84](#)
  - power supply [83](#)

- serial over LAN [100](#)
  - configuring [100](#)
- server [75, 77, 78, 79, 80, 88, 89, 90, 91](#)
  - viewing CPU details [77](#)
  - viewing current sensors [89](#)
  - viewing DIMM details [77](#)
  - viewing HDD details [79](#)
  - viewing HDD sensors [88](#)
  - viewing LED sensors [89](#)
  - viewing PCI Adapter properties [78](#)
  - viewing properties [75](#)
  - viewing storage adapter properties [80](#)
  - viewing temperature sensors [90](#)
  - viewing TPM inventory [80](#)
  - viewing voltage sensors [91](#)
- server management [23, 37, 38, 39, 49, 50, 51, 63, 64](#)
  - front locator LED [23](#)
  - hard drive locator LED [38](#)
  - power cycling the server [51](#)
  - powering off the server [50](#)
  - powering on the server [49](#)
  - server boot order [39](#)
  - server locator LED [37](#)
  - shutdown the server [64](#)
- server management BIOS parameters [285](#)
- server NICs [119](#)
- Server Overview [1](#)
  - rack-mounted server [1](#)
- server software [2](#)
- Servers' Details [19](#)
- set as boot drive [198](#)
- Sharing physical drives [32](#)
- shutdown the server [64](#)
- SNMP [217, 219, 220](#)
  - configuring properties [217](#)
  - configuring SNMPv3 users [220](#)
  - configuring trap settings [219](#)
  - sending test message [220](#)
- SSH properties [212](#)
- start-learn-cycle [208](#)
- storage firmware logs [196](#)
- Summary [17](#)
- syslog [247, 252, 253](#)
  - sending system log [247, 252, 253](#)
- System [247, 252, 253](#)
  - sending log [247, 252, 253](#)
- system event log [248, 249, 250](#)
  - clearing [250](#)
  - viewing [248, 249](#)

## T

- technical support data [255](#)
  - exporting [255](#)
- Telnet [4](#)
- thermal profile [59, 60](#)
- time zone [24](#)

## U

- Unassigning physical drives [31](#)
- undo prepare for removal [206](#)
- Updating Firmware on Server Components [23](#)
- Updating HDD firmware [34](#)
- Updating SAS Expander firmware [33](#)
- uploading a server certificate [228](#)
- user management [103, 107, 116, 117](#)
  - LDAP [107](#)
  - local users [103](#)
  - terminating user sessions [117](#)
  - viewing user sessions [116](#)
- user sessions [116, 117](#)
  - terminating [117](#)
  - viewing [116](#)
- usNIC [171](#)
  - viewing properties [171](#)

## V

- vHBA [144, 145, 150, 151, 152, 153, 154, 155, 156](#)
  - boot table [151](#)
  - creating [150](#)
  - creating boot table entry [152](#)
  - deleting [151](#)
  - deleting boot table entry [152, 153](#)
  - disabling persistent binding [155](#)
  - enabling persistent binding [154](#)
  - guidelines for managing [144](#)
  - modifying properties [145](#)
  - persistent binding [154](#)
  - rebuilding persistent binding [156](#)
  - viewing properties [145](#)
- viewing [62](#)
- viewing history [244](#)
- viewing storage controller logs [210](#)
- virtual drive [197, 198, 200](#)
  - initializing [197](#)
  - modifying attributes [200](#)
  - set as boot drive [198](#)
- virtual KVM [94, 95](#)
- virtual media [96](#)



VLAN properties [129](#)  
VM FEX [175](#)  
    description [175](#)  
    viewing properties [175](#)  
vNIC [156](#), [157](#), [159](#), [165](#), [166](#), [171](#), [173](#), [174](#)  
    creating [165](#)  
    deleting [166](#)  
    guidelines for managing [156](#)  
    iscsi-boot [173](#)  
    iscsi-boot deletion [174](#)  
    modifying properties [159](#)  
    usnic deletion [171](#)  
    viewing properties [157](#)  
vNICs [172](#)  
    iSCSI-boot guidelines [172](#)

## X

XML API [213](#)  
    description [213](#)  
    enabling [213](#)

## Y

YAML [9](#)

## Z

Zoning [19](#), [29](#)

