



## **Cisco UCS Integrated Management Controller CLI Configuration Guide for S3260 Storage Servers, Release 4.0**

**First Published:** 2018-08-14

**Last Modified:** 2019-04-26

### **Americas Headquarters**

Cisco Systems, Inc.  
170 West Tasman Drive  
San Jose, CA 95134-1706  
USA  
<http://www.cisco.com>  
Tel: 408 526-4000  
800 553-NETS (6387)  
Fax: 408 527-0883





## CONTENTS

---

### PREFACE

<b>Preface</b>	<b>xv</b>
Audience	xv
Conventions	xv
Related Cisco UCS Documentation	xvii

---

### CHAPTER 1

<b>Overview</b>	<b>1</b>
Overview of the Cisco UCS S-Series Rack-Mount Server S3260	1
Overview of the Server Software	2
Server Ports	2
Cisco Integrated Management Controller	3
Cisco IMC CLI	4
Command Modes	5
Command Mode Table	5
Complete a Command	8
Command History	9
Committing, Discarding, and Viewing Pending Commands	9
Command Output Formats	9
Online Help for the CLI	10
Logging In to Cisco IMC	10

---

### CHAPTER 2

<b>Installing the Server OS</b>	<b>13</b>
OS Installation Methods	13
Virtual KVM Console	13
Installing an OS Using the KVM Console	14
PXE Installation Servers	14
Installing an OS Using a PXE Installation Server	15

Booting an Operating System from a USB Port 15

---

**CHAPTER 3****Managing Chassis 17**

Viewing Chassis Properties 17

Viewing Chassis Summary 17

Viewing CMC Firmware Versions 18

Viewing LED Details 18

Viewing the Details of the Servers on the Chassis 19

Viewing Physical Drive Properties 19

Viewing Cisco VIC Adapter Properties 21

Viewing Power Supply Properties 22

Chassis Management Tasks 23

  Toggling the Front Locator LED for the Chassis 23

  Updating Firmware on Server Components 24

  Time Zone 25

    Selecting a Time Zone 25

    Setting a Time Zone 25

  Single Server Dual Connectivity 28

    Configuring Single Server Dual SIOC Connectivity 28

Managing Dynamic Storage 30

  Dynamic Storage Support 30

  Viewing SAS Expander Properties 30

  Viewing Dynamic Storage and Physical Drive Details 32

    Enabling 6G or 12G Mixed Mode Speed on SAS Expanders 34

Managing Physical Drives 35

  Assigning Physical Drives to Servers 35

  Unassigning Physical Drives to Servers 36

  Assigning Physical Drives as Chassis Wide Hot Spare 36

  Sharing Physical Drives with Servers 37

---

**CHAPTER 4****Managing the Server 39**

  Toggling the Server Locator LED 39

  Toggling the Locator LED for a Hard Drive 40

  Managing the Server Boot Order 41

Server Boot Order	41
Viewing the Boot Device Detail	42
Configuring the Precision Boot Order	43
Modifying the Attributes of a Boot Device	45
Rearranging Device Boot Order	46
Reapplying Boot Order Configuration	47
Deleting an Existing Boot Device	48
Overview to UEFI Secure Boot	48
Enabling or Disabling UEFI Secure Boot Mode	49
Viewing the Actual Server Boot Order	51
Configuring a Server to Boot With a One-Time Boot Device	51
Assigning User-defined Server Description and Asset Tag	53
Managing Server Power	53
Powering On the Server	53
Powering Off the Server	54
Powering Cycling the Server	55
Configuring the Power Restore Policy	56
Power Characterization	57
Power Profiles	57
Enabling Chassis Global Power Capping	58
Enabling Auto Balance Profile	59
Disabling Auto Balance Power Profile	61
Enabling Custom Profile on Server	62
Disabling Custom Profile on Server	63
Enabling Thermal Profile on Server	64
Disabling Thermal Profile on Server	65
Viewing Power Cap Configuration Details	66
Viewing Power Monitoring Details	67
Viewing CUPS Utilization Details	67
Resetting the Server	68
Shutting Down the Server	69
Configuring DIMM Black Listing	70
DIMM Black Listing	70
Enabling DIMM Black Listing	70

Configuring BIOS Settings	71
Viewing BIOS Status	71
Configuring Main BIOS Settings	72
Configuring Advanced BIOS Settings	73
Configuring Server Management BIOS Settings	73
Restoring BIOS Defaults	74
Entering BIOS Setup	75
Restoring BIOS Manufacturing Custom Defaults	75
BIOS Profiles	76
Activating a BIOS Profile	76
Taking a Back-Up of a BIOS Profile	77
Deleting a BIOS Profile	77
Displaying BIOS Profiles	78
Displaying Information of a BIOS Profile	78
Displaying details of the BIOS Profile	79
Viewing Product ID (PID) Catalog Details	79
Uploading and Activating PID Catalog	81
Deleting PID Catalog	83
Persistent Memory Module	84
Persistent Memory Modules	84

---

**CHAPTER 5**

<b>Viewing Server Properties</b>	<b>85</b>
Viewing Server Properties	85
Viewing CMC Properties	86
Viewing Server CPU Details	86
Viewing Memory Properties	87
Viewing PCI Adapter Properties for a Server	88
Viewing HDD Details for a Server	89
Viewing Storage Adapter Properties for a Server	90
Viewing TPM Properties	91

---

**CHAPTER 6**

<b>Viewing Sensors</b>	<b>93</b>
Viewing Chassis Sensors	93
Viewing Power Supply Sensors	93

Viewing Fan Sensors	94
Viewing Current Sensors	95
Viewing Voltage Sensors	96
Viewing Temperature Sensors	97
Viewing LED Sensor	98
Viewing Server Sensors	99
Viewing Storage Sensors	99
Viewing Current Sensors	99
Viewing LED Sensors	100
Viewing Temperature Sensors	101
Viewing Voltage Sensors	102

---

**CHAPTER 7**
**Managing Remote Presence 103**

Managing the Virtual KVM	103
Virtual KVM Console	103
Enabling the Virtual KVM	104
Disabling the Virtual KVM	105
Configuring the Virtual KVM	106
Configuring Virtual Media	107
Configuring a Cisco IMC-Mapped vMedia Volume	108
Viewing Cisco IMC-Mapped vMedia Volume Properties	109
Remapping an Existing Cisco IMC vMedia Image	110
Deleting a Cisco IMC vMedia Image	111
Managing Serial over LAN	112
Serial Over LAN	112
Guidelines and Restrictions for Serial Over LAN	112
Configuring Serial Over LAN	112

---

**CHAPTER 8**
**Managing User Accounts 115**

Configuring Local Users	115
Non-IPMI User Mode	117
Switching User Mode from IPMI to Non-IPMI	118
Switching User Mode from Non-IPMI to IPMI	119
Disabling Strong Password	119

- Password Expiry 120
- Resetting the User Password 121
- Configuring Password Expiry for Users 122
- LDAP Servers 123
- Configuring the LDAP Server 123
- Configuring LDAP in Cisco IMC 124
- Configuring LDAP Groups in Cisco IMC 126
- Configuring Nested Group Search Depth in LDAP Groups 128
- LDAP Certificates Overview 129
  - Exporting LDAP CA Certificate 129
  - Downloading LDAP CA Certificate Content by Copying Content 130
  - Downloading LDAP CA Certificate Using Remote Server 132
  - Testing LDAP Binding 133
  - Deleting LDAP CA Certificate 134
- Setting User Search Precedence 135
- Viewing User Sessions 135
- Terminating a User Session 136

---

**CHAPTER 9**

- Configuring Network-Related Settings 139**
  - Server NIC Configuration 139
    - Server NICs 139
    - Configuring NICs 141
  - Common Properties Configuration 143
    - Overview to Common Properties Configuration 143
    - Configuring Common Properties 143
  - Configuring Single IP Properties 145
  - Configuring IPv4 146
  - Configuring IPv6 149
  - Configuring VLAN 152
  - Connecting to a Port Profile 154
  - Configuring Interface Properties 156
  - Network Security Configuration 157
    - Network Security 157
    - Configuring Network Security 157



Network Time Protocol Configuration	159
Configuring Network Time Protocol Settings	159
Pinging an IP address	161

---

**CHAPTER 10**
**Managing Network Adapters 163**

Overview of the Cisco UCS C-Series Network Adapters	163
Viewing Network Adapter Properties	165
Configuring Network Adapter Properties	166
Managing vHBAs	169
Guidelines for Managing vHBAs	169
Viewing vHBA Properties	170
Modifying vHBA Properties	171
Creating a vHBA	176
Deleting a vHBA	178
vHBA Boot Table	178
Viewing the Boot Table	178
Creating a Boot Table Entry	179
Deleting a Boot Table Entry	180
vHBA Persistent Binding	181
Enabling Persistent Binding	181
Disabling Persistent Binding	182
Rebuilding Persistent Binding	183
Managing vNICs	184
Guidelines for Managing vNICs	184
Viewing vNIC Properties	184
Modifying vNIC Properties	186
Enabling or Disabling Link Training on External Ethernet Interfaces	195
Setting Admin FEC Mode on External Ethernet Interfaces	196
Creating a vNIC	197
Deleting a vNIC	198
Creating Cisco usNIC Using the Cisco IMC CLI	199
Modifying a Cisco usNIC value using the Cisco IMC CLI	202
Viewing usNIC Properties	203
Deleting Cisco usNIC from a vNIC	204

Configuring iSCSI Boot Capability	205
Configuring iSCSI Boot Capability for vNICs	205
Configuring iSCSI Boot Capability on a vNIC	205
Deleting an iSCSI Boot Configuration for a vNIC	206
Backing Up and Restoring the Adapter Configuration	207
Exporting the Adapter Configuration	207
Importing the Adapter Configuration	209
Restoring Adapter Defaults	210
Managing Adapter Firmware	210
Adapter Firmware	210
Installing Adapter Firmware	211
Activating Adapter Firmware	212
<hr/>	
<b>CHAPTER 11</b>	<b>Managing Storage Adapters 213</b>
Creating Virtual Drives from Unused Physical Drives	214
Creating Virtual Drive from an Existing Drive Group	216
Setting a Virtual Drive as Transport Ready	218
Clearing a Virtual Drive as Transport Ready	220
Importing Foreign Configuration	221
Clearing Foreign Configuration	222
Enabling and Disabling JBOD	223
Clearing a Boot Drive	224
Retrieving Storage Firmware Logs for a Controller	225
Self Encrypting Drives (Full Disk Encryption)	225
Enabling Security on a Controller	226
Disabling Security on a Controller	227
Modifying Controller Security Settings	228
Verifying the Security Key Authenticity	229
Switching Controller Security From Remote to Local Key Management	230
Switching Controller Security From Local to Remote Key Management	231
Deleting a Virtual Drive	232
Initializing a Virtual Drive	233
Set as Boot Drive	234
Editing a Virtual Drive	235

Modifying Attributes of a Virtual Drive	236
Making a Dedicated Hot Spare	237
Making a Global Hot Spare	237
Preparing a Drive for Removal	238
Toggling Physical Drive Status	239
Setting a Physical Drive as a Controller Boot Drive	240
Removing a Drive from Hot Spare Pools	242
Undo Preparing a Drive for Removal	242
Enabling Auto Learn Cycles for the Battery Backup Unit	243
Disabling Auto Learn Cycles for the Battery Backup Unit	244
Starting a Learn Cycle for a Battery Backup Unit	244
Toggling the Locator LED for a Physical Drive	245
Clearing Controller Configuration	246
Restoring Storage Controller to Factory Defaults	247
Viewing Storage Controller Logs	247
Viewing Physical Drive Details	248
Viewing SIOC NVMe Drive Details	249

---

**CHAPTER 12**
**Configuring Communication Services 253**

Configuring HTTP	253
Configuring SSH	255
Configuring XML API	256
XML API for Cisco IMC	256
Enabling XML API	256
Enabling Redfish	256
Configuring IPMI	257
IPMI Over LAN	257
Configuring IPMI over LAN for Cisco IMC	257
Configuring IPMI over LAN for CMCs	259
Configuring SNMP	261
SNMP	261
Configuring SNMP Properties	261
Configuring SNMP Trap Settings	263
Sending a Test SNMP Trap Message	264

Configuring SNMPv3 Users 265

Configuring a Server to Send Email Alerts Using SMTP 267

Configuring SMTP Servers for Receiving E-Mail Alerts 267

---

CHAPTER 13

**Managing Certificates and Server Security 269**

Managing the Server Certificate 269

Managing the Server Certificate 269

Generating a Certificate Signing Request 270

Creating an Untrusted CA-Signed Certificate 272

Uploading a Server Certificate 274

KMIP 275

Key Management Interoperability Protocol 275

Enabling or Disabling KMIP 275

Configuring KMIP Server Login Credentials 276

Creating a Client Private Key and Client Certificate for KMIP Configuration 277

Testing the KMIP Server Connection 278

Configuring KMIP Server Properties 279

Downloading a KMIP Client Certificate 280

Exporting a KMIP Client Certificate 282

Deleting a KMIP Client Certificate 284

Downloading a KMIP Client Private Key 284

Exporting KMIP Client Private Key 286

Deleting a KMIP Client Private Key 288

Downloading a KMIP Root CA Certificate 289

Exporting a KMIP Root CA Certificate 291

Deleting a KMIP Root CA Certificate 293

---

CHAPTER 14

**Configuring Platform Event Filters 295**

Platform Event Filters 295

Configuring Platform Event Filters 295

Resetting Event Platform Filters 296

---

CHAPTER 15

**Cisco IMC Firmware Management 299**

Overview of Firmware 299

Obtaining Firmware from Cisco	300
Installing Cisco IMC Firmware from a Remote Server	302
Activating Installed Cisco IMC Firmware	304
Installing BIOS Firmware from a Remote Server	306
Activating Installed BIOS Firmware	307
Canceling a Pending BIOS Activation	309
Installing CMC Firmware from a Remote Server	310
Activating Installed CMC Firmware	312
Managing SAS Expander and HDD Firmware	313
Updating and Activating SAS Expander Firmware	313
Updating HDD Firmware	314

---

**CHAPTER 16**
**Viewing Faults and Logs 317**

Fault Summary	317
Viewing the Faults and Logs Summary	317
Fault History	318
Viewing the Fault History	318
Cisco IMC Log	318
Viewing Cisco IMC Log	318
Clearing Trace Logs	319
Configuring the Cisco IMC Log Threshold	320
Sending the Cisco IMC Log to a Remote Server	321
System Event Log	322
Viewing the System Event Log	322
Viewing the System Event Log for Servers	323
Clearing the System Event Log	325
Logging Controls	325
Configuring the Cisco IMC Log Threshold	325
Sending the Cisco IMC Log to a Remote Server	327
Sending a Test Cisco IMC Log to a Remote Server	328

---

**CHAPTER 17**
**Server Utilities 329**

Exporting Technical Support Data	329
Rebooting the Cisco IMC	332

Clearing the BIOS CMOS 332

Resetting the BMC to factory Defaults 333

Resetting to Factory Defaults 334

Resetting to Factory Defaults 336

Exporting and Importing the Cisco IMC and BMC Configuration 338

    Importing a CMC Configuration 338

    Importing BMC Configuration 340

    Exporting the BMC Configuration 341

    Exporting the CMC Configuration 343

    Exporting VIC Adapter Configuration 345

    Importing VIC Adapter Configuration 346

Generating Non-Maskable Interrupts to the Host 347

Adding Cisco IMC Banner 348

Downloading and Viewing Inventory Details 349

---

**APPENDIX A**

**BIOS Parameters by Server Model 351**

S3260 M3 Servers 351

    Main BIOS Parameters 351

    Advance BIOS Parameters 352

    Server Management BIOS Parameters 370

S3260 M4 Servers 371

    Main BIOS Parameters 371

    Advance BIOS Parameters 372

    Server Management BIOS Parameters 395

S3260 M5 Servers 396

    I/O Tab 396

    Server Management Tab 402

    Security Tab 406

    Processor Tab 407

    Memory Tab 414

    Power/Performance Tab 415

---

**APPENDIX B**

**BIOS Token Name Comparison for Multiple Interfaces 417**

BIOS Token Name Comparison for Multiple Interfaces 417



## Preface

---

- [Audience, on page xv](#)
- [Conventions, on page xv](#)
- [Related Cisco UCS Documentation, on page xvii](#)

## Audience

This guide is intended primarily for data center administrators with responsibilities and expertise in one or more of the following:

- Server administration
- Storage administration
- Network administration
- Network security

## Conventions

Text Type	Indication
GUI elements	GUI elements such as tab titles, area names, and field labels appear in <b>this font</b> . Main titles such as window, dialog box, and wizard titles appear in <b>this font</b> .
Document titles	Document titles appear in <i>this font</i> .
TUI elements	In a Text-based User Interface, text the system displays appears in <i>this font</i> .
System output	Terminal sessions and information that the system displays appear in <i>this font</i> .
CLI commands	CLI command keywords appear in <b>this font</b> . Variables in a CLI command appear in <i>this font</i> .
[ ]	Elements in square brackets are optional.

Text Type	Indication
{x   y   z}	Required alternative keywords are grouped in braces and separated by vertical bars.
[x   y   z]	Optional alternative keywords are grouped in brackets and separated by vertical bars.
string	A nonquoted set of characters. Do not use quotation marks around the string or the string will include the quotation marks.
<>	Nonprinting characters such as passwords are in angle brackets.
[ ]	Default responses to system prompts are in square brackets.
!, #	An exclamation point (!) or a pound sign (#) at the beginning of a line of code indicates a comment line.




---

**Note** Means *reader take note*. Notes contain helpful suggestions or references to material not covered in the document.

---




---

**Tip** Means *the following information will help you solve a problem*. The tips information might not be troubleshooting or even an action, but could be useful information, similar to a Timesaver.

---




---

**Timesaver** Means *the described action saves time*. You can save time by performing the action described in the paragraph.

---




---

**Caution** Means *reader be careful*. In this situation, you might perform an action that could result in equipment damage or loss of data.

---




---

**Warning** IMPORTANT SAFETY INSTRUCTIONS

This warning symbol means danger. You are in a situation that could cause bodily injury. Before you work on any equipment, be aware of the hazards involved with electrical circuitry and be familiar with standard practices for preventing accidents. Use the statement number provided at the end of each warning to locate its translation in the translated safety warnings that accompanied this device.

SAVE THESE INSTRUCTIONS

---



# Related Cisco UCS Documentation

## Documentation Roadmaps

For a complete list of all B-Series documentation, see the *Cisco UCS B-Series Servers Documentation Roadmap* available at the following URL: [https://www.cisco.com/c/en/us/td/docs/unified\\_computing/ucs/overview/guide/UCS\\_roadmap.html](https://www.cisco.com/c/en/us/td/docs/unified_computing/ucs/overview/guide/UCS_roadmap.html)

For a complete list of all C-Series documentation, see the *Cisco UCS C-Series Servers Documentation Roadmap* available at the following URL: [https://www.cisco.com/c/en/us/td/docs/unified\\_computing/ucs/overview/guide/ucs\\_rack\\_roadmap.html](https://www.cisco.com/c/en/us/td/docs/unified_computing/ucs/overview/guide/ucs_rack_roadmap.html).

For information on supported firmware versions and supported UCS Manager versions for the rack servers that are integrated with the UCS Manager for management, refer to [Release Bundle Contents for Cisco UCS Software](#).

## Other Documentation Resources

Follow [Cisco UCS Docs on Twitter](#) to receive document update notifications.





# CHAPTER 1

## Overview

---

This chapter includes the following sections:

- [Overview of the Cisco UCS S-Series Rack-Mount Server S3260, on page 1](#)
- [Overview of the Server Software, on page 2](#)
- [Server Ports, on page 2](#)
- [Cisco Integrated Management Controller, on page 3](#)
- [Cisco IMC CLI, on page 4](#)

## Overview of the Cisco UCS S-Series Rack-Mount Server S3260

The Cisco UCS S3260 is a modular, dense storage server with dual M3, M4 or M5 server nodes, optimized for large datasets used in environments such as big data, cloud, object storage, and content delivery.

The UCS S3260 chassis is a modular architecture consisting of the following modules:

- **Base chassis:** contains four redundant, hot-pluggable power supplies, eight redundant, hot-pluggable fans, and a rail kit.
- **Server Node:** one or two M3, M4 or M5 server nodes, each with two CPUs, 64, 128, 256, or 512 GB of DIMM memory, and a pass-through controller or a RAID card with a 1 GB or 4 GB cache.
- **System I/O Controller (SIOC):** one or two System I/O Controllers, each of which includes an integrated 1300-series or 1400-series virtual interface capability.
- **Optional Drive Expansion Node:** Large Form Factor (LFF) 3.5-inch drives in a choice of capacities.
- **Solid State Drives:** Up to 14 solid-state disks (SSDs) of 400GB, 800 GB, 1.6TB, and 3.2 TB capacities. These replace the previously supported top-loading LFF HDDs.
- **Solid-State Boot Drives:** up to two SSDs per M3, M4, or M5 server node. On the M4 server node, boot drives support hardware RAID connected to the RAID controller on the server node.
- **I/O Expander:** provides one storage mezz slot with two PCIe expansion slots and up to two NVMe SSDs.

The enterprise-class UCS S3260 storage server extends the capabilities of Cisco's Unified Computing System portfolio in a 4U form factor that delivers the best combination of performance, flexibility, and efficiency gains.



**Note** An M3 Server Node has Intel E5-2600 V2 CPUs and DDR-3 DIMMs. An M4 Server Node has Intel E5-2600 v4 CPUs and DDR-4 DIMMs

## Overview of the Server Software

The Cisco UCS C-Series Rack-Mount Server ships with the Cisco IMC firmware.

### Cisco IMC Firmware

Cisco IMC is a separate management module built into the motherboard. A dedicated ARM-based processor, separate from the main server CPU, runs the Cisco IMC firmware. The system ships with a running version of the Cisco IMC firmware. You can update the Cisco IMC firmware, but no initial installation is needed.

### Server OS

The Cisco UCS C-Series rack servers support operating systems such as Windows, Linux, Oracle and so on. For more information on supported operating systems, see the *Hardware and Software Interoperability for Standalone C-series servers* at [http://www.cisco.com/en/US/products/ps10477/prod\\_technical\\_reference\\_list.html](http://www.cisco.com/en/US/products/ps10477/prod_technical_reference_list.html). You can use Cisco IMC to install an OS on the server using the KVM console and vMedia.

## Server Ports

Following is a list of server ports and their default port numbers:

**Table 1: Server Ports**

Port Name	Port Number
LDAP Port 1	389
LDAP Port 2	389
LDAP Port 3	389
LDAP Port 4	3268
LDAP Port 5	3268
LDAP Port 6	3268
SSH Port	22
HTTP Port	80
HTTPS Port	443
SMTP Port	25

Port Name	Port Number
KVM Port	2068
Andromeda Management Port	8889
Andromeda Cloud Port	8888
SOL SSH Port	2400
SNMP Port	161
SNMP Traps	162
External Syslog	514

## Cisco Integrated Management Controller

The Cisco IMC is the management service for the C-Series servers. Cisco IMC runs within the server.



**Note** The Cisco IMC management service is used only when the server is operating in Standalone Mode. If your C-Series server is integrated into a UCS system, you must manage it using UCS Manager. For information about using UCS Manager, see the configuration guides listed in the *Cisco UCS B-Series Servers Documentation Roadmap* at <http://www.cisco.com/go/unifiedcomputing/b-series-doc>.

### Management Interfaces

You can use a web-based GUI or SSH-based CLI or an XML-based API to access, configure, administer, and monitor the server. Almost all tasks can be performed in either interface, and the results of tasks performed in one interface are displayed in another. However, you cannot do the following:

- Use Cisco IMC GUI to invoke Cisco IMC CLI
- View a command that has been invoked through Cisco IMC CLI in Cisco IMC GUI
- Generate Cisco IMC CLI output from Cisco IMC GUI

### Tasks You Can Perform in Cisco IMC

You can use Cisco IMC to perform the following server management tasks:

- Power on, power off, power cycle, reset and shut down the server
- Toggle the locator LED
- Configuring BIOS settings
- Configure the server boot order
- View server properties and sensors
- Manage remote presence

- Create and manage local user accounts, and enable remote user authentication through Active Directory
- Configure network-related settings, including NIC properties, IPv4, VLANs, and network security
- Configure communication services, including HTTP, SSH, IPMI Over LAN, and SNMP.
- Manage certificates
- Configure platform event filters
- Update Cisco IMC firmware
- Monitor faults, alarms, and server status
- Set time zone and view local time
- Install and activate Cisco IMC firmware
- Install and activate BIOS firmware
- Install and activate CMC firmware

### No Operating System or Application Provisioning or Management

Cisco IMC provisions servers, and as a result, exists below the operating system on a server. Therefore, you cannot use it to provision or manage operating systems or applications on servers. For example, you cannot do the following:

- Deploy an OS, such as Windows or Linux
- Deploy patches for software, such as an OS or an application
- Install base software components, such as anti-virus software, monitoring agents, or backup clients
- Install software applications, such as databases, application server software, or web servers
- Perform operator actions, including restarting an Oracle database, restarting printer queues, or handling non-Cisco IMC user accounts
- Configure or manage external storage on the SAN or NAS storage

## Cisco IMC CLI

The Cisco IMC CLI is a command-line management interface for Cisco UCS C-Series servers. You can launch the Cisco IMC CLI and manage the server over the network by SSH or Telnet.

A user of the CLI will be one of three roles: admin, user (can control, cannot configure), and read-only.



---

**Note**

To recover from a lost admin password, see the Cisco UCS C-Series server installation and service guide for your platform.

---

## Command Modes

The CLI is organized into a hierarchy of command modes, with the EXEC mode being the highest-level mode of the hierarchy. Higher-level modes branch into lower-level modes. You use the **scope** command to move from higher-level modes to modes in the next lower level, and the **exit** command to move up one level in the mode hierarchy. The **top** command returns to the EXEC mode.



**Note** Most command modes are associated with managed objects. The **scope** command does not create managed objects and can only access modes for which managed objects already exist.

Each mode contains a set of commands that can be entered in that mode. Most of the commands available in each mode pertain to the associated managed object. Depending on your assigned role, you may have access to only a subset of the commands available in a mode; commands to which you do not have access are hidden.

The CLI prompt for each mode shows the full path down the mode hierarchy to the current mode. This helps you to determine where you are in the command mode hierarchy and can be an invaluable tool when you need to navigate through the hierarchy.

## Command Mode Table

The following table lists the first four levels of command modes, the commands used to access each mode, and the CLI prompt associated with each mode.

Mode Name	Command to Access	Mode Prompt
EXEC	<b>top</b> command from any mode	#
server	<b>scope server</b> <i>index</i> command from EXEC mode	/server #
bios	<b>scope bios</b> command from server mode	/server/bios #
advanced	<b>scope advanced</b> command from bios mode	/server/bios/advanced #
main	<b>scope main</b> command from bios mode	/server/bios/main #
server-management	<b>scope server-management</b> command from bios mode	/server/bios/server-management #
boot-device	<b>scope boot-device</b> command from bios mode	/server/bios/boot-device #
bmc	<b>scope bmc</b> command from server mode	/server/bmc #
firmware	<b>scope firmware</b> command from bmc mode	/server/bios/bmc #

Mode Name	Command to Access	Mode Prompt
import-export	<b>scope import-export</b> command from bmc mode	/server/bios/import-export #
network	<b>scope network</b> command from bmc mode	/server/bios/network #
power-restore-policy	<b>scope power-restore-policy</b> command from bmc mode	/server/bios/power-restore-policy #
kvm	<b>scope kvm</b> command from server mode	/server/kvm #
ipmi	<b>scope ipmi</b> command from server mode	/server/ipmi #
dim-blacklisting	<b>scope dim-blacklisting</b> command from server mode	/server/dimm-blacklisting #
reset-ecc	<b>scope reset-ecc</b> command from server mode	/server/reset-ecc #
sel	<b>scope sel</b> command from server mode	/server/sel #
sol	<b>scope sol</b> command from server mode	/server/sol #
vmedia	<b>scope vmedia</b> command from server mode	/server/vmedia #
certificate	<b>scope certificate</b> command from EXEC mode	/certificate #
fault	<b>scope fault</b> command from EXEC mode	/fault #
http	<b>scope http</b> command from EXEC mode	/http #
ldap	<b>scope ldap</b> command from EXEC mode	/ldap #
binding	<b>scope binding</b> command from ldap mode	/ldap/binding #
dns-search	<b>scope dns-search</b> command from ldap mode	/ldap/dns-search #
ldap-group-rule	<b>scope ldap-group-rule</b> command from ldap mode	/ldap/ldap-group-rule #
ldap-server	<b>scope ldap-server</b> command from ldap mode	/ldap/ldap-server #



Mode Name	Command to Access	Mode Prompt
role-group	<b>scope role-group</b> command from ldap mode	/ldap/role-group #
network	<b>scope network</b> command from EXEC mode	/network #
ipblocking	<b>scope ipblocking</b> command from network mode	/network/ipblocking #
chassis	<b>scope chassis</b> command from EXEC mode	/chassis #
adapter	<b>scope adapter</b> <i>index</i> command from chassis mode	/chassis/adapter #
host-eth-if	<b>scope host-eth-if</b> command from adapter mode	/chassis/adapter/host-eth-if #
host-fc-if	<b>scope host-fc-if</b> command from adapter mode	/chassis/adapter/host-fc-if #
port-profiles	<b>scope port-profiles</b> command from adapter mode	/chassis/adapter/port-profiles #
vmfex	<b>scope vmfex</b> <i>index</i> command from adapter mode	/chassis/adapter/vmfex #
cmc	<b>scope cmc</b> <i>index</i> command from chassis mode	/chassis/cmc #
ipmi	<b>scope ipmi</b> command from cmc mode	/chassis/cmc/ipmi #
network	<b>scope network</b> command from cmc mode	/chassis/cmc/network #
firmware	<b>scope firmware</b> command from chassis mode	/chassis/firmware #
import-export	<b>scope import-export</b> command from chassis mode	/chassis/import-export #
log	<b>scope log</b> command from chassis mode	/chassis/log #
server	<b>scope server</b> command from log mode	/chassis/log/server #
sas-expander	<b>scope sas-expander</b> <i>index</i> command from chassis mode	/chassis/sas-expander #
phy-stats	<b>scope phy-stats</b> command from sas-expander mode	/chassis/sas-expander/phy-stats #

Mode Name	Command to Access	Mode Prompt
server	<b>scope server</b> <i>index</i> command from chassis mode	/chassis/server #
storageadapter	<b>scope storageadapter</b> command from server mode	/chassis/server/storageadapter #
dimmm-summary	<b>scope dimm-summary</b> command from server mode	/chassis/server/dimm-summary #
tech-support	<b>scope tech-support</b> command from chassis mode	/chassis/tech-support #
sensor	<b>scope sensor</b> command from EXEC mode	/sensor #
snmp	<b>scope snmp</b> command from EXEC mode	/snmp #
trap-destinations	<b>scope trap-destinations</b> command from snmp mode	/snmp/trap-destinations #
v3users	<b>scope v3users</b> command from snmp mode	/snmp/v3users #
ssh	<b>scope ssh</b> command from EXEC mode	/ssh #
time	<b>scope time</b> command from EXEC mode	/time #
ntp	<b>scope ntp</b> command from time mode	/time/ntp #
user	<b>scope user</b> <i>user-number</i> command from EXEC mode	/user #
user-policy	<b>scope user-policy</b> command from EXEC mode	/user-policy #
user-session	<b>scope user-session</b> <i>session-number</i> command from EXEC mode	/user-session #
xmlapi	<b>scope xmlapi</b> command from EXEC mode	/xmlapi #

## Complete a Command

You can use the **Tab** key in any mode to complete a command. Partially typing a command name and pressing **Tab** causes the command to be displayed in full or to the point where another keyword must be chosen or an argument value must be entered.

## Command History

The CLI stores all commands used in the current session. You can step through the previously used commands by using the **Up Arrow** or **Down Arrow** keys. The **Up Arrow** key steps to the previous command in the history, and the **Down Arrow** key steps to the next command in the history. If you get to the end of the history, pressing the **Down Arrow** key does nothing.

All commands in the history can be entered again by simply stepping through the history to recall the desired command and pressing **Enter**. The command is entered as if you had manually typed it. You can also recall a command and change it before you press **Enter**.

## Committing, Discarding, and Viewing Pending Commands

When you enter a configuration command in the CLI, the command is not applied until you enter the **commit** command. Until committed, a configuration command is pending and can be discarded by entering a **discard** command. When any command is pending, an asterisk (\*) appears before the command prompt. The asterisk disappears when you enter the **commit** command, as shown in this example:

```
Server# scope chassis
Server /chassis # set locator-led off
Server /chassis *# commit
Server /chassis #
```

You can accumulate pending changes in multiple command modes and apply them together with a single **commit** command. You can view the pending commands by entering the **show configuration pending** command in any command mode.



---

**Note** Committing multiple commands together is not an atomic operation. If any command fails, the successful commands are applied despite the failure. Failed commands are reported in an error message.

---

## Command Output Formats

Most CLI **show** commands accept an optional **detail** keyword that causes the output information to be displayed as a list rather than a table. You can configure either of two presentation formats for displaying the output information when the **detail** keyword is used. The format choices are as follows:

- **Default**—For easy viewing, the command output is presented in a compact list.

This example shows command output in the default format:

```
Server /chassis # set cli output default
Server /chassis # show hdd detail
Name HDD_01_STATUS:
  Status : present
Name HDD_02_STATUS:
  Status : present
Name HDD_03_STATUS:
  Status : present
Name HDD_04_STATUS:
  Status : present

Server /chassis #
```

- **YAML**—For easy parsing by scripts, the command output is presented in the YAML (YAML Ain't Markup Language) data serialization language, delimited by defined character strings.

This example shows command output in the YAML format:

```
Server /chassis # set cli output yaml
Server /chassis # show hdd detail
---
  name: HDD_01_STATUS
  hdd-status: present
---
  name: HDD_02_STATUS
  hdd-status: present
---
  name: HDD_03_STATUS
  hdd-status: present
---
  name: HDD_04_STATUS
  hdd-status: present
...
Server /chassis #
```

For detailed information about YAML, see <http://www.yaml.org/about.html>.

In most CLI command modes, you can enter **set cli output default** to configure the default format, or **set cli output yaml** to configure the YAML format.

## Online Help for the CLI

At any time, you can type the ? character to display the options available at the current state of the command syntax.

If you have not typed anything at the prompt, typing ? lists all available commands for the mode you are in. If you have partially typed a command, typing ? lists all available keywords and arguments available at your current position in the command syntax.

## Logging In to Cisco IMC

### Procedure

- 
- Step 1** Connect to the console port.
- Step 2** When logging in to an unconfigured system for the first time, use **admin** as the username and **password** as the password.

The following situations occur when you login to the CLI for the first time:

- You cannot perform any operation until you change default admin credentials on the Cisco IMC web UI or CLI.

**Note** After an upgrade from Cisco IMC version 1.5(x) or 2.0(1) to the latest version, or when you do a factory reset, during first login Cisco IMC prompts for a password change. You cannot choose the word 'password' as your new password. If this creates problems for any scripts you may be running, you could change it to password by logging back into the user management options, but this is ENTIRELY at your own risk. It is not recommended by Cisco.

---

### Example

The following example shows how to login in to Cisco IMC first time:

```
Login as # admin
admin10.101.255.255's password # password

*****WARNING*****
Default credentials were used for login.
Administration passwords needs to be changed for security purpose.
*****

Enter current password # abcxyz
Re-enter new password # abcxyz
Updating password...
Password updated successfully.
Server #
```





## CHAPTER 2

# Installing the Server OS

---

This chapter includes the following sections:

- [OS Installation Methods, on page 13](#)
- [Virtual KVM Console, on page 13](#)
- [PXE Installation Servers, on page 14](#)
- [Booting an Operating System from a USB Port, on page 15](#)

## OS Installation Methods

C-Series servers support several operating systems. Regardless of the OS being installed, you can install it on your server using one of the following tools:

- KVM console
- PXE installation server

For more information on Cisco UCS Server Configuration Utility, see [Cisco UCS Server Configuration Utility Quick Start Guide](#).

## Virtual KVM Console

The vKVM console is an interface accessible from Cisco IMC that emulates a direct keyboard, video, and mouse (vKVM) connection to the server. The vKVM console allows you to connect to the server from a remote location.

Here are a few major advantages of using Cisco KVM Console:

- The Cisco KVM console provides connection to KVM, SOL, and vMedia whereas the Avocent KVM provides connection only to KVM and vMedia.
- In the KVM Console, the vMedia connection is established at the KVM Launch Manager and is available for all users.
- The KVM console offers you an advanced character replacement options for the unsupported characters while pasting text from the guest to the host.
- The KVM console provides you an ability to store the vMedia mappings on CIMC.

Instead of using CD/DVD or floppy drives physically connected to the server, the vKVM console uses virtual media, which are actual disk drives or disk image files that are mapped to virtual CD/DVD or floppy drives. You can map any of the following to a virtual drive:

- CD/DVD or floppy drive on your computer
- Disk image files (ISO or IMG files) on your computer
- USB flash drive on your computer
- CD/DVD or floppy drive on the network
- Disk image files (ISO or IMG files) on the network
- USB flash drive on the network

You can use the vKVM console to install an OS on the server.




---

**Note** To configure the vKVM console successfully for the S3260 Storage Server, you need to configure IP addresses for the Cisco IMC, CMC, and BMC components. You can configure the IP addresses for these components using the CLI interface or Web UI. For the CLI, use the command **scope network**, or view the setting using **scope <chassis/server1/2><cmc/bmc><network>**.

To configure IP addresses for network components on the web interface, see the steps described in the section **Configuring Network-Related Settings**.

---




---

**Note** The vKVM Console is operated only through the GUI. To launch the vKVM Console, see the instructions in the *Cisco UCS C-Series Servers Integrated Management Controller GUI Configuration Guide*.

---

## Installing an OS Using the KVM Console

Because the KVM console is operated only through the GUI, you cannot install a server OS using the CLI. To install an OS using the KVM console, follow the instructions in the "Installing an OS Using the KVM Console" section of the *Cisco UCS C-Series Servers Integrated Management Controller GUI Configuration Guide*.




---

**Note** Detailed guides for installing Linux, VMware, and Windows can be found at this URL: [http://www.cisco.com/en/US/products/ps10493/products\\_installation\\_and\\_configuration\\_guides\\_list.html](http://www.cisco.com/en/US/products/ps10493/products_installation_and_configuration_guides_list.html).

---

## PXE Installation Servers

A Preboot Execution Environment (PXE) installation server allows a client to boot and install an OS from a remote location. To use this method, a PXE environment must be configured and available on your VLAN, typically a dedicated provisioning VLAN. Additionally, the server must be set to boot from the network.



When the server boots, it sends a PXE request across the network. The PXE installation server acknowledges the request, and starts a sequence of events that installs the OS on the server.

PXE servers can use installation disks, disk images, or scripts to install an OS. Proprietary disk images can also be used to install an OS, additional components, or applications.



**Note** PXE installation is an efficient method for installing an OS on a large number of servers. However, considering that this method requires setting up a PXE environment, it might be easier to use another installation method.

## Installing an OS Using a PXE Installation Server

### Before you begin

- Verify that the server can be reached over a VLAN.
- You must log in as a user with admin privileges to install an OS.

### Procedure

**Step 1** Set the boot order to **PXE** first.

**Step 2** Reboot the server.

If a PXE install server is available on the VLAN, the installation process begins when the server reboots. PXE installations are typically automated and require no additional user input. Refer to the installation guide for the OS being installed to guide you through the rest of the installation process.

### What to do next

After the OS installation is complete, reset the LAN boot order to its original setting. Always follow your OS vendors recommended configuration, including software interoperability and driver compatibility. For more information on driver recommendations and installation, follow the Cisco UCS Hardware Compatibility list here:

<https://ucsheltool.cloudapps.cisco.com/public/>

## Booting an Operating System from a USB Port

All Cisco UCS C-series servers support booting an operating system from any USB port on the server. However, there are a few guidelines that you must keep in mind, prior to booting an OS from a USB port.

- To maintain the boot order configuration, it is recommended that you use an internal USB port for booting an OS.
- The USB port must be enabled prior to booting an OS from it.

By default, the USB ports are enabled. If you have disabled a USB port, you must enable it prior to booting an OS from it. For information on enabling a disabled USB ports, see topic *Enabling or Disabling the Internal USB Port* in the server-specific installation and service guide available at the following link:

[http://www.cisco.com/en/US/products/ps10493/prod\\_installation\\_guides\\_list.html](http://www.cisco.com/en/US/products/ps10493/prod_installation_guides_list.html).

- After you boot the OS from the USB port, you must set the second-level boot order so that the server boots from that USB source every time.



## CHAPTER 3

# Managing Chassis

This chapter includes the following sections:

- [Viewing Chassis Properties, on page 17](#)
- [Chassis Management Tasks, on page 23](#)
- [Managing Dynamic Storage, on page 30](#)

## Viewing Chassis Properties

### Viewing Chassis Summary

#### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>show detail</b>	Displays the chassis' properties.

#### Example

This example displays the chassis' properties:

```
Server# scope chassis
Server /chassis # show detail
Chassis:
  Serial Number: FOX1843G9EM
  Product Name: UCS S3260
  PID : UCSC-C3X60-BASE
  Front Panel Locator LED: on
  Description:
  CMC-1 State: Active
  CMC-2 State: Standby

Server /chassis #
```

## Viewing CMC Firmware Versions

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>show cmc</b>	Displays the CMC firmware versions.

### Example

This example displays the CMC firmware versions.:

```
Server# scope chassis
Server /chassis # show cmc
ID      Name      Serial Number  Update Stage  Update Progress  Current FW Version
-----
1       CMC1              NONE          100           2.0 (6.79)
2       CMC2              NONE          100           2.0 (6.79)

Server /chassis #
```

## Viewing LED Details

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>show led</b>	Displays the LED details at the chassis level.

### Example

This example the LED details at the chassis level:

```
Server# scope chassis
Server /chassis # show led
LED Name      LED State  LED Color
-----
CHS_FP_LED_ID  FAST BLINK BLUE
LED_HLTH_STATUS  ON         GREEN
LED_PSU_STATUS  ON         GREEN
LED_TEMP_STATUS  ON         GREEN
LED_FAN_STATUS  ON         GREEN
SERVER1_FP_ID_LED  OFF        BLUE
SERVER2_FP_ID_LED  OFF        BLUE
OVERALL_DIMM_STATUS  ON         GREEN

Server /chassis #
```

## Viewing the Details of the Servers on the Chassis

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>show server</b>	Displays the high level details of the servers on the chassis.

### Example

This example displays the high level details of the servers on the chassis:

```
Server# scope chassis
Server /chassis # show server
Server ID Power Serial Number Product Name PID          UUID
-----
-----
1          on    FCH1848794D  UCS C3160      UCSC-C3X60-SVRNB
60974271-A514-484C-BAE3-A5EE4FD16E06
2          on    FCH183978RD  UCS C3160      UCSC-C3X60-SVRNB
207BD0D4-C589-40C1-A73E-EF6E7F773198

Server /chassis #
```

## Viewing Physical Drive Properties

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope dynamic-storage</b>	Enters the dynamic storage command mode.
<b>Step 3</b>	Server /chassis/dynamic-storage # <b>scope physical-drive drive number</b>	Enters the physical drive command mode.
<b>Step 4</b>	Server /chassis/dynamic-storage/physical-drive # <b>show detail</b>	Displays the details of the physical drive.
<b>Step 5</b>	Server /chassis/dynamic-storage/physical-drive # <b>exit</b>	Exits to the dynamic storage command mode.
<b>Step 6</b>	Server /chassis/dynamic-storage # <b>scope physical-drive-fw drive number</b>	Enters the physical drive firmware command mode.
<b>Step 7</b>	Server /chassis/dynamic-storage/physical-drive-fw # <b>show detail</b>	Displays the firmware details of the physical drive.

	Command or Action	Purpose
<b>Step 8</b>	Server /chassis/dynamic-storage/physical-drive-fw # <b>exit</b>	Exits to the dynamic storage command mode.
<b>Step 9</b>	Server /chassis/dynamic-storage # <b>scope</b> <b>physical-drive-link drive number</b>	Enters the physical drive link command mode.
<b>Step 10</b>	Server /chassis/dynamic-storage/physical-drive-link # <b>show detail</b>	Displays the link details of the physical drive.
<b>Step 11</b>	Server /chassis/dynamic-storage/physical-drive-link # <b>exit</b>	Exits to the dynamic storage command mode.
<b>Step 12</b>	Server /chassis/dynamic-storage # <b>scope</b> <b>physical-slot-owner drive number</b>	Enters the physical slot ownership command mode.
<b>Step 13</b>	Server /chassis/dynamic-storage/physical-slot-owner # <b>show detail</b>	Displays details about which server the physical drive is assigned to.

### Example

This example displays the physical drive properties:

#### Viewing Physical Drive Properties

```
Server# scope chassis
Server /chassis # scope dynamic-storage
Server /chassis/dynamic-storage # scope physical-drive 1
Server /chassis/dynamic-storage/physical-drive # show detail
Slot 1:
  Ownership: server1
  Health: good
  Vendor: TOSHIBA
  Product ID: MG03SCA400
  Product Rev Level: 5702
  Size: 3.63 TB
  Serial Number: 94E0A0T9FVU4
svbu-huu-sanity-col2-1-vcmc /chassis/dynamic-storage/physical-drive #
```

#### Viewing Firmware Details

```
Server /chassis/dynamic-storage/physical-drive # exit
Server /chassis/dynamic-storage # scope physical-drive-fw 1
Server /chassis/dynamic-storage/physical-drive-fw # show detail

Slot 1:
  Vendor: TOSHIBA
  Product ID: MG03SCA400
  Current_FW: 5702
  Update Stage: NONE
  Update Progress: 0
Server /chassis/dynamic-storage/physical-drive-fw #
```

#### Viewing Link Details

```
Server /chassis/dynamic-storage/physical-drive # exit
Server /chassis/dynamic-storage # scope physical-drive-link 1
```

```

Server /chassis/dynamic-storage/physical-drive-link # show detail
Slot 1:
  Ownership: server1
  EX1 Link: 6.0 Gb
  EX2 Link: 6.0 Gb
  SAS Address 1: 50000395c8d2a1fe
  SAS Address 2: 50000395c8d2a1ff
Server /chassis/dynamic-storage/physical-drive-link #
Viewing the slot ownership
Server /chassis/dynamic-storage/physical-drive-link # exit
Server /chassis/dynamic-storage # scope physical-slot-owner 1
Server /chassis/dynamic-storage/physical-drive-link # show detailSlot 1:
  Ownership: server1
Server /chassis/dynamic-storage/physical-slot-owner #
    
```

## Viewing Cisco VIC Adapter Properties

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>show adapter</b>	Displays the high level details of the servers on the chassis.
<b>Step 3</b>	Server /chassis # <b>show adapter detail</b>	Displays the high level details of the servers on the chassis.

### Example

This example displays the high level details of the Cisco Virtual Interface Card properties:

```

Server# scope chassis
Server /chassis # show adapter
Server ID Power Serial Number Product Name PID UID
-----
1 on FCH1848794D UCS S3260M4 UCSC-C3X60-SVRNB
60974271-A514-484C-BAE3-A5EE4FD16E06
2 on FCH183978RD UCS S3260M4 UCSC-C3X60-SVRNB
207BD0D4-C589-40C1-A73E-EF6E7F773198
Server /chassis # show adapter detail
SIOC Slot 1:
  Product Name: UCSS-S3260-SIOC
  Serial Number: FCH18467P0U
  Product ID: UCSC-C3260-SIOC
  Adapter Hardware Revision:
  Current FW Version: 4.0(300.76)
  VNTAG: Disabled
  FIP: Enabled
  LLDP: Enabled
  Configuration Pending: no
  Cisco IMC Management Enabled: yes
  VID: V00
    
```

```

Vendor: Cisco Systems Inc
Description:
Bootloader Version: 4.0(300.76)
FW Image 1 Version: 4.0(300.76)
FW Image 1 State: RUNNING ACTIVATED
FW Image 2 Version: 4.0(300.71)
FW Image 2 State: BACKUP INACTIVATED
FW Update Status: Idle
FW Update Error: No error
FW Update Stage: No operation (0%)
FW Update Overall Progress: 0%
SIOC Slot 2:
Product Name: UCSS-S3260-SIOC
Serial Number: FCH18467P16
Product ID: UCSC-C3260-SIOC
Adapter Hardware Revision:
Current FW Version: 4.0(300.61)
VNTAG: Disabled
FIP: Enabled
LLDP: Enabled
Configuration Pending: no
Cisco IMC Management Enabled: yes
VID: V00
Vendor: Cisco Systems Inc
Description:
Bootloader Version: 4.0(300.61)
FW Image 1 Version: 4.0(300.61)
FW Image 1 State: RUNNING ACTIVATED
FW Image 2 Version: 4.0(300.51)
FW Image 2 State: BACKUP INACTIVATED
FW Update Status: Idle
FW Update Error: No error
FW Update Stage: No operation (0%)
FW Update Overall Progress: 0%
Server /chassis #

```

## Viewing Power Supply Properties

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>show psu</b>	Displays the properties of each power supply on the chassis.
<b>Step 3</b>	Server /chassis # <b>show psu detail</b>	Displays the properties of each power supply on the chassis.

### Example

This example displays the properties of each power supply on the chassis:

```

Server# scope chassis
Server /chassis # show psu
Name          In. Power (Watts)  Out. Power (Watts)  Firmware  Status  Product ID

```



```

-----
PSU1      101                79                10062012 Present UCSC-PSU1-1050W
PSU2      89                 73                10062012 Present UCSC-PSU1-1050W
PSU3      96                 79                10062012 Present UCSC-PSU1-1050W
PSU4      92                 82                10062012 Present UCSC-PSU1-1050W
Server /chassis # show psu detail
Name PSU1:
  In. Power (Watts): 100
  Out. Power (Watts): 77
  Firmware : 10062012
  Status : Present
  Product ID : UCSC-PSU1-1050W
Name PSU2:
  In. Power (Watts): 89
  Out. Power (Watts): 75
  Firmware : 10062012
  Status : Present
  Product ID : UCSC-PSU1-1050W
Name PSU3:
  In. Power (Watts): 96
  Out. Power (Watts): 81
  Firmware : 10062012
  Status : Present
  Product ID : UCSC-PSU1-1050W
Name PSU4:
  In. Power (Watts): 91
  Out. Power (Watts): 77
  Firmware : 10062012
  Status : Present
  Product ID : UCSC-PSU1-1050W

Server /chassis #
    
```

# Chassis Management Tasks

## toggling the Front Locator LED for the Chassis

### Before you begin

You must log in with user or admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>set front-locator-led {on   off}</b>	Enables or disables the chassis locator LED.
<b>Step 3</b>	Server /chassis # <b>commit</b>	Commits the transaction to the system configuration.

**Example**

This example disables the chassis locator LED and commits the transaction:

```
Server# scope chassis
Server /chassis # set front-locator-led off
Server /chassis *# commit

Server /chassis #
```

# Updating Firmware on Server Components



**Important** If any firmware or BIOS updates are in progress, do not reset the server until those tasks are complete.

**Before you begin**

You must log in with user or admin privileges to perform this task.  
 Server must be powered off.

**Procedure**

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope firmware</b>	Enters firmware command mode.
<b>Step 3</b>	Server /chassis/firmware # <b>show detail</b>	Displays the firmware update required on some components message.
<b>Step 4</b>	Server /chassis/firmware # <b>update-all</b>	Updates the firmware on the server components.

**Example**

This example resets the server:

```
Server# scope chassis
Server /chassis # scope firmware
Server /chassis / firmware # show detail

Firmware update required on some components,
please run update-all (under chassis/firmware scope).

Server /chassis / firmware # update-all
```

# Time Zone

## Selecting a Time Zone

Selecting a time zone helps you choose a local time zone so that you can view the local time rather than the default machine time. Cisco IMC Web UI and the CLI provide you options to choose and set a time zone of your choice.

Setting the time zone to your local time will apply the time zone variable to all the services that utilize the system timing. This impacts the logging information and is utilized in the following applications of the Cisco IMC:

- Fault summary and fault history logs
- Cisco IMC log
- rsyslog

When you set a local time, the timestamp on the applications that you can view are updated with the local time that you have chosen.

## Setting a Time Zone

### Before you begin

You must log in with user or admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope time</b>	Enters time command mode.
<b>Step 2</b>	Server /time # <b>timezone-select</b>	Displays a list of continents and oceans.
<b>Step 3</b>	Enter the number corresponding to your continent or ocean.	A list of all the countries or regions of the chosen continent or ocean displays.
<b>Step 4</b>	Enter the number corresponding to the country or region that you want to set as your time zone.	If a country or a region has more than one time zones, a list of time zones in that country or region displays.
<b>Step 5</b>	Enter the number corresponding to time zone.	<b>Is the above information OK?</b> message appears.
<b>Step 6</b>	Enter <b>1</b> .	<b>Continue?[y N]:</b> prompt appears.
<b>Step 7</b>	Enter <b>y</b> if you want to set the chosen time zone.	The chosen time zone is set as the time zone for your Cisco IMC server.

### Example

This example sets the time zone:

```
Server# scope time
Server /time # timezone-select
```

```
Please identify a location so that time zone rules can be set correctly.
Please select a continent or ocean.
```

- 1) Africa
- 2) Americas
- 3) Antarctica
- 4) Arctic Ocean
- 5) Asia
- 6) Atlantic Ocean
- 7) Australia
- 8) Europe
- 9) Indian Ocean
- 10) Pacific Ocean

```
#? 2
```

```
Please select a country whose clocks agree with yours.
```

- 1) Anguilla
- 2) Antigua & Barbuda
- 3) Argentina
- 4) Aruba
- 5) Bahamas
- 6) Barbados
- 7) Belize
- 8) Bolivia
- 9) Brazil
- 10) Canada
- 11) Caribbean Netherlands
- 12) Cayman Islands
- 13) Chile
- 14) Colombia
- 15) Costa Rica
- 16) Cuba
- 17) Curacao
- 18) Dominica
- 19) Dominican Republic
- 20) Ecuador
- 21) El Salvador
- 22) French Guiana
- 23) Greenland
- 24) Grenada
- 25) Guadeloupe
- 26) Guatemala
- 27) Guyana
- 28) Haiti
- 29) Honduras
- 30) Jamaica
- 31) Martinique
- 32) Mexico
- 33) Montserrat
- 34) Nicaragua
- 35) Panama
- 36) Paraguay
- 37) Peru
- 38) Puerto Rico
- 39) St Barthelemy
- 40) St Kitts & Nevis
- 41) St Lucia
- 42) St Maarten (Dutch part)
- 43) St Martin (French part)
- 44) St Pierre & Miquelon
- 45) St Vincent
- 46) Suriname
- 47) Trinidad & Tobago

```
48) Turks & Caicos Is
49) United States
50) Uruguay
51) Venezuela
52) Virgin Islands (UK)
53) Virgin Islands (US)
#? 49
Please select one of the following time zone regions.
1) Eastern Time
2) Eastern Time - Michigan - most locations
3) Eastern Time - Kentucky - Louisville area
4) Eastern Time - Kentucky - Wayne County
5) Eastern Time - Indiana - most locations
6) Eastern Time - Indiana - Daviess, Dubois, Knox & Martin Counties
7) Eastern Time - Indiana - Pulaski County
8) Eastern Time - Indiana - Crawford County
9) Eastern Time - Indiana - Pike County
10) Eastern Time - Indiana - Switzerland County
11) Central Time
12) Central Time - Indiana - Perry County
13) Central Time - Indiana - Starke County
14) Central Time - Michigan - Dickinson, Gogebic, Iron & Menominee Counties
15) Central Time - North Dakota - Oliver County
16) Central Time - North Dakota - Morton County (except Mandan area)
17) Central Time - North Dakota - Mercer County
18) Mountain Time
19) Mountain Time - south Idaho & east Oregon
20) Mountain Standard Time - Arizona (except Navajo)
21) Pacific Time
22) Alaska Time
23) Alaska Time - Alaska panhandle
24) Alaska Time - southeast Alaska panhandle
25) Alaska Time - Alaska panhandle neck
26) Alaska Time - west Alaska
27) Aleutian Islands
28) Metlakatla Time - Annette Island
29) Hawaii
#? 8
```

The following information has been given:

```
United States
Eastern Time - Indiana - Crawford County
```

Is the above information OK?

```
1) Yes
2) No
#? 1
```

You have chosen to set timezone settings to:

```
America/Indiana/Marengo
```

```
Continue?[y|N]: y
Timezone has been updated.
The local time now is: Wed Jul 1 02:21:15 2015 EST
```

```
Server /time #
```

## Single Server Dual Connectivity

On the S3260 storage server with the chassis having a dual VIC and single server hardware configuration, the virtual network interface (vNIC or vHBA) of the virtual interface card in the second SIOC is unused by the server for host network traffic. This second SIOC is only used for Chassis management controller (CMC) redundancy. Effective with this release, the S3260 storage server supports a single server with dual connectivity, which is based on these two factors:

- The PCIe between the server board and the SIOC card is connected using BIOS.
- The CMC controls the correct association of the server ID with the virtual network interfaces it creates.

This feature allows you to configure a new single server dual VIC chassis property on the Cisco IMC by enabling it or disabling it using the web UI or command line interface.

Based on the Cisco IMC hardware configuration, a specific PCI connectivity is enabled on the VIC. The CMC uses the single server dual VIC property along with the current chassis hardware configuration to identify the server ID property to be specified when you create a virtual network interface in either of the dual SIOC VICs. The VIC configuration page on the web UI displays the read-only attribute of the Server ID to which the VIC is PCIe linked, and this is used by the host server for the virtual network interface traffic.

## Configuring Single Server Dual SIOC Connectivity

### Before you begin

- You must log in with admin privileges to perform this task.
- The chassis must have a single server and two VIC adapters (SIOC).

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>server-sioc-connectivity</b>	Enter <b>y</b> at the confirmation prompt. Configures the server SIOC Connectivity of the chassis to single server dual SIOC.  <b>Note</b> This operation will reset the VIC adapter 2 to factory default configuration as part of these changes.
<b>Step 3</b>	Server /chassis # <b>show detail</b>	Displays the chassis details that has the server SIOC connectivity status.

### Example

The following example shows how to configuring single server dual SIOC connectivity:

```
Server # scope chassis
Server /chassis # server-sioc-connectivity
```

```
Do you want to configure Server SIOC Connectivity of the chassis to Single Server Dual SIOC?[y|N]y
```

This operation will reset the VIC Adapter-2 to factory default configuration as part of these changes.

Please take backup of VIC Adapter-2 configuration before proceeding with the operation. All your VIC Adapter-2 configuration will be lost.

```
Continue?[y|N]y
```

The VIC Adapter-2 factory default has been successfully restored. Please reboot the Server-1 Host.

The Chassis Server SIOC Connectivity successfully configured to Single Server Dual SIOC.

```
Server /chassis # show detail
```

```
Chassis:
```

```
Serial Number: FCH1819JUVM
Product Name: UCS S3260
PID : UCSS-S3260-BASE
Front Panel Locator LED: off
Description: Test Label22
Asset Tag: TESTTAG11
CMC-1 State: Active
CMC-2 State: Standby
```

```
Server SIOC Connectivity: Single_Server_Dual_SIOC
```

**When the server connectivity is set as Single Server Dual SIOC and if you want to change that to single server single SIOC:**

```
Server /chassis # server-sioc-connectivity
```

The Server SIOC Connectivity of the chassis is currently configured as Single Server Dual SIOC.

```
Do you want to configure Server SIOC Connectivity of the chassis to Single Server Single SIOC?[y|N]y
```

This operation will reset the VIC Adapter-2 to factory default configuration as part of these changes.

Please take backup of VIC Adapter-2 configuration before proceeding with the operation. All your VIC Adapter-2 configuration will be lost.

```
Continue?[y|N]y
```

The VIC Adapter-2 factory default has been successfully restored. Please reboot the Server-1 Host.

The Chassis Server SIOC Connectivity successfully configured to Single Server Single SIOC.

```
Server /chassis # show detail
```

```
Chassis:
```

```
Serial Number: FCH1819JUVM
Product Name: UCS S3260
PID : UCSS-S3260-BASE
Front Panel Locator LED: off
Description: Test Label22
Asset Tag: TESTTAG11
CMC-1 State: Active
CMC-2 State: Standby
```

```
Server SIOC Connectivity: Single_Server_Single_SIOC
```

```
Server /chassis #
```

# Managing Dynamic Storage

## Dynamic Storage Support

Effective with this release, The Cisco UCS C-Series rack-mount servers support dynamic storage of Serial Attached SCSI (SAS) drives in the Cisco Management Controller (CMC). This dynamic storage support is provided by the SAS fabric manager located in the CMC.

The fabric manager interacts with the PMC SAS expanders over an Out-of-Band ethernet connection. SAS Expanders allow you to maximize the storage capability of an SAS controller card. Using these expanders, you can employ SAS controllers support up to 60 hard drives. In CMC, an active SIOC configures the expander zoning, where you can assign the drives to the server nodes through the Web UI, command line interface or Cisco UCS Manager. The standby CMC is updated with the current state, so during a CMC fail-over standby, the CMC can take over the zoning responsibilities. Once the drives are visible to a particular server node, you can manage these using RAID controller.



### Note

The SAS controller support 56 hard disk drives (HDD) by default. There is also a provision to to replace Server node 2 with an additional four HDDs on Server 2. In that case the total number of HDDs shown in the Zoning page is 60. However, CMC would not support zoning for the additional HDDs 57, 58, 59, 60.

The SAS fabric manager provides an API library for other processes to configure and monitor the expanders and drives. Configuration of the fabric involves zoning the drives, updating the firmware for expanders and drives.

Dynamic Storage supports the following options:

- Assigning physical disks to server 1 and server 2
- Chassis Wide Hot Spare (supported only on RAID controllers)
- Shared mode (supported only in HBAs)
- Unassigning physical disks

## Viewing SAS Expander Properties

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>show sas-expander</b>	Displays the SAS expander properties.
<b>Step 3</b>	Server /chassis # <b>show sas-expander detail</b>	Displays detailed SAS expander properties.
<b>Step 4</b>	Server /chassis # <b>scope sas-expander sas expander ID</b>	Enters SAS expander mode.



	Command or Action	Purpose
<b>Step 5</b>	Server /chassis/sas-expander # <b>show detail</b>	Displays the properties of the chosen SAS expander.

**Example**

This example displays the SAS expander properties:

```

Server# scope chassis
Server /chassis # show sas-expander
ID      Name      Update Stage Update Progress Current FW Version
-----
1       SASEXP1    NONE         100           04.08.01_B055
2       SASEXP2    NONE         100           04.08.01_B055

Server /chassis # show sas-expander detail
Firmware Image Information:
  ID: 1
  Name: SASEXP1
  Update Stage: NONE
  Update Progress: 100
  Current FW Version: 04.08.01_B056
  FW Image 1 Version: 04.08.01_B056
  FW Image 1 State: RUNNING ACTIVATED
  FW Image 2 Version: 04.08.01_B056
  FW Image 2 State: BACKUP INACTIVATED
Firmware Image Information:
  ID: 2
  Name: SASEXP2
  Update Stage: NONE
  Update Progress: 100
  Current FW Version: 04.08.01_B056
  FW Image 1 Version: 04.08.01_B056
  FW Image 1 State: RUNNING ACTIVATED
  FW Image 2 Version: 04.08.01_B056
  FW Image 2 State: BACKUP INACTIVATED

Server /chassis # scope sas-expander 1
Server /chassis/sas-expander # show detail
Firmware Image Information:
  ID: 1
  Name: SASEXP1
  Update Stage: NONE
  Update Progress: 100
  Current FW Version: 04.08.01_B056
  FW Image 1 Version: 04.08.01_B056
  FW Image 1 State: RUNNING ACTIVATED
  FW Image 2 Version: 04.08.01_B056
  FW Image 2 State: BACKUP INACTIVATED

Server /chassis/sas-expander #
    
```

# Viewing Dynamic Storage and Physical Drive Details

**Procedure**

	<b>Command or Action</b>	<b>Purpose</b>
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>show dynamic-storage</b>	Displays the physical drives and the servers they are assigned to.
<b>Step 3</b>	Server /chassis/dynamic-storage # <b>scope dynamic-storage</b>	Enters dynamic storage command mode.
<b>Step 4</b>	Server /chassis/dynamic-storage # <b>show physical-drive</b>	Displays the physical drive properties.
<b>Step 5</b>	Server /chassis/dynamic-storage # <b>show physical-drive-fw</b>	Displays the firmware of the physical drives.
<b>Step 6</b>	Server /chassis/dynamic-storage # <b>show physical-drive-link</b>	Displays the links of the physical drives.
<b>Step 7</b>	Server /chassis/dynamic-storage # <b>show physical-slot-owner</b>	Displays the physical drives association with the servers.

**Example**

This example displays the dynamic storage properties:

```

Server# scope chassis
Server /chassis # show dynamic-storage
Slot  Ownership
-----
1      server1
2      server1
3      server1
4      server1
5      server1
6      server1
7      server1
8      server1
9      server1
.
.
.
Server /chassis # scope dynamic-storage
Server /chassis/dynamic-storage # show detail
Slot 1:
  Ownership: server1
Slot 2:
  Ownership: server1
Slot 3:
  Ownership: server1
Slot 4:
  Ownership: server1
Slot 5:
  Ownership: server1
    
```

```
Slot 6:
  Ownership: server1
Slot 7:
  Ownership: server1
Slot 8:
.
.
.
```

```
Server /chassis/dynamic-storage # show physical-drive
```

Slot	Ownership	Health	Vendor	Product ID	Size	Serial Number
1	server1	good	TOSHIBA	MG03SCA400	3.63 TB	94E0A0T9FVU4
2	server1	good	TOSHIBA	MG03SCA400	3.63 TB	94D0A0F7FVU4
3	server1	good	TOSHIBA	MG03SCA400	3.63 TB	94B0A12YFVU4
4	server1	good	TOSHIBA	MG03SCA400	3.63 TB	94B0A131FVU4
5	server1	good	TOSHIBA	MG03SCA400	3.63 TB	94C0A0I9FVU4
6	server1	good	TOSHIBA	MG03SCA400	3.63 TB	94B0A12ZFVU4
7	server1	good	TOSHIBA	MG03SCA400	3.63 TB	94B0A02AFVU4
8	server1	good	TOSHIBA	MG03SCA400	3.63 TB	94B0A00LFVU4
9	server1	good	TOSHIBA	MG03SCA400	3.63 TB	94B0A00WFVU4
10	server1	good	TOSHIBA	MG03SCA400	3.63 TB	94B0A00QFVU4
11	server1	good	TOSHIBA	MG03SCA400	3.63 TB	94B0A00MFVU4
12	server1	good	TOSHIBA	MG03SCA400	3.63 TB	94B0A00NFVU4
13	server1	good	TOSHIBA	MG03SCA400	3.63 TB	94B0A130FVU4
14	server1	good	TOSHIBA	MG03SCA400	3.63 TB	94B0A000FVU4

```
Server /chassis/dynamic-storage # show physical-drive-fw
```

Slot	Vendor	Product ID	Current_FW	Update Stage	Update Progress
1	TOSHIBA	MG03SCA400	5702	NONE	0
2	TOSHIBA	MG03SCA400	5702	NONE	0
3	TOSHIBA	MG03SCA400	5702	NONE	0
4	TOSHIBA	MG03SCA400	5702	NONE	0
5	TOSHIBA	MG03SCA400	5702	NONE	0
6	TOSHIBA	MG03SCA400	5702	NONE	0
7	TOSHIBA	MG03SCA400	5702	NONE	0
8	TOSHIBA	MG03SCA400	5702	NONE	0
9	TOSHIBA	MG03SCA400	5702	NONE	0
10	TOSHIBA	MG03SCA400	5702	NONE	0
11	TOSHIBA	MG03SCA400	5702	NONE	0
12	TOSHIBA	MG03SCA400	5702	NONE	0
13	TOSHIBA	MG03SCA400	5702	NONE	0
14	TOSHIBA	MG03SCA400	5702	NONE	0

```
Server /chassis/dynamic-storage # show physical-drive-link
```

Slot	Ownership	EX1 Link	EX2 Link	SAS Address 1	SAS Address 2
1	server1	6.0 Gb	6.0 Gb	50000395c8d2a1fe	50000395c8d2a1ff
2	server1	6.0 Gb	6.0 Gb	50000395c8d1f6de	50000395c8d1f6df
3	server1	6.0 Gb	6.0 Gb	50000395c8d0e93a	50000395c8d0e93b
4	server1	6.0 Gb	6.0 Gb	50000395c8d0e946	50000395c8d0e947
5	server1	6.0 Gb	6.0 Gb	50000395c8d17d2e	50000395c8d17d2f
6	server1	6.0 Gb	6.0 Gb	50000395c8d0e93e	50000395c8d0e93f
7	server1	6.0 Gb	6.0 Gb	50000395c8d09ace	50000395c8d09acf
8	server1	6.0 Gb	6.0 Gb	50000395c8d099ce	50000395c8d099cf
9	server1	6.0 Gb	6.0 Gb	50000395c8d099fa	50000395c8d099fb
10	server1	6.0 Gb	6.0 Gb	50000395c8d099e2	50000395c8d099e3
11	server1	6.0 Gb	6.0 Gb	50000395c8d099d2	50000395c8d099d3
12	server1	6.0 Gb	6.0 Gb	50000395c8d099d6	50000395c8d099d7
13	server1	6.0 Gb	6.0 Gb	50000395c8d0e942	50000395c8d0e943
14	server1	6.0 Gb	6.0 Gb	50000395c8d099da	50000395c8d099db

```

Server /chassis/dynamic-storage show physical-slot-owner
Slot  Ownership
-----
1     server1
2     server1
3     server1
4     server1
5     hotspare
6     server1
7     server1
8     server1
9     server1
10    server1
.
.
.
Server /chassis/dynamic-storage #

```

## Enabling 6G or 12G Mixed Mode Speed on SAS Expanders

Cisco IMC supports mixed mode speeds of 6 gigabytes or 12 gigabytes for SAS expanders. This support is added because 6 gigabyte solid state drives (SSDs) are now giving way to 12 gigabyte SSDs. Using this feature you can select a SAS expander in the Dynamic Storage tab and enable either modes based on your requirements.

### Enabling 6G or 12G Mixed Mode on a SAS Expander

This action is available only on some servers.

#### Before you begin

You must log in with admin privileges to perform this task.

#### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope sas-expander sas-expander ID</b>	Enters the SAS expander command mode.
<b>Step 3</b>	Server /chassis/sas-expander # <b>scope 6G-12G-Mixed-Mode-status</b>	Enters the 6G or 12G mixed mode command mode.
<b>Step 4</b>	Server /chassis/sas-expander/6G-12G-Mixed-Mode-status # <b>set set-6G-12G-mixed-mode Enabled</b>	Enables the 6G or 12G mixed mode on the SAS expander.
<b>Step 5</b>	Server /chassis/sas-expander/6G-12G-Mixed-Mode-status * # <b>commit</b>	Enter <b>y</b> at the confirmation prompt. Commits the transaction to the system configuration.
<b>Step 6</b>	(Optional) Server /chassis/sas-expander/6G-12G-Mixed-Mode-status # <b>show detail</b>	Displays the 6G or 12G mixed mode status.

### Example

This example shows how to enable the 6G or 12G mixed mode on the SAS expander:

```
Server# scope chassis
Server /chassis # scope sas-expander 1
Server /chassis/sas-expander # scope 6G-12G-Mixed-Mode-status
Server /chassis/sas-expander/6G-12G-Mixed-Mode-status # set set-6G-12G-mixed-mode Enabled
Server /chassis/sas-expander/6G-12G-Mixed-Mode-status *# commit
Are you sure you want to change the enable-mixed-mode setting to Enable mode?[y|N]y
Setting enable-mixed-mode setting to Enable ..
Successfully set enable-6G-12G-mixed-mode to Enable..
Server /chassis/sas-expander/6G-12G-Mixed-Mode-status # show detail
6G/12G Mixed Mode Settings:
    Mixed 6G/12G Drive Support: Enabled
Server /chassis/sas-expander/6G-12G-Mixed-Mode-status #
```

## Managing Physical Drives

### Assigning Physical Drives to Servers

#### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis/dynamic-storage # <b>scope dynamic-storage</b>	Enters dynamic storage command mode.
<b>Step 3</b>	Server /chassis/dynamic-storage # <b>assign-drive</b> <server1   server2   shared   hotspare> [SBMezz1   IOEMezz1   SBMezz2] [PATH_BOTH   PATH_0   PATH_1] <drive-slotid-list>	Enter <b>yes</b> at the confirmation prompt, this assigns the chosen physical drive to the server.

### Example

Example for assigning a physical drive to the servers:

```
Server# scope chassis
Server /chassis # scope dynamic-storage
Server /chassis/dynamic-storage # assign-drive server2 SBMezz1 PATH_0 15
Are you sure you want to assign drives 15 to server1-SBMezz1 using PATH_0?
Enter 'yes' to confirm -> yes
assign-drive operation successful.
Server /chassis/dynamic-storage #
```

## Unassigning Physical Drives to Servers

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>show dynamic-storage</b>	Displays the physical drives and the servers they are assigned to servers.
<b>Step 3</b>	Server /chassis/dynamic-storage # <b>scope dynamic-storage</b>	Enters dynamic storage command mode.
<b>Step 4</b>	Server /chassis/dynamic-storage # <b>unassign-drive &lt;drive-slotid-list&gt;</b>	Unassign the chosen physical drive.

### Example

This example unassigning a physical drive:

```
Server# scope chassis
Server /chassis # scope dynamic-storage
Server /chassis/dynamic-storage # unassign-drive 27
Are you sure you want to unassign drives 27
Host will loose access to drive(s). Enter 'yes' to confirm -> yes
unassign-drive operation successful.

Server /chassis/dynamic-storage #
```

## Assigning Physical Drives as Chassis Wide Hot Spare

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis/dynamic-storage # <b>scope dynamic-storage</b>	Enters dynamic storage command mode.
<b>Step 3</b>	Server /chassis/dynamic-storage # <b>assign-drive hotspare &lt;drive-slotid-list&gt;</b>	Assigns the physical drive as a global hotspare at the chassis level.

### Example

Example for assigning a physical drive as a global hotspare at the chassis level:

```
Server# scope chassis
Server /chassis # scope dynamic-storage
Server /chassis/dynamic-storage # assign-drive hotspare 5
Are you sure you want to assign drives 5 as hotspare
Enter 'yes' to confirm -> yes
```

```
assign-drive operation successful.

Server /chassis/dynamic-storage #
```

## Sharing Physical Drives with Servers

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis/dynamic-storage # <b>scope dynamic-storage</b>	Enters dynamic storage command mode.
<b>Step 3</b>	Server /chassis/dynamic-storage # <b>assign-drive shared &lt;drive-slotid-list&gt;</b>	Assigns the chosen physical drive for both the servers.

### Example

Example for assigning the same physical drive for both the servers:

```
Server# scope chassis
Server /chassis # scope dynamic-storage
svbu-huu-sanity-col2-1-vcmc /chassis/dynamic-storage # assign-drive shared 4
Are you sure you want to assign drives 4 as shared
Enter 'yes' to confirm -> yes
assign-drive operation successful.

Server /chassis/dynamic-storage #
```







## CHAPTER 4

# Managing the Server

This chapter includes the following sections:

- [Toggling the Server Locator LED, on page 39](#)
- [Toggling the Locator LED for a Hard Drive, on page 40](#)
- [Managing the Server Boot Order, on page 41](#)
- [Managing Server Power, on page 53](#)
- [Resetting the Server, on page 68](#)
- [Shutting Down the Server , on page 69](#)
- [Configuring DIMM Black Listing, on page 70](#)
- [Configuring BIOS Settings, on page 71](#)
- [Viewing Product ID \(PID\) Catalog Details, on page 79](#)
- [Uploading and Activating PID Catalog, on page 81](#)
- [Deleting PID Catalog, on page 83](#)
- [Persistent Memory Module, on page 84](#)

## Toggling the Server Locator LED

### Before you begin

You must log in with user or admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server server ID</b>	Enters server command mode.
<b>Step 2</b>	Server /server # <b>set locator-led {on   off}</b>	Enables or disables the server locator LED.
<b>Step 3</b>	Server /server # <b>commit</b>	Commits the transaction to the system configuration.

### Example

This example disables the server locator LED and commits the transaction:

```

Server# scope server 1
Server /server # set locator-led off
Server /server *# commit

Server /server #

```

## Toggling the Locator LED for a Hard Drive

### Before you begin

You must log in with user or admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /server # <b>scope sensor</b>	Enters sensor command.
<b>Step 3</b>	Server /server/sensor # <b>scope hdd</b>	Enters hard disk drive (HDD) command mode.
<b>Step 4</b>	Server /server/sensor/hdd # <b>set locateHDD</b> <i>drivenum</i> {1   2}	Where <i>drivenum</i> is the number of the hard drive whose locator LED you want to set. A value of 1 turns the LED on while a value of 2 turns the LED off.

### Example

This example turns on the locator LED on HDD 2:

```

Server# scope server 1
Server /server # scope sensor
Server /server/sensor # scope hdd
Server /server/sensor/hdd # locateHDD 2 1
HDD Locate LED Status changed to 1
Server /server/sensor/hdd # show
Name                               Status                               LocateLEDStatus
-----
HDD1_STATUS                         present                             TurnOFF
HDD2_STATUS                         present                             TurnON
HDD3_STATUS                         absent                              TurnOFF
HDD4_STATUS                         absent                              TurnOFF

Server /server/sensor/hdd #

```

# Managing the Server Boot Order

## Server Boot Order

Using Cisco IMC, you can configure the order in which the server attempts to boot from available boot device types. In the legacy boot order configuration, Cisco IMC allows you to reorder the device types but not the devices within the device types. With the precision boot order configuration, you can have a linear ordering of the devices. In the web UI or CLI you can change the boot order and boot mode, add multiple devices under each device types, rearrange the boot order, set parameters for each device type.

When you change the boot order configuration, Cisco IMC sends the configured boot order to BIOS the next time that server is rebooted. To implement the new boot order, reboot the server after you make the configuration change. The new boot order takes effect on any subsequent reboot. The configured boot order remains until the configuration is changed again in Cisco IMC or in the BIOS setup.



- 
- Note** The actual boot order differs from the configured boot order if either of the following conditions occur:
- BIOS encounters issues while trying to boot using the configured boot order.
  - A user changes the boot order directly through BIOS.
  - BIOS appends devices that are seen by the host but are not configured from the user.
- 



- 
- Note** When you create a new policy using the configure boot order feature, BIOS tries to map this new policy to the devices in the system. It displays the actual device name and the policy name to which it is mapped in the **Actual Boot Order** area. If BIOS cannot map any device to a particular policy in Cisco IMC, the actual device name is stated as **NonPolicyTarget** in the **Actual Boot Order** area.
- 



- 
- Note** During Cisco IMC 2.0(x) upgrade, the legacy boot order is migrated to the precision boot order. The previous boot order configuration is erased and all device types configured before updating to 2.0 version are converted to corresponding precision boot device types and some dummy devices are created for the same device types. you can view these devices in the **Configured Boot Order** area in the web UI. To view these devices in the CLI, enter **show boot-device** command. During this the server's actual boot order is retained and it can be viewed under actual boot order option in web UI and CLI.
- 

When you downgrade Cisco IMC prior to 2.0(x) version the server's last legacy boot order is retained, and the same can be viewed under **Actual Boot Order** area. For example:

- If you configured the server in a legacy boot order in 2.0(x) version, upon downgrade a legacy boot order configuration is retained.
- If you configured the server in a precision boot order in 2.0(x), upon downgrade the last configured legacy boot order is retained.

**Important**

- S3260 M4 servers support both Legacy and Precision Boot order configuration through Cisco IMC GUI and CLI interfaces.

For S3260 M5 servers, you must manually configure the intended boot order through Cisco IMC GUI or CLI interfaces.

- Boot order configuration prior to 2.0(x) is referred as legacy boot order. If your running version is 2.0(x), then you cannot configure legacy boot order through web UI, but you can configure through CLI and XML API. In the CLI, you can configure it by using **set boot-order HDD,PXE** command. Even though, you can configure legacy boot order through CLI or XML API, in the web UI this configured boot order is not displayed.
- Legacy and precision boot order features are mutually exclusive. You can configure either legacy or precision boot order. If you configure legacy boot order, it disables all the precision boot devices configured. If you configure precision boot order, then it erases legacy boot order configuration.

## Viewing the Boot Device Detail

**Note**

Do not change the boot order while the host is performing BIOS power-on self test (POST).

### Before you begin

You must log in with user or admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /server# <b>scope bios</b>	Enters BIOS command mode.
<b>Step 3</b>	Server /serve/bios # <b>show boot-device [detail]</b> .	Displays the detailed information of the boot devices.

### Example

This example displays the details of the created bootable devices:

```
Server# scope server 1
Server /server # scope bios
Server /server/bios # show boot-device
Boot Device          Device Type  Device State  Device Order
-----
TestUSB              USB         Enabled      1
TestPXE              PXE         Enabled      2
Server /server/bios # show boot-device detail
Boot Device TestSAN:
```

```

Device Type: SAN
Device State: Enabled
Device Order: 1
Slot Id:
Lun Id:
Boot Device TestUSB:
Device Type: USB
Device State: Enabled
Device Order: 2
Sub Type: HDD
Boot Device TestPXE:
Device Type: PXE
Device State: Enabled
Device Order: 3
Slot Id: L
Port Number: 1

```

## Configuring the Precision Boot Order



**Note** Do not change the boot order while the host is performing BIOS power-on self test (POST).

### Before you begin

You must log in with user or admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /server# <b>scope bios</b>	Enters BIOS command mode.
<b>Step 3</b>	Server /server/bios # <b>create-boot-device</b> [ <i>device name</i> ] [ <i>device type</i> ].	Creates a bootable device that BIOS chooses to boot. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>HDD</b>—Hard disk drive</li> <li>• <b>PXE</b>—PXE boot</li> <li>• <b>SAN</b> boot</li> <li>• <b>iSCSI</b> boot</li> <li>• <b>USB</b></li> <li>• <b>Virtual Media</b></li> <li>• <b>PCHStorage</b></li> <li>• <b>UEFISHELL</b></li> </ul>
<b>Step 4</b>	Server /server/bios # <b>scope boot-device</b> <i>created boot device name</i> .	Enters the management of the created bootable devices.

	Command or Action	Purpose
<b>Step 5</b>	Server /server/bios/boot-device # <i>set values</i>	<p>Specifies the property values for particular bootable device. You can set one or more of the following:</p> <ul style="list-style-type: none"> <li>• cli— CLI options</li> <li>• state— Whether the device will be visible by BIOS. By default, the device is disabled.</li> </ul> <p><b>Note</b> If enabled, the device will overwrite the legacy boot order configuration.</p> <ul style="list-style-type: none"> <li>• slot— Slot id where the device is plugged in.</li> <li>• port— Port of the slot in which the device is present.</li> <li>• LUN— Logical unit in a slot where the device is present.</li> <li>• sub-type— Sub device type under a certain device type.</li> <li>• order— The order of the device in the available list of devices.</li> </ul>
<b>Step 6</b>	Server /server/bios /boot-device # <b>commit</b>	Commits the transaction to the system configuration.

### Example

This example configures the boot order, creates a PXE boot device, sets the attributes of the new device and commits the transaction:

```
Server# scope server 1
Server /server # scope bios
Server /server/bios # create boot-device TestPXE PXE
Server /server/bios # scope boot-device TestPXE
Server /server/bios /boot-device # set state Enabled
Server /server/bios /boot-device # set slot L
Server /server/bios /boot-device # set port 1
Server /server/server/bios /boot-device # set order 1
Server /bios /boot-device # commit
Enabling boot device will overwrite Legacy Boot Order configuration
Continue?[y|N]y
Server /server/bios /boot-device # y
Committing device configuration
Server /server/bios/boot-device # show detail
BBIOS:
  BIOS Version: server-name.2.0.7c.0.071620151216
  Backup BIOS Version: server-name.2.0.7c.0.071620151216
  Boot Order: (none)
```

```

Boot Override Priority:
FW Update/Recovery Status: None, OK
UEFI Secure Boot: disabled
Configured Boot Mode: Legacy
Actual Boot Mode: Legacy
Last Configured Boot Order Source: CIMC

```

```

Server /server/bios/boot-device # show boot-device detail
Boot Device TestPXE:
  Device Type: PXE
  Device State: Enabled
  Device Order: 1
  Slot Id: L
  Port Number: 1

```

### What to do next

Reboot the server to boot with your new boot order.

## Modifying the Attributes of a Boot Device



**Note** Do not change the boot order while the host is performing BIOS power-on self test (POST).

### Before you begin

You must log in with user or admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /server# <b>scope bios</b>	Enters BIOS command mode.
<b>Step 3</b>	Server /server/bios # <b>scope boot-device</b> <i>created boot device name.</i>	Enters the management of the created bootable devices.
<b>Step 4</b>	Server /server/bios /boot-device # <b>set state</b> { <i>Enabled Disabled</i> }.	Enables or disables the device. The default state is disabled.  <b>Note</b> If enabled, the device will overwrite the legacy boot order configuration.
<b>Step 5</b>	Server /server/bios /boot-device* # <b>set order</b> { <i>Index   1-50</i> }.	Specifies the order of booting for particular device in the device list. Enter a number between 1 and 50 based on the total number of created device.

	Command or Action	Purpose
		<b>Note</b> When you set the boot device order individually, it is not assured that the order appears in the way it was set. So, it is recommended that to set the order for multiple devices in a single execution, use <b>re-arrange-boot-device</b> command.
<b>Step 6</b>	Server /server/bios /boot-device* # <b>set port</b> {value   1-255 }.	Specifies the port of the slot in which the device is present. Enter a number between 1 and 255.
<b>Step 7</b>	Server /server/bios /boot-device* # <b>commit</b>	Commits the transaction to the system configuration.

### Example

This example modifies the attributes of an HDD device:

```
Server# scope server 1
Server /server # scope bios
Server /server/bios *# scope boot-device scu-device-hdd
Server /server/bios/boot-device # set status enabled
Server /server/bios/boot-device *# set order 2
Server /server/bios/boot-device *# set port 1
Server /server/bios/boot-device *# commit
Enabling boot device will overwrite boot order Level 1 configuration
Continue?[y|N]y
Server /server/bios/boot-device #
```

## Rearranging Device Boot Order



**Note** Do not change the boot order while the host is performing BIOS power-on self test (POST).

### Before you begin

You must log in with user or admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /server# <b>scope bios</b>	Enters BIOS command mode.
<b>Step 3</b>	Server /server/bios # <b>rearrange boot-device</b> [device name]:[position].	Rearranges the selected boot devices in a single execution.



### Example

This example rearranges the selected boot devices:

```

Server# scope server 1
Server /server # scope bios
Server /server/bios # rearrange-boot-device TestPXE:1,TestUSB:2
Server /server/bios # show boot-device
-----
Boot Device           Device Type  Device State  Device Order
-----
TestPXE               PXE         Disabled     1
TestUSB               USB         Disabled     2
-----
Server /server/bios #

```

## Reapplying Boot Order Configuration



**Note** Do not change the boot order while the host is performing BIOS power-on self test (POST).

### Before you begin

You must log in with user or admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /server# <b>scope bios</b>	Enters BIOS command mode.
<b>Step 3</b>	Server /server/bios # <b>re-apply</b> .	Re-applies the boot order to BIOS, if the last configured boot order source is BIOS..

### Example

This example reapplies the boot order to BIOS:

```

Server# scope server 1
Server /server # scope bios
Server /server/bios # re-apply
Server /server/bios #

```

### What to do next

Reboot the host after reapplying the boot order to BIOS.

## Deleting an Existing Boot Device



**Note** Do not change the boot order while the host is performing BIOS power-on self test (POST).

### Before you begin

You must log in with user or admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /server# <b>scope bios</b>	Enters BIOS command mode.
<b>Step 3</b>	Server /server/bios # <b>remove-boot-device</b> <i>device name</i>	Deletes the particular device from the boot order.

### Example

This example deletes the selected device from the device list:

```
Server# scope server 1
Server /server # scope bios
Server /server/bios # remove-boot-device scu-device-hdd
Server /server/bios #
```

## Overview to UEFI Secure Boot

You can use Unified Extensible Firmware Interface (UEFI) secure boot to ensure that all the EFI drivers, EFI applications, option ROM or operating systems prior to loading and execution are signed and verified for authenticity and integrity, before you load and execute the operating system. You can enable this option using either web UI or CLI. When you enable UEFI secure boot mode, the boot mode is set to UEFI mode and you cannot modify the configured boot mode until the UEFI boot mode is disabled.



**Note** If you enable UEFI secure boot on a nonsupported OS, on the next reboot, you cannot boot from that particular OS. If you try to boot from the previous OS, an error is reported and recorded the under system software event in the web UI. You must disable the UEFI secure boot option using Cisco IMC to boot from your previous OS.

**Important**

Also, if you use an unsupported adapter, an error log event in Cisco IMC SEL is recorded. The error messages is displayed that says:

System Software event: Post sensor, System Firmware error. EFI Load Image Security Violation. [0x5302] was asserted .

UEFI secure boot is supported on the following components:

Components	Types
<b>Supported OS</b>	<ul style="list-style-type: none"> <li>• Windows Server 2019</li> <li>• Windows Server 2016</li> <li>• ESX 6.7</li> <li>• ESX 6.5</li> <li>• ESXi 7.0</li> <li>• Linux</li> </ul>
<b>QLogic PCI adapters</b>	<ul style="list-style-type: none"> <li>• 8362 dual port adapter</li> <li>• 2672 dual port adapter</li> </ul>
<b>Fusion-io</b>	
<b>LSI</b>	<ul style="list-style-type: none"> <li>• LSI MegaRAID SAS 9240-8i</li> <li>• LSI MegaRAID SAS 9220-8i</li> <li>• LSI MegaRAID SAS 9265CV-8i</li> <li>• LSI MegaRAID SAS 9285CV-8e</li> <li>• LSI MegaRAID SAS 9285CV-8e</li> <li>• LSI MegaRAID SAS 9266-8i</li> <li>• LSI SAS2008-8i mezz</li> <li>• LSI Nytro card</li> <li>• RAID controller for UCS Storage (SLOT-MEZZ)</li> <li>• Host Bus Adapter (HBA)</li> </ul>

## Enabling or Disabling UEFI Secure Boot Mode

### Before you begin

You must be logged in as admin to perform this task.

**Procedure**

	<b>Command or Action</b>	<b>Purpose</b>
<b>Step 1</b>	Server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /server# <b>scope bios</b>	Enters BIOS command mode.
<b>Step 3</b>	Server /server/bios # <b>set secure-boot</b> { <b>enable</b>   <b>disable</b> }	Enables or disables UEFI secure boot.  <b>Note</b> If enabled, the boot mode is set to UEFI secure mode. You cannot modify configure boot mode until UEFI secure boot mode is disabled.
<b>Step 4</b>	(Optional) Server /server/bios # <b>show detail</b>	Displays the details of the BIOS settings.

**Example**

The following examples show how to enable or disable secure boot and commit the transaction:

```

Server# scope server 1
Server /server # scope bios
Server /server/bios # set secure-boot enable
Setting Value : enable
Commit Pending.
Server /server/bios *# commit
UEFI Secure boot state changed successfully. Execute 'show detail' command to check the
current status
Server /server/bios # show detail
BIOS:
  BIOS Version: server-name.2.0.7c.0.071620151216
  Backup BIOS Version: server-name.2.0.8.0.071620152203
  Boot Order: (none)
  Boot Override Priority:
  FW Update/Recovery Status: None, OK
  UEFI Secure Boot: enabled
  Configured Boot Mode: Legacy
  Actual Boot Mode: Legacy
  Last Configured Boot Order Source: CIMC
Server /server/bios #
Server /server/bios #

erver# scope server 1
Server /server # scope bios
Server /server/bios # set secure-boot disable
Setting Value : disable
Commit Pending.
Server /server/bios *# commit
UEFI Secure boot state changed successfully. Execute 'show detail' command to check the
current status
Server /server/bios # show detail
BIOS:
  BIOS Version: server-name.2.0.7c.0.071620151216
  Backup BIOS Version: server-name.2.0.8.0.071620152203
  Boot Order: (none)
  Boot Override Priority:
  FW Update/Recovery Status: None, OK
  UEFI Secure Boot: disabled
  Configured Boot Mode: Legacy

```

```

Actual Boot Mode: Legacy
Last Configured Boot Order Source: CIMC
Server /server/bios #

```

### What to do next

Reboot the server to have your configuration boot mode settings take place.

## Viewing the Actual Server Boot Order

The actual server boot order is the boot order actually used by the BIOS when the server last booted. The actual boot order can differ from the boot order configured in Cisco IMC.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server {1   2}</b>	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /server# <b>scope bios</b>	Enters BIOS command mode.
<b>Step 3</b>	Server /server/bios # <b>show actual-boot-order [detail]</b>	Displays the boot order actually used by the BIOS when the server last booted.

### Example

This example displays the actual boot order of the legacy boot order from the last boot:

```

Server# scope server 1
Server /server # scope bios
Server /server/bios # show actual-boot-order

```

Boot Order	Boot Device	Device Type	Boot Policy
1	Cisco CIMC-Mapped vDVD1.22	VMEDIA	NIHUUCIMCDVD
2	Cisco vKVM-Mapped vDVD1.22	VMEDIA	dvd
3	Cisco vKVM-Mapped vHDD1.22	VMEDIA	dvd2
4	Cisco CIMC-Mapped vHDD1.22	VMEDIA	dvd3
5	(Bus 14 Dev 00)PCI RAID Adapter	HDD	NonPolicyTarget
6	"P1: INTEL SSDSC2BB120G4 "	PCHSTORAGE	NonPolicyTarget
7	"UEFI: Built-in EFI Shell "	EFI	NonPolicyTarget
8	"P0: INTEL SSDSC2BB120G4 "	PCHSTORAGE	NonPolicyTarget
9	Cisco vKVM-Mapped vFDD1.22	VMEDIA	NonPolicyTarge

```

Server /server/bios #

```

## Configuring a Server to Boot With a One-Time Boot Device

You can configure a server to boot from a particular device only for the next server boot, without disrupting the currently configured boot order. Once the server boots from the one time boot device, all its future reboots occur from the previously configured boot order.

**Before you begin**

You must log in with user or admin privileges to perform this task.

**Procedure**

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope bios</b>	Enters the BIOS command mode.
<b>Step 2</b>	Server# /bios <b>show boot-device</b>	Displays the list of available boot drives.
<b>Step 3</b>	Server# /bios <b>set one-time-boot-device device-order</b>	Sets the boot order.  <b>Note</b> The host boots to the one time boot device even when configured with a disabled advanced boot device.
<b>Step 4</b>	Server# /bios * <b>commit</b>	Commits the transaction.
<b>Step 5</b>	(Optional) Server# /bios <b>show detail</b>	Displays the BIOS details.

**Example**

This example shows how to configure a server to boot with a one-time boot device:

```

Server scope bios
Server /bios # show boot-device
Boot Device                Device Type  Device State  Device Order
-----
KVMDVD                     VMEDIA      Enabled       1
vkvm                       VMEDIA      Enabled       2

Server /bios # set one-time-boot-device KVMDVD
Server /bios *# commit
Changes to BIOS set-up parameters will require a reboot.
Do you want to reboot the system?[y|N]n
Changes will be applied on next reboot.
Server /bios # show detail
BIOS:
  BIOS Version: "C240M3.3.0.0.9 (Build Date: 10/02/16)"
  Boot Order: (none)
  FW Update/Recovery Status: None, OK
  UEFI Secure Boot: disabled
  Configured Boot Mode: Legacy
  Actual Boot Mode: Legacy
  Last Configured Boot Order Source: CIMC
  One time boot device: KVMDVD
Server /bios #

```

## Assigning User-defined Server Description and Asset Tag

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>set description</b> <Server Description>	Enters the server description.
<b>Step 3</b>	Server /chassis* # <b>set asset-tag</b> <Asset Tag>	Enters the asset tag.
<b>Step 4</b>	Server /chassis* # <b>commit</b>	Commits the transaction.
<b>Step 5</b>	(Optional) Server /chassis # <b>show detail</b>	Displays the server details.

### Example

This example shows how to assign user-defined server description and asset tag:

```
Server# scope chassis
Server/chassis # set description DN1-server
Server/chassis* # set asset-tag powerpolicy
Server /chassis* # commit
Server /chassis # show detail
Chassis:
  Power: on
  Serial Number: FCH1834V23X
  Product Name: UCS C220 M4S
  PID : UCSC-C220-M4S
  UUID: 414949AC-22D6-4D0D-B0C0-F7950E9217C1
  Locator LED: off
  Description: DN1-server
  Asset Tag: powerpolicy
Server /chassis #
```

## Managing Server Power

### Powering On the Server



#### Note

If the server was powered off other than through the Cisco IMC, the server will not become active immediately when powered on. In this case, the server will enter standby mode until the Cisco IMC completes initialization.



#### Important

If any firmware or BIOS updates are in progress, do not change the server power until those tasks are complete.

**Before you begin**

You must log in with user or admin privileges to perform this task.

**Procedure**

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server {1   2}</b>	Enters server command mode of server 1 or 2.
<b>Step 3</b>	Server /chassis/server # <b>power on</b>	Powers on the server.
<b>Step 4</b>	At the prompt, enter <b>y</b> to confirm.	Power on the server.

**Example**

This example shows how to power on the server:

```
Server# scope chassis
Server# /chassis scope server 1
Server /chassis/server # power on
This operation will change the server's power state.
Do you want to continue with power control for Server 1 ?[y|N] y

Server /chassis/server # show
Server ID Power Serial Number Product Name PID UUID
-----
-----
-----
1          On   FCH1848794D   UCS S3260M4   UCSC-C3X60-SVRNB
60974271-A514-484C-BAE3-A5EE4FD16E06

Server /chassis/server#
```

## Powering Off the Server

**Important**

If any firmware or BIOS updates are in progress, do not change the server power until those tasks are complete.

**Before you begin**

You must log in with user or admin privileges to perform this task.

**Procedure**

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server 1</b>	Enters the server command mode.



	Command or Action	Purpose
<b>Step 3</b>	Server /chassis/server # <b>power off</b>	Powers off the server.
<b>Step 4</b>	At the prompt, enter <b>y</b> to confirm.	Power off the server.

### Example

This example shows how to power off the server:

```
Server# scope chassis
Server# /chassis scope server 1
Server /chassis/server # power off
This operation will change the server's power state.
Do you want to continue with power control for Server 1 ?[y|N] y

Server /chassis/server # show
Server ID Power Serial Number Product Name PID UUID
-----
-----
1 Off FCH1848794D UCS S3260 UCSC-C3X60-SVRNB
60974271-A514-484C-BAE3-A5EE4FD16E06

Server /chassis/server#
```

## Powering Cycling the Server



### Important

If any firmware or BIOS updates are in progress, do not change the server power until those tasks are complete.

### Before you begin

You must log in with user or admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server 1</b>	Enters the server command mode.
<b>Step 3</b>	Server /chassis/server # <b>power cycle</b>	Power off and then powers on the server.
<b>Step 4</b>	At the prompt, enter <b>y</b> to confirm.	Power off and then powers on the server.

### Example

This example shows how to power cycle the server:

```

Server# scope chassis
Server# /chassis scope server 1
Server /chassis/server # power cycle
This operation will change the server's power state.
Do you want to continue with power control for Server 1 ?[y|N] y

Server /chassis/server # show
Server ID Power Serial Number Product Name PID UUID
-----
-----
1 On FCH1848794D UCS S3260 UCSC-C3X60-SVRNB
60974271-A514-484C-BAE3-A5EE4FD16E06

Server /chassis/server#

```

## Configuring the Power Restore Policy

The power restore policy determines how power is restored to the server after a chassis power loss.

### Before you begin

You must log in with admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server /server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	server /server # <b>scope bmc</b>	Enters bmc command mode.
<b>Step 3</b>	Server /server/bmc # <b>scope power-restore-policy</b>	Enters the power restore policy command mode.
<b>Step 4</b>	Server /server/bmc/power-restore-policy # <b>set policy</b> { <b>power-off</b>   <b>power-on</b>   <b>restore-last-state</b> }	<p>Specifies the action to be taken when chassis power is restored. Select one of the following:</p> <ul style="list-style-type: none"> <li>• <b>power-off</b>—Server power will remain off until manually turned on. This is the default action.</li> <li>• <b>power-on</b>—Server power will be turned on when chassis power is restored.</li> <li>• <b>restore-last-state</b>—Server power will return to the state before chassis power was lost.</li> </ul> <p>When the selected action is <b>power-on</b>, you can select a delay in the restoration of power to the server.</p>
<b>Step 5</b>	(Optional) Server /server/bmc/power-restore-policy # <b>set delay</b> { <b>fixed</b>   <b>random</b> }	Specifies whether server power will be restored after a fixed or random time. The default is

	Command or Action	Purpose
		<b>fixed.</b> This command is accepted only if the power restore action is <b>power-on</b> .
<b>Step 6</b>	(Optional) Server /server/bmc/power-restore-policy # <b>set delay-value</b> <i>delay</i>	Specifies the delay time in seconds. The range is 0 to 240; the default is 0.
<b>Step 7</b>	Server /CIMC/power-restore-policy # <b>commit</b>	Commits the transaction to the system configuration.

### Example

This example sets the power restore policy to power-on with a fixed delay of 180 seconds (3 minutes) and commits the transaction:

```
Server# scope server 1
Server /server # scope bmc
Server /server/bmc # Scope power-restore-policy
Server /server/bmc/power-restore-policy # set policy power-on
Server /server/bmc/power-restore-policy *# commit
Server /server/bmc/power-restore-policy # set delay fixed
Server /server/bmc/power-restore-policy *# set delay-value 180
Server /server/bmc/power-restore-policy *# commit
Server /server/bmc/power-restore-policy # show detail
Power Restore Policy:
  Power Restore Policy: power-on
  Power Delay Type: fixed
  Power Delay Value(sec): 180

Server /server/bmc/power-restore-policy #
```

## Power Characterization

The chassis power characterization range is calculated and derived from individual server node power characterization status, and from the power requirements of all the unmanageable components of the chassis.

This range varies for each configuration, so you need to run the power characterization every time a configuration changes.

To help you use the power characterization range appropriately for the different power profiles, the system represents the chassis' minimum power as auto profile minimum and custom profile minimum. However, custom power profile minimum is the actual minimum power requirement of the current chassis configuration. For more information see the section Run Power Characterization.

## Power Profiles

Power capping determines how server power consumption is actively managed. When you enable power capping option, the system monitors power consumption and maintains the power below the allocated power limit. If the server cannot maintain the power limit or cannot bring the platform power back to the specified power limit within the correction time, power capping performs actions that you specify in the Action field under the Power Profile area.

You can configure multiple profiles with the following combinations: automatic and thermal profiles; and custom and thermal profiles. These profiles are configured by using either the web user interface, command line interface, or XML API. In the web UI, the profiles are listed under the Power Capping area. In the CLI, the profiles are configured when you enter the **power-cap-config** command. You can configure the following power profiles for power capping feature:

- Automatic Power Limiting Profile
- Custom Power Limiting Profile
- Thermal Power Limiting Profile

Automatic power limiting profile sets the power limit of the individual server boards based on server priority selected by you, or as detected by the system, based on the server utilization sensor (which is known as manual or dynamic priority selection). The limiting values are calculated within the manageable chassis power budget and applied to the individual server, and the priority server is allocated with its maximum power limiting value, while the other server with the remaining of the manageable power budget. Power limiting occurs at each server board platform level that affects the overall chassis power consumption.

Custom power limiting profile allows you to set an individual server board's power limit from the Web UI or command line interface within the chassis power budget. In this scenario you can specify an individual server power limit.

Thermal power profile allows you to enable thermal failure power capping, which means you can set a specific platform temperature threshold and it sets P (min-x) as the power limit to be applied on the temperature threshold.

## Enabling Chassis Global Power Capping

### Before you begin

You must log in as a user with admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope power-cap-config</b>	Enters power cap configuration command mode.
<b>Step 3</b>	Server /chassis/power-cap-config # <b>set pow-cap-enable {yes   no}</b>	Enables or disables the power configuration.
<b>Step 4</b>	Server /chassis/power-cap-config *# <b>set chassis-budget</b> <i>power limit</i>	Sets the chassis power limit.
<b>Step 5</b>	Server /chassis/power-cap-config *# <b>commit</b>	Commits the transaction to the system.
<b>Step 6</b>	(Optional) Server /chassis/power-cap-config # <b>show detail</b>	Displays the chassis power configuration details.

## Example

The following example shows how to enable chassis global power capping:

```

Server # scope chassis
Server /chassis # scope power-cap-config
Server /chassis/power-cap-config # set pow-cap-enable yes
Server /chassis/power-cap-config *# set chassis-budget 1000
Server /chassis/power-cap-config *# commit
Server /chassis/power-cap-config # show detail
Chassis :
  Power Capping: yes
  Power Characterization Status: Completed
  Chassis Minimum (W): 756
  Chassis Maximum (W): 1089
  Chassis Budget (W): 1000
  Chassis Manageable Power Budget (W): 530
  Auto Balance Minimum Power Budget (W) : 966
Server 1 :
  Power Characterization Status: Completed
  Platform Minimum (W): 163
  Platform Maximum (W): 362
  Memory Minimum (W): 1
  Memory Maximum (W): 0
  CPU Minimum (W): 95
  CPU Maximum (W): 241
Server 2 :
  Power Characterization Status: Completed
  Platform Minimum (W): 136
  Platform Maximum (W): 253
  Memory Minimum (W): 1
  Memory Maximum (W): 0
  CPU Minimum (W): 57
  CPU Maximum (W): 139
Server /chassis/power-cap-config #

```

## Enabling Auto Balance Profile

### Before you begin

You must log in as a user with admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope power-cap-config</b>	Enters power cap configuration command mode.
<b>Step 3</b>	Server /chassis/power-cap-config # <b>scope power-profile auto_balance</b>	Enters auto balance power profile command mode.
<b>Step 4</b>	Server /chassis/power-cap-config/power-profile # <b>set enabled {yes   no}</b>	Enables or disables the power profile.

	Command or Action	Purpose
<b>Step 5</b>	Server /chassis/power-cap-config/power-profile *# <b>set priority-selection {dynamic   manual}</b>	Sets the priority type to the chosen value.
<b>Step 6</b>	Server /chassis/power-cap-config/power-profile *# <b>set priority-server-id {1   2}</b>	Assigns priority to the chosen server.
<b>Step 7</b>	Server /chassis/power-cap-config/power-profile *# <b>set corr-time Value</b>	Sets the correction time in which the platform power should be brought back to the specified power limit before taking the action specified in the <b>Action</b> mode.  The range is from 1 and 600 seconds. The default is 1 seconds.
<b>Step 8</b>	Server /chassis/power-cap-config/power-profile *# <b>set allow-throttle {yes   no}</b>	Enables or disables the system to maintain the power limit by forcing the processor to use the throttling state (T-state) and memory throttle.
<b>Step 9</b>	Server /chassis /power-cap-config# <b>set susp-pd {h:m-h:m   /ll,Mo,Tu,We,Th,Fr,Sa,Su.}</b>	Specifies the time period that the power capping profile will not be active.
<b>Step 10</b>	Server /chassis/power-cap-config/power-profile *# <b>commit</b>	Commits the transaction to the system configuration.
<b>Step 11</b>	(Optional) Server /chassis/power-cap-config/power-profile # <b>show detail</b>	Displays the auto balance power profile details.

### Example

The following example shows how to enable auto balance profile and setting the priority selection:

#### Setting Priority Using Dynamic Option

```
Server # scope chassis
Server /chassis # scope power-cap-config
Server /chassis/power-cap-config # scope power-profile auto_balance
Server /chassis/power-cap-config/power-profile # set enabled yes
Server /chassis/power-cap-config/power-profile *# set priority-selection dynamic
Server /chassis/power-cap-config/power-profile *# set corr-time 1
Server /chassis/power-cap-config/power-profile *# set allow-throttle yes
Server /chassis/power-cap-config/power-profile *# set susp-pd "2:0-4:30|All"
Server /chassis/power-cap-config/power-profile *# commit
Server /chassis/power-cap-config/power-profile # show detail
Profile Name : auto_balance
  Enabled: yes
  Priority Selection: dynamic
  Priority Server: 2
  Server1 Power Limit: 362
  Server2 Power Limit: 253
  Suspend Period: 2:0-4:30|All
  Exception Action: alert
```

```

Correction Time: 1
Throttling: no
Server /chassis/power-cap-config/power-profile #

Setting Priority Using the Manual Option
Server # scope chassis
Server /chassis # scope power-cap-config
Server /chassis/power-cap-config # scope power-profile auto_balance
Server /chassis/power-cap-config/power-profile # set enabled yes
Server /chassis/power-cap-config/power-profile *# set priority-selection manual
Server /chassis/power-cap-config/power-profile *# set priority-server-id 1
Server /chassis/power-cap-config/power-profile *# set corr-time 1
Server /chassis/power-cap-config/power-profile *# set allow-throttle yes
Server /chassis/power-cap-config/power-profile *# set susp-pd "2:0-4:30|All"
Server /chassis/power-cap-config/power-profile *# commit
Server /chassis/power-cap-config/power-profile # show detail
Profile Name : auto_balance
Enabled: yes
Priority Selection: manual
Priority Server: 1
Server1 Power Limit: 362
Server2 Power Limit: 253
Suspend Period: 2:0-4:30|All
Exception Action: alert
Correction Time: 1
Throttling: no
Server /chassis/power-cap-config/power-profile #
    
```

## Disabling Auto Balance Power Profile

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope power-cap-config</b>	Enters the power cap configuration mode.
<b>Step 3</b>	Server /chassis/power-cap-config # <b>scope power-profile auto_balance</b>	Enters the auto balance power profile mode.
<b>Step 4</b>	Server /chassis/power-cap-config/power-profile # <b>set enabled no</b>	Disables the auto balance power profile.
<b>Step 5</b>	Server /chassis/power-cap-config/power-profile # <b>commit</b>	Commits the transaction to the system configuration.

### Example

This example shows how to disable the auto balance profile:

```

Server # scope chassis
Server /chassis # scope power-cap-config
Server /chassis/power-cap-config # scope power-profile auto_balance
Server /chassis/power-cap-config/power-profile # set enabled no
    
```

```
Server /chassis/power-cap-config/power-profile *# commit
```

## Enabling Custom Profile on Server

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope power-cap-config</b>	Enters the power cap configuration mode.
<b>Step 3</b>	Server /chassis/power-cap-config # <b>scope power-profile custom</b>	Enters the custom power profile mode.
<b>Step 4</b>	Server /chassis/power-cap-config/power-profile # <b>set enabled yes</b>	Enables the custom power profile.
<b>Step 5</b>	Server /chassis/power-cap-config/power-profile *# <b>set power-limit value</b>	Specifies the power limit. Enter a value within the specified range.
<b>Step 6</b>	Server /chassis/power-cap-config/power-profile *# <b>set corr-time value</b>	Sets the correction time in which the platform power should be brought back to the specified power limit before taking the action specified in the <b>Action</b> mode.  The range is from 1 and 600 seconds. The default is 1 seconds
<b>Step 7</b>	Server /chassis/power-cap-config/power-profile *# <b>set allow-throttle yes</b>	Enables the system to maintain the power limit by forcing the processor to use the throttling state (T-state) and memory throttle.
<b>Step 8</b>	Server /chassis/power-cap-config/power-profile *# <b>commit</b>	Commits the transaction to the system configuration.
<b>Step 9</b>	At the prompt, enter the server ID for which you want to apply the custom power profile.	
<b>Step 10</b>	Server /chassis/power-cap-config/power-profile # <b>show detail</b>	Displays the power profile details.

### Example

This example shows how to enable the custom profile on any server node:

```
Server # scope chassis
Server /chassis # scope power-cap-config
Server /chassis/power-cap-config # scope power-profile custom
```



```

Server /chassis/power-cap-config/power-profile # set enabled yes
Server /chassis/power-cap-config/power-profile *# set power-limit 253
Server /chassis/power-cap-config/power-profile *# set corr-time 1
Server /chassis/power-cap-config/power-profile *# set allow-throttle no
Server /chassis/power-cap-config/power-profile *# commit
Please enter server Id for which 'custom' power profile setting needs to be done
[1|2]?2
Server /chassis/power-cap-config/power-profile # show detail
Profile Name : custom
Server Id 1:
    Enabled: no
    Power Limit: N/A
    Suspend Period:
    Exception Action: alert
    Correction Time: 1
    Throttling: no
Server Id 2:
    Enabled: yes
    Power Limit: 253
    Suspend Period:
    Exception Action: alert
    Correction Time: 1
    Throttling: yes

```

## Disabling Custom Profile on Server

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope power-cap-config</b>	Enters the power cap configuration mode.
<b>Step 3</b>	Server /chassis/power-cap-config # <b>scope power-profile custom</b>	Enters the custom power profile mode.
<b>Step 4</b>	Server /chassis/power-cap-config/power-profile # <b>set enabled no</b>	Disables the custom power profile.
<b>Step 5</b>	Server /chassis/power-cap-config/power-profile *# <b>commit</b>	Commits the transaction to the system configuration.
<b>Step 6</b>	At the prompt, enter the server ID for which you want to disable the custom power profile.	
<b>Step 7</b>	Server /chassis/power-cap-config/power-profile # <b>show detail</b>	Displays the power profile details.

### Example

This example shows how to disable the custom profile on any server node:

```

Server # scope chassis
Server /chassis # scope power-cap-config
Server /chassis/power-cap-config # scope power-profile custom

```

```

Server /chassis/power-cap-config/power-profile # set enabled no
Server /chassis/power-cap-config/power-profile *# commit
Please enter server Id for which 'custom' power profile setting needs to be done
[1|2]?2
Server /chassis/power-cap-config/power-profile # show detail
Profile Name : custom
Server Id 1:
  Enabled: no
  Power Limit: N/A
  Suspend Period:
  Exception Action: alert
  Correction Time: 1
  Throttling: no
Server Id 2:
  Enabled: no
  Power Limit: 253
  Suspend Period:
  Exception Action: alert
  Correction Time: 1
  Throttling: yes

```

## Enabling Thermal Profile on Server

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope power-cap-config</b>	Enters the power cap configuration mode.
<b>Step 3</b>	Server /chassis/power-cap-config # <b>scope power-profile thermal</b>	Enters the thermal power profile mode.
<b>Step 4</b>	Server /chassis/power-cap-config/power-profile # <b>set enabled yes</b>	Enables or disables the thermal power profile.
<b>Step 5</b>	Server /chassis/power-cap-config/power-profile *# <b>set temperature value</b>	Enter power in watts within the range specified. Enter the temperature in Celsius.
<b>Step 6</b>	Server /chassis/power-cap-config/power-profile *# <b>commit</b>	Commits the transaction to the system configuration.
<b>Step 7</b>	At the prompt, enter the server ID for which you want to enable the thermal power profile.	
<b>Step 8</b>	Server /chassis/power-cap-config/power-profile # <b>show detail</b>	Displays the power profile details.

### Example

This example shows how to enable the thermal profile on any server node:

```
Server # scope chassis
```

```

Server /chassis # scope power-cap-config
Server /chassis/power-cap-config # scope power-profile thermal
Server /chassis/power-cap-config/power-profile # set enabled yes
Server /chassis/power-cap-config/power-profile *# set temperature 26
Server /chassis/power-cap-config/power-profile *# commit
Please enter server Id for which 'thermal' power profile setting needs to be done
[1|2]?1
Server /chassis/power-cap-config/power-profile # show detail
Profile Name : thermal
Server Id 1:
    Enabled: yes
    Temperature Threshold (deg C): 26
    Power Limit: 163

```

## Disabling Thermal Profile on Server

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope power-cap-config</b>	Enters the power cap configuration mode.
<b>Step 3</b>	Server /chassis/power-cap-config # <b>scope power-profile thermal</b>	Enters the thermal power profile mode.
<b>Step 4</b>	Server /chassis/power-cap-config/power-profile # <b>set enabled no</b>	Disables the thermal power profile.
<b>Step 5</b>	Server /chassis/power-cap-config/power-profile *# <b>commit</b>	Commits the transaction to the system configuration.
<b>Step 6</b>	At the prompt, enter the server ID for which you want to disable the thermal power profile.	
<b>Step 7</b>	Server /chassis/power-cap-config/power-profile # <b>show detail</b>	Displays the power profile details.

### Example

This example shows how to disable the thermal profile on any server node:

```

Server # scope chassis
Server /chassis # scope power-cap-config
Server /chassis/power-cap-config # scope power-profile thermal
Server /chassis/power-cap-config/power-profile # set enabled no
Server /chassis/power-cap-config/power-profile *# commit
Please enter server Id for which 'thermal' power profile setting needs to be done
[1|2]?1
Server /chassis/power-cap-config/power-profile # show detail
Profile Name : thermal
Server Id 1:
    Enabled: no
    Temperature Threshold (deg C): 26
    Power Limit: 163

```

```

Server Id 2:
  Enabled: no
  Temperature Threshold (deg C): 0
  Power Limit: N/A
Server /chassis/power-cap-config/power-profile #

```

## Viewing Power Cap Configuration Details

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope power-cap-config</b>	Enters the power cap configuration mode.
<b>Step 3</b>	Server /chassis/power-cap-config # <b>show detail</b>	Displays the power characterization status of the chassis and servers.

### Example

This example shows how to view power cap configuration details:

```

Server # scope chassis
Server /chassis # scope power-cap-config
Server /chassis/power-cap-config # show detail
Chassis :
  Power Capping: yes
  Power Characterization Status: Completed
  Chassis Minimum (W): 756
  Chassis Maximum (W): 1089
  Chassis Budget (W): 1000
  Chassis Manageable Power Budget (W): 530
  Auto Balance Minimum Power Budget (W) : 966
  Auto Balance Efficient Budget (W): 1901
Server 1 :
  Power Characterization Status: Completed
  Platform Minimum (W): 163
  Platform Efficient (W): 396
  Platform Maximum (W): 362
  Memory Minimum (W): 1
  Memory Maximum (W): 0
  CPU Minimum (W): 95
  CPU Maximum (W): 241
Server 2 :
  Power Characterization Status: Completed
  Platform Minimum (W): 136
  Platform Efficient (W): 584
  Platform Maximum (W): 253
  Memory Minimum (W): 1
  Memory Maximum (W): 0
  CPU Minimum (W): 57
  CPU Maximum (W): 139
Server /chassis/power-cap-config #

```

## Viewing Power Monitoring Details

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>show power-monitoring</b>	Displays the power monitoring details.

### Example

This example shows how to view power monitoring details:

```
Server # scope chassis
Server /chassis # show power-monitoring
Chassis :
Current (W)  Minimum (W)  Maximum (W)  Average (W)  Period
-----
408          311          471          392          0days 9:5...
Server 1 :
Domain       Current (W)  Minimum (W)  Maximum (W)  Average (W)  Period
-----
Platform    68           61           178          68           0days 21:...
CPU         30           28           133          30           0days 21:...
Memory      1            0            1            1            0days 21:...
Server 2 :
Domain       Current (W)  Minimum (W)  Maximum (W)  Average (W)  Period
-----
Platform    97           62           200          100          1days 7:1:2
CPU         46           16           140          48           1days 7:1:2
Memory      1            0            1            1            1days 7:1:2
Server /chassis/server/pid-catalog #
```

## Viewing CUPS Utilization Details

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>show cups-utilization</b>	Displays the server utilization value on all the available CPUs.

### Example

This example shows how to view CUPS utilization details:

```
Server # scope chassis
Server /chassis # show cups-utilization
Server 1 :
CPU Utilization (%)  Memory Utilization (%)  I/O Utilization (%)  Overall Utilization (%)
```

```

-----
0                               0                               0                               0
Server 2 :
CPU Utilization (%)  Memory Utilization (%)  I/O Utilization (%)  Overall Utilization (%)
-----
7                               0                               0                               8

```

## Resetting the Server



**Important** If any firmware or BIOS updates are in progress, do not change the server power until those tasks are complete.

### Before you begin

You must log in with user or admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server 1</b>	Enters the server command mode.
<b>Step 3</b>	Server /chassis/server # <b>power hard-reset</b>	Reset the server, this is equivalent to pressing the reset button on the front panel or IPMI reset.
<b>Step 4</b>	At the prompt, enter <b>y</b> to confirm.	Reset the server, this is equivalent to pressing the reset button on the front panel or IPMI reset.

### Example

This example shows how to power hard reset the server:

```

Server# scope chassis
Server# /chassis scope server 1
Server /chassis/server # power hard-reset
This operation will change the server's power state.
Do you want to continue with power control for Server 1 ?[y|N] y

Server /chassis/server # show
Server ID Power Serial Number Product Name PID UUID
-----
1 Off FCH1848794D UCS S3260 UCSC-C3X60-SVRNB
60974271-A514-484C-BAE3-A5EE4FD16E06

Server /chassis/server#

```

# Shutting Down the Server



## Important

If any firmware or BIOS updates are in progress, do not change the server power until those tasks are complete.

## Before you begin

You must log in with user or admin privileges to perform this task.

## Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server 1</b>	Enters the server command mode.
<b>Step 3</b>	Server /chassis/server # <b>power shutdown</b>	Shuts down the host OS and powers off the server.
<b>Step 4</b>	At the prompt, enter <b>y</b> to confirm.	Shuts down the host OS and powers off the server.

## Example

This example shows how to shutdown the server:

```
Server# scope chassis
Server# /chassis scope server 1
Server /chassis/server # power shutdown
This operation will change the server's power state.
Do you want to continue with power control for Server 1 ?[y|N] y

Server /chassis/server # show
Server ID Power Serial Number Product Name PID          UUID
-----
-----
1          Off   FCH1848794D  UCS S3260      UCSC-C3X60-SVRNB
60974271-A514-484C-BAE3-A5EE4FD16E06

Server /chassis/server#
```

# Configuring DIMM Black Listing

## DIMM Black Listing

In Cisco IMC, the state of the Dual In-line Memory Module (DIMM) is based on SEL event records. A DIMM is marked bad if the BIOS encounters a non-correctable memory error or correctable memory error with 16000 error counts during memory test execution during BIOS post. If a DIMM is marked bad, it is considered a non-functional device.

If you enable DIMM blacklisting, Cisco IMC monitors the memory test execution messages and blacklists any DIMM that encounters memory errors at any given point of time in the DIMM SPD data. This allows the host to map out those DIMMs.

DIMMs are mapped out or blacklisted only when Uncorrectable errors occur. When a DIMM gets blacklisted, other DIMMs in the same channel are ignored or disabled, which means that the DIMM is no longer considered bad.



**Note** DIMMs do not get mapped out or blacklisted for 16000 Correctable errors.

## Enabling DIMM Black Listing

### Before you begin

You must be logged in as an administrator.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /server # <b>scope dimm-blacklisting</b> /	Enters the DIMM blacklisting mode.
<b>Step 3</b>	Server /server/dimm-blacklisting # <b>set enabled</b> {yes   no}	Enables or disables DIMM blacklisting.
<b>Step 4</b>	Server /server/dimm-blacklisting* # <b>commit</b>	Commits the transaction to the system configuration.

### Example

The following example shows how to enable DIMM blacklisting:

```
Server # scope server 1
Server /server # scope dimm-blacklisting
Server /server/dimm-blacklisting # set enabled yes
Server /server/dimm-blacklisting* # commit
Server /server/dimm-blacklisting #
```



```

Server /server/dimm-blacklisting # show detail

DIMM Blacklisting:
  Enabled: yes
Server /server/dimm-blacklisting #

```

# Configuring BIOS Settings

## Viewing BIOS Status

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /sever # <b>scope bios</b>	Enters the BIOS command mode.
<b>Step 3</b>	Server /sever/bios # <b>show detail</b>	Displays details of the BIOS status.

The BIOS status information contains the following fields:

Name	Description
BIOS Version	The version string of the running BIOS.
Backup BIOS Version	The backup version string of the BIOS.
Boot Order	The legacy boot order of bootable target types that the server will attempt to use.
Boot Override Priority	This can be None, or HV.
FW Update/Recovery Status	The status of any pending firmware update or recovery action.
UEFI Secure Boot	Enables or Disables UEFI secure boot.
Configured Boot Mode	The boot mode in which h BIOS will try to boot the devices.
Actual Boot Mode	The actual boot mode in which BIOS booted the devices.
Last Configured Boot Order Source	The last configured boot order source by BIOS.

### Example

This example displays the BIOS status:

```

Server# scope server 1
Server /server # scope bios
Server /server/bios # show detail
Server /server/bios # show detail
BIOS:
  BIOS Version: server-name.2.0.7c.0.071620151216
  Backup BIOS Version: server-name.2.0.7c.0.071620151216
  Boot Order: (none)
  Boot Override Priority:
  FW Update/Recovery Status: None, OK
  UEFI Secure Boot: disabled
  Configured Boot Mode: Legacy
  Actual Boot Mode: Legacy
  Last Configured Boot Order Source: CIMC
Server /server/bios #
    
```

## Configuring Main BIOS Settings

### Before you begin

You must log in with admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /server # <b>scope bios</b>	Enters the BIOS command mode.
<b>Step 3</b>	Server /server /bios # <b>scope main</b>	Enters the main BIOS settings command mode.
<b>Step 4</b>	Server /server /bios # <b>set TPMAdminCtrl</b> {Disbaled   Enabled}	Enables or disables TPM support.
<b>Step 5</b>	Server /server /bios/main # <b>commit</b>	Commits the transaction to the system configuration.  Changes are applied on the next server reboot. If server power is on, you are prompted to choose whether to reboot now.

### Example

This example configures the main BIOS parameter and commits the transaction:

```

Server /server # scope server 1
Server/server # scope bios
Server /server/bios # scope main
Server /server/bios/main # set TPMAdminCtrl Enabled
Server /server/bios/main *# commit
Changes to BIOS set-up parameters will require a reboot.
Do you want to reboot the system?[y|N] n
Changes will be applied on next reboot.
Server /server/bios/main #
    
```

## Configuring Advanced BIOS Settings

### Before you begin

You must log in with admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /sever # <b>scope bios</b>	Enters the BIOS command mode.
<b>Step 3</b>	Server /sever/bios # <b>scope advanced</b>	Enters the advanced BIOS settings command mode.
<b>Step 4</b>	Configure the BIOS settings.	<a href="#">BIOS Parameters by Server Model, on page 351</a>
<b>Step 5</b>	Server /sever/bios/advanced # <b>commit</b>	Commits the transaction to the system configuration.  Changes are applied on the next server reboot. If server power is on, you are prompted to choose whether to reboot now.

### Example

This example enables all the USB drives and commits the transaction:

```
Server# scope server 1
Server/sever # scope bios
Server /sever/bios # scope advanced
Server /sever/bios/advanced # set AllUsbDevices Enabled
Server /sever/bios/advanced *# commit
Changes to BIOS set-up parameters will require a reboot.
Do you want to reboot the system?[y|N] n
Changes will be applied on next reboot.
Server /sever/bios/advanced #
```

## Configuring Server Management BIOS Settings

### Before you begin

You must log in with admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /sever # <b>scope bios</b>	Enters the BIOS command mode.

	Command or Action	Purpose
<b>Step 3</b>	Server /sever/bios # <b>scope server-management</b>	Enters the server management BIOS settings command mode.
<b>Step 4</b>	Configure the BIOS settings.	<a href="#">BIOS Parameters by Server Model, on page 351</a>
<b>Step 5</b>	Server /sever/bios/server-management # <b>commit</b>	Commits the transaction to the system configuration.  Changes are applied on the next server reboot. If server power is on, you are prompted to choose whether to reboot now.

### Example

This example enables the OS watchdog timer and commits the transaction:

```
Server# scope bios
Server /sever # scope bios
Server /sever/bios # scope server-management
Server /sever/bios/server-management # set OSBootWatchdogTimer Enabled
Server /sever/bios/server-management *# commit
Changes to BIOS set-up parameters will require a reboot.
Do you want to reboot the system?[y|N] n
Changes will be applied on next reboot.
Server /sever/bios/server-management #
```

## Restoring BIOS Defaults

### Before you begin

You must log in as a user with admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /sever # <b>scope bios</b>	Enters the BIOS command mode.
<b>Step 3</b>	Server /sever/bios # <b>bios-setup-default</b>	Restores BIOS default settings. This command initiates a reboot.

### Example

This example restores BIOS default settings:

```
Server# scope bios
Server/sever # scope bios
Server /sever/bios # bios-setup-default
This operation will reset the BIOS set-up tokens to factory defaults.
```

```
All your configuration will be lost.
Changes to BIOS set-up parameters will initiate a reboot.
Continue?[y|N]y
```

## Entering BIOS Setup

### Before you begin

- The server must be powered on.
- You must log in as a user with admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /sever # <b>scope bios</b>	Enters the BIOS command mode.
<b>Step 3</b>	Server /sever/bios # <b>enter-bios-setup</b>	Enters BIOS setup on reboot.

### Example

This example enables you to enter BIOS setup:

```
Server# scope server 1
Server /sever # scope bios
Server /sever/bios # enter-bios-setup
This operation will enable Enter BIOS Setup option.
Host must be rebooted for this option to be enabled.
Continue?[y|N]y
```

## Restoring BIOS Manufacturing Custom Defaults

In instances where the components of the BIOS no longer function as desired, you can restore the BIOS set up tokens to the manufacturing default values.

### Before you begin

- You must log in with admin privileges to perform this task.
- The server must be powered off.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /sever # <b>scope bios</b>	Enters the BIOS command mode.

	Command or Action	Purpose
<b>Step 3</b>	Server /sever/bios # <b>restore-mfg-defaults</b>	Restores the set up tokens to the manufacturing default values.

### Example

This example shows how to restore the BIOS set up tokens to the manufacturing default values:

```
Server # scope bios
Server /sever/bios # restore-mfg-defaults
This operation will reset the BIOS set-up tokens to manufacturing defaults.
The system will be powered on.
Continue? [y|n] y
Server /sever/bios #
```

## BIOS Profiles

On the Cisco UCS server, default token files are available for every S3260 server platform, and you can configure the value of these tokens using the Graphic User Interface (GUI), CLI interface, and the XML API interface. To optimize server performance, these token values must be configured in a specific combination.

Configuring a BIOS profile helps you to utilize pre-configured token files with the right combination of the token values. Some of the pre-configured profiles that are available are virtualization, high-performance, low power, and so on. You can download the various options of these pre-configured token files from the Cisco website and apply it on the servers through the BMC.

You can edit the downloaded profile to change the value of the tokens or add new tokens. This allows you to customize the profile to your requirements without having to wait for turnaround time.

## Activating a BIOS Profile

### Before you begin

You must log in with user or admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope bios</b>	Enters the BIOS command mode.
<b>Step 2</b>	Server# /bios <b>scope bios-profile</b>	Enters the BIOS profile command mode.
<b>Step 3</b>	Server# /bios/bios-profile <b>activate</b> <i>virtualization</i>	You are prompted to back up the BIOS configuration. Enter <b>y</b> .
<b>Step 4</b>	You are prompted to reboot the system to apply the changes to the BIOS set-up parameters. Enter <b>y</b> .	Initiates the system reboot.

### Example

This example activates the specified BIOS profile:

```

Server # scope bios
Server /bios # scope bios-profile
Server /bios/bios-profile # activate virtualization
It is recommended to take a backup before activating a profile.
Do you want to take backup of BIOS configuration?[y/n] y
backup-bios-profile succeeded.
bios profile "virtualization" deleted
Changes to BIOS set-up parameters will require a reboot.
Do you want to reboot the system?[y|N]y
A system reboot has been initiated.
Server /bios/bios-profile #

```

## Taking a Back-Up of a BIOS Profile

### Before you begin

You must log in with user or admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope bios</b>	Enters the BIOS command mode.
<b>Step 2</b>	Server# /bios <b>scope bios-profile</b>	Enters the BIOS profile command mode.
<b>Step 3</b>	Server# /bios/bios-profile <b>backup</b>	Displays a message that the backup of the BIOS profile was successful.

### Example

This example backs up a BIOS profile:

```

Server # scope bios
Server /bios # scope bios-profile
Server /bios/bios-profile # backup
backup-bios-profile succeeded.
Server /bios #

```

## Deleting a BIOS Profile

### Before you begin

You must log in with user or admin privileges to perform this task.

**Procedure**

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope bios</b>	Enters the BIOS command mode.
<b>Step 2</b>	Server# /bios <b>scope bios-profile</b>	Enters the BIOS profile command mode.
<b>Step 3</b>	Server# /bios/bios-profile <b>delete BIOS profile</b>	Deletes the specified BIOS profile.

**Example**

This example deletes the specified BIOS profile:

```
Server # scope bios
Server /bios # scope bios-profile
Server /bios/bios-profile # delete performance
Server /bios/bios-profile #
```

**Displaying BIOS Profiles****Procedure**

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope bios</b>	Enters the BIOS command mode.
<b>Step 2</b>	Server# /bios <b>show bios-profile</b>	Displays all the BIOS profiles.

**Example**

This example displays all the BIOS profiles:

```
Server # scope bios
Server /bios # show bios-profile
ID      Name           Active
-----
1       performance      yes
2       virtualization   no
3       none              no
4       cisco_backup     no
Server /bios #scope bios-profile
Server /bios #
```

**Displaying Information of a BIOS Profile****Procedure**

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope bios</b>	Enters the BIOS command mode.
<b>Step 2</b>	Server# /bios <b>scope bios-profile</b>	Displays all the BIOS profiles.



	Command or Action	Purpose
<b>Step 3</b>	Server# /bios/bios-profile <b>info performance</b>	Displays information of the BIOS profile such as token name, profile value, and active value.

### Example

This example displays information of the specified BIOS profile:

```
Server # scope bios
Server /bios # scope bios-profile
Server /bios/bios-profile # info performance

TOKEN NAME                                PROFILE VALUE                            ACTUAL VALUE
-----
TPMAdminCtrl                             Enabled                                  Enabled
ASPMsupport                               Disabled                                 Disabled
Server /bios/bios-profile #
```

## Displaying details of the BIOS Profile

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope bios</b>	Enters the BIOS command mode.
<b>Step 2</b>	Server# /bios <b>scope bios-profile</b>	Enters the BIOS profile command mode.
<b>Step 3</b>	Server# /bios/bios-profile <b>show detail</b>	Displays the details of BIOS profile.

### Example

This example displays the details of the BIOS profile:

```
Server # scope bios
Server /bios # scope bios-profile
Server /bios/bios-profile # show detail
Active Profile: Virtualization
Install Status: bios profile install done
Server /bios/bios-profile #
```

## Viewing Product ID (PID) Catalog Details

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server {1   2}</b>	Enters server command mode of server 1 or 2.

	Command or Action	Purpose
<b>Step 3</b>	Server /chassis/server # <b>show cpu-pid</b>	Displays the CPU PID details.
<b>Step 4</b>	Server /chassis/server # <b>show dimm-pid</b>	Displays the memory PID details.
<b>Step 5</b>	Server /chassis/server # <b>show pciadapter-pid</b>	Displays the PCI adapters PID details.
<b>Step 6</b>	Server /chassis/server # <b>show hdd-pid</b>	Displays the HDD PID details.

## Example

This example shows how to create view PID details

```

Server # scope chassis
Server /chassis # scope server 1
Viewing CPU PID details
Server /chassis/server # show cpu-pid
Socket Product ID Model
-----
CPU1 UCS-CPU-E52660B Intel(R) Xeon(R) CPU E5-2660 v2 @ 2.2...
CPU2 UCS-CPU-E52660B Intel(R) Xeon(R) CPU E5-2660 v2 @ 2.2...
Viewing memory PID details
Server /chassis/server # show dimm-pid
Name Product ID Vendor ID Capacity Speed
-----
DIMM_A1 UNKNOWN NA Failed NA
DIMM_A2 UNKNOWN NA Ignore... NA
DIMM_B1 UCS-MR-1X162RZ-A 0xCE00 16384 MB 1866
DIMM_B2 UCS-MR-1X162RZ-A 0xCE00 16384 MB 1866
DIMM_C1 UCS-MR-1X162RZ-A 0xCE00 16384 MB 1866
DIMM_C2 UCS-MR-1X162RZ-A 0xCE00 16384 MB 1866
DIMM_D1 UCS-MR-1X162RZ-A 0xCE00 16384 MB 1866
DIMM_D2 UCS-MR-1X162RZ-A 0xCE00 16384 MB 1866
DIMM_E1 UCS-MR-1X162RZ-A 0xCE00 16384 MB 1866
DIMM_E2 UCS-MR-1X162RZ-A 0xCE00 16384 MB 1866
DIMM_F1 UCS-MR-1X162RZ-A 0xCE00 16384 MB 1866
DIMM_F2 UCS-MR-1X162RZ-A 0xCE00 16384 MB 1866
DIMM_G1 UCS-MR-1X162RZ-A 0xCE00 16384 MB 1866
DIMM_G2 UCS-MR-1X162RZ-A 0xCE00 16384 MB 1866
DIMM_H1 UCS-MR-1X162RZ-A 0xCE00 16384 MB 1866
DIMM_H2 UCS-MR-1X162RZ-A 0xCE00 16384 MB 1866
Viewing PCI adapters PID details
Server /chassis/server # show pciadapter-pid
Slot Product ID Vendor ID Device ID SubVendor ID SubDevice ID
-----
1 UCSC-MLOM-CSC-02 0x1137 0x0042 0x1137 0x012e
Viewing HDD PID details
Server /chassis/server # show hdd-pid
Disk Controller Product ID Vendor Model
-----
1 SBMezz1 UCSC-C3X60-HD6TB SEAGATE ST6000NM0014
2 SBMezz1 UCSC-C3X60-HD6TB SEAGATE ST6000NM0014
3 SBMezz1 UCSC-C3X60-HD6TB SEAGATE ST6000NM0014
4 SBMezz1 UCSC-C3X60-HD6TB SEAGATE ST6000NM0014
5 SBMezz1 UCSC-C3X60-HD6TB SEAGATE ST6000NM0014
6 SBMezz1 UCSC-C3X60-HD6TB SEAGATE ST6000NM0014
7 SBMezz1 UCSC-C3X60-HD6TB SEAGATE ST6000NM0014
8 SBMezz1 UCSC-C3X60-HD6TB SEAGATE ST6000NM0014
9 SBMezz1 UCSC-C3X60-HD6TB SEAGATE ST6000NM0014
10 SBMezz1 UCSC-C3X60-HD6TB SEAGATE ST6000NM0014

```

```

11  SBMezz1    UCSC-C3X60-HD6TB    SEAGATE    ST6000NM0014
12  SBMezz1    UCSC-C3X60-HD6TB    SEAGATE    ST6000NM0014
13  SBMezz1    UCSC-C3X60-HD6TB    SEAGATE    ST6000NM0014
14  SBMezz1    UCSC-C3X60-HD6TB    SEAGATE    ST6000NM0014
201 SBMezz1    UCSC-C3X60-12SSD    ATA        INTEL SSD...
202 SBMezz1    UCSC-C3X60-12SSD    ATA        INTEL SSD...
    
```

```
Server /chassis/server #
```

## Uploading and Activating PID Catalog



**Caution** BMC reboots automatically once a PID catalog is activated.

You must reboot the server after activating a PID catalog.

### Before you begin

You must log in as a user with admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope pid-catalog</b>	Enters the server PID catalog command mode.
<b>Step 3</b>	Server /chassis/pid-catalog # <b>upload-pid-catalog</b> <i>remote-protocol IP address</i> <i>PID Catalog file</i>	Specifies the protocol to connect to the remote server. It can be one of the following types: <ul style="list-style-type: none"> <li>• TFTP</li> <li>• FTP</li> <li>• SFTP</li> <li>• SCP</li> <li>• HTTP</li> </ul>

	Command or Action	Purpose
		<p><b>Note</b> The Cisco UCS C-Series server now supports fingerprint confirmation of the server when you update firmware through a remote server. This option is available only if you choose SCP or SFTP as the remote server type.</p> <p>If you chose SCP or SFTP as the remote server type while performing this action, a prompt with the message Server (RSA) key fingerprint is &lt;server_finger_print_ID&gt; Do you wish to continue? Click y or n depending on the authenticity of the server fingerprint.</p> <p>The fingerprint is based on the host's public key and helps you to identify or verify the host you are connecting to.</p> <p>Initiates the upload of the PID catalog.</p>
<b>Step 4</b>	(Optional) Server /chassis/pid-catalog # <b>show detail</b>	Displays the status of the upload.
<b>Step 5</b>	Server /chassis/pid-catalog # <b>exit</b>	Returns to the chassis command mode.
<b>Step 6</b>	Server /chassis # <b>scope server {1   2}</b>	Enters server command mode of server 1 or 2.
<b>Step 7</b>	Server /chassis/server # <b>scope pid-catalog</b>	Enters server PID catalog command mode.
<b>Step 8</b>	Server /chassis/server/pid-catalog # <b>activate</b>	Activates the uploaded PID catalog.
<b>Step 9</b>	(Optional) Server /chassis/server/pid-catalog # <b>show detail</b>	Displays the status of the activation.

### Example

This example shows how to upload and activate PID catalog:

```

Server # scope chassis
Server /chassis # scope pid-catalog
Uploading PID catalog
Server /chassis/pid-catalog # upload-pid-catalog tftp 10.10.10.10
pid-ctlg-2_0_12_78_01.tar.gz
upload-pid-catalog initialized.
Please check the status using "show detail".
Server /chassis/pid-catalog # show detail
    Upload Status: Upload Successful
Activating the uploaded PID catalog
Server /chassis/pid-catalog # exit
Server /chassis # scope server 2
Server /chassis/server # scope pid-catalog

```

```
Server /chassis/server/pid-catalog # activate
Successfully activated PID catalog
Server /chassis/server/pid-catalog # show detail
Upload Status:
Activation Status: Activation Successful
Current Activated Version: 2.0(12.78).01
Server /chassis/server/pid-catalog #
```

## Deleting PID Catalog



**Caution** BMC reboots automatically once a PID catalog is deleted.

You must reboot the server after deleting a PID catalog.

### Before you begin

You must log in as a user with admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server {1   2}</b>	Enters server command mode of server 1 or 2.
<b>Step 3</b>	Server /chassis/server # <b>scope pid-catalog</b>	Enters server PID catalog command mode.
<b>Step 4</b>	Server /chassis/server/pid-catalog # <b>delete</b>	Enter y at the confirmation prompt to delete the uploaded PID catalog.  <b>Note</b> You can delete a PID catalog only if it has been previously updated and activated.
<b>Step 5</b>	(Optional) Server /chassis/server/pid-catalog # <b>show detail</b>	Displays the PID catalog status.

### Example

This example shows how to upload and activate PID catalog:

```
Server # scope chassis
Server /chassis # scope server 2
Server /chassis/server # scope pid-catalog
Server /chassis/server/pid-catalog # delete
CIMC will be automatically rebooted after successful deletion of the uploaded catalog file.
Once this is complete, a host reboot will be required for the catalog changes to be reflected
in
the BIOS and host Operating System Continue?[y|N]y
```

```
Server /chassis/server/pid-catalog # show detail
PID Catalog:
  Upload Status: N/A
  Activation Status: N/A
  Current Activated Version: 4.1(0.41)
Server /chassis/server/pid-catalog #
```

# Persistent Memory Module

## Persistent Memory Modules

Cisco UCS S-Series Release 4.0(4) introduces support for the Intel<sup>®</sup> Optane<sup>™</sup> Data Center persistent memory modules on the UCS M5 servers that are based on the Second Generation Intel<sup>®</sup> Xeon<sup>®</sup> Scalable processors. These persistent memory modules can be used only with the Second Generation Intel<sup>®</sup> Xeon<sup>®</sup> Scalable processors.

Persistent memory modules are non-volatile memory modules that bring together the low latency of memory and the persistence of storage. Data stored in persistent memory modules can be accessed quickly compared to other storage devices, and is retained across power cycles.

For detailed information about configuring persistent memory modules, see the [Cisco UCS: Configuring and Managing Intel<sup>®</sup> Optane<sup>™</sup> Data Center Persistent Memory Modules Guide](#).



# CHAPTER 5

## Viewing Server Properties

This chapter includes the following sections:

- [Viewing Server Properties, on page 85](#)
- [Viewing CMC Properties, on page 86](#)
- [Viewing Server CPU Details, on page 86](#)
- [Viewing Memory Properties, on page 87](#)
- [Viewing PCI Adapter Properties for a Server, on page 88](#)
- [Viewing HDD Details for a Server, on page 89](#)
- [Viewing Storage Adapter Properties for a Server, on page 90](#)
- [Viewing TPM Properties, on page 91](#)

## Viewing Server Properties

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server {1   2}</b>	Enters server command mode of server 1 or 2.
<b>Step 3</b>	Server /chassis /server # <b>show detail</b>	Displays server properties.

### Example

This example displays server properties:

```
Server# scope chassis
Server /chassis #scope server 1
Server /chassis /Server #show
Server ID Power Serial Number Product Name PID UID
-----
-----
2 on FCH183978RD UCS S3260 UCSC-C3X60-SVRNB
207BD0D4-C589-40C1-A73E-EF6E7F773198
Server /chassis /Server #show detail
```

```

Server ID 1:
  Power: off
  Serial Number: FCH1848794D
  Product Name: UCS S3260
  PID: UCSC-C3X60-SVRNB
  UUID: 60974271-A514-484C-BAE3-A5EE4FD16E06
Server /chassis /Server #

```

## Viewing CMC Properties

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	server /chassis # <b>scope cmc 1 2</b>	Enters CMC on the chosen SIOC controller command mode.
<b>Step 3</b>	server /chassis/cmc # <b>show detail</b>	Displays the CMC details for the chosen SIOC controller.

This example shows how to view the CMC details:

```

server # scope chassis
server /chassis # scope cmc 1
server /chassis/cmc # show detail
CMC Firmware update initialized.
Please check the status using "show detail"
Server /chassis/cmc # show detail
Firmware Image Information:
  ID: 1
  Name: CMC1
  Serial Number: FCH19117MTU
  Update Stage: NONE
  Update Progress: 100
  Current FW Version: 2.0(10.97)
  FW Image 1 Version: 2.0(10.97)
  FW Image 1 State: RUNNING ACTIVATED
  FW Image 2 Version: 2.0(10.87)
  FW Image 2 State: BACKUP INACTIVATED
  Reset Reason: not-applicable (This provides the reason for the last Cisco IMC reboot.)
server /chassis/cmc #

```

## Viewing Server CPU Details

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.



	Command or Action	Purpose
<b>Step 2</b>	Server /chassis # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 3</b>	Server /chassis /server # <b>show cpu</b>	Displays CPU details for the server.
<b>Step 4</b>	Server# <b>show cpu-pid</b>	Displays the CPU product IDs .

### Example

This example displays the CPU details for the server:

```
Server# scope chassis
Server /chassis #scope server 1
Server /chassis /Server #show cpu
Name          Cores    Version
-----
CPU1          6        Intel(R) Xeon(R) CPU E5-2620 v2 @ 2.10GHz
CPU2          6        Intel(R) Xeon(R) CPU E5-2620 v2 @ 2.10GHz

Server /chassis /Server #show cpu-pid
Socket Product ID          Model
-----
CPU1   UCS-CPU-E52620B        Intel(R) Xeon(R) CPU E5-2620 v2 @ 2.1...
CPU2   UCS-CPU-E52620B        Intel(R) Xeon(R) CPU E5-2620 v2 @ 2.1...

Server /chassis /Server #
```

## Viewing Memory Properties

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 3</b>	Server /chassis /server # <b>show dimm</b>	Displays DIMM details for the server.
<b>Step 4</b>	Server# <b>show dimm-pid</b>	Displays the DIMM product IDs.
<b>Step 5</b>	Server# <b>show dimm-summary</b>	Displays the DIMM summary information .

### Example

This example displays the DIMM details for the server.:

```
Server# scope chassis
Server /chassis #scope server 1
Server /chassis /Server #show dimm
Name          Capacity      Channel Speed (MHz) Channel Type
-----
DIMM_A1          16384 MB        1866                DDR3
```

```

DIMM_A2          16384 MB      1866          DDR3
DIMM_B1          16384 MB      1866          DDR3
DIMM_B2          16384 MB      1866          DDR3
DIMM_C1          16384 MB      1866          DDR3
DIMM_C2          16384 MB      1866          DDR3
DIMM_D1          16384 MB      1866          DDR3
DIMM_D2          16384 MB      1866          DDR3
DIMM_E1          16384 MB      1866          DDR3
DIMM_E2          16384 MB      1866          DDR3
DIMM_F1          16384 MB      1866          DDR3
DIMM_F2          16384 MB      1866          DDR3
DIMM_G1          16384 MB      1866          DDR3
DIMM_G2          16384 MB      1866          DDR3
DIMM_H1          16384 MB      1866          DDR3
DIMM_H2          16384 MB      1866          DDR3

```

```
Server /chassis /Server #show dimm-pid
```

Name	Product ID	Vendor ID	Capacity	Speed
DIMM_A1	UCS-MR-1X162RZ-A	0xCE00	16384 MB	1866
DIMM_A2	UCS-MR-1X162RZ-A	0xCE00	16384 MB	1866
DIMM_B1	UCS-MR-1X162RZ-A	0xCE00	16384 MB	1866
DIMM_B2	UCS-MR-1X162RZ-A	0xCE00	16384 MB	1866
DIMM_C1	UCS-MR-1X162RZ-A	0xCE00	16384 MB	1866
DIMM_C2	UCS-MR-1X162RZ-A	0xCE00	16384 MB	1866
DIMM_D1	UCS-MR-1X162RZ-A	0xCE00	16384 MB	1866
DIMM_D2	UCS-MR-1X162RZ-A	0xCE00	16384 MB	1866
DIMM_E1	UCS-MR-1X162RZ-A	0xCE00	16384 MB	1866
DIMM_E2	UCS-MR-1X162RZ-A	0xCE00	16384 MB	1866
DIMM_F1	UCS-MR-1X162RZ-A	0xCE00	16384 MB	1866
DIMM_F2	UCS-MR-1X162RZ-A	0xCE00	16384 MB	1866
DIMM_G1	UCS-MR-1X162RZ-A	0xCE00	16384 MB	1866
DIMM_G2	UCS-MR-1X162RZ-A	0xCE00	16384 MB	1866
DIMM_H1	UCS-MR-1X162RZ-A	0xCE00	16384 MB	1866
DIMM_H2	UCS-MR-1X162RZ-A	0xCE00	16384 MB	1866

```
Server /chassis /Server #show dimm-summary
```

```
DIMM Summary:
```

```

Memory Speed: 1600 MHz
Total Memory: 262144 MB
Effective Memory: 262144 MB
Redundant Memory: 0 MB
Failed Memory: 0 MB
Ignored Memory: 0 MB
Number of Ignored Dimms: 0
Number of Failed Dimms: 0
Memory RAS possible: Independent Mirroring Lockstep
Memory Configuration: Independent

```

```
Server /chassis /Server #
```

## Viewing PCI Adapter Properties for a Server

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # scope chassis	Enters chassis command mode.

	Command or Action	Purpose
<b>Step 2</b>	Server /chassis # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 3</b>	Server /chassis /server # <b>show pci-adapter</b>	Displays PCI adapter details for the server.
<b>Step 4</b>	Server# <b>show pciadapter-pid</b>	Displays the PCI adapter product IDs.

### Example

This example displays the PCI adapter details for the server.:

```

Server# scope chassis
Server /chassis #scope server 1
Server /chassis /Server #show pci-adapter

Slot          Vendor ID  Device ID  SubVendor ID  SubDevice ID  Firmware Version  Product Name
-----
L             0x8086    0x1521     0x1137        0x00d5        0x80000E74... Intel(R) I350 1
  Gbps N...
1             0x1cc7    0x0200     0x1cc7        0x0200        N/A              Radian RMS-200
NVRAM card
MLOM         0x1137    0x0042     0x1137        0x0139        4.1(3S1)        Cisco UCS VIC
1227T MLOM
HBA          0x1000    0x005d     0x1137        0x00db        24.12.1-0107    Cisco 12G SAS
Modular ...

Option ROM Status
-----
Loaded
Not-Loaded
Not-Loaded
Loaded

Server /chassis /Server #show pciadapter-pid
Slot  Product ID          Vendor ID  Device ID  SubVendor ID  SubDevice ID
-----
1     UNKNOWN            0x1137    0x0042     0x1137        0x0157
M     UCSC-C3X60-RAID    0x1000    0x005d     0x1137        0x012d

Server /chassis /Server #

```

## Viewing HDD Details for a Server

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 3</b>	Server /chassis /server # <b>show hdd-pid</b>	Displays HDD details for the server.

**Example**

This example displays the HDD details for the server:

```
Server# scope chassis
Server /chassis #scope server 1
Server /chassis /Server #show hdd-pid
Disk Controller  Product ID          Vendor      Model
-----
1   SLOT-MEZZ      UCS-HD4T7KS3-E  TOSHIBA    MG03SCA400
2   SLOT-MEZZ      UCS-HD4T7KS3-E  TOSHIBA    MG03SCA400
3   SLOT-MEZZ      UCS-HD4T7KS3-E  TOSHIBA    MG03SCA400
4   SLOT-MEZZ      UCS-HD4T7KS3-E  TOSHIBA    MG03SCA400
5   SLOT-MEZZ      UCS-HD4T7KS3-E  TOSHIBA    MG03SCA400
6   SLOT-MEZZ      UCS-HD4T7KS3-E  TOSHIBA    MG03SCA400
7   SLOT-MEZZ      UCS-HD4T7KS3-E  TOSHIBA    MG03SCA400
8   SLOT-MEZZ      UCS-HD4T7KS3-E  TOSHIBA    MG03SCA400
9   SLOT-MEZZ      UCS-HD4T7KS3-E  TOSHIBA    MG03SCA400
10  SLOT-MEZZ      UCS-HD4T7KS3-E  TOSHIBA    MG03SCA400
11  SLOT-MEZZ      UCS-HD4T7KS3-E  TOSHIBA    MG03SCA400
12  SLOT-MEZZ      UCS-HD4T7KS3-E  TOSHIBA    MG03SCA400
13  SLOT-MEZZ      UCS-HD4T7KS3-E  TOSHIBA    MG03SCA400
14  SLOT-MEZZ      UCS-HD4T7KS3-E  TOSHIBA    MG03SCA400

Server /chassis /Server#
```

## Viewing Storage Adapter Properties for a Server

**Procedure**

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server {1   2}</b>	Enters server command mode of server 1 or 2.
<b>Step 3</b>	Server /chassis /server # <b>show storageadapter</b>	Displays storage adapter details for the server.

**Example**

This example displays the storage adapter details for the server.:

```
Server# scope chassis
Server /chassis #scope server 1
Server /chassis /Server #show storageadapter
PCI Slot      Health          Controller Status  ROC Temperature  Product Name
-----
SLOT-MEZZ     Good            Optimal            48 degrees C    RAID controller for UCS S3260
S...

Serial Number  Firmware Package Build  Product ID  D Battery Status  Cache Memory Size
-----
FCH184972F5   24.7.3-0006             LSI Logic   Optimal           3534 MB
```

```

Boot Drive  Boot Drive is PD
-----
0           false
Server /chassis /Server #

```

## Viewing TPM Properties

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server {1   2}</b>	Enters server command mode of server 1 or 2.
<b>Step 3</b>	Server /chassis/server # <b>show tpm-inventory</b>	Displays TPM properties for the server.

### Example

This example displays the TPM properties for the server:

```

Server# scope chassis
Server /chassis #scope server 1
Server /chassis /Server #show tpm-inventory
Version      Presence      Enabled-Status      Active-Status      Ownership Revision
-----
NA           empty        unknown            unknown            unknown  NA

Model          Vendor          Serial
-----

Server chassis /Server#

```





# CHAPTER 6

## Viewing Sensors

This chapter includes the following sections:

- [Viewing Chassis Sensors, on page 93](#)
- [Viewing Server Sensors, on page 99](#)

### Viewing Chassis Sensors

### Viewing Power Supply Sensors

#### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope sensor</b>	Enters sensor command mode.
<b>Step 2</b>	Server /sensor # <b>show psu</b>	Displays power supply sensor statistics for the server.
<b>Step 3</b>	Server /sensor # <b>show psu-redundancy</b>	Displays power supply redundancy sensor status for the server.

#### Example

This example displays power supply sensor statistics:

```
Server# scope sensor
Server /sensor # show psu
Name           Sensor Status  Reading  Units  Min. Warning  Max. Warning  Min. Failure  Max.
Failure
-----
SU1_PIN
1098           Normal         102     Watts  N/A           882           N/A
PSU2_PIN
1098           Normal         96      Watts  N/A           882           N/A
PSU3_PIN
1098           Normal         102     Watts  N/A           882           N/A
PSU4_PIN
1098           Normal         96      Watts  N/A           882           N/A
```

```

1098
PSU1_POUT          Normal      78      Watts    N/A      798      N/A
996
PSU2_POUT          Normal      78      Watts    N/A      798      N/A
996
PSU3_POUT          Normal      84      Watts    N/A      798      N/A
996
PSU4_POUT          Normal      84      Watts    N/A      798      N/A
996
POWER_USAGE        Normal      406     Watts    N/A      N/A      N/A
2674
PSU1_DC_OK         Normal      good
PSU2_DC_OK         Normal      good
PSU3_DC_OK         Normal      good
PSU4_DC_OK         Normal      good
PSU1_AC_OK         Normal      good
PSU2_AC_OK         Normal      good
PSU3_AC_OK         Normal      good
PSU4_AC_OK         Normal      good
PSU1_STATUS        Normal      present
PSU2_STATUS        Normal      present
PSU3_STATUS        Normal      present
PSU4_STATUS        Normal      present

Server /sensor # show psu-redundancy
Name              Reading          Sensor Status
-----
PS_RDNDNT_MODE    full             Normal

Server /sensor #

```

## Viewing Fan Sensors

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope sensor</b>	Enters sensor command mode.
<b>Step 2</b>	Server /sensor # <b>show fan [detail]</b>	Displays fan sensor statistics for the server.

### Example

This example displays fan sensor statistics:

```

Server# scope sensor
Server /sensor # show fan

```



```

Name           Sensor Status Reading   Units   Min. Warning Max. Warning Min. Failure Max. Failure
-----
PSU1_FAN_SPEED Normal      5160    RPM     1118         N/A         946
N/A
PSU2_FAN_SPEED Normal      6106    RPM     1118         N/A         946
N/A
PSU3_FAN_SPEED Normal      5762    RPM     1118         N/A         946
N/A
PSU4_FAN_SPEED Normal      4988    RPM     1118         N/A         946
N/A
FAN1_SPEED     Normal      6600    RPM     2040         N/A        1800
N/A
FAN2_SPEED     Normal      6660    RPM     2040         N/A        1800
N/A
FAN3_SPEED     Normal      6600    RPM     2040         N/A        1800
N/A
FAN4_SPEED     Normal      6660    RPM     2040         N/A        1800
N/A
FAN5_SPEED     Normal      6660    RPM     2040         N/A        1800
N/A
FAN6_SPEED     Normal      6660    RPM     2040         N/A        1800
N/A
FAN7_SPEED     Normal      6660    RPM     2040         N/A        1800
N/A
FAN8_SPEED     Normal      6660    RPM     2040         N/A        1800
N/A
Server /sensor #

```

## Viewing Current Sensors

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope sensor</b>	Enters sensor command mode.
<b>Step 2</b>	Server /sensor # <b>show current</b>	Displays current sensor statistics.

### Example

This example displays current sensor statistics:

```

Server# scope sensor
Server /sensor # show current
Name           Sensor Status Reading   Units   Min. Warning Max. Warning Min. Failure Max. Failure
-----
PSU1_IOUT     Normal      6.00    AMP     N/A         78.00       N/A
87.00
PSU2_IOUT     Normal      6.00    AMP     N/A         78.00       N/A
87.00
PSU3_IOUT     Normal      7.00    AMP     N/A         78.00       N/A
87.00
PSU4_IOUT     Normal      7.00    AMP     N/A         78.00       N/A
87.00

```

Server /sensor #

## Viewing Voltage Sensors

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope sensor</b>	Enters sensor command mode.
<b>Step 2</b>	Server /sensor # <b>show voltage</b>	Displays voltage sensor statistics.

### Example

This example displays voltage sensor statistics:

```
Server# scope sensor
Server /sensor # show voltage
Name           Sensor Status  Reading    Units  Min. Warning Max. Warning Min. Failure
Max. Failure
-----
SIOC_P1V0      Normal         1.000     V      N/A         N/A         0.944
  1.064
SIOC_P1V2      Normal         1.208     V      N/A         N/A         1.128
  1.272
SIOC_P1V5      Normal         1.500     V      N/A         N/A         1.410
  1.590
SIOC_P2V5      Normal         2.478     V      N/A         N/A         2.338
  2.646
SIOC_P3V3      Normal         3.320     V      N/A         N/A         3.100
  3.500
SIOC_P12V_STBY Normal         12.060    V      N/A         N/A        11.280
  12.720
SIOC_P3V3_STBY Normal         3.360     V      N/A         N/A         3.140
  3.460
PSU1_VIN       Normal         228.000   V      N/A         N/A         N/A
  264.000
PSU2_VIN       Normal         228.000   V      N/A         N/A         N/A
  264.000
PSU3_VIN       Normal         228.000   V      N/A         N/A         N/A
  264.000
PSU4_VIN       Normal         228.000   V      N/A         N/A         N/A
  264.000
P5V_1          Normal         5.010     V      N/A         N/A         4.500
  5.640
P5V_2          Normal         5.010     V      N/A         N/A         4.500
  5.640
P5V_3          Normal         5.010     V      N/A         N/A         4.500
  5.640
P5V_4          Normal         5.010     V      N/A         N/A         4.500
  5.640
POV9_EXP1_VCORE Normal         0.872     V      N/A         N/A         0.836
  0.976
POV9_EXP2_VCORE Normal         0.872     V      N/A         N/A         0.836
  0.976
POV9_EXP1_AVD  Normal         0.888     V      N/A         N/A         0.836
```

```

0.976
POV9_EXP2_AVD      Normal      0.904      V          N/A        N/A        0.836
0.976
PSU1_VOUT          Normal      12.000     V          N/A        N/A        N/A
12.600
PSU2_VOUT          Normal      12.000     V          N/A        N/A        N/A
12.600
PSU3_VOUT          Normal      12.000     V          N/A        N/A        N/A
12.600
PSU4_VOUT          Normal      12.000     V          N/A        N/A        N/A
Server /sensor #

```

## Viewing Temperature Sensors

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope sensor</b>	Enters sensor command mode.
<b>Step 2</b>	Server /sensor # <b>show temperature</b>	Displays temperature sensor statistics.

### Example

This example displays temperature sensor statistics:

```

Server# scope sensor
Server /sensor # show temperature
Name              Sensor Status  Reading Units  Min. Warning Max. Warning Min. Failure
Max. Failure
-----
SIOC1_BACK_TEMP   Normal        37.0    C          N/A        70.0        N/A
80.0
SIOC1_FRONT_TEMP  Normal        42.0    C          N/A        70.0        N/A
80.0
SIOC1_MID_TEMP    Normal        41.0    C          N/A        70.0        N/A
80.0
SIOC1_VIC_TEMP    Normal        44.0    C          N/A        70.0        N/A
80.0
SIOC2_VIC_TEMP    Normal        44.0    C          N/A        70.0        N/A
80.0
MOBO_R_BOT_TEMP   Normal        30.0    C          N/A        70.0        N/A
80.0
MOBO_L_BOT_TEMP   Normal        31.0    C          N/A        70.0        N/A
80.0
MOBO_R_MID_TEMP   Normal        25.0    C          N/A        50.0        N/A
55.0
MOBO_R_IN_TEMP    Normal        24.0    C          N/A        50.0        N/A
55.0
MOBO_L_IN_TEMP    Normal        26.0    C          N/A        50.0        N/A
55.0
MOBO_L_MID_TEMP   Normal        26.0    C          N/A        50.0        N/A
55.0
MOBO_R_OUT_TEMP   Normal        29.0    C          N/A        47.0        N/A
52.0
MOBO_L_OUT_TEMP   Normal        29.0    C          N/A        46.0        N/A
51.0

```

```

PSU1_TEMP           Normal      24.0      C          N/A        55.0      N/A
  60.0
PSU2_TEMP           Normal      27.0      C          N/A        55.0      N/A
  60.0
PSU3_TEMP           Normal      27.0      C          N/A        55.0      N/A
  60.0
PSU4_TEMP           Normal      25.0      C          N/A        55.0      N/A
  60.0
SIOC1_CMC_TEMP      Normal      51.0      C          N/A        75.0      N/A
  85.0
MOBO_R_EXP_TEMP     Normal      37.0      C          N/A        80.0      N/A
  90.0
MOBO_L_EXP_TEMP     Normal      40.0      C          N/A        80.0      N/A
  90.0
SIOC2_BACK_TEMP     Normal      36.0      C          N/A        70.0      N/A
  80.0
SIOC2_FRONT_TEMP    Normal      36.0      C          N/A        70.0      N/A
  80.0
SIOC2_MID_TEMP      Normal      36.0      C          N/A        70.0      N/A
  80.0
SIOC2_CMC_TEMP      Normal      36.0      C          N/A        75.0      N/A
  85.0
Server /sensor #

```

## Viewing LED Sensor

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope sensor</b>	Enters sensor command mode.
<b>Step 2</b>	Server /sensor # <b>show led</b>	Displays LED sensor statistics.

### Example

This example displays LED sensor statistics:

```

Server# scope sensor
Server /sensor # show led
LED Name                LED State  LED Color
-----
LED_FAN12_FAULT         OFF        AMBER
LED_FAN34_FAULT         OFF        AMBER
LED_FAN56_FAULT         OFF        AMBER
LED_FAN78_FAULT         OFF        AMBER
CHS_FP_LED_ID           OFF        BLUE
LED_HLTH_STATUS         ON         GREEN
LED_PSU_STATUS          ON         GREEN
LED_TEMP_STATUS         ON         GREEN
LED_FAN_STATUS          ON         GREEN
SERVER1_FP_ID_LED       OFF        BLUE
SERVER2_FP_ID_LED       OFF        BLUE
OVERALL_DIMM_STATUS     ON         GREEN
Server /sensor #

```

# Viewing Server Sensors

## Viewing Storage Sensors

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /server # <b>scope sensor</b>	Enters sensor command.
<b>Step 3</b>	Server /server /sensor # <b>show hdd</b>	Displays the storage sensors for the server.

### Example

This example displays the storage sensors for the server:

```
Server# scope server 1
Server /server #scope sensor
Server /server /sensor #show hdd
Name                Status
-----
SSD1_PRS            inserted
SSD2_PRS            inserted

Server server /sensor #
```

## Viewing Current Sensors

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /server # <b>scope sensor</b>	Enters sensor command.
<b>Step 3</b>	Server /server /sensor # <b>show current</b>	Displays the current sensors for the server.

### Example

This example displays the current sensors for the server:

```
Server# scope server 1
Server /server #scope sensor
Server /server /sensor #show current
Name                Sensor Status Reading Units Min. Warning Max. Warning Min. Failure Max.
Failure
-----
```

```

-----
P12V_CUR_SENS Normal      5.84      AMP      N/A      N/A      N/A
56.90
Server server /sensor #

```

## Viewing LED Sensors

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /server # <b>scope sensor</b>	Enters sensor command.
<b>Step 3</b>	Server /server /sensor # <b>show led</b>	Displays the LED sensors for the server.

### Example

This example displays the LED sensors for the server:

```

Server# scope server 1
Server /server #scope sensor
Server /server /sensor #show led
LED Name                LED State  LED Color
-----
FP_ID_LED                FAST BLINK BLUE
P1_DIMM_A1_LED           OFF        AMBER
P1_DIMM_A2_LED           OFF        AMBER
P1_DIMM_B1_LED           OFF        AMBER
P1_DIMM_B2_LED           OFF        AMBER
P1_DIMM_C1_LED           OFF        AMBER
P1_DIMM_C2_LED           OFF        AMBER
P1_DIMM_D1_LED           OFF        AMBER
P1_DIMM_D2_LED           OFF        AMBER
P2_DIMM_E1_LED           OFF        AMBER
P2_DIMM_E2_LED           OFF        AMBER
P2_DIMM_F1_LED           OFF        AMBER
P2_DIMM_F2_LED           OFF        AMBER
P2_DIMM_G1_LED           OFF        AMBER
P2_DIMM_G2_LED           OFF        AMBER
P2_DIMM_H1_LED           OFF        AMBER
P2_DIMM_H2_LED           OFF        AMBER
LED_HLTH_STATUS          ON         GREEN
LED_TEMP_STATUS          ON         GREEN
OVERALL_DIMM_STATUS      ON         GREEN

Server server /sensor #

```

## Viewing Temperature Sensors

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /server # <b>scope sensor</b>	Enters sensor command.
<b>Step 3</b>	Server /server /sensor # <b>show temperature</b>	Displays the temperature sensors for the server.

### Example

This example displays the temperature sensors for the server:

```

Server# scope server 1
Server /server #scope sensor
Server /server /sensor #show temperature
Name           Sensor Status  Reading  Units  Min. Warning Max. Warning Min. Failure
Max. Failure
-----
-----
TEMP_SENS_FRONT Normal        24.0    C      N/A     60.0     N/A
 70.0
TEMP_SENS_REAR  Normal        25.0    C      N/A     80.0     N/A
 85.0
P1_TEMP_SENS    Normal        21.0    C      N/A     74.0     N/A
 79.0
P2_TEMP_SENS    Normal        23.5    C      N/A     74.0     N/A
 79.0
DDR3_P1_A1_TEMP Normal        23.0    C      N/A     65.0     N/A
 85.0
DDR3_P1_A2_TEMP Normal        23.0    C      N/A     65.0     N/A
 85.0
DDR3_P1_B1_TEMP Normal        23.0    C      N/A     65.0     N/A
 85.0
DDR3_P1_B2_TEMP Normal        23.0    C      N/A     65.0     N/A
 85.0
DDR3_P1_C1_TEMP Normal        24.0    C      N/A     65.0     N/A
 85.0
DDR3_P1_C2_TEMP Normal        24.0    C      N/A     65.0     N/A
 85.0
DDR3_P1_D1_TEMP Normal        24.0    C      N/A     65.0     N/A
 85.0
DDR3_P1_D2_TEMP Normal        23.0    C      N/A     65.0     N/A
 85.0
DDR3_P2_E1_TEMP Normal        23.0    C      N/A     65.0     N/A
 85.0
DDR3_P2_E2_TEMP Normal        23.0    C      N/A     65.0     N/A
 85.0
DDR3_P2_F1_TEMP Normal        22.0    C      N/A     65.0     N/A
 85.0

Server server /sensor #

```

## Viewing Voltage Sensors

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /server # <b>scope sensor</b>	Enters sensor command.
<b>Step 3</b>	Server /server /sensor # <b>show voltage</b>	Displays the voltage sensors for the server.

### Example

This example displays the voltage sensors for the server:

```

Server# scope server 1
Server /server #scope sensor
Server /server /sensor #show voltage
Name           Sensor Status Reading Units   Min. Warning Max. Warning Min. Failure
Max. Failure
-----
-----
P3V_BAT_SCALED Normal          2.973   V      N/A      N/A      2.154
 3.418
P5V_STBY       Normal          4.909   V      N/A      N/A      4.555
 5.452
P3V3_STBY      Normal          3.302   V      N/A      N/A      3.018
 3.602
P1V1_SSB_STBY Normal          1.088   V      N/A      N/A      1.000
 1.205
P1V8_STBY     Normal          1.784   V      N/A      N/A      1.627
 1.980
P1V0_STBY     Normal          0.990   V      N/A      N/A      0.911
 1.088
P1V5_STBY     Normal          1.490   V      N/A      N/A      1.372
 1.637
P0V75_STBY    Normal          0.725   V      N/A      N/A      0.686
 0.823
P2V5_STBY     Normal          2.484   V      N/A      N/A      2.279
 2.734
P12V          Normal          11.977   V      N/A      N/A      11.210
 12.803
P5V           Normal          5.031   V      N/A      N/A      4.680
 5.335
P3V3         Normal          3.276   V      N/A      N/A      3.089
 3.526
P1V5_SSB     Normal          1.482   V      N/A      N/A      1.412
 1.607
P1V1_SSB     Normal          1.084   V      N/A      N/A      1.037
 1.178
PVTT_P1      Normal          0.991   V      N/A      N/A      0.944
 1.061
PVTT_P2      Normal          0.975   V      N/A      N/A      0.944
 1.061
PVSA_P1      Normal          0.959   V      N/A      N/A      0.593
 1.170

Server server /sensor #

```





## CHAPTER 7

# Managing Remote Presence

---

This chapter includes the following sections:

- [Managing the Virtual KVM, on page 103](#)
- [Configuring Virtual Media, on page 107](#)
- [Managing Serial over LAN, on page 112](#)

## Managing the Virtual KVM

### Virtual KVM Console

The vKVM console is an interface accessible from Cisco IMC that emulates a direct keyboard, video, and mouse (vKVM) connection to the server. The vKVM console allows you to connect to the server from a remote location.

Here are a few major advantages of using Cisco KVM Console:

- The Cisco KVM console provides connection to KVM, SOL, and vMedia whereas the Avocent KVM provides connection only to KVM and vMedia.
- In the KVM Console, the vMedia connection is established at the KVM Launch Manager and is available for all users.
- The KVM console offers you an advanced character replacement options for the unsupported characters while pasting text from the guest to the host.
- The KVM console provides you an ability to store the vMedia mappings on CIMC.

Instead of using CD/DVD or floppy drives physically connected to the server, the vKVM console uses virtual media, which are actual disk drives or disk image files that are mapped to virtual CD/DVD or floppy drives. You can map any of the following to a virtual drive:

- CD/DVD or floppy drive on your computer
- Disk image files (ISO or IMG files) on your computer
- USB flash drive on your computer
- CD/DVD or floppy drive on the network

- Disk image files (ISO or IMG files) on the network
- USB flash drive on the network

You can use the vKVM console to install an OS on the server.



**Note** To configure the vKVM console successfully for the S3260 Storage Server, you need to configure IP addresses for the Cisco IMC, CMC, and BMC components. You can configure the IP addresses for these components using the CLI interface or Web UI. For the CLI, use the command **scope network**, or view the setting using **scope <chassis/server1/2><cmc/bmc><network>**.

To configure IP addresses for network components on the web interface, see the steps described in the section **Configuring Network-Related Settings**.



**Note** The vKVM Console is operated only through the GUI. To launch the vKVM Console, see the instructions in the *Cisco UCS C-Series Servers Integrated Management Controller GUI Configuration Guide*.

## Enabling the Virtual KVM

### Before you begin

You must log in as a user with admin privileges to enable the virtual KVM.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /server # <b>scope kvm</b>	Enters KVM command mode.
<b>Step 3</b>	Server /server/kvm # <b>set enabled yes</b>	Enables the virtual KVM.
<b>Step 4</b>	Server /server/kvm # <b>commit</b>	Commits the transaction to the system configuration.
<b>Step 5</b>	Server /server/kvm # <b>show [detail]</b>	(Optional) Displays the virtual KVM configuration.

### Example

This example enables the virtual KVM:

```
Server# scope server 1
Server /server # scope kvm
Server /server/kvm # set enabled yes
Server /server/kvm *# commit
Server /server/kvm # show detail
```

```

KVM Settings:
  Encryption Enabled: yes
  Max Sessions: 4
  Local Video: yes
  Active Sessions: 1
  Enabled: yes
  KVM Port: 2068

Server /server/kvm #

```

## Disabling the Virtual KVM

### Before you begin

You must log in as a user with admin privileges to enable the virtual KVM.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /server # <b>scope kvm</b>	Enters KVM command mode.
<b>Step 3</b>	Server /server /kvm # <b>set enabled no</b>	Disables the virtual KVM.  <b>Note</b> Disabling the virtual KVM disables access to the virtual media feature, but does not detach the virtual media devices if virtual media is enabled.
<b>Step 4</b>	Server /server/kvm # <b>commit</b>	Commits the transaction to the system configuration.
<b>Step 5</b>	Server /server/kvm # <b>show [detail]</b>	(Optional) Displays the virtual KVM configuration.

### Example

This example enables the virtual KVM:

```

Server# scope server 1
Server /server # scope kvm
Server /server/kvm # set enabled no
Server /server/kvm *# commit
Server /server/kvm # show detail
KVM Settings:
  Encryption Enabled: yes
  Max Sessions: 4
  Local Video: yes
  Active Sessions: 0
  Enabled: no
  KVM Port: 2068

Server /server/kvm #

```

## Configuring the Virtual KVM

### Before you begin

You must log in as a user with admin privileges to configure the virtual KVM.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /server# <b>scope kvm</b>	Enters KVM command mode.
<b>Step 3</b>	Server /server/kvm # <b>set enabled</b> {yes   no}	Enables or disables the virtual KVM.
<b>Step 4</b>	Server /server/kvm # <b>set encrypted</b> {yes   no}	If encryption is enabled, the server encrypts all video information sent through the KVM.
<b>Step 5</b>	Server /server/kvm # <b>set kvm-port</b> <i>port</i>	Specifies the port used for KVM communication.
<b>Step 6</b>	Server /server/kvm # <b>set local-video</b> {yes   no}	If local video is <b>yes</b> , the KVM session is also displayed on any monitor attached to the server.
<b>Step 7</b>	Server /server/kvm # <b>set max-sessions</b> <i>sessions</i>	Specifies the maximum number of concurrent KVM sessions allowed. The <i>sessions</i> argument is an integer between 1 and 4.
<b>Step 8</b>	Server /server/kvm # <b>commit</b>	Commits the transaction to the system configuration.
<b>Step 9</b>	Server /server/kvm # <b>show</b> [ <b>detail</b> ]	(Optional) Displays the virtual KVM configuration.

### Example

This example configures the virtual KVM and displays the configuration:

```
Server# scope server 1
Server /server # scope kvm
Server /server/kvm # set enabled yes
Server /server/kvm *# set encrypted no
Server /server/kvm *# set kvm-port 2068
Server /server/kvm *# set max-sessions 4
Server /server/kvm *# set local-video yes
Server /server/kvm *# commit
Server /server/kvm # show detail
KVM Settings:
  Encryption Enabled: no
  Max Sessions: 4
  Local Video: yes
  Active Sessions: 0
  Enabled: yes
  KVM Port: 2068
```

```
Server /server/kvm #
```

### What to do next

Launch the virtual KVM from the GUI.

## Configuring Virtual Media

### Before you begin

You must log in as a user with admin privileges to configure virtual media.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope vmedia</b>	Enters virtual media command mode.
<b>Step 2</b>	Server /vmedia # <b>set enabled {yes   no}</b>	Enables or disables virtual media. By default, virtual media is disabled.  <b>Note</b> Disabling virtual media detaches the virtual CD, virtual floppy, and virtual HDD devices from the host.
<b>Step 3</b>	Server /vmedia # <b>set encryption {yes   no}</b>	Enables or disables virtual media encryption.
<b>Step 4</b>	Server /vmedia # <b>set low-power-usb-enabled {yes   no}</b>	Enables or disables low power USB.  <b>Note</b> While mapping an ISO to a server which has a UCS VIC P81E card and the NIC is in Cisco Card mode: <ul style="list-style-type: none"> <li>• If the low power USB is enabled, after mapping the ISO and rebooting the host the card resets and ISO mapping is lost. The virtual drives are not visible on the boot selection menu.</li> <li>• If the low power USB is disabled, after mapping the ISO, and rebooting the host and the Cisco IMC, the virtual drivers appear on the boot selection menu as expected.</li> </ul>
<b>Step 5</b>	Server /vmedia # <b>commit</b>	Commits the transaction to the system configuration.

	Command or Action	Purpose
<b>Step 6</b>	Server /vmedia # <b>show [detail]</b>	(Optional) Displays the virtual media configuration.

### Example

This example configures virtual media encryption:

```
Server# scope vmedia
Server /vmedia # set enabled yes
Server /vmedia *# set encryption yes
Server /vmedia *# set low-power-use-enabled no
Server /vmedia *# commit
Server /vmedia # show detail
vMedia Settings:
  Encryption Enabled: yes
  Enabled: yes
  Max Sessions: 1
  Active Sessions: 0
  Low Power USB Enabled: no

Server /vmedia #
```

### What to do next

Use the KVM to attach virtual media devices to a host.

## Configuring a Cisco IMC-Mapped vMedia Volume

### Before you begin

You must log in with admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server {1   2}</b>	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /server# <b>scope vmedia</b>	Enters the virtual media command mode.
<b>Step 3</b>	Server /server/vmedia # <b>map-cifs</b> { <b>volume-name</b>   <b>remote-share</b>   <b>remote-file-path</b> [ <i>mount options</i> ]	Maps a CIFS file for vMedia. You must specify the following: <ul style="list-style-type: none"> <li>• Name of the volume to create</li> <li>• Remote share including IP address and the exported directory</li> <li>• Path of the remote file corresponding to the exported directory.</li> <li>• (Optional) Mapping options</li> </ul>

	Command or Action	Purpose
		<ul style="list-style-type: none"> <li>• Username and password to connect to the server</li> </ul>
<b>Step 4</b>	Server /server/vmedia # <b>map-nfs</b> { <b>volume-name</b>   <b>remote-share</b>   <b>remote-file-path</b> } [ <i>mount options</i> ]	<p>Maps an NFS file for vMedia. You must specify the following:</p> <ul style="list-style-type: none"> <li>• Name of the volume to create</li> <li>• Remote share including IP address and the exported directory</li> <li>• Path of the remote file corresponding to the exported directory.</li> <li>• (Optional) Mapping options</li> </ul>
<b>Step 5</b>	Server /server/vmedia # <b>map-www</b> { <b>volume-name</b>   <b>remote-share</b>   <b>remote-file-path</b> } [ <i>mount options</i> ]	<p>Maps an HTTPS file for vMedia. You must specify the following:</p> <ul style="list-style-type: none"> <li>• Name of the volume to create</li> <li>• Remote share including IP address and the exported directory</li> <li>• Path of the remote file corresponding to the exported directory.</li> <li>• (Optional) Mapping options</li> <li>• Username and password to connect to the server</li> </ul>

### Example

This example shows how to create a CIFS Cisco IMC-mapped vmedia settings:

```
Server # scope server 1
Server /server #scope vmedia
Server /server/vmedia # map-cifs sample-volume //10.10.10.10/project /test/sample
Server username:
Server password: ****
Confirm password: ****

Server /server/vmedia #
```

## Viewing Cisco IMC-Mapped vMedia Volume Properties

### Before you begin

You must log in with admin privileges to perform this task.

**Procedure**

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /server # <b>scope vmedia</b>	Enters the virtual media command mode.
<b>Step 3</b>	Server /server/vmedia # <b>show mappings detail</b>	Displays information on all the vmedia mapping that are configured.

**Example**

This example shows how to view the properties of all the configured vmedia mapping:

```
Server # scope server 1
Server /server/ scope vmedia
Server /server/vmedia # show mappings
```

Volume	Map-status	Drive-type	remote-share	remote-file	mount-type
Huu	OK	removable	http://10.104.236.99/	rhel-server-6.1-x86_64.iso	www
Rhel	OK	CD	http://10.104.236.99/	rhel-server-6.1-x86_64.iso	www

```
Server /server/vmedia #
```

## Remapping an Existing Cisco IMC vMedia Image

**Before you begin**

You must log in with user or admin privileges to perform this task.

**Procedure**

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope vmedia</b>	Enters the vMedia command mode.
<b>Step 2</b>	Server /vmedia # <b>show saved-mappings</b>	Displays the available saved mappings.
<b>Step 3</b>	Server /vmedia # <b>remap mapping volume</b>	Remaps the vMedia.  <b>Note</b> You must use the volume name of the saved mapping as the variable for this command.
<b>Step 4</b>	(Optional) Server /vmedia # <b>show mappings</b>	Displays the mapped vMedia details.



### Example

This example shows how to remap a vMedia image to a saved mapping:

```

Server # scope vmedia
Server/vmedia # remap huu
Server/vmedia # show mappings
Volume           Map-Status           Drive-Type Remote-Share           Remote-File
                Mount-Type
-----
huu              OK                   CD          https://10.104.236.99...
ucs-c240-huu-3.0.0.33... www
Server/vmedia # show saved-mappings
Volume           Drive-Type Remote-Share           Remote-File           Mount-Type
-----
huu              CD          https://10.104.236.99... ucs-c240-huu-3.0.0.33... www
Server/vmedia #

```

## Deleting a Cisco IMC vMedia Image

### Before you begin

You must log in with user or admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope vmedia</b>	Enters the vMedia command mode.
<b>Step 2</b>	Server /vmedia # <b>delete-saved-mappings</b>	Enter <b>yes</b> in the confirmation prompt. Deletes the saved mapping.
<b>Step 3</b>	Server /vmedia # <b>show saved-mappings</b>	Does not display any saved mapping as it is deleted.

### Example

This example shows how to delete a saved mapping:

```

Server # scope vmedia
Server/vmedia # show saved-mappings
Volume           Drive-Type Remote-Share           Remote-File           Mount-Type
-----
huu              CD          https://10.104.236.99... ucs-c240-huu-3.0.0.33... www
Server/vmedia # delete-saved-mappings
Purge saved mappings? Enter 'yes' to confirm -> yes
Server/vmedia # show saved-mappings
Server/vmedia #

```

# Managing Serial over LAN

## Serial Over LAN

Serial over LAN (SoL) is a mechanism that enables the input and output of the serial port of a managed system to be redirected via an SSH session over IP. SoL provides a means of reaching the host console via Cisco IMC.

### Guidelines and Restrictions for Serial Over LAN

For redirection to SoL, the server console must have the following configuration:

- console redirection to serial port A
- no flow control
- baud rate the same as configured for SoL
- VT-100 terminal type
- legacy OS redirection disabled

The SoL session will display line-oriented information such as boot messages, and character-oriented screen menus such as BIOS setup menus. If the server boots an operating system or application with a bitmap-oriented display, such as Windows, the SoL session will no longer display. If the server boots a command-line-oriented operating system (OS), such as Linux, you may need to perform additional configuration of the OS in order to properly display in an SoL session.

In the SoL session, your keystrokes are transmitted to the console except for the function key F2. To send an F2 to the console, press the Escape key, then press 2.

## Configuring Serial Over LAN

### Before you begin

You must log in as a user with admin privileges to configure serial over LAN (SoL).

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /server# <b>scope sol</b>	Enters SoL command mode.
<b>Step 3</b>	Server /server/sol # <b>set enabled</b> {yes   no}	Enables or disables SoL on this server.
<b>Step 4</b>	Server /server/sol # <b>set baud-rate</b> {9600   19200   38400   57600   115200}	Sets the serial baud rate the system uses for SoL communication.

	Command or Action	Purpose
		<p><b>Note</b> The baud rate must match the baud rate configured in the server serial console.</p>
<b>Step 5</b>	(Optional) Server <code>/server/sol # set comport {com0   com1}</code>	<p>Sets the serial port through which the system routes SoL communications.</p> <p><b>Note</b> This option is only available on some C-Series servers. If it is not available, the server always uses COM port 0 for SoL communication.</p> <p>You can specify:</p> <ul style="list-style-type: none"> <li>• <b>com0</b>—SoL communication is routed through COM port 0, an externally accessible serial port that supports either a physical RJ45 connection to an external device or a virtual SoL connection to a network device.</li> </ul> <p>If you select this option, the system enables SoL and disables the RJ45 connection, which means that the server can no longer support an external serial device.</p> <ul style="list-style-type: none"> <li>• <b>com1</b>—SoL communication is routed through COM port 1, an internal port accessible only through SoL.</li> </ul> <p>If you select this option, you can use SoL on COM port 1 and the physical RJ45 connection on COM port 0.</p> <p><b>Note</b> Changing the comport setting disconnects any existing SoL sessions.</p>
<b>Step 6</b>	Server <code>/sol # commit</code>	Commits the transaction to the system configuration.
<b>Step 7</b>	Server <code>/sol # show [detail]</code>	(Optional) Displays the SoL settings.

### Example

This example configures SoL:

```
Server# scope server 1
Server /server #scope sol
Server /server/sol # set enabled yes
Server /server/sol *# set baud-rate 115200
```

```
Server /server/sol *# set comport com1
Server /server/sol *# commit
Server /server/sol # show
Enabled Baud Rate(bps)  Com Port
-----
yes      115200          com1
Server /sol # show detail
Serial Over LAN:
  Enabled: yes
  Baud Rate(bps): 115200
  Com Port: com1
Server /server/sol #
```



## CHAPTER 8

# Managing User Accounts

This chapter includes the following sections:

- [Configuring Local Users, on page 115](#)
- [Non-IPMI User Mode, on page 117](#)
- [Disabling Strong Password, on page 119](#)
- [Password Expiry, on page 120](#)
- [Resetting the User Password, on page 121](#)
- [Configuring Password Expiry for Users, on page 122](#)
- [LDAP Servers, on page 123](#)
- [Configuring the LDAP Server, on page 123](#)
- [Configuring LDAP in Cisco IMC, on page 124](#)
- [Configuring LDAP Groups in Cisco IMC, on page 126](#)
- [Configuring Nested Group Search Depth in LDAP Groups, on page 128](#)
- [LDAP Certificates Overview, on page 129](#)
- [Setting User Search Precedence, on page 135](#)
- [Viewing User Sessions, on page 135](#)
- [Terminating a User Session, on page 136](#)

## Configuring Local Users

### Before you begin

You must log in as a user with admin privileges to configure or modify local user accounts.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope user</b> <i>usernumber</i>	Enters user command mode for user number <i>usernumber</i> .
<b>Step 2</b>	Server /user # <b>set enabled</b> { <b>yes</b>   <b>no</b> }	Enables or disables the user account on the Cisco IMC.
<b>Step 3</b>	Server /user # <b>set name</b> <i>username</i>	Specifies the username for the user.

	Command or Action	Purpose
<b>Step 4</b>	Server /user # <b>set password</b>	<p>You are prompted to enter the password twice.</p> <p><b>Note</b> When strong password is enabled, you must follow these guidelines while setting a password:</p> <ul style="list-style-type: none"> <li>• The password must have a minimum of 8 and a maximum of 14 characters.</li> <li>• The password must not contain the User's Name.</li> <li>• The password must contain characters from three of the following four categories: <ul style="list-style-type: none"> <li>• English uppercase characters (A through Z)</li> <li>• English lowercase characters (a through z)</li> <li>• Base 10 digits (0 through 9)</li> <li>• Non-alphabetic characters (!, @, #, \$, %, ^, &amp;, *, -, _, +, =)</li> </ul> </li> </ul> <p>when strong password is disabled, you can set a password using characters of your choice (alphanumeric, special characters, or integers) within the range 1-20.</p>
<b>Step 5</b>	Server /user # <b>set role {readonly   user   admin}</b>	<p>Specifies the role assigned to the user. The roles are as follows:</p> <ul style="list-style-type: none"> <li>• <b>readonly</b>—This user can view information but cannot make any changes.</li> <li>• <b>user</b>—This user can do the following: <ul style="list-style-type: none"> <li>• View all information</li> <li>• Manage the power control options such as power on, power cycle, and power off</li> <li>• Launch the KVM console and virtual media</li> <li>• Clear all logs</li> </ul> </li> </ul>

	Command or Action	Purpose
		<ul style="list-style-type: none"> <li>• Toggle the locator LED</li> <li>• Set the time zone</li> <li>• Ping an IP address</li> <li>• admin—This user can perform all actions available through the GUI, CLI, and IPMI.</li> </ul>
<b>Step 6</b>	Server /user # <b>commit</b>	Commits the transaction to the system configuration.

### Example

This example configures user 5 as an admin:

```
Server# scope user 5
Server /user # set enabled yes
Server /user *# set name john
Server /user *# set password
Warning:
Strong Password Policy is enabled!
```

```
For CIMC protection your password must meet the following requirements:
    The password must have a minimum of 8 and a maximum of 14 characters.
    The password must not contain the User's Name.
    The password must contain characters from three of the following four categories.
        English uppercase characters (A through Z)
        English lowercase characters (a through z)
        Base 10 digits (0 through 9)
```

```
Please enter password:
Please confirm password:
Server /user *# set role readonly
Server /user *# commit
Server /user # show
User  Name          Role      Enabled
-----
5     john             readonly yes
```

## Non-IPMI User Mode

Release 4.1 introduces a new user configuration option called **User Mode** that allows you to switch between IPMI and non-IPMI user modes. Introduction of the non-IPMI user mode provides enhanced password security for users and security enhancements to the BMC database that were restricted in earlier releases due to the constraints posed by the IPMI 2.0 standards. Non-IPMI user mode allows you to use 127 characters to set user passwords whereas users in IPMI mode are restricted to a password length of 20 characters. Non-IPMI user mode enables you to set stronger passwords for users configured in this mode.

You must consider the following configuration changes that occur while switching between user modes, when you:

- Switch to the non-IPMI mode, IPMI over LAN will not be supported.

- Switch from the non-IPMI to IPMI mode, deletes all the local users and reverts user credentials to default username and password. On subsequent login, you will be prompted to change the password.

User data is not affected when you switch from IPMI to non-IPMI mode.

- Downgrade the firmware to a versions lower than 4.1 and if the user mode is non-IPMI, deletes all the local users and reverts user credentials to default username and password. On subsequent login, you will be prompted to change the default password.



**Note** When you reset to factory defaults, the user mode reverts to IPMI mode.

## Switching User Mode from IPMI to Non-IPMI

### Before you begin

You must log in as a user with admin privileges to perform this action.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope user-policy</b>	Enters user policy command mode.
<b>Step 2</b>	Server /user-policy # <b>scope user-mode</b>	Enters user mode command mode.
<b>Step 3</b>	Server /user-policy/user-mode # <b>set user-mode non-ipmi</b>	Enter y at the confirmation prompt to switch to Non-IPMI user mode.
<b>Step 4</b>	Server /user-policy/user-mode * # <b>commit</b>	Commits the transaction to the system configuration.
<b>Step 5</b>	Server /user-policy/user-mode # <b>show detail</b>	Displays the user mode.

### Example

This example shows how to disable strong password:

```
Server# scope user-policy
Server /user-policy # scope user-mode
Server /user-policy/user-mode # set user-mode non-ipmi
Server /user-policy/user-mode *# commit
Warning: This will enable NON-IPMI based user mode.
        Converting to Non-IPMI User Mode disables IPMI Services and removes IPMI user
support.
        SSH, KVM, Webserver, XMAPi and Redfish sessions will be disconnected.
Do you wish to continue? [y/N] y
Connection to 10.10.10.10 closed by remote host.
Connection to 10.10.10.10 closed.
Server /user-policy/user-mode # show detail
User Mode:
        User mode for IPMI accessibility: non-ipmi
Server /user-policy/user-mode #
```



## Switching User Mode from Non-IPMI to IPMI

### Before you begin

You must log in as a user with admin privileges to perform this action.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope user-policy</b>	Enters user policy command mode.
<b>Step 2</b>	Server /user-policy # <b>scope user-mode</b>	Enters user mode command mode.
<b>Step 3</b>	Server /user-policy/user-mode # <b>set user-mode ipmi</b>	Enter y at the confirmation prompt to switch to IPMI user mode.  <b>Note</b> Switching to IPMI user mode deletes all the UCS users and reverts to default username and password.
<b>Step 4</b>	Server /user-policy/user-mode * # <b>commit</b>	Commits the transaction to the system configuration.
<b>Step 5</b>	Server /user-policy/user-mode # <b>show detail</b>	Displays the user mode.

### Example

This example shows how to disable strong password:

```
Server# scope user-policy
Server /user-policy # scope user-mode
Server /user-policy/user-mode # set user-mode ipmi
Server /user-policy/user-mode *# commit
Warning: This will enable IPMI based user mode.
        Converting to IPMI User Mode deletes all UCS users and reverts to default
userid/password.
        SSH, KVM, Webserver, XMAPi and Redfish sessions will be disconnected.
Do you wish to continue? [y/N] y
Connection to 10.10.10.10 closed by remote host.
Connection to 10.10.10.10 closed.
Server /user-policy/user-mode # show detail
User Mode:
        User mode for IPMI accessibility: ipmi
Server /user-policy/user-mode #
```

## Disabling Strong Password

The Cisco IMC now implements a strong password policy wherein you are required to follow guidelines and set a strong password when you first log on to the server for the first time. The Cisco IMC CLI provides you option which allows you to disable the strong password policy and set a password of your choice by ignoring

the guidelines. Once you disable the strong password, an Enable Strong Password button is displayed. By default, the strong password policy is enabled.

### Before you begin

You must log in as a user with admin privileges to perform this action.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope user-policy</b>	Enters user policy command mode.
<b>Step 2</b>	Server /user-policy # <b>set password-policy</b> { <b>enabled</b>   <b>disabled</b> }	At the confirmation prompt, enter <b>y</b> to complete the action or <b>n</b> to cancel the action. Enables or disables the strong password.
<b>Step 3</b>	Server /user-policy # <b>commit</b>	Commits the transaction to the system configuration.

### Example

This example shows how to disable strong password:

```
Server# scope user-policy
Server /user-policy # set password-policy disabled
Warning: Strong password policy is being disabled.
Do you wish to continue? [y/N] y
Server /user-policy *# commit
Server /user-policy #
```

## Password Expiry

You can set a shelf life for a password, after which it expires. As an administrator, you can set this time in days. This configuration would be common to all users. Upon password expiry, the user is notified on login and would not be allowed to login unless the password is reset.



### Note

When you downgrade to an older database, existing users are deleted. The database returns to default settings. Previously configured users are cleared and the database is empty, that is, the database has the default username - 'admin' and password - 'password'. Since the server is left with the default user database, the change default credential feature is enabled. This means that when the 'admin' user logs on to the database for the first time after a downgrade, the user must mandatorily change the default credential.

### Password Set Time

A 'Password set time' is configured for every existing user, to the time when the migration or upgrade occurred. For new users (users created after an upgrade), the Password Set time is configured to the time when the user was created, and the password is set. For users in general (new and existing), the Password Set Time is updated whenever the password is changed.

# Resetting the User Password

You can use the change password option to change your password.



## Note

- This option is not available when you login as an admin, you can only change the password of the configured users with read-only user privileges.
- When you change your password you will be logged out of Cisco IMC.

## Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope user</b> <i>user ID</i>	Enters the chosen user command mode.
<b>Step 2</b>	Server /chassis/user # <b>set password</b>	Read the password requirements instructions and enter the current password, new password and confirm the password at the respective prompts.
<b>Step 3</b>	Server /chassis/user * # <b>commit</b>	Commits the transaction to the system configuration.

## Example

This example shows how to change the password of a configured user:

```
Server # scope user 2
Server /chassis/user # set password
Warning:
Strong Password Policy is enabled!
For CIMC protection your password must meet the following requirements:
  The password must have a minimum of 8 and a maximum of 20 characters.
  The password must not contain the User's Name.
  The password must contain characters from three of the following four categories.
    English uppercase characters (A through Z)
    English lowercase characters (a through z)
    Base 10 digits (0 through 9)
    Non-alphabetic characters (!, @, #, $, %, ^, &, *, -, _, +, =)
Please enter current password: Testabcd1
Please enter password: Testabcd2
Please confirm password: Testabcd2
Server /chassis/user * # commit
Server /chassis/user #
```

# Configuring Password Expiry for Users

## Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope user-policy</b>	Enters the user policy command mode.
<b>Step 2</b>	Server /user-policy # <b>scope password-expiration</b>	Enters the password expiration command mode.
<b>Step 3</b>	Server /user-policy/password-expiration # <b>set password-expiry-duration</b> <i>integer in the range 0-3650</i>	The time period that you can set for the existing password to expire (from the time you set a new password or modify an existing one). The range is between 0 to 3650 days. Entering 0 disables this option.
<b>Step 4</b>	Server /user-policy/password-expiration * # <b>set notification-period</b> <i>integer in the range 0-15</i>	Notifies the time by when the password expires. Enter a value between 0 to 15 days. Entering 0 disables this option.
<b>Step 5</b>	Server /user-policy/password-expiration * # <b>set grace-period</b> <i>integer in the range 0-5</i>	Time period till when the existing password can still be used, after it expires. Enter a value between 0 to 5 days. Entering 0 disables this option.
<b>Step 6</b>	Server /user-policy/password-expiration * # <b>set password-history</b> <i>integer in the range 0-5</i>	The number of occurrences when a password was entered. When this is enabled, you cannot repeat a password. Enter a value between 0 to 5. Entering 0 disables this option.
<b>Step 7</b>	Server /user-policy/password-expiration * # <b>commit</b>	Commits the transactions.
<b>Step 8</b>	(Optional) Server /user-policy/password-expiration # <b>show detail</b>	Shows the password expiration details.
<b>Step 9</b>	(Optional) Server /user-policy/password-expiration # <b>restore</b>	At the confirmation prompt, enter <b>yes</b> to restore the password expiry settings to default values.

## Example

This example sets the password expiration and restore the settings to default vales:

```
Server # scope user-policy
Server /user-policy # scope password-expiration
Server /user-policy/password-expiration # set password-expiry-duration 5
Server /user-policy/password-expiration * # set notification-period 2
Server /user-policy/password-expiration * # set grace-period 1
Server /user-policy/password-expiration * # set password-history 4
Server /user-policy/password-expiration * # commit
Server /user-policy/password-expiration # show detail
```

```

Password expiration parameters:
Valid password duration: 5
Number of stored old passwords: 4
Notification period: 2
Grace period: 1
Server /user-policy/password-expiration #
Restoring the password expiry parameters to default values:
Server /user-policy/password-expiration # restoreAre you sure you want to restore
User password expiration parameters to defaults?
Please enter 'yes' to confirm:yes
Server /user-policy/password-expiration #

```

## LDAP Servers

Cisco IMC supports directory services that organize information in a directory, and manage access to this information. Cisco IMC supports Lightweight Directory Access Protocol (LDAP), which stores and maintains directory information in a network. In addition, Cisco IMC supports Microsoft Active Directory (AD). Active Directory is a technology that provides a variety of network services including LDAP-like directory services, Kerberos-based authentication, and DNS-based naming. The Cisco IMC utilizes the Kerberos-based authentication service of LDAP.

When LDAP is enabled in the Cisco IMC, user authentication and role authorization is performed by the LDAP server for user accounts not found in the local user database. The LDAP user authentication format is `username@domain.com`.

By enabling encryption in the configuration of Active Directory on the server, you can require the server to encrypt data sent to the LDAP server.

## Configuring the LDAP Server

The Cisco IMC can be configured to use LDAP for user authentication and authorization. To use LDAP, configure users with an attribute that holds the user role and locale information for the Cisco IMC. You can use an existing LDAP attribute that is mapped to the Cisco IMC user roles and locales or you can modify the LDAP schema to add a new custom attribute, such as the `CiscoAVPair` attribute, which has an attribute ID of 1.3.6.1.4.1.9.287247.1.



### Important

For more information about altering the schema, see the article at <http://technet.microsoft.com/en-us/library/bb727064.aspx>.



### Note

This example creates a custom attribute named `CiscoAVPair`, but you can also use an existing LDAP attribute that is mapped to the Cisco IMC user roles and locales.

If you are using Group Authorization on the Cisco IMC LDAP configuration, then you can skip Steps 1-4 and perform the steps listed in the *Configuring LDAP Settings and Group Authorization in Cisco IMC* section.

The following steps must be performed on the LDAP server.

## Procedure

**Step 1** Ensure that the LDAP schema snap-in is installed.

**Step 2** Using the schema snap-in, add a new attribute with the following properties:

Properties	Value
Common Name	CiscoAVPair
LDAP Display Name	CiscoAVPair
Unique X500 Object ID	1.3.6.1.4.1.9.287247.1
Description	CiscoAVPair
Syntax	Case Sensitive String

**Step 3** Add the CiscoAVPair attribute to the user class using the snap-in:

- Expand the **Classes** node in the left pane and type **U** to select the user class.
- Click the **Attributes** tab and click **Add**.
- Type **C** to select the CiscoAVPair attribute.
- Click **OK**.

**Step 4** Add the following user role values to the CiscoAVPair attribute, for the users that you want to have access to Cisco IMC:

Role	CiscoAVPair Attribute Value
admin	shell:roles="admin"
user	shell:roles="user"
read-only	shell:roles="read-only"

**Note** For more information about adding values to attributes, see the article at <http://technet.microsoft.com/en-us/library/bb727064.aspx>.

## What to do next

Use the Cisco IMC to configure the LDAP server.

# Configuring LDAP in Cisco IMC

Configure LDAP in Cisco IMC when you want to use an LDAP server for local user authentication and authorization.

**Before you begin**

You must log in as a user with admin privileges to perform this task.

**Procedure**

	<b>Command or Action</b>	<b>Purpose</b>
<b>Step 1</b>	Server# <b>scope ldap</b>	Enters the LDAP command mode.
<b>Step 2</b>	Server /ldap # <b>set enabled</b> {yes   no}	Enables or disables LDAP security. When enabled, user authentication and role authorization is performed by LDAP for user accounts not found in the local user database.
<b>Step 3</b>	Server /ldap # <b>set domainLDAP</b> <i>domain name</i>	Specifies an LDAP domain name.
<b>Step 4</b>	Server /ldap # <b>set timeout</b> <i>seconds</i>	Specifies the number of seconds the Cisco IMC waits until the LDAP search operation times out. The value must be between 0 and 1800 seconds.
<b>Step 5</b>	Server /ldap # <b>set encrypted</b> {yes   no}	If encryption is enabled, the server encrypts all information sent to AD.
<b>Step 6</b>	Server /ldap # <b>set base-dn</b> <i>domain-name</i>	Specifies the Base DN that is searched on the LDAP server.
<b>Step 7</b>	Server /ldap # <b>set attribute</b> <i>name</i>	<p>Specify an LDAP attribute that contains the role and locale information for the user. This property is always a name-value pair. The system queries the user record for the value that matches this attribute name.</p> <p>You can use an existing LDAP attribute that is mapped to the Cisco IMC user roles and locales or you can create a custom attribute, such as the CiscoAVPair attribute, which has the following attribute ID:</p> <p>1.3.6.1.4.1.9.287247.1</p> <p><b>Note</b> If you do not specify this property, user access is denied.</p>
<b>Step 8</b>	Server /ldap # <b>set filter-attribute</b>	Specifies the account name attribute. If Active Directory is used, then specify <b>sAMAccountName</b> for this field.
<b>Step 9</b>	Server /ldap # <b>commit</b>	Commits the transaction to the system configuration.
<b>Step 10</b>	Server /ldap # <b>show</b> [detail]	(Optional) Displays the LDAP configuration.

### Example

This example configures LDAP using the CiscoAVPair attribute:

```

Server# scope ldap
Server /ldap # set enabled yes
Server /ldap *# set domain sample-domain
Server /ldap *# set timeout 60
Server /ldap *# set encrypted yes
Server /ldap *# set base-dn example.com
Server /ldap *# set attribute CiscoAVPair
Server /ldap *# set filter-attribute sAMAccountName
Server /ldap *# commit
Server /ldap # show detail
LDAP Settings:
  Enabled: yes
  Encrypted: yes
  Domain: sample-domain
  BaseDN: example.com
  Timeout: 60
  Filter-Attribute: sAMAccountName
  Attribute: CiscoAvPair
Server /ldap #

```

### What to do next

If you want to use LDAP groups for group authorization, see *Configuring LDAP Groups in Cisco IMC*.

## Configuring LDAP Groups in Cisco IMC



### Note

When Active Directory (AD) group authorization is enabled and configured, user authentication is also done on the group level for users that are not found in the local user database or who are not individually authorized to use Cisco IMC in the Active Directory.

### Before you begin

- You must log in as a user with admin privileges to perform this task.
- Active Directory (or LDAP) must be enabled and configured.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope ldap</b>	Enters the LDAP command mode for AD configuration.
<b>Step 2</b>	Server /ldap# <b>scope ldap-group-rule</b>	Enters the LDAP group rules command mode for AD configuration.



	Command or Action	Purpose
<b>Step 3</b>	Server /ldap/ldap-group-rule # <b>set group-auth</b> {yes   no}	Enables or disables LDAP group authorization.
<b>Step 4</b>	Server /ldap # <b>scope role-group</b> <i>index</i>	Selects one of the available group profiles for configuration, where <i>index</i> is a number between 1 and 28.
<b>Step 5</b>	Server /ldap/role-group # <b>set name</b> <i>group-name</i>	Specifies the name of the group in the AD database that is authorized to access the server.
<b>Step 6</b>	Server /ldap/role-group # <b>set domain</b> <i>domain-name</i>	Specifies the AD domain the group must reside in.
<b>Step 7</b>	Server /ldap/role-group # <b>set role</b> {admin   user   readonly}	Specifies the permission level (role) assigned to all users in this AD group. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>admin</b>—The user can perform all actions available.</li> <li>• <b>user</b>—The user can perform the following tasks: <ul style="list-style-type: none"> <li>• View all information</li> <li>• Manage the power control options such as power on, power cycle, and power off</li> <li>• Launch the KVM console and virtual media</li> <li>• Clear all logs</li> <li>• Toggle the locator LED</li> </ul> </li> <li>• <b>readonly</b>—The user can view information but cannot make any changes.</li> </ul>
<b>Step 8</b>	Server /ldap/role-group # <b>commit</b>	Commits the transaction to the system configuration.

### Example

This example shows how to configure LDAP group authorization:

```
Server# scope ldap
Server /ldap # scope ldap-group-rule
Server /ldap/ldap-group-rule # set group-auth yes
Server /ldap *# scope role-group 5
Server /ldap/role-group # set name Training
Server /ldap/role-group* # set domain example.com
Server /ldap/role-group* # set role readonly
Server /ldap/role-group* # commit
```

```
ucs-c250-M2 /ldap # show role-group
Group  Group Name      Domain Name      Assigned Role
-----
1      (n/a)              (n/a)           admin
2      (n/a)              (n/a)           user
3      (n/a)              (n/a)           readonly
4      (n/a)              (n/a)           (n/a)
5      Training           example.com     readonly

Server /ldap/role-group #
```

## Configuring Nested Group Search Depth in LDAP Groups

You can search for an LDAP group nested within another defined group in an LDAP group map.

- You must log in as a user with admin privileges to perform this task.
- Active Directory (or LDAP) must be enabled and configured.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope ldap</b>	Enters the LDAP command mode for AD configuration.
<b>Step 2</b>	Server /ldap# <b>scope ldap-group-rule</b>	Enters the LDAP group rules command mode for AD configuration.
<b>Step 3</b>	Server /ldap/ldap-group-rule # <b>set group-search-depth value</b>	Enables search for a nested LDAP group.
<b>Step 4</b>	Server /ldap/role-group-rule # <b>commit</b>	Commits the transaction to the system configuration.

### Example

This example shows how to search for run a search for an LDAP group nested within another defined group.

```
Server# scope ldap
Server /ldap # scope ldap-group-rule
Server /ldap/ldap-group-rule # set group-search-depth 10
Server /ldap/role-group-rule* # commit
Server /ldap/role-group-rule # show detail
Group rules for LDAP:
  Group search attribute: memberOf
  Enable Group Authorization: yes
  Nested group search depth: 10
Server/ldap/ldap-group-rule #
```

# LDAP Certificates Overview

Cisco S3260 C-series servers allow an LDAP client to validate a directory server certificate against an installed CA certificate or chained CA certificate during an LDAP binding step. This feature is introduced in the event where anyone can duplicate a directory server for user authentication and cause a security breach due to the inability to enter a trusted point or chained certificate into the Cisco IMC for remote user authentication.

An LDAP client needs a new configuration option to validate the directory server certificate during the encrypted TLS/SSL communication.

## Exporting LDAP CA Certificate

### Before you begin

You must log in as a user with admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope ldap</b>	Enters the LDAP command mode.
<b>Step 2</b>	Server# /ldap <b>scope binding-certificate</b>	Enters the LDAP CA certificate binding command mode.
<b>Step 3</b>	Server /ldap/binding-certificate # <b>export-ca-certificate</b> <i>remote-protocol IP Address LDAP CA Certificate file</i>	Specifies the protocol to connect to the remote server. It can be of the following types: <ul style="list-style-type: none"> <li>• TFTP</li> <li>• FTP</li> <li>• SFTP</li> <li>• SCP</li> <li>• HTTP</li> </ul>

	Command or Action	Purpose
		<p><b>Note</b> The Cisco UCS C-Series server now supports fingerprint confirmation of the server when you update firmware through a remote server. This option is available only if you choose SCP or SFTP as the remote server type.</p> <p>If you chose SCP or SFTP as the remote server type while performing this action, a prompt with the message Server (RSA) key fingerprint is &lt;server_finger_print_ID&gt; Do you wish to continue? Click y or n depending on the authenticity of the server fingerprint.</p> <p>The fingerprint is based on the host's public key and helps you to identify or verify the host you are connecting to.</p> <p>Initiates the export of the certificate.</p>

### Example

This example exports the LDAP certificate:

```
Server # scope ldap
Server /ldap # scope binding-certificate
Server /ldap/binding-certificate # export-ca-certificate tftp 172.22.141.66 test.csv
Initiating Export
  % Total      % Received % Xferd  Average Speed   Time    Time       Time  Current
                                 Dload  Upload    Total   Spent    Left   Speed
 100 1262    0    0  100 1262      0  1244  0:00:01  0:00:01  --:--:-- 1653
 100 1262    0    0  100 1262      0  1237  0:00:01  0:00:01  --:--:-- 1237
LDAP CA Certificate is exported successfully
Server /ldap/binding-certificate #
```

## Downloading LDAP CA Certificate Content by Copying Content

### Before you begin

You must log in as a user with admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# scope ldap	Enters the LDAP command mode.

	Command or Action	Purpose
<b>Step 2</b>	Server# /ldap <b>scope binding-certificate</b>	Enters the LDAP CA certificate binding command mode.
<b>Step 3</b>	Server# /ldap/binding-certificate <b>set enabled {yes   no}</b>	Enables or disables LDAP CA certificate binding.
<b>Step 4</b>	Server /ldap/binding-certificate* # <b>commit</b>	Commits the transaction to the system configuration.
<b>Step 5</b>	Server /ldap/binding-certificate # <b>paste-ca-certificate</b>	Prompts you to paste the certificate content.
<b>Step 6</b>	Paste the certificate content and press <b>CTRL+D</b> .	Confirmation prompt appears.
<b>Step 7</b>	At the confirmation prompt, enter <b>y</b> .	This begins the download of the LDAP CA certificate.

**Example**

This example downloads the LDAP certificate:

```

Server # scope ldap
Server /ldap # scope binding-certificate
Server /ldap/binding-certificate # set enabled yes
Server /ldap/binding-certificate *# commit
Server /ldap/binding-certificate # show detail
LDAP binding with Certificate:
  Enabled: yes
Server /ldap/binding-certificate # paste-ca-certificate
  Please paste your certificate here, when finished, press CTRL+D.
-----BEGIN CERTIFICATE-----
MIIDdzCCAl+gAwIBAgIQV06yJcJPAYNO8Cp+FYQttjANBgkqhkiG9w0BAQsFADBO
MRlWEAYKCIImiZPyLQGBGRYCaW4xGzAZBgoJkiaJk/IsZAEZFgs0T0JKUkEySkhC
UTEbMBkGAlUEAxMSV01OLTRPQkpSQTKSEJRLUNBMB4XDTE2MDIyNTE3MDczNl0X
DTIxmDIyNTE3MTczM1owTjESMBAGCgMSJomT8ixkARKWAmLRswGQYKCIImiZPy
LQGBGRYLINE9CS1JBMkpIQlExGzAZBgNVBAMTEldJTj00T0JKUkEySkhCUS1DQTC
ASiWdQYJKoZIhvcNAQEBBQADggEPADCCAQoCggEBAMM2cdgmrPTkZe4K2zI+EbeZ
mfQnjffiUz8OIY97w8lC/2S4qK46T+fnXl3rXe8vvVHA05wgPDVQTGS4nlF46A6Ba
FK+krKcIqFrQB1gnF74qs/ln1YtKHNbjrvG5KyeWFrA7So6Mi2XEw8w/zMPL0d8T
b+LM1YnhnuXA9G8gVCJ/iUhXfMpB20L8sv30Mek7bw8x2cxJYTuJAViVIRjSwU5j
fO3WKttRuyFpeOIi00weklpF0+8D3Z9mBinoTbL2pl0U32am6wTI+8WmtJ+8W68v
jh4Y8YBY/kzMHdpwjpZkC5pE9Bcm0rL9xKoIu6X0kSNEssoGnepFyNaH3t8vnMC
AwEAAaNRME8wCwYDVR0PBAQDAGGMA8GA1UdEwEB/wQFMAMBAf8wHQYDVR0OBBYE
FBAUulHTAWBT1OBz8IqAEzXsfccsMBAGCSsGAQQBggjcvAQQDAGEA0GCSqGSIb3
DQEBChUAA4IBAQAzUMZr+0rldWkVfFNbd7lu8tQbAEJf/A7PIKnJGNoUq8moAGS4
pMndoxdpNGZhYCWDX3GWdeF1HqZHhb38gGQ9ylu0pIK7tgQufZmeCBH6T7Tzq/w
Dq+TMFGIjXF84xW3N665y4ePgUcUI7e/6aBGcGkGeUYodBptExe28tQyeyWd4Zj
nLuZKkT+I4PAYyVCqxDGsvfRHdpGneb3R+GeonOf4ED/0tn5PLSL9khh9qkHu/V
do3/HmKVzUhl0TDBuAMq/wES2WZAWHGr3hBc4nWQnjZWEMOKDpYZVK/GhBmNF+xi
eRcFqgh64oEmH9qAp0caGS1e7UyYaN+LtPRE
-----END CERTIFICATE-----
CTRL+D
  You are going to overwrite the LDAP CA Certificate.
  Are you sure you want to proceed and overwrite the LDAP CA Certificate? [y|N]
y
Server /ldap/binding-certificate #
    
```

## Downloading LDAP CA Certificate Using Remote Server

### Before you begin

You must log in as a user with admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope ldap</b>	Enters the LDAP command mode.
<b>Step 2</b>	Server# /ldap <b>scope binding-certificate</b>	Enters the LDAP CA certificate binding command mode.
<b>Step 3</b>	Server# /ldap/binding-certificate <b>set enabled</b> {yes   no}	Enables or disables LDAP CA certificate binding.
<b>Step 4</b>	Server /ldap/binding-certificate* # <b>commit</b>	Commits the transaction to the system configuration.
<b>Step 5</b>	Server /ldap/binding-certificate # <b>download-ca-certificate remote-protocol IP</b> <i>Address LDAP CA Certificate file</i>	<p>Specifies the protocol to connect to the remote server. It can be of the following types:</p> <ul style="list-style-type: none"> <li>• TFTP</li> <li>• FTP</li> <li>• SFTP</li> <li>• SCP</li> <li>• HTTP</li> </ul> <p><b>Note</b> The Cisco UCS C-Series server now supports fingerprint confirmation of the server when you update firmware through a remote server. This option is available only if you choose SCP or SFTP as the remote server type.</p> <p>If you chose SCP or SFTP as the remote server type while performing this action, a prompt with the message Server (RSA) key fingerprint is &lt;server_finger_print_ID&gt; Do you wish to continue? Click y or n depending on the authenticity of the server fingerprint.</p> <p>The fingerprint is based on the host's public key and helps you to identify or verify the host you are connecting to.</p>

	Command or Action	Purpose
<b>Step 6</b>	At the confirmation prompt, enter <b>y</b> .	This begins the download of the LDAP CA certificate.

**Example**

This example downloads the LDAP certificate:

```

Server # scope ldap
Server /ldap # scope binding-certificate
Server /ldap/binding-certificate # set enabled yes
Server /ldap/binding-certificate *# commit
Server /ldap/binding-certificate # show detail
LDAP binding with Certificate:
    Enabled: yes
Server /ldap/binding-certificate # download-ca-certificate tftp 172.22.141.66
new_com_chain.cer
  % Total      % Received % Xferd  Average Speed   Time    Time       Time  Current
                                 Dload  Upload    Total   Spent    Left     Speed
100 1282 100 1282    0     0  1247      0  0:00:01  0:00:01  ---:---: 1635
100 1282 100 1282    0     0  1239      0  0:00:01  0:00:01  ---:---: 1239
    You are going to overwrite the LDAP CA Certificate.
    Are you sure you want to proceed and overwrite the LDAP CA Certificate? [y|N]y
LDAP CA Certificate is downloaded successfully
Server /ldap/binding-certificate #
    
```

## Testing LDAP Binding

**Before you begin**

You must log in as a user with admin privileges to perform this task.



**Note** If you checked the **Enable Encryption** and the **Enable Binding CA Certificate** check boxes, enter the fully qualified domain name (FQDN) of the LDAP server in the LDAP Server field. To resolve the FQDN of the LDAP server, configure the preferred DNS of Cisco IMC network with the appropriate DNS IP address.

**Procedure**

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope ldap</b>	Enters the LDAP command mode.
<b>Step 2</b>	Server# /ldap <b>scope binding-certificate</b>	Enters the LDAP CA certificate binding command mode.
<b>Step 3</b>	Server /ldap/binding-certificate # <b>test-ldap-binding username</b>	Password prompt appears.
<b>Step 4</b>	Enter the corresponding password.	Authenticates the user.

**Example**

This example tests the LDAP user binding:

```
Server # scope ldap
Server /ldap # scope binding-certificate
Server /ldap/binding-certificate # test-ldap-binding user
Password:
diagldapbinding: Authenticated by LDAP
User user authenticated successfully.
Server /ldap/binding-certificate #
```

## Deleting LDAP CA Certificate

**Before you begin**

You must log in as a user with admin privileges to perform this task.

**Procedure**

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope ldap</b>	Enters the LDAP command mode.
<b>Step 2</b>	Server# /ldap <b>scope binding-certificate</b>	Enters the LDAP CA certificate binding command mode.
<b>Step 3</b>	Server /ldap/binding-certificate # <b>delete-ca-certificate</b>	Confirmation prompt appears.
<b>Step 4</b>	At the confirmation prompt, enter <b>y</b> .	This deletes the LDAP CA certificate.

**Example**

This example deletes the LDAP certificate:

```
Server # scope ldap
Server /ldap # scope binding-certificate
Server /ldap/binding-certificate # delete-ca-certificate
You are going to delete the LDAP CA Certificate.
Are you sure you want to proceed and delete the LDAP CA Certificate? [y|N]y
LDAP CA Certificate is deleted successfully
Server /ldap/binding-certificate #
```



# Setting User Search Precedence

## Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope ldap</b>	Enters the BIOS command mode.
<b>Step 2</b>	Server# /ldap <b>set userSearchPrecedence</b> { <i>localUserDB</i>   <i>ldapUserDB</i> }	Sets the user search precedence to the LDAP database or the local user database depending on the option you choose.
<b>Step 3</b>	Server# /ldap * <b>commit</b>	Commits the transaction.
<b>Step 4</b>	(Optional) Server# /ldap <b>show detail</b>	Shows the LDAP details.

## Example

This example sets the user search precedence:

```
Server # scope ldap
Server /ldap # set userSearchPrecedence localUserDB
Server /ldap * # commit
Server /ldap # show detail
LDAP Settings:
Enabled: yes
Encrypted: no
Local User Search Precedence: localUserDB
Domain: new.com
Base DN: DC=new,DC=com
Timeout: 60
Filter Attribute: sAMAccountName
Attribute: CiscoAvPair
Server /ldap #
```

# Viewing User Sessions

## Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>show user-session</b>	Displays information about current user sessions.

The command output displays the following information about current user sessions:

Name	Description
<b>Terminate Session</b> button	If your user account is assigned the <b>admin</b> user role, this option enables you to force the associated user session to end.  <b>Note</b> You cannot terminate your current session from this tab.
<b>Session ID</b> column	The unique identifier for the session.
<b>BMC Session ID</b>	The identifier for the BMC session.
<b>User Name</b> column	The username for the user.
<b>IP Address</b> column	The IP address from which the user accessed the server. If this is a serial connection, it displays <b>N/A</b> .
<b>Session Type</b> column	The type of session the user chose to access the server. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>webgui</b>— indicates the user is connected to the server using the web UI.</li> <li>• <b>CLI</b>— indicates the user is connected to the server using CLI.</li> <li>• <b>serial</b>— indicates the user is connected to the server using the serial port.</li> </ul>

### Example

This example displays information about current user sessions:

```
Server# show user-session
ID      Name           IP Address      Type      Killable
-----
15      admin          10.20.30.138   CLI       yes

Server /user #
```

## Terminating a User Session

### Before you begin

You must log in as a user with admin privileges to terminate a user session.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>show user-session</b>	Displays information about current user sessions. The user session to be terminated must be eligible to be terminated (killable) and must not be your own session.

	Command or Action	Purpose
<b>Step 2</b>	Server /user-session # <b>scope user-session</b> <i>session-number</i>	Enters user session command mode for the numbered user session that you want to terminate.
<b>Step 3</b>	Server /user-session # <b>terminate</b>	Terminates the user session.

### Example

This example shows how the admin at user session 10 terminates user session 15:

```
Server# show user-session
ID      Name           IP Address      Type      Killable
-----
10      admin          10.20.41.234   CLI       yes
15      admin          10.20.30.138   CLI       yes
Server# scope user-session 15
Server /user-session # terminate
User session 15 terminated.

Server /user-session #
```





## CHAPTER 9

# Configuring Network-Related Settings

This chapter includes the following sections:

- [Server NIC Configuration, on page 139](#)
- [Common Properties Configuration, on page 143](#)
- [Configuring Single IP Properties, on page 145](#)
- [Configuring IPv4, on page 146](#)
- [Configuring IPv6, on page 149](#)
- [Configuring VLAN, on page 152](#)
- [Connecting to a Port Profile, on page 154](#)
- [Configuring Interface Properties, on page 156](#)
- [Network Security Configuration, on page 157](#)
- [Network Time Protocol Configuration, on page 159](#)
- [Pinging an IP address, on page 161](#)

## Server NIC Configuration

### Server NICs

#### NIC Mode

The NIC mode setting determines which ports can reach the Cisco IMC. The following network mode options are available, depending on your platform:

- **Dedicated**—The management port that is used to access the Cisco IMC.
- **Cisco Card**—Any port on the adapter card that can be used to access the Cisco IMC. The Cisco adapter card has to be installed in a slot with Network the Communications Services Interface protocol support (NCSI).
- **Shared LOM**—Any LOM (LAN on Motherboard) port that can be used to access Cisco IMC.
- **Shared LOM Extended**—Any LOM port or adapter card port that can be used to access Cisco IMC. The Cisco adapter card has to be installed in a slot with NCSI support.




---

**Note** **Shared LOM** and **Shared LOM Extended** ports are available only on some C-series servers.

---




---

**Note** For other UCS C-Series M4 and M5 servers, the NIC mode is set to **Shared LOM Extended** by default.

---

#### Default NIC Mode Setting:

- For UCS C-Series C125 M5 servers and S3260 servers, the **NIC Mode** is set to **Cisco Card** by default.

#### NIC Redundancy

The following NIC redundancy options are available, depending on the selected NIC mode and your platform:

- **active-active**—If supported, all ports that are associated with the configured NIC mode operate simultaneously. This feature increases throughput and provides multiple paths to the Cisco IMC.
- **active-standby**—If a port that is associated with the configured NIC mode fails, traffic fails over to one of the other ports associated with the NIC mode.




---

**Note** If you choose this option, make sure that all ports associated with the configured NIC mode are connected to the same subnet to ensure that traffic is secure regardless of which port is used.

---

- **None**—In *Dedicated* mode, NIC redundancy is set to *None*.

The available redundancy modes vary depending on the selected network mode and your platform. For the available modes, see the *Hardware Installation Guide* (HIG) for the type of server you are using. The C-Series HIGs are available at the following URL:

[http://www.cisco.com/en/US/products/ps10493/prod\\_installation\\_guides\\_list.html](http://www.cisco.com/en/US/products/ps10493/prod_installation_guides_list.html)

#### VIC Slots

The VIC slot that can be used for management functions in Cisco card mode.

For C220 M6, VIC slot options are as follows:




---

**Note** For C220 M6 , after resetting to factory default settings, the slot precedence is as follows:

1. mLOM
  2. Riser 1 - Slot 1
  3. Riser 3 - Slot 3
-

For C125 M5, VIC slot option is **Riser 2**.

For C220 M4, C220 M5 and C240 M5 servers, VIC slot options are as follows:

- **Riser 1**—Slot 1 is selected.
- **Riser 2**—Slot 2 is selected.
- **FLEX LOM**—Slot 3 (MLOM) is selected.

For C240 M4 servers, VIC slot options are as follows:

- **Riser 1**—Slot 2 is the primary slot, but you can also use slot 1.
- **Riser 2**—Slot 5 is the primary slot, but you can also use slot 4.
- **FLEX LOM**—Slot 7 (MLOM) is selected.

For C480 M5 ML servers, Cisco card mode slot is Slot 11 and Slot 12.

The following options are available only on some UCS C-Series servers:

- 4
- 5
- 9
- 10



**Note** This option is available only on some UCS C-Series servers.

## Configuring NICs

Configure a server NIC when you want to set the NIC mode and NIC redundancy.

### Before you begin

You must log in as a user with admin privileges to configure the NIC.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope network</b>	Enters the Cisco IMC network command mode.
<b>Step 2</b>	Server /network # <b>set mode {dedicated   cisco_card}</b>	Sets the NIC mode to one of the following: <ul style="list-style-type: none"> <li>• <b>Dedicated</b>—The management Ethernet port is used to access the Cisco IMC.</li> <li>• <b>Cisco card</b>—The ports on the adapter card are used to access the Cisco IMC.</li> </ul>

	Command or Action	Purpose
<b>Step 3</b>	Server /network # <b>set redundancy</b> { <b>none</b>   <b>active-active</b>   <b>active-standby</b> }	<p>Sets the NIC redundancy mode when the NIC mode is Shared LOM. The redundancy mode can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>none</b>—The LOM Ethernet ports operate independently and do not fail over if there is a problem.</li> <li>• <b>active-active</b>—If supported, all LOM Ethernet ports are utilized.</li> <li>• <b>active-standby</b>—If one LOM Ethernet port fails, traffic fails over to another LOM port.</li> </ul>
<b>Step 4</b>	Server /network # <b>commit</b>	<p>Commits the transaction to the system configuration.</p> <p><b>Note</b> The available NIC mode and NIC redundancy mode options may vary depending on your platform. If you select a mode not supported by your server, an error message displays when you save your changes.</p>
<b>Step 5</b>	At the prompt, enter <b>y</b> to confirm.	Configures the server NIC.

### Example

This example configures the Cisco IMC network interface:

```
Server # scope network
Server /network # set mode cisco_card
Server /network *# set redundancy <active-active>
Server /network *# commit
Changes to the network settings will be applied immediately.
You may lose connectivity to the Cisco IMC and may have to log in again.
Do you wish to continue? [y/N] y
Server /network #
```



# Common Properties Configuration

## Overview to Common Properties Configuration

### Hostname

The Dynamic Host Configuration Protocol (DHCP) enhancement is available with the addition of the hostname to the DHCP packet, which can either be interpreted or displayed at the DHCP server side. The hostname, which is now added to the options field of the DHCP packet, sent in the DHCP DISCOVER packet that was initially sent to the DHCP server.

The default hostname of the server is changed from ucs-c2XX to CXXX-YYYYYY, where XXX is the model number and YYYYYY is the serial number of the server. This unique string acts as a client identifier, allows you to track and map the IP addresses that are leased out to Cisco IMC from the DHCP server. The default serial number is provided by the manufacturer as a sticker or label on the server to help you identify the server.

### Dynamic DNS

Dynamic DNS (DDNS) is used to add or update the resource records on the DNS server from Cisco IMC. You can enable Dynamic DNS by using either the web UI or CLI. When you enable the DDNS option, the DDNS service records the current hostname, domain name, and the management IP address and updates the resource records in the DNS server from Cisco IMC.



**Note** The DDNS server deletes the prior resource records (if any) and adds the new resource records to the DNS server if any one of the following DNS configuration is changed:

- Hostname
- Domain name in the LDAP settings
- When DDNS and DHCP are enabled, if the DHCP gets a new IP address or DNS IP or domain name due to a change in a network or a subnet.
- When DHCP is disabled and if you set the static IP address by using CLI or web UI.
- When you enter the **dns-use-dhcp** command.

**Dynamic DNS Update Domain**— You can specify the domain. The domain could be either main domain or any sub-domain. This domain name is appended to the hostname of the Cisco IMC for the DDNS update.

## Configuring Common Properties

Use common properties to describe your server.

### Before you begin

You must log in as a user with admin privileges to configure common properties.

**Procedure**

	<b>Command or Action</b>	<b>Purpose</b>
<b>Step 1</b>	Server # <b>scope network</b>	Enters the Cisco IMC network command mode.
<b>Step 2</b>	Server /network # <b>set hostname-bmc1</b> <del>hostname-bmc2hostname-cmc1hostname-cmc2host-name</del>	Specifies the name of the host for the following components: <ul style="list-style-type: none"> <li>• BMC 1</li> <li>• BMC 2</li> <li>• CMC 1</li> <li>• CMC 2</li> </ul> <p>When you modify the hostname, you are prompted to confirm whether you want to create a new self-signed certificate with Common Name (CN) as the new hostname.</p> <p>If you enter <b>y</b> at the prompt, a new self-signed certificate is created with CN as the new hostname.</p> <p>If you enter <b>n</b> at the prompt, only the hostname is changed and no certificate will be generated.</p>
<b>Step 3</b>	(Optional) Server /network # <b>set ddns-enabled</b>	Enables the DDNS service for Cisco IMC
<b>Step 4</b>	(Optional) Server /network # <b>set ddns-update-domain value</b>	Updates the selected domain or its subdomain.
<b>Step 5</b>	Server /network # <b>commit</b>	Commits the transaction to the system configuration.
<b>Step 6</b>	At the prompt, enter <b>y</b> to confirm.	Configures common properties.

**Example**

This example shows how to configure the common properties:

```
Server # scope network
Server /network # set hostname-cmc1 cmc1
Server /network *# set ddns-enabled
Server /network *# set ddns-update-domain 1.2.3.4
Server /network *# commit
Changes to the network settings will be applied immediately.
You may lose connectivity to the Cisco IMC and may have to log in again.
Do you wish to continue? [y/N] y
Server /network #
```

**What to do next**

Changes to the network are applied immediately. You might lose connectivity to Cisco IMC and have to log in again. Because of the new SSH session created, you may be prompted to confirm the host key.

# Configuring Single IP Properties

**Before you begin**

You must log in as a user with admin privileges to configure single IP properties.

**Procedure**

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope network</b>	Enters the Cisco IMC network command mode.
<b>Step 2</b>	Server /network # <b>set enable-single-ip {yes   no}</b>	Enables the Single IP feature.
<b>Step 3</b>	Server /network # <b>set starting-port port number</b>	Specifies the starting port number for the single IP configuration. When single IP is enabled ports 9000-9006 are used by Cisco IMC for the starting port configuration. These ports cannot be used for any other configuration.
<b>Step 4</b>	Server /network * # <b>commit</b>	Choose <b>y</b> at the confirmation prompt, commits the transaction to the system configuration.
<b>Step 5</b>	Server /network # <b>show [detail]</b>	(Optional) Displays the network settings.

**Example**

This example configures and displays the single IP network settings:

```
Server# scope network
Server /network # set enable-single-ip yes
Server /network * # set starting-port 9000
Server /network * # commit
Server /network # show detail
Chassis Network Setting:
  IPv4 Enabled: yes
  SingleIP Mode: yes
  Starting Port: 10000
  IPv4 Netmask: 255.255.255.0
  IPv4 Gateway: 10.104.236.1
  DHCP Enabled: yes
  DDNS Enabled: yes
  DDNS Update Domain:
  DDNS Refresh Interval(0-8736 Hr): 0
  Obtain DNS Server by DHCP: yes
  Preferred DNS: 10.104.236.99
  Alternate DNS: 0.0.0.0
  IPv6 Enabled: yes
  IPv6 Prefix: 64
```

```

IPv6 Gateway: fe80::3e08:f6ff:fe21:29c0
IPv6 DHCP Enabled: yes
IPv6 Obtain DNS Server by DHCP: yes
IPv6 Preferred DNS: ::
IPv6 Alternate DNS: ::
VLAN Enabled: no
VLAN ID: 1
VLAN Priority: 0
Port Profile:
NIC Mode: cisco_card
NIC Redundancy: active-active
SIOC Slot: 2
Management IPv4 Address: 10.104.236.135
Management IPv6 Address: ::
Management Hostname: S3260-FOX2111P7VD
Auto Negotiate: no
Admin Network Speed: NA
Admin Duplex: NA
Operational Network Speed: NA
Operational Duplex: NA
CMC 1 Network Setting:
IPv6 Address CMC 1: ::
IPv6 Link Local CMC 1: ::
IPv6 SLAAC Address CMC 1: ::
Hostname CMC 1: UCS-C3260-FCH21277KB8-1
MAC Address CMC 1: 96:09:5C:EF:B6:32
CMC 2 Network Setting:
IPv6 Address CMC 2: ::
IPv6 Link Local CMC 2: fe80::522f:a8ff:fed2:34aa
IPv6 SLAAC Address CMC 2: ::
Hostname CMC 2: UCS-C3260-FCH21277KCA-2
MAC Address CMC 2: 50:2F:A8:D2:34:AA
BMC 1 Network Setting:
IPv6 Address BMC 1: ::
IPv6 Link Local BMC 1: fe80::3a90:a5ff:fe7f:a840
IPv6 SLAAC Address BMC 1: ::
Hostname BMC 1: S3X60M5-FCH21187159
MAC Address BMC 1: 38:90:A5:7F:A8:40

Server /network #

```

## Configuring IPv4

### Before you begin

You must log in as a user with admin privileges to configure IPv4 network settings.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope network</b>	Enters the Cisco IMC network command mode.

	Command or Action	Purpose
<b>Step 2</b>	Server /network # <b>set dhcp-enabled</b> {yes   no}	Selects whether the Cisco IMC uses DHCP.  <b>Note</b> If DHCP is enabled, we recommend that the DHCP server be configured to reserve a single IP address for the Cisco IMC. If the Cisco IMC is reachable through multiple ports on the server, the single IP address must be reserved for the full range of MAC addresses of those ports.
<b>Step 3</b>	Server /network # <b>set v4-addr</b> <i>ipv4-address</i>	Specifies the IP address for the Cisco IMC.
<b>Step 4</b>	Server /network # <b>set v4-netmask</b> <i>ipv4-netmask</i>	Specifies the subnet mask for the IP address.
<b>Step 5</b>	Server /network # <b>set v4-gateway</b> <i>gateway-ipv4-address</i>	Specifies the gateway for the IP address.
<b>Step 6</b>	Server /network # <b>set dns-use-dhcp</b> {yes   no}	Selects whether the Cisco IMC retrieves the DNS server addresses from DHCP.
<b>Step 7</b>	Server /network # <b>set preferred-dns-server</b> <i>dns1-ipv4-address</i>	Specifies the IP address of the primary DNS server.
<b>Step 8</b>	Server /network # <b>set alternate-dns-server</b> <i>dns2-ipv4-address</i>	Specifies the IP address of the secondary DNS server.
<b>Step 9</b>	Server /network # <b>commit</b>	Commits the transaction to the system configuration.
<b>Step 10</b>	At the prompt, enter <b>y</b> to confirm.	Configures IPv4.
<b>Step 11</b>	Server /network # <b>show [detail]</b>	(Optional) Displays the IPv4 network settings.

### Example

This example configures and displays the IPv4 network settings:

```
Server # scope network
Server /network # set dhcp-enabled yes
Server /network *# set v4-addr 10.20.30.11
Server /network *# set v4-netmask 255.255.248.0
Server /network *# set v4-gateway 10.20.30.1
Server /network *# set dns-use-dhcp-enabled no
Server /network *# set preferred-dns-server 192.168.30.31
Server /network *# set alternate-dns-server 192.168.30.32
Server /network *# commit
Changes to the network settings will be applied immediately.
You may lose connectivity to the Cisco IMC and may have to log in again.
Do you wish to continue? [y/N] y
Server /network # show detail
Network Setting:
    IPv4 Enabled: yes
```

```

IPv4 Netmask: 255.255.248.0
IPv4 Gateway: 10.20.30.1
DHCP Enabled: no
DDNS Enabled: yes
DDNS Update Domain:
Obtain DNS Server by DHCP: no
Preferred DNS: 192.168.30.31
Alternate DNS: 192.168.30.32
IPv6 Enabled: no
IPv6 Prefix: 64
IPv6 Gateway: ::
IPv6 DHCP Enabled: no
IPv6 Obtain DNS Server by DHCP: no
IPv6 Preferred DNS: ::
IPv6 Alternate DNS: ::
VLAN Enabled: no
VLAN ID: 1
VLAN Priority: 0
Port Profile: abcde12345
NIC Mode: dedicated
NIC Redundancy: none
SIOC Slot: 1
Management IPv4 Address: 10.106.145.202
Management IPv6 Address: ::
Management Hostname: S3260-FCH18207WF3
Network Speed: 100Mbps
Duplex: full
Auto Negotiate: yes
Admin Network Speed: auto
Admin Duplex: auto
Operational Network Speed: 1Gbps
Operational Duplex: full
CMC 1 Network Setting:
IPv4 Address CMC 1: 10.20.30.11
IPv6 Address CMC 1: ::
IPv6 Link Local CMC 1: ::
IPv6 SLAAC Address CMC 1: ::
Hostname CMC 1: UCS-S3260-FCH181772ZP-1
MAC Address CMC 1: F4:CF:E2:77:7F:D2
CMC 2 Network Setting:
IPv4 Address CMC 2: 10.20.30.11
IPv6 Address CMC 2: ::
IPv6 Link Local CMC 2: ::
IPv6 SLAAC Address CMC 2: ::
Hostname CMC 2: UCS-S3260--2
MAC Address CMC 2: F4:CF:E2:77:80:83
BMC 1 Network Setting:
IPv4 Address BMC 1: 10.20.30.11
IPv6 Address BMC 1: ::
IPv6 Link Local BMC 1: ::
IPv6 SLAAC Address BMC 1: ::
Hostname BMC 1: S3260-FCH1827K9YT
MAC Address BMC 1: 7C:0E:CE:5A:EF:26
BMC 2 Network Setting:
IPv4 Address BMC 2: 10.20.30.11
IPv6 Address BMC 2: ::
IPv6 Link Local BMC 2: ::
IPv6 SLAAC Address BMC 2: ::
Hostname BMC 2: S3260-FCH18407MYD
MAC Address BMC 2: A0:EC:F9:85:90:3F

```

```
Server /network #
```

# Configuring IPv6

## Before you begin

You must log in as a user with admin privileges to configure IPv6 network settings.

## Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope network</b>	Enters the Cisco IMC network command mode.
<b>Step 2</b>	Server /network # <b>set v6-enabled {yes   no}</b>	Enables IPv6.
<b>Step 3</b>	Server /network # <b>set v6-dhcp-enabled {yes   no}</b>	<p>Selects whether the Cisco IMC uses DHCP.</p> <p><b>Note</b> If DHCP is enabled, we recommend that the DHCP server be configured to reserve a single IPv6 address for the Cisco IMC. If the Cisco IMC is reachable through multiple ports on the server, the single IPv6 address must be reserved for the full range of MAC addresses of those ports.</p>
<b>Step 4</b>	Server /network # <b>set v6-addr-bmc1 v6-addr-bmc2 v6-addr-cmc1 v6-addr-cmc2 v6-addr-mgmt ipv6-address</b>	<p>Specifies the IP address for the following components:</p> <ul style="list-style-type: none"> <li>• BMC1 IPv6 Address</li> <li>• BMC2 IPv6 Address</li> <li>• CMC1 IPv6 Address</li> <li>• CMC2 IPv6 Address</li> <li>• Management IPv6 Address</li> </ul>
<b>Step 5</b>	Server /network # <b>set v6-prefix ipv6-prefix-length</b>	Specifies the prefix length for the IP address.
<b>Step 6</b>	Server /network # <b>set v6-gateway gateway-ipv6-address</b>	Specifies the gateway for the IP address.
<b>Step 7</b>	Server /network # <b>set v6-dns-use-dhcp {yes   no}</b>	<p>Selects whether the Cisco IMC retrieves the DNS server addresses from DHCP.</p> <p><b>Note</b> You can use this option only when DHCP enabled.</p>
<b>Step 8</b>	Server /network # <b>set v6-preferred-dns-server dns1-ipv6-address</b>	Specifies the IP address of the primary DNS server.

	Command or Action	Purpose
<b>Step 9</b>	Server /network # <b>set v6-alternate-dns-server</b> <i>dns2-ipv6-address</i>	Specifies the IP address of the secondary DNS server.
<b>Step 10</b>	Server /network # <b>commit</b>	Commits the transaction to the system configuration.
<b>Step 11</b>	At the prompt, enter <b>y</b> to confirm.	Configures IPv6.
<b>Step 12</b>	Server /network # <b>show [detail]</b>	(Optional) Displays the IPv6 network settings.

### Example

This example enables static IPv6 and displays the IPv6 network settings:

```

Server # scope network
Server /network # set v6-enabled yes
Server /network *# set v6-addr-bmc1 2010:201::279
Server /network *# set v6-gateway 2010:201::1
Server /network *# set v6-prefix 64
Server /network *# set v6-dns-use-dhcp no
Server /network *# set v6-preferred-dns-server 2010:201::100
Server /network *# set v6-alternate-dns-server 2010:201::101
Changes to the network settings will be applied immediately.
You may lose connectivity to the Cisco IMC and may have to log in again.
Server /network *# commit
Changes to the network settings will be applied immediately.
You may lose connectivity to the Cisco IMC and may have to log in again.
Do you wish to continue? [y/N] y
Server /network # show detail
Network Setting:
  IPv4 Enabled: yes
  IPv4 Netmask: 255.255.255.0
  IPv4 Gateway: 10.106.145.1
  DHCP Enabled: no
  DDNS Enabled: yes
  DDNS Update Domain:
  Obtain DNS Server by DHCP: no
  Preferred DNS: 171.70.168.183
  Alternate DNS: 0.0.0.0
  IPv6 Enabled: no
  IPv6 Prefix: 64
  IPv6 Gateway: 2010:201::1
  IPV6 DHCP Enabled: no
  IPV6 Obtain DNS Server by DHCP: no
  IPV6 Preferred DNS: 2010:201::100
  IPV6 Alternate DNS: 2010:201::101
  VLAN Enabled: no
  VLAN ID: 1
  VLAN Priority: 0
  Port Profile: abcde12345
  NIC Mode: dedicated
  NIC Redundancy: none
  SIOC Slot: 1
  Management IPv4 Address: 10.106.145.202
  Management IPv6 Address: ::
  Management Hostname: S3260-FCH18207WF3
  Network Speed: 100Mbps
  Duplex: full

```



```

Auto Negotiate: yes
Admin Network Speed: auto
Admin Duplex: auto
Operational Network Speed: 1Gbps
Operational Duplex: full
CMC 1 Network Setting:
IPv4 Address CMC 1: 10.106.145.135
IPv6 Address CMC 1: ::
IPv6 Link Local CMC 1: ::
IPv6 SLAAC Address CMC 1: ::
Hostname CMC 1: UCS-S3260-FCH181772ZP-1
MAC Address CMC 1: F4:CF:E2:77:7F:D2
CMC 2 Network Setting:
IPv4 Address CMC 2: 10.106.145.248
IPv6 Address CMC 2: ::
IPv6 Link Local CMC 2: ::
IPv6 SLAAC Address CMC 2: ::
Hostname CMC 2: UCS-S3260--2
MAC Address CMC 2: F4:CF:E2:77:80:83
BMC 1 Network Setting:
IPv4 Address BMC 1: 10.106.145.41
IPv6 Address BMC 1: 2010:201::279
IPv6 Link Local BMC 1: ::
IPv6 SLAAC Address BMC 1: ::
Hostname BMC 1: S3260-FCH1827K9YT
MAC Address BMC 1: 7C:0E:CE:5A:EF:26
BMC 2 Network Setting:
IPv4 Address BMC 2: 10.106.145.39
IPv6 Address BMC 2: ::
IPv6 Link Local BMC 2: ::
IPv6 SLAAC Address BMC 2: ::
Hostname BMC 2: S3260-FCH18407MYD
MAC Address BMC 2: A0:EC:F9:85:90:3F

```

```
Server /network #
```

This example enables DHCP for IPv6 and displays the IPv6 network settings:

```

Server # scope network
Server /network # set v6-enabled yes
Server /network *# set v6-dhcp-enabled yes
Changes to the network settings will be applied immediately.
You may lose connectivity to the Cisco IMC and may have to log in again.
Server /network *# commit
Changes to the network settings will be applied immediately.
You may lose connectivity to the Cisco IMC and may have to log in again.
Do you wish to continue? [y/N] y
Server /network # show detail
Network Setting:
IPv4 Enabled: yes
IPv4 Address: 10.106.145.76
IPv4 Netmask: 255.255.255.0
IPv4 Gateway: 10.106.145.1
DHCP Enabled: yes
DDNS Enabled: yes
DDNS Update Domain: example.com
Obtain DNS Server by DHCP: no
Preferred DNS: 171.70.168.183
Alternate DNS: 0.0.0.0
IPv6 Enabled: yes
IPv6 Address: 2010:201::253
IPv6 Prefix: 64
IPv6 Gateway: fe80::222:dff:fec2:8000
IPv6 Link Local: fe80::523d:e5ff:fe9d:395d

```

```

IPv6 SLAAC Address: 2010:201::523d:e5ff:fe9d:395d
IPv6 DHCP Enabled: yes
IPv6 Obtain DNS Server by DHCP: no
IPv6 Preferred DNS: ::
IPv6 Alternate DNS: ::
VLAN Enabled: no
VLAN ID: 1
VLAN Priority: 0
Port Profile:
Hostname: CIMC_C220
MAC Address: 50:3D:E5:9D:39:5C
NIC Mode: dedicated
NIC Redundancy: none
Network Speed: 100Mbps
Duplex: full
Auto Negotiate: no
Admin Network Speed: auto
Admin Duplex: auto
Operational Network Speed: 1Gbps
Operational Duplex: full
CMC 1 Network Setting:
IPv4 Address CMC 1: 10.106.145.135
IPv6 Address CMC 1: ::
IPv6 Link Local CMC 1: ::
IPv6 SLAAC Address CMC 1: ::
Hostname CMC 1: UCS-S3260-FCH181772ZP-1
MAC Address CMC 1: F4:CF:E2:77:7F:D2
CMC 2 Network Setting:
IPv4 Address CMC 2: 10.106.145.248
IPv6 Address CMC 2: ::
IPv6 Link Local CMC 2: ::
IPv6 SLAAC Address CMC 2: ::
Hostname CMC 2: UCS-S3260--2
MAC Address CMC 2: F4:CF:E2:77:80:83
BMC 1 Network Setting:
IPv4 Address BMC 1: 10.106.145.41
IPv6 Address BMC 1: ::
IPv6 Link Local BMC 1: ::
IPv6 SLAAC Address BMC 1: ::
Hostname BMC 1: S3260-FCH1827K9YT
MAC Address BMC 1: 7C:0E:CE:5A:EF:26
BMC 2 Network Setting:
IPv4 Address BMC 2: 10.106.145.39
IPv6 Address BMC 2: ::
IPv6 Link Local BMC 2: ::
IPv6 SLAAC Address BMC 2: ::
Hostname BMC 2: S3260-FCH18407MYD
MAC Address BMC 2: A0:EC:F9:85:90:3F

```

```
Server /network #
```

## Configuring VLAN

### Before you begin

You must be logged in as admin to configure the server VLAN.

**Procedure**

	<b>Command or Action</b>	<b>Purpose</b>
<b>Step 1</b>	Server # <b>scope network</b>	Enters the Cisco IMC network command mode.
<b>Step 2</b>	Server /network # <b>set vlan-enabled {yes   no}</b>	Selects whether the Cisco IMC is connected to a VLAN.
<b>Step 3</b>	Server /network # <b>set vlan-id id</b>	Specifies the VLAN number.
<b>Step 4</b>	Server /network # <b>set vlan-priority priority</b>	Specifies the priority of this system on the VLAN.
<b>Step 5</b>	Server /network # <b>commit</b>	Commits the transaction to the system configuration.
<b>Step 6</b>	At the prompt, enter <b>y</b> to confirm.	Configures the server LAN.
<b>Step 7</b>	Server /network # <b>show [detail]</b>	(Optional) Displays the network settings.

**Example**

This example configures the VLAN:

```

Server # scope network
Server /network # set vlan-enabled yes
Server /network *# set vlan-id 5
Server /network *# set vlan-priority 7
Server /network *# commit
Changes to the network settings will be applied immediately.
You may lose connectivity to the Cisco IMC and may have to log in again.
Do you wish to continue? [y/N] y
Server /network # show detail
Network Setting:
  IPv4 Enabled: yes
  IPv4 Netmask: 255.255.255.0
  IPv4 Gateway: 10.106.145.1
  DHCP Enabled: no
  DDNS Enabled: yes
  DDNS Update Domain:
  Obtain DNS Server by DHCP: no
  Preferred DNS: 171.70.168.183
  Alternate DNS: 0.0.0.0
  IPv6 Enabled: no
  IPv6 Prefix: 64
  IPv6 Gateway: ::
  IPV6 DHCP Enabled: no
  IPV6 Obtain DNS Server by DHCP: no
  IPV6 Preferred DNS: ::
  IPV6 Alternate DNS: ::
VLAN Enabled: yes
VLAN ID: 2
VLAN Priority: 7
  Port Profile: abcde12345
  NIC Mode: dedicated
  NIC Redundancy: none
  SIOC Slot: 1

```

```

Management IPv4 Address: 10.106.145.202
Management IPv6 Address: ::
Management Hostname: S3260-FCH18207WF3
Network Speed: 100Mbps
Duplex: full
Auto Negotiate: yes
Admin Network Speed: auto
Admin Duplex: auto
Operational Network Speed: 1Gbps
Operational Duplex: full
CMC 1 Network Setting:
IPv4 Address CMC 1: 10.106.145.135
IPv6 Address CMC 1: ::
IPv6 Link Local CMC 1: ::
IPv6 SLAAC Address CMC 1: ::
Hostname CMC 1: UCS-S3260-FCH181772ZP-1
MAC Address CMC 1: F4:CF:E2:77:7F:D2
CMC 2 Network Setting:
IPv4 Address CMC 2: 10.106.145.248
IPv6 Address CMC 2: ::
IPv6 Link Local CMC 2: ::
IPv6 SLAAC Address CMC 2: ::
Hostname CMC 2: UCS-S3260--2
MAC Address CMC 2: F4:CF:E2:77:80:83
BMC 1 Network Setting:
IPv4 Address BMC 1: 10.106.145.41
IPv6 Address BMC 1: ::
IPv6 Link Local BMC 1: ::
IPv6 SLAAC Address BMC 1: ::
Hostname BMC 1: S3260-FCH1827K9YT
MAC Address BMC 1: 7C:0E:CE:5A:EF:26
BMC 2 Network Setting:
IPv4 Address BMC 2: 10.106.145.39
IPv6 Address BMC 2: ::
IPv6 Link Local BMC 2: ::
IPv6 SLAAC Address BMC 2: ::
Hostname BMC 2: S3260-FCH18407MYD
MAC Address BMC 2: A0:EC:F9:85:90:3F

Server /network #

```

## Connecting to a Port Profile



**Note** You can configure a port profile or a VLAN, but you cannot use both. If you want to use a port profile, make sure the **set vlan-enabled** command is set to **no**.

### Before you begin

You must be logged in as admin to connect to a port profile.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope network</b>	Enters the Cisco IMC network command mode.

	Command or Action	Purpose
<b>Step 2</b>	Server /network # <b>set port-profile</b> <i>port_profile_name</i>	Specifies the port profile Cisco IMC should use to configure the management interface, the virtual Ethernet, and the VIF on supported adapter cards such as the Cisco UCS VIC 1225 Virtual Interface Card.  Enter up to 80 alphanumeric characters. You cannot use spaces or other special characters except for - (hyphen) and _ (underscore). In addition, the port profile name cannot begin with a hyphen.  <b>Note</b> The port profile must be defined on the switch to which this server is connected.
<b>Step 3</b>	Server /network # <b>commit</b>	Commits the transaction to the system configuration.
<b>Step 4</b>	At the prompt, enter <b>y</b> to confirm.	Connects to a port profile.
<b>Step 5</b>	(Optional) Server /network # <b>show [detail]</b>	Displays the network settings.

**Example**

This example connects to port profile abcde12345:

```
Server # scope network
Server /network # set port-profile abcde12345
Server /network *# commit
Changes to the network settings will be applied immediately.
You may lose connectivity to the Cisco IMC and may have to log in again.
Do you wish to continue? [y/N] y
Server /network # show detail
Network Setting:
  IPv4 Enabled: yes
  IPv4 Netmask: 255.255.255.0
  IPv4 Gateway: 10.106.145.1
  DHCP Enabled: no
  DDNS Enabled: yes
  DDNS Update Domain:
  Obtain DNS Server by DHCP: no
  Preferred DNS: 171.70.168.183
  Alternate DNS: 0.0.0.0
  IPv6 Enabled: no
  IPv6 Prefix: 64
  IPv6 Gateway: ::
  IPV6 DHCP Enabled: no
  IPV6 Obtain DNS Server by DHCP: no
  IPV6 Preferred DNS: ::
  IPV6 Alternate DNS: ::
  VLAN Enabled: no
  VLAN ID: 1
  VLAN Priority: 0
  Port Profile: abcde12345
  NIC Mode: dedicated
```

```

NIC Redundancy: none
SIOC Slot: 1
Management IPv4 Address: 10.106.145.202
Management IPv6 Address: ::
Management Hostname: S3260-FCH18207WF3
Network Speed: 100Mbps
Duplex: full
Auto Negotiate: yes
Admin Network Speed: auto
Admin Duplex: auto
Operational Network Speed: 1Gbps
Operational Duplex: full
CMC 1 Network Setting:
IPv4 Address CMC 1: 10.106.145.135
IPv6 Address CMC 1: ::
IPv6 Link Local CMC 1: ::
IPv6 SLAAC Address CMC 1: ::
Hostname CMC 1: UCS-S3260-FCH181772ZP-1
MAC Address CMC 1: F4:CF:E2:77:7F:D2
CMC 2 Network Setting:
IPv4 Address CMC 2: 10.106.145.248
IPv6 Address CMC 2: ::
IPv6 Link Local CMC 2: ::
IPv6 SLAAC Address CMC 2: ::
Hostname CMC 2: UCS-S3260--2
MAC Address CMC 2: F4:CF:E2:77:80:83
BMC 1 Network Setting:
IPv4 Address BMC 1: 10.106.145.41
IPv6 Address BMC 1: ::
IPv6 Link Local BMC 1: ::
IPv6 SLAAC Address BMC 1: ::
Hostname BMC 1: S3260-FCH1827K9YT
MAC Address BMC 1: 7C:0E:CE:5A:EF:26
BMC 2 Network Setting:
IPv4 Address BMC 2: 10.106.145.39
IPv6 Address BMC 2: ::
IPv6 Link Local BMC 2: ::
IPv6 SLAAC Address BMC 2: ::
Hostname BMC 2: S3260-FCH18407MYD
MAC Address BMC 2: A0:EC:F9:85:90:3F

Server /network #

```

## Configuring Interface Properties

The settings on the switch must match with the Cisco IMC settings to avoid any speed or duplex mismatch.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope network</b>	Enters the network command mode.
<b>Step 2</b>	Server /network* # <b>set mode dedicated</b>	Enters dedicated command mode.

	Command or Action	Purpose
<b>Step 3</b>	Server /network* # <b>set auto-negotiate</b> {yes   no}	Enables or disables auto negotiation command mode. <ul style="list-style-type: none"> <li>• If you enter <b>yes</b>, the setting for duplex will be ignored by the system. The Cisco IMC retains the speed at which the switch is configured.</li> <li>• If you enter <b>no</b>, you can set duplex. Else, a default speed of 100 Mbps will be applied, and duplex will retain its previous value.</li> </ul>
<b>Step 4</b>	Server /network* # <b>set duplex</b> {full   half}	Sets specified duplex mode type. By default, the duplex mode is set to <b>Full</b>

### Example

This example shows how to configure the interface properties and commit the transaction:

```
Server # scope network
Server /network* # set mode dedicated
Server /network* # set auto-negotiate no
Warning: You have chosen to set auto negotiate to no
If speed and duplex are not set then a default speed of 100Mbps will be applied
Duplex will retain its previous value
Server /network* # commit
Server /network # set duplex full
Server /network* # commit
Changes to the network settings will be applied immediately.
You may lose connectivity to the Cisco IMC and may have to log in again.
Do you wish to continue? [y/N] y
Server /network #
```

## Network Security Configuration

### Network Security

The Cisco IMC uses IP blocking as network security. IP blocking prevents the connection between a server or website and certain IP addresses or ranges of addresses. IP blocking effectively bans undesired connections from those computers to a website, mail server, or other Internet servers.

IP banning is commonly used to protect against denial of service (DoS) attacks. Cisco IMC bans IP addresses by setting up an IP blocking fail count.

### Configuring Network Security

Configure network security if you want to set up an IP blocking fail count.

**Before you begin**

You must log in as a user with admin privileges to configure network security.

**Procedure**

	<b>Command or Action</b>	<b>Purpose</b>
<b>Step 1</b>	Server # <b>scope network</b>	Enters the Cisco IMC network command mode.
<b>Step 2</b>	Server /network # <b>scope ipblocking</b>	Enters the IP blocking command mode.
<b>Step 3</b>	Server /network/ipblocking # <b>set enabled {yes   no}</b>	Enables or disables IP blocking.
<b>Step 4</b>	Server /network/ipblocking # <b>set fail-count</b> <i>fail-count</i>	Sets the number of times a user can attempt to log in unsuccessfully before the system locks that user out for a specified length of time.  The number of unsuccessful login attempts must occur within the time frame specified in the IP Blocking Fail Window field.  Enter an integer between 3 and 10.
<b>Step 5</b>	Server /network/ipblocking # <b>set fail-window</b> <i>fail-seconds</i>	Sets the length of time, in seconds, in which the unsuccessful login attempts must occur in order for the user to be locked out.  Enter an integer between 60 and 120.
<b>Step 6</b>	Server /network/ipblocking # <b>set penalty-time</b> <i>penalty-seconds</i>	Sets the number of seconds the user remains locked out if they exceed the maximum number of login attempts within the specified time window.  Enter an integer between 300 and 900.
<b>Step 7</b>	Server /network/ipblocking # <b>commit</b>	Commits the transaction to the system configuration.
<b>Step 8</b>	Server /network/ipblocking # <b>exit</b>	Exits the IP blocking to the network command mode.
<b>Step 9</b>	Server /network # <b>scope ipfiltering</b>	Enters the IP filtering command mode.
<b>Step 10</b>	Server /network/ipfiltering # <b>set enabled {yes   no}</b>	Enables or disables IP filtering. At the prompt enter <b>y</b> to enable IP filtering.
<b>Step 11</b>	Server /network/ipfiltering # <b>set filter-1</b> <i>IPv4 or IPv6 address or a range of IP addresses</i>	You can set four IP filters. You can assign an IPv4 or IPv6 IP address or a range of IP addresses.
<b>Step 12</b>	Server /network/ipfiltering # <b>commit</b>	Commits the transaction to the system configuration.



### Example

This example configures network security:

```

Server # scope network
Server /network # scope ipblocking
Server /network/ipblocking # set enabled yes
Server /network/ipblocking *# set fail-count 5
Server /network/ipblocking *# set fail-window 90
Server /network/ipblocking *# set penalty-time 600
Server /network/ipblocking *# commit
Server /network/ipblocking # exit
Server /network # scope ipfiltering
Server /network/ipfiltering # set enabled yes
This will enable IP Filtering
Do you wish to continue? [y/N] y
Server /network/ipfiltering *# set filter-1 1.1.1.1-255.255.255.255
                               set filter-2 10.10.10.10
                               set filter-3 2001:xxx::-2xxx:xx8::0001
                               set filter-4
2001:xxx::-2xxx:xx8::0001-2001:xxx::-2xxx:xx8::0020
Server /network/ipfiltering *# commit
Changes to the ipfiltering will be applied immediately.
You may lose connectivity to the Cisco IMC and may have to log in again.
Do you wish to continue? [y/N] Y

```

# Network Time Protocol Configuration

## Configuring Network Time Protocol Settings

By default, when Cisco IMC is reset, it synchronizes the time with the host. With the introduction of the NTP service, you can configure Cisco IMC to synchronize the time with an NTP server. The NTP server does not run in Cisco IMC by default. You must enable and configure the NTP service by specifying the IP/DNS address of at least one server or a maximum of four servers that function as NTP servers or time source servers. When you enable the NTP service, Cisco IMC synchronizes the time with the configured NTP server. The NTP service can be modified only through Cisco IMC.



**Note** To enable the NTP service, it is preferable to specify the IP address of a server rather than the DNS address.

### Before you begin

You must log in with admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
Step 1	Server # <b>scope time</b>	Enters time command mode.

	Command or Action	Purpose
<b>Step 2</b>	Server /time # <b>scope ntp</b>	Enters NTP service command mode.
<b>Step 3</b>	Server /time/ntp # <b>set enabled yes</b>	Enables the NTP service on the server.
<b>Step 4</b>	Server /time/ntp* # <b>commit</b>	Commits the transaction.
<b>Step 5</b>	Server /time/ntp # <b>set server-1 10.120.33.44</b>	Specifies the IP/DNS address of one of the four servers that act as an NTP server or the time source server.
<b>Step 6</b>	Server /time/ntp # <b>set server-2 10.120.34.45</b>	Specifies the IP/DNS address of one of the four servers that act as an NTP server or the time source server.
<b>Step 7</b>	Server /time/ntp # <b>set server-3 10.120.35.46</b>	Specifies the IP/DNS address of one of the four servers that act as an NTP server or the time source server.
<b>Step 8</b>	Server /time/ntp # <b>set server-4 10.120.36.48</b>	Specifies the IP/DNS address of one of the four servers that act as an NTP server or the time source server.
<b>Step 9</b>	Server /time/ntp # <b>commit</b>	Commits the transaction.
<b>Step 10</b>	Server /time/ntp # <b>show detail</b>	Displays the NTP configuration details.

### Example

This example shows how to configure the NTP service:

```

Server # scope time
Server /time # scope ntp
Server /time/ntp # set enabled yes
Warning: IPMI Set SEL Time Command will be
disabled if NTP is enabled.
Do you wish to continue? [y|N]
y
Server /time/ntp* # commit
Server /time/ntp # set server-1 10.120.33.44
Server /time/ntp* # set server-2 10.120.34.45
Server /time/ntp* # set server-3 10.120.35.46
Server /time/ntp* # set server-4 10.120.36.48
Server /time/ntp* # commit
Server /time/ntp # show details
NTP Service Settings:
  NTP Enabled: yes
  NTP Server 1: 10.120.33.44
  NTP Server 2: 10.120.34.45
  NTP Server 3: 10.120.35.46
  NTP Server 4: 10.120.36.48
  Status: NTP service enabled

```

# Pinging an IP address

Ping an IP address when you want to validate network connectivity with the IP address in the Cisco IMC.

## Before you begin

You must log in as a user with administration privileges to ping an IP address.

## Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope network</b>	Enters the network command mode.
<b>Step 2</b>	Server /network# <b>ping IP address   retriesnumber   timeoutseconds</b>	<p>Pings the IP address or host name for a specified number of times until timeout.</p> <ul style="list-style-type: none"> <li>• <b>IP address/hostname</b> - The IP address or the host name of the server.</li> <li>• <b>Number of retries</b> - The number of times the system tries to connect to the server. Default value is 3. Valid range is from 1 to 10.</li> <li>• <b>Timeout</b> - The number of seconds the system waits before it stops pinging. Default maximum value is 20 seconds. Valid range is from 1 to 20 seconds.</li> <li>• <b>Component</b> - The controller that you can ping.</li> </ul>
<b>Step 3</b>	Server /network # <b>commit</b>	Commits the transaction to the system configuration.
<b>Step 4</b>	At the prompt, enter <b>y</b> to confirm.	Pings the IP address.

## Example

This example pings an IP address:

```
Server # scope network
Server /network # ping 10.10.10.10
PING 10.10.10.10 (10.10.10.10): 56 data bytes
64 bytes from 10.10.10.10: seq=0 ttl=238 time=146.343 ms
64 bytes from 10.10.10.10: seq=1 ttl=238 time=146.140 ms
64 bytes from 10.10.10.10: seq=2 ttl=238 time=146.238 ms

--- 10.10.10.10 ping statistics ---
3 packets transmitted, 3 packets received, 0% packet loss
round-trip min/avg/max = 146.140/146.240/146.343 ms
Server /cimc/network #
```





## CHAPTER 10

# Managing Network Adapters

---

This chapter includes the following sections:

- [Overview of the Cisco UCS C-Series Network Adapters, on page 163](#)
- [Viewing Network Adapter Properties, on page 165](#)
- [Configuring Network Adapter Properties, on page 166](#)
- [Managing vHBAs, on page 169](#)
- [Managing vNICs, on page 184](#)
- [Backing Up and Restoring the Adapter Configuration, on page 207](#)
- [Managing Adapter Firmware, on page 210](#)

## Overview of the Cisco UCS C-Series Network Adapters



---

**Note** The procedures in this chapter are available only when a Cisco UCS C-Series network adapter is installed in the chassis.

---

A Cisco UCS C-Series network adapter can be installed to provide options for I/O consolidation and virtualization support. The following adapters are available:

- Cisco UCS VIC 1225 Virtual Interface Card
- Cisco UCS VIC 1227T Virtual Interface Card
- Cisco UCS VIC 1385 Virtual Interface Card
- Cisco UCS VIC 1387 Virtual Interface Card
- Cisco UCS VIC 1455 Virtual Interface Card
- Cisco UCS VIC 1457 Virtual Interface Card
- Cisco UCS VIC 1495 Virtual Interface Card
- Cisco UCS VIC 1497 Virtual Interface Card



**Note** You must have same generation VIC cards on a server. For example, you cannot have a combination of 3rd generation and 4th generation VIC cards on a single server.

The interactive *UCS Hardware and Software Interoperability Utility* lets you view the supported components and configurations for a selected server model and software release. The utility is available at the following URL: <http://www.cisco.com/web/techdoc/ucs/interoperability/matrix/matrix.html>

### **Cisco UCS VIC 1225 Virtual Interface Card**

The Cisco UCS VIC 1225 Virtual Interface Card is a high-performance, converged network adapter that provides acceleration for the various new operational modes introduced by server virtualization. It brings superior flexibility, performance, and bandwidth to the new generation of Cisco UCS C-Series Rack-Mount Servers.

### **Cisco UCS VIC 1385 Virtual Interface Card**

The Cisco UCS VIC 1385 Virtual Interface Card is a dual-port Enhanced Quad Small Form-Factor Pluggable (QSFP) 40 Gigabit Ethernet and Fibre Channel over Ethernet (FCoE)-capable half-height PCI Express (PCIe) card designed exclusively for Cisco UCS C-Series Rack Servers. It incorporates Cisco's next-generation converged network adapter (CNA) technology, with a comprehensive feature set, providing investment protection for future feature software releases.

### **Cisco UCS VIC 1227T Virtual Interface Card**

The Cisco UCS VIC 1227T Virtual Interface Card is a dual-port 10GBASE-T (RJ-45) 10-Gbps Ethernet and Fibre Channel over Ethernet (FCoE)-capable PCI Express (PCIe) modular LAN-on-motherboard (mLOM) adapter designed exclusively for Cisco UCS C-Series Rack Servers. New to Cisco rack servers, the mLOM slot can be used to install a Cisco VIC without consuming a PCIe slot, which provides greater I/O expandability. It incorporates next-generation converged network adapter (CNA) technology from Cisco, providing Fibre Channel connectivity over low-cost twisted pair cabling with a bit error rate (BER) of 10 to 15 up to 30 meters and investment protection for future feature releases.

### **Cisco UCS VIC 1387 Virtual Interface Card**

The Cisco UCS VIC 1387 Virtual Interface Card is a dual-port Enhanced Quad Small Form-Factor Pluggable (QSFP) 40 Gigabit Ethernet and Fibre Channel over Ethernet (FCoE)-capable half-height PCI Express (PCIe) card designed exclusively for Cisco UCS C-Series Rack Servers. It incorporates Cisco's next-generation converged network adapter (CNA) technology, with a comprehensive feature set, providing investment protection for future feature software releases.

### **Cisco UCS VIC 1455 Virtual Interface Card**

The Cisco UCS VIC 1455 is a quad-port Small Form-Factor Pluggable (SFP28) half-height PCIe card designed for M5 generation of Cisco UCS C-Series rack servers. The card supports 10/25-Gbps Ethernet or FCoE. It incorporates Cisco's next-generation CNA technology and offers a comprehensive feature set, providing investment protection for future feature software releases. The card can present PCIe standards-compliant interfaces to the host, and these can be dynamically configured as NICs and HBAs.

### Cisco UCS VIC 1457 Virtual Interface Card

The Cisco UCS VIC 1457 is a quad-port Small Form-Factor Pluggable (SFP28) mLOM card designed for M5 generation of Cisco UCS C-Series rack servers. The card supports 10/25-Gbps Ethernet or FCoE. It incorporates Cisco's next-generation CNA technology and offers a comprehensive feature set, providing investment protection for future feature software releases. The card can present PCIe standards-compliant interfaces to the host, and these can be dynamically configured as NICs and HBAs.

### Cisco UCS VIC 1495 Virtual Interface Card

The Cisco UCS VIC 1495 is a dual-port Small Form-Factor (QSFP28) PCIe card designed for the M5 generation of Cisco UCS C-Series Rack Servers. The card supports 40/100-Gbps Ethernet and FCoE. The card can present PCIe standards-compliant interfaces to the host, and these can be dynamically configured as NICs and HBAs.

### Cisco UCS VIC 1497 Virtual Interface Card

The Cisco VIC 1497 is a dual-port Small Form-Factor (QSFP28) mLOM card designed for the M5 generation of Cisco UCS C-Series Rack Servers. The card supports 40/100-Gbps Ethernet and FCoE. The card can present PCIe standards-compliant interfaces to the host, and these can be dynamically configured as NICs and HBAs.

## Viewing Network Adapter Properties

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>show adapter</b> [ <i>index</i> ] [ <b>detail</b> ]	Displays adapter properties. To display the properties of a single adapter, specify the PCI slot number as the <i>index</i> argument.

### Example

- This example displays the properties of adapter:

```
Server# scope chassis
Server /chassis # show adapter
PCI Slot Product Name Serial Number Product ID Vendor
-----
11 UCS VIC 1455 FCH233770S8 UCSC-PCIE-C... Cisco Systems Inc
Server /chassis # show adapter detail
PCI Slot 11:
Product Name: UCS VIC 1455
Serial Number: FCH233770S8
Product ID: UCSC-PCIE-C25Q-04
Adapter Hardware Revision: 5
Current FW Version: 5.1(1.64)
VNTAG: Disabled
FIP: Enabled
LLDP: Enabled
PORT CHANNEL: Enabled
Configuration Pending: no
Cisco IMC Management Enabled: no
```

```

VID: V04
Vendor: Cisco Systems Inc
Description:
Bootloader Version: 5.0(3c)
FW Image 1 Version: 5.1(1.64)
FW Image 1 State: RUNNING ACTIVATED
FW Image 2 Version: 5.1(1.59)
FW Image 2 State: BACKUP INACTIVATED
FW Update Status: Fwupdate never issued
FW Update Error: No error
FW Update Stage: No operation (0%)
FW Update Overall Progress: 0%
Server /chassis #

```

## Configuring Network Adapter Properties

### Before you begin

- You must log in with admin privileges to perform this task.
- A supported Virtual Interface Card (VIC) must be installed in the chassis and the server must be powered on.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>show adapter</b>	(Optional) Displays the available adapter devices.
<b>Step 3</b>	Server /chassis # <b>scope adapter</b> <i>index</i>	Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> .  <b>Note</b> The server must be powered on before you can view or change adapter settings.
<b>Step 4</b>	Server /chassis/adapter # <b>set fip-mode</b> { <b>disable</b>   <b>enable</b> }	Enables or disables FCoE Initialization Protocol (FIP) on the adapter card. FIP is enabled by default.  <b>Note</b> <ul style="list-style-type: none"> <li>• We recommend that you disable this option only when explicitly directed to do so by a technical support representative.</li> <li>• FCoE over port channel is not supported with 1455 or 1457 adapters. FCoE is supported in the non port channel mode.</li> </ul>



	Command or Action	Purpose
<b>Step 5</b>	Server /chassis/adapter # <b>set lldp</b> { <b>disable</b>   <b>enable</b> }	<p><b>Note</b> For LLDP change to be effective, it is required that you reboot the server.</p> <p>In case of S3260 chassis with two nodes, ensure to reboot the secondary node after making LLDP changes in the primary node.</p> <p>Enables or disables Link Layer Discovery Protocol (LLDP) on the adapter card. LLDP is enabled by default.</p> <p><b>Note</b> We recommend that you do not disable LLDP option, as it disables all the Data Center Bridging Capability Exchange protocol (DCBX) functionality.</p>
<b>Step 6</b>	Server /chassis/adapter # <b>set vntag-mode</b> { <b>disabled</b>   <b>enabled</b> }	<p>Enables or disables VNTAG on the adapter card. VNTAG is disabled by default.</p> <p><b>Note</b></p> <p>If VNTAG mode is enabled:</p> <ul style="list-style-type: none"> <li>• vNICs and vHBAs can be assigned to a specific channel.</li> <li>• vNICs and vHBAs can be associated to a port profile.</li> <li>• vNICs can fail over to another vNIC if there are communication problems.</li> </ul>
<b>Step 7</b>	Server /chassis/adapter # <b>set portchannel</b> <i>disabled</i>	<p>Allows you to enable or disable the port channel. When you disable port channel, four vNICs and vHBAs are available for use on the adapter.</p> <p>When Port channel is enabled:</p> <ul style="list-style-type: none"> <li>• Only two vNICs and vHBAs are available for use.</li> <li>• Port 0 and 1 are bundled as one port channel and Port 2 and 3 are bundled as the other port channel.</li> </ul>

	Command or Action	Purpose
		<p><b>Note</b></p> <ul style="list-style-type: none"> <li>• This option is enabled by default on Cisco UCS VIC 1455 and 1457.</li> <li>• When you change the port channel configuration, all the previously created vNICs and vHBAs will be deleted and the configuration will be restored to factory defaults.</li> <li>• VNTAG mode is supported only in the port-channel mode.</li> </ul>
<b>Step 8</b>	Server /chassis/adapter # <b>set physical-nic-mode enabled</b>	<p><b>Important</b> <b>Physical NIC Mode</b> option is added on an experimental basis and the need to configure this option is rear.</p> <p>Allows you to enable or disable the physical NIC mode. This option is disabled by default.</p> <p>When Physical NIC Mode is enabled, up-link ports of the VIC are set to pass-through mode. This allows the host to transmit packets without any modification. VIC ASIC does not rewrite the VLAN tag of the packets based on the VLAN and CoS settings for the vNIC.</p> <p><b>Note</b> This option is available only for Cisco UCS VIC 14xx series adapters.</p> <p>This option cannot be enabled on an adapter that has:</p> <ul style="list-style-type: none"> <li>• <b>Port Channel mode</b> enabled</li> <li>• <b>VNTAG mode</b> enabled</li> <li>• <b>LLDP</b> enabled</li> <li>• <b>FIP mode</b> enabled</li> <li>• <b>Cisco IMC Management Enabled</b> value set to <b>Yes</b></li> <li>• multiple user created vNICs</li> </ul>
<b>Step 9</b>	Server /chassis/adapter* # <b>commit</b>	Commits the transaction to the system configuration.

## Example

This example configures the properties of adapter 1:

```

Server# scope chassis
Server /chassis # scope adapter 1
Server /chassis/adapter # set fip-mode enable
Server /chassis/adapter *# set vntag-mode enabled
Server /chassis/adapter* # set portchannel disabled
Server /chassis/adapter *# commit
Warning: Enabling VNTAG mode
All the vnic configuration will be reset to factory defaults
New VNIC adapter settings will take effect upon the next server reset
Server /chassis/adapter # show detail
PCI Slot 1:
  Product Name: UCS VIC xxxx
  Serial Number: FCHXXXXXZV4
  Product ID: UCSC-PCIE-xxx-04
  Adapter Hardware Revision: 3
  Current FW Version: x.0(0.345)
  VNTAG: Enabled
  FIP: Enabled
  LLDP: Enabled
  PORT CHANNEL: Disabled
  Configuration Pending: no
  Cisco IMC Management Enabled: no
  VID: V00
  Vendor: Cisco Systems Inc
  Description:
  Bootloader Version: xxx
  FW Image 1 Version: x.0(0.345)
  FW Image 1 State: RUNNING ACTIVATED
  FW Image 2 Version: gafskl-dev-170717-1500-orosz-ET
  FW Image 2 State: BACKUP INACTIVATED
  FW Update Status: Fwupdate never issued
  FW Update Error: No error
  FW Update Stage: No operation (0%)
  FW Update Overall Progress: 0%
Server /chassis/adapter #

```

# Managing vHBAs

## Guidelines for Managing vHBAs

When managing vHBAs, consider the following guidelines and restrictions:

- The SIOCs with the Cisco UCS Virtual Interface Cards provide two vHBAs and two vNICs by default. You can create up to 14 additional vHBAs or vNICs on these adapter cards.

The Cisco UCS 1455 and 1457 Virtual Interface Cards, in non-port channel mode, provide four vHBAs and four vNICs by default. You can create up to 10 additional vHBAs or vNICs on these adapter cards in VNTAG mode.



**Note** If VNTAG mode is enabled for the adapter, you must assign a channel number to a vHBA when you create it.

- When using the Cisco UCS Virtual Interface Cards in an FCoE application, you must associate the vHBA with the FCoE VLAN. Follow the instructions in the **Modifying vHBA Properties** section to assign the VLAN.
- After making configuration changes, you must reboot the host for settings to take effect.

## Viewing vHBA Properties

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope adapter</b> <i>index</i>	Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> .  <b>Note</b> The server must be powered on before you can view or change adapter settings.
<b>Step 3</b>	Server /chassis/adapter # <b>show host-fc-if</b> [ <b>fc0</b>   <b>fc1</b>   <i>name</i> ] [ <b>detail</b> ]	Displays properties of a single vHBA, if specified, or all vHBAs.

### Example

This example displays all vHBAs on adapter card 1 and the detailed properties of fc0:

```
Server# scope chassis
Server /chassis # scope adapter 1
Server /chassis/adapter # show host-fc-if
Name          World Wide Port Name      FC SAN Boot Uplink Port
-----
fc0           20:00:00:22:BD:D6:5C:35   Disabled    0
fc1           20:00:00:22:BD:D6:5C:36   Disabled    1

Server /chassis/adapter # show host-fc-if fc0 detail
Name fc0:
  World Wide Node Name: 10:00:70:0F:6A:C0:97:43
  World Wide Port Name: 20:00:70:0F:6A:C0:97:43
  FC SAN Boot: disabled
  FC Type: fc-initiator
  Persistent LUN Binding: disabled
  Uplink Port: 0
  PCI Link: 0
  MAC Address: 70:0F:6A:C0:97:43
  CoS: 3
  VLAN: NONE
  Rate Limiting: OFF
```

```

PCIe Device Order: 2
EDTOV: 2000
RATOV: 10000
Maximum Data Field Size: 2112
Channel Number: N/A
Port Profile: N/A

```

```
Server /chassis/adapter #
```

## Modifying vHBA Properties

### Before you begin

You must log in with admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>show adapter</b>	(Optional) Displays the available adapter devices.
<b>Step 3</b>	Server /chassis # <b>scope adapter</b> <i>index</i>	Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> .  <b>Note</b> The server must be powered on before you can view or change adapter settings.
<b>Step 4</b>	Server /chassis/adapter # <b>scope host-fc-if</b> { <b>fc0</b>   <b>fc1</b>   <i>name</i> }	Enters the host Fibre Channel interface command mode for the specified vHBA.
<b>Step 5</b>	Server /chassis/adapter/host-fc-if # <b>set wwnn</b> <i>wwnn</i>	Specifies a unique World Wide Node Name (WWNN) for the adapter in the form hh:hh:hh:hh:hh:hh:hh:hh.  Unless specified by this command, the WWNN is generated automatically by the system.
<b>Step 6</b>	Server /chassis/adapter/host-fc-if # <b>set wwpn</b> <i>wwpn</i>	Specifies a unique World Wide Port Name (WWPN) for the adapter in the form hh:hh:hh:hh:hh:hh:hh:hh.  Unless specified by this command, the WWPN is generated automatically by the system.
<b>Step 7</b>	Server /chassis/adapter/host-fc-if # <b>set boot</b> { <b>disable</b>   <b>enable</b> }	Enables or disables FC SAN boot. The default is disable.
<b>Step 8</b>	Server /chassis/adapter/host-fc-if # <b>set persistent-lun-binding</b> { <b>disable</b>   <b>enable</b> }	Enables or disables persistent LUN binding. The default is disable.

	Command or Action	Purpose
<b>Step 9</b>	Server /chassis/adapter/host-fc-if # <b>set mac-addr</b> <i>mac-addr</i>	Specifies a MAC address for the vHBA.
<b>Step 10</b>	Server /chassis/adapter/host-fc-if # <b>set vlan</b> { <b>none</b>   <i>vlan-id</i> }	Specifies the default VLAN for this vHBA. Valid VLAN numbers are 1 to 4094; the default is none.
<b>Step 11</b>	Server /chassis/adapter/host-fc-if # <b>set cos</b> <i>cos-value</i>	Specifies the class of service (CoS) value to be marked on received packets unless the vHBA is configured to trust host CoS. Valid CoS values are 0 to 6; the default is 0. Higher values indicate more important traffic.  This setting is not functional in NIV mode.
<b>Step 12</b>	Server /chassis/adapter/host-fc-if # <b>set rate-limit</b> { <b>off</b>   <i>rate</i> }	Specifies a maximum data rate for the vHBA. The range is 1 to 100000 Mbps; the default is off.  This setting is not functional in NIV mode.
<b>Step 13</b>	Server /chassis/adapter/host-fc-if # <b>set order</b> { <b>any</b>   <i>0-99</i> }	Specifies the relative order of this device for PCIe bus device number assignment; the default is any.
<b>Step 14</b>	Server /chassis/adapter/host-fc-if # <b>set error-detect-timeout</b> <i>msec</i>	Specifies the error detect timeout value (EDTOV), the number of milliseconds to wait before the system assumes that an error has occurred. The range is 1000 to 100000; the default is 2000 milliseconds.
<b>Step 15</b>	Server /chassis/adapter/host-fc-if # <b>set resource-allocation-timeout</b> <i>msec</i>	Specifies the resource allocation timeout value (RATOV), the number of milliseconds to wait before the system assumes that a resource cannot be properly allocated. The range is 5000 to 100000; the default is 10000 milliseconds.
<b>Step 16</b>	Server /chassis/adapter/host-fc-if # <b>set max-data-field-size</b> <i>size</i>	Specifies the maximum size of the Fibre Channel frame payload (in bytes) that the vHBA supports. The range is 1 to 2112; the default is 2112 bytes.
<b>Step 17</b>	Server /chassis/adapter/host-fc-if # <b>set channel-number</b> <i>channel number</i>	The channel number that will be assigned to this vHBA. Enter an integer between 1 and 1,000.  <b>Note</b> VNTAG mode is required for this option.
<b>Step 18</b>	Server /chassis/adapter/host-fc-if # <b>set pci-link</b> <i>0/1</i>	The link through which vNICs can be connected. These are the following values:

	Command or Action	Purpose
		<ul style="list-style-type: none"> <li>• 0 — The first cross-edged link where the vNIC is placed.</li> <li>• 1 — The second cross-edged link where the vNIC is placed.</li> </ul> <p><b>Note</b> This option is available only on some Cisco UCS C-Series servers.</p>
<b>Step 19</b>	Server /chassis/adapter/host-fc-if # <b>set uplink</b> <i>Port number</i>	The uplink port associated with the vHBA.  <b>Note</b> This value cannot be changed for the system-defined vHBAs fc0 and fc1.
<b>Step 20</b>	Server /chassis/adapter/host-fc-if # <b>set vhma-type</b> <i>fc-initiator fc-target fc-nvme-initiator fc-nvme-target</i>	The vHBA type used in this policy. vHBAs supporting FC and FC-NVMe can now be created on the same adapter. The vHBA type used in this policy can be one of the following: <ul style="list-style-type: none"> <li>• fc-initiator—Legacy SCSI FC vHBA initiator</li> <li>• fc-target—vHBA that supports SCSI FC target functionality</li> </ul> <p><b>Note</b> This option is available as a Tech Preview.</p> <ul style="list-style-type: none"> <li>• fc-nvme-initiator—vHBA that is an FC NVMe initiator, which discovers FC NVMe targets and connects to them.</li> <li>• fc-nvme-target—vHBA that acts as an FC NVMe target and provides connectivity to the NVMe storage.</li> </ul>
<b>Step 21</b>	Server /chassis/adapter/host-fc-if # <b>scope error-recovery</b>	Enters the Fibre Channel error recovery command mode.
<b>Step 22</b>	Server /chassis/adapter/host-fc-if/error-recovery # <b>set fcp-error-recovery</b> {disable   enable}	Enables or disables FCP Error Recovery. The default is disable.
<b>Step 23</b>	Server /chassis/adapter/host-fc-if/error-recovery # <b>set link-down-timeout</b> msec	Specifies the link down timeout value, the number of milliseconds the uplink port should be offline before it informs the system that the uplink port is down and fabric connectivity has been lost. The range is 0 to 240000; the default is 30000 milliseconds.

	Command or Action	Purpose
<b>Step 24</b>	Server /chassis/adapter/host-fc-if/error-recovery # <b>set port-down-io-retry-count</b> <i>count</i>	Specifies the port down I/O retries value, the number of times an I/O request to a port is returned because the port is busy before the system decides the port is unavailable. The range is 0 to 255; the default is 8 retries.
<b>Step 25</b>	Server /chassis/adapter/host-fc-if/error-recovery # <b>set port-down-timeout</b> <i>msec</i>	Specifies the port down timeout value, the number of milliseconds a remote Fibre Channel port should be offline before informing the SCSI upper layer that the port is unavailable. The range is 0 to 240000; the default is 10000 milliseconds.
<b>Step 26</b>	Server /chassis/adapter/host-fc-if/error-recovery # <b>exit</b>	Exits to the host Fibre Channel interface command mode.
<b>Step 27</b>	Server /chassis/adapter/host-fc-if # <b>scope interrupt</b>	Enters the interrupt command mode.
<b>Step 28</b>	Server /chassis/adapter/host-fc-if/interrupt # <b>set interrupt-mode</b> { <b>intx</b>   <b>msi</b>   <b>msix</b> }	Specifies the Fibre Channel interrupt mode. The modes are as follows: <ul style="list-style-type: none"> <li>• <b>intx</b> —Line-based interrupt (INTx)</li> <li>• <b>msi</b> —Message-Signaled Interrupt (MSI)</li> <li>• <b>msix</b> —Message Signaled Interrupts with the optional extension (MSIx). This is the recommended and default option.</li> </ul>
<b>Step 29</b>	Server /chassis/adapter/host-fc-if/interrupt # <b>exit</b>	Exits to the host Fibre Channel interface command mode.
<b>Step 30</b>	Server /chassis/adapter/host-fc-if # <b>scope port</b>	Enters the Fibre Channel port command mode.
<b>Step 31</b>	Server /chassis/adapter/host-fc-if/port # <b>set outstanding-io-count</b> <i>count</i>	Specifies the I/O throttle count, the number of I/O operations that can be pending in the vHBA at one time. The range is 1 to 1024; the default is 512 operations.
<b>Step 32</b>	Server /chassis/adapter/host-fc-if/port # <b>set max-target-luns</b> <i>count</i>	Specifies the maximum logical unit numbers (LUNs) per target, the maximum number of LUNs that the driver will discover. This is usually an operating system platform limitation. The range is 1 to 1024; the default is 256 LUNs.
<b>Step 33</b>	Server /chassis/adapter/host-fc-if/port # <b>exit</b>	Exits to the host Fibre Channel interface command mode.
<b>Step 34</b>	Server /chassis/adapter/host-fc-if # <b>scope port-f-logi</b>	Enters the Fibre Channel fabric login command mode.



	Command or Action	Purpose
<b>Step 35</b>	Server /chassis/adapter/host-fc-if/port-f-logs # <b>set flogi-retries</b> {infinite   count}	Specifies the fabric login (FLOGI) retries value, the number of times that the system tries to log in to the fabric after the first failure. Enter a number between 0 and 4294967295 or enter <b>infinite</b> ; the default is infinite retries.
<b>Step 36</b>	Server /chassis/adapter/host-fc-if/port-f-logs # <b>set flogi-timeout</b> msec	Specifies the fabric login (FLOGI) timeout value, the number of milliseconds that the system waits before it tries to log in again. The range is 1 to 255000; the default is 2000 milliseconds.
<b>Step 37</b>	Server /chassis/adapter/host-fc-if/port-f-logs # <b>exit</b>	Exits to the host Fibre Channel interface command mode.
<b>Step 38</b>	Server /chassis/adapter/host-fc-if # <b>scope</b> <b>port-p-logs</b>	Enters the Fibre Channel port login command mode.
<b>Step 39</b>	Server /chassis/adapter/host-fc-if/port-p-logs # <b>set plogi-retries</b> count	Specifies the port login (PLOGI) retries value, the number of times that the system tries to log in to the fabric after the first failure. The range is 0 and 255; the default is 8 retries.
<b>Step 40</b>	Server /chassis/adapter/host-fc-if/port-p-logs # <b>set plogi-timeout</b> msec	Specifies the port login (PLOGI) timeout value, the number of milliseconds that the system waits before it tries to log in again. The range is 1 to 255000; the default is 2000 milliseconds.
<b>Step 41</b>	Server /chassis/adapter/host-fc-if/port-p-logs # <b>exit</b>	Exits to the host Fibre Channel interface command mode.
<b>Step 42</b>	Server /chassis/adapter/host-fc-if # <b>scope</b> <b>scsi-io</b>	Enters the SCSI I/O command mode.
<b>Step 43</b>	Server /chassis/adapter/host-fc-if/scsi-io # <b>set</b> <b>cdb-wq-count</b> count	The number of command descriptor block (CDB) transmit queue resources to allocate. The range is 1 to 8; the default is 1.
<b>Step 44</b>	Server /chassis/adapter/host-fc-if/scsi-io # <b>set</b> <b>cdb-wq-ring-size</b> size	The number of descriptors in the command descriptor block (CDB) transmit queue. The range is 64 to 512; the default is 512.
<b>Step 45</b>	Server /chassis/adapter/host-fc-if/scsi-io # <b>exit</b>	Exits to the host Fibre Channel interface command mode.
<b>Step 46</b>	Server /chassis/adapter/host-fc-if # <b>scope</b> <b>trans-queue</b>	Enters the Fibre Channel transmit queue command mode.
<b>Step 47</b>	Server /chassis/adapter/host-fc-if/trans-queue # <b>set fc-wq-ring-size</b> size	The number of descriptors in the Fibre Channel transmit queue. The range is 64 to 128; the default is 64.

	Command or Action	Purpose
<b>Step 48</b>	Server /chassis/adapter/host-fc-if/trans-queue # <b>exit</b>	Exits to the host Fibre Channel interface command mode.
<b>Step 49</b>	Server /chassis/adapter/host-fc-if # <b>scope recv-queue</b>	Enters the Fibre Channel receive queue command mode.
<b>Step 50</b>	Server /chassis/adapter/host-fc-if/recv-queue # <b>set fc-rq-ring-size size</b>	The number of descriptors in the Fibre Channel receive queue. The range is 64 to 128; the default is 64.
<b>Step 51</b>		
<b>Step 52</b>	Server /chassis/adapter/host-fc-if/recv-queue # <b>exit</b>	Exits to the host Fibre Channel interface command mode.
<b>Step 53</b>	Server /chassis/adapter/host-fc-if # <b>commit</b>	Commits the transaction to the system configuration.  <b>Note</b> The changes will take effect upon the next server reboot.

### Example

This example configures the properties of a vHBA (only few options are shown):

```
Server# scope chassis
Server /chassis # show adapter
PCI Slot Product Name Serial Number Product ID Vendor
-----
1 UCS VIC P81E QCI1417A0QK N2XX-ACPCI01 Cisco Systems Inc

Server /chassis # scope adapter 1
Server /chassis/adapter # scope host-fc-if fc1
Server /chassis/adapter/host-fc-if # set boot enable
Server /chassis/adapter/host-fc-if *# scope scsi-io
Server /chassis/adapter/host-fc-if/scsi-io *# set cdb-wq-count 2
Server /chassis/adapter/host-fc-if/scsi-io *# exit
Server /chassis/adapter/host-fc-if *# commit
Server /chassis/adapter/host-fc-if #
```

### What to do next

Reboot the server to apply the changes.

## Creating a vHBA

The adapter provides two permanent vHBAs. If NIV mode is enabled, you can create up to 16 additional vHBAs.



**Note** Additional vHBAs can be created only in **VNTAG** mode.

### Before you begin

You must log in with user or admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope adapter</b> <i>index</i>	Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> .  <b>Note</b> The server must be powered on before you can view or change adapter settings.
<b>Step 3</b>	Server /chassis/adapter # <b>create host-fc-if</b> <i>name</i>	Creates a vHBA and enters the host Fibre Channel interface command mode. The <i>name</i> argument can be up to 32 ASCII characters.
<b>Step 4</b>	Server /chassis/adapter/host-fc-if # <b>set channel-number</b> <i>number</i>	Assign a channel number to this vHBA. The range is 1 to 1000.
<b>Step 5</b>	Server /chassis/adapter/host-fc-if # <b>commit</b>	Commits the transaction to the system configuration.  <b>Note</b> The changes will take effect upon the next server reboot.

### Example

This example creates a vHBA on adapter 1:

```
Server# scope chassis
Server /chassis # scope adapter 1
Server /chassis/adapter # create host-fc-if Vhba5
Server /chassis/adapter/host-fc-if *# commit
New host-fc-if settings will take effect upon the next server reset
Server /chassis/adapter/host-fc-if #
```

### What to do next

- Reboot the server to create the vHBA.
- If configuration changes are required, configure the new vHBA as described in [Modifying vHBA Properties](#), on page 171.

## Deleting a vHBA

### Before you begin

You cannot delete the default vHBAs.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope adapter</b> <i>index</i>	Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> .  <b>Note</b> The server must be powered on before you can view or change adapter settings.
<b>Step 3</b>	Server /chassis/adapter # <b>delete host-fc-if</b> <i>name</i>	Deletes the specified vHBA.  <b>Note</b> You cannot delete either of the two default vHBAs, fc0 or fc1.
<b>Step 4</b>	Server /chassis/adapter # <b>commit</b>	Commits the transaction to the system configuration.  <b>Note</b> The changes will take effect upon the next server reboot.

### Example

This example deletes a vHBA on adapter 1:

```
Server# scope chassis
Server /chassis # scope adapter 1
Server /chassis/adapter # delete host-fc-if Vhba5
Server /chassis/adapter *# commit
Server /chassis/adapter #
```

## vHBA Boot Table

In the vHBA boot table, you can specify up to four LUNs from which the server can boot.

## Viewing the Boot Table

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters the chassis command mode.

	Command or Action	Purpose
<b>Step 2</b>	Server /chassis # <b>scope adapter</b> <i>index</i>	Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> .  <b>Note</b> The server must be powered on before you can view or change adapter settings.
<b>Step 3</b>	Server /chassis/adapter # <b>scope host-fc-if</b> { <b>fc0</b>   <b>fc1</b>   <i>name</i> }	Enters the host Fibre Channel interface command mode for the specified vHBA.
<b>Step 4</b>	Server /chassis/adapter/host-fc-if # <b>show boot</b>	Displays the boot table of the Fibre Channel interface.

### Example

This example displays the boot table for a vHBA:

```
Server# scope chassis
Server /chassis # scope adapter 1
Server /chassis/adapter # scope host-fc-if fc1
Server /chassis/adapter/host-fc-if # show boot
Boot Table Entry  Boot Target WWPN          Boot LUN ID
-----
0                 20:00:00:11:22:33:44:55    3
1                 20:00:00:11:22:33:44:56    5

Server /chassis/adapter/host-fc-if #
```

## Creating a Boot Table Entry

You can create up to four boot table entries.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope adapter</b> <i>index</i>	Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> .  <b>Note</b> The server must be powered on before you can view or change adapter settings.
<b>Step 3</b>	Server /chassis/adapter # <b>scope host-fc-if</b> { <b>fc0</b>   <b>fc1</b>   <i>name</i> }	Enters the host Fibre Channel interface command mode for the specified vHBA.

	Command or Action	Purpose
<b>Step 4</b>	Server /chassis/adapter/host-fc-if # <b>create-boot-entry</b> <i>wwpn lun-id</i>	Creates a boot table entry. <ul style="list-style-type: none"> <li>• <i>wwpn</i> — The World Wide Port Name (WWPN) for the boot target in the form hh:hh:hh:hh:hh:hh:hh:hh.</li> <li>• <i>lun-id</i> —The LUN ID of the boot LUN. The range is 0 to 255.</li> </ul>
<b>Step 5</b>	Server /chassis/adapter/host-fc-if # <b>commit</b>	Commits the transaction to the system configuration. <p><b>Note</b> The changes will take effect upon the next server reboot.</p>

### Example

This example creates a boot table entry for vHBA fc1:

```
Server# scope chassis
Server /chassis # scope adapter 1
Server /chassis/adapter # scope host-fc-if fc1
Server /chassis/adapter/host-fc-if # create-boot-entry 20:00:00:11:22:33:44:55 3
Server /chassis/adapter/host-fc-if *# commit
New boot table entry will take effect upon the next server reset
Server /chassis/adapter/host-fc-if #
```

## Deleting a Boot Table Entry

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope adapter</b> <i>index</i>	Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> . <p><b>Note</b> The server must be powered on before you can view or change adapter settings.</p>
<b>Step 3</b>	Server /chassis/adapter # <b>scope host-fc-if</b> { <b>fc0</b>   <b>fc1</b>   <i>name</i> }	Enters the host Fibre Channel interface command mode for the specified vHBA.
<b>Step 4</b>	Server /chassis/adapter/host-fc-if # <b>show boot</b>	Displays the boot table. From the Boot Table Entry field, locate the number of the entry to be deleted.

	Command or Action	Purpose
<b>Step 5</b>	Server /chassis/adapter/host-fc-if # <b>delete boot entry</b>	Deletes the boot table entry at the specified position in the table. The range of <i>entry</i> is 0 to 3. The change will take effect upon the next server reset.
<b>Step 6</b>	Server /chassis/adapter/host-fc-if # <b>commit</b>	Commits the transaction to the system configuration.  <b>Note</b> The changes will take effect upon the next server reboot.

### Example

This example deletes boot table entry number 1 for the vHBA fc1:

```
Server# scope chassis
Server /chassis # scope adapter 1
Server /chassis/adapter # scope host-fc-if fc1
Server /chassis/adapter/host-fc-if # show boot
Boot Table Entry  Boot Target WWPN                Boot LUN ID
-----
0                  20:00:00:11:22:33:44:55    3
1                  20:00:00:11:22:33:44:56    5

Server /chassis/adapter/host-fc-if # delete boot 1
Server /chassis/adapter/host-fc-if *# commit
New host-fc-if settings will take effect upon the next server reset
Server /chassis/adapter/host-fc-if # show boot
Boot Table Entry  Boot Target WWPN                Boot LUN ID
-----
0                  20:00:00:11:22:33:44:55    3

Server /chassis/adapter/host-fc-if #
```

### What to do next

Reboot the server to apply the changes.

## vHBA Persistent Binding

Persistent binding ensures that the system-assigned mapping of Fibre Channel targets is maintained after a reboot.

## Enabling Persistent Binding

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters the chassis command mode.

	Command or Action	Purpose
<b>Step 2</b>	Server /chassis # <b>scope adapter</b> <i>index</i>	Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> .  <b>Note</b> The server must be powered on before you can view or change adapter settings.
<b>Step 3</b>	Server /chassis/adapter # <b>scope host-fc-if</b> { <b>fc0</b>   <b>fc1</b>   <i>name</i> }	Enters the host Fibre Channel interface command mode for the specified vHBA.
<b>Step 4</b>	Server /chassis/adapter/host-fc-if # <b>scope perbi</b>	Enters the persistent binding command mode for the vHBA.
<b>Step 5</b>	Server /chassis/adapter/host-fc-if/perbi # <b>set persistent-lun-binding enable</b>	Enables persistent binding for the vHBA.
<b>Step 6</b>	Server /chassis/adapter/host-fc-if/perbi # <b>commit</b>	Commits the transaction to the system configuration.

### Example

This example enables persistent binding for a vHBA:

```
Server# scope chassis
Server /chassis # scope adapter 4
Server /chassis/adapter # scope host-fc-if fc1
Server /chassis/adapter/host-fc-if # scope perbi
Server /chassis/adapter/host-fc-if/perbi # set persistent-lun-binding enable
Server /chassis/adapter/host-fc-if/perbi *# commit
Server /chassis/adapter/host-fc-if/perbi #
```

## Disabling Persistent Binding

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope adapter</b> <i>index</i>	Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> .  <b>Note</b> The server must be powered on before you can view or change adapter settings.
<b>Step 3</b>	Server /chassis/adapter # <b>scope host-fc-if</b> { <b>fc0</b>   <b>fc1</b>   <i>name</i> }	Enters the host Fibre Channel interface command mode for the specified vHBA.



	Command or Action	Purpose
<b>Step 4</b>	Server /chassis/adapter/host-fc-if # <b>scope perbi</b>	Enters the persistent binding command mode for the vHBA.
<b>Step 5</b>	Server /chassis/adapter/host-fc-if/perbi # <b>set persistent-lun-binding disable</b>	Disables persistent binding for the vHBA.
<b>Step 6</b>	Server /chassis/adapter/host-fc-if/perbi # <b>commit</b>	Commits the transaction to the system configuration.

### Example

This example disables persistent binding for a vHBA:

```
Server# scope chassis
Server /chassis # scope adapter 4
Server /chassis/adapter # scope host-fc-if fc1
Server /chassis/adapter/host-fc-if # scope perbi
Server /chassis/adapter/host-fc-if/perbi # set persistent-lun-binding disable
Server /chassis/adapter/host-fc-if/perbi *# commit
Server /chassis/adapter/host-fc-if/perbi #
```

## Rebuilding Persistent Binding

### Before you begin

Persistent binding must be enabled in the vHBA properties.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope adapter</b> <i>index</i>	Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> .  <b>Note</b> The server must be powered on before you can view or change adapter settings.
<b>Step 3</b>	Server /chassis/adapter # <b>scope host-fc-if</b> { <b>fc0</b>   <b>fc1</b>   <i>name</i> }	Enters the host Fibre Channel interface command mode for the specified vHBA.
<b>Step 4</b>	Server /chassis/adapter/host-fc-if # <b>scope perbi</b>	Enters the persistent binding command mode for the vHBA.
<b>Step 5</b>	Server /chassis/adapter/host-fc-if/perbi # <b>rebuild</b>	Rebuilds the persistent binding table for the vHBA.

### Example

This example rebuilds the persistent binding table for a vHBA:

```

Server# scope chassis
Server /chassis # scope adapter 4
Server /chassis/adapter # scope host-fc-if fc1
Server /chassis/adapter/host-fc-if # scope perbi
Server /chassis/adapter/host-fc-if/perbi # rebuild

Server /chassis/adapter/host-fc-if/perbi #

```

## Managing vNICs

### Guidelines for Managing vNICs

When managing vNICs, consider the following guidelines and restrictions:

- The Cisco UCS Virtual Interface Cards provide two vHBAs and two vNICs by default. You can create up to 14 additional vHBAs or vNICs on these adapter cards.

Additional vHBAs can be created using VNTAG mode.

The Cisco UCS 1455 and 1457 Virtual Interface Cards, in non-port channel mode, provide four vHBAs and four vNICs by default. You can create up to 10 additional vHBAs or vNICs on these adapter cards.




---

**Note** If VNTAG mode is enabled for the adapter, you must assign a channel number to a vNIC when you create it.

---

- After making configuration changes, you must reboot the host for settings to take effect.

## Viewing vNIC Properties

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope adapter</b> <i>index</i>	Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> .  <b>Note</b> The server must be powered on before you can view or change adapter settings.
<b>Step 3</b>	Server /chassis/adapter # <b>show host-eth-if</b> [ <b>eth0</b>   <b>eth1</b>   <i>name</i> ] [ <b>detail</b> ]	Displays properties of a single vNIC, if specified, or all vNICs.

	Command or Action	Purpose
<b>Step 4</b>	Server /chassis/adapter # <b>show ext-eth-if [detail]</b>	Displays the external ethernet interfaces' details.

**Example**

Following examples display the brief properties of all vNICs and the detailed properties of eth0 and the external interfaces:



**Note** These examples may show features available only with certain releases.

```
Server# scope chassis
Server /chassis # scope adapter 1
Server /chassis/adapter # show host-eth-if
Name      MTU      Uplink Port  MAC Address      CoS VLAN PXE Boot  iSCSI Boot  usNIC
-----
eth0      1500    0             74:A2:E6:28:C6:AE N/A N/A  disabled disabled  0
eth1      1500    1             74:A2:E6:28:C6:AF N/A N/A  disabled disabled  0
srg       1500    0             74:A2:E6:28:C6:B2 N/A N/A  disabled disabled  64
hhh       1500    0             74:A2:E6:28:C6:B3 N/A N/A  disabled disabled  0
```

```
Server /chassis/adapter # show host-eth-if eth0 detail
```

```
Name eth0:
  MTU: 1500
  Uplink Port: 0
  MAC Address: B0:8B:CF:4C:ED:FF
  CoS: 0
  Trust Host CoS: disabled
  PCI Link: 0
  PCI Order: 0
  VLAN: NONE
  VLAN Mode: TRUNK
  Rate Limiting: OFF
  PXE Boot: disabled
  iSCSI Boot: disabled
  usNIC: 0
  Channel Number: N/A
  Port Profile: N/A
  Uplink Failover: N/A
  Uplink Failback Timeout: N/A
  aRFS: disabled
  VMQ: disabled
  NVGRE: disabled
  VXLAN: disabled
  CDN Name: VIC-MLOM-eth0
  RoCE Version1: disabled
  RoCE Version2: disabled
  RDMA Queue Pairs: 0
  RDMA Memory Regions: 0
  RDMA Resource Groups: 0
  RDMA COS: 0
  Multi Queue: disabled
  No of subVnics:
  Multi Queue Transmit Queue Count:
  Multi Queue Receive Queue Count:
  Multi Que Completion Queue Count:
  Multi Queue RoCE Version1:
```

```

Multi Queue RoCE Version2:
Multi Queue RDMA Queue Pairs:
Multi Queue RDMA Memory Regions:
Multi Queue RDMA Resource Groups:
Multi Queue RDMA COS:
Advanced Filters: disabled
Geneve Offload: disabled

```

```

Server# scope chassis
Server /chassis # scope adapter 1
Server /chassis/adapter # show ext-eth-if
Port MAC Address      Link State Encap.. Mode Admin Speed Oper..Speed  Link Training
Connector Present Connector Supported
-----
0 74:A2:E6:28:C6:A2 Link      CE          40Gbps 40Gbps N/A
Yes Yes
1 74:A2:E6:28:C6:A3 Link      CE          40Gbps 40Gbps N/A
Yes Yes

```

```
Server /chassis/adapter # show ext-eth-if detail
```

```
C220-FCH1834V23X /chassis/adapter # show ext-eth-if detail
```

```
Port 0:
```

```

MAC Address: 74:A2:E6:28:C6:A2
Link State: Link
Encapsulation Mode: CE
Admin Speed: 40Gbps
Operating Speed: 40Gbps
Link Training: N/A
Connector Present: Yes
Connector Supported: Yes
Connector Type: QSFP_XCVR_CR4
Connector Vendor: CISCO
Connector Part Number: 2231254-3
Connector Part Revision: B

```

```
Port 1:
```

```

MAC Address: 74:A2:E6:28:C6:A3
Link State: Link
Encapsulation Mode: CE
Admin Speed: 40Gbps
Operating Speed: 40Gbps
Link Training: N/A
Connector Present: Yes
Connector Supported: Yes
Connector Type: QSFP_XCVR_CR4
Connector Vendor: CISCO
Connector Part Number: 2231254-3
Connector Part Revision: B

```

```
Server /chassis/adapter #
```

## Modifying vNIC Properties

### Before you begin

You must log in with admin privileges to perform this task.

## Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>show adapter</b>	(Optional) Displays the available adapter devices.
<b>Step 3</b>	Server /chassis # <b>scope adapter</b> <i>index</i>	Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> .  <b>Note</b> The server must be powered on before you can view or change adapter settings.
<b>Step 4</b>	Server /chassis/adapter # <b>scope host-eth-if</b> { <b>eth0</b>   <b>eth1</b>   <i>name</i> }	Enters the host Ethernet interface command mode for the specified vNIC.
<b>Step 5</b>	Server /chassis/adapter/host-eth-if # <b>set mtu</b> <i>mtu-value</i>	Specifies the maximum transmission unit (MTU) or packet size that the vNIC accepts. Valid MTU values are 1500 to 9000 bytes; the default is 1500.
<b>Step 6</b>	Server /chassis/adapter/host-eth-if # <b>set uplink</b> { <b>0</b>   <b>1</b> }	Specifies the uplink port associated with this vNIC. All traffic for this vNIC goes through this uplink port.
<b>Step 7</b>	Server /chassis/adapter/host-eth-if # <b>set mac-addr</b> <i>mac-addr</i>	Specifies a MAC address for the vNIC in the form hh:hh:hh:hh:hh:hh or hhhh:hhhh:hhhh.
<b>Step 8</b>	Server /chassis/adapter/host-eth-if # <b>set cos</b> <i>cos-value</i>	Specifies the class of service (CoS) value to be marked on received packets unless the vNIC is configured to trust host CoS. Valid CoS values are 0 to 6; the default is 0. Higher values indicate more important traffic.  <b>Note</b> <ul style="list-style-type: none"> <li>You must set the <b>COS</b> value to 5 for the RDMA enabled interfaces.</li> <li>If NIV is enabled, this setting is determined by the switch, and the command is ignored.</li> </ul>
<b>Step 9</b>	Server /chassis/adapter/host-eth-if # <b>set trust-host-cos</b> { <b>disable</b>   <b>enable</b> }	Specifies whether the vNIC will trust host CoS or will remark packets. The behavior is as follows: <ul style="list-style-type: none"> <li><b>disable</b>—Received packets are remarked with the configured CoS. This is the default.</li> </ul>

	Command or Action	Purpose
		<ul style="list-style-type: none"> <li>• <b>enable</b> —The existing CoS value of received packets (host CoS) is preserved.</li> </ul>
<b>Step 10</b>	Server /chassis/adapters/host-eth-if # <b>set order</b> { <b>any</b>   0-99}	Specifies the relative order of this device for PCI bus device number assignment; the default is any.
<b>Step 11</b>	Server /chassis/adapters/host-eth-if # <b>set vlan</b> { <b>none</b>   <i>vlan-id</i> }	<p>Specifies the default VLAN for this vNIC. Valid VLAN numbers are 1 to 4094; the default is none.</p> <p><b>Note</b> If NIV is enabled, this setting is determined by the switch, and the command is ignored.</p>
<b>Step 12</b>	Server /chassis/adapters/host-eth-if # <b>set vlan-mode</b> { <b>access</b>   <b>trunk</b> }	<p>Specifies the VLAN mode for the vNIC. The modes are as follows:</p> <ul style="list-style-type: none"> <li>• <b>access</b> —The vNIC belongs to only one VLAN. When the VLAN is set to access mode, any frame received from the specified default VLAN (1-4094) that is received from the switch with a TAG removes that TAG when it is sent to the host OS through the vNIC.</li> <li>• <b>trunk</b> —The vNIC can belong to more than one VLAN. This is the default.</li> </ul> <p><b>Note</b> If NIV is enabled, this setting is determined by the switch, and the command is ignored.</p>
<b>Step 13</b>	Server /chassis/adapters/host-eth-if # <b>set rate-limit</b> { <b>off</b>   <i>rate</i> }	<p>Specifies a maximum data rate for the vNIC. The range is 1 to 10000 Mbps; the default is off.</p> <p>For VIC 13xx controllers, you can enter an integer between 1 and 40,000.</p> <p>For VIC 1455 and 1457 controllers:</p> <ul style="list-style-type: none"> <li>• If the adapter is connected to 25 Gbps link on a switch, then you can enter an integer between 1 to 25,000 Mbps.</li> <li>• If the adapter is connected to 10 Gbps link on a switch, then you can enter an integer between 1 to 10,000 Mbps.</li> </ul> <p>For VIC 1495 and 1497 controllers:</p>

	Command or Action	Purpose
		<ul style="list-style-type: none"> <li>If the adapter is connected to 40 Gbps link on a switch, then you can enter an integer between 1 to 40,000 Mbps.</li> <li>If the adapter is connected to 100 Gbps link on a switch, then you can enter an integer between 1 to 100,000 Mbps.</li> </ul> <p><b>Note</b> If NIV is enabled, this setting is determined by the switch, and the command is ignored.</p>
<b>Step 14</b>	Server /chassis/adapter/host-eth-if # <b>set boot</b> { <b>disable</b>   <b>enable</b> }	Specifies whether the vNIC can be used to perform a PXE boot. Default value is set to disable for the default vNICs and user-created vNICs.
<b>Step 15</b>	Server /chassis/adapter/host-eth-if # <b>set channel-number</b> <i>number</i>	If NIV mode is enabled for the adapter, select the channel number that will be assigned to this vNIC. The range is 1 to 1000.
<b>Step 16</b>	Server /chassis/adapter/host-eth-if # <b>set port-profile</b> <i>name</i>	If NIV mode is enabled for the adapter, select the port profile that should be associated with the vNIC.  <b>Note</b> The <i>name</i> must be a port profile defined on the switch to which this server is connected.
<b>Step 17</b>	Server /chassis/adapter/host-eth-if # <b>set uplink-failover</b> { <b>disable</b>   <b>enable</b> }	If NIV mode is enabled for the adapter, enable this setting if traffic on this vNIC should fail over to the secondary interface if there are communication problems.
<b>Step 18</b>	Server /chassis/adapter/host-eth-if # <b>set uplink-failback-timeout</b> <i>seconds</i>	After a vNIC has started using its secondary interface, this setting controls how long the primary interface must be available before the system resumes using the primary interface for the vNIC.  Enter a number of <i>seconds</i> between 0 and 600.
<b>Step 19</b>	Server /chassis/adapter/host-eth-if # <b>set vmq</b> { <b>disabled</b>   <b>enabled</b> }	Enables or disables Virtual Machine Queue (VMQ) for this adapter.

	Command or Action	Purpose
		<p><b>Note</b></p> <ul style="list-style-type: none"> <li>• Ensure that VMQ is not enabled when SR-IOV is enabled on the adapter.</li> <li>• This option is available only on some Cisco UCS C-Series servers with 1455 or 1457 adapters.</li> <li>•</li> </ul>
<b>Step 20</b>	Server /chassis/adapter/host-eth-if # <b>set multi-queue {disabled   enabled}</b>	<p>Enables or disables the multi queue option for this adapter and allows you to set the following multi queue parameters:</p> <ul style="list-style-type: none"> <li>• <b>mq-rq-count</b>—The number of receive queue resources to allocate. Enter an integer between 1 and 1000.</li> <li>• <b>mq-wq-count</b>—The number of transmit queue resources to allocate. Enter an integer between 1 and 1000.</li> <li>• <b>mq-cq-count</b>—The number of completion queue resources to allocate. In general, the number of completion queue resources you should allocate is equal to the number of transmit queue resources plus the number of receive queue resources. Enter an integer between 1 and 2000.</li> </ul> <p><b>Note</b></p> <ul style="list-style-type: none"> <li>• Multi queue is supported only on C-Series servers with 14xx adapters.</li> <li>• VMQ must be in enabled state to enable this option.</li> <li>• When you enable this option on one of the vNICs, configuring only VMQ (without choosing multi-queue) on other vNICs is not supported.</li> <li>• When this option is enabled usNIC configuration will be disabled.</li> </ul>
<b>Step 21</b>	Server /chassis/adapter/host-eth-if # <b>set arfs {disable   enable}</b>	Enables or disables Accelerated Receive Flow steering (aRFS) for this adapter.



	Command or Action	Purpose
<b>Step 22</b>	Server /chassis/adapter/host-eth-if # <b>scope interrupt</b>	Enters the interrupt command mode.
<b>Step 23</b>	Server /chassis/adapter/host-eth-if/interrupt # <b>set interrupt-count</b> <i>count</i>	Specifies the number of interrupt resources. The range is 1 to 514; the default is 8. In general, you should allocate one interrupt resource for each completion queue.
<b>Step 24</b>	Server /chassis/adapter/host-eth-if/interrupt # <b>set coalescing-time</b> <i>usec</i>	The time to wait between interrupts or the idle period that must be encountered before an interrupt is sent.  The range is 1 to 65535 microseconds; the default is 125. To turn off coalescing, enter 0 (zero).
<b>Step 25</b>	Server /chassis/adapter/host-eth-if/interrupt # <b>set coalescing-type</b> { <b>idle</b>   <b>min</b> }	The coalescing types are as follows: <ul style="list-style-type: none"> <li>• <b>idle</b> —The system does not send an interrupt until there is a period of no activity lasting as least as long as the time specified in the coalescing time configuration.</li> <li>• <b>min</b> —The system waits for the time specified in the coalescing time configuration before sending another interrupt event. This is the default.</li> </ul>
<b>Step 26</b>	Server /chassis/adapter/host-eth-if/interrupt # <b>set interrupt-mode</b> { <b>intx</b>   <b>msi</b>   <b>msix</b> }	Specifies the Ethernet interrupt mode. The modes are as follows: <ul style="list-style-type: none"> <li>• <b>intx</b> —Line-based interrupt (PCI INTx)</li> <li>• <b>msi</b> —Message-Signaled Interrupt (MSI)</li> <li>• <b>msix</b> —Message Signaled Interrupts with the optional extension (MSI-X). This is the recommended and default option.</li> </ul>
<b>Step 27</b>	Server /chassis/adapter/host-eth-if/interrupt # <b>exit</b>	Exits to the host Ethernet interface command mode.
<b>Step 28</b>	Server /chassis/adapter/host-eth-if # <b>scope rcv-queue</b>	Enters receive queue command mode.
<b>Step 29</b>	Server /chassis/adapter/host-eth-if/rcv-queue # <b>set rq-count</b> <i>count</i>	The number of receive queue resources to allocate. The range is 1 to 256; the default is 4.
<b>Step 30</b>	Server /chassis/adapter/host-eth-if/rcv-queue # <b>set rq-ring-size</b> <i>size</i>	The number of descriptors in the receive queue. The range is 64 to 4094; the default is 512.

	Command or Action	Purpose
<b>Step 31</b>	Server /chassis/adapter/host-eth-if/recv-queue # <b>exit</b>	Exits to the host Ethernet interface command mode.
<b>Step 32</b>	Server /chassis/adapter/host-eth-if # <b>scope trans-queue</b>	Enters transmit queue command mode.
<b>Step 33</b>	Server /chassis/adapter/host-eth-if/trans-queue # <b>set wq-count count</b>	The number of transmit queue resources to allocate. The range is 1 to 256; the default is 1.
<b>Step 34</b>	Server /chassis/adapter/host-eth-if/trans-queue # <b>set wq-ring-size size</b>	The number of descriptors in the transmit queue. The range is 64 to 4094; the default is 256.
<b>Step 35</b>	Server /chassis/adapter/host-eth-if/trans-queue # <b>exit</b>	Exits to the host Ethernet interface command mode.
<b>Step 36</b>	Server /chassis/adapter/host-eth-if # <b>scope comp-queue</b>	Enters completion queue command mode.
<b>Step 37</b>	Server /chassis/adapter/host-eth-if/comp-queue # <b>set cq-count count</b>	The number of completion queue resources to allocate. The range is 1 to 512; the default is 5.  In general, the number of completion queues equals the number of transmit queues plus the number of receive queues.
<b>Step 38</b>	Server /chassis/adapter/host-eth-if/comp-queue # <b>exit</b>	Exits to the host Ethernet interface command mode.
<b>Step 39</b>	Server /chassis/adapter/host-eth-if/ # <b>set rdma_mr number</b>	Sets the number of memory regions to be used per adapter. The values range from 4096 to 524288.
<b>Step 40</b>	Server /chassis/adapter/host-eth-if/ # <b>set rdma_qp number</b>	Sets the number of queue pairs to be used per adapter. The values range from 1-8192 queue pairs.
<b>Step 41</b>	Server /chassis/adapter/host-eth-if/ # <b>set rdma_resgrp number</b>	Sets the number of resource groups to be used. The values range from 1-128 resource groups.  <b>Note</b> After committing the RoCE details, you are required to reboot the server for the changes to take place.
<b>Step 42</b>	Server /chassis/adapter/host-eth-if # <b>scope offload</b>	Enters TCP offload command mode.
<b>Step 43</b>	Server /chassis/adapter/host-eth-if/offload # <b>set tcp-segment-offload {disable   enable}</b>	Enables or disables TCP Segmentation Offload as follows:  • <b>disable</b> —The CPU segments large TCP packets.

	Command or Action	Purpose
		<ul style="list-style-type: none"> <li>• <b>enable</b> —The CPU sends large TCP packets to the hardware to be segmented. This option may reduce CPU overhead and increase throughput rate. This is the default.</li> </ul> <p><b>Note</b> This option is also known as Large Send Offload (LSO).</p>
<b>Step 44</b>	Server /chassis/adapter/host-eth-if/offload # <b>set tcp-rx-checksum-offload {disable   enable}</b>	<p>Enables or disables TCP Receive Offload Checksum Validation as follows:</p> <ul style="list-style-type: none"> <li>• <b>disable</b> —The CPU validates all packet checksums.</li> <li>• <b>enable</b> —The CPU sends all packet checksums to the hardware for validation. This option may reduce CPU overhead. This is the default.</li> </ul>
<b>Step 45</b>	Server /chassis/adapter/host-eth-if/offload # <b>set tcp-tx-checksum-offload {disable   enable}</b>	<p>Enables or disables TCP Transmit Offload Checksum Validation as follows:</p> <ul style="list-style-type: none"> <li>• <b>disable</b> —The CPU validates all packet checksums.</li> <li>• <b>enable</b> —The CPU sends all packet checksums to the hardware for validation. This option may reduce CPU overhead. This is the default.</li> </ul>
<b>Step 46</b>	Server /chassis/adapter/host-eth-if/offload # <b>set tcp-large-receive-offload {disable   enable}</b>	<p>Enables or disables TCP Large Packet Receive Offload as follows:</p> <ul style="list-style-type: none"> <li>• <b>disable</b> —The CPU processes all large packets.</li> <li>• <b>enable</b> —The hardware reassembles all segmented packets before sending them to the CPU. This option may reduce CPU utilization and increase inbound throughput. This is the default.</li> </ul>
<b>Step 47</b>	Server /chassis/adapter/host-eth-if/offload # <b>exit</b>	Exits to the host Ethernet interface command mode.
<b>Step 48</b>	Server /chassis/adapter/host-eth-if # <b>scope rss</b>	Enters Receive-side Scaling (RSS) command mode.
<b>Step 49</b>	Server /chassis/adapter/host-eth-if/rss # <b>set rss {disable   enable}</b>	Enables or disables RSS, which allows the efficient distribution of network receive processing across multiple CPUs in

	Command or Action	Purpose
		multiprocessor systems. The default is enable for the two default vNICs, and disable for user-created vNICs.
<b>Step 50</b>	Server /chassis/adapter/host-eth-if/rss # <b>set rss-hash-ipv4 {disable   enable}</b>	Enables or disables IPv4 RSS. The default is enable.
<b>Step 51</b>	Server /chassis/adapter/host-eth-if/rss # <b>set rss-hash-tcp-ipv4 {disable   enable}</b>	Enables or disables TCP/IPv4 RSS. The default is enable.
<b>Step 52</b>	Server /chassis/adapter/host-eth-if/rss # <b>set rss-hash-ipv6 {disable   enable}</b>	Enables or disables IPv6 RSS. The default is enable.
<b>Step 53</b>	Server /chassis/adapter/host-eth-if/rss # <b>set rss-hash-tcp-ipv6 {disable   enable}</b>	Enables or disables TCP/IPv6 RSS. The default is enable.
<b>Step 54</b>	Server /chassis/adapter/host-eth-if/rss # <b>set rss-hash-ipv6-ex {disable   enable}</b>	Enables or disables IPv6 Extension RSS. The default is disable.
<b>Step 55</b>	Server /chassis/adapter/host-eth-if/rss # <b>set rss-hash-tcp-ipv6-ex {disable   enable}</b>	Enables or disables TCP/IPv6 Extension RSS. The default is disable.
<b>Step 56</b>	Server /chassis/adapter/host-eth-if/rss # <b>exit</b>	Exits to the host Ethernet interface command mode.
<b>Step 57</b>	Server /chassis/adapter/host-eth-if # <b>commit</b>	Commits the transaction to the system configuration.  <b>Note</b> The changes will take effect upon the next server reboot.

### Example

This example configures the properties of a vNIC:

```
Server# scope chassis
Server /chassis # show adapter
PCI Slot Product Name Serial Number Product ID Vendor
-----
1 UCS VIC P81E QCI1417A0QK N2XX-ACPCI01 Cisco Systems Inc

Server /chassis # scope adapter 1
Server /chassis/adapter # scope host-eth-if Test1
Server /chassis/adapter/host-eth-if # set uplink 1
Server /chassis/adapter/host-eth-if # set vmq enabled
Server /chassis/adapter/host-eth-if # set multi-queue enabled
Server /chassis/adapter/host-eth-if # enable arfs
Server /chassis/adapter/host-eth-if *# scope offload
Server /chassis/adapter/host-eth-if/offload *# set tcp-segment-offload enable
Server /chassis/adapter/host-eth-if/offload *# exit
Server /chassis/adapter/host-eth-if *# commit
Server /chassis/adapter/host-eth-if #
```

**What to do next**

Reboot the server to apply the changes.

## Enabling or Disabling Link Training on External Ethernet Interfaces

Link training for the port profile on the external ethernet interfaces of the specified vNIC can be enabled or disabled.

**Before you begin**

You must log in with admin privileges to perform this task.

**Procedure**

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>show adapter</b>	(Optional) Displays the available adapter devices.
<b>Step 3</b>	Server /chassis # <b>scope adapter</b> <i>index</i>	Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> .  <b>Note</b> The server must be powered on before you can view or change adapter settings.
<b>Step 4</b>	Server /chassis / adapter # <b>scope ext-eth-if 0   1 name</b>	Enters the external ethernet interface command mode for the specified vNIC.
<b>Step 5</b>	Server /chassis / adapter / ext-eth-if # <b>set link-training on   off</b>	Enables or disables the link training for the specified vNIC.
<b>Step 6</b>	Server /chassis / adapter / ext-eth-if* # <b>commit</b>	Commits the transaction to the system configuration.

**Example**

This example shows how to enable or disable link training on the external ethernet interface.

```
Server# scope chassis
Server /chassis # scope adapter 1
Server /chassis/adapter # scope ext-eth-if 1
Server /chassis/adapter/ext-eth-if # set link-training on
Server /chassis/adapter/ext-eth-if* # commit
You may lose connectivity to the Cisco IMC and may have to log in again.
Do you wish to continue? [y/N] y
Port 1:
  MAC Address: 74:A2:E6:28:C6:A3
  Link State: Link
  Encapsulation Mode: CE
  Admin Speed: 40Gbps
  Operating Speed: -
```

```

Link Training: N/A
Connector Present: Yes
Connector Supported: Yes
Connector Type: QSFP_XCVR_CR4
Connector Vendor: CISCO
Connector Part Number: 2231254-3
Connector Part Revision: B
Server /chassis/adapter/ext-eth-if

```

## Setting Admin FEC Mode on External Ethernet Interfaces

### Before you begin

You must log in with admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>show adapter</b>	(Optional) Displays the available adapter devices.
<b>Step 3</b>	Server /chassis # <b>scope adapter</b> <i>index</i>	Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> .  <b>Note</b> The server must be powered on before you can view or change adapter settings.
<b>Step 4</b>	Server /chassis / adapter # <b>scope ext-eth-if</b> {0   1 <i>name</i> }	Enters the external ethernet interface command mode for the specified vNIC.
<b>Step 5</b>	Server /chassis / adapter / ext-eth-if # <b>set admin-fec-mode</b> {Auto   cl74   cl91   off}	Sets the admin FEC mode. The default value is <b>Auto</b> .  <b>Note</b> FEC mode is applicable only for 25G link speed. On the 14xx adapters, FEC mode set on the adapter must match the FEC mode of the switch. Otherwise the link does not work.
<b>Step 6</b>	Server /chassis / adapter / ext-eth-if* # <b>commit</b>	At the prompt, select <b>y</b> . Commits the transaction to the system configuration.

### Example

This example shows how to set the admin FEC mode on the external ethernet interface.

```

Server# scope chassis
Server /chassis # scope adapter 1
Server /chassis/adapter # scope ext-eth-if 1

```

```

Server /chassis/adapter/ext-eth-if # set admin-fec-mode c174
Server /chassis/adapter/ext-eth-if* # commit
Changes to the network settings will be applied immediately.
You may lose connectivity to the Cisco IMC and may have to log in again.
Do you wish to continue? [y/N] y
Port 1:
  MAC Address: 00:5D:73:1C:6C:58
  Link State: LinkDown
  Encapsulation Mode: CE
  Admin Speed: Auto
  Operating Speed: -
  Link Training: N/A
  Admin FEC Mode: c174
  Operating FEC Mode: Off
  Connector Present: NO
  Connector Supported: N/A
  Connector Type: N/A
  Connector Vendor: N/A
  Connector Part Number: N/A
  Connector Part Revision: N/A
Server /chassis/adapter/ext-eth-if #

```

## Creating a vNIC

The adapter provides two permanent vNICs. You can create up to 16 additional vNICs.

### Before you begin

You must log in with user or admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope adapter</b> <i>index</i>	Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> .  <b>Note</b> The server must be powered on before you can view or change adapter settings.
<b>Step 3</b>	Server /chassis/adapter # <b>create host-eth-if</b> <i>name</i>	Creates a vNIC and enters the host Ethernet interface command mode. The <i>name</i> argument can be up to 32 ASCII characters.
<b>Step 4</b>	(Optional) Server /chassis/adapter/host-eth-if # <b>set channel-number</b> <i>number</i>	If NIV mode is enabled for the adapter, you must assign a channel number to this vNIC. The range is 1 to 1000.
<b>Step 5</b>	Server /chassis/adapter/host-eth-if # <b>commit</b>	Commits the transaction to the system configuration.  <b>Note</b> The changes will take effect upon the next server reboot.

**Example**

This example creates a vNIC on adapter 1:

```
Server# scope chassis
Server /chassis # scope adapter 1
Server /chassis/adapter # create host-eth-if Vnic5
Server /chassis/adapter/host-eth-if *# commit
New host-eth-if settings will take effect upon the next server reset
Server /chassis/adapter/host-eth-if #
```

## Deleting a vNIC

**Procedure**

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope adapter</b> <i>index</i>	Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> .  <b>Note</b> The server must be powered on before you can view or change adapter settings.
<b>Step 3</b>	Server /chassis/adapter # <b>delete host-eth-if</b> <i>name</i>	Deletes the specified vNIC.  <b>Note</b> You cannot delete either of the two default vNICs, eth0 or eth1.
<b>Step 4</b>	Server /chassis/adapter # <b>commit</b>	Commits the transaction to the system configuration.  <b>Note</b> The changes will take effect upon the next server reboot.

**Example**

This example deletes a vNIC on adapter 1:

```
Server# scope chassis
Server /chassis # scope adapter 1
Server /chassis/adapter # delete host-eth-if Vnic5
Server /chassis/adapter *# commit
Server /chassis/adapter #
```



## Creating Cisco usNIC Using the Cisco IMC CLI



**Note** Even though several properties are listed for Cisco usNIC in the usNIC properties dialog box, you must configure only the following properties because the other properties are not currently being used.

- **cq-count**
- **rq-count**
- **tq-count**
- **usnic-count**

### Before you begin

You must log in to the Cisco IMC CLI with administrator privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	server# <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	server/chassis# <b>scope adapter</b> <i>index</i>	Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> .  <b>Note</b> Make sure that the server is powered on before you attempt to view or change adapter settings. To view the index of the adapters configured on your server, use the <b>show adapter</b> command.
<b>Step 3</b>	server/chassis/adapter# <b>scope host-eth-if</b> { <b>eth0</b>   <b>eth1</b> }	Enters the command mode for the vNIC. Specify the Ethernet ID based on the number of vNICs that you have configured in your environment. For example, specify <b>eth0</b> if you configured only one vNIC.
<b>Step 4</b>	server/chassis/adapter/host-eth-if# <b>create usnic-config 0</b>	Creates a usNIC config and enters its command mode. Make sure that you always set the index value to 0.

	Command or Action	Purpose
		<p><b>Note</b> To create a Cisco usNIC for the first time for a given vNIC using the Cisco IMC CLI, you must first create a <b>usnic-config</b>. Subsequently, you only need to scope into the <b>usnic-config</b> and modify the properties for Cisco usNIC. For more information about modifying Cisco usNIC properties, see <a href="#">Modifying a Cisco usNIC value using the Cisco IMC CLI, on page 202</a>.</p>
<b>Step 5</b>	server/chassis/adapter/host-eth-if/usnic-config# <b>set cq-count</b> <i>count</i>	<p>Specifies the number of completion queue resources to allocate. We recommend that you set this value to 6.</p> <p>The number of completion queues equals the number of transmit queues plus the number of receive queues.</p>
<b>Step 6</b>	server/chassis/adapter/host-eth-if/usnic-config# <b>set rq-count</b> <i>count</i>	Specifies the number of receive queue resources to allocate. We recommend that you set this value to 6.
<b>Step 7</b>	server/chassis/adapter/host-eth-if/usnic-config# <b>set tq-count</b> <i>count</i>	Specifies the number of transmit queue resources to allocate. We recommend that you set this value to 6.
<b>Step 8</b>	server/chassis/adapter/host-eth-if/usnic-config# <b>set usnic-count</b> <i>number of usNICs</i> .	Specifies the number of Cisco usNICs to create. Each MPI process that is running on the server requires a dedicated Cisco usNIC. Therefore, you might need to create up to 64 Cisco usNICs to sustain 64 MPI processes running simultaneously. We recommend that you create at least as many Cisco usNICs, per Cisco usNIC-enabled vNIC, as the number of physical cores on your server. For example, if you have 8 physical cores on your server, create 8 Cisco usNICs.
<b>Step 9</b>	server/chassis/adapter/host-eth-if /usnic-config# <b>commit</b>	<p>Commits the transaction to the system configuration.</p> <p><b>Note</b> The changes take effect when the server is rebooted.</p>
<b>Step 10</b>	server/chassis/adapter/host-eth-if/usnic-config# <b>exit</b>	Exits to host Ethernet interface command mode.
<b>Step 11</b>	server/chassis/adapter/host-eth-if# <b>exit</b>	Exits to adapter interface command mode.

	Command or Action	Purpose
<b>Step 12</b>	server/chassis/adapter# <b>exit</b>	Exits to chassis interface command mode.
<b>Step 13</b>	server/chassis# <b>exit</b>	Exits to server interface command mode.
<b>Step 14</b>	server# <b>scope bios</b>	Enters Bios command mode.
<b>Step 15</b>	server/bios# <b>scope advanced</b>	Enters the advanced settings of BIOS command mode.
<b>Step 16</b>	server/bios/advanced# <b>set IntelVTD Enabled</b>	Enables the Intel Virtualization Technology.
<b>Step 17</b>	server/bios/advanced# <b>set ATS Enabled</b>	Enables the Intel VT-d Address Translation Services (ATS) support for the processor.
<b>Step 18</b>	server/bios/advanced# <b>set CoherencySupport Enabled</b>	Enables Intel VT-d coherency support for the processor.
<b>Step 19</b>	server /bios/advanced# <b>commit</b>	Commits the transaction to the system configuration.  <b>Note</b> The changes take effect when the server is rebooted.

### Example

This example shows how to configure Cisco usNIC properties:

```

Server # scope chassis
server /chassis # show adapter
server /chassis # scope adapter 2
server /chassis/adapter # scope host-eth-if eth0
server /chassis/adapter/host-eth-if # create usnic-config 0
server /chassis/adapter/host-eth-if/usnic-config *# set usnic-count 64
server /chassis/adapter/host-eth-if/usnic-config *# set cq-count 6
server /chassis/adapter/host-eth-if/usnic-config *# set rq-count 6
server /chassis/adapter/host-eth-if/usnic-config *# set tq-count 6
server /chassis/adapter/host-eth-if/usnic-config *# commit
Committed settings will take effect upon the next server reset
server /chassis/adapter/host-eth-if/usnic-config # exit
server /chassis/adapter/host-eth-if # exit
server /chassis/adapter # exit
server /chassis # exit
server # exit
server# scope bios
server /bios # scope advanced
server /bios/advanced # set IntelVTD Enabled
server /bios/advanced *# set ATS Enabled*
server /bios/advanced *# set CoherencySupport Enabled
server /bios/advanced *# commit
Changes to BIOS set-up parameters will require a reboot.
Do you want to reboot the system?[y|N]y
A system reboot has been initiated.

```

## Modifying a Cisco usNIC value using the Cisco IMC CLI

### Before you begin

You must log in to the Cisco IMC GUI with administrator privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	server# <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	server/chassis# <b>scope adapter</b> <i>index</i>	Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> .  <b>Note</b> Make sure that the server is powered on before you attempt to view or change adapter settings. To view the index of the adapters configured on your server, use the <b>show adapter</b> command.
<b>Step 3</b>	server/chassis/adapter# <b>scope host-eth-if</b> { <b>eth0</b>   <b>eth1</b> }	Enters the command mode for the vNIC. Specify the Ethernet ID based on the number of vNICs that you have configured in your environment. For example, specify <b>eth0</b> if you configured only one vNIC.
<b>Step 4</b>	server/chassis/adapter/host-eth-if# <b>scope usnic-config 0</b>	Enters the command mode for the usNIC. Make sure that you always set the index value as 0 to configure a Cisco usNIC.
<b>Step 5</b>	server/chassis/adapter/host-eth-if/usnic-config# <b>set usnic-count</b> <i>number of usNICs</i> .	Specifies the number of Cisco usNICs to create. Each MPI process running on the server requires a dedicated Cisco usNIC. Therefore, you might need to create up to 64 Cisco usNIC to sustain 64 MPI processes running simultaneously. We recommend that you create at least as many Cisco usNIC, per Cisco usNIC-enabled vNIC, as the number of physical cores on your server. For example, if you have 8 physical cores on your server, create 8 usNICs.
<b>Step 6</b>	server /chassis/adapter/host-eth-if /usnic-config# <b>commit</b>	Commits the transaction to the system configuration.  <b>Note</b> The changes take effect when the server is rebooted.
<b>Step 7</b>	server/chassis/adapter/host-eth-if/usnic-config# <b>exit</b>	Exits to host Ethernet interface command mode.

	Command or Action	Purpose
<b>Step 8</b>	server/chassis/adapter/host-eth-if# <b>exit</b>	Exits to adapter interface command mode.
<b>Step 9</b>	server/chassis/adapter# <b>exit</b>	Exits to chassis interface command mode.
<b>Step 10</b>	server/chassis# <b>exit</b>	Exits to server interface command mode.

### Example

This example shows how to configure Cisco usNIC properties:

```
server # scope chassis
server /chassis # show adapter
server /chassis # scope adapter 2
server /chassis/adapter # scope host-eth-if eth0
server /chassis/adapter/host-eth-if # scope usnic-config 0
server /chassis/adapter/host-eth-if/usnic-config # set usnic-count 32
server /chassis/adapter/host-eth-if/usnic-config # commit
Committed settings will take effect upon the next server reset
server /chassis/adapter/host-eth-if/usnic-config # exit
server /chassis/adapter/host-eth-if # exit
server /chassis/adapter # exit
server /chassis # exit
server # exit
```

## Viewing usNIC Properties

### Before you begin

You must log in with admin privileges to perform this task.

usNIC must be configured on a vNIC.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope adapter</b> <i>index</i>	Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> .  <b>Note</b> The server must be powered on before you can view or change adapter settings.
<b>Step 3</b>	Server /chassis/adapter # <b>scope host-eth-if</b> { <b>eth0</b>   <b>eth1</b>   <i>name</i> }	Enters the host Ethernet interface command mode for the specified vNIC.
<b>Step 4</b>	Server /chassis/adapter/host-eth-if # <b>show usnic-config</b> <i>index</i>	Displays the usNIC properties for a vNIC.

**Example**

This example displays the usNIC properties for a vNIC:

```
Server # scope chassis
Server /chassis # scope adapter 1
Server /chassis/adapter # scope host-eth-if eth0
Server /chassis/adapter/host-eth-if # show usnic-config 0
Idx usNIC Count TQ Count RQ Count CQ Count TQ Ring Size RQ Ring Size Interrupt Count
-----
0 113 2 2 4 256 512 4
Server /chassis/adapter/host-eth-if #
```

## Deleting Cisco usNIC from a vNIC

**Before you begin**

You must log in to Cisco IMC CLI with admin privileges to perform this task.

**Procedure**

	Command or Action	Purpose
<b>Step 1</b>	server# <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	server/chassis# <b>scope adapter</b> <i>index</i>	Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> .  <b>Note</b> Make sure that the server is powered on before you attempt to view or change adapter settings. To view the index of the adapters configured on you server, use the <b>show adapter</b> command.
<b>Step 3</b>	server/chassis/adapter# <b>scope host-eth-if</b> { <b>eth0</b>   <b>eth1</b> }	Enters the command mode for the vNIC. Specify the Ethernet ID based on the number of vNICs that you have configured in your environment. For example, specify <b>eth0</b> if you configured only one vNIC.
<b>Step 4</b>	Server/chassis/adapter/host-eth-if# <b>delete usnic-config 0</b>	Deletes the Cisco usNIC configuration for the vNIC.
<b>Step 5</b>	Server/chassis/adapter/host-eth-if# <b>commit</b>	Commits the transaction to the system configuration  <b>Note</b> The changes take effect when the server is rebooted.

### Example

This example shows how to delete the Cisco usNIC configuration for a vNIC:

```

server # scope chassis
server/chassis # show adapter
server/chassis # scope adapter 1
server/chassis/adapter # scope host-eth-if eth0
server/chassis/adapter/host-eth-if # delete usnic-config 0
server/chassis/host-eth-if/iscsi-boot *# commit
New host-eth-if settings will take effect upon the next adapter reboot

server/chassis/host-eth-if/usnic-config #

```

## Configuring iSCSI Boot Capability

### Configuring iSCSI Boot Capability for vNICs

To configure the iSCSI boot capability on a vNIC:

- You must log in with admin privileges to perform this task.
- To configure a vNIC to boot a server remotely from an iSCSI storage target, you must enable the PXE boot option on the vNIC.




---

**Note** You can configure a maximum of 2 iSCSI vNICs for each host.

---

### Configuring iSCSI Boot Capability on a vNIC

You can configure a maximum of 2 iSCSI vNICs for each host.

#### Before you begin

- To configure a vNIC to boot a server remotely from an iSCSI storage target, you must enable the PXE boot option on the vNIC.
- You must log in with admin privileges to perform this task.

#### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope adapter</b> <i>index</i>	Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> .  <b>Note</b> The server must be powered on before you can view or change adapter settings.

	Command or Action	Purpose
<b>Step 3</b>	Server /chassis/adapter # <b>scope host-eth-if</b> {eth0   eth1   name}	Enters the host Ethernet interface command mode for the specified vNIC.
<b>Step 4</b>	Server /chassis/adapter/host-eth-if # <b>create iscsi-boot index</b>	Creates the iSCSI boot index for the vNIC. At this moment, only 0 is allowed as the index.
<b>Step 5</b>	Server /chassis/adapter/host-eth-if/iscsi-boot* # <b>create iscsi-target index</b>	Creates an iSCSI target for the vNIC. The value can either be 0 or 1.
<b>Step 6</b>	Server /chassis/adapter/host-eth-if/iscsi-boot* # <b>set dhcp-net-settings enabled</b>	Enables the DHCP network settings for the iSCSI boot.
<b>Step 7</b>	Server /chassis/adapter/host-eth-if/iscsi-boot* # <b>set initiator-name string</b>	Sets the initiator name. It cannot be more than 223 characters.
<b>Step 8</b>	Server /chassis/adapter/host-eth-if/iscsi-boot* # <b>set dhcp-iscsi-settings enabled</b>	Enables the DHCP iSCSI settings.
<b>Step 9</b>	Server /chassis/adapter/host-eth-if/iscsi-boot* # <b>commit</b>	Commits the transaction to the system configuration.  <b>Note</b> The changes will take effect upon the next server reboot.

### Example

This example shows how to configure the iSCSI boot capability for a vNIC:

```
Server # scope chassis
Server /chassis # scope adapter 1
Server /chassis/adapter # scope host-eth-if eth0
Server /chassis/adapter/host-eth-if # create iscsi-boot 0
Server /adapter/host-eth-if/iscsi-boot *# set dhcp-net-settings enabled
Server /adapter/host-eth-if/iscsi-boot *# set initiator-name iqn.2012-01.com.adser:abcde
Server /adapter/host-eth-if/iscsi-boot *# set dhcp-iscsi-settings enabled
Server /adapter/host-eth-if/iscsi-boot *# commit
```

New host-eth-if settings will take effect upon the next server reset  
Server /adapter/host-eth-if/iscsi-boot #

## Deleting an iSCSI Boot Configuration for a vNIC

### Before you begin

You must log in with admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters the chassis command mode.



	Command or Action	Purpose
<b>Step 2</b>	Server /chassis # <b>scope adapter</b> <i>index</i>	Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> .  <b>Note</b> The server must be powered on before you can view or change adapter settings.
<b>Step 3</b>	Server /chassis/adapter # <b>scope host-eth-if</b> { <b>eth0</b>   <b>eth1</b>   <i>name</i> }	Enters the host Ethernet interface command mode for the specified vNIC.
<b>Step 4</b>	Server /chassis/adapter/host-eth-if # <b>delete iscsi-boot 0</b>	Deletes the iSCSI boot capability for the vNIC.
<b>Step 5</b>	Server /chassis/adapter/host-eth-if* # <b>commit</b>	Commits the transaction to the system configuration  <b>Note</b> The changes will take effect upon the next server reboot.

### Example

This example shows how to delete the iSCSI boot capability for a vNIC:

```
Server # scope chassis
Server /chassis # scope adapter 1
Server /chassis/adapter # scope host-eth-if eth0
Server /chassis/adapter/host-eth-if # delete iscsi-boot 0
Server /adapter/host-eth-if/iscsi-boot *# commit
New host-eth-if settings will take effect upon the next server reset

Server /adapter/host-eth-if/iscsi-boot #
```

## Backing Up and Restoring the Adapter Configuration

### Exporting the Adapter Configuration

The adapter configuration can be exported as an XML file to a TFTP server.



#### Important

If any firmware or BIOS updates are in progress, do not export the adapter configuration until those tasks are complete.

#### Before you begin

A supported Virtual Interface Card (VIC) must be installed in the chassis and the server must be powered on. Obtain the TFTP server IP address.

**Procedure**

	<b>Command or Action</b>	<b>Purpose</b>
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope adapter</b> <i>index</i>	Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> .  <b>Note</b> The server must be powered on before you can view or change adapter settings.
<b>Step 3</b>	Server /chassis/adapter # <b>export-vnic</b> <i>protocol</i> <i>remote server IP address</i>	Starts the export operation. The adapter configuration file will be stored at the specified path and filename on the remote server at the specified IP address. The protocol can be one of the following: <ul style="list-style-type: none"> <li>• TFTP</li> <li>• FTP</li> <li>• SFTP</li> <li>• SCP</li> <li>• HTTP</li> </ul> <b>Note</b> The Cisco UCS C-Series server now supports fingerprint confirmation of the server when you update firmware through a remote server. This option is available only if you choose SCP or SFTP as the remote server type.  If you chose SCP or SFTP as the remote server type while performing this action, a prompt with the message Server (RSA) key fingerprint is <server_finger_print_ID> Do you wish to continue? Click y or n depending on the authenticity of the server fingerprint.  The fingerprint is based on the host's public key and helps you to identify or verify the host you are connecting to.

**Example**

This example exports the configuration of adapter 1:

```

Server# scope chassis
Server /chassis # scope adapter 1
Server /chassis/adapter # export-vnic ftp 192.0.20.34 //test/dnld-ucs-k9-bundle.1.0.2h.bin
Server /chassis/adapter #

```

## Importing the Adapter Configuration



### Important

If any firmware or BIOS updates are in progress, do not import the adapter configuration until those tasks are complete.

### Before you begin

You must log in with admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope adapter</b> <i>index</i>	Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> .  <b>Note</b> The server must be powered on before you can view or change adapter settings.
<b>Step 3</b>	Server /chassis/adapter # <b>import-vnic</b> <i>tftp-ip-address path-and-filename</i>	Starts the import operation. The adapter downloads the configuration file from the specified path on the TFTP server at the specified IP address. The configuration will be installed during the next server reboot.

### Example

This example imports a configuration for the adapter in PCI slot 1:

```

Server# scope chassis
Server /chassis # scope adapter 1
Server /chassis/adapter # import-vnic 192.0.2.34 /ucs/backups/adapter4.xml
Import succeeded.
New VNIC adapter settings will take effect upon the next server reset.
Server /chassis/adapter #

```

### What to do next

Reboot the server to apply the imported configuration.

## Restoring Adapter Defaults

### Before you begin

You must log in with admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <code>scope chassis</code>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <code>adapter-reset-defaults index</code>	Restores factory default settings for the adapter at the PCI slot number specified by the <i>index</i> argument.  <b>Note</b> Resetting the adapter to default settings sets the port speed to 4 X 10 Gbps. Choose 40 Gbps as the port speed only if you are using a 40 Gbps switch.

### Example

This example restores the default configuration of the adapter in PCI slot 1:

```
Server# scope chassis
Server /chassis # adapter-reset-defaults 1
This operation will reset the adapter to factory default.
All your configuration will be lost.
Continue?[y|N] y
Server /chassis #
```

## Managing Adapter Firmware

### Adapter Firmware

A Cisco UCS C-Series network adapter contains the following firmware components:

- Adapter firmware—The main operating firmware, consisting of an active and a backup image, can be installed from the Cisco IMC GUI or CLI interface or from the Host Upgrade Utility (HUU). You can upload a firmware image from either a local file system or a TFTP server.
- Bootloader firmware—The bootloader firmware cannot be installed from the Cisco IMC. You can install this firmware using the Host Upgrade Utility.

# Installing Adapter Firmware



**Important** If any firmware or BIOS updates are in progress, do not install the adapter firmware until those tasks are complete.

## Before you begin

You must log in with admin privileges to perform this task.

## Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>update-adapter-fw</b> <i>tftp-ip-address path-and-filename</i> { <b>activate</b>   <b>no-activate</b> } [ <i>pci-slot</i> ] [ <i>pci-slot</i> ]	Downloads the specified adapter firmware file from the TFTP server, then installs the firmware as the backup image on one or two specified adapters or, if no adapter is specified, on all adapters. If the <b>activate</b> keyword is specified, the new firmware is activated after installation.
<b>Step 3</b>	(Optional) Server /chassis # <b>recover-adapter-update</b> [ <i>pci-slot</i> ] [ <i>pci-slot</i> ]	Clears an incomplete firmware update condition on one or two specified adapters or, if no adapter is specified, on all adapters.

## Example

This example begins an adapter firmware upgrade on the adapter in PCI slot 1:

```
Server# scope chassis
Server /chassis # update-adapter-fw 192.0.2.34 /ucs/adapters/adapter4.bin activate 1
Server /chassis #
```

## What to do next

To activate the new firmware, see [Activating Adapter Firmware, on page 212](#).

# Activating Adapter Firmware



- Important** While the activation is in progress, do not:
- Reset, power off, or shut down the server.
  - Reboot or reset Cisco IMC.
  - Activate any other firmware.
  - Export technical support or configuration data.

## Before you begin

You must log in with admin privileges to perform this task.

## Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>activate-adapter-fw pci-slot {1   2}</b>	Activates adapter firmware image 1 or 2 on the adapter in the specified PCI slot.  <b>Note</b> The changes will take effect upon the next server reboot.

## Example

This example activates adapter firmware image 2 on the adapter in PCI slot 1:

```
Server# scope chassis
Server /chassis # activate-adapter-fw 1 2
Firmware image activation succeeded
Please reset the server to run the activated image
Server /chassis #
```

## What to do next

Reboot the server to apply the changes.



# CHAPTER 11

## Managing Storage Adapters

This chapter includes the following sections:

- [Creating Virtual Drives from Unused Physical Drives, on page 214](#)
- [Creating Virtual Drive from an Existing Drive Group, on page 216](#)
- [Setting a Virtual Drive as Transport Ready, on page 218](#)
- [Clearing a Virtual Drive as Transport Ready, on page 220](#)
- [Importing Foreign Configuration, on page 221](#)
- [Clearing Foreign Configuration, on page 222](#)
- [Enabling and Disabling JBOD, on page 223](#)
- [Clearing a Boot Drive, on page 224](#)
- [Retrieving Storage Firmware Logs for a Controller , on page 225](#)
- [Self Encrypting Drives \(Full Disk Encryption\), on page 225](#)
- [Deleting a Virtual Drive, on page 232](#)
- [Initializing a Virtual Drive, on page 233](#)
- [Set as Boot Drive, on page 234](#)
- [Editing a Virtual Drive, on page 235](#)
- [Modifying Attributes of a Virtual Drive, on page 236](#)
- [Making a Dedicated Hot Spare, on page 237](#)
- [Making a Global Hot Spare, on page 237](#)
- [Preparing a Drive for Removal, on page 238](#)
- [Toggling Physical Drive Status, on page 239](#)
- [Setting a Physical Drive as a Controller Boot Drive, on page 240](#)
- [Removing a Drive from Hot Spare Pools, on page 242](#)
- [Undo Preparing a Drive for Removal, on page 242](#)
- [Enabling Auto Learn Cycles for the Battery Backup Unit, on page 243](#)
- [Disabling Auto Learn Cycles for the Battery Backup Unit, on page 244](#)
- [Starting a Learn Cycle for a Battery Backup Unit, on page 244](#)
- [Toggling the Locator LED for a Physical Drive, on page 245](#)
- [Clearing Controller Configuration, on page 246](#)
- [Restoring Storage Controller to Factory Defaults, on page 247](#)
- [Viewing Storage Controller Logs, on page 247](#)
- [Viewing Physical Drive Details, on page 248](#)
- [Viewing SIOC NVMe Drive Details , on page 249](#)

# Creating Virtual Drives from Unused Physical Drives

## Before you begin

You must log in with admin privileges to perform this task.

## Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server {1   2}</b>	Enters server command mode of server 1 or 2.
<b>Step 3</b>	Server /chassis/server # <b>scope storageadapter Slot-ID</b>	Enters storage adapter command mode.
<b>Step 4</b>	Server /chassis/server/storageadapter # <b>create virtual-drive</b>	At this point, you are prompted to enter information corresponding to the RAID level, the physical drives to be used, the size and the write policy for the new virtual drive. Enter the appropriate information at each prompt.  When you have finished specifying the virtual drive information, you are prompted to confirm that the information is correct. Enter <b>y</b> (yes) to confirm, or <b>n</b> (no) to cancel the operation.
<b>Step 5</b>	Server /chassis/storageadapter # <b>show virtual-drive</b>	Displays the existing virtual drives.

## Example

This example shows how to create a new virtual drive that spans two unused physical drives.

```
Server # scope chassis
Server /chassis # scope server 1
Server /chassis/server # scope storageadapter SLOT-3
Server /chassis/server/storageadapter # create-virtual-drive
Please enter RAID level
0, 1, 5, 10, 50 --> 1
```

Please choose from the following 10 unused physical drives:

ID	Size (MB)	Model	Interface	Type
1	571776	SEAGATE	SAS	HDD
2	571776	SEAGATE	SAS	HDD
4	571776	SEAGATE	SAS	HDD
5	428672	SEAGATE	SAS	HDD
6	571776	SEAGATE	SAS	HDD
7	571776	SEAGATE	SAS	HDD
8	571776	SEAGATE	SAS	HDD
9	428672	SEAGATE	SAS	HDD
10	571776	SEAGATE	SAS	HDD
11	953344	SEAGATE	SAS	HDD



```

Specify physical disks for span 0:
  Enter comma-separated PDs from above list--> 1,2
  Please enter Virtual Drive name (15 characters maximum)--> test_v_drive
  Please enter Virtual Drive size in MB, GB, or TB
  Example format: '400 GB' --> 10 GB

Optional attribute:

  stripsize: defaults to 64K Bytes

    0: 8K Bytes
    1: 16K Bytes
    2: 32K Bytes
    3: 64K Bytes
    4: 128K Bytes
    5: 256K Bytes
    6: 512K Bytes
    7: 1024K Bytes
  Choose number from above options or hit return to pick default--> 2
  stripsize will be set to 32K Bytes (6 and 'strip-size\:32k')

  Disk Cache Policy: defaults to Unchanged

    0: Unchanged
    1: Enabled
    2: Disabled
  Choose number from above options or hit return to pick default--> 0
  Disk Cache Policy will be set to Unchanged (0 and 'disk-cache-policy\:unchanged')

)

  Read Policy: defaults to No Read Ahead

    0: No Read Ahead
    1: Always
  Choose number from above options or hit return to pick default--> 0
  Read Policy will be set to No Read Ahead (0 and 'read-policy\:no-read-ahead')

  Write Policy: defaults to Write Through

    0: Write Through
    1: Write Back Good BBU
    2: Always Write Back
  Choose number from above options or hit return to pick default--> 0
  Write Policy will be set to Write Through (0 and 'write-policy\:write-through')

  IO Policy: defaults to Direct I/O

    0: Direct I/O
    1: Cached I/O
  Choose number from above options or hit return to pick default--> 0
  IO Policy will be set to Direct I/O (0 and 'io-policy\:direct-io')

  Access Policy: defaults to Read Write

    0: Read Write
    1: Read Only
    2: Blocked
  Choose number from above options or hit return to pick default--> 0
  Access Policy will be set to Read Write (0 and 'access-policy\:read-write')

New virtual drive will have the following characteristics:
- Spans: '[1.2]'
- RAID level: '1'

```

```

- Name: 'test_v_drive'
- Size: 10 GB
- stripsize: 32K Bytes
- Disk Cache Policy: Unchanged
- Read Policy: No Read Ahead
- Write Policy: Write Through
- IO Policy: Direct I/O
- Access Policy: Read Write

OK? (y or n)--> y

Server /chassis/server/storageadapter # show virtual-drive
Virtual Drive Health      Status      Name          Size      RAID Level
Boot Drive
-----
0          Good      Optimal      150528 MB RAID 0
false
1          Good      Optimal      20480 MB  RAID 0
true
2          Good      Optimal      114140 MB RAID 0
false
3          Good      Optimal      test_v_drive 10000 MB  RAID 1
false
4          Good      Optimal      new_from_test 500 MB    RAID 1
false

Server /chassis/storageadapter #

```

## Creating Virtual Drive from an Existing Drive Group

### Before you begin

You must log in with admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server {1   2}</b>	Enters server command mode of server 1 or 2.
<b>Step 3</b>	Server /chassis/server # <b>scope storageadapter Slot-ID</b>	Enters storage adapter command mode.
<b>Step 4</b>	Server /chassis/storageadapter # <b>carve-virtual-drive</b>	At this point, you are prompted to enter information corresponding to the virtual drives to be used, and the size and the write policy for the new virtual drive. Enter the appropriate information at each prompt.  When you have finished specifying the virtual drive information, you are prompted to confirm that the information is correct. Enter <b>y</b> (yes) to confirm, or <b>n</b> (no) to cancel the operation.

	Command or Action	Purpose
<b>Step 5</b>	Server /chassis/server/storageadapter # <b>show virtual-drive</b>	Displays the existing virtual drives.

### Example

This example shows how to carve a new virtual drive out of unused space in an existing RAID 1 drive group:

```
Server# scope chassis
Server /chassis # scope server 1
Server /chassis/server # scope storageadapter SLOT-3
Server /chassis/server/storageadapter # carve-virtual-drive
  < Fetching virtual drives...>

ID  Name          RL  VDSize      MaxPossibleSize PD(s)
-----
0   RAID0_12      0   100 MB      Unknown        1,2

Please choose from the above list the virtual drive number
whose space the new virtual drive will share--> 0
New virtual drive will share space with VD 0

Please enter Virtual Drive name (15 characters maximum)--> test_v_drive
Please enter Virtual Drive size in MB, GB, or TB (maximum: Unknown)
  Example format: '400 GB' --> 10 GB

Optional attributes:

  stripsize: defaults to 64K Bytes
    0: 8K Bytes
    1: 16K Bytes
    2: 32K Bytes
    3: 64K Bytes
    4: 128K Bytes
    5: 256K Bytes
    6: 512K Bytes
    7: 1024K Bytes
  Choose number from above options or hit return to pick default--> 0
  stripsize will be set to 8K Bytes (4 and 'strip-size\:8k')

  Disk Cache Policy: defaults to Unchanged
    0: Unchanged
    1: Enabled
    2: Disabled
  Choose number from above options or hit return to pick default--> 0
  Disk Cache Policy will be set to Unchanged (0 and 'disk-cache-policy\:unchanged')

  Read Policy: defaults to No Read Ahead
    0: No Read Ahead
    1: Always
  Choose number from above options or hit return to pick default--> 0
  Read Policy will be set to No Read Ahead (0 and 'read-policy\:no-read-ahead')

  Write Policy: defaults to Write Through
    0: Write Through
    1: Write Back Good BBU
    2: Always Write Back
  Choose number from above options or hit return to pick default--> 0
  Write Policy will be set to Write Through (0 and 'write-policy\:write-through')
```

```

IO Policy: defaults to Direct I/O
  0: Direct I/O
  1: Cached I/O
Choose number from above options or hit return to pick default--> 0
IO Policy will be set to Direct I/O (0 and 'io-policy\:direct-io')

Access Policy: defaults to Read Write
  0: Read Write
  1: Read Only
  2: Blocked
Choose number from above options or hit return to pick default--> 0
Access Policy will be set to Read Write (0 and 'access-policy\:read-write')

New virtual drive will have the following characteristics:
- It will share space with virtual drive 0
- Name: 'amit'
- Size: 10 GB
- stripsize: 8K Bytes
- Disk Cache Policy: Unchanged
- Read Policy: No Read Ahead
- Write Policy: Write Through
- IO Policy: Direct I/O
- Access Policy: Read Write

OK? (y or n)--> y
Server /chassis/storageadapter # show virtual-drive
Virtual Drive Health      Status      Name          Size      RAID Level
Boot Drive
-----
0          Good      Optimal      150528 MB RAID 0
false
1          Good      Optimal      20480 MB  RAID 0
true
2          Good      Optimal      114140 MB RAID 0
false
3          Good      Optimal      test_v_drive 10000 MB  RAID 1
false
4          Good      Optimal      new_from_test 500 MB    RAID 1
false

Server /chassis/server/storageadapter #

```

## Setting a Virtual Drive as Transport Ready

### Before you begin

- You must log in with admin privileges to perform this task.
- The virtual drive must be in optimal state to enable transport ready.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters the chassis command mode.

	Command or Action	Purpose
<b>Step 2</b>	Server /chassis # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 3</b>	Server /chassis/server # <b>scope storageadapter</b> <i>slot ID</i>	Enters the command mode for an installed storage card.
<b>Step 4</b>	Server /chassis/server/storageadapter # <b>scope virtual-drive</b> <i>drive-number</i>	Enters the command mode for the specified virtual drive.
<b>Step 5</b>	Server /chassis/server/storageadapter/virtual-drive # <b>set-transport-ready</b> { <i>include-all</i>   <i>exclude-all</i>   <i>include-dhsp</i> }	<p>Enter the initialization type using which you can set the selected virtual drive as transport ready. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>exclude-all</b>— Excludes all the dedicated hot spare drives.</li> <li>• <b>include-all</b>— Includes any exclusively available or shared dedicated hot spare drives.</li> <li>• <b>include-dhsp</b>— Includes exclusive dedicated hot spare drives.</li> </ul> <p>Sets the virtual drive to transport ready and assigns the chosen properties.</p> <p>When you are prompted to confirm the action. Enter <b>y</b> to confirm.</p> <p><b>Note</b> When you set a virtual drive to transport ready all the physical drives associated with it are displayed as Ready to remove.</p>
<b>Step 6</b>	(Optional) Server /chassis/server/storageadapter/virtual-drive # <b>show detail</b>	Display the virtual drive properties with the change.

### Example

This example shows how to set virtual drive 5 to transport ready:

```
Server # scope chassis
Server /chassis # scope server 1
Server /chassis/server # scope storageadapter SLOT-HBA
Server /chassis/server/storageadapter # scope virtual-drive 5
Server /chassis/storageadapter/virtual-drive # set-transport-ready exclude-all
Since they belong to same drive group, all these virtual drives will be set to Transport
Ready - 0
Are you sure you want to proceed?[y|N]y
Server /chassis/storageadapter/virtual-drive # show detail
Virtual Drive 0:
  Health: Good
  Status: Optimal
  Visibility : Visible
```

```

Name: RAID0_124_RHEL
Size: 2858160 MB
Physical Drives: 1, 2, 4
RAID Level: RAID 0
Boot Drive: false
FDE Capable: 0
FDE Enabled: 0
Target ID: 0
Strip Size: 64 KB
Drives Per Span: 3
Span Depth: 1
Access Policy: Transport Ready
Cache Policy: Direct
Read Ahead Policy: None
Requested Write Cache Policy: Write Through
Current Write Cache Policy: Write Through
Disk Cache Policy: Unchanged
Auto Snapshot: false
Auto Delete Oldest: true
Allow Background Init: true
Server /chassis/server/storageadapter/virtual-drive #

```

## Clearing a Virtual Drive as Transport Ready

### Before you begin

You must log in with admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server {1   2}</b>	Enters server command mode of server 1 or 2.
<b>Step 3</b>	Server /chassis/server # <b>scope storageadapter slot ID</b>	Enters the command mode for an installed storage card.
<b>Step 4</b>	Server /chassis/server/storageadapter # <b>scope virtual-drive drive-number</b>	Enters the command mode for the specified virtual drive.
<b>Step 5</b>	Server /chassis/server/storageadapter/virtual-drive # <b>clear-transport-ready</b>	This reverts the selected transport ready virtual drive to its original state.  When you are prompted to confirm the action. Enter <b>y</b> to confirm.
<b>Step 6</b>	(Optional) Server /chassis/server/storageadapter/virtual-drive # <b>show detail</b>	Display the virtual drive properties with the change.

## Example

This example shows how to revert the selected transport ready virtual drive to its original state:

```
Server # scope chassis
Server /chassis # scope server 1
Server /chassis/server # scope storageadapter SLOT-HBA
Server /chassis/server/storageadapter # scope virtual-drive 5
Server /chassis/server/storageadapter/virtual-drive # clear-transport-ready
Since they belong to same drive group, all these virtual drives will be moved out of Transport
Ready - 0
Are you sure you want to proceed?[y|N]y
Server /chassis/server/storageadapter/virtual-drive # show detail
Virtual Drive 0:
  Health: Good
  Status: Optimal
  Visibility : Visible
  Name: RAID0_124_RHEL
  Size: 2858160 MB
  Physical Drives: 1, 2, 4
  RAID Level: RAID 0
  Boot Drive: false
  FDE Capable: 0
  FDE Enabled: 0
  Target ID: 0
  Strip Size: 64 KB
  Drives Per Span: 3
  Span Depth: 1
  Access Policy: Read-Write
  Cache Policy: Direct
  Read Ahead Policy: None
  Requested Write Cache Policy: Write Through
  Current Write Cache Policy: Write Through
  Disk Cache Policy: Unchanged
  Auto Snapshot: false
  Auto Delete Oldest: true
  Allow Background Init: true
Server /chassis/server/storageadapter/virtual-drive #
```

# Importing Foreign Configuration

When one or more physical drives that have previously been configured with a different controller are inserted into a server, they are identified as foreign configurations. You can import these foreign configurations to a controller.

## Before you begin

You must log in with admin privileges to perform this task.

## Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server {1   2}</b>	Enters server command mode of server 1 or 2.

	Command or Action	Purpose
<b>Step 3</b>	Server /chassis/server # <b>scope storageadapter</b> <i>Slot-ID</i>	Enters storage adapter command mode.
<b>Step 4</b>	Server /chassis/server/storageadapter # <b>import-foreign-config</b>	You are prompted to confirm the action. Enter <b>yes</b> to confirm.  <b>Note</b> If you do not enter <b>yes</b> , the action is aborted.

### Example

This example shows how to import all foreign configurations on the MegaRAID controller in slot 3:

```
Server# scope chassis
Server /chassis/server # scope storageadapter SLOT-3
Server /chassis/server/storageadapter # import-foreign-config
Are you sure you want to import all foreign configurations on this controller?
Enter 'yes' to confirm -> yes
Server /chassis/server/storageadapter #
```

## Clearing Foreign Configuration



### Important

This task clears all foreign configuration on the controller. Also, all configuration information from all physical drives hosting foreign configuration is deleted. This action cannot be reverted.

### Before you begin

You must log in with admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 3</b>	Server /chassis/server # <b>scope storageadapter</b> <i>Slot-ID</i>	Enters storage adapter command mode.
<b>Step 4</b>	Server /chassis/server/storageadapter # <b>clear-foreign-config</b>	You are prompted to confirm the action. Enter <b>yes</b> to confirm.  <b>Note</b> If you do not enter <b>yes</b> , the action is aborted.



### Example

This example shows how to clear all foreign configurations on the MegaRAID controller in slot 3:

```
Server# scope chassis
Server /chassis # scope server 1
Server /chassis/server # scope storageadapter SLOT-3
Server /chassis/server/storageadapter # clear-foreign-config
Are you sure you want to clear all foreign configurations on this controller?
All data on the drive(s) will be lost.
Enter 'yes' to confirm -> yes
Server /chassis/server/storageadapter #
```

## Enabling and Disabling JBOD

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 3</b>	Server /chassis/server # <b>scope storageadapter</b> <i>Slot-ID</i>	Enters storage adapter command mode.
<b>Step 4</b>	Server /chassis/server/storageadapter # <b>enable-jbod-mode</b>	Enables the JBOD Mode for the selected controller
<b>Step 5</b>	Server /chassis/server/storageadapter # <b>disable-jbod-mode</b>	Disables the JBOD Mode for the selected controller

### Example

This example enables and disables the JBOD mode for the selected controller:

```
Server# scope chassis
Server /chassis # scope server 1
Server /chassis/server # scope storageadapter SLOT-3
Enabling JBOD
Server /chassis/server/storageadapter # enable-jbod-mode
Are you sure you want to enable JBOD mode?
Enter 'yes' to confirm -> yes
Server/chassis/server/storageadapter # show settings
PCI Slot SLOT-3:
  Info Valid: Yes
  Enable JBOD Mode: true
Disabling JBOD
Server /chassis/server/storageadapter # disable-jbod-mode
Are you sure you want to disable JBOD mode?
Enter 'yes' to confirm -> yes
Server/chassis/server/storageadapter # show settings
PCI Slot SLOT-3:
```

```
Info Valid: Yes
Enable JBOD Mode: false
```

### What to do next

.

## Clearing a Boot Drive



**Important** This task clears the boot drive configuration on the controller. This action cannot be reverted.

### Before you begin

You must log in with admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server {1   2}</b>	Enters server command mode of server 1 or 2.
<b>Step 3</b>	Server /chassis/server # <b>scope storageadapter Slot-ID</b>	Enters storage adapter command mode.
<b>Step 4</b>	Server /chassis/server/storageadapter # <b>clear-boot-drive</b>	You are prompted to confirm the action. Enter <b>yes</b> to confirm.  <b>Note</b> If you do not enter <b>yes</b> , the action is aborted.

### Example

This example shows how to clear the boot drive configuration on the MegaRAID controller in slot 3:

```
Server# scope chassis
Server/chassis # scope server 1
Server /chassis/server # scope storageadapter SLOT-3
Server /chassis/server/storageadapter # clear-boot-drive
Are you sure you want to clear the controller's boot drive?
Enter 'yes' to confirm -> yes
Server /chassis/server/storageadapter #
```

# Retrieving Storage Firmware Logs for a Controller

This task retrieves the firmware logs for the controller and places it in the `/var/log` location. This ensures that this log data is available when Technical Support Data is requested.

## Before you begin

You must log in with admin privileges to perform this task

## Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope storageadapter slot</b>	Enters the command mode for an installed storage card.
<b>Step 3</b>	Server /chassis/storageadapter # <b>get-storage-fw-log</b>	Retrieves the storage firmware log file to the specified controller.
<b>Step 4</b>	At the prompt, enter <b>yes</b> .	Begins download of the storage firmware log files.

## Example

This example shows how to view the download status of the retrieved storage firmware log files:

```
Server # scope chassis
Server /chassis # scope storageadapter SLOT-HBA
Server /chassis/storageadapter # get-storage-fw-log
```

You are initiating the retrieval of the storage firmware log to Cisco IMC. This task will take a few minutes to complete. You may monitor the status of the retrieval by running the 'get-storage-fw-log-download-progress' command. When the download is finished, the 'Storage Firmware Log Status' value will be 'Complete', along with the size of the logfile.

You may then download the log file using the Technical Support facility, accessible from `/cimc/tech-support` scope, or the WebUI's Utilities page.

```
Do you want to proceed?
Enter 'yes' to confirm -> yes
Server /chassis/storageadapter # get-storage-fw-log-download-progress
Storage Firmware Log Status: Complete (total size 61906 bytes)
```

# Self Encrypting Drives (Full Disk Encryption)

Cisco IMC supports self encrypting drives (SED). A special hardware in the drives encrypts incoming data and decrypts outgoing data in real-time. This feature is also called Full Disk Encryption (FDE).

The data on the drive is encrypted on its way into the drive and decrypted on its way out. However, if you lock the drive, no security key is required to retrieve the data.

When a drive is locked, an encryption key is created and stored internally. All data stored on this drive is encrypted using that key, and stored in encrypted form. Once you store the data in this manner, a security key is required in order to un-encrypt and fetch the data from the drive. Unlocking a drive deletes that encryption key and renders the stored data unusable. This is called a Secure Erase. The FDE comprises a key ID and a security key.

The FDE feature supports the following operations:

- Enable and disable security on a controller
- Create a secure virtual drive
- Secure a non-secure drive group
- Unlock foreign configuration drives
- Enable security on a physical drive (JBOD)
- Clear secure SED drives
- Clear secure foreign configuration

### Scenarios to consider While Configuring Controller Security in a Dual or Multiple Controllers Environment




---

**Note** Dual or Multiple controllers connectivity is available only on some servers.

---

Controller security can be enabled, disabled, or modified independently. However, local and remote key management applies to all the controllers on the server. Therefore security action involving switching the key management modes must be performed with caution. In a scenario where both controllers are secure, and you decide to move one of the controllers to a different mode, you need to perform the same operation on the other controller as well.

Consider the following two scenarios:

- Scenario 1—Key management is set to remote; both controllers are secure and use remote key management. If you now wish to switch to local key management, switch the key management for each controller and disable remote key management.
- Scenario 2—Key management is set to local; both controllers are secure and use local key management. If you now wish to switch to remote key management, enable remote key management and switch the key management for each controller.

If you do not modify the controller security method on any one of the controllers, it renders the secure key management in an unsupported configuration state.

## Enabling Security on a Controller

### Before you begin

You must log in with admin privileges to perform this task.

**Procedure**

	<b>Command or Action</b>	<b>Purpose</b>
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server {1   2}</b>	Enters server command mode of server 1 or 2.
<b>Step 3</b>	Server /chassis/server # <b>scope storageadapter Slot-ID</b>	Enters storage adapter command mode.
<b>Step 4</b>	Server /chassis/server/storageadapter # <b>enable-controller-security</b>	At this point, you are prompted to enter the key-id and then the security key, you can either enter a key-id or a security key of your choice in the respective prompts or you can use the suggested keys.  Depending on whether you want to use the suggested key-id and security key, or key-id and security key of your choice, enter <b>y</b> (yes) to use the suggested keys, or <b>n</b> (no) to enter the keys of your choice at the appropriate prompts.
<b>Step 5</b>	Server /chassis/server/storageadapter # <b>show detail</b>	Displays the storage drive details.

**Example**

The following example shows how to enable security on a controller:

```
Server# scope chassis
Server/chassis # scope server 1
Server /chassis/server # scope storageadapter SBMezz1
Server /chassis/server/storageadapter # enable-controller-security
Use generated key-id 'UCSC-MRAID12G_FHH18250010_1d85dcd3'? (y or n)--> y
Use suggested security-key '6ICsmuX@oVB7e9wXt79qsTgp6ICsmuX@'? (y or n)--> n
Enter security-key --> testSecurityKey
Will use security-key 'testSecurityKey'
Server /chassis/server/storageadapter show detail
PCI Slot SBMezz1:
<stuff deleted>
Controller is Secured: 1
Server /chassis/server/storageadapter #
```

## Disabling Security on a Controller

**Before you begin**

You must log in with admin privileges to perform this task.

**Procedure**

	<b>Command or Action</b>	<b>Purpose</b>
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server {1   2}</b>	Enters server command mode of server 1 or 2.
<b>Step 3</b>	Server /chassis/server # <b>scope storageadapter Slot-ID</b>	Enters storage adapter command mode.
<b>Step 4</b>	Server /chassis/server/storageadapter # <b>disable-controller-security</b>	A confirmation prompt appears. At the confirmation prompt, enter <b>yes</b> to confirm, or <b>n</b> (no) to cancel the operation. This disables the controller security.
<b>Step 5</b>	Server /chassis/server/storageadapter # <b>show detail</b>	Displays the storage drive details.

**Example**

The following example shows how to disable security on a controller:

```
Server# scope chassis
Server/chassis # scope server 2
Server /chassis/server # scope storageadapter SBMezz1
Server /chassis/server/storageadapter # disable-controller-security
Note: this operation will fail if any secured virtual drives or secure JBODs are present.
Are you sure you want to disable security on this controller?
Enter 'yes' to confirm -> yes
Server /chassis/server/storageadapter # show detail
PCI Slot SBMezz1:
<content deleted>
Controller is Secured: 0
Server /chassis/server/storageadapter #
```

## Modifying Controller Security Settings

**Before you begin**

You must log in with admin privileges to perform this task.

**Procedure**

	<b>Command or Action</b>	<b>Purpose</b>
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server {1   2}</b>	Enters server command mode of server 1 or 2.
<b>Step 3</b>	Server /chassis/server # <b>scope storageadapter Slot-ID</b>	Enters storage adapter command mode.

	Command or Action	Purpose
<b>Step 4</b>	Server /chassis/server/storageadapter # <b>modify-controller-security</b>	<p>At this point, you are prompted to enter the current security key, option to choose whether you want to reset the key-id and the new security key. Enter the appropriate information.</p> <p><b>Note</b> The modify command allows you to modify the key ID and/or the security key. You are prompted to enter the current security key only if you choose to modify the security key. Modifying the key ID alone does not require specifying the current security key.</p> <p>At the confirmation prompt, enter <b>y</b> (yes) to confirm, or <b>n</b> (no) to cancel the operation.</p>

### Example

The following example shows how to modify the security settings of a controller:

```
Server# scope chassis
Server /chassis # scope server 1
Server /chassis/server # scope storageadapter SBMezz1
Server /chassis/server/storageadapter # modify-controller-security
Please enter current security-key --> testSecurityKey
Keep current key-id 'UCSC-MRAID12G_FHH18250010_1d85dcd3'? (y or n)--> n
Enter new key-id: NewKeyId
Will change key-id to 'NewKeyId'
Keep current security-key? (y or n)--> y

Server /chassis/server/storageadapter #
```

## Verifying the Security Key Authenticity

If you are not sure about the security key, you can use this procedure to verify whether the security key that you provide matches the controller security key.

### Before you begin

You must log in with admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server {1   2}</b>	Enters server command mode of server 1 or 2.

	Command or Action	Purpose
<b>Step 3</b>	Server /chassis/server # <b>scope storageadapter</b> <i>Slot-ID</i>	Enters storage adapter command mode.
<b>Step 4</b>	Server /chassis/server/storageadapter # <b>verify-controller-security-key</b>	At the prompt, enter the security key and press Enter.  If you enter a security key that does not match the controller security key, a verification failure message appears.

### Example

The following example shows how to verify the security key of a controller:

```
Server # scope chassis
Server/chassis # scope server 2
Server /chassis/server # scope storageadapter SBMezz1
Server /chassis/server/storageadapter # verify-controller-security-key
Please enter the security key to verify -> WrongSecurityKey
verify-controller-security-key failed.
Error: "r-type: RAID controller: SBMezz1 command-status: Lock key from backup failed
verification"
Server /chassis/server/storageadapter #
Server /chassis/server/storageadapter # verify-controller-security-key
Please enter the security key to verify -> testSecurityKey
Server /chassis/server/storageadapter #
```

## Switching Controller Security From Remote to Local Key Management

### Before you begin

You must log in with admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 3</b>	Server /chassis/server # <b>scope storageadapter</b> <i>Slot-ID</i>	Enters storage adapter command mode.
<b>Step 4</b>	Server /chassis/server/storageadapter # <b>switch-to-local-key-mgmt</b>	Enter <b>y</b> at the confirmation prompt.  <b>Note</b> If you have multiple controller you must switch the security on those as well.
<b>Step 5</b>	Server /chassis/server/storageadapter # <i>key id</i>	Enter the new key ID at the prompt. Switches to local key management.



	Command or Action	Purpose
		<b>Note</b> Entering the security key is mandatory to perform this operation.

### Example

The following example shows how to switch controller security from remote to local key management:

```
Server # scope chassis
Server /chassis # scope server 1
Server /chassis/server # scope storageadapter SBMezz1
Server /chassis/server/storageadapter # switch-to-local-key-mgmt
Executing this command will require you to disable remote key management once switch is
complete.
Do you want to continue(y or n)?y
Proceeding to switch to local key management.
Enter new security-key: test
Will change security-key to 'test'
Switch to local key management complete on controller in SBMezz1.
***Remote key management needs to be disabled***
Please disable remote key management.
Server /chassis/server/storageadapter #
```

### What to do next

After you switch from Remote to Local Key Management, ensure that you disable KMIP secure key management.

## Switching Controller Security From Local to Remote Key Management

### Before you begin

- You must log in with admin privileges to perform this task.
- KMIP must be enabled.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server {1   2}</b>	Enters server command mode of server 1 or 2.
<b>Step 3</b>	Server /chassis/server # <b>scope storageadapter Slot-ID</b>	Enters storage adapter command mode.
<b>Step 4</b>	Server /chassis/server/storageadapter # <b>switch-to-remote-key-mgmt</b>	Enter <b>y</b> at the confirmation prompt.

	Command or Action	Purpose
<b>Step 5</b>	Server /chassis/server/storageadapter # <i>security id</i>	Enter the security key at the prompt. Switches to remote key management.  <b>Note</b> Entering the security key is mandatory to perform this operation.

### Example

The following example shows how to switch controller security from local to remote key management:

```
Server # scope chassis
Server /chassis # scope server 1
Server /chassis/server # scope storageadapter SBMezz1
Server /chassis/server/storageadapter # switch-to-remote-key-mgmt
Changing the security key requires existing security key.
Please enter current security-key --> test
Switch to remote key management complete on controller in SBMezz1.
Server /chassis/server/storageadapter #
```

## Deleting a Virtual Drive



### Important

This task deletes a virtual drive, including the drives that run the booted operating system. So back up any data that you want to retain before you delete a virtual drive.

### Before you begin

You must log in with admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server {1   2}</b>	Enters server command mode of server 1 or 2.
<b>Step 3</b>	Server /chassis/server # <b>scope storageadapter Slot-ID</b>	Enters storage adapter command mode.
<b>Step 4</b>	Server /chassis/server/storageadapter # <b>scope virtual-drive drive-number</b>	Enters command mode for the specified virtual drive.
<b>Step 5</b>	Server /chassis/server/storageadapter/virtual-drive # <b>delete-virtual-drive</b>	You are prompted to confirm the action. Enter <b>yes</b> to confirm.  <b>Note</b> If you do not enter <b>yes</b> , the action is aborted.

### Example

This example shows how to delete virtual drive 3.

```
Server# scope chassis
Server /chassis # scope server 1
Server /chassis/server # scope storageadapter SLOT-3
Server /chassis/server/storageadapter # scope virtual-drive 3
Server /chassis/server/storageadapter/virtual-drive # delete-virtual-drive
Are you sure you want to delete virtual drive 3?
All data on the drive will be lost. Enter 'yes' to confirm -> yes
Server /chassis/server/storageadapter/virtual-drive #
```

## Initializing a Virtual Drive

All data on a virtual drive is lost when you initialize the drive. Before you run an initialization, back up any data on the virtual drive that you want to save.

### Before you begin

You must log in with admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 3</b>	Server /chassis/server # <b>scope storageadapter</b> <i>Slot-ID</i>	Enters storage adapter command mode.
<b>Step 4</b>	Server /chassis/server/storageadapter # <b>scope</b> <b>virtual-drive</b> <i>drive-number</i>	Enters command mode for the specified virtual drive.
<b>Step 5</b>	Server /chassis/server/storageadapter/virtual-drive # <b>start-initialization</b>	Initializes the specified virtual drive.
<b>Step 6</b>	Server /chassis/server/storageadapter/virtual-drive # <b>cancel-initialization</b>	(Optional) Cancels the initialization of the specified virtual drive.
<b>Step 7</b>	Server /chassis/server/storageadapter/physical-drive # <b>get-operation-status</b>	Displays the status of the task that is in progress on the drive.

### Example

This example shows how to initialize virtual drive 3 using fast initialization:

```

Server# scope chassis
Server /chassis/server # scope storageadapter SLOT-3
Server /chassis/storageadapter # scope virtual-drive 3
Server /chassis/server/storageadapter/virtual-drive # start-initialization
Are you sure you want to initialize virtual drive 3?
All data on the drive will be lost. Enter 'yes' to confirm -> yes
Fast (0) or full (1) initialization? -> 0
Server /chassis/server/storageadapter/virtual-drive # get-operation-status

progress-percent: 20%
elapsed -seconds: 30
operation-in-progress: initializing virtual drive

Server /chassis/server/storageadapter/virtual-drive #

```

## Set as Boot Drive

### Before you begin

You must log in with admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server {1   2}</b>	Enters server command mode of server 1 or 2.
<b>Step 3</b>	Server /chassis/server # <b>scope storageadapter Slot-ID</b>	Enters storage adapter command mode.
<b>Step 4</b>	Server /chassis/server/storageadapter # <b>scope virtual-drive drive-number</b>	Enters command mode for the specified virtual drive.
<b>Step 5</b>	Server /chassis/server/storageadapter # <b>set-boot-drive</b>	Specifies the controller to boot from this virtual drive.

### Example

This example shows how to specify the controller to boot from virtual drive 3:

```

Server# scope chassis
Server /chassis # scope server 1
Server /chassis/server # scope storageadapter SLOT-3
Server /chassis/server/storageadapter # scope virtual-drive 3
Server /chassis/server/storageadapter/virtual-drive # set-boot-drive
Are you sure you want to set virtual drive 3 as the boot drive?
Enter 'yes' to confirm -> yes
Server /chassis/server/storageadapter/virtual-drive #

```

# Editing a Virtual Drive

## Before you begin

You must log in with admin privileges to perform this task.

## Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 3</b>	Server /chassis/server # <b>scope storageadapter</b> <i>Slot-ID</i>	Enters storage adapter command mode.
<b>Step 4</b>	Server chassis/server/storageadapter # <b>scope</b> <b>virtual-drive</b> <i>drive number</i>	Enters command mode for the specified virtual drive.
<b>Step 5</b>	Server chassis/server/storageadapter /virtual-drive # <b>modify-attributes</b>	Prompts you to select a different current policy.
<b>Step 6</b>	Server chassis/server/storageadapter/virtual-drive# <b>set</b> <b>raid-level</b> <i>value</i>	Specifies the RAID level for the specified virtual drive.
<b>Step 7</b>	Server chassis/server/storageadapter/virtual-drive# <b>set</b> <b>physical-drive</b> <i>value</i>	Specifies the physical drive for the specified virtual drive.

## Example

This example shows to edit a virtual drive:

```
Server# scope chassis
Server /chassis # scope chassis
Server /chassis/server # scope storageadapter slot-3
Server /chassis/server/storageadapter # scope virtual-drive 3
Server /chassis/server/storageadapter/virtual-drive #set raid-level 1
Server /chassis/server/storageadapter/virtual-drive *# physical-drive 1
Server /chassis/server/storageadapter/virtual-drive* #commit
Server /chassis/server/storageadapter /virtual-drive # modify-attribute
Current write policy: Write Back Good BBU

    0: Write Through
    1: Write Back Good BBU
    2: Always Write Back
Choose number from above options--> 0
The following attribute will be modified:
- Write Policy: Write Through

OK? (y or n)--> y
Server /chassis/server/storageadapter/virtual-drive #
```

# Modifying Attributes of a Virtual Drive

## Before you begin

You must log in with admin privileges to perform this task.

## Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server {1   2}</b>	Enters server command mode of server 1 or 2.
<b>Step 3</b>	Server /chassis/server # <b>scope storageadapter Slot-ID</b>	Enters storage adapter command mode.
<b>Step 4</b>	Server /chassis/server/storageadapter # <b>scope virtual-drive 3</b>	Enters the command mode for the virtual drive.
<b>Step 5</b>	Server /chassis/server/storageadapter/virtual-drive # <b>modify-attributes</b>	Prompts you to select a different current policy.

## Example

This example shows how to carve a new virtual drive out of unused space in an existing RAID 1 drive group:

```
Server# scope chassis
Server /chassis # scope server 1
Server /chassis/server # scope storageadapter SLOT-3
Server /chassis/server/storageadapter # scope virtual-drive
Server /chassis/server/storageadapter/virtual-drive # modify-attributes
```

```
Current write policy: Write Back
```

```
  0: Write Through
  1: Write Back
  2: Write Back even if Bad BBU
```

```
Choose number from above options --> 0
```

```
The following attribute will be modified:
```

```
- Write policy: Write Through
```

```
OK? (y or n) --> y
```

```
operation in progress.
```

```
Server /chassis/server/storageadapter/virtual-drive #
```

# Making a Dedicated Hot Spare

## Before you begin

You must log in with admin privileges to perform this task.

## Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 3</b>	Server /chassis/server # <b>scope storageadapter</b> <i>Slot-ID</i>	Enters storage adapter command mode.
<b>Step 4</b>	Server /chassis/server/storageadapter # <b>scope</b> <b>physical-drive</b> <i>drive-number</i>	Enters command mode for the specified physical drive.
<b>Step 5</b>	Server /chassis/server/storageadapter/physical-drive # <b>make-dedicated-hot-spare</b>	You are prompted to choose a virtual drive for which the dedicated hot spare is being created.

## Example

This example shows how to make physical drive 3 a dedicated hot spare for virtual drive 6:

```
Server# scope chassis
Server /chassis # scope server 1
Server /chassis/server # scope storageadapter SLOT-3
Server /chassis/server/storageadapter # scope physical-drive 3
Server /chassis/server/storageadapter/physical-drive # make-dedicated-hot-spare
  5: VD_OS_1, RAID 0, 102400 MB, physical disks: 1
  6: VD_OS_2, RAID 0, 12288 MB, physical disks: 1
  7: VD_OS_3, RAID 0, 12288 MB, physical disks: 1
  8: VD_DATA_1, RAID 0, 12512 MB, physical disks: 1
  9: RAID1_2358, RAID 1, 40000 MB, physical disks: 2,3,5,8
 11: JFB_RAID1_67, RAID 1, 20000 MB, physical disks: 6,7
 12: JFB_Crv_R1_40, RAID 1, 40000 MB, physical disks: 6,7
 13: JFB_R1_10GB, RAID 1, 10000 MB, physical disks: 6,7

Please choose from the above 8 virtual drives-->6

Server /chassis/server/storageadapter/physical-drive #
```

# Making a Global Hot Spare

## Before you begin

You must log in with admin privileges to perform this task.

**Procedure**

	<b>Command or Action</b>	<b>Purpose</b>
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server {1   2}</b>	Enters server command mode of server 1 or 2.
<b>Step 3</b>	Server /chassis/server # <b>scope storageadapter Slot-ID</b>	Enters storage adapter command mode.
<b>Step 4</b>	Server /chassis/server/storageadapter # <b>scope physical-drive drive-number</b>	Enters command mode for the specified physical drive.
<b>Step 5</b>	Server /chassis/server/storageadapter/physical-drive # <b>make-global-hot-spare</b>	
<b>Step 6</b>	Server /chassis/server/storageadapter/physical-drive # <b>get-operation-status</b>	Displays the status of the task that is in progress on the drive.

**Example**

This example shows how to make physical drive 3 a global hot spare:

```
Server# scope chassis
Server /chassis # scope server 1
Server /chassis/server # scope storageadapter SLOT-3
Server /chassis/server/storageadapter # scope physical-drive 3
Server /chassis/server/storageadapter/physical-drive # make-global-hot-spare
Server /chassis/server/storageadapter/physical-drive #
```

## Preparing a Drive for Removal

You can confirm this task only on physical drives that display the **Unconfigured Good** status.

**Before you begin**

You must log in with admin privileges to perform this task.

**Procedure**

	<b>Command or Action</b>	<b>Purpose</b>
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server {1   2}</b>	Enters server command mode of server 1 or 2.
<b>Step 3</b>	Server /chassis/server # <b>scope storageadapter Slot-ID</b>	Enters storage adapter command mode.
<b>Step 4</b>	Server /chassis/server/storageadapter # <b>scope physical-drive drive-number</b>	Enters command mode for the specified physical drive.



	Command or Action	Purpose
<b>Step 5</b>	Server /chassis/server/storageadapter/physical-drive # <b>prepare-for-removal</b>	

### Example

This example shows how to prepare physical drive 3 for removal.

```
Server# scope chassis
Server /chassis # scope server 1
Server /chassis/server # scope storageadapter SLOT-3
Server /chassis/server/storageadapter # scope physical-drive 3
Server /chassis/server/storageadapter/physical-drive # prepare-for-removal
Server /chassis/server/storageadapter/physical-drive #
```

## Toggling Physical Drive Status

### Before you begin

- You must log in with admin privileges to perform this task.
- The controller must support the JBOD mode and the JBOD mode must be enabled.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server {1   2}</b>	Enters server command mode of server 1 or 2.
<b>Step 3</b>	Server /chassis/server # <b>scope storageadapter</b> <i>Slot-ID</i>	Enters storage adapter command mode.
<b>Step 4</b>	Server /chassis/server/storageadapter # <b>scope</b> <b>physical-drive 4</b>	Enters command mode for the physical drive.
<b>Step 5</b>	Server /chassis/server/storageadapter/physical-drive # <b>make-unconfigured-good</b>	Modifies the status of the drive to Unconfigured good.
<b>Step 6</b>	Server /chassis/server/storageadapter/physical-drive # <b>make-jbod</b>	Enables the JBOD mode on the physical drive.

### Example

This example shows how to toggle between the status of the physical drive:

```

Server# scope chassis
Server /chassis # scope chassis
Server /chassis/server # scope storageadapter SLOT-3
Server /chassis/server/storageadapter # scope physical-drive 4
Server /chassis/server/storageadapter/physical-drive # show detail
Physical Drive Number 4:
  Controller: SLOT-4
  Health: Good
  Status: JBOD
  Boot Drive: true
  Manufacturer: ATA
  Model: ST500NM0011
  Predictive Failure Count: 0
  Drive Firmware: CC02
  Coerced Size: 476416 MB
  Type: HDD
Server /chassis/server/storageadapter/physical-drive # make-unconfigured-good
Server /chassis/server/storageadapter/physical-drive # show detail
Physical Drive Number 4:
  Controller: SLOT-4
  Health: Good
  Status: Unconfigured Good
  Boot Drive: true
  Manufacturer: ATA
  Model: ST500NM0011
  Predictive Failure Count: 0
  Drive Firmware: CC02
  Coerced Size: 476416 MB
  Type: HDD
Server /chassis/server/storageadapter/physical-drive # make-jbod
Server /chassis/server/storageadapter/physical-drive # show detail
Physical Drive Number 4:
  Controller: SLOT-4
  Health: Good
  Status: JBOD
  Boot Drive: true
  Manufacturer: ATA
  Model: ST500NM0011
  Predictive Failure Count: 0
  Drive Firmware: CC02
  Coerced Size: 476416 MB
  Type: HDD

```

## Setting a Physical Drive as a Controller Boot Drive

### Before you begin

- You must log in with admin privileges to perform this task.
- The controller must support the JBOD mode and the JBOD mode must be enabled.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server {1   2}</b>	Enters server command mode of server 1 or 2.

	Command or Action	Purpose
<b>Step 3</b>	Server /chassis/server # <b>scope storageadapter Slot-ID</b>	Enters storage adapter command mode.
<b>Step 4</b>	Server /chassis/server/storageadapter # <b>scope physical-drive 4</b>	Enters command mode for the physical drive.
<b>Step 5</b>	Server /chassis/server/storageadapter/physical-drive # <b>set-boot-drive</b>	You are prompted to confirm the action. Enter <b>yes</b> to confirm.  <b>Note</b> If you do not enter <b>yes</b> , the action is aborted.

### Example

This example shows how to set a physical drive as a boot drive for a controller:

```
Server# scope chassis
Server/chassis # scope server 1
Server /chassis/server # scope storageadapter SLOT-3
Server /chassis/server/storageadapter # show detail
PCI Slot SLOT-4:
  Health: Good
  Controller Status: Optimal
  ROC Temperature: Not Supported
  Product Name: MegaRAID 9240-8i (RAID 0,1,10,5)
  Serial Number: SP23807413
  Firmware Package Build: 20.11.1-0159
  Product ID: LSI Logic
  Battery Status: no battery
  Cache Memory Size: 0 MB
  Boot Drive: none
  Boot Drive is PD: false
  TTY Log Status: Not Downloaded
Server /chassis/server/storageadapter # scope physical-drive 4
Server /chassis/server/storageadapter/physical-drive # set-boot-drive
Are you sure you want to set physical drive 4 as the boot drive?
Enter 'yes' to confirm -> yes
Server /chassis/server/storageadapter/physical-drive # exit
Server /chassis/server/storageadapter # show detail
PCI Slot SLOT-4:
  Health: Good
  Controller Status: Optimal
  ROC Temperature: Not Supported
  Product Name: MegaRAID 9240-8i (RAID 0,1,10,5)
  Serial Number: SP23807413
  Firmware Package Build: 20.11.1-0159
  Product ID: LSI Logic
  Battery Status: no battery
  Cache Memory Size: 0 MB
  Boot Drive: 4
  Boot Drive is PD: true
  TTY Log Status: Not Downloaded
```

# Removing a Drive from Hot Spare Pools

## Before you begin

You must log in with admin privileges to perform this task.

## Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server {1   2}</b>	Enters server command mode of server 1 or 2.
<b>Step 3</b>	Server /chassis/server # <b>scope storageadapter Slot-ID</b>	Enters storage adapter command mode.
<b>Step 4</b>	Server /chassis/server/storageadapter # <b>scope physical-drive drive-number</b>	Enters command mode for the specified physical drive.
<b>Step 5</b>	Server /chassis/server/storageadapter/physical-drive # <b>remove-hot-spare</b>	Removes a drive from the host spare pool.

## Example

This example shows how to remove physical drive 3 from the hot spare pools:

```
Server# scope chassis
Server /chassis # scope server 1
Server /chassis/server # scope storageadapter SLOT-3
Server /chassis/server/storageadapter # scope physical-drive 3
Server /chassis/server/storageadapter/physical-drive # remove-hot-spare
Server /chassis/server/storageadapter/physical-drive #
```

# Undo Preparing a Drive for Removal

## Before you begin

You must log in with admin privileges to perform this task.

## Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server {1   2}</b>	Enters server command mode of server 1 or 2.

	Command or Action	Purpose
<b>Step 3</b>	Server /chassis/server # <b>scope storageadapter</b> <i>Slot-ID</i>	Enters storage adapter command mode.
<b>Step 4</b>	Server /chassis/server/storageadapter # <b>scope physical-drive</b> <i>drive-number</i>	Enters command mode for the specified physical drive.
<b>Step 5</b>	Server /chassis/server/storageadapter/physical-drive # <b>undo-prepare-for-removal</b>	

### Example

This example shows how to respin physical drive 3 after preparing the drive for removal.

```
Server# scope chassis
Server /chassis # scope server 1
Server /chassis/server # scope storageadapter SLOT-3
Server /chassis/server/storageadapter # scope physical-drive 3
Server /chassis/server/storageadapter/physical-drive # undo-prepare-for-removal
Server /chassis/server/storageadapter/physical-drive #
```

## Enabling Auto Learn Cycles for the Battery Backup Unit

### Before you begin

You must log in with admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 3</b>	Server /chassis/server # <b>scope storageadapter</b> <i>Slot-ID</i>	Enters storage adapter command mode.
<b>Step 4</b>	Server /chassis/server/storageadapter # <b>scope</b> <b>bbu</b>	Enter the battery backup unit command mode.
<b>Step 5</b>	Server /chassis/server/storageadapter # <b>enable-auto-learn</b>	Enables the battery auto-learn cycles

### Example

This example shows how to enable the battery auto-learn cycles:

```
Server # scope chassis
Server /chassis # scope server 1
```

```

Server /chassis/server # scope storageadapter SLOT-2
Server /chassis/server/storageadapter # scope bbu
Server /chassis/server/storageadapter/bbu # enable-auto-learn
Automatic BBU learn cycles will occur without notice if enabled.
Are you sure? [y/n] --> y
enable-auto-learn initiated
Server /chassis/server/storageadapter/bbu #

```

## Disabling Auto Learn Cycles for the Battery Backup Unit

### Before you begin

You must log in with admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server {1   2}</b>	Enters server command mode of server 1 or 2.
<b>Step 3</b>	Server /chassis/server # <b>scope storageadapter Slot-ID</b>	Enters storage adapter command mode.
<b>Step 4</b>	Server /chassis/server/storageadapter # <b>scope bbu</b>	Enter the battery backup unit command mode.
<b>Step 5</b>	Server /chassis/server/storageadapter # <b>disable-auto-learn</b>	Disables the battery auto-learn cycles

### Example

This example shows how to disables the battery auto-learn cycles:

```

Server # scope chassis
Server /chassis # scope server 1
Server /chassis/server # scope storageadapter SLOT-2
Server /chassis/server/storageadapter # scope bbu
Server /chassis/server/storageadapter/bbu # disable-auto-learn
Automatic BBU learn cycles will no longer occur if disabled.
Are you sure? [y/n] --> y
disable-auto-learn initiated

Server /chassis/server/storageadapter/bbu #

```

## Starting a Learn Cycle for a Battery Backup Unit

### Before you begin

You must be logged in as an admin to use this command.

**Procedure**

	<b>Command or Action</b>	<b>Purpose</b>
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server {1   2}</b>	Enters server command mode of server 1 or 2.
<b>Step 3</b>	Server /chassis/server # <b>scope storageadapter Slot-ID</b>	Enters storage adapter command mode.
<b>Step 4</b>	Server /chassis/server/storageadapter # <b>scope bbu</b>	Enter the battery backup unit command mode.
<b>Step 5</b>	Server /chassis/server/storageadapter # <b>start-learn-cycle</b>	Starts the learn cycle for the battery.

**Example**

This example shows how to initiate the learn cycles for a battery:

```
Server # scope chassis
Server /chassis # scope server 1
Server /chassis/server # scope storageadapter SLOT-2
Server /chassis/server/storageadapter # scope bbu
Server /chassis/server/storageadapter/bbu # start-learn-cycle
Server /chassis/server/storageadapter/bbu #
```

## Toggling the Locator LED for a Physical Drive

**Before you begin**

You must be logged in as an admin to perform this task.

**Procedure**

	<b>Command or Action</b>	<b>Purpose</b>
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server {1   2}</b>	Enters server command mode of server 1 or 2.
<b>Step 3</b>	Server /chassis/server # <b>scope storageadapter Slot-ID</b>	Enters storage adapter command mode.
<b>Step 4</b>	Server /chassis/server/storageadapter # <b>scope physical-drive 3</b>	Enters the physical drive command mode.
<b>Step 5</b>	Server /chassis/server/storageadapter/physical-drive # <b>locator-led {on   off}</b>	Enables or disables the physical drive locator LED.

### Example

This example shows how to enable the locator LED for physical drive 3:

```
Server # scope chassis
Server /chassis # scope server 1
Server /chassis/server # scope storageadapter SLOT-2
Server /chassis/server/storageadapter # scope physical-drive 3
Server /chassis/server/storageadapter/physical-drive # locator-led on
Server /chassis/server/storageadapter/physical-drive* # commit
Server /chassis/server/storageadapter/physical-drive #
```

## Clearing Controller Configuration

### Before you begin

You must log in with admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server {1   2}</b>	Enters server command mode of server 1 or 2.
<b>Step 3</b>	Server /chassis/server # <b>scope storageadapter Slot-ID</b>	Enters storage adapter command mode.
<b>Step 4</b>	Server /chassis/server/storageadapter # <b>clear-all-config</b>	Enter <b>yes</b> at the confirmation prompt. Clears the controller configuration.

### Example

The following example shows how to clear the controller configuration:

```
Server # scope chassis
Server /chassis # scope server 1
Server /chassis/server # scope storageadapter SBMezz1
Server /chassis/server/storageadapter # clear-all-config
Are you sure you want to clear the controller's config and delete all VDs?
Enter 'yes' to confirm -> yes
Enter administrative password to proceed with operation\n
Password -> Password accepted. Performing requested operation.
Server /chassis/server/storageadapter #
```



# Restoring Storage Controller to Factory Defaults

## Before you begin

You must log in with admin privileges to perform this task.

## Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server {1   2}</b>	Enters server command mode of server 1 or 2.
<b>Step 3</b>	Server /chassis/server # <b>scope storageadapter Slot-ID</b>	Enters storage adapter command mode.
<b>Step 4</b>	Server /chassis/server/storageadapter # <b>set-factory-defaults</b>	Enter <b>yes</b> at the confirmation prompt. Restores the controller configuration parameters to factory defaults.

## Example

The following example shows how to restore the controller configuration parameters to factory defaults:

```
Server # scope chassis
Server /chassis # scope server 1
Server /chassis/server # scope storageadapter SBMezz1
Server /chassis/server/storageadapter # set-factory-defaults
This operation will restore controller settings to factory default values. Do you want to proceed?
Enter 'yes' to confirm -> yes
Server /chassis/server/storageadapter #
```

# Viewing Storage Controller Logs

## Before you begin

You must log in with admin privileges to perform this task.

## Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server {1   2}</b>	Enters server command mode of server 1 or 2.

	Command or Action	Purpose
<b>Step 3</b>	Server /chassis/server # <b>scope storageadapter</b> <i>Slot-ID</i>	Enters storage adapter command mode.
<b>Step 4</b>	Server /chassis/server/storageadapter # <b>show log</b>	Displays the storage controller logs.

### Example

This example shows how to display storage controller logs:

```
Server # scope chassis
Server /chassis # scope server 1
Server /chassis/server # scope storageadapter SLOT-3
Server /chassis/server/storageadapter # show log
```

Time	Severity	Description
Fri March 1 09:52:19 2015	Warning	Predictive Failure
Fri March 1 07:50:19 2015	Info	Battery charge complete
Fri March 1 07:50:19 2015	Info	Battery charge started
Fri March 1 07:48:19 2015	Info	Battery relearn complete
Fri March 1 07:47:19 2015	Info	Battery is discharging
Fri March 1 07:45:19 2015	Info	Battery relearn started

```
Server /chassis/server/storageadapter #
```

## Viewing Physical Drive Details

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 3</b>	Server /chassis/server # <b>scope storageadapter</b> <i>slot</i>	Enters server storage adapter mode.
<b>Step 4</b>	Server /chassis/server/storageadapter # <b>scope physical-drive</b> 2	Enters the physical drive command mode.
<b>Step 5</b>	Server /chassis/server/storageadapter/physical-drive # <b>show detail</b>	Displays the physical drive details.

### Example

This example shows how to view the physical drive information:

```
Server# scope chassis
Server/chassis # scope server 1
```

```

Server /chassis/server/ # scope storageadapter SBMezz1
Server /chassis/server/storageadapter # scope physical-drive 202
Server /chassis/server/storageadapter/physical-drive # show detail
Physical Drive Number 202:
  Controller: SBMezz1
  Info Valid: Yes
  Info Invalid Cause:
  Enclosure Device ID: 252
  Device ID: 8
  Drive Number: 202
  Health: Good
  Status: Online
  Boot Drive: false
  Manufacturer: ATA
  Model: INTEL SSDSC2BB480G4
  Predictive Failure Count: 0
  Drive Firmware: 0370
  Type: SSD
  Block Size: 512
  Physical Block Size: 4096
  Negotiated Link Speed: 6.0 Gb/s
  Locator LED: false
  FDE Capable: 0
  FDE Enabled: 0
  FDE Secured: 0
  FDE Locked: 0
  FDE Locked Foreign Config: 0
  Enclosure Association: Direct Attached
  Enclosure Logical ID: N/A
  Enclosure SAS Address[0]: N/A
  Enclosure SAS Address[1]: N/A
  Power Cycle Count: 106
  Power On Hours: 10471
  Percentage Life Left: 100
  Wear Status in Days: 1825
  Percentage Reserved Capacity Consumed: 0
  Time of Last Refresh : 2017-03-04 13:47
  Operating Temperature: 34
  Media Error Count: 0
  Other Error Count: 0
  Interface Type: SATA
  Block Count: 937703088
  Raw Size: 457862 MB
  Non Coerced Size: 457350 MB
  Coerced Size: 456809 MB
  SAS Address 0: 4433221108000000
  SAS Address 1: 0x0
  Power State: active
Server /chassis/server/storageadapter/physical-drive #

```

## Viewing SIOC NVMe Drive Details

You must scope to a particular CMC to view the NVMe drives in SIOC associated with that CMC.



**Note** This feature is available only on some S-Series servers.

**Procedure**

	<b>Command or Action</b>	<b>Purpose</b>
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope cmc [1 / 2]</b>	Enters the CMC command mode.
<b>Step 3</b>	Server /chassis/CMC # <b>scope nvmeadapter adapter name</b>	Enters the NVMe adapter command mode.
<b>Step 4</b>	Server /chassis/CMC/nvmeadapter # <b>show nvme-physical-drive detail</b>	Displays the SIOC NVMe physical drive details.

**Example**

This example shows how to view SIOC NVMe drive details:

```

Server # scope chassis
Server /chassis # scope cmc
Server /chassis/cmc # show detail
Firmware Image Information:
  ID: 1
  Name: CMC1
  SIOC PID: UCS-S3260-PCISIOC
  Serial Number: FCH21277K8T
  Update Stage: ERROR
  Update Progress: OS_ERROR
  Current FW Version: 4.0(0.166)
  FW Image 1 Version: 0.0(4.r17601)
  FW Image 1 State: BACKUP INACTIVATED
  FW Image 2 Version: 4.0(0.166)
  FW Image 2 State: RUNNING ACTIVATED
  Reset Reason: ac-cycle
  Secure Boot: ENABLED
Server /chassis # scope cmc 1
Server /chassis/cmc # scope nvmeadapter NVMe-direct-U.2-drives
Server /chassis/cmc/nvmeadapter # show nvme-physical-drive detail
Physical Drive Number SIOCVMe1:
  Product Name: Cisco 2.5 inch 1TB Intel P4501 NVMe Med. Perf. Value Endurance
  Manufacturer: Intel
  Serial Number: PHLF7303008G1P0KGN
  Temperature: 39 degrees C
  % Drive Life Used: 1
  Performance Level: 100
  LED Fault status: Healthy
  Drive Status: Optimal
  % Power on Hours: 8
  Firmware Version: QDV1CP03
  PCI Slot: SIOCVMe1
  Managed Id: 1
  Controller Type: NVME-SFF
  Controller Temperature: 39
  Throttle State: 0
  Throttle Start Temperature: 70
  Shutdown Temperature: 80
Physical Drive Number SIOCVMe2:
  Product Name: Cisco 2.5 inch 500GB Intel P4501 NVMe Med. Perf. Value Endurance
  Manufacturer: Intel
  Serial Number: PHLF73440068500JGN

```

```
Temperature: 39 degrees C
% Drive Life Used: 1
Performance Level: 100
LED Fault status: Healthy
Drive Status: Optimal
% Power on Hours: 7
Firmware Version: QDV1CP03
PCI Slot: SIOCNVMe2
Managed Id: 2
Controller Type: NVME-SFF
Controller Temperature: 39
Throttle State: 0
Throttle Start Temperature: 70
Shutdown Temperature: 80
Server /chassis/cmc/nvmeadapter #
```





## CHAPTER 12

# Configuring Communication Services

---

This chapter includes the following sections:

- [Configuring HTTP, on page 253](#)
- [Configuring SSH, on page 255](#)
- [Configuring XML API, on page 256](#)
- [Enabling Redfish, on page 256](#)
- [Configuring IPMI, on page 257](#)
- [Configuring SNMP, on page 261](#)
- [Configuring a Server to Send Email Alerts Using SMTP, on page 267](#)

## Configuring HTTP

Beginning with release 4.1(2b), Cisco IMC supports separate HTTPS and HTTP communication services. You can disable only HTTP services using this functionality.

This functionality is supported only on the following servers:

- Cisco UCS C220 M5
- Cisco UCS C240 M5
- Cisco UCS C480 M5
- Cisco UCS C480 ML M5
- Cisco UCS C240 SD M5
- Cisco UCS C125 M5
- Cisco UCS S3260 M4/M5



---

**Note** If **Redirect HTTP to HTTPS Enabled** was disabled in any release earlier than 4.1(2b), then after upgrading to release 4.1(2b) or later, **HTTP Enabled** value is set to **Disabled** by the system.

---

### Before you begin

You must log in as a user with admin privileges to configure HTTP.

**Procedure**

	<b>Command or Action</b>	<b>Purpose</b>
<b>Step 1</b>	Server# <b>scope http</b>	Enters the HTTP command mode.
<b>Step 2</b>	Server /http # <b>set enabled {yes   no}</b>	Enables or disables HTTP and HTTPS service on the Cisco IMC.
<b>Step 3</b>	Server /http # <b>set http-enabled {yes   no}</b>	Enables or disables HTTP services on the Cisco IMC.
<b>Step 4</b>	Server /http # <b>set http-port number</b>	Sets the port to use for HTTP communication. The default is 80.
<b>Step 5</b>	Server /http # <b>set https-port number</b>	Sets the port to use for HTTPS communication. The default is 443.
<b>Step 6</b>	Server /http # <b>set http-redirect {yes   no}</b>	Enables or disables the redirection of an HTTP request to HTTPS.
<b>Step 7</b>	Server /http # <b>set timeout seconds</b>	Sets the number of seconds to wait between HTTP requests before the Cisco IMC times out and terminates the session.  Enter an integer between 60 and 10,800. The default is 1,800 seconds.
<b>Step 8</b>	Server /http # <b>commit</b>	Commits the transaction to the system configuration.

**Example**

This example configures HTTP for the Cisco IMC:

```

Server# scope http
Server /http # set enabled yes
Server /http *# set http-port 80
Server /http *# set https-port 443
Server /http *# set http-redirect yes
Server /http *# set timeout 1800
Server /http *# commit
Server /http # show
HTTP Port  HTTPS Port  Timeout  Active Sessions  Enabled  HTTP Redirected
-----
80          443          1800    0                 yes     yes
Server /http #

```



# Configuring SSH

## Before you begin

You must log in as a user with admin privileges to configure SSH.

## Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope ssh</b>	Enters the SSH command mode.
<b>Step 2</b>	Server /ssh # <b>set enabled {yes   no}</b>	Enables or disables SSH on the Cisco IMC.
<b>Step 3</b>	Server /ssh # <b>set ssh-port <i>number</i></b>	Sets the port to use for secure shell access. The default is 22.
<b>Step 4</b>	Server /ssh # <b>set timeout <i>seconds</i></b>	Sets the number of seconds to wait before the system considers an SSH request to have timed out.  Enter an integer between 60 and 10,800. The default is 300 seconds.
<b>Step 5</b>	Server /ssh # <b>commit</b>	Commits the transaction to the system configuration.
<b>Step 6</b>	Server /ssh # <b>show [detail]</b>	(Optional) Displays the SSH configuration.

## Example

This example configures SSH for the Cisco IMC:

```
Server# scope ssh
Server /ssh # set enabled yes
Server /ssh *# set ssh-port 22
Server /ssh *# set timeout 600
Server /ssh *# commit
Server /ssh # show
SSH Port   Timeout  Active Sessions  Enabled
-----
22         600     1                yes

Server /ssh #
```

# Configuring XML API

## XML API for Cisco IMC

The Cisco IMC XML application programming interface (API) is a programmatic interface to Cisco IMC for a C-Series Rack-Mount Server. The API accepts XML documents through HTTP or HTTPS.

For detailed information about the XML API, see *Cisco UCS Rack-Mount Servers Cisco IMC XML API Programmer's Guide*.

## Enabling XML API

### Before you begin

You must log in as a user with admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope xmlapi</b>	Enters XML API command mode.
<b>Step 2</b>	Server /xmlapi # <b>set enabled {yes   no}</b>	Enables or disables XML API control of Cisco IMC.
<b>Step 3</b>	Server /xmlapi # <b>commit</b>	Commits the transaction to the system configuration.

### Example

This example enables XML API control of Cisco IMC and commits the transaction:

```
Server# scope xmlapi
Server /xmlapi # set enabled yes
Server /xmlapi *# commit
Server /xmlapi # show detail
XMLAPI Settings:
  Enabled: yes
  Active Sessions: 0
  Max Sessions: 4

Server /xmlapi #
```

## Enabling Redfish

### Before you begin

You must log in as a user with admin privileges to perform this task.

**Procedure**

	<b>Command or Action</b>	<b>Purpose</b>
<b>Step 1</b>	Server# <b>scope redfish</b>	Enters redfish command mode.
<b>Step 2</b>	Server /redfish # <b>set enabled {yes   no}</b>	Enables or disables redfish control of Cisco IMC.
<b>Step 3</b>	Server /redfish* # <b>commit</b>	Commits the transaction to the system configuration.

**Example**

This example enables redfish control of Cisco IMC and commits the transaction:

```
Server# scope redfish
Server /redfish # set enabled yes
Server /redfish *# commit
Server /redfish # show detail
REDFISH Settings:
  Enabled: yes
  Active Sessions: 0
  Max Sessions: 4

Server /redfish #
```

# Configuring IPMI

## IPMI Over LAN

Intelligent Platform Management Interface (IPMI) defines the protocols for interfacing with a service processor embedded in a server platform. This service processor is called a Baseboard Management Controller (BMC) and resides on the server motherboard. The BMC links to a main processor and other on-board elements using a simple serial bus.

During normal operations, IPMI lets a server operating system obtain information about system health and control system hardware. For example, IPMI enables the monitoring of sensors, such as temperature, fan speeds and voltages, for proactive problem detection. If server temperature rises above specified levels, the server operating system can direct the BMC to increase fan speed or reduce processor speed to address the problem.

## Configuring IPMI over LAN for Cisco IMC

Configure IPMI over LAN when you want to manage the Cisco IMC with IPMI messages.

**Before you begin**

You must log in with admin privileges to perform this task.

## Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /server # <b>scope ipmi</b>	Enters the IPMI command mode.
<b>Step 3</b>	Server /server/ipmi # <b>set enabled</b> {yes   no}	Enables or disables IPMI access on this server.
<b>Step 4</b>	Server /server/ipmi # <b>set privilege-level</b> {readonly   user   admin}	<p>Specifies the highest privilege level that can be assigned to an IPMI session on this server. This can be:</p> <ul style="list-style-type: none"> <li>• <b>readonly</b> — IPMI users can view information but cannot make any changes. If you select this option, IPMI users with the "Administrator", "Operator", or "User" user roles can only create read-only IPMI sessions, regardless of their other IPMI privileges.</li> <li>• <b>user</b> — IPMI users can perform some functions but cannot perform administrative tasks. If you select this option, IPMI users with the "Administrator" or "Operator" user role can create user and read-only sessions on this server.</li> <li>• <b>admin</b> — IPMI users can perform all available actions. If you select this option, IPMI users with the "Administrator" user role can create admin, user, and read-only sessions on this server.</li> </ul>
<b>Step 5</b>	Server /server/ipmi # <b>set encryption-key</b> key	Sets the IPMI encryption key to use for IPMI communications. The key value must be 40 hexadecimal numbers.
<b>Step 6</b>	Server /server/ipmi # <b>commit</b>	Commits the transaction to the system configuration.
<b>Step 7</b>	Server /server/ipmi # <b>randomise-key</b>	<p>Sets the IPMI encryption key to a random value.</p> <p><b>Note</b> You can perform the Step 6 action instead of Steps 4 and 5.</p>
<b>Step 8</b>	At the prompt, enter <b>y</b> to randomize the encryption key.	Sets the IPMI encryption key to a random value.

**Example**

This example configures IPMI over LAN for the Cisco IMC:

```

Server # scope server 1
Server /server # scope ipmi
Server /server/ipmi # set enabled yes
Server /server/ipmi *# set privilege-level admin
Server /server/ipmi *# set encryption-key abcdef01234567890abcdef01234567890abcdef
Server /server/ipmi *# commit
Server /server/ipmi *# show
Enabled Encryption Key                               Privilege Level Limit
-----
yes          ABCDEF01234567890ABCDEF01234567890ABCDEF admin

Server /server/ipmi # randomise-key
This operation will change the IPMI Encryption Key to a random value
Continue?[y|N]y
Setting IPMI Encryption Key to a random value...

Server /server/ipmi # show
Enabled Encryption Key                               Privilege Level Limit
-----
yes          abcdef01234567890abcdef01234567890abcdef admin

Server /server/ipmi #

```

## Configuring IPMI over LAN for CMCs

Configure IPMI over LAN when you want to manage the CMC with IPMI messages.

**Before you begin**

You must log in with admin privileges to perform this task.

**Procedure**

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /chassis # <b>scope cmc</b> {1   2}	Enters CMC command mode.
<b>Step 3</b>	Server /server # <b>scope ipmi</b>	Enters the IPMI command mode.
<b>Step 4</b>	Server /chassis/cmc/ipmi # <b>set enabled</b> {yes   no}	Enables or disables IPMI access on this server.
<b>Step 5</b>	Server /chassis/cmc/ipmi # <b>set privilege-level</b> {readonly   user   admin}	Specifies the highest privilege level that can be assigned to an IPMI session on this server. This can be: <ul style="list-style-type: none"> <li>• <b>readonly</b> — IPMI users can view information but cannot make any changes. If you select this option, IPMI users with the "Administrator", "Operator", or "User"</li> </ul>

	Command or Action	Purpose
		<p>user roles can only create read-only IPMI sessions, regardless of their other IPMI privileges.</p> <ul style="list-style-type: none"> <li>• <b>user</b> — IPMI users can perform some functions but cannot perform administrative tasks. If you select this option, IPMI users with the "Administrator" or "Operator" user role can create user and read-only sessions on this server.</li> <li>• <b>admin</b> — IPMI users can perform all available actions. If you select this option, IPMI users with the "Administrator" user role can create admin, user, and read-only sessions on this server.</li> </ul>
<b>Step 6</b>	Server /chassis/cmc/ipmi # <b>set encryption-key key</b>	Sets the IPMI encryption key to use for IPMI communications. The key value must be 40 hexadecimal numbers.
<b>Step 7</b>	Server /chassis/cmc/ipmi # <b>commit</b>	Commits the transaction to the system configuration.
<b>Step 8</b>	Server /chassis/cmc/ipmi # <b>randomise-key</b>	<p>Sets the IPMI encryption key to a random value.</p> <p><b>Note</b> You can perform the Step 6 action instead of Steps 4 and 5.</p>
<b>Step 9</b>	At the prompt, enter <b>y</b> to randomize the encryption key.	Sets the IPMI encryption key to a random value.

### Example

This example configures IPMI over LAN for the CMC 1:

```

Server # scope chassis
Server # scope cmc 1
Server /chassis # scope ipmi
Server /chassis/cmc/ipmi # set enabled yes
Server /chassis/cmc/ipmi *# set privilege-level admin
Server /chassis/cmc/ipmi *# set encryption-key abcdef01234567890abcdef01234567890abcdef
Server /chassis/cmcipmi *# commit
Server /chassis/cmc/ipmi *# show
Enabled Encryption Key                               Privilege Level Limit
-----
yes          ABCDEF01234567890ABCDEF01234567890ABCDEF admin

Server /chassis/cmc/ipmi # randomise-key
This operation will change the IPMI Encryption Key to a random value
Continue?[y|N]y
Setting IPMI Encryption Key to a random value...

```

```

Server /chassis/cmc/ipmi # show
Enabled Encryption Key                               Privilege Level Limit
-----
yes          abcdef01234567890abcdef01234567890abcdef admin

Server /chassis/cmc/ipmi #

```

## Configuring SNMP

### SNMP

The Cisco UCS C-Series Rack-Mount Servers support the Simple Network Management Protocol (SNMP) for viewing server configuration and status and for sending fault and alert information by SNMP traps. For information on Management Information Base (MIB) files supported by Cisco IMC, see the *MIB Quick Reference for Cisco UCS* at this URL: [http://www.cisco.com/c/en/us/td/docs/unified\\_computing/ucs/sw/mib/b-series/b\\_UCS\\_MIBRef.html](http://www.cisco.com/c/en/us/td/docs/unified_computing/ucs/sw/mib/b-series/b_UCS_MIBRef.html).

### Configuring SNMP Properties

#### Before you begin

You must log in as a user with admin privileges to perform this task.

#### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope snmp</b>	Enters SNMP command mode.
<b>Step 2</b>	Server /snmp # <b>set enabled {yes   no}</b>	Enables or disables SNMP.  <b>Note</b> SNMP must be enabled and saved before additional SNMP configuration commands are accepted.
<b>Step 3</b>	Server /snmp # <b>commit</b>	Commits the transaction to the system configuration.
<b>Step 4</b>	Server /snmp # <b>set enable-serial-num {yes   no}</b>	Prefixes the traps with the serial number of the server.
<b>Step 5</b>	Server /snmp # <b>set snmp-port port number</b>	Sets the port number on which the SNMP agent runs. You can choose a number within the range 1 to 65535. The default port number is 161.

	Command or Action	Purpose
		<b>Note</b> The port numbers that are reserved for system calls, such as 22,23,80,123,443,623,389,636,3268,3269 and 2068, cannot be used as an SNMP port.
<b>Step 6</b>	Server /snmp # <b>set community-str</b> <i>community</i>	Specifies the default SNMP v1 or v2c community name that Cisco IMC includes on any trap messages it sends to the SNMP host. The name can be up to 18 characters.
<b>Step 7</b>	Server /snmp # <b>set community-access</b>	This can be one of the following : Disabled, Limited, or Full.
<b>Step 8</b>	Server /snmp # <b>set trap-community-str</b>	Specifies the SNMP community group to which trap information should be sent. The name can be up to 18 characters
<b>Step 9</b>	Server /snmp # <b>set sys-contact</b> <i>contact</i>	Specifies the system contact person responsible for the SNMP implementation. The contact information can be up to 254 characters, such as an email address or a name and telephone number. To enter a value that contains spaces, you must enclose the entry with quotation marks.
<b>Step 10</b>	Server /snmp # <b>set sys-location</b> <i>location</i>	Specifies the location of the host on which the SNMP agent (server) runs. The location information can be up to 254 characters. To enter a value that contains spaces, you must enclose the entry with quotation marks.
<b>Step 11</b>	Server /snmp # <b>commit</b>	Commits the transaction to the system configuration.

### Example

This example configures the SNMP properties and commits the transaction:

```
Server# scope snmp
Server /snmp # set enabled yes
Server /snmp *# commit
Server /snmp *# set enable-serial-num yes
Server /snmp *# set snmp-port 20000
Server /snmp *# set community-str cimcpublish
Server /snmp *# set community-access Full
Server /snmp *# set trap-community-str public
Server /snmp *# set sys-contact "User Name <username@example.com> +1-408-555-1212"
Server /snmp *# set sys-location "San Jose, California"
Server /snmp *# commit
Server /snmp # show detail
SNMP Settings:
    SNMP Port: 20000
```



```

System Contact: User Name <username@example.com> +1-408-555-1212
System Location: San Jose, California
SNMP Community: cimcpbublic
SNMP Trap Community: public
SNMP Community access: Full
Enabled: yes
Serial Number Enabled: yes

```

```
Server /snmp #
```

### What to do next

Configure SNMP trap settings as described in [Configuring SNMP Trap Settings, on page 263](#).

## Configuring SNMP Trap Settings

### Before you begin

- You must log in with admin privileges to perform this task.
- SNMP must be enabled and saved before trap settings can be configured.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope snmp</b>	Enters the SNMP command mode.
<b>Step 2</b>	Server /snmp # <b>scope trap-destinations</b> <i>number</i>	Enters the SNMP trap destination command mode for the specified destination. Four SNMP trap destinations are available. The destination <i>number</i> is an integer between 1 and 15.
<b>Step 3</b>	Server /snmp/trap-destinations # <b>set enabled</b> {yes   no}	Enables or disables the SNMP trap destination.
<b>Step 4</b>	Server /snmp/trap-destinations # <b>set version</b> { 2   3 }	Specify the desired SNMP version of the trap message.  <b>Note</b> SNMPv3 traps will be delivered only to locations where the SNMPv3 user and key values are configured correctly.
<b>Step 5</b>	Server /snmp/trap-destinations # <b>set type</b> {trap   inform}	Specifies whether SNMP notification messages are sent as simple traps or as inform requests requiring acknowledgment by the receiver.  <b>Note</b> The inform option can be chosen only for V2 users.
<b>Step 6</b>	Server /snmp/trap-destinations # <b>set user</b> <i>user</i>	

	Command or Action	Purpose
<b>Step 7</b>	Server /snmp/trap-destination # <b>set trap-addr</b> <i>trap destination address</i>	Specifies the trap destination address to which the trap information is sent. You can set an IPv4 or IPv6 address or a domain name as the trap destination.  <b>Note</b> When IPv6 is enabled, the SNMP Trap destination source address can either be the SLAAC IPv6 address (if available) or a user assigned IPv6 address. Both these are valid SNMP IPv6 destination addresses that uniquely identify the server.
<b>Step 8</b>	Server /snmp/trap-destinations # <b>set trap-port</b> <i>trap destination port</i>	Sets the port number the server uses to communicate with the trap destination. You can choose a number within the range 1 to 65535.
<b>Step 9</b>	Server /snmp/trap-destination # <b>commit</b>	Commits the transaction to the system configuration.

### Example

This example configures general SNMP trap settings and trap destination number 1 and commits the transaction:

```
Server# scope snmp
Server /snmp # Scope trap-destinations 1
Server /snmp/trap-destination *# set enabled yes
Server /snmp/trap-destination *# set version 2
Server /snmp/trap-destination *# set type inform
Server /snmp/trap-destination *# set user user1
Server /snmp/trap-destination *# set trap-addr www.cisco.com
Server /snmp/trap-destination *# set trap-port 10000
Server /snmp/trap-destination *# commit
Server /snmp/trap-destination # show detail
Trap Destination 1:
  Enabled: yes
  SNMP version: 2
  Trap type: inform
  SNMP user: user1
  Trap Address: www.cisco.com
  Trap Port: 10000
  Delete Trap: no
Server /snmp/trap-destination #
```

## Sending a Test SNMP Trap Message

### Before you begin

You must log in with admin privileges to perform this task.

**Procedure**

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope snmp</b>	Enters the SNMP command mode.
<b>Step 2</b>	Server /snmp # <b>send-test-trap</b>	Sends an SNMP test trap to the configured SNMP trap destination that are enabled.  <b>Note</b> The trap must be configured and enabled in order to send a test message.

**Example**

This example sends a test message to all the enabled SNMP trap destinations:

```
Server# scope snmp
Server /snmp # send-test-trap
SNMP Test Trap sent to the destination.
Server /snmp #
```

## Configuring SNMPv3 Users

**Before you begin**

- You must log in as a user with admin privileges to perform this task.
- SNMP must be enabled and saved before these configuration commands are accepted.

**Procedure**

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope snmp</b>	Enters the SNMP command mode.
<b>Step 2</b>	Server /snmp # <b>scope v3users number</b>	Enters the SNMPv3 users command mode for the specified user number.
<b>Step 3</b>	Server /snmp/v3users # <b>set v3add {yes   no}</b>	Adds or deletes an SNMPv3 user. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>yes</b>—This user is enabled as an SNMPv3 user and is allowed to access the SNMP OID tree.</li> </ul> <p><b>Note</b> The security name and security level must also be configured at this time or the user addition will fail.</p> <ul style="list-style-type: none"> <li>• <b>no</b>—This user configuration is deleted.</li> </ul>

	Command or Action	Purpose
<b>Step 4</b>	Server /snmp/v3users # <b>set v3security-name</b> <i>security-name</i>	Enter an SNMP username for this user.
<b>Step 5</b>	Server /snmp/v3users # <b>set v3security-level</b> { <b>noauthnopriv</b>   <b>authnopriv</b>   <b>authpriv</b> }	<p>Select a security level for this user. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>noauthnopriv</b>—The user does not require an authorization or privacy password.</li> <li>• <b>authnopriv</b>—The user requires an authorization password but not a privacy password. If you select this option, you must configure an authentication key.</li> <li>• <b>authpriv</b>—The user requires both an authorization password and a privacy password. If you select this option, you must configure an authentication key and a private encryption key.</li> </ul> <p><b>Note</b> For a v3 version, only authnopriv and authpriv security levels are available.</p>
<b>Step 6</b>	Server /snmp/v3users # <b>set v3proto</b> { <b>MD5</b>   <b>SHA</b> }	Select an authentication protocol for this user.
<b>Step 7</b>	Server /snmp/v3users # <b>set v3auth-key</b> <i>auth-key</i>	Enter an authorization password for this user.
<b>Step 8</b>	Server /snmp/v3users # <b>set v3priv-prot</b> { <b>DES</b>   <b>AES</b> }	Select an encryption protocol for this user.
<b>Step 9</b>	Server /snmp/v3users # <b>set v3priv-auth-key</b> <i>priv-auth-key</i>	Enter a private encryption key (privacy password) for this user.
<b>Step 10</b>	Server /snmp/v3users # <b>commit</b>	Commits the transaction to the system configuration.

### Example

This example configures SNMPv3 user number 2 and commits the transaction:

```
Server# scope snmp
Server /snmp # scope v3users 2
Server /snmp/v3users # set v3add yes
Server /snmp/v3users *# set v3security-name ucsSNMPV3user
Server /snmp/v3users *# set v3security-level authpriv
Server /snmp/v3users *# set v3proto SHA
Server /snmp/v3users *# set v3auth-key
Please enter v3auth-key:ex4mplek3y
Please confirm v3auth-key:ex4mplek3y
Server /snmp/v3users *# set v3priv-prot AES
Server /snmp/v3users *# set v3priv-auth-key
```

```

Please enter v3priv-auth-key:!1@2#3$4%5^6&7*8
Please confirm v3priv-auth-key:!1@2#3$4%5^6&7*8
Server /snmp/v3users *# commit
Settings are being applied ... allow a few minutes for the process to complete
Server /snmp/v3users # show detail
User 2:
  Add User: yes
  Security Name: ucsSNMPV3user
  Security Level: authpriv
  Auth Type: SHA
  Auth Key: *****
  Encryption: AES
  Private Key: *****

Server /snmp/v3users #

```

## Configuring a Server to Send Email Alerts Using SMTP

The Cisco IMC supports email-based notification of server faults to recipients without relying on the SNMP. The system uses the Simple Mail Transfer Protocol (SMTP) to send server faults as email alerts to the configured SMTP server.

A maximum of four recipients is supported.

## Configuring SMTP Servers for Receiving E-Mail Alerts

### Before you begin

You must log in as a user with admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope smtp</b>	Enters the SMTP command mode.
<b>Step 2</b>	Server /smtp # <b>set enabled {yes   no}</b>	Enables or disables the SMTP feature.
<b>Step 3</b>	Server /smtp * # <b>set server-addr <i>IP_Address</i></b>	Assigns the SMTP server IP address.
<b>Step 4</b>	Server /smtp * # <b>set fault-severity {critical   major   minor   warning   condition}</b>	Assigns the fault severity to the mail alerts.
<b>Step 5</b>	Server /smtp * # <b>set port <i>port_number</i></b>	Sets the port number for the SMTP server.
<b>Step 6</b>	Server /smtp * # <b>commit</b>	Commits the transaction to the system configuration.
<b>Step 7</b>	Server /smtp # <b>send-test-mail recipient1</b>	Sends a test mail alert to the email address assigned to the chosen recipient.

## Example

This example shows how to configure SMTP for receiving mail alerts:

```

Server # scope smtp
Server /smtp # set enabled yes
Server /smtp *# set server-addr 10.10.10.10
Server /smtp *# set fault-severity major
Server /smtp *# set port 25
Server /smtp # set-mail-addr recipient1 test@cisco.com
There is no change in the configured port number.
Please verify if you wish to choose a different one before commit.
Server /smtp *# commit
Server /smtp # show detail
SMTP Setting:
  Enabled: yes
  Port Number: 25
  Server Address: 10.104.10.10
  Minimum Severity to Report: critical
  Recipient1:
    Name      : test@cisco.com
    Reachable: na
  Recipient2:
    Name      :
    Reachable: na
  Recipient3:
    Name      :
    Reachable: na
  Recipient4:
    Name      :
    Reachable: na

Server /smtp # send-test-mail recipient1
Test mail sent Successful.
Server /smtp # show detail
SMTP Setting:
  Enabled: yes
  Port Number: 25
  Server Address: 10.10.10.10
  Minimum Severity to Report: critical
  Recipient1:
    Name      : test@cisco.com
    Reachable: yes
  Recipient2:
    Name      :
    Reachable: na
  Recipient3:
    Name      :
    Reachable: na
  Recipient4:
    Name      :
    Reachable: na

Server /smtp #

```



# CHAPTER 13

## Managing Certificates and Server Security

This chapter includes the following sections:

- [Managing the Server Certificate, on page 269](#)
- [KMIP, on page 275](#)

### Managing the Server Certificate

#### Managing the Server Certificate

You can generate a certificate signing request (CSR) to obtain a new certificate, and you can upload the new certificate to Cisco IMC to replace the current server certificate. The server certificate may be signed either by a public Certificate Authority (CA), such as Verisign, or by your own certificate authority. The generated certificate key length is 2048 bits.



---

**Note** Before performing any of the following tasks in this chapter, ensure that the Cisco IMC time is set to the current time.

---

#### Procedure

---

- Step 1** Generate the CSR from Cisco IMC.
- Step 2** Submit the CSR file to a certificate authority that will issue and sign your certificate. If your organization generates its own self-signed certificates, you can use the CSR file to generate a self-signed certificate.
- Step 3** Upload the new certificate to Cisco IMC.

**Note** The uploaded certificate must be created from a CSR generated by Cisco IMC. Do not upload a certificate that was not created by this method.

---

## Generating a Certificate Signing Request

You can either generate a self-signed certificate manually using the **generate-csr** command, or automatically when you change the hostname. For information on changing the hostname and auto generation of the self-signed certificate, see the **Configuring Common Properties** section.

To manually generate a certificate signing request, follow these steps:

### Before you begin

- You must log in as a user with admin privileges to configure certificates.
- Ensure that the Cisco IMC time is set to the current time.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope certificate</b>	Enters the certificate command mode.
<b>Step 2</b>	Server /certificate # <b>generate-csr</b>	Launches a dialog for the generation of a certificate signing request (CSR).

You will be prompted to enter the following information for the certificate signing request:

Name	Description
<b>Common Name</b> field	The fully qualified name of the Cisco IMC.  By default the CN of the servers appears in CXXX-YYYYYY format, where XXX is the model number and YYYYYY is the serial number of the server.  When you upgrade to latest version, CN is retained as is.
<b>Organization Name</b> field	The organization requesting the certificate.
<b>Organization Unit</b> field	The organizational unit.
<b>Locality</b> field	The city or town in which the company requesting the certificate is headquartered.
<b>State Name</b> field	The state or province in which the company requesting the certificate is headquartered.
<b>Country Code</b> drop-down list	The country in which the company resides.
<b>Email</b> field	The email contact at the company.

After you have entered the requested information, the system will generate and display a certificate signing request in the console output. A CSR file will not be created, but you can copy the CSR information from the console output and paste the information into a text file.



## Example

This example generates a certificate signing request:

```

Server# scope certificate
Server /certificate # generate-csr
Common Name (CN): test.example.com
Organization Name (O): Example, Inc.
Organization Unit (OU): Test Department
Locality (L): San Jose
StateName (S): CA
Country Code (CC): US
Email: user@example.com
Continue to generate CSR?[y|N]y

-----BEGIN CERTIFICATE REQUEST-----
MIIB/zCCAWgCAQAwZkxkCzAJBgNVBAYTA1VtMQswCQYDVQQLIEwJDQTEVMBGAlUE
BxMMU2FuIEpvc2UsIENBMRUwEwYDVQKEwxFeGFtcGx1IEluYy4xEzARBgNVBAST
ClRlc3QgR3JvdXAxGTAXBgNVBAMTEHRlc3QuZXhhbXBsZS5jb20xHzAdBgkqhkiG
9w0BCQEWEHVzZXJAZXhhbXBsZS5jb20wgZ8wDQYJKoZIhvcNAQEBBQADgY0AMIGJ
AoGBAMZw4nTepNIDhVzb0j7Z2Je4xAG56zmSHRMQeOGHemdh66u2/XAoLx7YCCyU
ZgAMivYCsKgb/6CjQtsofvzxmC/eAehuK3/SINv7wd6Vv2pBt6ZpXgD4VBNKOND1
GMbkPayVlQjbG4MD2dx2+H8EH3LMtdZrgKvPxPTE+bf5wzVNAgMBAAGgJTAjBgkq
hkiG9w0BCQcxFhMUQSBjaGFsbGVuZ2UgcGFzc3dvcmQwDQYJKoZIhvcNAQEFBQAD
gYEAG6lCaJoJaVMhzCl90306Mg51zqlzXcz75+VFj2I6rH9asckCl3mkOVx5gJU
Ptt5CVQpNgNLdvbDPSsXretysOhqHmp9+CLv8FDuy1CDYfuaLtv1WvfhevskV0j6
mK3Ku+YiORnv6DhxrOoqau8r/hyI/L43l7IPN1HhOi3oha4=
-----END CERTIFICATE REQUEST-----

Copy everything from "-----BEGIN ..." to "END CERTIFICATE REQUEST-----",
paste to a file, send to your chosen CA for signing,
and finally upload the signed certificate via upload command.
---OR---
Continue to self sign CSR and overwrite the current certificate?
All HTTPS and SSH sessions will be disconnected. [y|N]N

```

## What to do next

Perform one of the following tasks:

- If you do not want to obtain a certificate from a public certificate authority, and if your organization does not operate its own certificate authority, you can allow Cisco IMC to internally generate a self-signed certificate from the CSR and upload it immediately to the server. Type **y** after the final prompt in the example to perform this action.
- If your organization operates its own certificate server for generating self-signed certificates, copy the command output from "-----BEGIN ..." to "END CERTIFICATE REQUEST-----" and paste to a file named `csr.txt`. Input the CSR file to your certificate server to generate a self-signed certificate.
- If you will obtain a certificate from a public certificate authority, copy the command output from "-----BEGIN ..." to "END CERTIFICATE REQUEST-----" and paste to a file named `csr.txt`. Submit the CSR file to the certificate authority to obtain a signed certificate.
- Ensure that the certificate is of type **Server**.

If you did not use the first option, in which Cisco IMC internally generates and uploads a self-signed certificate, you must upload the new certificate using the **upload** command in certificate command mode.

## Creating an Untrusted CA-Signed Certificate

As an alternative to using a public Certificate Authority (CA) to generate and sign a server certificate, you can operate your own CA and sign your own certificates. This section shows commands for creating a CA and generating a server certificate using the OpenSSL certificate server running on Linux. For detailed information about OpenSSL, see <http://www.openssl.org>.



**Note** These commands are to be entered on a Linux server with the OpenSSL package, not in the Cisco IMC.

### Before you begin

- Obtain and install a certificate server software package on a server within your organization.
- Ensure that the Cisco IMC time is set to the current time.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	<b>openssl genrsa -out CA_keyfilename keysize</b> <b>Example:</b> <pre># openssl genrsa -out ca.key 2048</pre>	This command generates an RSA private key that will be used by the CA.  <b>Note</b> To allow the CA to access the key without user input, do not use the <code>-des3</code> option for this command.  The specified file name contains an RSA key of the specified key size.
<b>Step 2</b>	<b>openssl req -new -x509 -days numdays -key CA_keyfilename -out CA_certfilename</b> <b>Example:</b> <pre># openssl req -new -x509 -days 365 -key ca.key -out ca.crt</pre>	This command generates a new self-signed certificate for the CA using the specified key. The certificate is valid for the specified period. The command prompts the user for additional certificate information.  The certificate server is an active CA.
<b>Step 3</b>	<b>echo "nsCertType = server" &gt; openssl.conf</b> <b>Example:</b> <pre># echo "nsCertType = server" &gt; openssl.conf</pre>	This command adds a line to the OpenSSL configuration file to designate the certificate as a server-only certificate. This designation is a defense against a man-in-the-middle attack, in which an authorized client attempts to impersonate the server.  The OpenSSL configuration file <code>openssl.conf</code> contains the statement <code>"nsCertType = server"</code> .
<b>Step 4</b>	<b>openssl x509 -req -days numdays -in CSR_filename -CA CA_certfilename -set_serial 04 -CAkey CA_keyfilename -out server_certfilename -extfile openssl.conf</b>	This command directs the CA to use your CSR file to generate a server certificate.  Your server certificate is contained in the output file.

	Command or Action	Purpose
	<p><b>Example:</b></p> <pre># openssl x509 -req -days 365 -in csr.txt -CA ca.crt -set_serial 04 -CAkey ca.key -out myserver05.crt -extfile openssl.conf</pre>	
<b>Step 5</b>	<p><b>openssl x509 -noout -text -purpose -in &lt;cert file&gt;</b></p> <p><b>Example:</b></p> <pre>openssl x509 -noout -text -purpose -in &lt;cert file&gt;</pre>	<p>Verifies if the generated certificate is of type <b>Server</b>.</p> <p><b>Note</b> If the values of the fields <b>Server SSL</b> and <b>Netscape SSL</b> server are not yes, ensure that openssl.conf is configured to generate certificates of type server.</p>
<b>Step 6</b>	<p>(Optional) If the generated certificate does not have the correct validity dates, ensure the Cisco IMC time is set to the current time, and regenerate the certificate by repeating steps 1 through 5.</p>	<p>Certificate with the correct validity dates is created.</p>

**Example**

This example shows how to create a CA and to generate a server certificate signed by the new CA. These commands are entered on a Linux server running OpenSSL.

```
# /usr/bin/openssl genrsa -out ca.key 2048
Generating RSA private key, 2048 bit long modulus
.....+++++
.....+++++
e is 65537 (0x10001)
# /usr/bin/openssl req -new -x509 -days 365 -key ca.key -out ca.crt
You are about to be asked to enter information that will be incorporated
into your certificate request.
What you are about to enter is what is called a Distinguished Name or a DN.
There are quite a few fields but you can leave some blank
For some fields there will be a default value,
If you enter '.', the field will be left blank.
-----
Country Name (2 letter code) [GB]:US
State or Province Name (full name) [Berkshire]:California
Locality Name (eg, city) [Newbury]:San Jose
Organization Name (eg, company) [My Company Ltd]:Example Incorporated
Organizational Unit Name (eg, section) []:Unit A
Common Name (eg, your name or your server's hostname) []:example.com
Email Address []:admin@example.com
# echo "nsCertType = server" > openssl.conf
# /usr/bin/openssl x509 -req -days 365 -in csr.txt -CA ca.crt -set_serial 01
-CAkey ca.key -out server.crt -extfile openssl.conf
Signature ok
subject=/C=US/ST=California/L=San Jose/O=Example Inc./OU=Unit
A/CN=example.com/emailAddress=john@example.com
Getting CA Private Key
#
```

**What to do next**

Upload the new certificate to the Cisco IMC.

## Uploading a Server Certificate

**Before you begin**

- You must log in as a user with admin privileges to upload a certificate.
- The certificate to be uploaded must be available as readable text. During the upload procedure, you will copy the certificate text and paste it into the CLI.
- Ensure that the generated certificate is of type **Server**.
- The following certificate formats are supported:
  - .crt
  - .cer
  - .pem



**Note** You must first generate a CSR using the Cisco IMC certificate management CSR generation procedure, and you must use that CSR to obtain the certificate for uploading. Do not upload a certificate that was not obtained by this method.



**Note** All current HTTPS and SSH sessions are disconnected when the new server certificate is uploaded.

**Procedure**

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope certificate</b>	Enters the certificate command mode.
<b>Step 2</b>	Server /certificate # <b>upload</b>	Launches a dialog for entering and uploading the new server certificate.

Copy the certificate text, paste it into the console when prompted, and type CTRL+D to upload the certificate.

**Example**

This example uploads a new certificate to the server:

```
Server# scope certificate
Server /certificate # upload
Please paste your certificate here, when finished, press CTRL+D.
-----BEGIN CERTIFICATE-----
MIIB/zCCAQgCAQAwgZkxCzAJBgNVBAYTAlVTMQswCQYDVQQIEwJDQTEVMBMGA1UE
```

```
BxMMU2FuIEpvc2UsIENBMRUwEwYDVOQKEwxFeGFtcGx1IEluYy4xEzARBgNVBAst
CLR1c3QgR3JvdXAxGTAXBgNVBAMTEHR1c3QuZXhhbXBsZS5jb20xHZAAdBgkqhkiG
9w0BCQEWEHVzZXJAZXhhbXBsZS5jb20wgZ8wDQYJKoZIhvcNAQEBBQADgY0AMIGJ
AoGBAMZw4nTepNIDhVzb0j7Z2Je4xAG56zmSHRMQeOGHemdh66u2/XAoLx7YCcYU
ZgAMivycsKgb/6CjQtsofvzxmC/eAehuK3/SINv7wd6Vv2pBt6ZpXgD4VBKOND1
GMbkPayV1QjbG4MD2dx2+H8EH3LMtdZrgKvPxPTE+bf5wZVNAgMBAAGgJTAjBgkq
hkiG9w0BCQcxFhMUQSBjaGFsbGVuZ2UgcGFzc3dvcmQwDQYJKoZIhvcNAQEFBQAD
gYEAG61CaJoJaVMhzCL190306Mg51zq1zXcz75+VFj2I6rH9asckCLd3mkOVx5gJU
Ptt5CVQpNgNLdvbDPSsXretysOhqHmp9+CLv8FDuy1CDYfuaLtv1Wvfhevskv0j6
mK3Ku+YiORnv6DhxrOoqau8r/hyI/L4317IPN1HhOi3oha4=
-----END CERTIFICATE-----
<CTRL+D>
```

# KMIP

## Key Management Interoperability Protocol

Key Management Interoperability Protocol (KMIP) is a communication protocol that defines message formats to handle keys or classified data on a key management server. KMIP is an open standard and is supported by several vendors. Key management involves multiple interoperable implementations, so a KMIP client works effectively with any KMIP server.

Self-Encrypting Drives (SEDs) contain hardware that encrypts incoming data and decrypts outgoing data in realtime. A drive or media encryption key controls this function. However, the drives need to be locked in order to maintain security. A security key identifier and a security key (key encryption key) help achieve this goal. The key identifier provides a unique ID to the drive.

Different keys have different usage requirements. Currently, the responsibility of managing and tracking local keys lies primarily with the user, which could result in human error. The user needs to remember the different keys and their functions, which could prove to be a challenge. KMIP addresses this area of concern to manage the keys effectively without human involvement.

## Enabling or Disabling KMIP

### Before you begin

You must log in as a user with admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /server # <b>scope bmc</b>	Enters bmc command mode.
<b>Step 3</b>	Server /server/bmc # <b>scope kmip</b>	Enters the KMIP command mode.
<b>Step 4</b>	Server /server/bmc/kmip # <b>set enabled</b> {yes   no}	Enables or disables KMIP.

	Command or Action	Purpose
<b>Step 5</b>	Server /server/bmc/kmip *# <b>commit</b>	Commits the transaction to the system configuration.
<b>Step 6</b>	(Optional) Server /server/bmc/kmip # <b>show detail</b>	Displays the KMIP status.

### Example

This example enables KMIP:

```
Server # scope server 1
Server /server # scope bmc
Server /server/bmc # scope kmip
Server /server/bmc/kmip # set enabled yes
Server /server/bmc/kmip *# commit
Server /server/bmc/kmip # show detail
    Enabled: yes
Server /server/bmc/kmip #
```

## Configuring KMIP Server Login Credentials

This procedure shows you how to configure the login credentials for the KMIP server and make the KMIP server login credentials mandatory for message authentication.

### Before you begin

You must log in as a user with admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /server # <b>scope bmc</b>	Enters bmc command mode.
<b>Step 3</b>	Server /server/bmc # <b>scope kmip</b>	Enters the KMIP command mode.
<b>Step 4</b>	Server /server/bmc/kmip # <b>scope kmip-login</b>	Enters the KMIP login command mode.
<b>Step 5</b>	Server /server/bmc/kmip/kmip-login # <b>set login</b> <i>username</i>	Sets the KMIP server user name.
<b>Step 6</b>	Server /server/bmc/kmip/kmip-login * # <b>set</b> <b>password</b>	Enter the password at the prompt and enter the same password again at the confirm password prompt. This sets the KMIP server password.
<b>Step 7</b>	Server /server/bmc/kmip/kmip-login * # <b>set</b> <b>use-kmip-cred</b> {yes   no}	Decides whether the KMIP server login credentials should be mandatory for message authentication.

	Command or Action	Purpose
<b>Step 8</b>	Server /server/bmc/kmip/kmip-login * # <b>commit</b>	Commits the transaction to the system configuration.
<b>Step 9</b>	(Optional) Server /server/bmc/kmip/kmip-login # <b>restore</b>	Restores the KMIP settings to defaults.

### Example

This example shows how to configure the KMIP server credentials:

```
Server # scope server 1
Server /server # scope bmc
Server /server/bmc # scope kmip
Server /server/bmc/kmip # scope kmip-login
Server /server/bmc/kmip/kmip-login # set login username
Server /server/bmc/kmip/kmip-login *# set password
Please enter password:
Please confirm password:
Server /server/bmc/kmip/kmip-login *# set use-kmip-cred yes
Server /server/bmc/kmip/kmip-login *# commit
Server /server/bmc/kmip/kmip-login # show detail
    Use KMIP Login: yes
    Login name to KMIP server: username
    Password to KMIP server: *****
```

You can restore the KMIP server credentials to default settings by performing the following step:

```
Server /server/bmc/kmip/kmip-login # restore
Are you sure you want to restore KMIP settings to defaults?
Please enter 'yes' to confirm: yes
Restored factory-default configuration.
Server /server/bmc/kmip/kmip-login # show detail
    Use KMIP Login: no
    Login name to KMIP server:
    Password to KMIP server: *****
Server /server/bmc/kmip/kmip-login #
```

## Creating a Client Private Key and Client Certificate for KMIP Configuration

As an alternative to using a public Certificate Authority (CA) to generate and sign a server certificate, you can operate your own CA and sign your own certificates. This section shows commands for creating a CA and generating a server certificate using the OpenSSL certificate server running on Linux. For detailed information about OpenSSL, see <http://www.openssl.org>.



**Note** These commands are to be entered on a Linux server with the OpenSSL package, not in the Cisco IMC.

### Before you begin

- Obtain and install a certificate server software package on a server within your organization.

- Ensure that the Cisco IMC time is set to the current time.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	<b>openssl genrsa -out <i>Client_Privatekeyfilename</i> <i>keysize</i></b>  <b>Example:</b> <pre># openssl genrsa -out client_private.pem 2048</pre>	This command generates a client private key that will be used to generate the client certificate.  The specified file name contains an RSA key of the specified key size.
<b>Step 2</b>	<b>openssl req -new -x509 -days <i>numdays</i> -key <i>Client_Privatekeyfilename</i> -out <i>Client_certfilename</i></b>  <b>Example:</b> <pre># openssl req -new -x509 -key client_private.pem -out client.pem -days 365</pre>	This command generates a new self-signed client certificate using the client private key obtained from the previous step. The certificate is valid for the specified period. The command prompts the user for additional certificate information.  A new self-signed client certificate is created.
<b>Step 3</b>	Obtain the KMIP root CA certificate from the KMIP server.	Refer to the KMIP vendor documentation for details on obtaining the root CA certificate.

### What to do next

Upload the new certificate to the Cisco IMC.

## Testing the KMIP Server Connection

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server {1   2}</b>	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /server # <b>scope bmc</b>	Enters bmc command mode.
<b>Step 3</b>	Server /server/bmc # <b>scope kmip</b>	Enters the KMIP command mode.
<b>Step 4</b>	Server /server/bmc/kmip # <b>scope kmip-server <i>server ID</i></b>	Enters the chosen KMIP server command mode.
<b>Step 5</b>	Server /server/bmc/kmip/kmip-server # <b>test-connectivity</b>	Verifies the connection of the KMIP server.

### Example

This example tests the KMIP server connection:

```
Server # scope server 1
Server /server # scope bmc
```



```

Server /server/bmc # scope kmip
Server /server/bmc/kmip # scope kmip-server 1
Server /server/bmc/kmip/kmip-server # test-connectivity
Able to connect to KMIP server.
Server /server/bmc/kmip/kmip-server #

```

## Configuring KMIP Server Properties

### Before you begin

You must log in with admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /server # <b>scope bmc</b>	Enters bmc command mode.
<b>Step 3</b>	Server /server/bmc # <b>scope kmip</b>	Enters the KMIP command mode.
<b>Step 4</b>	Server /server/bmc/kmip # <b>scope kmip-server</b> <i>server ID</i>	Enters the chosen KMIP server command mode.
<b>Step 5</b>	Server /server/bmc/kmip/kmip-server # <b>set</b> <i>kmip-port</i>	Sets the KMIP port.
<b>Step 6</b>	Server /server/bmc/kmip/kmip-server *# <b>set</b> <i>kmip-server</i>	Sets the KMIP server ID.
<b>Step 7</b>	Server /server/bmc/kmip/kmip-server # <b>set</b> <i>kmip-timeout</i>	Sets the KMIP server timeout.
<b>Step 8</b>	Server /server/bmc/kmip/kmip-server # <b>commit</b>	Commits the transaction to system configuration.
<b>Step 9</b>	(Optional) Server /server/bmc/kmip/kmip-server # <b>show detail</b>	Displays the KMIP server details.

### Example

This example tests the KMIP server connection:

```

Server # scope server 1
Server /server # scope bmc
Server /server/bmc # scope kmip
Server /server/bmc/kmip # scope kmip-server 1
Server /server/bmc/kmip/kmip-server # set kmip-port 5696
Server /server/bmc/kmip/kmip-server * # set kmip-server kmipserver.com
Server /server/bmc/kmip/kmip-server * # set kmip-timeout 10
Server /server/bmc/kmip/kmip-server * # commit
Server /server/bmc/kmip/kmip-server # show detail
Server number 1:
  Server domain name or IP address: kmipserver.com

```

```

Port: 5696
Timeout: 10
Server /server/bmc/kmip/kmip-server #

```

## Downloading a KMIP Client Certificate

### Before you begin

You must log in as a user with admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /server # <b>scope bmc</b>	Enters bmc command mode.
<b>Step 3</b>	Server /server/bmc # <b>scope kmip</b>	Enters the KMIP command mode.
<b>Step 4</b>	Server /server/bmc/kmip # <b>set enabled yes</b>	Enables KMIP.
<b>Step 5</b>	Server /server/bmc/kmip *# <b>commit</b>	Commits the transaction to the system configuration.
<b>Step 6</b>	Server /server/bmc/kmip # <b>scope kmip-client-certificate</b>	Enters the KMIP client certificate command mode.
<b>Step 7</b>	Server /server/bmc/kmip/kmip-client-certificate # <b>download-client-certificate</b> <i>remote-protocol IP Address KMIP client certificate file</i>	Specifies the protocol to connect to the remote server. It can be of the following types: <ul style="list-style-type: none"> <li>• TFTP</li> <li>• FTP</li> <li>• SFTP</li> <li>• SCP</li> <li>• HTTP</li> </ul>

	Command or Action	Purpose
		<p><b>Note</b> The Cisco UCS C-Series server now supports fingerprint confirmation of the server when you update firmware through a remote server. This option is available only if you choose SCP or SFTP as the remote server type.</p> <p>If you chose SCP or SFTP as the remote server type while performing this action, a prompt with the message Server (RSA) key fingerprint is &lt;server_finger_print_ID&gt; Do you wish to continue? Click y or n depending on the authenticity of the server fingerprint.</p> <p>The fingerprint is based on the host's public key and helps you to identify or verify the host you are connecting to.</p>
<b>Step 8</b>	At the confirmation prompt, enter <b>y</b> .	This begins the download of the KMIP client certificate.
<b>Step 9</b>	(Optional) Server /server/bmc/kmip/kmip-client-certificate # <b>paste-client-certificate</b>	<p>At the prompt, paste the content of the signed certificate and press <b>CTRL+D</b>.</p> <p><b>Note</b> You can either use the remote server method from the previous steps or use the paste option to download the client certificate.</p>

**Example**

This example downloads the KMIP client certificate:

```

Server # scope server 1
Server /server # scope bmc
Server /server/bmc # scope kmip
Server /server/bmc/kmip # set enabled yes
Server /server/bmc/kmip *# commit
Server /server/bmc/kmip # scope kmip-client-certificate
Server /server/bmc/kmip/kmip-client-certificate # show detail
    KMIP client certificate Available: 1
    Download client certificate Status: COMPLETED
    Export client certificate Status: NONE
Server /server/bmc/kmip/kmip-client-certificate # download-client-certificate tftp
10.10.10.10 KmpCertificates/
svbu-xx-blr-dn1-13_ClientCert.pem
    You are going to overwrite the KMIP client certificate.
    Are you sure you want to proceed and overwrite the KMIP client certificate? [y|N]y
KMIP client certificate downloaded successfully
    
```

You can either use the remote server method from the previous steps or use the paste option to download the client certificate.

```
Server /server/bmc/kmip/kmip-client-certificate # paste-client-certificate
Please paste your certificate here, when finished, press CTRL+D.
----BEGIN CERTIFICATE-----
MIIDTzCCAjegAwIBAgIQXuWpDbbyTb5M7/FT8aAjZTANBgkqhkiG9w0BAQUFADA6
MRMwEQYKCZImiZPyLQBGRYDY29tMRMwEQYKCZImiZPyLQBGRYDbmV3MQ4wDAYD
VQQDEwVuzXkdQTAeFw0xNTAzMTIxMTM5MTZaFw0yMDAzMTIxMTQ5MTVaMDoxEzAR
BgoJkiaJk/IsZAEZFgNjb20xEzARBgoJkiaJk/IsZAEZFgNuZXcxZjAMBGNVBAMT
BW5ld0NBMIIBIjANBgkqhkiG9w0BAQEFAAOCAQ8AMIIBCgKCAQEAuPSAwHtk0IbM
Cd5tYdCa498bfX5Nfdgnq5ze+cGIOqv0dAkucofC/Y0+m7hne9H12aQ9SqtOK1+L
5IT3PVCzhasI7L7jAa+Oe5AOYw7Nsugw5Bd23n42BTVMmp7xsgrlmVfFoHXbBkQ
wiT9DieyImSyGiq5n0/8Iooc0iN5WPMVcHO2ys76jR8p07xRqgYNC16cbKAHwfZ
oYIwjhpZv0+SXES8sEJZKDUHwIfoIpnDL7MoZYgl/kymgs/0hsW4L338jy303c7T
TwnG2/7BOMK0YFkEhqjlkamGP7MKB2T9e/Cug6VkvFSkkim8M1eHx1gEnQxRtAG
YGp1n55iHQIDAQABo1EwTzALBgNVHQ8EBAMCAYYwDwYDVR0TAQH/BAUwAwEB/zAd
BgNVHQ4EFgQU12F3U7cggzCuvRWliZWg91n51ccwEAYJKwYBBAGCNxUBBAMCAQAw
DQYJKoZIhvcNAQEFBQADggEBAJXoJUDD3QH0q8VY8G/oC1SkAwyoE1dH0NdxFES
tNqQMTaRB2Sb2L/ZzAtfIaZ0Xab9Ig4MqNIMBbHDCw1zhD5gX42GPYWhA/GjRj30
Q5KcRaEFomxp+twRrJ25ScVSczKJaRonWqKDVL9TwoSuDar30biS9ZC0KuBBf0vu
dzrJEYY/1zz7WVPZVyevhba3VSt4LW75URTqOKBSuKO+fvGyyNHwvMPFEIEnJAKt
7Qmh02fiWhd8CxaPFIByqkvrJ96no6oBxdEcjm9n1MttF/UJcypSPH+46mRn5Az
SzgCBftYNjBPLcwbZGJkF/GpPwjD0Tc1MM08UOdqiTxR7Ts=
-----END CERTIFICATE-----
You are going to overwrite the KMIP Client Certificate.
Are you sure you want to proceed and overwrite the KMIP Client Certificate? [y|N]
y
Server /server/bmc/kmip/kmip-client-certificate #
```

## Exporting a KMIP Client Certificate

### Before you begin

- You must log in as a user with admin privileges to perform this task.
- You should have downloaded KMIP client certificate before you can export it.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /server # <b>scope bmc</b>	Enters bmc command mode.
<b>Step 3</b>	Server /server/bmc # <b>scope kmip</b>	Enters the KMIP command mode.
<b>Step 4</b>	Server /server/bmc/kmip # <b>scope kmip-client-certificate</b>	Enters the KMIP client certificate command mode.
<b>Step 5</b>	Server /server/bmc/kmip/kmip-client-certificate # <b>export-client-certificate remote-protocol IP Adresss KMIP root CA Certificate file</b>	Specifies the protocol to connect to the remote server. It can be of the following types: <ul style="list-style-type: none"> <li>• TFTP</li> </ul>

	Command or Action	Purpose
		<ul style="list-style-type: none"> <li>• FTP</li> <li>• SFTP</li> <li>• SCP</li> <li>• HTTP</li> </ul> <p><b>Note</b> The Cisco UCS C-Series server now supports fingerprint confirmation of the server when you update firmware through a remote server. This option is available only if you choose SCP or SFTP as the remote server type.</p> <p>If you chose SCP or SFTP as the remote server type while performing this action, a prompt with the message Server (RSA) key fingerprint is &lt;server_finger_print_ID&gt; Do you wish to continue? Click y or n depending on the authenticity of the server fingerprint.</p> <p>The fingerprint is based on the host's public key and helps you to identify or verify the host you are connecting to.</p> <p>Initiates the export of the certificate.</p>
<b>Step 6</b>	(Optional) Server /server/bmc/kmip/kmip-client-certificate # <b>show detail</b>	Displays the status of the certificate export.

**Example**

This example exports the KMIP client certificate:

```

Server # scope server 1
Server /server # scope bmc
Server /server/bmc # scope kmip
Server /server/bmc/kmip # scope kmip-client-certificate
Server /server/bmc/kmip/kmip-client-certificate # export-client-certificate ftp 10.10.10.10
/TFTP_DIR/KmipCertificates
/svbu-xx-blr-dn1-13_ClientCert.pem_exported_ftp
Username: username
Password:
KMIP Client Certificate exported successfully
Server /server/bmc/kmip/kmip-client-certificate # show detail
    KMIP Client Certificate Available: 1
    Download KMIP Client Certificate Status: COMPLETED
    Export KMIP Client Certificate Status: COMPLETED
Server /server/bmc/kmip/kmip-client-certificate #
    
```

## Deleting a KMIP Client Certificate

### Before you begin

You must log in as a user with admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /server # <b>scope bmc</b>	Enters bmc command mode.
<b>Step 3</b>	Server /server/bmc # <b>scope kmip</b>	Enters the KMIP command mode.
<b>Step 4</b>	Server /server/bmc/kmip # <b>scope kmip-client-certificate</b>	Enters the KMIP client certificate binding command mode.
<b>Step 5</b>	Server /server/bmc/kmip/kmip-client-certificate # <b>delete-client-certificate</b>	Confirmation prompt appears.
<b>Step 6</b>	At the confirmation prompt, enter <b>y</b> .	This deletes the KMIP client certificate.

### Example

This example deletes the KMIP client certificate:

```
Server # scope server 1
Server /server # scope bmc
Server /server/bmc # scope kmip
Server /server/bmc/kmip # scope kmip-client-certificate
Server /server/bmc/kmip/kmip-client-certificate # delete-client-certificate
You are going to delete the KMIP Client Certificate.
Are you sure you want to proceed and delete the KMIP Client Certificate? [y|N]y
KMIP Client Certificate deleted successfully.
```

## Downloading a KMIP Client Private Key

### Before you begin

You must log in as a user with admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /server # <b>scope bmc</b>	Enters bmc command mode.
<b>Step 3</b>	Server /server/bmc # <b>scope kmip</b>	Enters the KMIP command mode.

	Command or Action	Purpose
<b>Step 4</b>	Server /server/bmc/kmip # <b>set enabled yes</b>	Enables KMIP.
<b>Step 5</b>	Server /server/bmc/kmip *# <b>commit</b>	Commits the transaction to the system configuration.
<b>Step 6</b>	Server /server/bmc/kmip # <b>scope kmip-client-private-key</b>	Enters the KMIP client private key command mode.
<b>Step 7</b>	Server /server/bmc/kmip/kmip-client-private-key # <b>download-client-pvt-key remote-protocol IP Address KMIP client private key file</b>	<p>Specifies the protocol to connect to the remote server. It can be of the following types:</p> <ul style="list-style-type: none"> <li>• TFTP</li> <li>• FTP</li> <li>• SFTP</li> <li>• SCP</li> <li>• HTTP</li> </ul> <p><b>Note</b> The Cisco UCS C-Series server now supports fingerprint confirmation of the server when you update firmware through a remote server. This option is available only if you choose SCP or SFTP as the remote server type.</p> <p>If you chose SCP or SFTP as the remote server type while performing this action, a prompt with the message Server (RSA) key fingerprint is &lt;server_finger_print_ID&gt; Do you wish to continue? Click y or n depending on the authenticity of the server fingerprint.</p> <p>The fingerprint is based on the host's public key and helps you to identify or verify the host you are connecting to.</p>
<b>Step 8</b>	At the confirmation prompt, enter <b>y</b> .	This begins the download of the KMIP client private key.
<b>Step 9</b>	(Optional) Server /server/bmc/kmip/kmip-client-private-key # <b>paste-client-pvt-key</b>	<p>At the prompt, paste the content of the private key and press <b>CTRL+D</b>.</p> <p><b>Note</b> You can either use the remote server method from the previous steps or use the paste option to download the client private key.</p>

**Example**

This example downloads the KMIP client private key:

```
Server # scope server 1
Server /server # scope bmc
Server /server/bmc # scope kmip
Server /server/bmc/kmip # set enabled yes
Server /server/bmc/kmip *# commit
Server /server/bmc/kmip # scope kmip-client-private-key
Server /server/bmc/kmip/kmip-client-private-key # show detail
    KMIP Client Private Key Available: 1
    Download Client Private Key Status: COMPLETED
    Export Client Private Key Status: NONE
Server /server/bmc/kmip/kmip-client-private-key # download-client-pvt-key tftp 10.10.10.10
KmipCertificates/
svbu-xx-blr-dn1-13_ClientPvtKey.pem
    You are going to overwrite the KMIP Client Private Key.
    Are you sure you want to proceed and overwrite the KMIP Client Private Key? [y/N]y
KMIP Client Private Key downloaded successfully
```

**You can either use the remote server method from the previous steps or use the paste option to download the client certificate.**

```
Server /server/bmc/kmip/kmip-client-private-key # paste-client-pvt-key
Please paste your client private here, when finished, press CTRL+D.
----BEGIN CERTIFICATE-----
MIIDTzCCAjegAwIBAgIQXuWpDbByTb5M7/FT8aAjZTANBgkqhkiG9w0BAQUFADA6
MRMwEQYKCZImiZPyLQGGRYDY29tMRMwEQYKCZImiZPyLQGGRYDbmV3MQ4wDAYD
VQOEEwVuZXNdQTAeFw0xNTAzMTIxMTM5MTZaFw0yMDAzMTIxMTQ5MTVaMDoxEzAR
BgoJkiaJk/IsZAEZFgNjb20xEzARBgoJkiaJk/IsZAEZFgNuZXcxZjAMBGNVBAMT
BW5ld0NBMIIBIjANBgkqhkiG9w0BAQEFAAOCAQ8AMIIBCgKCAQEAuPSAwHtk0IbM
Cd5tYdCa498bfX5Nfdgnq5zE+cGIOqv0dAkucofC/Y0+m7hne9H12aQ9SqtOK1+L
5IT3PVCczhasI7L7jAa+Oe5AOYw7Nsugw5Bd23n42BTVMmp7xsgr1mVfFoHXbBkQ
wiT9DieyImSyGiq5n0/8Iooc0iN5WPMVcHO2ysz76jr8p07xRggYNC16cbKAHwFZ
oYIwJhpZv0+SXEs8sEJZKDUhWf0IpnDL7MoZYgl/kymgs/0hsW4L338jy303c7T
TwnG2/7BOMK0YFkEhqcjlkamGP7MKB2T9e/Cug6VkvFSkkim8M1eHx1gEnQxRtAG
YGpln55iHQIDAQABo1EwTzALBgNVHQ8EBAMCAYYwDwYDVR0TAQH/BAUwAwEB/zAd
BgNVHQ4EFgQU12F3U7cggzCuvRWliZWg91n51ccwEAYJKwYBBAGCNxUBBAMCAQAw
DQYJKoZIhvcNAQEFBQADggEBAJXoJJDDB3QH0q8VY8G/oc1SkAwyOE1dH0NdxFES
tNqQMTaRB2Sb2L/ZzAtfIaZ0Xab9Ig4MqNIMBbHDCw1zhD5gX42GPYWhA/GjRj30
Q5KcRaEFomxp+twRrJ25ScvSczKJaRonWqKDVL9TwoSuDar3Obis9ZC0KuBBf0vu
dzrJEYY/1zz7WVPZVYevhba3VSt4LW75URTqOKBSuKO+fvGyyNHwvMPFEIEnJAKt
7QmhO2fiWhD8CxaPFIBYqkvrJ96no6oBxdEcjm9n1MttF/UJcypSPH+46mRn5Az
SzgCBftYNjBPLcwbZGJkF/GpPwjD0Tc1MM08UOdqiTxR7Ts=
-----END CERTIFICATE-----
    You are going to overwrite the KMIP client private key.
    Are you sure you want to proceed and overwrite the KMIP Client Private Key? [y/N]
y
Server /server/bmc/kmip/kmip-client-private-key #
```

## Exporting KMIP Client Private Key

**Before you begin**

- You must log in as a user with admin privileges to perform this task.



- You should have downloaded KMIP client private key before you can export it.

**Procedure**

	<b>Command or Action</b>	<b>Purpose</b>
<b>Step 1</b>	Server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /server # <b>scope bmc</b>	Enters bmc command mode.
<b>Step 3</b>	Server /server/bmc # <b>scope kmip</b>	Enters the KMIP command mode.
<b>Step 4</b>	Server /server/bmc/kmip # <b>scope kmip-client-private-key</b>	Enters the KMIP client private key command mode.
<b>Step 5</b>	Server /server/bmc/kmip/kmip-client-private-key # <b>export-client-pvt-key</b> <i>remote-protocol IP</i> <i>Addresss KMIP root CA Certificate file</i>	<p>Specifies the protocol to connect to the remote server. It can be of the following types:</p> <ul style="list-style-type: none"> <li>• TFTP</li> <li>• FTP</li> <li>• SFTP</li> <li>• SCP</li> <li>• HTTP</li> </ul> <p><b>Note</b> The Cisco UCS C-Series server now supports fingerprint confirmation of the server when you update firmware through a remote server. This option is available only if you choose SCP or SFTP as the remote server type.</p> <p>If you chose SCP or SFTP as the remote server type while performing this action, a prompt with the message Server (RSA) key fingerprint is &lt;server_finger_print_ID&gt; Do you wish to continue? Click y or n depending on the authenticity of the server fingerprint.</p> <p>The fingerprint is based on the host's public key and helps you to identify or verify the host you are connecting to.</p> <p>Initiates the export of the certificate.</p>
<b>Step 6</b>	(Optional) Server /server/bmc/kmip/kmip-client-private-key # <b>show detail</b>	Displays the status of the certificate export.

### Example

This example exports the KMIP client private key:

```
Server # scope server 1
Server /server # scope bmc
Server /server/bmc # scope kmip
Server /server/bmc/kmip # scope kmip-client-private-key
Server /server/bmc/kmip/kmip-client-private-key # export-client-pvt-key tftp 10.10.10.10
KmpCertificates
/svbu-xx-blr-dnl-13_ClientPvtKey.pem_exported_tftp
KMIP Client Private Key exported successfully
Server /server/bmc/kmip/kmip-client-private-key # show detail
    KMIP Client Private Key Available: 1
    Download Client Private Key Status: COMPLETED
    Export Client Private Key Status: COMPLETED
Server /server/bmc/kmip/kmip-client-private-key #
```

## Deleting a KMIP Client Private Key

### Before you begin

You must log in as a user with admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server {1   2}</b>	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /server # <b>scope bmc</b>	Enters bmc command mode.
<b>Step 3</b>	Server /server/bmc # <b>scope kmip</b>	Enters the KMIP command mode.
<b>Step 4</b>	Server /server/bmc/kmip # <b>scope kmip-client-private-key</b>	Enters the KMIP client private key binding command mode.
<b>Step 5</b>	Server /server/bmc//kmip/kmip-client-private-key # <b>delete-client-pvt-key</b>	Confirmation prompt appears.
<b>Step 6</b>	At the confirmation prompt, enter <b>y</b> .	This deletes the KMIP client private key.

### Example

This example deletes the KMIP client private key:

```
Server # scope server 1
Server /server # scope bmc
Server /server/bmc # scope kmip
Server /server/bmc/kmip # scope kmip-client-private-key
Server /server/bmc/kmip/kmip-client-private-key # delete-client-pvt-key
    You are going to delete the KMIP client private key.
```

```
Are you sure you want to proceed and delete the KMIP client private key? [y|N]y
KMIP client private key deleted successfully.
```

## Downloading a KMIP Root CA Certificate

### Before you begin

You must log in as a user with admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /server # <b>scope bmc</b>	Enters bmc command mode.
<b>Step 3</b>	Server /server/bmc # <b>scope kmip</b>	Enters the KMIP command mode.
<b>Step 4</b>	Server /server/bmc/kmip # <b>set enabled yes</b>	Enables KMIP.
<b>Step 5</b>	Server /server/bmc/kmip * # <b>commit</b>	Commits the transaction to the system configuration.
<b>Step 6</b>	Server server/bmc/kmip # <b>scope kmip-root-ca-certificate</b>	Enters the KMIP root CA certificate command mode.
<b>Step 7</b>	Server server/bmc/kmip/kmip-root-ca-certificate # <b>download-root-ca-certificate</b> <i>remote-protocol IP Address KMIP CA Certificate file</i>	Specifies the protocol to connect to the remote server. It can be of the following types: <ul style="list-style-type: none"> <li>• TFTP</li> <li>• FTP</li> <li>• SFTP</li> <li>• SCP</li> <li>• HTTP</li> </ul>

	Command or Action	Purpose
		<p><b>Note</b> The Cisco UCS C-Series server now supports fingerprint confirmation of the server when you update firmware through a remote server. This option is available only if you choose SCP or SFTP as the remote server type.</p> <p>If you chose SCP or SFTP as the remote server type while performing this action, a prompt with the message Server (RSA) key fingerprint is &lt;server_finger_print_ID&gt; Do you wish to continue? Click y or n depending on the authenticity of the server fingerprint.</p> <p>The fingerprint is based on the host's public key and helps you to identify or verify the host you are connecting to.</p>
<b>Step 8</b>	At the confirmation prompt, enter <b>y</b> .	This begins the download of the KMIP root CA certificate.
<b>Step 9</b>	(Optional) Server server/bmc/kmip/kmip-root-ca-certificate # <b>paste-root-ca-certificate</b>	<p>At the prompt, paste the content of the root CA certificate and press <b>CTRL+D</b>.</p> <p><b>Note</b> You can either use the remote server method from the previous steps or use the paste option to download the root CA certificate.</p>

### Example

This example downloads the KMIP root CA certificate:

```

Server # scope server 1
Server /server # scope bmc
Server /server/bmc # scope kmip
Server /server/bmc/kmip # set enabled yes
Server /server/bmc/kmip *# commit
Server /server/bmc/kmip # scope kmip-root-ca-certificate
Server /server/bmc/kmip/kmip-root-ca-certificate # show detail
    KMIP Root CA Certificate Available: 1
    Download Root CA Certificate Status: COMPLETED
    Export Root CA Certificate Status: NONE
Server /server/bmc/kmip/kmip-root-ca-certificate # download-root-ca-certificate tftp
10.10.10.10 KmipCertificates/
svbu-xx-blr-dnl-13_ServerCert.pem
    You are going to overwrite the KMIP Root CA Certificate.
    Are you sure you want to proceed and overwrite the KMIP Root CA Certificate? [y|N]y
KMIP Root CA Certificate downloaded successfully

```

You can either use the remote server method from the previous steps or use the paste option to download the client certificate.

```
Server /server/bmc/kmip/kmip-root-ca-certificate # paste-root-ca-certificate
Please paste your certificate here, when finished, press CTRL+D.
-----BEGIN CERTIFICATE-----
MIIDTzCCAjegAwIBAgIQXuWpDbByTb5M7/FT8aAjZTANBgkqhkiG9w0BAQUFADA6
MRMwEQYKCZImiZPyLGBGRYDY29tMRMwEQYKCZImiZPyLGBGRYDmV3MQ4wDAYD
VQQDEwVuzXkdQTAeFw0xNTAzMTIxMTM5MTZaFw0yMDAzMTIxMTQ5MTVaMDoxEzAR
BgoJkiaJk/IsZAEZFgNjb20xEzARBgoJkiaJk/IsZAEZFgNuZXcxZjAMBGNVBAMT
BW5ld0NBMIIBIjANBgkqhkiG9w0BAQEFAAOCAQ8AMIIBCgKCAQEAAuPSAwHtk0TbM
Cd5tYdCa498bfX5Nfdgnq5zE+cGIOqv0dAkucofC/Y0+m7hne9H12aQ9SqtOK1+L
5IT3PVCczhasI7L7jAa+Oe5AOYw7Nsugw5Bd23n42BTVMmp7xsgr1mVfFoHXbBkQ
wiT9DieyImSyGi5n0/8Iooc0iN5WPMVcHO2ys76jR8p07xRqgYnc16cbKAHwFz
oYIwjhpzv0+SXEs8sEJZKDUhWIfOIpndL7MoZYgl/kymgs/0hsW4L338jy303c7T
TwnG2/7BOMK0YFkEhqcjlkamGP7MKB2T9e/Cug6VkvFSkkm8M1eHxlgEnQxRtAG
YGp1n55iHQIDAQABo1EwTzALBGNVHQ8EBAMCAYYwDwYDVR0TAQH/BAUwAwEB/zAd
BgNVHQ4EFgQU12F3U7cggzCuvRWLiZWg91n51ccwEAYJKwYBBAGCNxUBBAMCAQAw
DQYJKoZIhvcNAQEFBQADggEBAJXoJJDB3QH0q8VY8G/oc1SkAwYOE1dh0NdxFES
tNqQMTaRB2Sb2L/ZzAtfIaZ0Xab9I94MqNIMBbHDCwLzhD5gX42GPYWhA/GjRj30
Q5KcRaEFomxp+twRrJ25ScVSczKJaRonWqKDVL9TwoSuDar3Obis9ZC0KuBBf0vu
dzrJEYY/lzz7WVPZVyevhba3Vst4LW75URTqOKBSuKO+fvGyyNHwvMPFEIEEnJAKT
7Qmh02fiWhD8CxaPFIByqkvrJ96no6oBxdEcjm9n1MttF/UJcypSPH+46mRn5Az
SzgCBftYNjBPLcwbZGJkF/GpPwjD0TclMM08UOdqiTxR7Ts=
-----END CERTIFICATE-----

You are going to overwrite the KMIP Root CA Certificate.
Are you sure you want to proceed and overwrite the KMIP Root CA Certificate? [y|N]
y
Server /server/bmc/kmip/kmip-root-ca-certificate #
```

## Exporting a KMIP Root CA Certificate

### Before you begin

- You must log in as a user with admin privileges to perform this task.
- You should have downloaded KMIP root CA certificate before you can export it.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # scope server {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /server # scope bmc	Enters bmc command mode.
<b>Step 3</b>	Server /server/bmc # scope kmip	Enters the KMIP command mode.
<b>Step 4</b>	Server /server/bmc/kmip # scope kmip-root-ca-certificate	Enters the KMIP root CA certificate command mode.
<b>Step 5</b>	Server /server/bmc/kmip/kmip-root-ca-certificate # export-root-ca-certificate remote-protocol IP Adresss KMIP root CA Certificate file	Specifies the protocol to connect to the remote server. It can be of the following types: <ul style="list-style-type: none"> <li>• TFTP</li> </ul>

	Command or Action	Purpose
		<ul style="list-style-type: none"> <li>• FTP</li> <li>• SFTP</li> <li>• SCP</li> <li>• HTTP</li> </ul> <p><b>Note</b> The Cisco UCS C-Series server now supports fingerprint confirmation of the server when you update firmware through a remote server. This option is available only if you choose SCP or SFTP as the remote server type.</p> <p>If you chose SCP or SFTP as the remote server type while performing this action, a prompt with the message Server (RSA) key fingerprint is &lt;server_finger_print_ID&gt; Do you wish to continue? Click y or n depending on the authenticity of the server fingerprint.</p> <p>The fingerprint is based on the host's public key and helps you to identify or verify the host you are connecting to.</p> <p>Initiates the export of the certificate.</p>
<b>Step 6</b>	(Optional) Server /server/bmc/kmip/kmip-root-ca-certificate # <b>show detail</b>	Displays the status of the certificate export.

### Example

This example exports the KMIP root CA certificate:

```
Server # scope server 1
Server /server # scope bmc
Server /server/bmc # scope kmip
Server /server/bmc/kmip # scope kmip-root-ca-certificate
Server /server/bmc/kmip/kmip-root-ca-certificate # export-root-ca-certificate tftp
10.10.10.10 KmipCertificates/
svbu-xx-blr-dn1-13_ServerCert.pem_exported_tftp
KMIP Root CA Certificate exported successfully
Server /server/bmc/kmip/kmip-root-ca-certificate # show detail
    KMIP Root CA Certificate Available: 1
    Download Root CA Certificate Status: COMPLETED
    Export Root CA Certificate Status: COMPLETED
Server /server/bmc/kmip/kmip-root-ca-certificate #
```

## Deleting a KMIP Root CA Certificate

### Before you begin

You must log in as a user with admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /server # <b>scope bmc</b>	Enters bmc command mode.
<b>Step 3</b>	Server /server/bmc # <b>scope kmip</b>	Enters the KMIP command mode.
<b>Step 4</b>	Server /server/bmc/kmip # <b>scope kmip-root-ca-certificate</b>	Enters the KMIP root CA certificate binding command mode.
<b>Step 5</b>	Server /server/bmc/kmip/kmip-root-ca-certificate # <b>delete-root-ca-certificate</b>	Confirmation prompt appears.
<b>Step 6</b>	At the confirmation prompt, enter <b>y</b> .	This deletes the KMIP root CA certificate.

### Example

This example deletes the KMIP root CA certificate:

```
Server # scope server 1
Server /server # scope bmc
Server /server/bmc # scope kmip
Server /kmip # scope kmip-root-ca-certificate
Server /kmip/kmip-root-ca-certificate # delete-root-ca-certificate
  You are going to delete the KMIP root CA certificate.
  Are you sure you want to proceed and delete the KMIP root CA certificate? [y|N]y
KMIP root CA certificate deleted successfully.
```







# CHAPTER 14

## Configuring Platform Event Filters

This chapter includes the following sections:

- [Platform Event Filters, on page 295](#)
- [Configuring Platform Event Filters, on page 295](#)
- [Resetting Event Platform Filters, on page 296](#)

### Platform Event Filters

A platform event filter (PEF) can trigger an action. For each PEF, you can choose the action to be taken (or take no action) when a platform event occurs.

### Configuring Platform Event Filters

You can configure actions and alerts for the following platform event filters:

ID	Platform Event Filter
1	Temperature Critical Assert Filter
2	Voltage Critical Assert Filter
3	Current Assert Filter
4	Fan Critical Assert Filter
5	Processor Assert Filter
6	Power Supply Critical Assert Filter
7	Memory Critical Assert Filter

#### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope fault</b>	Enters the fault command mode.

	Command or Action	Purpose
<b>Step 2</b>	Server /fault # <b>scope pef id</b>	Enters the platform event filter command mode for the specified event.  See the Platform Event Filter table for event ID numbers.
<b>Step 3</b>	Server /fault/pef # <b>set action {none   reboot   power-cycle   power-off}</b>	Selects the desired system action when this event occurs. The action can be one of the following: <ul style="list-style-type: none"> <li>• <b>none</b> —No system action is taken.</li> <li>• <b>reboot</b> —The server is rebooted.</li> <li>• <b>power-cycle</b> —The server is power cycled.</li> <li>• <b>power-off</b> —The server is powered off.</li> </ul>
<b>Step 4</b>	Server /fault/pef # <b>commit</b>	Commits the transaction to the system configuration.

### Example

This example configures the platform event alert for an event:

```
Server# scope fault
Server /fault # scope pef 5
Server /fault/pef # set action reboot
Server /fault/pef *# commit
Server /fault/pef # show
Platform Event Filter Event          Action
-----
5          Processor Assert Filter    reboot

Server /fault/pef #
```

## Resetting Event Platform Filters

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope fault</b>	Enters the fault command mode.
<b>Step 2</b>	Server /fault # <b>set platform-event-enabled yes</b>	Enables platform event alerts.
<b>Step 3</b>	Server /fault # <b>commit</b>	Commits the transaction to the system configuration.
<b>Step 4</b>	Server /fault # <b>reset-event-filters</b>	Resets the platform event filters.

	Command or Action	Purpose
<b>Step 5</b>	Server /fault # <b>show pef</b>	Displays the latest platform event filters.

### Example

The following example enables platform event alerts:

```

Server# scope fault
Server /fault # set platform-event-enabled yes
Server /fault *# commit
Server /fault # show
Platform Event Enabled
-----
    yes

Server /fault # reset-event-filters
Server /fault # show pef
Platform Event Filter   Event                                     Action
-----
1                       Temperature Critical Assert Filter  none
2                       Voltage Critical Assert Filter      none
3                       Current Assert Filter                none
4                       Fan Critical Assert Filter           none
5                       Processor Assert Filter              none

Server /fault #

```





## CHAPTER 15

# Cisco IMC Firmware Management

---

This chapter includes the following sections:

- [Overview of Firmware, on page 299](#)
- [Obtaining Firmware from Cisco, on page 300](#)
- [Installing Cisco IMC Firmware from a Remote Server, on page 302](#)
- [Activating Installed Cisco IMC Firmware, on page 304](#)
- [Installing BIOS Firmware from a Remote Server, on page 306](#)
- [Activating Installed BIOS Firmware, on page 307](#)
- [Canceling a Pending BIOS Activation, on page 309](#)
- [Installing CMC Firmware from a Remote Server, on page 310](#)
- [Activating Installed CMC Firmware, on page 312](#)
- [Managing SAS Expander and HDD Firmware, on page 313](#)

## Overview of Firmware

C-Series servers use Cisco-certified firmware that is specific to the C-Series server model that you are using. You can download new releases of the firmware for all supported server models from Cisco.com.



---

**Note** If you choose to update the firmware of individual components, **you must first update and activate the CMC firmware** to the version that you want to update the individual component.

---



---

**Caution** When you install the new BIOS firmware, it must be from the same software release as the Cisco IMC firmware that is running on the server. Do not install the new BIOS firmware until after you have activated the matching Cisco IMC firmware or the server will not boot.

To avoid potential problems, we strongly recommend that you use the Cisco Host Upgrade Utility (HUU), which upgrades the BIOS, Cisco IMC, and other firmware to compatible levels. For detailed information about this utility, see the *Cisco Host Upgrade Utility Guide* for the version of the HUU that goes with the Cisco IMC software release that you want to install. The HUU guides are available at the following URL: [http://www.cisco.com/en/US/products/ps10493/products\\_user\\_guide\\_list.html](http://www.cisco.com/en/US/products/ps10493/products_user_guide_list.html).

---

If you want to update the firmware manually, you must update the Cisco IMC firmware first. The Cisco IMC firmware update process is divided into the following stages to minimize the amount of time that the server is offline:

- **Installation**—During this stage, Cisco IMC installs the selected Cisco IMC firmware in the nonactive, or backup, slot on the server.
- **Activation**—During this stage, Cisco IMC sets the nonactive firmware version as active, causing a disruption in service. When the server reboots, the firmware in the new active slot becomes the running version.

After you activate the Cisco IMC firmware, you can update the BIOS firmware.



#### Note

- You can either upgrade an older firmware version to a newer one, or downgrade a newer firmware version to an older one.
- This procedure only applies to the Cisco UCS C-Series server running on Stand-Alone mode. Contact Cisco Technical Assistance Center to upgrade firmware for UCS C-Series running on Cisco UCS Manager integrated mode.

Cisco IMC in a secure mode ensures that all the firmware images prior to loading and execution are digitally signed and are verified for authenticity and integrity to protect the device from running tampered software.

## Obtaining Firmware from Cisco

### Procedure

- Step 1** Navigate to <http://www.cisco.com>.
- Step 2** If you are not already logged in, click **Log In** at the top right-hand edge of the page and log in using your Cisco.com credentials.
- Step 3** In the menu bar at the top, click **Support**.
- Step 4** Click **All Downloads** in the roll down menu.
- Step 5** If your server model is listed in the **Recently Used Products** list, click the server name. Otherwise, do the following:
  - a) In the left-hand box, click **Products**.
  - b) In the center box, click **Unified Computing and Servers**.
  - c) In the right-hand box, click **Cisco UCS C-Series Rack-Mount Standalone Server Software**.
  - d) In the right-hand box, click the server model whose software you want to download.
- Step 6** Click the **Unified Computing System (UCS) Server Firmware** link.
- Step 7** (Optional) Select a prior release from the menu bar on the left-hand side of the page.
- Step 8** Click the **Download** button associated with the Cisco Host Upgrade Utility ISO for the selected release.
- Step 9** Click **Accept License Agreement**.
- Step 10** Save the ISO file to a local drive.

We recommend you upgrade the Cisco IMC and BIOS firmware on your server using this ISO file, which contains the Cisco Host Upgrade Utility. For detailed information about this utility, see the *Cisco Host Upgrade Utility Guide* for the version of the HUU that goes with the Cisco IMC software release that you want to install. The HUU guides are available at the following URL:  
[http://www.cisco.com/en/US/products/ps10493/products\\_user\\_guide\\_list.html](http://www.cisco.com/en/US/products/ps10493/products_user_guide_list.html).

**Step 11** (Optional) If you plan to upgrade the Cisco IMC and BIOS firmware manually, do the following:

Beginning with Release 3.0, the BIOS and Cisco IMC firmware files are no longer embedded inside the HUU as a standalone .zip file. BIOS and Cisco IMC firmware must now be extracted using the **getfw** utility, which is available in the GETFW folder of the HUU. Perform the following steps to extract the BIOS or Cisco IMC firmware files:

**Note** To perform this:

- Openssl must be installed in the target system.
- Squashfs kernel module must be loaded in the target system.

**Viewing the GETFW help menu:**

```
[root@RHEL65-***** tmp]# cd GETFW/
[root@RHEL65-***** GETFW]# ./getfw -h
Help:
Usage: getfw {-b -c -C -H -S -V -h} [-s SRC] [-d DEST]
-b      : Get BIOS Firmware
-c      : Get CIMC Firmware
-C      : Get CMC Firmware
-H      : Get HDD Firmware
-S      : Get SAS Firmware
-V      : Get VIC Firmware
-h      : Display Help
-s SRC  : Source of HUU ISO image
-d DEST : Destination to keep Firmware/s
Note : Default BIOS & CIMC get extracted
```

**Extracting the BIOS firmware:**

```
[root@RHEL65-***** GETFW]# ./getfw -s /root/Desktop/HUU/ucs-c2xxx-huu-3.0.1c.iso -d /tmp/HUU
FW/s available at '/tmp/HUUucs-c2xxx-huu-3.0.1c'
[root@RHEL65-***** GETFW]# cd /tmp/HUU/
[root@RHEL65-***** HUU]# cd ucs-c2xxx-huu-3.0.1c/
[root@RHEL65-***** ucs-c2xxx-huu-3.0.1c]# ls
bios  cimc
[root@RHEL65-***** ucs-c2xxx-huu-3.0.1c]# cd bios/
[root@RHEL65-***** bios]# ls
bios.cap
[root@RHEL65-***** bios]#
```

**Extracting the CIMC firmware:**

```
[root@RHEL65-***** GETFW]# ./getfw -s /root/Desktop/HUU/ucs-c2xxx-huu-3.0.1c.iso -d /tmp/HUU
FW/s available at '/tmp/HUUucs-c2xxx-huu-3.0.1c'
[root@RHEL65-***** GETFW]# cd /tmp/HUU/
[root@RHEL65-***** HUU]# cd ucs-c2xxx-huu-3.0.1c/
[root@RHEL65-***** ucs-c2xxx-huu-3.0.1c]# ls
bios  cimc
[root@RHEL65-***** ucs-c2xxx-huu-3.0.1c]# cd cimc/
[root@RHEL65-***** cimc]# ls
cimc.cap
[root@RHEL65-***** cimc]#
```

**Step 12** (Optional) If you plan to install the firmware from a remote server, copy the BIOS installation CAP file and the Cisco IMC installation BIN file to the remote server you want to use.

The remote server can be one of the following:

- TFTP
- FTP
- SFTP
- SCP
- HTTP

The server must have read permission for the destination folder on the remote server.

**Note** The Cisco UCS C-Series server now supports fingerprint confirmation of the server when you update firmware through a remote server. This option is available only if you choose SCP or SFTP as the remote server type.

If you chose SCP or SFTP as the remote server type while performing this action, a prompt with the message Server (RSA) key fingerprint is <server\_finger\_print\_ID> Do you wish to continue? Click y or n depending on the authenticity of the server fingerprint.

The fingerprint is based on the host's public key and helps you to identify or verify the host you are connecting to.

---

### What to do next

Use the Cisco Host Upgrade Utility to upgrade all firmware on the server or manually install the Cisco IMC firmware on the server.

## Installing Cisco IMC Firmware from a Remote Server

### Before you begin

- Log in to the Cisco IMC as a user with admin privileges.
- Activate the Cisco IMC firmware that goes with the BIOS version you want to install, as described in the **Activating Installed Cisco IMC Firmware** section.
- Power off the server.



---

**Note** You must not initiate a Cisco IMC update when another Cisco IMC update is already in progress.

---



**Procedure**

	<b>Command or Action</b>	<b>Purpose</b>
<b>Step 1</b>	Server /server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	server /server # <b>scope bmc</b>	Enters bmc command mode.
<b>Step 3</b>	server /server/bmc # <b>scope firmware</b>	Enters the firmware command mode.
<b>Step 4</b>	server /server/bmc/firmware # <b>update protocol</b> <i>IP Address path</i>	<p>Specifies the protocol, IP address of the remote server, and the file path to the firmware file on the server. The protocol can be one of the following:</p> <ul style="list-style-type: none"> <li>• TFTP</li> <li>• FTP</li> <li>• SFTP</li> <li>• SCP</li> <li>• HTTP</li> </ul> <p><b>Note</b> The Cisco UCS C-Series server now supports fingerprint confirmation of the server when you update firmware through a remote server. This option is available only if you choose SCP or SFTP as the remote server type.</p> <p>If you chose SCP or SFTP as the remote server type while performing this action, a prompt with the message Server (RSA) key fingerprint is &lt;server_finger_print_ID&gt; Do you wish to continue? Click y or n depending on the authenticity of the server fingerprint.</p> <p>The fingerprint is based on the host's public key and helps you to identify or verify the host you are connecting to.</p>
<b>Step 5</b>	(Optional) server /server/bmc/firmware # <b>show detail</b>	Displays the progress of the firmware update.

**Example**

This example shows how to update the Cisco IMC firmware:

```
server# scope server 1
server /server # scope bmc
```

```

server /server/bmc # scope firmware
server /server/bmc/firmware # update ftp 192.0.20.34 //test/dnld-ucs-k9-bundle.1.0.2h.bin
Firmware update has started.
Please check the status using "show detail"
server /server/bmc/firmware # show detail
Firmware Image Information:
  Update Stage: NONE
  Update Progress: 5
  Current FW Version: 2.0(6.56)
  FW Image 1 Version: 2.0(6.56)
  FW Image 1 State: RUNNING ACTIVATED
  FW Image 2 Version: 2.0(6.55)
  FW Image 2 State: BACKUP INACTIVATED
  Boot-loader Version: 2.0(6.56).36
  Secure Boot: ENABLED

server /server/bmc/firmware #

```

**What to do next**

Activate the new firmware.

# Activating Installed Cisco IMC Firmware

**Before you begin**

Install the Cisco IMC firmware on the server.

**Important**

p

While the activation is in progress, do not:

- Reset, power off, or shut down the server.
- Reboot or reset Cisco IMC.
- Activate any other firmware.
- Export technical support or configuration data.

**Procedure**

	Command or Action	Purpose
<b>Step 1</b>	Server /server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	server /server # <b>scope bmc</b>	Enters bmc command mode.
<b>Step 3</b>	server /server/bmc # <b>scope firmware</b>	Enters the firmware command mode.
<b>Step 4</b>	Server /server/bmc/firmware # <b>show detail</b>	Displays the available firmware images and statuses.

	Command or Action	Purpose
<b>Step 5</b>	Server /server/bmc/firmware # <b>activate</b>	Activates the selected image. If no image number is specified, the server activates the currently inactive image.
<b>Step 6</b>	At the prompt, enter <b>y</b> to activate the selected firmware image.	The BMC reboots, terminating all CLI and GUI sessions until the reboot completes.
<b>Step 7</b>	(Optional) Log back into the CLI and repeat steps 1–4 to verify the activation.	

### Example

This example activates firmware image 2 and then verifies the activation after the BMC reboots:

```
Server# scope server 1
Server/server# scope bmc
Server /server/bmc # scope firmware
Server /server/bmc/firmware # show detail
Firmware Image Information:
  Update Stage: NONE
  Update Progress: 100
  Current FW Version: 2.0(6.55)
  FW Image 1 Version: 2.0(6.56)
  FW Image 1 State: BACKUP INACTIVATED
  FW Image 2 Version: 2.0(6.55)
  FW Image 2 State: RUNNING ACTIVATED
  Boot-loader Version: 2.0(6.55).36
  Secure Boot: ENABLED
```

```
Server /server/bmc/firmware # activate
This operation will activate firmware 1 and reboot the BMC.
Continue?[y|N]y
.
.
-- BMC reboot --
.
.
-- Log into CLI as Admin --
```

```
Server# scope server 1
Server/server# scope bmc
Server /server/bmc # scope firmware
Server /server/bmc/firmware # show detail
Firmware Image Information:
  Update Stage: NONE
  Update Progress: 100
  Current FW Version: 2.0(6.55)
  FW Image 1 Version: 2.0(6.56)
  FW Image 1 State: RUNNING ACTIVATED
  FW Image 2 Version: 2.0(6.55)
  FW Image 2 State: BACKUP INACTIVATED
  Boot-loader Version: 2.0(6.55).36
  Secure Boot: ENABLED
Server /server/bmc/firmware #
```

# Installing BIOS Firmware from a Remote Server

## Before you begin

- Log in to the Cisco IMC as a user with admin privileges.
- Activate the Cisco IMC firmware that goes with the BIOS version you want to install, as described in the **Activating Installed BIOS Firmware** section.
- Power off the server.



**Note** You must not initiate a BIOS update while another BIOS update is already in progress.

## Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server /server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	server /server # <b>scope bios</b>	Enters BIOS command mode.
<b>Step 3</b>	server /server/bios # <b>update protocol IP Address pathrecovery</b>	Specifies the protocol, IP address of the remote server, and the file path to the firmware file on the server. The protocol can be one of the following: <ul style="list-style-type: none"> <li>• TFTP</li> <li>• FTP</li> <li>• SFTP</li> <li>• SCP</li> <li>• HTTP</li> </ul>

	Command or Action	Purpose
		<p><b>Note</b> The Cisco UCS C-Series server now supports fingerprint confirmation of the server when you update firmware through a remote server. This option is available only if you choose SCP or SFTP as the remote server type.</p> <p>If you chose SCP or SFTP as the remote server type while performing this action, a prompt with the message Server (RSA) key fingerprint is &lt;server_finger_print_ID&gt; Do you wish to continue? Click y or n depending on the authenticity of the server fingerprint.</p> <p>The fingerprint is based on the host's public key and helps you to identify or verify the host you are connecting to.</p>
<b>Step 4</b>	(Optional) server /server/bios # <b>show detail</b>	Displays the progress of the firmware update.

### Example

This example updates the BIOS firmware to Cisco IMC software release 2.0(7c):

```

Server# scope server 1
Server /server# scope bios
Server /server/bios# show detail
BIOS:
  BIOS Version: server-name.2.0.7c.0.071620151216
  Backup BIOS Version: server-name.2.0.7c.0.071620151216
  Boot Order: (none)
  Boot Override Priority:
  FW Update/Recovery Status: None, OK
  UEFI Secure Boot: disabled
  Configured Boot Mode: Legacy
  Actual Boot Mode: Legacy
  Last Configured Boot Order Source: CIMC
Server /server/bios # update ftp 192.0.20.34 //upgrade_bios_files/C3620-BIOS-2-0-7c-0.CAP
<CR> Press Enter key
Firmware update has started.
Check the status using "show detail"
Server /bios #

```

## Activating Installed BIOS Firmware

### Before you begin

- Install the BIOS firmware on the server.

- Power off the host.



**Important** While the activation is in progress, do not:

- Reset, power off, or shut down the server.
- Reboot or reset Cisco IMC.
- Activate any other firmware.
- Export technical support or configuration data.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server /server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	server /server # <b>scope bios</b>	Enters BIOS command mode.
<b>Step 3</b>	Server /server/bios # <b>activate</b>	Activates the currently inactive image.
<b>Step 4</b>	At the prompt, enter <b>y</b> to activate the selected firmware image.	Initiates the activation.

### Example

This example activates firmware and then verifies the activation:

```
Server# scope server 1
Server /server# scope bios
Server /server/bios# show detail
BIOS:
  BIOS Version: server-name.2.0.7c.0.071620151216
  Backup BIOS Version: server-name.2.0.7c.0.071620151216
  Boot Order: (none)
  Boot Override Priority:
  FW Update/Recovery Status: None, OK
  UEFI Secure Boot: disabled
  Configured Boot Mode: Legacy
  Actual Boot Mode: Legacy
  Last Configured Boot Order Source: CIMC

Server /server/bios # activate
This operation will activate "C240M4.2.0.2.66.071820142034" after next host power off
Continue?[y|N]

Server# scope server 1
Server /server# scope bios
Server /server/bios# show detail
BIOS:
  BIOS Version: server-name.2.0.7c.0.071620151216
  Backup BIOS Version: server-name.2.0.7c.0.071620151216
  Boot Order: (none)
  Boot Override Priority:
  FW Update/Recovery Status: None, OK
```

```

UEFI Secure Boot: disabled
Configured Boot Mode: Legacy
Actual Boot Mode: Legacy
Last Configured Boot Order Source: CIMC

```

## Canceling a Pending BIOS Activation

### Before you begin

BIOS firmware must be in pending state.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope bios</b>	Enters the BIOS command mode.
<b>Step 2</b>	Server /bios # <b>show detail</b>	Displays the available firmware images and status.
<b>Step 3</b>	Server /bios # <b>cancel-activate</b>	<b>Note</b> BIOS firmware must be in pending state.  Cancel the BIOS activation that is pending.
<b>Step 4</b>	At the prompt, enter <b>y</b> to cancel activation.	

### Example

This example cancels a pending BIOS firmware activation:

```

Server# scope bios
Server /bios # show detail
BIOS:
  BIOS Version: Cxxx.4.0.0.19.0528180450
  Backup BIOS Version: Cxxx.4.0.0.23.0612180433
  Boot Order: (none)
  FW Update Status: Done, Activation pending
  UEFI Secure Boot: disabled
  Actual Boot Mode: Uefi
  Last Configured Boot Order Source: BIOS
  One time boot device: (none)
Server /bios # cancel-activate
This will cancel Pending BIOS activation[y|N]y
Server /bios # show detail
BIOS:
  BIOS Version: Cxxx.4.0.0.19.0528180450
  Backup BIOS Version: Cxxx.4.0.0.23.0612180433
  Boot Order: (none)
  FW Update Status: None, OK
  UEFI Secure Boot: disabled
  Actual Boot Mode: Uefi
  Last Configured Boot Order Source: BIOS

```

```

One time boot device: (none)
Server /bios #

```

## Installing CMC Firmware from a Remote Server



**Note** You must not initiate a CMC update while another CMC update is already in progress.

### Before you begin

- Log in to the Cisco IMC as a user with admin privileges.
- Obtain the Cisco Host Upgrade Utility ISO file from Cisco.com and extract the firmware installation files as described in [Obtaining Firmware from Cisco, on page 300](#).

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	server /chassis # <b>scope cmc 1 2</b>	Enters CMC on the chosen SIOC controller command mode.
<b>Step 3</b>	server /chassis/cmc # <b>update protocol IP Address path</b>	Specifies the protocol, IP address of the remote server, and the file path to the firmware file on the server. The protocol can be one of the following: <ul style="list-style-type: none"> <li>• TFTP</li> <li>• FTP</li> <li>• SFTP</li> <li>• SCP</li> <li>• HTTP</li> </ul>



	Command or Action	Purpose
		<p><b>Note</b> The Cisco UCS C-Series server now supports fingerprint confirmation of the server when you update firmware through a remote server. This option is available only if you choose SCP or SFTP as the remote server type.</p> <p>If you chose SCP or SFTP as the remote server type while performing this action, a prompt with the message Server (RSA) key fingerprint is &lt;server_finger_print_ID&gt; Do you wish to continue? Click y or n depending on the authenticity of the server fingerprint.</p> <p>The fingerprint is based on the host's public key and helps you to identify or verify the host you are connecting to.</p>
<b>Step 4</b>	(Optional) server /chassis/cmc # <b>show detail</b>	Displays the progress of the firmware update.

### Example

This example shows how to update the CMC firmware:

```
server # scope chassis
server /chassis # scope cmc 1
server /chassis/cmc # update http 10.104.236.99 colusa2_cmc.2.0.7a.img
CMC Firmware update initialized.
Please check the status using "show detail"
Server /chassis/cmc # show detail
Firmware Image Information:
  Name: CMC1
  Update Stage: DOWNLOAD
  Update Progress: 25
  Current FW Version: 2.0(7a)
  FW Image 1 Version: 2.0(7a)
  FW Image 1 State: RUNNING ACTIVATED
  FW Image 2 Version: 2.0(7a)
  FW Image 2 State: BACKUP INACTIVATED
server /chassis/cmc #
```

### What to do next

Activate the new firmware.

# Activating Installed CMC Firmware



**Note** CMCs are configured to have one in an active state while other acts as a backup, when you activate the backup CMC the previously active CMC changes to backup CMC activating the other.

## Before you begin

Install the CMC firmware on the server.



## Important

While the activation is in progress, do not:

- Reset, power off, or shut down the server.
  - Reboot or reset Cisco IMC.
  - Activate any other firmware.
  - Export technical support or configuration data.
- 
- CMC-1 activation interrupts Cisco IMC network connectivity.

## Procedure

	Command or Action	Purpose
<b>Step 1</b>	server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server# <b>scope cmc</b>   2	Enters the CMC of the chosen SIOC slot command mode.
<b>Step 3</b>	Server /cmc # <b>activate</b>	Activates the selected image for the chosen CMC.
<b>Step 4</b>	At the prompt, enter <b>y</b> to activate the selected firmware image.	The CMC-1 reboots, terminating all CLI and GUI sessions until the reboot completes, but CMC-2 reboot will not affect any active sessions.

## Example

This example activates CMC firmware on the SIOC slot 1:

```
Server # scope chassis
Server /chassis # scope cmc 1
Server /chassis/cmc # activate
Warning: The CMC will be rebooted immediately to complete the activation.
```

The network may go down temporarily till CMC boots up again  
Continue?[y|N]y

# Managing SAS Expander and HDD Firmware

## Updating and Activating SAS Expander Firmware

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope sas-expandersas expander ID</b>	Enters SAS expander mode.
<b>Step 3</b>	Server /chassis/sas-expander # <b>update protocol IP Address path</b>	<p>Initiates the firmware update by specifying the protocol, IP address of the remote server, and the file path to the firmware file on the server. The protocol can be one of the following:</p> <ul style="list-style-type: none"> <li>• TFTP</li> <li>• FTP</li> <li>• SFTP</li> <li>• SCP</li> <li>• HTTP</li> </ul> <p><b>Note</b> The Cisco UCS C-Series server now supports fingerprint confirmation of the server when you update firmware through a remote server. This option is available only if you choose SCP or SFTP as the remote server type.</p> <p>If you chose SCP or SFTP as the remote server type while performing this action, a prompt with the message Server (RSA) key fingerprint is &lt;server_finger_print_ID&gt; Do you wish to continue? Click y or n depending on the authenticity of the server fingerprint.</p> <p>The fingerprint is based on the host's public key and helps you to identify or verify the host you are connecting to.</p>

	Command or Action	Purpose
<b>Step 4</b>	(Optional) Server /chassis/sas-expander # <b>show detail</b>	Displays the status of the firmware upgrade.

### Example

This example shows how to update and activate the SAS expander firmware:

```
Server# scope chassis
Server /chassis # scope sas-expander 1
Updating the firmware
Server /chassis/sas-expander# update tftp 10.10.10.10 /tftpboot/skasargo/<firmware file>
updating the firmware.
Checking the status of the upgrade
Server /chassis/sas-expander# show detail
Firmware Image Information:
  ID: 1
  Name: SASEXP1
  Update Stage: In Progress
  Update Progress: 25
  Current FW Version: 04.08.01_B056
  FW Image 1 Version: 04.08.01_B056
  FW Image 1 State: RUNNING ACTIVATED
  FW Image 2 Version: 04.08.01_B056
  FW Image 2 State: BACKUP INACTIVATED

Activating the firmware
svbu-huu-sanity-col2-1-vmc /chassis/sas-expander # activate
This operation will activate backup firmware and reboot the SAS-Expander.
Continue?[y|N]y

Server /chassis/sas-expander #
```

## Updating HDD Firmware

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis/dynamic-storage # <b>scope dynamic-storage</b>	Enters dynamic storage command mode.
<b>Step 3</b>	Server /chassis/dynamic-storage # <b>update-drive</b> <i>protocol IP Address path HDD slot-ids</i>	Specifies the protocol, IP address of the remote server, and the file path to the firmware file on the server. The protocol can be one of the following: <ul style="list-style-type: none"> <li>• TFTP</li> <li>• FTP</li> <li>• SFTP</li> <li>• SCP</li> </ul>

	Command or Action	Purpose
		<ul style="list-style-type: none"> <li>• HTTP</li> </ul> <p><b>Note</b> The Cisco UCS C-Series server now supports fingerprint confirmation of the server when you update firmware through a remote server. This option is available only if you choose SCP or SFTP as the remote server type.</p> <p>If you chose SCP or SFTP as the remote server type while performing this action, a prompt with the message Server (RSA) key fingerprint is &lt;server_finger_print_ID&gt; Do you wish to continue? Click y or n depending on the authenticity of the server fingerprint.</p> <p>The fingerprint is based on the host's public key and helps you to identify or verify the host you are connecting to.</p> <p><b>Note</b> You can update firmware for multiple servers from the same vendor.</p>
<b>Step 4</b>	(Optional) Server /chassis/dynamic-storage # <b>show physical-drive-fw</b>	Displays the status of the firmware upgrade.

### Example

This example provides steps to update the HDD firmware:

```

Server# scope chassis
Server /chassis # scope dynamic-storage
Updating for a single HDD
Server /chassis/dynamic-storage #update-drive tftp 10.10.10.10 /tftpboot/skasargo/sg4.1od
14
updating FW for slot 1 HDD
Updating for Multiple HDD
Server /chassis/dynamic-storage#update-drive tftp 10.10.10.10 /tftpboot/skasargo/sg4.1od
1-14
updating fw for multiple HDDs
Viewing the Status of the Upgrade
Server /chassis/dynamic-storage# show physical-drive-fw

```

Slot	Vendor	Product ID	Current_FW	Update Stage	Update Progress
1	TOSHIBA	MG03SCA400	5702	Progress	25
2	TOSHIBA	MG03SCA400	5702	NONE	0
3	TOSHIBA	MG03SCA400	5702	NONE	0
4	TOSHIBA	MG03SCA400	5702	NONE	0
5	TOSHIBA	MG03SCA400	5702	NONE	0

```
6      TOSHIBA  MG03SCA400      5702      NONE      0
7      TOSHIBA  MG03SCA400      5702      NONE      0
8      TOSHIBA  MG03SCA400      5702      NONE      0
9      TOSHIBA  MG03SCA400      5702      NONE      0
10     TOSHIBA  MG03SCA400      5702      NONE      0
11     TOSHIBA  MG03SCA400      5702      NONE      0
12     TOSHIBA  MG03SCA400      5702      NONE      0
13     TOSHIBA  MG03SCA400      5702      NONE      0
14     TOSHIBA  MG03SCA400      5702      NONE      0
Server /chassis/dynamic-storage #
```



# CHAPTER 16

## Viewing Faults and Logs

This chapter includes the following sections:

- [Fault Summary, on page 317](#)
- [Fault History, on page 318](#)
- [Cisco IMC Log, on page 318](#)
- [System Event Log, on page 322](#)
- [Logging Controls, on page 325](#)

## Fault Summary

### Viewing the Faults and Logs Summary

#### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope fault</b>	Enters fault command mode.
<b>Step 2</b>	Server # <b>show fault-entries</b>	Displays a log of all the faults.

#### Example

This example displays a summary of faults:

```
Server # scope fault
Server /fault # show fault-entries

Time                Severity          Distinguished Name (DN)
-----
2015-08-18T06:44:02  major            sys/chassis-1/server-2/board/memarray-1/mem-2
2015-08-18T06:43:48  major            sys/chassis-1/server-2/board/memarray-1/mem-1

Description
-----
"DDR3_P1_A2_ECC: DIMM 2 is inoperable : Check or replace DIMM"
"DDR3_P1_A1_ECC: DIMM 1 is inoperable : Check or replace DIMM"
```

```
Server /fault #
```

## Fault History

### Viewing the Fault History

#### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope fault</b>	Enters fault command mode.
<b>Step 2</b>	Server # <b>show fault-history</b>	Displays the faults' history.

#### Example

This example displays the faults' history:

```
Server # scope fault
Server /fault # show fault-history
Time                Severity  Source  Cause                Description
-----
2014 Feb 6 23:24:49 error      %CIMC   PSU_REDUNDANCY-FAIL
"[F0743][major][psu-redundancy-fail]....
2014 Feb 6 23:24:49 error      %CIMC   EQUIPMENT_INOPERABLE
"[F0374][major][equipment-inoperable]...
2014 Feb 6 23:24:19 debug      %CIMC   2014 Feb 6 23      "24:19:7:%CIMC::: SEL INIT DONE"
```

```
Server /fault #
```

## Cisco IMC Log

### Viewing Cisco IMC Log

#### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope log</b>	Enters log command mode.
<b>Step 3</b>	Server /chassis/log # <b>show entries detail</b>	Displays the CMC trace log details.



**Example**

This example displays the CMC trace log details:

```
Server# scope chassis
Server /chassis # scope log
Server /chassis/log # show entries detail
Trace Log:
    Time: 2015 Jul 26 06:35:15
    Severity: Notice
    Source: CMC:dropbear:19566
    Description: PAM password auth succeeded for 'cli' from 10.127.148.234:53791
    Order: 0
Trace Log:
    Time: 2015 Jul 26 06:35:15
    Severity: Notice
    Source: CMC:AUDIT:19566
    Description: Session open (user:admin, ip:10.127.148.234, id:6, type:CLI)
    Order: 1
Trace Log:
    Time: 2015 Jul 26 06:35:15
    Severity: Informational
    Source: CMC:dropbear:19566
    Description: " pam_session_manager(sshd:session): session (6) opened for user admin
from 10.127.148.234 by (uid=0) "
    Order: 2
Trace Log:
    Time: 2015 Jul 26 06:35:15
    Severity: Notice
    Source: CMC:AUDIT:1779
.
.
.
Server /chassis/log #
```

## Clearing Trace Logs

**Procedure**

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope log</b>	Enters the log command mode.
<b>Step 3</b>	Server /chassis/log # <b>clear</b>	Clears the trace log.

**Example**

The following example clears the log of trace logs:

```
Server# scope chassis
Server /chassis # scope log
Server /chassis/log # clear
```

```
Server /chassis/log #
```

## Configuring the Cisco IMC Log Threshold

You can specify the lowest level of messages that will be included in the syslog log.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope log</b>	Enters log command mode.
<b>Step 3</b>	Server /chassis/log # <b>set local-syslog-severity level</b>	<p>The severity <i>level</i> can be one of the following, in decreasing order of severity:</p> <ul style="list-style-type: none"> <li>• emergency</li> <li>• alert</li> <li>• critical</li> <li>• error</li> <li>• warning</li> <li>• notice</li> <li>• informational</li> <li>• debug</li> </ul> <p><b>Note</b> Cisco IMC does not log any messages with a severity below the selected severity. For example, if you select <b>error</b>, then the Cisco IMC log will contain all messages with the severity Emergency, Alert, Critical, or Error. It will not show Warning, Notice, Informational, or Debug messages.</p>
<b>Step 4</b>	Server /chassis/log # <b>set remote-syslog-severity level</b>	<p>The severity <i>level</i> can be one of the following, in decreasing order of severity:</p> <ul style="list-style-type: none"> <li>• emergency</li> <li>• alert</li> <li>• critical</li> <li>• error</li> <li>• warning</li> </ul>

	Command or Action	Purpose
		<ul style="list-style-type: none"> <li>• notice</li> <li>• informational</li> <li>• debug</li> </ul> <p><b>Note</b> Cisco IMC does not log any messages with a severity below the selected severity. For example, if you select <b>error</b>, then the Cisco IMC log will contain all messages with the severity Emergency, Alert, Critical, or Error. It will not show Warning, Notice, Informational, or Debug messages.</p>
<b>Step 5</b>	Server /chassis/log # <b>commit</b>	Commits the transaction to the system configuration.
<b>Step 6</b>	(Optional) Server /chassis/log # <b>show</b>	Displays the configured severity level.

### Example

This example shows how to configure the logging of messages with a minimum severity of Debug for the local syslogs and error for the remote syslog:

```
Server# scope chassis
Server /chassis # scope log
Server /chassis/log # set local-syslog-severity debug
Server /chassis/log # set remote-syslog-severity error
Server /chassis/log *# commit
Server /chassis/log # show
Local Syslog Severity Remote Syslog Severity
-----
debug                  error

Server /chassis/log #
```

## Sending the Cisco IMC Log to a Remote Server

You can configure profiles for one or two remote syslog servers to receive system log entries.

### Before you begin

- The remote syslog server must be configured to receive logs from a remote host.
- The remote syslog server must be configured to receive all types of logs, including authentication-related logs.
- The remote syslog server's firewall must be configured to allow syslog messages to reach the syslog server.

**Procedure**

	<b>Command or Action</b>	<b>Purpose</b>
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope log</b>	Enters log command mode.
<b>Step 3</b>	Server /chassis/log # <b>scope server {1   2}</b>	Selects one of the two remote syslog server profiles and enters the command mode for configuring the profile.
<b>Step 4</b>	Server /chassis/log/server # <b>set server-ip</b> <i>ipv4 or ipv6 address or domain name</i>	Specifies the remote syslog server address. <b>Note</b> You can set an IPv4 or IPv6 address or a domain name as the remote server address.
<b>Step 5</b>	Server /chassis/log/server # <b>set server-port</b> <i>port number</i>	Sets the destination port number of the remote syslog server.
<b>Step 6</b>	Server /chassis/log/server # <b>set enabled {yes   no}</b>	Enables the sending of system log entries to this syslog server.
<b>Step 7</b>	Server /chassis/log/server # <b>commit</b>	Commits the transaction to the system configuration.
<b>Step 8</b>	Server /chassis/log/server # <b>exit</b>	Exits to the log command mode.
<b>Step 9</b>	Server /chassis/log/server # <b>showserver</b>	Exits to the log command mode.

**Example**

This example shows how to configure a remote syslog server profile and enable the sending of system log entries:

# System Event Log

## Viewing the System Event Log

**Procedure**

	<b>Command or Action</b>	<b>Purpose</b>
<b>Step 1</b>	Server# <b>scope sel</b>	Enters the system event log (SEL) command mode.
<b>Step 2</b>	Server /sel # <b>show entries [detail]</b>	For system events, displays timestamp, the severity of the event, and a description of the

	Command or Action	Purpose
		event. The <b>detail</b> keyword displays the information in a list format instead of a table format.

### Example

This example displays the system event log:

```
Server# scope sel
Server /sel # show entries
Time                Severity      Description
-----
[System Boot]       Informational " LED_PSU_STATUS: Platform sensor, OFF event was asserted"

[System Boot]       Informational " LED_HLTH_STATUS: Platform sensor, GREEN was asserted"
[System Boot]       Normal        " PSU_REDUNDANCY: PS Redundancy sensor, Fully Redundant
was asserted"
[System Boot]       Normal        " PSU2 PSU2_STATUS: Power Supply sensor for PSU2, Power
Supply input lost (AC/DC) was deasserted"
[System Boot]       Informational " LED_PSU_STATUS: Platform sensor, ON event was asserted"

[System Boot]       Informational " LED_HLTH_STATUS: Platform sensor, AMBER was asserted"
[System Boot]       Critical      " PSU_REDUNDANCY: PS Redundancy sensor, Redundancy Lost
was asserted"
[System Boot]       Critical      " PSU2 PSU2_STATUS: Power Supply sensor for PSU2, Power
Supply input lost (AC/DC) was asserted"
[System Boot]       Normal        " HDD_01_STATUS: Drive Slot sensor, Drive Presence was
asserted"
[System Boot]       Critical      " HDD_01_STATUS: Drive Slot sensor, Drive Presence was
deasserted"
[System Boot]       Informational " DDR3_P2_D1_INFO: Memory sensor, OFF event was asserted"

2001-01-01 08:30:16 Warning      " PSU2 PSU2_VOUT: Voltage sensor for PSU2, failure event
was deasserted"
2001-01-01 08:30:16 Critical      " PSU2 PSU2_VOUT: Voltage sensor for PSU2, non-recoverable
event was deasserted"
2001-01-01 08:30:15 Informational " LED_PSU_STATUS: Platform sensor, ON event was asserted"

2001-01-01 08:30:15 Informational " LED_HLTH_STATUS: Platform sensor, AMBER was asserted"
2001-01-01 08:30:15 Informational " LED_HLTH_STATUS: Platform sensor, FAST BLINK event was
asserted"
2001-01-01 08:30:14 Non-Recoverable " PSU2 PSU2_VOUT: Voltage sensor for PSU2, non-recoverable
event was asserted"
2001-01-01 08:30:14 Critical      " PSU2 PSU2_VOUT: Voltage sensor for PSU2, failure event
was asserted"
--More--
```

## Viewing the System Event Log for Servers

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope server</b> {1   2 }	Enters the server mode for server 1 or 2.

	Command or Action	Purpose
<b>Step 2</b>	Server /server # <b>scope sel</b>	Enters the system event log (SEL) command mode.
<b>Step 3</b>	Server /server/sel # <b>show entries [detail]</b>	For system events, displays timestamp, the severity of the event, and a description of the event. The <b>detail</b> keyword displays the information in a list format instead of a table format.

### Example

This example displays the system event log:

```

Server # scope server 1
Server/server # scope sel
Server /server/sel # show entries
Time                Severity  Description
-----
2015-08-18 08:46:03 Normal    "BIOS_POST_CMPLT: Presence sensor, Device Inserted / Device
Present was asserted"
2015-08-18 08:46:00 Normal    "System Software event: System Event sensor, OEM System Boot
Event was asserted"
2010-03-21 00:17:42 Normal    "System Software event: System Event sensor, Timestamp Clock
Synch (second of pair) was asserted"
2015-08-18 08:44:34 Normal    "System Software event: System Event sensor, Timestamp Clock
Synch (first of pair) was asserted"
2015-08-18 08:44:00 Normal    "BIOS_POST_CMPLT: Presence sensor, Device Removed / Device
Absent was asserted"
2015-08-18 08:44:00 Normal    "MAIN_POWER_PRS: Presence sensor, Device Inserted / Device
Present was asserted"
2015-08-18 08:43:39 Normal    "MAIN_POWER_PRS: Presence sensor, Device Removed / Device
Absent was asserted"
2015-08-18 08:16:18 Normal    "BIOS_POST_CMPLT: Presence sensor, Device Inserted / Device
Present was asserted"
2015-08-18 08:16:16 Normal    "System Software event: System Event sensor, OEM System Boot
Event was asserted"
2010-03-20 23:47:59 Normal    "System Software event: System Event sensor, Timestamp Clock
Synch (second of pair) was asserted"
2015-08-18 08:14:50 Normal    "System Software event: System Event sensor, Timestamp Clock
Synch (first of pair) was asserted"
2015-08-18 08:14:20 Normal    "BIOS_POST_CMPLT: Presence sensor, Device Removed / Device
Absent was asserted"
2015-08-18 08:14:20 Normal    "MAIN_POWER_PRS: Presence sensor, Device Inserted / Device
Present was asserted"
2015-08-18 08:13:44 Normal    "MAIN_POWER_PRS: Presence sensor, Device Removed / Device
Absent was asserted"
2015-08-18 08:12:57 Normal    "FRU_RAM_SEL_FULLNESS: Event Log sensor for FRU_RAM, Log Area
Reset/Cleared was asserted"

```

## Clearing the System Event Log

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope sel</b>	Enters the system event log command mode.
<b>Step 2</b>	Server /sel # <b>clear</b>	You are prompted to confirm the action. If you enter <b>y</b> at the prompt, the system event log is cleared.

### Example

This example clears the system event log:

```
Server# scope sel
Server /sel # clear
This operation will clear the whole sel.
Continue?[y|N]y
```

## Logging Controls

### Configuring the Cisco IMC Log Threshold

You can specify the lowest level of messages that will be included in the syslog log.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope log</b>	Enters log command mode.
<b>Step 3</b>	Server /chassis/log # <b>set local-syslog-severity level</b>	The severity <i>level</i> can be one of the following, in decreasing order of severity: <ul style="list-style-type: none"> <li>• emergency</li> <li>• alert</li> <li>• critical</li> <li>• error</li> <li>• warning</li> <li>• notice</li> <li>• informational</li> </ul>

	Command or Action	Purpose
		<ul style="list-style-type: none"> <li>• debug</li> </ul> <p><b>Note</b> Cisco IMC does not log any messages with a severity below the selected severity. For example, if you select <b>error</b>, then the Cisco IMC log will contain all messages with the severity Emergency, Alert, Critical, or Error. It will not show Warning, Notice, Informational, or Debug messages.</p>
<b>Step 4</b>	Server /chassis/log # <b>set remote-syslog-severity level</b>	<p>The severity <i>level</i> can be one of the following, in decreasing order of severity:</p> <ul style="list-style-type: none"> <li>• emergency</li> <li>• alert</li> <li>• critical</li> <li>• error</li> <li>• warning</li> <li>• notice</li> <li>• informational</li> <li>• debug</li> </ul> <p><b>Note</b> Cisco IMC does not log any messages with a severity below the selected severity. For example, if you select <b>error</b>, then the Cisco IMC log will contain all messages with the severity Emergency, Alert, Critical, or Error. It will not show Warning, Notice, Informational, or Debug messages.</p>
<b>Step 5</b>	Server /chassis/log # <b>commit</b>	Commits the transaction to the system configuration.
<b>Step 6</b>	(Optional) Server /chassis/log # <b>show</b>	Displays the configured severity level.

### Example

This example shows how to configure the logging of messages with a minimum severity of Debug for the local syslogs and error for the remote syslog:



```

Server# scope chassis
Server /chassis # scope log
Server /chassis/log # set local-syslog-severity debug
Server /chassis/log # set remote-syslog-severity error
Server /chassis/log *# commit
Server /chassis/log # show
Local Syslog Severity  Remote Syslog Severity
-----
debug                  error

Server /chassis/log #

```

## Sending the Cisco IMC Log to a Remote Server

You can configure profiles for one or two remote syslog servers to receive system log entries.

### Before you begin

- The remote syslog server must be configured to receive logs from a remote host.
- The remote syslog server must be configured to receive all types of logs, including authentication-related logs.
- The remote syslog server's firewall must be configured to allow syslog messages to reach the syslog server.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope log</b>	Enters log command mode.
<b>Step 3</b>	Server /chassis/log # <b>scope server {1   2}</b>	Selects one of the two remote syslog server profiles and enters the command mode for configuring the profile.
<b>Step 4</b>	Server /chassis/log/server # <b>set server-ip</b> <i>ipv4 or ipv6 address or domain name</i>	Specifies the remote syslog server address. <b>Note</b> You can set an IPv4 or IPv6 address or a domain name as the remote server address.
<b>Step 5</b>	Server /chassis/log/server # <b>set server-port</b> <i>port number</i>	Sets the destination port number of the remote syslog server.
<b>Step 6</b>	Server /chassis/log/server # <b>set enabled {yes   no}</b>	Enables the sending of system log entries to this syslog server.
<b>Step 7</b>	Server /chassis/log/server # <b>commit</b>	Commits the transaction to the system configuration.
<b>Step 8</b>	Server /chassis/log/server # <b>exit</b>	Exits to the log command mode.

	Command or Action	Purpose
<b>Step 9</b>	Server /chassis/log/server # <b>showserver</b>	Exits to the log command mode.

### Example

This example shows how to configure a remote syslog server profile and enable the sending of system log entries:

## Sending a Test Cisco IMC Log to a Remote Server

### Before you begin

- The remote syslog server must be configured to receive logs from a remote host.
- The remote syslog server must be configured to receive all types of logs, including authentication-related logs.
- The remote syslog server's firewall must be configured to allow syslog messages to reach the syslog server.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope log</b>	Enters log command mode.
<b>Step 3</b>	Server /chassis/log # <b>send-test-syslog</b>	Sends a test log to the remote server.

### Example

This example shows how send a test log to a remote server:



# CHAPTER 17

## Server Utilities

This chapter includes the following sections:

- [Exporting Technical Support Data, on page 329](#)
- [Rebooting the Cisco IMC, on page 332](#)
- [Clearing the BIOS CMOS, on page 332](#)
- [Resetting the BMC to factory Defaults, on page 333](#)
- [Resetting to Factory Defaults, on page 334](#)
- [Resetting to Factory Defaults, on page 336](#)
- [Exporting and Importing the Cisco IMC and BMC Configuration, on page 338](#)
- [Generating Non-Maskable Interrupts to the Host, on page 347](#)
- [Adding Cisco IMC Banner, on page 348](#)
- [Downloading and Viewing Inventory Details, on page 349](#)

## Exporting Technical Support Data

Perform this task when requested by the Cisco Technical Assistance Center (TAC). This utility creates a summary report containing configuration information, logs and diagnostic data that will help TAC in troubleshooting and resolving a technical issue.



### Important

If any firmware or BIOS updates are in progress, do not export the technical support data until those tasks are complete.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope tech-support</b>	Enters the tech-support command mode.
<b>Step 3</b>	Server /chassis/tech-support # <b>set collect-from</b> { <b>all</b>   <b>cmc</b>   <b>peercmc</b>   <b>bmc1</b>   <b>bmc2</b> }	Specifies the component for which the technical support data has to be exported.

	Command or Action	Purpose
<b>Step 4</b>	Server /chassis/tech-support # <b>set remote-ip</b> <i>ip-address</i>	Specifies the IP address of the remote server on which the technical support data file should be stored.
<b>Step 5</b>	Server /chassis/tech-support # <b>set remote-path</b> <i>path/filename</i>	Specifies the file name in which the support data should be stored on the remote server. When you enter this name, include the relative path for the file from the top of the server tree to the desired location.  <b>Tip</b> To have the system auto-generate the file name, enter the file name as <b>default.tar.gz</b> .
<b>Step 6</b>	Server /chassis/tech-support # <b>set remote-protocol</b> <i>protocol</i>	Specifies the protocol to connect to the remote server. It can be of the following types: <ul style="list-style-type: none"> <li>• TFTP</li> <li>• FTP</li> <li>• SFTP</li> <li>• SCP</li> <li>• HTTP</li> </ul> <b>Note</b> The Cisco UCS C-Series server now supports fingerprint confirmation of the server when you update firmware through a remote server. This option is available only if you choose SCP or SFTP as the remote server type.  If you chose SCP or SFTP as the remote server type while performing this action, a prompt with the message Server (RSA) key fingerprint is <server_finger_print_ID> Do you wish to continue? Click y or n depending on the authenticity of the server fingerprint.  The fingerprint is based on the host's public key and helps you to identify or verify the host you are connecting to.
<b>Step 7</b>	Server /chassis/tech-support # <b>set remote-username</b> <i>name</i>	Specifies the user name on the remote server on which the technical support data file should

	Command or Action	Purpose
		be stored. This field does not apply if the protocol is TFTP or HTTP.
<b>Step 8</b>	Server /chassis/tech-support # <b>set remote-password</b> <i>password</i>	Specifies the password on the remote server on which the technical support data file should be stored. This field does not apply if the protocol is TFTP or HTTP.
<b>Step 9</b>	Server /chassis/tech-support # <b>commit</b>	Commits the transaction to the system configuration.
<b>Step 10</b>	Server /chassis/tech-support # <b>start</b>	Begins the transfer of the data file to the remote server.
<b>Step 11</b>	(Optional) Server /chassis/tech-support # <b>show detail</b>	Displays the progress of the transfer of the data file to the remote server.
<b>Step 12</b>	(Optional) Server /chassis/tech-support # <b>cancel</b>	Cancels the transfer of the data file to the remote server.

### Example

This example creates a technical support data file and transfers the file to a TFTP server:

```
Server# scope chassis
Server /chassis # scope tech-support
Server /chassis/tech-support # set collect-from all
Server /chassis/tech-support* # set remote-ip 192.0.20.41
Server /chassis/tech-support* # set remote-protocol tftp
Server /chassis/tech-support *# set remote-path /user/user1/default.tar.gz
Server /chassis/tech-support *# commit
Server /chassis/tech-support # start
Tech Support upload started.

Server /chassis/tech-support # show detail

Tech Support:
  Server Address: 192.0.20.41
    Path('default' for auto-naming): default.tar.gz
    Protocol: tftp
    Username:
    Password: *****
    Collect from: all
    Progress(%): 100
    Status: COMPLETED

Server /chassis/tech-support #
```

### What to do next

Provide the generated report file to Cisco TAC.

## Rebooting the Cisco IMC

On rare occasions, such as an issue with the current running firmware, troubleshooting a server may require you to reboot the Cisco IMC. This procedure is not part of the normal maintenance of a server. After you reboot the Cisco IMC, you are logged off and the Cisco IMC will be unavailable for a few minutes.



**Note** If you reboot the Cisco IMC while the server is performing power-on self test (POST) or is operating in the Extensible Firmware Interface (EFI) shell, the server will be powered down until the Cisco IMC reboot is complete.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /server # <b>scope bmc</b>	Enters bmc command mode.
<b>Step 3</b>	Server /server/bmc # <b>reboot</b>	The Cisco IMC reboots.

### Example

This example reboots the Cisco IMC:

```
Server# scope server 1
Server /server # scope bmc
Server /server/bmc # reboot
```

## Clearing the BIOS CMOS

On rare occasions, troubleshooting a server may require you to clear the server's BIOS CMOS memory. This procedure is not part of the normal maintenance of a server.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /server # <b>scope bios</b>	Enters the bios command mode.
<b>Step 3</b>	Server /server/bios # <b>clear-cmos</b>	After a prompt to confirm, clears the CMOS memory.

**Example**

This example clears the BIOS CMOS memory:

```
Server# scope server 2
Server/server # scope bios
Server /server/bios # clear-cmos
```

This operation will clear the BIOS CMOS.

Note: Server should be in powered off state to clear CMOS.

Continue?[y|n] **y**

```
Server /server/bios #
```

## Resetting the BMC to factory Defaults

On rare occasions, such as an issue with the current running firmware, troubleshooting a server may require you to reset the BMC to the factory default. When this happens, all user-configurable settings are reset.

This procedure is not part of the normal server maintenance. After you reset the BMC, you are logged off and must log in again. You may also lose connectivity and may need to reconfigure the network settings.

**Procedure**

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /server # <b>scope bmc</b>	Enters bmc command mode.  <b>Note</b> Depending on the server number you have chosen, enters the BMC1 or BMC2 mode.
<b>Step 3</b>	Server /server/bmc # <b>factory-default</b>	After a prompt to confirm, the BMC resets to factory defaults. All your BMC configuration is lost and some of the inventory information may not be available until the server is powered on or power cycled.

**Example**

This example resets BMC1 to factory defaults:

```
Server# scope server 1
Server /server # scope bmc
Server /server/bmc # factory-default
```

This operation will reset the Server BMC configuration to factory default.

All your configuration will be lost. Some inventory information may not be available until the server is powered on or power cycled.

Continue?[y|N] **y**

# Resetting to Factory Defaults

## Before you begin

You must log in with admin privileges to perform this task.

## Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>factory-default</b> { <b>storage</b>   <b>vic</b>   <b>bmc1</b>   <b>bmc2</b>   <b>cmc</b>   <b>all</b> }	<p>Depending on the component that you choose to rest to factory default, the configuration parameters of that component is restored to factory defaults. You can choose one of the following components:</p> <ul style="list-style-type: none"> <li>• <b>all</b>—Resets the storage controllers, VIC, BMC1, BMC2, and CMCs settings to factory defaults.</li> <li>• <b>bmc1</b> —Resets the BMC1 settings to factory defaults.</li> <li>• <b>bmc2</b> —Resets the BMC2 settings to factory defaults.</li> <li>• <b>cmc</b> —Resets the CMCs settings to factory defaults.</li> <li>• <b>storage</b> —Resets the storage controller settings to factory default.</li> <li>• <b>vic</b> —Resets the VICs settings to factory default.</li> </ul> <p>Enter <b>y</b> at the confirmation prompt to reset the chosen component to default.</p>



	Command or Action	Purpose
		<p><b>Note</b> When you reset the CMC to defaults, all your CMC configuration is lost and the network configuration mode is set to <b>Cisco Card</b> mode by default. The CMCs factory defaults include the following conditions:</p> <ul style="list-style-type: none"> <li>• SSH is enabled for access to the Cisco IMC CLI. Telnet is disabled.</li> <li>• HTTPS is enabled for access to the Cisco IMC GUI.</li> <li>• A single user account exists (user name is <b>admin</b>, password is <b>password</b>).</li> <li>• DHCP is enabled on the management port.</li> <li>• The previous actual boot order is retained.</li> <li>• KVM and vMedia are enabled.</li> <li>• USB is enabled.</li> <li>• SoL is disabled.</li> </ul>
<b>Step 3</b>	(Optional) Server /chassis # <b>show factory-reset-status</b>	Displays the factory defaults status.

### Example

This example resets to factory defaults:

```

Server# scope chassis
Server /chassis # factory-default vic
his factory-default operation does the following on these components without any back-up:
VIC - all user configured data will deleted and controller properties reset to default
values
(Host power-cycle is required for it to be effective)
Storage - all user configured data (including OS VD/drive if any) will be deleted,
controller properties and zoning settings reset to default values (Host power-cycle is
required for it to be effective)
BMC - all Server BMC configuration reset to factory default values
CMC - all user configured data (including admin password) will be deleted and CMC settings
reset to default values
Continue?[y|N]y
factory-default for ' vic' started. Please check the status using "show factory-reset-status".
Server /chassis # show factory-reset-status
Factory Reset Status:
Storage: NA
VIC: Pending

```

```

BMC1: NA
BMC2: NA
CMC: NA
Server /chassis #

```

## Resetting to Factory Defaults

### Before you begin

You must log in with admin privileges to perform this task.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>factory-default</b> { <b>storage</b>   <b>vic</b>   <b>bmc1</b>   <b>bmc2</b>   <b>cmc</b>   <b>all</b> }	<p>Depending on the component that you choose to rest to factory default, the configuration parameters of that component is restored to factory defaults. You can choose one of the following components:</p> <ul style="list-style-type: none"> <li>• <b>all</b>—Resets the storage controllers, VIC, BMC1, BMC2, and CMCs settings to factory defaults.</li> <li>• <b>bmc1</b> —Resets the BMC1 settings to factory defaults.</li> <li>• <b>bmc2</b> —Resets the BMC2 settings to factory defaults.</li> <li>• <b>cmc</b> —Resets the CMCs settings to factory defaults.</li> <li>• <b>storage</b> —Resets the storage controller settings to factory default.</li> <li>• <b>vic</b> —Resets the VICs settings to factory default.</li> </ul> <p>Enter <b>y</b> at the confirmation prompt to reset the chosen component to default.</p>

	Command or Action	Purpose
		<p><b>Note</b> When you reset the CMC to defaults, all your CMC configuration is lost and the network configuration mode is set to <b>Cisco Card</b> mode by default. The CMCs factory defaults include the following conditions:</p> <ul style="list-style-type: none"> <li>• SSH is enabled for access to the Cisco IMC CLI. Telnet is disabled.</li> <li>• HTTPS is enabled for access to the Cisco IMC GUI.</li> <li>• A single user account exists (user name is <b>admin</b>, password is <b>password</b>).</li> <li>• DHCP is enabled on the management port.</li> <li>• The previous actual boot order is retained.</li> <li>• KVM and vMedia are enabled.</li> <li>• USB is enabled.</li> <li>• SoL is disabled.</li> </ul>
<b>Step 3</b>	(Optional) Server /chassis # <b>show factory-reset-status</b>	Displays the factory defaults status.

### Example

This example resets to factory defaults:

```

Server# scope chassis
Server /chassis # factory-default vic
his factory-default operation does the following on these components without any back-up:
VIC - all user configured data will deleted and controller properties reset to default
values
(Host power-cycle is required for it to be effective)
Storage - all user configured data (including OS VD/drive if any) will be deleted,
controller properties and zoning settings reset to default values (Host power-cycle is
required for it to be effective)
BMC - all Server BMC configuration reset to factory default values
CMC - all user configured data (including admin password) will be deleted and CMC settings
reset to default values
Continue?[y|N]y
factory-default for ' vic' started. Please check the status using "show factory-reset-status".
Server /chassis # show factory-reset-status
Factory Reset Status:
Storage: NA
VIC: Pending

```

```

BMC1: NA
BMC2: NA
CMC: NA
Server /chassis #

```

# Exporting and Importing the Cisco IMC and BMC Configuration

## Importing a CMC Configuration



**Important** If any firmware or BIOS updates are in progress, do not import the Cisco IMC configuration until those tasks are complete.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope import-export</b>	Enters the import-export command mode.
<b>Step 3</b>	Server /chassis/import-export # <b>import-config</b> <i>protocol ip-address path-and-filename</i>	The configuration file at the specified path and file name on the remote server at the specified IPv4 or IPv6 address or a hostname will be imported. The remote server can be one of the following: <ul style="list-style-type: none"> <li>• TFTP</li> <li>• FTP</li> <li>• SFTP</li> <li>• SCP</li> <li>• HTTP</li> </ul>

	Command or Action	Purpose
		<p><b>Note</b> The Cisco UCS C-Series server now supports fingerprint confirmation of the server when you update firmware through a remote server. This option is available only if you choose SCP or SFTP as the remote server type.</p> <p>If you chose SCP or SFTP as the remote server type while performing this action, a prompt with the message Server (RSA) key fingerprint is &lt;server_finger_print_ID&gt; Do you wish to continue? Click y or n depending on the authenticity of the server fingerprint.</p> <p>The fingerprint is based on the host's public key and helps you to identify or verify the host you are connecting to.</p>
<b>Step 4</b>	Enter the Username, Password and Pass Phrase.	Sets the username, password and the pass phrase for the file being imported. Starts the import operation.

To determine whether the import operation has completed successfully, use the **show detail** command. To abort the operation, type CTRL+C.

### Example

This example shows how to import a Cisco IMC configuration:

```

Server# scope chassis
Server /chassis # scope import-export
Server /chassis/import-export # import-config tftp 192.0.2.34 /ucs/backups/cimc5.xml
Username:pynj
Password:****
Passphrase:***
Import config started. Please check the status using "show detail".
Server /chassis/import-export # show detail
Import Export:
  Operation: Import
  Status: COMPLETED
  Error Code: 100 (No Error)
  Diagnostic Message: NONE
Server /chassis/import-export #

```

## Importing BMC Configuration



**Important** If any firmware or BIOS updates are in progress, do not import the Cisco IMC configuration until those tasks are complete.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /server # <b>scope bmc</b>	Enters bmc command mode.
<b>Step 3</b>	Server /server/bmc # <b>scope import-export</b>	Enters the import-export command mode.
<b>Step 4</b>	Server /server/bmc/import-export # <b>import-config</b> <i>protocol ip-address path-and-filename</i>	<p>The configuration file at the specified path and file name on the remote server at the specified IPv4 or IPv6 address or a hostname will be imported. The remote server can be one of the following:</p> <ul style="list-style-type: none"> <li>• TFTP</li> <li>• FTP</li> <li>• SFTP</li> <li>• SCP</li> <li>• HTTP</li> </ul> <p><b>Note</b> The Cisco UCS C-Series server now supports fingerprint confirmation of the server when you update firmware through a remote server. This option is available only if you choose SCP or SFTP as the remote server type.</p> <p>If you chose SCP or SFTP as the remote server type while performing this action, a prompt with the message Server (RSA) key fingerprint is &lt;server_finger_print_ID&gt; Do you wish to continue? Click y or n depending on the authenticity of the server fingerprint.</p> <p>The fingerprint is based on the host's public key and helps you to identify or verify the host you are connecting to.</p>

	Command or Action	Purpose
<b>Step 5</b>	Enter the Username and Password.	Sets the username and password for the file being imported. Starts the import operation.

To determine whether the import operation has completed successfully, use the **show detail** command. To abort the operation, type CTRL+C.

### Example

This example shows how to import a Cisco IMC configuration:

```
Server# scope server 2
Server /server# scope bmc
Server /server/bmc # scope import-export
Server /server/bmc/import-export # import-config tftp 192.0.2.34 /ucs/backups/cimc5.xml
Username:pynj
Password:****
Import config started. Please check the status using "show detail".
Server /chassis/import-export # show detail
Import Export:
  Operation: Import
  Status: COMPLETED
  Error Code: 100 (No Error)
  Diagnostic Message: NONE
Server /server/bmc/import-export #
```

## Exporting the BMC Configuration



**Note** For security reasons, this operation does not export user accounts or the server certificate.



**Important** If any firmware or BIOS updates are in progress, do not export the Cisco IMC configuration until those tasks are complete.

### Before you begin

Obtain the backup remote server IP address.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope server</b> {1   2}	Enters server command mode of server 1 or 2.
<b>Step 2</b>	Server /server # <b>scope bmc</b>	Enters bmc command mode.
<b>Step 3</b>	Server /server/bmc # <b>scope import-export</b>	Enters the import-export command mode.

	Command or Action	Purpose
<b>Step 4</b>	Server /server/bmc/import-export # <b>export-config</b> <i>protocol ip-address path-and-filename</i>	<p>The configuration file will be stored at the specified path and file name on a remote server at the specified IPv4 or IPv6 address or a hostname. The remote server could be one of the following types:</p> <ul style="list-style-type: none"> <li>• TFTP</li> <li>• FTP</li> <li>• SFTP</li> <li>• SCP</li> <li>• HTTP</li> </ul> <p><b>Note</b> The Cisco UCS C-Series server now supports fingerprint confirmation of the server when you update firmware through a remote server. This option is available only if you choose SCP or SFTP as the remote server type.</p> <p>If you chose SCP or SFTP as the remote server type while performing this action, a prompt with the message Server (RSA) key fingerprint is &lt;server_finger_print_ID&gt; Do you wish to continue? Click y or n depending on the authenticity of the server fingerprint.</p> <p>The fingerprint is based on the host's public key and helps you to identify or verify the host you are connecting to.</p>
<b>Step 5</b>	Enter the Username and Password.	Sets the username, password and the pass phrase for the file being exported. Starts the backup operation.

To determine whether the export operation has completed successfully, use the **show detail** command. To abort the operation, type CTRL+C.

### Example

This example shows how to back up the Cisco IMC configuration:

```
Server# scope server 2
Server /server# scope bmc
Server /server/bmc # scope import-export
Server /server/bmc/import-export # export-config tftp 192.0.2.34 /ucs/backups/cimc5.xml
Username:pynj
```



```

Password:****
Export config started. Please check the status using "show detail".
Server /cimc/import-export # show detail
Import Export:
  Operation: EXPORT
  Status: COMPLETED
  Error Code: 100 (No Error)
  Diagnostic Message: NONE

Server /server/bmc/import-export #

```

## Exporting the CMC Configuration



**Note** For security reasons, this operation does not export user accounts or the server certificate.



**Important** If any firmware or BIOS updates are in progress, do not export the Cisco IMC configuration until those tasks are complete.

### Before you begin

Obtain the backup remote server IP address.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope import-export</b>	Enters the import-export command mode.
<b>Step 3</b>	Server /chassis/import-export # <b>export-config protocol ip-address path-and-filename</b>	The configuration file will be stored at the specified path and file name on a remote server at the specified IPv4 or IPv6 address or a hostname. The remote server could be one of the following types: <ul style="list-style-type: none"> <li>• TFTP</li> <li>• FTP</li> <li>• SFTP</li> <li>• SCP</li> <li>• HTTP</li> </ul>

	Command or Action	Purpose
		<p><b>Note</b> The Cisco UCS C-Series server now supports fingerprint confirmation of the server when you update firmware through a remote server. This option is available only if you choose SCP or SFTP as the remote server type.</p> <p>If you chose SCP or SFTP as the remote server type while performing this action, a prompt with the message Server (RSA) key fingerprint is &lt;server_finger_print_ID&gt; Do you wish to continue? Click y or n depending on the authenticity of the server fingerprint.</p> <p>The fingerprint is based on the host's public key and helps you to identify or verify the host you are connecting to.</p>
<b>Step 4</b>	Enter the Username, Password and Pass Phrase.	Sets the username, password and the pass phrase for the file being exported. Starts the backup operation.

To determine whether the export operation has completed successfully, use the **show detail** command. To abort the operation, type CTRL+C.

### Example

This example shows how to back up the Cisco IMC configuration:

```
Server# scope chassis
Server /chassis # scope import-export
Server /chassis/import-export # export-config tftp 192.0.2.34 /ucs/backups/cimc5.xml
Username:pynj
Password:****
Passphrase:***
Export config started. Please check the status using "show detail".
Server /chassis/import-export # show detail
Import Export:
  Operation: EXPORT
  Status: COMPLETED
  Error Code: 100 (No Error)
  Diagnostic Message: NONE

Server /chassis/import-export #
```

## Exporting VIC Adapter Configuration



**Important** If any firmware or BIOS updates are in progress, do not export the VIC adapter configuration until those tasks are complete.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>export-all-adapters</b> <i>protocol ip-address path-and-filename</i>	<p>The configuration file at the specified path and file name on the remote server at the specified IPv4 or IPv6 address or a hostname will be imported. The remote server can be one of the following:</p> <ul style="list-style-type: none"> <li>• TFTP</li> <li>• FTP</li> <li>• SFTP</li> <li>• SCP</li> <li>• HTTP</li> </ul> <p><b>Note</b> The Cisco UCS C-Series server now supports fingerprint confirmation of the server when you update firmware through a remote server. This option is available only if you choose SCP or SFTP as the remote server type.</p> <p>If you chose SCP or SFTP as the remote server type while performing this action, a prompt with the message Server (RSA) key fingerprint is &lt;server_finger_print_ID&gt; Do you wish to continue? Click y or n depending on the authenticity of the server fingerprint.</p> <p>The fingerprint is based on the host's public key and helps you to identify or verify the host you are connecting to.</p>

To determine whether the export operation has completed successfully, use the **show detail** command. To abort the operation, type CTRL+C.

## Example

This example shows how to export a VIC adapter configuration:

```

Server# scope chassis
Server /chassis # export-all-adapters tftp 10.10.10.10 /ucs/backups/cfdes.xml
Do you wish to continue? [y/N]y
Username: draf
Password:
Export config for all Adapters is triggered. Please check status using show adapter-ie-status
detail.
Server /chassis # show adapter-ie-status detail
All VIC Import Export:
  Operation: ALL-VIC-EXPORT
  Status: COMPLETED
  Error Code: 100 (No Error)
  Diagnostic Message: NONE
Server /chassis #

```

# Importing VIC Adapter Configuration



### Important

If any firmware or BIOS updates are in progress, do not import the VIC Adapter configuration until those tasks are complete.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server/chassis # <b>import-all-adapters</b> <i>protocol ip-address path-and-filename</i>	The configuration file at the specified path and file name on the remote server at the specified IPv4 or IPv6 address or a hostname will be imported. The remote server can be one of the following: <ul style="list-style-type: none"> <li>• TFTP</li> <li>• FTP</li> <li>• SFTP</li> <li>• SCP</li> <li>• HTTP</li> </ul>

	Command or Action	Purpose
		<p><b>Note</b> The Cisco UCS C-Series server now supports fingerprint confirmation of the server when you update firmware through a remote server. This option is available only if you choose SCP or SFTP as the remote server type.</p> <p>If you chose SCP or SFTP as the remote server type while performing this action, a prompt with the message Server (RSA) key fingerprint is &lt;server_finger_print_ID&gt; Do you wish to continue? Click y or n depending on the authenticity of the server fingerprint.</p> <p>The fingerprint is based on the host's public key and helps you to identify or verify the host you are connecting to.</p>
<b>Step 3</b>	Enter the username, and password.	Starts the import operation.

To determine whether the import operation has completed successfully, use the **show detail** command. To abort the operation, type CTRL+C.

### Example

This example shows how to import the VIC adapter configuration:

```

Server# scope chassis
Server /chassis # import-all-adapters tftp 10.10.10.10 /ucs/backups/cfdes.xml
Do you wish to continue? [y/N]y
Username: gdts
Password:
Import config for all Adapters is triggered. Please check status using show adapter-ie-status detail.
Server /chassis # show adapter-ie-status detail
All VIC Import Export:
  Operation: ALL-VIC-IMPORT
  Status: COMPLETED
  Error Code: 100 (No Error)
  Diagnostic Message: NONE
Server /chassis #

```

## Generating Non-Maskable Interrupts to the Host

In some situations, the server might hang and not respond to traditional debug mechanisms. By generating a non maskable interrupt (NMI) to the host, you can create and send a crash dump file of the server and use it to debug the server.

Depending on the type of operating system associated with the server, this task might restart the OS.

**Procedure**

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope server {1   2}</b>	Enters server command mode of server 1 or 2.
<b>Step 3</b>	Server /chassis/server # <b>generate-nmi</b>	Generates the crash dump file for the server.  To use this command, the server must be powered on, and you must be logged in as an administrator.

**Example**

This example shows how to generate NMI signals to the host:

```
Server # scope chassis
Server /chassis # scope server 2
Server /chassis/server # generate-nmi
This operation will send NMI to host and may cause reboot of OS
OS reboot depends on it's NMI configuration
Do you want to continue? [y|N] y
Server /chassis/server #
```

## Adding Cisco IMC Banner

**Procedure**

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>upload-banner</b>	A prompt to enter the banner displays.
<b>Step 3</b>	Enter the banner and press CTRL+D.	At the prompt, enter <b>y</b> . This results in a loss of the current session, when you log back on again, the new banner appears.
<b>Step 4</b>	(Optional) Server /chassis # <b>show-banner</b>	The banner that you have added displays.

**Example**

This example shows how to add the Cisco IMC banner:

```
Server # scope chassis
Server /chassis # upload-banner
Please paste your custom banner here, when finished, press enter and CTRL+D.
hello world
This will terminate all open SSH session to take an immediate action.
Do you wish to continue? [y/N] yy
Server /chassis # show-banner
```

```
hello world
Server /chassis #
```

## Downloading and Viewing Inventory Details

You can retrieve and save in a file, the following inventory details from the Web UI:

- System Properties
- CPU Information
- Power supply unit inventory
- PCI adapters Cards
- Memory Details
- Trusted Platform Module information
- Disk Information
- Network interface card
- Storage adapter card
- Virtual interface card
- Fan status
- Flex flash card
- BBU Status

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server # <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>inventory-refresh</b>	Initiates the data collection activity and saves the data in a file.
<b>Step 3</b>	Server /chassis # <b>inventory-all</b>	Displays inventory information.

### Example

This example shows the inventory details and the status of inventory collection :

```
Server# scope chassis
Server /chassis #inventory-refresh

Inventory data collection started.

Server /chassis #inventory-all

Hardware Inventory Information:
```

```
Status: IN-PROGRESS
Progress(%): 5
...
Progress(%): 50
sysProductName: UCS C240 M3S
sysProductID: UCSC-C240-M3S
sysSerialNum: FCH1925V21U
...
CPU
id: 1
SocketDesignation: CPU1
ProcessorManufacturer: Intel(R) Corporation
ProcessorFamily: Xeon
ThreadCount: 4
Server /chassis #
```





## APPENDIX **A**

# BIOS Parameters by Server Model

This appendix contains the following sections:

- [S3260 M3 Servers, on page 351](#)
- [S3260 M4 Servers, on page 371](#)
- [S3260 M5 Servers, on page 396](#)

## S3260 M3 Servers

### Main Tab

Name	Description
<b>Reboot Host Immediately</b> checkbox	Upon checking, reboots the host server immediately. You must check the checkbox after saving changes.
<b>TPM Support</b> set TPMAdminCtrl	<p>TPM (Trusted Platform Module) is a microchip designed to provide basic security-related functions primarily involving encryption keys. This option allows you to control the TPM Security Device support for the system. It can be one of the following:</p> <ul style="list-style-type: none"><li>• <b>Disabled</b>—The server does not use the TPM.</li><li>• <b>Enabled</b>—The server uses the TPM.</li></ul> <p><b>Note</b> We recommend that you contact your operating system vendor to make sure the operating system supports this feature.</p>

Name	Description
<b>Power ON Password Support</b> drop-down	<p>This token requires that you set a BIOS password before using the F2 BIOS configuration. If enabled, password needs to be validated before you access BIOS functions such as IO configuration, BIOS set up, and booting to an operating system using BIOS. It can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Support is disabled.</li> <li>• <b>Enabled</b>—Support is enabled.</li> </ul> <p><b>Note</b> This field is available only on some C-series servers.</p>

#### Actions Area

Name	Description
<b>Save</b> button	<p>Saves the settings for the BIOS parameters on all three tabs and closes the dialog box.</p> <p>If the <b>Reboot Host Immediately</b> check box is checked, the server is rebooted immediately and the new BIOS settings go into effect. Otherwise the changes are saved until the server is manually rebooted.</p>
<b>Reset</b> button	Resets the values for the BIOS parameters on all three tabs to the settings that were in effect when this dialog box was first opened.
<b>Restore Defaults</b> button	Sets the BIOS parameters on all three tabs to their default settings.

## Advanced Tab

#### Reboot Server Option

If you want to apply your changes at a later time, clear the **Reboot Host Immediately** check box. Cisco IMC stores the changes and applies them the next time the server reboots.




---

**Note** If there are existing BIOS parameter changes pending, Cisco IMC automatically overwrites the stored values with the current settings when you click **Save Changes**.

---

## Processor Configuration Parameters

Name	Description
<b>Intel Hyper-Threading Technology</b> <b>set IntelHyperThread</b>	<p>Whether the processor uses Intel Hyper-Threading Technology, which allows multithreaded software applications to execute threads in parallel within each processor. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not permit hyperthreading.</li> <li>• <b>Enabled</b>—The processor allows for the parallel execution of multiple threads.</li> </ul> <p>We recommend that you contact your operating system vendor to make sure the operating system supports this feature.</p>
<b>Number of Enabled Cores</b> <b>set CoreMultiProcessing</b>	<p>Allows you to disable one or more of the physical cores on the server. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>All</b>—Enables all physical cores. This also enables Hyper Threading on the associated logical processor cores.</li> <li>• <b>1 through <i>n</i></b>—Specifies the number of physical processor cores that can run on the server. Each physical core has an associated logical core.</li> </ul> <p>We recommend that you contact your operating system vendor to make sure the operating system supports this feature.</p>
<b>Execute Disable</b> <b>set ExecuteDisable</b>	<p>Classifies memory areas on the server to specify where application code can execute. As a result of this classification, the processor disables code execution if a malicious worm attempts to insert code in the buffer. This setting helps to prevent damage, worm propagation, and certain classes of malicious buffer overflow attacks. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not classify memory areas.</li> <li>• <b>Enabled</b>—The processor classifies memory areas.</li> </ul> <p>We recommend that you contact your operating system vendor to make sure the operating system supports this feature.</p>
<b>Intel VT</b> <b>set IntelVT</b>	<p>Whether the processor uses Intel Virtualization Technology (VT), which allows a platform to run multiple operating systems and applications in independent partitions. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not permit virtualization.</li> <li>• <b>Enabled</b>—The processor allows multiple operating systems in independent partitions.</li> </ul> <p><b>Note</b> If you change this option, you must power cycle the server before the setting takes effect.</p>

Name	Description
<b>Intel VT-d</b> <b>set IntelVTD</b>	Whether the processor uses Intel Virtualization Technology for Directed I/O (VT-d). This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not use virtualization technology.</li> <li>• <b>Enabled</b>—The processor uses virtualization technology.</li> </ul>
<b>Intel VT-d Coherency Support</b> <b>set CoherencySupport</b>	Whether the processor supports Intel VT-d Coherency. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not support coherency.</li> <li>• <b>Enabled</b>—The processor uses VT-d Coherency as required.</li> </ul>
<b>Intel VT-d ATS Support</b> <b>set ATS</b>	Whether the processor supports Intel VT-d Address Translation Services (ATS). This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not support ATS.</li> <li>• <b>Enabled</b>—The processor uses VT-d ATS as required.</li> </ul>
<b>CPU Performance</b> <b>set CPUPerformance</b>	Sets the CPU performance profile for the server. The performance profile consists of the following options: <ul style="list-style-type: none"> <li>• DCU Streamer Prefetcher</li> <li>• DCU IP Prefetcher</li> <li>• Hardware Prefetcher</li> <li>• Adjacent Cache-Line Prefetch</li> </ul> This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Enterprise</b>—All options are enabled.</li> <li>• <b>High Throughput</b>—Only the DCU IP Prefetcher is enabled. The rest of the options are disabled.</li> <li>• <b>HPC</b>—All options are enabled. This setting is also known as high performance computing.</li> <li>• <b>Custom</b>—All performance profile options can be configured from the BIOS setup on the server. In addition, the Hardware Prefetcher and Adjacent Cache-Line Prefetch options can be configured in the fields below.</li> </ul>

Name	Description
<b>Hardware Prefetcher</b> <b>set HardwarePrefetch</b>	Whether the processor allows the Intel hardware prefetcher to fetch streams of data and instruction from memory into the unified second-level cache when necessary. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The hardware prefetcher is not used.</li> <li>• <b>Enabled</b>—The processor uses the hardware prefetcher when cache issues are detected.</li> </ul>
<b>Adjacent Cache Line Prefetcher</b> <b>set AdjacentCacheLinePrefetch</b>	Whether the processor fetches cache lines in even/odd pairs instead of fetching just the required line. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor only fetches the required line.</li> <li>• <b>Enabled</b>— The processor fetches both the required line and its paired line.</li> </ul>
<b>DCU Streamer Prefetch</b> <b>set DcuStreamerPrefetch</b>	Whether the processor uses the DCU IP Prefetch mechanism to analyze historical cache access patterns and preload the most relevant lines in the L1 cache. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not try to anticipate cache read requirements and only fetches explicitly requested lines.</li> <li>• <b>Enabled</b>—The DCU prefetcher analyzes the cache read pattern and prefetches the next line in the cache if it determines that it may be needed.</li> </ul>
<b>DCU IP Prefetcher</b> <b>set DcuIpPrefetch</b>	Whether the processor uses the DCU IP Prefetch mechanism to analyze historical cache access patterns and preload the most relevant lines in the L1 cache. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not preload any cache data.</li> <li>• <b>Enabled</b>—The DCU IP prefetcher preloads the L1 cache with the data it determines to be the most relevant.</li> </ul>
<b>Direct Cache Access Support</b> <b>set DirectCacheAccess</b>	Allows processors to increase I/O performance by placing data from I/O devices directly into the processor cache. This setting helps to reduce cache misses. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Data from I/O devices is not placed directly into the processor cache.</li> <li>• <b>Enabled</b>—Data from I/O devices is placed directly into the processor cache.</li> </ul>

Name	Description
<p><b>Power Technology</b> set <b>CPUPowerManagement</b></p>	<p>Enables you to configure the CPU power management settings for the following options:</p> <ul style="list-style-type: none"> <li>• Enhanced Intel Speedstep Technology</li> <li>• Intel Turbo Boost Technology</li> <li>• Processor Power State C6</li> </ul> <p>Power Technology can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Custom</b>—The server uses the individual settings for the BIOS parameters mentioned above. You must select this option if you want to change any of these BIOS parameters.</li> <li>• <b>Disabled</b>—The server does not perform any CPU power management and any settings for the BIOS parameters mentioned above are ignored.</li> <li>• <b>Energy_Efficient</b>—The server determines the best settings for the BIOS parameters mentioned above and ignores the individual settings for these parameters.</li> </ul>
<p><b>Enhanced Intel Speedstep Technology</b> set <b>EnhancedIntelSpeedStep</b></p>	<p>Whether the processor uses Enhanced Intel SpeedStep Technology, which allows the system to dynamically adjust processor voltage and core frequency. This technology can result in decreased average power consumption and decreased average heat production. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor never dynamically adjusts its voltage or frequency.</li> <li>• <b>Enabled</b>—The processor utilizes Enhanced Intel SpeedStep Technology and enables all supported processor sleep states to further conserve power.</li> </ul> <p>We recommend that you contact your operating system vendor to make sure the operating system supports this feature.</p> <p><b>Note</b>     <b>CPUPowerManagement</b> must be set to <b>Custom</b> or the server ignores the setting for this parameter.</p>

Name	Description
<b>Intel Turbo Boost Technology</b> <b>set IntelTurboBoostTech</b>	<p>Whether the processor uses Intel Turbo Boost Technology, which allows the processor to automatically increase its frequency if it is running below power, temperature, or voltage specifications. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not increase its frequency automatically.</li> <li>• <b>Enabled</b>—The processor utilizes Turbo Boost Technology if required.</li> </ul> <p><b>Note</b> <b>CPUPowerManagement</b> must be set to <b>Custom</b> or the server ignores the setting for this parameter.</p>
<b>Processor Power State C6</b> <b>set ProcessorC6Report</b>	<p>Whether the BIOS sends the C6 report to the operating system. When the OS receives the report, it can transition the processor into the lower C6 power state to decrease energy usage while maintaining optimal processor performance. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The BIOS does not send the C6 report.</li> <li>• <b>Enabled</b>—The BIOS sends the C6 report, allowing the OS to transition the processor to the C6 low power state.</li> </ul> <p><b>Note</b> <b>CPUPowerManagement</b> must be set to <b>Custom</b> or the server ignores the setting for this parameter.</p>
<b>Processor Power State C1 Enhanced</b> <b>set ProcessorC1EReport</b>	<p>Whether the CPU transitions to its minimum frequency when entering the C1 state. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The CPU continues to run at its maximum frequency in C1 state.</li> <li>• <b>Enabled</b>—The CPU transitions to its minimum frequency. This option saves the maximum amount of power in C1 state.</li> </ul>
<b>Frequency Floor Override</b> <b>set CpuFreqFloor</b>	<p>Whether the CPU is allowed to drop below the maximum non-turbo frequency when idle. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>— The CPU can drop below the maximum non-turbo frequency when idle. This option decreases power consumption but may reduce system performance.</li> <li>• <b>Enabled</b>— The CPU cannot drop below the maximum non-turbo frequency when idle. This option improves system performance but may increase power consumption.</li> </ul>

Name	Description
<p><b>P-STATE Coordination</b> set PsdCoordType</p>	<p>Allows you to define how BIOS communicates the P-state support model to the operating system. There are 3 models as defined by the Advanced Configuration and Power Interface (ACPI) specification.</p> <ul style="list-style-type: none"> <li>• <b>HW_ALL</b>—The processor hardware is responsible for coordinating the P-state among logical processors with dependencies (all logical processors in a package).</li> <li>• <b>SW_ALL</b>—The OS Power Manager (OSPM) is responsible for coordinating the P-state among logical processors with dependencies (all logical processors in a physical package), and must initiate the transition on all of the logical processors.</li> <li>• <b>SW_ANY</b>—The OS Power Manager (OSPM) is responsible for coordinating the P-state among logical processors with dependencies (all logical processors in a package), and may initiate the transition on any of the logical processors in the domain.</li> </ul> <p><b>Note</b>     <b>CPUPowerManagement</b> must be set to <b>Custom</b> or the server ignores the setting for this parameter.</p>
<p><b>Energy Performance</b> set CpuEngPerfBias</p>	<p>Allows you to determine whether system performance or energy efficiency is more important on this server. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Balanced_Energy</b></li> <li>• <b>Balanced_Performance</b></li> <li>• <b>Energy_Efficient</b></li> <li>• <b>Performance</b></li> </ul>



### Memory Configuration Parameters

Name	Description
<b>Select Memory RAS</b> <b>set SelectMemoryRAS</b>	<p>How the memory reliability, availability, and serviceability (RAS) is configured for the server. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Maximum_Performance</b>—System performance is optimized.</li> <li>• <b>Mirroring</b>—System reliability is optimized by using half the system memory as backup.</li> <li>• <b>Lockstep</b>—If the DIMM pairs in the server have an identical type, size, and organization and are populated across the SMI channels, you can enable lockstep mode to minimize memory access latency and provide better performance. This option offers better system performance than Mirroring and better reliability than Maximum Performance but lower reliability than Mirroring and lower system performance than Maximum Performance.</li> </ul>
<b>DRAM Clock Throttling</b> <b>set DRAMClockThrottling</b>	<p>Allows you to tune the system settings between the memory bandwidth and power consumption. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Balanced</b>—DRAM clock throttling is reduced, providing a balance between performance and power.</li> <li>• <b>Performance</b>—DRAM clock throttling is disabled, providing increased memory bandwidth at the cost of additional power.</li> <li>• <b>Energy_Efficient</b>—DRAM clock throttling is increased to improve energy efficiency.</li> </ul>
<b>NUMA</b> <b>set NUMAOptimize</b>	<p>Whether the BIOS supports Non-Uniform Memory Access (NUMA). This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The BIOS does not support NUMA.</li> <li>• <b>Enabled</b>—The BIOS includes the ACPI tables that are required for NUMA-aware operating systems. If you enable this option, the system must disable Inter-Socket Memory interleaving on some platforms.</li> </ul>

Name	Description
<b>Low Voltage DDR Mode</b> set LvDDRMode	Whether the system prioritizes low voltage or high frequency memory operations. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Power_Saving_Mode</b>—The system prioritizes low voltage memory operations over high frequency memory operations. This mode may lower memory frequency in order to keep the voltage low.</li> <li>• <b>Performance_Mode</b>—The system prioritizes high frequency operations over low voltage operations.</li> </ul>
<b>DRAM Refresh rate</b> set DramRefreshRate	Allows you to set the rate at which the DRAM cells are refreshed. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>1x</b>—DRAM cells are refreshed every 64ms.</li> <li>• <b>2x</b>—DRAM cells are refreshed every 32ms.</li> <li>• <b>3x</b>—DRAM cells are refreshed every 21ms.</li> <li>• <b>4x</b>—DRAM cells are refreshed every 16ms.</li> <li>• <b>Auto</b>—DRAM cells refresh rate is automatically chosen by the BIOS based on the system configuration. This is the recommended setting for this parameter.</li> </ul>
<b>Channel Interleaving</b> set ChannelInterLeave	Whether the CPU divides memory blocks and spreads contiguous portions of data across interleaved channels to enable simultaneous read operations. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Auto</b>—The CPU determines what interleaving is done.</li> <li>• <b>1_Way</b>—Some channel interleaving is used.</li> <li>• <b>2_Way</b></li> <li>• <b>3_Way</b></li> <li>• <b>4_Way</b>—The maximum amount of channel interleaving is used.</li> </ul>
<b>Rank Interleaving</b> set RankInterLeave	Whether the CPU interleaves physical ranks of memory so that one rank can be accessed while another is being refreshed. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Auto</b>—The CPU determines what interleaving is done.</li> <li>• <b>1_Way</b>—Some rank interleaving is used.</li> <li>• <b>2_Way</b></li> <li>• <b>4_Way</b></li> <li>• <b>8_Way</b>—The maximum amount of rank interleaving is used.</li> </ul>

Name	Description
<b>Patrol Scrub</b> <b>set PatrolScrub</b>	<p>Whether the system actively searches for, and corrects, single bit memory errors even in unused portions of the memory on the server. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The system checks for memory ECC errors only when the CPU reads or writes a memory address.</li> <li>• <b>Enabled</b>—The system periodically reads and writes memory searching for ECC errors. If any errors are found, the system attempts to fix them. This option may correct single bit errors before they become multi-bit errors, but it may adversely affect performance when the patrol scrub is running.</li> </ul>
<b>Demand Scrub</b> <b>set DemandScrub</b>	<p>Whether the system corrects single bit memory errors encountered when the CPU or I/O makes a demand read. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>— Single bit memory errors are not corrected.</li> <li>• <b>Enabled</b>— Single bit memory errors are corrected in memory and the corrected data is set in response to the demand read.</li> </ul>
<b>Altitude</b> <b>set Altitude</b>	<p>The approximate number of meters above sea level at which the physical server is installed. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Auto</b>—The CPU determines the physical elevation.</li> <li>• <b>300_M</b>—The server is approximately 300 meters above sea level.</li> <li>• <b>900_M</b>—The server is approximately 900 meters above sea level.</li> <li>• <b>1500_M</b>—The server is approximately 1500 meters above sea level.</li> <li>• <b>3000_M</b>—The server is approximately 3000 meters above sea level.</li> </ul>

## QPI Configuration Parameters

Name	Description
<b>QPI Link Frequency Select</b> set <b>QPILinkFrequency</b>	The Intel QuickPath Interconnect (QPI) link frequency, in gigatransfers per second (GT/s). This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Auto</b>—The CPU determines the QPI link frequency.</li> <li>• <b>6.4_GT/s</b></li> <li>• <b>7.2_GT/s</b></li> <li>• <b>8.0_GT/s</b></li> </ul>
<b>QPI Snoop Mode</b> Drop-down list	The Intel QuickPath Interconnect (QPI) snoop mode. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Auto</b>—The CPU automatically recognizes this as Early Snoop mode.</li> <li>• <b>Early Snoop</b>—The distributed cache ring stops can send a snoop probe or a request to another caching agent directly. This mode has lower latency and it is best for workloads that have shared data sets across threads and can benefit from a cache-to-cache transfer, or for workloads that are not NUMA optimized.</li> <li>• <b>Home Snoop</b>—The snoop is always spawned by the home agent (centralized ring stop) for the memory controller. This mode has a higher local latency than early snoop, but it provides extra resources for a larger number of outstanding transactions.</li> <li>• <b>Home Directory Snoop</b>— The home directory is an optional enabled feature that is implemented at both the HA and iMC logic in the processor. The goal of the directory is to filter snoops to the remote sockets and a node controller in scalable platforms and 2S and 4S configurations.</li> <li>• <b>Home Directory Snoop with OSB</b>— In the Opportunistic Snoop Broadcast (OSB) directory mode, the HA could choose to do speculative home snoop broadcast under very lightly loaded conditions even before the directory information has been collected and checked.</li> <li>• <b>Cluster on Die</b>—Enables Cluster On Die. When enabled LLC is split into two parts with an independent caching agent for each. This helps increase the performance in some workloads. This mode is available only for processors that have 10 or more cores. It is the best mode for highly NUMA optimized workloads.</li> </ul>

**SATA Configuration Parameters**

Name	Description
<b>SATA Mode</b> <b>set SataMode</b>	Mode of operation of Serial Advanced Technology Attachment (SATA) Solid State Drives (SSD). <ul style="list-style-type: none"> <li>• <b>Disabled</b>— All SATA ports is disabled, and drivers are not enumerated.</li> <li>• <b>AHCI Mode</b>—The default mode. Drives operate according to newer standard of Advance Host Controller Interface(AHCI).</li> </ul>

**USB Configuration Parameters**

Name	Description
<b>Legacy USB Support</b> <b>set LegacyUSBSupport</b>	Whether the system supports legacy USB devices. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—USB devices are only available to EFI applications.</li> <li>• <b>Enabled</b>—Legacy USB support is always available.</li> <li>• <b>Auto</b>—Disables legacy USB support if no USB devices are connected.</li> </ul>
<b>Port 60/64 Emulation</b> <b>set UsbEmul6064</b>	Whether the system supports 60h/64h emulation for complete USB keyboard legacy support. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—60h/64 emulation is not supported.</li> <li>• <b>Enabled</b>—60h/64 emulation is supported.</li> </ul> You should select this option if you are using a non-USB aware operating system on the server.
<b>All USB Devices</b> <b>set AllUsbDevices</b>	Whether all physical and virtual USB devices are enabled or disabled. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—All USB devices are disabled.</li> <li>• <b>Enabled</b>—All USB devices are enabled.</li> </ul>
<b>USB Port: Rear</b> <b>set UsbPortRear</b>	Whether the rear panel USB devices are enabled or disabled. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Disables the rear panel USB ports. Devices connected to these ports are not detected by the BIOS and operating system.</li> <li>• <b>Enabled</b>—Enables the rear panel USB ports. Devices connected to these ports are detected by the BIOS and operating system.</li> </ul>

Name	Description
<b>USB Port: Internal</b> set <code>UsbPortInt</code>	Whether the internal USB devices are enabled or disabled. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Disables the internal USB ports. Devices connected to these ports are not detected by the BIOS and operating system.</li> <li>• <b>Enabled</b>—Enables the internal USB ports. Devices connected to these ports are detected by the BIOS and operating system.</li> </ul>
<b>USB Port: KVM</b> set <code>UsbPortKVM</code>	Whether the vKVM ports are enabled or disabled. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Disables the vKVM keyboard and/or mouse devices. Keyboard and/or mouse will not work in the vKVM window.</li> <li>• <b>Enabled</b>—Enables the vKVM keyboard and/or mouse devices.</li> </ul>
<b>USB Port: vMedia</b> set <code>UsbPortVMedia</code>	Whether the virtual media devices are enabled or disabled. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Disables the vMedia devices.</li> <li>• <b>Enabled</b>—Enables the vMedia devices.</li> </ul>

### PCI Configuration Parameters

Name	Description
<b>PCI ROM CLP</b> set <code>PciRomClp</code>	PCI ROM Command Line Protocol (CLP) controls the execution of different Option ROMs such as PxE and iSCSI that are present in the card. By default, it is disabled. <ul style="list-style-type: none"> <li>• <b>Enabled</b>— Enables you to configure execution of different option ROMs such as PxE and iSCSI for an individual ports separately.</li> <li>• <b>Disabled</b>—The default option. You cannot choose different option ROMs. A default option ROM is executed during PCI enumeration.</li> </ul>
<b>ASPM Support</b> set <code>ASPMSupport</code>	Allows you to set the level of ASPM (Active Power State Management) support in the BIOS. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—ASPM support is disabled in the BIOS.</li> <li>• <b>Force L0s</b>—Force all links to L0 standby (L0s) state.</li> <li>• <b>Auto</b>—The CPU determines the power state.</li> </ul>

## Serial Configuration Parameters

Name	Description
<b>Out-of-Band Mgmt Port</b> <b>set comSpcrEnable</b>	<p>Allows you to configure the COM port 0 that can be used for Windows Emergency Management services. ACPI SPCR table is reported based on this setup option. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Configures the COM port 0 as a general purpose port for use with the Windows Operating System.</li> <li>• <b>Enabled</b>—Configures the COM port 0 as a remote management port for Windows Emergency Management services.</li> </ul>
<b>Console Redirection</b> <b>set ConsoleRedir</b>	<p>Allows a serial port to be used for console redirection during POST and BIOS booting. After the BIOS has booted and the operating system is responsible for the server, console redirection is irrelevant and has no effect. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—No console redirection occurs during POST.</li> <li>• <b>COM_0</b>—Enables console redirection on COM port 0 during POST.</li> <li>• <b>COM_1</b>—Enables console redirection on COM port 1 during POST.</li> </ul>
<b>Terminal Type</b> <b>set TerminalType</b>	<p>What type of character formatting is used for console redirection. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>PC-ANSI</b>—The PC-ANSI terminal font is used.</li> <li>• <b>VT100</b>—A supported vt100 video terminal and its character set are used.</li> <li>• <b>VT100+</b>—A supported vt100-plus video terminal and its character set are used.</li> <li>• <b>VT-UTF8</b>—A video terminal with the UTF-8 character set is used.</li> </ul> <p><b>Note</b> This setting must match the setting on the remote terminal application.</p>

Name	Description
<b>Bits per second</b> <b>set BaudRate</b>	<p>What BAUD rate is used for the serial port transmission speed. If you disable Console Redirection, this option is not available. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>9600</b>—A 9,600 BAUD rate is used.</li> <li>• <b>19200</b>—A 19,200 BAUD rate is used.</li> <li>• <b>38400</b>—A 38,400 BAUD rate is used.</li> <li>• <b>57600</b>—A 57,600 BAUD rate is used.</li> <li>• <b>115200</b>—A 115,200 BAUD rate is used.</li> </ul> <p><b>Note</b> This setting must match the setting on the remote terminal application.</p>
<b>Flow Control</b> <b>set FlowCtrl</b>	<p>Whether a handshake protocol is used for flow control. Request to Send / Clear to Send (RTS/CTS) helps to reduce frame collisions that can be introduced by a hidden terminal problem. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>None</b>—No flow control is used.</li> <li>• <b>Hardware_RTS/CTS</b>—RTS/CTS is used for flow control.</li> </ul> <p><b>Note</b> This setting must match the setting on the remote terminal application.</p>



Name	Description
<b>Putty Keypad</b> <b>set PuttyFunctionKeypad</b>	<p>Allows you to change the action of the PuTTY function keys and the top row of the numeric keypad. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>VT100</b>—The function keys generate <b>ESC OP</b> through <b>ESC O[</b>.</li> <li>• <b>LINUX</b>—Mimics the Linux virtual console. Function keys F6 to F12 behave like the default mode, but F1 to F5 generate <b>ESC [ [A</b> through <b>ESC [ [E</b>.</li> <li>• <b>XTERM6</b>—Function keys F5 to F12 behave like the default mode. Function keys F1 to F4 generate <b>ESC OP</b> through <b>ESC OS</b>, which are the sequences produced by the top row of the keypad on Digital terminals.</li> <li>• <b>SCO</b>—The function keys F1 to F12 generate <b>ESC [M</b> through <b>ESC [X</b>. The function and shift keys generate <b>ESC [Y</b> through <b>ESC [j</b>. The control and function keys generate <b>ESC [k</b> through <b>ESC [v</b>. The shift, control and function keys generate <b>ESC [w</b> through <b>ESC [t</b>.</li> <li>• <b>ESCN</b>—The default mode. The function keys match the general behavior of Digital terminals. The function keys generate sequences such as <b>ESC [11~</b> and <b>ESC [12~</b>.</li> <li>• <b>VT400</b>—The function keys behave like the default mode. The top row of the numeric keypad generates <b>ESC OP</b> through <b>ESC OS</b>.</li> </ul>
<b>Redirection After BIOS POST</b> <b>set RedirectionAfterPOST</b>	<p>Whether BIOS console redirection should be active after BIOS POST is complete and control given to the OS bootloader. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Always_Enabled</b>—BIOS Legacy console redirection is active during the OS boot and run time.</li> <li>• <b>Bootloader</b>—BIOS Legacy console redirection is disabled before giving control to the OS boot loader.</li> </ul>

### LOM and PCIe Slots Configuration Parameters

Name	Description
<b>CDN Support for VIC</b> <b>set CdnEnable</b>	<p>Whether the Ethernet Network naming convention is according to Consistent Device Naming (CDN) or the traditional way of naming conventions. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>— CDN support for VIC cards is disabled.</li> <li>• <b>Enabled</b>— CDN support is enabled for VIC cards.</li> </ul> <p><b>Note</b>      CDN support for VIC cards work with Windows 2012 or the latest OS only.</p>

Name	Description
<b>All PCIe Slots OptionROM</b> set <code>PcieOptionROMs</code>	Whether the server can use Option ROM present in the PCIe Cards. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The Option ROM for all PCIe slots are not available.</li> <li>• <b>Enabled</b>—The Option ROMs for all the PCIe slots are available.</li> <li>• <b>UEFI_Only</b>—The Option ROMs for slot <i>n</i> are available for UEFI only.</li> <li>• <b>Legacy_Only</b>—The Option ROM for slot <i>n</i> are available for legacy only.</li> </ul>
<b>PCIe Slot:<i>n</i> OptionROM</b> set <code>PcieSlot<i>n</i>OptionROM</code>	Whether the server can use the Option ROMs present in the PCIe Cards. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The Option ROM for slot <i>n</i> is not available.</li> <li>• <b>Enabled</b>—The Option ROM for slot <i>n</i> is available.</li> <li>• <b>UEFI_Only</b>—The Option ROM for slot <i>n</i> is available for UEFI only.</li> <li>• <b>Legacy_Only</b>—The Option ROM for slot <i>n</i> is available for legacy only.</li> </ul>
<b>PCIe Mezzanine OptionROM</b> set <code>PcieMezzOptionROM</code>	Whether the PCIe mezzanine slot expansion ROM is available to the server. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>— The Option ROM for slot <i>M</i> is not available.</li> <li>• <b>Enabled</b>— The Option ROM for slot <i>M</i> is available.</li> <li>• <b>UEFI_Only</b>—The Option ROM for slot <i>M</i> is available for UEFI only.</li> <li>• <b>Legacy_Only</b>—The expansion slot for slot <i>M</i> is available for legacy only.</li> </ul>
<b>SIOC1 Link Speed</b> Set <code>PcieSlot1LinkSpeed</code>	System IO Controller 1 (SIOC1) add-on slot 1 link speed. <ul style="list-style-type: none"> <li>• <b>GEN1</b> — Link speed can reach up to first generation.</li> <li>• <b>GEN2</b> — Link speed can reach up to second generation.</li> <li>• <b>GEN3</b>— The default link speed. Link speed can reach up to third generation.</li> <li>• <b>Disabled</b> — Slot is disabled, and the card is not enumerated.</li> </ul>

Name	Description
<b>SIOC2 Link Speed</b> <b>set PcieSlot2LinkSpeed</b>	System IO Controller 2 (SIOC2) add-on slot 2 link speed. <ul style="list-style-type: none"> <li>• <b>GEN1</b> — Link speed can reach up to first generation.</li> <li>• <b>GEN2</b> — Link speed can reach up to second generation.</li> <li>• <b>GEN3</b>— The default link speed. Link speed can reach up to third generation.</li> <li>• <b>Disabled</b> — Slot is disabled, and the card is not enumerated.</li> </ul>
<b>Mezz Link Speed</b>	Mezz link speed. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>GEN 1</b>— Link speed can reach up to first generation.</li> <li>• <b>GEN 2</b>— Link speed can reach up to second generation.</li> <li>• <b>GEN 3</b>—The default link speed. Link speed can reach up to third generation.</li> <li>• <b>Disabled</b>—Slot is disabled, and the card is not enumerated.</li> </ul>

### BIOS Configuration Dialog Box Button Bar



#### Important

The buttons in this dialog box affect all BIOS parameters on all available tabs, not just the parameters on the tab that you are viewing.

Name	Description
<b>Save Changes</b> button	Saves the settings for the BIOS parameters on all three tabs and closes the dialog box.  If the <b>Reboot Host Immediately</b> check box is checked, the server is rebooted immediately and the new BIOS settings go into effect. Otherwise the changes are saved until the server is manually rebooted.
<b>Reset</b> button	Restores the values for the BIOS parameters on all three tabs to the settings that were in effect when this dialog box was first opened.
<b>Restore Defaults</b> button	Sets the BIOS parameters on all three tabs to their default settings.

## Server Management Tab

### Server Management BIOS Parameters

Name	Description
<b>FRB-2 Timer</b> <b>set FRB-2</b>	Whether the FRB2 timer is used by Cisco IMC to recover the system if it hangs during POST. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The FRB2 timer is not used.</li> <li>• <b>Enabled</b>—The FRB2 timer is started during POST and used to recover the system if necessary.</li> </ul>
<b>OS Watchdog Timer</b> <b>set OSBootWatchdogTimer</b>	Whether the BIOS programs the watchdog timer with a specified timeout value. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The watchdog timer is not used to track how long the server takes to boot.</li> <li>• <b>Enabled</b>—The watchdog timer tracks how long the server takes to boot. If the server does not boot within the length of time specified by the <b>set OSBootWatchdogTimerTimeout</b> command, the Cisco IMC logs an error and takes the action specified by the <b>set OSBootWatchdogTimerPolicy</b> command.</li> </ul>
<b>OS Watchdog Timer Timeout</b> <b>set OSBootWatchdogTimerTimeOut</b>	If OS does not boot within the specified time, OS watchdog timer expires and system takes action according to timer policy. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>5_Minutes</b>—The OS watchdog timer expires 5 minutes after it begins to boot.</li> <li>• <b>10_Minutes</b>—The OS watchdog timer expires 10 minutes after it begins to boot.</li> <li>• <b>15_Minutes</b>—The OS watchdog timer expires 15 minutes after it begins to boot.</li> <li>• <b>20_Minutes</b>—The OS watchdog timer expires 20 minutes after it begins to boot.</li> </ul> <p><b>Note</b> This option is only applicable if you enable the OS Boot Watchdog Timer.</p>

Name	Description
<b>OS Watchdog Timer Policy</b> set OSBootWatchdogTimerPolicy	<p>What action the system takes if the watchdog timer expires. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Do_Nothing</b>—The server takes no action if the watchdog timer expires during OS boot.</li> <li>• <b>Power_Down</b>—The server is powered off if the watchdog timer expires during OS boot.</li> <li>• <b>Reset</b>—The server is reset if the watchdog timer expires during OS boot.</li> </ul> <p><b>Note</b> This option is only applicable if you enable the OS Boot Watchdog Timer.</p>

## S3260 M4 Servers

### Main Tab

Name	Description
<b>Reboot Host Immediately</b> checkbox	Upon checking, reboots the host server immediately. You must check the checkbox after saving changes.
<b>TPM Support</b>	<p>TPM (Trusted Platform Module) is a microchip designed to provide basic security-related functions primarily involving encryption keys. This option allows you to control the TPM Security Device support for the system. It can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The server does not use the TPM.</li> <li>• <b>Enabled</b>—The server uses the TPM.</li> </ul> <p><b>Note</b> We recommend that you contact your operating system vendor to make sure the operating system supports this feature.</p>
<b>Power ON Password Support</b> drop-down	<p>This token requires that you set a BIOS password before using the F2 BIOS configuration. If enabled, password needs to be validated before you access BIOS functions such as IO configuration, BIOS set up, and booting to an operating system using BIOS. It can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Support is disabled.</li> <li>• <b>Enabled</b>—Support is enabled.</li> </ul>

**Actions Area**

Name	Description
Save button	Saves the settings for the BIOS parameters on all three tabs and closes the dialog box.  If the <b>Reboot Host Immediately</b> check box is checked, the server is rebooted immediately and the new BIOS settings go into effect. Otherwise the changes are saved until the server is manually rebooted.
Reset button	Resets the values for the BIOS parameters on all three tabs to the settings that were in effect when this dialog box was first opened.
Restore Defaults button	Sets the BIOS parameters on all three tabs to their default settings.

## Advanced Tab

**Reboot Server Option**

If you want your changes applied automatically after you click **Save Changes**, check the **Reboot Host Immediately** check box. Cisco IMC immediately reboots the server and applies your changes.

If you want to apply your changes at a later time, clear the **Reboot Host Immediately** check box. Cisco IMC stores the changes and applies them the next time the server reboots.




---

**Note** If there are existing BIOS parameter changes pending, Cisco IMC automatically overwrites the stored values with the current settings when you click **Save Changes**.

---

**Processor Configuration Parameters**

Name	Description
<b>Intel Hyper-Threading Technology</b> set IntelHyperThread	Whether the processor uses Intel Hyper-Threading Technology, which allows multithreaded software applications to execute threads in parallel within each processor. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not permit hyperthreading.</li> <li>• <b>Enabled</b>—The processor allows for the parallel execution of multiple threads.</li> </ul> <p>We recommend that you contact your operating system vendor to make sure the operating system supports this feature.</p>

Name	Description
<b>Number of Enabled Cores</b> set CoreMultiProcessing	<p>Allows you to disable one or more of the physical cores on the server. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>All</b>—Enables all physical cores. This also enables Hyper Threading on the associated logical processor cores.</li> <li>• <b>1 through <i>n</i></b>—Specifies the number of physical processor cores that can run on the server. Each physical core has an associated logical core.</li> </ul> <p>We recommend that you contact your operating system vendor to make sure the operating system supports this feature.</p>
<b>Execute Disable</b> set ExecuteDisable	<p>Classifies memory areas on the server to specify where application code can execute. As a result of this classification, the processor disables code execution if a malicious worm attempts to insert code in the buffer. This setting helps to prevent damage, worm propagation, and certain classes of malicious buffer overflow attacks. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not classify memory areas.</li> <li>• <b>Enabled</b>—The processor classifies memory areas.</li> </ul> <p>We recommend that you contact your operating system vendor to make sure the operating system supports this feature.</p>
<b>Intel VT</b> set IntelVT	<p>Whether the processor uses Intel Virtualization Technology (VT), which allows a platform to run multiple operating systems and applications in independent partitions. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not permit virtualization.</li> <li>• <b>Enabled</b>—The processor allows multiple operating systems in independent partitions.</li> </ul> <p><b>Note</b> If you change this option, you must power cycle the server before the setting takes effect.</p>
<b>Intel VT-d</b> set IntelVTD	<p>Whether the processor uses Intel Virtualization Technology for Directed I/O (VT-d). This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not use virtualization technology.</li> <li>• <b>Enabled</b>—The processor uses virtualization technology.</li> </ul>

Name	Description
<b>Intel VT-d Interrupt Remapping</b> <b>set InterruptRemap</b>	Whether the processor supports Intel VT-d Interrupt Remapping. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not support remapping.</li> <li>• <b>Enabled</b>—The processor uses VT-d Interrupt Remapping as required.</li> </ul>
<b>Intel VT-d PassThrough DMA</b> <b>set PassThroughDMA</b>	Whether the processor supports Intel VT-d Pass-through DMA. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not support pass-through DMA.</li> <li>• <b>Enabled</b>—The processor uses VT-d Pass-through DMA as required.</li> </ul>
<b>Intel VT-d Coherency Support</b> <b>set CoherencySupport</b>	Whether the processor supports Intel VT-d Coherency. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not support coherency.</li> <li>• <b>Enabled</b>—The processor uses VT-d Coherency as required.</li> </ul>
<b>Intel VT-d ATS Support</b> <b>set ATS</b>	Whether the processor supports Intel VT-d Address Translation Services (ATS). This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not support ATS.</li> <li>• <b>Enabled</b>—The processor uses VT-d ATS as required.</li> </ul>



Name	Description
<p><b>CPU Performance</b> set CPUPerformance</p>	<p>Sets the CPU performance profile for the server. The performance profile consists of the following options:</p> <ul style="list-style-type: none"> <li>• DCU Streamer Prefetcher</li> <li>• DCU IP Prefetcher</li> <li>• Hardware Prefetcher</li> <li>• Adjacent Cache-Line Prefetch</li> </ul> <p>This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Enterprise</b>—All options are enabled.</li> <li>• <b>High_Throughput</b>—Only the DCU IP Prefetcher is enabled. The rest of the options are disabled.</li> <li>• <b>HPC</b>—All options are enabled. This setting is also known as high performance computing.</li> <li>• <b>Custom</b>—All performance profile options can be configured from the BIOS setup on the server. In addition, the Hardware Prefetcher and Adjacent Cache-Line Prefetch options can be configured in the fields below.</li> </ul>
<p><b>Hardware Prefetcher</b> set HardwarePrefetch</p>	<p>Whether the processor allows the Intel hardware prefetcher to fetch streams of data and instruction from memory into the unified second-level cache when necessary. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The hardware prefetcher is not used.</li> <li>• <b>Enabled</b>—The processor uses the hardware prefetcher when cache issues are detected.</li> </ul>
<p><b>Adjacent Cache Line Prefetcher</b> set AdjacentCacheLinePrefetch</p>	<p>Whether the processor fetches cache lines in even/odd pairs instead of fetching just the required line. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor only fetches the required line.</li> <li>• <b>Enabled</b>— The processor fetches both the required line and its paired line.</li> </ul>

Name	Description
<b>DCU Streamer Prefetch</b> <b>set DcuStreamerPrefetch</b>	<p>Whether the processor uses the DCU IP Prefetch mechanism to analyze historical cache access patterns and preload the most relevant lines in the L1 cache. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not try to anticipate cache read requirements and only fetches explicitly requested lines.</li> <li>• <b>Enabled</b>—The DCU prefetcher analyzes the cache read pattern and prefetches the next line in the cache if it determines that it may be needed.</li> </ul>
<b>DCU IP Prefetcher</b> <b>set DcuIpPrefetch</b>	<p>Whether the processor uses the DCU IP Prefetch mechanism to analyze historical cache access patterns and preload the most relevant lines in the L1 cache. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not preload any cache data.</li> <li>• <b>Enabled</b>—The DCU IP prefetcher preloads the L1 cache with the data it determines to be the most relevant.</li> </ul>
<b>Direct Cache Access Support</b> <b>set DirectCacheAccess</b>	<p>Allows processors to increase I/O performance by placing data from I/O devices directly into the processor cache. This setting helps to reduce cache misses. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Data from I/O devices is not placed directly into the processor cache.</li> <li>• <b>Enabled</b>—Data from I/O devices is placed directly into the processor cache.</li> </ul>
<b>Power Technology</b> <b>set CPUPowerManagement</b>	<p>Enables you to configure the CPU power management settings for the following options:</p> <ul style="list-style-type: none"> <li>• Enhanced Intel Speedstep Technology</li> <li>• Intel Turbo Boost Technology</li> <li>• Processor Power State C6</li> </ul> <p>Power Technology can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Custom</b>—The server uses the individual settings for the BIOS parameters mentioned above. You must select this option if you want to change any of these BIOS parameters.</li> <li>• <b>Disabled</b>—The server does not perform any CPU power management and any settings for the BIOS parameters mentioned above are ignored.</li> <li>• <b>Energy Efficient</b>—The server determines the best settings for the BIOS parameters mentioned above and ignores the individual settings for these parameters.</li> </ul>

Name	Description
<b>Enhanced Intel Speedstep Technology</b> <b>set EnhancedIntelSpeedStep</b>	<p>Whether the processor uses Enhanced Intel SpeedStep Technology, which allows the system to dynamically adjust processor voltage and core frequency. This technology can result in decreased average power consumption and decreased average heat production. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor never dynamically adjusts its voltage or frequency.</li> <li>• <b>Enabled</b>—The processor utilizes Enhanced Intel SpeedStep Technology and enables all supported processor sleep states to further conserve power.</li> </ul> <p>We recommend that you contact your operating system vendor to make sure the operating system supports this feature.</p> <p><b>Note</b>     <b>CPUPowerManagement</b> must be set to <b>Custom</b> or the server ignores the setting for this parameter.</p>
<b>Intel Turbo Boost Technology</b> <b>set IntelTurboBoostTech</b>	<p>Whether the processor uses Intel Turbo Boost Technology, which allows the processor to automatically increase its frequency if it is running below power, temperature, or voltage specifications. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not increase its frequency automatically.</li> <li>• <b>Enabled</b>—The processor utilizes Turbo Boost Technology if required.</li> </ul> <p><b>Note</b>     <b>CPUPowerManagement</b> must be set to <b>Custom</b> or the server ignores the setting for this parameter.</p>
<b>Processor C3 Report</b> <b>set ProcessorC3Report</b>	<p>Whether the BIOS sends the C3 report to the operating system. When the OS receives the report, it can transition the processor into the lower C3 power state to decrease energy usage while maintaining optimal processor performance. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—BIOS does not send C3 report.</li> <li>• <b>Enabled</b>—BIOS sends the C3 report, allowing the OS to transition the processor to the C3 low power state.</li> </ul> <p><b>Note</b>     <b>CPUPowerManagement</b> must be set to <b>Custom</b> or the server ignores the setting for this parameter.</p>

Name	Description
<b>Processor C6 Report</b> <b>set ProcessorC6Report</b>	<p>Whether the BIOS sends the C6 report to the operating system. When the OS receives the report, it can transition the processor into the lower C6 power state to decrease energy usage while maintaining optimal processor performance. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The BIOS does not send the C6 report.</li> <li>• <b>Enabled</b>—The BIOS sends the C6 report, allowing the OS to transition the processor to the C6 low power state.</li> </ul> <p><b>Note</b>     <b>CPUPowerManagement</b> must be set to <b>Custom</b> or the server ignores the setting for this parameter.</p>
<b>Processor Power State C1 Enhanced</b> <b>set ProcessorC1EReport</b>	<p>Whether the CPU transitions to its minimum frequency when entering the C1 state. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The CPU continues to run at its maximum frequency in C1 state.</li> <li>• <b>Enabled</b>—The CPU transitions to its minimum frequency. This option saves the maximum amount of power in C1 state.</li> </ul>
<b>P-STATE Coordination</b> <b>set PsdCoordType</b>	<p>Allows you to define how BIOS communicates the P-state support model to the operating system. There are 3 models as defined by the Advanced Configuration and Power Interface (ACPI) specification.</p> <ul style="list-style-type: none"> <li>• <b>HW_ALL</b>—The processor hardware is responsible for coordinating the P-state among logical processors with dependencies (all logical processors in a package).</li> <li>• <b>SW_ALL</b>—The OS Power Manager (OSPM) is responsible for coordinating the P-state among logical processors with dependencies (all logical processors in a physical package), and must initiate the transition on all of the logical processors.</li> <li>• <b>SW_ANY</b>—The OS Power Manager (OSPM) is responsible for coordinating the P-state among logical processors with dependencies (all logical processors in a package), and may initiate the transition on any of the logical processors in the domain.</li> </ul> <p><b>Note</b>     <b>CPUPowerManagement</b> must be set to <b>Custom</b> or the server ignores the setting for this parameter.</p>

Name	Description
<b>Boot Performance Mode</b> drop-down list <b>set BootPerformanceMode</b>	Allows the user to select the BIOS performance state that is set before the operating system handoff. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Max Performance</b>—Processor P-state ratio is maximum</li> <li>• <b>Max Efficient</b>— Processor P-state ratio is minimum</li> </ul>
<b>Energy Performance Tuning</b> <b>set PwrPerfTuning</b>	Allows you to choose BIOS or Operating System for energy performance bias tuning. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>OS</b>— Chooses OS for energy performance tuning.</li> <li>• <b>BIOS</b>— Chooses BIOS for energy performance tuning.</li> </ul>
<b>Energy Performance</b> <b>set CpuEngPerfBias</b>	Allows you to determine whether system performance or energy efficiency is more important on this server. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Balanced_Energy</b></li> <li>• <b>Balanced_Performance</b></li> <li>• <b>Energy_Efficient</b></li> <li>• <b>Performance</b></li> </ul>

Name	Description
<b>Package C State Limit</b> set PackageCStateLimit	<p>The amount of power available to the server components when they are idle. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>C0_state</b>—The server provides all server components with full power at all times. This option maintains the highest level of performance and requires the greatest amount of power.</li> <li>• <b>C1_state</b>—When the CPU is idle, the system slightly reduces the power consumption. This option requires less power than C0 and allows the server to return quickly to high performance mode.</li> <li>• <b>C3_state</b>—When the CPU is idle, the system reduces the power consumption further than with the C1 option. This requires less power than C1 or C0, but it takes the server slightly longer to return to high performance mode.</li> <li>• <b>C6_state</b>—When the CPU is idle, the system reduces the power consumption further than with the C3 option. This option saves more power than C0, C1, or C3, but there may be performance issues until the server returns to full power.</li> <li>• <b>C7_state</b>—When the CPU is idle, the server makes a minimal amount of power available to the components. This option saves the maximum amount of power but it also requires the longest time for the server to return to high performance mode.</li> <li>• <b>No_Limit</b>—The server may enter any available C state.</li> </ul>
<b>Extended APIC</b> set LocalX2Apic	<p>Allows you to enable or disable extended APIC support. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>XAPIC</b>—Enables APIC support.</li> <li>• <b>X2APIC</b>—Enables APIC and also enables Intel VT-d and Interrupt Remapping .</li> </ul>
<b>Workload Configuration</b> set WorkLdConfig	<p>Allows you to set a parameter to optimize workload characterization. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Balanced</b>— Chooses balanced option for optimization.</li> <li>• <b>I/O Sensitive</b>— Chooses I/O sensitive option for optimization.</li> </ul> <p><b>Note</b> We recommend you to set the workload configuration to <b>Balanced</b>.</p>

Name	Description
<b>CPU HWPM</b> drop-down list <b>set HWPMEnable</b>	Enables the Hardware Power Management (HWPM) interface for better CPU performance and energy efficiency. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The P-States are controlled the same way as on predecessor processor generations.</li> <li>• <b>Native Mode</b>—HWPM works with the operating system through a software interface.</li> <li>• <b>OOB Mode</b>—The CPU autonomously controls its frequency based on the operating system energy efficiency.</li> </ul>
<b>CPU Autonomous Cstate</b> drop-down list <b>set AutonomousCstateEnable</b>	Enables CPU Autonomous C-State, which converts the HALT instructions to the MWAIT instructions. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—CPU Autonomous C-state is disabled. This is the default value.</li> <li>• <b>Enabled</b>—CPU Autonomous C-state is enabled.</li> </ul>
<b>Processor CMCI</b> drop-down list <b>set CmcEnable</b>	Allows the CPU to trigger interrupts on corrected machine check events. The corrected machine check interrupt (CMCI) allows faster reaction than the traditional polling timer. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Disables CMCI.</li> <li>• <b>Enabled</b>—Enables CMCI. This is the default value.</li> </ul>

### Memory Configuration Parameters

Name	Description
<b>Select Memory RAS</b> <b>set SelectMemoryRAS</b>	How the memory reliability, availability, and serviceability (RAS) is configured for the server. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Maximum_Performance</b>—System performance is optimized.</li> <li>• <b>Mirroring</b>—System reliability is optimized by using half the system memory as backup.</li> <li>• <b>Lockstep</b>—If the DIMM pairs in the server have an identical type, size, and organization and are populated across the SMI channels, you can enable lockstep mode to minimize memory access latency and provide better performance. This option offers better system performance than Mirroring and better reliability than Maximum Performance but lower reliability than Mirroring and lower system performance than Maximum Performance.</li> </ul>

Name	Description
<b>NUMA</b> set NUMAOptimize	Whether the BIOS supports Non-Uniform Memory Access (NUMA). This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The BIOS does not support NUMA.</li> <li>• <b>Enabled</b>—The BIOS includes the ACPI tables that are required for NUMA-aware operating systems. If you enable this option, the system must disable Inter-Socket Memory interleaving on some platforms.</li> </ul>
<b>Channel Interleaving</b> set ChannelInterLeave	Whether the CPU divides memory blocks and spreads contiguous portions of data across interleaved channels to enable simultaneous read operations. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Auto</b>—The CPU determines what interleaving is done.</li> <li>• <b>1_Way</b>—Some channel interleaving is used.</li> <li>• <b>2_Way</b></li> <li>• <b>3_Way</b></li> <li>• <b>4_Way</b>—The maximum amount of channel interleaving is used.</li> </ul>
<b>Rank Interleaving</b> set RankInterLeave	Whether the CPU interleaves physical ranks of memory so that one rank can be accessed while another is being refreshed. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Auto</b>—The CPU determines what interleaving is done.</li> <li>• <b>1_Way</b>—Some rank interleaving is used.</li> <li>• <b>2_Way</b></li> <li>• <b>4_Way</b></li> <li>• <b>8_Way</b>—The maximum amount of rank interleaving is used.</li> </ul>
<b>Patrol Scrub</b> set PatrolScrub	Whether the system actively searches for, and corrects, single bit memory errors even in unused portions of the memory on the server. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The system checks for memory ECC errors only when the CPU reads or writes a memory address.</li> <li>• <b>Enabled</b>—The system periodically reads and writes memory searching for ECC errors. If any errors are found, the system attempts to fix them. This option may correct single bit errors before they become multi-bit errors, but it may adversely affect performance when the patrol scrub is running.</li> </ul>



Name	Description
<b>Demand Scrub</b> <b>set DemandScrub</b>	Whether the system corrects single bit memory errors encountered when the CPU or I/O makes a demand read. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>— Single bit memory errors are not corrected.</li> <li>• <b>Enabled</b>— Single bit memory errors are corrected in memory and the corrected data is set in response to the demand read.</li> </ul>
<b>Altitude</b> <b>set Altitude</b>	The approximate number of meters above sea level at which the physical server is installed. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Auto</b>—The CPU determines the physical elevation.</li> <li>• <b>300_M</b>—The server is approximately 300 meters above sea level.</li> <li>• <b>900_M</b>—The server is approximately 900 meters above sea level.</li> <li>• <b>1500_M</b>—The server is approximately 1500 meters above sea level.</li> <li>• <b>3000_M</b>—The server is approximately 3000 meters above sea level.</li> </ul>

#### QPI Configuration Parameters

Name	Description
<b>QPI Link Frequency Select</b> <b>set QPILinkFrequency</b>	The Intel QuickPath Interconnect (QPI) link frequency, in gigatransfers per second (GT/s). This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Auto</b>—The CPU determines the QPI link frequency.</li> <li>• <b>6.4_GT/s</b></li> <li>• <b>7.2_GT/s</b></li> <li>• <b>8.0_GT/s</b></li> </ul>

Name	Description
<b>QPI Snoop Mode</b> set <code>QpiSnoopMode</code>	<p>The Intel QuickPath Interconnect (QPI) snoop mode. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Home Snoop</b>—The snoop is always spawned by the home agent (centralized ring stop) for the memory controller. This mode has a higher local latency than early snoop, but it provides extra resources for a larger number of outstanding transactions.</li> <li>• <b>Cluster on Die</b>—Enables Cluster On Die. When enabled LLC is split into two parts with an independent caching agent for each. This helps increase the performance in some workloads. This mode is available only for processors that have 10 or more cores. It is the best mode for highly NUMA optimized workloads.</li> <li>• <b>Early Snoop</b>—The distributed cache ring stops can send a snoop probe or a request to another caching agent directly. This mode has lower latency and it is best for workloads that have shared data sets across threads and can benefit from a cache-to-cache transfer, or for workloads that are not NUMA optimized.</li> </ul>

### USB Configuration Parameters

Name	Description
<b>Legacy USB Support</b> set <code>LegacyUSBSupport</code>	<p>Whether the system supports legacy USB devices. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—USB devices are only available to EFI applications.</li> <li>• <b>Enabled</b>—Legacy USB support is always available.</li> <li>• <b>Auto</b>—Disables legacy USB support if no USB devices are connected.</li> </ul>
<b>Port 60/64 Emulation</b> set <code>UsbEmul6064</code>	<p>Whether the system supports 60h/64h emulation for complete USB keyboard legacy support. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—60h/64 emulation is not supported.</li> <li>• <b>Enabled</b>—60h/64 emulation is supported.</li> </ul> <p>You should select this option if you are using a non-USB aware operating system on the server.</p>
<b>xHCI Mode</b> set <code>PchUsb30Mode</code>	<p>Whether the xHCI controller legacy support is enabled or disabled. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Disables the xHCI controller legacy support.</li> <li>• <b>Enabled</b>—Enables the xHCI controller legacy support.</li> </ul>

Name	Description
<b>xHCI Legacy Support</b> drop-down list <b>set UsbXhciSupport</b>	Whether the system supports legacy xHCI controller. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Disables xHCI legacy support.</li> <li>• <b>Enabled</b>—Enables xHCI legacy support. This is the default value.</li> </ul>
<b>All USB Devices</b> <b>set AllUsbDevices</b>	Whether all physical and virtual USB devices are enabled or disabled. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—All USB devices are disabled.</li> <li>• <b>Enabled</b>—All USB devices are enabled.</li> </ul>
<b>USB Port: Rear</b> <b>set UsbPortRear</b>	Whether the rear panel USB devices are enabled or disabled. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Disables the rear panel USB ports. Devices connected to these ports are not detected by the BIOS and operating system.</li> <li>• <b>Enabled</b>—Enables the rear panel USB ports. Devices connected to these ports are detected by the BIOS and operating system.</li> </ul>
<b>USB Port: KVM</b> <b>set UsbPortKVM</b>	Whether the vKVM ports are enabled or disabled. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Disables the vKVM keyboard and/or mouse devices. Keyboard and/or mouse will not work in the vKVM window.</li> <li>• <b>Enabled</b>—Enables the vKVM keyboard and/or mouse devices.</li> </ul>
<b>USB Port: vMedia</b> <b>set UsbPortVMedia</b>	Whether the virtual media devices are enabled or disabled. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Disables the vMedia devices.</li> <li>• <b>Enabled</b>—Enables the vMedia devices.</li> </ul>

### PCI Configuration Parameters

Name	Description
<b>Memory Mapped I/O Above 4GB</b> <b>set MemoryMappedIOAbove4GB</b>	<p>Whether to enable or disable MMIO above 4GB or not. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The server does not map I/O of 64-bit PCI devices to 4GB or greater address space.</li> <li>• <b>Enabled</b>—The server maps I/O of 64-bit PCI devices to 4GB or greater address space.</li> </ul> <p><b>Note</b> PCI devices that are 64-bit compliant but use a legacy option ROM may not function correctly with this setting enabled.</p>
<b>SrIov</b> <b>set SrIov</b>	<p>Whether SR-IOV (Single Root I/O Virtualization) is enabled or disabled on the server. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—SR-IOV is disabled.</li> <li>• <b>Enabled</b>—SR-IOV is enabled.</li> </ul>

### Serial Configuration Parameters

Name	Description
<b>Out-of-Band Mgmt Port</b> <b>set comSpcrEnable</b>	<p>Allows you to configure the COM port 0 that can be used for Windows Emergency Management services. ACPI SPCR table is reported based on this setup option. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Configures the COM port 0 as a general purpose port for use with the Windows Operating System.</li> <li>• <b>Enabled</b>—Configures the COM port 0 as a remote management port for Windows Emergency Management services.</li> </ul>
<b>Console Redirection</b> <b>set ConsoleRedir</b>	<p>Allows a serial port to be used for console redirection during POST and BIOS booting. After the BIOS has booted and the operating system is responsible for the server, console redirection is irrelevant and has no effect. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—No console redirection occurs during POST.</li> <li>• <b>COM_0</b>—Enables console redirection on COM port 0 during POST.</li> <li>• <b>COM_1</b>—Enables console redirection on COM port 1 during POST.</li> </ul>

Name	Description
<b>Terminal Type</b> <b>set TerminalType</b>	<p>What type of character formatting is used for console redirection. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>PC-ANSI</b>—The PC-ANSI terminal font is used.</li> <li>• <b>VT100</b>—A supported vt100 video terminal and its character set are used.</li> <li>• <b>VT100+</b>—A supported vt100-plus video terminal and its character set are used.</li> <li>• <b>VT-UTF8</b>—A video terminal with the UTF-8 character set is used.</li> </ul> <p><b>Note</b> This setting must match the setting on the remote terminal application.</p>
<b>Bits per second</b> <b>set BaudRate</b>	<p>What BAUD rate is used for the serial port transmission speed. If you disable Console Redirection, this option is not available. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>9600</b>—A 9,600 BAUD rate is used.</li> <li>• <b>19200</b>—A 19,200 BAUD rate is used.</li> <li>• <b>38400</b>—A 38,400 BAUD rate is used.</li> <li>• <b>57600</b>—A 57,600 BAUD rate is used.</li> <li>• <b>115200</b>—A 115,200 BAUD rate is used.</li> </ul> <p><b>Note</b> This setting must match the setting on the remote terminal application.</p>
<b>Flow Control</b> <b>set FlowCtrl</b>	<p>Whether a handshake protocol is used for flow control. Request to Send / Clear to Send (RTS/CTS) helps to reduce frame collisions that can be introduced by a hidden terminal problem. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>None</b>—No flow control is used.</li> <li>• <b>Hardware_RTS/CTS</b>—RTS/CTS is used for flow control.</li> </ul> <p><b>Note</b> This setting must match the setting on the remote terminal application.</p>

Name	Description
<b>Putty KeyPad</b> set <b>PuttyFunctionKeyPad</b>	Allows you to change the action of the PuTTY function keys and the top row of the numeric keypad. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>VT100</b>—The function keys generate <b>ESC OP</b> through <b>ESC O[</b> .</li> <li>• <b>LINUX</b>—Mimics the Linux virtual console. Function keys F6 to F12 behave like the default mode, but F1 to F5 generate <b>ESC [ [A</b> through <b>ESC [ [E</b>.</li> <li>• <b>XTERMR6</b>—Function keys F5 to F12 behave like the default mode. Function keys F1 to F4 generate <b>ESC OP</b> through <b>ESC OS</b>, which are the sequences produced by the top row of the keypad on Digital terminals.</li> <li>• <b>SCO</b>—The function keys F1 to F12 generate <b>ESC [M</b> through <b>ESC [X</b>. The function and shift keys generate <b>ESC [Y</b> through <b>ESC [j</b>. The control and function keys generate <b>ESC [k</b> through <b>ESC [v</b>. The shift, control and function keys generate <b>ESC [w</b> through <b>ESC [ {</b>.</li> <li>• <b>ESCN</b>—The default mode. The function keys match the general behavior of Digital terminals. The function keys generate sequences such as <b>ESC [11~</b> and <b>ESC [12~</b>.</li> <li>• <b>VT400</b>—The function keys behave like the default mode. The top row of the numeric keypad generates <b>ESC OP</b> through <b>ESC OS</b>.</li> </ul>
<b>Redirection After BIOS POST</b> set <b>RedirectionAfterPOST</b>	Whether BIOS console redirection should be active after BIOS POST is complete and control given to the OS bootloader. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Always_Enable</b>—BIOS Legacy console redirection is active during the OS boot and run time.</li> <li>• <b>Bootloader</b>—BIOS Legacy console redirection is disabled before giving control to the OS boot loader.</li> </ul>

### LOM and PCIe Slots Configuration Parameters

Name	Description
<b>CDN Support for VIC</b> set <b>CdnEnable</b>	Whether the Ethernet Network naming convention is according to Consistent Device Naming (CDN) or the traditional way of naming conventions. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>— CDN support for VIC cards is disabled.</li> <li>• <b>Enabled</b>— CDN support is enabled for VIC cards.</li> </ul> <p><b>Note</b>      CDN support for VIC cards work with Windows 2012 or the latest OS only.</p>

Name	Description
<b>PCI ROM CLP</b> <b>set PciRomClp</b>	PCI ROM Command Line Protocol (CLP) controls the execution of different Option ROMs such as PxE and iSCSI that are present in the card. By default, it is disabled. <ul style="list-style-type: none"> <li>• <b>Enabled</b>— Enables you to configure execution of different option ROMs such as PxE and iSCSI for an individual ports separately.</li> <li>• <b>Disabled</b>—The default option. You cannot choose different option ROMs. A default option ROM is executed during PCI enumeration.</li> </ul>
<b>All PCIe Slots OptionROM</b> <b>set PcieOptionROMs</b>	Whether the server can use Option ROM present in the PCIe Cards. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The Option ROM for slot <i>n</i> is not available.</li> <li>• <b>Enabled</b>—The Option ROM for slot <i>n</i> is available.</li> <li>• <b>UEFI_Only</b>—The Option ROM for slot <i>n</i> is available for UEFI only.</li> <li>• <b>Legacy_Only</b>—The Option ROM for slot <i>n</i> is available for legacy only.</li> </ul>
<b>PCH SATA Mode</b> <b>set SataModeSelect</b>	This options allows you to select the PCH SATA mode. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>AHCI</b>—Sets both SATA and sSATA controllers to AHCI mode.</li> <li>• <b>Disabled</b>—Disables both SATA and sSATA controllers.</li> <li>• <b>LSI SW Raid</b>— Sets both SATA and sSATA controllers to raid mode for LSI SW Raid</li> </ul>
<b>SBNVMe1 OptionROM</b> <b>set SBNVMe1OptionROM</b>	Whether the server can use Option ROM present in SBNVMe1 controller. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The Option ROM for SBNVMe1 controllers is not available.</li> <li>• <b>Enabled</b>—The Option ROMs for SBNVMe1 controller is available.</li> <li>• <b>UEFI_Only</b>—The Option ROMs for slot are available for UEFI only.</li> <li>• <b>Legacy_Only</b>—The Option ROM for slot are available for legacy only.</li> </ul>

Name	Description
<b>SIOC1 OptionROM</b> set SIOC1OptionROM	Whether the server can use Option ROM present in System IO Controller 1 (SIOC1). This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The Option ROM for System IO Controller 1 (SIOC1) is not available.</li> <li>• <b>Enabled</b>—The Option ROMs for System IO Controller 1 (SIOC1) is available.</li> <li>• <b>UEFI_Only</b>—The Option ROMs for slot are available for UEFI only.</li> <li>• <b>Legacy_Only</b>—The Option ROM for slot are available for legacy only.</li> </ul>
<b>SIOC2 OptionROM</b> set SIOC2OptionROM	Whether the server can use Option ROM present in System IO Controller 2 (SIOC2). This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The Option ROM for System IO Controller 2 (SIOC2) is not available.</li> <li>• <b>Enabled</b>—The Option ROMs for System IO Controller 2 (SIOC2) is available.</li> <li>• <b>UEFI_Only</b>—The Option ROMs for slot are available for UEFI only.</li> <li>• <b>Legacy_Only</b>—The Option ROM for slot are available for legacy only.</li> </ul>
<b>SBMezz1 OptionROM</b> set SBMezz1OptionROM	Whether the server can use Option ROM present in SBMezz1 controller. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The Option ROM for SBMezz1 controllers is not available.</li> <li>• <b>Enabled</b>—The Option ROMs for SBMezz1 controller is available.</li> <li>• <b>UEFI_Only</b>—The Option ROMs for slot are available for UEFI only.</li> <li>• <b>Legacy_Only</b>—The Option ROM for slot are available for legacy only.</li> </ul>



Name	Description
<b>SBMezz2 OptionROM</b> drop-down list <b>set SBMezz2OptionROM</b>	Whether the server can use Option ROM that is available in the SBMezz2 controller. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The Option ROM for SBMezz 2 controllers is not available.</li> <li>• <b>Enabled</b>—The Option ROM for SBMezz 2 controllers is available.</li> <li>• <b>UEFI Only</b>—The Option ROMs for slot are available for UEFI only.</li> <li>• <b>Legacy Only</b>—The Option ROMs for slot are available for legacy only.</li> </ul>
<b>IOESlot1 OptionROM</b> <b>set IOESlot1OptionROM</b>	Whether option ROM is enabled on the IOE slot 1. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>— Option ROM is disabled.</li> <li>• <b>Enabled</b>— Default value. Option ROM is enabled.</li> <li>• <b>UEFI Only</b>— slot 1 option ROM is available for UEFI only.</li> <li>• <b>Legacy Only</b>— slot 1 option ROM is available for legacy only.</li> </ul>
<b>IOEMezz1 OptionROM</b> <b>set IOEMezz1OptionROM</b>	Whether option ROM is enabled on the IOE Mezz1. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>— Option ROM is disabled.</li> <li>• <b>Enabled</b>— Default value. Option ROM is enabled.</li> <li>• <b>UEFI Only</b>— Mezz1 option ROM is available for UEFI only.</li> <li>• <b>Legacy Only</b>— Mezz1 option ROM is available for legacy only.</li> </ul>
<b>IOESlot2 OptionROM</b> <b>set IOESlot2OptionROM</b>	Whether option ROM is enabled on the IOE slot 2. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>— Option ROM is disabled.</li> <li>• <b>Enabled</b>— Default value. Option ROM is enabled.</li> <li>• <b>UEFI Only</b>— slot 2 option ROM is available for UEFI only.</li> <li>• <b>Legacy Only</b>— slot 2 option ROM is available for legacy only.</li> </ul>

Name	Description
<b>IOENVMe1 OptionROM</b> <b>set IOENVMe1OptionROM</b>	Whether option ROM is enabled on the IOE NVMe1. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>— Option ROM is disabled.</li> <li>• <b>Enabled</b>— Default value. Option ROM is enabled.</li> <li>• <b>UEFI Only</b>— Mezz1 option ROM is available for UEFI only.</li> <li>• <b>Legacy Only</b>— Mezz1 option ROM is available for legacy only.</li> </ul>
<b>IOENVMe2 OptionROM</b> <b>set IOENVMe2OptionROM</b>	Whether option ROM is enabled on the IOE NVMe2. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>— Option ROM is disabled.</li> <li>• <b>Enabled</b>— Default value. Option ROM is enabled.</li> <li>• <b>UEFI Only</b>— Mezz1 option ROM is available for UEFI only.</li> <li>• <b>Legacy Only</b>— Mezz1 option ROM is available for legacy only.</li> </ul>
<b>SBNVMe1 Link Speed</b> <b>Set SBNVMe1LinkSpeed</b>	SBNVMe1 add-on slot 1 link speed. <ul style="list-style-type: none"> <li>• <b>Auto</b>—Link speed is automatically assigned.</li> <li>• <b>GEN1</b>— Link speed can reach up to first generation.</li> <li>• <b>GEN2</b>—The default link speed. Link speed can reach up to second generation.</li> <li>• <b>GEN3</b>— Link speed can reach up to third generation.</li> <li>• <b>Disabled</b>—Slot is disabled, and the card is not enumerated.</li> </ul>
<b>SIOC1 Link Speed</b> <b>Set PcieSlot1LinkSpeed</b>	System IO Controller 1 (SIOC1) add-on slot 1 link speed. <ul style="list-style-type: none"> <li>• <b>GEN1</b> — Link speed can reach up to first generation.</li> <li>• <b>GEN2</b> — Link speed can reach up to second generation.</li> <li>• <b>GEN3</b>— The default link speed. Link speed can reach up to third generation.</li> <li>• <b>Disabled</b> — Slot is disabled, and the card is not enumerated.</li> </ul>
<b>SIOC2 Link Speed</b> <b>set PcieSlot2LinkSpeed</b>	System IO Controller 2 (SIOC2) add-on slot 2 link speed. <ul style="list-style-type: none"> <li>• <b>GEN1</b> — Link speed can reach up to first generation.</li> <li>• <b>GEN2</b> — Link speed can reach up to second generation.</li> <li>• <b>GEN3</b>— The default link speed. Link speed can reach up to third generation.</li> <li>• <b>Disabled</b> — Slot is disabled, and the card is not enumerated.</li> </ul>

Name	Description
<b>SBMezz1 Link Speed</b> <b>set SBMezz1LinkSpeed</b>	SBMezz1 add-on slot 1 link speed. <ul style="list-style-type: none"> <li>• <b>Auto</b>—Link speed is automatically assigned.</li> <li>• <b>GEN1</b>— Link speed can reach up to first generation.</li> <li>• <b>GEN2</b>—The default link speed. Link speed can reach up to second generation.</li> <li>• <b>GEN3</b>— Link speed can reach up to third generation.</li> <li>• <b>Disabled</b>—Slot is disabled, and the card is not enumerated.</li> </ul>
<b>SBMezz2 Link Speed</b> drop-down list <b>set SBMezz2LinkSpeed</b>	Assigns SBMezz2 add-on slot 2 link speed. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Auto</b>— Default value. Slot is enabled.</li> <li>• <b>GEN 1</b>— Link speed can reach up to first generation.</li> <li>• <b>GEN 2</b>— Link speed can reach up to second generation.</li> <li>• <b>GEN 3</b>— Link speed can reach up to third generation.</li> <li>• <b>Disabled</b>—Slot is disabled, and the card is not enumerated.</li> </ul>
<b>IOESlot1 Link Speed</b> <b>set IOESlot1LinkSpeed</b>	Slot 1 link speed. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Auto</b>— Default value. Slot is enabled.</li> <li>• <b>GEN 1</b>— Link speed can reach up to first generation.</li> <li>• <b>GEN 2</b>— Link speed can reach up to second generation.</li> <li>• <b>GEN 3</b>— Link speed can reach up to third generation.</li> <li>• <b>Disabled</b>—Slot is disabled, and the card is not enumerated.</li> </ul>
<b>IOEMezz1 Link Speed</b> <b>set IOEMezz1LinkSpeed</b>	Mezz1 link speed. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Auto</b>— Default value. Slot is enabled.</li> <li>• <b>GEN 1</b>— Link speed can reach up to first generation.</li> <li>• <b>GEN 2</b>— Link speed can reach up to second generation.</li> <li>• <b>GEN 3</b>— Link speed can reach up to third generation.</li> <li>• <b>Disabled</b>—Slot is disabled, and the card is not enumerated.</li> </ul>

Name	Description
<b>IOESlot2 Link Speed</b> set IOESlot2LinkSpeed	Slot 2 link speed. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Auto</b>— Default value. Slot is enabled.</li> <li>• <b>GEN 1</b>— Link speed can reach up to first generation.</li> <li>• <b>GEN 2</b>— Link speed can reach up to second generation.</li> <li>• <b>GEN 3</b>— Link speed can reach up to third generation.</li> <li>• <b>Disabled</b>—Slot is disabled, and the card is not enumerated.</li> </ul>
<b>IOENVMe1 Link Speed</b> set IOENVMe1LinkSpeed	NVMe1 link speed. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Auto</b>— Default value. Slot is enabled.</li> <li>• <b>GEN 1</b>— Link speed can reach up to first generation.</li> <li>• <b>GEN 2</b>— Link speed can reach up to second generation.</li> <li>• <b>GEN 3</b>— Link speed can reach up to third generation.</li> <li>• <b>Disabled</b>—Slot is disabled, and the card is not enumerated.</li> </ul>
<b>IOENVMe2 Link Speed</b> set IOENVMe2LinkSpeed	NVMe2 link speed. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Auto</b>— Default value. Slot is enabled.</li> <li>• <b>GEN 1</b>— Link speed can reach up to first generation.</li> <li>• <b>GEN 2</b>— Link speed can reach up to second generation.</li> <li>• <b>GEN 3</b>— Link speed can reach up to third generation.</li> <li>• <b>Disabled</b>—Slot is disabled, and the card is not enumerated.</li> </ul>

### BIOS Configuration Dialog Box Button Bar



#### Important

The buttons in this dialog box affect all BIOS parameters on all available tabs, not just the parameters on the tab that you are viewing.

Name	Description
<b>Save Changes</b> button	Saves the settings for the BIOS parameters on all three tabs and closes the dialog box.  If the <b>Reboot Host Immediately</b> check box is checked, the server is rebooted immediately and the new BIOS settings go into effect. Otherwise the changes are saved until the server is manually rebooted.
<b>Reset Values</b> button	Restores the values for the BIOS parameters on all three tabs to the settings that were in effect when this dialog box was first opened.

Name	Description
<b>Restore Defaults</b> button	Sets the BIOS parameters on all three tabs to their default settings.
<b>Cancel</b> button	Closes the dialog box without making any changes.

## Server Management Tab

### Server Management BIOS Parameters

Name	Description
<b>FRB-2 Timer</b> set <b>FRB-2</b>	Whether the FRB2 timer is used by Cisco IMC to recover the system if it hangs during POST. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The FRB2 timer is not used.</li> <li>• <b>Enabled</b>—The FRB2 timer is started during POST and used to recover the system if necessary.</li> </ul>
<b>OS Watchdog Timer</b> set <b>OSBootWatchdogTimer</b>	Whether the BIOS programs the watchdog timer with a specified timeout value. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The watchdog timer is not used to track how long the server takes to boot.</li> <li>• <b>Enabled</b>—The watchdog timer tracks how long the server takes to boot. If the server does not boot within the length of time specified by the set <b>OSBootWatchdogTimerTimeout</b> command, the Cisco IMC logs an error and takes the action specified by the set <b>OSBootWatchdogTimerPolicy</b> command.</li> </ul>
<b>OS Watchdog Timer Timeout</b> set <b>OSBootWatchdogTimerTimeOut</b>	If OS does not boot within the specified time, OS watchdog timer expires and system takes action according to timer policy. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>5_Minutes</b>—The OS watchdog timer expires 5 minutes after it begins to boot.</li> <li>• <b>10_Minutes</b>—The OS watchdog timer expires 10 minutes after it begins to boot.</li> <li>• <b>15_Minutes</b>—The OS watchdog timer expires 15 minutes after it begins to boot.</li> <li>• <b>20_Minutes</b>—The OS watchdog timer expires 20 minutes after it begins to boot.</li> </ul> <p><b>Note</b> This option is only applicable if you enable the OS Boot Watchdog Timer.</p>

Name	Description
<b>OS Watchdog Timer Policy</b> set <code>OSBootWatchdogTimerPolicy</code>	What action the system takes if the watchdog timer expires. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Do_Nothing</b>—The server takes no action if the watchdog timer expires during OS boot.</li> <li>• <b>Power_Down</b>—The server is powered off if the watchdog timer expires during OS boot.</li> <li>• <b>Reset</b>—The server is reset if the watchdog timer expires during OS boot.</li> </ul> <p><b>Note</b> This option is only applicable if you enable the OS Boot Watchdog Timer.</p>

## S3260 M5 Servers

### I/O Tab



**Note** BIOS parameters listed in this tab may vary depending on the server.

*Table 2: BIOS Parameters in I/O Tab*

Name	Description
<b>Reboot Host Immediately</b> checkbox	Upon checking, reboots the host server immediately. You must check the checkbox after saving changes.
<b>Legacy USB Support</b> drop-down list set <code>UsbLegacySupport</code>	Whether the system supports legacy USB devices. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—USB devices are only available to EFI applications.</li> <li>• <b>Enabled</b>—Legacy USB support is always available.</li> </ul>
<b>Intel VT for directed IO</b> drop-down list set <code>IntelVTD</code>	Whether the processor uses Intel Virtualization Technology (VT), which allows a platform to run multiple operating systems and applications in independent partitions. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not permit virtualization.</li> <li>• <b>Enabled</b>—The processor allows multiple operating systems in independent partitions.</li> </ul> <p><b>Note</b> If you change this option, you must power cycle the server before the setting takes effect.</p>

Name	Description
<b>Intel VTD coherency support</b> drop-down list <b>set CoherencySupport</b>	Whether the processor supports Intel VT-d Coherency. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not support coherency.</li> <li>• <b>Enabled</b>—The processor uses VT-d Coherency as required.</li> </ul>
<b>Intel VTD ATS support</b> drop-down list <b>set ATS</b>	Whether the processor supports Intel VT-d Address Translation Services (ATS). This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not support ATS.</li> <li>• <b>Enabled</b>—The processor uses VT-d ATS as required.</li> </ul>
<b>VMD Enable</b> drop-down list	Intel Volume Management Device (VMD) is for PCIe NVMe SSDs that provides hardware logic to manage and aggregate NVMe SSDs. <p>This can be one the following:</p> <ul style="list-style-type: none"> <li>• <b>Enabled</b>— Enables benefits like robust surprise hot-plug, status LED management.</li> <li>• <b>Disabled</b>— Disables benefits like robust surprise hot-plug, status LED management.</li> </ul> <p>Default value: <b>Disabled</b>.</p> <p>Refer <a href="#">Intel® Virtual RAID on CPU User Guide</a> and <a href="#">Intel® Virtual RAID on CPU (Intel® VROC)</a> to configure VMD.</p>
<b>All Onboard LOM Oprom</b> drop-down list <b>set AllLomPortControl</b>	Whether Option ROM is available on all LOM ports. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Option ROM is disabled on all the ports.</li> <li>• <b>Enabled</b>—Option ROM is enabled on all the ports.</li> </ul>
<b>Onboard LOM Port0 Oprom</b> drop-down list <b>set LomOpromControlPort0</b>	Whether Option ROM is available on the LOM port 0. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Option ROM is not available on LOM port 0.</li> <li>• <b>Enabled</b>—Option ROM is available on LOM port 0.</li> </ul>
<b>Onboard LOM Port1 Oprom</b> drop-down list <b>set LomOpromControlPort1</b>	Whether Option ROM is available on the LOM port 1. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Option ROM is not available on LOM port 1.</li> <li>• <b>Enabled</b>—Option ROM is available on LOM port 1.</li> </ul>

Name	Description
<b>Pcie Slot<math>n</math> Oprom</b> drop-down list  <b>set</b> <b>PcieSlot<math>n</math>OptionROM</b>	Whether the server can use the Option ROMs present in the PCIe card slot designated by $n$ . This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Option ROM for slot <math>n</math> is not available.</li> <li>• <b>Enabled</b>—Option ROM for slot <math>n</math> is available.</li> </ul>
<b>MLOM Oprom</b> drop-down list  <b>set</b> <b>PcieSlotMLOMOptionROM</b>	This options allows you to control the Option ROM execution of the PCIe adapter connected to the MLOM slot. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Does not execute Option ROM of the PCIe adapter connected to the MLOM slot.</li> <li>• <b>Enabled</b>—Executes Option ROM of the PCIe adapter connected to the MLOM slot.</li> </ul>
<b>HBA Oprom</b> drop-down list  <b>set</b> <b>PcieSlotHBAOptionROM</b>	This options allows you to control the Option ROM execution of the PCIe adapter connected to the HBA slot. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Does not execute Option ROM of the PCIe adapter connected to the HBA slot.</li> <li>• <b>Enabled</b>—Executes Option ROM of the PCIe adapter connected to the HBA slot.</li> </ul>
<b>Front NVME1 Oprom</b> drop-down list  <b>set</b> <b>PcieSlotN1OptionROM</b>	This options allows you to control the Option ROM execution of the PCIe adapter connected to the SSD:NVMe1 slot. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Does not execute Option ROM of the PCIe adapter connected to the SSD:NVMe1 slot.</li> <li>• <b>Enabled</b>—Executes Option ROM of the PCIe adapter connected to the SSD:NVMe1 slot</li> </ul>
<b>Front NVME2 Oprom</b> drop-down list  <b>set</b> <b>PcieSlotN2OptionROM</b>	This options allows you to control the Option ROM execution of the PCIe adapter connected to the SSD:NVMe2 slot. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Does not execute Option ROM of the PCIe adapter connected to the SSD:NVMe2 slot.</li> <li>• <b>Enabled</b>—Executes Option ROM of the PCIe adapter connected to the SSD:NVMe2 slot</li> </ul>



Name	Description
<b>HBA Link Speed</b> drop-down list  <b>set</b> <b>PcieSlotHBALinkSpeed</b>	This option allows you to restrict the maximum speed of an adapter card installed in PCIe HBA slot. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The maximum speed is not restricted.</li> <li>• <b>Auto</b>—System selects the maximum speed allowed.</li> <li>• <b>GEN1</b>—2.5GT/s (gigatransfers per second) is the maximum speed allowed.</li> <li>• <b>GEN2</b>—5GT/s is the maximum speed allowed.</li> <li>• <b>GEN3</b>—8GT/s is the maximum speed allowed.</li> </ul>
<b>MLOM Link Speed</b> drop-down list  <b>set</b> <b>PcieSlotMLOMLinkSpeed</b>	This option allows you to restrict the maximum speed of an adapter card installed in PCIe MLOM slot. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The maximum speed is not restricted.</li> <li>• <b>Auto</b>—System selects the maximum speed allowed.</li> <li>• <b>GEN1</b>—2.5GT/s (gigatransfers per second) is the maximum speed allowed.</li> <li>• <b>GEN2</b>—5GT/s is the maximum speed allowed.</li> <li>• <b>GEN3</b>—8GT/s is the maximum speed allowed.</li> </ul>
<b>PCIe Slot<math>n</math> Link Speed</b> drop-down list  <b>set</b> <b>PcieSlot<math>n</math>LinkSpeed</b>	System IO Controller $n$ (SIOCN) add-on slot (designated by $n$ ) link speed. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Slot is disabled, and the card is not enumerated.</li> <li>• <b>Auto</b>— The default link speed. Link speed is automatically assigned.</li> <li>• <b>GEN1</b>—Link speed can reach up to first generation.</li> <li>• <b>GEN2</b>—Link speed can reach up to second generation.</li> <li>• <b>GEN3</b>—Link speed can reach up to third generation.</li> </ul>
<b>Front NVME1 Link Speed</b> drop-down list  <b>set</b> <b>PcieSlotFrontNvme1LinkSpeed</b>	Link speed for NVMe front slot 1. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Slot is disabled, and the card is not enumerated.</li> <li>• <b>Auto</b>—The default link speed. Link speed is automatically assigned.</li> <li>• <b>GEN1</b>—Link speed can reach up to first generation.</li> <li>• <b>GEN2</b>—Link speed can reach up to second generation.</li> <li>• <b>GEN3</b>—Link speed can reach up to third generation.</li> </ul>

Name	Description
<b>Front NVME2 Link Speed</b> drop-down list set PcieSlotFrontNvme2LinkSpeed	Link speed for NVMe front slot 2. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Slot is disabled, and the card is not enumerated.</li> <li>• <b>Auto</b>—The default link speed. Link speed is automatically assigned.</li> <li>• <b>GEN1</b>—Link speed can reach up to first generation.</li> <li>• <b>GEN2</b>—Link speed can reach up to second generation.</li> <li>• <b>GEN3</b>—Link speed can reach up to third generation.</li> </ul>
<b>Rear NVME1 Link Speed</b> drop-down list set PcieSlotRearNvme1LinkSpeed	Link speed for NVMe rear slot 1. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Slot is disabled, and the card is not enumerated.</li> <li>• <b>Auto</b>—The default link speed. Link speed is automatically assigned.</li> <li>• <b>GEN1</b>—Link speed can reach up to first generation.</li> <li>• <b>GEN2</b>—Link speed can reach up to second generation.</li> <li>• <b>GEN3</b>—Link speed can reach up to third generation.</li> </ul>
<b>Rear NVME2 Link Speed</b> drop-down list set PcieSlotRearNvme2LinkSpeed	Link speed for NVMe rear slot 2. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Slot is disabled, and the card is not enumerated.</li> <li>• <b>Auto</b>—The default link speed. Link speed is automatically assigned.</li> <li>• <b>GEN1</b>—Link speed can reach up to first generation.</li> <li>• <b>GEN2</b>—Link speed can reach up to second generation.</li> <li>• <b>GEN3</b>—Link speed can reach up to third generation.</li> </ul>
<b>VGA Priority</b> drop-down list set VgaPriority	Allows you to set the priority for VGA graphics devices if multiple VGA devices are found in the system. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>OnBoard</b>—Priority is given to the onboard VGA device. BIOS post screen and OS boot are driven through the onboard VGA port.</li> <li>• <b>OffBoard</b>—Priority is given to the PCIE Graphics adapter. BIOS post screen and OS boot are driven through the external graphics adapter port.</li> <li>• <b>OnBoardDisabled</b>—Priority is given to the PCIe Graphics adapter, and the onboard VGA device is disabled. The vKVM does not function when the onboard VGA is disabled.</li> </ul>
<b>P-SATA OptionROM</b> drop-down list set pSATA	Allows you to select the PCH SATA optionROM mode. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>LSI SW Raid</b>— Sets both SATA and sSATA controllers to raid mode for LSI SW Raid.</li> <li>• <b>Disabled</b>— Disables both SATA and sSATA controllers.</li> </ul>

Name	Description
<b>M2.SATA OptionROM</b> drop-down list  <b>set SataModeSelect</b>	Mode of operation of Serial Advanced Technology Attachment (SATA) Solid State Drives (SSD). This can be one of the following: <ul style="list-style-type: none"> <li>• <b>AHCI</b>— Sets both SATA and sSATA controllers to AHCI mode.</li> <li>• <b>LSI SW Raid</b>— Sets both SATA and sSATA controllers to raid mode for LSI SW Raid.</li> <li>• <b>Disabled</b>— Disables both SATA and sSATA controllers.</li> </ul>
<b>USB Port Rear</b> drop-down list  <b>set UsbPortRear</b>	Whether the rear panel USB devices are enabled or disabled. This can be one of the following <ul style="list-style-type: none"> <li>• <b>Disabled</b>— Disables the rear panel USB ports. Devices connected to these ports are not detected by the BIOS and operating system.</li> <li>• <b>Enabled</b>— Enables the rear panel USB ports. Devices connected to these ports are detected by the BIOS and operating system.</li> </ul>
<b>USB Port Front</b> drop-down list  <b>set UsbPortFront</b>	Whether the front panel USB devices are enabled or disabled. This can be one of the following <ul style="list-style-type: none"> <li>• <b>Disabled</b>— Disables the front panel USB ports. Devices connected to these ports are not detected by the BIOS and operating system.</li> <li>• <b>Enabled</b>— Enables the front panel USB ports. Devices connected to these ports are detected by the BIOS and operating system.</li> </ul>
<b>USB Port Internal</b> drop-down list  <b>set UsbPortInt</b>	Whether the internal USB devices are enabled or disabled. This can be one of the following <ul style="list-style-type: none"> <li>• <b>Disabled</b>— Disables the internal USB ports. Devices connected to these ports are not detected by the BIOS and operating system.</li> <li>• <b>Enabled</b>— Enables the internal USB ports. Devices connected to these ports are detected by the BIOS and operating system.</li> </ul>
<b>USB Port KVM</b> drop-down list  <b>set UsbPortKVM</b>	Whether the vKVM ports are enabled or disabled. This can be one of the following <ul style="list-style-type: none"> <li>• <b>Disabled</b>— Disables the vKVM keyboard and/or mouse devices. Keyboard and/or mouse will not work in the KVM window.</li> <li>• <b>Enabled</b>— Enables the vKVM keyboard and/or mouse devices.</li> </ul>
<b>USB Port SD Card</b> drop-down list  <b>set UsbPortSdCard</b>	Whether the SD card is enabled or disabled. This can be one of the following <ul style="list-style-type: none"> <li>• <b>Disabled</b>— Disables the SD card ports. Devices connected to these ports are not detected by the BIOS and operating system.</li> <li>• <b>Enabled</b>— Enables the SD card ports. Devices connected to these ports are detected by the BIOS and operating system.</li> </ul>

Name	Description
<b>IPv6 PXE Support</b> drop-down list set <b>IPV6PXE</b>	Enables or disables IPv6 support for PXE. This can be one of the following <ul style="list-style-type: none"> <li>• <b>disabled</b>—IPv6 PXE support is not available.</li> <li>• <b>enabled</b>—IPv6 PXE support is always available.</li> </ul>

## Server Management Tab



**Note** BIOS parameters listed in this tab may vary depending on the server.

*Table 3: BIOS Parameters in Server Management Tab*

Name	Description
<b>Reboot Host Immediately</b> checkbox	If the Reboot Host Immediately check box is checked, the server is rebooted immediately and the new BIOS settings go into effect. Otherwise the changes are saved until the server is manually rebooted.
<b>OS Boot Watchdog Timer Policy</b> drop-down list set <b>OSBootWatchdogTimerPolicy</b>	What action the system takes if the watchdog timer expires. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Power Off</b>—The server is powered off if the watchdog timer expires during OS boot.</li> <li>• <b>Reset</b>—The server is reset if the watchdog timer expires during OS boot.</li> </ul> <p><b>Note</b> This option is only applicable if you enable the OS Boot Watchdog Timer.</p>
<b>OS Watchdog Timer</b> drop-down list set <b>OSBootWatchdogTimer</b>	Whether the BIOS programs the watchdog timer with a specified timeout value. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The watchdog timer is not used to track how long the server takes to boot.</li> <li>• <b>Enabled</b>—The watchdog timer tracks how long the server takes to boot. If the server does not boot within the length of time specified in the <b>OS Boot Watchdog Timer Timeout</b> field, the Cisco IMC logs an error and takes the action specified in the <b>OS Boot Watchdog Policy</b> field.</li> </ul>

Name	Description
<p><b>OS Watchdog Timer Timeout</b> drop-down list  <b>set OSBootWatchdogTimerTimeOut</b></p>	<p>If OS does not boot within the specified time, OS watchdog timer expires and system takes action according to timer policy. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>5 Minutes</b>—The OS watchdog timer expires 5 minutes after it begins to boot.</li> <li>• <b>10 Minutes</b>—The OS watchdog timer expires 10 minutes after it begins to boot.</li> <li>• <b>15 Minutes</b>—The OS watchdog timer expires 15 minutes after it begins to boot.</li> <li>• <b>20 Minutes</b>—The OS watchdog timer expires 20 minutes after it begins to boot.</li> </ul> <p><b>Note</b> This option is only applicable if you enable the OS Boot Watchdog Timer.</p>
<p><b>Baud Rate</b> drop-down list  <b>set BaudRate</b></p>	<p>What Baud rate is used for the serial port transmission speed. If you disable Console Redirection, this option is not available. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>9.6k</b>—A 9,600 Baud rate is used.</li> <li>• <b>19.2k</b>—A 19,200 Baud rate is used.</li> <li>• <b>38.4k</b>—A 38,400 Baud rate is used.</li> <li>• <b>57.6k</b>—A 57,600 Baud rate is used.</li> <li>• <b>115.2k</b>—A 115,200 Baud rate is used.</li> </ul> <p>This setting must match the setting on the remote terminal application.</p>
<p><b>Console Redirection</b> drop-down list  <b>set ConsoleRedir</b></p>	<p>Allows a serial port to be used for console redirection during POST and BIOS booting. After the OS has booted, console redirection is irrelevant. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Serial Port A</b>—Enables console redirection on serial port A during POST.</li> <li>• <b>Serial Port B</b>—Enables console redirection on serial port B during POST.</li> <li>• <b>Disabled</b>—No console redirection occurs during POST.</li> </ul>

Name	Description
<b>Adaptive Memory Training</b>	<p>When this option is <b>Enabled</b>:</p> <p>The Memory training will not happen in every boot but the BIOS will use the saved memory training result in every re-boot.</p> <p>Some exceptions when memory training happens in every boot are:</p> <p>BIOS update, CMOS reset, CPU or Memory configuration change, SPD or run-time uncorrectable error or the last boot has occurred more than 24 hours before.</p> <p>When this option is <b>Disabled</b>, the Memory training happens in every boot.</p> <p>Default value: <b>Enabled</b>.</p> <p><b>Note</b> To disable the Fast Boot option, the end user must set the following tokens as mentioned below:</p> <p style="padding-left: 40px;">Adaptive Memory Training to <b>Disabled</b></p> <p style="padding-left: 40px;">BIOS Techlog level to <b>Normal</b></p> <p style="padding-left: 40px;">OptionROM Launch Optimization to <b>Disabled</b>.</p>
<b>BIOS Techlog Level</b>	<p>This option denotes the type of messages in <b>BIOS tech log</b> file.</p> <p>The log file can be one of the following types:</p> <ul style="list-style-type: none"> <li>• <b>Minimum</b> - Critical messages will be displayed in the log file.</li> <li>• <b>Normal</b> - Warning and loading messages will be displayed in the log file.</li> <li>• <b>Maximum</b> - Normal and information related messages will be displayed in the log file.</li> </ul> <p>Default value: <b>Minimum</b>.</p> <p><b>Note</b> This option is mainly for internal debugging purposes.</p>

Name	Description
<b>OptionROM Launch Optimization</b>	<p>When this option is <b>Enabled</b>, the OptionROMs only for the controllers present in the boot order policy will be launched.</p> <p><b>Note</b> Some controllers such as Onboard storage controllers, Emulex FC adapters, and GPU controllers though not listed in the boot order policy will have the OptionROM launched.</p> <p>When this option is <b>Disabled</b>, all the OptionROMs will be launched.</p> <p>Default value: <b>Enabled</b></p>
<b>CDN Control</b> drop-down list <b>set cdnEnable</b>	<p>Whether the Ethernet Network naming convention is according to Consistent Device Naming (CDN) or the traditional way of naming conventions. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>— CDN support for VIC cards is disabled</li> <li>• <b>Enabled</b>— CDN support is enabled for VIC cards.</li> </ul>
<b>FRB 2 Timer</b> drop-down list <b>set FRB-2</b>	<p>Whether the FRB2 timer is used by Cisco IMC to recover the system if it hangs during POST. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The FRB2 timer is not used.</li> <li>• <b>Enabled</b>—The FRB2 timer is started during POST and used to recover the system if necessary.</li> </ul>
<b>Flow Control</b> drop-down list <b>set FlowCtrl</b>	<p>Whether a handshake protocol is used for flow control. Request to Send / Clear to Send (RTS/CTS) helps to reduce frame collisions that can be introduced by a hidden terminal problem. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>None</b>—No flow control is used.</li> <li>• <b>RTS/CTS</b>—RTS/CTS is used for flow control.</li> </ul> <p><b>Note</b> This setting must match the setting on the remote terminal application.</p>

Name	Description
<b>Terminal type</b> drop-down list set <b>TerminalType</b>	<p>What type of character formatting is used for console redirection. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>PC-ANSI</b>—The PC-ANSI terminal font is used.</li> <li>• <b>VT100</b>—A supported VT100 video terminal and its character set are used.</li> <li>• <b>VT100-PLUS</b>—A supported VT100-plus video terminal and its character set are used.</li> <li>• <b>VT-UTF8</b>—A video terminal with the UTF-8 character set is used.</li> </ul>

## Security Tab



**Note** BIOS parameters listed in this tab may vary depending on the server.

*Table 4: BIOS Parameters in Security Tab*

Name	Description
<b>Reboot Host Immediately</b> checkbox	<b>If the Reboot Host Immediately check box is checked, the server is rebooted immediately and the new BIOS settings go into effect. Otherwise the changes are saved until the server is manually rebooted.</b>
<b>Trusted Platform Module Support</b> drop-down list set <b>TPMAdminCtrl</b>	<p>Trusted Platform Module (TPM ) is a microchip designed to provide basic security-related functions primarily involving encryption keys. This option allows you to control the TPM Security Device support for the system. It can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The server does not use the TPM.</li> <li>• <b>Enabled</b>—The server uses the TPM.</li> </ul> <p><b>Note</b> Contact your operating system vendor to make sure the operating system supports this feature.</p>



Name	Description
<b>Reboot Host Immediately</b> checkbox	<b>If the Reboot Host Immediately check box is checked, the server is rebooted immediately and the new BIOS settings go into effect. Otherwise the changes are saved until the server is manually rebooted.</b>
<b>Power on Password</b> drop-down list <b>set PowerOnPassword</b>	This token requires that you set a BIOS password before using the F2 BIOS configuration. If enabled, password needs to be validated before you access BIOS functions such as IO configuration, BIOS set up, and booting to an operating system using BIOS. It can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Support is disabled.</li> <li>• <b>Enabled</b>—Support is enabled.</li> </ul>

## Processor Tab



**Note** BIOS parameters listed in this tab may vary depending on the server.

*Table 5: BIOS Parameters in Processor Tab*

Name	Description
<b>Intel Virtualization Technology</b> drop-down list <b>set IntelVT</b>	Whether the processor uses Intel Virtualization Technology (VT), which allows a platform to run multiple operating systems and applications in independent partitions. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not permit virtualization.</li> <li>• <b>Enabled</b>—The processor allows multiple operating systems in independent partitions.</li> </ul>
<b>Extended Apic</b> drop-down list <b>set LocalX2Apic</b>	Allows you to enable or disable extended APIC support. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Enabled</b>—Enables APIC support</li> <li>• <b>Disabled</b>—Disables APIC support.</li> </ul>

Name	Description
<p><b>Processor C1E</b> drop-down list set <b>ProcessorC1E</b></p>	<p>Whether the CPU transitions to its minimum frequency when entering the C1 state. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The CPU continues to run at its maximum frequency in C1 state.</li> <li>• <b>Enabled</b>—The CPU transitions to its minimum frequency. This option saves the maximum amount of power in C1 state.</li> </ul> <p><b>Note</b> This option is available only on some C-Series servers.</p>
<p><b>Processor C6 Report</b> drop-down list set <b>ProcessorC6Report</b></p>	<p>Whether the BIOS sends the C6 report to the operating system. When the OS receives the report, it can transition the processor into the lower C6 power state to decrease energy usage while maintaining optimal processor performance. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The BIOS does not send the C6 report.</li> <li>• <b>Enabled</b>—The BIOS sends the C6 report, allowing the OS to transition the processor to the C6 low power state.</li> </ul> <p><b>Note</b> <b>CPUPowerManagement</b> must be set to <b>Custom</b> or the server ignores the setting for this parameter.</p> <p><b>Note</b> This option is available only on some C-Series servers.</p>

Name	Description
<p><b>Execute Disable Bit</b> drop-down list set <b>ExecuteDisable</b></p>	<p>Classifies memory areas on the server to specify where application code can execute. As a result of this classification, the processor disables code execution if a malicious worm attempts to insert code in the buffer. This setting helps to prevent damage, worm propagation, and certain classes of malicious buffer overflow attacks. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not classify memory areas.</li> <li>• <b>Enabled</b>—The processor classifies memory areas.</li> </ul> <p><b>Note</b> Contact your operating system vendor to make sure the operating system supports this feature.</p>
<p><b>Intel Turbo Boost Tech</b> drop-down list set <b>IntelTurboBoostTech</b></p>	<p>Whether the processor uses Intel Turbo Boost Technology, which allows the processor to automatically increase its frequency if it is running below power, temperature, or voltage specifications. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not increase its frequency automatically.</li> <li>• <b>Enabled</b>—The processor utilizes Turbo Boost Technology if required.</li> </ul> <p><b>Note</b> <b>CPUPowerManagement</b> must be set to <b>Custom</b> or the server ignores the setting for this parameter.</p>

Name	Description
<p><b>Enhanced Intel SpeedStep Tech</b> drop-down list set <b>EnhancedIntelSpeedStep</b></p>	<p>Whether the processor uses Enhanced Intel SpeedStep Technology, which allows the system to dynamically adjust processor voltage and core frequency. This technology can result in decreased average power consumption and decreased average heat production. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor never dynamically adjusts its voltage or frequency.</li> <li>• <b>Enabled</b>—The processor utilizes Enhanced Intel SpeedStep Technology and enables all supported processor sleep states to further conserve power.</li> </ul> <p>We recommend that you contact your operating system vendor to make sure the operating system supports this feature.</p> <p><b>Note</b> <b>CPUPowerManagement</b> must be set to <b>Custom</b> or the server ignores the setting for this parameter.</p>
<p><b>Intel HyperThreading Tech</b> drop-down list set <b>IntelHyperThread</b></p>	<p>Whether the processor uses Intel Hyper-Threading Technology, which allows multithreaded software applications to execute threads in parallel within each processor. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not permit hyperthreading.</li> <li>• <b>Enabled</b>—The processor allows for the parallel execution of multiple threads.</li> </ul>
<p><b>Workload Configuration</b> drop-down list set <b>WorkLdConfig</b></p>	<p>This feature allows for workload optimization. The options are Balanced and I/O Sensitive:</p> <ul style="list-style-type: none"> <li>• <b>NUMA</b></li> <li>• <b>UMA</b></li> </ul>

Name	Description
<p><b>Core MultiProcessing</b> drop-down list set <b>CoreMultiProcessing</b></p>	<p>Allows you to disable one or more of the physical cores on the server. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>All</b>—Enables all physical cores. This also enables Hyper Threading on the associated logical processor cores.</li> <li>• <b>1 through 28</b>—Specifies the number of physical processor cores that can run on the server. Each physical core has an associated logical core.</li> </ul> <p><b>Note</b> Contact your operating system vendor to make sure the operating system supports this feature.</p>
<p><b>Sub NUMA Clustering</b> drop-down list</p>	<p>Whether the CPU supports sub NUMA clustering, in which the tag directory and the memory channel are always in the same region. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>disabled</b>— Sub NUMA clustering does not occur.</li> <li>• <b>enabled</b>— Sub NUMA clustering occurs.</li> <li>• <b>auto</b> — The BIOS determines what Sub NUMA clustering is done.</li> </ul>
<p><b>XPT Prefetch</b> drop-down list</p>	<p>Whether XPT prefetch is used to enable a read request sent to the last level cache to issue a copy of that request to the memory controller prefetcher. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>disabled</b>—The CPU does not use the XPT Prefetch option.</li> <li>• <b>enabled</b>—The CPU enables the XPT prefetch option.</li> </ul>
<p><b>UPI Prefetch</b> drop-down list</p>	<p>UPI prefetch is a mechanism to get the memory read started early on a DDR bus. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>disabled</b>—The processor does not preload any cache data.</li> <li>• <b>enabled</b>—The UPI prefetcher preloads the L1 cache with the data it determines to be the most relevant.</li> </ul>

Name	Description
<b>Energy Performance Bias Config</b> drop-down list <b>set CpuEngPerfBias</b>	<p>Allows you to determine whether system performance or energy efficiency is more important on this server. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• — The server provides all server components with full power at all times. This option maintains the highest level of performance and requires the greatest amount of power.</li> <li>• — The server provides all server components with enough power to keep a balance between performance and power.</li> <li>• — The server provides all server components with enough power to keep a balance between performance and power.</li> <li>• — The server provides all server components with maximum power to keep reduce power consumption.</li> </ul>
<b>Power Performance Tuning</b> drop-down list <b>set PwrPerfTuning</b>	<p>Determines if the BIOS or Operating System can turn on the energy performance bias tuning. The options are BIOS and OS.</p> <ul style="list-style-type: none"> <li>• <b>bios</b>— Chooses BIOS for energy performance tuning.</li> <li>• <b>os</b>— Chooses OS for energy performance tuning.</li> </ul>
<b>LLC Prefetch</b> drop-down list	<p>Whether the processor uses the LLC Prefetch mechanism to fetch the date into the LLC. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>disabled</b>—The processor does not preload any cache data.</li> <li>• <b>enabled</b>—The LLC prefetcher preloads the L1 cache with the data it determines to be the most relevant.</li> </ul>

Name	Description
<p><b>Package C State</b></p> <p><b>set package-c-state-limit-config</b></p> <p><b>package-c-state-limit</b></p>	<p>The amount of power available to the server components when they are idle. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>no-limit</b>—The server may enter any available C state.</li> <li>• <b>auto</b> —The CPU determines the physical elevation.</li> <li>• —The server provides all server components with full power at all times. This option maintains the highest level of performance and requires the greatest amount of power.</li> <li>• —When the CPU is idle, the system reduces the power consumption further than with the C1 option. This requires less power than C1 or C0, but it takes the server slightly longer to return to high performance mode.</li> <li>• —When the CPU is idle, the system reduces the power consumption further than with the C3 option. This option saves more power than C0, C1, or C3, but there may be performance issues until the server returns to full power.</li> <li>• —When the CPU is idle, the system reduces the power consumption further than with the C3 option. This option saves more power than C0, C1, or C3, but there may be performance issues until the server returns to full power.</li> </ul>
<p><b>Hardware P-States</b> drop-down list</p> <p><b>set CpuHWPM</b></p>	<p>Enables processor Hardware P-State. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>disabled</b>—HWPM is disabled.</li> <li>• <b>hwpm-native-mode</b>—HWPM native mode is enabled.</li> <li>• <b>hwpm-oob-mode</b>—HWPM Out-Of-Box mode is enabled.</li> <li>• <b>Native Mode with no Legacy</b> (only GUI)</li> </ul>

Name	Description
<b>Intel Speed Select</b> drop-down list <b>set IntelSpeedSelect</b>	<p><b>Intel Speed Select</b> modes will allow users to run the CPU with different speed and cores.</p> <p>This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Base</b>— It will allow users to access maximum core and Thermal Design Power (TDP) ratio.</li> <li>• <b>Config 1</b>— It will allow users to access core and TDP ratio lesser than <b>Base</b>.</li> <li>• <b>Config 2</b>— It will allow users to access core and TDP ratio lesser than <b>Config 1</b>.</li> </ul> <p>Default value: <b>Base</b>.</p>

## Memory Tab



**Note** BIOS parameters listed in this tab may vary depending on the server.

*Table 6: BIOS Parameters in Memory Tab*

Name	Description
<b>Reboot Host Immediately</b> checkbox	<p>Upon checking, reboots the host server immediately. You must check the checkbox after saving changes.</p>
<b>Select Memory RAS configuration</b> drop-down list <b>set SelectMemoryRAS</b>	<p>Determines how the memory reliability, availability, and serviceability (RAS) is configured for the server. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Maximum Performance</b>—System performance is optimized.</li> <li>• <b>ADDDC Sparing</b>—Adaptive virtual lockstep is an algorithm implemented in the hardware and firmware to support the ADDDC mode. When selected, the system performance is optimized till the algorithm is activated. The algorithm is activated in case of DRAM device failure. Once the algorithm is activated, the virtual lockstep regions are activated to map out the failed region during run-time dynamically, and the performance impact is restricted at a region level.</li> <li>• <b>Mirror Mode 1LM</b>—System reliability is optimized by using half the system memory as backup.</li> </ul>



Name	Description
<b>Above 4G Decoding</b> drop-down list <b>set MemoryMappedIOAbove4GB</b>	Enables or disables MMIO above 4GB or not. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The server does not map I/O of 64-bit PCI devices to 4GB or greater address space.</li> <li>• <b>Enabled</b>—The server maps I/O of 64-bit PCI devices to 4GB or greater address space.</li> </ul> <p><b>Note</b> PCI devices that are 64-bit compliant but use a legacy option ROM may not function correctly with this setting enabled.</p>
<b>DCPMM Firmware Downgrade</b> drop-down list <b>set DCPMMFirmwareDowngrade</b>	Whether the BIOS supports downgrading the DCPMM firmware. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Support is disabled.</li> <li>• <b>Enabled</b>—Support is enabled.</li> </ul>
<b>NUMA</b> drop-down list <b>set NUMAOptimize</b>	Whether the BIOS supports Non-Uniform Memory Access (NUMA). This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Support is disabled.</li> <li>• <b>Enabled</b>—Support is enabled.</li> </ul>

## Power/Performance Tab



**Note** BIOS parameters listed in this tab may vary depending on the server.

*Table 7: BIOS Parameters in Power/Performance Tab*

Name	Description
<b>Reboot Host Immediately</b> checkbox	Upon checking, reboots the host server immediately. You must check the checkbox after saving changes.
<b>Hardware Prefetcher</b> drop-down list <b>set HardwarePrefetch</b>	Whether the processor allows the Intel hardware prefetcher to fetch streams of data and instruction from memory into the unified second-level cache when necessary. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The hardware prefetcher is not used.</li> <li>• <b>Enabled</b>—The processor uses the hardware prefetcher when cache issues are detected.</li> </ul>

Name	Description
<b>Adjacent Cache Line Prefetcher</b> drop-down list <b>set AdjacentCacheLinePrefetch</b>	Whether the processor fetches cache lines in even or odd pairs instead of fetching just the required line. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor only fetches the required line.</li> <li>• <b>Enabled</b>—The processor fetches both the required line and its paired line.</li> </ul>
<b>DCU Streamer Prefetch</b> drop-down list <b>set DcuStreamerPrefetch</b>	Whether the processor uses the DCU IP Prefetch mechanism to analyze historical cache access patterns and preload the most relevant lines in the L1 cache. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not try to anticipate cache read requirements and only fetches explicitly requested lines.</li> <li>• <b>Enabled</b>—The DCU prefetcher analyzes the cache read pattern and prefetches the next line in the cache if it determines that it may be needed.</li> </ul>
<b>DCU IP Prefetcher</b> drop-down list <b>set DcuIpPrefetch</b>	Whether the processor uses the DCU IP Prefetch mechanism to analyze historical cache access patterns and preload the most relevant lines in the L1 cache. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not preload any cache data.</li> <li>• <b>Enabled</b>—The DCU IP prefetcher preloads the L1 cache with the data it determines to be the most relevant.</li> </ul>
<b>CPU Performance</b> drop-down list <b>set CPUPerformance</b>	Sets the CPU performance profile for the options listed above. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Enterprise</b>—All options are enabled.</li> <li>• <b>HPC</b>—All options are enabled. This setting is also known as high performance computing.</li> <li>• <b>High Throughput</b>—Only the DCU IP Prefetcher is enabled. The rest of the options are disabled.</li> <li>• <b>Custom</b>—All performance profile options can be configured from the BIOS setup on the server. In addition, the Hardware Prefetcher and Adjacent Cache-Line Prefetch options can be configured as well.</li> </ul>



## APPENDIX **B**

# BIOS Token Name Comparison for Multiple Interfaces

This appendix contains the following section:

- [BIOS Token Name Comparison for Multiple Interfaces, on page 417](#)

## BIOS Token Name Comparison for Multiple Interfaces

The following table lists the BIOS token names used in the XML, CLI and Web GUI interfaces. You can use this list to map the names across these interfaces.



**Note** The parameters that are available depend on the type of Cisco UCS server you are using.

BIOS Token Group	BIOS Token Name	XML Object	CLI and Web GUI Object
<b>Main</b>	TPM Support	biosVfTPMSupport/ vpTPMSupport	TPMAdminCtrl
<b>Process Configuration</b>	Intel(R) Hyper-Threading Technology	biosVfIntelHyperThreadingTech/ vpIntelHyperThreadingTech	IntelHyperThread
	Number of Enable Cores	biosVfCoreMultiProcessing/ vpCoreMultiProcessing	CoreMultiProcessing
	Execute Disable	biosVfExecuteDisableBit/ vpExecuteDisableBit	ExecuteDisable
	Intel(R) VT	biosVfIntelVirtualizationTechnology/ vpIntelVirtualizationTechnology	IntelVT

BIOS Token Group	BIOS Token Name	XML Object	CLI and Web GUI Object
	Intel(R) VT-d	biosVfIntelVTForDirectedIO/ vpIntelVTForDirectedIO	IntelVTD
	Intel(R) VT-d Coherency Support	biosVfIntelVTForDirectedIO/ vpIntelVTDCoherencySupport	CoherencySupport
	Intel(R) VT-d ATS Support	biosVfIntelVTForDirectedIO/ vpIntelVTDATSSupport	ATS
	CPU Performance	biosVfCPUPerformance/ vpCPUPerformance	CpuPerformanceProfile
	Hardware Prefetcher	biosVfHardwarePrefetch/ vpHardwarePrefetch	HardwarePrefetch
	Adjacent Cache Line Prefetcher	biosVfAdjacentCacheLinePrefetch/ vpAdjacentCacheLinePrefetch	AdjacentCacheLinePrefetch
	DCU Streamer Prefetch	biosVfDCUPrefetch/ vvpStreamerPrefetch	DcuStreamerPrefetch
	DCU IP Prefetcher	biosVfDCUPrefetch/ vpIPPrefetch	DcuIpPrefetch
	Direct Cache Access Support	biosVfDirectCacheAccess/ vpDirectCacheAccess	DirectCacheAccess
	Power Technology	biosVfCPUPowerManagement/ vpCPUPowerManagement	CPUPowerManagement
	Enhanced Intel Speedstep(R) Technology	biosVfEnhancedIntelSpeedStepTech/ vpEnhancedIntelSpeedStepTech	EnhancedIntelSpeedStep
	Intel(R) Turbo Boost Technology	biosVfIntelTurboBoostTech/ vpIntelTurboBoostTech	IntelTurboBoostTech
	Processor Power state C6	biosVfProcessorCState/ vpProcessorCState	ProcessorC6Report
	Processor Power state C1 Enhanced	biosVfProcessorC1E/ vpProcessorC1E	ProcessorC1E

BIOS Token Group	BIOS Token Name	XML Object	CLI and Web GUI Object
	Frequency Floor Override	biosVfCPUFrequencyFloor/ vpCPUFrequencyFloor	CpuFreqFloor
	P-STATE Coordination	biosVfPStateCoordType/ vpPStateCoordType	PsdCoordType
	Energy Performance	biosVfCPUEnergyPerformance/ vpCPUEnergyPerformance	CpuEngPerfBias
<b>Memory Configuration</b>	Select Memory RAS	biosVfSelectMemoryRASConfiguration/ vpSelectMemoryRASConfiguration	SelectMemoryRAS
	DRAM Clock Throttling	biosVfDRAMClockThrottling/ vpDRAMClockThrottling	DRAMClockThrottling
	NUMA	biosVfNUMAOptimized/ vpNUMAOptimized	NUMAOptimize
	Low Voltage DDR Mode	biosVfLvDIMMSupport/ vpNUMAOptimized	LvDDRMode
	DRAM Refresh rate	biosVfDramRefreshRate/ vpDramRefreshRate	DramRefreshRate
	Channel Interleaving	biosVfMemoryInterleave/ vpChannelInterLeave	ChannelInterLeave
	Rank Interleaving	biosVfMemoryInterleave/ vpRankInterLeave	RankInterLeave
	Patrol Scrub	biosVfPatrolScrub/ vpPatrolScrub	PatrolScrub
	Demand Scrub	biosVfDemandScrub/ vpDemandScrub	DemandScrub
	Altitude	biosVfAltitude/ vpAltitude	Altitude
<b>QPI Configuration</b>	QPI Link Frequency Select	biosVfQPICongfig/ vpQPILinkFrequency	QPILinkFrequency
	Cluster on Die	biosVfCODEnable/ vpCODEnable	CODEnable

BIOS Token Group	BIOS Token Name	XML Object	CLI and Web GUI Object
	Snoop Mode	biosVfEarlySnoop/ vpEarlySnoop	EarlySnoop
<b>SATA Configuration</b>	SATA Mode	Not supported	SATAMode
<b>Onboard Storage</b>	Onboard SCU Storage Support	biosVfOnboardStorage/ vpOnboardSCUStorageSupport	DisableSCU
	Onboard SCU Storage SW Stack	biosVfOnboardStorageSWStack vpOnboardSCUStorageSWStack	PchScuOromSelect
<b>USB Configuration</b>	Legacy USB Support	biosVfLegacyUSBSupport/ vpLegacyUSBSupport	LegacyUSBSupport
	Port 60/64 Emulation	biosVfUSBEmulation/ vpUSBEmul6064	UsbEmul6064
	All USB Devices	biosVfUSBPortsConfig/ vpAllUsbDevices	AllUsbDevices
	USB Port:Rear	biosVfUSBPortsConfig/ vpUsbPortRear	UsbPortRear
	USB Port:Front	biosVfUSBPortsConfig/ vpUsbPortFront	UsbPortFront
	USB Port:Internal	biosVfUSBPortsConfig/ vpUsbPortInternal	UsbPortInt
	USB Port:KVM	biosVfUSBPortsConfig/ vpUsbPortKVM	UsbPortKVM
	USB Port:Vmedia	biosVfUSBPortsConfig/ vpUsbPortVMedia	UsbPortVMedia
	USB Port:SD Card	biosVfUSBPortsConfig/ vpUsbPortSDCard	UsbPortSdCard
	xHCI Mode	biosVfPchUsb30Mode/ vpPchUsb30Mode	PchUsb30Mode
<b>PCI Configuration</b>	PCI ROM CLP	Not Supported	PciRomClp

BIOS Token Group	BIOS Token Name	XML Object	CLI and Web GUI Object
	MMIO above 4GB	biosVfMemoryMappedIOAbove4GB/ vpMemoryMappedIOAbove4GB	MemoryMappedIOAbove4GB
	ASPM Support	biosVfASPMSupport/ vpASPMSupport	ASPMSupport
	VGA Priority	biosVfVgaPriority/ vpVgaPriority	VgaPriority
<b>Serial Configuration</b>	Console Redirection	biosVfConsoleRedirection/ vpConsoleRedirection	ConsoleRedir
	Terminal Type	biosVfConsoleRedirection/ vpTerminalType	TerminalType
	Bits per second	biosVfConsoleRedirection/ vpBaudRate	BaudRate
	Flow Control	biosVfConsoleRedirection/ vpFlowControl	FlowCtrl
	Putty KeyPad	biosVfConsoleRedirection/ vpPuttyKeyPad	PuttyFunctionKeyPad
	Redirection After BIOS POST	biosVfConsoleRedirection/ vpLegacyOSRedirection	RedirectionAfterPOST
<b>LOM and PCIe Slots Configuration</b>	PCH SATA Mode	biosVfSataModeSelect/ vpSataModeSelect	SataModeSelect
	All Onboard LOM Ports	biosVfSataModeSelect/ vpSataModeSelect	AllLomPortControl
	LOM Port 0 OptionROM	biosVfLOMPortOptionROM/ vpLOMPort0State	LomOpromControlPort0
	LOM Port 1 OptionROM	biosVfLOMPortOptionROM/ vpLOMPort1State	LomOpromControlPort1
	All PCIe Slots OptionROM	biosVfPCIOptionROMs/ vpPCIOptionROMs	PcieOptionROMs

BIOS Token Group	BIOS Token Name	XML Object	CLI and Web GUI Object
	PCIe Slot: <i>n</i> OptionROM	biosVfPCISlotOptionROMEnable/ vpSlot <i>n</i> State	PcieSlot <i>n</i> OptionROM
	PCIe Mezzanine OptionROM	biosVfPCISlotOptionROMEnable/ vpSlotMezzState	PcieMezzOptionROM
	PCIe Slot:1 Link Speed or SIOC1 Link Speed	biosVfPCISlotOptionROMEnable/ vpSlot1LinkSpeed	PcieSlot1LinkSpeed
	PCIe Slot:2 Link Speed or SIOC2 Link Speed	biosVfPCISlotOptionROMEnable/ vpSlot2LinkSpeed	PcieSlot2LinkSpeed
	PCIe Slot:MLOM OptionROM	biosVfPCISlotOptionROMEnable/ vpSlotMLOMState	PcieSlotMLOMOptionROM
	PCIe Slot:HBA OptionROM	biosVfPCISlotOptionROMEnable/ vpSlotHBAState	PcieSlotHBAOptionROM
	PCIe Slot:N1 OptionROM	biosVfPCISlotOptionROMEnable/ vpSlotN1State	PcieSlotN1OptionROM
	PCIe Slot:N2 OptionROM	biosVfPCISlotOptionROMEnable/ vpSlotN2State	PcieSlotN2OptionROM
<b>Server Management</b>	FRB-2 Timer	biosVfFRB2Enable/ vpFRB2Enable	FRB-2
	OS Watchdog Timer	biosVfOSBootWatchdogTimer/ vpOSBootWatchdogTimer	OSBootWatchdogTimer
	OS Watchdog Timer Timeout	biosVfOSBootWatchdogTimerPolicy/ vpOSBootWatchdogTimerPolicy	OSBootWatchdogTimerTimeout
	OS Watchdog Timer Policy	biosVfOSBootWatchdogTimerTimeOut/ vpOSBootWatchdogTimerPolicy	OSBootWatchdogTimerPolicy



<b>BIOS Token Group</b>	<b>BIOS Token Name</b>	<b>XML Object</b>	<b>CLI and Web GUI Object</b>
	Boot Order Rules	biosVfUCSMBootOrderRuleControl/ vpUCSMBootOrderRule	UCSMBootOrderRule





## INDEX

6G or 12G [34](#)

### A

Active Directory [124, 126](#)  
    configuring groups [126](#)  
adapter [165, 166, 207, 209, 210, 211, 212](#)  
    activating firmware [212](#)  
    configuring properties [166](#)  
    exporting the configuration [207](#)  
    importing the configuration [209](#)  
    installing firmware [211](#)  
    network [165](#)  
    restoring default configuration [210](#)  
    viewing properties [165](#)  
adapters [163](#)  
    overview [163](#)  
add banner [348](#)  
Assigning physical drives [35](#)  
auto balance power profile [61](#)

### B

backing up [341, 343](#)  
    configuration [341, 343](#)  
BIOS [306, 307](#)  
    activating firmware [307](#)  
    installing from remote server [306](#)  
BIOS Parameters [370, 395](#)  
    Server Management [370, 395](#)  
BIOS settings [72, 73, 74, 278](#)  
    advanced [73, 278](#)  
    main [72](#)  
    restoring defaults [74](#)  
    server management [73](#)  
BIOS setup [75](#)  
    entering [75](#)  
BIOS status [71](#)  
    viewing [71](#)  
blacklisting [70](#)  
boot drive [224](#)  
    clearing [224](#)  
boot order [51](#)  
    viewing [51](#)

boot table [178, 179, 180](#)  
    creating entry [179](#)  
    deleting entry [178, 180](#)  
    description [178](#)

### C

certificate management [274](#)  
    uploading a certificate [274](#)  
Chassis [17, 18, 19, 21, 22, 30, 32, 35, 36, 37, 313, 314, 318, 319](#)  
    clearing log [319](#)  
    Dynamic Storage [19, 30, 32, 35, 36, 37, 313, 314](#)  
chassis current sensors [95](#)  
chassis LED sensors [98](#)  
chassis temperature sensors [97](#)  
chassis voltage sensors [96](#)  
Cisco IMC [210, 302, 304, 320, 325](#)  
    activating firmware [304](#)  
    configuring log threshold [320, 325](#)  
    firmware [210](#)  
    installing firmware from remote server [302](#)  
Cisco VIC Adapter Details [21](#)  
Clearing BIOS CMOS [332](#)  
clearing foreign configuration [222](#)  
CLI [4](#)  
CMC [310, 312](#)  
    activating firmware [312](#)  
    installing firmware from remote server [310](#)  
CMC Firmware [18](#)  
common properties [143](#)  
communication services properties [255, 257, 259](#)  
    IPMI over LAN properties [257](#)  
    IPMI over LAN properties for CMC [259](#)  
    SSH properties [255](#)  
configuration [338, 340, 341, 343](#)  
    backing up [341, 343](#)  
    importing [338, 340](#)  
Configure Bios Main Tab [351, 371](#)  
Configuring [267](#)  
create virtual drive [214](#)  
Create Virtual Drive [216](#)  
CUPS utilization [67](#)  
custom profile [62, 63](#)

**D**

- delete virtual drive [232](#)
- Deleting boot device [48](#)
- DIMM [70](#)
- disabling [61, 63, 65](#)
- disabling KVM [105](#)
- disabling-auto-learn [244](#)
- Drive Security [226, 228, 230, 231](#)
- Dynamic Storage [30](#)
  - SAS Expanders [30](#)
  - Zoning [30](#)

**E**

- edit virtual drive [235](#)
- enabling [62, 64](#)
- Enabling [34, 226](#)
- enabling JBOD [223](#)
- enabling KVM [104, 106](#)
- Enabling secure boot [49](#)
- enabling-auto-learn [243](#)
- encrypting virtual media [107](#)
- event filters, platform [295](#)
  - about [295](#)
  - configuring [295](#)
- event log, system [322, 323, 325](#)
  - clearing [325](#)
  - viewing [322, 323](#)
- exporting [341, 343, 345](#)
  - configuration [341, 343](#)
  - VIC configuration [345](#)

**F**

- Factory Defaults [247](#)
- fan sensors [94](#)
- fault summary [317](#)
  - viewing [317](#)
- faults [318](#)
- faults, logs [317](#)
  - viewing summary [317](#)
- FIP mode [166](#)
  - enabling [166](#)
- firmware [299, 302, 304, 307, 310, 312](#)
  - about [299](#)
  - activating [304, 307, 312](#)
  - installing from remote server [302, 310](#)
- firmware overview [299](#)
- floppy disk emulation [107](#)
- foreign configuration [221](#)
  - importing [221](#)
- front locator LED [23](#)
  - chassis [23](#)

**G**

- generate NMI [347](#)

**H**

- hard drive locator LED [40](#)
- hard reset [68](#)
- hot spare [237, 242](#)
  - dedicated [237](#)
  - global [237, 242](#)

**I**

- importing [338, 340](#)
  - configuration [338, 340](#)
- initializing virtual drive [233](#)
- IP address [161](#)
- IP blocking [157](#)
- IPMI over LAN [257](#)
  - description [257](#)
- IPMI over LAN properties [257, 259](#)
- IPv4 properties [146](#)
- IPv6 properties [149](#)
- iscsi-boot [205](#)
  - vNIC [205](#)

**K**

- KMIP [275](#)
  - Key Management Interoperability Protocol [275](#)
    - Secure Key Management [275](#)
- KVM [104, 105, 106](#)
  - configuring [106](#)
  - disabling [105](#)
  - enabling [104, 106](#)

**L**

- LDAP [123, 124](#)
  - configuring in Cisco IMC [124](#)
    - See also* [Active Directory](#)
- LDAP Server [123](#)
- LED Details [18](#)
- local users [115](#)
- locator LED [40](#)
  - hard drive [40](#)
- Locator LED [39](#)
  - server [39](#)
- locator-led [245](#)
  - bbu [245](#)
- Logs [318](#)

**M**

- Main tab for C3X60M4 servers [371](#)
- making a dedicated hot spare [237](#)
- making a global hot spare [237, 242](#)
- mapped vmedia volume [108, 109](#)
  - cifs [108](#)
  - nfs [108](#)
  - viewing properties [109](#)
  - www [108](#)
- Mixed Mode [34](#)
- Modifying [228](#)
- Modifying Boot Order [45](#)

**N**

- network adapter [165](#)
  - viewing properties [165](#)
- network properties [141, 143, 146, 149, 152, 154](#)
  - common properties [143](#)
  - IPv4 properties [146](#)
  - IPv6 properties [149](#)
  - NIC properties [141](#)
  - port profile properties [154](#)
  - VLAN properties [152](#)
- network security [157](#)
- NIC properties [141](#)
- NIV mode [166](#)
  - enabling [166](#)
- NTP settings [159](#)

**O**

- OS boot [15](#)
  - USB port [15](#)
- OS installation [13, 15](#)
  - methods [13](#)
  - PXE [15](#)
- Overview [3](#)

**P**

- persistent binding [181, 182, 183](#)
  - description [181](#)
  - disabling [182](#)
  - enabling [181](#)
  - rebuilding [183](#)
- physical drive status [239](#)
  - toggling [239](#)
- pinging [161](#)
- platform event filters [295](#)
  - about [295](#)
  - configuring [295](#)
- port profile properties [154](#)
- power characterization [57](#)

- power cycling the server [55](#)
- power restore policy [56](#)
- Power Supply Properties [22](#)
- power supply sensors [93](#)
- powering off the server [54](#)
- powering on the server [53](#)
- Precision Boot Order [43](#)
- prepare for removal [238](#)
- PXE installation [14](#)

**R**

- Reapplying Boot Order [47](#)
- Rearranging boot order [46](#)
- Rebooting the Cisco IMC [332](#)
- remote presence [104, 105, 106, 107, 112](#)
  - configuring serial over LAN [112](#)
  - virtual KVM [104, 105, 106](#)
  - virtual media [107](#)
- Resetting Cisco IMC factory defaults [333](#)
- resetting to factory defaults [334, 336](#)
- restore BIOS manufacturing custom defaults [75](#)
- Restoring [247](#)
- retrieving [225](#)

**S**

- SAS Expander [30](#)
- Self Encrypting Drives [225](#)
  - Full Disk Encryption [225](#)
- self-signed certificate [272](#)
- sensors [93, 94](#)
  - fan [94](#)
  - power supply [93](#)
- serial over LAN [112](#)
  - configuring [112](#)
- server [85, 86, 87, 88, 89, 90, 91, 99, 100, 101, 102](#)
  - viewing CPU details [86](#)
  - viewing current sensors [99](#)
  - viewing DIMM details [87](#)
  - viewing HDD details [89](#)
  - viewing HDD sensors [99](#)
  - viewing LED sensors [100](#)
  - viewing PCI Adapter properties [88](#)
  - viewing properties [85](#)
  - viewing storage adapter properties [90](#)
  - viewing temperature sensors [101](#)
  - viewing TPM inventory [91](#)
  - viewing voltage sensors [102](#)
- server management [23, 39, 40, 53, 54, 55, 68, 69](#)
  - front locator LED [23](#)
  - hard drive locator LED [40](#)
  - power cycling the server [55](#)
  - powering off the server [54](#)
  - powering on the server [53](#)

server management (*continued*)

- server locator LED [39](#)
- shutdown the server [69](#)
- server NICs [139](#)
- Server Overview [1](#)
  - rack-mounted server [1](#)
- server software [2](#)
- Servers' Details [19](#)
- set as boot drive [234](#)
- Sharing physical drives [37](#)
- shutdown the server [69](#)
- Single Server [28](#)
  - Dual SIOC [28](#)
- SMTP [267](#)
- SNMP [261, 263, 264, 265](#)
  - configuring properties [261](#)
  - configuring SNMPv3 users [265](#)
  - configuring trap settings [263](#)
  - sending test message [264](#)
- SSH properties [255](#)
- start-learn-cycle [244](#)
- storage firmware logs [225](#)
- Summary [17](#)
- Switching [230, 231](#)
- syslog [321, 327, 328](#)
  - sending system log [321, 327, 328](#)
- System [321, 327, 328](#)
  - sending log [321, 327, 328](#)
- system event log [322, 323, 325](#)
  - clearing [325](#)
  - viewing [322, 323](#)

## T

- technical support data [329](#)
  - exporting [329](#)
- Telnet [4](#)
- thermal profile [64, 65](#)
- time zone [25](#)

## U

- Unassigning physical drives [36](#)
- undo prepare for removal [242](#)
- Updating Firmware on Server Components [24](#)
- Updating HDD firmware [314](#)
- Updating SAS Expander firmware [313](#)
- uploading a server certificate [274](#)
- user management [115, 124, 135, 136](#)
  - LDAP [124](#)
  - local users [115](#)
  - terminating user sessions [136](#)
  - viewing user sessions [135](#)

- user sessions [135, 136](#)
  - terminating [136](#)
  - viewing [135](#)
- usNIC [203](#)
  - viewing properties [203](#)

## V

- vHBA [169, 178, 179, 180, 181, 182, 183](#)
  - boot table [178](#)
  - creating boot table entry [179](#)
  - deleting [178](#)
  - deleting boot table entry [178, 180](#)
  - disabling persistent binding [182](#)
  - enabling persistent binding [181](#)
  - guidelines for managing [169](#)
  - persistent binding [181](#)
  - rebuilding persistent binding [183](#)
- viewing [67](#)
- viewing history [318](#)
- viewing storage controller logs [247](#)
- virtual drive [233, 234, 236](#)
  - initializing [233](#)
  - modifying attributes [236](#)
  - set as boot drive [234](#)
- virtual KVM [104, 105, 106](#)
- Virtual KVM console [13, 103](#)
- virtual media [107](#)
- VLAN properties [152](#)
- vNIC [184, 186, 197, 198, 204, 205, 206](#)
  - creating [197](#)
  - deleting [198](#)
  - guidelines for managing [184](#)
  - iscsi-boot [205](#)
  - iscsi-boot deletion [206](#)
  - modifying properties [186](#)
  - usnic deletion [204](#)
  - viewing properties [184](#)
- vNICs [205](#)
  - iSCSI-boot guidelines [205](#)

## X

- XML API [256](#)
  - description [256](#)
  - enabling [256](#)

## Y

- YAML [9](#)

## Z

- Zoning [19, 32](#)