



Cisco UCS C-Series Servers Integrated Management Controller GUI Configuration Guide, Release 1.1(2)

First Published: May 28, 2010

Americas Headquarters

Cisco Systems, Inc.
170 West Tasman Drive
San Jose, CA 95134-1706
USA
<http://www.cisco.com>
Tel: 408 526-4000
800 553-NETS (6387)
Fax: 408 527-0883

Text Part Number: OL-22894-01

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NON-INFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Cisco and the Cisco Logo are trademarks of Cisco Systems, Inc. and/or its affiliates in the U.S. and other countries. A listing of Cisco's trademarks can be found at <http://cisco.com/go/trademarks>. Third party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1005R)

Any Internet Protocol (IP) addresses used in this document are not intended to be actual addresses. Any examples, command display output, and figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses in illustrative content is unintentional and coincidental.

© 2010 Cisco Systems, Inc. All rights reserved.



CONTENTS

Preface vii

Audience vii

Organization vii

Conventions viii

Related Documentation ix

Documentation Feedback x

Obtaining Documentation and Submitting a Service Request x

Overview 1

Overview of the Cisco UCS C-Series Rack-Mount Servers 1

Overview of the Server Software 2

Cisco Integrated Management Controller 2

Overview of the CIMC User Interface 3

CIMC Home Page 4

Navigation Pane 4

Work Pane 5

Toolbar 7

Cisco Integrated Management Controller Online Help Overview 8

Logging Into CIMC 8

Logging Out of CIMC 8

Installing the Server OS 11

OS Installation Methods 11

KVM Console 11

Installing an OS Using the KVM Console 12

PXE Installation Servers 12

Installing an OS Using a PXE Installation Server 13

Managing the Server 15

Viewing Overall Server Status 15

Toggling the Locator LED 17

Configuring the Server Boot Order	17
Powering On the Server	19
Powering Off the Server	19
Power Cycling the Server	19
Resetting the Server	20
Shutting Down the Server	20
Viewing Server Properties	21
Viewing CPU Properties	21
Viewing Memory Properties	22
Viewing Power Supply Properties	22
Viewing Storage Properties	23
Viewing Server Sensors	25
Viewing Current Sensors	25
Viewing LED Sensors	26
Viewing Fan Sensors	27
Viewing Power Supply Sensors	27
Viewing Temperature Sensors	29
Viewing Voltage Sensors	30
Managing Remote Presence	31
Configuring Serial Over LAN	31
Configuring Virtual Media	32
KVM Console	32
Configuring the Virtual KVM	33
Disabling the Virtual KVM	33
Enabling the Virtual KVM	34
Managing User Accounts	35
Active Directory	35
Configuring Active Directory in CIMC	35
Configuring the Active Directory Server	36
Configuring Local Users	37
Viewing User Sessions	39
Configuring Network-Related Settings	41
Server NIC Configuration	41
Server NICs	41
Configuring Server NICs	42

Configuring Common Properties	43
Configuring IPv4	43
Connecting to a VLAN	44
Network Security Configuration	45
Network Security	45
Configuring Network Security	45
Configuring Communication Services	47
Configuring HTTP	47
Configuring SSH	48
IPMI Over LAN	49
Configuring IPMI over LAN	49
Managing Certificates	51
Managing the Server Certificate	51
Generating a Certificate Signing Request	52
Creating a Self-Signed Certificate	53
Uploading a Server Certificate	54
Configuring Platform Event Filters	57
Platform Event Filters	57
Enabling Platform Event Alerts	57
Disabling Platform Event Alerts	58
Configuring Platform Event Filters	58
Configuring SNMP Trap Settings	59
CIMC Firmware Management	61
Overview of Firmware	61
Obtaining CIMC Firmware from Cisco	62
Installing CIMC Firmware from the TFTP Server	63
Installing CIMC Firmware Through the Browser	64
Activating Installed Firmware	64
Viewing Logs	65
CIMC Log	65
Viewing the CIMC Log	65
Clearing the CIMC Log	66
Sending the CIMC Log to a Remote Server	66
System Event Log	67
Viewing the System Event Log	67

Clearing the System Event Log **67**

Server Utilities 69

Exporting Technical Support Data **69**

Rebooting CIMC **70**

Recovering from a Corrupted BIOS **70**

Resetting CIMC to Factory Defaults **71**

Backing Up and Importing the CIMC Configuration **71**

 Backing Up and Importing the CIMC Configuration **71**

 Backing Up the CIMC Configuration **72**

 Importing a CIMC Configuration **73**



Preface

This preface includes the following sections:

- [Audience, page vii](#)
- [Organization, page vii](#)
- [Conventions, page viii](#)
- [Related Documentation, page ix](#)
- [Documentation Feedback , page x](#)
- [Obtaining Documentation and Submitting a Service Request , page x](#)

Audience

This guide is intended primarily for data center administrators with responsibilities and expertise in one or more of the following:

- Server administration
- Storage administration
- Network administration
- Network security

Organization

This document includes the following chapters:

Title	Description
Overview	Describes the Cisco UCS C-Series Rack-Mount Servers and the CIMC .
Managing the Server	Describes how to configure the boot device order, how to control power to the server, and how to reset the server.

Title	Description
Viewing Server Properties	Describes how to view the CPU, memory, power supply, and storage properties of the server.
Viewing Server Sensors	Describes how to view the power supply, fan, temperature, current, and voltage sensors.
Managing Remote Presence	Describes how to configure and manage the virtual KVM, virtual media, and the serial over LAN connection.
Managing User Accounts	Describes how to add, delete, and authenticate users, and how to manage user sessions.
Configuring Network-Related Settings	Describes how to configure network interfaces, network settings, and network security.
Configuring Communication Services	Describes how to configure server management communication by HTTP, SSH, and IPMI.
Managing Certificates	Describes how to generate, upload, and manage server certificates.
Configuring Platform Event Filters	Describes how to configure and manage platform event filters and SNMP settings.
CIMC Firmware Management	Describes how to obtain, install, and activate firmware images.
Viewing Logs	Describes how to view, export, and clear log messages.
Server Utilities	Describes how to export support data, how to reset the server configuration to factory defaults, how to back up the configuration, and how to reboot the management interface.

Conventions

This document uses the following conventions:

Convention	Indication
bold font	Commands, keywords, GUI elements, and user-entered text appear in bold font .
<i>italic font</i>	Document titles, new or emphasized terms, and arguments for which you supply values are in <i>italic font</i> .
[]	Elements in square brackets are optional.

Convention	Indication
{x y z}	Required alternative keywords are grouped in braces and separated by vertical bars.
[x y z]	Optional alternative keywords are grouped in brackets and separated by vertical bars.
string	A nonquoted set of characters. Do not use quotation marks around the string or the string will include the quotation marks.
<code>courier font</code>	Terminal sessions and information the system displays appear in <code>courier font</code> .
<>	Nonprinting characters such as passwords are in angle brackets.
[]	Default responses to system prompts are in square brackets.
!, #	An exclamation point (!) or a pound sign (#) at the beginning of a line of code indicates a comment line.

**Note**

Means *reader take note*.

**Tip**

Means *the following information will help you solve a problem*.

**Caution**

Means *reader be careful*. In this situation, you might perform an action that could result in equipment damage or loss of data.

**Timesaver**

Means *the described action saves time*. You can save time by performing the action described in the paragraph.

**Warning**

Means *reader be warned*. In this situation, you might perform an action that could result in bodily injury.

Related Documentation

Documentation for Cisco UCS C-Series Rack-Mount Servers is available at the following URL:

<http://www.cisco.com/go/unifiedcomputing/c-series-doc>

Documentation Feedback

To provide technical feedback on this document, or to report an error or omission, please send your comments to ucs-docfeedback@cisco.com. We appreciate your feedback.

Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, submitting a service request, and gathering additional information, see the monthly *What's New in Cisco Product Documentation*, which also lists all new and revised Cisco technical documentation, at:

<http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html>

Subscribe to the *What's New in Cisco Product Documentation* as a Really Simple Syndication (RSS) feed and set content to be delivered directly to your desktop using a reader application. The RSS feeds are a free service and Cisco currently supports RSS version 2.0.



CHAPTER 1

Overview

This chapter includes the following sections:

- [Overview of the Cisco UCS C-Series Rack-Mount Servers, page 1](#)
- [Overview of the Server Software, page 2](#)
- [Cisco Integrated Management Controller, page 2](#)
- [Overview of the CIMC User Interface, page 3](#)

Overview of the Cisco UCS C-Series Rack-Mount Servers

Following are the Cisco UCS C-Series rack-mount servers:

- Cisco UCS C200 Rack-Mount Server
- Cisco UCS C210 Rack-Mount Server
- Cisco UCS C250 Rack-Mount Server
- Cisco UCS C460 Rack-Mount Server



Note

To determine which Cisco UCS C-Series rack-mount servers are supported by this firmware release, see the *Release Notes for Cisco Integrated Management Controller*.

UCS C200 Rack-Mount Server

The Cisco UCS C200 server is a high-density, two-socket, 1 RU rack-mount server. This server is built for production-level network infrastructure, web services, and mainstream data centers, and branch and remote-office applications.

UCS C210 Rack-Mount Server

The Cisco UCS C210 server is a general-purpose, two-socket, 2 RU rack-mount server. It is designed to balance performance, density, and efficiency for storage-intensive workloads. This server is built for applications such as network file and appliances, storage, database, and content-delivery.

UCS C250 Rack-Mount Server

The Cisco UCS C250 server is a high-performance, memory-intensive, two-socket, 2 RU rack-mount server. It is designed to increase performance, and it has the capacity for demanding virtualization and large-data-set workloads. The C250 server can also reduce the cost of smaller memory footprints.

UCS C460 Rack-Mount Server

The UCS C460 server is a high-density, 4U rack-mount server. Supporting one to four multi-core processors, it is built for heavy workload applications like data warehousing, ERP, and large-scale virtualization.

Overview of the Server Software

The Cisco UCS C-Series Rack-Mount Server ships with two major software systems installed.

CIMC Firmware

Cisco Integrated Management Controller (CIMC) is a separate management module built into the motherboard. A dedicated ARM-based processor, separate from the main server CPU, runs the CIMC firmware. The system ships with a running version of the CIMC firmware. You can update the CIMC firmware, but no initial installation is needed.

Server OS

The main server CPU runs an OS such as Windows or Linux. The server ships with a pre-installed OS, but you can install a different OS using the DVD drive or over the network. You can use CIMC to install the new OS using the KVM console and vMedia.

**Note**

Use product-specific installation documentation when installing an OS.

Cisco Integrated Management Controller

The Cisco Integrated Management Controller (CIMC) is the management service for the C-Series servers. CIMC runs within the server.

Management Interfaces

You can use a web-based GUI or SSH-based CLI to access, configure, administer, and monitor the server. Almost all tasks can be performed in either interface, and the results of tasks performed in one interface are displayed in another. However, you cannot do the following:

- Use CIMC GUI to invoke CIMC CLI
- View a command that has been invoked through CIMC CLI in CIMC GUI
- Generate CIMC CLI output from CIMC GUI

Tasks You Can Perform in CIMC

You can use CIMC to perform the following server management tasks:

- Power on, power off, power cycle, reset and shut down the server
- Toggle the locator LED
- Configure the server boot order
- View server properties and sensors
- Manage remote presence
- Create and manage local user accounts, and enable remote user authentication through Active Directory
- Configure network-related settings, including NIC properties, IPv4, VLANs, and network security
- Configure communication services, including HTTP, SSH, and IPMI Over LAN
- Manage certificates
- Configure platform event filters
- Update CIMC firmware
- Monitor faults, alarms, and server status

No Operating System or Application Provisioning or Management

CIMC provisions servers, and as a result, exists below the operating system on a server. Therefore, you cannot use it to provision or manage operating systems or applications on servers. For example, you cannot do the following:

- Deploy an OS, such as Windows or Linux
- Deploy patches for software, such as an OS or an application
- Install base software components, such as anti-virus software, monitoring agents, or backup clients
- Install software applications, such as databases, application server software, or web servers
- Perform operator actions, including restarting an Oracle database, restarting printer queues, or handling non-CIMC user accounts
- Configure or manage external storage on the SAN or NAS storage

Overview of the CIMC User Interface

The CIMC user interface is a web-based management interface for Cisco C-Series servers. You can launch the CIMC user interface and manage the server from any remote host that meets the following minimum requirements:

- Java 1.6 or higher
- HTTP and HTTPS enabled
- Adobe Flash Player 10 or higher




Note

In case you lose or forget the password that you use to log into CIMC, see the Cisco UCS C-Series server installation and service guide for your platform for password recovery instructions.

CIMC Home Page

Figure 1 shows the CIMC home page.

Figure 1: CIMC Home Page



Navigation Pane

The Navigation pane displays on the left side in the CIMC user interface. Clicking links on the **Server** or **Admin** tabs in the **Navigation** pane displays the selected pages in the **Work** pane on the right side of the CIMC user interface.

The following table describes the elements in the **Navigation** pane:

Element Name	Description
Overall Server Status area	The Overall Server Status area is found above the Server and Admin tabs. Click this area to refresh the Server Summary page.
Server tab	The Server tab is found in the Navigation pane. It contains links to the following pages: <ul style="list-style-type: none"> • Summary • Inventory

	<ul style="list-style-type: none"> • Sensors • System Event Log • Remote Presence • BIOS
Admin tab	<p>The Admin tab is found in the Navigation pane. It contains links to the following pages:</p> <ul style="list-style-type: none"> • Users Management • Network • Communication Services • Certificate Management • CIMC Log • Event Management • Firmware Management • Utilities

Work Pane

The **Work** pane displays on the right side of the UI. Different pages appear in the **Work** pane, depending on what link you click on the **Server** or **Admin** tab.

The following table describes the elements and pages in the **Work** pane.

Page or Element Name	Description
Summary	On the page, you view server properties, server status, and CIMC information. You also perform actions like powering the server on and off.
Inventory	<p>There are four tabs on the page:</p> <ul style="list-style-type: none"> • CPUs—Use this tab to view information about the CPU. • Memory—Use this tab to view information about memory. • Power Supplies—Use this tab to view information about power supplies. • Storage—Use this tab to view information about storage.
Sensors	<p>There are six tabs on the page:</p> <ul style="list-style-type: none"> • Power Supply—Use this tab to view the power supply sensor. • Fan—Use this tab to view the fan sensor.

	<ul style="list-style-type: none"> • Temperature—Use this tab to view the temperature sensor. • Voltage—Use this tab to view the voltage sensor. • Current—Use this tab to view the current sensor. • LEDs—Use this tab to view the state and color of the LEDs.
System Event Log	On the page, you can view the system event log.
Remote Presence	<p>There are three tabs on the page:</p> <ul style="list-style-type: none"> • Virtual KVM—Use this tab to set vKVM properties. • Virtual Media—Use this tab to set virtual media properties. • Serial over LAN—Use this tab to set serial over LAN properties.
BIOS	<p>There are three areas on this page:</p> <ul style="list-style-type: none"> • Actions—Use this area to configure the server boot order, recover corrupted BIOS, and clear the BIOS CMOS. • BIOS Properties—Use this area to view the running version of the BIOS. • Boot Order—Use this area to view the configured and actual boot order.
User Management	<p>There are three tabs on the page:</p> <ul style="list-style-type: none"> • Local Users—Use this tab to create users. • Active Directory—Use this tab to set active directory properties. • Sessions—Use this tab to view current user sessions.
Network	<p>There are two tabs on the page:</p> <ul style="list-style-type: none"> • Network Settings—Use this tab to set network properties. • Network Security—Use this tab to set up network security.
Communications Services	<p>There are three areas on this page:</p> <ul style="list-style-type: none"> • HTTP Properties—Use this area to set HTTP properties. • SSH Properties—Use this area to set SSH properties. • IPMI over LAN Properties—Use this area to set IPMI over LAN properties.
Certificate Management	<p>There are two areas on this page:</p> <ul style="list-style-type: none"> • Actions—Use this area to generate and upload a certificate.

	<ul style="list-style-type: none"> • Current Certificate—Use this area to view the current certificate for the server.
CIMC Log	On this page, you view the CIMC Log.
Event Management	<p>There are two tabs on the page:</p> <ul style="list-style-type: none"> • Platform Event Filters—Use this tab to set up platform event filters. • Trap Settings—Use this tab to set up SNMP traps.
Firmware Management	<p>There are four areas on this page:</p> <ul style="list-style-type: none"> • Actions—Use this area to install CIMC firmware from a client browser or TFTP server, or to activate installed CIMC firmware. • CIMC Firmware—Use this area to view the status of the running, backup, and boot-loader versions of the firmware. • Last Firmware Install—Use this area to view information about the last firmware update.
Utilities	<p>There are three areas on this page:</p> <ul style="list-style-type: none"> • Actions—Use this area to export technical support data, export or import the CIMC configuration, reset the CIMC to factory default, and reboot the CIMC. • Last Technical Support Data Export—Use this area to view information about the last technical support data export. • CIMC Configuration Import/Export—Use this area to view the action type and its status.

Toolbar

The toolbar displays above the **Work** pane.

Element Name	Description
Refresh	Refreshes the current page.
Power On Server	Powers on the server.
Power Off Server	Powers off the server.
Launch KVM Console	Launches the KVM console.
Help	Launches help.

Info	Launches server information.
-------------	------------------------------

Cisco Integrated Management Controller Online Help Overview

The Cisco Integrated Management Controller is divided into two main sections, a **Navigation** pane on the left and a **Work** pane on the right.

This help system describes the fields on each GUI page and in each dialog box.

To access the page help, do the following:

- In a particular tab in the GUI, click the **Help** icon in the toolbar above the **Work** pane.
- In a dialog box, click the **Help** button in that dialog box.



Note

For a complete list of the available C-Series documentation, see the *Cisco UCS C-Series Servers Documentation Roadmap* at <http://www.cisco.com/go/unifiedcomputing/c-series-doc>.

Logging Into CIMC

Before You Begin

If not installed, install Adobe Flash Player 10 or higher on your local machine.

Procedure

-
- Step 1** In your web browser, type or select the web link for CIMC.
- Step 2** If a security dialog box displays, do the following:
- (Optional) Check the check box to accept all content from Cisco.
 - Click **Yes** to accept the certificate and continue.
- Step 3** In the log in window, enter your username and password.
- Step 4** Click **Log In**.
-

Logging Out of CIMC

Procedure

-
- Step 1** In the upper right of CIMC, click **Log Out**.
Logging out returns you to the CIMC log in page.
- Step 2** (Optional) Log back in or close your web browser.
-



CHAPTER 2

Installing the Server OS

This chapter includes the following sections:

- [OS Installation Methods, page 11](#)
- [KVM Console, page 11](#)
- [PXE Installation Servers, page 12](#)

OS Installation Methods

C-Series servers support several operating systems. Regardless of the OS being installed, you can install it on your server using one of the following tools:

- KVM console
- PXE installation server

KVM Console

The KVM console is an interface accessible from CIMC that emulates a direct keyboard, video, and mouse (KVM) connection to the server. The KVM console allows you to connect to the server from a remote location.

Instead of using CD/DVD or floppy drives physically connected to the server, the KVM console uses virtual media, which are actual disk drives or disk image files that are mapped to virtual CD/DVD or floppy drives. You can map any of the following to a virtual drive:

- CD/DVD or floppy drive on your computer
- Disk image files (ISO or IMG files) on your computer
- USB flash drive on your computer
- CD/DVD or floppy drive on the network
- Disk image files (ISO or IMG files) on the network
- USB flash drive on the network

You can use the KVM console to install an OS on the server.

Installing an OS Using the KVM Console

Before You Begin

- Locate the OS installation disk or disk image file.
- You must log in as a user with admin privileges to install an OS.

Procedure

-
- Step 1** Load the OS installation disk into your CD/DVD drive, or copy the disk image files to your computer.
- Step 2** If CIMC is not open, log in.
- Step 3** In the **Navigation** pane, click the **Server** tab.
- Step 4** On the **Server** tab, click **Remote Presence**.
- Step 5** In the **Remote Presence** pane, click the **Virtual KVM** tab.
- Step 6** In the **Actions** area, click **Launch KVM Console**.
The **KVM Console** opens in a separate window.
- Step 7** From the KVM console, choose **Tools ► Launch Virtual Media** to open the **Virtual Media Session** dialog box.
- Step 8** In the **Virtual Media Session** dialog box, map the virtual media using either of the following methods:
- Check the **Mapped** check box for the CD/DVD drive containing the OS installation disk.
 - Click **Add Image**, navigate to and select the OS installation disk image, click **Open** to mount the disk image, and then check the **Mapped** check box for the mounted disk image.
- Note** You must keep the **Virtual Media Session** dialog box open during the OS installation process. Closing the dialog box unmaps all virtual media.
- Step 9** Reboot the server and select the virtual CD/DVD drive as the boot device.
When the server reboots, it begins the installation process from the virtual CD/DVD drive. Refer to the installation guide for the OS being installed to guide you through the rest of the installation process.
-

What to Do Next

After the OS installation is complete, reset the virtual media boot order to its original setting.

PXE Installation Servers

A Preboot Execution Environment (PXE) installation server allows a client to boot and install an OS from a remote location. To use this method, a PXE environment must be configured and available on your VLAN, typically a dedicated provisioning VLAN. Additionally, the server must be set to boot from the network. When the server boots, it sends a PXE request across the network. The PXE installation server acknowledges the request, and starts a sequence of events that installs the OS on the server.

PXE servers can use installation disks, disk images, or scripts to install an OS. Proprietary disk images can also be used to install an OS, additional components, or applications.



Note PXE installation is an efficient method for installing an OS on a large number of servers. However, considering that this method requires setting up a PXE environment, it might be easier to use another installation methods.

Installing an OS Using a PXE Installation Server

Before You Begin

- Verify that the server can be reached over a VLAN.
- You must log in as a user with admin privileges to install an OS.

Procedure

Step 1 Set the boot order to **PXE** first.

Step 2 Reboot the server.

If a PXE install server is available on the VLAN, the installation process begins when the server reboots. PXE installations are typically automated and require no additional user input. Refer to the installation guide for the OS being installed to guide you through the rest of the installation process.

What to Do Next

After the OS installation is complete, reset the LAN boot order to its original setting.



CHAPTER 3

Managing the Server

This chapter includes the following sections:

- [Viewing Overall Server Status, page 15](#)
- [Toggling the Locator LED, page 17](#)
- [Configuring the Server Boot Order, page 17](#)
- [Powering On the Server, page 19](#)
- [Powering Off the Server, page 19](#)
- [Power Cycling the Server, page 19](#)
- [Resetting the Server, page 20](#)
- [Shutting Down the Server, page 20](#)

Viewing Overall Server Status

Procedure

- Step 1** In the **Overall Server Status** area of the **Navigation** pane, click the blue health report link to refresh the Server Summary pane.
- Step 2** (Optional) Review the following information in the **Server Summary** pane:

Name	Description
Power State field	The current power state.
Overall Server Status field	The overall status of the server. This can be: <ul style="list-style-type: none">• Memory Test In Progress—The server is performing a self-test of the installed memory. This condition normally occurs during the boot process.• Good

Name	Description
	<ul style="list-style-type: none"> • Moderate Fault • Severe Fault • Powered Off
Processors field	<p>The overall status of the processors. This can be:</p> <ul style="list-style-type: none"> • Good • Fault • Powered Off <p>You can click the link in this field to view more information about the processors.</p>
Memory field	<p>The overall status of the memory modules. This can be:</p> <ul style="list-style-type: none"> • Good • Fault • Powered Off <p>You can click the link in this field to view detailed status information.</p>
Power Supplies field	<p>The overall status of the power supplies. This can be:</p> <ul style="list-style-type: none"> • Good • Fault • Powered Off <p>You can click the link in this field to view detailed status information.</p>
Fans field	<p>The overall status of the power supplies. This can be:</p> <ul style="list-style-type: none"> • Good • Fault • Powered Off <p>You can click the link in this field to view detailed status information.</p> <p>Note This field is only displayed for some C Series servers.</p>
HDD field	<p>The overall status of the hard drives. This can be:</p> <ul style="list-style-type: none"> • Good • Fault • Powered Off

Name	Description
	<p>You can click the link in this field to view detailed status information.</p> <p>Note This field is only displayed for some C Series servers.</p>
Locator LED field	Whether the locator LEDs are on or off.

Toggling the Locator LED

Before You Begin

You must have user privileges for all power control operations including this operation.

Procedure

-
- Step 1** In the **Navigation** pane, click the **Server** tab.
 - Step 2** On the **Server** tab, click **Summary**.
 - Step 3** In the **Actions** area, click **Turn On Locator LED**.
The locator LED turns on and is blinking.
 - Step 4** In the **Actions** area, click **Turn Off Locator LED**.
The locator LED turns off.
-

Configuring the Server Boot Order

Before You Begin

You must log in as a user with admin privileges to configure server boot order.

Procedure

-
- Step 1** In the **Navigation** pane, click the **Server** tab.
 - Step 2** On the **Server** tab, click **BIOS**.
The BIOS page appears.
 - Step 3** In the **Actions** area, click **Configure Boot Order**.
A dialog box with boot order instructions appears.
 - Step 4** Review the instructions, and then click **OK**.

The **Configure Boot Order** dialog box displays.

Step 5 In the **Configure Boot Order** dialog box, update the following properties:

Name	Description
Device Types table	The server boot options. You can select one or more of the following: <ul style="list-style-type: none"> • HDD—Hard disk drive • FDD—Floppy disk drive • CDROM—Bootable CD-ROM • PXE—PXE boot • EFI—Extensible Firmware Interface
Add >	Moves the selected device type to the Boot Order table.
< Remove	Removes the selected device type from the Boot Order table.
Boot Order table	Displays the device types from which this server can boot, in the order in which the boot will be attempted.
Up	Moves the selected device type to a higher priority in the Boot Order table.
Down	Moves the selected device type to a lower priority in the Boot Order table.
Apply button	Saves the changes to the configured boot order or reapplies a previously-configured boot order. CIMC sends the configured boot order to the BIOS the next time the server is rebooted.
Cancel button	Closes the dialog box without saving any changes or reapplying the existing configuration. If you select this option, the actual boot order will not be changed the next time the server is rebooted.

Step 6 Click **Apply**.
Additional device types may be appended to the actual boot order, depending on what devices you have connected to your server.

What to Do Next

Reboot the server to boot with your new boot order.

Powering On the Server



Note If the server was powered off by any means other than through CIMC, it will not become active immediately when powered on. The server will remain in standby mode until CIMC completes initialization.

Before You Begin

You must log in with user or admin privileges to perform this task.

Procedure

- Step 1** In the **Navigation** pane, click the **Server** tab.
 - Step 2** On the **Server** tab, click **Summary**.
 - Step 3** In the **Actions** area, click **Power On Server**.
A dialog box with the message **Power on the server?** appears.
 - Step 4** Click **OK**.
-

Powering Off the Server

Before You Begin

You must log in with user or admin privileges to perform this task.

Procedure

- Step 1** In the **Navigation** pane, click the **Server** tab.
 - Step 2** On the **Server** tab, click **Summary**.
 - Step 3** In the **Actions** area, click **Power Off Server**.
A dialog box with the message **Power Off the Server?** appears.
 - Step 4** Click **OK**.
-

Power Cycling the Server

Before You Begin

You must log in with user or admin privileges to perform this task.

Procedure

- Step 1** In the **Navigation** pane, click the **Server** tab.
 - Step 2** On the **Server** tab, click **Summary**.
 - Step 3** In the **Actions** area, click **Power Cycle Server**.
A dialog box with the message **Power Cycle the Server?** appears.
 - Step 4** Click **OK**.
-

Resetting the Server

Before You Begin

You must log in with user or admin privileges to perform this task.

Procedure

- Step 1** In the **Navigation** pane, click the **Server** tab.
 - Step 2** On the **Server** tab, click **Summary**.
 - Step 3** In the **Actions** area, click **Hard Reset Server**.
A dialog box with the message **Hard Reset the Server?** appears.
 - Step 4** Click **OK**.
-

Shutting Down the Server

Before You Begin

You must log in with user or admin privileges to perform this task.

Procedure

- Step 1** In the **Navigation** pane, click the **Server** tab.
 - Step 2** On the **Server** tab, click **Summary**.
 - Step 3** In the **Actions** area, click **Shut Down Server**.
A dialog box with the message **Shut Down the Server?** appears.
 - Step 4** Click **OK**.
-



CHAPTER 4

Viewing Server Properties

This chapter includes the following sections:

- [Viewing CPU Properties, page 21](#)
- [Viewing Memory Properties, page 22](#)
- [Viewing Power Supply Properties, page 22](#)
- [Viewing Storage Properties, page 23](#)

Viewing CPU Properties

Procedure

- Step 1** In the **Navigation** pane, click the **Server** tab.
- Step 2** On the **Server** tab, click **Inventory**.
- Step 3** In the **Inventory** pane, click the **CPUs** tab.
- Step 4** Review the following information for each CPU:

Name	Description
Socket Name field	The socket in which the CPU is installed.
Serial Number field	The serial number for the CPU.
Vendor field	The vendor for the CPU.
Version field	The CPU version.
Number of Cores field	The number of cores in the CPU.
Signature field	The CPU signature.
Max Speed field	The maximum CPU speed supported by the socket.

Name	Description
Number of Threads field	The maximum number of threads that the CPU can process concurrently.

Viewing Memory Properties

Procedure

Step 1 In the **Navigation** pane, click the **Server** tab.

Step 2 On the **Server** tab, click **Inventory**.

Step 3 In the **Inventory** pane, click the **Memory** tab.

Step 4 Review the following information about memory:

Tip Click a column header to sort the table rows, according to the entries in that column.

Name	Description
Name column	The name of the DIMM slot in which the memory module is installed.
Capacity column	The size of the DIMM, in megabytes.
Speed column	The clock speed of the memory module, in megahertz.
Type column	The memory type.

Viewing Power Supply Properties

Procedure

Step 1 In the **Navigation** pane, click the **Server** tab.

Step 2 On the **Server** tab, click **Inventory**.

Step 3 In the **Inventory** pane, click the **Power Supplies** tab.

Step 4 Review the following information for each power supply:

Tip Click a column header to sort the table rows, according to the entries in that column.

Name	Description
Device ID column	The identifier for the power supply unit.

Name	Description
Input column	The input into the power supply, in watts.
Max Output column	The maximum output from the power supply, in watts.
FW Version column	The firmware version for the power supply.

Viewing Storage Properties

Procedure

- Step 1** In the **Navigation** pane, click the **Server** tab.
- Step 2** On the **Server** tab, click **Inventory**.
- Step 3** In the **Inventory** pane, click the **Storage** tab.
- Step 4** Review the following information about storage:
- Tip** Click a column header to sort the table rows, according to the entries in that column.

Name	Description
Name column	The name of the storage device.
Status column	The status of the storage device. This can be: <ul style="list-style-type: none"> • absent • present



CHAPTER 5

Viewing Server Sensors

This chapter includes the following sections:

- [Viewing Current Sensors, page 25](#)
- [Viewing LED Sensors, page 26](#)
- [Viewing Fan Sensors, page 27](#)
- [Viewing Power Supply Sensors, page 27](#)
- [Viewing Temperature Sensors, page 29](#)
- [Viewing Voltage Sensors, page 30](#)

Viewing Current Sensors

Procedure

- Step 1** In the **Navigation** pane, click the **Server** tab.
- Step 2** On the **Server** tab, click **Sensors**.
- Step 3** In the **Sensors** pane, click the **Current** tab.
- Step 4** View the following current-related statistics on the **Current** tab:

Name	Description
Sensor Name column	The name of the sensor.
Status column	The status of the sensor. This can be: <ul style="list-style-type: none">• Unknown• Informational• Normal• Warning

Name	Description
	<ul style="list-style-type: none"> • Critical • Non-Recoverable
Current column	The current in amperes.
Warning Threshold Min column	The minimum warning threshold.
Warning Threshold Max column	The maximum warning threshold.
Critical Threshold Min column	The minimum critical threshold.
Critical Threshold Max column	The maximum critical threshold.

Viewing LED Sensors

Procedure

- Step 1** In the **Navigation** pane, click the **Server** tab.
- Step 2** On the **Server** tab, click **Sensors**.
- Step 3** In the **Sensors** pane, click the **LEDs** tab.
- Step 4** View the following LED-related statistics for the server:

Name	Description
Sensor Name column	The name of the sensor.
LED State column	Whether the LED is on or off.
LED Color column	The current color of the LED.

Viewing Fan Sensors

Procedure

Step 1 In the **Navigation** pane, click the **Server** tab.

Step 2 On the **Server** tab, click **Sensors**.

Step 3 In the **Sensors** pane, click the **Fan** tab.

Step 4 View the following fan-related statistics for the server:

Tip Click a column header to sort the table rows according to the entries in that column.

Name	Description
Sensor Name column	The name of the sensor.
Status column	The status of the sensor. This can be: <ul style="list-style-type: none"> • Unknown • Informational • Normal • Warning • Critical • Non-Recoverable
Speed column	The fan speed in RPM.
Warning Threshold Min column	The minimum warning threshold.
Warning Threshold Max column	The maximum warning threshold.
Critical Threshold Min column	The minimum critical threshold.
Critical Threshold Max column	The maximum critical threshold.

Viewing Power Supply Sensors



Tip Click a column header to sort the table rows according to the entries in that column.

Procedure

- Step 1** In the **Navigation** pane, click the **Server** tab.
- Step 2** On the **Server** tab, click **Sensors**.
- Step 3** In the **Sensors** pane, click the **Power Supply** tab.
- Step 4** In the **Properties** area, the **Redundancy Status** field displays the status of the power supply redundancy of the server.
- Step 5** In the **Threshold Sensors** area, you can view the following statistics for the server:

Name	Description
Sensor Name column	The name of the sensor.
Status column	The status of the sensor. This can be: <ul style="list-style-type: none"> • Unknown • Informational • Normal • Warning • Critical • Non-Recoverable
Reading column	The current power supply usage, in watts.
Warning Threshold Min column	The minimum warning threshold.
Warning Threshold Max column	The maximum warning threshold.
Critical Threshold Min column	The minimum critical threshold.
Critical Threshold Max column	The maximum critical threshold.

- Step 6** In the **Discrete Sensors** area, you can view the following statistics for the server:

Name	Description
Sensor Name column	The name of the sensor.
Status column	The status of the sensor. This can be: <ul style="list-style-type: none"> • Unknown • Informational • Normal • Warning • Critical

Name	Description
	<ul style="list-style-type: none"> • Non-Recoverable
Reading column	This can be: <ul style="list-style-type: none"> • absent • present

Viewing Temperature Sensors

Procedure

- Step 1** In the **Navigation** pane, click the **Server** tab.
- Step 2** On the **Server** tab, click **Sensors**.
- Step 3** In the **Sensors** pane, click the **Temperature** tab.
- Step 4** View the following temperature-related statistics for the server:
- Tip** Click a column header to sort the table rows according to the entries in that column.

Name	Description
Sensor Name column	The name of the sensor.
Status column	The status of the sensor. This can be: <ul style="list-style-type: none"> • Unknown • Informational • Normal • Warning • Critical • Non-Recoverable
Temperature column	The current temperature, in Celsius.
Warning Threshold Min column	The minimum warning threshold.
Warning Threshold Max column	The maximum warning threshold.
Critical Threshold Min column	The minimum critical threshold.

Name	Description
Critical Threshold Max column	The maximum critical threshold.

Viewing Voltage Sensors

Procedure

Step 1 In the **Navigation** pane, click the **Server** tab.

Step 2 On the **Server** tab, click **Sensors**.

Step 3 In the **Sensors** pane, click the **Voltage** tab.

Step 4 View the following voltage-related statistics for the server:

Tip Click a column header to sort the table rows according to the entries in that column.

Name	Description
Sensor Name column	The name of the sensor.
Status column	The status of the sensor. This can be: <ul style="list-style-type: none"> • Unknown • Informational • Normal • Warning • Critical • Non-Recoverable
Voltage column	The current voltage, in volts.
Warning Threshold Min column	The minimum warning threshold.
Warning Threshold Max column	The maximum warning threshold.
Critical Threshold Min column	The minimum critical threshold.
Critical Threshold Max column	The maximum critical threshold.



CHAPTER 6

Managing Remote Presence

This chapter includes the following sections:

- [Configuring Serial Over LAN, page 31](#)
- [Configuring Virtual Media, page 32](#)
- [KVM Console, page 32](#)
- [Configuring the Virtual KVM, page 33](#)

Configuring Serial Over LAN

Serial over LAN enables the input and output of the serial port of a managed system to be redirected over IP. Configure and use serial over LAN on your server when you want to reach the host console with CIMC.

Before You Begin

You must log in as a user with admin privileges to configure serial over LAN.

Procedure

- Step 1** In the **Navigation** pane, click the **Server** tab.
- Step 2** On the **Server** tab, click **Remote Presence**.
- Step 3** In the **Remote Presence** pane, click the **Serial over LAN** tab.
- Step 4** In the **Serial over LAN Properties** area, update the following properties:

Name	Description
Enabled check box	If checked, Serial over LAN is enabled on this server.
Baud Rate field	The baud rate the system uses for Serial over LAN communication.

- Step 5** Click **Save Changes**.
-

Configuring Virtual Media

Before You Begin

You must log in as a user with admin privileges to configure virtual media.

Procedure

-
- Step 1** In the **Navigation** pane, click the **Server** tab.
- Step 2** On the **Server** tab, click **Remote Presence**.
- Step 3** In the **Remote Presence** pane, click the **Virtual Media** tab.
- Step 4** In the **Virtual Media Properties** area, update the following properties:

Name	Description
Enabled check box	If checked, virtual media is enabled. Note If you clear this check box, all virtual media devices are automatically detached from the host.
Active Sessions field	The number of virtual media sessions currently running.
Enable Virtual Media Encryption check box	If checked, all virtual media communications are encrypted.

- Step 5** Click **Save Changes**.
-

KVM Console

The KVM console is an interface accessible from CIMC that emulates a direct keyboard, video, and mouse (KVM) connection to the server. The KVM console allows you to connect to the server from a remote location.

Instead of using CD/DVD or floppy drives physically connected to the server, the KVM console uses virtual media, which are actual disk drives or disk image files that are mapped to virtual CD/DVD or floppy drives. You can map any of the following to a virtual drive:

- CD/DVD or floppy drive on your computer
- Disk image files (ISO or IMG files) on your computer
- USB flash drive on your computer
- CD/DVD or floppy drive on the network
- Disk image files (ISO or IMG files) on the network
- USB flash drive on the network

You can use the KVM console to install an OS on the server.

Configuring the Virtual KVM

Before You Begin

You must log in as a user with admin privileges to configure the virtual KVM.

Procedure

- Step 1** In the **Navigation** pane, click the **Server** tab.
- Step 2** On the **Server** tab, click **Remote Presence**.
- Step 3** In the **Remote Presence** pane, click the **Virtual KVM** tab.
- Step 4** On the **Virtual KVM** tab, complete the following fields:

Name	Description
Enabled check box	If checked, the virtual KVM is enabled. Note The virtual media viewer is accessed through the KVM. If you disable the KVM console, CIMC also disables access to all virtual media devices attached to the host.
Max Sessions field	The maximum number of concurrent KVM sessions allowed. Enter an integer between 1 and 4.
Active Sessions field	The number of KVM sessions running on the server.
Remote Port field	The port used for KVM communication.
Enable Video Encryption check box	If checked, the server encrypts all video information sent through the KVM.
Enable Local Server Video check box	If checked, the KVM session is also displayed on any monitor attached to the server.

- Step 5** Click **Save Changes**.

Disabling the Virtual KVM

Before You Begin

You must log in as a user with admin privileges to disable the virtual KVM.

Procedure

- Step 1** In the **Navigation** pane, click the **Server** tab.
 - Step 2** On the **Server** tab, click **Remote Presence**.
 - Step 3** In the **Remote Presence** pane, click the **Virtual KVM** tab.
 - Step 4** On the **Virtual KVM** tab, uncheck the **Enabled** check box.
 - Step 5** Click **Save Changes**.
-

Enabling the Virtual KVM

Before You Begin

You must log in as a user with admin privileges to enable the virtual KVM.

Procedure

- Step 1** In the **Navigation** pane, click the **Server** tab.
 - Step 2** On the **Server** tab, click **Remote Presence**.
 - Step 3** In the **Remote Presence** pane, click the **Virtual KVM** tab.
 - Step 4** On the **Virtual KVM** tab, check the **Enabled** check box.
 - Step 5** Click **Save Changes**.
-



CHAPTER 7

Managing User Accounts

This chapter includes the following sections:

- [Active Directory, page 35](#)
- [Configuring Local Users, page 37](#)
- [Viewing User Sessions, page 39](#)

Active Directory

Active Directory is a technology that provides a variety of network services including LDAP-like directory services, Kerberos-based authentication, and DNS-based naming. The CIMC utilizes the Kerberos-based authentication service of Active Directory.

When Active Directory is enabled in the CIMC, all user authentication and role authorization is performed by Active Directory, and the CIMC ignores the local database. If the CIMC cannot connect to Active Directory, it reverts to the local database.

you can require the server to encrypt data sent to Active Directory.

Configuring Active Directory in CIMC

Before You Begin

You must log in as a user with admin privileges to configure active directory.

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
- Step 2** On the **Admin** tab, click **User Management**.
- Step 3** In the **User Management** pane, click the **Active Directory** tab.
- Step 4** In the **Active Directory Properties** area, update the following properties:

Name	Description
Enabled check box	If checked, user authentication and role authorization is performed by Active Directory for user accounts not found in the local user database.
Server IP Address field	The Active Directory server IP address.
Timeout field	The number of seconds the CIMC waits until it assumes the connection to Active Directory cannot be established.
Enable Encryption check box	If checked, the server encrypts all information it sends to Active Directory.
Domain field	The domain that all users must be in.
Attributes field	<p>An LDAP attribute that contains the role and locale information for the user. This property is always a name-value pair. The system queries the user record for the value that matches this attribute name.</p> <p>The LDAP attribute must have the following attribute ID: 1.3.6.1.4.1.9.287247.1</p> <p>Note If you do not specify this property, user access is restricted to read-only.</p>

Step 5 Click **Save Changes**.

Configuring the Active Directory Server

The CIMC can be configured to use Active Directory for user authentication and authorization. To use Active Directory, configure users with an attribute that holds the user role and locale information for the CIMC. You can use an existing LDAP attribute that is mapped to the CIMC user roles and locales or you can modify the Active Directory schema to add a new custom attribute, such as the CiscoAVPair attribute, which has an attribute ID of 1.3.6.1.4.1.9.287247.1. For more information about altering the Active Directory schema, see the article at <http://technet.microsoft.com/en-us/library/bb727064.aspx>.

The following steps are to be performed on the Active Directory server.



Note

This example creates a custom attribute named CiscoAVPair, but you can also use an existing LDAP attribute that is mapped to the CIMC user roles and locales.

Procedure

- Step 1** Ensure that the Active Directory schema snap-in is installed.
- Step 2** Using the Active Directory schema snap-in, add a new attribute with the following properties:

Properties	Value
Common Name	CiscoAVPair
LDAP Display Name	CiscoAVPair
Unique X500 Object ID	1.3.6.1.4.1.9.287247.1
Description	CiscoAVPair
Syntax	Case Sensitive String

Step 3 Add the CiscoAVPair attribute to the user class using the Active Directory snap-in:

- a) Expand the **Classes** node in the left pane and type U to select the user class.
- b) Click the **Attributes** tab and click **Add**.
- c) Type C to select the CiscoAVPair attribute.
- d) Click **OK**.

Step 4 Add the following user role values to the CiscoAVPair attribute, for the users that you want to have access to CIMC:

Role	CiscoAVPair Attribute Value
admin	shell:roles="admin"
user	shell:roles="user"
read-only	shell:roles="read-only"

Note For more information about adding values to attributes, see the article at <http://technet.microsoft.com/en-us/library/bb727064.aspx>.

What to Do Next

Use the CIMC to configure Active Directory.

Configuring Local Users

Before You Begin

You must log in as a user with admin privileges to configure local users.

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
- Step 2** On the **Admin** tab, click **User Management**.
- Step 3** In the **User Management** pane, click the **Local User** tab.
- Step 4** To configure a local user, click in a row.
- Step 5** In the **User Details** dialog box, update the following properties:

Name	Description
ID column	The unique identifier for the user.
Enabled check box	If checked, the user is enabled on the CIMC.
User Name column	The user name for the user.
Role column	<p>The role assigned to the user. This can be:</p> <ul style="list-style-type: none"> • read-only—This user can view information but cannot make any changes. • user—This user can: <ul style="list-style-type: none"> ◦ View all information ◦ Manage the power control options such as power on, power cycle, and power off ◦ Launch the KVM console and virtual media ◦ Clear all logs ◦ Toggle the locator LED • admin—This user can perform all actions available through the GUI, CLI, and IPMI.

- Step 6** Enter password information.
- Step 7** Click **Save Changes**.
-

Viewing User Sessions

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
- Step 2** On the **Admin** tab, click **User Management**.
- Step 3** In the **User Management** pane, click the **Sessions** tab.
- Step 4** View the following information about current user sessions:
- Tip** Click a column header to sort the table rows, according to the entries in that column.

Name	Description
Session ID column	The unique identifier for the session.
Username column	The user name for the user.
IP Address column	The IP address from which the user accessed the server.
Type column	The method by which the user accessed the server.
Action column	If your user account has admin privileges, this column displays Terminate if you can force the associated user session to end. Otherwise it displays N/A . Note You cannot terminate your current session from this tab.



CHAPTER 8

Configuring Network-Related Settings

This chapter includes the following sections:

- [Server NIC Configuration, page 41](#)
- [Configuring Common Properties, page 43](#)
- [Configuring IPv4, page 43](#)
- [Connecting to a VLAN, page 44](#)
- [Network Security Configuration, page 45](#)

Server NIC Configuration

Server NICs

Two NIC modes are available for connection to the CIMC. In one mode, you can also choose an active-active or active-standby redundancy mode, depending on your platform.

NIC Mode

- **Dedicated**—A connection to the CIMC is available through the management Ethernet port or ports.
- **Shared LOM**—A connection to the CIMC is available only through the LAN On Motherboard (LOM) Ethernet host ports.



Note In shared LOM mode, all host ports must belong to the same subnet.

- **Shipping (if supported)**—A connection to the CIMC is available through the management Ethernet port or ports using a limited factory default configuration.



Note Shipping mode is intended only for your initial connection to the CIMC. Configure another mode for operation.

NIC Redundancy

- **None**—Redundancy is not available.
- **Active-Active**—All Ethernet ports operate simultaneously. This mode provides multiple paths to the CIMC.
- **Active-Standby**—One port fails over to the other.

The available redundancy modes vary depending on the selected network mode and your platform. For the available modes, see the Installation and Service Guide for your platform.

Configuring Server NICs

Configure a server NIC when you want to set the NIC mode and NIC redundancy.

Before You Begin

You must log in as a user with admin privileges to configure the NIC.

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
- Step 2** On the **Admin** tab, click **Network**.
- Step 3** In the **Network** pane, click the **Network Settings** tab.
- Step 4** In the **NIC Properties** area, update the following properties:

Name	Description
NIC Mode drop-down list	<p>The NIC mode. This can be:</p> <ul style="list-style-type: none"> • Dedicated—The management port is used to access the CIMC. • Shared LOM—The LOM (LAN On Motherboard) ports are used to access the CIMC. • Shipping—The out-of-the-box defaults will be used for all options. <p>Note This option is only available for some C-Series servers.</p>
NIC Redundancy drop-down list	<p>The NIC redundancy options depend on the mode chosen in the NIC Mode drop-down list. If you do not see a particular option, then it is not available for the selected mode.</p> <p>The available options are:</p> <ul style="list-style-type: none"> • None—Each port associated with the configured NIC mode operates independently. The ports do not failover if there is a problem. • active-active—If supported, all ports associated with the configured NIC mode operate simultaneously. This increases throughput and provides multiple paths to the CIMC.

Name	Description
	<ul style="list-style-type: none"> • active-standby—If a port associated with the configured NIC mode fails, traffic will failover to one of the other ports associated with the NIC mode. <p>Note If you select this option, make sure all ports associated with the configured NIC mode are connected to the same subnet to ensure that traffic is secure regardless of which port is used.</p>
MAC Address field	The MAC address of the CIMC network interface selected in the NIC Mode field.

Step 5 Click **Save Changes**.

Configuring Common Properties

Use common properties to describe your server.

Before You Begin

You must log in as a user with admin privileges to configure common properties.

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
 - Step 2** On the **Admin** tab, click **Network**.
 - Step 3** In the **Network** pane, click the **Network Settings** tab.
 - Step 4** In the **Hostname** field, enter the name of the host.
 - Step 5** Click **Save Changes**.
-

Configuring IPv4

Before You Begin

You must log in as a user with admin privileges to configure IPv4.

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
- Step 2** On the **Admin** tab, click **Network**.
- Step 3** In the **Network** pane, click the **Network Settings** tab.
- Step 4** In the **IPv4 Properties** area, update the following properties:

Name	Description
Enable IPv4 check box	If checked, IPv4 is enabled.
Use DHCP check box	If checked, the CIMC uses DHCP.
IP Address field	The IP address for the CIMC.
Subnet Mask field	The subnet mask for the IP address.
Gateway field	The gateway for the IP address.
Obtain DNS Server Addresses from DHCP check box	If checked, the CIMC retrieves the DNS server addresses from DHCP.
Preferred DNS Server field	The IP address of the primary DNS server.
Alternate DNS Server field	The IP address of the secondary DNS server.

- Step 5** Click **Save Changes**.

Connecting to a VLAN

Before You Begin

You must be logged in as admin to connect to a VLAN.

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
- Step 2** On the **Admin** tab, click **Network**.
- Step 3** In the **Network** pane, click the **Network Settings** tab.
- Step 4** In the **VLAN Properties** area, update the following properties:

Name	Description
Enable VLAN check box	If checked, the CIMC is connected to a virtual LAN.

Name	Description
VLAN ID field	The VLAN ID.
Priority field	The priority of this system on the VLAN.

Step 5 Click **Save Changes**.

Network Security Configuration

Network Security

The CIMC uses IP blocking as network security. IP blocking prevents the connection between a server or website and certain IP addresses or ranges of addresses. IP blocking effectively bans undesired connections from those computers to a website, mail server, or other Internet servers.

IP banning is commonly used to protect against denial of service (DoS) attacks. CIMC bans IP addresses by setting up an IP blocking fail count.

Configuring Network Security

Configure network security if you want to set up an IP blocking fail count.

Before You Begin

You must log in as a user with admin privileges to configure network security.

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
- Step 2** On the **Admin** tab, click **Network**.
- Step 3** In the **Network** pane, click the **Network Security** tab.
- Step 4** In the **IP Blocking Properties** area, update the following properties:

Name	Description
Enable IP Blocking check box	Check this box to enable IP blocking.
IP Blocking Fail Count field	The number of times a user can attempt to log in unsuccessfully before the system locks that user out for a specified length of time. The number of unsuccessful login attempts must occur within the time frame specified in the IP Blocking Fail Window field. Enter an integer between 3 and 10.

Name	Description
IP Blocking Fail Window field	The length of time, in seconds, in which the unsuccessful login attempts must occur in order for the user to be locked out. Enter an integer between 60 and 120.
IP Blocking Penalty Time field	The number of seconds the user remains locked out if they exceed the maximum number of login attempts within the specified time window. Enter an integer between 300 and 900.

Step 5 Click **Save Changes**.



CHAPTER 9

Configuring Communication Services

This chapter includes the following sections:

- [Configuring HTTP, page 47](#)
- [Configuring SSH, page 48](#)
- [IPMI Over LAN, page 49](#)
- [Configuring IPMI over LAN, page 49](#)

Configuring HTTP

Before You Begin

You must log in as a user with admin privileges to configure HTTP.

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
- Step 2** On the **Admin** tab, click **Communication Services**.
- Step 3** In the **HTTP Properties** area, update the following properties:

Name	Description
HTTP/S Enabled check box	Whether HTTP and HTTPS are enabled on the CIMC.
HTTP Port field	The port to use for HTTP communication. The default is 80.
HTTPS Port field	The port to use for HTTPS communication. The default is 443
Session Timeout field	The number of seconds to wait between HTTP requests before the CIMC times out and terminates the session. Enter an integer between 60 and 10,800. The default is 1,800 seconds.

Name	Description
Max Sessions field	The maximum number of concurrent HTTP and HTTPS sessions allowed on the CIMC. This value may not be changed.
Active Sessions field	The number of HTTP and HTTPS sessions currently running on the CIMC.

Step 4 Click **Save Changes**.

Configuring SSH

Before You Begin

You must log in as a user with admin privileges to configure SSH.

Procedure

Step 1 In the **Navigation** pane, click the **Admin** tab.

Step 2 On the **Admin** tab, click **Communication Services**.

Step 3 In the **SSH Properties** area, update the following properties:

Name	Description
SSH Enabled check box	Whether SSH is enabled on the CIMC.
SSH Port field	The port to use for secure shell access. The default is 22.
SSH Timeout field	The number of seconds to wait before the system considers an SSH request to have timed out. Enter an integer between 60 and 10,800. The default is 1,800 seconds.
Max Sessions field	The maximum number of concurrent SSH sessions allowed on the CIMC. This value may not be changed.
Active Sessions field	The number of SSH sessions currently running on the CIMC.

Step 4 Click **Save Changes**.

IPMI Over LAN

IPMI defines the protocols for interfacing with a service processor embedded in a server platform. This service processor is called a Baseboard Management Controller (BMC), and resides on the server motherboard. The BMC links to a main processor and other on-board elements using a simple serial bus.

During normal operations, IPMI lets a server operating system obtain information about system health and control system hardware. For example, IPMI enables the monitoring of sensors, such as temperature, fan speeds and voltages, for proactive problem detection. If server temperature rises above specified levels, the server operating system can direct the BMC to increase fan speed or reduce processor speed to address the problem.

Configuring IPMI over LAN

Configure IPMI over LAN when you want to manage the CIMC with IPMI messages.

Before You Begin

You must log in as a user with admin privileges to configure IPMI over LAN.

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
- Step 2** On the **Admin** tab, click **Communication Services**.
- Step 3** In the **IPMI over LAN Properties** area, update the following properties:

Name	Description
Enabled check box	Whether IPMI access is allowed on this server.
Privilege Level Limit drop-down list	<p>The user role that must be assigned to users accessing the system through IPMI. This can be:</p> <ul style="list-style-type: none"> • read-only—This user can view information but cannot make any changes. • user—This user can: <ul style="list-style-type: none"> ◦ View all information ◦ Manage the power control options such as power on, power cycle, and power off ◦ Launch the KVM console and virtual media ◦ Clear all logs ◦ Toggle the locator LED • admin—This user can perform all actions available through the GUI, CLI, and IPMI.

Name	Description
	Note The value of this field must match exactly the role assigned to the user attempting to log in. For example, if this field is set to read-only and a user with the admin role attempts to log in through IPMI, that login attempt will fail.
Encryption Key field	The IPMI encryption key to use for IPMI communications.

Step 4 Click **Save Changes**.



CHAPTER 10

Managing Certificates

This chapter includes the following sections:

- [Managing the Server Certificate, page 51](#)
- [Generating a Certificate Signing Request, page 52](#)
- [Creating a Self-Signed Certificate, page 53](#)
- [Uploading a Server Certificate, page 54](#)

Managing the Server Certificate

You can generate a certificate signing request (CSR) to obtain a new certificate, and you can upload the new certificate to the CIMC to replace the current server certificate. The server certificate may be signed either by a public Certificate Authority (CA), such as Verisign, or by your own certificate authority.

Procedure

	Command or Action	Purpose
Step 1	Generate the CSR from the CIMC.	
Step 2	Submit the CSR file to a certificate authority that will issue and sign your certificate. If your organization generates its own self-signed certificates, you can use the CSR file to generate a self-signed certificate.	
Step 3	Upload the new certificate to the CIMC.	Note The uploaded certificate must be created from a CSR generated by the CIMC. Do not upload a certificate that was not created by this method.

Generating a Certificate Signing Request

Before You Begin

You must log in as a user with admin privileges to configure certificates.

Procedure

-
- Step 1** In the **Navigation** pane, click the **Admin** tab.
- Step 2** On the **Admin** tab, click **Certificate Management**.
- Step 3** In the **Actions** area, click the **Generate New Certificate Signing Request** link. The **Generate New Certificate Signing Request** dialog box appears.
- Step 4** In the **Generate New Certificate Signing Request** dialog box, update the following properties:

Name	Description
Common Name field	The fully qualified hostname of the CIMC.
Organization Name field	The organization requesting the certificate.
Organization Unit field	The organizational unit.
Locality field	The city or town in which the company requesting the certificate is headquartered.
State Name field	The state or province in which the company requesting the certificate is headquartered.
Country Code drop-down list	The country in which the company resides.
Email field	The email contact at the company.

- Step 5** Click **Generate CSR**. The **Opening csr.txt** dialog box appears.
- Step 6** Perform any one of the following steps to manage the CSR file, csr.txt:
- Click **Open With** to view csr.txt.
 - Click **Save File** and then click **OK** to save csr.txt to your local machine.
-

What to Do Next

Submit the CSR file to a certificate authority that will issue and sign your certificate. If your organization generates its own self-signed certificates, you can use the CSR file to generate a self-signed certificate.

Creating a Self-Signed Certificate

As an alternative to using a public Certificate Authority (CA) to generate and sign a server certificate, you can operate your own CA and sign your own certificates. This section shows commands for creating a CA and generating a server certificate using the OpenSSL certificate server running on Linux. For detailed information about OpenSSL, see <http://www.openssl.org>.



Note These commands are to be entered on a Linux server with the OpenSSL package, not in the CIMC CLI.

Before You Begin

Obtain and install a certificate server software package on a server within your organization.

Procedure

	Command or Action	Purpose
Step 1	<p>openssl genrsa -out CA_keyfilename keysize</p> <p>Example: # openssl genrsa -out ca.key 1024</p>	<p>This command generates an RSA private key that will be used by the CA.</p> <p>Note To allow the CA to access the key without user input, do not use the -des3 option for this command.</p> <p>The specified file name contains an RSA key of the specified key size.</p>
Step 2	<p>openssl req -new -x509 -days numdays -key CA_keyfilename -out CA_certfilename</p> <p>Example: # openssl req -new -x509 -days 365 -key ca.key -out ca.crt</p>	<p>This command generates a new self-signed certificate for the CA using the specified key. The certificate is valid for the specified period. The command prompts the user for additional certificate information.</p> <p>The certificate server is an active CA.</p>
Step 3	<p>echo "nsCertType = server" > openssl.conf</p> <p>Example: # echo "nsCertType = server" > openssl.conf</p>	<p>This command adds a line to the OpenSSL configuration file to designate the certificate as a server-only certificate. This designation is a defense against a man-in-the-middle attack, in which an authorized client attempts to impersonate the server.</p> <p>The OpenSSL configuration file openssl.conf contains the statement "nsCertType = server".</p>
Step 4	<p>openssl x509 -req -days numdays -in CSR_filename -CA CA_certfilename -set_serial 04 -CAkey CA_keyfilename -out server_certfilename -extfile openssl.conf</p> <p>Example: # openssl x509 -req -days 365 -in csr.txt -CA ca.crt -set_serial 04</p>	<p>This command directs the CA to use your CSR file to generate a server certificate.</p> <p>Your server certificate is contained in the output file.</p>

	Command or Action	Purpose
	<code>-CAkey ca.key -out myserver05.crt -extfile openssl.conf</code>	

This example shows how to create a CA and to generate a server certificate signed by the new CA. These commands are entered on a Linux server running OpenSSL.

```
# /usr/bin/openssl genrsa -out ca.key 1024
Generating RSA private key, 1024 bit long modulus
.....++++++
.....++++++
e is 65537 (0x10001)
# /usr/bin/openssl req -new -x509 -days 365 -key ca.key -out ca.crt
You are about to be asked to enter information that will be incorporated
into your certificate request.
What you are about to enter is what is called a Distinguished Name or a
DN.
There are quite a few fields but you can leave some blank
For some fields there will be a default value,
If you enter '.', the field will be left blank.
-----
Country Name (2 letter code) [GB]:US
State or Province Name (full name) [Berkshire]:California
Locality Name (eg, city) [Newbury]:San Jose
Organization Name (eg, company) [My Company Ltd]:Example Incorporated
Organizational Unit Name (eg, section) []:Unit A
Common Name (eg, your name or your server's hostname) []:example.com
Email Address []:admin@example.com
# echo "nsCertType = server" > openssl.conf
# /usr/bin/openssl x509 -req -days 365 -in csr.txt -CA ca.crt -set_serial 01 -CAkey ca.key -out server.crt
-extfile openssl.conf
Signature ok
subject=/C=US/ST=California/L=San Jose/O=Example Inc./OU=Unit
A/CN=example.com/emailAddress=john@example.com
Getting CA Private Key
#
```

What to Do Next

Upload the new certificate to the CIMC.

Uploading a Server Certificate

Before You Begin

You must log in as a user with admin privileges to upload a certificate.

The certificate file to be uploaded must reside on a locally-accessible file system.



Note You must first generate a CSR using the CIMC Certificate Management menu, and you must use that CSR to obtain the certificate for uploading. Do not upload a certificate that was not obtained by this method.

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
- Step 2** On the **Admin** tab, click **Certificate Management**.
- Step 3** In the **Actions** area, click **Upload Server Certificate**.
The **Upload Certificate** dialog box appears.
- Step 4** In the **Upload Certificate** dialog box, update the following properties:

Name	Description
File field	The certificate file you want to upload.
Browse button	Opens a dialog box that allows you to navigate to the appropriate certificate file.

- Step 5** Click **Upload Certificate**.
-



CHAPTER 11

Configuring Platform Event Filters

This chapter includes the following sections:

- [Platform Event Filters, page 57](#)
- [Enabling Platform Event Alerts, page 57](#)
- [Disabling Platform Event Alerts, page 58](#)
- [Configuring Platform Event Filters, page 58](#)
- [Configuring SNMP Trap Settings, page 59](#)

Platform Event Filters

A platform event filter (PEF) can trigger an action and generate an alert when a critical hardware-related event occurs. For each PEF, you can choose the action to be taken (or take no action) when a platform event occurs. You can also choose to generate and send an alert when a platform event occurs. Alerts are sent as an SNMP trap, so you must configure an SNMP trap destination before the alerts can be sent.

You can globally enable or disable the generation of platform event alerts. When disabled, alerts are not sent even if PEFs are configured to send them.

Enabling Platform Event Alerts

Before You Begin

You must log in as a user with admin privileges to enable platform event alerts.

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
 - Step 2** On the **Admin** tab, click **Event Management**.
 - Step 3** In the **Event Management** pane, click the **Platform Event Filters** tab.
 - Step 4** In the **Platform Event Alerts** area, check the **Enable Platform Event Alerts** check box.
 - Step 5** Click **Save Changes**.
-

Disabling Platform Event Alerts

Before You Begin

You must log in as a user with admin privileges to disable platform event alerts.

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
 - Step 2** On the **Admin** tab, click **Event Management**.
 - Step 3** In the **Event Management** pane, click the **Platform Event Filters** tab.
 - Step 4** In the **Platform Event Alerts** area, uncheck the **Enable Platform Event Alerts** check box.
 - Step 5** Click **Save Changes**.
-

Configuring Platform Event Filters

Before You Begin

You must log in as a user with admin privileges to configure platform event filters.

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
- Step 2** On the **Admin** tab, click **Event Management**.
- Step 3** In the **Event Management** pane, click the **Platform Event Filters** tab.
- Step 4** In the **Platform Event Filters** area, complete the following fields for each event:

Name	Description
ID column	The unique filter ID.
Event column	The name of the event filter.

Name	Description
Action column	For each filter, select the desired action from the scrolling list box. This can be: <ul style="list-style-type: none"> • None—An alert is sent but no other action is taken • Reboot—An alert is sent and the server is rebooted • Power Cycle—An alert is sent and the server is power cycled • Power Off—An alert is sent and the server is powered off
Send Alert column	For each filter that you want to send an alert, check the associated check box in this column. <p>Note In order to send an alert, the filter trap settings must be configured properly and the Enable Platform Event Alerts check box must also be checked.</p>

Step 5 Click **Save Changes**.

What to Do Next

If you configure any PEFs to send an alert, complete the following tasks:

- [Enabling Platform Event Alerts, page 57](#)
- [Configuring SNMP Trap Settings, page 59](#)

Configuring SNMP Trap Settings

Before You Begin

You must log in as a user with admin privileges to configure the NIC.

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
- Step 2** On the **Admin** tab, click **Event Management**.
- Step 3** In the **Event Management** pane, click the **Trap Settings** tab.
- Step 4** In the **SNMP Community** area, enter the name of the SNMP community to which trap information should be sent.
- Step 5** In the **Trap Destinations** area, complete the following fields:

Name	Description
ID column	The trap destination ID. This value cannot be modified.

Name	Description
Enabled column	For each SNMP trap destination that you want to use, check the associated check box in this column.
Trap Destination IP Address column	The IP address to which SNMP trap information is sent.

Step 6 Click **Save Changes**.



CHAPTER 12

CIMC Firmware Management

This chapter includes the following sections:

- [Overview of Firmware, page 61](#)
- [Obtaining CIMC Firmware from Cisco, page 62](#)
- [Installing CIMC Firmware from the TFTP Server, page 63](#)
- [Installing CIMC Firmware Through the Browser, page 64](#)
- [Activating Installed Firmware, page 64](#)

Overview of Firmware

C-Series servers use firmware downloaded from cisco.com. This firmware is certified by Cisco to upgrade firmware on a C-Series server.

The firmware you download is packaged in a .zip file. After you have downloaded a firmware .zip from Cisco, you can use it to update the firmware on your server. Cisco also provides release notes with each image, which you can obtain from the same website from which you obtained the image.



Warning

Do not use the .zip file to reimage your server.

You use a .bin file to reimage. You must extract the proper .bin upgrade file from this .zip file. You can extract this .bin to a TFTP server or your local machine.



Note

When you update the firmware, you can either upgrade an older firmware version to a newer one, or downgrade a newer firmware version to an older one.

The CIMC separates the firmware update process into stages to ensure that you can install the firmware to a component while the server is running without affecting its uptime. Because you do not need to reboot the server until after you activate, you can perform that task overnight or during other maintenance periods. When you update firmware, the following stages occur:

Install

During this stage, the CIMC transfers the selected firmware version to the server. The install process always overwrites the firmware in the non-active slot on the server. You can install the firmware using either of the following methods:

- Through a browser client—this method allows you to browse for a firmware image on your computer and install it on the server.
- From a TFTP server—this method allows you to install a firmware image residing on a TFTP server.

Activate

During this stage, the CIMC sets the non-active firmware version as active and reboots the server. When the server reboots, the non-active slot becomes the active slot, and the active slot becomes the non-active slot. The firmware in the new active slot becomes the running version.

Obtaining CIMC Firmware from Cisco

Procedure

-
- Step 1** Navigate to cisco.com.
 - Step 2** Click **Support** on the top toolbar, and then select Software Download from the drop-down menu.
 - Step 3** Click the **Unified Computing** link in the lower left corner, and then log in.
 - Step 4** Expand the **Cisco C-Series Rack-Mount Servers** node to display links to each model of the Cisco C-Series Rack-Mount Servers.
 - Step 5** Click the appropriate link for your server model.
 - Step 6** Click the **Unified Computing System (UCS) Integrated Management Controller Firmware** link, and then click the appropriate release version link.
 - Step 7** Click **Download Now**.
The **Download Cart** dialog box appears.
 - Step 8** Review the information in the **Download Cart** dialog box, and then click **Proceed with Download**.
The **Software Download Rules** page appears.
 - Step 9** Review the download rules, and click **Agree**.
A dialog box listing your download appears. The **Select Location** dialog box also appears. This dialog box has the focus.
 - Step 10** Select a location in the **Select Location** dialog box, and then click **Open**.
The download begins.
 - Step 11** Click **Close** when the download is finished.
The file that you downloaded is a .zip file.
- Warning** Do not use the .zip file to reimage your server.
You use a .bin file to reimage. You must extract the proper .bin upgrade file from this .zip file. You can extract this .bin to an TFTP server or your local machine.

The name of the proper .bin you extract file depends on the model server you are reimaging. Following are examples of 1.0.2 firmware update files:

- C200 and C210—upd-pkg-c200-m1-cimc.full.1.0.2.bin
- C250—upd-pkg-c250-m1-cimc.full.1.0.2.bin

What to Do Next

Install the CIMC firmware on the server.

Installing CIMC Firmware from the TFTP Server

Before You Begin

- You must log in as a user with admin privileges to install CIMC firmware through the browser.
- Obtain the CIMC .zip firmware file from Cisco.
- Unzip the proper .bin upgrade file on your TFTP server.

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
- Step 2** On the **Admin** tab, click **Firmware Management**.
- Step 3** In the **Actions** area, click **Install CIMC Firmware from TFTP Server**.
- Step 4** In the **Install Firmware** dialog box, complete the following fields:

Name	Description
TFTP Server IP Address field	The IP address of the TFTP server on which the firmware image resides.
Image Path and Filename field	The firmware image file name on the server. When you enter this name, include the relative path for the image file from the top of the TFTP tree to the file location.

- Step 5** Click **Install Firmware**.

What to Do Next

Activate the CIMC firmware.

Installing CIMC Firmware Through the Browser

Before You Begin

- You must log in as a user with admin privileges to install CIMC firmware through the browser.
- Obtain the CIMC .zip firmware file from Cisco.
- Unzip the proper .bin upgrade file to your local machine.

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
- Step 2** On the **Admin** tab, click **Firmware Management**.
- Step 3** In the **Actions** area, click **Install CIMC Firmware through Browser Client**.
- Step 4** In the **Install Firmware** dialog box, click **Browse** and use the **Choose File** dialog box to select the .bin file you want to install.
- Step 5** Click **Install Firmware**.
-

What to Do Next

Activate the CIMC firmware.

Activating Installed Firmware

Before You Begin

- You must log in as a user with admin privileges to activate firmware.
- Install CIMC firmware on the server.

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
- Step 2** On the **Admin** tab, click **Firmware Management**.
- Step 3** In the **Actions** area, click **Activate CIMC Firmware**.
The **Activate Firmware** dialog box appears.
- Step 4** In the **Activate Firmware** dialog box, choose the firmware image to activate.
- Step 5** Click **Activate Firmware**.
-



CHAPTER 13

Viewing Logs

This chapter includes the following sections:

- [CIMC Log, page 65](#)
- [System Event Log, page 67](#)

CIMC Log

Viewing the CIMC Log

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
- Step 2** On the **Admin** tab, click **CIMC Log**.
- Step 3** Review the following information for each CIMC event in the log.

Name	Description
Timestamp column	The date and time the event occurred.
Source column	The software module that logged the event.
Description column	A description of the event.

- Step 4** From the **Entries Per Page** drop-down list , select the number of CIMC events to display on each page.
- Step 5** Click **<Newer** and **>Older** to move backward and forward through the pages of CIMC events, or click **<<Newest** to move to the top of the list.
By default, the newest CIMC events are displayed at the top if the list.
-

Clearing the CIMC Log

Before You Begin

You must log in as a user with user privileges to clear the CIMC log.

Procedure

-
- Step 1** In the **Navigation** pane, click the **Admin** tab.
 - Step 2** On the **Admin** tab, click **CIMC Log**.
 - Step 3** In the **CIMC Log** pane, click **Clear Log**.
 - Step 4** In the dialog box that appears, click **OK**.
-

Sending the CIMC Log to a Remote Server

You can configure profiles for one or two remote syslog servers to receive CIMC log entries.

Procedure

-
- Step 1** In the **Navigation** pane, click the **Admin** tab.
 - Step 2** On the **Admin** tab, click **CIMC Log**.
 - Step 3** In the **CIMC Log** pane, click the **Remote Logging** tab.
 - Step 4** In either of the **Remote Syslog Server** dialog boxes, complete the following fields:

Name	Description
Enabled check box	If checked, CIMC sends log messages to the Syslog server named in the IP Address field.
IP Address field	The IP address of the Syslog server on which the CIMC log should be stored.

- Step 5** Click **Save Changes**.
-

System Event Log

Viewing the System Event Log

Procedure

- Step 1** In the **Navigation** pane, click the **Server** tab.
- Step 2** On the **Server** tab, click **System Event Log**.
- Step 3** Review the following information for each system event in the log:

Name	Description
Timestamp column	The date and time the event occurred.
Severity column	The event severity. This can be: <ul style="list-style-type: none"> • Unknown • Informational • Normal • Warning • Critical • Non-Recoverable
Description column	A description of the event.

- Step 4** From the **Entries Per Page** drop-down list, select the number of system events to display on each page.
- Step 5** Click **<Newer** and **Older>** to move backward and forward through the pages of system events, or click **<<Newest** to move to the top of the list.
By default, the newest system events are displayed at the top of the list.

Clearing the System Event Log

Before You Begin

You must log in as a user with user privileges to clear the system event log.

Procedure

- Step 1** In the **Navigation** pane, click the **Server** tab.
 - Step 2** On the **Server** tab, click **System Event Log**.
 - Step 3** In the **System Event Log** pane, click **Clear Log**.
 - Step 4** In the dialog box that appears, click **OK**.
-



CHAPTER 14

Server Utilities

This chapter includes the following sections:

- [Exporting Technical Support Data, page 69](#)
- [Rebooting CIMC, page 70](#)
- [Recovering from a Corrupted BIOS, page 70](#)
- [Resetting CIMC to Factory Defaults, page 71](#)
- [Backing Up and Importing the CIMC Configuration, page 71](#)

Exporting Technical Support Data

Perform this task when requested by the Cisco Technical Assistance Center (TAC). This utility creates a summary report containing configuration information, logs and diagnostic data that will help TAC in troubleshooting and resolving a technical issue.

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
- Step 2** On the **Admin** tab, click **Utilities**.
- Step 3** In the **Actions** area of the **Utilities** pane, click **Export Technical Support Data**.
- Step 4** In the **Export Technical Support Data** dialog box, complete the following fields:

Name	Description
TFTP Server IP Address field	The IP address of the TFTP server on which the support data file should be stored.
Path and Filename field	The name of the file in which the support data should be stored on the server. When you enter this name, include the relative path for the file from the top of the TFTP tree to the desired location.

- Step 5** Click **Export**.

What to Do Next

Provide the generated report file to Cisco TAC.

Rebooting CIMC

On rare occasions, such as an issue with the current running firmware, troubleshooting a server may require you to reboot the CIMC. This procedure is not part of the normal maintenance of a server. After you reboot the CIMC, you are logged off and the CIMC will be unavailable for a few minutes.

**Note**

If you reboot the CIMC while the server is performing power-on self test (POST) or is operating in the Extensible Firmware Interface (EFI) shell, the server will be powered down until the CIMC reboot is complete.

Before You Begin

You must log in as a user with admin privileges to reboot the CIMC.

Procedure

-
- Step 1** In the **Navigation** pane, click the **Admin** tab.
 - Step 2** On the **Admin** tab, click **Utilities**.
 - Step 3** In the **Actions** area of the **Utilities** pane, click **Reboot CIMC**.
 - Step 4** Click **OK**.
-

Recovering from a Corrupted BIOS

Before You Begin

- You must be logged in as admin to recover corrupt BIOS.
- Have the BIOS recovery ISO image ready. You will find the BIOS recovery ISO image under the **Recovery** folder of the firmware distribution package.
- Schedule some down time for the server because it will be powered cycled at the end of the recovery procedure.

Procedure

-
- Step 1** In the **Navigation** pane, click the **Server** tab.
 - Step 2** On the server tab, click **BIOS**.

The BIOS page appears.

- Step 3** In the **Actions** area, click **Recover Corrupt BIOS**. The **Recover Corrupt BIOS** wizard appears.
 - Step 4** Use the **Recover Corrupt BIOS** wizard to recover your corrupt BIOS.
-

Resetting CIMC to Factory Defaults

On rare occasions, such as an issue with the current running firmware, troubleshooting a server may require you to reset the CIMC to the factory default. When this happens, all user-configurable settings are reset.

This procedure is not part of the normal server maintenance. After you reset the CIMC, you are logged off and must log in again. You may also lose connectivity and may need to reconfigure the network settings.

Before You Begin

You must log in as a user with admin privileges to reset the CIMC to factory defaults.

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
 - Step 2** On the **Admin** tab, click **Utilities**.
 - Step 3** In the **Actions** area of the **Utilities** pane, click **Reset CIMC to Factory Default Configuration**.
 - Step 4** Click **OK**.
A reboot of CIMC while the host is performing BIOS POST (Power on Self Test) or is in EFI shell will turn off the host for a short amount of time. CIMC will power on when it is ready.
-

Backing Up and Importing the CIMC Configuration

Backing Up and Importing the CIMC Configuration

When you perform a backup of the CIMC configuration, you take a snapshot of the system configuration and export the resulting CIMC configuration file to a location on your network. The backup operation saves information from the management plane only; it does not back up data on the servers. Sensitive configuration information such as user accounts and the server certificate are not exported.

You can restore a backup CIMC configuration file to the same system or you can import it to another CIMC system, provided that the software version of the importing system is the same as or is configuration-compatible with the software version of the exporting system. When you import a configuration file to another system as a configuration template, you must modify system-specific settings such as IP addresses and host names. An import operation modifies information on the management plane only.

The CIMC configuration file is an XML text file whose structure and elements correspond to the CIMC command modes.

When performing a backup or import operation, consider these guidelines:

- You can perform a backup or an import while the system is up and running. While a backup operation has no impact on the server or network traffic, some modifications caused by an import operation, such as IP address changes, can disrupt traffic or cause a server reboot.
- You cannot execute a backup and an import simultaneously.

Backing Up the CIMC Configuration



Note For security reasons, this operation does not export user accounts or the server certificate.

Before You Begin

Obtain the backup TFTP server IP address.

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
- Step 2** On the **Admin** tab, click **Utilities**.
- Step 3** In the **Actions** area of the **Utilities** pane, click **Export CIMC Configuration**.
- Step 4** In the **Export CIMC Configuration** dialog box, complete the following fields:

Name	Description
Export to a local file field	Select this option and click Export to save the XML configuration file to a drive that is local to the computer running the CIMC GUI.
Export to TFTP server field	Select this option to save the XML configuration file to a TFTP server.
TFTP Server IP Address field	The IP address of the TFTP server to which the configuration file will be exported.
Path and Filename field	The path and filename CIMC should use when exporting the file to the TFTP server.

- Step 5** Click **Export**.

Importing a CIMC Configuration

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
- Step 2** On the **Admin** tab, click **Utilities**.
- Step 3** In the **Actions** area of the **Utilities** pane, click **Import CIMC Configuration**.
- Step 4** In the **Import CIMC Configuration** dialog box, complete the following fields:

Name	Description
Import from a local file field	Select this option and click Import to navigate to the XML configuration file stored on a drive that is local to the computer running the CIMC GUI.
Import from TFTP server field	Select this option to import the XML configuration file from a TFTP server.
TFTP Server IP Address field	The IP address of the TFTP server on which the configuration file resides.
Path and Filename field	The path and filename of the configuration file on the TFTP server.

- Step 5** Click **Import**.
-



INDEX

A

active directory [35](#)
Active Directory [35, 36](#)

B

backing up
 CIMC configuration [71, 72](#)
boot order, configuring [17](#)

C

certificate management
 new certificates [52](#)
 uploading a certificate [54](#)
certificates [52](#)
CIMC
 clearing log [66](#)
 firmware
 about [61](#)
 activating [64](#)
 installing from TFTP server [63](#)
 installing through browser [64](#)
 obtaining from Cisco [62](#)
 rebooting [70](#)
 resetting to factory defaults [71](#)
 sending log [66](#)
 viewing log [65](#)
CIMC GUI [3, 4](#)
CIMC overview [2](#)
common properties [43](#)
communication services properties
 HTTP properties [47](#)
 IPMI over LAN properties [49](#)
 SSH properties [48](#)
configuration
 backing up [71, 72](#)
 importing [73](#)
CPU properties [21](#)

current sensors [25](#)

D

disabling KVM [33](#)

E

enabling KVM [33, 34](#)
encrypting virtual media [32](#)
event filters, platform
 about [57](#)
 configuring [58](#)
event log, system
 clearing [67](#)
 viewing [67](#)
events
 platform
 disabling alerts [58](#)
 enabling alerts [57](#)
exporting
 CIMC configuration [71, 72](#)

F

fan sensors [27](#)
firmware
 about [61](#)
 activating [64](#)
 installing from TFTP server [63](#)
 installing through browser [64](#)
 obtaining from Cisco [62](#)
floppy disk emulation [32](#)

H

HTTP properties [47](#)

I

- importing
 - CIMC configuration [73](#)
- IP blocking [45](#)
- IPMI over LAN [49](#)
- IPMI over LAN properties [49](#)
- IPv4 properties [43](#)

K

- KVM
 - configuring [33](#)
 - disabling [33](#)
 - enabling [33, 34](#)
- KVM console [11, 32](#)

L

- led sensors [26](#)
- local users [37](#)
- locator LED [17](#)
- logging in [8](#)
- logging out [8](#)

M

- memory properties [22](#)

N

- navigation pane [4](#)
- network properties
 - common properties [43](#)
 - IPv4 properties [43](#)
 - NIC properties [42](#)
 - VLAN properties [44](#)
- network security [45](#)
- NIC properties [42](#)

O

- operating system installation [12](#)
- OS installation [11, 12, 13](#)
 - KVM console [12](#)
 - PXE [13](#)

P

- platform event filters
 - about [57](#)
 - configuring [58](#)
- platform events
 - disabling alerts [58](#)
 - enabling alerts [57](#)
- power cycling the server [19](#)
- power supply properties [22](#)
- power supply sensors [27](#)
- powering off the server [19](#)
- powering on the server [19](#)
- PXE installation [12](#)

R

- recovering from a corrupted bios [70](#)
- remote presence
 - serial over LAN [31](#)
 - virtual KVM [33, 34](#)
 - virtual media [32](#)
- resetting the server [20](#)

S

- self-signed certificate [53](#)
- sensors
 - current [25](#)
 - fan [27](#)
 - led [26](#)
 - power supply [27](#)
 - temperature [29](#)
 - voltage [30](#)
- serial over LAN [31](#)
- server health [15](#)
- server management
 - configuring the boot order [17](#)
 - locator LED [17](#)
 - power cycling the server [19](#)
 - powering off the server [19](#)
 - powering on the server [19](#)
 - resetting the server [20](#)
 - server health [15](#)
 - shutting down the server [20](#)
- server NICs [41](#)
- server overview [1](#)
- server software [2](#)
- shutting down the server [20](#)
- SNMP traps [59](#)
- SSH properties [48](#)

storage properties [23](#)
syslog
 sending CIMC log [66](#)
system event log
 clearing [67](#)
 viewing [67](#)

T

technical support data, exporting [69](#)
temperature sensors [29](#)
toolbar [7](#)

U

uploading a server certificate [54](#)

user management
 active directory [35](#)
 local users [37](#)
 user sessions [39](#)
user sessions [39](#)

V

virtual KVM [33, 34](#)
virtual media [32](#)
VLAN properties [44](#)
voltage sensors [30](#)

W

work pane [5](#)

