



Cisco UCS Manager GUI Configuration Guide, 1.0(2)

First Published: 07/29/2009

Last Modified: 10/15/2009

Americas Headquarters

Cisco Systems, Inc.

170 West Tasman Drive

San Jose, CA 95134-1706

USA

<http://www.cisco.com>

Tel: 408 526-4000

800 553-NETS (6387)

Fax: 408 527-0883

Text Part Number: OL-20884-01

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NON-INFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

CCDE, CCENT, CCSI, Cisco Eos, Cisco HealthPresence, Cisco IronPort, the Cisco logo, Cisco Lumin, Cisco Nexus, Cisco Nurse Connect, Cisco Pulse, Cisco StackPower, Cisco StadiumVision, Cisco TelePresence, Cisco Unified Computing System, Cisco WebEx, DCE, Flip Channels, Flip for Good, Flip Mino, Flipshare (Design), Flip Ultra, Flip Video, Flip Video (Design), Instant Broadband, and Welcome to the Human Network are trademarks; Changing the Way We Work, Live, Play, and Learn, Cisco Capital, Cisco Capital (Design), Cisco:Financed (Stylized), Cisco Store, and Flip Gift Card are service marks; and Access Registrar, Aironet, AllTouch, AsyncOS, Bringing the Meeting To You, Catalyst, CCDA, CCDP, CCIE, CCIP, CCNA, CCNP, CCSP, CCVP, Cisco, the Cisco Certified Internetwork Expert logo, Cisco IOS, Cisco Press, Cisco Systems, Cisco Systems Capital, the Cisco Systems logo, Cisco Unity, Collaboration Without Limitation, Continuum, EtherFast, EtherSwitch, Event Center, Explorer, Fast Step, Follow Me Browsing, FormShare, GainMaker, GigaDrive, HomeLink, iLYNX, Internet Quotient, IOS, iPhone, iQuick Study, IronPort, the IronPort logo, Laser Link, LightStream, Linksys, MediaTone, MeetingPlace, MeetingPlace Chime Sound, MGX, Networkers, Networking Academy, Network Registrar, PCNow, PIX, PowerKEY, PowerPanels, PowerTV, PowerTV (Design), PowerVu, Prisma, ProConnect, ROSA, ScriptShare, SenderBase, SMARTnet, Spectrum Expert, StackWise, The Fastest Way to Increase Your Internet Quotient, TransPath, WebEx, and the WebEx logo are registered trademarks of Cisco Systems, Inc. and/or its affiliates in the United States and certain other countries.

All other trademarks mentioned in this document or website are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (0908R)

Any Internet Protocol (IP) addresses used in this document are not intended to be actual addresses. Any examples, command display output, and figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses in illustrative content is unintentional and coincidental.



CONTENTS

Preface xix

Audience xix

Organization xix

Conventions xx

Related Documentation xxi

Documentation Feedback xxii

Obtaining Documentation and Submitting a Service Request xxii

Introduction 1

Overview of Cisco Unified Computing System 3

About Cisco Unified Computing System 3

Unified Fabric 4

Fibre Channel over Ethernet 5

Link-Level Flow Control 5

Priority Flow Control 5

Server Architecture and Connectivity 5

Overview of Service Profiles 5

Network Connectivity through Service Profiles 6

Configuration through Service Profiles 6

Service Profiles that Override Server Identity 7

Service Profiles that Inherit Server Identity 8

Service Profile Templates 8

Policies 9

Configuration Policies 9

Boot Policy 9

Chassis Discovery Policy 10

Ethernet and Fibre Channel Adapter Policies 10

Host Firmware Pack 11

IPMI Access Profile 11

Local Disk Configuration Policy	12
Management Firmware Pack	12
Network Control Policy	12
Quality of Service Policies	12
Server Autoconfiguration Policy	12
Server Discovery Policy	13
Server Inheritance Policy	13
Server Pool Policy	13
Server Pool Policy Qualifications	13
vHBA Template	14
vNIC Template	14
Operational Policies	14
Fault Collection Policy	14
Scrub Policy	14
Serial over LAN Policy	14
Statistics Collection Policy	14
Statistics Threshold Policy	15
Pools	15
Server Pools	16
MAC Pools	16
UUID Suffix Pools	16
WWN Pools	16
Management IP Pool	17
Traffic Management	17
Oversubscription	17
Oversubscription Considerations	17
Guidelines for Estimating Oversubscription	18
Pinning	19
Pinning Server Traffic to Server Ports	19
Guidelines for Pinning	20
Quality of Service	20
System Classes	20
Quality of Service Policies	21
Flow Control Policies	21
Opt-In Features	22

Stateless Computing	22
Multi-Tenancy	23
Overview of Virtualization	24
Virtualization with the Cisco UCS CNA M71KR and Cisco UCS 82598KR-CI Adapters	24
Overview of Cisco UCS Manager	25
About Cisco UCS Manager	25
Tasks You Can Perform in Cisco UCS Manager	26
Tasks You Cannot Perform in Cisco UCS Manager	28
Cisco UCS Manager in a Cluster Environment	28
Overview of Cisco UCS Manager GUI	29
Overview of Cisco UCS Manager GUI	29
Fault Summary Area	29
Navigation Pane	30
Toolbar	31
Work Pane	31
Status Bar	31
Table Customization	32
LAN Uplinks Manager	33
Internal Fabric Manager	33
Hybrid Display	33
Logging in to Cisco UCS Manager GUI through HTTPS	34
Logging in to Cisco UCS Manager GUI through HTTP	35
Logging Off Cisco UCS Manager GUI	35
Changing the Cisco UCS Manager GUI Properties	35
System Configuration	39
Configuring the Fabric Interconnects	41
Initial System Setup	41
Setup Mode	42
System Configuration Type	42
Management Port IP Address	42
Performing an Initial System Setup for a Standalone Configuration	43
Initial System Setup for a Cluster Configuration	45
Performing an Initial System Setup on the First fabric interconnect	45
Performing an Initial System Setup on the Second Fabric Interconnect	47

Enabling a Standalone Fabric Interconnect for Cluster Configuration	48
Ethernet Switching Mode	48
Configuring the Ethernet Switching Mode	49
Monitoring a Fabric Interconnect	50
Changing Properties of a Fabric Interconnect	51
Changing Access to a Fabric Interconnect	51
Configuring Ports	53
Server and Uplink Ports on the Fabric Interconnect	53
Configuring Server Ports	54
Configuring Uplink Ethernet Ports	54
Reconfiguring a Port on a Fabric Interconnect	55
Enabling a Port on a Fabric Interconnect	55
Disabling a Port on a Fabric Interconnect	56
Unconfiguring a Port on a Fabric Interconnect	56
Configuring Uplink Ethernet Port Channels	57
Creating an Uplink Ethernet Port Channel	57
Enabling an Uplink Ethernet Port Channel	58
Disabling an Uplink Ethernet Port Channel	58
Adding Ports to an Uplink Ethernet Port Channel	58
Removing Ports from an Uplink Ethernet Port Channel	59
Deleting an Uplink Ethernet Port Channel	59
Configuring Server Ports with the Internal Fabric Manager	59
Internal Fabric Manager	59
Launching the Internal Fabric Manager	60
Configuring a Server Port with the Internal Fabric Manager	60
Unconfiguring a Server Port with the Internal Fabric Manager	60
Enabling a Server Port with the Internal Fabric Manager	61
Disabling a Server Port with the Internal Fabric Manager	61
Configuring Communication Services	63
Communication Services	63
Configuring CIM-XML	64
Configuring HTTP	65
Configuring HTTPS	65
Creating a Key Ring	65
Creating a Certificate Request for a Key Ring	66

Creating a Trusted Point	66
Importing a Certificate into a Key Ring	67
Configuring HTTPS	67
Deleting a Key Ring	68
Deleting a Trusted Point	68
Configuring SNMP	68
Enabling SNMP	68
Configuring Trap Hosts	69
Configuring SNMPv3 users	69
Enabling Telnet	70
Disabling Communication Services	70
Configuring Primary Authentication	73
Primary Authentication	73
Remote Authentication Providers	73
Creating a Remote Authentication Provider	74
Creating an LDAP Provider	74
Creating a RADIUS Provider	76
Creating a TACACS+ Provider	78
Deleting a Remote Authentication Provider	79
Deleting an LDAP Provider	79
Deleting a RADIUS Provider	79
Deleting a TACACS+ Provider	79
Selecting a Primary Authentication Service	79
Configuring Organizations	81
Organizations in a Multi-Tenancy Environment	81
Hierarchical Name Resolution in a Multi-Tenancy Environment	82
Creating an Organization under the Root Organization	83
Creating an Organization under an Organization that is not Root	84
Deleting an Organization	84
Configuring Role-Based Access Control	85
Role-Based Access Control	85
User Accounts	85
User Roles	86
Privileges	87
User Locales	89

Configuring User Roles	89
Creating a User Role	89
Adding Privileges to a User Role	90
Removing Privileges from a User Role	90
Deleting a User Role	90
Configuring Locales	91
Creating a Locale	91
Adding an Organization to a Locale	92
Deleting an Organization from a Locale	92
Deleting a Locale	92
Configuring User Accounts	93
Creating a User Account	93
Deleting a Locally Authenticated User Account	95
Monitoring User Sessions	95
Firmware Management	97
Overview of Firmware	97
Image Management	97
Image Headers	98
Image Catalog	98
Firmware Updates	98
Firmware Versions	99
Direct Firmware Update at Endpoints	99
Stages of a Direct Firmware Update	100
Recommended Order of Components for Firmware Activation	100
Outage Impacts of Direct Firmware Updates	101
Firmware Updates through Service Profiles	102
Host Firmware Pack	102
Management Firmware Pack	103
Stages of a Firmware Update through Service Profiles	103
Firmware Downgrades	103
Downloading and Managing Images	104
Obtaining Images from Cisco	104
Checking the Available Space on a Fabric Interconnect	104
Downloading Images to the Fabric Interconnect	104
Canceling an Image Download	106

Directly Updating Firmware at Endpoints	106
Updating the Firmware on Multiple Components	106
Activating the Firmware on Multiple Components	106
Updating the Firmware on an Adapter	107
Activating the Firmware on an Adapter	108
Updating the Firmware on a BMC	108
Activating the Firmware on a BMC	109
Updating the Firmware on an IOM	109
Activating the Firmware on an IOM	110
Updating and Activating the Firmware on a Fabric Interconnect	110
Updating and Activating the Cisco UCS Manager Software	111
Updating Firmware through Service Profiles	111
Creating a Host Firmware Package	111
Updating a Host Firmware Pack	112
Creating a Management Firmware Package	113
Updating a Management Firmware Pack	114
Verifying Firmware Versions on Components	114
Configuring DNS Servers	115
DNS Servers in Cisco UCS	115
Adding a DNS Server	115
Deleting a DNS Server	116
Network Configuration	117
Using the LAN Uplinks Manager	119
LAN Uplinks Manager	119
Launching the LAN Uplinks Manager	120
Changing the Ethernet Switching Mode with the LAN Uplinks Manager	120
Configuring a Port with the LAN Uplinks Manager	120
Configuring Server Ports	121
Enabling a Server Port with the LAN Uplinks Manager	121
Disabling a Server Port with the LAN Uplinks Manager	121
Unconfiguring a Server Port with the LAN Uplinks Manager	122
Configuring Uplink Ethernet Ports	122
Enabling an Uplink Ethernet Port with the LAN Uplinks Manager	122
Disabling an Uplink Ethernet Port with the LAN Uplinks Manager	122
Unconfiguring an Uplink Ethernet Port with the LAN Uplinks Manager	123

Configuring Uplink Ethernet Port Channels	123
Creating a Port Channel with the LAN Uplinks Manager	123
Enabling a Port Channel with the LAN Uplinks Manager	124
Disabling a Port Channel with the LAN Uplinks Manager	124
Adding Ports to a Port Channel with the LAN Uplinks Manager	124
Removing Ports from a Port Channel with the LAN Uplinks Manager	125
Deleting a Port Channel with the LAN Uplinks Manager	125
Configuring LAN Pin Groups	125
Creating a Pin Group with the LAN Uplinks Manager	125
Deleting a Pin Group with the LAN Uplinks Manager	126
Configuring Named VLANs	126
Creating a Named VLAN with the LAN Uplinks Manager	126
Deleting a Named VLAN with the LAN Uplinks Manager	128
Configuring QoS System Classes with the LAN Uplinks Manager	128
Configuring Named VLANs	131
Named VLANs	131
Creating a Named VLAN	131
Deleting a Named VLAN	133
Configuring LAN Pin Groups	135
LAN Pin Groups	135
Creating a LAN Pin Group	135
Deleting a LAN Pin Group	136
Configuring MAC Pools	137
MAC Pools	137
Creating a MAC Pool	137
Deleting a MAC Pool	138
Configuring Quality of Service	139
Quality of Service	139
System Classes	139
Quality of Service Policies	140
Flow Control Policies	140
Configuring QoS System Classes	141
Creating a QoS Policy	142
Deleting a QoS Policy	143
Creating a Flow Control Policy	143

Deleting a Flow Control Policy	144
Configuring Network-Related Policies	145
Configuring vNIC Templates	145
vNIC Template	145
Creating a vNIC Template	145
Deleting a vNIC Template	147
Binding a vNIC to a vNIC Template	148
Unbinding a vNIC from a vNIC Template	148
Configuring Ethernet Adapter Policies	149
Ethernet and Fibre Channel Adapter Policies	149
Creating an Ethernet Adapter Policy	150
Deleting an Ethernet Adapter Policy	152
Configuring Network Control Policies	152
Network Control Policy	152
Creating a Network Control Policy	153
Deleting a Network Control Policy	154
Storage Configuration	155
Configuring Named VSANs	157
Named VSANs	157
Creating a Named VSAN	157
Deleting a Named VSAN	158
Configuring SAN Pin Groups	161
SAN Pin Groups	161
Creating a SAN Pin Group	161
Deleting a SAN Pin Group	162
Configuring WWN Pools	163
WWN Pools	163
Creating a WWNN Pool	164
Deleting a WWNN Pool	165
Creating a WWPN Pool	165
Deleting a WWPN Pool	166
Configuring Storage-Related Policies	167
Configuring vHBA Templates	167
vHBA Template	167
Creating a vHBA Template	167

Deleting a vHBA Template	169
Binding a vHBA to a vHBA Template	169
Unbinding a vHBA from a vHBA Template	170
Configuring Fibre Channel Adapter Policies	170
Ethernet and Fibre Channel Adapter Policies	170
Creating a Fibre Channel Adapter Policy	171
Deleting a Fibre Channel Adapter Policy	174
Server Configuration	175
Configuring Server-Related Pools	177
Configuring Server Pools	177
Server Pools	177
Creating a Server Pool	177
Deleting a Server Pool	178
Adding Servers to a Server Pool	178
Removing Servers from a Server Pool	179
Configuring UUID Suffix Pools	179
UUID Suffix Pools	179
Creating a UUID Suffix Pool	179
Deleting a UUID Suffix Pool	180
Configuring the Management IP Pool	181
Management IP Pool	181
Creating an IP Address Block in the Management IP Pool	181
Deleting an IP Address Block from the Management IP Pool	182
Configuring Server-Related Policies	183
Configuring Boot Policies	183
Boot Policy	183
Creating a Boot Policy	185
Deleting a Boot Policy	187
Configuring Chassis Discovery Policies	187
Chassis Discovery Policy	187
Configuring a Chassis Discovery Policy	187
Configuring IPMI Profiles	188
IPMI Access Profile	188
Creating an IPMI Profile	188
Deleting an IPMI Profile	189

Configuring Local Disk Configuration Policies	189
Local Disk Configuration Policy	189
Creating a Local Disk Configuration Policy	190
Changing a Local Disk Configuration Policy	191
Deleting a Local Disk Configuration Policy	192
Configuring Scrub Policies	192
Scrub Policy	192
Creating a Scrub Policy	192
Deleting a Scrub Policy	193
Configuring Serial over LAN Policies	193
Serial over LAN Policy	193
Creating a Serial over LAN Policy	194
Deleting a Serial over LAN Policy	195
Configuring Server Autoconfiguration Policies	195
Server Autoconfiguration Policy	195
Creating an Autoconfiguration Policy	195
Deleting an Autoconfiguration Policy	196
Configuring Server Discovery Policies	196
Server Discovery Policy	196
Creating a Server Discovery Policy	197
Deleting a Server Discovery Policy	198
Configuring Server Inheritance Policies	198
Server Inheritance Policy	198
Creating a Server Inheritance Policy	198
Deleting a Server Inheritance Policy	199
Configuring Server Pool Policies	199
Server Pool Policy	199
Creating a Server Pool Policy	200
Deleting a Server Pool Policy	201
Configuring Server Pool Policy Qualifications	201
Server Pool Policy Qualifications	201
Creating Server Pool Policy Qualifications	201
Deleting Server Pool Policy Qualifications	204
Deleting Qualifications from Server Pool Policy Qualifications	204
Configuring Service Profiles	207

Service Profiles that Override Server Identity	207
Service Profiles that Inherit Server Identity	208
Service Profile Templates	208
Creating Service Profiles	209
Creating a Service Profile with the Expert Wizard	209
Page 1: Identifying the Service Profile	209
Page 2: Configuring the Storage Options	210
Page 3: Configuring the Networking Options	215
Page 4: Setting the Server Boot Order	218
Page 5: Specifying the Server Assignment	220
Page 6: Adding Operational Policies	221
Creating a Service Profile that Inherits Server Identity	222
Creating a Hardware Based Service Profile for a Server	225
Working with Service Profile Templates	226
Creating a Service Profile Template	226
Page 1: Identifying the Service Profile Template	226
Page 2: Specifying the Template Storage Options	227
Page 3: Specifying the Template Networking Options	232
Page 4: Specifying the Template Server Boot Order Options	234
Page 5: Specifying the Template Server Assignment Options	236
Page 6: Specifying Template Policy Options	238
Creating Service Profiles from a Service Profile Template	239
Creating a Template Based Service Profile for a Server	239
Changing the UUID in a Service Profile Template	240
Associating a Service Profile Template with a Server Pool	241
Disassociating a Service Profile Template from its Server Pool	241
Managing Service Profiles	242
Cloning a Service Profile	242
Associating a Service Profile with a Server or Server Pool	242
Disassociating a Service Profile from a Server or Server Pool	243
Changing the UUID in a Service Profile	243
Creating a vNIC for a Service Profile	245
Deleting a vNIC from a Service Profile	247
Creating a vHBA for a Service Profile	247
Changing the WWPN for a vHBA	249

Clearing Persistent Binding for a vHBA	250
Deleting a vHBA from a Service Profile	250
Binding a Service Profile to a Service Profile Template	250
Unbinding a Service Profile from a Service Profile Template	251
Deleting a Service Profile	251
Installing an OS on a Server	253
OS Installation Methods	253
PXE Install Server	253
KVM Dongle	254
KVM Console	254
Installation Targets	254
Installing an OS Using a PXE Installation Server	255
Installing an OS Using the KVM Dongle	255
Installing an OS Using the KVM Console	256
System Management	259
Managing Time Zones	261
Time Zones	261
Setting the Time Zone	261
Adding an NTP Server	262
Deleting an NTP Server	262
Managing the Chassis	263
Chassis Management in Cisco UCS Manager GUI	263
Acknowledging a Chassis	263
Removing a Chassis	264
Recommissioning a Chassis	264
Toggling the Locator LED	265
Turning on the Locator LED for a Chassis	265
Turning off the Locator LED for a Chassis	265
Monitoring a Chassis	265
Viewing the POST Results for a Chassis	267
Managing the Servers	269
Server Management in Cisco UCS Manager GUI	269
Booting Servers	270
Booting a Server	270
Booting a Server from the Service Profile	270

Shutting Down Servers	271
Shutting Down a Server	271
Shutting down a Server from the Service Profile	271
Resetting a Server	271
Reacknowledging a Server	272
Removing a Server from a Chassis	273
Decommissioning a Server	273
Reacknowledging a Server Slot in a Chassis	274
Removing a Non-Existent Server from the Configuration Database	274
Toggling the Locator LED	275
Turning on the Locator LED for a Server	275
Turning off the Locator LED for a Server	275
Starting the KVM Console	276
Starting the KVM Console from a Server	276
Starting the KVM Console from a Service Profile	276
Resetting the CMOS for a Server	277
Resetting the BMC for a Server	277
Recovering the Corrupt BIOS on a Server	278
Monitoring a Server	279
Viewing the POST Results for a Server	280
Managing the IO Modules	281
I/O Module Management in Cisco UCS Manager GUI	281
Resetting an I/O Module	281
Monitoring an I/O Module	282
Viewing the POST Results for an I/O Module	282
Configuring Call Home	285
Call Home	285
Call Home Considerations	286
Cisco Smart Call Home	286
Configuring Call Home	287
Disabling Call Home	289
Enabling Call Home	289
Configuring System Inventory Messages	290
Sending System Inventory Messages	290
Configuring Call Home Profiles	291

Creating a Call Home Profile	291
Deleting a Call Home Profile	293
Configuring Call Home Policies	293
Configuring a Call Home Policy	293
Disabling a Call Home Policy	294
Enabling a Call Home Policy	295
Deleting a Call Home Policy	295
Configuring Call Home for Smart Call Home	295
Configuring Smart Call Home	295
Configuring the Default Cisco TAC-1 Profile	297
Configuring System Inventory Messages for Smart Call Home	298
Registering Smart Call Home	299
Backing Up and Restoring the Configuration	301
Backup and Export Configuration	301
Backup Types	301
Considerations and Recommendations for Backup Operations	302
Import Configuration	302
Import Methods	303
System Restore	303
Required User Role for Backup and Import Operations	303
Backup Operations	303
Creating a Backup Operation	303
Running a Backup Operation	306
Modifying a Backup Operation	306
Deleting One or More Backup Operations	307
Import Operations	307
Creating an Import Operation	307
Running an Import Operation	309
Modifying an Import Operation	310
Deleting One or More Import Operations	311
Restoring the Configuration for a Fabric Interconnect	311
Configuring Settings for Faults, Events, and Logs	315
Configuring Settings for the Fault Collection Policy	315
Fault Collection Policy	315
Configuring the Fault Collection Policy	316

Configuring Settings for the Core File Exporter	317
Core File Exporter	317
Configuring the Core File Exporter	317
Disabling the Core File Exporter	318
Configuring the Syslog	318
Recovering a Lost Password	323
Password Recovery for the Admin Account	323
Determining the Leadership Role of a Fabric Interconnect	324
Verifying the Firmware Versions on a Fabric Interconnect	324
Recovering the Admin Account Password in a Standalone Configuration	324
Recovering the Admin Account Password in a Cluster Configuration	325
Configuring Statistics-Related Policies	327
Configuring Statistics Collection Policies	327
Statistics Collection Policy	327
Modifying a Statistics Collection Policy	328
Configuring Statistics Threshold Policies	329
Statistics Threshold Policy	329
Creating a Server and Server Component Threshold Policy	330
Adding a Threshold Class to a Server and Server Component Threshold Policy	332
Deleting a Server and Server Component Threshold Policy	334
Adding a Threshold Class to the Uplink Ethernet Port Threshold Policy	334
Adding a Threshold Class to the Ethernet Server Port, Chassis, and Fabric Interconnect Threshold Policy	335
Adding a Threshold Class to the Fibre Channel Port Threshold Policy	337



Preface

This preface includes the following sections:

- [Audience, page xix](#)
- [Organization, page xix](#)
- [Conventions, page xx](#)
- [Related Documentation, page xxi](#)
- [Documentation Feedback , page xxii](#)
- [Obtaining Documentation and Submitting a Service Request , page xxii](#)

Audience

This guide is intended primarily for data center administrators with responsibilities and expertise in one or more of the following:

- Server administration
- Storage administration
- Network administration
- Network security

Organization

This document includes the following parts:

Part	Title	Description
Part 1	Introduction	Contains chapters that describe the Cisco Unified Computing System (Cisco UCS), Cisco UCS Manager, and UCS Manager GUI.

Part	Title	Description
Part 2	System Configuration	Contains chapters that describe how to configure fabric interconnects, ports, communication services, primary authentication, and role-based access control configuration, and how to manage firmware on a system.
Part 3	Network Configuration	Contains chapters that describe how to configure named VLANs, LAN pin groups, MAC pools, and Quality of Service (QoS).
Part 4	Storage Configuration	Contains chapters that describe how to configure named VSANs, SAN pin groups, and WWN pools.
Part 5	Server Configuration	Contains chapters that describe how to configure server-related policies, server-related pools, and service profiles, and how to install an OS on a server.
Part 6	System Management	Contains chapters that describe how to manage chassis, servers, and I/O modules, and how to back up and restore the configuration.

Conventions

This document uses the following conventions:

Convention	Indication
bold font	Commands, keywords, GUI elements, and user-entered text appear in bold font .
<i>italic font</i>	Document titles, new or emphasized terms, and arguments for which you supply values are in <i>italic font</i> .
[]	Elements in square brackets are optional.
{x y z}	Required alternative keywords are grouped in braces and separated by vertical bars.
[x y z]	Optional alternative keywords are grouped in brackets and separated by vertical bars.
string	A nonquoted set of characters. Do not use quotation marks around the string or the string will include the quotation marks.
<code>courier font</code>	Terminal sessions and information the system displays appear in <code>courier font</code> .
<>	Nonprinting characters such as passwords are in angle brackets.

Convention	Indication
[]	Default responses to system prompts are in square brackets.
!, #	An exclamation point (!) or a pound sign (#) at the beginning of a line of code indicates a comment line.

**Note**

Means *reader take note*.

**Tip**

Means *the following information will help you solve a problem*.

**Caution**

Means *reader be careful*. In this situation, you might perform an action that could result in equipment damage or loss of data.

**Timesaver**

Means *the described action saves time*. You can save time by performing the action described in the paragraph.

**Warning**

Means *reader be warned*. In this situation, you might perform an action that could result in bodily injury.

Related Documentation

Documentation for Cisco Unified Computing System (Cisco UCS) is available at the following URL:

<http://www.cisco.com>

The following are related Cisco UCS documents:

- *Cisco UCS Documentation Roadmap*
- *Cisco UCS Manager GUI Configuration Guide*
- *Cisco UCS Manager XML API Programmer's Guide*
- *Cisco UCS Manager Troubleshooting Guide*
- *Cisco UCS Site Preparation Guide*
- *Cisco UCS 6100 Series Fabric Interconnect Hardware Installation Guide*
- *Cisco UCS 5108 Server Chassis Hardware Installation Guide*
- *Regulatory Compliance and Safety Information for Cisco UCS*
- *Release Notes for Cisco UCS*

Documentation Feedback

To provide technical feedback on this document, or to report an error or omission, please send your comments to ucs-docfeedback@cisco.com. We appreciate your feedback.

Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, submitting a service request, and gathering additional information, see the monthly *What's New in Cisco Product Documentation*, which also lists all new and revised Cisco technical documentation, at:

<http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html>

Subscribe to the *What's New in Cisco Product Documentation* as a Really Simple Syndication (RSS) feed and set content to be delivered directly to your desktop using a reader application. The RSS feeds are a free service and Cisco currently supports RSS version 2.0.



PART **I**

Introduction

- [Overview of Cisco Unified Computing System, page 3](#)
- [Overview of Cisco UCS Manager, page 25](#)
- [Overview of Cisco UCS Manager GUI, page 29](#)



CHAPTER 1

Overview of Cisco Unified Computing System

This chapter includes the following sections:

- [About Cisco Unified Computing System](#) , page 3
- [Unified Fabric](#), page 4
- [Server Architecture and Connectivity](#), page 5
- [Traffic Management](#), page 17
- [Opt-In Features](#), page 22
- [Overview of Virtualization](#), page 24

About Cisco Unified Computing System

Cisco Unified Computing System (Cisco UCS) fuses access layer networking and servers. This high-performance, next-generation server system provides a data center with a high degree of workload agility and scalability.

The hardware and software components support Cisco's unified fabric, which runs multiple types of data-center traffic over a single converged network adapter.

Architectural Simplification

The simplified architecture of Cisco UCS reduces the number of required devices and centralizes switching resources. By eliminating switching inside a chassis, network access-layer fragmentation is significantly reduced.

Cisco UCS implements Cisco unified fabric within racks and groups of racks, supporting Ethernet and Fibre Channel protocols over 10 Gigabit Cisco Data Center Ethernet and Fibre Channel over Ethernet (FCoE) links.

The result of this radical simplification is a reduction by up to two-thirds of the switches, cables, adapters, and management points. All devices in a Cisco UCS instance remain under a single management domain, which remains highly available through the use of redundant components.

High Availability

The management and data plane of Cisco UCS is designed for high availability and redundant access layer fabric interconnects. In addition, Cisco UCS supports existing high availability and disaster recovery solutions for the data center, such as data replication and application-level clustering technologies.

Scalability

A single Cisco UCS instance supports multiple chassis and their servers, all of which are administered through one Cisco UCS Manager. For more detailed information about the scalability, speak to your Cisco representative.

Flexibility

A Cisco UCS instance allows you to quickly align computing resources in the data center with rapidly changing business requirements. This built-in flexibility is determined by whether you choose to fully implement the stateless computing feature.

Pools of servers and other system resources can be applied as necessary to respond to workload fluctuations, support new applications, scale existing software and business services, and accommodate both scheduled and unscheduled downtime. Server identity can be abstracted into a mobile service profile that can be moved from server to server with minimal downtime and no need for additional network configuration.

With this level of flexibility, you can quickly and easily scale server capacity without having to change the server identity or reconfigure the server, LAN, or SAN. During a maintenance window, you can quickly:

- Deploy new servers to meet unexpected workload demand and rebalance resources and traffic.
- Shut down an application, such as a database management system, on one server and then boot it up again on another server with increased I/O capacity and memory resources.

Optimized for Server Virtualization

Cisco UCS has been optimized to implement VN-Link technology. This technology provides improved support for server virtualization, including better policy-based configuration and security, conformance with a company's operational model, and accommodation for VMware's VMotion.

Unified Fabric

With unified fabric, multiple types of data center traffic can run over a single Data Center Ethernet (DCE) network. Instead of having a series of different host bus adapters (HBAs) and network interface cards (NICs) present in a server, unified fabric uses a single converged network adapter. This adapter can carry LAN and SAN traffic on the same cable.

Cisco UCS uses Fibre Channel over Ethernet (FCoE) to carry Fibre Channel and Ethernet traffic on the same physical Ethernet connection between the fabric interconnect and the server. This connection terminates at a converged network adapter on the server, and the unified fabric terminates on the uplink ports of the fabric interconnect. On the core network, the LAN and SAN traffic remains separated. Cisco UCS does not require that you implement unified fabric across the data center.

The converged network adapter presents an Ethernet interface and Fibre Channel interface to the operating system. At the server, the operating system is not aware of the FCoE encapsulation because it sees a standard Fibre Channel HBA.

At the fabric interconnect, the server-facing Ethernet port receives the Ethernet and Fibre Channel traffic. The fabric interconnect (using Ethertype to differentiate the frames) separates the two traffic types. Ethernet frames and Fibre Channel frames are switched to their respective uplink interfaces.

Fibre Channel over Ethernet

Cisco UCS leverages Fibre Channel over Ethernet (FCoE) standard protocol to deliver Fibre Channel. The upper Fibre Channel layers are unchanged, so the Fibre Channel operational model is maintained. FCoE network management and configuration is similar to a native Fibre Channel network.

FCoE encapsulates Fibre Channel traffic over a physical Ethernet link. FCoE is encapsulated over Ethernet with the use of a dedicated Ethertype, 0x8906, so that FCoE traffic and standard Ethernet traffic can be carried on the same link. FCoE has been standardized by the ANSI T11 Standards Committee.

Fibre Channel traffic requires a lossless transport layer. Instead of the buffer-to-buffer credit system used by native Fibre Channel, FCoE depends upon the Ethernet link to implement lossless service.

Ethernet links on the fabric interconnect provide two mechanisms to ensure lossless transport for FCoE traffic:

- Link-level flow control
- Priority flow control

Link-Level Flow Control

IEEE 802.3x link-level flow control allows a congested receiver to signal the endpoint to pause data transmission for a short time. This link-level flow control pauses all traffic on the link.

The transmit and receive directions are separately configurable. By default, link-level flow control is disabled for both directions.

On each Ethernet interface, the fabric interconnect can enable either priority flow control or link-level flow control (but not both).

Priority Flow Control

The priority flow control (PFC) feature applies pause functionality to specific classes of traffic on the Ethernet link. For example, PFC can provide lossless service for the FCoE traffic, and best-effort service for the standard Ethernet traffic. PFC can provide different levels of service to specific classes of Ethernet traffic (using IEEE 802.1p traffic classes).

PFC decides whether to apply pause based on the IEEE 802.1p CoS value. When the fabric interconnect enables PFC, it configures the connected adapter to apply the pause functionality to packets with specific CoS values.

By default, the fabric interconnect negotiates to enable the PFC capability. If the negotiation succeeds, PFC is enabled and link-level flow control remains disabled (regardless of its configuration settings). If the PFC negotiation fails, you can either force PFC to be enabled on the interface or you can enable IEEE 802.x link-level flow control.

Server Architecture and Connectivity

Overview of Service Profiles

Service profiles are the central concept of Cisco UCS. Each service profile serves a specific purpose: ensuring that the associated server hardware has the configuration required to support the applications it will host.

The service profile maintains configuration information about the server hardware, interfaces, fabric connectivity, and server and network identity. This information is stored in a format that you can manage through Cisco UCS Manager. All service profiles are centrally managed and stored in a database on the fabric interconnect.

Every server must be associated with a service profile.



Important At any given time, each server can be associated with only one service profile. Similarly, each service profile can be associated with only one server at a time.

After you associate a service profile with a server, the server is ready to have an operating system and applications installed, and you can use the service profile to review the configuration of the server. If the server associated with a service profile fails, the service profile does not automatically fail over to another server.

When a service profile is disassociated from a server, the identity and connectivity information for the server is reset to factory defaults.

Network Connectivity through Service Profiles

Each service profile specifies the LAN and SAN network connections for the server through the Cisco UCS infrastructure and out to the external network. You do not need to manually configure the network connections for Cisco UCS servers and other components. All network configuration is performed through the service profile.

When you associate a service profile with a server, the Cisco UCS internal fabric is configured with the information in the service profile. If the profile was previously associated with a different server, the network infrastructure reconfigures to support identical network connectivity to the new server.

Configuration through Service Profiles

A service profile can take advantage of resource pools and policies to handle server and connectivity configuration.

Hardware Components Configured by Service Profiles

When a service profile is associated with a server, the following components are configured according to the data in the profile:

- Server, including BIOS and BMC
- Adapters
- Fabric interconnects

You do not need to configure these hardware components directly.

Server Identity Management through Service Profiles

You can use the network and device identities burned into the server hardware at manufacture or you can use identities that you specify in the associated service profile either directly or through identity pools, such as MAC, WWN, and UUID.

The following are examples of configuration information that you can include in a service profile:

- Profile name and description
- Unique server identity (UUID)
- LAN connectivity attributes, such as the MAC address
- SAN connectivity attributes, such as the WWN

Operational Aspects configured by Service Profiles

You can configure some of the operational functions for a server in a service profile, such as:

- Firmware packages and versions
- Operating system boot order and configuration
- IPMI and KVM access

vNIC Configuration by Service Profiles

A vNIC is a virtualized network interface that is configured on a physical network adapter and appears to be a physical NIC to the operating system of the server. The type of adapter in the system determines how many vNICs you can create. For example, a Cisco UCS CNA M71KR adapter has two NICs, which means you can create a maximum of two vNICs for each adapter.

A vNIC communicates over Ethernet and handles LAN traffic. At a minimum, each vNIC must be configured with a name and with fabric and network connectivity.

vHBA Configuration by Service Profiles

A vHBA is a virtualized host bus adapter that is configured on a physical network adapter and appears to be a physical HBA to the operating system of the server. The type of adapter in the system determines how many vHBAs you can create. For example, a Cisco UCS CNA M71KR has two HBAs, which means you can create a maximum of two vHBAs for each of those adapters. In contrast, a Cisco UCS 82598KR-CI does not have any HBAs, which means you cannot create any vHBAs for those adapters.

A vHBA communicates over FCoE and handles SAN traffic. At a minimum, each vHBA must be configured with a name and fabric connectivity.

Service Profiles that Override Server Identity

This type of service profile provides the maximum amount of flexibility and control. This profile allows you to override the identity values that are on the server at the time of association and use the resource pools and policies set up in Cisco UCS Manager to automate some administration tasks.

You can disassociate this service profile from one server and then associate it with another server. This re-association can be done either manually or through an automated server pool policy. The burned-in settings, such as UUID and MAC address, on the new server are overwritten with the configuration in the service profile. As a result, the change in server is transparent to your network. You do not need to reconfigure any component or application on your network to begin using the new server.

This profile allows you to take advantage of and manage system resources through resource pools and policies, such as:

- Virtualized identity information, including pools of MAC addresses, WWN addresses, and UUIDs
- Ethernet and Fibre Channel adapter profile policies

- Firmware package policies
- Operating system boot order policies

Service Profiles that Inherit Server Identity

This hardware-based service profile is the simplest to use and create. This profile uses the default values in the server and mimics the management of a rack-mounted server. It is tied to a specific server and cannot be moved to another server.

You do not need to create pools or configuration policies to use this service profile.

This service profile inherits and automatically applies the identity and configuration information that is present at the time of association, such as the following:

- MAC addresses for the two NICs
- For the Cisco UCS CNA M71KR adapters, the WWN addresses for the two HBAs
- BIOS versions
- Server UUID



Important

The server identity and configuration information inherited through this service profile may not be the values burned into the server hardware at manufacture if those values were changed before this profile is associated with the server.

Service Profile Templates

With a service profile template, you can quickly create several service profiles with the same basic parameters, such as the number of vNICs and vHBAs, and with identity information drawn from the same pools.



Tip

If you need only one service profile with similar values to an existing service profile, you can clone a service profile in the Cisco UCS Manager GUI.

For example, if you need several service profiles with similar values to configure servers to host database software, you can create a service profile template, either manually or from an existing service profile. You then use the template to create the service profiles.

Cisco UCS supports the following types of service profile templates:

- | | |
|--------------------------|--|
| Initial template | Service profiles created from an initial template inherit all the properties of the template. However, after you create the profile, it is no longer connected to the template. If you need to make changes to one or more profiles created from this template, you must change each profile individually. |
| Updating template | Service profiles created from an updating template inherit all the properties of the template and remain connected to the template. Any changes to the template automatically update the service profiles created from the template. |

Policies

Policies determine how Cisco UCS components will act in specific circumstances. You can create multiple instances of most policies. For example, you might want different boot policies, so that some servers can PXE boot, some can SAN boot, and others can boot from local storage.

Policies allow separation of functions within the system. A subject matter expert can define policies that are used in a service profile, which is created by someone without that subject matter expertise. For example, a LAN administrator can create adapter policies and quality of service policies for the system. These policies can then be used in a service profile that is created by someone who has limited or no subject matter expertise with LAN administration.

You can create and use two types of policies in Cisco UCS Manager:

- Configuration policies that configure the servers and other components
- Operational policies that control certain management, monitoring, and access control functions

Configuration Policies

Boot Policy

The boot policy determines the following:

- Configuration of the boot device
- Location from which the server boots
- Order in which boot devices are invoked

For example, you can choose to have associated servers boot from a local device, such as a local disk or CD-ROM (VMedia), or you can select a SAN boot or a LAN (PXE) boot.

You must include this policy in a service profile, and that service profile must be associated with a server for it to take effect. If you do not include a boot policy in a service profile, the server uses the default settings in the BIOS to determine the boot order.



Important

Changes to a boot policy may be propagated to all servers created with an updating service profile template that includes that boot policy. Reassociation of the service profile with the server to rewrite the boot order information in the BIOS is auto-triggered.

Guidelines

When you create a boot policy, you can add one or more of the following to the boot policy and specify their boot order:

Boot type	Description
SAN boot	Boots from an operating system image on the SAN. You can specify a primary and a secondary SAN boot. If the primary boot fails, the server attempts to boot from the secondary. We recommend that you use a SAN boot, because it offers the most service profile mobility within the system. If you boot from the SAN,

Boot type	Description
	when you move a service profile from one server to another, the new server boots from the exact same operating system image. Therefore, the new server appears to be the exact same server to the network.
LAN boot	Boots from a centralized provisioning server. It is frequently used to install operating systems on a server from that server.
Local disk boot	If the server has a local drive, boots from that drive.
Virtual media boot	Mimics the insertion of a physical CD-ROM disk (read-only) or floppy disk (read-write) into a server. It is typically used to manually install operating systems on a server.



Note The default boot order is as follows:

- 1 Local disk boot
- 2 LAN boot
- 3 Virtual media read-only boot
- 4 Virtual media read-write boot

Chassis Discovery Policy

This discovery policy determines how the system reacts when you add a new chassis. If you create a chassis discovery policy, the system does the following:

- Automatically configures the chassis for the number of links between the chassis and the fabric interconnect specified in the policy.
- Specifies the power policy to be used by the chassis.

Ethernet and Fibre Channel Adapter Policies

These policies govern the host-side behavior of the adapter, including how the adapter handles traffic. For example, you can use these policies to change default settings for the following:

- Queues
- Interrupt handling
- Performance enhancement
- RSS hash
- Failover in a cluster configuration with two fabric interconnects

By default, Cisco UCS provides a set of Ethernet adapter policies and Fibre Channel adapter policies. These policies include the recommended settings for each supported server operating system. Operating systems are sensitive to the settings in these policies. Storage vendors typically require non-default adapter settings. You can find the details of these required settings on the support list provided by those vendors.

**Note**

For Fibre Channel adapter policies, the values displayed by Cisco UCS Manager may not match those displayed by applications such as QLogic SANsurfer. For example, the following values may result in an apparent mismatch between SANsurfer and Cisco UCS Manager:

- Max LUNs Per Target—SANsurfer has a maximum of 256 LUNs and does not display more than that number. Cisco UCS Manager supports a higher maximum number of LUNs.
- Link Down Timeout—In SANsurfer, you configure the timeout threshold for link down in seconds. In Cisco UCS Manager, you configure this value in milliseconds. Therefore, a value of 5500 ms in Cisco UCS Manager displays as 5s in SANsurfer.
- Max Data Field Size—SANsurfer has allowed values of 512, 1024, and 2048. Cisco UCS Manager allows you to set values of any size. Therefore, a value of 900 in Cisco UCS Manager displays as 512 in SANsurfer.

Host Firmware Pack

This policy enables you to specify a common set of firmware versions that make up the host firmware pack. The host firmware includes the following server and adapter components:

- BIOS
- SAS controller
- Emulex Option ROM (applicable only to Emulex-based Converged Network Adapters [CNAs])
- Emulex firmware (applicable only to Emulex-based CNAs)
- QLogic option ROM (applicable only to QLogic-based CNAs)
- Adapter firmware

The firmware pack is pushed to all servers associated with service profiles that include this policy.

This policy ensures that the host firmware is identical on all servers associated with service profiles which use the same policy. Therefore, if you move the service profile from one server to another, the firmware versions are maintained. Also, if you change the firmware version of the component in the firmware pack, new versions are applied to all the affected service profiles immediately, which could cause server reboots.

You must include this policy in a service profile, and that service profile must be associated with a server for it to take effect.

Prerequisites

This policy is not dependent upon any other policies. However, you must ensure that the appropriate firmware has been downloaded to the fabric interconnect. If the firmware image is not available when Cisco UCS Manager is associating a server with a service profile, Cisco UCS Manager ignores the firmware update and completes the association.

IPMI Access Profile

This policy allows you to determine whether IPMI commands can be sent directly to the server, using the IP address. For example, you can send commands to retrieve sensor data from the BMC. This policy defines the IPMI access, including a username and password that can be authenticated locally on the server, and whether the access is read-only or read-write.

You must include this policy in a service profile and that service profile must be associated with a server for it to take effect.

Local Disk Configuration Policy

This policy configures any optional SAS local drives that have been installed on a server through the onboard RAID controller of the local drive. This policy enables you to set a local disk mode for all servers that are associated with a service profile that includes the local disk configuration policy. The local disk modes include the following:

- **Any Configuration**—For a server configuration that carries forward the local disk configuration without any changes.
- **No Local Storage**—For a diskless workstation or a SAN only configuration. If you select this option, you cannot associate any service profile which uses this policy with a server that has a local disk.
- **No RAID**—For a server configuration that removes the RAID and leaves the disk MBR and payload unaltered.
- **RAID Mirrored**—For a 2-disk RAID 1 server configuration.
- **RAID Stripes**—For a 2-disk RAID 0 server configuration.

You must include this policy in a service profile, and that service profile must be associated with a server for it to take effect.

Management Firmware Pack

This policy enables you to specify a common set of firmware versions that make up the management firmware pack. The management firmware includes the server controller (BMC) on the server.

The firmware pack is pushed to all servers associated with service profiles that include this policy.

This policy ensures that the BMC firmware is identical on all servers associated with service profiles which use the same policy. Therefore, if you move the service profile from one server to another, the firmware versions are maintained.

You must include this policy in a service profile, and that service profile must be associated with a server for it to take effect.

Prerequisites

This policy is not dependent upon any other policies. However, you must ensure that the appropriate firmware has been downloaded to the fabric interconnect.

Network Control Policy

This policy configures the network control settings for the Cisco UCS instance, including the following:

- Whether the Cisco Discovery Protocol (CDP) is enabled or disabled
- How the VIF behaves if no uplink port is available in end-host mode

Quality of Service Policies

QoS policies assign a system class to the outgoing traffic for a vNIC or vHBA. This system class determines the quality of service for that traffic.

You must include a QoS policy in a vNIC policy or vHBA policy and then include that policy in a service profile to configure the vNIC or vHBA.

Server Autoconfiguration Policy

This policy determines whether one or more of the following is automatically applied to a new server:

- A server pool policy qualification that qualifies the server for one or more server pools
- An organization
- A service profile template that associates the server with a service profile created from that template

Server Discovery Policy

This discovery policy determines how the system reacts when you add a new server. If you create a server discovery policy, you can control whether the system conducts a deep discovery when a server is added to a chassis, or whether a user must first acknowledge the new server. By default, the system conducts a full discovery.

With this policy, an inventory of the server is conducted, then server pool policy qualifications are run to determine whether the new server qualifies for one or more server pools.

Server Inheritance Policy

This policy is invoked during the server discovery process to create a service profile for the server. All service profiles created from this policy use the values burned into the blade at manufacture. The policy performs the following:

- Analyzes the inventory of the server
- If configured, assigns the server to the selected organization
- Creates a service profile for the server with the identity burned into the server at manufacture

You cannot migrate a service profile created with this policy to another server.

Server Pool Policy

This policy is invoked during the server discovery process. It determines what happens if server pool policy qualifications match a server to the target pool specified in the policy.

If a server qualifies for more than one pool and those pools have server pool policies, the server is added to all those pools.

Server Pool Policy Qualifications

This policy qualifies servers based on the inventory of a server conducted during the discovery process. The qualifications are individual rules that you configure in the policy to determine whether a server meets the selection criteria. For example, you can create a rule that specifies the minimum memory capacity for servers in a data center pool.

Qualifications are used in other policies to place servers, not just by the server pool policies. For example, if a server meets the criteria in a qualification policy, it can be added to one or more server pools or have a service profile automatically associated with it.

Depending upon the implementation, you may include server pool policy qualifications in the following policies:

- Autoconfiguration policy
- Chassis discovery policy
- Server discovery policy
- Server inheritance policy
- Server pool policy

vHBA Template

This template is a policy that defines how a vHBA on a server connects to the SAN. It is also referred to as a vHBA SAN connectivity template.

You need to include this policy in a service profile for it to take effect.

vNIC Template

This policy defines how a vNIC on a server connects to the LAN. This policy is also referred to as a vNIC LAN connectivity policy.

You need to include this policy in a service profile for it to take effect.

Operational Policies

Fault Collection Policy

The fault collection policy controls the lifecycle of a fault in a Cisco UCS instance, including when faults are cleared, the flapping interval (the length of time between the fault being raised and the condition being cleared), and the retention interval (the length of time a fault is retained in the system).

A fault in Cisco UCS has the following lifecycle:

- 1 A condition occurs in the system and Cisco UCS Manager raises a fault. This is the active state.
- 2 When the fault is alleviated, it is cleared if the time between the fault being raised and the condition being cleared is greater than the flapping interval, otherwise, the fault remains raised but its status changes to soaking-clear. Flapping occurs when a fault is raised and cleared several times in rapid succession. During the flapping interval the fault retains its severity for the length of time specified in the fault collection policy.
- 3 If the condition reoccurs during the flapping interval, the fault remains raised and its status changes to flapping. If the condition does not reoccur during the flapping interval, the fault is cleared.
- 4 When a fault is cleared, it is deleted if the clear action is set to delete, or if the fault was previously acknowledged, otherwise, it is retained until either the retention interval expires, or if the fault is acknowledged.
- 5 If the condition reoccurs during the retention interval, the fault returns to the active state. If the condition does not reoccur, the fault is deleted.

Scrub Policy

This policy determines what happens to local data on a server during the discovery process and when the server is disassociated from a service profile. This policy can ensure that the data on local drives is erased at those times.

Serial over LAN Policy

This policy sets the configuration for the serial over LAN connection for all servers associated with service profiles that use the policy. By default, the serial over LAN connection is disabled.

If you implement a serial over LAN policy, we recommend that you also create an IPMI profile.

You must include this policy in a service profile and that service profile must be associated with a server for it to take effect.

Statistics Collection Policy

A statistics collection policy defines how frequently statistics are to be collected (collection interval), and how frequently the statistics are to be reported (reporting interval). Reporting intervals are longer than collection intervals so that multiple statistical data points can be collected during the reporting interval, which provides Cisco UCS Manager with sufficient data to calculate and report minimum, maximum, and average values.

Statistics can be collected and reported for the following five functional areas of the Cisco UCS system:

- Adapter—statistics related to the adapters
- Chassis—statistics related to the blade chassis
- Host—this policy is a placeholder for future support
- Port—statistics related to the ports, including server ports, uplink Ethernet ports, and uplink Fibre Channel ports
- Server—statistics related to servers

**Note**

Cisco UCS Manager has one default statistics collection policy for each of the five functional areas. You cannot create additional statistics collection policies and you cannot delete the existing default policies. You can only modify the default policies.

Statistics Threshold Policy

A statistics threshold policy monitors statistics about certain aspects of the system and generates an event if the threshold is crossed. You can set both minimum and maximum thresholds. For example, you can configure the policy to raise an alarm if the CPU temperature exceeds a certain value, or if a server is overutilized or underutilized.

These threshold policies do not control the hardware or device-level thresholds enforced by endpoints, such as the BMC. Those thresholds are burned in to the hardware components at manufacture.

Cisco UCS enables you to configure statistics threshold policies for the following components:

- Servers and server components
- Uplink Ethernet ports
- Ethernet server ports, chassis, and fabric interconnects
- Fibre Channel port

**Note**

You cannot create or delete a statistics threshold policy for Ethernet server ports, uplink Ethernet ports, or uplink Fibre Channel ports. You can only configure the existing default policy.

Pools

Pools are collections of identities, or physical or logical resources, that are available in the system. All pools increase the flexibility of service profiles and allow you to centrally manage your system resources.

You can use pools to segment unconfigured servers or available ranges of server identity information into groupings that make sense for the data center. For example, if you create a pool of unconfigured servers with similar characteristics and include that pool in a service profile, you can use a policy to associate that service profile with an available, unconfigured server.

If you pool identifying information, such as MAC addresses, you can pre-assign ranges for servers that will host specific applications. For example, all database servers could be configured within the same range of MAC addresses, UUIDs, and WWNs.

Server Pools

A server pool contains a set of servers. These servers typically share the same characteristics. Those characteristics can be their location in the chassis, or an attribute such as server type, amount of memory, local storage, type of CPU, or local drive configuration. You can manually assign a server to a server pool, or use server pool policies and server pool policy qualifications to automate the assignment.

If your system implements multi-tenancy through organizations, you can designate one or more server pools to be used by a specific organization. For example, a pool that includes all servers with two CPUs could be assigned to the Marketing organization, while all servers with 64 GB memory could be assigned to the Finance organization.

A server pool can include servers from any chassis in the system. A given server can belong to multiple server pools.

MAC Pools

A MAC pool is a collection of network identities, or MAC addresses, that are unique in their layer 2 environment and are available to be assigned to vNICs on a server. If you use MAC pools in service profiles, you do not have to manually configure the MAC addresses to be used by the server associated with the service profile.

In a system that implements multi-tenancy, you can use the organizational hierarchy to ensure that MAC pools can only be used by specific applications or business services. Cisco UCS Manager uses the name resolution policy to assign MAC addresses from the pool.

To assign a MAC address to a server, you must include the MAC pool in a vNIC policy. The vNIC policy is then included in the service profile assigned to that server.

You can specify your own MAC addresses or use a group of MAC addresses provided by Cisco.

UUID Suffix Pools

A UUID suffix pool is a collection of SMBIOS UUIDs that are available to be assigned to servers. The first number of digits that constitute the prefix of the UUID are fixed. The remaining digits, the UUID suffix, is variable. A UUID suffix pool ensures that these variable values are unique for each server associated with a service profile which uses that particular pool to avoid conflicts.

If you use UUID suffix pools in service profiles, you do not have to manually configure the UUID of the server associated with the service profile.

WWN Pools

A WWN pool is a collection of WWNs for use by the Fibre Channel vHBAs in a Cisco UCS instance. You create separate pools for the following:

- WW node names assigned to the server
- WW port names assigned to the vHBA



Important

A WWN pool can include only WWNNs or WWPNS in the ranges from 20:00:00:00:00:00:00:00 to 20:FF:FF:FF:FF:FF:FF:FF or from 50:00:00:00:00:00:00:00 to 5F:FF:FF:FF:FF:FF:FF:FF. All other WWN ranges are reserved.

If you use WWN pools in service profiles, you do not have to manually configure the WWNs that will be used by the server associated with the service profile. In a system that implements multi-tenancy, you can use a WWN pool to control the WWNs used by each organization.

You assign WWNs to pools in blocks. For each block or individual WWN, you can assign a boot target.

WWNN Pools

A WWNN pool is a WWN pool which contains only WW node names. If you include a pool of WWNNs in a service profile, the associated server is assigned a WWNN from that pool.

WWPN Pools

A WWPN pool is a WWN pool which contains only WW port names. If you include a pool of WWPNs in a service profile, the port on each vHBA of the associated server is assigned a WWPN from that pool.

Management IP Pool

The management IP pool is a collection of external IP addresses. Cisco UCS Manager reserves each block of IP addresses in the management IP pool for external access that terminates in the server controller (BMC) in a server.

Cisco UCS Manager uses the IP addresses in a management IP pool for external access to a server through the following:

- KVM console
- Serial over LAN
- IPMI

Traffic Management

Oversubscription

Oversubscription occurs when multiple network devices are connected to the same fabric interconnect port. This practice optimizes fabric interconnect use, since ports rarely run at maximum speed for any length of time. As a result, when configured correctly, oversubscription allows you to take advantage of unused bandwidth. However, incorrectly configured oversubscription can result in contention for bandwidth and a lower quality of service to all services that use the oversubscribed port.

For example, oversubscription can occur if four servers share a single uplink port, and all four servers attempt to send data at a cumulative rate higher than available bandwidth of uplink port.

Oversubscription Considerations

The following elements can impact how you configure oversubscription in a Cisco UCS:

The ratio of server-facing ports to uplink ports	You need to know what how many server-facing ports and uplink ports are in the system, because that ratio can impact performance. For example, if your system has twenty ports that can communicate down to the servers and only two ports that can communicate up to the network, your uplink ports will be oversubscribed. In this situation, the amount of traffic created by the servers can also affect performance.
---	---

The number of uplink ports from the fabric interconnect to the network You can choose to add more uplink ports between the Cisco UCS fabric interconnect and the upper layers of the LAN to increase bandwidth. In Cisco UCS, you must have at least one uplink port per fabric interconnect to ensure that all servers and NICs to have access to the LAN. The number of LAN uplinks should be determined by the aggregate bandwidth needed by all Cisco UCS servers.

FC uplink ports are available on the expansion slots only. You must add more expansion slots to increase number of available FC uplinks. Ethernet uplink ports can exist on the fixed slot and on expansion slots.

For example, if you have two Cisco UCS 5100 series chassis that are fully populated with half width Cisco UCS B200-M1 servers, you have 16 servers. In a cluster configuration, with one LAN uplink per fabric interconnect, these 16 servers share 20GbE of LAN bandwidth. If more capacity is needed, more uplinks from the fabric interconnect should be added. We recommend that you have symmetric configuration of the uplink in cluster configurations. In the same example, if 4 uplinks are used in each fabric interconnect, the 16 servers are sharing 80 GB of bandwidth, so each has approximately 5 GB of capacity. When multiple uplinks are used on a Cisco UCS fabric interconnect the network design team should consider using a port channel to make best use of the capacity.

The number of uplink ports from the I/O module to the fabric interconnect You can choose to add more bandwidth between I/O module and fabric interconnect by using more uplink ports and increasing the number of cables. In Cisco UCS, you can have one, two, or four cables connecting a I/O module to a Cisco UCS fabric interconnect. The number of cables determines the number of active uplink ports and the oversubscription ratio. For example, one cable results in 8:1 oversubscription for one I/O module. If two I/O modules are in place, each with one cable, and you have 8 half-width blades, the 8 blades will be sharing two uplinks (one left IOM and one right IOM). This results in 8 blades sharing an aggregate bandwidth of 20 GB of Unified Fabric capacity. If two cables are used, this results in 4:1 oversubscription per IOM (assuming all slots populated with half width blades), and four cables result in 2:1 oversubscription. The lower oversubscription ratio gives you higher performance, but is also more costly as you consume more fabric interconnect ports.

The number of active links from the server to the fabric interconnect Oversubscription is affected by how many servers are in a particular chassis and how bandwidth intensive those servers are. The oversubscription ratio will be reduced if the servers which generate a large amount of traffic are not in the same chassis, but are shared between the chassis in the system. The number of cables between chassis and fabric interconnect determines the oversubscription ratio. For example, one cable results in 8:1 oversubscription, two cables result in 4:1 oversubscription, and four cables result in 2:1 oversubscription. The lower oversubscription ratio gives you higher performance, but it is also more costly.

Guidelines for Estimating Oversubscription

When you estimate the optimal oversubscription ratio for a fabric interconnect port, consider the following guidelines:

Cost/performance slider The prioritization of cost and performance is different for each data center and has a direct impact on the configuration of oversubscription. When you plan hardware usage for oversubscription, you need to know where the data center is located on this slider. For example, oversubscription can be minimized if the data center is more concerned

with performance than cost. However, cost is a significant factor in most data centers, and oversubscription requires careful planning.

Bandwidth usage The estimated bandwidth that you expect each server to actually use is important when you determine the assignment of each server to a fabric interconnect port and, as a result, the oversubscription ratio of the ports. For oversubscription, you must consider how many GBs of traffic the server will consume on average, the ratio of configured bandwidth to used bandwidth, and the times when high bandwidth use will occur.

Network type The network type is only relevant to traffic on uplink ports, because FCoE does not exist outside Cisco UCS. The rest of the data center network only differentiates between LAN and SAN traffic. Therefore, you do not need to take the network type into consideration when you estimate oversubscription of a fabric interconnect port.

Pinning

Pinning in Cisco UCS is only relevant to uplink ports. You can pin Ethernet or FCoE traffic from a given server to a specific uplink Ethernet port or uplink FC port.

When you pin the NIC and HBA of both physical and virtual servers to uplink ports, you give the fabric interconnect greater control over the unified fabric. This control ensures more optimal utilization of uplink port bandwidth.

Cisco UCS uses pin groups to manage which NICs, vNICs, HBAs, and vHBAs are pinned to an uplink port. To configure pinning for a server, you can either assign a pin group directly, or include a pin group in a vNIC policy, and then add that vNIC policy to the service profile assigned to that server. All traffic from the vNIC or vHBA on the server travels through the I/O module to the same uplink port.

Pinning Server Traffic to Server Ports

All server traffic travels through the I/O module to server ports on the fabric interconnect. The number of links for which the chassis is configured determines how this traffic is pinned.

The pinning determines which server traffic goes to which server port on the fabric interconnect. This pinning is fixed. You cannot modify it. As a result, you must consider the server location when you determine the appropriate allocation of bandwidth for a chassis.



Note

You must review the allocation of ports to links before you allocate servers to slots. The cabled ports are not necessarily port 1 and port 2 on the I/O module. If you change the number of links between the fabric interconnect and the I/O module, you must reacknowledge the chassis to have the traffic rerouted.

All port numbers refer to the fabric interconnect-side ports on the I/O module.

Chassis with One I/O Module

Links on Chassis	Servers Pinned to Link 1	Servers Pinned to Link 2	Servers Pinned to Link 3	Servers Pinned to Link 4
1 link	All server slots	None	None	None
2 links	Slots 1, 3, 5, and 9	Slots 2, 4, 6, and 8	None	None

Links on Chassis	Servers Pinned to Link 1	Servers Pinned to Link 2	Servers Pinned to Link 3	Servers Pinned to Link 4
4 links	Slots 1 and 5	Slots 2 and 6	Slots 3 and 7	Slots 4 and 8

Chassis with Two I/O Modules

If a chassis has two I/O modules, traffic from one I/O module goes to one of the fabric interconnects and traffic from the other I/O module goes to the second fabric interconnect. You cannot connect two I/O modules to a single fabric interconnect.

Adding a second I/O module to a chassis does not improve oversubscription. The server port pinning is the same for a single I/O module. The second I/O module improves the high availability of the system through the vNIC binding to the fabric interconnect.

Fabric Interconnect Configured in vNIC	Server Traffic Path
A	Server traffic goes to fabric interconnect A. If A fails, the server traffic does not fail over to B.
B	All server traffic goes to fabric interconnect B. If B fails, the server traffic does not fail over to A.
A-B	All server traffic goes to fabric interconnect A. If A fails, the server traffic fails over to B.
B-A	All server traffic goes to fabric interconnect B. If B fails, the server traffic fails over to A.

Guidelines for Pinning

When you determine the optimal configuration for pin groups and pinning for an uplink port, consider the estimated bandwidth usage for the servers. If you know that some servers in the system will use a lot of bandwidth, ensure that you pin these servers to different uplink ports.

Quality of Service

Cisco UCS provides the following methods to implement quality of service:

- System classes that specify the global configuration for certain types of traffic across the entire system
- QoS policies that assign system classes for individual vNICs
- Flow control policies that determine how uplink Ethernet ports handle pause frames

System Classes

Cisco UCS uses Data Center Ethernet (DCE) to handle all traffic inside a Cisco UCS instance. This industry standard enhancement to Ethernet divides the bandwidth of the Ethernet pipe into eight virtual lanes. System classes determine how the DCE bandwidth in these virtual lanes is allocated across the entire Cisco UCS instance.

Each system class reserves a specific segment of the bandwidth for a specific type of traffic. This provides a level of traffic management, even in an oversubscribed system. For example, you can configure the Fibre Channel Priority system class to determine the percentage of DCE bandwidth allocated to FCoE traffic.

The following table describes the system classes:

System Class	Description
Platinum Priority Gold Priority Silver Priority Bronze Priority	A configurable set of system classes that you can include in the QoS policy for a service profile. Each system class manages one lane of traffic. All properties of these system classes are available for you to assign custom settings and policies.
Best Effort Priority	A system class that sets the quality of service for the lane reserved for Basic Ethernet traffic. Some properties of this system class are preset and cannot be modified. For example, this class has a drop policy that allows it to drop data packets if required.
Fibre Channel Priority	A system class that sets the quality of service for the lane reserved for Fibre Channel over Ethernet traffic. Some properties of this system class are preset and cannot be modified. For example, this class has a no-drop policy that ensures it never drops data packets.

Quality of Service Policies

QoS policies assign a system class to the outgoing traffic for a vNIC or vHBA. This system class determines the quality of service for that traffic.

You must include a QoS policy in a vNIC policy or vHBA policy and then include that policy in a service profile to configure the vNIC or vHBA.

Flow Control Policies

Flow control policies determine whether the uplink Ethernet ports in a Cisco UCS instance send and receive IEEE 802.3x pause frames when the receive buffer for a port fills. These pause frames request that the transmitting port stop sending data for a few milliseconds until the buffer clears.

For flow control to work between a LAN port and an uplink Ethernet port, you must enable the corresponding receive and send flow control parameters for both ports. For Cisco UCS, the flow control policies configure these parameters.

When you enable the send function, the uplink Ethernet port sends a pause request to the network port if the incoming packet rate becomes too high. The pause remains in effect for a few milliseconds before traffic is reset to normal levels. If you enable the receive function, the uplink Ethernet port honors all pause requests from the network port. All traffic is halted on that uplink port until the network port cancels the pause request.

Because you assign the flow control policy to the port, changes to the policy have an immediate effect on how the port reacts to a pause frame or a full receive buffer.

Opt-In Features

Each Cisco UCS instance is licensed for all functionality. Depending upon how the system is configured, you can decide to opt in to some features or opt out of them for easier integration into existing environment. If a process change happens, you can change your system configuration and include one or both of the opt-in features.

The opt-in features are as follows:

- Stateless computing, which takes advantage of mobile service profiles with pools and policies where each component, such as a server or an adapter, is stateless.
- Multi-tenancy, which uses organizations and role-based access control to divide the system into smaller logical segments.

Stateless Computing

Stateless computing allows you to use a service profile to apply the personality of one server to a different server in the same Cisco UCS instance. The personality of the server includes the elements that identify that server and make it unique in the instance. If you change any of these elements, the server could lose its ability to access, use, or even achieve booted status.

The elements that make up a server's personality include the following:

- Firmware versions
- UUID (used for server identification)
- MAC address (used for LAN connectivity)
- World Wide Names (used for SAN connectivity)
- Boot settings

Stateless computing creates a dynamic server environment with highly flexible servers. Every physical server in a Cisco UCS instance remains anonymous until you associate a service profile with it, then the server gets the identity configured in the service profile. If you no longer need a business service on that server, you can shut it down, disassociate the service profile, and then associate another service profile to create a different identity for the same physical server. The "new" server can then host another business service.

To take full advantage of the flexibility of statelessness, the optional local disks on the servers should only be used for swap or temp space and not to store operating system or application data.

You can choose to fully implement stateless computing for all physical servers in a Cisco UCS instance, to not have any stateless servers, or to have a mix of the two types.

If You Opt In to Stateless Computing

Each physical server in the Cisco UCS instance is defined through a service profile. Any server can be used to host one set of applications, then reassigned to another set of applications or business services, if required by the needs of the data center.

You create service profiles that point to policies and pools of resources that are defined in the instance. The server pools, WWN pools, and MAC pools ensure that all unassigned resources are available on an as-needed basis. For example, if a physical server fails, you can immediately assign the service profile to another server. Because the service profile provides the new server with the same identity as the original server, including

WWN and MAC address, the rest of the data center infrastructure sees it as the same server and you do not need to make any configuration changes in the LAN or SAN.

If You Opt Out of Stateless Computing

Each server in the Cisco UCS instance is treated as a traditional rack mount server.

You create service profiles that inherit the identify information burned into the hardware and use these profiles to configure LAN or SAN connectivity for the server. However, if the server hardware fails, you cannot reassign the service profile to a new server.

Multi-Tenancy

In Cisco UCS, you can use multi-tenancy to divide up the large physical infrastructure of an instance into logical entities known as organizations. As a result, you can achieve a logical isolation between organizations without providing a dedicated physical infrastructure for each organization.

You can assign unique resources to each tenant through the related organization, in the multi-tenant environment. These resources can include different policies, pools, and quality of service definitions. You can also implement locales to assign or restrict Cisco UCS user privileges and roles by organization, if you do not want all users to have access to all organizations.

If you set up a multi-tenant environment, all organizations are hierarchical. The top-level organization is always root. The policies and pools that you create in root are system-wide and are available to all organizations in the system. However, any policies and pools created in other organizations are only available to organizations that are above it in the same hierarchy. For example, if a system has organizations named Finance and HR that are not in the same hierarchy, Finance cannot use any policies in the HR organization, and HR cannot access any policies in the Finance organization. However, both Finance and HR can use policies and pools in the root organization.

If you create organizations in a multi-tenant environment, you can also set up one or more of the following for each organization or for a sub-organization in the same hierarchy:

- Resource pools
- Policies
- Service profiles
- Service profile templates

If You Opt In to Multi-Tenancy

The Cisco UCS instance is divided into several distinct organizations. The types of organizations you create in a multi-tenancy implementation depends upon the business needs of the company. Examples include organizations that represent the following:

- Enterprise groups or divisions within a company, such as marketing, finance, engineering, or human resources
- Different customers or name service domains, for service providers

You can create locales to ensure that users have access only to those organizations that they are authorized to administer.

If You Opt Out of Multi-Tenancy

The Cisco UCS instance remains a single logical entity with everything in the root organization. All policies and resource pools can be assigned to any server in the instance.

Overview of Virtualization

Virtualization allows the creation of multiple virtual machines to run in isolation, side-by-side on the same physical machine.

Each virtual machine has its own set of virtual hardware (RAM, CPU, NIC) upon which an operating system and fully configured applications are loaded. The operating system sees a consistent, normalized set of hardware regardless of the actual physical hardware components.

In a virtual machine, both hardware and software are encapsulated in a single file for rapid copying, provisioning, and moving between physical servers. You can move a virtual machine, within seconds, from one physical server to another for zero-downtime maintenance and continuous workload consolidation.

The virtual hardware makes it possible for many servers, each running in an independent virtual machine, to run on a single physical server. The advantages of virtualization include better use of computing resources, greater server density, and seamless server migration.

Virtualization with the Cisco UCS CNA M71KR and Cisco UCS 82598KR-CI Adapters

The Cisco UCS 82598KR-CI 10-Gigabit Ethernet Adapter, Cisco UCS M71KR - E Emulex Converged Network Adapter, and Cisco UCS M71KR - Q QLogic Converged Network Adapter support virtualized environments with the following VMware versions:

- VMware 3.5 update 4
- VMware 4.0

These environments support the standard VMware integration with ESX installed on the server and all virtual machine management performed through the VC.

Portability of Virtual Machines

If you implement service profiles you retain the ability to easily move a server identity from one server to another. After you image the new server, the ESX treats that server as if it were the original.

Communication between Virtual Machines on the Same Server

These adapters implement the standard communications between virtual machines on the same server. If an ESX host includes multiple virtual machines, all communications must go through the virtual switch on the server.

If the system uses the native VMware drivers, the virtual switch is out of the network administrator's domain and is not subject to any network policies. As a result, for example, quality of service policies on the network are not applied to any data packets traveling from VM1 to VM2 through the virtual switch.

If the system includes another virtual switch, such as the Nexus 1000, that virtual switch is subject to the network policies configured on that switch by the network administrator.



CHAPTER 2

Overview of Cisco UCS Manager

This chapter includes the following sections:

- [About Cisco UCS Manager , page 25](#)
- [Tasks You Can Perform in Cisco UCS Manager , page 26](#)
- [Tasks You Cannot Perform in Cisco UCS Manager , page 28](#)
- [Cisco UCS Manager in a Cluster Environment, page 28](#)

About Cisco UCS Manager

Cisco UCS Manager is the management service for all components in a Cisco UCS instance. Cisco UCS Manager runs within the fabric interconnect. You can use any of the interfaces available with this management service to access, configure, administer, and monitor the network and server resources for all chassis connected to the fabric interconnect.

Multiple Management Interfaces

Cisco UCS Manager includes the following interfaces you can use to manage a Cisco UCS instance:

- Cisco UCS Manager GUI
- Cisco UCS Manager CLI
- XML API

Almost all tasks can be performed in any of the interfaces, and the results of tasks performed in one interface are automatically displayed in another.

However, you cannot do the following:

- Use Cisco UCS Manager GUI to invoke Cisco UCS Manager CLI.
- View a command that has been invoked through Cisco UCS Manager CLI in Cisco UCS Manager GUI.
- Generate CLI output from Cisco UCS Manager GUI.

Centralized Management

Cisco UCS Manager centralizes the management of resources and devices, rather than using multiple management points. This centralized management includes management of the following devices in a Cisco UCS instance:

- Fabric interconnects
- Software switches for virtual servers
- Power and environmental management for chassis and servers
- Configuration and firmware updates for Ethernet NICs and Fibre Channel HBAs
- Firmware and BIOS settings for servers

Support for Virtual and Physical Servers

Cisco UCS Manager abstracts server state information—including server identity, I/O configuration, MAC addresses and World Wide Names, firmware revision, and network profiles—into a service profile. You can apply the service profile to any server resource in the system, providing the same flexibility and support to physical servers, virtual servers, and virtual machines connected to a virtual device provided by the Palo adapter.

Role-Based Administration and Multi-Tenancy Support

Cisco UCS Manager supports flexibly defined roles so that data centers can use the same best practices with which they manage discrete servers, storage, and networks to operate a Cisco UCS instance. You can create user roles with privileges that reflect user responsibilities in the data center. For example, you can create the following:

- Server administrator roles with control over server-related configurations
- Storage administrator roles with control over tasks related to the SAN
- Network administrator roles with control over tasks related to the LAN

In a multi-tenancy environment, Cisco UCS Manager enables you to create locales for user roles that can limit the scope of a user to a particular organization.

Tasks You Can Perform in Cisco UCS Manager

You can use Cisco UCS Manager to perform management tasks for all physical and virtual devices within a Cisco UCS instance.

Cisco UCS Hardware Management

You can use Cisco UCS Manager to manage all hardware within a Cisco UCS instance, including the following:

- Chassis
- Servers
- Fabric interconnects
- Fans
- Ports

- Cards
- Slots
- I/O modules

Cisco UCS Resource Management

You can use Cisco UCS Manager to create and manage all resources within a Cisco UCS instance, including the following:

- Servers
- WWN addresses
- MAC addresses
- UUIDs
- Bandwidth

Server Administration in a Cisco UCS Instance

A server administrator can use Cisco UCS Manager to perform server management tasks within a Cisco UCS instance, including the following:

- Create server pools and policies related to those pools, such as qualification policies
- Create policies for the servers, such as discovery policies, scrub policies, and IPMI policies
- Create service profiles and, if desired, service profile templates
- Apply service profiles to servers
- Monitor faults, alarms, and the status of equipment

Network Administration in a Cisco UCS Instance

A network administrator can use Cisco UCS Manager to perform tasks required to create LAN configuration for a Cisco UCS instance, including the following:

- Configure uplink ports, port channels, and LAN PIN groups
- Create VLANs
- Configure the quality of service classes and definitions
- Create the pools and policies related to network configuration, such as MAC address pools and Ethernet adapter profiles

Storage Administration in a Cisco UCS Instance

A storage administrator can use Cisco UCS Manager to perform tasks required to create SAN configuration for a Cisco UCS instance, including the following:

- Configure ports, port channels, and SAN PIN groups
- Create VSANs
- Configure the quality of service classes and definitions

- Create the pools and policies related to the network configuration, such as WWN pools and Fibre Channel adapter profiles

Tasks You Cannot Perform in Cisco UCS Manager

You cannot use Cisco UCS Manager to perform certain system management tasks that are not specifically related to device management within a Cisco UCS instance

No Cross-System Management

You cannot use Cisco UCS Manager to manage systems or devices that are outside the Cisco UCS instance where Cisco UCS Manager is located. For example, you cannot manage heterogeneous environments, such as non-Cisco UCS x86 systems, SPARC systems, or PowerPC systems.

No Operating System or Application Provisioning or Management

Cisco UCS Manager provisions servers and, as a result, exists below the operating system on a server. Therefore, you cannot use it to provision or manage operating systems or applications on servers. For example, you cannot do the following:

- Deploy an OS, such as Windows or Linux
- Deploy patches for software, such as an OS or an application
- Install base software components, such as anti-virus software, monitoring agents, or backup clients
- Install software applications, such as databases, application server software, or web servers
- Perform operator actions, including restarting an Oracle database, restarting printer queues, or handling non-Cisco UCS user accounts
- Configure or manage external storage on the SAN or NAS storage

Cisco UCS Manager in a Cluster Environment

In a cluster Cisco UCS instance with two fabric interconnects, you can run a separate instance of Cisco UCS Manager on each fabric interconnect. The Cisco UCS Manager on the primary fabric interconnect acts as the primary management instance, and the Cisco UCS Manager on the other fabric interconnect is the subordinate management instance.

The two instances of Cisco UCS Manager communicate across a private network between the L1 and L2 Ethernet ports on the fabric interconnects. Configuration and status information is communicated across this private network to ensure that all management information is replicated. This ongoing communication ensures that the management information for Cisco UCS persists even if the primary fabric interconnect fails. In addition, the "floating" management IP address that runs on the primary Cisco UCS Manager ensures a smooth transition in the event of a failover to the subordinate fabric interconnect.



CHAPTER 3

Overview of Cisco UCS Manager GUI

This chapter includes the following sections:

- [Overview of Cisco UCS Manager GUI](#) , page 29
- [Logging in to Cisco UCS Manager GUI through HTTPS](#), page 34
- [Logging in to Cisco UCS Manager GUI through HTTP](#), page 35
- [Logging Off Cisco UCS Manager GUI](#) , page 35
- [Changing the Cisco UCS Manager GUI Properties](#), page 35

Overview of Cisco UCS Manager GUI

Cisco UCS Manager GUI is the Java application that provides a GUI interface to Cisco UCS Manager. You can start and access Cisco UCS Manager GUI from any computer that meets the following requirements:

- Has Java 1.6 or higher installed
- Runs a supported operating system
- Has HTTP or HTTPS access to the fabric interconnect

Each time you start Cisco UCS Manager GUI, Cisco UCS Manager uses Java Web Start technology to cache the current version of the application on your computer. As a result, you do not have to download the application every time you log in. You only have to download the application the first time that you log in from a computer after the Cisco UCS Manager software has been updated on a system.

**Tip**

The title bar displays the name of the Cisco UCS instance to which you are connected.

Fault Summary Area

The **Fault Summary** area displays in the upper left of Cisco UCS Manager GUI. This area displays a summary of all faults that have occurred in the Cisco UCS instance.

Each type of fault is represented by a different icon. The number below each icon indicates how many faults of that type have occurred in the system. If you click an icon, Cisco UCS Manager GUI opens the **Faults** tab in the **Work** area and displays the details of all faults of that type.

The following table describes the types of faults each icon in the **Fault Summary** area represents:

Fault Type	Description
Critical Alarms	Critical problems exist with one or more components. These issues should be researched and fixed immediately.
Major Alarms	Serious problems exist with one or more components. These issues should be researched and fixed immediately.
Minor Alarms	Problems exist with one or more components that may adversely affect system performance. These issues should be researched and fixed as soon as possible before they become major or critical issues.
Warning Alarms	Potential problems exist with one or more components that may adversely affect system performance if they are allowed to continue. These issues should be researched and fixed as soon as possible before the problem grows worse.

**Tip**

If you only want to see faults for a specific object, navigate to that object and then review the **Faults** tab for that object.

Navigation Pane

The **Navigation** pane displays on the left side of Cisco UCS Manager GUI below the **Fault Summary** area. This pane provides centralized navigation to all equipment and other components in the Cisco UCS instance. When you select a component in the **Navigation** pane, the object displays in the **Work** area.

The **Navigation** pane has five tabs. Each tab includes the following elements:

- A **Filter** combo box that you can use to filter the navigation tree to view all nodes or only one node.
- An expandable navigation tree that you can use to access all components on that tab. An icon next to an folder indicates that the node or folder has subcomponents.

The following table describes the tabs in the **Navigation** pane:

Tab name	Description
Equipment tab	This tab contains a basic inventory of the equipment in the Cisco UCS instance. A system or server administrator can use this tab to access and manage the chassis, fabric interconnects, servers, and other hardware. A red, orange, or yellow rectangle around a device name indicate that the device has a fault.
Servers tab	This tab contains the server-related components, such as service profiles, policies, and pools. A server administrator typically accesses and manages the components on this tab.

Tab name	Description
LAN tab	This tab contains the components related to LAN configuration, such as LAN pin groups, quality of service classes, VLANs, policies, pools, the internal domain, and VM systems. A network administrator typically accesses and manages the components on this tab.
SAN tab	This tab contains the components related to SAN configuration, such as pin groups, VSANs, policies, and pools. A storage administrator typically accesses and manages the components on this tab.
Admin tab	This tab contains system-wide settings, such as user manager and communication services, and troubleshooting components, such as faults and events. The system administrator typically accesses and manages the components on this tab.

Toolbar

The toolbar displays on the right side of Cisco UCS Manager GUI above the **Work** pane. You can use the menu buttons in the toolbar to perform common actions, including the following actions:

- Navigate between previously viewed items in the **Work** pane
- Create elements for the Cisco UCS instance
- Set options for Cisco UCS Manager GUI
- Access online help for Cisco UCS Manager GUI

Work Pane

The **Work** pane displays on the right side of Cisco UCS Manager GUI. This pane displays details about the component selected in the **Navigation** pane.

The **Work** pane includes the following elements:

- A navigation bar that displays the path from the main node of the tab in the **Navigation** pane to the selected element. You can click any component in this path to display that component in the **Work** pane.
- A content area that displays tabs with information related to the component selected in the **Navigation** pane. The tabs displayed in the content area depends upon the selected component. You can use these tabs to view information about the component, create components, modify properties of the component, and examine a selected object.

Status Bar

The status bar displays across the bottom of Cisco UCS Manager GUI. The status bar provides information about the state of the application.

On the left, the status bar displays the following information about your current session in Cisco UCS Manager GUI:

- A lock icon that indicates the protocol you used to log in. If the icon is locked, you connected with HTTPS and if the icon is unlocked, you connected with HTTP.
- The username you used to log in.
- The IP address of the server where you logged in.

On the right, the status bar displays the system time.

Table Customization

Cisco UCS Manager GUI enables you to customize the tables on each tab. You can change the type of content that you view and filter the content.

Table Customization Menu Button

This menu button in the upper right of every table enables you to control and customize your view of the table. The drop-down menu for this button includes the following options:

Menu Item	Description
<i>Column Name</i>	The menu contains an entry for each column in the table. Click a column name to display or hide the column.
Horizontal Scroll	If selected, adds a horizontal scroll bar to the table. If not selected, when you widen one of the columns, all columns to the right narrow and do not scroll.
Pack All Columns	Resizes all columns to their default width.
Pack Selected Column	Resizes only the selected column to its default width.

Table Content Filtering

The **Filter** button above each table enables you to filter the content in the table according to the criteria that you set in the **Filter** dialog box. The dialog box includes the following filtering options:

Name	Description
Disable option	No filtering criteria is used on the content of the column. This is the default setting.
Equal option	Displays only that content in the column which exactly matches the value specified.
Not Equal option	Displays only that content in the column which does not exactly match the value specified.
Wildcard option	The criteria you enter can include one of the following wildcards: <ul style="list-style-type: none"> • <code>_</code> (underscore) or <code>?</code> (question mark)—replaces a single character

Name	Description
	<ul style="list-style-type: none"> • % (percent sign) or * (asterisk)—replaces any sequence of characters
Less Than option	Displays only that content in the column which is less than the value specified.
Less Than Or Equal option	Displays only that content in the column which is less than or equal to the value specified.
Greater Than option	Displays only that content in the column which is greater than the value specified.
Greater Than Or Equal option	Displays only that content in the column which is greater than or equal to the value specified.

LAN Uplinks Manager

The LAN Uplinks Manager provides a single interface where you can configure the connections between Cisco UCS and the LAN. You can use the LAN Uplinks Manager to create and configure the following:

- Ethernet switching mode
- Uplink Ethernet ports
- Port channels
- LAN pin groups
- Named VLANs
- Server ports
- QoS system classes

Some of the configuration that you can do in the LAN Uplinks Manager can also be done in nodes on other tabs, such as the **Equipment** tab or the **LAN** tab.

Internal Fabric Manager

The Internal Fabric Manager provides a single interface where you can configure server ports for a fabric interconnect in a Cisco UCS instance. The Internal Fabric Manager is accessible from the **General** tab for that fabric interconnect.

Some of the configuration that you can do in the Internal Fabric Manager can also be done in nodes on the **Equipment** tab, on the **LAN** tab, or in the LAN Uplinks Manager.

Hybrid Display

For each chassis in a Cisco UCS instance, Cisco UCS Manager GUI provides a hybrid display that includes both physical components and connections between the chassis and the fabric interconnects.

This tab displays detailed information about the connections between the selected chassis and the fabric interconnects. It has an icon for the following:

- Each fabric interconnect in the system
- The I/O module (IOM) in the selected chassis, which is shown as an independent unit to make the connection paths easier to see
- The selected chassis showing the servers and PSUs

The lines between the icons represent the connections between the following:

- DCE interface on each server and the associated server port on the IOM. These connections are created by Cisco and cannot be changed.
- Server port on the IOM and the associated port on the fabric interconnect. You can change these connections if desired.

You can mouse over the icons and lines to view tooltips identifying each component or connection, and you can double-click any component to view properties for that component.

If there is a fault associated with the component or any of its subcomponents, Cisco UCS Manager GUI displays a fault icon on top of the appropriate component. If there are multiple fault messages, Cisco UCS Manager GUI displays the icon associated with the most serious fault message in the system.

Logging in to Cisco UCS Manager GUI through HTTPS

Procedure

Step 1 In your web browser, type or select the web link for Cisco UCS Manager GUI.

Example:

The default web link is `http://UCSManager_IP` or `https://UCSManager_IP`. In a standalone configuration, `CalManager_IP` is the IP address for the management port on the fabric interconnect. In a cluster configuration, `UCSManager_IP` is the IP address assigned to Cisco UCS Manager.

Step 2 If a **Security Alert** dialog box appears, click **Yes** to accept the security certificate and continue.

Step 3 On the Cisco UCS Manager page, click **Launch**.

Depending upon the web browser you use to log in, you may be prompted to download or save the .JNLP file.

Step 4 If a **Security** dialog box displays, do the following:

- a) (Optional) Check the check box to accept all content from Cisco.
- b) Click **Yes** to accept the certificate and continue.

Step 5 In the **Login** dialog box, enter your username and password.

Step 6 Click **Login**.

Logging in to Cisco UCS Manager GUI through HTTP

Procedure

Step 1 In your web browser, type or select the web link for Cisco UCS Manager GUI.

Example:

The default web link is `http://UCSManager_IP` or `https://UCSManager_IP`. In a standalone configuration, `CalManager_IP` is the IP address for the management port on the fabric interconnect. In a cluster configuration, `UCSManager_IP` is the IP address assigned to Cisco UCS Manager.

Step 2 In the Cisco UCS Manager page, click **Launch**.

Depending upon the web browser you use to log in, you may be prompted to download or save the .JNLP file.

Step 3 In the **Login** dialog box, enter your username and password.

Step 4 Click **Login**.

Logging Off Cisco UCS Manager GUI

Procedure

Step 1 In Cisco UCS Manager GUI, click **Exit** in the upper right.

Cisco UCS Manager GUI blurs on your screen to indicate that you cannot use it and displays the **Exit** dialog box.

Step 2 From the drop-down list, select one of the following:

- **Exit** to log out and shut down Cisco UCS Manager GUI.
- **Log Off** to log out of Cisco UCS Manager GUI and log in a different user.

Step 3 Click **OK**.

Changing the Cisco UCS Manager GUI Properties

Procedure

Step 1 In the toolbar, click **Options** to open the **Properties** dialog box.

Step 2 (Optional) To specify if Cisco UCS Manager GUI will require confirmation for certain procedures, do the following:

- a) In the right pane, click **Confirmation Messages**.
- b) In the left pane, complete the following fields:

Name	Description
Confirm Deletion check box	If checked, Cisco UCS Manager GUI requires that you confirm all delete operations.
Confirm Discard Changes check box	If checked, Cisco UCS Manager GUI requires that you confirm before the system discards any changes.
Confirm Modification/Creation check box	If checked, Cisco UCS Manager GUI requires that you confirm before the system modifies or creates objects.
Confirm Successful Operations check box	If checked, Cisco UCS Manager GUI displays a confirmation when operations are successful.

Step 3 (Optional) To configure SSH external applications, do the following:

- a) In the right pane, click **External Applications**.
- b) In the left pane, complete the following fields:

Name	Description
SSH field	The application to use for SSH processing.
SSH Parameters field	Any parameters to include in all SSH commands.

Step 4 (Optional) To change the session properties, do the following:

- a) In the right pane, click **Session**.
- b) In the **Session** page, update one or more of the following fields:

Name	Description
Automatically Reconnect check box	If checked, the system tries to reconnect if communication between the GUI and the fabric interconnect is interrupted.
GUI Inactivity Time Out drop-down list	The number of minutes the system should wait before ending an inactive session. To specify that the session should not time out regardless of the length of inactivity, choose NEVER .
Reconnection Interval field	If the Automatically Reconnect check box is checked, this is the number of seconds the system waits before trying to reconnect.

Step 5 (Optional) To change the look of Cisco UCS Manager GUI, do the following:

- a) In the right pane, click **Visual Enhancements**.
- b) In the **Visual Enhancements** page, update one or more of the following fields:

Name	Description
Right Aligned Labels check box	If checked, all labels are right-aligned with respect to one another. Otherwise all labels are left-aligned.
Show Image while Dragging check box	If checked, when you drag an object from one place to another, the GUI displays a transparent version of that object until you drop the object in its new location.
Visual Theme drop-down list	<p>The color scheme used by the GUI. You can select:</p> <ul style="list-style-type: none"> • Modern—Pale blue-grey borders, dark blue-grey tab areas, and black text. This is the default theme. • Classic—Blue borders with light grey tabs and black text. This theme offers more contrast between the GUI elements. <p>Note If you change this option the system requires you to re-log into the GUI.</p>
Wizard Transition Effects check box	If checked, when you go to a new page in a wizard the first page fades out and the new page fades in. Otherwise the page changes without a visible transition.

Step 6 Click **OK**.



PART **II**

System Configuration

- [Configuring the Fabric Interconnects, page 41](#)
- [Configuring Ports, page 53](#)
- [Configuring Communication Services, page 63](#)
- [Configuring Primary Authentication, page 73](#)
- [Configuring Organizations, page 81](#)
- [Configuring Role-Based Access Control, page 85](#)
- [Firmware Management, page 97](#)
- [Configuring DNS Servers, page 115](#)



CHAPTER 4

Configuring the Fabric Interconnects

This chapter includes the following sections:

- [Initial System Setup, page 41](#)
- [Performing an Initial System Setup for a Standalone Configuration, page 43](#)
- [Initial System Setup for a Cluster Configuration, page 45](#)
- [Enabling a Standalone Fabric Interconnect for Cluster Configuration, page 48](#)
- [Ethernet Switching Mode, page 48](#)
- [Configuring the Ethernet Switching Mode, page 49](#)
- [Monitoring a Fabric Interconnect, page 50](#)
- [Changing Properties of a Fabric Interconnect, page 51](#)
- [Changing Access to a Fabric Interconnect, page 51](#)

Initial System Setup

The first time that you access a fabric interconnect in a Cisco UCS instance, a setup wizard prompts you for the following information required to configure the system:

- Installation method (GUI or CLI)
- Setup mode (restore from full system backup or initial setup)
- System configuration type (standalone or cluster configuration)
- System name
- Admin password
- Management port IP address and subnet mask
- Default gateway IP address
- DNS Server IP address
- Default domain name

Setup Mode

You can choose to either restore the system configuration from an existing backup file, or manually setup the system by going through the setup wizard. If you choose to restore the system, the backup file must be reachable from the management network.

System Configuration Type

You can configure a Cisco UCS instance to use a single fabric interconnect in a standalone configuration or to use a redundant pair of fabric interconnects in a cluster configuration.

A cluster configuration provides high availability. If one fabric interconnect becomes unavailable, the other takes over. Only one management port (Mgmt0) connection is required to support a cluster configuration; however, both Mgmt0 ports should be connected to provide link-level redundancy.

**Note**

The cluster configuration only provides redundancy for the management plane. Data redundancy is dependent on the user configuration and may require a third-party tool to support data redundancy.

To use the cluster configuration, the two fabric interconnects must be directly connected together using Ethernet cables between the L1 (L1-to-L1) and L2 (L2-to-L2) high availability ports, with no other fabric interconnects in between. This allows the two fabric interconnects to continuously monitor the status of each other and quickly know when one has failed.

Both fabric interconnects in a cluster configuration must go through the initial setup process. The first fabric interconnect to be setup must be enabled for a cluster configuration, then when the second fabric interconnect is setup, it detects the first fabric interconnect as a peer fabric interconnect in the cluster.

For more information, refer to the *Cisco UCS 6100 Series Fabric Interconnect Hardware Installation Guide*.

Management Port IP Address

In a standalone configuration, you must specify only one IP address and the subnet mask for the single management port on the fabric interconnect.

In a cluster configuration, you must specify the following three IP addresses in the same subnet:

- Management port IP address for fabric interconnect A
- Management port IP address for fabric interconnect B
- Cluster IP address

**Tip**

After the initial configuration, you can change the management IP port and the related subnet mask in the Cisco UCS Manager CLI. You cannot make this change in the Cisco UCS Manager GUI.

Performing an Initial System Setup for a Standalone Configuration

Before You Begin

- 1 Verify the following physical connections on the fabric interconnect:

- The console port is physically connected to a computer terminal or console server.
- The management Ethernet port (mgmt0) is connected to an external hub, switch, or router.

For more information, refer to the *Cisco UCS Hardware Installation Guide* for your fabric interconnect.

- 2 Verify that the console port parameters on the computer terminal (or console server) attached to the console port are as follows:

- 9600 baud
- 8 data bits
- No parity
- 1 stop bit

- 3 Collect the following information that you will need to supply during the initial setup:

- System name
- Password for the admin account
- Management port IP address and subnet mask
- Default gateway IP address
- DNS server IP address (optional)
- Domain name for the system (optional)

Procedure

Step 1 Connect to the console port.

Step 2 Power on the fabric interconnect.

You will see the power on self-test messages as the fabric interconnect boots.

Step 3 At the installation method prompt, enter gui.

Step 4 If the system cannot access a DHCP server, you are prompted to enter the following information:

- IP address for the management port on the fabric interconnect
- Subnet mask for the management port on the fabric interconnect

- IP address for the default gateway assigned to the fabric interconnect

Step 5 Copy the web link from the prompt into a supported web browser and go to the Cisco UCS Manager GUI launch page.

Step 6 On the Cisco UCS Manager GUI launch page, select **Express Setup**.

Step 7 On the **Springfield Express Setup** page, select **Initial Setup** and click **Submit**.

Step 8 In the **Cluster and Fabric Setup** Area, select the **Standalone Mode** option.

Step 9 In the **System Setup** Area, complete the following fields:

Field	Description
System Name field	The name assigned to the Cisco UCS instance In a standalone configuration, the system adds "-A" to the system name. In a cluster configuration, the system adds "-A" to the fabric interconnect assigned to fabric A, and "-B" to the fabric interconnect assigned to fabric B.
Admin Password field	The password used for the Admin account on the fabric interconnect.
Confirm Admin Password field	The password used for the Admin account on the fabric interconnect.
Mgmt IP Address field	The static IP address for the management port on the fabric interconnect.
Mgmt IP Netmask field	The subnet mask for the management port on the fabric interconnect.
Default Gateway field	The IP address for the default gateway assigned to the management port on the fabric interconnect.
DNS Server IP field	The IP address for the DNS server assigned to the fabric interconnect.
Domain Name field	The name of the domain in which the fabric interconnect resides.

Step 10 Click **Submit**.

A page displays the results of your setup operation.

Initial System Setup for a Cluster Configuration

Performing an Initial System Setup on the First fabric interconnect

Before You Begin

- 1 Verify the following physical connections on the fabric interconnect:
 - A console port on the first fabric interconnect is physically connected to a computer terminal or console server.
 - The management Ethernet port (mgmt0) is connected to an external hub, switch, or router.
 - The L1 ports on both fabric interconnects are directly connected to each other.
 - The L2 ports on both fabric interconnects are directly connected to each other.

For more information, refer to the *Cisco UCS Hardware Installation Guide* for your fabric interconnect.

- 2 Verify that the console port parameters on the computer terminal (or console server) attached to the console port are as follows:
 - 9600 baud
 - 8 data bits
 - No parity
 - 1 stop bit
- 3 Collect the following information that you will need to supply during the initial setup:
 - System name
 - Password for the admin account
 - Three static IP addresses: two for the management port on both fabric interconnects (one per fabric interconnect), and one for the cluster IP address used by Cisco UCS Manager
 - Subnet mask for the three static IP addresses
 - Default gateway IP address
 - DNS server IP address (optional)
 - Domain name for the system (optional)

Procedure

- Step 1** Connect to the console port.
- Step 2** Power on the fabric interconnect.

You will see the power on self-test messages as the fabric interconnect boots.

Step 3 At the installation method prompt, enter `gui`.

Step 4 If the system cannot access a DHCP server, you are prompted to enter the following information:

- IP address for the management port on the fabric interconnect
- Subnet mask for the management port on the fabric interconnect
- IP address for the default gateway assigned to the fabric interconnect

Step 5 Copy the web link from the prompt into a web browser and go to the Cisco UCS Manager GUI launch page.

Step 6 On the Cisco UCS Manager GUI launch page, select **Express Setup**.

Step 7 On the **Springfield Express Setup** page, select **Initial Setup** and click **Submit**.

Step 8 In the **Cluster and Fabric Setup** Area:

- a) Click the **Enable Clustering** option.
- b) For the **Fabric Setup** option, select **Fabric A**.
- c) In the **Cluster IP Address** field, enter the IP address that Cisco UCS Manager will use.

Step 9 In the **System Setup** Area, complete the following fields:

Field	Description
System Name field	The name assigned to the Cisco UCS instance In a standalone configuration, the system adds "-A" to the system name. In a cluster configuration, the system adds "-A" to the fabric interconnect assigned to fabric A, and "-B" to the fabric interconnect assigned to fabric B.
Admin Password field	The password used for the Admin account on the fabric interconnect.
Confirm Admin Password field	The password used for the Admin account on the fabric interconnect.
Mgmt IP Address field	The static IP address for the management port on the fabric interconnect.
Mgmt IP Netmask field	The subnet mask for the management port on the fabric interconnect.
Default Gateway field	The IP address for the default gateway assigned to the management port on the fabric interconnect.
DNS Server IP field	The IP address for the DNS server assigned to the fabric interconnect.
Domain Name field	The name of the domain in which the fabric interconnect resides.

Step 10 Click **Submit**.

A page displays the results of your setup operation.

Performing an Initial System Setup on the Second Fabric Interconnect

Before You Begin

You must ensure the following:

- A console port on the second fabric interconnect is physically connected to a computer terminal or console server.
- You know the password for the admin account on the first fabric interconnect that you configured.

Procedure

- Step 1** Connect to the console port.
- Step 2** Power on the fabric interconnect.
You will see the power on self-test messages as the fabric interconnect boots.
- Step 3** At the installation method prompt, enter `gui`.
- Step 4** If the system cannot access a DHCP server, you are prompted to enter the following information:
- IP address for the management port on the fabric interconnect
 - Subnet mask for the management port on the fabric interconnect
 - IP address for the default gateway assigned to the fabric interconnect
- Step 5** Copy the web link from the prompt into a web browser and go to the Cisco UCS Manager GUI launch page.
- Step 6** On the Cisco UCS Manager GUI launch page, select **Express Setup**.
- Step 7** On the **Springfield Express Setup** page, select **Initial Setup** and click **Submit**.
The fabric interconnect should detect the configuration information for the first fabric interconnect.
- Step 8** In the **Cluster and Fabric Setup** Area:
- a) Select the **Enable Clustering** option.
 - b) For the **Fabric Setup** option, make sure **Fabric B** is selected.
- Step 9** In the **System Setup** Area, enter the password for the Admin account into the **Admin Password of Master** field.
- Step 10** Click **Submit**.
A page displays the results of your setup operation.
-

Enabling a Standalone Fabric Interconnect for Cluster Configuration

You can add a second fabric interconnect to an existing Cisco UCS instance that uses a single standalone fabric interconnect. To do this, you must enable the standalone fabric interconnect for cluster operation, and then add the second fabric interconnect to the cluster.

Procedure

	Command or Action	Purpose
Step 1	UCS-A# connect local-mgmt	Enters local management mode.
Step 2	UCS-A(local-mgmt) # enable cluster ip-addr	Enables cluster operation on the standalone fabric interconnect with the specified IP address. When you enter this command, you are prompted to confirm that you want to enable cluster operation. Type yes to confirm.

The following example enables a standalone fabric interconnect with IP address 192.168.1.101 for cluster operation:

```
UCS-A# connect local-mgmt
UCS-A(local-mgmt)# enable cluster 192.168.1.101
This command will enable cluster mode on this setup. You cannot change it
back to stand-alone. Are you sure you want to continue? (yes/no): yes
UCS-A(local-mgmt)#
```

What to Do Next

Add the second fabric interconnect to the cluster.

Ethernet Switching Mode

The Ethernet switching mode determines how the fabric interconnect behaves as a switching device between the servers and the network. The fabric interconnect operates in either of the following Ethernet switching modes:

End-Host Mode

End-host mode allows the fabric interconnect to act as an end host to the network, representing all server (hosts) connected to it through vNICs. This is achieved by pinning (either dynamically pinned or hard pinned) vNICs to uplink ports, which provides redundancy toward the network, and makes the uplink ports appear as server ports to the rest of the fabric. When in end-host mode, the fabric interconnect does not run the Spanning Tree Protocol (STP) and avoids loops by denying uplink ports from forwarding traffic to each other, and by denying egress server traffic on more than one uplink port at a time. End-host mode is the default Ethernet switching mode and should be used if either of the following are used upstream:

- Layer 2 switching for L2 Aggregation
- Virtual Switching System (VSS) aggregation layer

**Note**

When end-host mode is enabled, if a vNIC is hard pinned to an uplink port and this uplink port goes down, the system cannot re-pin the vNIC, and the vNIC remains down.

Switch Mode

Switch mode is the traditional Ethernet switching mode. The fabric interconnect runs STP to avoid loops, and broadcast and multicast packets are handled in the traditional way. Switch mode is not the default Ethernet switching mode, and should be used only if the fabric interconnect is directly connected to a router, or if either of the following are used upstream:

- Layer 3 aggregation
- VLAN in a box

**Note**

For both Ethernet switching modes, even when vNICs are hard pinned to uplink ports, all server-to-server unicast traffic in the server array is sent only through the fabric interconnect and is never sent through uplink ports. Server-to-server multicast and broadcast traffic is sent through all uplink ports in the same VLAN.

Configuring the Ethernet Switching Mode

**Important**

When you change the Ethernet switching mode, Cisco UCS Manager logs you out and restarts the fabric interconnect. For a cluster configuration, Cisco UCS Manager restarts both fabric interconnects sequentially. The second fabric interconnect can take several minutes to complete the change in Ethernet switching mode and become system ready.

Procedure

- Step 1** In the **Navigation** pane, click the **Equipment** tab.
- Step 2** On the **Equipment** tab, expand **Equipment** ► **Fabric Interconnects** ► *Fabric_Interconnect_Name*.
- Step 3** In the **Work** pane, click the **General** tab.
- Step 4** In the **Actions** area of the **General** tab, click one of the following links:
 - **Set Switching Mode**
 - **Set End-Host Mode**The link for the current Ethernet switching mode is dimmed.
- Step 5** In the dialog box, click **Yes**.
Cisco UCS Manager restarts the fabric interconnect, logs you out, and disconnects Cisco UCS Manager GUI.
- Step 6** Launch Cisco UCS Manager GUI and log back in to continue configuring your system.

Monitoring a Fabric Interconnect

Procedure

- Step 1** In the **Navigation** pane, click the **Equipment** tab.
- Step 2** On the **Equipment** tab, expand **Equipment** ► **Fabric Interconnects**.
- Step 3** In the **Work** pane, click one of the following tabs to view the status of the fabric interconnect:

Option	Description
General tab	Provides an overview of the status of the fabric interconnect, including a summary of any faults, a summary of the fabric interconnect properties, and a physical display of the fabric interconnect and its components.
Physical Ports tab	Displays the status of all ports on the fabric interconnect. This tab includes the following sub-tabs: <ul style="list-style-type: none"> • Uplink Ports tab • Server Ports tab • Fibre Channel Ports tab • Unconfigured Ports tab
Fans tab	Displays the status of all fan modules in the fabric interconnect.
PSUs tab	Displays the status of all power supply units in the fabric interconnect.
Physical Display tab	Provides a graphical view of the fabric interconnect and all ports and other components. If a component has a fault, the fault icon is displays next to that component.
Faults tab	Provides details of faults generated by the fabric interconnect.
Events tab	Provides details of events generated by the fabric interconnect.
Statistics tab	Provides statistics about the fabric interconnect and its components. You can view these statistics in tabular or chart format.

Changing Properties of a Fabric Interconnect

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
- Step 2** On the **Admin** tab, click **All**.
- Step 3** In the **Work** pane, click the **General** tab.
- Step 4** In the **Actions** area, click **Change System Name/IP Address**.
- Step 5** In the **Properties for: UCS Manager** dialog box, change one or more of the following fields:

Name	Description
System Name field	The name assigned to this Cisco UCS system.
System IP Address field	The IP address assigned to the Cisco UCS Manager GUI.
HA Configuration field	How this system is configured for high availability. This can be: <ul style="list-style-type: none"> • cluster • stand-alone

- Step 6** Click **OK**.
- Step 7** Log out of Cisco UCS Manager GUI and log back in again to see your changes.

Changing Access to a Fabric Interconnect

In-band access cannot be changed from Cisco UCS Manager GUI.

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
- Step 2** On the **Admin** tab, click **All**.
- Step 3** In the **Work** pane, click the **General** tab.
- Step 4** In the **Actions** area, click **Change Fabric_Interconnect_Name Access**.
- Step 5** In the **Properties for: Fabric_Interconnect_Name** dialog box, click the **Communication Services** tab.
- Step 6** Change one or more of the following fields:

Name	Description
IP Address field	The IP address to use when communicating with the fabric interconnect.
Subnet Mask field	The associated subnet mask.

Name	Description
Default Gateway field	The associated gateway.

Step 7 Click OK.



CHAPTER 5

Configuring Ports

This chapter includes the following sections:

- [Server and Uplink Ports on the Fabric Interconnect, page 53](#)
- [Configuring Server Ports, page 54](#)
- [Configuring Uplink Ethernet Ports, page 54](#)
- [Reconfiguring a Port on a Fabric Interconnect, page 55](#)
- [Enabling a Port on a Fabric Interconnect, page 55](#)
- [Disabling a Port on a Fabric Interconnect, page 56](#)
- [Unconfiguring a Port on a Fabric Interconnect, page 56](#)
- [Configuring Uplink Ethernet Port Channels, page 57](#)
- [Configuring Server Ports with the Internal Fabric Manager, page 59](#)

Server and Uplink Ports on the Fabric Interconnect

Each fabric interconnect has a set of ports in a fixed port module that you can configure as either server ports or uplink Ethernet ports. These ports are not reserved. They cannot be used by a Cisco UCS instance until you configure them. You can add expansion modules to increase the number of uplink ports on the fabric interconnect, or to add uplink Fibre Channel ports to the fabric interconnect.

You need to create LAN pin groups and SAN pin groups to pin traffic from servers to an uplink port.

Each fabric interconnect can include the following types of ports:

- | | |
|------------------------------|--|
| Server Ports | Server ports handle data traffic between the fabric interconnect and the adapter cards on the servers.

You can only configure server ports on the fixed port module. Expansion modules do not include server ports. |
| Uplink Ethernet Ports | Uplink Ethernet ports handle Ethernet traffic between the fabric interconnect and the next layer of the network. All network-bound Ethernet traffic is pinned to one of these ports. |

You can configure uplink Ethernet ports on either the fixed module or an expansion module.

Uplink Fibre Channel Ports Uplink Fibre Channel ports handle FCoE traffic between the fabric interconnect and the next layer of the network. All network-bound FCoE traffic is pinned to one of these ports.

You can only configure uplink Fibre Channel ports on an expansion module. The fixed module does not include uplink Fibre Channel ports.

Configuring Server Ports

You can only configure server ports on the fixed port module. Expansion modules do not include server ports. This task describes only one method of configuring ports. You can also configure ports from a right-click menu, from the **General** tab for the port, or in the LAN Uplinks Manager.

Procedure

-
- Step 1** In the **Navigation** pane, click the **Equipment** tab.
 - Step 2** In the **Equipment** tab, expand **Fabric Interconnects** ► *Fabric Interconnect_Name* ► **Fixed Module** ► **Unconfigured Ports** .
 - Step 3** Click one or more ports under the **Unconfigured Ports** node.
 - Step 4** Drag the selected port or ports and drop them in the **Server Ports** node.
The port or ports are configured as server ports, removed from the list of unconfigured ports, and added to the **Server Ports** node.
-

Configuring Uplink Ethernet Ports

You can configure uplink Ethernet ports on either the fixed module or an expansion module.

This task describes only one method of configuring uplink Ethernet ports. You can also configure uplink Ethernet ports from a right-click menu or from the **General** tab for the port.

Procedure

-
- Step 1** In the **Navigation** pane, click the **Equipment** tab.
 - Step 2** On the **Equipment** tab, expand **Equipment** ► **Fabric Interconnects** ► *Fabric_Interconnect_Name*.
 - Step 3** Depending upon the location of the ports you want to configure, expand one of the following:
 - **Fixed Module**

- **Expansion Module**

Step 4 Click one or more of the ports under the **Unconfigured Ports** node.

Step 5 Drag the selected port or ports and drop them in the **Uplink Ethernet Ports** node.
The port or ports are configured as uplink Ethernet ports, removed from the list of unconfigured ports, and added to the **Uplink Ethernet Ports** node.

Reconfiguring a Port on a Fabric Interconnect

Procedure

Step 1 In the **Navigation** pane, click the **Equipment** tab.

Step 2 On the **Equipment** tab, expand **Equipment** ► **Fabric Interconnects** ► *Fabric_Interconnect_Name*.

Step 3 Depending upon the location of the ports you want to reconfigure, expand one of the following:

- **Fixed Module**
- **Expansion Module**

Step 4 Click the port or ports you want to reconfigure.

Step 5 Drag the selected port or ports and drop them in the appropriate node.
The port or ports are reconfigured as the appropriate type of port, removed from the original node, and added to the new node.

Example: Reconfiguring an Uplink Ethernet Port as a Server Port

- 1 Expand the **Uplink Ethernet Ports** node and select the port you want to reconfigure.
- 2 Drag the port and drop it into the **Server Ports** node.

Enabling a Port on a Fabric Interconnect

Procedure

Step 1 In the **Navigation** pane, click the **LAN** tab.

Step 2 On the **LAN** tab, expand **LAN** ► **LAN Cloud**.

Step 3 Expand *Fabric_Interconnect_Name* ► **Ports**.

Step 4 Right-click the port that you want to enable and choose **Enable Port**.

Step 5 If Cisco UCS Manager displays a confirmation dialog box, click **Yes**.

Disabling a Port on a Fabric Interconnect

Procedure

- Step 1** In the **Navigation** pane, click the **LAN** tab.
- Step 2** On the **LAN** tab, expand **LAN > LAN Cloud**.
- Step 3** Expand *Fabric_Interconnect_Name* > **Ports**.
- Step 4** Right-click the port that you want to disable and choose **Disable Port**.
- Step 5** If Cisco UCS Manager displays a confirmation dialog box, click **Yes**.
-

Unconfiguring a Port on a Fabric Interconnect

Procedure

- Step 1** In the **Navigation** pane, click the **Equipment** tab.
- Step 2** On the **Equipment** tab, expand **Equipment > Fabric Interconnects > Fabric_Interconnect_Name**.
- Step 3** Depending upon the location of the ports you want to unconfigure, expand one of the following:
- **Fixed Module**
 - **Expansion Module**
- Step 4** Click the port or ports you want to unconfigure.
- Step 5** Drag the selected port or ports and drop them in the **Unconfigured Ports** node.
The port or ports are unconfigured, removed from the original node, and added to the new node.
-

Configuring Uplink Ethernet Port Channels

Creating an Uplink Ethernet Port Channel

Procedure

- Step 1** In the **Navigation** pane, click the **LAN** tab.
- Step 2** On the **LAN** tab, expand **LAN ► LAN Cloud**.
- Step 3** Expand the node for the fabric interconnect where you want to add the port channel.
- Step 4** Right-click the **Port Channels** node and choose **Add Ports**.
- Step 5** In the **Set Port Channel Name** page of the **Create Port Channel** wizard, do the following:
- Complete the following fields:

Name	Description
ID field	The identifier for the port channel.
Name field	A user-defined name for the port channel. This name can be between 1 and 16 alphanumeric characters. You cannot use spaces or any special characters, and you cannot change this name after the object has been saved.

- Click **Next**.

- Step 6** In the **Add Ports** page of the **Create Port Channel** wizard, do the following:
- In the **Ports** table, choose one or more ports to include the port channel.
 - Click the **>>** button to add the ports to the **Ports in the port channel** table. You can use the **<<** button to remove ports from the port channel.

Note Cisco UCS Manager warns you if you select a port that has been configured as a server port. You can click **Yes** in the dialog box to reconfigure that port as an uplink Ethernet port and include it in the port channel.

- Step 7** Click **Finish**.

Enabling an Uplink Ethernet Port Channel

Procedure

- Step 1** In the **Navigation** pane, click the **LAN** tab.
 - Step 2** On the **LAN** tab, expand **LAN ► LAN Cloud**.
 - Step 3** Expand the node for the fabric interconnect that includes the port channel you want to enable.
 - Step 4** Expand the **Port Channels** node.
 - Step 5** Right-click the port channel you want to enable and choose **Enable Port Channel**.
-

Disabling an Uplink Ethernet Port Channel

Procedure

- Step 1** In the **Navigation** pane, click the **LAN** tab.
 - Step 2** On the **LAN** tab, expand **LAN ► LAN Cloud**.
 - Step 3** Expand the node for the fabric interconnect that includes the port channel you want to disable.
 - Step 4** Expand the **Port Channels** node.
 - Step 5** Right-click the port channel you want to disable and choose **Enable Port Channel**.
-

Adding Ports to an Uplink Ethernet Port Channel

Procedure

- Step 1** In the **Navigation** pane, click the **LAN** tab.
 - Step 2** On the **LAN** tab, expand **LAN ► LAN Cloud**.
 - Step 3** Expand the node for the fabric interconnect that includes the port channel to which you want to add ports.
 - Step 4** Right-click the port channel and choose **Add Ports**.
 - Step 5** In the **Add Ports** dialog box:
 - a) In the **Ports** table, chose one or more ports to include the port channel.
 - b) Click the **>>** button to add the ports to the **Ports in the port channel** table.
You can use the **<<** button to remove ports from the port channel.
 - c) Click **Finish**.
-

Removing Ports from an Uplink Ethernet Port Channel

Procedure

- Step 1** In the **Navigation** pane, click the **LAN** tab.
 - Step 2** On the **LAN** tab, expand **LAN ► LAN Cloud**.
 - Step 3** Expand **Fabric_Interconnect_Name ► Port Channels ► Port_Channel_ID**.
 - Step 4** Right-click the port you want to remove from the port channel and choose **Delete**.
 - Step 5** If Cisco UCS Manager displays a confirmation dialog box, click **Yes**.
-

Deleting an Uplink Ethernet Port Channel

Procedure

- Step 1** In the **Navigation** pane, click the **LAN** tab.
 - Step 2** On the **LAN** tab, expand **LAN ► LAN Cloud**.
 - Step 3** Expand the node for the fabric interconnect where you want to delete the port channel.
 - Step 4** Click the **Port Channels** node.
 - Step 5** In the **General** tab for the **Port Channels** node, choose the port channel you want to delete.
 - Step 6** Right-click the port channel and choose **Delete**.
-

Configuring Server Ports with the Internal Fabric Manager

Internal Fabric Manager

The Internal Fabric Manager provides a single interface where you can configure server ports for a fabric interconnect in a Cisco UCS instance. The Internal Fabric Manager is accessible from the **General** tab for that fabric interconnect.

Some of the configuration that you can do in the Internal Fabric Manager can also be done in nodes on the **Equipment** tab, on the **LAN** tab, or in the LAN Uplinks Manager.

Launching the Internal Fabric Manager

Procedure

- Step 1** In the **Navigation** pane, click the **Equipment** tab.
 - Step 2** On the **Equipment** tab, expand **Equipment** ► **Fabric Interconnects** ► *Fabric_Interconnect_Name*.
 - Step 3** Click **Fixed Module**.
 - Step 4** In the **Work** pane, click **Internal Fabric Manager** in the **Actions** area.
The Internal Fabric Manager opens in a separate window.
-

Configuring a Server Port with the Internal Fabric Manager

Procedure

- Step 1** In the Internal Fabric Manager, click the down arrows to expand the **Unconfigured Ports** area.
 - Step 2** Right-click the port that you want to configure and choose **Configure as Server Port**.
 - Step 3** If Cisco UCS Manager displays a confirmation dialog box, click **Yes**.
 - Step 4** If you have completed all tasks in the Internal Fabric Manager, click **OK**.
-

Unconfiguring a Server Port with the Internal Fabric Manager

Procedure

- Step 1** In the Internal Fabric Manager, click the server port in the **Server Ports** table.
 - Step 2** Click **Unconfigure Port**.
 - Step 3** If Cisco UCS Manager displays a confirmation dialog box, click **Yes**.
 - Step 4** If you have completed all tasks in the Internal Fabric Manager, click **OK**.
-

Enabling a Server Port with the Internal Fabric Manager

Procedure

- Step 1** In the Internal Fabric Manager, click the server port in the **Server Ports** table.
 - Step 2** Click **Enable Port**.
 - Step 3** If Cisco UCS Manager displays a confirmation dialog box, click **Yes**.
 - Step 4** If you have completed all tasks in the Internal Fabric Manager, click **OK**.
-

Disabling a Server Port with the Internal Fabric Manager

Procedure

- Step 1** In the Internal Fabric Manager, click the server port in the **Server Ports** table.
 - Step 2** Click **Disable Port**.
 - Step 3** If Cisco UCS Manager displays a confirmation dialog box, click **Yes**.
 - Step 4** If you have completed all tasks in the Internal Fabric Manager, click **OK**.
-



CHAPTER 6

Configuring Communication Services

This chapter includes the following sections:

- [Communication Services, page 63](#)
- [Configuring CIM-XML, page 64](#)
- [Configuring HTTP, page 65](#)
- [Configuring HTTPS, page 65](#)
- [Configuring SNMP, page 68](#)
- [Enabling Telnet, page 70](#)
- [Disabling Communication Services, page 70](#)

Communication Services

You can use the following communication services to interface third-party applications with Cisco UCS:

Communication Service	Description
CIM XML	This service is disabled by default and is only available in read-only mode. The default port is 5988. This common information model is one of the standards defined by the Distributed Management Task Force.
HTTP	This service is enabled on port 80 by default. You must enable either HTTP or HTTPS to run Cisco UCS Manager GUI. If you select HTTP, all data is exchanged in clear text mode. For security purposes, we recommend that you enable HTTPS and disable HTTP.
HTTPS	This service is enabled on port 443 by default. You must enable either HTTP or HTTPS to run Cisco UCS Manager GUI. If you select HTTPS, all data is exchanged in encrypted mode through a secure server.

Communication Service	Description
	For security purposes, we recommend that you enable HTTPS and disable HTTP.
SMASH CLP	This service is enabled for read-only access and supports a limited subset of the protocols, such as the show command. You cannot disable it. This shell service is one of the standards defined by the Distributed Management Task Force.
SNMP	This service is disabled by default. If enabled, the default port is 161. You must configure the community and at least one SNMP trap. Only enable this service if your system includes integration with an SNMP server.
SSH	This service is enabled on port 22. You cannot disable it, nor can you change the default port. This service provides access to the Cisco UCS Manager CLI.
Telnet	This service is disabled by default. This service provides access to the Cisco UCS Manager CLI.

Configuring CIM-XML

Procedure

-
- Step 1** In the **Navigation** pane, click the **Admin** tab.
 - Step 2** In the **Admin** tab, expand **All > Communication Services**.
 - Step 3** Select the **Communication Services** tab.
 - Step 4** In the **CIM-XML** area, click the **enabled** radio button.
The **CIM-XML** area expands to display the available configuration options.
 - Step 5** (Optional) In the **Port** field, change the default port that Cisco UCS Manager GUI will use for CIM-XML.
The default port is 5988.
 - Step 6** Click **Save Changes**.
-

Configuring HTTP

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
 - Step 2** In the **Admin** tab, expand **All ► Communication Services**.
 - Step 3** Select the **Communication Services** tab.
 - Step 4** In the **HTTP** area, click the **enabled** radio button.
The **HTTP** area expands to display the available configuration options.
 - Step 5** (Optional) In the **Port** field, change the default port that Cisco UCS Manager GUI will use for HTTP.
The default port is 80.
 - Step 6** Click **Save Changes**.
-

Configuring HTTPS

Creating a Key Ring

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
 - Step 2** On the **Admin** tab, expand **All ► Key Management ► Root**.
 - Step 3** Right-click **Root** and choose **Create Key Ring**.
 - Step 4** In the **Create Key Ring** dialog box, do the following:
 - a) In the **Name** field, enter a unique name for the key ring.
 - b) In the **Modulus** field, select one of the following radio buttons:
 - **mod512**
 - **mod1024**
 - **mod1536**
 - **mod2048**
 - c) Click **OK**.
-

What to Do Next

Create a certificate request for this key ring.

Creating a Certificate Request for a Key Ring

Procedure

-
- Step 1** In the **Navigation** pane, click the **Admin** tab.
 - Step 2** On the **Admin** tab, expand **All ► Key Management ► Root**.
 - Step 3** Click the key ring for which you want to create a certificate request.
 - Step 4** In the **Work** pane, click the **General** tab.
 - Step 5** In the **General** tab, click **Create Certificate Request**.
 - Step 6** In the **Create Certificate Request** dialog box, complete the following fields:

Name	Description
Subject field	The fully qualified domain name of the fabric interconnect.
IP Address field	The virtual IP address of the fabric interconnect.
Request field	The text of the certificate request.

- Step 7** Click **OK**.
 - Step 8** Copy the text of the certificate request out of the **Request** field and save in a file.
 - Step 9** Send the file with the certificate request to the trust anchor or certificate authority.
-

What to Do Next

Create a trusted point and set the certificate chain for the certificate of trust received from the trust anchor.

Creating a Trusted Point

Procedure

-
- Step 1** In the **Navigation** pane, click the **Admin** tab.
 - Step 2** On the **Admin** tab, expand **All ► Key Management ► Root**.
 - Step 3** Right-click **Root** and choose **Create Trusted Point**.
 - Step 4** In the **Create Trusted Point** dialog box, complete the following fields:

Name	Description
Name field	The name of the trusted point.
Certificate Chain field	The certificate information for this trusted point.

- Step 5** Click **OK**.
-

What to Do Next

When you receive the certificate from the trust anchor or certificate authority, import it into the key ring.

Importing a Certificate into a Key Ring

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
 - Step 2** On the **Admin** tab, expand **All > Key Management > Root**.
 - Step 3** Click the key ring into which you want to import the certificate.
 - Step 4** In the **Work** pane, click the **General** tab.
 - Step 5** In the **Certificate** area, complete the following fields:
 - a) From the **Trusted Point** drop-down list, select the trusted point for the trust anchor that granted this certificate.
 - b) In the **Certificate** field, paste the text from the certificate you received from the trust anchor or certificate authority.
- Tip** If the fields in an area are not displayed, click the **Expand** icon to the right of the heading.
- Step 6** Click **Save Changes**.
-

What to Do Next

Configure your HTTPS service with the key ring.

Configuring HTTPS

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
 - Step 2** In the **Admin** tab, expand **All > Communication Services**.
 - Step 3** Select the **Communication Services** tab.
 - Step 4** In the **HTTPS** area, click the **enabled** radio button.
The **HTTPS** area expands to display the available configuration options.
 - Step 5** (Optional) In the **Port** field, change the default port that Cisco UCS Manager GUI will use for HTTPS.
The default port is 443.
 - Step 6** (Optional) In the **Key Ring** field, enter the name of the key ring you created for HTTPS.
Caution If you update the **Key Ring** field, all current HTTP and HTTPS sessions will be closed without warning after you click **Save Changes**.
 - Step 7** Click **Save Changes**.
 - Step 8** Click **OK**.
-

Deleting a Key Ring

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
 - Step 2** On the **Admin** tab, expand **All** ► **Key Management** ► **Root**.
 - Step 3** Right-click the key ring you want to delete and select **Delete**.
 - Step 4** If Cisco UCS Manager displays a confirmation dialog box, click **Yes**.
-

Deleting a Trusted Point

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
 - Step 2** On the **Admin** tab, expand **All** ► **Key Management** ► **Root**.
 - Step 3** Right-click the trusted point you want to delete and select **Delete**.
 - Step 4** If Cisco UCS Manager displays a confirmation dialog box, click **Yes**.
 - Step 5** Click **OK**.
-

Configuring SNMP

Enabling SNMP

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
- Step 2** In the **Admin** tab, expand **All** ► **Communication Services**.
- Step 3** Select the **Communication Services** tab.
- Step 4** In the **SNMP** area, click the **enabled** radio button.
The **SNMP** area expands to display the available configuration options. You cannot change the port on which Cisco UCS Manager communicates with the SNMP host.
- Step 5** In the **Community** field, enter the default community name that Cisco UCS Manager GUI should include with any trap messages it sends to the SNMP server.

The default community is public.

- Step 6** Click **Save Changes**.
-

Configuring Trap Hosts

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
- Step 2** In the **Admin** tab, expand **All ► Communication Services**.
- Step 3** Select the **Communication Services** tab.
- Step 4** In the **SNMP Traps** area, click +.
- Step 5** In the **Create SNMP Trap** dialog box, complete the following fields:

Name	Description
IP Address field	The IP address of the SNMP host to which the fabric interconnect should send the trap.
Community field	The community name the fabric interconnect includes when it sends the trap to the SNMP host. This must be the same community as you configured for the SNMP service. Enter an alphanumeric string between 1 and 32 characters.
Port field	The port on which the fabric interconnect communicates with the SNMP host. The default port is 162.

- Step 6** Click **OK**.
- Step 7** Click **Save Changes**.
-

Configuring SNMPv3 users

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
- Step 2** In the **Admin** tab, expand **All ► Communication Services**.
- Step 3** Select the **Communication Services** tab.
- Step 4** In the **SNMP Users** area, click +.
- Step 5** In the **Create SNMP User** dialog box, complete the following fields:

Name	Description
Name field	The username assigned to the SNMP user.
Auth Type field	The authorization type. This can be: <ul style="list-style-type: none"> • MD5 • SHA
Use AES-128 check box	If checked, this user uses AES-128 encryption.
Password field	The password for this user.
Confirm Password field	The password again for confirmation purposes.
Privacy Password field	The privacy password for this user.
Confirm Privacy Password field	The privacy password again for confirmation purposes.

Step 6 Click **OK**.

Step 7 Click **Save Changes**.

Enabling Telnet

Procedure

Step 1 In the **Navigation** pane, click the **Admin** tab.

Step 2 In the **Admin** tab, expand **All ► Communication Services**.

Step 3 Click the **Communication Services** tab.

Step 4 In the **Telnet** area, click the **enabled** radio button.

Step 5 Click **Save Changes**.

Disabling Communication Services



Note

We recommend that you disable all communication services that are not required to interface with other network applications.

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
 - Step 2** In the **Admin** tab, expand **All > Communication Services**.
 - Step 3** On the **Communication Services** tab, click the **disable** radio button for each service that you want to disable.
 - Step 4** Click **Save Changes**.
-



CHAPTER 7

Configuring Primary Authentication

This chapter includes the following sections:

- [Primary Authentication, page 73](#)
- [Remote Authentication Providers, page 73](#)
- [Creating a Remote Authentication Provider, page 74](#)
- [Deleting a Remote Authentication Provider, page 79](#)
- [Selecting a Primary Authentication Service, page 79](#)

Primary Authentication

Cisco UCS supports two methods to authenticate user logins:

- Local to Cisco UCS Manager
- Remote through one of the following protocols:
 - LDAP
 - RADIUS
 - TACACS+



Note

You can only use one authentication method. For example, if you select LDAP as your authentication provider, you cannot use local, RADIUS, or TACACS+ for authentication.

Remote Authentication Providers

If a system is configured for one of the supported remote authentication services, you must create a provider for that service to ensure that Cisco UCS Manager can communicate with it. In addition, you need to be aware of the following guidelines that impact user authorization:

User Accounts in Remote Authentication Services

You can create user accounts in Cisco UCS Manager or in the remote authentication server.

The temporary sessions for users who log in through remote authentication services can be viewed through Cisco UCS Manager GUI or Cisco UCS Manager CLI.

User Roles and Related Attributes in Remote Authentication Services

If you create user accounts in the remote authentication server, you must ensure that the accounts include the roles those users require for working in Cisco UCS Manager and that the names of those roles match the names used in Cisco UCS Manager. If an account does not have the required roles, the user is granted only read-only privileges.

The following table contains the name of the attribute that contains the value of the roles. Cisco UCS Manager checks for the value of this attribute when it queries the remote authentication service during login.



Note

You cannot use any other attribute in the remote authentication service for the Cisco UCS roles. You must create the attribute required for that specific remote authentication service.

Remote Authentication Protocol	Attribute Name
LDAP	CiscoAVPair
RADIUS	cisco-av-pair
TACACS+	cisco-av-pair

For LDAP, the following is the full definition for the CiscoAVPair OID:

```
CN=CiscoAVPair,CN=Schema,CN=Configuration,CN=X
objectClass: top
objectClass: attributeSchema
cn: CiscoAVPair
distinguishedName: CN=CiscoAVPair,CN=Schema,CN=Configuration,CN=X
instanceType: 0x4
uSNCreated: 26318654
attributeID: 1.3.6.1.4.1.9.287247.1
attributeSyntax: 2.5.5.12
isSingleValued: TRUE
showInAdvancedViewOnly: TRUE
adminDisplayName: CiscoAVPair
adminDescription: UCS User Authorization Field
oMSyntax: 64
LDAPDisplayName: CiscoAVPair
name: CiscoAVPair
objectCategory: CN=Attribute-Schema,CN=Schema,CN=Configuration,CN=X
```

Creating a Remote Authentication Provider

Creating an LDAP Provider

Before You Begin

Perform the following configuration in the LDAP server:

- Create a CiscoAVPair attribute with an attribute ID of 1.3.6.1.4.1.9.287247.1. You cannot use an existing LDAP attribute.
- For a cluster configuration, add the management port IP addresses for both fabric interconnects. This configuration ensures that remote users can continue to log in if the first fabric interconnect fails and the system fails over to the second fabric interconnect. All log-in requests are sourced from these IP addresses, not the virtual IP address used by Cisco UCS Manager.

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
- Step 2** In the Admin tab, expand **User Management > LDAP**.
- Step 3** Complete all fields in the **Properties** area, except for those in the **States** section:

Name	Description
Timeout field	<p>The length of time in seconds the system should spend trying to contact the LDAP database before it times out. The valid range is from 1 to 60 seconds. The default value is 5 seconds.</p> <p>This property is optional.</p>
Attribute field	<p>An LDAP attribute that contains the role and locale information for the user. This property is always a name-value pair. The system queries the user record for the value that matches this attribute name.</p> <p>You must create an attribute named CiscoAVPair in the remote authentication service with the following attribute ID: 1.3.6.1.4.1.9.287247.1</p> <p>The CiscoAVPair attribute stores the values of role and locales for the user.</p> <p>Note If you do not specify this property, user access is restricted to read-only.</p>
Base DN field	<p>The specific distinguished name in the LDAP hierarchy where the server should begin a search when it receives an authorization request. The maximum supported string length is 128 characters.</p> <p>This property is required.</p>
Filter field	<p>If specified, the LDAP search is restricted to those usernames that match the defined filter.</p> <p>This property is optional.</p>
States Section	
Current Task field	<p>This field shows the task that is executing on behalf of this component. For details, see the associated FSM tab.</p>

Name	Description
	Note If there is no current task, this field is not displayed.

Step 4 In the **Actions** area of the **General** tab, click **Create LDAP Provider**.

Step 5 In the **Create LDAP Provider** dialog box:

a) Complete the following fields with the information about the LDAP service you want to use:

Name	Description
Hostname (or IP Address) field	The hostname or IP address on which the LDAP provider resides.
Bind DN field	The distinguished name (DN) for the LDAP database superuser account. The maximum supported string length is 128 characters.
Port field	The port through which Cisco UCS communicates with the LDAP database.
Enable SSL check box	If checked, communications to the LDAP database require SSL encryption.
Key field	If Enable SSL is checked, the SSL encryption key for the database.
Confirm Key field	The SSL encryption key repeated for confirmation purposes.

b) Click **OK**.

Step 6 Click **Save Changes**.

What to Do Next

Select LDAP as the primary authentication service. For more information, see [Selecting a Primary Authentication Service](#), page 79.

Creating a RADIUS Provider

Before You Begin

Perform the following configuration in the RADIUS server:

- Create the cisco-av-pairs attribute. You cannot use an existing RADIUS attribute.
- For a cluster configuration, add the management port IP addresses for both fabric interconnects. This configuration ensures that remote users can continue to log in if the first fabric interconnect fails and the system fails over to the second fabric interconnect. All log-in requests are sourced from these IP addresses, not the virtual IP address used by Cisco UCS Manager.

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
- Step 2** In the **Admin** tab, expand **User Management ► RADIUS** .
- Step 3** Complete the following fields in the **Properties** area:

Name	Description
Timeout field	The length of time in seconds the system should spend trying to contact the RADIUS database before it times out. Enter a value from 1 to 60 seconds. The default value is 5 seconds.
Retries field	The number of times to retry the connection before the request is considered to have failed.
States Section	
Current Task field	This field shows the task that is executing on behalf of this component. For details, see the associated FSM tab. Note If there is no current task, this field is not displayed.

- Step 4** In the **Actions** area of the **General** tab, click **Create RADIUS Provider**.
- Step 5** In the **Create RADIUS Provider** dialog box:
- a) Complete the fields with the information about the RADIUS service you want to use.

Name	Description
Hostname (or IP Address) field	The hostname or IP address on which the RADIUS provider resides.
Key field	The SSL encryption key for the database.
Confirm Key field	The SSL encryption key repeated for confirmation purposes.
Authorization Port field	The port through which Cisco UCS communicates with the RADIUS database.

- b) Click **OK**.

- Step 6** Click **Save Changes**.

What to Do Next

Select RADIUS as the primary authentication service. For more information, see [Selecting a Primary Authentication Service, page 79](#).

Creating a TACACS+ Provider

Before You Begin

Perform the following configuration in the TACACS+ server:

- Create the cisco-av-pairs attribute. You cannot use an existing TACACS+ attribute.
- For a cluster configuration, add the management port IP addresses for both fabric interconnects. This configuration ensures that remote users can continue to log in if the first fabric interconnect fails and the system fails over to the second fabric interconnect. All log-in requests are sourced from these IP addresses, not the virtual IP address used by Cisco UCS Manager.

Procedure

Step 1 In the **Navigation** pane, click the **Admin** tab.

Step 2 In the **Admin** tab, expand **User Management** ► **TACACS+** .

Step 3 Complete the following field in the **Properties** area:

Name	Description
Timeout field	The length of time in seconds the system should spend trying to contact the TACACS+ database before it times out. Enter a value from 1 to 60 seconds. The default is 5 seconds.

Step 4 In the **Actions** area of the **General** tab, click **Create TACACS Provider**.

Step 5 In the **Create TACACS+ Provider** dialog box:

a) Complete the fields with the information about the TACACS service you want to use.

Name	Description
Hostname (or IP Address) field	The hostname or IP address on which the TACAS provider resides.
Key field	The SSL encryption key for the database.
Confirm Key field	The SSL encryption key repeated for confirmation purposes.
Port field	The port through which the system should communicate with the TACACS+ database.

b) Click **OK**.

Step 6 Click **Save Changes**.

What to Do Next

Select TACACS as the primary authentication service. For more information, see [Selecting a Primary Authentication Service](#), page 79.

Deleting a Remote Authentication Provider

Deleting an LDAP Provider

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
 - Step 2** In the **Admin** tab, expand **User Management** ► **LDAP** .
 - Step 3** Right-click the LDAP provider you want to delete and choose **Delete**.
 - Step 4** If Cisco UCS Manager displays a confirmation dialog box, click **Yes**.
-

Deleting a RADIUS Provider

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
 - Step 2** In the **Admin** tab, expand **User Management** ► **RADIUS** .
 - Step 3** Right-click the RADIUS provider you want to delete and choose **Delete**.
 - Step 4** If Cisco UCS Manager displays a confirmation dialog box, click **Yes**.
-

Deleting a TACACS+ Provider

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
 - Step 2** In the **Admin** tab, expand **User Management** ► **TACACS+** .
 - Step 3** Right-click the TACACS+ provider you want to delete and choose **Delete**.
 - Step 4** If Cisco UCS Manager displays a confirmation dialog box, click **Yes**.
-

Selecting a Primary Authentication Service

Before You Begin

If the system uses a remote authentication service, create a provider for that authentication service. If you chose console, you do not need to create a provider first.

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
 - Step 2** In the **Admin** tab, expand **User Management** ► **Authorization** .
 - Step 3** On the **General** tab, click the radio button for the primary authentication method you want to use.
 - Step 4** Click **Save Changes**.
-



CHAPTER 8

Configuring Organizations

This chapter includes the following sections:

- [Organizations in a Multi-Tenancy Environment, page 81](#)
- [Hierarchical Name Resolution in a Multi-Tenancy Environment, page 82](#)
- [Creating an Organization under the Root Organization, page 83](#)
- [Creating an Organization under an Organization that is not Root, page 84](#)
- [Deleting an Organization, page 84](#)

Organizations in a Multi-Tenancy Environment

In Cisco UCS, you can use multi-tenancy to divide up the large physical infrastructure of an instance into logical entities known as organizations. As a result, you can achieve a logical isolation between organizations without providing a dedicated physical infrastructure for each organization.

You can assign unique resources to each tenant through the related organization, in the multi-tenant environment. These resources can include different policies, pools, and quality of service definitions. You can also implement locales to assign or restrict Cisco UCS user privileges and roles by organization, if you do not want all users to have access to all organizations.

If you set up a multi-tenant environment, all organizations are hierarchical. The top-level organization is always root. The policies and pools that you create in root are system-wide and are available to all organizations in the system. However, any policies and pools created in other organizations are only available to organizations that are above it in the same hierarchy. For example, if a system has organizations named Finance and HR that are not in the same hierarchy, Finance cannot use any policies in the HR organization, and HR cannot access any policies in the Finance organization. However, both Finance and HR can use policies and pools in the root organization.

If you create organizations in a multi-tenant environment, you can also set up one or more of the following for each organization or for a sub-organization in the same hierarchy:

- Resource pools
- Policies
- Service profiles

- Service profile templates

The root organization is always the top level organization.

Hierarchical Name Resolution in a Multi-Tenancy Environment

In a multi-tenant environment, Cisco UCS uses the hierarchy of an organization to resolve the names of policies and resource pools. When Cisco UCS Manager searches for details of a policy or a resource assigned to a pool, the following occurs:

- 1 Cisco UCS Manager checks for policies and pools with the specified name within the organization assigned to the service profile or policy.
- 2 If a policy is found or an available resource is inside a pool, Cisco UCS Manager uses that policy or resource. If the pool does not have any available resources at the local level, Cisco UCS Manager moves up in the hierarchy to the parent organization and searches for a pool with the same name. Cisco UCS Manager repeats this step until the search reaches the root organization.
- 3 If the search reaches the root organization and has not found an available resource or policy, Cisco UCS Manager returns to the local organization and begins to search for a default policy or available resource in the default pool.
- 4 If an applicable default policy or available resource in a default pool is found, Cisco UCS Manager uses that policy or resource. If the pool does not have any available resources, Cisco UCS Manager moves up in the hierarchy to the parent organization and searches for a default pool. Cisco UCS Manager repeats this step until the search reaches the root organization.
- 5 If Cisco UCS Manager cannot find an applicable policy or available resource in the hierarchy, it returns an allocation error.

Example: Server Pool Name Resolution in a Single-Level Hierarchy

In this example, all organizations are at the same level below the root organization. For example, a service provider creates separate organizations for each customer. In this configuration, organizations only have access to the policies and resource pools assigned to that organization and to the root organization.

In this example, a service profile in the XYZcustomer organization is configured to use servers from the XYZcustomer server pool. When resource pools and policies are assigned to the service profile, the following occurs:

- 1 Cisco UCS Manager checks for an available server in the XYZcustomer server pool.
- 2 If the XYZcustomer server pool has an available server, Cisco UCS Manager associates that server with the service profile and discontinues the search. If the pool does not have an available server, Cisco UCS Manager checks the root organization for a server pool with the same name.
- 3 If the root organization includes an XYZcustomer server pool and that pool has an available server, Cisco UCS Manager associates that server with the service profile and discontinues the search. If the pool does not have an available server, Cisco UCS Manager returns to the XYZcustomer organization to check the default server pool.
- 4 If the default pool in the XYZcustomer organization has an available server, Cisco UCS Manager associates that server with the service profile and discontinues the search. If the default pool does not have an available server, Cisco UCS Manager checks the default server pool in the root organization.

- 5 If the default server pool in the root organization has an available server, Cisco UCS Manager associates that server with the service profile and discontinues the search. If the default pool does not have an available server, Cisco UCS Manager returns an allocation error.

Example: Server Pool Name Resolution in a Multi-Level Hierarchy

In this example, each organization includes at least one suborganization. For example, a company could create organizations for each major division in the company and for subdivisions of those divisions. In this configuration, each organization has access to its local policies and resource pools and to the resource pools in the parent hierarchy.

In this example, the Finance organization includes two sub-organizations, AccountsPayable and AccountsReceivable. A service profile in the AccountsPayable organization is configured to use servers from the AP server pool. When resource pools and policies are assigned to the service profile, the following occurs:

- 1 Cisco UCS Manager checks for an available server in the AP server pool defined in the service profile.
- 2 If the AP server pool has an available server, Cisco UCS Manager associates that server with the service profile and discontinues the search. If the pool does not have an available server, Cisco UCS Manager moves one level up the hierarchy and checks the Finance organization for a pool with the same name.
- 3 If the Finance organization includes a pool with the same name and that pool has an available server, Cisco UCS Manager associates that server with the service profile and discontinues the search. If the pool does not have an available server, Cisco UCS Manager moves one level up in the hierarchy and checks the root organization for a pool with the same name.
- 4 If the root organization includes a pool with the same name and that pool has an available server, Cisco UCS Manager associates that server with the service profile and discontinues the search. If the pool does not have an available server, Cisco UCS Manager returns to the AccountsPayable organization to check the default server pool.
- 5 If the default pool in the AccountsPayable organization has an available server, Cisco UCS Manager associates that server with the service profile and discontinues the search. If the default pool does not have an available server, Cisco UCS Manager moves one level up in the hierarchy and checks the default server pool in the Finance organization.
- 6 If the default pool in the Finance organization has an available server, Cisco UCS Manager associates that server with the service profile and discontinues the search. If the default pool does not have an available server, Cisco UCS Manager moves one level up in the hierarchy and checks the default server pool in the root organization.
- 7 If the default server pool in the root organization has an available server, Cisco UCS Manager associates that server with the service profile and discontinues the search. If the default pool does not have an available server, Cisco UCS Manager returns an allocation error.

Creating an Organization under the Root Organization

Procedure

-
- Step 1** On the toolbar, choose **New ► Create Organization**.
 - Step 2** In the **Create Organization** dialog box, perform the following steps:
 - a) In the **Name** field, enter a unique name for the organization.

This name can be between 1 and 16 alphanumeric characters. You cannot use spaces or any special characters, and you cannot change this name after the object has been saved.

- b) Click **OK**.
-

Creating an Organization under an Organization that is not Root

Procedure

- Step 1** In the **Navigation** pane, click the **Servers** tab.
 - Step 2** In the **Servers** tab, navigate to the organization under which you want to create the organization.
 - Step 3** Right-click the organization under which you want to create the new organization and choose **Create Organization**.
 - Step 4** In the **Create Organization** dialog box, perform the following steps:
 - a) In the **Name** field, enter a unique name for the organization.
This name can be between 1 and 16 alphanumeric characters. You cannot use spaces or any special characters, and you cannot change this name after the object has been saved.
 - b) Click **OK**.
-

Deleting an Organization

Procedure

- Step 1** In the **Navigation** pane, click the **Servers** tab.
 - Step 2** Navigate to the organization that you want to delete.
 - Step 3** Right-click the organization and choose **Delete**.
 - Step 4** If Cisco UCS Manager displays a confirmation dialog box, click **Yes**.
-



CHAPTER 9

Configuring Role-Based Access Control

This chapter includes the following sections:

- [Role-Based Access Control, page 85](#)
- [User Accounts, page 85](#)
- [User Roles, page 86](#)
- [Privileges, page 87](#)
- [User Locales, page 89](#)
- [Configuring User Roles, page 89](#)
- [Configuring Locales, page 91](#)
- [Configuring User Accounts, page 93](#)
- [Monitoring User Sessions, page 95](#)

Role-Based Access Control

Role-Based Access Control (RBAC) is a method of restricting or authorizing system access for users based on user roles and locales. A role defines the privileges of a user in the system and the locale defines the organizations (domains) that a user is allowed access. Because users are not directly assigned privileges, management of individual user privileges is simply a matter of assigning the appropriate roles and locales.

A user is granted write access to desired system resources only if the assigned role grants the access privileges and the assigned locale allows access. For example, a user with the Server Administrator role in the Engineering organization could update server configurations in the Engineering organization, but would not be able to update server configurations in the Finance organization unless the locales assigned to the user include the Finance organization.

User Accounts

User accounts are used to access the system. Up to 48 user accounts can be configured in each Cisco UCS instance. Each user account must have a unique username and password.

The system has a default user account, admin, which cannot be modified or deleted. This account is the system administrator or superuser account and has full privileges. There is no default password assigned to the admin account; you must choose the password during the initial system setup.

The unique username for each user account cannot be all-numeric and cannot start with a number. If an all-numeric user name exists on an AAA server (RADIUS or TACACS+) and is entered during login, Cisco UCS Manager cannot log in the user. Local users with all-numeric names cannot be created.

For authentication purposes, a password is required for each user account. To prevent users from choosing insecure passwords, each password must meet the following requirements:

- At least eight characters long
- Does not contain more than three consecutive characters, such as abcd
- Does not contain more than two repeating characters, such as aaabbb
- Does not contain dictionary words
- Does not contain common proper names

A user account can also be set with a SSH public key. The public key can be set in one of the two formats: OpenSSH and SECSH.

User accounts can be configured to expire at a predefined time. When the expiration time is reached the user account is disabled. By default, user accounts do not expire.

User Roles

User roles contain one or more privileges that define the operations allowed for the user who is assigned the role. A user can be assigned one or more roles. A user assigned multiple roles has the combined privileges of all assigned roles. For example, if Role1 has storage related privileges, and Role2 has server related privileges, users who are assigned to both Role1 and Role2 have storage and server related privileges.

All roles include read access to all configuration settings in the Cisco UCS instance. The difference between the read-only role and other roles is that a user who is only assigned the read-only role cannot modify the system state. A user assigned another role can modify the system state in that user's assigned area or areas.

The system contains the following default user roles:

AAA Administrator	Read-and-write access to users, roles, and AAA configuration. Read access to the rest of the system.
Administrator	Complete read-and-write access to the entire system. The default admin account is assigned this role by default and it cannot be changed.
Network Administrator	Read-and-write access to fabric interconnect infrastructure and network security operations. Read access to the rest of the system.
Operations	Read-and-write access to systems logs, including the syslog servers, and faults. Read access to the rest of the system.
Read-Only	Read-only access to system configuration with no privileges to modify the system state.

Server Equipment Administrator	Read-and-write access to physical server related operations. Read access to the rest of the system.
Server Profile Administrator	Read-and-write access to logical server related operations. Read access to the rest of the system.
Server Security Administrator	Read-and-write access to server security related operations. Read access to the rest of the system.
Storage Administrator	Read-and-write access to storage operations. Read access to the rest of the system.

Roles can be created, modified to add new or remove existing privileges, or deleted. When a role is modified, the new privileges are applied to all users assigned to that role. Privilege assignment is not restricted to the privileges defined for the default roles. That is, you can use a custom set of privileges to create a unique role. For example, the default Server Administrator and Storage Administrator roles have different set of privileges, but a new Server and Storage Administrator role can be created that combines the privileges of both roles.

If a role is deleted after it has been assigned to users, it is also deleted from those user accounts.

User profiles on AAA servers (RADIUS or TACACS+) should be modified to add the roles corresponding to the privileges granted to that user. The cisco-av-pair vendor-specific attribute is used to store the role information. The AAA servers return this attribute with the request and parse it to get the roles. LDAP servers return the roles in the user profile attributes.

Privileges

Privileges give users assigned to user roles access to specific system resources and permission to perform specific tasks. The following table lists each privilege and the user role given that privilege by default.

Privilege	Description	Default Role Assignment
aaa	System security and AAA	AAA Administrator
admin	System administration	Administrator
ext-lan-config	External LAN configuration	Network Administrator
ext-lan-policy	External LAN policy	Network Administrator
ext-lan-qos	External LAN QoS	Network Administrator
ext-lan-security	External LAN security	Network Administrator
ext-san-config	External SAN configuration	Storage Administrator
ext-san-policy	External SAN policy	Storage Administrator
ext-san-qos	External SAN QoS	Storage Administrator
ext-san-security	External SAN security	Storage Administrator

Privilege	Description	Default Role Assignment
fault	Alarms and alarm policies	Operations
operations	Logs and Smart Call Home	Operations
pod-config	Pod configuration	Network Administrator
pod-policy	Pod policy	Network Administrator
pod-qos	Pod QoS	Network Administrator
pod-security	Pod security	Network Administrator
read-only	Read-only access Read-only cannot be selected as a privilege; it is assigned to every user role.	Read-Only
server-equipment	Server hardware management	Server Equipment Administrator
server-maintenance	Server maintenance	Server Equipment Administrator
server-policy	Server policy	Server Equipment Administrator
server-security	Server security	Server Security Administrator
service-profile-config	Service profile configuration	Server Profile Administrator
service-profile-config-policy	Service profile configuration policy	Server Profile Administrator
service-profile-ext-access	Service profile end point access	Server Profile Administrator
service-profile-network	Service profile network	Network Administrator
service-profile-network-policy	Service profile network policy	Network Administrator
service-profile-qos	Service profile QoS	Network Administrator
service-profile-qos-policy	Service profile QoS policy	Network Administrator
service-profile-security	Service profile security	Server Security Administrator
service-profile-security-policy	Service profile security policy	Server Security Administrator
service-profile-server	Service profile server management	Server Security Administrator
service-profile-server-policy	Service profile pool policy	Server Security Administrator
service-profile-storage	Service profile storage	Storage Administrator

Privilege	Description	Default Role Assignment
service-profile-storage-policy	Service profile storage policy	Storage Administrator

User Locales

A user can be assigned one or more locales. Each locale defines one or more organizations (domains) the user is allowed access, and access would be limited to the organizations specified in the locale. One exception to this rule is a locale without any organizations, which gives unrestricted access to system resources in all organizations.

Users with AAA Administrator privileges (AAA Administrator role) can assign organizations to the locale of other users. The assignment of organizations is restricted to only those in the locale of the user assigning the organizations. For example, if a locale contains only the Engineering organization then a user assigned that locale can only assign the Engineering organization to other users.

You can hierarchically manage organizations. A user that is assigned at a top level organization has automatic access to all organizations under it. For example, an Engineering organization can contain a Software Engineering organization and a Hardware Engineering organization. A locale containing only the Software Engineering organization has access to system resources only within that organization; however, a locale that contains the Engineering organization has access to the resources for both the Software Engineering and Hardware Engineering organizations.

Configuring User Roles

Creating a User Role

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
- Step 2** On the **Admin** tab, expand **All > User Management > User Services**.
- Step 3** Right-click **User Services** and choose **Create Role**.
- Step 4** In the **Create Role** dialog box, complete the following fields:

Name	Description
Name field	A user-defined name for this user role. This name can be between 1 and 16 alphanumeric characters. You cannot use spaces or any special characters, and you cannot change this name after the object has been saved.
Privileges list box	A list of the privileges defined in the system. Click a privilege to view a description of that privilege. Check the check box to assign that privilege to the selected user.
Help Section	

Name	Description
Description field	A description of the most recent privilege you clicked in the Privileges list box.

Step 5 Click **OK**.

Adding Privileges to a User Role

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
 - Step 2** On the **Admin** tab, expand **All ► User Management ► User Services**.
 - Step 3** Expand the **Roles** node.
 - Step 4** Choose the role to which you want to add privileges.
 - Step 5** In the **General** tab, check the boxes for the privileges you want to add to the role.
 - Step 6** Click **Save Changes**.
-

Removing Privileges from a User Role

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
 - Step 2** On the **Admin** tab, expand **All ► User Management ► User Services**.
 - Step 3** Expand the **Roles** node.
 - Step 4** Choose the role from which you want to remove privileges.
 - Step 5** In the **General** tab, uncheck the boxes for the privileges you want to remove from the role.
 - Step 6** Click **Save Changes**.
-

Deleting a User Role

When you delete a user role, Cisco UCS Manager removes that role from all user accounts to which the role has been assigned.

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
 - Step 2** On the **Admin** tab, expand **All > User Management > User Services**.
 - Step 3** Expand the **Roles** node.
 - Step 4** Right-click the role you want to delete and choose **Delete**.
 - Step 5** In the **Delete** dialog box, click **Yes**.
-

Configuring Locales

Creating a Locale

Before You Begin

One or more organizations must exist before you create a locale.

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
 - Step 2** On the **Admin** tab, expand **All > User Management > User Services**.
 - Step 3** Right-click on **Locales** and choose **Create a Locale**.
 - Step 4** In the **Create Locale** page, do the following:
 - a) In the **Name** field, enter a unique name for the locale.
This name can be between 1 and 16 alphanumeric characters. You cannot use spaces or any special characters, and you cannot change this name after the object has been saved.
 - b) Click **Next**.
 - Step 5** In the **Assign Organizations** page, do the following:
 - a) Expand the **Organizations** area to view the organizations in the Cisco UCS instance.
 - b) Click an organization that you want to assign to the locale.
 - c) Drag the organization from the **Organizations** area and drop it into the design area on the right.
 - d) Repeat Steps b and c until you have assigned all desired organizations to the locale.
 - Step 6** Click **Finish**.
-

What to Do Next

Add the locale to one or more user accounts.

Adding an Organization to a Locale

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
 - Step 2** On the **Admin** tab, expand **All > User Management > User Services**.
 - Step 3** Expand the **Locales** node and click the locale to which you want to add an organization.
 - Step 4** In the **Work** pane, click the **General** tab.
 - Step 5** In the **Organizations** area, click + on the table icon bar.
 - Step 6** In the **Assign Organizations** page, do the following:
 - a) Expand the **Organizations** area to view the organizations in the Cisco UCS instance.
 - b) Click an organization that you want to assign to the locale.
 - c) Drag the organization from the **Organizations** area and drop it into the design area on the right.
 - d) Repeat Steps b and c until you have assigned all desired organizations to the locale.
 - Step 7** Click **OK**.
-

Deleting an Organization from a Locale

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
 - Step 2** On the **Admin** tab, expand **All > User Management > User Services**.
 - Step 3** Expand the **Locales** node and click the locale from which you want to delete an organization.
 - Step 4** In the **Work** pane, click the **General** tab.
 - Step 5** In the **Organizations** area, right-click the organization that you want to delete from the locale and choose **Delete**.
 - Step 6** Click **Save Changes**.
-

Deleting a Locale

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
- Step 2** On the **Admin** tab, expand **All > User Management > User Services**.
- Step 3** Expand the **Locales** node.
- Step 4** Right-click the locale you want to delete and choose **Delete**.
- Step 5** If Cisco UCS Manager displays a confirmation dialog box, click **Yes**.

Configuring User Accounts

Creating a User Account

At a minimum, we recommend that you create the following users:

- Server administrator account
- Network administrator account
- Storage administrator

Before You Begin

If the system includes any of the following:

- Remote authentication services, ensure the users exist in the remote authentication server with the appropriate roles and privileges.
- Multi-tenancy with organizations, create one or more locales. If you do not have any locales, all users are created in root and are assigned roles and privileges in all organizations.
- SSH authentication, obtain the SSH key.

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
- Step 2** On the **Admin** tab, expand **All > User Management > User Services**.
- Step 3** Right-click **User Services** and choose **Create User** to open the **User Properties** dialog box.
- Step 4** Complete the following fields with the required information about the user:

Name	Description
Login ID field	<p>The account name that is used when logging into this account.</p> <p>The login ID can contain between 1 and 32 characters, including the following:</p> <ul style="list-style-type: none"> • Any alphabetic character • Any digit • _ (underscore) • - (dash) • @ <p>After you save the user, the login ID cannot be changed.</p> <p>Note You can create up to 48 user accounts in a Cisco UCS instance.</p>

Name	Description
First Name field	The first name of the user. This field can contain up to 32 characters.
Last Name field	The last name of the user. This field can contain up to 32 characters.
Email field	The email address for the user.
Phone field	The telephone number for the user.
Password field	The password associated with this account. The password must contain at least 8 characters and it must pass a basic strength check. A strong password contains a mix of the alphanumeric characters, including uppercase and lowercase letters. It can also contain special characters such as !, @, or #. Passwords cannot contain the characters \$ (dollar sign) or ? (question mark).
Confirm Password field	The password a second time for confirmation purposes.
Password Expires check box	If checked, this password expires and must be changed on a given date.
Expiration Date field	If Password Expires is checked, this field specifies the date on which the password expires. The date should be in the format yyyy-mm-dd. Click the down arrow at the end of this field to view a calendar that you can use to select the expiration date.

Step 5 In the **Roles** area, check one or more boxes to assign roles and privileges to the user account.

Step 6 (Optional) If the system includes organizations, check one or more boxes in the **Locales** area to assign the user to the appropriate locales.

Step 7 In the **SSH** area, complete the following fields:

a) In the **Type** field, do the following:

- **Password Required**—The user must enter a password when they log in.
- **Key**—SSH encryption is used when this user logs in.

b) If you chose **Key**, enter the SSH key in the **SSH data** field.

Step 8 Click **OK**.

Deleting a Locally Authenticated User Account

Procedure

-
- Step 1** In the **Navigation** pane, click the **Admin** tab.
 - Step 2** On the **Admin** tab, expand **All ► User Management ► User Services**.
 - Step 3** Expand the **Locally Authenticated Users** node.
 - Step 4** Right-click the user account you want to delete and choose **Delete**.
 - Step 5** In the **Delete** dialog box, click **Yes**.
-

Monitoring User Sessions

You can monitor Cisco UCS Manager sessions for both locally authenticated users and remotely authenticated users, whether they logged in through the CLI or the GUI.

Procedure

-
- Step 1** In the **Navigation** pane, click the **Admin** tab.
 - Step 2** In the **Admin** tab, expand **All ► User Management**.
 - Step 3** Click the **User Services** node.
 - Step 4** In the **Work** pane, click the **Sessions** tab.
The tab displays the following details of user sessions:

Name	Description
Name column	The name for the session.
User column	The username that is involved in the session.
Fabric ID column	The fabric interconnect that the user logged in to for the session.
Login Time column	The date and time the session started.
Terminal Type column	The kind of terminal the user is logged in through.
Host column	The IP address from which the user is logged in.



CHAPTER 10

Firmware Management

This chapter includes the following sections:

- [Overview of Firmware, page 97](#)
- [Image Management, page 97](#)
- [Firmware Updates, page 98](#)
- [Firmware Downgrades, page 103](#)
- [Downloading and Managing Images, page 104](#)
- [Directly Updating Firmware at Endpoints, page 106](#)
- [Updating Firmware through Service Profiles, page 111](#)
- [Verifying Firmware Versions on Components, page 114](#)

Overview of Firmware

Cisco UCS uses firmware obtained from and certified by Cisco to upgrade firmware on the following components:

- Servers, including the BIOS, storage controller, and server controller (BMC)
- Adapters, including NIC and HBA firmware, and Option ROM (where applicable)
- I/O modules
- Fabric interconnects
- Cisco UCS Manager

Cisco maintains a set of best practices for managing firmware images and updates in the following technical note: [Unified Computing System Firmware Management Best Practices](#).

Image Management

Cisco delivers all firmware updates or packages to Cisco UCS components in images. These images can be the following:

- Component image, which contains the firmware for one component
- Package, which is a collection of component images

Cisco also provides release notes with each image, which you can obtain from the same website from which you obtained the image.

Cisco UCS Manager provides mechanisms to download both component images and packages to the fabric interconnect.

Image Headers

Every image has a header, which includes the following:

- Checksum
- Version information
- Compatibility information that the system can use to verify the compatibility of component images and any dependencies

Image Catalog

Cisco UCS Manager provides you with two views of the catalog of firmware images and their contents that have been downloaded to the fabric interconnect:

Packages This view provides you with a read-only representation of the packages that have been downloaded onto the fabric interconnect. This view is sorted by image, not by the contents of the image. For packages, you can use this view to see which component images are (were) in each downloaded package.

Images The images view lists the component images available on the system. You cannot use this view to see packages. The information available about each component image includes the name of the component, the image size, the image version, and the vendor and model of the component.

You can use this view to identify the firmware updates available for each component. You can also use this view to delete obsolete and unneeded images. Cisco UCS Manager deletes a package after all images in the package have been deleted.



Tip

Cisco UCS Manager stores the images in bootflash on the fabric interconnect. In a cluster system, space usage in bootflash on both fabric interconnects is the same, because all images are synchronized between them. If Cisco UCS Manager reports that the bootflash is out of space, delete obsolete images to free up space.

Firmware Updates

You can use any of the Cisco UCS Manager interfaces to update firmware in the system, including Cisco UCS Manager GUI and the Cisco UCS Manager CLI.

You can use either of the following methods to update the firmware:

- Direct update at the endpoints.
- Updates to server components through service profiles that include a host firmware package policy and a management firmware package policy.

**Note**

Direct update is not available for some server components, such as BIOS and storage controller.

Firmware Versions

The firmware versions on a component depend upon the type of component.

Firmware Versions in BMC, I/O Modules, and Adapters

Each BMC, I/O module, and adapter has two slots for firmware in flash. Each slot holds a version of firmware. One slot is active and the other is the backup slot. A component boots from whichever slot is designated as active.

The following firmware version terminology is used in the GUI and CLI:

Running Version	The running version is the firmware that is active and in use by the component.
Startup Version	The startup version is the firmware that will be used when the component next boots up. Cisco UCS Manager provides the activate operation to change the startup version.
Backup Version	The backup version is the firmware that is sitting in the other slot and is not in use by the component. This can be firmware that you have updated to the component but have not yet activated, or it can be an older firmware version that was replaced by a recent activate. Cisco UCS Manager provides the update operation to replace the image in the backup slot.

If the component cannot boot from the startup version, the component boots from the backup version.

Firmware Versions in the Fabric Interconnect and Cisco UCS Manager

You can update the fabric interconnect firmware and Cisco UCS Manager on the fabric interconnect. The fabric interconnect and Cisco UCS Manager firmware do not have backup versions, because all the images are stored on the fabric interconnect. As a result, the number of bootable fabric interconnect images is not limited to two, like the server BMC and adapters. Instead, the number of bootable fabric interconnect images is limited by the available space in the flash memory.

**Note**

There are running and startup versions of the fabric interconnect and Cisco UCS Manager firmware, but there are no backup versions.

Direct Firmware Update at Endpoints

You can perform direct firmware updates on the following endpoints:

- Fabric interconnects

- Cisco UCS Manager
- I/O modules
- BMC
- Adapters

**Note**

You cannot update the BIOS firmware directly. You must perform the BIOS firmware update through a host firmware package in a service profile. If the BIOS fails, you can use Cisco UCS Manager to recover the BIOS.

Stages of a Direct Firmware Update

Cisco UCS Manager separates the direct update process into stages to ensure that you can push the firmware to a component while the system is running without affecting uptime on the server or other components. Because you do not need to reboot the server until after you activate, you can perform that task overnight or during other maintenance periods.

When you manually update firmware, the following stages occur:

Update

During this stage, the system pushes the selected firmware version to the component. The update process always overwrites the firmware in the backup slot on the component. The update stage applies only to I/O modules, BMCs, and adapters.

Activate

During this stage, the system sets the specified image version (normally the backup version) as active and reboots the endpoint. When the endpoint is rebooted, the backup slot becomes the active slot, and the active slot becomes the backup slot. The firmware in the new active slot becomes the startup version and the running version.

If the component cannot boot from the startup firmware, it defaults to the backup version and raises an alarm.

Recommended Order of Components for Firmware Activation

If you upgrade firmware by individual components in a Cisco UCS instance, we recommend that you activate the updates in the following order for quicker activation:

- 1 Adapter
- 2 BMC
- 3 I/O module
- 4 Fabric interconnect or Cisco UCS Manager

**Note**

Consider the following when activating the firmware:

- You can update all components in parallel.
 - While activating adapters and I/O modules, you can use the set-startup-only option to set the startup version and skip the reset.
 - Activating a fabric interconnect resets the fabric interconnect and all I/O modules connected to it.
-

Outage Impacts of Direct Firmware Updates

When you perform a direct firmware update on an endpoint, you can disrupt traffic or cause an outage in one or more of the components in the Cisco UCS instance.

Outage Impact of a Fabric Interconnect Firmware Update

When you update the firmware for a fabric interconnect, you cause the following outage impacts and disruptions:

- The fabric interconnect restarts.
- The corresponding I/O modules restart.

Outage Impact of a Cisco UCS Manager Firmware Update

A firmware update to Cisco UCS Manager disrupts Cisco UCS Manager GUI, but not Cisco UCS Manager CLI. The following disruptions occur in Cisco UCS Manager GUI during a firmware update:

- All users logged into Cisco UCS Manager GUI are logged out and their sessions ended.
- Any unsaved work in progress is lost.

Outage Impact of an I/O Module Firmware Update

When you update the firmware for an I/O module, you cause the following outage impacts and disruptions:

- I/O modules restart when the corresponding fabric interconnect is updated.
- An I/O module can take a few minutes to become available after a firmware update.

Outage Impact of a BMC Firmware Update

When you update the firmware for a BMC in a server, you impact only the BMC and internal processes. You do not interrupt server traffic. This firmware update causes the following outage impacts and disruptions to the BMC:

- Any activities being performed on the server through the KVM console and vMedia are interrupted.
- Any monitoring or IPMI polling is interrupted.

Outage Impact of an Adapter Firmware Update

When you activate the firmware for an adapter, you cause the following outage impacts and disruptions:

- The server resets.
- Server traffic is disrupted.

Firmware Updates through Service Profiles

You can use service profiles to update the server and adapter firmware, including the BIOS on the server, by defining the following policies and including them in the service profile associated with a server:

- Host Firmware Package policy
- Management Firmware Package policy



Note

You cannot update the firmware on an I/O module, fabric interconnect, or Cisco UCS Manager through service profiles. You must update the firmware on those components directly.

Host Firmware Pack

This policy enables you to specify a common set of firmware versions that make up the host firmware pack. The host firmware includes the following server and adapter components:

- BIOS
- SAS controller
- Emulex Option ROM (applicable only to Emulex-based Converged Network Adapters [CNAs])
- Emulex firmware (applicable only to Emulex-based CNAs)
- QLogic option ROM (applicable only to QLogic-based CNAs)
- Adapter firmware

The firmware pack is pushed to all servers associated with service profiles that include this policy.

This policy ensures that the host firmware is identical on all servers associated with service profiles which use the same policy. Therefore, if you move the service profile from one server to another, the firmware versions are maintained. Also, if you change the firmware version of the component in the firmware pack, new versions are applied to all the affected service profiles immediately, which could cause server reboots.

You must include this policy in a service profile, and that service profile must be associated with a server for it to take effect.

Prerequisites

This policy is not dependent upon any other policies. However, you must ensure that the appropriate firmware has been downloaded to the fabric interconnect. If the firmware image is not available when Cisco UCS Manager is associating a server with a service profile, Cisco UCS Manager ignores the firmware update and completes the association.

Management Firmware Pack

This policy enables you to specify a common set of firmware versions that make up the management firmware pack. The management firmware includes the server controller (BMC) on the server.

The firmware pack is pushed to all servers associated with service profiles that include this policy.

This policy ensures that the BMC firmware is identical on all servers associated with service profiles which use the same policy. Therefore, if you move the service profile from one server to another, the firmware versions are maintained.

You must include this policy in a service profile, and that service profile must be associated with a server for it to take effect.

Prerequisites

This policy is not dependent upon any other policies. However, you must ensure that the appropriate firmware has been downloaded to the fabric interconnect.

Stages of a Firmware Update through Service Profiles

If you use policies in service profiles to update server and adapter firmware, you must complete the following stages:

Firmware Package Policy Creation

During this stage, you create the host and/or management firmware packages and include them in the appropriate firmware policies.

Associate

During this stage, you include a firmware policy in a service profile, and then associate the service profile with a server. The system pushes the selected firmware versions to the endpoints and reboots to ensure that the endpoints are running the versions specified in the firmware pack.

When the firmware versions in the policies change, the system performs firmware updates (wherever necessary), activates, and reboots the endpoints.

**Caution**

As this type of update requires a reboot of the endpoints, it can be disruptive.

Firmware Downgrades

You downgrade firmware in a Cisco UCS instance in the same way that you upgrade firmware. The package or version that you select when you update the firmware determines whether you are performing an upgrade or a downgrade.

Downloading and Managing Images

Obtaining Images from Cisco

Procedure

- Step 1** In a web browser, navigate to the web link provided by Cisco to obtain firmware images for Cisco UCS.
 - Step 2** Choose one or more firmware images and copy them to a network server.
 - Step 3** Read the release notes provided with the image or images.
-

What to Do Next

Download the firmware image to the fabric interconnect.

Checking the Available Space on a Fabric Interconnect

You cannot download new firmware images if the bootflash on the fabric interconnect or fabric interconnects in the Cisco UCS does not have sufficient available space. In a cluster system, the available space is the same on both fabric interconnects because Cisco UCS mirrors the configuration on both fabric interconnects.

Procedure

- Step 1** In the **Navigation** pane, click the **Equipment** tab.
 - Step 2** On the **Equipment** tab, expand **Equipment** ► **Fabric Interconnects**.
 - Step 3** In the **Work** pane, click the **General** tab.
 - Step 4** Expand the **Local Storage Information** area.
If the bootflash area does not have sufficient available space, you can delete obsolete images through the **Firmware Management** tab on the **Equipment** node.
-

Downloading Images to the Fabric Interconnect



Note

In a cluster setup, the firmware image is automatically downloaded to both fabric interconnects, regardless of which fabric interconnect is used to initiate the download. Cisco UCS Manager always keeps the images in both fabric interconnects in sync. If one fabric interconnect is down while downloading, the download still finishes successfully. The images are synced to the other fabric interconnect when it comes back online.

Before You Begin

Obtain the firmware images from Cisco.

Procedure

- Step 1** In the **Navigation** pane, click the **Equipment** tab.
- Step 2** Click the **Equipment** node.
- Step 3** In the **Work** pane, click the **Firmware Management** tab.
- Step 4** Click the **Installed Firmware** tab.
- Step 5** Click **Download Firmware**.
- Step 6** In the **Download Firmware** dialog box, complete the following fields:

Name	Description
Protocol field	The protocol to use when communicating with the remote server. This can be: <ul style="list-style-type: none"> • FTP • SCP • SFTP • TFTP
Server field	The IP address or hostname of the remote server on which the files resides.
Filename field	The name of the firmware executable you want to download.
Remote Path field	The absolute path to the file on the remote server, if required. If you use SCP, the absolute path is always required. If you use any other protocol, you may not need to specify a remote path if the file resides in the default download folder. For details about how your file server is configured, contact your system administrator.
User field	The username the system should use to log in to the remote server. This field does not apply if the protocol is TFTP.
Password field	The password for the remote server username. This field does not apply if the protocol is TFTP.

Cisco UCS Manager GUI begins downloading the firmware bundle to the fabric interconnect.

- Step 7** Click **OK**.
- Step 8** (Optional) Monitor the status of the image download on the **Download Tasks** tab.
 - Note** If Cisco UCS Manager reports that the bootflash is out of space, delete obsolete images to free up space. To view the available space in bootflash, navigate to the fabric interconnect on the **Equipment** tab and expand the **Local Storage Information** area on the **General** tab.

What to Do Next

Update the firmware on the components.

Canceling an Image Download

You can cancel an image download only while it is in progress. After the image has downloaded, deleting the download task does not delete the image that was downloaded.

Procedure

- Step 1** In the **Navigation** pane, click the **Equipment** tab.
 - Step 2** Expand the **Equipment** node.
 - Step 3** In the **Work** pane, select the **Firmware Management** tab.
 - Step 4** On the **Download Tasks** tab, right-click the task you want to cancel and select **Delete**.
-

Directly Updating Firmware at Endpoints**Updating the Firmware on Multiple Components****Procedure**

- Step 1** In the **Navigation** pane, click the **Equipment** tab.
 - Step 2** In the **Equipment** tab, select the **Equipment Node**.
 - Step 3** In the **Work** pane, select the **Firmware Management** tab.
 - Step 4** In the **Installed Firmware** tab, select **Update Firmware**.
 - Step 5** In the **Update Firmware** dialog box:
 - a) For each component whose firmware you want to update, select the appropriate version from the drop-down list in the **Backup Version** column.
 - b) Click **OK**.

Cisco UCS Manager GUI copies the selected firmware package to the backup memory slot, where it remains until you explicitly activate it.
-

What to Do Next

Activate the firmware.

Activating the Firmware on Multiple Components

After you activate the firmware, you may need to reboot the server.

Procedure

- Step 1** In the **Navigation** pane, click the **Equipment** tab.
 - Step 2** In the **Equipment** tab, select the **Equipment Node**.
 - Step 3** In the **Work** pane, select the **Firmware Management** tab.
 - Step 4** In the **Installed Firmware** tab, select **Activate Firmware**.
 - Step 5** In the **Activate Firmware** dialog box:
 - a) For each component whose firmware you want to update, select the appropriate version from the drop-down list in the **Startup Version** column.
 - b) (Optional) If you want to activate the firmware regardless of any possible incompatibilities or currently executing tasks, check the **Ignore Compatibility Check** check box.
 - c) If you only want to set the start up version and not change the version running on the component, check the **Set Startup Version Only** check box.
 - d) Click **OK**.
-

Updating the Firmware on an Adapter

Procedure

- Step 1** In the **Navigation** pane, click the **Equipment** tab.
 - Step 2** On the **Equipment** tab, expand **Equipment** ► **Chassis** ► *Chassis Number* ► **Servers**.
 - Step 3** Expand the node for the server which includes the adapter you want to update.
 - Step 4** Expand **Interface Cards** and select the interface card for the adapter you want to upgrade.
 - Step 5** In the **General** tab, click **Update Firmware**.
 - Step 6** In the **Update Firmware** dialog box:
 - a) From the **Version** drop-down list, select the firmware version to which you want to update the BMC.
 - b) (Optional) If you want to update the firmware regardless of any possible incompatibilities or currently executing tasks, check the **Force** check box.
 - c) Click **OK**.

Cisco UCS Manager copies the selected firmware package to the backup memory slot, where it remains until you explicitly activate it.
 - Step 7** (Optional) Monitor the status of the update in the **Update Status** area.

The update process can take several minutes. Do not activate the firmware until the selected firmware package displays in the **Backup Version** field in the **Firmware** area of the **General** tab.
-

What to Do Next

Activate the firmware.

Activating the Firmware on an Adapter

Procedure

- Step 1** In the **Navigation** pane, click the **Equipment** tab.
- Step 2** On the **Equipment** tab, expand **Equipment** ► **Chassis** ► *Chassis Number* ► **Servers**.
- Step 3** Expand the node for the server that includes the adapter for which you want to activate the updated firmware.
- Step 4** Expand **Interface Cards** and select the interface card for the adapter.
- Step 5** In the **General** tab, click **Activate Firmware**.
- Step 6** In the **Activate Firmware** dialog box:
- Select the appropriate version from the **Version To Be Activated** drop-down list.
 - (Optional) If you want to activate the firmware regardless of any possible incompatibilities or currently executing tasks, check the **Ignore Compatibility Check** check box.
 - If you only want to set the start up version and not change the version running on the component, check the **Set Startup Version Only** check box.
 - Click **OK**.
-

Updating the Firmware on a BMC

Procedure

- Step 1** In the **Navigation** pane, click the **Equipment** tab.
- Step 2** On the **Equipment** tab, expand **Equipment** ► **Chassis** ► *Chassis Number* ► **Servers**.
- Step 3** Expand the node for the server for which you want to update the BMC.
- Step 4** In the **General** tab, click the **Inventory** tab.
- Step 5** Click the **BMC** tab.
- Step 6** In the **Actions** area, click **Update Firmware**.
- Step 7** In the **Update Firmware** dialog box:
- From the **Version** drop-down list, select the firmware version to which you want to update the BMC.
 - (Optional) If you want to update the firmware regardless of any possible incompatibilities or currently executing tasks, check the **Force** check box.
 - Click **OK**.
- Cisco UCS Manager copies the selected firmware package to the backup memory slot, where it remains until you explicitly activate it.
- Step 8** (Optional) Monitor the status of the update in the **Update Status** area. The update process can take several minutes. Do not activate the firmware until the selected firmware package displays in the **Backup Version** field in the **Firmware** area of the **General** tab.
-

What to Do Next

Activate the firmware.

Activating the Firmware on a BMC

Procedure

- Step 1** In the **Navigation** pane, click the **Equipment** tab.
 - Step 2** On the **Equipment** tab, expand **Equipment** ► **Chassis** ► *Chassis Number* ► **Servers**.
 - Step 3** Expand the node for the server that includes the BMC for which you want to activate the updated firmware.
 - Step 4** On the **General** tab, click the **Inventory** tab.
 - Step 5** Click the **BMC** tab.
 - Step 6** In the **Actions** area, click **Activate Firmware**.
 - Step 7** In the **Activate Firmware** dialog box:
 - a) Select the appropriate version from the **Version To Be Activated** drop-down list.
 - b) (Optional) If you want to activate the firmware regardless of any possible incompatibilities or currently executing tasks, check the **Ignore Compatibility Check** check box.
 - c) If you only want to set the start up version and not change the version running on the component, check the **Set Startup Version Only** check box.
 - d) Click **OK**.
-

Updating the Firmware on an IOM

Procedure

- Step 1** In the **Navigation** pane, click the **Equipment** tab.
 - Step 2** On the **Equipment** tab, expand **Equipment** ► **Chassis** ► *Chassis Number* ► **IO Modules**.
 - Step 3** Click the I/O module that you want to update.
 - Step 4** In the **General** tab, click **Update Firmware**.
 - Step 5** In the **Update Firmware** dialog box:
 - a) From the **Version** drop-down list, select the firmware version to which you want to update the BMC.
 - b) (Optional) If you want to update the firmware regardless of any possible incompatibilities or currently executing tasks, check the **Force** check box.
 - c) Click **OK**.

Cisco UCS Manager copies the selected firmware package to the backup memory slot, where it remains until you explicitly activate it.
 - Step 6** (Optional) Monitor the status of the update in the **Update Status** area.

The update process can take several minutes. Do not activate the firmware until the selected firmware package displays in the **Backup Version** field in the **Firmware** area of the **General** tab.
-

What to Do Next

Activate the firmware.

Activating the Firmware on an IOM**Procedure**

-
- Step 1** In the **Navigation** pane, click the **Equipment** tab.
- Step 2** On the **Equipment** tab, expand **Equipment** ► **Chassis** ► *Chassis Number* ► **IO Modules**.
- Step 3** Select the **IO Module** node that includes the I/O module for which you want to activate the updated firmware.
- Step 4** In the **General** tab, click **Activate Firmware**.
- Step 5** In the **Activate Firmware** dialog box:
- Select the appropriate version from the **Version To Be Activated** drop-down list.
 - (Optional) If you want to activate the firmware regardless of any possible incompatibilities or currently executing tasks, check the **Ignore Compatibility Check** check box.
 - If you only want to set the start up version and not change the version running on the component, check the **Set Startup Version Only** check box.
 - Click **OK**.
-

Updating and Activating the Firmware on a Fabric Interconnect**Procedure**

-
- Step 1** In the **Navigation** pane, click the **Equipment** tab.
- Step 2** In the **Equipment** tab, expand the **Equipment** node.
- Step 3** Expand the **Fabric Interconnects** node and click the fabric interconnect for which you want to update and activate the firmware.
- Step 4** On the **General** tab, click **Activate Firmware**.
- Step 5** In the **Activate Firmware** dialog box, complete the following fields:

Name	Description
Kernel Version drop-down list	Choose the version that you want to use for the kernel.
System Version drop-down list	Choose the version you want to use for the system.
Ignore Compatibility Check check box	By default, Cisco UCS makes sure that the firmware version is compatible with everything running on the server before it activates that version. Check this check box if you want Cisco UCS to activate the firmware without making sure that it is compatible first.

Name	Description
	Note We recommend that you use this option only when explicitly directed to do so by a technical support representative.

- Step 6** Click **OK**.
Cisco UCS Manager updates and activates the firmware, and then reboots the fabric interconnect.

Updating and Activating the Cisco UCS Manager Software

You can also update Cisco UCS Manager when you update and activate the fabric interconnect firmware.

Procedure

- Step 1** In the **Navigation** pane, click the **Equipment** tab.
- Step 2** Click the **Equipment** tab, expand the **Equipment** node.
- Step 3** Select the **Fabric Interconnects** node.
- Step 4** In the **Work** pane, click the **Installed Firmware** tab.
- Step 5** Click **Activate Firmware**.
- Step 6** On the **UCS Manager** row of the **Activate Firmware** dialog box:
- From the drop-down list in the **Startup Version** column, select the version to which you want to update the software.
 - (Optional) If you want to activate the firmware regardless of any possible incompatibilities or currently executing tasks, check the **Ignore Compatibility Check** check box.
 - Click **OK**.
- Cisco UCS Manager disconnects, and then updates and activates the software.

Updating Firmware through Service Profiles

Creating a Host Firmware Package

Before You Begin

Ensure that the appropriate firmware has been downloaded to the fabric interconnect.

Procedure

- Step 1** In the **Navigation** pane, click the **Servers** tab.
- Step 2** On the **Servers** tab, expand **Servers** ► **Policies**.
- Step 3** Expand the node for the organization where you want to create the policy.

If the system does not include multi-tenancy, expand the **root** node.

- Step 4** Right-click **Host Firmware Packages** and select **Create Package**.
- Step 5** In the **Create Host Firmware Package** dialog box, enter a unique name and description for the package. This name can be between 1 and 16 alphanumeric characters. You cannot use spaces or any special characters, and you cannot change this name after the object has been saved.
- Step 6** Click the down arrows to expand one or more of the following sections on the left of the dialog box:
- **Adapter Firmware Packages**
 - **Storage Controller Firmware Packages**
 - **Fibre Channel Adapters Firmware Packages**
 - **BIOS Firmware Packages**
 - **HBA Option ROM Packages**
- Step 7** In each section for the component to which you want to include firmware in the pack:
- a) Select the line in the table which lists the firmware version that you want to add to the pack.
 - b) Drag the line to the table on the right.
 - c) Click **Yes** to confirm that you selected the correct version.
- Step 8** When you have added all the desired firmware to the pack, click **OK**.

What to Do Next

Include the policy in a service profile and/or template.

Updating a Host Firmware Pack

If the policy is associated with a service profile, Cisco UCS Manager updates and activates the firmware in the server and adapter with the new versions and reboots the server.

Before You Begin

Ensure that the appropriate firmware has been downloaded to the fabric interconnect.

Procedure

- Step 1** In the **Navigation** pane, click the **Servers** tab.
- Step 2** On the **Servers** tab, expand **Servers** ► **Policies**.
- Step 3** Expand the node for the organization that includes the policy you want to update. If the system does not include multi-tenancy, expand the **root** node.
- Step 4** Expand **Host Firmware Packages** and select the policy you want to update.
- Step 5** In the table on the right, delete the existing entries for the firmware you want to update:
- a) Select the line in the table for the firmware version that you want to change.
 - b) Right-click and select **Delete**.

c) Click **Yes** to confirm that you want to delete that entry.

Step 6 On the **General** tab, click the down arrows to expand one or more of the following sections on the left:

- **Adapter Firmware Packages**
- **Storage Controller Firmware Packages**
- **Fibre Channel Adapters Firmware Packages**
- **BIOS Firmware Packages**
- **HBA Option ROM Packages**

Step 7 In each section for the component to which you want to include firmware in the pack:

- a) Select the line in the table for the firmware version that you want to add to the pack.
- b) Drag the line to the table on the right.
- c) Click **Yes** to confirm that you selected the correct version.

Step 8 Click **Save Changes**.

Creating a Management Firmware Package

Before You Begin

Ensure that the appropriate firmware has been downloaded to the fabric interconnect.

Procedure

Step 1 In the **Navigation** pane, click the **Servers** tab.

Step 2 On the **Servers** tab, expand **Servers ► Policies**.

Step 3 Expand the node for the organization where you want to create the policy.
If the system does not include multi-tenancy, expand the **root** node.

Step 4 Right-click **Management Firmware Packages** and select **Create Package**.

Step 5 In the **Create Management Firmware Package** dialog box, enter a unique name and description for the package.
This name can be between 1 and 16 alphanumeric characters. You cannot use spaces or any special characters, and you cannot change this name after the object has been saved.

Step 6 In the **BMC Firmware Packages** section on the left of the dialog box:

- a) Click the down arrows to expand the section.
- b) Select the line in the table which lists the firmware version that you want to add to the package.
- c) Drag the line to the table on the right.
- d) Click **Yes** to confirm that you selected the correct version.

Step 7 When you have added the desired firmware to the package, click **OK**.

What to Do Next

Include the policy in a service profile and/or template.

Updating a Management Firmware Pack

If the policy is associated with a service profile, Cisco UCS Manager updates and activates the firmware in the server and adapter with the new versions and reboots the server.

Before You Begin

Ensure that the appropriate firmware has been downloaded to the fabric interconnect.

Procedure

-
- Step 1** In the **Navigation** pane, click the **Servers** tab.
 - Step 2** On the **Servers** tab, expand **Servers ► Policies**.
 - Step 3** Expand the node for the organization that includes the policy you want to update.
If the system does not include multi-tenancy, expand the **root** node.
 - Step 4** Expand **Management Firmware Packages** and select the policy you want to update.
 - Step 5** In the table on the right, delete the existing entry for the firmware you want to update:
 - a) Select the line in the table for the firmware version that you want to change.
 - b) Right-click and select **Delete**.
 - c) Click **Yes** to confirm that you want to delete that entry.
 - Step 6** In the **BMC Firmware Packages** section on the left:
 - a) Click the down arrows to expand the section.
 - b) Select the line in the table which lists the firmware version that you want to add to the pack.
 - c) Drag the line to the table on the right.
 - d) Click **Yes** to confirm that you selected the correct version.
 - Step 7** Click **Save Changes**.
-

Verifying Firmware Versions on Components**Procedure**

-
- Step 1** In the **Navigation** pane, click the **Equipment** tab.
 - Step 2** On the **Equipment** tab, select the **Equipment Node**.
 - Step 3** In the **Work** pane, select the **Firmware Management** tab.
 - Step 4** On the **Installed Firmware** tab, review the firmware versions listed for each component.
-



CHAPTER 11

Configuring DNS Servers

This chapter includes the following sections:

- [DNS Servers in Cisco UCS, page 115](#)
- [Adding a DNS Server, page 115](#)
- [Deleting a DNS Server, page 116](#)

DNS Servers in Cisco UCS

You need to specify an external DNS server for each Cisco UCS instance to use if the system requires name resolution of host names. For example, you cannot use a name such as `www.cisco.com` on a fabric interconnect if you do not configure a DNS server.

Adding a DNS Server

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
 - Step 2** In the **Admin** tab, expand **All ► Communication Services**.
 - Step 3** Click **DNS Management**.
 - Step 4** In the **Work** pane, click the **General** tab.
 - Step 5** In the **DNS Server** area, click **+**.
 - Step 6** In the **Specify DNS Server** dialog box, enter the IP address of the DNS server.
 - Step 7** Click **OK**.
-

Deleting a DNS Server

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
 - Step 2** In the **Admin** tab, expand **All ► Communication Services**.
 - Step 3** Click **DNS Management**.
 - Step 4** In the **Work** pane, click the **General** tab.
 - Step 5** In the **DNS Server** area, right-click on the DNS server you want to delete and choose **Delete**.
 - Step 6** If Cisco UCS Manager displays a confirmation dialog box, click **Yes**.
 - Step 7** Click **Save Changes**.
-



PART **III**

Network Configuration

- [Using the LAN Uplinks Manager, page 119](#)
- [Configuring Named VLANs, page 131](#)
- [Configuring LAN Pin Groups, page 135](#)
- [Configuring MAC Pools, page 137](#)
- [Configuring Quality of Service, page 139](#)
- [Configuring Network-Related Policies, page 145](#)



CHAPTER 12

Using the LAN Uplinks Manager

This chapter includes the following sections:

- [LAN Uplinks Manager, page 119](#)
- [Launching the LAN Uplinks Manager, page 120](#)
- [Changing the Ethernet Switching Mode with the LAN Uplinks Manager, page 120](#)
- [Configuring a Port with the LAN Uplinks Manager, page 120](#)
- [Configuring Server Ports, page 121](#)
- [Configuring Uplink Ethernet Ports, page 122](#)
- [Configuring Uplink Ethernet Port Channels, page 123](#)
- [Configuring LAN Pin Groups, page 125](#)
- [Configuring Named VLANs, page 126](#)
- [Configuring QoS System Classes with the LAN Uplinks Manager, page 128](#)

LAN Uplinks Manager

The LAN Uplinks Manager provides a single interface where you can configure the connections between Cisco UCS and the LAN. You can use the LAN Uplinks Manager to create and configure the following:

- Ethernet switching mode
- Uplink Ethernet ports
- Port channels
- LAN pin groups
- Named VLANs
- Server ports
- QoS system classes

Some of the configuration that you can do in the LAN Uplinks Manager can also be done in nodes on other tabs, such as the **Equipment** tab or the **LAN** tab.

Launching the LAN Uplinks Manager

Procedure

-
- Step 1** In the **Navigation** pane, click the **LAN** tab.
 - Step 2** On the **LAN** tab, click the **LAN** node.
 - Step 3** In the **Work** pane, click the **LAN Uplinks Manager** link on the **LAN Uplinks** tab. The LAN Uplinks Manager opens in a separate window.
-

Changing the Ethernet Switching Mode with the LAN Uplinks Manager



Important

When you change the Ethernet switching mode, Cisco UCS Manager logs you out and restarts the fabric interconnect. For a cluster configuration, Cisco UCS Manager restarts both fabric interconnects sequentially. The second fabric interconnect can take several minutes to complete the change in Ethernet switching mode and become system ready.

Procedure

-
- Step 1** In the LAN Uplinks Manager, click the **LAN Uplinks** tab.
 - Step 2** In the **Uplink Mode** area, click one of the following buttons:
 - **Set Switching Mode**
 - **Set End-Host Mode**

The button for the current switching mode is dimmed.
 - Step 3** In the dialog box, click **Yes**.
Cisco UCS Manager restarts the fabric interconnect, logs you out, and disconnects Cisco UCS Manager GUI.
 - Step 4** Launch Cisco UCS Manager GUI and log back in to continue configuring your system.
-

Configuring a Port with the LAN Uplinks Manager

You can only configure server ports on the fixed port module. Expansion modules do not include server ports.

Procedure

- Step 1** In the LAN Uplinks Manager, click the **LAN Uplinks** tab.
 - Step 2** In the **Ports** area, click the down arrows to expand the **Unconfigured Ports** section.
 - Step 3** Expand **Fabric Interconnects** ► *Fabric_Interconnect_Name*.
 - Step 4** Right-click the port that you want to configure and choose one of the following:
 - **Configure as Server Port**
 - **Configure as Uplink Port**
 - Step 5** If Cisco UCS Manager displays a confirmation dialog box, click **Yes**.
-

Configuring Server Ports

Enabling a Server Port with the LAN Uplinks Manager

Procedure

- Step 1** In the LAN Uplinks Manager, click the **LAN Uplinks** tab.
 - Step 2** In the **Ports** area, click the down arrows to expand the **Server Ports** section.
 - Step 3** Expand **Fabric Interconnects** ► *Fabric_Interconnect_Name*.
 - Step 4** Right-click the port that you want to enable and choose **Enable**.
-

Disabling a Server Port with the LAN Uplinks Manager

Procedure

- Step 1** In the LAN Uplinks Manager, click the **LAN Uplinks** tab.
 - Step 2** In the **Ports** area, click the down arrows to expand the **Server Ports** section.
 - Step 3** Expand **Fabric Interconnects** ► *Fabric_Interconnect_Name*.
 - Step 4** Right-click the port that you want to disable and choose **Disable**.
 - Step 5** If Cisco UCS Manager displays a confirmation dialog box, click **Yes**.
-

Unconfiguring a Server Port with the LAN Uplinks Manager

Procedure

- Step 1** In the LAN Uplinks Manager, click the **LAN Uplinks** tab.
 - Step 2** In the **Ports** area, click the down arrows to expand the **Server Ports** section.
 - Step 3** Expand **Fabric Interconnects** ► *Fabric_Interconnect_Name*.
 - Step 4** Right-click the port that you want to unconfigure and choose **Unconfigure**.
 - Step 5** If Cisco UCS Manager displays a confirmation dialog box, click **Yes**.
-

Configuring Uplink Ethernet Ports

Enabling an Uplink Ethernet Port with the LAN Uplinks Manager

Procedure

- Step 1** In the LAN Uplinks Manager, click the **LAN Uplinks** tab.
 - Step 2** In the **Ports and Port Channels** area, expand **Ports** ► **Fabric Interconnects** ► *Fabric_Interconnect_Name*.
 - Step 3** Right-click the port that you want to enable and choose **Enable Port**.
 - Step 4** If Cisco UCS Manager displays a confirmation dialog box, click **Yes**.
-

Disabling an Uplink Ethernet Port with the LAN Uplinks Manager

Procedure

- Step 1** In the LAN Uplinks Manager, click the **LAN Uplinks** tab.
 - Step 2** In the **Ports and Port Channels** area, expand **Ports** ► **Fabric Interconnects** ► *Fabric_Interconnect_Name*.
 - Step 3** Right-click the port that you want to disable and choose **Disable Port**.
 - Step 4** If Cisco UCS Manager displays a confirmation dialog box, click **Yes**.
-

Unconfiguring an Uplink Ethernet Port with the LAN Uplinks Manager

Procedure

-
- Step 1** In the LAN Uplinks Manager, click the **LAN Uplinks** tab.
- Step 2** In the **Ports and Port Channels** area, expand **Ports** ► **Fabric Interconnects** ► *Fabric_Interconnect_Name*.
- Step 3** Click the port that you want to unconfigure.
You can select multiple ports if you want to unconfigure more than one uplink Ethernet port.
- Step 4** Click **Unconfigure**.
- Step 5** If Cisco UCS Manager displays a confirmation dialog box, click **Yes**.
-

Configuring Uplink Ethernet Port Channels

Creating a Port Channel with the LAN Uplinks Manager

Procedure

-
- Step 1** In the LAN Uplinks Manager, click the **LAN Uplinks** tab.
- Step 2** In the **Ports and Port Channels** area, click **Create Port Channel**.
- Step 3** From the pop-up menu, select one of the following fabric interconnects where you want to create the port channel:
- **Fabric Interconnect A**
 - **Fabric Interconnect B**
- Step 4** In the **Set Port Channel Name** page of the **Create Port Channel** wizard, do the following:
- a) Complete the following fields:

Name	Description
ID field	The identifier for the port channel.
Name field	A user-defined name for the port channel. This name can be between 1 and 16 alphanumeric characters. You cannot use spaces or any special characters, and you cannot change this name after the object has been saved.

- b) Click **Next**.
- Step 5** In the **Add Ports** page of the **Create Port Channel** wizard, do the following:
- a) In the **Ports** table, choose one or more ports to include the port channel.

- b) Click the >> button to add the ports to the **Ports in the port channel** table. You can use the << button to remove ports from the port channel.

Note Cisco UCS Manager warns you if you select a port that has been configured as a server port. You can click **Yes** in the dialog box to reconfigure that port as an uplink Ethernet port and include it in the port channel.

Step 6 Click **Finish**.

Enabling a Port Channel with the LAN Uplinks Manager

Procedure

- Step 1** In the LAN Uplinks Manager, click the **LAN Uplinks** tab.
- Step 2** In the **Ports and Port Channels** area, expand **Port Channels** > **Fabric Interconnects** > *Fabric_Interconnect_Name*.
- Step 3** Right-click the port channel that you want to enable and choose **Enable Port Channel**.
- Step 4** If Cisco UCS Manager displays a confirmation dialog box, click **Yes**.
-

Disabling a Port Channel with the LAN Uplinks Manager

Procedure

- Step 1** In the LAN Uplinks Manager, click the **LAN Uplinks** tab.
- Step 2** In the **Ports and Port Channels** area, expand **Port Channels** > **Fabric Interconnects** > *Fabric_Interconnect_Name*.
- Step 3** Right-click the port channel that you want to disable and choose **Disable Port Channel**.
- Step 4** If Cisco UCS Manager displays a confirmation dialog box, click **Yes**.
-

Adding Ports to a Port Channel with the LAN Uplinks Manager

Procedure

- Step 1** In the LAN Uplinks Manager, click the **LAN Uplinks** tab.
- Step 2** In the **Ports and Port Channels** area, expand **Port Channels** > **Fabric Interconnects** > *Fabric_Interconnect_Name*.
- Step 3** Right-click the port channel to which you want to add ports and choose **Add Ports**.
- Step 4** In the **Add Ports** dialog box, do the following:

- a) In the **Ports** table, choose one or more ports to include the port channel.
- b) Click the >> button to add the ports to the **Ports in the port channel** table.
You can use the << button to remove ports from the port channel.

Note Cisco UCS Manager warns you if you select a port that has been configured as a server port. You can click **Yes** in the dialog box to reconfigure that port as an uplink Ethernet port and include it in the port channel.

Step 5 Click **OK**.

Removing Ports from a Port Channel with the LAN Uplinks Manager

Procedure

- Step 1** In the LAN Uplinks Manager, click the **LAN Uplinks** tab.
 - Step 2** In the **Ports and Port Channels** area, expand **Port Channels** ► **Fabric Interconnects** ► *Fabric_Interconnect_Name*.
 - Step 3** Expand the port channel from which you want to remove ports.
 - Step 4** Right-click the port you want to remove from the port channel and choose **Delete**.
 - Step 5** If Cisco UCS Manager displays a confirmation dialog box, click **Yes**.
-

Deleting a Port Channel with the LAN Uplinks Manager

Procedure

- Step 1** In the LAN Uplinks Manager, click the **LAN Uplinks** tab.
 - Step 2** In the **Ports and Port Channels** area, expand **Port Channels** ► **Fabric Interconnects** ► *Fabric_Interconnect_Name*.
 - Step 3** Right-click the port channel you want to delete and choose **Delete**.
 - Step 4** If Cisco UCS Manager displays a confirmation dialog box, click **Yes**.
-

Configuring LAN Pin Groups

Creating a Pin Group with the LAN Uplinks Manager

In a system with two fabric interconnects, you can associate the pin group with only one fabric interconnect or with both fabric interconnects.

Before You Begin

Configure the ports and port channels with which you want to configure the pin group. You can only include ports and port channels configured as uplink ports in a LAN pin group

Procedure

- Step 1** In the LAN Uplinks Manager, click the **LAN Uplinks** tab.
- Step 2** In the **Ports and Port Channels** area, click **Create Pin Group**.
- Step 3** In the **Create LAN Pin Group** dialog box, enter a unique name and description for the pin group.
- Step 4** To pin traffic for fabric interconnect A, do the following in the **Targets** area:
- Check the **Fabric Interconnect A** check box.
 - Click the drop-down arrow on the **Interface** field and navigate through the tree-style browser to select the port or port channel you want to associate with the pin group.
- Step 5** To pin traffic for fabric interconnect B, do the following in the **Targets** area:
- Check the **Fabric Interconnect B** check box.
 - Click the drop-down arrow on the **Interface** field and navigate through the tree-style browser to select the port or port channel you want to associate with the pin group.
- Step 6** Click **OK**.
-

What to Do Next

Include the pin group in a vNIC template.

Deleting a Pin Group with the LAN Uplinks Manager

Procedure

- Step 1** In the LAN Uplinks Manager, click the **LAN Uplinks** tab.
- Step 2** In the **Pin Groups** area, right-click the pin group you want to delete and choose **Delete**.
- Step 3** If Cisco UCS Manager displays a confirmation dialog box, click **Yes**.
-

Configuring Named VLANs

Creating a Named VLAN with the LAN Uplinks Manager

In a Cisco UCS instance with two switches, you can create a named VLAN that is accessible to both switches or to only one switch.



Important You cannot create VLANs with IDs from 3968 to 4048. This range of VLAN IDs is reserved.

Procedure

- Step 1** In the LAN Uplinks Manager, click the **VLANs** tab.
- Step 2** On the icon bar to the right of the table, click +.
If the + icon is disabled, click an entry in the table to enable it.
- Step 3** In the **Create VLAN** dialog box, complete the following fields:

Name	Description
Name field	The name of the virtual LAN. This name can be between 1 and 16 alphanumeric characters. You cannot use spaces or any special characters, and you cannot change this name after the object has been saved.
Configuration options	You can select: <ul style="list-style-type: none"> • Common/Global—This VLAN applies to both fabrics and uses the same configuration parameters in both cases • Fabric A—The VLAN only applies to fabric A. • Fabric B—The VLAN only applies to fabric B. • Both Fabrics Configured Differently—This VLAN applies to both fabrics but it enables you to specify a different VLAN ID for each fabric.
VLAN ID field	Enter a numeric ID for this VLAN. This value can: <ul style="list-style-type: none"> • Be in the range from 1 to 3967 • Be in the range from 4049 to 4093 • Overlap with other VLAN IDs already defined on the system <p>Important The VLAN IDs from 3968 to 4048 are reserved. You cannot specify an ID within this range.</p>
Check Overlap button	Click this button to determine whether the VLAN ID overlaps with any other IDs on the system.

- Step 4** Click **OK**.
Cisco UCS Manager GUI adds the VLAN to one of the following **VLANs** nodes:
 - The **LAN Cloud > VLANs** node for a VLAN accessible to both fabric interconnects.
 - The **Fabric_Interconnect_Name > VLANs** node for a VLAN accessible to only one fabric interconnect.

Deleting a Named VLAN with the LAN Uplinks Manager

If Cisco UCS Manager includes a named VLAN with the same VLAN ID as the one you delete, the VLAN is not removed from the fabric interconnect configuration until all named VLANs with that ID are deleted.

Procedure

- Step 1** In the LAN Uplinks Manager, click the **VLANs** tab.
- Step 2** Click one of the following subtabs, depending upon what type of VLAN you want to delete:

Subtab	Description
All	Displays all VLANs in the Cisco UCS instance.
Dual Mode	Displays the VLANs that are accessible to both fabric interconnects.
Fabric A	Displays the VLANs that are accessible to only fabric interconnect A.
Fabric B	Displays the VLANs that are accessible to only fabric interconnect B.

- Step 3** In the table, click the VLAN you want to delete.
You can use the Shift key or Ctrl key to select multiple entries.
- Step 4** Right-click the highlighted VLAN or VLANs and select **Delete**.
- Step 5** If Cisco UCS Manager displays a confirmation dialog box, click **Yes**.

Configuring QoS System Classes with the LAN Uplinks Manager

Procedure

- Step 1** In the LAN Uplinks Manager, click the **QoS** tab.
- Step 2** Update the following properties for the system class you want to configure to meet the traffic management needs of the system:
- Note** Some properties may not be configurable for all system classes.

Name	Description
Enabled check box	If checked, the associated QoS class is configured on the fabric interconnect and can be assigned to a QoS policy. If unchecked, the class is not configured on the fabric interconnect and any QoS policies associated with this class default to Best Effort Priority .

Name	Description
	<p>Note This field is always checked for Best Effort Priority and Fibre Channel Priority.</p>
<p>Cos field</p>	<p>The class of service. You can enter an integer value between 0 and 6, with 0 being the lowest priority and 6 being the highest priority.</p> <p>Note This field is set to 7 for internal traffic and to any for Best Effort Priority. Both of these values are reserved and cannot be assigned to any other priority.</p>
<p>Packet Drop check box</p>	<p>If checked, packet drop is allowed for this class. If unchecked, packets cannot be dropped during transmission.</p> <p>Besides the Fibre Channel Priority class, which never allows dropped packets, only one other class can have this field unchecked.</p>
<p>Weight drop-down list</p>	<p>This can be:</p> <ul style="list-style-type: none"> • An integer between 1 and 10. If you enter an integer, Cisco UCS determines the percentage of network bandwidth assigned to the priority level as described in the Weight (%) field. • best-effort. • none.
<p>Weight (%) field</p>	<p>To determine the bandwidth allocated to a channel, Cisco UCS:</p> <ol style="list-style-type: none"> 1 Adds the weights for all of the channels 2 Divides the channel weight by the sum of all weights to get a percentage 3 Allocates that percentage of the bandwidth to the channel
<p>MTU drop-down list</p>	<p>The maximum transmission unit for the channel. This can be:</p> <ul style="list-style-type: none"> • An integer between 1538 and 9216. This value corresponds to the maximum packet size. • fc—A predefined packet size of 2240. • normal—A predefined packet size of 1359. <p>Note This field is always set to fc for Fibre Channel Priority.</p>
<p>Multicast Optimized check box</p>	<p>If checked, the class is optimized to send packets to multiple destinations simultaneously.</p> <p>Note This option is not applicable to the Fibre Channel Priority.</p>

Step 3 Do one of the following:

- Click **OK** to save your changes and exit from the LAN Uplinks Manager.
 - Click **Apply** to save your changes without exiting from the LAN Uplinks Manager.
-



CHAPTER 13

Configuring Named VLANs

This chapter includes the following sections:

- [Named VLANs, page 131](#)
- [Creating a Named VLAN, page 131](#)
- [Deleting a Named VLAN, page 133](#)

Named VLANs

A named VLAN creates a connection to a specific external LAN. The VLAN isolates traffic to that external LAN, including broadcast traffic.

The name that you assign to a VLAN ID adds a layer of abstraction that allows you to globally update all servers associated with service profiles that use the named VLAN. You do not need to reconfigure the servers individually to maintain communication with the external LAN.

You can create more than one named VLAN with the same VLAN ID. For example, if servers that host business services for HR and Finance need to access the same external LAN, you can create VLANs named HR and Finance with the same VLAN ID. Then, if the network is reconfigured and Finance is assigned to a different LAN, you only have to change the VLAN ID for the named VLAN for Finance.

In a cluster configuration, you can configure a named VLAN to be accessible only to one fabric interconnect or to both fabric interconnects.

Creating a Named VLAN

In a Cisco UCS instance with two fabric interconnects, you can create a named VLAN that is accessible to both fabric interconnects or to only one fabric interconnect.



Important

You cannot create VLANs with IDs from 3968 to 4048. This range of VLAN IDs is reserved.

Procedure

- Step 1** In the **Navigation** pane, click the **LAN** tab.
- Step 2** On the **LAN** tab, click the **LAN** node.
- Step 3** In the **Work** pane, click the **VLANs** tab.
- Step 4** On the icon bar to the right of the table, click +.
If the + icon is disabled, click an entry in the table to enable it.
- Step 5** In the **Create VLAN** dialog box, complete the following fields:

Name	Description
Name field	<p>The name of the virtual LAN.</p> <p>This name can be between 1 and 16 alphanumeric characters. You cannot use spaces or any special characters, and you cannot change this name after the object has been saved.</p>
Configuration options	<p>You can select:</p> <ul style="list-style-type: none"> • Common/Global—This VLAN applies to both fabrics and uses the same configuration parameters in both cases • Fabric A—The VLAN only applies to fabric A. • Fabric B—The VLAN only applies to fabric B. • Both Fabrics Configured Differently—This VLAN applies to both fabrics but it enables you to specify a different VLAN ID for each fabric.
VLAN ID field	<p>Enter a numeric ID for this VLAN. This value can:</p> <ul style="list-style-type: none"> • Be in the range from 1 to 3967 • Be in the range from 4049 to 4093 • Overlap with other VLAN IDs already defined on the system <p>Important The VLAN IDs from 3968 to 4048 are reserved. You cannot specify an ID within this range.</p>
Check Overlap button	Click this button to determine whether the VLAN ID overlaps with any other IDs on the system.

- Step 6** Click **OK**.
- Cisco UCS Manager GUI adds the VLAN to one of the following **VLANs** nodes:
- The **LAN Cloud > VLANs** node for a VLAN accessible to both fabric interconnects.
 - The **Fabric_Interconnect_Name > VLANs** node for a VLAN accessible to only one fabric interconnect.

Deleting a Named VLAN

If Cisco UCS Manager includes a named VLAN with the same VLAN ID as the one you delete, the VLAN is not removed from the fabric interconnect configuration until all named VLANs with that ID are deleted.

Procedure

-
- Step 1** In the **Navigation** pane, click the **LAN** tab.
- Step 2** On the **LAN** tab, click the **LAN** node.
- Step 3** In the **Work** pane, click the **VLANS** tab.
- Step 4** Click one of the following subtabs, depending upon what type of VLAN you want to delete:

Subtab	Description
All	Displays all VLANs in the Cisco UCS instance.
Dual Mode	Displays the VLANs that are accessible to both fabric interconnects.
Fabric A	Displays the VLANs that are accessible to only fabric interconnect A.
Fabric B	Displays the VLANs that are accessible to only fabric interconnect B.

- Step 5** In the table, click the VLAN you want to delete.
You can use the Shift key or Ctrl key to select multiple entries.
- Step 6** Right-click the highlighted VLAN or VLANs and select **Delete**.
- Step 7** If Cisco UCS Manager displays a confirmation dialog box, click **Yes**.
-



CHAPTER 14

Configuring LAN Pin Groups

This chapter includes the following sections:

- [LAN Pin Groups, page 135](#)
- [Creating a LAN Pin Group, page 135](#)
- [Deleting a LAN Pin Group, page 136](#)

LAN Pin Groups

Cisco UCS uses LAN pin groups to pin Ethernet traffic from a vNIC on a server to an uplink Ethernet port or port channel on the fabric interconnect. You can use this pinning to manage the distribution of traffic from the servers.

To configure pinning for a server, you must include the LAN pin group in a vNIC policy. The vNIC policy is then included in the service profile assigned to that server. All traffic from the vNIC travels through the I/O module to the specified uplink Ethernet port.



Note

If you do not assign a pin group to a server interface through a vNIC policy, Cisco UCS Manager chooses an uplink Ethernet port or port channel for traffic from that server interface dynamically. This choice is not permanent. A different uplink Ethernet port or port channel may be used for traffic from that server interface after an interface flap or a server reboot.

Creating a LAN Pin Group

In a system with two fabric interconnects, you can associate the pin group with only one fabric interconnect or with both fabric interconnects.

Before You Begin

Configure the ports and port channels with which you want to configure the pin group. You can only include ports and port channels configured as uplink ports in a LAN pin group

Procedure

- Step 1** In the **Navigation** pane, click the **LAN** tab.
- Step 2** On the **LAN** tab, expand **LAN ► LAN Cloud**.
- Step 3** Right-click **LAN Pin Groups** and select **Create LAN Pin Group**.
- Step 4** In the **Create LAN Pin Group** dialog box, enter a unique name and description for the pin group.
- Step 5** To pin traffic for fabric interconnect A, do the following in the **Targets** area:
- Check the **Fabric Interconnect A** check box.
 - Click the drop-down arrow on the **Interface** field and navigate through the tree-style browser to select the port or port channel you want to associate with the pin group.
- Step 6** To pin traffic for fabric interconnect B, do the following in the **Targets** area:
- Check the **Fabric Interconnect B** check box.
 - Click the drop-down arrow on the **Interface** field and navigate through the tree-style browser to select the port or port channel you want to associate with the pin group.
- Step 7** Click **OK**.
-

What to Do Next

Include the pin group in a vNIC template.

Deleting a LAN Pin Group

Procedure

- Step 1** In the **Navigation** pane, click the **LAN** tab.
- Step 2** In the **LAN** tab, expand **LAN ► LAN Cloud ► LAN Pin Groups** .
- Step 3** Right-click the LAN pin group you want to delete and select **Delete**.
- Step 4** If Cisco UCS Manager displays a confirmation dialog box, click **Yes**.
-



CHAPTER 15

Configuring MAC Pools

This chapter includes the following sections:

- [MAC Pools, page 137](#)
- [Creating a MAC Pool, page 137](#)
- [Deleting a MAC Pool, page 138](#)

MAC Pools

A MAC pool is a collection of network identities, or MAC addresses, that are unique in their layer 2 environment and are available to be assigned to vNICs on a server. If you use MAC pools in service profiles, you do not have to manually configure the MAC addresses to be used by the server associated with the service profile.

In a system that implements multi-tenancy, you can use the organizational hierarchy to ensure that MAC pools can only be used by specific applications or business services. Cisco UCS Manager uses the name resolution policy to assign MAC addresses from the pool.

To assign a MAC address to a server, you must include the MAC pool in a vNIC policy. The vNIC policy is then included in the service profile assigned to that server.

You can specify your own MAC addresses or use a group of MAC addresses provided by Cisco.

Creating a MAC Pool

Procedure

- Step 1** In the **Navigation** pane, click the **LAN** tab.
- Step 2** In the **LAN** tab, expand **LAN ► Pools**.
- Step 3** Expand the node for the organization where you want to create the pool. If the system does not include multi-tenancy, expand the **root** node.
- Step 4** Right-click **MAC Pools** and select **Create MAC Pool**.
- Step 5** In the first page of the **Create MAC Pool** wizard:

- a) Enter a unique name and description for the MAC Pool.
- b) Click **Next**.

Step 6 In the second page of the **Create MAC Pool** wizard:

- a) Click **Add**.
 - b) In the **Create a Block of MAC Addresses** page, enter the first MAC address in the pool and the number of MAC addresses to include in the pool.
 - c) Click **OK**.
 - d) Click **Finish**.
-

What to Do Next

Include the MAC pool in a vNIC template.

Deleting a MAC Pool

Procedure

- Step 1** In the **Navigation** pane, click the **LAN** tab.
 - Step 2** In the **LAN** tab, expand **LAN ► Pools ► Organization_Name** .
 - Step 3** Expand the **MAC Pools** node.
 - Step 4** Right-click the MAC pool you want to delete and select **Delete**.
 - Step 5** If Cisco UCS Manager displays a confirmation dialog box, click **Yes**.
-



CHAPTER 16

Configuring Quality of Service

This chapter includes the following sections:

- [Quality of Service, page 139](#)
- [System Classes, page 139](#)
- [Quality of Service Policies, page 140](#)
- [Flow Control Policies, page 140](#)
- [Configuring QoS System Classes, page 141](#)
- [Creating a QoS Policy, page 142](#)
- [Deleting a QoS Policy, page 143](#)
- [Creating a Flow Control Policy, page 143](#)
- [Deleting a Flow Control Policy, page 144](#)

Quality of Service

Cisco UCS provides the following methods to implement quality of service:

- System classes that specify the global configuration for certain types of traffic across the entire system
- QoS policies that assign system classes for individual vNICs
- Flow control policies that determine how uplink Ethernet ports handle pause frames

System Classes

Cisco UCS uses Data Center Ethernet (DCE) to handle all traffic inside a Cisco UCS instance. This industry standard enhancement to Ethernet divides the bandwidth of the Ethernet pipe into eight virtual lanes. System classes determine how the DCE bandwidth in these virtual lanes is allocated across the entire Cisco UCS instance.

Each system class reserves a specific segment of the bandwidth for a specific type of traffic. This provides a level of traffic management, even in an oversubscribed system. For example, you can configure the Fibre Channel Priority system class to determine the percentage of DCE bandwidth allocated to FCoE traffic.

The following table describes the system classes:

System Class	Description
Platinum Priority Gold Priority Silver Priority Bronze Priority	A configurable set of system classes that you can include in the QoS policy for a service profile. Each system class manages one lane of traffic. All properties of these system classes are available for you to assign custom settings and policies.
Best Effort Priority	A system class that sets the quality of service for the lane reserved for Basic Ethernet traffic. Some properties of this system class are preset and cannot be modified. For example, this class has a drop policy that allows it to drop data packets if required.
Fibre Channel Priority	A system class that sets the quality of service for the lane reserved for Fibre Channel over Ethernet traffic. Some properties of this system class are preset and cannot be modified. For example, this class has a no-drop policy that ensures it never drops data packets.

Quality of Service Policies

QoS policies assign a system class to the outgoing traffic for a vNIC or vHBA. This system class determines the quality of service for that traffic.

You must include a QoS policy in a vNIC policy or vHBA policy and then include that policy in a service profile to configure the vNIC or vHBA.

Flow Control Policies

Flow control policies determine whether the uplink Ethernet ports in a Cisco UCS instance send and receive IEEE 802.3x pause frames when the receive buffer for a port fills. These pause frames request that the transmitting port stop sending data for a few milliseconds until the buffer clears.

For flow control to work between a LAN port and an uplink Ethernet port, you must enable the corresponding receive and send flow control parameters for both ports. For Cisco UCS, the flow control policies configure these parameters.

When you enable the send function, the uplink Ethernet port sends a pause request to the network port if the incoming packet rate becomes too high. The pause remains in effect for a few milliseconds before traffic is reset to normal levels. If you enable the receive function, the uplink Ethernet port honors all pause requests from the network port. All traffic is halted on that uplink port until the network port cancels the pause request.

Because you assign the flow control policy to the port, changes to the policy have an immediate effect on how the port reacts to a pause frame or a full receive buffer.

Configuring QoS System Classes

Procedure

- Step 1** In the **Navigation** pane, click the **LAN** tab.
- Step 2** In the **LAN** tab, expand **LAN ► LAN Cloud** .
- Step 3** Select the **QoS System Class** node.
- Step 4** In the **General** tab, update the following properties for the system class you want to configure to meet the traffic management needs of the system:
- Note** Some properties may not be configurable for all system classes.

Name	Description
Enabled check box	<p>If checked, the associated QoS class is configured on the fabric interconnect and can be assigned to a QoS policy.</p> <p>If unchecked, the class is not configured on the fabric interconnect and any QoS policies associated with this class default to Best Effort Priority.</p> <p>Note This field is always checked for Best Effort Priority and Fibre Channel Priority.</p>
Cos field	<p>The class of service. You can enter an integer value between 0 and 6, with 0 being the lowest priority and 6 being the highest priority.</p> <p>Note This field is set to 7 for internal traffic and to any for Best Effort Priority. Both of these values are reserved and cannot be assigned to any other priority.</p>
Packet Drop check box	<p>If checked, packet drop is allowed for this class. If unchecked, packets cannot be dropped during transmission.</p> <p>Besides the Fibre Channel Priority class, which never allows dropped packets, only one other class can have this field unchecked.</p>
Weight drop-down list	<p>This can be:</p> <ul style="list-style-type: none"> • An integer between 1 and 10. If you enter an integer, Cisco UCS determines the percentage of network bandwidth assigned to the priority level as described in the Weight (%) field. • best-effort. • none.
Weight (%) field	<p>To determine the bandwidth allocated to a channel, Cisco UCS:</p> <ol style="list-style-type: none"> 1 Adds the weights for all of the channels 2 Divides the channel weight by the sum of all weights to get a percentage

Name	Description
	3 Allocates that percentage of the bandwidth to the channel
MTU drop-down list	<p>The maximum transmission unit for the channel. This can be:</p> <ul style="list-style-type: none"> • An integer between 1538 and 9216. This value corresponds to the maximum packet size. • fc—A predefined packet size of 2240. • normal—A predefined packet size of 1359. <p>Note This field is always set to fc for Fibre Channel Priority.</p>
Multicast Optimized check box	<p>If checked, the class is optimized to send packets to multiple destinations simultaneously.</p> <p>Note This option is not applicable to the Fibre Channel Priority.</p>

Step 5 Click **Save Changes**.

Creating a QoS Policy

Procedure

- Step 1** In the **Navigation** pane, click the **LAN** tab.
- Step 2** In the **LAN** tab, expand **LAN ► Policies**.
- Step 3** Expand the node for the organization where you want to create the pool. If the system does not include multi-tenancy, expand the **root** node.
- Step 4** Right-click **QoS Policy** and select **Create QoS Policy**.
- Step 5** In the **Create QoS Policy** dialog box:
- In the **Name** field, enter a unique name for the policy.
 - From the **Priority** drop-down list, select the system class you want to assign to traffic through the vNIC.
 - Click **OK**.
-

What to Do Next

Include the QoS policy in a vNIC template.

Deleting a QoS Policy

If you delete a QoS policy that is in use or disable a system class that is used in a QoS policy, any vNIC which uses that QoS policy is assigned to the Best Effort Priority system class. In a system that implements multi-tenancy, Cisco UCS Manager first attempts to find a matching QoS policy in the organization hierarchy.

Procedure

-
- Step 1** In the **Navigation** pane, click the **LAN** tab.
 - Step 2** On the **Servers** tab, expand **Servers** ► **Policies** ► *Organization_Name*.
 - Step 3** Expand the **QoS Policies** node.
 - Step 4** Right-click the QoS policy you want to delete and select **Delete**.
 - Step 5** If Cisco UCS Manager displays a confirmation dialog box, click **Yes**.
-

Creating a Flow Control Policy

Before You Begin

Configure the network port with the corresponding setting for the flow control that you need. For example, if you enable the send setting for flow-control pause frames in the policy, make sure that the receive parameter in the network port is set to on or desired. If you want the Cisco UCS port to receive flow-control frames, make sure that the network port has a send parameter set to on or desired. If you do not want to use flow control, you can set the send and receive parameters on the network port to off.

Procedure

-
- Step 1** In the **Navigation** pane, click the **LAN** tab.
 - Step 2** On the **LAN** tab, expand **LAN** ► **Policies**.
 - Step 3** Expand the node for the organization where you want to create the policy. If the system does not include multi-tenancy, expand the **root** node.
 - Step 4** Right-click the **Flow Control Policies** node and select **Create Flow Control Policy**.
 - Step 5** In the **Create Flow Control Policy** wizard, complete the following fields:

Name	Description
Name field	The name of the policy. This name can be between 1 and 16 alphanumeric characters. You cannot use spaces or any special characters, and you cannot change this name after the object has been saved.
Priority field	This can be: <ul style="list-style-type: none"> • auto—Cisco UCS and the network negotiate whether PPP is used on this fabric interconnect

Name	Description
	<ul style="list-style-type: none"> • on—PPP is enabled on this fabric interconnect
Receive field	This can be: <ul style="list-style-type: none"> • off—Pause requests from the network are ignored and traffic flow continues as normal • on—Pause requests are honored and all traffic is halted on that uplink port until the network cancels the pause request
Send field	This can be: <ul style="list-style-type: none"> • off—Traffic on the port flows normally regardless of the packet load. • on—Cisco UCS sends a pause request to the network if the incoming packet rate becomes too high. The pause remains in effect for a few milliseconds before traffic is reset to normal levels.

Step 6 Click **OK**.

What to Do Next

Associate the flow control policy with an uplink Ethernet port or port channel.

Deleting a Flow Control Policy

Procedure

- Step 1** In the **Navigation** pane, click the **LAN** tab.
 - Step 2** On the **LAN** tab, expand **LAN > Policies > Organization_Name**.
 - Step 3** Expand the **Flow Control Policies** node.
 - Step 4** Right-click the policy you want to delete and select **Delete**.
 - Step 5** If Cisco UCS Manager displays a confirmation dialog box, click **Yes**.
-



CHAPTER 17

Configuring Network-Related Policies

This chapter includes the following sections:

- [Configuring vNIC Templates, page 145](#)
- [Configuring Ethernet Adapter Policies, page 149](#)
- [Configuring Network Control Policies, page 152](#)

Configuring vNIC Templates

vNIC Template

This policy defines how a vNIC on a server connects to the LAN. This policy is also referred to as a vNIC LAN connectivity policy.

You need to include this policy in a service profile for it to take effect.

Creating a vNIC Template

Before You Begin

This policy requires that one or more of the following resources already exist in the system:

- Named VLAN
- MAC pool
- QoS policy
- LAN pin group
- Statistics threshold policy

Procedure

- Step 1** In the **Navigation** pane, click the **LAN** tab.
- Step 2** On the **LAN** tab, expand **LAN ► Policies**.
- Step 3** Expand the node for the organization where you want to create the policy.
If the system does not include multi-tenancy, expand the **root** node.
- Step 4** Right-click the **vNIC Templates** node and choose **Create vNIC Template**.
- Step 5** In the **Create vNIC Template** dialog box:
- a) In the **General** area, complete the following fields:

Name	Description
Name field	The name of the vNIC template.
Description field	A user-defined description of the template.
Fabric ID field	The fabric interconnect associated with the component. If you want vNICs created from this template to be able to access the second fabric interconnect if the default one is unavailable, check the Enable Failover check box. Note Do not select Enable Failover if you plan to associate vNICs created from this template with servers that have a Cisco UCS 82598KR-CI 10-Gigabit Ethernet Adapter. If you do so, Cisco UCS Manager generates a configuration fault when you associate the service profile with the server.
Target list box	A list of the possible targets for vNICs created from this template. This can be: <ul style="list-style-type: none"> • Adapter—The vNICs apply to all adapters. • VM—The vNICs apply to all virtual machines.
Template Type field	This can be: <ul style="list-style-type: none"> • Initial Template—vNICs created from this template are not updated if the template changes. • Updating Template—vNICs created from this template are updated if the template changes.

- b) In the **VLANs** area, use the table to select the VLAN to assign to vNICs created from this template. The table contains the following columns:

Name	Description
Select column	Check the check box in this column to associate the VLAN with the vNIC template.

Name	Description
Name column	The name of the VLAN.
Native VLAN column	To designate one of the VLANs as the native VLAN, click the radio button in this column.
Create VLAN link	Click this link if you want to create a VLAN.

c) In the **Policies** area, complete the following fields:

Name	Description
MAC Pool drop-down list	The MAC address pool that vNICs created from this vNIC template should use.
QoS Policy drop-down list	The quality of service policy that vNICs created from this vNIC template should use.
Network Control Policy drop-down list box	The network control policy that vNICs created from this vNIC template should use.
Pin Group drop-down list	The LAN pin group that vNICs created from this vNIC template should use.
Stats Threshold Policy drop-down list	The statistics collection policy that vNICs created from this vNIC template should use.

Step 6 Click **OK**.

What to Do Next

Include the vNIC template in a service profile.

Deleting a vNIC Template

Procedure

- Step 1** In the **Navigation** pane, click the **LAN** tab.
- Step 2** On the **LAN** tab, expand **LAN** ► **Policies** ► *Organization_Name*.
- Step 3** Expand the **vNIC Templates** node.
- Step 4** Right-click the policy you want to delete and choose **Delete**.
- Step 5** If Cisco UCS Manager displays a confirmation dialog box, click **Yes**.

Binding a vNIC to a vNIC Template

You can bind a vNIC associated with a service profile to a vNIC template. When you bind the vNIC to a vNIC template, Cisco UCS Manager configures the vNIC with the values defined in the vNIC template. If the existing vNIC configuration does not match the vNIC template, Cisco UCS Manager reconfigures the vNIC. You can only change the configuration of a bound vNIC through the associated vNIC template. You cannot bind a vNIC to a vNIC template if the service profile that includes the vNIC is already bound to a service profile template.



Important If the vNIC is reconfigured when you bind it to a template, Cisco UCS Manager reboots the server associated with the service profile.

Procedure

-
- Step 1** In the **Navigation** pane, click the **Servers** tab.
 - Step 2** On the **Servers** tab, expand **Servers** ► **Service Profiles**.
 - Step 3** Expand the node for the organization that includes the service profile with the vNIC you want to bind. If the system does not include multi-tenancy, expand the **root** node.
 - Step 4** Expand *Service_Profile_Name* ► **vNICs**.
 - Step 5** Click the vNIC you want to bind to a template.
 - Step 6** In the **Work** pane, click the **General** tab.
 - Step 7** In the **Actions** area, click **Bind to a Template**.
 - Step 8** In the **Bind to a vNIC Template** dialog box, do the following:
 - a) From the **vNIC Template** drop-down list, choose the template to which you want to bind the vNIC.
 - b) Click **OK**.
 - Step 9** In the warning dialog box, click **Yes** to acknowledge that Cisco UCS Manager may need to reboot the server if the binding causes the vNIC to be reconfigured.
-

Unbinding a vNIC from a vNIC Template

Procedure

-
- Step 1** In the **Navigation** pane, click the **Servers** tab.
 - Step 2** On the **Servers** tab, expand **Servers** ► **Service Profiles**.
 - Step 3** Expand the node for the organization that includes the service profile with the vNIC you want to unbind.

If the system does not include multi-tenancy, expand the **root** node.

- Step 4** Expand *Service_Profile_Name* ► vNICs.
 - Step 5** Click the vNIC you want to unbind from a template.
 - Step 6** In the **Work** pane, click the **General** tab.
 - Step 7** In the **Actions** area, click **Unbind from a Template**.
 - Step 8** If Cisco UCS Manager displays a confirmation dialog box, click **Yes**.
-

Configuring Ethernet Adapter Policies

Ethernet and Fibre Channel Adapter Policies

These policies govern the host-side behavior of the adapter, including how the adapter handles traffic. For example, you can use these policies to change default settings for the following:

- Queues
- Interrupt handling
- Performance enhancement
- RSS hash
- Failover in an cluster configuration with two fabric interconnects

By default, Cisco UCS provides a set of Ethernet adapter policies and Fibre Channel adapter policies. These policies include the recommended settings for each supported server operating system. Operating systems are sensitive to the settings in these policies. Storage vendors typically require non-default adapter settings. You can find the details of these required settings on the support list provided by those vendors.

**Note**

For Fibre Channel adapter policies, the values displayed by Cisco UCS Manager may not match those displayed by applications such as QLogic SANsurfer. For example, the following values may result in an apparent mismatch between SANsurfer and Cisco UCS Manager:

- **Max LUNs Per Target**—SANsurfer has a maximum of 256 LUNs and does not display more than that number. Cisco UCS Manager supports a higher maximum number of LUNs.
 - **Link Down Timeout**—In SANsurfer, you configure the timeout threshold for link down in seconds. In Cisco UCS Manager, you configure this value in milliseconds. Therefore, a value of 5500 ms in Cisco UCS Manager displays as 5s in SANsurfer.
 - **Max Data Field Size**—SANsurfer has allowed values of 512, 1024, and 2048. Cisco UCS Manager allows you to set values of any size. Therefore, a value of 900 in Cisco UCS Manager displays as 512 in SANsurfer.
-

Creating an Ethernet Adapter Policy



Tip If the fields in an area are not displayed, click the **Expand** icon to the right of the heading.

Procedure

- Step 1** In the **Navigation** pane, click the **LAN** tab.
- Step 2** On the **LAN** tab, expand **LAN > Policies**.
- Step 3** Expand the node for the organization where you want to create the policy.
If the system does not include multi-tenancy, expand the **root** node.
- Step 4** Right-click on **Adapter Policies** and choose **Create Ethernet Adapter Policy**.
- Step 5** Enter a name and description for the policy in the following fields:

Name	Description
Name field	The name of the policy.
Description field	A description of the policy. We recommend including information about where and when the policy should be used.

- Step 6** (Optional) In the **Queues** area, adjust the following values for the transmit, receive, and completion queues:

Name	Description
Count field	The number of queue resources to allocate. For transmit and receive queues, enter an integer between 1 and 256. For completion queues, enter an integer between 1 and 521. In general, the number of completion queues equals the number of transmit queues plus the number of receive queues.
Ring size field	The number of descriptors in each queue. Enter an integer between 64 and 4096.

- Step 7** (Optional) In the **Interrupt Handling** area, adjust the following values:

Name	Description
Coalescing Time field	The time to wait between interrupts or the idle period that must be encountered before an interrupt is sent. Enter a value between 1 and 65535. To turn off coalescing, enter 0 (zero) in this field.
Coalescing Type field	This can be: <ul style="list-style-type: none"> • min—The system waits for the time specified in the Coalescing Time field before sending another interrupt event.

Name	Description
	<ul style="list-style-type: none"> • idle—The system does not send an interrupt until there is a period of no activity lasting as long as the time specified in the Coalescing Time field.
Count field	<p>The number of interrupt resources to allocate.</p> <p>Enter an integer between 1 and 514. In general, you should allocate one interrupt resource for each completion queue.</p>

Step 8 (Optional) In the **Performance Enhancement** area, adjust the following values:

Name	Description
Receive Checksum Offload field	<p>This can be:</p> <ul style="list-style-type: none"> • disabled—The CPU validates all packet checksums. • enabled—The CPU sends all packet checksums to the hardware for validation. This option may reduce CPU overhead.
Transmit Checksum Offload field	<p>This can be:</p> <ul style="list-style-type: none"> • disabled—The CPU calculates all packet checksums. • enabled—The CPU sends all packets to the hardware so that the checksum can be calculated. This option may reduce CPU overhead.
TCP Segment Offload field	<p>This can be:</p> <ul style="list-style-type: none"> • disabled—The CPU segments large TCP packets. • enabled—The CPU sends large TCP packets to the hardware to be segmented. This option may reduce CPU overhead and increase throughput rate. <p>Note This option is also known as Large Send Offload (LSO).</p>
TCP Large Receive Offload field	<p>This can be:</p> <ul style="list-style-type: none"> • disabled—The CPU processes all large packets. • enabled—The hardware reassembles all segmented packets before sending them to the CPU. This option may reduce CPU utilization and increase inbound throughput.

Step 9 In the **RSS Hash** area, adjust the following values for the appropriate protocols:

Name	Description
Receive Side Scaling field	Receive-side Scaling (RSS) enables the efficient distribution of network receive processing across multiple CPUs in multiprocessor systems. This can be: <ul style="list-style-type: none"> • disabled—The system does not use RSS. • enabled—The system uses RSS. <p>Note The setting of this field applies to all enabled protocols.</p>
IP field	Whether IP is enabled for IPv4.
TCP field	Whether TCP is enabled for IPv4.

Step 10 In the **Failover** area, adjust the value for the following field:

Name	Description
Failback Timeout field	After a vNIC has started using its secondary interface, this setting controls how long the primary interface must be available before the system resumes using the primary interface for the vNIC. Enter a number of seconds between 0 and 600.

Step 11 Click **OK**.

Deleting an Ethernet Adapter Policy

Procedure

- Step 1** In the **Navigation** pane, click the **LAN** tab.
- Step 2** On the **LAN** tab, expand **LAN ► Policies ► Organization_Name**.
- Step 3** Expand the **Adapter Policies** node.
- Step 4** Right-click the Ethernet adapter policy that you want to delete and choose **Delete**.
- Step 5** If Cisco UCS Manager displays a confirmation dialog box, click **Yes**.

Configuring Network Control Policies

Network Control Policy

This policy configures the network control settings for the Cisco UCS instance, including the following:

- Whether the Cisco Discovery Protocol (CDP) is enabled or disabled
- How the VIF behaves if no uplink port is available in end-host mode

Creating a Network Control Policy

Procedure

- Step 1** In the **Navigation** pane, click the **LAN** tab.
- Step 2** On the **LAN** tab, expand **LAN ► Policies**.
- Step 3** Expand the node for the organization where you want to create the policy. If the system does not include multi-tenancy, expand the **root** node.
- Step 4** Right-click the **Network Control Policies** node and select **Create Network Control Policy**.
- Step 5** In the **Create Network Control Policy** dialog box, complete the following fields:

Name	Description
Name field	<p>The name of the policy.</p> <p>This name can be between 1 and 16 alphanumeric characters. You cannot use spaces or any special characters, and you cannot change this name after the object has been saved.</p>
CDP field	<p>This option determines whether Cisco Discovery Protocol (CDP) is enabled on servers associated with a service profile that includes this policy. This can be:</p> <ul style="list-style-type: none"> • disabled • enabled
Action on Uplink Fail field	<p>This option determines how the VIF behaves is no uplink port is available when the fabric interconnect is in end-host mode. This can be:</p> <ul style="list-style-type: none"> • link-down— Changes the operational state of a vNIC to down when uplink connectivity is lost on the fabric interconnect, and facilitates fabric failover for vNICs. • warning— Maintains server-to-server connectivity even when no uplink port is available, and disables fabric failover when uplink connectivity is lost on the fabric interconnect. <p>The default is link-down.</p>

- Step 6** Click **OK**.

Deleting a Network Control Policy

Procedure

- Step 1** In the **Navigation** pane, click the **LAN** tab.
 - Step 2** On the **LAN** tab, expand **LAN ► Policies ► *Organization_Name***.
 - Step 3** Expand the **Network Control Policies** node.
 - Step 4** Right-click the policy you want to delete and select **Delete**.
 - Step 5** If Cisco UCS Manager displays a confirmation dialog box, click **Yes**.
-



PART **IV**

Storage Configuration

- [Configuring Named VSANs, page 157](#)
- [Configuring SAN Pin Groups, page 161](#)
- [Configuring WWN Pools, page 163](#)
- [Configuring Storage-Related Policies, page 167](#)



CHAPTER 18

Configuring Named VSANs

This chapter includes the following sections:

- [Named VSANs, page 157](#)
- [Creating a Named VSAN, page 157](#)
- [Deleting a Named VSAN, page 158](#)

Named VSANs

A named VSAN creates a connection to a specific external SAN. The VSAN isolates traffic to that external SAN, including broadcast traffic. The traffic on one named VSAN knows that the traffic on another named VSAN exists, but cannot read or access that traffic.

Like a named VLAN, the name that you assign to a VSAN ID adds a layer of abstraction that allows you to globally update all servers associated with service profiles that use the named VSAN. You do not need to reconfigure the servers individually to maintain communication with the external SAN. You can create more than one named VSAN with the same VSAN ID.

In a cluster configuration, a named VSAN can be configured to be accessible only to the FC uplinks on one fabric interconnect or to the FC Uplinks on both fabric interconnects.

Creating a Named VSAN

You can create a named VSAN with IDs from 1 to 4093.

Procedure

- Step 1** In the **Navigation** pane, click the **SAN** tab.
- Step 2** In the **SAN** tab, click the **SAN** node.
- Step 3** In the **Work** pane, click the **VSANs** tab.
- Step 4** On the icon bar to the right of the table, click **+**.
If the **+** icon is disabled, click an entry in the table to enable it.
- Step 5** In the **Create VSAN** dialog box, complete the following fields:

Name	Description
Name field	<p>The name assigned to the network.</p> <p>This name can be between 1 and 16 alphanumeric characters. You cannot use spaces or any special characters, and you cannot change this name after the object has been saved.</p>
Type radio button	<p>Click the radio button to determine how the VSAN should be configured. You can choose:</p> <ul style="list-style-type: none"> • Common/Global—The VSAN maps to the same VSAN ID in all available fabrics. • Fabric A—The VSAN maps to the a VSAN ID that exists only in fabric A. • Fabric B—The VSAN maps to the a VSAN ID that exists only in fabric B. • Both Fabrics Configured Differently—The VSAN maps to a different VSAN ID in each available fabric. If you choose this option, Cisco UCS Manager GUI displays a VSAN ID field and a FCoE VLAN field for each fabric.
VSAN ID field	<p>The unique identifier assigned to the network.</p> <p>The ID can be between 1 and 4093.</p>
FCoE VLAN field	<p>The unique identifier assigned to the VLAN used for Fibre Channel connections.</p>

Step 6 Click **OK**.

Cisco UCS Manager GUI adds the VSAN to one of the following **VSANs** nodes:

- The **SAN Cloud > VSANs** node for a VSAN accessible to both fabric interconnects.
- The **FC Uplinks - Switch_Name > VSANs** node for a VSAN accessible to only one fabric interconnect.

Deleting a Named VSAN

If Cisco UCS Manager includes a named VSAN with the same VSAN ID as the one you delete, the VSAN is not removed from the fabric interconnect configuration until all named VSANs with that ID are deleted.

Procedure

- Step 1** In the **Navigation** pane, click the **SAN** tab.
- Step 2** In the **SAN** tab, click the **SAN** node.
- Step 3** In the **Work** pane, click the **VSANs** tab.
- Step 4** Click one of the following subtabs, depending upon what type of VSAN you want to delete:

Subtab	Description
All	Displays all VSANs in the Cisco UCS instance.
Dual Mode	Displays the VSANs that are accessible to both fabric interconnects.
Switch A	Displays the VSANs that are accessible to only fabric interconnect A.
Switch B	Displays the VSANs that are accessible to only fabric interconnect B.

- Step 5** In the table, click the VSAN you want to delete.
You can use the Shift key or Ctrl key to select multiple entries.
- Step 6** Right-click the highlighted VSAN or VSANs and select **Delete**.
- Step 7** If Cisco UCS Manager displays a confirmation dialog box, click **Yes**.
- Step 8** Click **OK**.



CHAPTER 19

Configuring SAN Pin Groups

This chapter includes the following sections:

- [SAN Pin Groups, page 161](#)
- [Creating a SAN Pin Group, page 161](#)
- [Deleting a SAN Pin Group, page 162](#)

SAN Pin Groups

Cisco UCS uses SAN pin groups to pin Fibre Channel traffic from a vHBA on a server to an uplink Fibre Channel port on the fabric interconnect. You can use this pinning to manage the distribution of traffic from the servers.

To configure pinning for a server, you must include the SAN pin group in a vHBA policy. The vHBA policy is then included in the service profile assigned to that server. All traffic from the vHBA will travel through the I/O module to the specified uplink Fibre Channel port.

You can assign the same pin group to multiple vHBA policies. As a result, you do not need to manually pin the traffic for each vHBA.



Important

Changing the target interface for an existing SAN pin group disrupts traffic for all vHBAs which use that pin group. The fabric interconnect performs a log in and log out for the Fibre Channel protocols to re-pin the traffic.

Creating a SAN Pin Group

In a system with two fabric interconnects, you can associate the pin group with only one fabric interconnect or with both fabric interconnects.

Procedure

- Step 1** In the **Navigation** pane, click the **SAN** tab.
- Step 2** In the **SAN** tab, expand **SAN ► SAN Cloud** .
- Step 3** Right-click **SAN Pin Groups** and select **Create SAN Pin Group**.
- Step 4** Enter a unique name and description for the pin group.
- Step 5** To pin traffic for fabric interconnect A, do the following in the **Targets** area:
- Check the **Fabric A** check box.
 - Click the drop-down arrow on the **Interface** field and navigate through the tree-style browser to select the uplink Fibre Channel port you want to associate with the pin group.
- Step 6** To pin traffic for fabric interconnect B, do the following in the **Targets** area:
- Check the **Fabric B** check box.
 - Click the drop-down arrow on the **Interface** field and navigate through the tree-style browser to select the uplink Fibre Channel port you want to associate with the pin group.
- Step 7** Click **OK**.
-

What to Do Next

Include the pin group in a vHBA template.

Deleting a SAN Pin Group

Procedure

- Step 1** In the **Navigation** pane, click the **SAN** tab.
- Step 2** In the **SAN** tab, expand **SAN ► SAN Cloud ► SAN Pin Groups** .
- Step 3** Right-click the SAN pin group you want to delete and select **Delete**.
- Step 4** If Cisco UCS Manager displays a confirmation dialog box, click **Yes**.
-



CHAPTER 20

Configuring WWN Pools

This chapter includes the following sections:

- [WWN Pools, page 163](#)
- [Creating a WWNN Pool, page 164](#)
- [Deleting a WWNN Pool, page 165](#)
- [Creating a WWPN Pool, page 165](#)
- [Deleting a WWPN Pool, page 166](#)

WWN Pools

A WWN pool is a collection of WWNs for use by the Fibre Channel vHBAs in a Cisco UCS instance. You create separate pools for the following:

- WW node names assigned to the server
- WW port names assigned to the vHBA



Important

A WWN pool can include only WWNNs or WWPNs in the ranges from 20:00:00:00:00:00:00:00 to 20:FF:FF:FF:FF:FF:FF:FF or from 50:00:00:00:00:00:00:00 to 5F:FF:FF:FF:FF:FF:FF:FF. All other WWN ranges are reserved.

If you use WWN pools in service profiles, you do not have to manually configure the WWNs that will be used by the server associated with the service profile. In a system that implements multi-tenancy, you can use a WWN pool to control the WWNs used by each organization.

You assign WWNs to pools in blocks. For each block or individual WWN, you can assign a boot target.

WWNN Pools

A WWNN pool is a WWN pool which contains only WW node names. If you include a pool of WWNNs in a service profile, the associated server is assigned a WWNN from that pool.

WWPN Pools

A WWPN pool is a WWN pool which contains only WW port names. If you include a pool of WWPNs in a service profile, the port on each vHBA of the associated server is assigned a WWPN from that pool.

Creating a WWNN Pool



Important

A WWN pool can include only WWNNs or WWPNs in the ranges from 20:00:00:00:00:00:00 to 20:FF:FF:FF:FF:FF:FF or from 50:00:00:00:00:00:00 to 5F:FF:FF:FF:FF:FF:FF. All other WWN ranges are reserved.

Procedure

- Step 1** In the **Navigation** pane, click the **SAN** tab.
- Step 2** In the **SAN** tab, expand **SAN ► Pools**.
- Step 3** Expand the node for the organization where you want to create the pool.
If the system does not include multi-tenancy, expand the **root** node.
- Step 4** Right-click **WWNN Pools** and select **Create WWNN Pool**.
- Step 5** In the **Define Name and Description** page of the **Create WWNN Pool** wizard:
 - a) Enter a unique name and description for the WWNN Pool.
This name can be between 1 and 16 alphanumeric characters. You cannot use spaces or any special characters, and you cannot change this name after the object has been saved.
 - b) Click **Next**.
- Step 6** In the **Add WWN Blocks** page of the **Create WWNN Pool** wizard:
 - a) Click **Add**.
 - b) In the **Create WWN Block** page, complete the following fields:
 - In the **From** field, enter the first WWNN in the pool.
 - In the **Size** field, enter the number of WWNNs to include in the pool.
 - c) Click **Finish Stage**.
 - d) Do one of the following:
 - Repeat steps a through c to add another block to the pool.
 - Click **Next** to move to the next page.
- Step 7** In the **Add Individual WWN** page of the **Create WWNN Pool** wizard:
 - a) Click **Add**.
 - b) In the **World Wide Name** field, enter the WWNN initiator.
 - c) In the **Name** field, enter a unique name for the WWNN initiator.
 - d) In the **Description** field, enter a description of the WWNN initiator.
 - e) Click **Add** to expand the **Boot Target** area.
 - f) In the **Boot Target WWNN** field, enter the WWNN associated with the initiator.

- g) In the **Boot Target LUN** field, enter the unique identifier for the LUN associated with the initiator.
- h) Click **OK**.

Step 8 Click **Finish**.

Deleting a WWNN Pool

Procedure

- Step 1** In the **Navigation** pane, click the **SAN** tab.
 - Step 2** In the **SAN** tab, expand **SAN ► Pools ► Organization_Name** .
 - Step 3** Expand the **WWNN Pools** node.
 - Step 4** Right-click the WWNN pool you want to delete and select **Delete**.
 - Step 5** If Cisco UCS Manager displays a confirmation dialog box, click **Yes**.
-

Creating a WWPN Pool



Important

A WWN pool can include only WWNNs or WWPNs in the ranges from 20:00:00:00:00:00:00:00 to 20:FF:FF:FF:FF:FF:FF:FF:FF or from 50:00:00:00:00:00:00:00 to 5F:FF:FF:FF:FF:FF:FF:FF:FF. All other WWN ranges are reserved.

Procedure

- Step 1** In the **Navigation** pane, click the **SAN** tab.
- Step 2** In the **SAN** tab, expand **SAN ► Pools** .
- Step 3** Expand the node for the organization where you want to create the pool.
If the system does not include multi-tenancy, expand the **root** node.
- Step 4** Right-click **WWPN Pools** and select **Create WWPN Pool**.
- Step 5** In the **Define Name and Description** page of the **Create WWN Pool** wizard:
 - a) Enter a unique name and description for the WWPN Pool.
This name can be between 1 and 16 alphanumeric characters. You cannot use spaces or any special characters, and you cannot change this name after the object has been saved.
 - b) Click **Next**.
- Step 6** In the **Add WWN Blocks** page of the **Create WWPN Pool** wizard:
 - a) Click **Add**.
 - b) In the **Create WWN Block** page, complete the following fields:

- In the **From** field, enter the first WWPN in the pool.
 - In the **Size** field, enter the number of WWPNs to include in the pool.
- c) Click **Finish Stage**.
- d) Do one of the following:
- Repeat steps a through c to add another block to the pool.
 - Click **Next** to move to the next page.

Step 7 In the **Add Individual WWN** page of the **Create WWPN Pool** wizard:

- a) Click **Add**.
- b) In the **World Wide Name** field, enter the WWPN initiator.
- c) In the **Name** field, enter a unique name for the WWPN initiator.
- d) In the **Description** field, enter a description of the WWPN initiator.
- e) Click **Add** to expand the **Boot Target** area.
- f) In the **Boot Target WWPN** field, enter the WWPN associated with the initiator.
- g) In the **Boot Target LUN** field, enter the unique identifier for the LUN associated with the initiator.
- h) Click **OK**.

Step 8 Click **Finish**.

What to Do Next

Include the WWPN pool in a vHBA template.

Deleting a WWPN Pool

Procedure

- Step 1** In the **Navigation** pane, click the **SAN** tab.
 - Step 2** In the **SAN** tab, expand **SAN > Pools > Organization_Name** .
 - Step 3** Expand the **WWPN Pools** node.
 - Step 4** Right-click the WWPN pool you want to delete and select **Delete**.
 - Step 5** If Cisco UCS Manager displays a confirmation dialog box, click **Yes**.
-



CHAPTER 21

Configuring Storage-Related Policies

This chapter includes the following sections:

- [Configuring vHBA Templates, page 167](#)
- [Configuring Fibre Channel Adapter Policies, page 170](#)

Configuring vHBA Templates

vHBA Template

This template is a policy that defines how a vHBA on a server connects to the SAN. It is also referred to as a vHBA SAN connectivity template.

You need to include this policy in a service profile for it to take effect.

Creating a vHBA Template

Before You Begin

This policy requires that one or more of the following resources already exist in the system:

- Named VSAN
- WWNN pool or WWPN pool
- SAN pin group
- Statistics threshold policy

Procedure

- Step 1** In the **Navigation** pane, click the **SAN** tab.
- Step 2** On the **SAN** tab, expand **SAN ► Policies**.
- Step 3** Expand the node for the organization where you want to create the policy.

If the system does not include multi-tenancy, expand the **root** node.

Step 4 Right-click the **vHBA Templates** node and choose **Create vHBA Template**.

Step 5 In the **Create vHBA Template** dialog box, complete the following fields:

Name	Description
Name field	The name of the virtual HBA template. This name can be between 1 and 16 alphanumeric characters. You cannot use spaces or any special characters, and you cannot change this name after the object has been saved.
Description field	A user-defined description of the template.
Fabric ID field	The name of the fabric interconnect that vHBAs created with this template are associated with.
Select VSAN drop-down list	The VSAN to associate with vHBAs created from this template.
Create VSAN link	Click this link if you want to create a VSAN.
Template Type field	This can be: <ul style="list-style-type: none"> • Initial Template—vHBAs created from this template are not updated if the template changes. • Updating Template—vHBAs created from this template are updated if the template changes.
WWN Pool drop-down list	The WWN pool that a vHBA created from this template uses to derive its WWN address.
Pin Group drop-down list	The LAN pin group that is associated with vHBAs created from this template.
Stats Threshold Policy drop-down list	The statistics collection policy that is associated with vHBAs created from this template.

Step 6 Click **OK**.

What to Do Next

Include the vHBA template in a service profile.

Deleting a vHBA Template

Procedure

- Step 1** In the **Navigation** pane, click the **SAN** tab.
 - Step 2** On the **SAN** tab, expand **SAN ► Policies ► Organization_Name**.
 - Step 3** Expand the **vHBA Templates** node.
 - Step 4** Right-click the vHBA template that you want to delete and choose **Delete**.
 - Step 5** If Cisco UCS Manager displays a confirmation dialog box, click **Yes**.
-

Binding a vHBA to a vHBA Template

You can bind a vHBA associated with a service profile to a vHBA template. When you bind the vHBA to a vHBA template, Cisco UCS Manager configures the vHBA with the values defined in the vHBA template. If the existing vHBA configuration does not match the vHBA template, Cisco UCS Manager reconfigures the vHBA. You can only change the configuration of a bound vHBA through the associated vHBA template. You cannot bind a vHBA to a vHBA template if the service profile that includes the vHBA is already bound to a service profile template.



Important If the vHBA is reconfigured when you bind it to a template, Cisco UCS Manager reboots the server associated with the service profile.

Procedure

- Step 1** In the **Navigation** pane, click the **Servers** tab.
 - Step 2** On the **Servers** tab, expand **Servers ► Service Profiles**.
 - Step 3** Expand the node for the organization that includes the service profile with the vHBA you want to bind. If the system does not include multi-tenancy, expand the **root** node.
 - Step 4** Expand **Service_Profile_Name ► vHBAs**.
 - Step 5** Click the vHBA you want to bind to a template.
 - Step 6** In the **Work** pane, click the **General** tab.
 - Step 7** In the **Actions** area, click **Bind to a Template**.
 - Step 8** In the **Bind to a vHBA Template** dialog box, do the following:
 - a) From the **vHBA Template** drop-down list, choose the template to which you want to bind the vHBA.
 - b) Click **OK**.
 - Step 9** In the warning dialog box, click **Yes** to acknowledge that Cisco UCS Manager may need to reboot the server if the binding causes the vHBA to be reconfigured.
-

Unbinding a vHBA from a vHBA Template

Procedure

- Step 1** In the **Navigation** pane, click the **Servers** tab.
- Step 2** On the **Servers** tab, expand **Servers** ► **Service Profiles**.
- Step 3** Expand the node for the organization that includes the service profile with the vHBA you want to unbind. If the system does not include multi-tenancy, expand the **root** node.
- Step 4** Expand *Service_Profile_Name* ► **vHBAs**.
- Step 5** Click the vHBA you want to unbind from a template.
- Step 6** In the **Work** pane, click the **General** tab.
- Step 7** In the **Actions** area, click **Unbind from a Template**.
- Step 8** If Cisco UCS Manager displays a confirmation dialog box, click **Yes**.
-

Configuring Fibre Channel Adapter Policies

Ethernet and Fibre Channel Adapter Policies

These policies govern the host-side behavior of the adapter, including how the adapter handles traffic. For example, you can use these policies to change default settings for the following:

- Queues
- Interrupt handling
- Performance enhancement
- RSS hash
- Failover in a cluster configuration with two fabric interconnects

By default, Cisco UCS provides a set of Ethernet adapter policies and Fibre Channel adapter policies. These policies include the recommended settings for each supported server operating system. Operating systems are sensitive to the settings in these policies. Storage vendors typically require non-default adapter settings. You can find the details of these required settings on the support list provided by those vendors.

**Note**

For Fibre Channel adapter policies, the values displayed by Cisco UCS Manager may not match those displayed by applications such as QLogic SANsurfer. For example, the following values may result in an apparent mismatch between SANsurfer and Cisco UCS Manager:

- **Max LUNs Per Target**—SANsurfer has a maximum of 256 LUNs and does not display more than that number. Cisco UCS Manager supports a higher maximum number of LUNs.
- **Link Down Timeout**—In SANsurfer, you configure the timeout threshold for link down in seconds. In Cisco UCS Manager, you configure this value in milliseconds. Therefore, a value of 5500 ms in Cisco UCS Manager displays as 5s in SANsurfer.
- **Max Data Field Size**—SANsurfer has allowed values of 512, 1024, and 2048. Cisco UCS Manager allows you to set values of any size. Therefore, a value of 900 in Cisco UCS Manager displays as 512 in SANsurfer.

Creating a Fibre Channel Adapter Policy

**Tip**

If the fields in an area are not displayed, click the **Expand** icon to the right of the heading.

Procedure

- Step 1** In the **Navigation** pane, click the **SAN** tab.
- Step 2** On the **SAN** tab, expand **SAN ► Policies**.
- Step 3** Expand the node for the organization where you want to create the policy.
If the system does not include multi-tenancy, expand the **root** node.
- Step 4** Right-click **Fibre Channel Policies** and choose **Create Fibre Channel Adapter Policy**.
- Step 5** Enter a name and description for the policy in the following fields:

Name	Description
Name field	The name of the policy. This name can be between 1 and 16 alphanumeric characters. You cannot use spaces or any special characters, and you cannot change this name after the object has been saved.
Description field	A description of the policy. We recommend including information about where and when the policy should be used.

- Step 6** (Optional) In the **Queues** area, adjust the following values for the transmit, receive, and SCSI IO queues:

Name	Description
Count field	The number of SCSI IO queue resources the system should allocate. Enter an integer between 1 and 8.

Name	Description
	Note You can only have one transmit queue and one receive queue.
Ring size field	The number of descriptors in each queue. For transmit and receive queues, enter an integer between 64 and 128. For completion queues, enter an integer between 64 and 512.

Step 7 (Optional) In the **FLogi/PLogi** area, adjust the following values:

Name	Description
Flogi Area	
Retries field	The number of times that the system tries to log in to the fabric after the first failure. Enter an integer between 0 and 255. To specify that the system continue to try indefinitely, enter -1 in this field.
Timeout field	The number of milliseconds that the system waits before it tries to log in again. Enter an integer between 1000 and 255000.
Plogi Area	
Retries field	The number of times that the system tries to log into a port after the first failure. Enter an integer between 0 and 255.
Timeout field	The number of milliseconds that the system waits before it tries to log in again. Enter an integer between 1000 and 255000.

Step 8 (Optional) In the **Error Handling** area, adjust the following values:

Name	Description
Error Detect Timeout field	The number of milliseconds to wait before the system assumes that there has been an error. Enter an integer between 1,000 and 100,000. The default is 2,000.
Port Down Timeout field	The number of milliseconds a remote Fibre Channel port should be offline before informing the SCSI upper layer that the port is unavailable. Enter an integer between 0 and 240,000. The default is 10,000.
Port Down IO Retry field	The number of times an IO request to a port is returned because the port is busy before the system decides the port is unavailable.

Name	Description
	Enter an integer between 0 and 255. The default is 8.
Link Down Timeout field	The number of milliseconds the uplink port should be offline before it informs the system that the uplink port is down and fabric connectivity has been lost. Enter an integer between 0 and 240,000. The default is 30,000.
Resource Allocation Timeout field	The number of milliseconds to wait before the system assumes that a resource cannot be properly allocated. Enter an integer between 5,000 and 100,000. The default is 10,000.
FCP Error Recovery field	Whether the system uses FCP Sequence Level Error Recovery protocol (FC-TAPE). This can be: <ul style="list-style-type: none"> • disabled • enabled

Step 9 (Optional) In the **FC Port Behavior** area, adjust the following values:

Name	Description
IO Throttle Count field	The number of IO operations that can be pending in the vHBA at one time. Enter an integer between 256 and 4,096. The default is 512.
Max LUNs Per Target field	The maximum number of LUNs that the driver supports. This is usually an operating system platform limitation. Enter an integer between 1 and 1,024. The default is 256.
Max Data Field Size field	The maximum size of the Fibre Channel frame payload bytes that the vHBA supports. Enter an integer between 256 and 2,112. The default is 2,112.

Step 10 Click **OK**.

Deleting a Fibre Channel Adapter Policy

Procedure

- Step 1** In the **Navigation** pane, click the **SAN** tab.
 - Step 2** On the **SAN** tab, expand **SAN ► Policies ► *Organization_Name***.
 - Step 3** Expand the **Fibre Channel Policies** node.
 - Step 4** Right-click the policy you want to delete and choose **Delete**.
 - Step 5** If Cisco UCS Manager displays a confirmation dialog box, click **Yes**.
-



PART **V**

Server Configuration

- [Configuring Server-Related Pools, page 177](#)
- [Configuring Server-Related Policies, page 183](#)
- [Configuring Service Profiles, page 207](#)
- [Installing an OS on a Server, page 253](#)



CHAPTER 22

Configuring Server-Related Pools

This chapter includes the following sections:

- [Configuring Server Pools, page 177](#)
- [Configuring UUID Suffix Pools, page 179](#)
- [Configuring the Management IP Pool, page 181](#)

Configuring Server Pools

Server Pools

A server pool contains a set of servers. These servers typically share the same characteristics. Those characteristics can be their location in the chassis, or an attribute such as server type, amount of memory, local storage, type of CPU, or local drive configuration. You can manually assign a server to a server pool, or use server pool policies and server pool policy qualifications to automate the assignment.

If your system implements multi-tenancy through organizations, you can designate one or more server pools to be used by a specific organization. For example, a pool that includes all servers with two CPUs could be assigned to the Marketing organization, while all servers with 64 GB memory could be assigned to the Finance organization.

A server pool can include servers from any chassis in the system. A given server can belong to multiple server pools.

Creating a Server Pool

Procedure

- Step 1** In the **Navigation** pane, click the **Servers** tab.
- Step 2** On the **Servers** tab, expand **Servers** ► **Pools**.
- Step 3** Expand the node for the organization where you want to create the pool.

If the system does not include multi-tenancy, expand the **root** node.

Step 4 Right-click the **Server Pools** node and select **Create Server Pool**.

Step 5 On the **Set Name and Description** page of the **Create Server Pool** wizard, complete the following fields:

Name	Description
Name field	The name of the server pool. This name can be between 1 and 16 alphanumeric characters. You cannot use spaces or any special characters, and you cannot change this name after the object has been saved.
Description field	A user-defined description of the server pool.

Step 6 Click **Next**.

Step 7 On the **Add Servers** page of the **Create Server Pool** wizard:

- a) Select one or more servers from the **Available Servers** table.
- b) Click the >> button to add the servers to the server pool.
- c) When you have added all desired servers to the pool, click **Finish**.

Deleting a Server Pool

Procedure

- Step 1** In the **Navigation** pane, click the **Servers** tab.
- Step 2** On the **Servers** tab, expand **Servers > Pools > Organization_Name**.
- Step 3** Expand the **Server Pools** node.
- Step 4** Right-click the pool you want to delete and select **Delete**.
- Step 5** If Cisco UCS Manager displays a confirmation dialog box, click **Yes**.

Adding Servers to a Server Pool

Procedure

- Step 1** In the **Navigation** pane, click the **Servers** tab.
- Step 2** On the **Servers** tab, expand **Servers > Pools > Organization_Name**.
- Step 3** Right-click the pool to which you want to add one or more servers and select **Add Servers to Server Pool**.
- Step 4** In the **Add Servers to Server Pool** dialog box, do the following:
 - a) In the **Servers** table, select the servers that you want to add to the server pool.
You can use the Shift key or Ctrl key to select multiple entries.

- b) Click the >> button to move those servers to the **Pooled Servers** table and add them to the server pool.
 - c) Click **OK**.
-

Removing Servers from a Server Pool

Procedure

- Step 1** In the **Navigation** pane, click the **Servers** tab.
 - Step 2** On the **Servers** tab, expand **Servers > Pools > Organization_Name**.
 - Step 3** Right-click the pool from which you want to remove one or more servers and select **Add Servers to Server Pool**.
 - Step 4** In the **Add Servers to Server Pool** dialog box, do the following:
 - a) In the **Pooled Servers** table, select the servers that you want to remove from the server pool. You can use the Shift key or Ctrl key to select multiple entries.
 - b) Click the << button to move those servers to the **Servers** table and remove them from the server pool.
 - c) Click **OK**.
-

Configuring UUID Suffix Pools

UUID Suffix Pools

A UUID suffix pool is a collection of SMBIOS UUIDs that are available to be assigned to servers. The first number of digits that constitute the prefix of the UUID are fixed. The remaining digits, the UUID suffix, is variable. A UUID suffix pool ensures that these variable values are unique for each server associated with a service profile which uses that particular pool to avoid conflicts.

If you use UUID suffix pools in service profiles, you do not have to manually configure the UUID of the server associated with the service profile.

Creating a UUID Suffix Pool

Procedure

- Step 1** In the **Navigation** pane, click the **Servers** tab.
- Step 2** On the **Servers** tab, expand **Servers > Pools**.
- Step 3** Expand the node for the organization where you want to create the pool.

If the system does not include multi-tenancy, expand the **root** node.

Step 4 Right-click **UUID Suffix Pools** and select **Create UUID Suffix Pool**.

Step 5 In the **Define Name and Description** page of the **Create UUID Suffix Pool** wizard, fill in the following fields:

Name	Description
Name field	The name of the UUID pool. This name can be between 1 and 16 alphanumeric characters. You cannot use spaces or any special characters, and you cannot change this name after the object has been saved.
Description field	The user-defined description of the pool.
Prefix field	This can be: <ul style="list-style-type: none"> • derived—The system creates the suffix. • other—You specify the desired suffix. If you select this option, Cisco UCS Manager GUI displays a text field where you can enter the desired suffix, in the format <code>XXXXXXXX-XXXX-XXXX</code>.

Step 6 In the **Add UUID Blocks** page of the **Create UUID Suffix Pool** wizard:

- Click **Add**.
- In the **Create a Block of UUID Suffixes** page, enter the first UUID suffix in the pool and the number of UUID suffixes to include in the pool.
- Click **OK**.
- If you want to add another block to the pool, repeat steps a through c.

Step 7 Click **Finish** to complete the wizard.

What to Do Next

Include the UUID suffix pool in a service profile and/or template.

Deleting a UUID Suffix Pool

Procedure

Step 1 In the **Navigation** pane, click the **Servers** tab.

Step 2 On the **Servers** tab, expand **Servers** ► **Pools** ► **Organization_Name**.

Step 3 Expand the **UUID Suffix Pools** node.

Step 4 Right-click the pool you want to delete and select **Delete**.

Step 5 If Cisco UCS Manager displays a confirmation dialog box, click **Yes**.

Configuring the Management IP Pool

Management IP Pool

The management IP pool is a collection of external IP addresses. Cisco UCS Manager reserves each block of IP addresses in the management IP pool for external access that terminates in the server controller (BMC) in a server.

Cisco UCS Manager uses the IP addresses in a management IP pool for external access to a server through the following:

- KVM console
- Serial over LAN
- IPMI

Creating an IP Address Block in the Management IP Pool

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
- Step 2** In the **Admin** tab, expand **All ► Communication Services**.
- Step 3** Right-click **Management IP Pool (ext-mgmt)** and select **Create Block of IP Addresses**.
- Step 4** In the **Create a Block of IP Addresses** dialog box, complete the following fields:

Name	Description
From field	The first IP address in the block.
Size field	The number of IP addresses in the pool.
Subnet Mask field	The subnet mask associated with the IP addresses in the block.
Default Gateway field	The default gateway associated with the IP addresses in the block.

- Step 5** Click **OK**.

Deleting an IP Address Block from the Management IP Pool

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
 - Step 2** In the **Admin** tab, expand **All ► Communication Services ► Management IP Pool (ext-mgmt)**.
 - Step 3** Right-click the IP address block that you want to delete and select **Delete**.
 - Step 4** If Cisco UCS Manager displays a confirmation dialog box, click **Yes**.
-



CHAPTER 23

Configuring Server-Related Policies

This chapter includes the following sections:

- [Configuring Boot Policies, page 183](#)
- [Configuring Chassis Discovery Policies, page 187](#)
- [Configuring IPMI Profiles, page 188](#)
- [Configuring Local Disk Configuration Policies, page 189](#)
- [Configuring Scrub Policies, page 192](#)
- [Configuring Serial over LAN Policies, page 193](#)
- [Configuring Server Autoconfiguration Policies, page 195](#)
- [Configuring Server Discovery Policies, page 196](#)
- [Configuring Server Inheritance Policies, page 198](#)
- [Configuring Server Pool Policies, page 199](#)
- [Configuring Server Pool Policy Qualifications, page 201](#)

Configuring Boot Policies

Boot Policy

The boot policy determines the following:

- Configuration of the boot device
- Location from which the server boots
- Order in which boot devices are invoked

For example, you can choose to have associated servers boot from a local device, such as a local disk or CD-ROM (VMedia), or you can select a SAN boot or a LAN (PXE) boot.

You must include this policy in a service profile, and that service profile must be associated with a server for it to take effect. If you do not include a boot policy in a service profile, the server uses the default settings in the BIOS to determine the boot order.

**Important**

Changes to a boot policy may be propagated to all servers created with an updating service profile template that includes that boot policy. Reassociation of the service profile with the server to rewrite the boot order information in the BIOS is auto-triggered.

Guidelines

When you create a boot policy, you can add one or more of the following to the boot policy and specify their boot order:

Boot type	Description
SAN boot	Boots from an operating system image on the SAN. You can specify a primary and a secondary SAN boot. If the primary boot fails, the server attempts to boot from the secondary. We recommend that you use a SAN boot, because it offers the most service profile mobility within the system. If you boot from the SAN, when you move a service profile from one server to another, the new server boots from the exact same operating system image. Therefore, the new server appears to be the exact same server to the network.
LAN boot	Boots from a centralized provisioning server. It is frequently used to install operating systems on a server from that server.
Local disk boot	If the server has a local drive, boots from that drive.
Virtual media boot	Mimics the insertion of a physical CD-ROM disk (read-only) or floppy disk (read-write) into a server. It is typically used to manually install operating systems on a server.

**Note**

The default boot order is as follows:

- 1 Local disk boot
- 2 LAN boot
- 3 Virtual media read-only boot
- 4 Virtual media read-write boot

Creating a Boot Policy

You can also create a local boot policy that is restricted to a service profile or service profile template. However, we recommend that you create a global boot policy that can be included in multiple service profiles or service profile templates.

Procedure

-
- Step 1** In the **Navigation** pane, click the **Servers** tab.
 - Step 2** On the **Servers** tab, expand **Servers** ► **Policies**.
 - Step 3** Expand the node for the organization where you want to create the policy.
If the system does not include multi-tenancy, expand the **root** node.
 - Step 4** Right-click **Boot Policies** and select **Create Boot Policy**.
The **Create Boot Policy** wizard displays.
 - Step 5** Enter a unique name and description for the policy.
This name can be between 1 and 16 alphanumeric characters. You cannot use spaces or any special characters, and you cannot change this name after the object has been saved.
 - Step 6** (Optional) To reboot all servers that use this boot policy after you make changes to the boot order, check the **Reboot on Boot Order Change** check box.
 - Step 7** (Optional) To ensure that Cisco UCS Manager uses any vNICs or vHBAs in the order shown in the **Boot Order** table, check the **Enforce vNIC/vHBA Name** check box.
If you do not check this check box, Cisco UCS Manager uses the priority specified in the vNIC or vHBA.
 - Step 8** To add a local disk, virtual CD-ROM, or virtual floppy to the boot order:
 - a) Click the down arrows to expand the **Local Devices** area.
 - b) Click one of the following links to add the device to the **Boot Order** table:
 - **Add Local Disk**
 - **Add CD-ROM**
 - **Add Floppy**
 - c) Add another boot device to the **Boot Order** table or click **OK** to finish.
 - Step 9** To add a LAN boot to the boot order:
 - a) Click the down arrows to expand the **vNICs** area.
 - b) Click the **Add LAN Boot** link.
 - c) In the **Add LAN Boot** dialog box, enter the name of the vNIC that you want to use for the LAN boot in the **vNIC** field, then click **OK**.
 - d) Add another device to the **Boot Order** table or click **OK** to finish.
 - Step 10** To add a SAN boot to the boot order:
 - a) Click the down arrows to expand the **vHBAs** area.
 - b) Click the **Add SAN Boot** link.
 - c) In the **Add SAN Boot** dialog box, complete the following fields, then click **OK**:

Name	Description
vHBA field	Enter the name of the vHBA you want to use for the SAN boot.
Type field	This can be: <ul style="list-style-type: none"> • primary—If the server boots using a SAN WWN address, this is the first address it tries. Each boot policy can have only one primary SAN boot location. • secondary—If the server cannot boot from the primary SAN location, it attempts to boot from this location. Each boot policy can have only one secondary SAN boot location.

- d) If this vHBA points to a bootable SAN image, click the **Add SAN Boot Target** link and, in the **Add SAN Boot Target** dialog box, complete the following fields, then click **OK**:

Name	Description
Boot Target LUN field	The LUN that corresponds to the location of the boot image.
Boot Target WWPN field	The WWPN that corresponds to the location of the boot image.
Type field	This can be: <ul style="list-style-type: none"> • primary—If the server boots using a SAN WWN address, this is the first address it tries. Each boot policy can have only one primary SAN boot location. • secondary—If the server cannot boot from the primary SAN location, it attempts to boot from this location. Each boot policy can have only one secondary SAN boot location.

- e) Add another boot device to the **Boot Order** table or click **OK** to finish.

What to Do Next

Include the boot policy in a service profile and/or template.

Deleting a Boot Policy

Procedure

- Step 1** In the **Navigation** pane, click the **Servers** tab.
 - Step 2** On the **Servers** tab, expand **Servers** ► **Policies** ► *Organization_Name*.
 - Step 3** Expand the **Boot Policies** node.
 - Step 4** Right-click the policy you want to delete and select **Delete**.
 - Step 5** If Cisco UCS Manager displays a confirmation dialog box, click **Yes**.
-

Configuring Chassis Discovery Policies

Chassis Discovery Policy

This discovery policy determines how the system reacts when you add a new chassis. If you create a chassis discovery policy, the system does the following:

- Automatically configures the chassis for the number of links between the chassis and the fabric interconnect specified in the policy.
- Specifies the power policy to be used by the chassis.

Configuring a Chassis Discovery Policy

Procedure

- Step 1** In the **Navigation** pane, click the **Equipment** tab.
 - Step 2** On the **Equipment** node, select the **Global Policies** tab in the **Work** pane.
 - Step 3** From the **Action** drop-down list, select the number of links to be used by the chassis.
 - Step 4** In the **Redundancy** field of the **Power Policy** area, select one of the following options:
 - **non-redundant**
 - **n+1**
 - **grid**
 - Step 5** Click **Save Changes**.
-

Configuring IPMI Profiles

IPMI Access Profile

This policy allows you to determine whether IPMI commands can be sent directly to the server, using the IP address. For example, you can send commands to retrieve sensor data from the BMC. This policy defines the IPMI access, including a username and password that can be authenticated locally on the server, and whether the access is read-only or read-write.

You must include this policy in a service profile and that service profile must be associated with a server for it to take effect.

Creating an IPMI Profile

Before You Begin

An IPMI profile requires that one or more of the following resources already exist in the system:

- Username with appropriate permissions that can be authenticated by the operating system of the server
- Password for the username
- Permissions associated with the username

Procedure

-
- Step 1** In the **Navigation** pane, click the **Servers** tab.
- Step 2** On the **Servers** tab, expand **Servers** ► **Policies**.
- Step 3** Expand the node for the organization where you want to create the policy. If the system does not include multi-tenancy, expand the **root** node.
- Step 4** Right-click **IPMI Profiles** and select **Create IPMI Profiles**.
- Step 5** In the **Create IPMI Profile** dialog box:
- a) Enter a unique name and description for the profile.
 - b) Click **OK**.
- Step 6** In the **IPMI Profile Users** area of the navigator, click +.
- Step 7** In the **User Properties** dialog box:
- a) Complete the following fields:

Name	Description
Name field	The username to associate with this IPMI profile.
Password field	The password associated with this username.
Confirm Password field	The password a second time for confirmation purposes.
Role field	This can be:

Name	Description
	<ul style="list-style-type: none"> • admin • Read Only

b) Click **OK**.

Step 8 Repeat Steps 6 and 7 to add another user.

Step 9 Click **OK** to return to the IPMI profiles in the **Work** pane.

What to Do Next

Include the IPMI profile in a service profile and/or template.

Deleting an IPMI Profile

Procedure

Step 1 In the **Navigation** pane, click the **Servers** tab.

Step 2 In the **Servers** tab, expand **Servers** ► **Policies** ► *Organization_Name*

Step 3 Expand the **IPMI Profiles** node.

Step 4 Right-click the profile you want to delete and select **Delete**.

Step 5 If Cisco UCS Manager displays a confirmation dialog box, click **Yes**.

Configuring Local Disk Configuration Policies

Local Disk Configuration Policy

This policy configures any optional SAS local drives that have been installed on a server through the onboard RAID controller of the local drive. This policy enables you to set a local disk mode for all servers that are associated with a service profile that includes the local disk configuration policy. The local disk modes include the following:

- **Any Configuration**—For a server configuration that carries forward the local disk configuration without any changes.
- **No Local Storage**—For a diskless workstation or a SAN only configuration. If you select this option, you cannot associate any service profile which uses this policy with a server that has a local disk.
- **No RAID**—For a server configuration that removes the RAID and leaves the disk MBR and payload unaltered.
- **RAID Mirrored**—For a 2-disk RAID 1 server configuration.
- **RAID Stripes**—For a 2-disk RAID 0 server configuration.

You must include this policy in a service profile, and that service profile must be associated with a server for it to take effect.

Creating a Local Disk Configuration Policy

Procedure

- Step 1** In the **Navigation** pane, click the **Servers** tab.
- Step 2** On the **Servers** tab, expand **Servers ► Policies**.
- Step 3** Expand the node for the organization where you want to create the policy.
If the system does not include multi-tenancy, expand the **root** node.
- Step 4** Right-click **Local Disk Config Policies** and select **Create Local Disk Configuration Policy**.
- Step 5** In the **Create Local Disk Configuration Policy** dialog box, complete the following fields:

Name	Description
Name field	<p>The name of the policy.</p> <p>This name can be between 1 and 16 alphanumeric characters. You cannot use spaces or any special characters, and you cannot change this name after the object has been saved.</p>
Description field	<p>A description of the policy. We recommend including information about where and when the policy should be used.</p>
Mode drop-down list	<p>This can be one of the following local disk policy modes:</p> <ul style="list-style-type: none"> • Any Configuration—For a server configuration that carries forward the local disk configuration without any changes. • No Local Storage—For a diskless workstation or a SAN only configuration. If you select this option, you cannot associate any service profile which uses this policy with a server that has a local disk. • No RAID—For a server configuration that removes the RAID and leaves the disk MBR and payload unaltered. • RAID Mirrored—For a 2-disk RAID 1 server configuration. • RAID Stripes—For a 2-disk RAID 0 server configuration.

Name	Description
	<p>Note If you choose No RAID and you apply this policy to a server that already has an operating system with RAID storage configured, the system does not remove the disk contents. Therefore, there may be no visible differences after you apply the No RAID mode.</p> <p>To make sure that any previous RAID configuration information is removed from a disk, apply a scrub policy that removes all disk information after you apply the No RAID configuration mode.</p>

Step 6 Click **OK**.

Changing a Local Disk Configuration Policy

This procedure describes how to change a local disk configuration policy from an associated service profile. You can also change a local disk configuration policy from the **Policies** node of the **Servers** tab.

Procedure

- Step 1** In the **Navigation** pane, click the **Servers** tab.
- Step 2** On the **Servers** tab, expand **Servers** ► **Service Profiles**.
- Step 3** Expand the organization that includes the service service profile with the local disk configuration policy you want to change.
If the system does not include multi-tenancy, expand the **root** node.
- Step 4** Click the service profile that contains the local disk configuration policy you want to change.
- Step 5** In the **Work** pane, click the **Policies** tab.
- Step 6** In the **Actions** area, click **Change Local Disk Configuration Policy**.
- Step 7** In the **Change Local Disk Configuration Policy** dialog box, choose one of the following options from the **Select the Local Disk Configuration Policy** drop-down list.

Option	Description
Use a Disk Policy	Select an existing local disk configuration policy from the list below this option. Cisco UCS Manager assigns this policy to the service profile.
Create a Local Disk Policy	Enables you to create a local disk configuration policy that can only be accessed by the selected service profile.
No Disk Policy	Does not use a local disk configuration policy for the selected service profile.

Step 8 Click **OK**.

Step 9 (Optional) Expand the **Local Disk Configuration Policy** area to confirm that the change has been made.

Deleting a Local Disk Configuration Policy

Procedure

- Step 1** In the **Navigation** pane, click the **Servers** tab.
- Step 2** On the **Servers** tab, expand **Servers** ► **Policies** ► *Organization_Name*.
- Step 3** Expand the **Local Disk Config Policies** node.
- Step 4** Right-click the policy you want to delete and select **Delete**.
- Step 5** If Cisco UCS Manager displays a confirmation dialog box, click **Yes**.

Configuring Scrub Policies

Scrub Policy

This policy determines what happens to local data on a server during the discovery process and when the server is disassociated from a service profile. This policy can ensure that the data on local drives is erased at those times.

Creating a Scrub Policy

Procedure

- Step 1** In the **Navigation** pane, click the **Servers** tab.
- Step 2** On the **Servers** tab, expand **Servers** ► **Policies**.
- Step 3** Expand the node for the organization where you want to create the policy.
If the system does not include multi-tenancy, expand the **root** node.
- Step 4** Right-click **Scrub Policies** and select **Create Scrub Policy**.
- Step 5** In the **Create Scrub Policy** wizard, complete the following fields:

Name	Description
Name field	The name of the policy. This name can be between 1 and 16 alphanumeric characters. You cannot use spaces or any special characters, and you cannot change this name after the object has been saved.
Description field	A description of the policy. We recommend including information about where and when the policy should be used.

Name	Description
Disk Scrub field	If this field is set to yes , when a service profile containing this scrub policy is associated with a server, the disks on that server are completely erased. If this field is set to no , the contents of the disks are preserved.
BIOS Settings Scrub field	If this field is set to yes , when a service profile containing this scrub policy is associated with a server, the BIOS settings on that server are reset to the defaults. If this field is set to no , the BIOS settings are preserved.

Step 6 Click **OK**.

Deleting a Scrub Policy

Procedure

- Step 1** In the **Navigation** pane, click the **Servers** tab.
 - Step 2** On the **Servers** tab, expand **Servers** ► **Policies** ► *Organization_Name*.
 - Step 3** Expand the **Scrub Policies** node.
 - Step 4** Right-click the policy you want to delete and select **Delete**.
 - Step 5** If Cisco UCS Manager displays a confirmation dialog box, click **Yes**.
-

Configuring Serial over LAN Policies

Serial over LAN Policy

This policy sets the configuration for the serial over LAN connection for all servers associated with service profiles that use the policy. By default, the serial over LAN connection is disabled.

If you implement a serial over LAN policy, we recommend that you also create an IPMI profile.

You must include this policy in a service profile and that service profile must be associated with a server for it to take effect.

Creating a Serial over LAN Policy

Procedure

- Step 1** In the **Navigation** pane, click the **Servers** tab.
- Step 2** On the **Servers** tab, expand **Servers ► Policies**.
- Step 3** Expand the node for the organization where you want to create the policy.
If the system does not include multi-tenancy, expand the **root** node.
- Step 4** Right-click **Serial over LAN Policies** and select **Create Serial over LAN Policy**.
- Step 5** In the **Create Serial over LAN Policy** wizard, complete the following fields:

Name	Description
Name field	The name of the policy. This name can be between 1 and 16 alphanumeric characters. You cannot use spaces or any special characters, and you cannot change this name after the object has been saved.
Description field	A description of the policy. We recommend including information about where and when the policy should be used.
Admin State field	This can be: <ul style="list-style-type: none"> • enabled • disabled
Speed drop-down list	This can be: <ul style="list-style-type: none"> • 115200 • 19200 • 38400 • 57600 • 9600

- Step 6** Click **OK**.

Deleting a Serial over LAN Policy

Procedure

- Step 1** In the **Navigation** pane, click the **Servers** tab.
 - Step 2** On the **Servers** tab, expand **Servers** ► **Policies** ► *Organization_Name*.
 - Step 3** Expand the **Serial over LAN Policies** node.
 - Step 4** Right-click the policy you want to delete and select **Delete**.
 - Step 5** If Cisco UCS Manager displays a confirmation dialog box, click **Yes**.
-

Configuring Server Autoconfiguration Policies

Server Autoconfiguration Policy

This policy determines whether one or more of the following is automatically applied to a new server:

- A server pool policy qualification that qualifies the server for one or more server pools
- An organization
- A service profile template that associates the server with a service profile created from that template

Creating an Autoconfiguration Policy

Before You Begin

This policy requires that one or more of the following resources already exist in the system:

- Server pool policy qualifications
- Service profile template
- Organizations, if a system implements multi-tenancy

Procedure

- Step 1** In the **Navigation** pane, click the **Equipment** tab.
- Step 2** Click the **Equipment** node.
- Step 3** In the **Work** pane, click the **Policies** tab.
- Step 4** Click the **Autoconfig Policies** subtab.
- Step 5** On the icon bar to the right of the table, click +.
If the + icon is disabled, click an entry in the table to enable it.
- Step 6** In the **Create Autoconfiguration Policy** dialog box, complete the following fields:

Name	Description
Name field	The name of the policy. This name can be between 1 and 16 alphanumeric characters. You cannot use spaces or any special characters, and you cannot change this name after the object has been saved.
Description field	A description of the policy. We recommend including information about where and when the policy should be used.
Qualification drop-down list	If you want to associate this policy with one or more specific server pools, choose the server pool qualification policy that identifies these pools from the drop-down list.
Org drop-down list	If you want to associate an organization with this policy, or if you want to change the current association, choose the desired organization from the drop-down list.
Service Profile Template Name drop-down list	The service profile template associated with this policy.

Step 7 Click **OK**.

Deleting an Autoconfiguration Policy

Procedure

- Step 1** In the **Navigation** pane, click the **Equipment** tab.
 - Step 2** Click the **Equipment** node.
 - Step 3** In the **Work** pane, click the **Policies** tab.
 - Step 4** Click the **Autoconfig Policies** subtab.
 - Step 5** Right-click the autoconfiguration policy that you want to delete and choose **Delete**.
 - Step 6** If Cisco UCS Manager displays a confirmation dialog box, click **Yes**.
-

Configuring Server Discovery Policies

Server Discovery Policy

This discovery policy determines how the system reacts when you add a new server. If you create a server discovery policy, you can control whether the system conducts a deep discovery when a server is added to a

chassis, or whether a user must first acknowledge the new server. By default, the system conducts a full discovery.

With this policy, an inventory of the server is conducted, then server pool policy qualifications are run to determine whether the new server qualifies for one or more server pools.

Creating a Server Discovery Policy

Before You Begin

If you plan to associate this policy with a server pool, create server pool policy qualifications.

Procedure

- Step 1** In the **Navigation** pane, click the **Equipment** tab.
 - Step 2** Click the **Equipment** node.
 - Step 3** In the **Work** pane, click the **Policies** tab.
 - Step 4** Click the **Server Discovery Policies** subtab.
 - Step 5** Click the + icon on the table icon bar to open the **Create Server Discovery Policy** dialog box.
 - Step 6** In the **Description** field, enter a description for the discovery policy.
 - Step 7** In the **Action** field, select one of the following options:
 - **immediate**—The system attempts to discover new servers automatically
 - **user-acknowledged**—The system waits until the user tells it to search for new servers
 - **diag**—Reserved for diagnostic use
 - Step 8** (Optional) To associate this policy with a server pool, select server pool policy qualifications from the **Qualification** drop-down list.
 - Step 9** (Optional) To include a scrub policy, select a policy from the **Scrub Policy** drop-down list.
 - Step 10** Click **OK**.
-

What to Do Next

Include the server discovery policy in a service profile and/or template.

Deleting a Server Discovery Policy

Procedure

-
- Step 1** In the **Navigation** pane, click the **Equipment** tab.
 - Step 2** Click the **Equipment** node.
 - Step 3** In the **Work** pane, click the **Policies** tab.
 - Step 4** Click the **Server Discovery Policies** subtab.
 - Step 5** Right-click the server discover policy that you want to delete and choose **Delete**.
 - Step 6** If Cisco UCS Manager displays a confirmation dialog box, click **Yes**.
-

Configuring Server Inheritance Policies

Server Inheritance Policy

This policy is invoked during the server discovery process to create a service profile for the server. All service profiles created from this policy use the values burned into the blade at manufacture. The policy performs the following:

- Analyzes the inventory of the server
- If configured, assigns the server to the selected organization
- Creates a service profile for the server with the identity burned into the server at manufacture

You cannot migrate a service profile created with this policy to another server.

Creating a Server Inheritance Policy

Procedure

-
- Step 1** In the **Navigation** pane, click the **Equipment** tab.
 - Step 2** Click the **Equipment** node.
 - Step 3** In the **Work** pane, click the **Policies** tab.
 - Step 4** Click the **Server Inheritance Policies** subtab.
 - Step 5** On the icon bar to the right of the table, click +.
If the + icon is disabled, click an entry in the table to enable it.
 - Step 6** In the **Create Server Inheritance Policy** dialog box, complete the following fields:

Name	Description
Name field	The name of the policy.

Name	Description
	This name can be between 1 and 16 alphanumeric characters. You cannot use spaces or any special characters, and you cannot change this name after the object has been saved.
Description field	A description of the policy. We recommend including information about where and when the policy should be used.
Qualification drop-down list	If you want to associate this policy with one or more specific server pools, choose the server pool qualification policy that identifies these pools from the drop-down list.
Org drop-down list	If you want to associate an organization with this policy, or if you want to change the current association, choose the desired organization from the drop-down list.

Step 7 Click **OK**.

Deleting a Server Inheritance Policy

Procedure

- Step 1** In the **Navigation** pane, click the **Equipment** tab.
 - Step 2** Click the **Equipment** node.
 - Step 3** In the **Work** pane, click the **Policies** tab.
 - Step 4** Click the **Server Inheritance Policies** subtab.
 - Step 5** Right-click the server inheritance policy that you want to delete and choose **Delete**.
 - Step 6** If Cisco UCS Manager displays a confirmation dialog box, click **Yes**.
-

Configuring Server Pool Policies

Server Pool Policy

This policy is invoked during the server discovery process. It determines what happens if server pool policy qualifications match a server to the target pool specified in the policy.

If a server qualifies for more than one pool and those pools have server pool policies, the server is added to all those pools.

Creating a Server Pool Policy

Before You Begin

This policy requires that one or more of the following resources already exist in the system:

- A minimum of one server pool
- Server pool policy qualifications, if you choose to have servers automatically added to pools

Procedure

Step 1 In the **Navigation** pane, click the **Servers** tab.

Step 2 On the **Servers** tab, expand **Servers ► Policies**.

Step 3 Expand the node for the organization where you want to create the policy.
If the system does not include multi-tenancy, expand the **root** node.

Step 4 Right-click **Server Pool Policies** and select **Create Server Pool Policy**.

Step 5 In the **Create Server Pool Policy** dialog box, complete the following fields:

Name	Description
Name field	The name of the policy. This name can be between 1 and 16 alphanumeric characters. You cannot use spaces or any special characters, and you cannot change this name after the object has been saved.
Description field	A description of the policy. We recommend including information about where and when the policy should be used.
Target Pool drop-down list	If you want to associate this policy with a server pool, select that pool from the drop-down list.
Qualification drop-down list	If you want to associate this policy with one or more specific server pools, choose the server pool qualification policy that identifies these pools from the drop-down list.

Step 6 Click **OK**.

Deleting a Server Pool Policy

Procedure

- Step 1** In the **Navigation** pane, click the **Servers** tab.
 - Step 2** On the **Servers** tab, expand **Servers** ► **Policies** ► *Organization_Name*.
 - Step 3** Expand the **Server Pool Policies** node.
 - Step 4** Right-click the policy you want to delete and select **Delete**.
 - Step 5** If Cisco UCS Manager displays a confirmation dialog box, click **Yes**.
-

Configuring Server Pool Policy Qualifications

Server Pool Policy Qualifications

This policy qualifies servers based on the inventory of a server conducted during the discovery process. The qualifications are individual rules that you configure in the policy to determine whether a server meets the selection criteria. For example, you can create a rule that specifies the minimum memory capacity for servers in a data center pool.

Qualifications are used in other policies to place servers, not just by the server pool policies. For example, if a server meets the criteria in a qualification policy, it can be added to one or more server pools or have a service profile automatically associated with it.

Depending upon the implementation, you may include server pool policy qualifications in the following policies:

- Autoconfiguration policy
- Chassis discovery policy
- Server discovery policy
- Server inheritance policy
- Server pool policy

Creating Server Pool Policy Qualifications

Procedure

- Step 1** In the **Navigation** pane, click the **Servers** tab.
- Step 2** On the **Servers** tab, expand **Servers** ► **Policies**.
- Step 3** Expand the node for the organization where you want to create the policy.

If the system does not include multi-tenancy, expand the **root** node.

Step 4 Right-click the **Server Pool Policy Qualifications** node and select **Create Server Pool Policy Qualification**.

Step 5 In the **Create Server Pool Policy Qualification** dialog box, enter a unique name and description for the policy.

Step 6 (Optional) To use this policy to qualify servers according to their adapter configuration:

a) Click **Create Adapter Qualifications**.

b) In the **Create Adapter Qualifications** dialog box, complete the following fields:

Name	Description
Type drop-down list	Choose the adapter type from the drop-down list. This can be: <ul style="list-style-type: none"> • fcoe—Fibre Channel over Ethernet • non-virtualized-eth-if • non-virtualized-fc-if • path-encap-consolidated • path-encap-virtual • protected-eth-if • protected-fc-if • protected-fcoe • virtualized-eth-if • virtualized-fc-if • virtualized-scsi-if
Maximum Capacity field	Enter the maximum capacity for the selected type.

c) Click **OK**.

Step 7 (Optional) To use this policy to qualify servers according to their physical location:

a) Click **Create Chassis and Server Qualifications**.

b) In the **Create Chassis and Server Qualifications** dialog box, click **Add**.

c) In the first page of the **Create Server Qualifications** wizard, enter the range of server slot numbers where the server should be located in the **From** field and the **To** field, then click **Finish Stage**.

Example:

For example, if you want to include all servers in slots 3 through 5 in all chassis in the policy, enter 3 in the **From** field and 5 in the **To** field. However, if you want to include all servers in slots 3 and 5, enter 3 in the **From** field and 3 **To** field to create an entry for slot 3. You will need to create another server qualification entry for slot 5.

d) In the second page of the **Create Server Qualifications** wizard, enter the range of chassis numbers where the server should be located in the **From** field and the **To** field, then click **Finish**.

Example:

For example, if you want to include all servers in chassis 1 through 4 in the policy, enter 1 in the **From** field and 4 in the **To** field. However, if you want to include all servers in chassis 1 and 4, enter 1 in the **From** field and 1 **To** field to create an entry for chassis 1. You will need to create another server qualification entry for chassis 4.

Step 8 (Optional) To use this policy to qualify servers according to their memory configuration:

- a) Click **Create Memory Qualifications**.
- b) In the **Create Memory Qualifications** dialog box, complete the following fields:

Name	Description
Clock field	The minimum clock speed required, in megahertz.
Latency field	The maximum latency allowed, in nanoseconds.
Min Cap field	The minimum CPU capacity required, in megabytes.
Max Cap field	The maximum CPU capacity allowed, in megabytes.
Width field	The minimum width of the data bus.
Units field	The unit of measure to associate with the value in the Width field.

- c) Click **OK**.

Step 9 (Optional) To use this policy to qualify servers according to their CPU/Cores configuration:

- a) Click **Create CPU/Cores Qualifications**.
- b) In the **Create CPU/Cores Qualifications** dialog box, complete the following fields:

Name	Description
Processor Architecture drop-down list	The CPU architecture to which this policy applies.
Min Number of Cores field	The minimum number of CPU cores required.
Max Number of Cores field	The maximum number of CPU cores allowed.
Min Number of Threads field	The minimum number of CPU threads required.
Max Number of Threads field	The maximum number of CPU threads allowed.
CPU Speed field	The minimum CPU speed required.
CPU Stepping field	The minimum CPU version required.

- c) Click **OK**.

Step 10 (Optional) To use this policy to qualify servers according to their storage configuration and capacity:

- a) Click **Create Storage Qualifications**.
- b) In the **Create Storage Qualifications** dialog box, complete the following fields:

Name	Description
Number of Blocks field	The minimum number of blocks required.
Block Size field	The minimum block size required, in bytes.
Min Cap field	The minimum storage capacity required, in megabytes.
Max Cap field	The maximum storage capacity allowed, in megabytes.
Per Disk Cap field	The minimum storage capacity per disk required, in gigabytes.
Units field	The number of units.

c) Click **OK**.

Step 11 Verify the qualifications in the table and correct if necessary.

Step 12 Click **OK**.

Deleting Server Pool Policy Qualifications

Procedure

- Step 1** In the **Navigation** pane, click the **Servers** tab.
- Step 2** On the **Servers** tab, expand **Servers** ► **Policies** ► *Organization_Name*.
- Step 3** Expand the **Server Pool Policy Qualifications** node.
- Step 4** Right-click the policy qualifications you want to delete and select **Delete**.
- Step 5** If Cisco UCS Manager displays a confirmation dialog box, click **Yes**.

Deleting Qualifications from Server Pool Policy Qualifications

Use this procedure to modify Server Pool Policy Qualifications by deleting one or more sets of qualifications.

Procedure

- Step 1** In the **Navigation** pane, click the **Servers** tab.
- Step 2** On the **Servers** tab, expand **Servers** ► **Policies** ► *Organization_Name*.
- Step 3** Expand the **Server Pool Policy Qualifications** node.
- Step 4** Choose the policy you want to modify.
- Step 5** In the **Work** pane, choose the **Qualifications** tab.
- Step 6** To delete a set of qualifications:

- a) In the table, choose the row that represents the set of qualifications.
- b) Right-click the row and select **Delete**.

Step 7 Click **Save Changes**.



CHAPTER 24

Configuring Service Profiles

This chapter includes the following sections:

- [Service Profiles that Override Server Identity, page 207](#)
- [Service Profiles that Inherit Server Identity, page 208](#)
- [Service Profile Templates, page 208](#)
- [Creating Service Profiles, page 209](#)
- [Working with Service Profile Templates, page 226](#)
- [Managing Service Profiles, page 242](#)

Service Profiles that Override Server Identity

This type of service profile provides the maximum amount of flexibility and control. This profile allows you to override the identity values that are on the server at the time of association and use the resource pools and policies set up in Cisco UCS Manager to automate some administration tasks.

You can disassociate this service profile from one server and then associate it with another server. This re-association can be done either manually or through an automated server pool policy. The burned-in settings, such as UUID and MAC address, on the new server are overwritten with the configuration in the service profile. As a result, the change in server is transparent to your network. You do not need to reconfigure any component or application on your network to begin using the new server.

This profile allows you to take advantage of and manage system resources through resource pools and policies, such as:

- Virtualized identity information, including pools of MAC addresses, WWN addresses, and UUIDs
- Ethernet and Fibre Channel adapter profile policies
- Firmware package policies
- Operating system boot order policies

Service Profiles that Inherit Server Identity

This hardware-based service profile is the simplest to use and create. This profile uses the default values in the server and mimics the management of a rack-mounted server. It is tied to a specific server and cannot be moved to another server.

You do not need to create pools or configuration policies to use this service profile.

This service profile inherits and automatically applies the identity and configuration information that is present at the time of association, such as the following:

- MAC addresses for the two NICs
- For the Cisco UCS CNA M71KR adapters, the WWN addresses for the two HBAs
- BIOS versions
- Server UUID



Important

The server identity and configuration information inherited through this service profile may not be the values burned into the server hardware at manufacture if those values were changed before this profile is associated with the server.

Service Profile Templates

With a service profile template, you can quickly create several service profiles with the same basic parameters, such as the number of vNICs and vHBAs, and with identity information drawn from the same pools.



Tip

If you need only one service profile with similar values to an existing service profile, you can clone a service profile in the Cisco UCS Manager GUI.

For example, if you need several service profiles with similar values to configure servers to host database software, you can create a service profile template, either manually or from an existing service profile. You then use the template to create the service profiles.

Cisco UCS supports the following types of service profile templates:

Initial template

Service profiles created from an initial template inherit all the properties of the template. However, after you create the profile, it is no longer connected to the template. If you need to make changes to one or more profiles created from this template, you must change each profile individually.

Updating template

Service profiles created from an updating template inherit all the properties of the template and remain connected to the template. Any changes to the template automatically update the service profiles created from the template.

Creating Service Profiles

Creating a Service Profile with the Expert Wizard

Procedure

- Step 1** In the **Navigation** pane, click the **Servers** tab.
- Step 2** On the **Servers** tab, expand **Servers** ► **Service Profiles**.
- Step 3** Expand the node for the organization where you want to create the service profile. If the system does not include multi-tenancy, expand the **root** node.
- Step 4** Right-click the organization and select **Create Service Profile (expert)**.
- Step 5** In the **Create Service Profile (expert)** wizard, complete the following:
 - [Page 1: Identifying the Service Profile](#) , page 209
 - [Page 2: Configuring the Storage Options](#), page 210
 - [Page 3: Configuring the Networking Options](#), page 215
 - [Page 4: Setting the Server Boot Order](#), page 218
 - [Page 5: Specifying the Server Assignment](#), page 220
 - [Page 6: Adding Operational Policies](#), page 221

Page 1: Identifying the Service Profile

This procedure directly follows the steps in [Creating a Service Profile with the Expert Wizard](#), page 209. It describes how to set the identity of a service profile on the **Identify Service Profile** page of the **Create Service Profile (expert)** wizard.

Procedure

- Step 1** In the **Name** field, enter a unique name that you can use to identify the service profile. This name can be between 1 and 16 alphanumeric characters. You cannot use spaces or any special characters, and you cannot change this name after the object has been saved.
- Step 2** From the **UUID Assignment** drop-down list, do one of the following:

Option	Description
Select (pool default used by default)	Assigns a UUID from the default UUID Suffix pool. Continue with Step 4.

Option	Description
Hardware Default	<p>Uses the UUID assigned to the server by the manufacturer.</p> <p>If you choose this option, the UUID remains unassigned until the service profile is associated with a server. At that point, the UUID is set to the UUID value assigned to the server by the manufacturer. If the service profile is later moved to a different server, the UUID is changed to match the new server.</p> <p>Continue with Step 4.</p>
XXXXXXXX-XXXX-XXXX-XXXX-XXXXXXXXXXXX	<p>Uses the UUID that you manually assign.</p> <p>Continue with Step 3.</p>
Pools <i>Pool_Name</i>	<p>Assigns a UUID from the UUID Suffix pool that you select from the list at the bottom of the drop-down list.</p> <p>Each pool name is followed by two numbers in parentheses that show the number of UUIDs still available in the pool and the total number of UUIDs in the pool.</p> <p>Continue with Step 4.</p>

Step 3 (Optional) If you selected the **XXXXXXXX-XXXX-XXXX-XXXX-XXXXXXXXXXXX** option, do the following:

- a) In the **UUID** field, enter the valid UUID that you want to assign to the server which uses this service profile.
- b) To verify that the selected UUID is available, click the **here** link.

Step 4 (Optional) In the text box, enter a description of this service profile. The description can contain up to 256 characters.

Step 5 Click **Next**.

What to Do Next

Complete the steps in [Page 2: Configuring the Storage Options, page 210](#).

Page 2: Configuring the Storage Options

This procedure directly follows [Page 1: Identifying the Service Profile, page 209](#). It describes how to configure the storage options for a service profile on the **Storage** page of the **Create Service Profile (expert)** wizard.

Procedure

Step 1 From the **Local Storage** drop-down list, choose one of the following:

Option	Description
Select Local Storage Policy to use	Assigns the default local disk storage policy to this service profile. Continue with Step 4.
Create a Specific Storage Policy	Enables you to create a local disk policy that can only be accessed by this service profile. Continue with Step 2.
Storage Policies <i>Policy_Name</i>	Select an existing local disk policy from the list at the bottom of the drop-down list. Cisco UCS Manager assigns this policy to the service profile. If you do not want use any of the existing policies, but instead want to create a new policy that all service profiles can access, continue with Step 3. Otherwise, continue with Step 4.

Step 2 (Optional) If you chose **Create a Specific Storage Policy**, do the following:

a) From the **Mode** drop-down list, choose one of the following:

- **Any Configuration**—For a server configuration that carries forward the local disk configuration without any changes.
- **No Local Storage**—For a diskless workstation or a SAN only configuration. If you select this option, you cannot associate any service profile which uses this policy with a server that has a local disk.
- **No RAID**—For a server configuration that removes the RAID and leaves the disk MBR and payload unaltered.
- **RAID Mirrored**—For a 2-disk RAID 1 server configuration.
- **RAID Stripes**—For a 2-disk RAID 0 server configuration.

Note If you choose **No RAID** and you apply this policy to a server that already has an operating system with RAID storage configured, the system does not remove the disk contents. Therefore, there may be no visible differences after you apply the **No RAID** mode.

To make sure that any previous RAID configuration information is removed from a disk, apply a scrub policy that removes all disk information after you apply the **No RAID** configuration mode.

b) Continue with Step 4.

Step 3 (Optional) To create a local disk configuration policy that will be available to all service profiles, do the following:

- a) Click the **Create Local Disk Configuration Policy** link.
- b) In the **Create Local Disk Configuration** dialog box, complete the fields.
For more information, see [Creating a Local Disk Configuration Policy](#), page 190.
- c) Click **OK**.

d) From the **Local Storage** drop-down list, choose the policy you created.

Step 4 From the **Scrub Policy** drop-down list, choose one of the following:

Option	Description
<not set>	Does not include a scrub policy in the service profile.
<i>Policy_Name</i>	Assigns an existing scrub policy to the service profile. If you do not want use any of the existing policies, but instead want to create a new policy that all service profiles can access, continue with Step 5. Otherwise, continue with Step 6.

Step 5 (Optional) To create a scrub policy that will be available to all service profiles, do the following:

- a) Click the **Create Scrub Policy** link .
- b) In the **Create Scrub Policy** dialog box, complete the fields.
For more information, see [Creating a Scrub Policy, page 192](#).
- c) Click **OK**.
- d) From the **Scrub Policy** drop-down list, choose the policy you created.

Step 6 In the **How would you like to configure SAN storage?** field, click one of the following options:

Option	Description
Simple	Allows you to create a maximum of two vHBAs for this service profile. Continue with Step 7.
Expert	Allows you to create an unlimited number of vHBAs for this service profile. Continue with Step 8.
No vHBAs	Does not include any vHBAs for connections to a Fibre Channel SAN in the service profile. Continue with Step 9.
Hardware Inherited	Uses the vHBAs assigned to the Fibre Channel adapter profile associated with the server. Continue with Step 9.

Step 7 (Optional) If you chose the simple SAN storage option, do the following:

- a) From the **WWNN Assignment** drop-down list:
 - Choose **Select (pool default used by default)** to use the default WWN pool.
 - Choose **Derived from vHBA** to use a WWN derived from the first vHBA you specify.
 - Choose one of the options listed under **Manual Using OUI** and then enter the WWN in the **World Wide Node Name** field.

You can specify a WWNN in the range from 20:00:00:00:00:00:00:00 to 20:FF:FF:FF:FF:FF:FF:FF or from 50:00:00:00:00:00:00:00 to 5F:FF:FF:FF:FF:FF:FF:FF. You can click the **here** link to verify that the WWNN you specified is available.

- Choose a WWN pool name from the list to have a WWN automatically assigned from the specified pool. Each pool name is followed by two numbers in parentheses that show the number of WWNs still available in the pool and the total number of WWNs in the pool.

b) In the **vHBA 0 (Fabric A)** area:

- In the **Name** field, enter a unique name for the vHBA.
- From the **Select VSAN** drop-down list, choose the name of the VSAN with which this vHBA should be associated.

If the VSAN you need is not in the drop-down list, click the **Create VSAN** link. For more information, see [Creating a Named VSAN, page 157](#).

- c) Repeat Step 7b in the **vHBA 1 (Fabric B)** area to create a VSAN for that vHBA.
 d) Continue with Step 9.

Step 8 (Optional) If you chose the expert SAN storage option, do the following:

a) From the **WWNN Assignment** drop-down list:

- Choose **Select (pool default used by default)** to use the default WWN pool.
- Choose **Derived from vHBA** to use a WWN derived from the first vHBA you specify.
- Choose one of the options listed under **Manual Using OUI** and then enter the WWN in the **World Wide Node Name** field.

You can specify a WWNN in the range from 20:00:00:00:00:00:00 to 20:FF:FF:FF:FF:FF:FF or from 50:00:00:00:00:00:00 to 5F:FF:FF:FF:FF:FF:FF. You can click the **here** link to verify that the WWNN you specified is available.

- Choose a WWN pool name from the list to have a WWN automatically assigned from the specified pool. Each pool name is followed by two numbers in parentheses that show the number of WWNs still available in the pool and the total number of WWNs in the pool.

- b) Click **Add** on the icon bar of the table to open the **Create vHBA** dialog box.
 c) Complete the following fields to specify the identity information for the vHBA:

Name	Description
Name field	The name of this vHBA. This name can be between 1 and 16 alphanumeric characters. You cannot use spaces or any special characters, and you cannot change this name after the object has been saved.
Use SAN Connectivity Template check box	Check this check box if you want to use a template to create the vHBA. Cisco UCS Manager GUI displays the vHBA Template drop-down list from which you can select the appropriate template, and the Adapter Performance Profile area from which you can select an adapter profile. Note You can only select this option if one or more SAN connectivity templates exist in the system.
Create vHBA Template link	Click this link if you want to create a vHBA template.

Name	Description
WWPN Assignment drop-down list	<p>If you want to:</p> <ul style="list-style-type: none"> • Use the default WWPN pool, leave this field set to Select (pool default used by default). • Use the WWPN assigned to the server by the manufacturer, select Hardware Default. • A specific WWPN, select 20:00:00:25:B5:00:00:00, 20:XX:XX:XX:XX:XX:XX:XX, or 5X:XX:XX:XX:XX:XX:XX:XX and enter the WWPN in the WWPN field. To verify that this WWPN is available, click the corresponding link. • A WWPN from a pool, select the pool name from the list. Each pool name is followed by a pair of numbers in parentheses. The first number is the number of available WWN addresses in the pool and the second is the total number of WWPN addresses in the pool.

d) In the **VSAN** area, complete the following fields:

Name	Description
Fabric ID field	The fabric interconnect associated with the component.
Select VSAN drop-down list box	The VSAN that this vHBA is associated with.
Create VSAN link	Click this link if you want to create a VSAN.
Pin Group drop-down list box	The pin group that this vHBA is associated with.
Create SAN Pin Group link	Click this link if you want to create a pin group.
Persistent Binding field	<p>This can be:</p> <ul style="list-style-type: none"> • disabled • enabled
Operational Parameters Section	
Stats Threshold Policy drop-down list box	The threshold policy that this vHBA is associated with.

e) In the **Adapter Performance Profile** area, complete the following fields:

Name	Description
Adapter Policy drop-down list box	The Fibre Channel adapter policy that this vHBA is associated with.

Name	Description
Create Fibre Channel Adapter Policy link	Click this link if you want to create a Fibre Channel adapter policy.

f) Click **OK**.

Step 9 Click **Next**.

What to Do Next

Complete [Page 3: Configuring the Networking Options, page 215](#).

Page 3: Configuring the Networking Options

This procedure directly follows [Page 2: Configuring the Storage Options, page 210](#). It describes how to configure the networking options, including LAN connectivity, on the **Networking** page of the **Create Service Profile (expert)** wizard.

Procedure

Step 1 In the **How would you like to configure LAN connectivity?** field, click one of the following options:

Option	Description
Simple	Allows you to create a maximum of two vNICs, in dual fabric mode, for this service profile. Continue with Step 2.
Expert	Allows you to create an unlimited number of vNICs for this service profile. Continue with Step 3.
No vNICs	Does not include any vNICs for connections to a LAN in the service profile. Any server associated with this service profile will not be able to communicate with a LAN unless you modify the service profile to add vNICs. Continue with Step 4.
Hardware Inherited	Uses the vNICs assigned to the Ethernet adapter profile associated with the server. Continue with Step 4.

Step 2 (Optional) If you chose the simple LAN connectivity option, do the following:

- a) In the **vNIC 0 (Fabric A)** area:
 - In the **Name** field, enter a unique name for the vNIC.
 - From the **Select Native VLAN** drop-down list, choose the name of the VLAN with which this vNIC should communicate.

If the VLAN you need is not in the drop-down list, click the **Create VLAN** link. For more information, see [Creating a Named VLAN, page 131](#).

- b) Repeat Step 2a in the **vNIC 1 (Fabric B)** area to create a VLAN for that vNIC.
- c) Continue with Step 4.

Step 3 If you chose the expert LAN connectivity option, do the following:

- a) Click **Add** on the icon bar of the table to open the **Create vNICs** dialog box.
- b) Complete the following fields to specify the identity information for the vNIC:

Name	Description
Name field	Enter a name for this vNIC.
Use LAN Connectivity Template check box	Check this check box if you want to use a template to create the vNIC. Cisco UCS Manager GUI displays the vNIC Template drop-down list from which you can select the appropriate template, and the Adapter Performance Profile area from which you can select an adapter profile. Note You can only select this option if one or more LAN connectivity templates exist in the system.
Create vNIC Template link	Click this link if you want to create a vNIC template.
MAC Address Assignment drop-down list	If you want to: <ul style="list-style-type: none"> • Use the default MAC address pool, leave this field set to Select (pool default used by default). • Use the MAC address assigned to the server by the manufacturer, select Hardware Default. • A specific MAC address, select 02:25:B5:XX:XX:XX and enter the address in the MAC Address field. To verify that this address is available, click the corresponding link. • A MAC address from a pool, select the pool name from the list. Each pool name is followed by a pair of numbers in parentheses. The first number is the number of available MAC addresses in the pool and the second is the total number of MAC addresses in the pool.

- c) In the **Fabric Interconnect** area, complete the following fields:

Name	Description
Fabric ID field	The fabric interconnect associated with the component. If you want this vNIC to be able to access the second fabric interconnect if the default one is unavailable, check the Enable Failover check box.

Name	Description
	Note Do not select Enable Failover if you plan to associate this vNIC configuration with a server that has a Cisco UCS 82598KR-CI 10-Gigabit Ethernet Adapter. If you do so, Cisco UCS Manager generates a configuration fault when you associate the service profile with the server.
VLAN Trunking field	If you want to use VLAN trunking, click Yes . Otherwise, select No .
Select VLAN drop-down list box	The VLAN that this vNIC is associated with.
Create VLAN link	Click this link if you want to create a VLAN.
Native VLAN check box	Check this check box if this vNIC is associated with the native VLAN.
Pin Group drop-down list box	Choose the LAN pin group you want associated with this vNIC.
Create LAN Pin Group link	Click this link if you want to create a LAN pin group.
Operational Parameters Section	
Stats Threshold Policy drop-down list box	The statistics collection policy that this vNIC is associated with.

d) In the **Adapter Performance Profile** area, complete the following fields:

Name	Description
Adapter Policy drop-down list box	The Ethernet adapter policy that this vNIC is associated with.
Create Ethernet Adapter Policy link	Click this link if you want to create an Ethernet adapter policy.
QoS drop-down list box	The quality of service policy that this vNIC is associated with.
Create QoS Policy link	Click this link if you want to create a quality of service policy.
Network Control Policy drop-down list box	The network control policy that this vNIC is associated with.
Create Network Control Policy link	Click this link if you want to create a network control policy.

e) Click **OK**.

Step 4 Click **Next**.

What to Do Next

Complete [Page 4: Setting the Server Boot Order](#), page 218.

Page 4: Setting the Server Boot Order

This procedure directly follows [Page 3: Configuring the Networking Options](#), page 215. It describes how to set the server boot order options on the **Server Boot Order** page of the **Create Service Profile (expert)** wizard.

Procedure

Step 1 From the **Boot Policy** drop-down list, choose one of the following:

Option	Description
Select Boot Policy to use	Assigns the default boot policy to this service profile. Continue with Step 7.
Create a Specific Boot Policy	Enables you to create a local boot policy that can only be accessed by this service profile. Continue with Step 3.
Boot Policies <i>Policy_Name</i>	Assigns an existing boot policy to the service profile. If you choose this option, Cisco UCS Manager displays the details of the policy. If you do not want use any of the existing policies, but instead want to create a policy that all service profiles can access, click Create Boot Policy and continue with Step 2. Otherwise, continue with Step 7.

Step 2 If you chose to create a boot policy, in the **Create Boot Policy** dialog box, enter a unique name and description for the policy.

This name can be between 1 and 16 alphanumeric characters. You cannot use spaces or any special characters, and you cannot change this name after the object has been saved.

Step 3 (Optional) To reboot all servers that use this boot policy after you make changes to the boot order, check the **Reboot on Boot Order Change** check box.

Step 4 To add a local disk, virtual CD-ROM, or virtual floppy to the boot order:

- a) Click the down arrows to expand the **Local Devices** area.
- b) Click one of the following links to add the device to the **Boot Order** table:

- **Add Local Disk**
- **Add CD-ROM**
- **Add Floppy**

- c) Add another boot device to the **Boot Order** table or click **OK** to finish.

Step 5 To add a LAN boot to the boot order:

- a) Click the down arrows to expand the **vNICs** area.
- b) Click the **Add LAN Boot** link.

- c) In the **Add LAN Boot** dialog box, enter the name of the vNIC that you want to use for the LAN boot in the vNIC field, then click **OK**.
- d) Add another device to the **Boot Order** table or click **OK** to finish.

Step 6 To add a SAN boot to the boot order:

- a) Click the down arrows to expand the **vHBAs** area.
- b) Click the **Add SAN Boot** link.
- c) In the **Add SAN Boot** dialog box, complete the following fields, then click **OK**:

Name	Description
vHBA field	Enter the name of the vHBA you want to use for the SAN boot.
Type field	This can be: <ul style="list-style-type: none"> • primary—If the server boots using a SAN WWN address, this is the first address it tries. Each boot policy can have only one primary SAN boot location. • secondary—If the server cannot boot from the primary SAN location, it attempts to boot from this location. Each boot policy can have only one secondary SAN boot location.

- d) If this vHBA points to a bootable SAN image, click the **Add SAN Boot Target** link and, in the **Add SAN Boot Target** dialog box, complete the following fields, then click **OK**:

Name	Description
Boot Target LUN field	The LUN that corresponds to the location of the boot image.
Boot Target WWPN field	The WWPN that corresponds to the location of the boot image.
Type field	This can be: <ul style="list-style-type: none"> • primary—If the server boots using a SAN WWN address, this is the first address it tries. Each boot policy can have only one primary SAN boot location. • secondary—If the server cannot boot from the primary SAN location, it attempts to boot from this location. Each boot policy can have only one secondary SAN boot location.

- e) Add another boot device to the **Boot Order** table or click **OK** to finish.

Step 7 Click **Next**.

What to Do Next

Complete [Page 5: Specifying the Server Assignment, page 220](#)

Page 5: Specifying the Server Assignment

This procedure directly follows [Page 4: Setting the Server Boot Order, page 218](#). It describes how to specify the way a server is assigned to the service profile on the **Server Assignment** page of the **Create Service Profile (expert)** wizard.

Procedure

Step 1 From the **Server Assignment** drop-down list, choose one of the following:

Option	Description
Assign Later	Allows you to assign a server after you have created and configured the service profile. Continue with Step 6.
Pre-provision a slot	Specifies the chassis and slot that contains the server which will be assigned to the service profile. If the server is not in the slot or is otherwise unavailable, the service profile will be associated with the server when it becomes available. Continue with Step 2.
Select existing Server	Displays a table of available, unassociated servers that you can use to select the server which will be assigned to the service profile. Continue with Step 3.
Select from a Pool <i>Pool_Name</i>	Select a server pool from the list at the bottom of the drop-down list. Cisco UCS Manager assigns a server from this pool to the service profile. Continue with Step 4.

Step 2 If you chose **Pre-provision a slot**, do the following:

- In the **Chassis Id** field, enter the number of the chassis where the selected server is located.
- In the **Slot Id** field, enter the number of the slot where the selected server is located.
- Continue with Step 4.

Step 3 If you chose **Select existing Server**, do the following:

- In the **Select** column of the table of available servers, click the radio button for the server that meets the needs of this service profile.
- Continue with Step 4.

Step 4 In the **Power State** field, click one of the following radio buttons to set the power state that will be applied to the server when it is associated with this service profile:

- **Down** if you want the server to be powered down before the profile is associated with the server.
- **Up** if you want the server to be powered up before the profile is associated with the server

By default, the server is powered up.

Step 5 (Optional) In the **Firmware Management** area, do the following to use policies to update the firmware on the server associated with the service profile:

- a) Click the down arrows on the **Firmware Management** bar to expand the area.
- b) Complete the following fields:

Name	Description
Host Firmware drop-down list	To associate a host firmware package with this service profile, choose its name from the drop-down list.
Create Host Firmware Package link	Click this link if you want to create a host firmware package.
Management Firmware drop-down list	To associate a management firmware package with this service profile, choose its name from the drop-down list.
Create Management Firmware Package link	Click this link if you want to create a management firmware package.

Step 6 Click Next.

What to Do Next

Complete [Page 6: Adding Operational Policies, page 221](#).

Page 6: Adding Operational Policies

This procedure directly follows [Page 5: Specifying the Server Assignment, page 220](#). It describes how to add operational policies to the service profile on the **Operational Policies** page of the **Create Service Profile (expert)** wizard. These policies are optional.

Procedure

- Step 1** To provide external access to the BMC on the server, click the down arrows on the **External IPMI Management Configuration** bar and add an IPMI profile and a serial over LAN policy. If you do not want to provide external access, continue with Step 4.
- Step 2** To add an IPMI profile to the service profile, do one of the following:
 - a) To add an existing policy, select the desired IPMI profile from the **IPMI Profile** drop-down list.
 - b) If the **IPMI Profile** drop-down list does not include an IPMI profile with the desired user access, click the **Create IPMI Profile** link to create an IPMI profile that is available to all service profiles. For more information about how to create an IPMI profile, see [Creating an IPMI Profile, page 188](#).
 - c) If you chose to create an IPMI profile, select that profile from the **IPMI Profile** drop-down list.
- Step 3** To add a Serial over LAN policy to the service profile:
 - a) To add an existing policy, select the desired Serial over LAN policy from the **SoL Configuration Profile** drop-down list.

- b) To create a Serial over LAN policy that is only available to this service profile, select **Create a Specific SoL Policy** from the **SoL Configuration Profile** drop-down list and complete the **Admin State** field and the **Speed** drop-down list.
- c) To create a Serial over LAN policy that is available to all service profiles, click the **Create Serial over LAN Policy** link and complete the fields in the dialog box.
- d) If you chose to create a Serial over LAN policy that is available to all service profiles, select that policy from the **SoL Configuration Profile** drop-down list.

Step 4 To monitor thresholds and collect statistics for the associated server:

- a) Click the down arrows on the **Monitoring Configuration** bar.
- b) To add an existing policy, select the desired threshold policy from the **Threshold Policy** drop-down list.
- c) To create a threshold policy that is available to all service profiles, click the **Create Threshold Policy** link and complete the fields in the dialog box.
- d) If you chose to create a threshold policy that is available to all service profiles, select that policy from the **Threshold Policy** drop-down list.

Step 5 Click **Finish**.

Creating a Service Profile that Inherits Server Identity

Procedure

Step 1 In the **Navigation** pane, click the **Servers** tab.

Step 2 On the **Servers** tab, expand **Servers ► Service Profiles**.

Step 3 Expand the node for the organization where you want to create the service profile.
If the system does not include multi-tenancy, expand the **root** node.

Step 4 Right-click the organization and select **Create Service Profile**.

Step 5 In the **Naming** area of the **Create Service Profile** dialog box, complete the following fields:

- a) In the **Name** field, enter a unique name that you can use to identify the service profile.
This name can be between 1 and 16 alphanumeric characters. You cannot use spaces or any special characters, and you cannot change this name after the object has been saved.
- b) In the **Description** field, enter a description of this service profile.

Step 6 In the **vNICs** area of the **Create Service Profile** dialog box, complete the following fields:

Name	Description
Primary vNIC Section	
Primary vNIC check box	Check this check box if you want to create a vNIC for this service profile. If you check this box, Cisco UCS Manager GUI displays the rest of the fields in this section.
Name field	The name of the vNIC.
Fabric field	The fabric interconnect that this vNIC is associated with.

Name	Description
Network drop-down list	The LAN that this vNIC is associated with.
Secondary vNIC Section	
Secondary vNIC check box	Check this check box if you want to create a second vNIC for this service profile. If you check this box, Cisco UCS Manager GUI displays the rest of the fields in this section.
Name field	The name of the vNIC.
Fabric field	The fabric interconnect that this vNIC is associated with.
Network drop-down list	The LAN that this vNIC is associated with.

Step 7 In the vHBAs area of the **Create Service Profile** dialog box, complete the following fields:

Name	Description
Primary vHBA Section	
Primary vHBA check box	Check this check box if you want to create a vHBA for this service profile. If you check this box, Cisco UCS Manager GUI displays the rest of the fields in this section.
Name field	The name of the vHBA.
Fabric field	The fabric interconnect that this vHBA is associated with.
Secondary vHBA Section	
Secondary vHBA check box	Check this check box if you want to create a second vHBA for this service profile. If you check this box, Cisco UCS Manager GUI displays the rest of the fields in this section.
Name field	The name of the vHBA.
Fabric field	The fabric interconnect that this vHBA is associated with.

Step 8 In the **Boot Order** area of the **Create Service Profile** dialog box, complete the following fields:

Name	Description
Primary Boot Device Section	
Primary Boot Device check box	Check this check box if you want to set a boot device for this service profile. If you check this box, Cisco UCS Manager GUI displays the rest of the fields in this section.
Type field	This can be:

Name	Description
	<ul style="list-style-type: none"> • local-disk—The server boots from its local disk. Note If you select this option, you cannot select local-disk or san as your secondary boot type. • san—The server boots from an image stored in a SAN. If you select this option, Cisco UCS Manager GUI displays the SAN area. • lan—The server boots from the LAN. If you select this option, Cisco UCS Manager GUI displays the Network area that lets you specify which vNIC the server should use for the PXE boot. • virtual CD-ROM—The server boots from a virtual CD-ROM. • virtual Floppy—The server boots from a virtual floppy.
SAN area	If Type is set to san , this area contains the following field: <ul style="list-style-type: none"> • vHBA—The vHBA used to access the SAN boot image • LUN—The LUN that corresponds to the location of the boot image • WWN—The WWN that corresponds to the location of the boot image
Network (PXE) area	If Type is set to lan , this area contains the vNIC drop-down list from which you can choose the vNIC from which the server should boot.
Secondary Boot Device Section	
Primary Boot Device check box	Check this check box if you want to set a second boot device for this service profile. If you check this box, Cisco UCS Manager GUI displays the rest of the fields in this section.
Type field	This can be: <ul style="list-style-type: none"> • local-disk—The server boots from its local disk. • san—The server boots from an image stored in a SAN. If you select this option, Cisco UCS Manager GUI displays the SAN area. • lan—The server boots from the LAN. If you select this option, Cisco UCS Manager GUI displays the Network area that lets you specify which vNIC the server should use for the PXE boot. • virtual CD-ROM—The server boots from a virtual CD-ROM. • virtual Floppy—The server boots from a virtual floppy.
SAN area	If Type is set to san , this area contains the following field:

Name	Description
	<ul style="list-style-type: none"> • vHBA—The vHBA used to access the SAN boot image • LUN—The LUN that corresponds to the location of the boot image • WWN—The WWN that corresponds to the location of the boot image
Network (PXE) area	If Type is set to lan , this area contains the vNIC drop-down list from which you can choose the vNIC from which the server should boot.

Step 9 (Optional) In the **Select** column of the **Server Association (optional)** area, click the radio button for a server to associate this service profile with that server.

Step 10 Click **OK**.

Creating a Hardware Based Service Profile for a Server

You cannot move a hardware based service profile to another server.

Procedure

Step 1 In the **Navigation** pane, click the **Equipment** tab.

Step 2 On the **Equipment** tab, expand **Equipment** ► **Chassis** ► *Chassis Number* ► **Servers**.

Step 3 Choose the server for which you want to create a hardware based service profile.

Step 4 In the **Work** pane, click the **General** tab.

Step 5 In the **Actions** area, click **Create Service Profile**.

Step 6 In the **Create Service Profile for Server** dialog box:

- a) Click the **Hardware Based Service Profile** radio button.
- b) In the **Name** field, enter a unique name for the service profile.
This name can be between 1 and 16 alphanumeric characters. You cannot use spaces or any special characters, and you cannot change this name after the object has been saved.
- c) If you want Cisco UCS Manager to create vNICs for the service profile, check the **Create Default vNICs** check box.
- d) If you want Cisco UCS Manager to create vHBAs for the service profile, check the **Create Default vHBAs** check box.
- e) Click **OK**.

Cisco UCS Manager inherits and automatically applies the identity and configuration information in the server, creates the service profile, and associates it with the server.

Working with Service Profile Templates

Creating a Service Profile Template

Procedure

- Step 1** In the **Navigation** pane, click the **Servers** tab.
- Step 2** On the **Servers** tab, expand **Servers** ► **Service Profile Templates**.
- Step 3** Expand the node for the organization where you want to create the service profile template. If the system does not include multi-tenancy, expand the **root** node.
- Step 4** Right-click the organization and select **Create Service Profile Template**.
- Step 5** In the **Create Service Profile Template** wizard, complete the following:
- [Page 1: Identifying the Service Profile Template](#), page 226
 - [Page 2: Specifying the Template Storage Options](#), page 227
 - [Page 3: Specifying the Template Networking Options](#), page 232
 - [Page 4: Specifying the Template Server Boot Order Options](#), page 234
 - [Page 5: Specifying the Template Server Assignment Options](#), page 236
 - [Page 6: Specifying Template Policy Options](#), page 238
-

Page 1: Identifying the Service Profile Template

This procedure directly follows the steps in [Creating a Service Profile Template](#), page 226. It describes how to set the identity of a service profile template on the **Identify Service Profile Template** page of the **Create Service Profile Template** wizard.

Procedure

- Step 1** In the **Name** field, enter a unique name that you can use to identify this service profile template. This name can be between 1 and 16 alphanumeric characters. You cannot use spaces or any special characters, and you cannot change this name after the object has been saved.
- Step 2** In the **Type** field, click one of the following radio buttons:
- **Initial Template**—Any service profiles created from this template are not updated if the template changes
 - **Updating Template**—Any service profiles created from this template are updated if the template changes
- Step 3** From the **UUID Assignment** drop-down list, choose one of the following:

Option	Description
Select (pool default used by default)	Assigns a UUID from the default UUID Suffix pool.
Hardware Default	Uses the UUID assigned to the server by the manufacturer. If you choose this option, the UUID remains unassigned until the service profile is associated with a server. At that point, the UUID is set to the UUID value assigned to the server by the manufacturer. If the service profile is later moved to a different server, the UUID is changed to match the new server.
Pools <i>Pool_Name</i>	Assigns a UUID from the UUID Suffix pool that you select from the list at the bottom of the drop-down list. Each pool name is followed by two numbers in parentheses that show the number of UUIDs still available in the pool and the total number of UUIDs in the pool.

Step 4 (Optional) In the text box, enter a description of this service profile template. The description can contain up to 256 characters.

Step 5 Click Next.

What to Do Next

Complete the steps in [Page 2: Specifying the Template Storage Options, page 227](#).

Page 2: Specifying the Template Storage Options

This procedure directly follows [Page 1: Identifying the Service Profile Template, page 226](#). It describes how to configure the storage options for a service profile template on the **Storage** page of the **Create Service Profile Template** wizard.

Procedure

Step 1 From the **Local Storage** drop-down list, choose one of the following:

Option	Description
Select Local Storage Policy to use	Assigns the default local disk storage policy to every service profile created from this template. Continue with Step 4.
Create a Specific Storage Policy	Enables you to create a local disk policy that can only be accessed by a service profile created from this template. Continue with Step 2.

Option	Description
Storage Policies <i>Policy_Name</i>	Select an existing local disk policy from the list at the bottom of the drop-down list. Cisco UCS Manager assigns this policy to every service profile created from this template. If you do not want use any of the existing policies, but instead want to create a new policy that all service profiles and templates can access, continue with Step 3. Otherwise, continue with Step 4.

Step 2 (Optional) If you chose **Create a Specific Storage Policy**, do the following:

a) From the **Mode** drop-down list, choose one of the following:

- **Any Configuration**—For a server configuration that carries forward the local disk configuration without any changes.
- **No Local Storage**—For a diskless workstation or a SAN only configuration. If you select this option, you cannot associate any service profile which uses this policy with a server that has a local disk.
- **No RAID**—For a server configuration that removes the RAID and leaves the disk MBR and payload unaltered.
- **RAID Mirrored**—For a 2-disk RAID 1 server configuration.
- **RAID Stripes**—For a 2-disk RAID 0 server configuration.

Note If you choose **No RAID** and you apply this policy to a server that already has an operating system with RAID storage configured, the system does not remove the disk contents. Therefore, there may be no visible differences after you apply the **No RAID** mode.

To make sure that any previous RAID configuration information is removed from a disk, apply a scrub policy that removes all disk information after you apply the **No RAID** configuration mode.

b) Continue with Step 4.

Step 3 (Optional) To create a local disk configuration policy that will be available to all service profiles and templates, do the following:

- a) Click the **Create Local Disk Configuration Policy** link.
- b) In the **Create Local Disk Configuration** dialog box, complete the fields.
For more information, see [Creating a Local Disk Configuration Policy](#), page 190.
- c) Click **OK**.
- d) From the **Local Storage** drop-down list, choose the policy you created.

Step 4 From the **Scrub Policy** drop-down list, choose one of the following:

Option	Description
<not set>	Does not include a scrub policy in a service profile created from this template.

Option	Description
<i>Policy_Name</i>	Assigns an existing scrub policy to every service profile created from this template. If you do not want use any of the existing policies, but instead want to create a new policy that all service profiles and templates can access, continue with Step 5. Otherwise, continue with Step 6.

Step 5 (Optional) To create a scrub policy that will be available to all service profiles and templates, do the following:

- a) Click the **Create Scrub Policy** link.
- b) In the **Create Scrub Policy** dialog box, complete the fields.
For more information, see [Creating a Scrub Policy](#), page 192.
- c) Click **OK**.
- d) From the **Scrub Policy** drop-down list, choose the policy you created.

Step 6 In the **How would you like to configure SAN storage?** field, click one of the following options:

Option	Description
Simple	Allows you to create a maximum of two vHBAs for every service profile created from this template. Continue with Step 7.
Expert	Allows you to create an unlimited number of vHBAs for every service profile created from this template. Continue with Step 8.
No vHBAs	Does not include any vHBAs for connections to a Fibre Channel SAN in a service profile created from this template. Continue with Step 9.

Step 7 (Optional) If you chose the simple SAN storage option, do the following:

- a) From the **WWNN Assignment** drop-down list:
 - Choose **Select (pool default used by default)** to use the default WWN pool.
 - Choose **Derived from vHBA** to use a WWN derived from the first vHBA you specify.
 - Choose one of the options listed under **Manual Using OUI** and then enter the WWN in the **World Wide Node Name** field.
You can specify a WWNN in the range from 20:00:00:00:00:00:00:00 to 20:FF:FF:FF:FF:FF:FF:FF or from 50:00:00:00:00:00:00:00 to 5F:FF:FF:FF:FF:FF:FF:FF. You can click the **here** link to verify that the WWNN you specified is available.
 - Choose a WWN pool name from the list to have a WWN automatically assigned from the specified pool. Each pool name is followed by two numbers in parentheses that show the number of WWNs still available in the pool and the total number of WWNs in the pool.
- b) In the **vHBA 0 (Fabric A)** area:
 - In the **Name** field, enter a unique name for the vHBA.

- From the **Select VSAN** drop-down list, choose the name of the VSAN with which this vHBA should be associated.

If the VSAN you need is not in the drop-down list, click the **Create VSAN** link. For more information, see [Creating a Named VSAN](#), page 157.

- Repeat Step 7b in the **vHBA 1 (Fabric B)** area to create a VSAN for that vHBA.
- Continue with Step 9.

Step 8 (Optional) If you chose the expert SAN storage option, do the following:

- From the **WWNN Assignment** drop-down list:
 - Choose **Select (pool default used by default)** to use the default WWN pool.
 - Choose **Derived from vHBA** to use a WWN derived from the first vHBA you specify.
 - Choose one of the options listed under **Manual Using OUI** and then enter the WWN in the **World Wide Node Name** field.
 You can specify a WWNN in the range from 20:00:00:00:00:00:00:00 to 20:FF:FF:FF:FF:FF:FF:FF or from 50:00:00:00:00:00:00:00 to 5F:FF:FF:FF:FF:FF:FF:FF. You can click the **here** link to verify that the WWNN you specified is available.
 - Choose a WWN pool name from the list to have a WWN automatically assigned from the specified pool. Each pool name is followed by two numbers in parentheses that show the number of WWNs still available in the pool and the total number of WWNs in the pool.
- Click **Add** on the icon bar of the table to open the **Create vHBA** dialog box.
- Complete the following fields to specify the identity information for the vHBA:

Name	Description
Name field	The name of this vHBA. This name can be between 1 and 16 alphanumeric characters. You cannot use spaces or any special characters, and you cannot change this name after the object has been saved.
Use SAN Connectivity Template check box	Check this check box if you want to use a template to create the vHBA. Cisco UCS Manager GUI displays the vHBA Template drop-down list from which you can select the appropriate template, and the Adapter Performance Profile area from which you can select an adapter profile. Note You can only select this option if one or more SAN connectivity templates exist in the system.
Create vHBA Template link	Click this link if you want to create a vHBA template.
WWPN Assignment drop-down list	If you want to: <ul style="list-style-type: none"> • Use the default WWPN pool, leave this field set to Select (pool default used by default). • Use the WWPN assigned to the server by the manufacturer, select Hardware Default.

Name	Description
	<ul style="list-style-type: none"> A specific WWPN, select 20:00:00:25:B5:00:00:00, 20:XX:XX:XX:XX:XX:XX:XX, or 5X:XX:XX:XX:XX:XX:XX:XX and enter the WWPN in the WWPN field. To verify that this WWPN is available, click the corresponding link. A WWPN from a pool, select the pool name from the list. Each pool name is followed by a pair of numbers in parentheses. The first number is the number of available WWN addresses in the pool and the second is the total number of WWPN addresses in the pool.

d) In the **VSAN** area, complete the following fields:

Name	Description
Fabric ID field	The fabric interconnect associated with the component.
Select VSAN drop-down list box	The VSAN that this vHBA is associated with.
Create VSAN link	Click this link if you want to create a VSAN.
Pin Group drop-down list box	The pin group that this vHBA is associated with.
Create SAN Pin Group link	Click this link if you want to create a pin group.
Persistent Binding field	This can be: <ul style="list-style-type: none"> disabled enabled
Operational Parameters Section	
Stats Threshold Policy drop-down list box	The threshold policy that this vHBA is associated with.

e) In the **Adapter Performance Profile** area, complete the following fields:

Name	Description
Adapter Policy drop-down list box	The Fibre Channel adapter policy that this vHBA is associated with.
Create Fibre Channel Adapter Policy link	Click this link if you want to create a Fibre Channel adapter policy.

f) Click **OK**.

Step 9 Click **Next**.

What to Do Next

Complete [Page 3: Specifying the Template Networking Options, page 232](#).

Page 3: Specifying the Template Networking Options

This procedure directly follows [Page 2: Specifying the Template Storage Options, page 227](#). It describes how to configure the networking options, including LAN connectivity, on the **Networking** page of the **Create Service Profile Template** wizard.

Procedure

Step 1 In the **How would you like to configure LAN connectivity?** field, click one of the following options:

Option	Description
Simple	Allows you to create a maximum of two vNICs, in dual fabric mode, for every service profile created from this template. Continue with Step 2.
Expert	Allows you to create an unlimited number of vNICs for every service profile created from this template. Continue with Step 3.
No vNICs	Does not include any vNICs for connections to a LAN in a service profile created from this template. Any server associated with these service profiles cannot communicate with a LAN unless you modify the individual service profile later. Continue with Step 4.

Step 2 (Optional) If you chose the simple LAN connectivity option, do the following:

a) In the **vNIC 0 (Fabric A)** area:

- In the **Name** field, enter a unique name for the vNIC.
- From the **Select Native VLAN** drop-down list, choose the name of the VLAN with which this vNIC should communicate.

If the VLAN you need is not in the drop-down list, click the **Create VLAN** link. For more information, see [Creating a Named VLAN, page 131](#).

b) Repeat Step 2a in the **vNIC 1 (Fabric B)** area to create a VLAN for that vNIC.

c) Continue with Step 4.

Step 3 If you chose the expert LAN connectivity option, do the following:

a) Click **Add** on the icon bar of the table to open the **Create vNICs** dialog box.

b) Complete the following fields to specify the identity information for the vNIC:

Name	Description
Name field	Enter a name for this vNIC.
Use LAN Connectivity Template check box	<p>Check this check box if you want to use a template to create the vNIC. Cisco UCS Manager GUI displays the vNIC Template drop-down list from which you can select the appropriate template, and the Adapter Performance Profile area from which you can select an adapter profile.</p> <p>Note You can only select this option if one or more LAN connectivity templates exist in the system.</p>
Create vNIC Template link	Click this link if you want to create a vNIC template.
MAC Address Assignment drop-down list	<p>If you want to:</p> <ul style="list-style-type: none"> • Use the default MAC address pool, leave this field set to Select (pool default used by default). • Use the MAC address assigned to the server by the manufacturer, select Hardware Default. • A specific MAC address, select 02:25:B5:XX:XX:XX and enter the address in the MAC Address field. To verify that this address is available, click the corresponding link. • A MAC address from a pool, select the pool name from the list. Each pool name is followed by a pair of numbers in parentheses. The first number is the number of available MAC addresses in the pool and the second is the total number of MAC addresses in the pool.

c) In the **Fabric Interconnect** area, complete the following fields:

Name	Description
Fabric ID field	<p>The fabric interconnect associated with the component.</p> <p>If you want this vNIC to be able to access the second fabric interconnect if the default one is unavailable, check the Enable Failover check box.</p> <p>Note Do not select Enable Failover if you plan to associate this vNIC configuration with a server that has a Cisco UCS 82598KR-CI 10-Gigabit Ethernet Adapter. If you do so, Cisco UCS Manager generates a configuration fault when you associate the service profile with the server.</p>
VLAN Trunking field	If you want to use VLAN trunking, click Yes . Otherwise, select No .
Select VLAN drop-down list box	The VLAN that this vNIC is associated with.
Create VLAN link	Click this link if you want to create a VLAN.

Name	Description
Native VLAN check box	Check this check box if this vNIC is associated with the native VLAN.
Pin Group drop-down list box	Choose the LAN pin group you want associated with this vNIC.
Create LAN Pin Group link	Click this link if you want to create a LAN pin group.
Operational Parameters Section	
Stats Threshold Policy drop-down list box	The statistics collection policy that this vNIC is associated with.

- d) In the **Adapter Performance Profile** area, complete the following fields:

Name	Description
Adapter Policy drop-down list box	The Ethernet adapter policy that this vNIC is associated with.
Create Ethernet Adapter Policy link	Click this link if you want to create an Ethernet adapter policy.
QoS drop-down list box	The quality of service policy that this vNIC is associated with.
Create QoS Policy link	Click this link if you want to create a quality of service policy.
Network Control Policy drop-down list box	The network control policy that this vNIC is associated with.
Create Network Control Policy link	Click this link if you want to create a network control policy.

- e) Click **OK**.

Step 4 Click **Next**.

What to Do Next

Complete [Page 4: Specifying the Template Server Boot Order Options, page 234](#).

Page 4: Specifying the Template Server Boot Order Options

This procedure directly follows [Page 3: Specifying the Template Networking Options, page 232](#). It describes how to set the server boot order options on the **Server Boot Order** page of the **Create Service Profile Template** wizard.

Procedure

Step 1 From the **Boot Policy** drop-down list, choose one of the following:

Option	Description
Select Boot Policy to use	Assigns the default boot policy to every service profile created from this template. Continue with Step 7.
Create a Specific Boot Policy	Enables you to create a local boot policy that can only be accessed by a service profile created from this template. Continue with Step 3.
Boot Policies <i>Policy_Name</i>	Assigns an existing boot policy to every service profile created from this template. If you choose this option, Cisco UCS Manager displays the details of the policy. If you do not want use any of the existing policies, but instead want to create a policy that all service profiles and templates can access, continue with Step 2. Otherwise, continue with Step 7.

Step 2 If you chose to create a boot policy, in the **Create Boot Policy** dialog box, enter a unique name and description for the policy.

This name can be between 1 and 16 alphanumeric characters. You cannot use spaces or any special characters, and you cannot change this name after the object has been saved.

Step 3 (Optional) To reboot all servers that use this boot policy after you make changes to the boot order, check the **Reboot on Boot Order Change** check box.

Step 4 To add a local disk, virtual CD-ROM, or virtual floppy to the boot order:

- a) Click the down arrows to expand the **Local Devices** area.
- b) Click one of the following links to add the device to the **Boot Order** table:

- **Add Local Disk**
- **Add CD-ROM**
- **Add Floppy**

- c) Add another boot device to the **Boot Order** table or click **OK** to finish.

Step 5 To add a LAN boot to the boot order:

- a) Click the down arrows to expand the **vNICs** area.
- b) Click the **Add LAN Boot** link.
- c) In the **Add LAN Boot** dialog box, enter the name of the vNIC that you want to use for the LAN boot in the **vNIC** field, then click **OK**.
- d) Add another device to the **Boot Order** table or click **OK** to finish.

Step 6 To add a SAN boot to the boot order:

- a) Click the down arrows to expand the **vHBAs** area.
- b) Click the **Add SAN Boot** link.

- c) In the **Add SAN Boot** dialog box, complete the following fields, then click **OK**:

Name	Description
vHBA field	Enter the name of the vHBA you want to use for the SAN boot.
Type field	This can be: <ul style="list-style-type: none"> • primary—If the server boots using a SAN WWN address, this is the first address it tries. Each boot policy can have only one primary SAN boot location. • secondary—If the server cannot boot from the primary SAN location, it attempts to boot from this location. Each boot policy can have only one secondary SAN boot location.

- d) If this vHBA points to a bootable SAN image, click the **Add SAN Boot Target** link and, in the **Add SAN Boot Target** dialog box, complete the following fields, then click **OK**:

Name	Description
Boot Target LUN field	The LUN that corresponds to the location of the boot image.
Boot Target WWPN field	The WWPN that corresponds to the location of the boot image.
Type field	This can be: <ul style="list-style-type: none"> • primary—If the server boots using a SAN WWN address, this is the first address it tries. Each boot policy can have only one primary SAN boot location. • secondary—If the server cannot boot from the primary SAN location, it attempts to boot from this location. Each boot policy can have only one secondary SAN boot location.

- e) Add another boot device to the **Boot Order** table or click **OK** to finish.

Step 7 Click **Next**.

What to Do Next

Complete [Page 5: Specifying the Template Server Assignment Options](#), page 236.

Page 5: Specifying the Template Server Assignment Options

This procedure directly follows [Page 4: Specifying the Template Server Boot Order Options](#), page 234. It describes how to specify the way a server is assigned to service profile created from this template on the **Server Assignment** page of the **Create Service Profile Template** wizard.

Procedure

Step 1 From the **Server Assignment** drop-down list, choose one of the following:

Option	Description
Assign Later	Allows you to assign a server after you have created and configured the service profile template. Continue with Step 2.
Select from a Pool <i>Pool_Name</i>	Select a server pool from the list at the bottom of the drop-down list. Cisco UCS Manager assigns a server from this pool to a service profile created from this template. Continue with Step 2.

Step 2 In the **Power State** field, click one of the following radio buttons to set the power state that will be applied to the server when it is associated with a service profile created from this template:

- **Down** if you want the server to be powered down before the profile is associated with the server.
- **Up** if you want the server to be powered up before the profile is associated with the server

By default, the server is powered up.

Step 3 (Optional) In the **Firmware Management** area, do the following to use policies to update the firmware on the server associated with a service profile created from this template:

- Click the down arrows on the **Firmware Management** bar.
- Complete the following fields:

Name	Description
Host Firmware drop-down list	To associate a host firmware package with this service profile, choose its name from the drop-down list.
Create Host Firmware Package link	Click this link if you want to create a host firmware package.
Management Firmware drop-down list	To associate a management firmware package with this service profile, choose its name from the drop-down list.
Create Management Firmware Package link	Click this link if you want to create a management firmware package.

Step 4 Click **Next**.

What to Do Next

Complete [Page 6: Specifying Template Policy Options](#), page 238.

Page 6: Specifying Template Policy Options

This procedure directly follows [Page 5: Specifying the Template Server Assignment Options](#), page 236. It describes how to add operational policies to the service profile template on the **Operational Policies** page of the **Create Service Profile Template** wizard. These policies are optional.

Procedure

- Step 1** To provide external access to the BMC on the server, click the down arrows on the **External IPMI Management Configuration** bar and add an IPMI profile and a serial over LAN policy. If you do not want to provide external access, continue with Step 4.
- Step 2** To add an IPMI profile to service profile created from this template, do one of the following:
- To add an existing policy, select the desired IPMI profile from the **IPMI Profile** drop-down list.
 - If the **IPMI Profile** drop-down list does not include an IPMI profile with the desired user access, click the **Create IPMI Profile** link to create an IPMI profile that is available to all service profiles templates. For more information about how to create an IPMI profile, see [Creating an IPMI Profile](#), page 188.
 - If you chose to create an IPMI profile, select that profile from the **IPMI Profile** drop-down list.
- Step 3** To add a Serial over LAN policy to service profile created from this template:
- To add an existing policy, select the desired Serial over LAN policy from the **SoL Configuration Profile** drop-down list.
 - To create a Serial over LAN policy that is only available to service profile created from this template, select **Create a Specific SoL Policy** from the **SoL Configuration Profile** drop-down list and complete the **Admin State** field and the **Speed** drop-down list.
 - To create a Serial over LAN policy that is available to all service profile templates, click the **Create Serial over LAN Policy** link and complete the fields in the dialog box.
 - If you chose to create a Serial over LAN policy that is available to all service profile templates, select that policy from the **SoL Configuration Profile** drop-down list.
- Step 4** To monitor thresholds and collect statistics for the associated server:
- Click the down arrows on the **Monitoring Configuration** bar.
 - To add an existing policy, select the desired threshold policy from the **Threshold Policy** drop-down list.
 - To create a threshold policy that is available to all service profile templates, click the **Create Threshold Policy** link and complete the fields in the dialog box.
 - If you chose to create a threshold policy that is available to all service profile templates, select that policy from the **Threshold Policy** drop-down list.
- Step 5** Click **Finish**.
-

Creating Service Profiles from a Service Profile Template

Procedure

-
- Step 1** In the **Navigation** pane, click the **Servers** tab.
- Step 2** On the **Servers** tab, expand **Servers** ► **Service Profile Templates**.
- Step 3** Expand the node for the organization that contains the service profile template that you want to use as the basis for your service profiles.
If the system does not include multi-tenancy, expand the **root** node.
- Step 4** Right-click the service profile template you want to create the profiles from and select **Create Service Profiles From Template**.
- Step 5** In the **Create Service Profiles From Template** dialog box, complete the following fields:

Name	Description
Naming Prefix field	The prefix to use for the template name. When the system creates the service profiles, it appends a unique numeric identifier to this prefix. For example, if you specify the prefix MyProfile and request two profiles, the first service profile would be called MyProfile1 and the second would be MyProfile2. If you return at a later date and create three more profiles with the same prefix, they would be named MyProfile3, MyProfile4, and MyProfile5.
Number field	The number of service profiles to create.

- Step 6** Click **OK**.
-

Creating a Template Based Service Profile for a Server

Before You Begin

A qualified service profile template with the desired values must exist in Cisco UCS Manager.

Procedure

-
- Step 1** In the **Navigation** pane, click the **Equipment** tab.
- Step 2** On the **Equipment** tab, expand **Equipment** ► **Chassis** ► **Chassis Number** ► **Servers**.
- Step 3** Choose the server for which you want to create a hardware based service profile.
- Step 4** In the **Work** pane, click the **General** tab.
- Step 5** In the **Actions** area, click **Create Service Profile**.
- Step 6** In the **Create Service Profile for Server** dialog box:
- Click the **Template Based Service Profile** radio button.
 - In the **Name** field, enter a unique name for the service profile.

This name can be between 1 and 16 alphanumeric characters. You cannot use spaces or any special characters, and you cannot change this name after the object has been saved.

- c) From the **Service Profile Template** drop-down list, select the template from which you want to create the service profile associated with this server.
- d) Click **OK**.

Changing the UUID in a Service Profile Template

Procedure

- Step 1** In the **Navigation** pane, click the **Servers** tab.
- Step 2** On the **Servers** tab, expand **Servers ► Service Profile Templates**.
- Step 3** Expand the node for the organization that contains the service profile template for which you want to change the UUID.
If the system does not include multi-tenancy, expand the **root** node.
- Step 4** Choose the service profile template whose UUID assignment you want to change.
- Step 5** In the **Work** pane, click the **General** tab.
- Step 6** In the **Actions** area, click **Change UUID**.
- Step 7** From the **UUID Assignment** drop-down list, choose one of the following:

Option	Description
Select (pool default used by default)	Assigns a UUID from the default UUID Suffix pool.
Hardware Default	Uses the UUID assigned to the server by the manufacturer. If you choose this option, the UUID remains unassigned until the service profile is associated with a server. At that point, the UUID is set to the UUID value assigned to the server by the manufacturer. If the service profile is later moved to a different server, the UUID is changed to match the new server.
Pools <i>Pool_Name</i>	Assigns a UUID from the UUID Suffix pool that you select from the list at the bottom of the drop-down list. Each pool name is followed by two numbers in parentheses that show the number of UUIDs still available in the pool and the total number of UUIDs in the pool.

- Step 8** Click **OK**.

Associating a Service Profile Template with a Server Pool

Follow this procedure if you did not associate the service profile template with a server pool when you created it, or to change the server pool with which a service profile created from this template is associated.

Procedure

- Step 1** In the **Navigation** pane, click the **Servers** tab.
 - Step 2** On the **Servers** tab, expand **Servers** ► **Service Profile Templates**.
 - Step 3** Expand the node for the organization that contains the service profile that you want to associate with a server pool.
If the system does not include multi-tenancy, expand the **root** node.
 - Step 4** Right-click the service profile template you want to associate with a server pool and select **Associate with Server Pool**.
The **Associate with Server Pool** dialog box opens.
 - Step 5** From the **Server Pool** section of the **Pool Assignment** drop-down list, select a server pool.
If you select **Assign Later**, the service profile template is not associated with a server pool.
 - Step 6** Select one of the following radio buttons to determine the power state applied to a server which is associated with a service profile profile created from this template:
 - **Down**
 - **Up**
 - Step 7** From the **Select Qualification** dropdown list, select the server pool policy qualifications that you want to apply to a server which is associated with a service profile created from this template.
 - Step 8** Click **OK**.
-

Disassociating a Service Profile Template from its Server Pool

Procedure

- Step 1** In the **Navigation** pane, click the **Servers** tab.
 - Step 2** On the **Servers** tab, expand **Servers** ► **Service Profile Templates**.
 - Step 3** Expand the node for the organization that contains the service profile that you want to disassociate from its server pool.
If the system does not include multi-tenancy, expand the **root** node.
 - Step 4** Right-click the service profile template you want to disassociate from its server pool and select **Disassociate Template**.
 - Step 5** If Cisco UCS Manager displays a confirmation dialog box, click **Yes**.
-

Managing Service Profiles

Cloning a Service Profile

Procedure

-
- Step 1** In the **Navigation** pane, click the **Servers** tab.
- Step 2** On the **Servers** tab, expand **Servers** ► **Service Profiles**.
- Step 3** Expand the node for the organization where you want to create the service profile.
If the system does not include multi-tenancy, expand the **root** node.
- Step 4** Right-click the service profile you want to clone and select **Create a Clone**.
- Step 5** In the **Create Clone From Service Profile** dialog box:
- Enter the name you want to use for the new profile in the **Clone Name** field.
 - Click **OK**.
- Step 6** Navigate to the service profile you just created and make sure that all options are correct.
-

Associating a Service Profile with a Server or Server Pool

Follow this procedure if you did not associate the service profile with a server or server pool when you created it, or to change the server or server pool with which a service profile is associated.

Procedure

-
- Step 1** In the **Navigation** pane, click the **Servers** tab.
- Step 2** On the **Servers** tab, expand **Servers** ► **Service Profiles**.
- Step 3** Expand the node for the organization that contains the service profile that you want to associate with a new server or server pool.
If the system does not include multi-tenancy, expand the **root** node.
- Step 4** Right-click the service profile you want to associate with a server and select **Change Service Profile Association**.
- Step 5** In the **Associate Service Profile** dialog box, select one of the following options:

Option	Description
Server Pool	Select a server pool from the drop-down list. Cisco UCS Manager assigns a server from this pool to the service profile. Continue with Step 7.
Server	Navigate to the desired available server in the navigation tree and select the server which will be assigned to the service profile. Continue with Step 7.

Option	Description
Custom Server	Specifies the chassis and slot that contains the server which will be assigned to the service profile. If the server is not in the slot or is otherwise unavailable, the service profile will be associated with the server when it becomes available. Continue with Step 6.

- Step 6** If you chose **Custom Server**, do the following:
- In the **Chassis Id** field, enter the number of the chassis where the selected server is located.
 - In the **Server Id** field, enter the number of the slot where the selected server is located.
- Step 7** Click **OK**.

Disassociating a Service Profile from a Server or Server Pool

When you disassociate a service profile, Cisco UCS Manager attempts to shutdown the OS on the server. If the OS does not shutdown within a reasonable length of time, Cisco UCS Manager forces the server to shutdown.

Procedure

- In the **Navigation** pane, click the **Servers** tab.
- On the **Servers** tab, expand **Servers** ► **Service Profiles**.
- Expand the node for the organization that contains the service profile that you want to disassociate from a server or server pool.
If the system does not include multi-tenancy, expand the **root** node.
- Right-click the service profile you want to disassociate from a server and select **Disassociate Service Profile**.
- In the **Disassociate Service Profile** dialog box, click **Yes** to confirm that you want to disassociate the service profile.
- (Optional) Monitor the status and FSM for the server to confirm that the disassociation completed.

Changing the UUID in a Service Profile

Procedure

- In the **Navigation** pane, click the **Servers** tab.
- On the **Servers** tab, expand **Servers** ► **Service Profiles**.
- Expand the node for the organization that contains the service profile for which you want to change the UUID.

If the system does not include multi-tenancy, expand the **root** node.

Step 4 Choose the service profile that requires the UUID for the associated server to be changed.

Step 5 In the **Work** pane, click the **General** tab.

Step 6 In the **Actions** area, click **Change UUID**.

Step 7 From the **UUID Assignment** drop-down list, do one of the following:

Option	Description
Select (pool default used by default)	Assigns a UUID from the default UUID Suffix pool. Continue with Step 9.
Hardware Default	Uses the UUID assigned to the server by the manufacturer. If you choose this option, the UUID remains unassigned until the service profile is associated with a server. At that point, the UUID is set to the UUID value assigned to the server by the manufacturer. If the service profile is later moved to a different server, the UUID is changed to match the new server. Continue with Step 9.
XXXXXXXX-XXXX-XXXX-XXXX-XXXXXXXXXXXX	Uses the UUID that you manually assign. Continue with Step 8.
Pools <i>Pool_Name</i>	Assigns a UUID from the UUID Suffix pool that you select from the list at the bottom of the drop-down list. Each pool name is followed by two numbers in parentheses that show the number of UUIDs still available in the pool and the total number of UUIDs in the pool. Continue with Step 9.

Step 8 (Optional) If you selected the **XXXXXXXX-XXXX-XXXX-XXXX-XXXXXXXXXXXX** option, do the following:

- a) In the **UUID** field, enter the valid UUID that you want to assign to the server which uses this service profile.
- b) To verify that the selected UUID is available, click the **here** link.

Step 9 Click **OK**.

Creating a vNIC for a Service Profile

Procedure

- Step 1** In the **Navigation** pane, click the **Servers** tab.
- Step 2** On the **Servers** tab, expand **Servers** ► **Service Profiles**.
- Step 3** Expand the node for the organization that contains the service profile for which you want to create a vNIC.
- Step 4** Expand the service profile for which you want to create a vNIC.
- Step 5** Right-click on the **vNICs** node and choose **Create vNICs**.
- Step 6** In the **Create vNICs** dialog box, do the following:

- a) Complete the following fields to specify the identity information for the vNIC:

Name	Description
Name field	Enter a name for this vNIC.
Use LAN Connectivity Template check box	Check this check box if you want to use a template to create the vNIC. Cisco UCS Manager GUI displays the vNIC Template drop-down list from which you can select the appropriate template, and the Adapter Performance Profile area from which you can select an adapter profile. Note You can only select this option if one or more LAN connectivity templates exist in the system.
Create vNIC Template link	Click this link if you want to create a vNIC template.
MAC Address Assignment drop-down list	If you want to: <ul style="list-style-type: none"> • Use the default MAC address pool, leave this field set to Select (pool default used by default). • Use the MAC address assigned to the server by the manufacturer, select Hardware Default. • A specific MAC address, select 02:25:B5:XX:XX:XX and enter the address in the MAC Address field. To verify that this address is available, click the corresponding link. • A MAC address from a pool, select the pool name from the list. Each pool name is followed by a pair of numbers in parentheses. The first number is the number of available MAC addresses in the pool and the second is the total number of MAC addresses in the pool.

- b) In the **Fabric Interconnect** area, complete the following fields:

Name	Description
Fabric ID field	The fabric interconnect associated with the component.

Name	Description
	If you want this vNIC to be able to access the second fabric interconnect if the default one is unavailable, check the Enable Failover check box. Note Do not select Enable Failover if you plan to associate this vNIC configuration with a server that has a Cisco UCS 82598KR-CI 10-Gigabit Ethernet Adapter. If you do so, Cisco UCS Manager generates a configuration fault when you associate the service profile with the server.
VLAN Trunking field	If you want to use VLAN trunking, click Yes . Otherwise, select No .
Select VLAN drop-down list box	The VLAN that this vNIC is associated with.
Create VLAN link	Click this link if you want to create a VLAN.
Native VLAN check box	Check this check box if this vNIC is associated with the native VLAN.
Pin Group drop-down list box	Choose the LAN pin group you want associated with this vNIC.
Create LAN Pin Group link	Click this link if you want to create a LAN pin group.
Operational Parameters Section	
Stats Threshold Policy drop-down list box	The statistics collection policy that this vNIC is associated with.

c) In the **Adapter Performance Profile** area, complete the following fields:

Name	Description
Adapter Policy drop-down list box	The Ethernet adapter policy that this vNIC is associated with.
Create Ethernet Adapter Policy link	Click this link if you want to create an Ethernet adapter policy.
QoS drop-down list box	The quality of service policy that this vNIC is associated with.
Create QoS Policy link	Click this link if you want to create a quality of service policy.
Network Control Policy drop-down list box	The network control policy that this vNIC is associated with.
Create Network Control Policy link	Click this link if you want to create a network control policy.

d) Click **OK**.

Deleting a vNIC from a Service Profile

Procedure

-
- Step 1** In the **Navigation** pane, click the **Servers** tab.
 - Step 2** On the **Servers** tab, expand **Servers** ► **Service Profiles**.
 - Step 3** Expand the node for the organization that contains the service profile from which you want to delete a vNIC.
 - Step 4** Expand the service profile from which you want to delete a vNIC.
 - Step 5** Expand the **vNICs** node.
 - Step 6** Right-click on the vNIC you want to delete and choose **Delete**.
 - Step 7** If Cisco UCS Manager displays a confirmation dialog box, click **Yes**.
-

Creating a vHBA for a Service Profile

Procedure

-
- Step 1** In the **Navigation** pane, click the **Servers** tab.
 - Step 2** On the **Servers** tab, expand **Servers** ► **Service Profiles**.
 - Step 3** Expand the node for the organization that contains the service profile for which you want to create a vHBA.
 - Step 4** Expand the service profile for which you want to create a vHBA.
 - Step 5** Right-click on the **vHBAs** node and choose **Create vHBAs**.
 - Step 6** In the **Create vHBAs** dialog box, do the following:
 - a) Complete the following fields to specify the identity information for the vHBA:

Name	Description
Name field	The name of this vHBA. This name can be between 1 and 16 alphanumeric characters. You cannot use spaces or any special characters, and you cannot change this name after the object has been saved.
Use SAN Connectivity Template check box	Check this check box if you want to use a template to create the vHBA. Cisco UCS Manager GUI displays the vHBA Template drop-down list from which you can select the appropriate template, and the Adapter Performance Profile area from which you can select an adapter profile. Note You can only select this option if one or more SAN connectivity templates exist in the system.
Create vHBA Template link	Click this link if you want to create a vHBA template.

Name	Description
WWPN Assignment drop-down list	<p>If you want to:</p> <ul style="list-style-type: none"> Use the default WWPN pool, leave this field set to Select (pool default used by default). Use the WWPN assigned to the server by the manufacturer, select Hardware Default. A specific WWPN, select 20:00:00:25:B5:00:00:00, 20:XX:XX:XX:XX:XX:XX:XX, or 5X:XX:XX:XX:XX:XX:XX:XX and enter the WWPN in the WWPN field. To verify that this WWPN is available, click the corresponding link. A WWPN from a pool, select the pool name from the list. Each pool name is followed by a pair of numbers in parentheses. The first number is the number of available WWN addresses in the pool and the second is the total number of WWPN addresses in the pool.

b) In the **VSAN** area, complete the following fields:

Name	Description
Fabric ID field	The fabric interconnect associated with the component.
Select VSAN drop-down list box	The VSAN that this vHBA is associated with.
Create VSAN link	Click this link if you want to create a VSAN.
Pin Group drop-down list box	The pin group that this vHBA is associated with.
Create SAN Pin Group link	Click this link if you want to create a pin group.
Persistent Binding field	<p>This can be:</p> <ul style="list-style-type: none"> disabled enabled
Operational Parameters Section	
Stats Threshold Policy drop-down list box	The threshold policy that this vHBA is associated with.

c) In the **Adapter Performance Profile** area, complete the following fields:

Name	Description
Adapter Policy drop-down list box	The Fibre Channel adapter policy that this vHBA is associated with.

Name	Description
Create Fibre Channel Adapter Policy link	Click this link if you want to create a Fibre Channel adapter policy.

d) Click **OK**.

Changing the WWPN for a vHBA

Procedure

- Step 1** In the **Navigation** pane, click the **Servers** tab.
- Step 2** On the **Servers** tab, expand **Servers** ► **Service Profiles**.
- Step 3** Expand the node for the organization that contains the service profile for which you want to change the WWPN.
- Step 4** Expand *Service_Profile_Name* ► **vHBAs**.
- Step 5** Click the vHBA for which you want to change the WWPN.
- Step 6** In the **Work** pane, click the **General** tab.
- Step 7** In the **Actions** area, click **Change World Wide Name**.
- Step 8** In the **Change World Wide Port Name** dialog box, do the following:
- a) From the **WWPN Assignment** drop-down list, do one of the following:
 - Use the default WWPN pool, choose **Select (pool default used by default)**.
 - Use a WWPN derived from the manufacturers specifications, choose **Hardware Default**.
 - A specific WWPN, choose **20:00:00:25:B5:00:00:00** and enter the WWNN in the **WWPN** field.
 - A WWPN from a pool, select the pool name from the list. Each pool name is followed by number of available/total WWPNs in the pool.
 - b) Click **OK**.
-

Clearing Persistent Binding for a vHBA

Procedure

- Step 1** In the **Navigation** pane, click the **Servers** tab.
 - Step 2** On the **Servers** tab, expand **Servers** ► **Service Profiles**.
 - Step 3** Expand the node for the organization that contains the service profile for which you want to modify the vHBA.
 - Step 4** Expand *Service_Profile_Name* ► **vHBAs**.
 - Step 5** Click the vHBA for which you want to clear the persistent binding.
 - Step 6** In the **Work** pane, click the **General** tab.
 - Step 7** In the **Actions** area, click **Clear Persistent Binding**.
 - Step 8** If Cisco UCS Manager displays a confirmation dialog box, click **Yes**.
-

Deleting a vHBA from a Service Profile

Procedure

- Step 1** In the **Navigation** pane, click the **Servers** tab.
 - Step 2** On the **Servers** tab, expand **Servers** ► **Service Profiles**.
 - Step 3** Expand the node for the organization that contains the service profile from which you want to delete a vHBA.
 - Step 4** Expand the service profile from which you want to delete a vHBA.
 - Step 5** Expand the **vHBAs** node.
 - Step 6** Right-click on the vHBA you want to delete and choose **Delete**.
 - Step 7** If Cisco UCS Manager displays a confirmation dialog box, click **Yes**.
-

Binding a Service Profile to a Service Profile Template

You can bind a service profile to a service profile template. When you bind the service profile to a template, Cisco UCS Manager configures the service profile with the values defined in the service profile template. If the existing service profile configuration does not match the template, Cisco UCS Manager reconfigures the service profile. You can only change the configuration of a bound service profile through the associated template.

Procedure

- Step 1** In the **Navigation** pane, click the **Servers** tab.
- Step 2** On the **Servers** tab, expand **Servers** ► **Service Profiles**.
- Step 3** Expand the node for the organization that includes the service profile you want to bind.

If the system does not include multi-tenancy, expand the **root** node.

- Step 4** Click the service profile you want to bind.
 - Step 5** In the **Work** pane, click the **General** tab.
 - Step 6** In the **Actions** area, click **Bind to a Template**.
 - Step 7** In the **Bind to a Service Profile Template** dialog box, do the following:
 - a) From the **Service Profile Template** drop-down list, choose the template to which you want to bind the service profile.
 - b) Click **OK**.
-

Unbinding a Service Profile from a Service Profile Template

Procedure

- Step 1** In the **Navigation** pane, click the **Servers** tab.
 - Step 2** On the **Servers** tab, expand **Servers** ► **Service Profiles**.
 - Step 3** Expand the node for the organization that includes the service profile you want to unbind. If the system does not include multi-tenancy, expand the **root** node.
 - Step 4** Click the service profile you want to unbind.
 - Step 5** In the **Work** pane, click the **General** tab.
 - Step 6** In the **Actions** area, click **Unbind from the Template**.
 - Step 7** If Cisco UCS Manager displays a confirmation dialog box, click **Yes**.
-

Deleting a Service Profile

Procedure

- Step 1** In the **Navigation** pane, click the **Servers** tab.
 - Step 2** In the **Servers** tab, expand **Servers** ► **Service Profiles** ► *Organization_Name* .
 - Step 3** Right-click the service profile you want to delete and select **Delete**.
 - Step 4** If Cisco UCS Manager displays a confirmation dialog box, click **Yes**.
 - Step 5** Click **OK**.
-



CHAPTER 25

Installing an OS on a Server

This chapter includes the following sections:

- [OS Installation Methods, page 253](#)
- [Installation Targets, page 254](#)
- [Installing an OS Using a PXE Installation Server, page 255](#)
- [Installing an OS Using the KVM Dongle, page 255](#)
- [Installing an OS Using the KVM Console, page 256](#)

OS Installation Methods

Servers in the Cisco UCS support several operating systems, including Windows- and Linux-based operating systems. Regardless of the OS being installed, you can install it on a server using one of the following methods:

- PXE install server
- KVM dongle directly connected to the server
- KVM console in the UCS Manager GUI
- Third-party tool (not covered in this document)

PXE Install Server

A Preboot Execution Environment (PXE) install server allows clients (servers) to boot and install an OS over the network. To use this method, a PXE environment must be configured and available on a VLAN, typically a dedicated provisioning VLAN, and a client server must be set to boot from the network. When a client server boots, it sends a PXE request across the network, and the PXE install server acknowledges the request and starts a sequence of events that installs the OS on the client server.

PXE servers can use installation disks, disk images, and scripts to install the OS. Proprietary disk images can also be used install an OS and additional components or applications.

PXE installation is an efficient method for consistently installing an OS on a large number of servers. However, considering that this method requires configuring a PXE environment, if you do not already have an PXE

install server set up, it might be easier to use one of the other installation methods if you are installing an OS on only one or two servers,

KVM Dongle

The KVM dongle plugs into the front of a server and allows you to directly connect a keyboard, video monitor, mouse, and USB CD/DVD or floppy drive to the server. This direct access to the server allows you to locally install an OS.

To install an OS from a CD/DVD or floppy drive connected to the USB port, you must ensure that the CD/DVD or floppy drive is set as the first boot device in the service profile.

KVM Console

The KVM console is an interface accessible from the Cisco UCS Manager GUI that emulates a direct KVM connection. Unlike the KVM dongle, which requires you to be physically connected to the server, the KVM console allows you to connect to the server from a remote location across the network.

Instead of using CD/DVD or floppy drives directly connected to the server, the KVM console uses virtual media, which are actual disk drives or disk image files that are mapped to virtual CD/DVD or floppy drives. You can map any of the following to virtual drives:

- CD/DVD or floppy drives on your computer
- Disk image files on your computer
- CD/DVD or floppy drives on the network
- Disk image files on the network

To install an OS from a virtual CD/DVD or floppy drive, you must ensure that the virtual CD/DVD or floppy drive is set as the first boot device in the service profile.

Installing an OS using the KVM console may be slower than using the KVM dongle because the installation files must be downloaded across the network to the server. If you map a disk drive or disk image file from a network share to a virtual drive, the installation may be even slower because the installation files must be downloaded from the network to the KVM console (your computer) and then from the KVM console to the server. When using this installation method, we recommend that you have the installation media as close as possible to the system with the KVM console.

Installation Targets

The installation target is the location where you install the OS. The UCS server has two possible installation targets: a local hard drive or a SAN LUN. During the OS installation process, drivers for the local disk controller or HBA must be loaded so that the installer can find the drives. If the installer cannot find any drives, the drivers were probably not loaded. Newer OS installation disks should have the drivers; however, older OS installation disks may not have them.

If your OS installation disk does not have the needed drivers, you must provide them during the installation process. For local drives, you need LSI controller drivers, and for HBAs you need Emulex or Qlogic drivers.

Installing an OS Using a PXE Installation Server

Before You Begin

- Verify that a PXE installation environment has been configured to install the appropriate OS, and that the client server can be reached over a VLAN.
- Verify that a service profile is associated with the server onto which the OS is being installed.

Procedure

- Step 1** Depending on whether the service profile is associated with a boot policy, or contains the definition for a local boot policy, perform one of the following:
- a) For a service profile with a boot policy, set the boot order for the boot policy to boot from the LAN first. For more information, see [Creating a Boot Policy, page 185](#)
 - b) For a service profile which contains the definition for a local boot policy, set the boot order for the local boot definition to boot from the LAN first.

- Step 2** Reboot the server.
For more information, see [Booting a Server from the Service Profile, page 270](#)

If a PXE install server is available on a VLAN, the installation process begins when the server reboots. PXE installations are typically automated and require no additional user input. Refer to the installation guide for the OS being installed to guide you through the rest of the installation process.

What to Do Next

After the OS installation is complete, reset the LAN boot order to its original setting.

Installing an OS Using the KVM Dongle

Before You Begin

- Locate the following items:
 - USB keyboard and mouse
 - Video monitor
 - USB CD/DVD drive
 - USB floppy drive (optional)
 - OS installation disk or disk image file
- Verify that a service profile is associated with the server onto which the OS is being installed.

Procedure

- Step 1** Connect the KVM dongle to the front of the server.
- Step 2** Connect the keyboard, video monitor, mouse, USB CD/DVD drive, and optionally a USB floppy drive to the KVM console.
- Note** The USB dongle contains only two USB ports. To connect more than two USB devices to the dongle, first connect a USB hub to the dongle and then connect your USB devices to the hub.
- Step 3** Load the OS installation disk into the USB CD/DVD drive connected to the dongle.
- Step 4** If Cisco UCS Manager GUI is not open, log in.
- Step 5** Depending on whether the service profile is associated with a boot policy, or contains the definition for a local boot policy, perform one of the following:
- For a service profile with a boot policy, set the boot order for the boot policy to boot from the virtual media first.
For more information, see [Creating a Boot Policy, page 185](#).
 - For a service profile which contains the definition for a local boot policy, set the boot order for the local boot definition to boot from the virtual media first.
- Step 6** Reboot the server.
For more information, see [Booting a Server from the Service Profile, page 270](#)
- When the server reboots, it begins the installation process from the CD/DVD drive. Refer to the installation guide for the OS being installed to guide you through the rest of the installation process.
-

What to Do Next

After the OS installation is complete, reset the virtual media boot order to its original setting.

Installing an OS Using the KVM Console

Before You Begin

- Locate the OS installation disk or disk image file.
- Verify that a service profile is associated with the server onto which the OS is being installed.

Procedure

- Step 1** Load the OS installation disk into your CD/DVD drive, or copy the disk image files to your computer.
- Step 2** If Cisco UCS Manager GUI is not open, log in.
- Step 3** In the **Navigation** pane, click the **Servers** tab.
- Step 4** On the **Servers** tab, expand **Servers** ► **Service Profiles**.
- Step 5** Expand the node for the organization that contains the service profile associated with the server on which the OS is being installed and click the service profile.

If the system does not include multi-tenancy, expand the **root** node and click the service profile.

Step 6 In the **Work** pane, click the **General** tab.

Step 7 In the **Actions** area, click **KVM Console**.
The KVM Console opens in a separate window.

Step 8 From the KVM console, choose **Tools ► Launch Virtual Media** to open the Virtual Media Session dialog box.

Step 9 In the Virtual Media Session dialog box, map the virtual media using either of the following methods:

- Check the **Mapped** checkbox for the CD/DVD drive containing the OS installation disk.
- Click **Add Image**, navigate to and select the OS installation disk image, click **Open** to mount the disk image, and then check the **Mapped** checkbox for the mounted disk image.

Note You must keep the **Virtual Media Session** dialog box open during the OS installation process; closing the dialog box unmaps all virtual media.

Step 10 Depending on whether the service profile is associated with a boot policy, or contains the definition for a local boot policy, perform one of the following in Cisco UCS Manager GUI:

- For a service profile with a boot policy, set the boot order for the boot policy to boot from the virtual media first.
For more information, see [Creating a Boot Policy](#), page 185.
- For a service profile which contains the definition for a local boot policy, set the boot order for the local boot definition to boot from the virtual media first.

Step 11 Reboot the server.

For more information, see [Booting a Server from the Service Profile](#), page 270

When the server reboots, it begins the installation process from the virtual CD/DVD drive. Refer to the installation guide for the OS being installed to guide you through the rest of the installation process.

What to Do Next

After the OS installation is complete, reset the virtual media boot order to its original setting.



PART VI

System Management

- [Managing Time Zones, page 261](#)
- [Managing the Chassis, page 263](#)
- [Managing the Servers, page 269](#)
- [Managing the IO Modules, page 281](#)
- [Configuring Call Home, page 285](#)
- [Backing Up and Restoring the Configuration, page 301](#)
- [Configuring Settings for Faults, Events, and Logs, page 315](#)
- [Recovering a Lost Password, page 323](#)
- [Configuring Statistics-Related Policies, page 327](#)



CHAPTER 26

Managing Time Zones

This chapter includes the following sections:

- [Time Zones, page 261](#)
- [Setting the Time Zone, page 261](#)
- [Adding an NTP Server, page 262](#)
- [Deleting an NTP Server, page 262](#)

Time Zones

Cisco UCS requires an instance-specific time zone setting and an NTP server to ensure the correct time display in Cisco UCS Manager. If you do not configure both of these settings in a Cisco UCS instance, the time does not display correctly.

Setting the Time Zone

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
 - Step 2** In the **Admin** tab, expand **All**.
 - Step 3** Click **Timezone Management**.
 - Step 4** In the **Work** pane, click the **General** tab.
 - Step 5** From the **Timezone** drop-down list, select the time zone you want to use for the Cisco UCS instance.
 - Step 6** Click **Save Changes**.
-

Adding an NTP Server

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
 - Step 2** In the **Admin** tab, expand **All**.
 - Step 3** Click **Timezone Management**.
 - Step 4** In the **Work** pane, click the **General** tab.
 - Step 5** In the **NTP Servers** area, click the + button on the table icon bar.
 - Step 6** In the **Add NTP Server** dialog box, do the following:
 - a) In the **NTP Server** field, enter the IP address or hostname of the NTP server you want to use for this Cisco UCS instance.
 - b) Click **OK**.
-

Deleting an NTP Server

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
 - Step 2** In the **Admin** tab, expand **All**.
 - Step 3** Click **Timezone Management**.
 - Step 4** In the **Work** pane, click the **General** tab.
 - Step 5** In the **NTP Servers** area, right-click the server you want to delete and select **Delete**.
 - Step 6** If Cisco UCS Manager displays a confirmation dialog box, click **Yes**.
 - Step 7** Click **Save Changes**.
-



CHAPTER 27

Managing the Chassis

This chapter includes the following sections:

- [Chassis Management in Cisco UCS Manager GUI](#) , page 263
- [Acknowledging a Chassis](#), page 263
- [Removing a Chassis](#), page 264
- [Recommissioning a Chassis](#), page 264
- [Toggling the Locator LED](#), page 265
- [Monitoring a Chassis](#), page 265
- [Viewing the POST Results for a Chassis](#), page 267

Chassis Management in Cisco UCS Manager GUI

You can manage and monitor all chassis in a Cisco UCS instance through Cisco UCS Manager GUI.

Acknowledging a Chassis

Perform the following procedure if you increase or decrease the number of links that connect the chassis to the fabric interconnect. Acknowledging the chassis ensures that Cisco UCS Manager is aware of the change in the number of links and that traffics flows along all available links.

Procedure

- Step 1** In the **Navigation** pane, click the **Equipment** tab.
- Step 2** On the **Equipment** tab, expand **Equipment** ► **Chassis**.
- Step 3** Choose the chassis that you want to acknowledge.
- Step 4** In the **Work** pane, click the **General** tab.
- Step 5** In the **Actions** area, click **Acknowledge Chassis**.
- Step 6** If Cisco UCS Manager displays a the confirmation dialog box, click **Yes**.

Cisco UCS Manager disconnects the chassis and then rebuilds the connections between the chassis and the fabric interconnect or fabric interconnects in the system.

Removing a Chassis

This procedure removes the chassis from the configuration. As long as the chassis physically remains in the Cisco UCS instance, Cisco UCS Manager considers the chassis to be decommissioned and ignores it.

Procedure

- Step 1** In the **Navigation** pane, click the **Equipment** tab.
 - Step 2** On the **Equipment** tab, expand **Equipment** > **Chassis**.
 - Step 3** Choose the chassis that you want to remove.
 - Step 4** In the **Work** pane, click the **General** tab.
 - Step 5** In the **Actions** area, click **Remove Chassis**.
 - Step 6** If Cisco UCS Manager displays a confirmation dialog box, click **Yes**.
The removal may take several minutes to complete. After the chassis has been removed from the configuration, Cisco UCS Manager adds the chassis to the **Decommissioned** tab.
-

Recommissioning a Chassis

This procedure returns the chassis to the configuration and applies the chassis discovery policy to the chassis.

Procedure

- Step 1** In the **Navigation** pane, click the **Equipment** tab.
 - Step 2** In the **Equipment** tab, expand the **Equipment** node.
 - Step 3** Click the **Chassis** node.
 - Step 4** In the **Work** pane, click the **Decommissioned** tab.
 - Step 5** Right-click the chassis you want to enable and choose **Recommission**.
 - Step 6** If Cisco UCS Manager displays a confirmation dialog box, click **Yes**.
This procedure may take several minutes to complete. After the chassis has been recommissioned, Cisco UCS Manager runs the chassis discovery policy and adds the chassis to the list in the **Navigation** pane.
-

Toggling the Locator LED

Turning on the Locator LED for a Chassis

Procedure

- Step 1** In the **Navigation** pane, click the **Equipment** tab.
 - Step 2** On the **Equipment** tab, expand **Equipment** ► **Chassis**.
 - Step 3** Click the chassis that you need to locate.
 - Step 4** In the **Work** pane, click the **General** tab.
 - Step 5** In the **Actions** area, click **Turn on Locator LED**.
This action is not available if the locator LED is already turned on.
The LED on the chassis starts flashing.
-

Turning off the Locator LED for a Chassis

Procedure

- Step 1** In the **Navigation** pane, click the **Equipment** tab.
 - Step 2** On the **Equipment** tab, expand **Equipment** ► **Chassis**.
 - Step 3** Choose the chassis for which you want to turn off the locator LED.
 - Step 4** In the **Work** pane, click the **General** tab.
 - Step 5** In the **Actions** area, click **Turn off Locator LED**.
This action is not available if the locator LED is already turned off.
The LED on the chassis stops flashing.
-

Monitoring a Chassis

**Tip**

To monitor an individual component in a chassis, expand the node for that component.

Procedure

- Step 1** In the **Navigation** pane, click the **Equipment** tab.
- Step 2** On the **Equipment** tab, expand **Equipment > Chassis**.
- Step 3** Click the chassis that you want to monitor.
- Step 4** Click one of the following tabs to view the status of the chassis:

Option	Description
General tab	Provides an overview of the status of the chassis, including a summary of any faults, a summary of the chassis properties, and a physical display of the chassis and its components.
Servers tab	Displays the status and selected properties of all servers in the chassis.
Service Profiles tab	Displays the status of the service profiles associated with servers in the chassis.
IO Modules tab	Displays the status and selected properties of all IO modules in the chassis.
Fans tab	Displays the status of all fan modules in the chassis.
PSUs	Displays the status of all power supply units in the chassis.
Hybrid Display tab	Displays detailed information about the connections between the chassis and the fabric interconnects. The display has an icon for the following: <ul style="list-style-type: none"> • Each fabric interconnect in the system • The I/O module (IOM) in the selected chassis, which is shown as an independent unit to make the connection paths easier to see • The selected chassis showing the servers and PSUs
Slots tab	Displays the status of all slots in the chassis.
Installed Firmware tab	Displays the current firmware versions on the IO modules and servers in the chassis. You can also use this tab to update and activate the firmware on those components.
Faults tab	Provides details of faults generated by the chassis.
Events tab	Provides details of events generated by the chassis.
FSM tab	Provides details about and the status of FSM tasks related to the chassis. You can use this information to diagnose errors with those tasks.
Statistics tab	Provides statistics about the chassis and its components. You can view these statistics in tabular or chart format.

Option	Description
Temperatures tab	Provides temperature statistics for the components of the chassis. You can view these statistics in tabular or chart format.
Power tab	Provides power statistics for the components of the chassis. You can view these statistics in tabular or chart format.

Viewing the POST Results for a Chassis

You can view any errors collected during the Power On Self-Test process for all servers and adapters in a chassis.

Procedure

- Step 1** In the **Navigation** pane, click the **Equipment** tab.
- Step 2** On the **Equipment** tab, expand **Equipment** ► **Chassis**.
- Step 3** Choose the chassis for which you want to view the POST results.
- Step 4** In the **Work** pane, click the **General** tab.
- Step 5** In the **Actions** area, click **View POST Results**.
The **POST Results** dialog box lists the POST results for each server in the chassis and its adapters.
- Step 6** (Optional) Click the link in the **Affected Object** column to view the properties of that adapter.
- Step 7** Click **OK** to close the **POST Results** dialog box.



CHAPTER 28

Managing the Servers

This chapter includes the following sections:

- [Server Management in Cisco UCS Manager GUI](#), page 269
- [Booting Servers](#), page 270
- [Shutting Down Servers](#), page 271
- [Resetting a Server](#), page 271
- [Reacknowledging a Server](#), page 272
- [Removing a Server from a Chassis](#), page 273
- [Decommissioning a Server](#), page 273
- [Reacknowledging a Server Slot in a Chassis](#), page 274
- [Removing a Non-Existent Server from the Configuration Database](#), page 274
- [Toggling the Locator LED](#), page 275
- [Starting the KVM Console](#), page 276
- [Resetting the CMOS for a Server](#), page 277
- [Resetting the BMC for a Server](#), page 277
- [Recovering the Corrupt BIOS on a Server](#), page 278
- [Monitoring a Server](#), page 279
- [Viewing the POST Results for a Server](#), page 280

Server Management in Cisco UCS Manager GUI

You can manage and monitor all servers in a Cisco UCS instance through Cisco UCS Manager GUI. Some server management tasks, such as changes to the power state, can be performed from the following locations:

- **General** tab for the server
- **General** tab for the service profile associated with the server

The remaining management tasks can only be performed on the server.

If a server slot in a chassis is empty, Cisco UCS Manager provides information, errors, and faults for that slot. You can also reacknowledge the slot to resolve server mismatch errors and to have Cisco UCS Manager rediscover the server in the slot.

Booting Servers

Booting a Server

If the **Boot Server** link is dimmed in the **Actions** area, you must shut down the server first.

Procedure

- Step 1** In the **Navigation** pane, click the **Equipment** tab.
 - Step 2** On the **Equipment** tab, expand **Equipment** ► **Chassis** ► *Chassis Number* ► **Servers**.
 - Step 3** Choose the server that you want to boot.
 - Step 4** In the **Work** pane, click the **General** tab.
 - Step 5** In the **Actions** area, click **Boot Server**.
 - Step 6** If Cisco UCS Manager displays a confirmation dialog box, click **Yes**.
-

After the server has booted, the **Overall Status** field on the **General** tab displays an OK status.

Booting a Server from the Service Profile

Procedure

- Step 1** In the **Navigation** pane, click the **Servers** tab.
 - Step 2** On the **Servers** tab, expand **Servers** ► **Service Profiles**.
 - Step 3** Expand the node for the organization where you want to create the service profile. If the system does not include multi-tenancy, expand the **root** node.
 - Step 4** Choose the service profile that requires the associated server to be booted.
 - Step 5** In the **Work** pane, click the **General** tab.
 - Step 6** In the **Actions** area, click **Boot Server**.
 - Step 7** If Cisco UCS Manager displays a confirmation dialog box, click **Yes**.
 - Step 8** Click **OK** in the **Boot Server** dialog box. After the server has booted, the **Overall Status** field on the **General** tab displays an ok status or an up status.
-

Shutting Down Servers

Shutting Down a Server

When you use this procedure to shut down a server with an installed operating system, Cisco UCS Manager triggers the OS into a graceful shutdown sequence.

If the **Shut Down** link is dimmed in the **Actions** area, the server is not running.

Procedure

- Step 1** In the **Navigation** pane, click the **Equipment** tab.
 - Step 2** On the **Equipment** tab, expand **Equipment** ► **Chassis** ► *Chassis Number* ► **Servers**.
 - Step 3** Choose the server that you want to shut down.
 - Step 4** In the **Work** pane, click the **General** tab.
 - Step 5** In the **Actions** area, click **Shut Down**.
 - Step 6** If Cisco UCS Manager displays a confirmation dialog box, click **Yes**.
-

After the server has been successfully shut down, the **Overall Status** field on the **General** tab displays a power-off status.

Shutting down a Server from the Service Profile

Procedure

- Step 1** In the **Navigation** pane, click the **Servers** tab.
 - Step 2** On the **Servers** tab, expand **Servers** ► **Service Profiles**.
 - Step 3** Expand the node for the organization where you want to create the service profile.
If the system does not include multi-tenancy, expand the **root** node.
 - Step 4** Choose the service profile that requires the associated server to be shut down.
 - Step 5** In the **Work** pane, click the **General** tab.
 - Step 6** In the **Actions** area, click **Shut Down**.
 - Step 7** If Cisco UCS Manager displays a confirmation dialog box, click **Yes**.
-

After the server has been successfully shut down, the **Overall Status** field on the **General** tab displays a down status or a power-off status.

Resetting a Server

When you reset a server, Cisco UCS Manager sends a pulse on the reset line. You can choose to gracefully shutdown the operating system. If the operating system does not support a graceful shutdown, the server will

be power cycled. The option to have Cisco UCS Manager complete all management operations before it resets the server, does not guarantee that these operations will be completed before the server is reset.

Procedure

- Step 1** In the **Navigation** pane, click the **Equipment** tab.
 - Step 2** On the **Equipment** tab, expand **Equipment** > **Chassis** > *Chassis Number* > **Servers**.
 - Step 3** Choose the server that you want to reset.
 - Step 4** In the **Work** pane, click the **General** tab.
 - Step 5** In the **Actions** area, click **Reset**.
 - Step 6** In the **Reset Server** dialog box, do the following:
 - a) Click the **Power Cycle** option.
 - b) (Optional) Check the check box if you want Cisco UCS Manager to complete all management operations that are pending on this server.
 - c) Click **OK**.
-

The reset may take several minutes to complete. After the server has been reset, the **Overall Status** field on the **General** tab displays an ok status.

Reacknowledging a Server

Perform the following procedure if you need to have Cisco UCS Manager rediscover the server and all components in the server. For example, you can use this procedure if a server is stuck in an unexpected state, such as the discovery state.

Procedure

- Step 1** In the **Navigation** pane, click the **Equipment** tab.
- Step 2** On the **Equipment** tab, expand **Equipment** > **Chassis** > *Chassis Number* > **Servers**.
- Step 3** Choose the server that you want to acknowledge.
- Step 4** In the **Work** pane, click the **General** tab.
- Step 5** In the **Actions** area, click **Server Maintenance**.
- Step 6** In the **Maintenance** dialog box, do the following:
 - a) Click **Re-acknowledge**.
 - b) Click **OK**.

Cisco UCS Manager disconnects the server and then builds the connections between the server and the fabric interconnect or fabric interconnects in the system. The acknowledgment may take several minutes to complete. After the server has been acknowledged, the **Overall Status** field on the **General** tab displays an OK status.

Removing a Server from a Chassis

Perform the following procedure when you remove a server from a chassis. Do not physically remove the server first.

Procedure

- Step 1** In the **Navigation** pane, click the **Equipment** tab.
 - Step 2** On the **Equipment** tab, expand **Equipment** ► **Chassis** ► *Chassis Number* ► **Servers**.
 - Step 3** Choose the server that you want to remove from the chassis.
 - Step 4** In the **Work** pane, click the **General** tab.
 - Step 5** In the **Actions** area, click **Server Maintenance**.
 - Step 6** In the **Maintenance** dialog box, do the following:
 - a) Click **Decommission**.
 - b) Click **OK**.The server is removed from the Cisco UCS configuration.
 - Step 7** Go to the physical location of the chassis and remove the server hardware from the slot.
For instructions on how to remove the server hardware, see the *Cisco UCS Hardware Installation Guide* for your chassis.
-

What to Do Next

If you do not want to physically remove the server hardware, you must re-acknowledge the slot to have Cisco UCS Manager rediscover the server.

For more information, see [Reacknowledging a Server Slot in a Chassis](#), page 274

Decommissioning a Server

This procedure removes the server from the configuration. As long as the server physically remains in the Cisco UCS instance, Cisco UCS Manager considers the server to be decommissioned and ignores it.

Procedure

- Step 1** In the **Navigation** pane, click the **Equipment** tab.
- Step 2** On the **Equipment** tab, expand **Equipment** ► **Chassis** ► *Chassis Number* ► **Servers**.
- Step 3** Choose the server that you want to decommission.
- Step 4** In the **Work** pane, click the **General** tab.
- Step 5** In the **Actions** area, click **Server Maintenance**.
- Step 6** In the **Maintenance** dialog box, do the following:
 - a) Click **Decommission**.
 - b) Click **OK**.

The server is removed from the Cisco UCS configuration.

What to Do Next

If you do not want to physically remove the server hardware, you must re-acknowledge the slot to have Cisco UCS Manager rediscover the server.

For more information, see [Reacknowledging a Server Slot in a Chassis, page 274](#)

Reacknowledging a Server Slot in a Chassis

Perform the following procedure if you decommission a server without removing the physical hardware and you want Cisco UCS Manager to rediscover and recommission the server.

Procedure

- Step 1** In the **Navigation** pane, click the **Equipment** tab.
- Step 2** On the **Equipment** tab, expand **Equipment** ► **Chassis** ► **Chassis Number** ► **Servers**.
- Step 3** Choose the server whose slot you want to reacknowledge.
- Step 4** If Cisco UCS Manager displays a **Resolve Slot Issue** dialog box, do one of the following:

Option	Description
The here link in the Situation area	Click this link and then click Yes in the confirmation dialog box. Cisco UCS Manager reacknowledges the slot and discovers the server in the slot.
OK	Click this button if you want to proceed to the General tab. You can use the Reacknowledge Slot link in the Actions area to have Cisco UCS Manager reacknowledge the slot and discover the server in the slot.

Removing a Non-Existent Server from the Configuration Database

Perform the following procedure if you physically removed a server from its slot in a chassis without first decommissioning the server. You cannot perform this procedure if the server is physically present in the chassis slot.

If you want to physically remove a server, see [Removing a Server from a Chassis, page 273](#).

Procedure

- Step 1** In the **Navigation** pane, click the **Equipment** tab.
- Step 2** On the **Equipment** tab, expand **Equipment** ► **Chassis** ► *Chassis Number* ► **Servers**.
- Step 3** Choose the server that you want to remove from the configuration database.
- Step 4** In the **Work** pane, click the **General** tab.
- Step 5** In the **Actions** area, click **Server Maintenance**.
- Step 6** In the **Maintenance** dialog box, do the following:
 - a) Click **Remove**.
 - b) Click **OK**.

Cisco UCS Manager removes all data about the server from its configuration database. The server slot is now available for you to insert new server hardware.

Toggling the Locator LED

Turning on the Locator LED for a Server

Procedure

- Step 1** In the **Navigation** pane, click the **Equipment** tab.
 - Step 2** On the **Equipment** tab, expand **Equipment** ► **Chassis** ► *Chassis Number* ► **Servers**.
 - Step 3** Choose the server that you need to locate.
 - Step 4** In the **Work** pane, click the **General** tab.
 - Step 5** In the **Actions** area, click **Turn on Locator LED**.
This action is not available if the locator LED is already turned on.
The LED on the chassis starts flashing.
-

Turning off the Locator LED for a Server

Procedure

- Step 1** In the **Navigation** pane, click the **Equipment** tab.
- Step 2** On the **Equipment** tab, expand **Equipment** ► **Chassis** ► *Chassis Number* ► **Servers**.
- Step 3** Choose the server for which you want to turn off the locator LED.
- Step 4** In the **Work** pane, click the **General** tab.
- Step 5** In the **Actions** area, click **Turn off Locator LED**.

This action is not available if the locator LED is already turned off.
The LED on the server stops flashing.

Starting the KVM Console

Starting the KVM Console from a Server

Procedure

- Step 1** In the **Navigation** pane, click the **Equipment** tab.
 - Step 2** On the **Equipment** tab, expand **Equipment** ► **Chassis** ► *Chassis Number* ► **Servers**.
 - Step 3** Choose the server that you want to access through the KVM Console.
 - Step 4** In the **Work** pane, click the **General** tab.
 - Step 5** In the **Actions** area, click **KVM Console**.
The KVM Console opens in a separate window.
- Tip** If the Caps Lock key on your keyboard is on when you open a KVM session, and you subsequently turn off your Caps Lock key, the KVM Console may continue to act as if Caps Lock is turned on. To synchronize the KVM Console and your keyboard, press Caps Lock once without the KVM Console in focus and then press Caps Lock again with the KVM Console in focus.
-

Starting the KVM Console from a Service Profile

Procedure

- Step 1** In the **Navigation** pane, click the **Servers** tab.
 - Step 2** On the **Servers** tab, expand **Servers** ► **Service Profiles**.
 - Step 3** Expand the node for the organization which contains the service profile for which you want to launch the KVM Console.
If the system does not include multi-tenancy, expand the **root** node.
 - Step 4** Choose the service profile for which you need KVM access to the associated server.
 - Step 5** In the **Work** pane, click the **General** tab.
 - Step 6** In the **Actions** area, click **KVM Console**.
The KVM Console opens in a separate window.
- Tip** If the Caps Lock key on your keyboard is on when you open a KVM session, and you subsequently turn off your Caps Lock key, the KVM Console may continue to act as if Caps Lock is turned on. To synchronize the KVM Console and your keyboard, press Caps Lock once without the KVM Console in focus and then press Caps Lock again with the KVM Console in focus.
-

Resetting the CMOS for a Server

On rare occasions, troubleshooting a server may require you to reset the CMOS. This procedure is not part of the normal maintenance of a server.

Procedure

-
- Step 1** In the **Navigation** pane, click the **Equipment** tab.
 - Step 2** On the **Equipment** tab, expand **Equipment** > **Chassis** > *Chassis Number* > **Servers**.
 - Step 3** Choose the server for which you want to reset the CMOS.
 - Step 4** In the **Work** pane, click the **General** tab.
 - Step 5** In the **Actions** area, click **Recover Server**.
 - Step 6** In the **Recover Server** dialog box, do the following:
 - a) Click **Reset CMOS**.
 - b) Click **OK**.
-

Resetting the BMC for a Server

On rare occasions, such as an issue with the current running firmware, troubleshooting a server may require you to reset the BMC. This procedure is not part of the normal maintenance of a server. After you reset the BMC, the server boots with the running version of the firmware for that server.

Procedure

-
- Step 1** In the **Navigation** pane, click the **Equipment** tab.
 - Step 2** On the **Equipment** tab, expand **Equipment** > **Chassis** > *Chassis Number* > **Servers**.
 - Step 3** Choose the server for which you want to reset the BMC.
 - Step 4** In the **Work** pane, click the **General** tab.
 - Step 5** In the **Actions** area, click **Recover Server**.
 - Step 6** In the **Recover Server** dialog box, do the following:
 - a) Click **Recover Corrupt BIOS**.
 - b) Click **OK**.
 - Step 7** In the **Recover Corrupt BIOS** dialog box, do the following:
 - a) Complete the following fields:

Name	Description
Version To Be Activated drop-down list	Choose the firmware version that you want to activate from the drop-down list.

Name	Description
Ignore Compatibility Check check box	<p>By default, Cisco UCS makes sure that the firmware version is compatible with everything running on the server before it activates that version.</p> <p>Check this check box if you want Cisco UCS to activate the firmware without making sure that it is compatible first.</p> <p>Note We recommend that you use this option only when explicitly directed to do so by a technical support representative.</p>

b) Click **OK**.

Recovering the Corrupt BIOS on a Server

On rare occasions, an issue with a server may require you to recover the corrupted BIOS. This procedure is not part of the normal maintenance of a server. After you recover the BIOS, the server boots with the running version of the firmware for that server. This radio button may be dimmed if the BIOS does not require recovery or the option is not available for a particular server.

Before You Begin



Important Remove all attached or mapped USB storage from a server before you attempt to recover the corrupt BIOS on that server. If an external USB drive is attached or mapped from vMedia to the server, BIOS recovery fails.

Procedure

- Step 1** In the **Navigation** pane, click the **Equipment** tab.
- Step 2** On the **Equipment** tab, expand **Equipment** ► **Chassis** ► *Chassis Number* ► **Servers**.
- Step 3** Choose the server for which you want to recover the BIOS.
- Step 4** In the **Work** pane, click the **General** tab.
- Step 5** In the **Actions** area, click **Recover Server**.
- Step 6** In the **Recover Server** dialog box, do the following:
 - a) Click **Reset iBMC (Server Controller)**.
 - b) Click **OK**.

Monitoring a Server

Procedure

- Step 1** In the **Navigation** pane, click the **Equipment** tab.
- Step 2** On the **Equipment** tab, expand **Equipment** ► **Chassis** ► **Chassis Number** ► **Servers**.
- Step 3** Click the server that you want to monitor.
- Step 4** In the **Work** pane, click one of the following tabs to view the status of the server:

Option	Description
General tab	Provides an overview of the status of the server, including a summary of any faults, a summary of the server properties, and a physical display of the server and its components.
Inventory tab	The sub-tabs display the properties and status of the components of the server.
Installed Firmware tab	Displays the current firmware versions on the BMC and interface cards in the server. You can also use this tab to update and activate the firmware on those components.
Faults tab	Provides details of faults generated by the server.
Events tab	Provides details of events generated by the server.
FSM tab	Provides details about and the status of FSM tasks related to the server. You can use this information to diagnose errors with those tasks.
Statistics tab	Provides statistics about the server and its components. You can view these statistics in tabular or chart format.
Temperatures tab	Provides temperature statistics for the components of the server. You can view these statistics in tabular or chart format.
Power tab	Provides power statistics for the components of the server. You can view these statistics in tabular or chart format.

- Step 5** In the **Navigation** pane, expand **Server_ID** ► **Interface Cards** ► **Interface_Card_ID**.
- Step 6** In the **Work** pane, you can view the status of one or more of the following components of the interface card:
- Interface card
 - DCE interfaces
 - HBAs
 - NICs

Tip If you expand these nodes, you can view the status of the components of that element. For example, if you expand a NIC node, you can view the properties and status of each VIF created on that NIC.

Viewing the POST Results for a Server

You can view any errors collected during the Power On Self-Test process for a server and its adapters.

Procedure

- Step 1** In the **Navigation** pane, click the **Equipment** tab.
 - Step 2** On the **Equipment** tab, expand **Equipment** ► **Chassis** ► *Chassis Number* ► **Servers**.
 - Step 3** Choose the server for which you want to view the POST results.
 - Step 4** In the **Work** pane, click the **General** tab.
 - Step 5** In the **Actions** area, click **View POST Results**.
The **POST Results** dialog box lists the POST results for the server and its adapters.
 - Step 6** (Optional) Click the link in the **Affected Object** column to view the properties of that adapter.
 - Step 7** Click **OK** to close the **POST Results** dialog box.
-



CHAPTER 29

Managing the IO Modules

This chapter includes the following sections:

- [I/O Module Management in Cisco UCS Manager GUI](#) , page 281
- [Resetting an I/O Module](#), page 281
- [Monitoring an I/O Module](#), page 282
- [Viewing the POST Results for an I/O Module](#), page 282

I/O Module Management in Cisco UCS Manager GUI

You can manage and monitor all I/O modules in a Cisco UCS instance through Cisco UCS Manager GUI.

Resetting an I/O Module

Procedure

- Step 1** In the **Navigation** pane, click the **Equipment** tab.
 - Step 2** On the **Equipment** tab, expand **Equipment** ► **Chassis** ► *Chassis Number* ► **IO Modules**.
 - Step 3** Choose the I/O module that you want to reset.
 - Step 4** In the **Work** pane, click the **General** tab.
 - Step 5** In the **Actions** area, click **Reset IO Module**.
 - Step 6** If Cisco UCS Manager displays a confirmation dialog box, click **Yes**.
-

Monitoring an I/O Module

Procedure

- Step 1** In the **Navigation** pane, click the **Equipment** tab.
- Step 2** On the **Equipment** tab, expand **Equipment** ► **Chassis** ► **Chassis Number** ► **IO Modules**.
- Step 3** Click the I/O module that you want to monitor.
- Step 4** Click one of the following tabs to view the status of the I/O module:

Option	Description
General tab	Provides an overview of the status of the I/O module, including a summary of any faults, a summary of the module properties, and a physical display of the module and its components.
Fabric Ports tab	Displays the status and selected properties of all fabric ports in the I/O module.
Backplane Ports tab	Displays the status and selected properties of all backplane ports in the I/O module.
Faults tab	Provides details of faults generated by the I/O module.
Events tab	Provides details of events generated by the I/O module.
FSM tab	Provides details about and the status of FSM tasks related to the I/O module. You can use this information to diagnose errors with those tasks.
Statistics tab	Provides statistics about the I/O module and its components. You can view these statistics in tabular or chart format.

Viewing the POST Results for an I/O Module

You can view any errors collected during the Power On Self-Test process for an I/O module.

Procedure

- Step 1** In the **Navigation** pane, click the **Equipment** tab.
- Step 2** On the **Equipment** tab, expand **Equipment** ► **Chassis** ► **Chassis Number** ► **IO Modules**.
- Step 3** Choose the I/O module for which you want to view the POST results.
- Step 4** In the **Work** pane, click the **General** tab.
- Step 5** In the **Actions** area, click **View POST Results**.

The **POST Results** dialog box lists the POST results for the I/O module.

Step 6 Click **OK** to close the **POST Results** dialog box.



CHAPTER 30

Configuring Call Home

This chapter includes the following sections:

- [Call Home, page 285](#)
- [Call Home Considerations, page 286](#)
- [Cisco Smart Call Home, page 286](#)
- [Configuring Call Home, page 287](#)
- [Disabling Call Home, page 289](#)
- [Enabling Call Home, page 289](#)
- [Configuring System Inventory Messages, page 290](#)
- [Sending System Inventory Messages, page 290](#)
- [Configuring Call Home Profiles, page 291](#)
- [Configuring Call Home Policies, page 293](#)
- [Configuring Call Home for Smart Call Home, page 295](#)

Call Home

Call Home provides an e-mail-based notification for critical system policies. A range of message formats are available for compatibility with pager services or XML-based automated parsing applications. You can use this feature to page a network support engineer, email a Network Operations Center, or use Cisco Smart Call Home services to automatically generate a case with the Technical Assistance Center.

Call Home provides email-based and web-based notification of critical system events. A versatile range of message formats are available for optimal compatibility with pager services or XML-based automated parsing applications. Common uses of this feature may include direct paging of a network support engineer, notification of a Network Operations Center, XML delivery to a support website, and utilization of Cisco Smart Call Home services for direct case generation with the Cisco Systems Technical Assistance Center (TAC).

The Call Home feature can deliver alert messages containing information about configuration, diagnostics, environmental conditions, inventory, and syslog events.

The Call Home feature can deliver alerts to multiple recipients, referred to as Call Home destination profiles. Each profile includes configurable message formats and content categories. A predefined destination profile is provided for sending alerts to the Cisco TAC, but you also can define your own destination profiles.

When you configure Call Home to send messages, Cisco UCS Manager automatically executes the appropriate CLI show command and attaches the command output to the message.

Cisco UCS delivers Call Home messages in the following formats:

- Short text format that is suitable for pagers or printed reports.
- XML machine readable format that uses Extensible Markup Language (XML) and Adaptive Messaging Language (AML) XML schema definition (XSD). The AML XSD is published on the Cisco.com website at <http://www.cisco.com/>. The XML format enables communication with the Cisco Systems Technical Assistance Center.

Call Home Considerations

How you configure Call Home depends on how you intend to use the feature. The information you need to consider before you configure Call Home includes the following:

- You must configure at least one destination profile. The destination profile or profiles that you use depend upon whether the receiving entity is a pager, email, or automated service such as Cisco Smart Call Home.
- If the destination profile uses email message delivery, you must specify a Simple Mail Transfer Protocol (SMTP) server when you configure Call Home.
- The contact email, phone, and street address information should be configured so that the receiver can determine the origin of messages received.
- The fabric interconnect must have IP connectivity to an email server or the destination HTTP server.
- If Cisco Smart Call Home is used, an active service contract must cover the device being configured.

Cisco Smart Call Home

Cisco Smart Call Home is a web application which leverages the Call Home feature of Cisco UCS. Smart Call Home offers proactive diagnostics and real-time email alerts of critical system events, which results in higher network availability and increased operational efficiency. Smart Call Home is a secure connected service offered by Cisco Unified Computing Support Service and Cisco Unified Computing Mission Critical Support Service for Cisco UCS.



Note

Using Smart Call Home requires the following:

- A CCO ID associated with a corresponding Cisco Unified Computing Support Service or Cisco Unified Computing Mission Critical Support Service contract for your company.
- Cisco Unified Computing Support Service or Cisco Unified Computing Mission Critical Support Service for the device to be registered.

You can configure and register Cisco UCS Manager to send Smart Call Home email alerts to either the Smart Call Home System or the secure Transport Gateway. Email alerts sent to the secure Transport Gateway are forwarded to the Smart Call Home System using HTTPS.



Note For security reasons, we recommend using the Transport Gateway option. The Transport Gateway can be downloaded from Cisco.

To configure Smart Call Home, you must do the following:

- Enable the Smart Call Home feature
- Configure the contact information
- Configure the email information
- Configure the SMTP server information
- Configure the default CiscoTAC-1 profile
- Send a Smart Call Home inventory message to start the registration process



Tip By default, email alerts are sent for all critical system events. However, you can optionally configure Call Home policies to enable or disable sending email alerts for other critical system events.

Configuring Call Home

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
- Step 2** In the **Admin** tab, expand **All ► Communication Services**.
- Step 3** Click **Call Home**.
- Step 4** In the **Work** pane, click the **General** tab.
- Step 5** In the **Admin** area, do the following to enable Call Home:
 - a) In the **State** field, click **on**.

Note If this field is set to **on**, Cisco UCS Manager GUI displays the rest of the fields on this tab.
 - b) From the **Urgency** drop-down list, select one of the following urgency levels:
 - **alerts**
 - **critical**
 - **debugging**
 - **emergencies**
 - **errors**
 - **information**

- notifications
- warnings

Step 6 In the **Contact Information** area, complete the following fields with the required contact information:

Name	Description
Contact field	The main Call Home contact person.
Phone field	The telephone number for the main contact. Enter the number in international format, starting with a + (plus sign) and a country code.
Email field	The email address for the main contact.
Address field	The mailing address for the main contact.

Step 7 (Optional) In the **Ids** area, complete the following fields with the identification information that Call Home should use:

Name	Description
Customer Id field	The unique identification number for the customer.
Contract Id field	The Call Home contract number for the customer.
Site Id field	The unique Call Home identification number for the customer site.

Step 8 In the **Email Addresses** area, complete the following fields with email information for Call Home alert messages:

Name	Description
From field	The email address that should appear in the From field on Call Home alert messages sent by the system.
Reply To field	The return email address that should appear in the From field on Call Home alert messages sent by the system.

Step 9 In the **SMTP Server** area, complete the following fields with information about the SMTP server where Call Home should send email messages:

Name	Description
Host (IP Address or Hostname) field	The IP address or hostname of the SMTP server.
Port field	The port number the system should use to talk to the SMTP server.

Step 10 Click **Save Changes**.

Disabling Call Home

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
 - Step 2** In the **Admin** tab, expand **All ► Communication Services**.
 - Step 3** Click **Call Home**.
 - Step 4** In the **Work** pane, click the **General** tab.
 - Step 5** In the **Admin** area, click **off** in the **State** field.
Note If this field is set to **off**, Cisco UCS Manager hides the rest of the fields on this tab.
 - Step 6** Click **Save Changes**.
-

Enabling Call Home

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
 - Step 2** In the **Admin** tab, expand **All ► Communication Services**.
 - Step 3** Click **Call Home**.
 - Step 4** In the **Work** pane, click the **General** tab.
 - Step 5** In the **Admin** area, click **on** in the **State** field.
Note If this field is set to **on**, Cisco UCS Manager GUI displays the rest of the fields on this tab.
 - Step 6** Click **Save Changes**.
-

What to Do Next

Ensure that Call Home is fully configured.

Configuring System Inventory Messages

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
- Step 2** In the **Admin** tab, expand **All ► Communication Services**.
- Step 3** Click **Call Home**.
- Step 4** In the **Work** pane, click the **System Inventory** tab.
- Step 5** In the **Properties** area, complete the following fields:

Name	Description
Send Periodically field	If this field is set to on, Cisco UCS automatically sends the system inventory to the Call Home database. When the information is sent depends on the other fields in this area.
Send Interval field	The number of days that should pass between automatic system inventory data collection.
Hour of Day to Send field	The hour that the data should be sent using the 24-hour clock format.
Minute of Hour field	The number of minutes after the hour that the data should be sent.
Time Last Sent field	The date and time the information was last sent. Note This field is displayed after the first inventory has been sent.
Next Scheduled field	The date and time for the upcoming data collection. Note This field is displayed after the first inventory has been sent.

- Step 6** Click **Save Changes**.

Sending System Inventory Messages

Use this procedure if you need to manually send a system inventory message outside of the scheduled messages.

Procedure

-
- Step 1** In the **Navigation** pane, click the **Admin** tab.
 - Step 2** In the **Admin** tab, expand **All ► Communication Services**.
 - Step 3** Click **Call Home**.
 - Step 4** In the **Work** pane, click the **System Inventory** tab.
 - Step 5** In the **Actions** area, click **Send System Inventory Now**.
Cisco UCS Manager immediately sends a system inventory message to the recipient configured for Call Home.
-

Configuring Call Home Profiles

Creating a Call Home Profile

By default, you must configure the Cisco TAC-1 profile. However, you can also create additional profiles to send email alerts to one or more specified groups when events occur at the level that you specify.

Procedure

-
- Step 1** In the **Navigation** pane, click the **Admin** tab.
 - Step 2** In the **Admin** tab, expand **All ► Communication Services**.
 - Step 3** Click **Call Home**.
 - Step 4** In the **Work** pane, click the **Profiles** tab.
 - Step 5** On the icon bar to the right of the table, click +.
If the + icon is disabled, click an entry in the table to enable it.
 - Step 6** In the **Create Call Home Profile** dialog box, complete the following information fields:

Name	Description
Name field	A user-defined name for this profile. This name can be between 1 and 16 alphanumeric characters. You cannot use spaces or any special characters, and you cannot change this name after the object has been saved.
Level field	This can be: <ul style="list-style-type: none"> • critical • debug • disaster • fatal • major

Name	Description
	<ul style="list-style-type: none"> • minor • normal • notification • warning
Alert Groups field	<p>The group or groups that are alerted based on this Call Home profile. This can be one or more of the following:</p> <ul style="list-style-type: none"> • ciscoTac • diagnostic • environmental • inventory • license • lifeCycle • linecard • supervisor • syslogPort • system • test

Step 7 In the **Email Configuration** area, complete the following fields to configure the email alerts:

Name	Description
Format field	<p>This can be:</p> <ul style="list-style-type: none"> • xml • shortTxt
Max Message Size field	<p>The maximum message size that is sent to the designated Call Home recipients.</p>

Step 8 In the **Recipients** area, complete the following fields to add one or more email recipients for the email alerts:

- a) On the icon bar to the right of the table, click +.
- b) In the **Add Email Recipients** dialog box, enter the email address to which Call Home alerts should be sent in the **Email** field.
After you save this email address, it can be deleted but it cannot be changed.

c) Click **OK**.

Step 9 Click **OK**.

Deleting a Call Home Profile

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
- Step 2** In the **Admin** tab, expand **All > Communication Services**.
- Step 3** Click **Call Home**.
- Step 4** In the **Work** pane, click the **Profiles** tab.
- Step 5** Right-click the profile you want to delete and choose **Delete**.
- Step 6** Click **Save Changes**.

Configuring Call Home Policies

Configuring a Call Home Policy



Tip

By default, email alerts are sent for all critical system events. However, you can optionally configure Call Home policies to enable or disable sending email alerts for other critical system events.

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
- Step 2** In the **Admin** tab, expand **All > Communication Services**.
- Step 3** Click **Call Home**.
- Step 4** In the **Work** pane, click the **Policies** tab.
- Step 5** On the icon bar to the right of the table, click **+**.
If the **+** icon is disabled, click an entry in the table to enable it.
- Step 6** In the **Create Call Home Policy** dialog box, complete the following fields:

Name	Description
State field	If this field is enabled , the system uses this policy when an error matching the associated cause is encountered. Otherwise, the system ignores this policy even if a matching error occurs.
Cause field	The event that triggers this policy. This can be:

Name	Description
	<ul style="list-style-type: none"> • equipment-degraded • equipment-inoperable • fru-problem • identity-unestablishable • power-problem • thermal-problem • voltage-problem <p>Note You cannot change the cause after you save this policy.</p>

Step 7 Click **OK**.

Step 8 Repeat Steps 6 and 7 to configure a Call Home policy for each event that you want to have send a Call Home email alert.

Disabling a Call Home Policy

Procedure

Step 1 In the **Navigation** pane, click the **Admin** tab.

Step 2 In the **Admin** tab, expand **All > Communication Services**.

Step 3 Click **Call Home**.

Step 4 In the **Work** pane, click the **Policies** tab.

Step 5 Click the policy that you want to disable and choose **Show Navigator**.

Step 6 In the **State** field, click **Disabled**.

Step 7 Click **OK**.

Enabling a Call Home Policy

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
 - Step 2** In the **Admin** tab, expand **All ► Communication Services**.
 - Step 3** Click **Call Home**.
 - Step 4** In the **Work** pane, click the **Policies** tab.
 - Step 5** Click the policy that you want to enable and choose **Show Navigator**.
 - Step 6** In the **State** field, click **Enabled**.
 - Step 7** Click **OK**.
-

Deleting a Call Home Policy

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
 - Step 2** In the **Admin** tab, expand **All ► Communication Services**.
 - Step 3** Click **Call Home**.
 - Step 4** In the **Work** pane, click the **Policies** tab.
 - Step 5** Right-click the policy that you want to disable and choose **Delete**.
 - Step 6** Click **Save Changes**.
-

Configuring Call Home for Smart Call Home

Configuring Smart Call Home

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
- Step 2** In the **Admin** tab, expand **All ► Communication Services**.
- Step 3** Click **Call Home**.
- Step 4** In the **Work** pane, click the **General** tab.
- Step 5** In the **Admin** area, do the following to enable Call Home:
 - a) In the **State** field, click **on**.

Note If this field is set to **on**, Cisco UCS Manager GUI displays the rest of the fields on this tab.

b) From the **Urgency** drop-down list, select one of the following urgency levels:

- **alerts**
- **critical**
- **debugging**
- **emergencies**
- **errors**
- **information**
- **notifications**
- **warnings**

Step 6 In the **Contact Information** area, complete the following fields with the required contact information:

Name	Description
Contact field	The main Call Home contact person.
Phone field	The telephone number for the main contact. Enter the number in international format, starting with a + (plus sign) and a country code.
Email field	The email address for the main contact.
Address field	The mailing address for the main contact.

Step 7 In the **Ids** area, complete the following fields with the Smart Call Home identification information:

Name	Description
Customer Id field	The unique identification number for the customer.
Contract Id field	The Call Home contract number for the customer.
Site Id field	The unique Call Home identification number for the customer site.

Step 8 In the **Email Addresses** area, complete the following fields with the email information for Smart Call Home alert messages:

Name	Description
From field	The email address that should appear in the From field on Call Home alert messages sent by the system.

Name	Description
Reply To field	The return email address that should appear in the From field on Call Home alert messages sent by the system.

Step 9 In the **SMTP Server** area, complete the following fields with information about the SMTP server that Call Home should use to send email messages:

Name	Description
Host (IP Address or Hostname) field	The IP address or hostname of the SMTP server.
Port field	The port number the system should use to talk to the SMTP server.

Step 10 Click **Save Changes**.

Configuring the Default Cisco TAC-1 Profile

The default settings of the CiscoTAC-1 profile are:

- Level is normal
- Only the CiscoTAC alert group is selected
- Format is xml
- Maximum message size is 5000000

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
- Step 2** In the **Admin** tab, expand **All ► Communication Services**.
- Step 3** Click **Call Home**.
- Step 4** In the **Work** pane, click the **Profiles** tab.
- Step 5** Right-click the Cisco TAC-1 profile and choose **Recipient**.
- Step 6** In the **Add Email Recipients** dialog box, do the following:
- a) In the **Email** field, enter the email address to which Call Home alerts should be sent. For example, enter `callhome@cisco.com`.
After you save this email address, it can be deleted but it cannot be changed.
 - b) Click **OK**.

Configuring System Inventory Messages for Smart Call Home

Procedure

-
- Step 1** In the **Navigation** pane, click the **Admin** tab.
- Step 2** In the **Admin** tab, expand **All ► Communication Services**.
- Step 3** Click **Call Home**.
- Step 4** In the **Work** pane, click the **System Inventory** tab.
- Step 5** In the **Properties** area, complete the following fields to specify how system inventory messages will be sent to Smart Call Home:

Name	Description
Send Periodically field	If this field is set to on, Cisco UCS automatically sends the system inventory to the Call Home database. When the information is sent depends on the other fields in this area.
Send Interval field	The number of days that should pass between automatic system inventory data collection.
Hour of Day to Send field	The hour that the data should be sent using the 24-hour clock format.
Minute of Hour field	The number of minutes after the hour that the data should be sent.
Time Last Sent field	The date and time the information was last sent. Note This field is displayed after the first inventory has been sent.
Next Scheduled field	The date and time for the upcoming data collection. Note This field is displayed after the first inventory has been sent.

- Step 6** Click **Save Changes**.
-

Registering Smart Call Home

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
 - Step 2** In the **Admin** tab, expand **All ► Communication Services**.
 - Step 3** Click **Call Home**.
 - Step 4** In the **Work** pane, click the **System Inventory** tab.
 - Step 5** In the **Actions** area, click **Send System Inventory Now** to start the registration process.
 - Step 6** When you receive the email response from Cisco, click the link in the email to complete registration for Smart Call Home.
-



CHAPTER 31

Backing Up and Restoring the Configuration

This chapter includes the following sections:

- [Backup and Export Configuration, page 301](#)
- [Backup Types, page 301](#)
- [Considerations and Recommendations for Backup Operations, page 302](#)
- [Import Configuration, page 302](#)
- [Import Methods, page 303](#)
- [System Restore, page 303](#)
- [Required User Role for Backup and Import Operations, page 303](#)
- [Backup Operations, page 303](#)
- [Import Operations, page 307](#)
- [Restoring the Configuration for a Fabric Interconnect, page 311](#)

Backup and Export Configuration

When you perform a backup through Cisco UCS Manager, you take a snapshot of all or part of the system configuration and export the file to a location on your network. You cannot use Cisco UCS Manager to back up data on the servers.

You can perform a backup while the system is up and running. The backup operation only saves information from the management plane. It does not have any impact on the server or network traffic.

Backup Types

You can perform one or more of the following types of backups through Cisco UCS Manager:

- **Full state**—Includes a snapshot of the entire system. You can use the file generated from this backup to restore the system during disaster recovery. This file can restore or rebuild the configuration on the original fabric interconnect, or recreate the configuration on a different fabric interconnect. You cannot use this file for an import.

- **All configuration**—Includes all system and logical configuration settings. You can use the file generated from this backup to import these configuration settings to the original fabric interconnect or to a different fabric interconnect. You cannot use this file for a system restore.
- **System configuration**—Includes all system configuration settings such as usernames, roles, and locales. You can use the file generated from this backup to import these configuration settings to the original fabric interconnect or to a different fabric interconnect. You cannot use this file for a system restore.
- **Logical configuration**—Includes all logical configuration settings such as service profiles, VLANs, VSANs, pools, and policies. You can use the file generated from this backup to import these configuration settings to the original fabric interconnect or to a different fabric interconnect. You cannot use this file for a system restore.

Considerations and Recommendations for Backup Operations

Before you create a backup operation, consider the following:

Backup Locations	The backup location is the destination or folder on the network where you want Cisco UCS Manager to export the backup file. You can maintain only one backup operation for each location where you plan to save a backup file.
Potential to Overwrite Backup Files	If you rerun a backup operation without changing the filename, Cisco UCS Manager overwrites the existing file on the server. To avoid overwriting existing backup files, change the filename in the backup operation or copy the existing file to another location.
Multiple Types of Backups	You can run and export more than one type of backup to the same location. You need to change the backup type before you rerun the backup operation. We recommend that you change the filename for easier identification of the backup type and to avoid overwriting the existing backup file.
Scheduled Backups	You cannot schedule a backup operation. You can, however, create a backup operation in advance and leave the admin state disabled until you are ready to run the backup. Cisco UCS Manager does not run the backup operation, save, or export the configuration file until you set the admin state of the backup operation to enabled.
Incremental Backups	You cannot perform incremental backups of the Cisco UCS Manager system configuration.

Import Configuration

You can import any configuration file that was exported from Cisco UCS Manager. The file does not have to have been exported from the same Cisco UCS Manager.

The import function is available for all configuration, system configuration, and logical configuration files. You can perform an import while the system is up and running. An import operation modifies information on the management plane only. Some modifications caused by an import operation, such as a change to a vNIC assigned to a server, can cause a server reboot or other operations that disrupt traffic.

You cannot schedule an import operation. You can, however, create an import operation in advance and leave the admin state disabled until you are ready to run the import. Cisco UCS Manager will not run the import operation on the configuration file until you set the admin state to enabled.

You can maintain only one import operation for each location where you saved a configuration backup file.

Import Methods

You can use one of the following methods to import and update a system configuration through Cisco UCS Manager:

- **Merge**—The information in the imported configuration file is compared with the existing configuration information. If there are conflicts, the import operation overwrites the information on the Cisco UCS instance with the information in the import configuration file.
- **Replace**—The current configuration information is replaced with the information in the imported configuration file one object at a time.

System Restore

You can restore a system configuration from any full state backup file that was exported from Cisco UCS Manager. The file does not have to have been exported from the Cisco UCS Manager on the system that you are restoring.

The restore function is only available for a full state backup file. You cannot import a full state backup file. You perform a restore through the initial system setup.

You can use the restore function for disaster recovery.

Required User Role for Backup and Import Operations

You must have a user account that includes the admin role to create and run backup and import operations.

Backup Operations

Creating a Backup Operation

Before You Begin

Obtain the backup server IP address and authentication credentials.

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
- Step 2** Click the **All** node.
- Step 3** In the **Work** pane, click the **General** tab.
- Step 4** In the **Actions** area, click **Backup Configuration**.
- Step 5** In the **Backup Configuration** dialog box, click **Create Backup Operation**.
- Step 6** In the **Create Backup Operation** dialog box, complete the following fields:

Name	Description
Admin State field	This can be: <ul style="list-style-type: none"> • enabled—Cisco UCS Manager runs the backup operation automatically as soon as you click OK. • disabled—Cisco UCS Manager does not run the backup operation automatically when you click OK. If you select this option, all fields in the dialog box remain visible. However, you must manually run the backup from the Backup Configuration dialog box.
Type field	The information saved in the backup configuration file. This can be: <ul style="list-style-type: none"> • Full state—Includes a snapshot of the entire system. You can use this file for disaster recovery if you need to recreate every configuration on a fabric interconnect or rebuild a fabric interconnect. • All configuration—Includes all system and logical configuration information. • System configuration—Includes all system configuration settings such as user names, roles, and locales. • Logical configuration—Includes all logical configuration settings such as service profiles, LAN configuration settings, SAN configuration settings, pools, and policies.
Protocol field	The protocol to use when communicating with the remote server. This can be: <ul style="list-style-type: none"> • FTP • SCP • SFTP • TFTP

Name	Description
Hostname field	The hostname on which the backup file is stored. This can be a server, storage array, local drive, or any read/write media that the fabric interconnect can access through the network.
Remote File field	The full path to the backup configuration file. This field can contain the filename as well as the path. If you omit the filename, the backup procedure creates a filename automatically.
User field	The username the system should use to log in to the remote server. This field does not apply if the protocol is TFTP.
Password field	The password for the remote server username. This field does not apply if the protocol is TFTP. Cisco UCS Manager does not store this password. Therefore, you do not need to enter this password unless you intend to enable and run the backup operation immediately.

Step 7 Click **OK**.

Step 8 In the confirmation dialog box, click **OK**.

If you set the **Admin State** to enabled, Cisco UCS Manager takes a snapshot of the configuration type that you selected and exports the file to the network location. The backup operation displays in the **Backup Operations** table in the **Backup Configuration** dialog box.

Step 9 (Optional) To view the progress of the backup operation:

- a) If the operation does not automatically display in the **Properties** area, click the operation in the **Backup Operations** table.
- b) In the **Properties** area, click the down arrows on the **FSM Details** bar.
The **FSM Details** area expands and displays the operation status.

Step 10 Click **OK** to close the **Backup Configuration** dialog box.

The backup operation continues to run until it is completed. To view the progress, re-open the **Backup Configuration** dialog box.

Running a Backup Operation

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
- Step 2** Click the **All** node.
- Step 3** In the **Work** pane, click the **General** tab.
- Step 4** In the **Actions** area, click **Backup Configuration**.
- Step 5** In the **Backup Operations** table of the **Backup Configuration** dialog box, click the backup operation that you want to run.
The details of the selected backup operation display in the **Properties** area.
- Step 6** In the **Properties** area, complete the following fields:
- In the **Admin State** field, click the **Enabled** radio button.
 - For all protocols except TFTP, enter the password for the user name in the **Password** field.
 - (Optional) Change the content of the other available fields.
- Step 7** Click **Apply**.
Cisco UCS Manager takes a snapshot of the configuration type that you selected and exports the file to the network location. The backup operation displays in the **Backup Operations** table in the **Backup Configuration** dialog box.
- Step 8** (Optional) To view the progress of the backup operation, click the down arrows on the **FSM Details** bar. The **FSM Details** area expands and displays the operation status.
- Step 9** Click **OK** to close the **Backup Configuration** dialog box.
The backup operation continues to run until it is completed. To view the progress, re-open the **Backup Configuration** dialog box.
-

Modifying a Backup Operation

You can modify a backup operation to save a file of another backup type to that location or to change the filename and avoid overwriting previous backup files.

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
- Step 2** Click the **All** node.
- Step 3** In the **Work** pane, click the **General** tab.
- Step 4** In the **Actions** area, click **Backup Configuration**.
- Step 5** In the **Backup Operations** area of the **Backup Configuration** dialog box, click the backup operation that you want to modify.

The details of the selected backup operation display in the **Properties** area. If the backup operation is in a disabled state, the fields are dimmed.

- Step 6** In the **Admin State** field, click the **enabled** radio button
- Step 7** Modify the appropriate fields.
You do not have to enter the password unless you want to run the backup operation immediately.
- Step 8** (Optional) If you do not want to run the backup operation immediately, click the **disabled** radio button in the **Admin State** field.
- Step 9** Click **OK**.

Deleting One or More Backup Operations

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
- Step 2** Click the **All** node.
- Step 3** In the **Work** pane, click the **General** tab.
- Step 4** In the **Actions** area, click **Backup Configuration**.
- Step 5** In the **Backup Operations** table of the **Backup Configuration** dialog box, click the backup operations that you want to delete.
Tip You cannot click a backup operation in the table if the admin state of the operation is set to **Enabled**.
- Step 6** Click the **Delete** icon in the icon bar of the **Backup Operations** table.
- Step 7** If Cisco UCS Manager displays a confirmation dialog box, click **Yes**.
- Step 8** In the **Backup Configuration** dialog box, click one of the following:

Option	Description
Apply	Deletes the selected backup operations without closing the dialog box.
OK	Deletes the selected backup operations and closes the dialog box.

Import Operations

Creating an Import Operation

You cannot import a Full State configuration file. You can import any of the following configuration files:

- All configuration
- System configuration
- Logical configuration

Before You Begin

Collect the following information that you will need to import a configuration file:

- Backup server IP address and authentication credentials
- Fully qualified name of a backup file

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
- Step 2** Click the **All** node.
- Step 3** In the **Work** pane, click the **General** tab.
- Step 4** In the **Actions** area, click **Import Configuration**.
- Step 5** In the **Import Configuration** dialog box, click **Create Import Operation**.
- Step 6** In the **Create Import Operation** dialog box, complete the following fields:

Name	Description
Admin State field	This can be: <ul style="list-style-type: none"> • enabled—Cisco UCS runs the import operation automatically as soon as you click OK. • disabled—Cisco UCS does not run the import operation automatically when you click OK. If you select this option, all fields in the dialog box remain visible. However, you must manually run the import from the Import Configuration dialog box.
Action field	You can select: <ul style="list-style-type: none"> • Merge—The configuration information is merged with the existing information. If there are conflicts, the system replaces the information on the current system with the information in the import configuration file. • Replace—The system takes each object in the import configuration file and overwrites the corresponding object in the current configuration.
Protocol field	The protocol to use when communicating with the remote server. This can be: <ul style="list-style-type: none"> • FTP • SCP • SFTP • TFTP

Name	Description
Hostname field	The hostname from which the configuration file should be imported.
Remote File field	The name of the configuration file that is being imported.
User field	The username the system should use to log in to the remote server. This field does not apply if the protocol is TFTP.
Password field	The password for the remote server username. This field does not apply if the protocol is TFTP. Cisco UCS Manager does not store this password. Therefore, you do not need to enter this password unless you intend to enable and run the import operation immediately.

Step 7 Click **OK**.

Step 8 In the confirmation dialog box, click **OK**.

If you set the **Admin State** to enabled, Cisco UCS Manager imports the configuration file from the network location. Depending upon which action you selected, the information in the file is either merged with the existing configuration or replaces the existing configuration.. The import operation displays in the **Import Operations** table of the **Import Configuration** dialog box.

Step 9 (Optional) To view the progress of the import operation:

- a) If the operation does not automatically display in the **Properties** area, click the operation in the **Import Operations** table.
- b) In the **Properties** area, click the down arrows on the **FSM Details** bar.
The **FSM Details** area expands and displays the operation status.

Step 10 Click **OK** to close the **Import Configuration** dialog box.

The import operation continues to run until it is completed. To view the progress, re-open the **Import Configuration** dialog box.

Running an Import Operation

You cannot import a Full State configuration file. You can import any of the following configuration files:

- All configuration
- System configuration
- Logical configuration

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
- Step 2** Click the **All** node.
- Step 3** In the **Work** pane, click the **General** tab.
- Step 4** In the **Actions** area, click **Import Configuration**.
- Step 5** In the **Import Operations** table of the **Import Configuration** dialog box, click the operation that you want to run.
The details of the selected import operation display in the **Properties** area.
- Step 6** In the **Properties** area, complete the following fields:
- In the **Admin State** field, click the **Enabled** radio button.
 - For all protocols except TFTP, enter the password for the user name in the **Password** field.
 - (Optional) Change the content of the other available fields.
- Step 7** Click **Apply**.
Cisco UCS Manager imports the configuration file from the network location. Depending upon which action you selected, the information in the file is either merged with the existing configuration or replaces the existing configuration. The import operation displays in the **Import Operations** table of the **Import Configuration** dialog box.
- Step 8** (Optional) To view the progress of the import operation, click the down arrows on the **FSM Details** bar.
The **FSM Details** area expands and displays the operation status.
- Step 9** Click **OK** to close the **Import Configuration** dialog box.
The import operation continues to run until it is completed. To view the progress, re-open the **Import Configuration** dialog box.
-

Modifying an Import Operation

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
- Step 2** Click the **All** node.
- Step 3** In the **Work** pane, click the **General** tab.
- Step 4** In the **Actions** area, click **Import Configuration**.
- Step 5** In the **Import Operations** area of the **Import Configuration** dialog box, click the import operation that you want to modify.
The details of the selected import operation display in the **Properties** area. If the import operation is in a disabled state, the fields are dimmed.
- Step 6** In the **Admin State** field, click the **enabled** radio button.
- Step 7** Modify the appropriate fields.

You do not have to enter the password unless you want to run the import operation immediately.

- Step 8** (Optional) If you do not want to run the import operation immediately, click the **disabled** radio button in the **Admin State** field.
- Step 9** Click **OK**.

Deleting One or More Import Operations

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
- Step 2** Click the **All** node.
- Step 3** In the **Work** pane, click the **General** tab.
- Step 4** In the **Actions** area, click **Import Configuration**.
- Step 5** In the **Import Operations** table of the **Backup Configuration** dialog box, click the import operations that you want to delete.
- Tip** You cannot click an import operation in the table if the admin state of the operation is set to **Enabled**.
- Step 6** Click the **Delete** icon in the icon bar of the **Import Operations** table.
- Step 7** If Cisco UCS Manager displays a confirmation dialog box, click **Yes**.
- Step 8** In the **Import Configuration** dialog box, click one of the following:

Option	Description
Apply	Deletes the selected import operations without closing the dialog box.
OK	Deletes the selected import operations and closes the dialog box.

Restoring the Configuration for a Fabric Interconnect

Before You Begin

Collect the following information that you will need to restore the system configuration:

- Fabric interconnect management port IP address and subnet mask
- Default gateway IP address
- Backup server IP address and authentication credentials
- Fully qualified name of a Full State backup file

**Note**

You must have access to a Full State configuration file to perform a system restore. You cannot perform a system restore with any other type of configuration or backup file.

Procedure

- Step 1** Connect to the console port.
- Step 2** If the fabric interconnect is off, power on the fabric interconnect. You will see the power on self-test message as the fabric interconnect boots.
- Step 3** At the installation method prompt, enter `gui`.
- Step 4** If the system cannot access a DHCP server, you may be prompted to enter the following information:
- IP address for the management port on the fabric interconnect
 - Subnet mask for the management port on the fabric interconnect
 - IP address for the default gateway assigned to the fabric interconnect
- Step 5** Copy the web link from the prompt into a web browser and go to the Cisco UCS Manager GUI launch page.
- Step 6** On the launch page, select **Express Setup**.
- Step 7** On the **Springfield Express Setup** page, select **Restore From Backup** and click **Submit**.
- Step 8** In the **Protocol** area of the **Cisco UCS Manager Initial Setup** page, select the protocol you want to use to upload the full state backup file:
- SCP
 - TFTP
 - FTP
 - SFTP
- Step 9** In the **Server Information** area, complete the following fields:

Name	Description
Server IP	The IP address of the computer where the full state backup file is located. This can be a server, storage array, local drive, or any read/write media that the fabric interconnect can access through the network.
Backup File Path	The file path where the full state backup file is located, including the folder names and filename.
User ID	The username the system should use to log in to the remote server. This field does not apply if the protocol is TFTP.

Name	Description
Password	The password for the remote server username. This field does not apply if the protocol is TFTP.

Step 10 Click **Submit**.

You can return to the console to watch the progress of the system restore.

The fabric interconnect logs in to the backup server, retrieves a copy of the specified full-state backup file, and restores the system configuration.

For a cluster configuration, you do not need to restore the secondary fabric interconnect. As soon as the secondary fabric interconnect reboots, Cisco UCS Manager synchronizes the configuration with the primary fabric interconnect.



CHAPTER 32

Configuring Settings for Faults, Events, and Logs

This chapter includes the following sections:

- [Configuring Settings for the Fault Collection Policy, page 315](#)
- [Configuring Settings for the Core File Exporter, page 317](#)
- [Configuring the Syslog, page 318](#)

Configuring Settings for the Fault Collection Policy

Fault Collection Policy

The fault collection policy controls the lifecycle of a fault in a Cisco UCS instance, including when faults are cleared, the flapping interval (the length of time between the fault being raised and the condition being cleared), and the retention interval (the length of time a fault is retained in the system).

A fault in Cisco UCS has the following lifecycle:

- 1 A condition occurs in the system and Cisco UCS Manager raises a fault. This is the active state.
- 2 When the fault is alleviated, it is cleared if the time between the fault being raised and the condition being cleared is greater than the flapping interval, otherwise, the fault remains raised but its status changes to soaking-clear. Flapping occurs when a fault is raised and cleared several times in rapid succession. During the flapping interval the fault retains its severity for the length of time specified in the fault collection policy.
- 3 If the condition reoccurs during the flapping interval, the fault remains raised and its status changes to flapping. If the condition does not reoccur during the flapping interval, the fault is cleared.
- 4 When a fault is cleared, it is deleted if the clear action is set to delete, or if the fault was previously acknowledged, otherwise, it is retained until either the retention interval expires, or if the fault is acknowledged.
- 5 If the condition reoccurs during the retention interval, the fault returns to the active state. If the condition does not reoccur, the fault is deleted.

Configuring the Fault Collection Policy

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
- Step 2** On the **Admin** tab, expand **All ► Faults, Events, and Audit Log**.
- Step 3** Click **Settings**.
- Step 4** In the **Work** pane, complete the following fields in the **Fault Collection Policy** area:

Name	Description
Flapping Interval field	<p>Flapping occurs when a fault is raised and cleared several times in rapid succession. To prevent this, the system does not allow a fault to change its state until this amount of time has elapsed since the last state change.</p> <p>If the condition reoccurs during the flapping interval, the fault returns to the active state. If the condition does not reoccur during the flapping interval, the fault is cleared. What happens at that point depends on the setting in the Clear Action field.</p> <p>Enter an integer between 5 and 3,600. The default is 10.</p>
Clear Action field	<p>This can be:</p> <ul style="list-style-type: none"> • retain—Cisco UCS Manager GUI displays the Length of time to retain cleared faults section. • delete—The system immediately deletes all fault messages as soon as they are marked as cleared.
Length of Time to Retain Cleared Faults Section	
Retention Interval field	<p>This can be:</p> <ul style="list-style-type: none"> • forever—The system leaves all cleared fault messages on the fabric interconnect regardless of how long they have been in the system. • other—Cisco UCS Manager GUI displays the dd:hh:mm:ss field.
dd:hh:mm:ss field	The number of days, hours, minutes, and seconds that should pass before the system deletes a cleared fault message.

- Step 5** Click **Save Changes**.

Configuring Settings for the Core File Exporter

Core File Exporter

Cisco UCS Manager uses the Core File Exporter to export core files as soon as they occur to a specified location on the network through TFTP. This functionality allows you to export the tar file with the contents of the core file.

Configuring the Core File Exporter

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
- Step 2** On the **Admin** tab, expand **All ► Faults, Events, and Audit Log**.
- Step 3** Click **Settings**.
- Step 4** In the **Work** pane, complete the following fields in the **TFTP Core Exporter** area:

Name	Description
Admin State field	This can be: <ul style="list-style-type: none"> • enabled—If an error causes the server to perform a core dump, the system sends the core dump file via FTP to a given location. When this option is selected, Cisco UCS Manager GUI displays the other fields in this area that enable you to specify the FTP export options. • disabled—Core dump files are not automatically exported.
Description field	A user-defined description of the core file.
Port field	The port number to use when exporting the core dump file via TFTP.
Hostname field	The hostname to connect with via TFTP.
Path field	The path to use when storing the core dump file on the remote system.

- Step 5** Click **Save Changes**.

Disabling the Core File Exporter

Procedure

-
- Step 1** In the **Navigation** pane, click the **Admin** tab.
- Step 2** On the **Admin** tab, expand **All ► Faults, Events, and Audit Log**.
- Step 3** Click **Settings**.
- Step 4** In the **Work** pane, click the **Settings** tab.
- Step 5** In the **TFTP Core Exporter** area, click the **disabled** radio button in the **Admin State** field.
- Step 6** Click **Save Changes**.
-

Configuring the Syslog

Procedure

-
- Step 1** In the **Navigation** pane, click the **Admin** tab.
- Step 2** On the **Admin** tab, expand **All ► Faults, Events, and Audit Log**.
- Step 3** Click **Syslog**.
- Step 4** In the **Work** pane, click the **Syslog** tab.
- Step 5** In the **Local Destinations** area, complete the following fields:

Name	Description
Console Section	
Admin State field	This can be: <ul style="list-style-type: none"> • enabled • disabled
Level field	If the Admin State field is enabled , select the lowest message level that you want displayed. The system automatically displays that level and above on the console. <ul style="list-style-type: none"> • emergencies • alerts • critical
Monitor Section	
Admin State field	This can be:

Name	Description
	<ul style="list-style-type: none"> • enabled • disabled <p>If Admin State is enabled, Cisco UCS Manager GUI displays the rest of the fields in this section.</p>
Level drop-down list	<p>If the Admin State field is enabled, select the lowest message level that you want displayed. The system automatically displays that level and above on the monitor.</p> <ul style="list-style-type: none"> • alerts • critical • debugging • emergencies • errors • information • notifications • warnings
File Section	
Admin State field	<p>This can be:</p> <ul style="list-style-type: none"> • enabled • disabled <p>If Admin State is enabled, Cisco UCS Manager GUI displays the rest of the fields in this section.</p>
Level drop-down list	<p>Select the lowest message level that you want the system to store. The system automatically stores that level and above in a file on the fabric interconnect.</p> <ul style="list-style-type: none"> • alerts • critical • debugging • emergencies • errors • information • notifications • warnings

Name	Description
Name field	The name of the file in which the messages are logged.
Size field	The maximum size, in bytes, the file can be before Cisco UCS Manager GUI begins to write over the oldest messages with the newest ones.

Step 6 In the **Remote Destinations** area, complete the following fields to configure up to three external logs that can store messages generated by the Cisco UCS components:

Name	Description
Admin State field	This can be: <ul style="list-style-type: none"> • enabled • disabled <p>If Admin State is enabled, Cisco UCS Manager GUI displays the rest of the fields in this section.</p>
Level drop-down list	Select the lowest message level that you want the system to store. The system automatically stores that level and above in the remote file. <ul style="list-style-type: none"> • alerts • critical • debugging • emergencies • errors • information • notifications • warnings
Hostname field	The hostname or IP address on which the remote log file resides.
Facility drop-down list	This can be: <ul style="list-style-type: none"> • local0 • local1 • local2 • local3 • local4 • local5 • local6

Name	Description
	• local7

Step 7 Click **Save Changes**.



CHAPTER 33

Recovering a Lost Password

This chapter includes the following sections:

- [Password Recovery for the Admin Account, page 323](#)
- [Determining the Leadership Role of a Fabric Interconnect, page 324](#)
- [Verifying the Firmware Versions on a Fabric Interconnect, page 324](#)
- [Recovering the Admin Account Password in a Standalone Configuration, page 324](#)
- [Recovering the Admin Account Password in a Cluster Configuration, page 325](#)

Password Recovery for the Admin Account

The admin account is the system administrator or superuser account. If an administrator loses the password to this account, you can have a serious security issue. As a result, the procedure to recover the password for the admin account requires you to power cycle all fabric interconnects in a Cisco UCS instance.

When you recover the password for the admin account, you actually change the password for that account. You cannot retrieve the original password for that account.

You can reset the password for all other local accounts through Cisco UCS Manager. However, you must log into Cisco UCS Manager with an account that includes aaa or admin privileges.



Caution

This procedure requires you to power down all fabric interconnects in a Cisco UCS instance. As a result, all data transmission in the instance is stopped until you restart the fabric interconnects.

Determining the Leadership Role of a Fabric Interconnect

Procedure

- Step 1** In the **Navigation** pane, click the **Equipment** tab.
 - Step 2** In the **Equipment** tab, expand **Equipment** ► **Fabric Interconnects**.
 - Step 3** Click the fabric interconnect for which you want to identify the role.
 - Step 4** In the **Work** pane, click the **General** tab.
 - Step 5** In the **General**, click the down arrows on the **High Availability Details** bar to expand that area.
 - Step 6** View the **Leadership** field to determine the role of the fabric interconnect.
-

Verifying the Firmware Versions on a Fabric Interconnect

You can use the following procedure to verify the firmware versions on all fabric interconnects in a Cisco UCS instance. You can verify the firmware for a single fabric interconnect through the **Installed Firmware** tab for that fabric interconnect.

Procedure

- Step 1** In the **Navigation** pane, click the **Equipment** tab.
 - Step 2** In the **Equipment** tab, select the **Equipment Node**.
 - Step 3** In the **Work** pane, select the **Firmware Management** tab.
 - Step 4** In the **Installed Firmware** tab, verify that the following firmware versions for each fabric interconnect match the version to which you updated the firmware:
 - Kernel version
 - System version
-

Recovering the Admin Account Password in a Standalone Configuration

Before You Begin

- 1 Physically connect the console port on the fabric interconnect to a computer terminal or console server
- 2 Obtain the following information:
 - The firmware kernel version on the fabric interconnect
 - The firmware system version

Procedure

- Step 1** Connect to the console port.
- Step 2** Power cycle the fabric interconnect:
- a) Turn off the power to the fabric interconnect.
 - b) Turn on the power to the fabric interconnect.
- Step 3** In the console, press one of the following key combinations as it boots to get the loader prompt:
- Ctrl+l
 - Ctrl+Shift+r
- You may need to press the selected key combination multiple times before your screen displays the loader prompt.
- Step 4** Boot the kernel firmware version on the fabric interconnect.
 loader > **boot**
 /installables/fabric/kernel_firmware_version
- Step 5** Enter config terminal mode.
 Fabric(boot)# **config terminal**
- Step 6** Reset the admin password.
 Fabric(boot) (config)# **admin-password**
 password
 The new password displays in clear text mode.
- Step 7** Exit config terminal mode and return to the boot prompt.
- Step 8** Boot the system firmware version on the fabric interconnect.
 Fabric(boot)# **load** /installables/fabric/system_firmware_version
- Step 9** After the system image loads, log in to Cisco UCS Manager.
-

Recovering the Admin Account Password in a Cluster Configuration

Before You Begin

- 1 Physically connect a console port on one of the fabric interconnects to a computer terminal or console server
- 2 Obtain the following information:
 - The firmware kernel version on the fabric interconnect
 - The firmware system version
 - Which fabric interconnect has the primary leadership role and which is the subordinate

Procedure

Step 1 Connect to the console port.

Step 2 For the subordinate fabric interconnect:

- a) Turn off the power to the fabric interconnect.
- b) Turn on the power to the fabric interconnect.
- c) In the console, press one of the following key combinations as it boots to get the loader prompt:
 - Ctrl+l
 - Ctrl+Shift+r

You may need to press the selected key combination multiple times before your screen displays the loader prompt.

Step 3 Power cycle the primary fabric interconnect:

- a) Turn off the power to the fabric interconnect.
- b) Turn on the power to the fabric interconnect.

Step 4 In the console, press one of the following key combinations as it boots to get the loader prompt:

- Ctrl+l
- Ctrl+Shift+r

You may need to press the selected key combination multiple times before your screen displays the loader prompt.

Step 5 Boot the kernel firmware version on the primary fabric interconnect.

```
loader > boot
/installables/fabric/kernel_firmware_version
```

Step 6 Enter config terminal mode.

```
Fabric (boot) # config terminal
```

Step 7 Reset the admin password.

```
Fabric (boot) (config) # admin-password
password
```

The new password displays in clear text mode.

Step 8 Exit config terminal mode and return to the boot prompt.

Step 9 Boot the system firmware version on the primary fabric interconnect.

```
Fabric (boot) # load /installables/fabric/system_firmware_version
```

Step 10 After the system image loads, log in to Cisco UCS Manager.

Step 11 In the console for the subordinate fabric interconnect, do the following to bring it up:

- a) Boot the kernel firmware version on the subordinate fabric interconnect.

```
loader > boot
/installables/fabric/kernel_firmware_version
```

- b) Boot the system firmware version on the subordinate fabric interconnect.

```
Fabric (boot) # load /installables/fabric/system_firmware_version
```



CHAPTER 34

Configuring Statistics-Related Policies

This chapter includes the following sections:

- [Configuring Statistics Collection Policies, page 327](#)
- [Configuring Statistics Threshold Policies, page 329](#)

Configuring Statistics Collection Policies

Statistics Collection Policy

A statistics collection policy defines how frequently statistics are to be collected (collection interval), and how frequently the statistics are to be reported (reporting interval). Reporting intervals are longer than collection intervals so that multiple statistical data points can be collected during the reporting interval, which provides Cisco UCS Manager with sufficient data to calculate and report minimum, maximum, and average values.

Statistics can be collected and reported for the following five functional areas of the Cisco UCS system:

- Adapter—statistics related to the adapters
- Chassis—statistics related to the blade chassis
- Host—this policy is a placeholder for future support
- Port—statistics related to the ports, including server ports, uplink Ethernet ports, and uplink Fibre Channel ports
- Server—statistics related to servers



Note

Cisco UCS Manager has one default statistics collection policy for each of the five functional areas. You cannot create additional statistics collection policies and you cannot delete the existing default policies. You can only modify the default policies.

Modifying a Statistics Collection Policy



Note Cisco UCS Manager has one default statistics collection policy for each of the five functional areas. You cannot create additional statistics collection policies and you cannot delete the existing default policies. You can only modify the default policies.

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
- Step 2** In the **Admin** tab, expand **All > Stats Management > Stats**.
- Step 3** Right-click on the policy that you want to modify and select **Modify Collection Policy**.
- Step 4** In the **Modify Collection Policy** dialog box, complete the following fields:

Name	Description
Collection Interval field	<p>The length of time the fabric interconnect should wait between data recordings. This can be:</p> <ul style="list-style-type: none"> • 30 Seconds • 1 Minute • 2 Minutes • 5 Minutes
Reporting Interval field	<p>The length of time the fabric interconnect should wait before sending any data collected for the counter to Cisco UCS Manager GUI.</p> <p>This can be:</p> <ul style="list-style-type: none"> • 15 Minutes • 30 Minutes • 60 Minutes <p>When this time has elapsed, the fabric interconnect groups all data collected since the last time it sent information to Cisco UCS Manager GUI, and it extracts four pieces of information from that group and sends them to Cisco UCS Manager GUI:</p> <ul style="list-style-type: none"> • The most recent statistic collected. • The average of this group of statistics. • The maximum value within this group. • The minimum value within this group. <p>For example, if the collection interval is set to 1 minute and the reporting interval is 15 minutes, the fabric interconnect collects 15 samples in</p>

Name	Description
	that 15 minute reporting interval. Instead of sending 15 statistics to Cisco UCS Manager GUI, it sends the only the most recent recording along with the average, minimum, and maximum values for the entire group.
States Section	
Current Task field	This field shows the task that is executing on behalf of this component. For details, see the associated FSM tab. Note If there is no current task, this field is not displayed.

Step 5 Click **OK**.

Configuring Statistics Threshold Policies

Statistics Threshold Policy

A statistics threshold policy monitors statistics about certain aspects of the system and generates an event if the threshold is crossed. You can set both minimum and maximum thresholds. For example, you can configure the policy to raise an alarm if the CPU temperature exceeds a certain value, or if a server is overutilized or underutilized.

These threshold policies do not control the hardware or device-level thresholds enforced by endpoints, such as the BMC. Those thresholds are burned in to the hardware components at manufacture.

Cisco UCS enables you to configure statistics threshold policies for the following components:

- Servers and server components
- Uplink Ethernet ports
- Ethernet server ports, chassis, and fabric interconnects
- Fibre Channel port



Note

You cannot create or delete a statistics threshold policy for Ethernet server ports, uplink Ethernet ports, or uplink Fibre Channel ports. You can only configure the existing default policy.

Creating a Server and Server Component Threshold Policy



Tip

This procedure documents how to create a server and server component threshold policy in the **Server** tab. You can also create and configure these threshold policies within the appropriate organization in the **Policies** node on the **LAN** tab, **SAN** tab, and under the **Stats Management** node of the **Admin** tab.

Procedure

- Step 1** In the **Navigation** pane, click the **Servers** tab.
- Step 2** On the **Servers** tab, expand **Servers** ► **Policies**.
- Step 3** Expand the node for the organization where you want to create the policy. If the system does not include multi-tenancy, expand the **root** node.
- Step 4** Right-click **Threshold Policies** and select **Create Threshold Policy**.
- Step 5** In the **Define Name and Description** page of the **Create Threshold Policy** wizard, do the following:
- Complete the following fields:

Name	Description
Name field	The name assigned to the threshold policy. This name can be between 1 and 16 alphanumeric characters. You cannot use spaces or any special characters, and you cannot change this name after the object has been saved.
Description field	A description of the threshold policy.

- Click **Next**.

- Step 6** In the **Threshold Classes** page of the **Create Threshold Policy** wizard, do the following:
- Click **Add**.
 - In the **Choose Statistics Class** dialog box, select one of the following classes to configure from the **Stat Class** drop-down list:
 - **ethernet-port-stats-by-size-large-packets**
 - **ethernet-port-stats-by-size-small-packets**
 - **ethernet-port-err-stats**
 - **ethernet-port-multicast-stats**
 - **ethernet-port-over-under-sized-stats**
 - **ethernet-port-stats**
 - **fc-port-stats**
 - **vnic-stats**
 - **cpu-stats**

- **dimmm-stats**
- **mb-power-stats**
- **mb-temp-stats**

Note If you see a different list of statistics classes, verify that you are creating the threshold policy in an organization.

c) Click **Next**.

Step 7 In the **Threshold Definitions** page, do the following:

- a) Click **Add**.
The **Create Threshold Definition** dialog box opens.
- b) From the **Property Type** field, select the threshold property that you want to define for the class.
- c) In the **Normal Value** field, enter the desired value for the property type.
- d) In the **Alarm Triggers (Above Normal Value)** fields, check one or more of the following check boxes:
 - **Critical**
 - **Major**
 - **Minor**
 - **Warning**
 - **Condition**
 - **Info**
- e) In the **Up** and **Down** fields, enter the range of values that should trigger the alarm.
- f) In the **Alarm Triggers (Below Normal Value)** fields, check one or more of the following check boxes:
 - **Info**
 - **Condition**
 - **Warning**
 - **Minor**
 - **Major**
 - **Critical**
- g) In the **Up** and **Down** fields, enter the range of values that should trigger the alarm.
- h) Click **Finish Stage**.
- i) Do one of the following:
 - To define another threshold property for the class, repeat Step 7.
 - If you have defined all required properties for the class, click **Finish Stage**.

Step 8 In the **Threshold Classes** page of the **Create Threshold Policy** wizard, do one the following:

- To configure another threshold class for the policy, repeat Steps 6 and 7.

- If you have configured all required threshold classes for the policy, click **Finish**.

Step 9 Click **OK**.

Adding a Threshold Class to a Server and Server Component Threshold Policy



Tip

This procedure documents how to add a threshold class to a server and server component threshold policy in the **Server** tab. You can also create and configure these threshold policies within the appropriate organization in the **Policies** node on the **LAN** tab, **SAN** tab, and under the **Stats Management** node of the **Admin** tab.

Procedure

- Step 1** In the **Navigation** pane, click the **Servers** tab.
- Step 2** On the **Servers** tab, expand **Servers** ► **Policies** ► *Organization_Name*.
- Step 3** Expand the **Threshold Policies** node.
- Step 4** Right-click on the policy to which you want to add a threshold class and select **Create Threshold Class**.
- Step 5** In the **Create Threshold Class** page of the **Create Threshold Policy** wizard, do the following:
- Click **Add**.
 - In the **Statistics Class** dialog box, select one of the following classes to configure from the **Stat Class** drop-down list:
 - **ethernet-port-stats-by-size-large-packets**
 - **ethernet-port-stats-by-size-small-packets**
 - **ethernet-port-err-stats**
 - **ethernet-port-multicast-stats**
 - **ethernet-port-over-under-sized-stats**
 - **ethernet-port-stats**
 - **fc-port-stats**
 - **vnic-stats**
 - **cpu-stats**
 - **dimms-stats**
 - **mb-power-stats**
 - **mb-temp-stats**

Note If you see a different list of statistics classes, verify that you are creating the threshold policy in an organization.

c) Click **Next**.

Step 6 In the **Threshold Definitions** page, do the following:

a) Click **Add**.

The **Create Threshold Definition** dialog box opens.

b) From the **Property Type** field, select the threshold property that you want to define for the class.

c) In the **Normal Value** field, enter the desired value for the property type.

d) In the **Alarm Triggers (Above Normal Value)** fields, check one or more of the following check boxes:

- **Critical**
- **Major**
- **Minor**
- **Warning**
- **Condition**
- **Info**

e) In the **Up** and **Down** fields, enter the range of values that should trigger the alarm.

f) In the **Alarm Triggers (Below Normal Value)** fields, check one or more of the following check boxes:

- **Info**
- **Condition**
- **Warning**
- **Minor**
- **Major**
- **Critical**

g) In the **Up** and **Down** fields, enter the range of values that should trigger the alarm.

h) Click **Finish Stage**.

i) Do one of the following:

- To define another threshold property for the class, repeat Step 6.
- If you have defined all required properties for the class, click **Finish Stage**.

Step 7 In the **Create Threshold Class** page of the **Create Threshold Policy** wizard, do one the following:

- To configure another threshold class for the policy, repeat Steps 5 and 6.
- If you have configured all required threshold classes for the policy, click **Finish**.

Step 8 Click **OK**.

Deleting a Server and Server Component Threshold Policy

Procedure

-
- Step 1** In the **Navigation** pane, click the **Servers** tab.
- Step 2** On the **Servers** tab, expand **Servers** ► **Policies** ► *Organization_Name*.
- Step 3** Expand the **Threshold Policies** node.
- Step 4** Right-click the policy you want to delete and select **Delete**.
- Step 5** If Cisco UCS Manager displays a confirmation dialog box, click **Yes**.
-

Adding a Threshold Class to the Uplink Ethernet Port Threshold Policy



Tip You cannot create an uplink Ethernet port threshold policy. You can only modify or delete the default policy.

Procedure

-
- Step 1** In the **Navigation** pane, click the **LAN** tab.
- Step 2** On the **LAN** tab, expand **LAN** ► **LAN Cloud**.
- Step 3** Expand the **Threshold Policies** node.
- Step 4** Right-click on **Thr-policy-default** and select the **Create Threshold Class**.
- Step 5** In the **Create Threshold Class** page, do the following:
- Click **Add**.
 - In the **Statistics Class** dialog box, select one of the following classes to configure from the **Stat Class** drop-down list:
 - **ether-error-stats**
 - **ether-loss-stats**
 - **ether-rx-stats**
 - **ether-tx-stats**
- Note** If you see a different list of statistics classes, verify that you are creating the threshold policy in the **LAN Cloud** node.
- Click **Next**.
- Step 6** In the **Threshold Definitions** page, do the following:
- Click **Add**.
The **Create Threshold Definition** dialog box opens.
 - From the **Property Type** field, select the threshold property that you want to define for the class.

- c) In the **Normal Value** field, enter the desired value for the property type.
- d) In the **Alarm Triggers (Above Normal Value)** fields, check one or more of the following check boxes:
- **Critical**
 - **Major**
 - **Minor**
 - **Warning**
 - **Condition**
 - **Info**
- e) In the **Up** and **Down** fields, enter the range of values that should trigger the alarm.
- f) In the **Alarm Triggers (Below Normal Value)** fields, check one or more of the following check boxes:
- **Info**
 - **Condition**
 - **Warning**
 - **Minor**
 - **Major**
 - **Critical**
- g) In the **Up** and **Down** fields, enter the range of values that should trigger the alarm.
- h) Click **Finish Stage**.
- i) Do one of the following:
- To define another threshold property for the class, repeat Step 6.
 - If you have defined all required properties for the class, click **Finish Stage**.

Step 7 In the **Create Threshold Class** page of the **Create Threshold Policy** wizard, do one the following:

- To configure another threshold class for the policy, repeat Steps 5 and 6.
- If you have configured all required threshold classes for the policy, click **Finish**.

Adding a Threshold Class to the Ethernet Server Port, Chassis, and Fabric Interconnect Threshold Policy

**Tip**

You cannot create an Ethernet server port, chassis, and fabric interconnect threshold policy. You can only modify or delete the default policy.

Procedure

- Step 1** In the **Navigation** pane, click the **LAN** tab.
- Step 2** In the **LAN** tab, expand **LAN** ► **Internal LAN**.
- Step 3** Expand the **Threshold Policies** node.
- Step 4** Right-click on **Thr-policy-default** and select the **Create Threshold Class**.
- Step 5** In the **Create Threshold Class** page, do the following:
- Click **Add**.
 - In the **Statistics Class** dialog box, select one of the following classes to configure from the **Stat Class** drop-down list:
 - **chassis-stats**
 - **fan-module-stats**
 - **fan-stats**
 - **io-card-stats**
 - **psu-input-stats**
 - **psu-stats**
 - **ether-error-stats**
 - **ether-loss-stats**
 - **ether-rx-stats**
 - **ether-tx-stats**
 - **env-stats**
 - **system-stats**
- Note** If you see a different list of statistics classes, verify that you are creating the threshold policy in the **Internal LAN** node.
- Click **Next**.
- Step 6** In the **Threshold Definitions** page, do the following:
- Click **Add**.
The **Create Threshold Definition** dialog box opens.
 - From the **Property Type** field, select the threshold property that you want to define for the class.
 - In the **Normal Value** field, enter the desired value for the property type.
 - In the **Alarm Triggers (Above Normal Value)** fields, check one or more of the following check boxes:
 - **Critical**
 - **Major**
 - **Minor**
 - **Warning**
 - **Condition**

- **Info**

- e) In the **Up** and **Down** fields, enter the range of values that should trigger the alarm.
- f) In the **Alarm Triggers (Below Normal Value)** fields, check one or more of the following check boxes:

- **Info**
- **Condition**
- **Warning**
- **Minor**
- **Major**
- **Critical**

- g) In the **Up** and **Down** fields, enter the range of values that should trigger the alarm.
- h) Click **Finish Stage**.
- i) Do one of the following:
 - To define another threshold property for the class, repeat Step 6.
 - If you have defined all required properties for the class, click **Finish Stage**.

- Step 7** In the **Create Threshold Class** page of the **Create Threshold Policy** wizard, do one the following:
- To configure another threshold class for the policy, repeat Steps 5 and 6.
 - If you have configured all required threshold classes for the policy, click **Finish**.
-

Adding a Threshold Class to the Fibre Channel Port Threshold Policy

You cannot create a Fibre Channel port threshold policy. You can only modify or delete the default policy.

Procedure

- Step 1** In the **Navigation** pane, click the **SAN** tab.
- Step 2** On the **SAN** tab, expand **SAN ► SAN Cloud**.
- Step 3** Expand the **Threshold Policies** node.
- Step 4** Right-click **Thr-policy-default** and select the **Create Threshold Class**.
- Step 5** In the **Create Threshold Class** page, do the following:
 - a) Click **Add**.
 - b) In the **Statistics Class** dialog box, select one of the following classes to configure from the **Stat Class** drop-down list:
 - **fc-error-stats**
 - **fc-stats**

Note If you see a different list of statistics classes, verify that you are creating the threshold policy in the **SAN Cloud** node.

c) Click **Next**.

Step 6 In the **Threshold Definitions** page, do the following:

a) Click **Add**.

The **Create Threshold Definition** dialog box opens.

b) From the **Property Type** field, select the threshold property that you want to define for the class.

c) In the **Normal Value** field, enter the desired value for the property type.

d) In the **Alarm Triggers (Above Normal Value)** fields, check one or more of the following check boxes:

- **Critical**
- **Major**
- **Minor**
- **Warning**
- **Condition**
- **Info**

e) In the **Up** and **Down** fields, enter the range of values that should trigger the alarm.

f) In the **Alarm Triggers (Below Normal Value)** fields, check one or more of the following check boxes:

- **Info**
- **Condition**
- **Warning**
- **Minor**
- **Major**
- **Critical**

g) In the **Up** and **Down** fields, enter the range of values that should trigger the alarm.

h) Click **Finish Stage**.

i) Do one of the following:

- To define another threshold property for the class, repeat Step 6.
- If you have defined all required properties for the class, click **Finish Stage**.

Step 7 In the **Create Threshold Class** page of the **Create Threshold Policy** wizard, do one the following:

- To configure another threshold class for the policy, repeat Steps 5 and 6.
 - If you have configured all required threshold classes for the policy, click **Finish**.
-



INDEX

A

- access
 - in-band access [51](#)
 - out-of-band [51](#)
- accounts
 - creating user [93](#)
 - deleting local [95](#)
 - user [85](#)
- acknowledging
 - chassis [263](#)
 - servers [272](#)
- activate firmware [99](#)
- activating
 - adapter firmware [108](#)
 - BMC firmware [109](#)
 - firmware [106](#)
 - IOM firmware [110](#)
- adapters
 - activating firmware [108](#)
 - Cisco UCS 82598KR-CI [24](#)
 - updating firmware [107](#)
 - virtualization [24](#)
- adding
 - NTP servers [262](#)
 - ports to a port channel [58, 124](#)
- administration [25](#)
- all configuration [301](#)
- architectural simplification [3](#)
- area, Fault Summary [29](#)
- associating servers [242](#)
- authentication
 - primary [73](#)
 - remote [73](#)
- autoconfiguration policy
 - about [12, 195](#)
 - creating [195](#)
 - deleting [196](#)
- Automatically Reconnect [35](#)

B

- backing up
 - about [301](#)
 - considerations [302](#)
 - creating operations [303](#)
 - deleting operation [307](#)
 - modifying operations [306](#)
 - running operations [306](#)
 - types [301](#)
 - user role [303](#)
- backup operations
 - creating [303](#)
 - deleting [307](#)
 - modifying [306](#)
 - running [306](#)
- beacon
 - chassis [265](#)
 - servers [275](#)
- best effort priority system class [21, 128, 140, 141](#)
- binding
 - service profiles [250](#)
 - vHBAs [169](#)
 - vNICs [148](#)
- BIOS, recovering [278](#)
- BMC
 - activating firmware [109](#)
 - resetting [277](#)
 - updating firmware [108](#)
- boot policies
 - about [9, 183](#)
 - creating [185](#)
 - deleting [187](#)
- bootflash, available space [104](#)
- booting servers [270](#)
- bronze priority system class [21, 128, 140, 141](#)
- bundle, firmware [97](#)
- burned in values [8, 208](#)

C

- Call Home
 - about [285](#)
 - Cisco TAC-1 profile [297](#)
 - configuring [287](#)
 - configuring policies [293](#)
 - considerations [286](#)
 - creating profiles [291](#)
 - deleting policies [295](#)
 - deleting profiles [293](#)
 - disabling [289](#)
 - disabling policies [294](#)
 - enabling [289](#)
 - enabling policies [295](#)
 - registering Smart Call Home [299](#)
 - Smart Call Home [286](#)
 - system inventory messages [290](#)
- canceling image downloads [106](#)
- catalog, images [98](#)
- changing
 - ports [55](#)
 - properties [35](#)
- chassis
 - acknowledging [263](#)
 - acknowledging servers [272](#)
 - discovery policy [10, 187](#)
 - enabling decommissioned [264](#)
 - hybrid display [33](#)
 - management [263](#)
 - monitoring [265](#)
 - POST results [267](#)
 - reacknowledging slot [274](#)
 - removing [264](#)
 - removing server [273](#)
 - turning off locator LED [265](#)
 - turning on locator LED [265](#)
- chassis discovery policy
 - about [10, 187](#)
 - configuring [187](#)
- chassis management [263, 264, 265](#)
 - acknowledging [263](#)
 - enabling decommissioned [264](#)
 - monitoring [265](#)
 - removing [264](#)
 - turning off locator LED [265](#)
 - turning on locator LED [265](#)
- CIM-XML, configuring [64](#)
- Cisco Discovery Protocol [12, 152](#)
- Cisco TAC-1 profile, configuring [297](#)
- Cisco UCS 82598KR-CI
 - virtualization [24](#)
- Cisco UCS CNA M71KR
 - virtualization [24](#)
- Cisco UCS Manager
 - about [25](#)
 - GUI [29](#)
 - impact of firmware update [101](#)
- cisco-av-pair [74](#)
- CiscoAVPair [74](#)
- cloning service profiles [242](#)
- cluster configuration
 - about [28](#)
 - primary fabric interconnect [45](#)
 - subordinate fabric interconnect [47](#)
- CMOS resetting [277](#)
- communication services
 - about [63](#)
 - CIM-XML [64](#)
 - configuring [70](#)
 - HTTP [65](#)
 - HTTPS [65, 66, 67](#)
 - SNMP [68, 69](#)
 - Telnet [70](#)
- component, firmware [97](#)
- configuration
 - backing up [303, 306](#)
 - import methods [303](#)
 - importing [302](#)
 - restoring [303, 307, 311](#)
- configuration, cluster [45, 47](#)
- configuration, standalone [43](#)
- configuring
 - CIM-XML [64](#)
 - communication services [70](#)
 - HTTP [65](#)
 - HTTPS [65, 66, 67](#)
 - ports [60, 120](#)
 - server ports [54](#)
- considerations
 - backup operations [302](#)
 - Call Home [286](#)
- console, KVM [256, 276](#)
- Core File Exporter
 - about [317](#)
 - configuring [317](#)
 - disabling [318](#)
- corrupt BIOS [278](#)
- creating
 - host firmware policy [111](#)
 - management firmware policy [113](#)
 - service profiles [239](#)

D

- database
 - backing up [301](#)
 - restoring [303](#)
- decommissioning
 - chassis [264](#)
 - servers [273](#)
- default service profiles [8, 208, 225](#)
- deleting
 - port channels [59](#)
 - service profiles [251](#)
- disabling
 - Call Home [289](#)
 - communication services [70](#)
 - Core File Exporter [318](#)
 - port channels [124](#)
 - ports [56, 61](#)
 - server ports [121](#)
 - uplink Ethernet port channels [58](#)
 - uplinkEthernet ports [122](#)
- disassociating servers [243](#)
- disaster recovery [301, 303](#)
- discovery policy
 - chassis [10, 187](#)
 - server [13, 196, 197, 198](#)
- DNS servers
 - about [115](#)
 - adding [115](#)
 - deleting [116](#)
- dongle, KVM [255](#)
- downgrade firmware [103](#)
- download firmware [99](#)
- downloading
 - canceling [106](#)
 - images [104](#)

E

- enabling
 - Call Home [287, 289](#)
 - Core File Exporter [317](#)
 - decommissioned chassis [264](#)
 - port channels [124](#)
 - ports [55, 61](#)
 - server ports [121](#)
 - Smart Call Home [295](#)
 - SNMP [68](#)
 - Telnet [70](#)
 - uplink Ethernet port channels [58](#)
 - uplinkEthernet ports [122](#)
- end-host mode [49, 120](#)

- endpoints
 - direct firmware update [99, 101](#)
 - service profile update [102](#)
- Ethernet
 - Fibre Channel over [5](#)
 - flow control policies [21, 140](#)
 - server ports [54](#)
 - switching mode [49, 120](#)
 - uplink port channels [57, 58, 59, 123](#)
 - uplink ports [53, 54](#)
- Ethernet adapter policies
 - about [10, 149, 170](#)
 - creating [150](#)
 - deleting [152](#)
- Ethernet switching mode
 - about [48](#)
 - modifying [49](#)
- exiting [35](#)
- exporting
 - backup [303](#)
 - backup types [301](#)
 - configuration [301](#)
 - user role [303](#)

F

- fabric interconnects
 - admin password recover [324, 325](#)
 - admin password recovery [323](#)
 - available space [104](#)
 - changing access [51](#)
 - changing ports [55](#)
 - changing properties [51](#)
 - cluster [28](#)
 - determining leadership role [324](#)
 - disabling ports [56](#)
 - enabling ports [55](#)
 - enabling standalone for cluster [48](#)
 - Ethernet switching mode [48](#)
 - high availability [28](#)
 - impact of firmware update [101](#)
 - initial setup
 - about [41](#)
 - first [45](#)
 - management port [42](#)
 - second [47](#)
 - setup mode [42](#)
 - standalone [43](#)
 - mode [49](#)
 - monitoring [50](#)
 - restoring configuration [311](#)
 - system configuration type [42](#)

fabric interconnects (*continued*)
 unconfiguring ports [56](#)
 updating firmware [110](#)
 updating UCS Manager [111](#)
 verifying firmware [324](#)

fault collection policy
 about [14, 315](#)
 configuring [316](#)

Fault Summary area [29](#)

faults
 collection policy [14, 315, 316](#)
 Core File Exporter [317, 318](#)
 lifecycle [14, 315](#)

FCoE [5](#)

features
 opt-in [22](#)
 stateless computing [22](#)

Fibre Channel
 link-level flow control [5](#)
 over Ethernet [5](#)
 priority flow control [5](#)
 uplink ports [53](#)

Fibre Channel adapter policies
 about [10, 149, 170](#)
 creating [171](#)
 deleting [174](#)

Fibre Channel priority system class [21, 128, 140, 141](#)

filtering tables [32](#)

firmware
 about [97](#)
 activating [106](#)
 activating adapters [108](#)
 activating BMC [109](#)
 activating IOM [110](#)
 canceling image download [106](#)
 direct update [99](#)
 downgrades [103](#)
 downloading images [104](#)
 fabric interconnect [324](#)
 host pack [11, 102, 111, 112](#)
 image headers [98](#)
 images [97, 98](#)
 management [99](#)
 management pack [12, 103](#)
 management package [113, 114](#)
 obtaining images [104](#)
 outage impacts [101](#)
 service profiles [102](#)
 update stages [100, 103](#)
 updates [98](#)
 updating [106](#)
 updating adapters [107](#)
 updating BMC [108](#)
 updating fabric interconnects [110](#)

firmware (*continued*)
 updating IOM [109](#)
 updating UCS Manager [111](#)
 upgrade order [100](#)
 verifying [114](#)

flexibility [4](#)

flow control
 link-level [5](#)
 priority [5](#)

flow control policy
 about [21, 140](#)
 creating [143](#)
 deleting [144](#)

full state [301](#)

G

gold priority system class [21, 128, 140, 141](#)

graceful shutdown [271](#)

GUI

about [29](#)
 customizing tables [32](#)
 Fault Summary area [29](#)
 hybrid display [33](#)
 logging in, HTTP [35](#)
 logging in, HTTPS [34](#)
 logging out [35](#)
 Navigation pane [30](#)
 session properties [35](#)
 status bar [31](#)
 toolbar [31](#)
 Work pane [31](#)

GUI Inactivity Timeout [35](#)

guidelines
 oversubscription [18](#)
 pinning [20](#)

H

hard reset, server [271](#)
 hardware based service profiles [225](#)
 hardware-based service profiles [8, 208](#)
 hardware, stateless [22](#)
 headers, images [98](#)
 high availability [4, 28, 45, 47](#)
 about [28](#)
 initial setup [45, 47](#)
 host firmware pack
 about [11, 102](#)
 creating [111](#)
 updating [112](#)

- HTTP
 - configuring [65](#)
 - logging in [35](#)
 - HTTPS
 - certificate request [66](#)
 - configuring [67](#)
 - creating key ring [65](#)
 - importing certificate [67](#)
 - logging in [34](#)
 - trusted point [66](#)
 - hybrid display [33](#)
- I**
- I/O module
 - management [281](#)
 - I/O modules
 - activating firmware [110](#)
 - monitoring [282](#)
 - POST results [282](#)
 - resetting [281](#)
 - updating firmware [109](#)
 - IEEE 802.3x link-level flow control [5](#)
 - images [97, 98](#)
 - bundle [97](#)
 - component [97](#)
 - contents [98](#)
 - headers [98](#)
 - import operations
 - creating [307](#)
 - deleting [311](#)
 - modifying [310](#)
 - running [309](#)
 - importing
 - about [302](#)
 - creating operations [307](#)
 - deleting operation [311](#)
 - modifying operations [310](#)
 - restore methods [303](#)
 - user role [303](#)
 - in-band access [51](#)
 - inheritance, servers [13, 198](#)
 - inherited values [8, 208](#)
 - initial setup
 - about [41](#)
 - cluster configuration [45, 47](#)
 - management port IP address [42](#)
 - setup mode [42](#)
 - standalone configuration [43](#)
 - initial templates [8, 208](#)
 - Internal Fabric Manager
 - about [33, 59](#)
 - Internal Fabric Manager (*continued*)
 - configuring ports [60](#)
 - disabling ports [61](#)
 - enabling ports [61](#)
 - launching [60](#)
 - unconfiguring ports [60](#)
 - IOM
 - activating firmware [110](#)
 - monitoring [282](#)
 - POST results [282](#)
 - updating firmware [109](#)
 - IP
 - pools [182](#)
 - IP addresses
 - management IP pool [17, 181](#)
 - management port [42](#)
 - IP pools
 - creating IP address block [181](#)
 - management [17, 181](#)
 - IPMI profiles
 - about [11, 188](#)
 - creating [188](#)
 - deleting [189](#)
- K**
- key ring
 - certificate request [66](#)
 - creating [65](#)
 - deleting [68](#)
 - importing certificate [67](#)
 - trusted point [66](#)
 - KVM console
 - about [254](#)
 - KVM Console
 - installing OS [256](#)
 - starting from server [276](#)
 - starting from service profile [276](#)
 - KVM dongle
 - about [254](#)
 - installing OS [255](#)
- L**
- LAN
 - MAC pools [137, 138](#)
 - named VLANs
 - creating [126, 131](#)
 - deleting [128, 133](#)
 - pin groups [125, 126, 135, 136](#)
 - creating [125, 135](#)

- LAN (*continued*)
 - pin groups (*continued*)
 - deleting [126, 136](#)
 - uplinks manager [33, 119](#)
 - VLANs [131](#)
 - vNIC policy [14, 145](#)
 - LAN pin groups
 - creating [125, 135](#)
 - deleting [126, 136](#)
 - LAN Uplinks Manager
 - about [33, 119](#)
 - changing Ethernet switching mode [120](#)
 - configuring ports [120](#)
 - disabling server ports [121](#)
 - disabling uplinkEthernet ports [122](#)
 - enabling server ports [121](#)
 - enabling uplinkEthernet ports [122](#)
 - launching [120](#)
 - named VLANs
 - creating [126](#)
 - deleting [128](#)
 - pin groups
 - creating [125](#)
 - deleting [126](#)
 - port channels
 - adding ports [124](#)
 - creating [123](#)
 - deleting [125](#)
 - disabling [124](#)
 - enabling [124](#)
 - removing ports [125](#)
 - system classes, configuring [128](#)
 - unconfiguring server ports [122](#)
 - unconfiguring uplink Ethernet ports [123](#)
 - lanes, virtual [20, 139](#)
 - launching
 - GUI, HTTP [35](#)
 - GUI, HTTPS [34](#)
 - Internal Fabric Manager [60](#)
 - LAN Uplinks Manager [120](#)
 - LDAP [73](#)
 - LDAP provider
 - creating [74](#)
 - deleting [79](#)
 - LED locator
 - chassis [265](#)
 - servers [275](#)
 - lifecycle, faults [14, 315](#)
 - link-level flow control [5](#)
 - local disk configuration policy
 - about [12, 189](#)
 - changing [191](#)
 - creating [190](#)
 - deleting [192](#)
 - locales
 - about [89](#)
 - adding organizations [92](#)
 - creating [91](#)
 - deleting [92](#)
 - deleting organizations [92](#)
 - locally authenticated users
 - creating [93](#)
 - deleting [95](#)
 - locating
 - chassis [265](#)
 - servers [275](#)
 - log, system [318](#)
 - logging in
 - HTTP [35](#)
 - HTTPS [34](#)
 - logging out [35](#)
 - logical configuration [301](#)
- ## M
- MAC addresses
 - creating pools [137](#)
 - deleting pools [138](#)
 - pools [16, 137](#)
 - MAC pools
 - creating [137](#)
 - deleting [138](#)
 - management
 - chassis [263](#)
 - I/O modules [281](#)
 - servers [269](#)
 - management firmware pack
 - about [12, 103](#)
 - updating [114](#)
 - management firmware package
 - creating [113](#)
 - management IP pools
 - about [17, 181](#)
 - creating IP address block [181](#)
 - deleting IP address block [182](#)
 - management port IP address [42](#)
 - merging configuration [303](#)
 - messages, system inventory [290, 298](#)
 - mobility [22](#)
 - mode
 - end-host [48, 49, 120](#)
 - Ethernet switching [48](#)
 - setup [42](#)
 - switching [49, 120](#)
 - monitoring
 - chassis [265](#)

monitoring (*continued*)
 fabric interconnects [50, 51](#)
 I/O modules [282](#)
 servers [279](#)
 user sessions [95](#)

multi-tenancy
 about [23](#)
 name resolution [82](#)
 opt-in [23](#)
 opt-out [24](#)
 organizations [81, 83, 84](#)
 creating [83, 84](#)
 deleting [84](#)

N

name resolution [82, 115](#)

named VLANs
 about [131](#)
 creating [126, 131](#)
 deleting [128, 133](#)

named VSANs
 about [157](#)
 creating [157](#)
 deleting [158](#)

Navigation pane [30](#)

network
 connectivity [6](#)
 creating [157](#)
 named VLANs [126, 128, 131, 133](#)
 creating [126, 131](#)
 deleting [128, 133](#)
 named VSANs [157, 158](#)
 deleting [158](#)

network control policy [12, 152, 153, 154](#)
 creating [153](#)
 deleting [154](#)

NTP servers
 about [261](#)
 adding [262](#)
 deleting [262](#)

O

obtaining image bundles [104](#)

operating system installation
 about [253](#)
 KVM console [254, 256](#)
 KVM dongle [254, 255](#)
 methods [253](#)
 PXE [255](#)

operating system installation (*continued*)
 targets [254](#)

operations
 backup [303, 306, 307](#)
 confirming [36](#)
 import [307, 311](#)

opt-in
 about [22](#)
 multi-tenancy [23](#)
 stateless computing [22](#)

opt-out [22, 23, 24](#)
 multi-tenancy [24](#)
 stateless computing [23](#)

organizations
 about [81](#)
 adding to locales [92](#)
 creating [83, 84](#)
 creating locales [91](#)
 deleting [84](#)
 deleting from the locales [92](#)
 deleting locales [92](#)
 locales [89](#)
 multi-tenancy [23](#)
 name resolution [82](#)

OS installation
 about [253](#)
 KVM console [254, 256](#)
 KVM dongle [254, 255](#)
 methods [253](#)
 PXE [255](#)
 targets [254](#)

out-of-band access [51](#)

outage impacts
 firmware update [101](#)
 Cisco UCS Manager [101](#)
 fabric interconnects [101](#)

overriding
 server identity [209](#)

overriding server identity [7, 207, 209](#)

oversubscription
 about [17](#)
 considerations [17](#)
 guidelines [18](#)

overview [3](#)

P

packages
 management firmware [113](#)

packs
 host firmware [11, 102, 111, 112](#)
 management firmware [12, 103, 114](#)

- pane
 - Navigation [30](#)
 - Work [31](#)
- passwords, recovering admin [323, 324, 325](#)
- persistent binding, clearing [250](#)
- PFC [5](#)
- pin groups
 - about [19](#)
 - LAN [125, 126, 135, 136](#)
 - SAN [161, 162](#)
- pinning
 - about [19](#)
 - guidelines [20](#)
 - servers to server ports [19](#)
- platinum priority system class [21, 128, 140, 141](#)
- policies
 - about [9](#)
 - autoconfiguration [12, 195, 196](#)
 - boot [9, 183, 185, 187](#)
 - Call Home [293, 294, 295](#)
 - chassis discovery [10, 187](#)
 - Ethernet [10, 149, 170](#)
 - fault collection [14, 315, 316](#)
 - Fibre Channel adapter [10, 149, 170](#)
 - flow control [21, 140, 143, 144](#)
 - host firmware [11, 102, 111, 112](#)
 - IPMI profiles [11, 188, 189](#)
 - local disk configuration [12, 189, 190, 191, 192](#)
 - management firmware [12, 103, 113, 114](#)
 - network control [12, 152, 153, 154](#)
 - QoS [12, 21, 140, 142, 143](#)
 - scrub [14, 192, 193](#)
 - serial over LAN
 - about [14, 193](#)
 - creating [194](#)
 - deleting [195](#)
 - server discovery [13, 196, 197, 198](#)
 - server inheritance
 - about [13, 198](#)
 - creating [198](#)
 - deleting [199](#)
 - server pool [13, 199, 200, 201](#)
 - server pool qualification [13, 201](#)
 - server pool qualifications [201, 204](#)
 - statistics collection [14, 327, 328](#)
 - threshold [15, 329, 330, 332, 334](#)
 - vHBA [14, 167](#)
 - vNIC [14, 145](#)
- pools
 - about [15](#)
 - MAC [16, 137, 138](#)
 - management IP [17, 181, 182](#)
 - servers [16, 177, 178, 179](#)
 - UUID suffixes [16, 179, 180](#)
- pools (*continued*)
 - WWN [16, 163](#)
 - WWNN [164, 165](#)
 - WWPN [165, 166](#)
- port channels
 - adding ports [58, 124](#)
 - creating [57, 123](#)
 - deleting [59, 125](#)
 - disabling [58, 124](#)
 - enabling [58, 124](#)
 - removing ports [59, 125](#)
- ports
 - changing [55](#)
 - disabling [56, 121, 122](#)
 - enabling [55, 121, 122](#)
 - Ethernet server port [335](#)
 - fabric interconnect [53](#)
 - Fibre Channel port [337](#)
 - management [42](#)
 - pin groups [125, 126, 135, 136, 161, 162](#)
 - pinning server traffic [19](#)
 - server [53, 54, 60, 61, 120](#)
 - unconfiguring [56, 122, 123](#)
 - uplink [53](#)
 - uplink Ethernet [54, 120, 334](#)
- POST
 - viewing for chassis [267](#)
 - viewing for I/O modules [282](#)
 - viewing for server [280](#)
- Power on Self-Test
 - viewing for chassis [267](#)
 - viewing for I/O modules [282](#)
 - viewing for server [280](#)
- powercycling servers [271](#)
- primary authentication
 - about [73](#)
 - LDAP provider [74, 79](#)
 - RADIUS provider [76, 79](#)
 - remote [73](#)
 - selecting [79](#)
 - TACACS provider [78, 79](#)
- priority flow control [5](#)
- privileges
 - about [87](#)
 - adding [90](#)
 - removing [90](#)
- profiles [5](#)
- properties
 - fabric interconnects [51](#)
 - session [35](#)
- provider
 - LDAP [74, 79](#)
 - RADIUS [76, 79](#)
 - TACACS [78, 79](#)

PXE, installing OS [255](#)

Q

QoS policies

- about [12, 21, 140](#)
- creating [142](#)
- deleting [143](#)

quality of service

- about [20, 139](#)
- flow control policies [21, 140](#)
- policies [12, 21, 140, 142, 143](#)
- system classes [20, 128, 139, 141](#)

R

RADIUS [73](#)

RADIUS provider

- creating [76](#)
- deleting [79](#)

reacknowledging

- server slots [274](#)
- servers [272](#)

rebooting server [271](#)

recommendations

- backup operations [302](#)

recommissioning, chassis [264](#)

Reconnection Interval [35](#)

recovering admin password [323, 324, 325](#)

recovering BIOS [278](#)

registration, Smart Call Home [299](#)

remote authentication

- user accounts [74](#)
- user roles [74](#)

removing

- chassis [264](#)
- ports from a port channel [59](#)
- ports from port channel [125](#)
- server from chassis [273](#)
- server from configuration [274](#)

replacing configuration [303](#)

resetting

- BMC [277](#)
- CMOS [277](#)
- IOM [281](#)

resetting server, hard [271](#)

resolution, name [115](#)

restoring

- about [303](#)
- configuration [311](#)
- import operations [307](#)

restoring *(continued)*

- user role [303](#)

role-based access control [85](#)

roles

- about [86](#)
- adding privileges [90](#)
- backing up [303](#)
- creating [89](#)
- deleting [90](#)
- privileges [87](#)
- removing privileges [90](#)

root organization [83](#)

running

- backup operation [306](#)
- import operation [309](#)

S

SAN

named VSANs

- creating [157](#)
- deleting [158](#)

pin groups [161, 162](#)

vHBA policy [14, 167](#)

VSANs [157](#)

SAN pin groups

- creating [161](#)
- deleting [162](#)

scalability [4](#)

scrub policy

- about [14, 192](#)
- creating [192](#)
- deleting [193](#)

selecting primary authentication [79](#)

serial over LAN policy

- about [14, 193](#)
- creating [194](#)
- deleting [195](#)

server autoconfiguration policy

- about [12, 195](#)
- creating [195](#)
- deleting [196](#)

server discovery policy

- about [13, 196](#)
- creating [197](#)
- deleting [198](#)

server inheritance policy

- about [13, 198](#)
- creating [198](#)
- deleting [199](#)

server management [269](#)

- server pool policy
 - about [13, 199](#)
 - creating [200](#)
 - deleting [201](#)
- server pool policy qualification
 - about [13, 201](#)
- server pool policy qualifications
 - creating [201](#)
 - deleting [204](#)
 - deleting qualifications [204](#)
- server pools
 - adding servers [178](#)
 - associating service profile [242](#)
 - associating service profile templates [241](#)
 - creating [177](#)
 - deleting [178](#)
 - disassociating service profile [243](#)
 - disassociating service profile templates [241](#)
 - removing servers [179](#)
- server ports
 - about [53](#)
 - configuring
 - Equipment tab [54](#)
 - Internal Fabric Manager [60](#)
 - LAN Uplink Manager [120](#)
 - disabling [61, 121](#)
 - Internal Fabric Manager [61](#)
 - enabling [61, 121](#)
 - Internal Fabric Manager [61](#)
 - Internal Fabric Manager [33, 59](#)
 - unconfiguring [60, 122](#)
 - Internal Fabric Manager [60](#)
- server virtualization [4](#)
- servers
 - acknowledging [272](#)
 - adding to pools [178](#)
 - associating with service profiles [242](#)
 - boot policies [9, 183, 185, 187](#)
 - booting [270](#)
 - changing UUID [243](#)
 - cloning service profiles [242](#)
 - configuration [6](#)
 - creating service profile templates [226](#)
 - creating service profiles [209, 222](#)
 - decommissioning [273](#)
 - disassociating from service profiles [243](#)
 - discovery policy [13, 196, 197, 198](#)
 - DNS [115, 116](#)
 - hard reset [271](#)
 - hardware based service profiles [225](#)
 - inheritance policy [13, 198](#)
 - IPMI profiles [11, 188, 189](#)
 - KVM Console [276](#)
 - local disk configuration [12, 189, 190, 191, 192](#)
- servers (*continued*)
 - locator LED
 - turning off [275](#)
 - turning on [275](#)
 - management [269](#)
 - monitoring [279](#)
 - multi-tenancy [23](#)
 - pinning [19](#)
 - pool policy [13, 199, 200, 201](#)
 - pool qualifications [13, 201, 204](#)
 - pools [16, 177, 178](#)
 - POST results [280](#)
 - power cycling [271](#)
 - reacknowledging slots [274](#)
 - recovering BIOS [278](#)
 - removing
 - from chassis [273](#)
 - from database [274](#)
 - removing from pools [179](#)
 - resetting
 - BMC [277](#)
 - CMOS [277](#)
 - service profiles [5, 7, 207, 251](#)
 - service profiles from templates [239](#)
 - shutting down [271](#)
 - stateless [22](#)
 - statistics threshold policies [330, 332, 334](#)
 - template based service profiles [239](#)
- service profile template wizard
 - opening [226](#)
 - page 1, identity [226](#)
 - page 2, storage [227](#)
 - page 3, networking [232](#)
 - page 4, server boot order [234](#)
 - page 5, server assignment [236](#)
 - page 6, policies [238](#)
- service profile templates
 - associating with server pool [241](#)
 - binding service profiles [250](#)
 - changing UUID [240](#)
 - creating [226, 227, 232, 234, 236, 238](#)
 - identity [226](#)
 - networking [232](#)
 - policies [238](#)
 - server assignment [236](#)
 - server boot order [234](#)
 - disassociating from server pool [241](#)
 - unbinding service profiles [251](#)
- service profile wizard
 - opening [209](#)
 - page 1, identity [209](#)
 - page 2, storage [210](#)
 - page 3, networking [215](#)
 - page 4, server boot order [218](#)

- service profile wizard (*continued*)
 - page 5, server assignment [220](#)
 - page 6, policies [221](#)
- service profiles
 - about [5](#)
 - associating [242](#)
 - binding to template [250](#)
 - changing UUID [243](#)
 - cloning [242](#)
 - configuration [6](#)
 - creating from template [239](#)
 - creating hardware based [225](#)
 - creating template based [239](#)
 - creating with inherited values [222](#)
 - creating with wizard [209, 210, 215, 218, 220, 221](#)
 - identity [209](#)
 - networking [215](#)
 - policies [221](#)
 - server assignment [220](#)
 - server boot order [218](#)
 - storage [210](#)
 - disassociating [243](#)
 - firmware updates [102](#)
 - inherited values [8, 208, 225](#)
 - network connectivity [6](#)
 - override identity [7, 207](#)
 - servers
 - booting [270](#)
 - KVM Console [276](#)
 - shutting down [271](#)
 - templates [8, 208](#)
 - unbinding from template [251](#)
 - vHBAs [247, 249, 250](#)
 - vNICs [245, 247](#)
- session properties [36](#)
- sessions, users [95](#)
- setting
 - session properties [35](#)
 - switching mode [49, 120](#)
- setting up
 - primary fabric interconnect [45](#)
 - subordinate fabric interconnect [47](#)
- setup mode [42](#)
- shutdown, graceful [271](#)
- shutting down servers [271](#)
- silver priority system class [21, 128, 140, 141](#)
- Smart Call Home
 - about [286](#)
 - Cisco TAC-1 profile [297](#)
 - configuring [295](#)
 - considerations [286](#)
 - registering [299](#)
 - system inventory messages [298](#)
- SNMP
 - enabling [68](#)
 - SNMPv3 users [69](#)
 - trap hosts [69](#)
- SNMPv3 users, configuring [69](#)
- software [97](#)
- SSH, configuring [36](#)
- stages, firmware updates [100, 103](#)
- standalone configuration [43](#)
- starting
 - GUI [34, 35](#)
 - Internal Fabric Manager [60](#)
 - KVM Console from server [276](#)
 - KVM Console from service profile [276](#)
 - LAN Uplinks Manager [120](#)
- starting servers [270](#)
- stateless computing
 - about [22](#)
 - opt-in [22](#)
 - opt-out [23](#)
- statelessness [22](#)
- statistics
 - threshold policies [15, 329, 330, 332, 334, 335, 337](#)
 - Ethernet server port [335](#)
 - Fibre Channel port [337](#)
 - server and server component [330, 332, 334](#)
 - uplink Ethernet port [334](#)
- statistics collection policies
 - about [14, 327](#)
 - modifying [328](#)
- status bar [31](#)
- stopping servers [271](#)
- subordinate fabric interconnect
 - initial setup [47](#)
- suborganization [84](#)
- supported tasks [26](#)
- switching mode [49, 120](#)
- syslog [318](#)
- system classes [20, 21, 128, 139, 140, 141](#)
 - best effort priority [21, 128, 140, 141](#)
 - bronze priority [21, 128, 140, 141](#)
 - Fibre Channel priority [21, 128, 140, 141](#)
 - gold priority [21, 128, 140, 141](#)
 - platinum priority [21, 128, 140, 141](#)
 - silver priority [21, 128, 140, 141](#)
- system configuration [301](#)
- system inventory messages [290, 298](#)
 - configuring [290](#)
 - sending [290](#)
- system management
 - chassis [263](#)
 - I/O module [281](#)
 - servers [269](#)

T

- tables
 - customizing [32](#)
 - customizing tables [32](#)
 - filtering [32](#)
- TACACS provider
 - creating [78](#)
 - deleting [79](#)
- TACACS+ [73](#)
- tasks
 - supported [26](#)
 - unsupported [28](#)
- Telnet, enabling [70](#)
- template based service profiles [239](#)
- templates
 - creating service profiles [239](#)
 - service profiles [8, 208](#)
- TFTP Core Exporter [317, 318](#)
- threshold policies
 - about [15, 329](#)
 - Ethernet server port
 - adding threshold class [335](#)
 - Fibre Channel port
 - adding threshold class [337](#)
 - server and server component
 - adding threshold class [332](#)
 - creating [330](#)
 - deleting [334](#)
 - uplink Ethernet port
 - adding threshold class [334](#)
- time zones
 - about [261](#)
 - setting [261](#)
- toolbar [31](#)
- traffic management
 - oversubscription [17, 18](#)
 - quality of service [20, 139](#)
 - system classes [20, 139](#)
 - virtual lanes [20, 139](#)
- trap hosts, configuring [69](#)
- trusted points
 - creating [66](#)
 - deleting [68](#)
- turning off
 - chassis locator LED [265](#)
 - server locator LED [275](#)
- turning on
 - chassis locator LED [265](#)
 - server locator LED [275](#)

U

- UCS Manager
 - GUI [29](#)
- unbinding
 - service profiles [251](#)
 - vHBAs [170](#)
 - vNICs [148](#)
- unconfiguring
 - ports [60](#)
- unconfiguring ports [56, 122, 123](#)
- unified fabric
 - about [4](#)
 - Fibre Channel [5](#)
- unsupported tasks [28](#)
- updating
 - firmware [98, 100, 103](#)
 - firmware order [100](#)
 - firmware, direct [99](#)
 - firmware, service profiles [102](#)
 - host firmware policy [112](#)
 - management firmware policy [114](#)
- updating firmware [106, 107, 108, 109, 110, 111](#)
- updating templates [8, 208](#)
- upgrading firmware
 - activating [106](#)
 - adapters [107](#)
 - BMC [108](#)
 - downloading images [104](#)
 - fabric interconnects [110](#)
 - IOM [109](#)
 - obtaining images [104](#)
 - UCS Manager [111](#)
 - updating [106](#)
- uplink Ethernet ports
 - configuring
 - Equipment tab [54](#)
 - LAN Uplink Manager [120](#)
 - disabling [122](#)
 - enabling [122](#)
 - unconfiguring [123](#)
- uplink port channels
 - adding ports [58, 124](#)
 - creating [57, 123](#)
 - deleting [59, 125](#)
 - disabling [58, 124](#)
 - enabling [58, 124](#)
 - removing ports [59, 125](#)
- uplink ports
 - about [53](#)
 - Ethernet [54](#)
 - flow control policies [21, 140](#)
 - pin groups [125, 126, 135, 136, 161, 162](#)
 - creating [125, 135](#)

- uplink ports (*continued*)
 - pin groups (*continued*)
 - deleting [126, 136](#)
 - uplinks, Manager for LAN [33, 119](#)
 - user accounts
 - about [85](#)
 - creating [93](#)
 - deleting [95](#)
 - user roles
 - about [86](#)
 - adding privileges [90](#)
 - creating [89](#)
 - deleting [90](#)
 - privileges [87](#)
 - removing privileges [90](#)
 - users
 - access control [85](#)
 - accounts [85](#)
 - adding privileges [90](#)
 - authentication [73](#)
 - creating accounts [93](#)
 - creating roles [89](#)
 - deleting local accounts [95](#)
 - deleting roles [90](#)
 - locales
 - about [89](#)
 - adding organizations [92](#)
 - creating [91](#)
 - deleting [92](#)
 - deleting organizations [92](#)
 - monitoring sessions [95](#)
 - privileges [87](#)
 - recovering admin password [323, 324, 325](#)
 - remote authentication [74](#)
 - removing privileges [90](#)
 - roles [86](#)
 - SNMPv3 [69](#)
 - UUID
 - changing [243](#)
 - changing in service profile template [240](#)
 - UUID suffix pools
 - about [16, 179](#)
 - creating [179](#)
 - deleting [180](#)
- ## V
- verifying firmware [114](#)
 - vHBA SAN Connectivity policies
 - about [14, 167](#)
 - binding vHBAs [169](#)
 - creating [167](#)
 - vHBA SAN Connectivity policies (*continued*)
 - deleting [169](#)
 - unbinding vHBAs [170](#)
 - vHBA templates
 - about [14, 167](#)
 - binding vHBAs [169](#)
 - creating [167](#)
 - deleting [169](#)
 - unbinding vHBAs [170](#)
 - vHBAs
 - binding to vHBA template [169](#)
 - changing WWPN [249](#)
 - clearing persistent binding [250](#)
 - creating for service profiles [247](#)
 - deleting from service profiles [250](#)
 - unbinding from vHBA template [170](#)
 - VIF status [279](#)
 - virtual lanes [20, 139](#)
 - virtualization
 - about [24](#)
 - Cisco UCS 82598KR-CI [24](#)
 - Cisco UCS CNA M71KR [24](#)
 - VLANs
 - named
 - about [131](#)
 - creating [126, 131](#)
 - deleting [128, 133](#)
 - VMware [24](#)
 - vNIC
 - policy [14, 145](#)
 - vNIC LAN Connectivity policies
 - about [14, 145](#)
 - binding vNICs [148](#)
 - creating [145](#)
 - deleting [147](#)
 - unbinding vNICs [148](#)
 - vNIC templates
 - about [14, 145](#)
 - binding vNICs [148](#)
 - creating [145](#)
 - deleting [147](#)
 - unbinding vNICs [148](#)
 - vNICs
 - binding to vNIC template [148](#)
 - creating for service profiles [245](#)
 - deleting from service profiles [247](#)
 - unbinding from vNIC template [148](#)
 - VSANs
 - creating [157](#)
 - deleting [158](#)
 - named [157](#)

W

Work pane [31](#)

WWN

creating WWNN pools [164](#)

creating WWPN pools [165](#)

deleting WWNN pools [165](#)

deleting WWPN pools [166](#)

WWN pools

about [16](#), [163](#)

creating WWNN [164](#)

creating WWPN [165](#)

deleting WWNN [165](#)

deleting WWPN [166](#)

WWNN [17](#), [163](#), [164](#), [165](#)

WWPN [17](#), [164](#), [165](#), [166](#)