



Overview of Cisco UCS Manager GUI

This chapter includes the following sections:

- [Overview of Cisco UCS Manager GUI](#) , page 1
- [Logging in to Cisco UCS Manager GUI through HTTPS](#), page 7
- [Logging in to Cisco UCS Manager GUI through HTTP](#), page 8
- [Logging Off Cisco UCS Manager GUI](#) , page 9
- [Web Session Limits](#), page 9
- [Pre-Login Banner](#), page 10
- [Cisco UCS Manager GUI Properties](#), page 11
- [Determining the Acceptable Range of Values for a Field](#), page 14
- [Determining Where a Policy Is Used](#), page 15
- [Determining Where a Pool Is Used](#), page 15
- [Copying the XML](#), page 15

Overview of Cisco UCS Manager GUI

Cisco UCS Manager GUI is the Java application that provides a GUI interface to Cisco UCS Manager. You can start and access Cisco UCS Manager GUI from any computer that meets the requirements listed in the System Requirements section of the [Cisco UCS Software Release Notes](#).

Each time you start Cisco UCS Manager GUI, Cisco UCS Manager uses Java Web Start technology to cache the current version of the application on your computer. As a result, you do not have to download the application every time you log in. You only have to download the application the first time that you log in from a computer after the Cisco UCS Manager software has been updated on a system.



Tip

The title bar displays the name of the Cisco UCS domain to which you are connected.

Fault Summary Area

The **Fault Summary** area displays in the upper left of Cisco UCS Manager GUI. This area displays a summary of all faults that have occurred in the Cisco UCS domain.

Each type of fault is represented by a different icon. The number below each icon indicates how many faults of that type have occurred in the system. If you click an icon, Cisco UCS Manager GUI opens the **Faults** tab in the **Work** area and displays the details of all faults of that type.

The following table describes the types of faults each icon in the **Fault Summary** area represents:

Fault Type	Description
Critical Alarms	Critical problems exist with one or more components. These issues should be researched and fixed immediately.
Major Alarms	Serious problems exist with one or more components. These issues should be researched and fixed immediately.
Minor Alarms	Problems exist with one or more components that might adversely affect system performance. These issues should be researched and fixed as soon as possible before they become major or critical issues.
Warning Alarms	Potential problems exist with one or more components that might adversely affect system performance if they are allowed to continue. These issues should be researched and fixed as soon as possible before the problem grows worse.



Tip

If you only want to see faults for a specific object, navigate to that object and then review the **Faults** tab for that object.

Navigation Pane

The **Navigation** pane displays on the left side of Cisco UCS Manager GUI below the **Fault Summary** area. This pane provides centralized navigation to all equipment and other components in the Cisco UCS domain. When you select a component in the **Navigation** pane, the object displays in the **Work** area.

The **Navigation** pane has five tabs. Each tab includes the following elements:

- A **Filter** combo box that you can use to filter the navigation tree to view all nodes or only one node.
- An expandable navigation tree that you can use to access all components on that tab. An icon next to an folder indicates that the node or folder has subcomponents.

Equipment Tab

This tab contains a basic inventory of the equipment in the Cisco UCS domain. A system or server administrator can use this tab to access and manage the chassis, fabric interconnects, servers, and other hardware. A red, orange, or yellow rectangle around a device name indicate that the device has a fault.

The major nodes below the **Equipment** node in this tab are the following:

- **Chassis**
- **Fabric Interconnects**

Servers Tab

This tab contains the server-related components, such as service profiles, policies, and pools. A server administrator typically accesses and manages the components on this tab.

The major nodes below the **Servers** node in this tab are the following:

- **Service Profiles**
- **Service Profile Templates**
- **Policies**
- **Pools**

LAN Tab

This tab contains the components related to LAN configuration, such as LAN pin groups, quality of service classes, VLANs, policies, pools, and the internal domain. A network administrator typically accesses and manages the components on this tab.

The major nodes below the **LAN** node in this tab are the following:

- **LAN Cloud**
- **Policies**
- **Pools**
- **Internal LAN Domains**

SAN Tab

This tab contains the components related to SAN configuration, such as pin groups, VSANs, policies, and pools. A storage administrator typically accesses and manages the components on this tab.

The major nodes below the **SAN** node in this tab are the following:

- **SAN Cloud**
- **Policies**
- **Pools**

VM Tab

This tab contains the components required to configure VM-FEX for servers with a VIC adapter. For example, you use components on this tab to configure the connection between Cisco UCS Manager and VMware vCenter, to configure distributed virtual switches, port profiles, and to view the virtual machines hosted on servers in the Cisco UCS domain.

The major node below the **All** node in this tab is the **VMware** node.

Admin Tab

This tab contains system-wide settings, such as user manager and communication services, and troubleshooting components, such as faults and events. The system administrator typically accesses and manages the components on this tab.

The major nodes below the **All** node in this tab are the following:

- **Faults, Events and Audit Log**
- **User Management**
- **Key Management**
- **Communication Management**
- **Stats Management**
- **Timezone Management**
- **Capability Catalog**

Toolbar

The toolbar displays on the right side of Cisco UCS Manager GUI above the **Work** pane. You can use the menu buttons in the toolbar to perform common actions, including the following actions:

- Navigate between previously viewed items in the **Work** pane
- Create elements for the Cisco UCS domain
- Set options for Cisco UCS Manager GUI
- Access online help for Cisco UCS Manager GUI

Work Pane

The **Work** pane displays on the right side of Cisco UCS Manager GUI. This pane displays details about the component selected in the **Navigation** pane.

The **Work** pane includes the following elements:

- A navigation bar that displays the path from the main node of the tab in the **Navigation** pane to the selected element. You can click any component in this path to display that component in the **Work** pane.
- A content area that displays tabs with information related to the component selected in the **Navigation** pane. The tabs displayed in the content area depends upon the selected component. You can use these tabs to view information about the component, create components, modify properties of the component, and examine a selected object.

Status Bar

The status bar displays across the bottom of Cisco UCS Manager GUI. The status bar provides information about the state of the application.

On the left, the status bar displays the following information about your current session in Cisco UCS Manager GUI:

- A lock icon that indicates the protocol you used to log in. If the icon is locked, you connected with HTTPS and if the icon is unlocked, you connected with HTTP.
- The username you used to log in.
- The IP address of the server where you logged in.

On the right, the status bar displays the system time.

Table Customization

Cisco UCS Manager GUI enables you to customize the tables on each tab. You can change the type of content that you view and filter the content.

Table Customization Menu Button

This menu button in the upper right of every table enables you to control and customize your view of the table. The drop-down menu for this button includes the following options:

Menu Item	Description
<i>Column Name</i>	The menu contains an entry for each column in the table. Click a column name to display or hide the column.
Horizontal Scroll	If selected, adds a horizontal scroll bar to the table. If not selected, when you widen one of the columns, all columns to the right narrow and do not scroll.
Pack All Columns	Resizes all columns to their default width.
Pack Selected Column	Resizes only the selected column to its default width.

Table Content Filtering

The **Filter** button above each table enables you to filter the content in the table according to the criteria that you set in the **Filter** dialog box. The dialog box includes the following filtering options:

Name	Description
Disable option	No filtering criteria is used on the content of the column. This is the default setting.
Equal option	Displays only that content in the column which exactly matches the value specified.
Not Equal option	Displays only that content in the column which does not exactly match the value specified.

Name	Description
Wildcard option	The criteria you enter can include one of the following wildcards: <ul style="list-style-type: none"> • _ (underscore) or ? (question mark)—replaces a single character • % (percent sign) or * (asterisk)—replaces any sequence of characters
Less Than option	Displays only that content in the column which is less than the value specified.
Less Than Or Equal option	Displays only that content in the column which is less than or equal to the value specified.
Greater Than option	Displays only that content in the column which is greater than the value specified.
Greater Than Or Equal option	Displays only that content in the column which is greater than or equal to the value specified.

LAN Uplinks Manager

The LAN Uplinks Manager provides a single interface where you can configure the connections between Cisco UCS and the LAN. You can use the LAN Uplinks Manager to create and configure the following:

- Ethernet switching mode
- Uplink Ethernet ports
- Port channels
- LAN pin groups
- Named VLANs
- Server ports
- QoS system classes

Some of the configuration that you can do in the LAN Uplinks Manager can also be done in nodes on other tabs, such as the **Equipment** tab or the **LAN** tab.

Internal Fabric Manager

The Internal Fabric Manager provides a single interface where you can configure server ports for a fabric interconnect in a Cisco UCS domain. The Internal Fabric Manager is accessible from the **General** tab for that fabric interconnect.

Some of the configuration that you can do in the Internal Fabric Manager can also be done in nodes on the **Equipment** tab, on the **LAN** tab, or in the LAN Uplinks Manager.

Hybrid Display

For each chassis in a Cisco UCS domain, Cisco UCS Manager GUI provides a hybrid display that includes both physical components and connections between the chassis and the fabric interconnects.

This tab displays detailed information about the connections between the selected chassis and the fabric interconnects. It has an icon for the following:

- Each fabric interconnect in the system
- The I/O module (IOM) in the selected component, which is shown as an independent unit to make the connection paths easier to see
- The selected chassis showing the servers and PSUs

The lines between the icons represent the connections between the following:

- DCE interface on each server and the associated server port on the IOM. These connections are created by Cisco and cannot be changed.
- Server port on the IOM and the associated port on the fabric interconnect. You can change these connections if desired.

You can mouse over the icons and lines to view tooltips identifying each component or connection, and you can double-click any component to view properties for that component.

If there is a fault associated with the component or any of its subcomponents, Cisco UCS Manager GUI displays a fault icon on top of the appropriate component. If there are multiple fault messages, Cisco UCS Manager GUI displays the icon associated with the most serious fault message in the system.

Logging in to Cisco UCS Manager GUI through HTTPS

The default HTTPS web link for Cisco UCS Manager GUI is `https://UCSManager_IP`, where `UCSManager_IP` represents the IP address assigned to Cisco UCS Manager. This IP address can be one of the following:

- Cluster configuration: `UCSManager_IP` represents the virtual or cluster IP address assigned to Cisco UCS Manager. Do not use the IP addresses assigned to the management port on the fabric interconnects.
- Standalone configuration: `UCSManager_IP` represents the IP address for the management port on the fabric interconnect.

Procedure

- Step 1** In your web browser, type the Cisco UCS Manager GUI web link or select the bookmark in your browser.
- Step 2** If a **Security Alert** dialog box appears, click **Yes** to accept the security certificate and continue.
- Step 3** In the Cisco UCS Manager launch page, click **Launch UCS Manager**.
Depending upon the web browser you use to log in, you may be prompted to download or save the .JNLP file.

- Step 4** If Cisco UCS Manager displays a pre-login banner, review the message and click **OK** to close the dialog box.
- Step 5** If a **Security** dialog box displays, do the following:
- (Optional) Check the check box to accept all content from Cisco.
 - Click **Yes** to accept the certificate and continue.
- Step 6** In the **Login** dialog box, do the following:
- Enter your username and password.
 - If your Cisco UCS implementation includes multiple domains, select the appropriate domain from the **Domain** drop-down list.
 - Click **Login**.
-

Logging in to Cisco UCS Manager GUI through HTTP

The default HTTP web link for Cisco UCS Manager GUI is `http://UCSManager_IP`, where *UCSManager_IP* represents the IP address assigned to Cisco UCS Manager. This IP address can be one of the following:

- Cluster configuration: *UCSManager_IP* represents the virtual or cluster IP address assigned to Cisco UCS Manager. Do not use the IP addresses assigned to the management port on the fabric interconnects.
- Standalone configuration: *UCSManager_IP* represents the IP address for the management port on the fabric interconnect

Procedure

- Step 1** In your web browser, type the Cisco UCS Manager GUI web link or select the bookmark in your browser.
- Step 2** If Cisco UCS Manager displays a pre-login banner, review the message and click **OK** to close the dialog box.
- Step 3** In the Cisco UCS Manager launch page, click **Launch UCS Manager**. Depending upon the web browser you use to log in, you may be prompted to download or save the .JNLP file.
- Step 4** In the **Login** dialog box, do the following:
- Enter your username and password.
 - If your Cisco UCS implementation includes multiple domains, select the appropriate domain from the **Domain** drop-down list.
 - Click **Login**.
-

Logging Off Cisco UCS Manager GUI

Procedure

-
- Step 1** In Cisco UCS Manager GUI, click **Exit** in the upper right. Cisco UCS Manager GUI blurs on your screen to indicate that you cannot use it and displays the **Exit** dialog box.
- Step 2** From the drop-down list, select one of the following:
- **Exit** to log out and shut down Cisco UCS Manager GUI.
 - **Log Off** to log out of Cisco UCS Manager GUI and log in a different user.
- Step 3** Click **OK**.
-

Web Session Limits

Web session limits are used by Cisco UCS Manager to restrict the number of web sessions (both GUI and XML) permitted access to the system at any one time.

By default, the number of concurrent web sessions allowed by Cisco UCS Manager is set to the maximum value: 256.

Setting the Web Session Limit for Cisco UCS Manager

Procedure

-
- Step 1** In the **Navigation** pane, click the **Admin** tab.
- Step 2** On the **Admin** tab, expand **All > Communication Management > Communication Services**.
- Step 3** In the **Work** pane, click the **Communication Services** tab.
- Step 4** In the **Web Session Limits** area, complete the following fields:

Name	Description
Maximum Sessions Per User field	The maximum number of concurrent HTTP and HTTPS sessions allowed for each user. Enter an integer between 1 and 256.
Maximum Sessions field	The maximum number of concurrent HTTP and HTTPS sessions allowed for all users within the system. Enter an integer between 1 and 256.

Step 5 Click **Save Changes**.

Pre-Login Banner

With a pre-login banner, when a user logs into Cisco UCS Manager GUI, Cisco UCS Manager displays the banner text in the **Create Pre-Login Banner** dialog box and waits until the user dismisses that dialog box before it prompts for the username and password. When a user logs into Cisco UCS Manager CLI, Cisco UCS Manager displays the banner text in a dialog box and waits for the user to dismiss that dialog box before it prompts for the password. It then repeats the banner text above the copyright block that it displays to the user.

Creating the Pre-Login Banner

If the **Pre-Login Banner** area does not appear on the **Banners** tab, Cisco UCS Manager does not display a pre-login banner when users log in. If the **Pre-Login Banner** area does appear, you cannot create a second pre-login banner. You can only delete or modify the existing banner.

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
 - Step 2** On the **Admin** tab, expand **All > User Management**.
 - Step 3** Click the **User Services** node.
 - Step 4** In the **Work** pane, click the **Banners** tab.
 - Step 5** In the **Actions** area, click **Create Pre-Login Banner**.
 - Step 6** In the **Create Pre-Login Banner** dialog box, click in the text field and enter the message that you want users to see when they log in to Cisco UCS Manager.
You can enter any standard ASCII character in this field.
 - Step 7** Click **OK**.
-

Modifying the Pre-Login Banner

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
 - Step 2** On the **Admin** tab, expand **All > User Management**.
 - Step 3** Click the **User Services** node.
 - Step 4** In the **Work** pane, click the **Banners** tab.
 - Step 5** Click in the text field in the **Pre-Login Banner** area and make the necessary changes to the text. You can enter any standard ASCII character in this field.
 - Step 6** Click **Save Changes**.
-

Deleting the Pre-Login Banner

Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
 - Step 2** On the **Admin** tab, expand **All > User Management**.
 - Step 3** Click the **User Services** node.
 - Step 4** In the **Work** pane, click the **Banners** tab.
 - Step 5** In the **Actions** area, click **Delete**.
 - Step 6** If the Cisco UCS Manager GUI displays a confirmation dialog box, click **Yes**.
-

Cisco UCS Manager GUI Properties

Configuring the Cisco UCS Manager GUI Session and Log Properties

These properties determine how Cisco UCS Manager GUI reacts to session interruptions and inactivity, and configures the Cisco UCS Manager GUI Java message logging.

Procedure

- Step 1** In the toolbar, click **Options** to open the **Properties** dialog box.
- Step 2** In the right pane, click **Session**.
- Step 3** In the **Session** page, update one or more of the following fields:

Name	Description
Automatically Reconnect check box	If checked, the system tries to reconnect if communication between the GUI and the fabric interconnect is interrupted.
GUI Inactivity Time Out drop-down list	The number of minutes the system should wait before ending an inactive session. To specify that the session should not time out regardless of the length of inactivity, choose NEVER .
Log Level drop-down list	The amount of Java message logging done for Cisco UCS Manager GUI on the user's local machine. This can be one of the following: <ul style="list-style-type: none"> • All—All relevant Java information for the GUI is logged. There can be a maximum of 10 log files, each of which can be a maximum of 10 MB in size. Once the final file has been filled, Cisco UCS Manager deletes the oldest log file and starts a new one. • Off—Cisco UCS Manager does not create any Java log files for the GUI. <p>Note The log file location is determined by the Java runtime settings on the user's local machine. For more information, see the documentation for the version of Java that you are using.</p>
Max Log Size drop-down list	The maximum size, in megabytes, that Cisco UCS Manager allocates to any of the logs it saves for this Cisco UCS domain.
Reconnection Interval field	If the Automatically Reconnect check box is checked, this is the number of seconds the system waits before trying to reconnect.

Step 4 Click **OK**.

Configuring Properties for Confirmation Messages

These properties determine whether or not Cisco UCS Manager GUI displays a confirmation message after configuration changes and other operations.

Procedure

- Step 1** In the toolbar, click **Options** to open the **Properties** dialog box.
- Step 2** In the right pane, click **Confirmation Messages**.
- Step 3** In the **Confirmation Messages** page, complete the following fields:

Name	Description
Confirm Deletion check box	If checked, Cisco UCS Manager GUI requires that you confirm all delete operations.
Confirm Discard Changes check box	If checked, Cisco UCS Manager GUI requires that you confirm before the system discards any changes.
Confirm Modification/Creation check box	If checked, Cisco UCS Manager GUI requires that you confirm before the system modifies or creates objects.
Confirm Successful Operations check box	If checked, Cisco UCS Manager GUI displays a confirmation when operations are successful.

Step 4 Click **OK**.

Configuring Properties for External Applications

Cisco UCS Manager GUI uses these properties to connect with external applications, such as SSH.

Procedure

Step 1 In the toolbar, click **Options** to open the **Properties** dialog box.

Step 2 In the right pane, click **External Applications**.

Step 3 In the **External Applications** page, complete the following fields:

Name	Description
SSH field	The application to use for SSH processing.
SSH Parameters field	Any parameters to include in all SSH commands.

Step 4 Click **OK**.

Customizing the Appearance of Cisco UCS Manager GUI

These properties allow you to customize the some of the visual properties of Cisco UCS Manager GUI.

Procedure

- Step 1** In the toolbar, click **Options** to open the **Properties** dialog box.
- Step 2** In the right pane, click **Visual Enhancements**.
- Step 3** In the **Visual Enhancements** page, update one or more of the following fields:

Name	Description
Automatically Pack Table Columns check box	If checked, Cisco UCS Manager GUI automatically resizes all table columns based on their contents.
Max History Size field	The number of tabs the system should store in memory for use with the Forward and Back toolbar buttons.
Right Aligned Labels check box	If checked, all labels are right-aligned with respect to one another. Otherwise all labels are left-aligned.
Show Image while Dragging check box	If checked, when you drag an object from one place to another, the GUI displays a transparent version of that object until you drop the object in its new location.
Wizard Transition Effects check box	If checked, when you go to a new page in a wizard the first page fades out and the new page fades in. Otherwise the page changes without a visible transition.

- Step 4** Click **OK**.

Determining the Acceptable Range of Values for a Field

Some properties have a restricted range of values that you can enter. You can use this procedure to determine that acceptable range for fields in a dialog box, window, or tab. You cannot use this procedure to determine the acceptable range of values for properties listed in a table or tree.

Procedure

- Step 1** Place your cursor in the field for which you want to check the range to give focus to that field.
- Step 2** Press **Alt + Shift + R**.
Cisco UCS Manager GUI displays the acceptable range of values for a few seconds. The range disappears if you click anywhere on the screen.

Determining Where a Policy Is Used

You can use this procedure to determine which service profiles and service profile templates are associated with the selected policy.

Procedure

- Step 1** In the **Navigation** pane, click the policy whose usage you want to view.
 - Step 2** In the **Work** pane, click the **General** tab.
 - Step 3** In the **Actions** area, click **Show Policy Usage**.
Cisco UCS Manager GUI displays the **Service Profiles/Templates** dialog box that shows the associated service profiles and service profile templates.
-

Determining Where a Pool Is Used

You can use this procedure to determine which service profiles and service profile templates are associated with the selected pool.

Procedure

- Step 1** In the **Navigation** pane, click the pool whose usage you want to view.
 - Step 2** In the **Work** pane, click the **General** tab.
 - Step 3** In the **Actions** area, click **Show Pool Usage**.
Cisco UCS Manager GUI displays the **Service Profiles/Templates** dialog box that shows the associated service profiles and service profile templates.
-

Copying the XML

To assist you in developing scripts or creating applications with the XML API for Cisco UCS, Cisco UCS Manager GUI includes an option to copy the XML used to create an object in Cisco UCS Manager. This option is available on the right-click menu for most object nodes in the **Navigation** pane, such as the **Port Profiles** node or the node for a specific service profile.

Procedure

- Step 1** In the **Navigation** pane, navigate to the object for which you want to copy the XML.
 - Step 2** Right-click on that object and choose **Copy XML**.
 - Step 3** Paste the XML into an XML editor, Notepad, or another application.
-