X Commands

show xml server logging configuration

show xml server logging configuration

Syntax Description

show	Show running system information
xml	Show xmlagent logging configuration
server	xml agent server
logging	Show logging configuration and contents of logfile
configuration	Show facility logging configuration

Command Mode

- /exec

show xml server status

show xml server status [__readonly__ { operational_status <o_status> } { maximum_sessions_configured <max_session> } [{ TABLE_sessions <session_id> <user_name> <start_time> <sap_id> <timeout> <time_remaining_to_timeout> <ip_addr> }]]

Syntax Description

show	to display xml agent information
xml	xml agent
server	xml agent server
status	display xml agent information
__readonly__	(Optional)
operational_status	(Optional) run-time info about xml
o_status	(Optional) operational status of the xml
maximum_sessions_configured	(Optional) the max session configured
max_session	(Optional) max sessions number
TABLE_sessions	(Optional) all xml sessions
session_id	(Optional) one xml session id
user_name	(Optional) the xml session user name
start_time	(Optional) the xml session start time
sap_id	(Optional) the mts sap id
timeout	(Optional) inactivity timeout value
time_remaining_to_timeout	(Optional) time remaining to timeout
ip_addr	(Optional) ip address of the session

Command Mode

- /exec

show xml server status