



Auto QoS コマンド

- [auto qos classify](#) (2 ページ)
- [auto qos trust](#) (5 ページ)
- [auto qos video](#) (13 ページ)
- [auto qos voip](#) (24 ページ)
- [debug auto qos](#) (38 ページ)
- [show auto qos](#) (39 ページ)

auto qos classify

QoS ドメイン内で信頼できないデバイスの Quality of Service (QoS) の分類を自動的に設定するには、インターフェイス コンフィギュレーション モードで **auto qos classify** コマンドを使用します。デフォルト設定に戻すには、このコマンドの **no** 形式を使用します。

auto qos classify [police]
no auto qos classify [police]

構文の説明

police (任意) 信頼できないデバイスの QoS ポリシングを設定します。

コマンド デフォルト

auto-QoS 分類は、すべてのポートでディセーブルです。

コマンド モード

インターフェイス コンフィギュレーション

コマンド履歴

リリース	変更内容
Cisco IOS XE Everest 16.5.1a	このコマンドが導入されました。

使用上のガイドライン

QoS ドメイン内の信頼インターフェイスに QoS を設定する場合は、このコマンドを使用します。QoS ドメインには、ネットワーク内部、QoS の着信トラフィックを分類することのできるエッジデバイスなどが含まれます。

auto-QoS がイネーブルの場合は、入力パケットのラベルを使用して、トラフィックの分類、パケットラベルの割り当て、および入力/出力キューの設定を行います。

表 1: 出力キューに対する **auto-QoS** の設定

出力キュー	キュー番号	CoS からキューへのマッピング	キューウェイト (帯域幅)	ギガビット対応ポートのキュー (バッファ) サイズ	10/100 イーサネットポートのキュー (バッファ) サイズ
プライオリティ (シェイプド)	1	4、5	最大 100%	25%	15%
SRR 共有	2	2、3、6、7	10%	25%	25%
SRR 共有	3	0	60%	25%	40%
SRR 共有	4	1	20%	25%	20%

auto-QoS は、信頼インターフェイスと接続するように設定します。着信パケットの QoS ラベルは信頼されます。非ルーテッドポートの場合は、着信パケットの CoS 値が信頼されます。ルーテッドポートでは、着信パケットの DSCP 値が信頼されます。

auto-QoS のデフォルトを利用するには、auto-QoS をイネーブルにしてから、その他の QoS コマンドを設定する必要があります。auto-QoS をイネーブルにした後で、auto-QoS を調整できません。



(注) は、コマンドラインインターフェイス (CLI) からコマンドが入力された場合と同じように、auto-QoS によって生成されたコマンドを適用します。既存のユーザ設定では、生成されたコマンドの適用に失敗することがあります。また、生成されたコマンドで既存の設定が上書きされることもあります。これらのアクションは、警告を表示せずに実行されます。生成されたコマンドがすべて正常に適用された場合、上書きされなかったユーザ入力の設定は実行コンフィギュレーション内に残ります。上書きされたユーザ入力の設定は、現在の設定をメモリに保存せずに、をリロードすると復元できます。生成されたコマンドの適用に失敗した場合は、前の実行コンフィギュレーションが復元されます。

auto-QoS をイネーブルにした後、名前に *AutoQoS* を含むポリシー マップや集約ポリサーを変更しないでください。ポリシー マップや集約ポリサーを変更する必要がある場合、そのコピーを作成し、コピーしたポリシー マップやポリサーを変更します。生成されたポリシー マップの代わりに新しいポリシー マップを使用するには、生成したポリシー マップをインターフェイスから削除して、新しいポリシー マップを適用します。

auto-QoS がイネーブルのときに自動的に生成される QoS の設定を表示するには、auto-QoS をイネーブルにする前にデバッグをイネーブルにします。**debug auto qos** 特権 EXEC コマンドを使用すると、auto-QoS のデバッグがイネーブルになります。

auto qos classify コマンドおよび **auto qos classify police** コマンドを実行する場合、次のポリシー マップおよびクラス マップが作成され、適用されます。

ポリシー マップ (**auto qos classify police** コマンドの場合) :

- AutoQos-4.0-Classify-Police-Input-Policy
- AutoQos-4.0-Output-Policy

クラス マップ :

- AutoQos-4.0-Multimedia-Conf-Class (match-any)
- AutoQos-4.0-Bulk-Data-Class (match-any)
- AutoQos-4.0-Transaction-Class (match-any)
- AutoQos-4.0-Scavanger-Class (match-any)
- AutoQos-4.0-Signaling-Class (match-any)
- AutoQos-4.0-Default-Class (match-any)
- class-default (match-any)
- AutoQos-4.0-Output-Priority-Queue (match-any)
- AutoQos-4.0-Output-Control-Mgmt-Queue (match-any)

- AutoQos-4.0-Output-Multimedia-Conf-Queue (match-any)
- AutoQos-4.0-Output-Trans-Data-Queue (match-any)
- AutoQos-4.0-Output-Bulk-Data-Queue (match-any)
- AutoQos-4.0-Output-Scavenger-Queue (match-any)
- AutoQos-4.0-Output-Multimedia-Strm-Queue (match-any)

ポートの auto-QoS を無効にするには、**no auto qos classify** インターフェイス コンフィギュレーション コマンドを使用します。このポートに対して、**auto-QoS** によって生成されたインターフェイス コンフィギュレーション コマンドだけが削除されます。**auto-QoS** を有効にした最後のポートで、**no auto qos classify** コマンドを入力すると、**auto-QoS** によって生成されたグローバル コンフィギュレーション コマンドが残っている場合でも、**auto-QoS** は無効と見なされず（グローバルコンフィギュレーションによって影響を受ける他のポートでのトラフィックの中断を避けるため）。

例

次の例では、信頼できないデバイスの auto-QoS 分類をイネーブルにし、トラフィックをポリシングする方法を示します。

設定を確認するには、**show auto qos interface interface-id** 特権 EXEC コマンドを入力します。

auto qos trust

QoS ドメイン内の信頼インターフェイスのサービス品質 (QoS) を自動的に設定するには、インターフェイス コンフィギュレーション モードで **auto qos trust** コマンドを使用します。デフォルト設定に戻すには、このコマンドの **no** 形式を使用します。

```
auto qos trust {cos|dscp}
no auto qos trust {cos|dscp}
```

構文の説明

cos CoS パケット分類を信頼します。

dscp DSCP パケット分類を信頼します。

コマンドデフォルト

auto-QoS 信頼は、すべてのポートでディセーブルです。

コマンドモード

インターフェイス コンフィギュレーション

コマンド履歴

リリース	変更内容
Cisco IOS XE Everest 16.5.1a	このコマンドが導入されました。

使用上のガイドライン

QoS ドメイン内の信頼インターフェイスに QoS を設定する場合は、このコマンドを使用します。QoS ドメインには、ネットワーク内部、QoS の着信トラフィックを分類することのできるエッジデバイスなどが含まれます。auto-QoS がイネーブルの場合は、入力パケットのラベルを使用して、トラフィックの分類、パケット ラベルの割り当て、および入力/出力キューの設定を行います。

表 2: トラフィック タイプ、パケット ラベル、およびキュー

	VoIP データ トラフィック	VOIP コントロール トラフィック	ルーティングプロ トコ ラフィック	STP ¹ BPDU ² ト ラフィック	リアルタイムビデオ トラフィック	その他すべてのト ラフィック	
DSCP ³	46	24、26	48	56	34	-	
CoS ⁴	5	3	6	7	3	-	
CoS から出力 キューへの マッピング	4、5 (キュー 1)	2、3、6、7 (キュー 2)			0 (キュー 3)	2 (キュー 3)	0、1 (キュー 4)

¹ STP = スパニング ツリー プロトコル

² BPDU = ブリッジ プロトコル データ ユニット

- ³ DSCP = DiffServ コード ポイント
⁴ CoS = サービス クラス

表 3: 出力キューに対する *auto-QoS* の設定

出力キュー	キュー番号	CoS からキューへのマッピング	キューウェイト (帯域幅)	ギガビット対応ポートのキュー (バッファ) サイズ	10/100 イーサネットポートのキュー (バッファ) サイズ
プライオリティ (シェイプド)	1	4、5	最大 100%	25%	15%
SRR 共有	2	2、3、6、7	10%	25%	25%
SRR 共有	3	0	60%	25%	40%
SRR 共有	4	1	20%	25%	20%

(注) は、コマンドラインインターフェイス (CLI) からコマンドが入力された場合と同じように、*auto-QoS* によって生成されたコマンドを適用します。既存のユーザ設定では、生成されたコマンドの適用に失敗することがあります。また、生成されたコマンドで既存の設定が上書きされることもあります。これらのアクションは、警告を表示せずに実行されます。生成されたコマンドがすべて正常に適用された場合、上書きされなかったユーザ入力の設定は実行コンフィギュレーション内に残ります。上書きされたユーザ入力の設定は、現在の設定をメモリに保存せずに、をリロードすると復元できます。生成されたコマンドの適用に失敗した場合は、前の実行コンフィギュレーションが復元されます。

auto-QoS をイネーブルにした後、名前に *AutoQoS* を含むポリシー マップや集約ポリサーを変更しないでください。ポリシーマップや集約ポリサーを変更する必要がある場合、そのコピーを作成し、コピーしたポリシーマップやポリサーを変更します。生成されたポリシーマップの代わりに新しいポリシーマップを使用するには、生成したポリシーマップをインターフェイスから削除して、新しいポリシーマップを適用します。

auto-QoS がイネーブルのときに自動的に生成される QoS の設定を表示するには、*auto-QoS* をイネーブルにする前にデバッグをイネーブルにします。**debug auto qos** 特権 EXEC コマンドを使用すると、*auto-QoS* のデバッグがイネーブルになります。

auto qos trust cos コマンドを実行する場合、次のポリシーマップおよびクラスマップが作成され、適用されます。

ポリシー マップ :

- AutoQos-4.0-Trust-Cos-Input-Policy
- AutoQos-4.0-Output-Policy

クラス マップ :

- class-default (match-any)
- AutoQos-4.0-Output-Priority-Queue (match-any)
- AutoQos-4.0-Output-Control-Mgmt-Queue (match-any)
- AutoQos-4.0-Output-Multimedia-Conf-Queue (match-any)
- AutoQos-4.0-Output-Trans-Data-Queue (match-any)
- AutoQos-4.0-Output-Bulk-Data-Queue (match-any)
- AutoQos-4.0-Output-Scavenger-Queue (match-any)
- AutoQos-4.0-Output-Multimedia-Strm-Queue (match-any)

auto qos trust dscp コマンドを実行する場合、次のポリシーマップおよびクラス マップが作成され、適用されます。

ポリシー マップ :

- AutoQos-4.0-Trust-Dscp-Input-Policy
- AutoQos-4.0-Output-Policy

クラス マップ :

- class-default (match-any)
- AutoQos-4.0-Output-Priority-Queue (match-any)
- AutoQos-4.0-Output-Control-Mgmt-Queue (match-any)
- AutoQos-4.0-Output-Multimedia-Conf-Queue (match-any)
- AutoQos-4.0-Output-Trans-Data-Queue (match-any)
- AutoQos-4.0-Output-Bulk-Data-Queue (match-any)
- AutoQos-4.0-Output-Scavenger-Queue (match-any)
- AutoQos-4.0-Output-Multimedia-Strm-Queue (match-any)

ポートの auto-QoS をディセーブルにするには、**no auto qos trust** インターフェイス コンフィギュレーション コマンドを使用します。このポートに対して、auto-QoS によって生成されたインターフェイス コンフィギュレーション コマンドだけが削除されます。auto-QoS をイネーブルにした最後のポートで、**no auto qos trust** コマンドを入力すると、auto-QoS によって生成されたグローバル コンフィギュレーション コマンドが残っている場合でも、auto-QoS はディセーブルと見なされます (グローバル コンフィギュレーション によって影響を受ける他のポートでのトラフィックの中断を避けるため)。

例

次に、特定の CoS 分類を持つ信頼できるインターフェイスの auto-QoS を有効にする方法を示します。

```
Device(config)# interface gigabitEthernet1/0/17
Device(config-if)# auto qos trust cos
Device(config-if)# end
Device# show policy-map interface GigabitEthernet1/0/17

GigabitEthernet1/0/17

Service-policy input: AutoQos-4.0-Trust-Cos-Input-Policy

Class-map: class-default (match-any)
  0 packets
  Match: any
    0 packets, 0 bytes
    5 minute rate 0 bps
  QoS Set
    cos cos table AutoQos-4.0-Trust-Cos-Table

Service-policy output: AutoQos-4.0-Output-Policy

queue stats for all priority classes:
  Queueing
  priority level 1

  (total drops) 0
  (bytes output) 0

Class-map: AutoQos-4.0-Output-Priority-Queue (match-any)
  0 packets
  Match: dscp cs4 (32) cs5 (40) ef (46)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Match: cos 5
    0 packets, 0 bytes
    5 minute rate 0 bps
  Priority: 30% (300000 kbps), burst bytes 7500000,

  Priority Level: 1

Class-map: AutoQos-4.0-Output-Control-Mgmt-Queue (match-any)
  0 packets
  Match: dscp cs2 (16) cs3 (24) cs6 (48) cs7 (56)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Match: cos 3
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing
  queue-limit dscp 16 percent 80
  queue-limit dscp 24 percent 90
  queue-limit dscp 48 percent 100
  queue-limit dscp 56 percent 100

  (total drops) 0
  (bytes output) 0
  bandwidth remaining 10%

  queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Multimedia-Conf-Queue (match-any)
  0 packets
  Match: dscp af41 (34) af42 (36) af43 (38)
    0 packets, 0 bytes
    5 minute rate 0 bps
```



```
Match: cos 4
      0 packets, 0 bytes
      5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 10%
queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Trans-Data-Queue (match-any)
0 packets
Match: dscp af21 (18) af22 (20) af23 (22)
      0 packets, 0 bytes
      5 minute rate 0 bps
Match: cos 2
      0 packets, 0 bytes
      5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 10%
queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Bulk-Data-Queue (match-any)
0 packets
Match: dscp af11 (10) af12 (12) af13 (14)
      0 packets, 0 bytes
      5 minute rate 0 bps
Match: cos 1
      0 packets, 0 bytes
      5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 4%
queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Scavenger-Queue (match-any)
0 packets
Match: dscp cs1 (8)
      0 packets, 0 bytes
      5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 1%
queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Multimedia-Strm-Queue (match-any)
0 packets
Match: dscp af31 (26) af32 (28) af33 (30)
      0 packets, 0 bytes
      5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 10%
queue-buffers ratio 10
```

```

Class-map: class-default (match-any)
  0 packets
  Match: any
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing

  (total drops) 0
  (bytes output) 0
  bandwidth remaining 25%
  queue-buffers ratio 25

```

次に、特定の DSCP 分類を持つ信頼できるインターフェイスの auto-QoS を有効にする方法を示します。

```

Device(config)# interface GigabitEthernet1/0/18
Device(config-if)# auto qos trust dscp
Device(config-if)# end
Device#show policy-map interface GigabitEthernet1/0/18

GigabitEthernet1/0/18

  Service-policy input: AutoQos-4.0-Trust-Dscp-Input-Policy

    Class-map: class-default (match-any)
      0 packets
      Match: any
        0 packets, 0 bytes
        5 minute rate 0 bps
      QoS Set
        dscp dscp table AutoQos-4.0-Trust-Dscp-Table

  Service-policy output: AutoQos-4.0-Output-Policy

  queue stats for all priority classes:
    Queueing
    priority level 1

    (total drops) 0
    (bytes output) 0

  Class-map: AutoQos-4.0-Output-Priority-Queue (match-any)
    0 packets
    Match: dscp cs4 (32) cs5 (40) ef (46)
      0 packets, 0 bytes
      5 minute rate 0 bps
    Match: cos 5
      0 packets, 0 bytes
      5 minute rate 0 bps
    Priority: 30% (300000 kbps), burst bytes 7500000,

    Priority Level: 1

  Class-map: AutoQos-4.0-Output-Control-Mgmt-Queue (match-any)
    0 packets
    Match: dscp cs2 (16) cs3 (24) cs6 (48) cs7 (56)
      0 packets, 0 bytes
      5 minute rate 0 bps
    Match: cos 3
      0 packets, 0 bytes
      5 minute rate 0 bps

```

```
Queueing
queue-limit dscp 16 percent 80
queue-limit dscp 24 percent 90
queue-limit dscp 48 percent 100
queue-limit dscp 56 percent 100

(total drops) 0
(bytes output) 0
bandwidth remaining 10%

queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Multimedia-Conf-Queue (match-any)
 0 packets
Match: dscp af41 (34) af42 (36) af43 (38)
 0 packets, 0 bytes
 5 minute rate 0 bps
Match: cos 4
 0 packets, 0 bytes
 5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 10%
queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Trans-Data-Queue (match-any)
 0 packets
Match: dscp af21 (18) af22 (20) af23 (22)
 0 packets, 0 bytes
 5 minute rate 0 bps
Match: cos 2
 0 packets, 0 bytes
 5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 10%
queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Bulk-Data-Queue (match-any)
 0 packets
Match: dscp af11 (10) af12 (12) af13 (14)
 0 packets, 0 bytes
 5 minute rate 0 bps
Match: cos 1
 0 packets, 0 bytes
 5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 4%
queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Scavenger-Queue (match-any)
 0 packets
Match: dscp cs1 (8)
 0 packets, 0 bytes
 5 minute rate 0 bps
Queueing
```

```
(total drops) 0
(bytes output) 0
bandwidth remaining 1%
queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Multimedia-Strm-Queue (match-any)
 0 packets
Match: dscp af31 (26) af32 (28) af33 (30)
 0 packets, 0 bytes
 5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 10%
queue-buffers ratio 10

Class-map: class-default (match-any)
 0 packets
Match: any
 0 packets, 0 bytes
 5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 25%
queue-buffers ratio 25
```

設定を確認するには、**show auto qos interface *interface-id*** 特権 EXEC コマンドを入力します。

auto qos video

QoS ドメイン内のビデオのサービス品質 (QoS) を自動的に設定するには、インターフェイス コンフィギュレーション モードで **auto qos video** コマンドを使用します。デフォルト設定に戻すには、このコマンドの **no** 形式を使用します。

```
auto qos video {cts | ip-camera | media-player}
no auto qos video {cts | ip-camera | media-player}
```

構文の説明

cts	Cisco TelePresence System に接続されるポートを指定し、自動的にビデオの QoS を設定します。
ip-camera	Cisco IP カメラに接続されるポートを指定し、自動的にビデオの QoS を設定します。
media-player	Cisco Digital Media Player に接続されるポートを指定し、自動的にビデオの QoS を設定します。

コマンド デフォルト

Auto-QoS ビデオは、ポート上でディセーブルに設定されています。

コマンド モード

インターフェイス コンフィギュレーション

コマンド履歴

リリース	変更内容
Cisco IOS XE Everest 16.5.1a	このコマンドが導入されました。

使用上のガイドライン

QoS ドメイン内のビデオトラフィックに適切な QoS を設定するには、このコマンドを使用します。QoS ドメインには、ネットワーク内部、QoS の着信トラフィックを分類することのできるエッジデバイスなどが含まれます。auto-QoS がイネーブルの場合は、入力パケットのラベルを使用して、トラフィックの分類、パケットラベルの割り当て、および入力/出力キューの設定を行います。詳細については、この項の最後にあるキューテーブルを参照してください。

auto-QoS は、Cisco TelePresence システム、Cisco IP カメラ、または Cisco Digital Media Player へのビデオ接続用に設定します。

auto-QoS のデフォルトを利用するには、auto-QoS をイネーブルにしてから、その他の QoS コマンドを設定する必要があります。auto-QoS をイネーブルにした後で、auto-QoS を調整できます。

は、コマンドラインインターフェイス (CLI) からコマンドが入力された場合と同じように、auto-QoS によって生成されたコマンドを適用します。既存のユーザ設定では、生成されたコマンドの適用に失敗することがあります。また、生成されたコマンドで既存の設定が上書きされることもあります。これらのアクションは、警告を表示せずに実行されます。生成されたコマンドがすべて正常に適用された場合、上書きされなかったユーザ入力の設定は実行コンフィ

ギュレーション内に残ります。上書きされたユーザ入力の設定は、現在の設定をメモリに保存せずに、をリロードすると復元できます。生成されたコマンドの適用に失敗した場合は、前の実行コンフィギュレーションが復元されます。

これが **auto-QoS** をイネーブルにする最初のポートの場合は、**auto-QoS** によって生成されたグローバル コンフィギュレーション コマンドに続いてインターフェイス コンフィギュレーション コマンドが実行されます。別のポートで **auto-QoS** をイネーブルにすると、そのポートに対して **auto-QoS** によって生成されたインターフェイス コンフィギュレーション コマンドだけが実行されます。

auto-QoS をイネーブルにした後、名前に *AutoQoS* を含むポリシー マップや集約ポリサーを変更しないでください。ポリシー マップや集約ポリサーを変更する必要がある場合、そのコピーを作成し、コピーしたポリシー マップやポリサーを変更します。生成されたポリシー マップの代わりに新しいポリシー マップを使用するには、生成したポリシー マップをインターフェイスから削除して、新しいポリシー マップを適用します。

auto-QoS がイネーブルのときに自動的に生成される QoS の設定を表示するには、**auto-QoS** をイネーブルにする前にデバッグをイネーブルにします。**debug auto qos** 特権 EXEC コマンドを使用すると、**auto-QoS** のデバッグがイネーブルになります。

auto qos video cts コマンドを実行する場合、次のポリシーマップおよびクラス マップが作成され、適用されます。

ポリシー マップ :

- AutoQos-4.0-Trust-Cos-Input-Policy
- AutoQos-4.0-Output-Policy

クラス マップ

- class-default (match-any)
- AutoQos-4.0-Output-Priority-Queue (match-any)
- AutoQos-4.0-Output-Control-Mgmt-Queue (match-any)
- AutoQos-4.0-Output-Multimedia-Conf-Queue (match-any)
- AutoQos-4.0-Output-Trans-Data-Queue (match-any)
- AutoQos-4.0-Output-Bulk-Data-Queue (match-any)
- AutoQos-4.0-Output-Scavenger-Queue (match-any)
- AutoQos-4.0-Output-Multimedia-Strm-Queue (match-any)

auto qos video ip-camera コマンドを実行する場合、次のポリシーマップおよびクラス マップが作成され、適用されます。

ポリシー マップ :

- AutoQos-4.0-Trust-Dscp-Input-Policy
- AutoQos-4.0-Output-Policy

クラス マップ :

- class-default (match-any)
- AutoQos-4.0-Output-Priority-Queue (match-any)
- AutoQos-4.0-Output-Control-Mgmt-Queue (match-any)
- AutoQos-4.0-Output-Multimedia-Conf-Queue (match-any)
- AutoQos-4.0-Output-Trans-Data-Queue (match-any)
- AutoQos-4.0-Output-Bulk-Data-Queue (match-any)
- AutoQos-4.0-Output-Scavenger-Queue (match-any)
- AutoQos-4.0-Output-Multimedia-Strm-Queue (match-any)

auto qos video media-player コマンドを実行する場合、次のポリシーマップおよびクラス マップが作成され、適用されます。

ポリシー マップ :

- AutoQos-4.0-Trust-Dscp-Input-Policy
- AutoQos-4.0-Output-Policy

クラス マップ :

- class-default (match-any)
- AutoQos-4.0-Output-Priority-Queue (match-any)
- AutoQos-4.0-Output-Control-Mgmt-Queue (match-any)
- AutoQos-4.0-Output-Multimedia-Conf-Queue (match-any)
- AutoQos-4.0-Output-Trans-Data-Queue (match-any)
- AutoQos-4.0-Output-Bulk-Data-Queue (match-any)
- AutoQos-4.0-Output-Scavenger-Queue (match-any)
- AutoQos-4.0-Output-Multimedia-Strm-Queue (match-any)

ポートの **auto-QoS** をディセーブルにするには、**no auto qos video** インターフェイス コンフィギュレーション コマンドを使用します。このポートに対して、**auto-QoS** によって生成されたインターフェイス コンフィギュレーション コマンドだけが削除されます。**auto-QoS** を有効にした最後のポートで、**no auto qos video** コマンドを入力すると、**auto-QoS** によって生成されたグローバル コンフィギュレーション コマンドが残っている場合でも、**auto-QoS** は無効と見なされます (グローバルコンフィギュレーションによって影響を受ける他のポートでのトラフィックの中断を避けるため)。

表 4: トラフィック タイプ、パケットラベル、およびキュー

	VoIP データ トラフィック	VOIP コントロール トラフィック	ルーティング プロトコル トラフィック	STP ⁵ BPD ⁶ ト ラフィック	リアルタイム ビデオ トラフィック	その他すべての トラフィック	
DSCP ⁷	46	24、26	48	56	34	-	
CoS ⁸	5	3	6	7	3	-	
CoS から出力 キューへのマッ ピング	4、5 (キュー 1)	2、3、6、 7 (キュー 2)	2、3、 6、7 (キュー 2)	2、3、6、7 (キュー 2)	0 (キュー 3)	2 (キュー 3)	0、1 (キュー 4)

⁵ STP = スパニング ツリー プロトコル

⁶ BPD⁶ = ブリッジ プロトコル データ ユニット

⁷ DSCP = DiffServ コード ポイント

⁸ CoS = サービス クラス

表 5: 出力キューに対する *auto-QoS* の設定

出力キュー	キュー 番号	CoS から キューへの マッピング	キュー ウェイ ト (帯域幅)	ギガビット対応 ポートのキュー (バッファ) サ イズ	10/100 イーサネッ トポートの キュー (バッ ファ) サイズ
プライオリティ (シェイプド)	1	4、5	最大 100%	25%	15%
SRR 共有	2	2、3、6、7	10%	25%	25%
SRR 共有	3	0	60%	25%	40%
SRR 共有	4	1	20%	25%	20%

例

次に、**auto qos video cts** コマンドと、適用されるポリシーとクラス マップの例を示します。

```
Device(config)# interface gigabitEthernet1/0/12
Device(config-if)# auto qos video cts
Device(config-if)# end
Device# show policy-map interface gigabitEthernet1/0/12

GigabitEthernet1/0/12
```


Service-policy input: AutoQos-4.0-Trust-Cos-Input-Policy

```
Class-map: class-default (match-any)
  0 packets
  Match: any
    0 packets, 0 bytes
    5 minute rate 0 bps
  QoS Set
    cos cos table AutoQos-4.0-Trust-Cos-Table
```

Service-policy output: AutoQos-4.0-Output-Policy

queue stats for all priority classes:

```
Queueing
priority level 1
```

```
(total drops) 0
(bytes output) 0
```

Class-map: AutoQos-4.0-Output-Priority-Queue (match-any)

```
  0 packets
  Match: dscp cs4 (32) cs5 (40) ef (46)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Match: cos 5
    0 packets, 0 bytes
    5 minute rate 0 bps
  Priority: 30% (300000 kbps), burst bytes 7500000,
```

```
  Priority Level: 1
```

Class-map: AutoQos-4.0-Output-Control-Mgmt-Queue (match-any)

```
  0 packets
  Match: dscp cs2 (16) cs3 (24) cs6 (48) cs7 (56)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Match: cos 3
    0 packets, 0 bytes
    5 minute rate 0 bps
```

```
Queueing
queue-limit dscp 16 percent 80
queue-limit dscp 24 percent 90
queue-limit dscp 48 percent 100
queue-limit dscp 56 percent 100
```

```
(total drops) 0
(bytes output) 0
bandwidth remaining 10%
```

```
queue-buffers ratio 10
```

Class-map: AutoQos-4.0-Output-Multimedia-Conf-Queue (match-any)

```
  0 packets
  Match: dscp af41 (34) af42 (36) af43 (38)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Match: cos 4
    0 packets, 0 bytes
    5 minute rate 0 bps
```

```
Queueing
```

```
(total drops) 0
(bytes output) 0
```

```
bandwidth remaining 10%
queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Trans-Data-Queue (match-any)
  0 packets
  Match: dscp af21 (18) af22 (20) af23 (22)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Match: cos 2
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing

  (total drops) 0
  (bytes output) 0
  bandwidth remaining 10%
  queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Bulk-Data-Queue (match-any)
  0 packets
  Match: dscp af11 (10) af12 (12) af13 (14)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Match: cos 1
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing

  (total drops) 0
  (bytes output) 0
  bandwidth remaining 4%
  queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Scavenger-Queue (match-any)
  0 packets
  Match: dscp cs1 (8)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing

  (total drops) 0
  (bytes output) 0
  bandwidth remaining 1%
  queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Multimedia-Strm-Queue (match-any)
  0 packets
  Match: dscp af31 (26) af32 (28) af33 (30)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing

  (total drops) 0
  (bytes output) 0
  bandwidth remaining 10%
  queue-buffers ratio 10

Class-map: class-default (match-any)
  0 packets
  Match: any
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing
```

```
(total drops) 0
(bytes output) 0
bandwidth remaining 25%
queue-buffers ratio 25
```

次に、**auto qos video ip-camera** コマンドと、適用されるポリシーとクラス マップの例を示します。

```
Device(config)# interface GigabitEthernet1/0/9
Device(config-if)# auto qos video ip-camera
Device(config-if)# end
Device# show policy-map interface GigabitEthernet1/0/9

GigabitEthernet1/0/9

Service-policy input: AutoQos-4.0-Trust-Dscp-Input-Policy

Class-map: class-default (match-any)
  0 packets
  Match: any
    0 packets, 0 bytes
    5 minute rate 0 bps
  QoS Set
    dscp dscp table AutoQos-4.0-Trust-Dscp-Table

Service-policy output: AutoQos-4.0-Output-Policy

queue stats for all priority classes:
  Queueing
  priority level 1

  (total drops) 0
  (bytes output) 0

Class-map: AutoQos-4.0-Output-Priority-Queue (match-any)
  0 packets
  Match: dscp cs4 (32) cs5 (40) ef (46)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Match: cos 5
    0 packets, 0 bytes
    5 minute rate 0 bps
  Priority: 30% (300000 kbps), burst bytes 7500000,

  Priority Level: 1

Class-map: AutoQos-4.0-Output-Control-Mgmt-Queue (match-any)
  0 packets
  Match: dscp cs2 (16) cs3 (24) cs6 (48) cs7 (56)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Match: cos 3
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing
  queue-limit dscp 16 percent 80
  queue-limit dscp 24 percent 90
  queue-limit dscp 48 percent 100
  queue-limit dscp 56 percent 100

  (total drops) 0
```

```
(bytes output) 0
bandwidth remaining 10%

queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Multimedia-Conf-Queue (match-any)
 0 packets
Match: dscp af41 (34) af42 (36) af43 (38)
 0 packets, 0 bytes
 5 minute rate 0 bps
Match: cos 4
 0 packets, 0 bytes
 5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 10%
queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Trans-Data-Queue (match-any)
 0 packets
Match: dscp af21 (18) af22 (20) af23 (22)
 0 packets, 0 bytes
 5 minute rate 0 bps
Match: cos 2
 0 packets, 0 bytes
 5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 10%
queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Bulk-Data-Queue (match-any)
 0 packets
Match: dscp af11 (10) af12 (12) af13 (14)
 0 packets, 0 bytes
 5 minute rate 0 bps
Match: cos 1
 0 packets, 0 bytes
 5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 4%
queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Scavenger-Queue (match-any)
 0 packets
Match: dscp cs1 (8)
 0 packets, 0 bytes
 5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 1%
queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Multimedia-Strm-Queue (match-any)
 0 packets
```

```

Match: dscp af31 (26) af32 (28) af33 (30)
      0 packets, 0 bytes
      5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 10%
queue-buffers ratio 10

Class-map: class-default (match-any)
  0 packets
Match: any
  0 packets, 0 bytes
  5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 25%
queue-buffers ratio 25

```

次の例は、**auto qos video media-player** コマンドと、適用されるポリシーとクラスマップを示しています。

```

Device(config)# interface GigabitEthernet1/0/7
Device(config-if)# auto qos video media-player
Device(config-if)# end
Device# show policy-map interface GigabitEthernet1/0/7

GigabitEthernet1/0/7

Service-policy input: AutoQos-4.0-Trust-Dscp-Input-Policy

Class-map: class-default (match-any)
  0 packets
Match: any
  0 packets, 0 bytes
  5 minute rate 0 bps
QoS Set
  dscp dscp table AutoQos-4.0-Trust-Dscp-Table

Service-policy output: AutoQos-4.0-Output-Policy

queue stats for all priority classes:
Queueing
priority level 1

(total drops) 0
(bytes output) 0

Class-map: AutoQos-4.0-Output-Priority-Queue (match-any)
  0 packets
Match: dscp cs4 (32) cs5 (40) ef (46)
  0 packets, 0 bytes
  5 minute rate 0 bps
Match: cos 5
  0 packets, 0 bytes
  5 minute rate 0 bps
Priority: 30% (300000 kbps), burst bytes 7500000,

```

```
Priority Level: 1

Class-map: AutoQos-4.0-Output-Control-Mgmt-Queue (match-any)
  0 packets
  Match: dscp cs2 (16) cs3 (24) cs6 (48) cs7 (56)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Match: cos 3
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing
  queue-limit dscp 16 percent 80
  queue-limit dscp 24 percent 90
  queue-limit dscp 48 percent 100
  queue-limit dscp 56 percent 100

  (total drops) 0
  (bytes output) 0
  bandwidth remaining 10%

  queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Multimedia-Conf-Queue (match-any)
  0 packets
  Match: dscp af41 (34) af42 (36) af43 (38)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Match: cos 4
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing

  (total drops) 0
  (bytes output) 0
  bandwidth remaining 10%
  queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Trans-Data-Queue (match-any)
  0 packets
  Match: dscp af21 (18) af22 (20) af23 (22)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Match: cos 2
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing

  (total drops) 0
  (bytes output) 0
  bandwidth remaining 10%
  queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Bulk-Data-Queue (match-any)
  0 packets
  Match: dscp af11 (10) af12 (12) af13 (14)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Match: cos 1
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing

  (total drops) 0
  (bytes output) 0
```

```
bandwidth remaining 4%
queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Scavenger-Queue (match-any)
 0 packets
Match: dscp cs1 (8)
  0 packets, 0 bytes
  5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 1%
queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Multimedia-Strm-Queue (match-any)
 0 packets
Match: dscp af31 (26) af32 (28) af33 (30)
  0 packets, 0 bytes
  5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 10%
queue-buffers ratio 10

Class-map: class-default (match-any)
 0 packets
Match: any
  0 packets, 0 bytes
  5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 25%
queue-buffers ratio 25
```

設定を確認するには、**show auto qos video interface *interface-id*** 特権 EXEC コマンドを入力します。

auto qos voip

QoS ドメイン内の Voice over IP (VoIP) の Quality of Service (QoS) を自動的に設定するには、インターフェイス コンフィギュレーション モードで **auto qos voip** コマンドを使用します。デフォルト設定に戻すには、このコマンドの **no** 形式を使用します。

```
auto qos voip {cisco-phone | cisco-softphone | trust}
no auto qos voip {cisco-phone | cisco-softphone | trust}
```

構文の説明

cisco-phone	Cisco IP Phone に接続されるポートを指定し、自動的にビデオの VoIP を設定します。着信パケットの QoS ラベルが信頼されるのは、IP Phone が検知される場合に限ります。
cisco-softphone	Cisco SoftPhone が動作している装置に接続されるポートを指定し、自動的にビデオの VoIP を設定します。
trust	信頼できるに接続されるポートを指定し、自動的にビデオの VoIP を設定します。着信パケットの QoS ラベルは信頼されます。非ルーテッドポートの場合は、着信パケットの CoS 値が信頼されます。ルーテッドポートでは、着信パケットの DSCP 値が信頼されます。

コマンド デフォルト

auto-QoS は、すべてのポートでディセーブルです。

auto-QoS がイネーブルの場合は、入力パケットのラベルを使用して、トラフィックの分類、パケット ラベルの割り当て、および入力/出力キューの設定を行います。

コマンド デフォルト

インターフェイス コンフィギュレーション

コマンド履歴

リリース	変更内容
Cisco IOS XE Everest 16.5.1a	このコマンドが導入されました。

使用上のガイドライン

QoS ドメイン内の VoIP トラフィックに適切な QoS を設定する場合は、このコマンドを使用します。QoS ドメインには、、ネットワーク内部、QoS の着信トラフィックを分類することのできるエッジデバイスなどが含まれます。

Auto-QoS は、とルーテッドポート上の Cisco IP Phone を使用した VoIP と、Cisco SoftPhone アプリケーションが動作する装置に対してを設定します。これらのリリースは Cisco IP SoftPhone バージョン 1.3(3)以降だけをサポートします。接続される装置は Cisco Call Manager バージョン 4 以降を使用する必要があります。

auto-QoS のデフォルトを利用するには、auto-QoS をイネーブルにしてから、その他の QoS コマンドを設定する必要があります。auto-QoS をイネーブルにした後で、auto-QoS を調整できます。



(注) は、コマンドラインインターフェイス (CLI) からコマンドが入力された場合と同じように、**auto-QoS**によって生成されたコマンドを適用します。既存のユーザ設定では、生成されたコマンドの適用に失敗することがあります。また、生成されたコマンドで既存の設定が上書きされることもあります。これらのアクションは、警告を表示せずに実行されます。生成されたコマンドがすべて正常に適用された場合、上書きされなかったユーザ入力の設定は実行コンフィギュレーション内に残ります。上書きされたユーザ入力の設定は、現在の設定をメモリに保存せずに、をリロードすると復元できます。生成されたコマンドの適用に失敗した場合は、前の実行コンフィギュレーションが復元されます。

これが **auto-QoS** をイネーブルにする最初のポートの場合は、**auto-QoS** によって生成されたグローバル コンフィギュレーション コマンドに続いてインターフェイス コンフィギュレーション コマンドが実行されます。別のポートで **auto-QoS** をイネーブルにすると、そのポートに対して **auto-QoS** によって生成されたインターフェイス コンフィギュレーション コマンドだけが実行されます。

Cisco IP Phone に接続されたネットワーク エッジのポートで **auto qos voip cisco-phone** インターフェイス コンフィギュレーション コマンドを入力すると、により信頼境界の機能が有効になります。は、Cisco Discovery Protocol (CDP) を使用して、Cisco IP Phone の存在を検出します。Cisco IP Phone が検出されると、ポートの入力分類は、パケットで受け取った QoS ラベルを信頼するように設定されます。また、はポリシングを使用してパケットがプロファイル内か、プロファイル外かを判断し、パケットに対するアクションを指定します。パケットに 24、26、または 46 という DSCP 値がない場合、またはパケットがプロファイル外にある場合、は DSCP 値を 0 に変更します。Cisco IP Phone が存在しない場合、ポートの入力分類は、パケットで受け取った QoS ラベルを信頼しないように設定されます。ポリシングがポリシーマップ分類と一致したトラフィックに適用された後で、が信頼境界の機能をイネーブルにします。

- Cisco SoftPhone が動作するデバイスに接続されたネットワーク エッジにあるポートに **auto qos voip cisco-softphone** インターフェイス コンフィギュレーション コマンドを入力した場合、はポリシングを使用してパケットがプロファイル内かプロファイル外かを判断し、パケットに対するアクションを指定します。パケットに 24、26、または 46 という DSCP 値がない場合、またはパケットがプロファイル外にある場合、は DSCP 値を 0 に変更します。
- ネットワーク内部に接続されたポート上で **auto qos voip trust** インターフェイス コンフィギュレーション コマンドを入力すると、非ルーテッドポートの場合は入力パケット内の CoS 値、ルーテッドポートの場合は入力パケット内の DSCP 値が信頼されます (前提条件は、トラフィックがすでに他のエッジデバイスによって分類されていることです)。

スタティック ポート、ダイナミック アクセス ポート、音声 VLAN アクセス ポート、および トランク ポートで **auto-QoS** をイネーブルにすることができます。ルーテッドポートで Cisco IP Phone の自動 QoS を有効にすると、スタティック IP アドレスを IP Phone に割り当てます。



(注) Cisco SoftPhone が稼働するデバイスがまたはルーテッドポートに接続されている場合、はポートごとに 1 つの Cisco SoftPhone アプリケーションだけをサポートします。

auto-QoS をイネーブルにした後、名前に *AutoQoS* を含むポリシー マップや集約ポリサーを変更しないでください。ポリシーマップや集約ポリサーを変更する必要がある場合、そのコピーを作成し、コピーしたポリシー マップやポリサーを変更します。生成されたポリシー マップの代わりに新しいポリシー マップを使用するには、生成したポリシー マップをインターフェイスから削除して、新しいポリシー マップを適用します。

auto-QoS がイネーブルのときに自動的に生成される QoS の設定を表示するには、auto-QoS をイネーブルにする前にデバッグをイネーブルにします。 **debug auto qos** 特権 EXEC コマンドを使用すると、auto-QoS のデバッグがイネーブルになります。

auto qos voip trust コマンドを実行する場合、次のポリシーマップおよびクラス マップが作成され、適用されます。

ポリシー マップ :

- AutoQos-4.0-Trust-Cos-Input-Policy
- AutoQos-4.0-Output-Policy

クラス マップ :

- class-default (match-any)
- AutoQos-4.0-Output-Priority-Queue (match-any)
- AutoQos-4.0-Output-Control-Mgmt-Queue (match-any)
- AutoQos-4.0-Output-Multimedia-Conf-Queue (match-any)
- AutoQos-4.0-Output-Trans-Data-Queue (match-any)
- AutoQos-4.0-Output-Bulk-Data-Queue (match-any)
- AutoQos-4.0-Output-Scavenger-Queue (match-any)
- AutoQos-4.0-Output-Multimedia-Strm-Queue (match-any)

auto qos voip cisco-softphone コマンドを実行する場合、次のポリシーマップおよびクラス マップが作成され、適用されます。

ポリシー マップ :

- AutoQos-4.0-CiscoSoftPhone-Input-Policy
- AutoQos-4.0-Output-Policy

クラス マップ :

- AutoQos-4.0-Voip-Data-Class (match-any)

- AutoQos-4.0-Voip-Signal-Class (match-any)
- AutoQos-4.0-Multimedia-Conf-Class (match-any)
- AutoQos-4.0-Bulk-Data-Class (match-any)
- AutoQos-4.0-Transaction-Class (match-any)
- AutoQos-4.0-Scavenger-Class (match-any)
- AutoQos-4.0-Signaling-Class (match-any)
- AutoQos-4.0-Default-Class (match-any)
- class-default (match-any)
- AutoQos-4.0-Output-Priority-Queue (match-any)
- AutoQos-4.0-Output-Control-Mgmt-Queue (match-any)
- AutoQos-4.0-Output-Multimedia-Conf-Queue (match-any)
- AutoQos-4.0-Output-Trans-Data-Queue (match-any)
- AutoQos-4.0-Output-Bulk-Data-Queue (match-any)
- AutoQos-4.0-Output-Scavenger-Queue (match-any)
- AutoQos-4.0-Output-Multimedia-Strm-Queue (match-any)

auto qos voip cisco-phone コマンドを実行する場合、次のポリシーマップおよびクラス マップが作成され、適用されます。

ポリシー マップ :

- service-policy input AutoQos-4.0-CiscoPhone-Input-Policy
- service-policy output AutoQos-4.0-Output-Policy

クラス マップ :

- class AutoQos-4.0-Voip-Data-CiscoPhone-Class
- class AutoQos-4.0-Voip-Signal-CiscoPhone-Class
- class AutoQos-4.0-Default-Class

ポートの auto-QoS をディセーブルにするには、**no auto qos voip** インターフェイス コンフィギュレーション コマンドを使用します。このポートに対して、auto-QoS によって生成されたインターフェイス コンフィギュレーション コマンドだけが削除されます。auto-QoS をイネーブルにした最後のポートで、**no auto qos voip** コマンドを入力すると、auto-QoS によって生成されたグローバル コンフィギュレーション コマンドが残っている場合でも、auto-QoS はディセーブルと見なされます (グローバル コンフィギュレーション によって影響を受ける他のポートでのトラフィックの中断を避けるため)。

は、このテーブルの設定にしたがってポートの出力キューを設定します。

表 6: 出力キューに対する *auto-QoS* の設定

出力キュー	キュー番号	CoS からキューへのマッピング	キューウェイト (帯域幅)	ギガビット対応ポートのキュー (バッファ) サイズ	10/100イーサネットポートのキュー (バッファ) サイズ
プライオリティ (シェイプド)	1	4、5	最大 100%	25%	15%
SRR 共有	2	2、3、6、7	10%	25%	25%
SRR 共有	3	0	60%	25%	40%
SRR 共有	4	1	20%	25%	20%

例

次に、**auto qos voip trust** コマンドと、適用されるポリシーとクラスマップの例を示します。

```
Device(config)# interface gigabitEthernet1/0/31
Device(config-if)# auto qos voip trust
Device(config-if)# end
Device# show policy-map interface GigabitEthernet1/0/31

GigabitEthernet1/0/31

  Service-policy input: AutoQos-4.0-Trust-Cos-Input-Policy

    Class-map: class-default (match-any)
      0 packets
      Match: any
        0 packets, 0 bytes
        5 minute rate 0 bps
      QoS Set
        cos cos table AutoQos-4.0-Trust-Cos-Table

  Service-policy output: AutoQos-4.0-Output-Policy

    queue stats for all priority classes:
      Queueing
        priority level 1

      (total drops) 0
      (bytes output) 0

    Class-map: AutoQos-4.0-Output-Priority-Queue (match-any)
      0 packets
      Match: dscp cs4 (32) cs5 (40) ef (46)
        0 packets, 0 bytes
        5 minute rate 0 bps
      Match: cos 5
        0 packets, 0 bytes
        5 minute rate 0 bps
      Priority: 30% (300000 kbps), burst bytes 7500000,
```

```
Priority Level: 1

Class-map: AutoQos-4.0-Output-Control-Mgmt-Queue (match-any)
  0 packets
  Match: dscp cs2 (16) cs3 (24) cs6 (48) cs7 (56)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Match: cos 3
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing
  queue-limit dscp 16 percent 80
  queue-limit dscp 24 percent 90
  queue-limit dscp 48 percent 100
  queue-limit dscp 56 percent 100

  (total drops) 0
  (bytes output) 0
  bandwidth remaining 10%

  queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Multimedia-Conf-Queue (match-any)
  0 packets
  Match: dscp af41 (34) af42 (36) af43 (38)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Match: cos 4
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing

  (total drops) 0
  (bytes output) 0
  bandwidth remaining 10%
  queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Trans-Data-Queue (match-any)
  0 packets
  Match: dscp af21 (18) af22 (20) af23 (22)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Match: cos 2
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing

  (total drops) 0
  (bytes output) 0
  bandwidth remaining 10%
  queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Bulk-Data-Queue (match-any)
  0 packets
  Match: dscp af11 (10) af12 (12) af13 (14)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Match: cos 1
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing

  (total drops) 0
```

```

(bytes output) 0
bandwidth remaining 4%
queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Scavenger-Queue (match-any)
 0 packets
Match: dscp cs1 (8)
 0 packets, 0 bytes
 5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 1%
queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Multimedia-Strm-Queue (match-any)
 0 packets
Match: dscp af31 (26) af32 (28) af33 (30)
 0 packets, 0 bytes
 5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 10%
queue-buffers ratio 10

Class-map: class-default (match-any)
 0 packets
Match: any
 0 packets, 0 bytes
 5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 25%
queue-buffers ratio 25

```

次に、**auto qos voip cisco-phone** コマンドと、適用されるポリシーとクラスマップの例を示します。

```

Device(config)# interface gigabitEthernet1/0/5
Device(config-if)# auto qos voip cisco-phone
Device(config-if)# end
Device# show policy-map interface gigabitEthernet1/0/5

GigabitEthernet1/0/5

Service-policy input: AutoQos-4.0-CiscoPhone-Input-Policy

Class-map: AutoQos-4.0-Voip-Data-CiscoPhone-Class (match-any)
 0 packets
Match: cos 5
 0 packets, 0 bytes
 5 minute rate 0 bps
QoS Set
 dscp ef
police:
  cir 128000 bps, bc 8000 bytes
 conformed 0 bytes; actions:

```

```
        transmit
    exceeded 0 bytes; actions:
        set-dscp-transmit dscp table policed-dscp
    conformed 0000 bps, exceed 0000 bps

Class-map: AutoQos-4.0-Voip-Signal-CiscoPhone-Class (match-any)
  0 packets
  Match: cos 3
    0 packets, 0 bytes
    5 minute rate 0 bps
  QoS Set
    dscp cs3
  police:
    cir 32000 bps, bc 8000 bytes
    conformed 0 bytes; actions:
        transmit
    exceeded 0 bytes; actions:
        set-dscp-transmit dscp table policed-dscp
    conformed 0000 bps, exceed 0000 bps

Class-map: AutoQos-4.0-Default-Class (match-any)
  0 packets
  Match: access-group name AutoQos-4.0-Acl-Default
    0 packets, 0 bytes
    5 minute rate 0 bps
  QoS Set
    dscp default

Class-map: class-default (match-any)
  0 packets
  Match: any
    0 packets, 0 bytes
    5 minute rate 0 bps

Service-policy output: AutoQos-4.0-Output-Policy

queue stats for all priority classes:
  Queueing
  priority level 1

  (total drops) 0
  (bytes output) 0

Class-map: AutoQos-4.0-Output-Priority-Queue (match-any)
  0 packets
  Match: dscp cs4 (32) cs5 (40) ef (46)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Match: cos 5
    0 packets, 0 bytes
    5 minute rate 0 bps
  Priority: 30% (300000 kbps), burst bytes 7500000,

  Priority Level: 1

Class-map: AutoQos-4.0-Output-Control-Mgmt-Queue (match-any)
  0 packets
  Match: dscp cs2 (16) cs3 (24) cs6 (48) cs7 (56)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Match: cos 3
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing
```

```
queue-limit dscp 16 percent 80
queue-limit dscp 24 percent 90
queue-limit dscp 48 percent 100
queue-limit dscp 56 percent 100

(total drops) 0
(bytes output) 0
bandwidth remaining 10%

queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Multimedia-Conf-Queue (match-any)
 0 packets
Match: dscp af41 (34) af42 (36) af43 (38)
 0 packets, 0 bytes
 5 minute rate 0 bps
Match: cos 4
 0 packets, 0 bytes
 5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 10%
queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Trans-Data-Queue (match-any)
 0 packets
Match: dscp af21 (18) af22 (20) af23 (22)
 0 packets, 0 bytes
 5 minute rate 0 bps
Match: cos 2
 0 packets, 0 bytes
 5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 10%
queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Bulk-Data-Queue (match-any)
 0 packets
Match: dscp af11 (10) af12 (12) af13 (14)
 0 packets, 0 bytes
 5 minute rate 0 bps
Match: cos 1
 0 packets, 0 bytes
 5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 4%
queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Scavenger-Queue (match-any)
 0 packets
Match: dscp cs1 (8)
 0 packets, 0 bytes
 5 minute rate 0 bps
Queueing

(total drops) 0
```



```

(bytes output) 0
bandwidth remaining 1%
queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Multimedia-Strm-Queue (match-any)
 0 packets
Match: dscp af31 (26) af32 (28) af33 (30)
 0 packets, 0 bytes
 5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 10%
queue-buffers ratio 10

Class-map: class-default (match-any)
 0 packets
Match: any
 0 packets, 0 bytes
 5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 25%
queue-buffers ratio 25

```

次に、**auto qos voip cisco-softphone** コマンドと、適用されるポリシーとクラス マップの例を示します。

```

Device(config)# interface gigabitEthernet1/0/20
Device(config-if)# auto qos voip cisco-softphone
Device(config-if)# end
Device# show policy-map interface gigabitEthernet1/0/20

GigabitEthernet1/0/20

Service-policy input: AutoQos-4.0-CiscoSoftPhone-Input-Policy

Class-map: AutoQos-4.0-Voip-Data-Class (match-any)
 0 packets
Match: dscp ef (46)
 0 packets, 0 bytes
 5 minute rate 0 bps
Match: cos 5
 0 packets, 0 bytes
 5 minute rate 0 bps
QoS Set
 dscp ef
police:
  cir 128000 bps, bc 8000 bytes
  conformed 0 bytes; actions:
    transmit
  exceeded 0 bytes; actions:
    set-dscp-transmit dscp table policed-dscp
  conformed 0000 bps, exceed 0000 bps

Class-map: AutoQos-4.0-Voip-Signal-Class (match-any)
 0 packets
Match: dscp cs3 (24)
 0 packets, 0 bytes

```

```

    5 minute rate 0 bps
Match: cos 3
    0 packets, 0 bytes
    5 minute rate 0 bps
QoS Set
    dscp cs3
police:
    cir 32000 bps, bc 8000 bytes
    conformed 0 bytes; actions:
        transmit
    exceeded 0 bytes; actions:
        set-dscp-transmit dscp table policed-dscp
    conformed 0000 bps, exceed 0000 bps

Class-map: AutoQos-4.0-Multimedia-Conf-Class (match-any)
    0 packets
Match: access-group name AutoQos-4.0-Acl-MultiEnhanced-Conf
    0 packets, 0 bytes
    5 minute rate 0 bps
QoS Set
    dscp af41
police:
    cir 5000000 bps, bc 156250 bytes
    conformed 0 bytes; actions:
        transmit
    exceeded 0 bytes; actions:
        drop
    conformed 0000 bps, exceed 0000 bps

Class-map: AutoQos-4.0-Bulk-Data-Class (match-any)
    0 packets
Match: access-group name AutoQos-4.0-Acl-Bulk-Data
    0 packets, 0 bytes
    5 minute rate 0 bps
QoS Set
    dscp af11
police:
    cir 10000000 bps, bc 312500 bytes
    conformed 0 bytes; actions:
        transmit
    exceeded 0 bytes; actions:
        set-dscp-transmit dscp table policed-dscp
    conformed 0000 bps, exceed 0000 bps

Class-map: AutoQos-4.0-Transaction-Class (match-any)
    0 packets
Match: access-group name AutoQos-4.0-Acl-Transactional-Data
    0 packets, 0 bytes
    5 minute rate 0 bps
QoS Set
    dscp af21
police:
    cir 10000000 bps, bc 312500 bytes
    conformed 0 bytes; actions:
        transmit
    exceeded 0 bytes; actions:
        set-dscp-transmit dscp table policed-dscp
    conformed 0000 bps, exceed 0000 bps

Class-map: AutoQos-4.0-Scavenger-Class (match-any)
    0 packets
Match: access-group name AutoQos-4.0-Acl-Scavenger
    0 packets, 0 bytes
    5 minute rate 0 bps

```

```
QoS Set
  dscp cs1
  police:
    cir 10000000 bps, bc 312500 bytes
    conformed 0 bytes; actions:
      transmit
    exceeded 0 bytes; actions:
      drop
    conformed 0000 bps, exceed 0000 bps

Class-map: AutoQos-4.0-Signaling-Class (match-any)
  0 packets
  Match: access-group name AutoQos-4.0-Acl-Signaling
    0 packets, 0 bytes
    5 minute rate 0 bps
  QoS Set
    dscp cs3
    police:
      cir 32000 bps, bc 8000 bytes
      conformed 0 bytes; actions:
        transmit
      exceeded 0 bytes; actions:
        drop
      conformed 0000 bps, exceed 0000 bps

Class-map: AutoQos-4.0-Default-Class (match-any)
  0 packets
  Match: access-group name AutoQos-4.0-Acl-Default
    0 packets, 0 bytes
    5 minute rate 0 bps
  QoS Set
    dscp default
    police:
      cir 10000000 bps, bc 312500 bytes
      conformed 0 bytes; actions:
        transmit
      exceeded 0 bytes; actions:
        set-dscp-transmit dscp table policed-dscp
      conformed 0000 bps, exceed 0000 bps

Class-map: class-default (match-any)
  0 packets
  Match: any
    0 packets, 0 bytes
    5 minute rate 0 bps

Service-policy output: AutoQos-4.0-Output-Policy

queue stats for all priority classes:
  Queueing
  priority level 1

  (total drops) 0
  (bytes output) 0

Class-map: AutoQos-4.0-Output-Priority-Queue (match-any)
  0 packets
  Match: dscp cs4 (32) cs5 (40) ef (46)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Match: cos 5
    0 packets, 0 bytes
    5 minute rate 0 bps
  Priority: 30% (300000 kbps), burst bytes 7500000,
```

```
Priority Level: 1

Class-map: AutoQos-4.0-Output-Control-Mgmt-Queue (match-any)
  0 packets
  Match: dscp cs2 (16) cs3 (24) cs6 (48) cs7 (56)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Match: cos 3
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing
  queue-limit dscp 16 percent 80
  queue-limit dscp 24 percent 90
  queue-limit dscp 48 percent 100
  queue-limit dscp 56 percent 100

  (total drops) 0
  (bytes output) 0
  bandwidth remaining 10%

  queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Multimedia-Conf-Queue (match-any)
  0 packets
  Match: dscp af41 (34) af42 (36) af43 (38)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Match: cos 4
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing

  (total drops) 0
  (bytes output) 0
  bandwidth remaining 10%
  queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Trans-Data-Queue (match-any)
  0 packets
  Match: dscp af21 (18) af22 (20) af23 (22)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Match: cos 2
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing

  (total drops) 0
  (bytes output) 0
  bandwidth remaining 10%
  queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Bulk-Data-Queue (match-any)
  0 packets
  Match: dscp af11 (10) af12 (12) af13 (14)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Match: cos 1
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing

  (total drops) 0
```

```
(bytes output) 0
bandwidth remaining 4%
queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Scavenger-Queue (match-any)
 0 packets
Match: dscp cs1 (8)
  0 packets, 0 bytes
  5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 1%
queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Multimedia-Strm-Queue (match-any)
 0 packets
Match: dscp af31 (26) af32 (28) af33 (30)
  0 packets, 0 bytes
  5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 10%
queue-buffers ratio 10

Class-map: class-default (match-any)
 0 packets
Match: any
  0 packets, 0 bytes
  5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 25%
queue-buffers ratio 25
```

設定を確認するには、**show auto qos interface *interface-id*** 特権 EXEC コマンドを入力します。

debug auto qos

Automatic Quality of Service (auto-QoS; 自動 QoS) 機能のデバッグをイネーブルにするには、特権 EXEC モードで **debug auto qos** コマンドを使用します。デバッグをディセーブルにする場合は、このコマンドの **no** 形式を使用します。

debug auto qos
no debug auto qos

構文の説明

このコマンドには引数またはキーワードはありません。

コマンド デフォルト

auto-QoS デバッグはディセーブルです。

コマンド モード

特権 EXEC

コマンド履歴

リリース	変更内容
Cisco IOS XE Everest 16.5.1a	このコマンドが導入されました。

使用上のガイドライン

auto-QoS がイネーブルのときに自動的に生成される QoS の設定を表示するには、auto-QoS をイネーブルにする前にデバッグをイネーブルにします。デバッグをイネーブルにするには、**debug auto qos** 特権 EXEC コマンドを入力します。

undebug auto qos コマンドは、**no debug auto qos** コマンドと同じです。

ある スタック 上でデバッグをイネーブルにした場合、アクティブ でのみイネーブルになります。スタック メンバのデバッグをイネーブルにする場合は、**session switch-number** 特権 EXEC コマンドでアクティブ からセッションを開始してください。次に、スタック メンバのコマンドラインプロンプトで **debug** コマンドを入力します。最初にセッションを開始せずにメンバのデバッグをイネーブルにするには、アクティブ 上で **remote command stack-member-number LINE** 特権 EXEC コマンドを使用することもできます。

例

次の例では、auto-QoS がイネーブルの場合に自動的に生成される QoS 設定を表示する方法を示します。

```
Device# debug auto qos
AutoQoS debugging is on
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# interface gigabitethernet2/0/1
Device(config-if)# auto qos voip cisco-phone
```

show auto qos

automatic QoS (auto-QoS) が有効になっているインターフェイスに入力された Quality of Service (QoS) コマンドを表示するには、特権 EXEC モードで **show auto qos** コマンドを使用します。

show auto qos [**interface** *interface-id*]

構文の説明

interface *interface-id* (任意) 指定されたポートまたはすべてのポートの auto-QoS 情報を表示します。有効なインターフェイスには、物理ポートが含まれます。

コマンドモード

ユーザ EXEC
特権 EXEC

コマンド履歴

リリース	変更内容
Cisco IOS XE Everest 16.5.1a	このコマンドが導入されました。

使用上のガイドライン

show auto qos コマンド出力には、各インターフェイスに入力された **auto qos** コマンドだけが表示されます。**show auto qos interface interface-id** コマンド出力には、特定のインターフェイス上に入力された **auto qos** コマンドが表示されます。

auto-QoS 設定およびユーザ変更を表示する場合は、**show running-config** 特権 EXEC コマンドを使用します。

Cisco IOS リリース 12.2(40)SE 以降、**show auto qos** コマンドの出力には、Cisco IP Phone のサービス ポリシー情報が表示されます。

例

次の例では、**auto qos voip cisco-phone** および **auto qos voip cisco-softphone** インターフェイス コンフィギュレーション コマンドを入力した場合の **show auto qos** コマンドの出力を示します。

```
Device# show auto qos
GigabitEthernet2/0/4
auto qos voip cisco-softphone
```

```
GigabitEthernet2/0/5
auto qos voip cisco-phone
```

```
GigabitEthernet2/0/6
auto qos voip cisco-phone
```

次に、**auto qos voip cisco-phone** インターフェイス コンフィギュレーション コマンドが入力された場合の **show auto qos interface interface-id** コマンドの出力例を示します。

```
Device# show auto qos interface gigabitethernet 2/0/5
GigabitEthernet2/0/5
```

```
auto qos voip cisco-phone
```

次に、**auto qos voip cisco-phone** インターフェイス コンフィギュレーション コマンドが入力された場合の **show auto qos interface *interface-id*** コマンドの出力例を示します。

```
Device# show auto qos interface gigabitethernet1/0/2  
GigabitEthernet1/0/2  
auto qos voip cisco-phone
```

次の例では、auto-QoS がインターフェイスでディセーブルになっている場合の **show auto qos interface *interface-id*** コマンドの出力を示します。

```
Device# show auto qos interface gigabitethernet3/0/1  
AutoQoS is disabled
```