

CHAPTER 37

Configuring Unknown Unicast and Multicast Flood Blocking

This chapter describes how to configure the unknown unicast flood blocking (UUFB) and unknown multicast flood blocking (UMFB) features on the Catalyst 6500 series switches.



For complete syntax and usage information for the commands used in this chapter, refer to the *Catalyst Supervisor Engine 32 PISA Cisco IOS Command Reference*, Release 12.2ZY, at this URL:

http://www.cisco.com/en/US/docs/switches/lan/catalyst 6500/ios/12.2ZY/command/reference/cmdref.html

This chapter contains these sections:

- Understanding Unknown Traffic Flood Control, page 37-1
- Configuring UUFB or UMFB, page 37-2

Understanding Unknown Traffic Flood Control

By default, unknown unicast and multicast traffic is flooded to all Layer 2 ports in a VLAN. You can use the UUFB and UMFB features to prevent or limit this traffic.

The UUFB and UMFB features block unknown unicast and multicast traffic flooding at a specific port, only permitting egress traffic with MAC addresses that are known to exist on the port. The UUFB and UMFB features are supported on all ports that are configured with the **switchport** command, including private VLAN (PVLAN) ports.



Entering the **switchport block multicast** command on nonreceiver (router) ports of the VLAN could disrupt routing protocols. This command could also disrupt ARP functionality and other protocols, such as Network Time Protocol (NTP), that make use of local subnetwork multicast control groups in the 224.0.0.0/24 range.

Configuring UUFB or UMFB

To configure UUFB or UFMB, perform this task:

	Command	Purpose
Step 1	Router# configure terminal	Enters global configuration mode.
Step 2	Router(config)# interface {{type1 slot/port} {port-channel number}}	Selects the interface to configure.
Step 3	Router(config-if)# switchport	Configures the port for Layer 2 switching.
Step 4	Router(config-if)# switchport block {unicast multicast}	Enables unknown unicast or multicast flood blocking on the port.
Step 5	Router(config-if)# do show interfaces [type ¹ slot/port] switchport include Unknown	Verifies the configuration.

^{1.} type = fastethernet, gigabitethernet, or tengigabitethernet

This example shows how to configure UUFB on Fast Ethernet port 5/12 and how to verify the configuration:

```
Router# configure terminal
Router(config)# interface fastethernet 5/12
Router(config-if)# switchport
Router(config-if)# switchport block unicast
Router(config-if)# do show interface fastethernet 5/12 switchport | include Unknown
Unknown unicast blocked: enabled
```