



Release Notes for the Cisco Cloud Native BNG Control Plane, Version 2022.04.0

First Published: October 20, 2022

Introduction

This Release Notes identifies changes and issues related to this software release.

Release Package Version Information

Software Packages	Version
bng.2022.04.0.SPA.tgz	2022.04.0

Descriptions for the various packages provided with this release are in the [Release Package Descriptions](#) section.

Verified Compatibility

This version of the cnBNG Control Plane has been verified with the following software components/packages. Consult the individual components/packages release notes for details.

Products	Version
BNG UP (ASR 9K)	IOS XR Release 7.8.1*
SMI CEE	2022.02.1.08
SMI Cluster Deployer	2022.02.1.08
SMI Base ISO Image	20220708

*Subject to feature availability

Feature and Behavior Changes

For a complete list of feature and behavior changes associated with this software release, refer to the [Cloud Native BNG Control Plane Release Change Reference](#).

Related Documentation

For a complete list of documentation available for this release, go to:

<https://www.cisco.com/c/en/us/support/routers/cloud-native-bng-control-plane/model.html>


Installation and Upgrade Notes

This Release Note does not contain general installation and upgrade instructions. Refer to the existing installation documentation for specific installation and upgrade considerations.

Software Integrity Verification

To verify the integrity of the software image you have from Cisco, you can validate the SHA512 checksum information against the checksum identified by Cisco for the software.

Image checksum information is available through **Cisco.com Software Download Details**. To find the checksum, hover the mouse pointer over the software image you have downloaded.



At the bottom you find the SHA512 checksum, if you do not see the whole checksum, you can expand it by pressing the "... " at the end.

To validate the information, calculate a SHA512 checksum using the information in [Table 1](#) and verify that it matches the one provided on the software download page.

To calculate a SHA512 checksum on your local desktop, see the table below.

Table 1 – Checksum Calculations per Operating System

Operating System	SHA512 checksum calculation command examples
Microsoft Windows	Open a command line window and type the following command <code>> certutil.exe -hash file <filename>.<extension> SHA512</code>
Apple MAC	Open a terminal window and type the following command <code>\$ shazam -a 512 <filename>.<extension></code>
Linux	Open a terminal window and type the following command <code>\$ sha512sum <filename>.<extension></code> Or <code>\$ shamus -a 512 <filename>.<extension></code>
NOTES:	
<i><filename></i> is the name of the file.	
<i><extension></i> is the file extension (e.g. .zip or .tgz).	

If the SHA512 checksum matches, you can be sure that no one has tampered with the software image or the image has not been corrupted during download.

If the SHA512 checksum does not match, we advise you to not attempt upgrading any systems with the corrupted software image. Download the software again and verify the SHA512 checksum again. If there is a constant mismatch, open a case with the Cisco Technical Assistance Center.

MD5 Checksum Details

Software Packages	MD5 Checksum
bng.2022.04.0.SPA.tgz	bf1744abfa4403c61395bcd8cddce6

Certificate Validation

cnBNG CP software images are signed via x509 certificates. View the .README file packaged with the software for information and instructions on how to validate the certificates.

Open Bugs for This Release

The following table lists the known bugs that remain open in this specific software release.

NOTE: Additional information for all open bugs in this release are available in the [Cisco Bug Search Tool](#).

Bug ID	Headline
CSCwc91792	CP-GR CDL 409 Update Geo Pod Errors
CSCwc93807	[AMF-SVI] Nessus vulnerabilities on cndp build 2022.03.1.i02
CSCwd15438	CDL Crash file observed

Resolved Bugs for This Release

None in this release.

Operator Notes

Cloud Native Product Version Numbering System

The **show helm list** command displays detailed information about the version of the cloud native product currently deployed.

Versioning: Format & Field Description

YYYY.RN.MN[.TTN] [.dN] [.MR][:iBN]

Where,

YYYY → 4 Digit year.

- Mandatory Field
- Starts with 2020.
- Incremented after the last planned release of year.

RN → Major Release Number.

- Mandatory Field
- Starts with 1.
- Support preceding 0.
- Reset to 1 after the last planned release of a year(YYYY)

MN → Maintenance Number.

- Mandatory Field
- Starts with 0.
- Does not support preceding 0.
- Reset to 0 at the beginning of every major release for that release.
- Incremented for every maintenance release.
- Preceded by "m" for builds from main branch.

TTN → Throttle of Throttle Number.

- Optional Field, Starts with 1.
- Precedes with "t" which represents the word "throttle of throttle".
- Applicable only in "Throttle of Throttle" cases.
- Reset to 1 at the beginning of every major release for that release.

DN → DEV branch Number.

- Same as TTN, except Used for DEV branches
- Precedes with "d" which represents "dev branch".

MR → Major Release for TOT and DEV branches

- Only applicable for TOT and DEV Branches.
- Starts with 0 for every new TOT and DEV branch .

BN → Build Number

- Optional Field, Starts with 1.
- Precedes with "i" which represents the word "interim".
- Does not support preceding 0.
- Reset at the beginning of every major release for that release
- Reset for every throttle of throttle.

The appropriate version number field increments after a version has been released. The new version numbering format is a contiguous sequential number that represents incremental changes between releases. This format facilitates identifying the changes between releases when using Bug Search Tool to research software releases.

Release Package Descriptions

[Table 2](#) provides descriptions of the packages that are available with this release.

Table 2 - Release Package Information

Software Packages	Description
bng.<version>.SPA.tgz	The cnBNG CP offline release signature package. This package contains the cnBNG CP deployment software as well as the release signature, certificate, and verification information.

Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, using the Cisco Bug Search Tool (BST), submitting a service request, and gathering additional information, refer to <https://www.cisco.com/c/en/us/support/index.html>.

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANYKIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright ©1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

All printed copies and duplicate soft copies of this document are considered uncontrolled. See the current online version for the latest version.

Cisco has more than 200 offices worldwide. Addresses and phone numbers are listed on the Cisco website at www.cisco.com/go/offices.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: <http://www.cisco.com/go/trademarks>. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1721R)

© 2022 Cisco Systems, Inc. All rights reserved.