



Introduction

This document describes the commands used to configure Cisco IOS Optimized Edge Routing (OER). For information about OER configuration, refer to the *Cisco IOS Optimized Edge Routing Configuration Guide*.

