



INDEX

A

additional software requirements

client [1-8](#)

master and server [1-7](#)

audience for this document [i-ix](#)

B

before you begin installation

Solaris [3-2](#)

Windows [2-2](#)

browser requirements for client [1-8](#)

C

cautions

regarding stopping CVMDbMonitor or
CVMDbEngine on the CWVM master

on Solaris systems [3-16](#)

on Windows systems [2-15](#)

significance of [i-x](#)

Cisco UBE directory gatekeepers [1-5](#)

client system requirements [1-7](#)

browser [1-8](#)

hardware and software [1-8](#)

memory (RAM) [1-8](#)

collecting installation parameters

on Solaris systems [3-2](#)

passwords [3-2](#)

ports [3-2](#)

on Windows systems [2-2](#)

passwords [2-2](#)

ports [2-2](#)

CWVM daemons

starting

on Solaris systems [3-15](#)

on Windows systems [2-14](#)

stopping

on Solaris systems [3-17](#)

on Windows systems [2-16](#)

CWVM security, and user roles [1-3](#)

Master Administrator [1-4](#)

Network Operator [1-4](#)

Server Administrator [1-4](#)

D

daemons (see CWVM daemons) [2-14](#)

devices supported by CWVM [1-8](#)

distributed CWVM installation, planning [1-5](#)

documentation

related to this product [i-xi](#)

specific to this product [i-x](#)

drive space requirements for master and server
systems [1-7](#)

E

estimating installation or upgrade time

on Solaris systems [3-1](#)

on Windows systems [2-1](#)

H

hardware requirements

- client [1-8](#)
 - master and server [1-7](#)
-

Iinstallation on Solaris systems [3-1](#)

- before you begin [3-2](#)
- CWVM master, installation procedure [3-11](#)
- CWVM server, installation procedure [3-13](#)
- distributed CWVM installation, planning [1-5](#)
- installation notes [3-1](#)
 - collecting installation parameters [3-2](#)
 - estimating installation or upgrade time [3-1](#)
 - preparing network devices [3-2](#)
- installation parameters, collecting [3-2](#)
 - passwords [3-2](#)
 - ports [3-2](#)
- overall procedure [3-10](#)
- registering a CWVM server with the CWVM master [3-12](#)
- reinstalling CWVM [4-3](#)
- removing CWVM [4-4](#)
- system requirements [1-6](#)
 - client requirements [1-7](#)
 - master and server requirements [1-7](#)
- troubleshooting [4-1](#)
- verifying the installation [3-14](#)

installation on Windows systems [2-1](#)

- before you begin [2-2](#)
- collecting installation parameters [2-2](#)
- CWVM master, installation procedure [2-10](#)
- CWVM server, installation procedure [2-12](#)
- distributed CWVM installation, planning [1-5](#)
- installation notes [2-1](#)
 - collecting installation parameters [2-2](#)
 - estimating installation or upgrade time [2-1](#)

- preparing network devices [2-3](#)
 - installation parameters, collecting
 - passwords [2-2](#)
 - ports [2-2](#)
 - overall procedure [2-9](#)
 - registering a CWVM server with the CWVM master [2-11](#)
 - reinstalling CWVM [4-3](#)
 - removing CWVM [4-4](#)
 - system requirements [1-6](#)
 - client requirements [1-7](#)
 - master and server requirements [1-7](#)
 - troubleshooting [4-1](#)
 - upgrading
 - CWVM [2-4](#)
 - verifying the installation [2-13](#)
 - IP address of a CWVM master or server, changing [4-2](#)
-

J

Java Plug-in

- installing
 - on Solaris systems [3-15](#)
 - on Windows systems [2-15](#)
-

L

- log files, checking [4-2](#)
-

M

Master Administrator

- password, changing [4-2](#)
- user role, definition [1-4](#)
- memory (RAM) requirements
 - client [1-8](#)
 - master and server [1-7](#)

N

- network devices, preparing for installation [2-3](#)
- Network Operator user role, definition [1-4](#)
- network partitioning
 - examples [1-2](#)
 - Networks and CWVMServers Known to CWVMMaster (table) [1-3](#)
 - Networks in CWVM1 (table) [1-3](#)
 - Networks in CWVM2 (table) [1-3](#)
 - Networks in CWVM3 (table) [1-3](#)
 - support for, in this release [1-2](#)
- new in this release [1-1](#)
 - CWVM security, changes to [1-3](#)
 - distributed CWVM [1-2](#)
 - network partitioning [1-2](#)
 - new features [1-1](#)

P

- password for Master Administrator, changing [4-2](#)
- process status, checking [4-2](#)

R

- reinstalling CWVM [4-3](#)
- removing
 - CWVM [4-4](#)
 - CWVM Master, and reinstalling [4-3](#)

S

- Server Administrator, user role [1-4](#)
- Server Administrator user role, defined [1-4](#)
- software requirements
 - additional
 - client [1-8](#)
 - master and server [1-7](#)

- system

- client [1-8](#)
- master and server [1-7](#)

- starting

- CWVM
 - on Solaris systems [3-14](#)
 - on Windows systems [2-13](#)
- CWVM daemons
 - on Solaris systems [3-15](#)
 - on Windows systems [2-14](#)

- stopping

- CWVM
 - on Solaris systems [3-16](#)
 - on Windows systems [2-15](#)
- CWVM daemons
 - on Solaris systems [3-17](#)
 - on Windows systems [2-16](#)

- superadmin password, changing [4-2](#)

- system requirements [1-6](#)

- client requirements [1-7](#)
 - additional software [1-8](#)
 - browser [1-8](#)
 - memory (RAM) [1-8](#)
 - system hardware [1-8](#)
 - system software [1-8](#)

- master and server requirements [1-7](#)

- additional software [1-7](#)
- drive space [1-7](#)
- memory (RAM) [1-7](#)
- system hardware [1-7](#)
- system software [1-7](#)

T

- time required for installation, estimating

- on Solaris systems [3-1](#)
- on Windows systems [2-1](#)

troubleshooting installation [4-1](#)

- IP Address of a CWVM master or server, changing [4-2](#)
- log files, checking [4-2](#)
- password for the Master Administrator, changing [4-2](#)
- process status, checking [4-2](#)
- reinstalling CWVM [4-3](#)
- removing and reinstalling the CWVM master [4-3](#)
- removing CWVM [4-4](#)
- service pack 2 for Common Services [1-5](#)
- users cannot log in
 - to any CWVM server [4-1](#)
 - to a particular CWVM server [4-1](#)

typographical conventions used in this document [i-ix](#)on Windows systems [2-13](#)

- installing the Java Plug-in on client machines [2-15](#)
- logging in to CWVM [2-15](#)
- starting CWVM [2-13](#)
- starting CWVM daemons [2-14](#)
- stopping CWVM [2-15](#)
- stopping CWVM daemons [2-16](#)

U

upgrading

- CWVM
 - on Windows systems [2-4](#)
- CWVM master
 - on Solaris systems [3-7](#)
 - on Windows systems [2-6](#)
- CWVM server
 - on Solaris systems [3-8](#)
 - on Windows systems [2-8](#)

V

verifying CWVM installation

- on Solaris systems [3-14](#)
 - installing the Java Plug-in on client machines [3-15](#)
 - logging in to CWVM [3-16](#)
 - starting CWVM [3-14](#)
 - starting CWVM daemons [3-15](#)
 - stopping CWVM [3-16](#)
 - stopping CWVM daemons [3-17](#)