Configure and Troubleshoot TITAN with CURWB

Contents

Introduction
FITAN Basics
How does TITAN work?
Fixed Infrastructure
Configuration
<u>Fest Scenario</u>
Mesh End failover
Testing failover on the Vehicle Radio
Froubleshooting TITAN

Introduction

This document describes the use of TITAN, its configuration, and troubleshooting in CURWB deployments.


TITAN Basics

TITAN is a critical feature that offers high availability with hardware redundancy in CURWB deployments. It can be configured throughout various features of the fixed part of the fluidity network. The most common applications are in enabling TITAN on the Core Network Global Gateways, Local Mesh End Gateways, and Onboard Vehicle radios. It works on both layer 2 and layer 3 networks.

When enabled, TITAN provides fast failover from a Primary device to a Secondary device, in less than 500 milliseconds. The Secondary device immediately resumes CURWB MPLS communications.

The example seen here shows TITAN failover on all three conditions.

- Core Network Global Gateways,
- Local Mesh End Gateways, and
- Onboard Vehicle radios



How does TITAN work?

To fully comprehend the concept of Titan, it is essential to become familiar with Autotap. It is a networkloop prevention mechanism that allows CUWRB devices to detect connections and allow only a dedicated ingress/egress route to and from the Mesh End or network core.

Radios with the same passphrase, connected to the same network switch on the same broadcast domain, act as a single unit with multiple antennas.

CURWB Mesh Protocol detects wired connections among radios, with routes being built automatically. The result is like having a single AP with multiple wireless interfaces.

The AutoTap functionality prevents network loops in such configurations. Only the radio elected as Primary (lowest numerical Mesh ID) in a physically connected group publishes MAC address information. Traffic is seen coming only from the radio elected as the Primary radio of the connected group.

Fixed Infrastructure

The user sets two Mesh End units with the same configuration and connect to the same switch. Those devices share information to elect the Primary and the other unit is on standby. When failure occurs, the Standby unit takes over in 500 ms and connect all the Mesh Points back to the system. For fixed networks, TITAN can only be enabled on Mesh End units and the Points automatically establish a connection with the End that took over.

Vehicles for Mobility

The process is the same as in a fixed network, the units must be on the same switch with the same configuration. The algorithm sets one as the Primary unit and the other as the secondary. In case the primary fails, the secondary unit takes over in 500 ms and establish a connection with the closed trackside unit. The only difference with mobility is, that TITAN can be enabled on Mesh Point units. In that case, the Fluidity feature supersedes the operation mode of the radio.

Trackside Radio

When the radio can't communicate with the backbone network, the system forces the vehicle(s) to connect to the closest trackside as an immediate response to the failure. It is the same process as for fixed networks but with the possibility of more than one active standby trackside. On the trackside system, the backup is not a radio on standby mode but a fully operational and active one that can cover for the failure.

Gateway connected to the corporate network

Just as Mesh Ends on a fixed network, the gateways (FM1000 and FM10000) work together to elect a Primary, and the backup takes over on a failure.

Primary Election

All CURWB units connected to the same wired broadcast domain and configured with the same passphrase perform a distributed primary election process every few seconds. The Primary unit constitutes an edge point of the CURWB MPLS network, that is, a device where the user traffic can enter or leave the mesh. Secondary units act as MPLS relay points. For each neighbor, the algorithm computes a precedence value based on the role of the unit (mesh-end or mesh-point) and its mesh-ID. Mesh-ends are assigned a higher priority than mesh-points and, among the same priority, the unit having the lowest mesh-ID is preferred. The election mechanism relies on a dedicated signaling protocol that constantly runs in the network, and it guarantees that all units elect the same Primary.

Mesh End failover

During normal operation, the Primary and Secondary mesh ends continuously to communicate with each other about their status and to exchange network reachability information. In particular, the Primary periodically sends updates to the Secondary regarding its internal forwarding table and multicast routes.

Configuration

In the basic TITAN configuration setup, a deployment would need two gateways (Mesh End); one primary and other secondary.

Both the primary and secondary pieces of hardware must have these TITAN configurations.

configure mpls fastfail status enabled

configure mpls fastfail timeout 150

config mpls unicast-flood enabled

config mpls arp-unicast disabled

config spanning-tree link-guard 40

config arp gratuitous enabled

configure arp gratuitous delay 150

In Layer 3 configurations if HA is required on each mesh end, then we would need two mesh ends on which the previous TITAN configuration needs to be executed.


While configuring TITAN on the vehicle radio, first the vehicle needs to have 2 radios on it. In the event of a failure on the primary, the secondary takes over the communication. In this scenario, the vehicle radios and the mesh end of the fluidity network need to have the TITAN configuration.

Test Scenario

Our current network topology includes seven radios. Within this setup, the Mesh End radios have their wireless interfaces deactivated. Their role is confined to serving as gateways, rather than functioning as part of the Trackside radio system. The primary Mesh End unit is assigned the IP address 10.122.136.50 and the secondary unit with the IP address 10.122.136.47.

We have 3 Trackside radios (10.122.136.9, 10.122.136.16 and 10.122.136.15). Trackside radio with the IP address 10.122.136.9 is hardwired into the core network infrastructure. This pivotal radio also extends a backhaul link to a pair of trailer radios with IP 10.122.136.15 and 10.122.136.16. These fixed infrastructure backhaul links are operating on the 5240 MHz frequency band. Collectively, the three radio provides wireless coverage to the mobile vehicle operating on a 5180 MHz frequency with the IP address 10.122.136.13).

The mobile vehicle is equipped with two radios with IP address 10.122.136.13 as the primary and 10.122.136.14 as the secondary. Both radios are interconnected through a single switch. The secondary radio is not shown here.



Mesh End failover

Step 1: Both Primary and Secondary mesh ends are connected to the network and are active. We can see the radio with lower Mesh ID acting as mesh end.

ME_Primary#show fluidity network unit 5.246.268 infrastructure meshend primary vehicles 1 total_mobiles 2 infrastructure 5 backbone 0 Wehicle ID Path Infrastr.ID via Mobile ID via H/O Seq H/O Age #M Primary ID Secondary IDs	ME_Secondarysham fluidity network unit 5,240-278. Birfastructure meshand backup vehicles 1 total_mobiles 2 infrastructure 5 backbome 6 meshand 5.246.226.200 Vehicle ID Path Infrastr.ID via Mobile ID via H/O Seq H/O Age #M Primary ID Secondary IDs
88261156 0 5.66.195.20 R1 5.66.194.36 R1 23 31.303 2 5.66.194.36 5.246.2.120 Typ Infrastr.ID #V Vehicle IDs	88261156 0 5.66.195.20 R1 5.66.194.36 R1 23 54.065 2 5.66.194.36 5.246.2.120 Typ Infrastr.ID #V Vehicle IDs
M 5.246.227.8 0 5.137.250.80 0 5.137.250.80 0 5.60.1395.20 1 88261156 ★ M 5.246.226.220 0 ML_Prinary#	M 5.246.226.200 0 5.137.258.80 0 5.6.195.20 1 88261156 5.137.259.148 0 ★ M 5.246.227.8 0 H⊑.Secondsyr∥]
soumyray - ping 10.122.136.14 - 111×10	soumyray – ping 10.122.136.13 – 111×10
64 bytes from 10.122.236.44: icmg_seqm424 ttl=51 time=32.422 ms 64 bytes from 10.122.236.44: icmg_seqm426 ttl=51 time=32.712 ms 64 bytes from 10.122.236.44: icmg_seqm426 ttl=51 time=32.712 ms 64 bytes from 10.122.236.74: icmg_seqm428 ttl=51 time=32.792 ms 64 bytes from 10.122.236.74: icmg_seqm428 ttl=51 time=32.922 ms 64 bytes from 10.122.236.74: icmg_seqm428 ttl=51 time=32.921 ms 64 bytes from 10.122.236.74: icmg_seqm420 ttl=51 time=32.921 ms 64 bytes from 10.122.236.74: icmg_seqm420 ttl=51 time=32.931 ms 64 bytes from 10.122.236.14: icmg_seqm420 ttl=51 time=32.931 ms	64 bytes from 10.122.136.131 icmp_sequ423 ttl=51 time=28.670 ms 64 bytes from 10.122.136.131 icmp_sequ422 ttl=51 time=20.673 ms 64 bytes from 10.122.136.131 icmp_sequ422 ttl=51 time=20.679 ms 64 bytes from 10.122.136.131 icmp_sequ422 ttl=51 time=20.879 ms 64 bytes from 10.122.136.131 icmp_sequ420 ttl=51 time=32.677 ms 64 bytes from 10.122.136.131 icmp_sequ420 ttl=51 time=31.865 ms 64 bytes from 10.122.136.131 icmp_sequ431 ttl=51 time=31.865 ms 64 bytes from 10.122.136.131 icmp_sequ431 ttl=51 time=29.165 ms
	<u>.</u>
ME_Primary#show fluidity network unit 5.246.226.200 infrastructure meshend primary var 1.1 to 2.26.200 infrastructure deshend 5.246.226.200	ME Secondaryschow fluidity network unit 5.244.227.8 infrastvorture meshend backup vicies 1.242
unit 5.246.226.200 infrastructure meshend primary vehicles 1 total_mobiles 2	unit 6.246.227.8 infrastructure meshend backup vehicles 1 tol.mobiles 0 meshend 5.246.226.200 infrastructure 5 backbone 0 meshend 5.246.226.200
unit 5.246.220.200 infrastructure meshend primary vehicles 1 total_mobiles 2 infrastructure 5 backbone 0 Wehicle ID Path Infrastr.ID via Mobile ID via H/O Seq H/O Age #M Primary ID Secondary IDs	unit 6,246.227.8 infrastructure meshend backup vehicles 1 total_mobiles 2 infrastructure 5 backbone 0 Vehicle ID Path Infrastr.ID via Mobile ID via H/O Seq H/O Age #M Primary ID Secondary IDs
unit 5,246.226.200 infrastructure meshend primary vehicles 1 total_mobiles 2 infrastructure 5 backbone 0 Vehicle ID Path Infrastr.ID via Mobile ID via H/O Seq H/O Age #M Primary ID Secondary IDs 88261156 0 5.66.195.20 Rl 5.66.194.36 Rl 23 31.303 2 5.66.194.36 5.246.2.120	unit 6.246.227.8 infrastructure meshend backup vehicles 1 total.mobiles / meshend 5.246.226.200 Vehicle ID Path Infrastr.ID via Mobile ID via H/O Seq H/O Age #M Primary ID Secondary IDs 88261156 0 5.66.195.20 Rl 5.66.194.36 Rl 23 54.065 2 5.66.194.36 5.246.2.120
unit 5.246.228.200 infristructure meshend primary vehicles 1 total_mobiles 2 infrastructure 5 backbone 0 emeshend 5.246.226.200 Vehicle ID Path Infrastr.ID via Mobile ID via H/O Seq H/O Age #M Primary ID Secondary IDs 88201156 0 5.66.195.20 R1 5.66.194.36 R1 23 31.303 2 5.66.194.36 5.246.2.120 Typ Infrastr.ID #V Vehicle IDs 5.267.278.00 5.137.250.180 0 5.137.250.180 0 5.137.250.180 0 5.137.250.180 1 85.267.278.00 5.137.250.180 0 5.137.250.180 0 5.137.250.180 0 5.137.250.180 0 5.137.250.180 0 5.137.250.200 0 5.137.250.2500 0	unit 6.246.227.8 infrastructure meshend backup vehicles 10 tol_mobiles 0 vehicles 10 Path Infrastr.10 via Mobile 10 via H/O Seq H/O Age #M Primary ID Secondary IDs 82621156 0 6.66.195.20 RI 5.66.194.36 RI 23 54.065 2 5.66.194.36 5.246.2.120 Typ Infrastr.10 #V Vehicle IDs 5.66.4.262.2020 0 5.66.55.20 1 88261156 5.66.57.269.16 0 5.66.195.20 1 88261156 5.66.195.20 1 88261156 5.66.277.80 0

Step 2: When the primary goes does, the secondary Mesh End takes over and acts as the mesh end for the entire network. Note that the failed primary mesh end is now missing from the list of infrastructure radios.

unit vehi	econdary#show f 5.246.227.8 in cles 1 total_mol astructure 4 bac	frastructure m piles 2	eshend							
v	ehicle ID Path	Infrastr.ID	via	Mobile ID	via	H/O Seq	H/O Age	#M	Primary ID	Secondary IDs
	88261156 0	5.66.195.20	R1	5.66.194.36	R1	26	7.192	2	5.66.194.36	5.246.2.120
Тур	Infrastr.ID	#V Vehicle I	Ds							
	5.137.250.80 5.66.195.20 5.137.250.148 5.246.227.8 econdary#	0 1 88261156 0 0								

Step 3: The failed primary radio is now back and operational. However, it waits for the preemption delay to learn the network topology

```
[ME_Secondary#show fluidity network
unit 5.246.227.8 infrastructure meshend primary
vehicles 1 total_mobiles 2
infrastructure 5 backbone 0 meshend 5.246.227.8
                                                                             #M Primary ID
   Vehicle ID Path Infrastr.ID
                                 via
                                       Mobile ID
                                                      via H/O Seq H/O Age
                                                                                                Secondary IDs
     88261156
                 0 5.66.195.20 R1
                                        5.66.194.36
                                                      R1
                                                               26
                                                                    58.026
                                                                              2 5.66.194.36
                                                                                                5.246.2.120
                   #V Vehicle IDs
Typ Infrastr.ID
     5.137.250.80
                    0
  M 5.246.226.200
                    0
     5.66.195.20
                    1 88261156
     5.137.250.148
                    0
* M 5.246.227.8
                    0
ME_Secondary#
```

Step 4: Once the preemption timer is reached, the Mesh ID 5.246.226.200 takes over the role of primary and radio with mesh ID 5.246.227.8 again becomes the secondary.


Testing failover on the Vehicle Radio

In this lab network, we have a fluidity network with one vehicle connected to the trackside. The vehicle has two radios with IP 10.122.136.13 – Mesh ID 5.66.194.36 (P) and 10.122.136.14 – Mesh ID 5.246.2.120 (S).

Step 1: Both Primary and Secondary vehicle radios are online. We can see the radio with a lower Mesh ID acting as the primary radio and the other as secondary. Based on the wireless quality both the primary and secondary radio can communicate with the trackside radio. But all downstream communication to the onboard network always goes through the primary radio. With TITAN secondary vehicle radio becomes Primary during failure within 500ms.


In this screenshot, the MPLS tunnel can be seen from the mesh end to the vehicle radios.

<5.246.226.200 5.246.2.120 1586093897> ESTABLISHED ftn 31 ilm 256008 pim	38.540539100 ka 0 { 5.246.226.200 5.137.250.148 5.66.194.36 5.246.2.120 }
<pre><5.246.226.200 5.137.250.148 537701201> ESTABLISHED ftn 1 ilm 256000 pi-</pre>	11.153242652 ka 0 { 5.246.226.200 5.137.250.148 }
<5.246.226.200 5.137.250.80 785530390> ESTABLISHED ftn 2 ilm 256001 pi-	11.151503173 ka 0 { 5.246.226.200 5.137.250.148 5.137.250.80 }
<5.246.226.200 5.66.194.36 633206167> ESTABLISHED ftn 30 ilm 256007 pim	38.540566965 ka 0 { 5.246.226.200 5.137.250.148 5.66.194.36 }
<5.246.226.200 5.246.227.8 1774125858> ESTABLISHED ftn 28 ilm 256006 pi-	11.153574318 ka 0 { 5.246.226.200 5.246.227.8 }
<5.246.226.200 5.66.195.20 526811188> ESTABLISHED ftn 4 ilm 256003 pi- 9	.151122548 ka 0 { 5.246.226.200 5.137.250.148 5.66.195.20 }
ME_Primary#	
ME_Primary# ME_Primary#show fluidity network	88261156 0 5.66.195.20 R1 5.66.194.36 R1 23 54.065 2 5.66.194.36 5.246.2.120
unit 5.246.226.200 infrastructure meshend primary	Typ Infrastr.ID #V Vehicle IDs
vehicles 1 total_mobiles 2 infrastructure 5 backbone 0 meshend 5.246.226.200	M 5.246.226.200 0
Infrastructure b backdone v mesnend 5.246-220	5.240.220.220 0
Vehicle ID Path Infrastr.ID via Mobile ID via H/O Seq H/O Age #M Primary ID Secondary ID	
88261156 0 5.66.195.20 R1 5.66.194.36 R1 23 31.303 2 5.66.194.36 5.246.2.120	- 5.137.250.148 0 * M 5.246.227.8 0
	ME_Secondary#show fluidity network
Typ Infrastr.ID #V Vehicle IDs	unit 5.246.227.8 infrastructure meshend backup vehicles 1 total_mobiles 2
M 5.246.227.8 0	Venteles i tota_mobiles z infrastructure 5 backbone 0 meshend 5.246.226.200
5.137.250.80 0	
5.137.250.148 0 5.66.195.20 1 88261156	Vehicle ID Path Infrastr.ID via Mobile ID via H/O Seq H/O Age #M Primary ID Secondary IDs
M 5.246.226.200 0	88261156 @ 5.66.195.20 R1 5.66.194.36 R1 25 33.951 2 5.66.194.36 5.246.2.120
ME_Primary#reload Proceed with reload command (cold)? [confirm]	
Proceed with reload command (cold)? [confirm]	Typ Infrastr.ID #V Vehicle IDs
cli: AP Rebooting: CLI triggered cold reboot (reload command)	M 5.246.226.200 0
	5.137.250.80 0 5.66.195.20 1 88261156
ME_Primary#Connection to 10.122.136.50 closed by remote host.	5.137.256.148 0
Connection to 10.122.136.50 closed.	* M 5.246.227.8 0
soumyray@SOUMYRAY-M-QXTV ~ № []	ME_Secondary#
Soumyray - ping 10.122.136.14 - 111×10	● ● ■ soumyray - ping 10.122.136.13 - 111×10
64 bytes from 10.122.136.14: icmp_seq=512 ttl=51 time=35.446 ms	64 bytes from 10.122.136.13: icmp_seq=451 ttl=51 time=28.182 ms
Request timeout for icmp_seq 513 64 bytes from 10.122.136.14: icmp_seq=514 ttl=51 time=32.646 ms	64 bytes from 10.122.136.13: icmp_seq=452 ttl=51 time=29.582 ms 64 bytes from 10.122.136.13: icmp_seq=453 ttl=51 time=29.980 ms
04 bytes from 10.122.130.14: 1cmp_s0q=50.4 tl=51 tlme=20.206 ms	64 bytes from 10.122.136.13: icmp_seq=453 til=51 time=28.958 ms
64 bytes from 10.122.136.14: icmp_seq=516 ttl=51 time=30.794 ms	64 bytes from 10.122.136.13: icmp_seq=455 ttl=51 time=40.943 ms
64 bytes from 10.122.136.14: icmp_seq=517 ttl=51 time=28.981 ms	64 bytes from 18.122.136.13: icmp_seq=456 ttl=51 time=28.578 ms
64 bytes from 10.122.136.14: icmp_seq#518 ttl=51 time=28.228 ms 64 bytes from 10.122.136.14: icmp_seq#519 ttl=51 time=31.112 ms	64 bytes from 10.122.136.13: icmp_seq=457 ttl=51 time=31.743 ms 64 bytes from 10.122.136.13: icmp_seq=458 ttl=51 time=27.375 ms
64 bytes from 10.122.136.14: icmp_seq=520 t1=51 time=29.437 ms	64 bytes from 10.122.136.13: icmp_seq=459 ttl=51 time=29.563 ms
	64 bytes from 10.122.136.13: icmp_seq=459 ttl=51 time=29.563 ms



Step 2: As we shut down the primary radio10.122.136.13 it fails over to the secondary and now 10.122.136.14 becomes the primary.


	structure 5 bac hicle ID Path				via	H/O Seq	H/O Age	#M	Primary ID	Secondary II
							11/0 Age			
		5.137.250.14	8 R1	5.246.2.120	R1	120	1.450	1	5.246.2.120	
* 10	00008568 0	5.137.250.14								
		#V Vehicle I								
Typ I	Infrastr.ID	#V Vehicle I								
Typ I M 5										
Typ I M 5 5	Infrastr.ID 5.246.226.200	#V Vehicle II								
Typ I M 5 5	Infrastr.ID 5.246.226.200 5.246.227.8	#V Vehicle II 0 0								



Step 3: Failed Primary onboard radio on the vehicle is powered back and operational. However, although this radio connects to the network, it waits for the preemption delay and not actively participate in the fluidity network.

As seen in this screenshot, 5.66.194.36 came back online but still, it is acting as secondary during the preemption delay and 5.246.2.120 is still managing the communication. The MPLS tunnel also shows that 5.246.2.120 is communicating with the trackside radio.

[MP_Vehicle_Secondary#show fluidity network unit 5.246.2.120 vehicle 100008568 primary idle vehicles 1 total_mobiles 2 infrastructure 5 backbone 0 meshend 5.246.226.200 Vehicle ID Path Infrastr.ID via Mobile ID via H/O Seq H/O Age #M Primary ID Secondary IDs 5.66.194.36 R1 141 5.606 2 5.246.2.120 5.66.194.36 100008568 0 5.137.250.148 R1 * Typ Infrastr.ID #V Vehicle IDs M 5.246.226.200 0 5.246.227.8 0 0 5.66.195.20 5.137.250.80 5.137.250.80 0 5.137.250.148 1 100008568 MP_Vehicle_Secondary#



<5.246.226.200 5.246.2.120 1586093897> ESTABLISHED ftn 31 ilm 256008 pim 19.454668222 ka 0 { 5.246.226.200 5.137.250.148 5.66.194.36 5.246.2.120 }
<5.246.226.200 5.137.250.148 537701201> ESTABLISHED ftn 1 ilm 256008 pim 19.454668222 ka 0 { 5.246.226.200 5.137.250.148 5.66.194.36 5.246.2.120 }
<5.246.226.200 5.66.194.36 1227625941> ESTABLISHED ftn 1 2 ilm 256009 pim 19.45468853 ka 0 { 5.246.226.200 5.137.250.148 5.66.194.36 }
<5.246.226.200 5.137.250.80 785530390> ESTABLISHED ftn 2 ilm 256001 pim 0.104544792 ka 0 { 5.246.226.200 5.137.250.148 5.137.250.80 }
<5.246.226.200 5.246.227.8 1774125858> ESTABLISHED ftn 2 ilm 256006 pim 0.111126458 ka 0 { 5.246.226.200 5.246.227.8 }
<5.246.226.200 5.66.195.20 5.26811188> ESTABLISHED ftn 4 ilm 256003 pim 20.105585305 ka 0 { 5.246.226.200 5.137.250.148 5.66.195.20 }
ME_Primary#

Troubleshooting TITAN

- During TITAN configuration all configurations need to be identical on all required radios.
- Based on the size of the deployment, the preemption delay might need to be increased. This is to ensure that when the failed unit becomes operational, it does not take over the role too early before learning the topology.
- Configuring the fast fail timeout too small can create an unstable network. A value of 150 ms could be used in most deployments.