

## **Monitoring the Cisco Remote PHY Shelf 7200**

• Verifying the Cisco Remote PHY Shelf 7200 Using the CLI, on page 1

## Verifying the Cisco Remote PHY Shelf 7200 Using the CLI

To verify the Cisco RPD status and configuration, use the **show cable rpd group** command. For more information, see the Cisco CMTS Cable Command Reference guide.

Verifying the Cisco Remote PHY Shelf 7200 Using the CLI