G Show Commands

- show gnss-receiver, on page 2
- show guestshell, on page 3

show gnss-receiver

show gnss-receiver

Syntax Description

gnss-receiver	Select GNSS Receiver

Command Mode

- /exec

show guestshell

show guestshell [{ detail }]

Syntax Description

show	Show running system information
guestshell	Display guest shell service information
detail	(Optional) Detailed guest shell service information

Command Mode

- /exec

show guestshell