



Getting Started

- [Is This Guide for You?](#), on page 1

Is This Guide for You?

This guide explains how to prepare for and complete a successful upgrade of the Firepower 4100/9300 chassis with:

- Firepower Threat Defense (FTD) logical devices managed by Firepower Management Center (FMC), **Version 6.0.1–7.0.x**
- Adaptive Security Appliance (ASA) logical devices, **Version 9.4(1)–9.16(x)**
- Firepower eXtensible Operating System (FXOS), **Version 1.1.1-2.10.1**

Additional Resources

If you are upgrading a different platform/component, or to a different version, see one of the following resources.

Upgrade	Target Version	Resource
FMC	Version 7.1.0+	Cisco Firepower Threat Defense Upgrade Guide for Firepower Management Center
FTD with FMC	Version 7.1.0+	Cisco Firepower Threat Defense Upgrade Guide for Firepower Management Center
FTD with FDM	Version 7.1.0+	Cisco Firepower Threat Defense Upgrade Guide for Firepower Device Manager

Upgrade	Target Version	Resource
FTD with FDM	Version 7.0.x or earlier	<p data-bbox="920 289 1485 449">Cisco Firepower Threat Defense Configuration Guide for Firepower Device Manager, to upgrade the FTD software on any FTD device. See the <i>System Management</i> chapter for the version you are currently running.</p> <p data-bbox="920 466 1485 590">Cisco Firepower 4100/9300 Upgrade Guide, Firepower 6.0.1–7.0.x or ASA 9.4(1)–9.16(x) with FXOS 1.1.1–2.10.1 (this guide), to upgrade FXOS on the Firepower 4100/9300.</p>
ASA logical devices on the Firepower 4100/9300	ASA 9.17(x)+	Cisco ASA Upgrade Guide
BIOS and firmware for FMC	Latest	Cisco Firepower Hotfix Release Notes