



New or Changed Commands

This section lists the new and changed information in this document by release and where it is located and describes new and changed commands in Release 4.2(1)SP1(6.1).

Table 1 New and Changed Information in Release 4.2(1)SP1(6.1)

New or Changed Command	Added	Changed	Removed	Feature	Configuration Document
<code>interface name mode passthrough</code>	X			VSB	<i>Cisco Nexus Cloud Services Platform Software Configuration Guide, Release 4.2(1)SP1(6.1)</i>
<code>numcpu</code>		X		VSB	<i>Cisco Nexus Cloud Services Platform Software Configuration Guide, Release 4.2(1)SP1(6.1)</i>

This section lists and describes new and changed commands in Release 4.2(1)SP1(5.1).

Table 2 New and Changed Information in Release 4.2(1)SP1(5.1)

New or Changed Command	Added	Changed	Removed	Feature	Configuration Document
<code>control uplink</code>	X			Uplinks	<i>Cisco Nexus Cloud Services Platform Software Configuration Guide, Release 4.2(1)SP1(6.1)</i>
<code>channel-group</code>	X			Uplinks	<i>Cisco Nexus Cloud Services Platform Software Configuration Guide, Release 4.2(1)SP1(6.1)</i>
<code>interface GigabitEthernet</code>	X			Uplinks	<i>Cisco Nexus Cloud Services Platform Software Configuration Guide, Release 4.2(1)SP1(6.1)</i>
<code>interface PortChannel</code>	X			Uplinks	<i>Cisco Nexus Cloud Services Platform Software Configuration Guide, Release 4.2(1)SP1(6.1)</i>



New or Changed Command	Added	Changed	Removed	Feature	Configuration Document
interface uplink	X			Uplinks	<i>Cisco Nexus Cloud Services Platform Software Configuration Guide, Release 4.2(1)SP1(6.1)</i>
management uplink	X			Uplinks	<i>Cisco Nexus Cloud Services Platform Software Configuration Guide, Release 4.2(1)SP1(6.1)</i>
network-uplink type		X		Uplinks	<i>Cisco Nexus Cloud Services Platform Software Configuration Guide, Release 4.2(1)SP1(6.1)</i>

This section lists and describes new and changed commands in Release 4.2(1)SP1(4)

Table 3 *New and Changed Information in Release 4.2(1)SP1(4)*

New or Changed Command	Added	Changed	Removed	Feature	Configuration Document
native VLAN	X			Native VLAN	<i>Cisco Nexus Cloud Services Platform Software Configuration Guide, Release 4.2(1)SP1(6.1)</i>
show network port-channel summary	X			Uplinks	<i>Cisco Nexus Cloud Services Platform Software Configuration Guide, Release 4.2(1)SP1(6.1)</i>

This section lists and describes new and changed commands in Release 4.2(1)SP1(3).

Table 4 *New and Changed Information in Release 4.2(1)SP1(3)*

New or Changed Command	Added	Changed	Removed	Feature	Configuration Document
export	X			Virtual Service Blade	<i>Cisco Nexus Cloud Services Platform Software Configuration Guide, Release 4.2(1)SP1(6.1)</i>
import	X			Virtual Service Blade	<i>Cisco Nexus Cloud Services Platform Software Configuration Guide, Release 4.2(1)SP1(6.1)</i>

Send document comments to nexus1k-docfeedback@cisco.com.

Table 4 ***New and Changed Information in Release 4.2(1)SP1(3)***

New or Changed Command	Added	Changed	Removed	Feature	Configuration Document
interface VsbEthernet	X			Virtual Service Blade	<i>Cisco Nexus Cloud Services Platform Software Configuration Guide, Release 4.2(1)SP1(6.1)</i>
show network summary	X			CDP	<i>Cisco Nexus Cloud Services Platform Software Configuration Guide, Release 4.2(1)SP1(6.1)</i>
show network cdp neighbors detail	X			CDP	<i>Cisco Nexus Cloud Services Platform Software Configuration Guide, Release 4.2(1)SP1(6.1)</i>
show virtual-service-blade		X		Virtual Service Blade	<i>Cisco Nexus Cloud Services Platform Software Configuration Guide, Release 4.2(1)SP1(6.1)</i>
shutdown (interface)	X			Virtual Service Blade	<i>Cisco Nexus Cloud Services Platform Software Configuration Guide, Release 4.2(1)SP1(6.1)</i>

Send document comments to nexus1k-docfeedback@cisco.com.