



# Nexus Dashboard Controller License Consumption

---

- [Nexus Dashboard controller license consumption, on page 1](#)

## Nexus Dashboard controller license consumption

Nexus Dashboard (ND) controller or cluster is bundled with Day2Ops applications. These applications request for controller licenses such as controller-ess, controller-adv, or controller-pre from the NX-OS switch. Based on this request, the corresponding licenses such as NXOS\_ESSENTIALS, NXOS\_ADVANTAGE, or DCN\_PREMIER are used on the switch.



---

**Note** If you downgrade from NX-OS Release 10.5(2)F to a lower image version, and upgrade to the 10.5(2)F or later versions, you must verify the controller license again.

---

You can verify the license usage using the **show license controller usage** or **show license usage** commands.

This is a sample output for **show license controller usage** command.

```
switch# show license controller usage
cluster01
NXOS_ESSENTIALS: TRUE
NXOS_ADVANTAGE: FALSE
DCN_PREMIER: FALSE

cluster02
NXOS_ESSENTIALS: FALSE
NXOS_ADVANTAGE: TRUE
DCN_PREMIER: FALSE

cluster03
NXOS_ESSENTIALS: FALSE
NXOS_ADVANTAGE: FALSE
DCN_PREMIER: TRUE

switch#
```

This is a sample output for **show license usage** command.

```
switch# show license usage
```

```
License Authorization:
Status: Not Applicable
```

```
(DCN_PREMIER):
Description: ACI Premier SW license for a 10/25/40G (XF) N9K Leaf
Count: 1
Version: 1.0
Status: IN USE
Enforcement Type: NOT ENFORCED
License Type: Generic
```

```
switch# show license usage DCN_PREMIER
Feature List:
controller-adv
controller-ess
controller-pre
```

```
switch#
```

When the feature is enabled on the NX-OS switch with the license feature on the ND controller side, the highest between the two licenses is used. This is a sample output that depicts this scenario.

```
switch# show license usage
```

```
License Authorization:
Status: Not Applicable
```

```
(DCN_PREMIER):
Description: ACI Premier SW license for a 10/25/40G (XF) N9K Leaf
Count: 1
Version: 1.0
Status: IN USE
Enforcement Type: NOT ENFORCED
License Type: Generic
```

```
switch# show license usage DCN_PREMIER
Feature List:
bgp
controller-adv
controller-ess
controller-pre
```

```
switch#
```




---

**Note** If there is no communication between the NX-OS switch and the ND controller for more than 24 hours, then the controller license usage information is deleted from the switch.

---