



CHAPTER 9

Headset Control Screen

Revised: September, 2010, OL-21702-01

The Headset Control Screen allows you to switch between a headset device and the integrated Cisco TelePresence System (CTS) Cisco Unified IP Phone speaker.

Figure 9-1 *Headset Control Screen*



Table 9-1 shows available Headset Settings Screen buttons and softkeys.

Table 9-1 Headset Settings Screen Buttons and Softkeys

Navigation Type	Description
Button	
Headset	<ul style="list-style-type: none"> • Touch to enable. • Touch to disable.
Speaker	<ul style="list-style-type: none"> • Touch to enable. • Touch to disable.
Softkey	
Save	Saves your current headset setting.
Exit	Exits the current Screen to go to the previous one (Manual Idle Screen).

Related Information

See the *Cisco TelePresence System User Guide* for more information about using the Cisco TelePresence System and the CTS Cisco Unified IP Phone.