



vRealize Orchestrator Inventory Types for UCS Manager Plugin

This appendix contains the following section:

- [vRealize Orchestrator Inventory Types for Cisco UCS Manager Plugin, page 1](#)

vRealize Orchestrator Inventory Types for Cisco UCS Manager Plugin

The table below lists the new vRealize Orchestrator inventory types for objects managed by the Cisco UCS Manager, in alphabetical order.

Inventory Type	Inventory Type	Inventory Type
AdaptorExtEthIf	FanModule	ScrubPolicy
AdaptorHostEthIf	FcAdapterPolicy	ServerPool
AdaptorHostFcIf	FiFcPort	ServerPoolPolicy
AdaptorHostIscsiIf	FirmwareComputeMgmtPack	ServerPoolQualification
AdaptorUnit	FixedModule	ServiceProfile
BackplanePorts	HostFirmwarePack	ServiceProfileTemplate
BiosPolicy	IOM	SolPolicy
Blade	IpmiAccessProfile	StorageLocalDiskSlotEp
BootPolicy	IscsiAdapterPolicy	ThresholdPolicy
Chassis	IscsiAuthProfile	UuidSuffixPool

Inventory Type	Inventory Type	Inventory Type
ComputePlatform	LocalDiskConfigPolicy	VHBA
EthAdapterPolicy	MaintenancePolicy	VNIC
EtherServerIntFio	NetworkElement	VhbaInterface
EtherSwitchIntFio	OnetimeOccurrence	VnicDynamicConPolicyRef
EthernetPorts	OrganizationHierarchy	VnicInterface
ExpansionModule	PSU	VnicIscsi
FCPorts	PlacementPolicy	
FEX	PowerPolicy	
FabricPort	RackUnit	
FabricPorts	RecurringOccurrence	
Fan	Schedule	