

## New and Changed Information for this Release

This chapter contains the following section:

• New and Changed Information, on page 1

## **New and Changed Information**

The following table provides an overview of the significant changes to this guide for the current release. The table does not provide an exhaustive list of all changes made to this guide or of all new features in this release.

Table 1: New and Changed Information for Release 6.7.2.0

| Feature | Description  | Where Documented                                     |
|---------|--|--|
| 11 1    | Supports vSphere/ESXi 6.7 Baremetal OS installation. | Adding a Non-Windows OS<br>Image in Bare Metal Agent |

Table 2: New and Changed Information for Release 6.7.3.1

| Feature                  | Description              | Where Documented                                   |
|--------------------------|--------------------------|--|
| Support for Windows 2019 | Support for Windows 2019 | Windows Server 2019 x64<br>Operating System Images |

Table 3: New and Changed Information for Release 6.7.4.0

| Feature             | Description | Where Documented                         |
|---------------------|-------------|--|
| Support for RHEL8.0 |             | Downloading Cisco UCS<br>Storage Drivers |

Table 4: New and Changed Information for Connector Pack, Release 6.7.4.2

| Feature                               | Description                        | Where Documented                           |
|---------------------------------------|------------------------------------|--|
| Support for CentOS8.0 and ESXi<br>7.0 | Support for CentOS8.0 and ESXi 7.0 | Setting Up UEFI as Network<br>Boot Manager |