



# Preface

---

**Revised: August 10, 2011, OL-25013-01**

This document serves as the PacketCable Subscriber Provisioning (PCSP) Programmer's Guide for the Cisco BTS 10200 Softswitch.

## Organization

This document is divided into the following chapters and appendixes:

- Chapter 1—[Overview](#)
- Chapter 2—[SOAP/XML Environment](#)
- Chapter 3—[Data Model](#)
- Chapter 4—[PCSP SOAP API](#)
- Chapter 5—[PCSP Rules and Mapping](#)
- Chapter 6—[PCSP Objects – XML Example \(PUT\)](#)
- Chapter 7—[Performance Considerations](#)
- Chapter 8—[Troubleshooting Guide](#)
- Appendix A—[Cisco BTS 10200 Extensions for PcsP Objects](#)
- Appendix B—[Sample Entity Encodings](#)

## Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, submitting a service request, and gathering additional information, see the monthly *What's New in Cisco Product Documentation*, which also lists all new and revised Cisco technical documentation, at

<http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html>

Subscribe to the *What's New in Cisco Product Documentation* as a Really Simple Syndication (RSS) feed and set content to be delivered directly to your desktop using a reader application. The RSS feeds are a free service and Cisco currently supports RSS Version 2.0.

## Document Change History

The following table lists the revision history for the *Cisco BTS 10200 Softswitch PCSP Programmer's Guide, Release 6.0.3*.

<b>Version Number</b>	<b>Issue Date</b>	<b>Status</b>	<b>Reason for Change</b>
OL-25013-01	August 10, 2011	Initial	Initial document for Release 6.0.3.