

## **Preface**

#### Revised: May 14, 2012, OL-25013-02

This document serves as the PacketCable Subscriber Provisioning (PCSP) Programmer's Guide for the Cisco BTS 10200 Softswitch.

### Organization

This document is divided into the following chapters and appendixes:

- Chapter 1—Overview
- Chapter 2—SOAP/XML Environment
- Chapter 3—Data Model
- Chapter 4—PCSP SOAP API
- Chapter 5—PCSP Rules and Mapping
- Chapter 6—PCSP Objects XML Example (PUT)
- Chapter 7—Performance Considerations
- Chapter 8—Troubleshooting Guide
- Appendix A—Cisco BTS 10200 Extensions for Pcsp Objects
- Appendix B—Sample Entity Encodings

### **Obtaining Documentation and Submitting a Service Request**

For information on obtaining documentation, submitting a service request, and gathering additional information, see the monthly *What's New in Cisco Product Documentation*, which also lists all new and revised Cisco technical documentation, at

http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html

Subscribe to the *What's New in Cisco Product Documentation* as a Really Simple Syndication (RSS) feed and set content to be delivered directly to your desktop using a reader application. The RSS feeds are a free service and Cisco currently supports RSS Version 2.0.

# **Document Change History**

The following table lists the revision history for the *Cisco BTS 10200 Softswitch PCSP Programmer's Guide, Release 6.0.4.* 

| Version Number | Issue Date      | Status  | Reason for Change                  |
|----------------|-----------------|---------|------------------------------------|
| OL-25013-02    | May 14,<br>2012 | Initial | Initial document for Release 6.0.4 |