

SPA3102 interactieve spraak-respons (IVR)-menu gebruiken

Doel

De interactieve spraakrespons geeft instructies voor verschillende configuraties binnen het apparaat. Deze instructies worden verkregen bij het aansluiten van een telefoon op het apparaat. Dit document biedt een beter begrip van het IVR-menu van SPA3102 (Interactive Voice Response).

Toepasselijke apparaten

- SPA8000
- SPA3102
- SPA9000
- SPA2102
- SPA112
- PAP2T

Softwareversie

- v6.1.12

Interactive Voice Response (IVR)-menu

Het Interactive Voice Response-menu gebruiken

Stap 1. Gebruik een telefoon die op de TELEFOONpoort van de Spraakgateway is aangesloten. Het Interactive Voice Response-menu is alleen toegankelijk via een analoge telefoon.

Stap 2. Druk op vier sterretjes (*)-toetsen.

Stap 3. Wacht tot u de voicemail-melding "Linksys-configuratiemenu" hoort. Voer de optie in die wordt gevolgd door de # (pound)-toets of hang omhoog om te sluiten".

Stap 4. Raadpleeg de volgende tabel waarin acties, opdrachten, menukeuzes en beschrijvingen zijn opgenomen. Druk na het selecteren van een optie op de # (pound)-toets. Als u het menu wilt verlaten, hangt u de telefoon op.

Het Interactive Voice Response-menu

IVR Action	IVR Menu	Parameter(s)	Notes
Activate IVR Menu	****	None	Ignore SIT or other tones until you hear, "Sipura configuration menu. Please enter option followed by the pound key or hang-up to exit."
Check WAN IP Address	110	None	IVR will announce the IP address of the WAN port
Check WAN Network Mask	120	None	IVR will announce the network mask of the WAN port
Check WAN Gateway	130	None	IVR will announce the gateway of the WAN port
Check MAC Address	140	None	IVR will announce MAC address of the SPA-2100
Check Firmware Version	150	None	IVR will announce the firmware version running on SPA-2100
Check Primary DNS Server IP Address	160	None	IVR will announce the primary DNS server IP address
Check WAN Port Web Server Port	170	None	IVR will announce the WAN port web server port
Check LAN IP Address	210	None	IVR will announce the IP address of the LAN port
Check WAN Internet Connection Type	100	None	IVR will announce the WAN Internet Connection Type
Set WAN Internet Connection Type (see "Wan Setup" -> "Internet Connection Settings")	101	Enter 0 to use DHCP Enter 1 to use Static IP Enter 3 to use PPPoE	Requires Password
Set Static IP address (WAN Port)	111	Enter IP address using numbers on the telephone keypad. Use the * (star) key when enter a decimal point	WAN Internet Connection Type must be set to "Static IP", otherwise you will hear "Invalid Option" when you try to use this option. Requires Password.
Set WAN Network Mask	121	Enter network mask using numbers on the telephone keypad. Use the * (star) key when enter a decimal point	WAN Internet Connection Type must be set to "Static IP", otherwise you will hear "Invalid Option" when you try to use this option. Requires Password.
Set WAN Gateway	131	Enter IP address using numbers on the telephone keypad. Use the * (star) key when entering a decimal point.	WAN Internet Connection Type must be set to "Static IP", otherwise you will hear "Invalid Option" when you try to use this option. Requires Password.
Set Primary DNS Server IP Address	161	Enter IP address using numbers on the telephone keypad. Use the * (star) key when entering a decimal point.	Requires Password.
		Press 0 to select the router/NAT mode.	If the Voice Gateway acts as the router for your network, use the

Opmerking: Als het wachtwoord van de beheerder niet is ingesteld of de gebruiker het wachtwoord mag wijzigen, zijn voor de items met een *Wachtwoord* vereist geen wachtwoord.