

Acesso ao menu Resposta de Voz Interativa (IVR) SPA3102

Objetivo

A resposta de voz interativa fornece instruções para diferentes configurações dentro do dispositivo. Essas instruções são obtidas quando um telefone é conectado ao dispositivo. Este documento fornece uma melhor compreensão do menu de Resposta de Voz Interativa (IVR - Interactive Voice Response) do SPA3102.

Dispositivos aplicáveis

SPA8000

SPA3102

SPA9000

SPA2102

SPA112

PAP2T

Versão de software

•v6.1.12

Menu de Resposta de Voz Interativa (IVR)

Acesso ao menu de resposta de voz interativa

Etapa 1. Use um telefone conectado à porta do TELEFONE do Gateway de Voz. O menu de resposta de voz interativa só pode ser acessado através de um telefone analógico.

Etapa 2. Pressione quatro teclas de asterisco (*).

Etapa 3. Aguarde até ouvir o aviso de voz e diga "Linksys configuration menu. Insira a opção seguida pela tecla # (libra) ou desligue para sair".

Etapa 4. Consulte a tabela a seguir que lista ações, comandos, opções de menu e descrições. Depois de selecionar uma opção, pressione a tecla # (libra). Para sair do menu, desligue o telefone.

O menu Resposta de voz interativa

IVR Action	IVR Menu	Parameter(s)	Notes
Activate IVR Menu	****	None	Ignore SIT or other tones until you hear, "Sipura configuration menu. Please enter option followed by the pound key or hang-up to exit."
Check WAN IP Address	110	None	IVR will announce the IP address of the WAN port
Check WAN Network Mask	120	None	IVR will announce the network mask of the WAN port
Check WAN Gateway	130	None	IVR will announce the gateway of the WAN port
Check MAC Address	140	None	IVR will announce MAC address of the SPA-2100
Check Firmware Version	150	None	IVR will announce the firmware version running on SPA-2100
Check Primary DNS Server IP Address	160	None	IVR will announce the primary DNS server IP address
Check WAN Port Web Server Port	170	None	IVR will announce the WAN port web server port
Check LAN IP Address	210	None	IVR will announce the IP address of the LAN port
Check WAN Internet Connection Type	100	None	IVR will announce the WAN Internet Connection Type
Set WAN Internet Connection Type (see "Wan Setup" -> "Internet Connection Settings")	101	Enter 0 to use DHCP Enter 1 to use Static IP Enter 3 to use PPPoE	Requires Password
Set Static IP address (WAN Port)	111	Enter IP address using numbers on the telephone keypad. Use the * (star) key when enter a decimal point	WAN Internet Connection Type must be set to "Static IP", otherwise you will hear "Invalid Option" when you try to use this option. Requires Password.
Set WAN Network Mask	121	Enter network mask using numbers on the telephone keypad. Use the * (star) key when enter a decimal point	WAN Internet Connection Type must be set to "Static IP", otherwise you will hear "Invalid Option" when you try to use this option. Requires Password.
Set WAN Gateway	131	Enter IP address using numbers on the telephone keypad. Use the * (star) key when entering a decimal point.	WAN Internet Connection Type must be set to "Static IP", otherwise you will hear "Invalid Option" when you try to use this option. Requires Password.
Set Primary DNS Server IP Address	161	Enter IP address using numbers on the telephone keypad. Use the * (star) key when entering a decimal point.	Requires Password.
		Press 0 to select the router/NAT mode.	If the Voice Gateway acts as the router for your network, use the

Note: Se a senha do administrador não estiver definida ou o usuário tiver permissão para alterá-la, os itens marcados como *Requer senha* não exigirão uma senha.