



# PPP-Max-Payload and IWF PPPoE Tag Support

**Last Updated: December 1, 2011**

The PPP-Max-Payload and IWF PPPoE Tag Support feature enables the Point-to-Point Protocol (PPP) over Ethernet (PPPoE) component to process the PPP-Max-Payload and Interworking Functionality (IWF) PPPoE tags in the PPPoE discovery frame:

- The **tag ppp-max-payload** command allows PPPoE peers to negotiate PPP maximum receive units (MRUs) greater than 1492 octets if the underlying network supports a maximum transmission unit (MTU) size greater than 1500 octets.
- The IWF PPPoE tag allows the Broadband Remote Access Server (BRAS) to distinguish the IWF PPPoE from the regular PPPoE sessions to overcome the per-MAC session limit put on the BRAS as a protection from denial of service (DOS) attacks sourced from the same MAC address.
- [Finding Feature Information, page 1](#)
- [Prerequisites for the PPP-Max-Payload and IWF PPPoE Tag Support Feature, page 2](#)
- [Restrictions for the PPP-Max-Payload and IWF PPPoE Tag Support Feature, page 2](#)
- [Information About the PPP-Max-Payload and IWF PPPoE Tag Support Feature, page 2](#)
- [How to Configure the PPP-Max-Payload and IWF PPPoE Tag Support Feature, page 3](#)
- [Configuration Examples for the PPP-Max Payload and IWF PPPoE Tag Support Feature, page 6](#)
- [Additional References, page 7](#)
- [Feature Information for PPP-Max Payload and IWF PPPoE Tag Support, page 8](#)
- [Glossary, page 9](#)

## Finding Feature Information

Your software release may not support all the features documented in this module. For the latest feature information and caveats, see the release notes for your platform and software release. To find information about the features documented in this module, and to see a list of the releases in which each feature is supported, see the Feature Information Table at the end of this document.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to [www.cisco.com/go/cfn](http://www.cisco.com/go/cfn). An account on Cisco.com is not required.



---

**Americas Headquarters:**  
Cisco Systems, Inc., 170 West Tasman Drive, San Jose, CA 95134-1706 USA

## Prerequisites for the PPP-Max-Payload and IWF PPPoE Tag Support Feature

To enable the PPP-Max-Payload and IWF PPPoE Tag Support feature, you should have configured PPPoE profile.

## Restrictions for the PPP-Max-Payload and IWF PPPoE Tag Support Feature

PPPoE peers can negotiate only MRUs with a maximum of 1492 octets so that the PPPoE header and PPP protocol ID can be inserted in the PPPoE session data packet.

## Information About the PPP-Max-Payload and IWF PPPoE Tag Support Feature

- [Accommodating an MTU MRU Greater than 1492 in PPPoE, page 2](#)
- [Interworking Functionality, page 2](#)

## Accommodating an MTU MRU Greater than 1492 in PPPoE

Per the RFC, Accommodating an MTU/MRU Greater than 1492 in PPPoE, PPPoE peers can negotiate only MRUs with a maximum of 1492 octets so that the PPPoE header and PPP protocol ID can be inserted in the PPPoE session data packet. The maximum for an Ethernet payload is 1500 octets.

RFC 2516 defines a new tag to allow PPPoE peers to negotiate PPP MRU greater than 1492 if the underlying networks can support an Ethernet payload of greater than 1500 bytes. To enable processing of this new tag, a command has been defined in the Cisco IOS command-line interface as **tag ppp-max-payload**. The PPP-Max-Payload and IWF PPPoE Tag Support feature enhances the PPPoE component so the **tag ppp-max-payload** command can process the new tag to influence the Link Control Protocol (LCP) MRU negotiations for the PPP session based on the MRU value specified in the tag from the PPPoE client.

## Interworking Functionality

The DSL Forum defined IWF to define the process for conversion of PPP over ATM (PPPoA) sessions to PPPoE sessions at the digital subscriber line access multiplexer (DSLAM) to the BRAS. This functionality was defined to help the migration of DSLAM networks from ATM to Ethernet media. So, essentially, the PPPoA session comes in to the DSLAM over ATM and is converted to a PPPoE session at the DSLAM, which is then connected to the BRAS as a PPPoE session. Each PPPoA session is mapped to a corresponding PPPoE session.

Typically, the BRAS is configured to limit PPPoE sessions originating from the same MAC address to protect itself from a DOS attack. This presents a problem for IWF PPPoE sessions because all PPPoE sessions originate from the same MAC address DSLAM. To overcome this issue, the IWF PPPoE tag is inserted at the DSLAM and read by the BRAS to distinguish the IWF PPPoE session from the regular PPPoE session during the PPPoE discovery frames.

For more information about this subject, refer to the DSL Forum Technical Report 101: *Migration to Ethernet-Based DSL Aggregation*.

# How to Configure the PPP-Max-Payload and IWF PPPoE Tag Support Feature

- [Enabling the PPP-Max-Payload and IWF PPPoE Tag Support Feature, page 3](#)
- [Disabling the PPP-Max-Payload and IWF PPPoE Tag Support Feature, page 5](#)

## Enabling the PPP-Max-Payload and IWF PPPoE Tag Support Feature

To enable the PPP-Max-Payload and IWF PPPoE Tag Support feature, perform this task.

### SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **bba-group pppoe** *group-name*
4. **virtual-template** *template-number*
5. **tag ppp-max-payload** [**minimum** *value* **maximum** *value*] [**deny**]
6. **sessions per-mac limit** *per-mac-limit*
7. **interface ethernet** *slot / port*
8. **pppoe enable group** *group-name*
9. **virtual-template** *template-number*
10. **ppp lcp echo mru verify** [**minimum** *value*]
11. **end**
12. **show pppoe session** [**all**] **packets**]

### DETAILED STEPS

	Command or Action	Purpose
Step 1	<b>enable</b>  <b>Example:</b> Router> enable	Enables privileged EXEC mode. <ul style="list-style-type: none"> <li>• Enter your password if prompted.</li> </ul>
Step 2	<b>configure terminal</b>  <b>Example:</b> Router# configure terminal	Enters global configuration mode.

	Command or Action	Purpose
Step 3	<b>bba-group pppoe</b> <i>group-name</i>  <b>Example:</b>  <pre>Router(config)# bba-group pppoe ppoe-group</pre>	Enters BBA group configuration mode and defines a PPPoE profile.
Step 4	<b>virtual-template</b> <i>template-number</i>  <b>Example:</b>  <pre>Router(config-bba-group)# virtual- template 1</pre>	Configures a PPPoE profile with a virtual template to be used for cloning virtual access interfaces. <ul style="list-style-type: none"> <li>The <i>template-number</i> argument is an identifying number of the virtual template that will be used to clone virtual-access interfaces.</li> </ul>
Step 5	<b>tag ppp-max-payload</b> [ <b>minimum value</b> <b>maximum value</b> ] [ <b>deny</b> ]  <b>Example:</b>  <pre>Router(config-bba-group)# tag ppp- max-payload minimum 1200 maximum 3000</pre>	Specifies a range for the ppp-max payload tag value that will be accepted by the BRAS. <ul style="list-style-type: none"> <li>Default values are 1492 for the minimum and 1500 for the maximum.</li> <li>The ppp-max-payload tag value accepted from the client cannot exceed the physical interface value for MTU minus 8.</li> </ul>
Step 6	<b>sessions per-mac limit</b> <i>per-mac-limit</i>  <b>Example:</b>  <pre>Router(config-bba-group)# sessions per-mac iwf limit 200</pre>	Specifies a limit for IWF-specific sessions per MAC address (separate from session limits that are not IWF-specific). <ul style="list-style-type: none"> <li>If this command is not entered, the normal MAC-address session limit is applied to IWF sessions.</li> <li>The <i>per-mac-limit</i> argument specifies the allowable number of IWF sessions. The default is 100.</li> </ul>
Step 7	<b>interface ethernet</b> <i>slot / port</i>  <b>Example:</b>  <pre>Router(config-bba-group)# interface ethernet 1/0</pre>	Enters interface configuration mode for an Ethernet interface: <ul style="list-style-type: none"> <li>The <i>slot / port</i> arguments identify the slot number and the port number to which this configuration applies.</li> <li>The slash mark is required.</li> </ul>
Step 8	<b>pppoe enable group</b> <i>group-name</i>  <b>Example:</b>  <pre>Router(config-if)# pppoe enable group 1</pre>	Enables PPPoE sessions on an Ethernet interface or subinterface.

	Command or Action	Purpose
Step 9	<b>virtual-template</b> <i>template-number</i>  <b>Example:</b>  <pre>Router(config-if)# virtual-template 1</pre>	Configures a PPPoE profile with a virtual template to be used for cloning virtual access interfaces. <ul style="list-style-type: none"> <li>The <i>template-number</i> argument is an identifying number of the virtual template that will be used to clone virtual-access interfaces.</li> </ul>
Step 10	<b>ppp lcp echo mru verify</b> [ <b>minimum value</b> ]  <b>Example:</b>  <pre>Router(config-if)# ppp lcp echo mru verify minimum 1304</pre>	Verifies the negotiated MRU and adjusts the PPP virtual access interface MTU for troubleshooting purposes. <ul style="list-style-type: none"> <li>If the optional <b>minimum</b> keyword is entered, the <i>value</i> can be from 64 to 1500.</li> <li>If the verification of minimum MTU succeeds, the PPP connection's interface MTU is set to that value. This reset is useful when you troubleshoot and need to adjust the sessions according to underlying physical network capability. After this command is configured, IP Control Protocol (IPCP) is delayed until verification of the MTU is completed at the LCP.</li> </ul>
Step 11	<b>end</b>  <b>Example:</b>  <pre>Router(config-if)# end</pre>	Exits the current configuration mode and returns to privileged EXEC mode.
Step 12	<b>show pppoe session</b> [ <b>all</b>   <b>packets</b> ]  <b>Example:</b>  <pre>Router# show pppoe session all</pre>	Verifies the configuration and displays session information. <ul style="list-style-type: none"> <li><b>all</b> --Displays output indicating if a session is IWF-specific or if the PPP-Max-Payload tag is in the discovery frame and accepted.</li> <li><b>packets</b> --Displays packet statistics for the PPPoE session.</li> </ul>

## Disabling the PPP-Max-Payload and IWF PPPoE Tag Support Feature

The tag **ppp-max-payload** command adjusts PPP MTU of the PPPoE session above the default maximum limit of 1492 bytes. But MTU values greater than 1492 can only be supported (with PPPoE) if the underlying Ethernet network supports these larger frames. Not all Ethernet networks support higher values. If your network does not support values higher than the default maximum, you should disable the PPP-Max-Payload and IWF PPPoE Tag Support feature by performing this task.

### SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **bba-group pppoe** *group-name*
4. **tag ppp-max-payload deny**
5. **end**

## DETAILED STEPS

Command or Action	Purpose
<b>Step 1</b> <code>enable</code>  <b>Example:</b> <pre>Router&gt; enable</pre>	Enables privileged EXEC mode. <ul style="list-style-type: none"> <li>Enter your password if prompted.</li> </ul>
<b>Step 2</b> <code>configure terminal</code>  <b>Example:</b> <pre>Router# configure terminal</pre>	Enters interface configuration mode.
<b>Step 3</b> <code>bba-group pppoe group-name</code>  <b>Example:</b> <pre>Router(config-if)# bba-group pppoe pppoe-group</pre>	Enters BBA group configuration mode and defines a PPPoE profile.
<b>Step 4</b> <code>tag ppp-max-payload deny</code>  <b>Example:</b> <pre>Router(config-bba-group)# tag ppp-max-payload deny</pre>	Disables the processing of the ppp-max-payload tag value higher than the default of 1492 bytes.
<b>Step 5</b> <code>end</code>  <b>Example:</b> <pre>Router(config-bba-group)# end</pre>	Exits the BBA group configuration mode and returns to privileged EXEC mode.

## Configuration Examples for the PPP-Max Payload and IWF PPPoE Tag Support Feature

This section provides a sample configuration showing the PPP-Max-Payload and IWF PPPoE Tag Support feature enabled and a configuration in which the effects of this feature are disabled:

- [Configuration with the PPP-Max-Payload and IWF PPPoE Tag Support Feature Enabled Example, page 7](#)
- [Configuration with the PPP-Max-Payload and IWF PPPoE Tag Support Feature Disabled Example, page 7](#)

## Configuration with the PPP-Max-Payload and IWF PPPoE Tag Support Feature Enabled Example

The following configuration example shows the PPP-Max-Payload and IWF PPPoE Tag Support enabled to accept PPP-Max-Payload tag values from 1492 to 1892, limits the number of sessions per MAC address to 2000 when the IWF is present, and verifies that the PPP session can accept 1500-byte packets in both directions:

```
bba-group pppoe global
virtual-template 1
tag ppp-max-payload minimum 1492 maximum 1892
sessions per-mac limit 1
sessions per-mac iwf limit 2000
!
interface Virtual-Template 1
!
```

## Configuration with the PPP-Max-Payload and IWF PPPoE Tag Support Feature Disabled Example

The following configuration example disables the effect of the **tag ppp-max-payload** command:

```
bba-group pppoe global
virtual-template 1
tag ppp-max-payload deny
```

## Additional References

The following sections provide references related to the PPP-Max-Payload and IWF PPPoE Tag Support feature.

### Related Documents

Related Topic	Document Title
Command reference information for broadband and DSL	Cisco IOS Broadband Access Aggregation and DSL Command Reference

### Standards

Standard	Title
DSL Forum Technical Report 101	<i>Migration to Ethernet-Based DSL Aggregation</i>

**MIBs**

MIB	MIBs Link
No new or modified MIBs are supported by this feature, and support for existing MIBs has not been modified by this feature.	To locate and download MIBs for selected platforms, Cisco IOS releases, and feature sets, use Cisco MIB Locator found at the following URL: <a href="http://www.cisco.com/go/mibs">http://www.cisco.com/go/mibs</a>

**RFCs**

RFC	Title
RFC 2516	<a href="#">A Method for Transmitting PPP Over Ethernet (PPPoE)</a>
Draft RFC document	<a href="#">Accommodating an MTU/MRU Greater than 1492 in PPPoE</a>

**Technical Assistance**

Description	Link
<p>The Cisco Support website provides extensive online resources, including documentation and tools for troubleshooting and resolving technical issues with Cisco products and technologies.</p> <p>To receive security and technical information about your products, you can subscribe to various services, such as the Product Alert Tool (accessed from Field Notices), the Cisco Technical Services Newsletter, and Really Simple Syndication (RSS) Feeds.</p> <p>Access to most tools on the Cisco Support website requires a Cisco.com user ID and password.</p>	<a href="http://www.cisco.com/techsupport">http://www.cisco.com/techsupport</a>

## Feature Information for PPP-Max Payload and IWF PPPoE Tag Support

The following table provides release information about the feature or features described in this module. This table lists only the software release that introduced support for a given feature in a given software release train. Unless noted otherwise, subsequent releases of that software release train also support that feature.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to [www.cisco.com/go/cfn](http://www.cisco.com/go/cfn). An account on Cisco.com is not required.



**Table 1 Feature Information for PPP-Max-Payload and IWF PPPoE Tag Support**

Feature Name	Releases	Feature Information
PPP-Max Payload and IWF PPPoE Tag Support	12.2(31)SB2 12.2(33)SRC 15.0(1)M	<p>The PPP-Max-Payload and IWF PPPoE Tag Support feature enables the PPP over Ethernet (PPPoE) component to process the PPP-Max-Payload and Interworking Functionality (IWF) PPPoE tags in the PPPoE discovery frame:</p> <ul style="list-style-type: none"> <li>• The <b>tag ppp-max-payload</b> command allows PPPoE peers to negotiate PPP maximum receive units (MRUs) greater than 1492 octets if the underlying network supports a maximum transmission unit (MTU) size greater than 1500 octets.</li> <li>• The IWF PPPoE tag allows the Broadband Remote Access Server (BRAS) to distinguish the IWF PPPoE from the regular PPPoE sessions to overcome the per-MAC session limit put on the BRAS as a protection from denial of service (DOS) attacks sourced from the same MAC address.</li> </ul> <p>The following commands were introduced or modified:</p> <p><b>ppp lcp echo mru verify , tag ppp-max-payload</b></p>

## Glossary

**BBA** --Broadband access.

**BRAS** --Broadband Remote Access Server, typically acting as a PPPoE server.

**DOS** --Denial of service (a form of security attacks).

**DSLAM** --Digital subscriber line access multiplexer.

**IPCP** --IP Control Protocol.

**IWF** --Interworking Functionality (used to describe the PPPoA conversion to PPPoE sessions at the DSLAM).

**IWF PPPoE session** --A PPPoE session from the DSLAM to the BRAS that is actually a PPPoA session from the end user to the DSLAM.

**LCP** --Link Control Protocol.

**MRU** --PPP maximum received unit as negotiated in LCP.

**MTU** --Maximum transmission unit of an interface.

**PADO** --PPPoE Active Discovery Offer.

**PADR** --PPPoE Active Discovery Request.

**PADS** --PPPoE Active Discovery Session Confirmation.

**PPP** --Point-to-Point Protocol

**PPPoE** --PPP over Ethernet protocol or PPPoE component.

**VPDN** --virtual private dialup network.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: [www.cisco.com/go/trademarks](http://www.cisco.com/go/trademarks). Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1110R)

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

© 2011 Cisco Systems, Inc. All rights reserved.