



Introduction

This document describes the commands used to configure IP switching features such as Cisco Express Forwarding, Distributed Cisco Express Forwarding, and Fast Switching in Cisco IOS software.



Note

Prior to Cisco IOS Release 12.3(14)T, the commands for configuring IP switching features were presented in the *Cisco IOS Switching Services Command Reference*.

Refer to the configuration guide indicated here for configuration guidelines:

For Information About Configuring This Cisco IOS Feature...	Refer to the Following Cisco IOS Configuration Guide...
IP switching features	<i>Cisco IOS IP Switching Configuration Guide</i> .

