



---

## A

About screen [1-3](#)

### action

activate [2-3](#)

deactivate [2-3](#)

delete [2-3](#)

manage [2-3](#)

start [2-2, 2-3](#)

stop [2-3](#)

upgrade [2-3](#)

activate action [2-3](#)

ACTIVATED status [2-2](#)

activating, app [3-2](#)

### adding

app [3-2](#)

internal network [3-16](#)

### app

activating [3-2](#)

adding [3-2](#)

configuration file [2-16, 3-8](#)

console access [3-9](#)

### container

managing [2-16](#)

### data directory

deleting file from [3-11](#)

downloading file from [3-11](#)

uploading file to [3-10](#)

deactivating [3-5](#)

deleting [3-7](#)

deploying [3-2](#)

host system resources for [2-12](#)

lifecycle workflows [3-1](#)

log file [2-17, 3-10](#)

resource profile [2-12, 3-3](#)

starting [3-5](#)

status [2-2, 3-1](#)

stopping [3-6](#)

upgrading [3-6](#)

### *App-ID* page

#### App-Config page

accessing [2-16](#)

description [2-16](#)

fields and options [2-16](#)

#### App-DataDir page

accessing [2-16](#)

description [2-16](#)

fields and options [2-17](#)

#### App-info page

accessing [2-14](#)

description [2-13](#)

fields and options [2-14](#)

#### description [2-11](#)

#### Logs page

accessing [2-17](#)

description [2-17](#)

fields and options [2-17](#)

#### Resources page

accessing [2-11](#)

description [2-11](#)

fields and options [2-12](#)

tabs [2-11](#)

### *App-ID* tab

App-Config [2-11](#)

App-DataDir [2-11](#)

App-info [2-11](#)

- description [2-2](#)
- displaying [2-11](#)
- Logs [2-11](#)
- removing from menu bar [2-2, 2-11](#)
- Resources [2-11](#)

#### Applications page

- accessing [2-2](#)
- description [2-1, 2-2](#)
- fields and options [2-2](#)

#### Applications tab, description [2-1](#)

#### app signature validation

- configuring [3-20](#)
- description [3-20](#)

---

## B

- browser guidelines and requirements [1-1](#)

---

## C

#### cartridge

- deleting [3-13](#)
- description [2-4, 3-12](#)
- for PAAS app [2-4, 3-12](#)
- installing [3-12](#)
- viewing information about [3-14](#)

#### Cartridges page

- accessing [2-4](#)
- description [2-4](#)
- fields and options [2-4](#)

#### Cartridges tab, description [2-1](#)

#### Cisco Data in Motion

- description [2-10](#)
- license, uploading [3-14](#)
- starting [3-15](#)
- status [2-10](#)
- stopping [3-15](#)

#### Cisco IOx

- framework [1-1](#)
- network
  - See* network, internal
- overview [1-1](#)

#### Cisco IOx Local Manager

- About screen [1-3](#)
- Cartridges [2-4, 3-12](#)
- exiting [1-3](#)
- logging in to [1-2](#)
- logging out [1-3](#)
- overview [1-1](#)
- pages
  - App-ID* [2-11](#)
  - App-ID* > App-Config [2-16](#)
  - App-ID* > App-DataDir [2-16](#)
  - App-ID* > App-info [2-13](#)
  - App-ID* > Logs [2-17](#)
  - App-ID* > Resources [2-11](#)
  - Applications [2-2](#)
  - Middleware Service [2-10, 3-14](#)
  - System Info [2-4](#)
  - System Setting [2-5](#)
  - System Troubleshoot [2-7](#)
- SSL connection to the CAF [3-19](#)
- starting [1-2](#)
- tabs [2-1](#)
- timeout period [1-2](#)

#### configuration file

- description [2-16, 3-8](#)
- package\_config.ini [2-16, 3-8](#)
- updating [3-8](#)

#### configuring

- host system for Cisco IOx [1-2](#)
- log file [3-23](#)

#### console access, of app [3-9](#)

#### container of app

- managing [2-16](#)

core dump file  
 deleting [2-10, 3-27](#)  
 description [3-27](#)  
 downloading [2-10, 3-27](#)  
 CPU, on host system [2-12, 3-2](#)

---

## D

data directory  
 deleting file from [3-11](#)  
 downloading file from [3-11](#)  
 uploading file to [3-10](#)  
 deactivate action [2-3](#)  
 deactivating, app [3-5](#)  
 delete action [2-3](#)  
 deleting  
 app [3-7](#)  
 app data directory file [3-11](#)  
 cartridge [3-13](#)  
 core dump file [3-27](#)  
 internal network [3-18](#)  
 snapshot file [3-26](#)  
 DEPLOYED status [2-2](#)  
 deploying app [3-2](#)  
 diagnostic information  
 description [3-25](#)  
 generating [3-25](#)  
 viewing [3-25](#)  
 downloading  
 app log file [3-10](#)  
 core dump file [3-27](#)  
 from data directory [3-11](#)  
 log file [3-24](#)  
 snapshot file [3-26](#)

---

## E

editing, internal network [3-18](#)

error  
 description [3-22](#)  
 viewing [3-22](#)  
 event  
 description [3-21](#)  
 viewing [3-21](#)  
 exiting, Cisco IOx Local Manager [1-3](#)

---

## F

flash storage, caveat [1-2](#)

---

## G

generating, snapshot file [3-26](#)

---

## H

host system  
 CPU [2-12](#)  
 error  
 description [3-22](#)  
 viewing [3-22](#)  
 event  
 description [3-21](#)  
 viewing [3-21](#)  
 log file [2-9, 3-24](#)  
 configuring [3-23](#)  
 description [3-23](#)  
 downloading [3-24](#)  
 memory [2-12](#)  
 resources [2-12](#)

---

## I

installing, cartridge [3-12](#)

## L

license, uploading for Cisco Data in Motion [3-14](#)

license, uploading for middleware [3-14](#)

log file

app [2-17, 3-10](#)

configuring [3-23](#)

description [3-23](#)

downloading [3-24](#)

downloading app log file [3-10](#)

host system [2-9, 3-24](#)

logging in, to Cisco IOx Local Manager [1-2](#)

logging out, from Cisco IOx Local Manager [1-3](#)

## M

manage action [2-3](#)

memory, on host system [2-12, 3-2](#)

middleware

license, uploading [3-14](#)

starting [3-15](#)

status [2-10](#)

stopping [3-15](#)

Middleware Service page

accessing [2-10](#)

description [2-10](#)

fields and options [2-10](#)

Middleware Service tab, description [2-1](#)

## N

network, internal

adding [3-16](#)

deleting [3-18](#)

description [2-6, 3-16](#)

editing [3-18](#)

svcbr\_0 [2-6, 3-18](#)

viewing information about [3-17](#)

## O

ordering information on pages [2-2](#)

## P

PAAS app, cartridge for [2-4, 3-12](#)

package\_config.ini configuration file [2-16, 3-8](#)

## R

refresh, information on pages [1-2](#)

resource profile [2-12, 3-3](#)

resources, on host system [2-12, 3-2](#)

RUNNING status [2-2](#)

## S

snapshot file

deleting [2-9, 3-26](#)

description [2-9, 3-25](#)

downloading [2-9, 3-26](#)

generating [3-26](#)

SSL

certificate [3-19](#)

connection, configuring [3-19](#)

start action [2-2, 2-3](#)

starting

app [3-5](#)

Cisco Data in Motion [3-15](#)

middleware [3-15](#)

starting Cisco IOx Local Manager [1-2](#)

status

ACTIVATED [2-2](#)

DEPLOYED [2-2](#)

of app [2-2, 3-1](#)

RUNNING [2-2](#)

STOPPED [2-2](#)

stop action [2-3](#)  
 STOPPED status [2-2](#)  
 stopping
 

- app [3-6](#)
- Cisco Data in Motion [3-15](#)
- middleware [3-15](#)

 System Info page
 

- accessing [2-5](#)
- description [2-4](#)
- fields and options [2-5](#)

 System Info tab, description [2-1](#)  
 System Setting page
 

- accessing [2-6](#)
- description [2-5](#)
- fields and options [2-6](#)

 System Troubleshoot page
 

- accessing [2-8](#)
- description [2-7](#)
- fields and options [2-8](#)

 System Troubleshoot tab, description [2-1](#)

---

## T

tab
 

- accessing [2-1](#)
- App-ID [2-2](#)
- App-ID* > App-Config [2-11](#)
- App-ID* > App-DataDir [2-11](#)
- App-ID* > App-Info [2-11](#)
- App-ID* > Logs [2-11](#)
- App-ID* > Resources [2-11](#)
- Applications [2-1](#)
- Cartridges [2-1](#)
- in Cisco IOx Local Manager [2-1](#)
- Middleware Service [2-1](#)
- System Info [2-1](#)
- System Troubleshoot [2-1](#)

 timeout period [1-2](#)  
 trust anchor [2-7, 3-20](#)

---

## U

updating, configuration file [3-8](#)  
 upgrade action [2-3](#)  
 upgrading, app [3-6](#)  
 uploading, file to app data directory [3-10](#)

---

## V

viewing
 

- cartridge information [3-14](#)
- errors [3-22](#)
- events [3-21](#)

 visualization, of app data [2-3](#)

