

Preface

This preface contains the following sections:

- · Audience, page i
- Document Conventions, page i
- Related Documentation for Nexus 3548 Switch NX-OS Software, page ii
- Documentation Feedback, page iii

Audience

This publication is for experienced network administrators who configure and maintain Cisco Nexus devices

Document Conventions

Command descriptions use the following conventions:

Convention	Description
bold	Bold text indicates the commands and keywords that you enter literally as shown.
Italic	Italic text indicates arguments for which the user supplies the values.
[x]	Square brackets enclose an optional element(keyword or argument).
[x y]	Square brackets enclosing keywords or arguments separated by a vertical bar indicate an optional choice.
{x y}	Braces enclosing keywords or arguments separated by a vertical bar indicate a required choice.

Convention	Description
[x {y z}]	Nested set of square brackets or braces indicate optional or required choices within optional or required elements. Braces and a vertical bar within square brackets indicate a required choice within an optional element.
variable	Indicates a variable for which you supply values, in context where italics cannot be used.
string	A nonquoted set of characters. Do not use quotation marks around the string or the string will include the quotation marks.

Examples use the following conventions:

Convention	Description
screen font	Terminal sessions and information the switch displays are in screen font.
boldface screen font	Information you must enter is in boldface screen font.
italic screen font	Arguments for which you supply values are in italic screen font.
<>	Nonprinting characters, such as passwords, are in angle brackets.
[]	Default responses to system prompts are in square brackets.
!,#	An exclamation point (!) or a pound sign (#) at the beginning of a line of code indicates a comment line.

This document uses the following conventions:



Note

Means reader take note. Notes contain helpful suggestions or references to material not covered in the manual.



Means reader be careful. In this situation, you might do something that could result in equipment damage or loss of data.

Related Documentation for Nexus 3548 Switch NX-OS Software

The Cisco Nexus 3548 Switch NX-OS documentation set is available at the following URL: http://www.cisco.com/en/US/products/ps11541/tsd_products_support_series_home.html

Release Notes

The release notes are available at the following URL:

http://cisco.com/en/US/products/ps11541/prod release notes list.html

Installation and Upgrade Guides

The installation and upgrade guides are available at the following URL:

http://cisco.com/en/US/products/ps11541/prod installation guides list.html

License Information

For information about feature licenses in NX-OS, see the *Cisco NX-OS Licensing Guide*, available at the following URL: http://www.cisco.com/en/US/docs/switches/datacenter/sw/nx-os/licensing/guide/b_Cisco_NX-OS Licensing Guide.html.

For the NX-OS end user agreement and copyright information, see *License and Copyright Information for Cisco NX-OS Software*, available at the following URL: http://www.cisco.com/en/US/docs/switches/datacenter/sw/4_0/nx-os/license_agreement/nx-ossw_lisns.html.

Configuration Guides

The configuration guides are available at the following URL:

http://cisco.com/en/US/products/ps11541/products_installation_and_configuration_guides_list.html

Command References

The command references are available at the following URL:

http://cisco.com/en/US/products/ps11541/prod_command_reference_list.html

Error and System Messages

The error and system message reference guides are available at the following URL:

http://cisco.com/en/US/products/ps11541/products_system_message_guides_list.html

Documentation Feedback

To provide technical feedback on this document, or to report an error or omission, please send your comments to nexus3k-docfeedback@cisco.com . We appreciate your feedback.

Documentation Feedback