



T Show Commands

- [show table-map](#), on page 6
- [show tacacs-server](#), on page 7
- [show tacacs-server \(host0\)](#), on page 8
- [show tacacs-server directed-request](#), on page 9
- [show tacacs-server groups](#), on page 10
- [show tacacs-server sorted](#), on page 11
- [show tacacs-server statistics](#), on page 12
- [show tech-support](#), on page 13
- [show tech-support aaa](#), on page 14
- [show tech-support aclmgr](#), on page 15
- [show tech-support aclmgr compressed](#), on page 16
- [show tech-support aclqos](#), on page 17
- [show tech-support aclqos](#), on page 18
- [show tech-support aclqos compressed](#), on page 19
- [show tech-support adjmgr](#), on page 20
- [show tech-support all-binary](#), on page 21
- [show tech-support all](#), on page 22
- [show tech-support all binary](#), on page 23
- [show tech-support arp](#), on page 24
- [show tech-support ascii-cfg](#), on page 25
- [show tech-support bfd](#), on page 26
- [show tech-support bgp](#), on page 27
- [show tech-support biosd](#), on page 28
- [show tech-support bloggerd-all](#), on page 29
- [show tech-support bloggerd](#), on page 30
- [show tech-support bootvar](#), on page 31
- [show tech-support brief](#), on page 32
- [show tech-support callhome](#), on page 33
- [show tech-support cdp](#), on page 34
- [show tech-support cert-enroll](#), on page 35
- [show tech-support cfs](#), on page 36
- [show tech-support cli](#), on page 37
- [show tech-support clis](#), on page 38

- [show tech-support clock_manager](#), on page 39
- [show tech-support commands](#), on page 40
- [show tech-support controller](#), on page 41
- [show tech-support copp](#), on page 42
- [show tech-support cts](#), on page 43
- [show tech-support details](#), on page 44
- [show tech-support dhclient](#), on page 45
- [show tech-support dhcp](#), on page 46
- [show tech-support dme](#), on page 47
- [show tech-support dot1x](#), on page 48
- [show tech-support eem](#), on page 49
- [show tech-support eigrp](#), on page 50
- [show tech-support eltm](#), on page 51
- [show tech-support ethpm](#), on page 52
- [show tech-support evb](#), on page 53
- [show tech-support fabric forwarding](#), on page 54
- [show tech-support fips](#), on page 55
- [show tech-support gold](#), on page 56
- [show tech-support gpixm](#), on page 57
- [show tech-support ha](#), on page 58
- [show tech-support ha standby](#), on page 59
- [show tech-support hsrp](#), on page 60
- [show tech-support hsrp brief](#), on page 61
- [show tech-support icmpv6](#), on page 62
- [show tech-support im](#), on page 63
- [show tech-support inband counters](#), on page 64
- [show tech-support include-time](#), on page 65
- [show tech-support install](#), on page 66
- [show tech-support interface-vlan](#), on page 67
- [show tech-support ip](#), on page 68
- [show tech-support ip igmp](#), on page 69
- [show tech-support ip igmp snooping](#), on page 70
- [show tech-support ip msdp](#), on page 71
- [show tech-support ip pim](#), on page 72
- [show tech-support ip rsvp](#), on page 73
- [show tech-support ipqos](#), on page 74
- [show tech-support ipv6](#), on page 75
- [show tech-support ipv6 pim](#), on page 76
- [show tech-support isis](#), on page 77
- [show tech-support issu](#), on page 78
- [show tech-support l2](#), on page 79
- [show tech-support l2fm clients](#), on page 80
- [show tech-support l2fm detail](#), on page 81
- [show tech-support l2fm l2dbg](#), on page 82
- [show tech-support l2fm l2dbg](#), on page 83
- [show tech-support l2rib](#), on page 84

- [show tech-support l3vm](#), on page 85
- [show tech-support lacp](#), on page 86
- [show tech-support ldap](#), on page 87
- [show tech-support license](#), on page 88
- [show tech-support lim](#), on page 89
- [show tech-support lisp](#), on page 90
- [show tech-support lldp](#), on page 91
- [show tech-support logging](#), on page 92
- [show tech-support m2rib](#), on page 93
- [show tech-support mmode](#), on page 94
- [show tech-support module](#), on page 95
- [show tech-support module all](#), on page 96
- [show tech-support monitor](#), on page 97
- [show tech-support monitor erspan](#), on page 98
- [show tech-support monitorc-all](#), on page 99
- [show tech-support mpls ldp](#), on page 100
- [show tech-support mpls static](#), on page 101
- [show tech-support mpls strip](#), on page 102
- [show tech-support mpls switching](#), on page 103
- [show tech-support mpls traffic-eng](#), on page 104
- [show tech-support mpls fwd](#), on page 105
- [show tech-support nat](#), on page 106
- [show tech-support netflow](#), on page 107
- [show tech-support netstack](#), on page 108
- [show tech-support netstack detail](#), on page 109
- [show tech-support npacl](#), on page 110
- [show tech-support ns](#), on page 111
- [show tech-support ntp](#), on page 112
- [show tech-support nve](#), on page 113
- [show tech-support onep](#), on page 114
- [show tech-support ospf](#), on page 115
- [show tech-support ospfv3](#), on page 116
- [show tech-support otv](#), on page 117
- [show tech-support otv isis](#), on page 118
- [show tech-support page](#), on page 119
- [show tech-support patch](#), on page 120
- [show tech-support pbr](#), on page 121
- [show tech-support pfstat](#), on page 122
- [show tech-support pixm-all](#), on page 123
- [show tech-support pixm](#), on page 124
- [show tech-support pixmc-all](#), on page 125
- [show tech-support pktmgr](#), on page 126
- [show tech-support platform](#), on page 127
- [show tech-support plcmgr](#), on page 128
- [show tech-support pltfm-config](#), on page 129
- [show tech-support port-channel](#), on page 130

- [show tech-support port-client-all](#), on page 131
- [show tech-support port-profile](#), on page 132
- [show tech-support port](#), on page 133
- [show tech-support private-vlan](#), on page 134
- [show tech-support ptp](#), on page 135
- [show tech-support radius](#), on page 136
- [show tech-support rip](#), on page 137
- [show tech-support routing](#), on page 138
- [show tech-support routing ipv6](#), on page 139
- [show tech-support rpm](#), on page 140
- [show tech-support satmgr](#), on page 141
- [show tech-support security](#), on page 142
- [show tech-support services](#), on page 143
- [show tech-support session-mgr](#), on page 144
- [show tech-support sflow](#), on page 145
- [show tech-support sksd](#), on page 146
- [show tech-support sla responder](#), on page 147
- [show tech-support sla sender](#), on page 148
- [show tech-support smm](#), on page 149
- [show tech-support snmp](#), on page 150
- [show tech-support sockets](#), on page 151
- [show tech-support statsclient](#), on page 152
- [show tech-support stp](#), on page 153
- [show tech-support sup-filesys](#), on page 154
- [show tech-support sysmgr](#), on page 155
- [show tech-support tacacs+](#), on page 156
- [show tech-support track](#), on page 157
- [show tech-support tunnel](#), on page 158
- [show tech-support udld](#), on page 159
- [show tech-support usd-all](#), on page 160
- [show tech-support vdc](#), on page 161
- [show tech-support virtual-service](#), on page 162
- [show tech-support vmtracker](#), on page 163
- [show tech-support vpc](#), on page 164
- [show tech-support vrrp](#), on page 165
- [show tech-support vrrp brief](#), on page 166
- [show tech-support vrrpv3](#), on page 167
- [show tech-support vxlan-evpn](#), on page 168
- [show tech-support vxlan](#), on page 169
- [show tech-support vxlan platform](#), on page 170
- [show tech-support xbar](#), on page 171
- [show tech-support xml](#), on page 172
- [show telnet server](#), on page 173
- [show terminal](#), on page 174
- [show time-range](#), on page 175
- [show track](#), on page 176

- [show track](#), on page 177
- [show tunnel iftable](#), on page 178
- [show tunnel inetconfigtable](#), on page 179

show table-map

show table-map [<imap-name> | <default-imap-enum-name>]

Syntax Description

show	Show running system information
table-map	Table maps
<i>imap-name</i>	(Optional) Show a particular table map
<i>default-imap-enum-name</i>	(Optional)

Command Mode

- /exec

show tacacs-server

show tacacs-server

Syntax Description

show	Show running system information
tacacs-server	Show TACACS+ configuration information

Command Mode

- /exec

show tacacs-server (host0)

show tacacs-server { <host0> }

Syntax Description

show	Show running system information
tacacs-server	Show TACACS+ configuration information
<i>host0</i>	DNS name or IP address

Command Mode

- /exec

show tacacs-server directed-request

show tacacs-server directed-request

Syntax Description

show	Show running system information
tacacs-server	Show TACACS+ configuration information
directed-request	Show directed server enable configuration

Command Mode

- /exec

show tacacs-server groups

show tacacs-server groups [<s0>]

Syntax Description

show	Show running system information
tacacs-server	Show TACACS+ configuration information
groups	Show TACACS+ server group configuration information
s0	(Optional) TACACS+ server group name

Command Mode

- /exec

show tacacs-server sorted

show tacacs-server sorted

Syntax Description

show	Show running system information
tacacs-server	Show TACACS+ configuration information
sorted	Show TACACS+ servers sorted by server name

Command Mode

- /exec

show tacacs-server statistics

show tacacs-server statistics { <host0> }

Syntax Description

show	Show running system information
tacacs-server	Show TACACS+ configuration information
statistics	Show TACACS statistics
<i>host0</i>	DNS name or IP address

Command Mode

- /exec

show tech-support

show tech-support [time-optimized] [forced]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
time-optimized	(Optional) Gather tech-support faster, requires more memory and disk space
forced	(Optional) Do not check for standby being present

Command Mode

- /exec

show tech-support aaa

show tech-support aaa

Syntax Description

show	show tech-support
tech-support	Gather information for troubleshooting
aaa	Display aaa information

Command Mode

- /exec

show tech-support aclmgr

show tech-support aclmgr [detail]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
aclmgr	ACL commands
detail	(Optional) Detailed Tech Support

Command Mode

- /exec

show tech-support aclmgr compressed

show tech-support aclmgr compressed <uri0> [detail]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
aclmgr	ACL commands
compressed	Save compressed aclqos technical support
<i>uri0</i>	Enter filename to store
detail	(Optional) Detailed Tech Support

Command Mode

- /exec

show tech-support aclqos

show tech-support aclqos

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
aclqos	Configure aclqos debug

Command Mode

- /exec

show tech-support aclqos

show tech-support aclqos

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
aclqos	Show information for aclqos technical support

Command Mode

- /exec

show tech-support aclqos compressed

show tech-support aclqos compressed <uri0>

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
aclqos	Show information for aclqos technical support
compressed	Save compressed aclqos technical support
<i>uri0</i>	Enter filename to store

Command Mode

- /exec

show tech-support adjmgr

show tech-support adjmgr [brief]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
adjmgr	Display Adjmgr information
brief	(Optional) Brief information

Command Mode

- /exec

show tech-support all-binary

show tech-support all-binary

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
all-binary	Dump tech support for all applications in binary

Command Mode

- /exec

show tech-support all

show tech-support all

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
all	Gather detailed information for troubleshooting

Command Mode

- /exec

show tech-support all binary

show tech-support all binary <uri0>

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
all	Gather detailed information for troubleshooting
binary	Gather tech support for all applications in binary format
<i>uri0</i>	Select destination filesystem to save the binary output (NOTE: The output file name will be automatically generated and cannot be chosen)

Command Mode

- /exec

show tech-support arp

show tech-support arp [brief]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
arp	Display ARP information
brief	(Optional) Brief information

Command Mode

- /exec

show tech-support ascii-cfg

show tech-support ascii-cfg

Syntax Description

show	Show running system information
tech-support	Show information for technical support personnel
ascii-cfg	Show ascii-cfg information for technical support personnel

Command Mode

- /exec

show tech-support bfd

show tech-support bfd

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
bfd	BFD commands

Command Mode

- /exec

show tech-support bgp

show tech-support bgp [brief]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
bgp	Display BGP status and configuration
brief	(Optional) Brief information

Command Mode

- /exec

show tech-support biosd

show tech-support biosd

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
biosd	Gather bios install log for trouble shooting

Command Mode

- /exec

show tech-support bloggerd-all

show tech-support bloggerd-all

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
bloggerd-all	Gather detailed information for bloggerd troubleshooting from ALL modules

Command Mode

- /exec

show tech-support bloggerd

show tech-support bloggerd

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
bloggerd	Gather detailed information for bloggerd troubleshooting

Command Mode

- /exec

show tech-support bootvar

show tech-support bootvar

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
bootvar	Gather detailed information for bootvar troubleshooting

Command Mode

- /exec

show tech-support brief

show tech-support brief

Syntax Description

show	Show running system summary information
tech-support	Gather information for troubleshooting
brief	Gather summary information for troubleshooting

Command Mode

- /exec

show tech-support callhome

show tech-support callhome

Syntax Description

show	show tech-support
tech-support	Gather information for troubleshooting
callhome	callhome troubleshooting information

Command Mode

- /exec

show tech-support cdp

show tech-support cdp

Syntax Description

show	show running system information
tech-support	Gather information for troubleshooting
cdp	Gather information for CDP trouble shooting

Command Mode

- /exec

show tech-support cert-enroll

show tech-support cert-enroll

Syntax Description

show	show commands
tech-support	Gather information for troubleshooting
cert-enroll	Display certificates information

Command Mode

- /exec

show tech-support cfs

show tech-support cfs [{ commands | name <cfs-dyn-app-name> [commands1] }]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
cfs	Gather detailed information for cfs troubleshooting
commands	(Optional) CFS show tech commands
name	(Optional) Gather detailed information of cfs for a specified application
<i>cfs-dyn-app-name</i>	(Optional) Registered name of the local application
commands1	(Optional) CFS application show tech commands

Command Mode

- /exec

show tech-support cli

show tech-support cli

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
cli	Gather information for parser troubleshooting

Command Mode

- /exec

show tech-support clis

show tech-support clis [brief]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
clis	Gather information for CLI Server troubleshooting
brief	(Optional) Detailed information

Command Mode

- /exec

show tech-support clock_manager

show tech-support clock_manager

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
clock_manager	Gather detailed information for clock manager troubleshooting

Command Mode

- /exec

show tech-support commands

show tech-support commands

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
commands	Show commands executed as part of show tech-support commands

Command Mode

- /exec

show tech-support controller

show tech-support controller

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
controller	Gather information for Controller troubleshooting

Command Mode

- /exec

show tech-support copp

show tech-support copp

Syntax Description

show	Show running system information
tech-support	Gather information for trouble shooting
copp	Gather information for copp trouble shooting

Command Mode

- /exec

show tech-support cts

show tech-support cts

Syntax Description

tech-support	Gather information for troubleshooting
cts	Gather information for cts troubleshooting

Command Mode

- /exec

show tech-support details

show tech-support details [space-optimized]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
details	Gather detailed information for troubleshooting
space-optimized	(Optional) Gather tech-support info. using less memory and disk space

Command Mode

- /exec

show tech-support dhclient

show tech-support dhclient

Syntax Description

show	Show running system information
tech-support	Gather information for trouble shooting
dhclient	Gather information for dhclient trouble shooting

Command Mode

- /exec

show tech-support dhcp

show tech-support dhcp

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
dhcp	Gather detailed information for dhcp troubleshooting

Command Mode

- /exec

show tech-support dme

show tech-support dme

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
dme	Gather detailed information for dme troubleshooting

Command Mode

- /exec

show tech-support dot1x

show tech-support dot1x

Syntax Description

show	show tech-support
tech-support	Gather information for troubleshooting
dot1x	Display dot1x information

Command Mode

- /exec

show tech-support eem

show tech-support eem

Syntax Description

show	Show running system information
tech-support	Gather information for trouble shooting
eem	Show EEM tech-support information

Command Mode

- /exec

show tech-support eigrp

show tech-support eigrp [brief]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
eigrp	Display EIGRP status and configuration
brief	(Optional) Brief information

Command Mode

- /exec

show tech-support eltm

show tech-support eltm [detail]

Syntax Description

show	show tech-support
tech-support	Gather information for trouble-shooting
eltm	eltm debug info
detail	(Optional) Detailed information

Command Mode

- /exec

show tech-support ethpm

show tech-support ethpm

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
ethpm	Gather detailed information for ETHPM troubleshooting

Command Mode

- /exec

show tech-support evb

show tech-support evb

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
evb	EVB (Edge Virtual Bridge)

Command Mode

- /exec

show tech-support fabric forwarding

show tech-support fabric forwarding

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
fabric	Fabric
forwarding	Fabric Forwarding Protocol: Host Mobility Manager (HMM)

Command Mode

- /exec

show tech-support fips

show tech-support fips

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
fips	show tech support information for security

Command Mode

- /exec

show tech-support gold

show tech-support gold

Syntax Description

show	Show running system information
tech-support	Gather information for trouble shooting
gold	Show gold tech-support information

Command Mode

- /exec

show tech-support gpixm

show tech-support gpixm

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
gpixm	Gather detailed information for GLOBAL-PIXM troubleshooting

Command Mode

- /exec

show tech-support ha

show tech-support ha [commands]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
ha	Gather detailed information for HA troubleshooting
commands	(Optional) Show commands executed as part of show tech-support ha commands

Command Mode

- /exec

show tech-support ha standby

show tech-support ha standby [commands]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
ha	Gather detailed information for HA troubleshooting
standby	Gather detailed information for HA troubleshooting from standby supervisor
commands	(Optional) Show commands executed as part of show tech-support ha commands

Command Mode

- /exec

show tech-support hsrp

show tech-support hsrp

Syntax Description

show	Show running system information
tech-support	Gather information for trouble shooting
hsrp	Show hsrp tech-support information

Command Mode

- /exec

show tech-support hsrp brief

show tech-support hsrp brief

Syntax Description

show	Show running system information
tech-support	Gather information for trouble shooting
hsrp	Show hsrp tech-support information
brief	Show tech-support information in brief

Command Mode

- /exec

show tech-support icmpv6

show tech-support icmpv6 [brief]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
icmpv6	Display Icmpv6 information
brief	(Optional) Brief information

Command Mode

- /exec

show tech-support im

show tech-support im

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
im	Gather detailed information for IM troubleshooting

Command Mode

- /exec

show tech-support inband counters

show tech-support inband counters

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
inband	Gather all information about inband data path
counters	Gather all counters in inband data path

Command Mode

- /exec

show tech-support include-time

show tech-support include-time

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
include-time	Gather tech-support and capture time taken to execute each command

Command Mode

- /exec

show tech-support install

show tech-support install

Syntax Description

show	Show running system information
tech-support	Gather information for trouble shooting
install	Gather detailed information for rpm/package install operation

Command Mode

- /exec

show tech-support interface-vlan

show tech-support interface-vlan

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
interface-vlan	Gather detailed information for interface-vlan troubleshooting

Command Mode

- /exec

show tech-support ip

show tech-support ip [brief]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
ip	Display IP information
brief	(Optional) Brief information

Command Mode

- /exec

show tech-support ip igmp

show tech-support ip igmp [brief]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
ip	Display IP information
igmp	Display IGMP status and configuration
brief	(Optional) Brief information

Command Mode

- /exec

show tech-support ip igmp snooping

show tech-support ip igmp snooping [brief]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
ip	Display IP information
igmp	Display IGMP status and configuration
snooping	IGMP Snooping information
brief	(Optional) Brief information

Command Mode

- /exec

show tech-support ip msdp

show tech-support ip msdp [brief]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
ip	Display IP information
msdp	Display MSDP status and configuration
brief	(Optional) Brief information

Command Mode

- /exec

show tech-support ip pim

show tech-support ip pim [brief]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
ip	Display IP information
pim	PIM global configuration commands
brief	(Optional) Brief information

Command Mode

- /exec

show tech-support ip rsvp

```
show tech-support ip rsvp [ brief ]
```

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
ip	Configure IP features
rsvp	RSVP configuration commands
brief	(Optional) Brief information

Command Mode

- /exec

show tech-support ipqos

show tech-support ipqos [server-only] [all] [snmp]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
server-only	(Optional) Dump the tech-support information only from IP QoS Manager server only
all	(Optional) Dump the tech-support information IP QoS Manager plus brief summary of system
snmp	(Optional) Dump the tech-support information only from IP QoS Manager server only (SNMP only)

Command Mode

- /exec

show tech-support ipv6

show tech-support ipv6 [brief]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
ipv6	Display IPV6 information
brief	(Optional) Brief information

Command Mode

- /exec

show tech-support ipv6 pim

show tech-support ipv6 pim [brief]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
ipv6	Display IPv6 information
pim	PIM6 global configuration commands
brief	(Optional) Brief information

Command Mode

- /exec

show tech-support isis

show tech-support isis [brief]

Syntax Description

show	Show running system information
tech-support	Gather information for trouble shooting
isis	IS-IS events
brief	(Optional) Brief information

Command Mode

- /exec

show tech-support issu

show tech-support issu [commands]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
issu	Gather detailed information for issu troubleshooting
commands	(Optional) Show commands executed as part of show tech-support issu command

Command Mode

- /exec

show tech-support l2

show tech-support l2

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
l2	Gather detailed information for layer 2 troubleshooting

Command Mode

- /exec

show tech-support l2fm clients

show tech-support l2fm clients [module <module>]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
l2fm	l2fm debug info
clients	debug info of l2fm clients only running on linecard(mtm)
module	(Optional) Slot number
<i>module</i>	(Optional) Module Number

Command Mode

- /exec

show tech-support l2fm detail

show tech-support l2fm detail [module <module>]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
l2fm	l2fm debug info
detail	All info related to l2fm
module	(Optional) Slot number
<i>module</i>	(Optional) Module Number

Command Mode

- /exec

show tech-support l2fm l2dbg

show tech-support l2fm l2dbg

Syntax Description

show	show tech-support
tech-support	Gather information for trouble-shooting
l2fm	l2fm debug info
l2dbg	tech support capturing additional debug info for l2fm(l2dbg)

Command Mode

- /exec

show tech-support l2fm l2dbg

```
show tech-support l2fm l2dbg [ module <module> ]
```

Syntax Description

show	show tech-support
tech-support	Gather information for trouble-shooting
l2fm	l2fm debug info
l2dbg	tech support capturing additional debug info for l2fm(l2dbg)
module	(Optional) Slot number
<i>module</i>	(Optional) Module Number

Command Mode

- /exec

show tech-support l2rib

show tech-support l2rib

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
l2rib	Display L2RIB information

Command Mode

- /exec

show tech-support l3vm

show tech-support l3vm [brief]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
l3vm	Display VRF information
brief	(Optional) Brief information

Command Mode

- /exec

show tech-support lacp

show tech-support lacp [all]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
lacp	Gather detailed information for LACP component
all	(Optional) Gather detailed information of LACP and related components

Command Mode

- /exec

show tech-support ldap

show tech-support ldap

Syntax Description

show	show tech-support
tech-support	Gather information for troubleshooting
ldap	Display ldap information

Command Mode

- /exec

show tech-support license

show tech-support license

Syntax Description

show	show commands
tech-support	Gather information for troubleshooting
license	Display licensing information

Command Mode

- /exec

show tech-support lim

show tech-support lim

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
lim	Gather detailed information for LIM troubleshooting

Command Mode

- /exec

show tech-support lisp

show tech-support lisp [brief]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
lisp	LISP show commands
brief	(Optional) Brief information

Command Mode

- /exec

show tech-support lldp

show tech-support lldp

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
lldp	Gather detailed information for LLDP troubleshooting

Command Mode

- /exec

show tech-support logging

show tech-support logging

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
logging	Show information on logging for technical support staff

Command Mode

- /exec

show tech-support m2rib

show tech-support m2rib

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
m2rib	Gather detailed information for M2RIB troubleshooting

Command Mode

- /exec

show tech-support mmode

show tech-support mmode

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
mmode	Gather information for troubleshooting mmode

Command Mode

- /exec

show tech-support module

show tech-support module <module>

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
module	Gather info related to a module
<i>module</i>	Enter module number

Command Mode

- /exec

show tech-support module all

show tech-support module all

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
module	Gather info related to a module
all	Gather info related to all modules in the system

Command Mode

- /exec

show tech-support monitor

show tech-support monitor

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
monitor	Gather detailed information for monitor troubleshooting

Command Mode

- /exec

show tech-support monitor erspan

show tech-support monitor erspan

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
monitor	Gather detailed information for monitor troubleshooting
erspan	Gather detailed information for erspan session troubleshooting

Command Mode

- /exec

show tech-support monitorc-all

show tech-support monitorc-all

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
monitorc-all	Gather detailed information for LC MONITORC troubleshooting

Command Mode

- /exec

show tech-support mpls ldp

show tech-support mpls ldp [brief]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
mpls	Display MPLS status and configuration
ldp	Display LDP configuration and status for troubleshooting
brief	(Optional) Brief information

Command Mode

- /exec

show tech-support mpls static

show tech-support mpls static [brief]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
mpls	Display MPLS status and configuration
static	Display STATIC configuration and status for troubleshooting
brief	(Optional) Brief information

Command Mode

- /exec

show tech-support mpls strip

show tech-support mpls strip

Syntax Description

show	Show running system information
tech-support	Gather information for trouble shooting
mpls	MPLS
strip	Gather MPLS label strip troubleshooting info

Command Mode

- /exec

show tech-support mpls switching

show tech-support mpls switching

Syntax Description

show	Show running system information
tech-support	Gather MPLS switching information
mpls	Display MPLS status and configuration
switching	Display the MPLS label switching database

Command Mode

- /exec

show tech-support mpls traffic-eng

show tech-support mpls traffic-eng [brief]

Syntax Description

show	Show running system information
tech-support	Gather information for trouble shooting
mpls	Display MPLS status and configuration
traffic-eng	Traffic engineering information
brief	(Optional) Brief information

Command Mode

- /exec

show tech-support mpls fwd

show tech-support mpls fwd [brief]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
mplsfwd	Display MPLS forwarding information
brief	(Optional) Brief information

Command Mode

- /exec

show tech-support nat

show tech-support nat

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
nat	Gather information for troubleshooting NAT

Command Mode

- /exec

show tech-support netflow

show tech-support netflow [brief]

Syntax Description

show	Show running system information
tech-support	Gather information for trouble shooting
netflow	Show NetFlow tech-support information
brief	(Optional) Brief information

Command Mode

- /exec

show tech-support netstack

show tech-support netstack

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
netstack	Gather information for NETSTACK troubleshooting

Command Mode

- /exec

show tech-support netstack detail

show tech-support netstack detail

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
netstack	Gather information for NETSTACK troubleshooting
detail	Gather detailed information for NETSTACK troubleshooting

Command Mode

- /exec

show tech-support npacl

show tech-support npacl [brief]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
npacl	Display npacl information
brief	(Optional) Brief npacl information

Command Mode

- /exec

show tech-support ns

show tech-support ns

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
ns	Gather detailed information for northstar asic

Command Mode

- /exec

show tech-support ntp

show tech-support ntp

Syntax Description

show	show running system information
tech-support	Gather information for trouble shooting
ntp	Gather information for NTP trouble shooting

Command Mode

- /exec

show tech-support nve

show tech-support nve

Syntax Description

show	Show running system information
tech-support	Gather information for trouble shooting
nve	Display NVE information

Command Mode

- /exec

show tech-support onep

show tech-support onep

Syntax Description

show	Show running system information
tech-support	Diagnostic information for technical support
onep	One Platform

Command Mode

- /exec

show tech-support ospf

show tech-support ospf [brief]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
ospf	Display OSPF status and configuration
brief	(Optional) Brief information

Command Mode

- /exec

show tech-support ospfv3

show tech-support ospfv3 [brief]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
ospfv3	Display OSPFv3 status and configuration
brief	(Optional) Brief information

Command Mode

- /exec

show tech-support otv

show tech-support otv [brief]

Syntax Description

show	Show running system information
tech-support	Gather information for trouble shooting
otv	Display OTV information
brief	(Optional) Brief OTV information

Command Mode

- /exec

show tech-support otv isis

show tech-support otv isis [brief]

Syntax Description

show	Show running system information
tech-support	Gather information for trouble shooting
otv	IS-IS events
isis	IS-IS events
brief	(Optional) Brief information

Command Mode

- /exec

show tech-support page

show tech-support page [time-optimized] [forced]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
page	Page through the output
time-optimized	(Optional) Gather tech-support faster, requires more memory and disk space
forced	(Optional) Do not check for standby being present

Command Mode

- /exec

show tech-support patch

show tech-support patch

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
patch	Gather detailed information for patch troubleshooting

Command Mode

- /exec

show tech-support pbr}

```
{ show tech-support pbr }
```

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
pbr	Display Policy Based Routing (PBR) information

Command Mode

- /exec

show tech-support pfstat

show tech-support pfstat

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
pfstat	Gather detailed information for pfstat troubleshooting

Command Mode

- /exec

show tech-support pixm-all

show tech-support pixm-all

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
pixm-all	Gather detailed information for PIXM troubleshooting

Command Mode

- /exec

show tech-support pixm

show tech-support pixm

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
pixm	Gather detailed information for vdc-local-PIXM troubleshooting

Command Mode

- /exec

show tech-support pixmc-all

show tech-support pixmc-all

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
pixmc-all	Gather detailed information for LC PIXMC troubleshooting

Command Mode

- /exec

show tech-support pktmgr

show tech-support pktmgr [brief]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
pktmgr	Display Packet Manager information
brief	(Optional) Brief information

Command Mode

- /exec

show tech-support platform

show tech-support platform

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
platform	Get platform related information

Command Mode

- /exec

show tech-support plcmgr

show tech-support plcmgr [detail]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
plcmgr	Policy Manager
detail	(Optional) Print more details (e.g. messages,etc)

Command Mode

- /exec

show tech-support pltfm-config

show tech-support pltfm-config

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
pltfm-config	Gather detailed information for pltfm-config troubleshooting

Command Mode

- /exec

show tech-support port-channel

show tech-support port-channel

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
port-channel	Gather detailed information for port channel troubleshooting

Command Mode

- /exec

show tech-support port-client-all

show tech-support port-client-all

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
port-client-all	Gather detailed information for LC port client troubleshooting

Command Mode

- /exec

show tech-support port-profile

show tech-support port-profile

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
port-profile	Gather information for troubleshooting port-profiles

Command Mode

- /exec

show tech-support port

show tech-support port

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
port	Gather detailed information for port manager troubleshooting

Command Mode

- /exec

show tech-support private-vlan

show tech-support private-vlan

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
private-vlan	Gather detailed information for private-vlan troubleshooting

Command Mode

- /exec

show tech-support ptp

show tech-support ptp

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
ptp	Gather detailed information for PTP troubleshooting

Command Mode

- /exec

show tech-support radius

show tech-support radius

Syntax Description

show	show tech-support
tech-support	Gather information for troubleshooting
radius	Display radius information

Command Mode

- /exec

show tech-support rip

show tech-support rip [brief]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
rip	Display RIP routing protocol status
brief	(Optional) Brief information

Command Mode

- /exec

show tech-support routing

show tech-support routing [ip | ipv4] [unicast] [brief]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
routing	Display routing information
ip	(Optional) Display IP information
ipv4	(Optional) Display IP information
unicast	(Optional) Display unicast routing information
brief	(Optional) Brief information

Command Mode

- /exec

show tech-support routing ipv6

show tech-support routing ipv6 [unicast] [brief]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
routing	Display routing information
ipv6	Display IPv6 information
unicast	(Optional) Display unicast routing information
brief	(Optional) Brief information

Command Mode

- /exec

show tech-support rpm}

```
{ show tech-support rpm }
```

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
rpm	Display Route Policy Manager (RPM) information

Command Mode

- /exec

show tech-support satmgr

show tech-support satmgr

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
satmgr	Gather detailed information for satmgr troubleshooting

Command Mode

- /exec

show tech-support security

show tech-support security

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
security	show tech support information for security

Command Mode

- /exec

show tech-support services

show tech-support services [detail]

Syntax Description

show	Show running system information
tech-support	Gather information for trouble shooting
services	Services
detail	(Optional) Show more details

Command Mode

- /exec

show tech-support session-mgr

show tech-support session-mgr

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
session-mgr	Gather information for troubleshooting session manager

Command Mode

- /exec

show tech-support sflow

show tech-support sflow

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
sflow	Gather detailed information for sflow feature

Command Mode

- /exec

show tech-support sksd

show tech-support sksd

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
sksd	show tech support information for sksd

Command Mode

- /exec

show tech-support sla responder

show tech-support sla responder [brief | detail]

Syntax Description

show	Show running system information
tech-support	Gather information for trouble shooting
sla	Service Level Agreement (SLA)
responder	Configure sla-responder tech support
brief	(Optional) Show less details
detail	(Optional) Show more details

Command Mode

- /exec

show tech-support sla sender

show tech-support sla sender [brief | detail]

Syntax Description

show	Show running system information
tech-support	Gather information for trouble shooting
sla	Service Level Agreement (SLA)
sender	Configure sla-sender tech support
brief	(Optional) Show less details
detail	(Optional) Show more details

Command Mode

- /exec

show tech-support smm

show tech-support smm

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
smm	Shared memory

Command Mode

- /exec

show tech-support snmp

show tech-support snmp

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
snmp	Gather info related to snmp

Command Mode

- /exec

show tech-support sockets

show tech-support sockets [brief]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
sockets	Display sockets status and configuration
brief	(Optional) Brief information

Command Mode

- /exec

show tech-support statsclient

show tech-support statsclient [module <module>]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
statsclient	Gather statsclient tech-support
module	(Optional) Gather info related to one module
<i>module</i>	(Optional) Enter module number

Command Mode

- /exec

show tech-support stp

show tech-support stp

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
stp	Gather detailed information for STP troubleshooting

Command Mode

- /exec

show tech-support sup-filesys

show tech-support sup-filesys

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
sup-filesys	File-sys related issue

Command Mode

- /exec

show tech-support sysmgr

show tech-support sysmgr [commands]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
sysmgr	Gather detailed information for sysmgr troubleshooting
commands	(Optional) Show commands executed as part of show tech-support sysmgr

Command Mode

- /exec

show tech-support tacacs+

show tech-support tacacs +

Syntax Description

show	show tech-support
tech-support	Gather information for troubleshooting

Command Mode

- /exec

show tech-support track

show tech-support track

Syntax Description

show	Show running system information
tech-support	Gather information for trouble shooting
track	Show track tech-support information

Command Mode

- /exec

show tech-support tunnel

show tech-support tunnel [{ commands | detail [commands1] }]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
tunnel	Gather detailed information for tunnel troubleshooting
commands	(Optional) Lists commands under 'show tunnel tech-support' command
detail	(Optional) Gather detailed information for tunnel troubleshooting
commands1	(Optional) Lists commands under 'Show tech-support tunnel detail' commands

Command Mode

- /exec

show tech-support udd

show tech-support udd

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
udd	Gather detailed information for udd troubleshooting

Command Mode

- /exec

show tech-support usd-all

show tech-support usd-all

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
usd-all	Gather detailed information for LC USD troubleshooting

Command Mode

- /exec

show tech-support vdc

show tech-support vdc

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
vdc	Gather detailed information for VDC troubleshooting

Command Mode

- /exec

show tech-support virtual-service

show tech-support virtual-service

Syntax Description

show	Show running system information
tech-support	Gather information for trouble shooting
virtual-service	Gather information for virtualization services trouble shooting

Command Mode

- /exec

show tech-support vmtracker

show tech-support vmtracker

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
vmtracker	VMTRACKER commands

Command Mode

- /exec

show tech-support vpc

show tech-support vpc

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
vpc	Gather detailed information for VPC troubleshooting

Command Mode

- /exec

show tech-support vrrp

show tech-support vrrp

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
vrrp	Show information for vrrp technical support

Command Mode

- /exec

show tech-support vrrp brief

show tech-support vrrp brief

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
vrrp	Show information for vrrp technical support
brief	Show information for vrrp technical support in brief

Command Mode

- /exec

show tech-support vrrpv3

show tech-support vrrpv3 [detail]

Syntax Description

vrrpv3	VRRPv3 configuration commands
show	Show running system information
tech-support	Gather information for trouble shooting
detail	(Optional) Detailed output

Command Mode

- /exec

show tech-support vxlan-evpn

show tech-support vxlan-evpn

Syntax Description

show	Show running system information
tech-support	Gather information for trouble shooting
vxlan-evpn	VxLAN evpn feature

Command Mode

- /exec

show tech-support vxlan

show tech-support vxlan

Syntax Description

show	Show running system information
tech-support	Gather information for trouble shooting
vxlan	VxLAN feature

Command Mode

- /exec

show tech-support vxlan platform

show tech-support vxlan platform

Syntax Description

show	Show tech-support for PD VxLAN component
tech-support	Gather information for troubleshooting
vxlan	VxLAN components
platform	VxLAN platform components

Command Mode

- /exec

show tech-support xbar

show tech-support xbar

Syntax Description

show	Show running system information
tech-support	Gather information for trouble shooting
xbar	Show xbar tech-support information

Command Mode

- /exec

show tech-support xml

show tech-support xml

Syntax Description

show	show running system information
tech-support	Gather information for trouble shooting
xml	Gather information for xml trouble shooting

Command Mode

- /exec

show telnet server

show telnet server

Syntax Description

show	Show running system information
telnet	Show telnet server configuration
server	Show telnet server configuration

Command Mode

- /exec

show terminal

show terminal

Syntax Description

show	Show running system information
terminal	Display terminal configuration parameters

Command Mode

- /exec

show time-range

show time-range [<name>]

Syntax Description

show	Show running system information
time-range	Define time range entries
<i>name</i>	(Optional) Time range name

Command Mode

- /exec

show track

show track { [<object-id> | interface | ip { route | sla } | ipv6 routev6 | list boolean and | list boolean or | list threshold weight | list threshold percentage] }

Syntax Description

show	Negate a command or set its defaults
track	Tracking information
<i>object-id</i>	(Optional) Tracked object
interface	(Optional) Interface objects
ip	(Optional) IPv4 Protocol objects
route	(Optional) route (ipv4) objects
sla	(Optional) Service Level Agreement objects
ipv6	(Optional) IPv6 Protocol objects
routev6	(Optional) route (ipv6) objects
list	(Optional) Tracklist objects
boolean	(Optional) Boolean Traclist
and	(Optional) AND boolean objects
or	(Optional) OR boolean objects
threshold	(Optional) Threshold parameters
weight	(Optional) Threshold weight
percentage	(Optional) Threshold percentage

Command Mode

- /exec

show track

show track { [<object-id> | interface | ip { route | sla } | ipv6 routev6 | list boolean and | list boolean or | list threshold weight | list threshold percentage] } brief

Syntax Description

show	Negate a command or set its defaults
track	Tracking information
<i>object-id</i>	(Optional) Tracked object
interface	(Optional) Interface objects
ip	(Optional) IPv4 Protocol objects
route	(Optional) route (ipv4) objects
sla	(Optional) Service Level Agreement objects
ipv6	(Optional) IPv6 Protocol objects
routev6	(Optional) route (ipv6) objects
list	(Optional) Tracklist objects
boolean	(Optional) Boolean Traclist
and	(Optional) AND boolean objects
or	(Optional) OR boolean objects
threshold	(Optional) Threshold parameters
weight	(Optional) Threshold weight
percentage	(Optional) Threshold percentage
brief	Brief output

Command Mode

- /exec

show tunnel iftable

show tunnel iftable [<ifindex-in>]

Syntax Description

show	Show running system information
tunnel	Show information about Tunnel
iftable	Show tunnel interface table
<i>ifindex-in</i>	(Optional) Tunnel ifindex

Command Mode

- /exec

show tunnel inetconfigtable

```
show tunnel inetconfigtable [ <tunnelInetConfigAddressType-in> [ [ <tunnelInetConfigLocalAddress-in> [
<tunnelInetConfigRemoteAddress-in> [ <tunnelInetConfigEncapsMethod-in> [ <tunnelInetConfigID-in> ]
]]]]]
```

Syntax Description

show	Show running system information
tunnel	Show information about Tunnel
inetconfigtable	Show inet config table
<i>tunnelInetConfigAddressType-in</i>	(Optional) Address Type
<i>tunnelInetConfigLocalAddress-in</i>	(Optional) Local IP Address
<i>tunnelInetConfigRemoteAddress-in</i>	(Optional) Remote IP Address
<i>tunnelInetConfigEncapsMethod-in</i>	(Optional) Encapsulation Method
<i>tunnelInetConfigID-in</i>	(Optional) Configuration ID

Command Mode

- /exec

```
show tunnel inetconfigtable
```