



Feature Defaults Quick Reference

- [Feature Defaults](#), on page 1

Feature Defaults

The following table indicates what features are enabled or disabled by default.

Feature	Default
5G Non Standalone	Disabled - Configuration Required
Cisco Ultra Traffice Optimization	Disabled - License Required
Dynamic Transport Selection based on Transaction or Origin-Host	Disabled - Configuration Required
Enabling EMM and ESM Cause Code Mapping	Enabled - Always-on
Extraction of IPv4 Addresses Embedded in IPv6 Addresses	Disabled - License Required
Non-IP PDN Support	Disabled - License Required
P-GW Buffering Optimization	Enabled - Configuration Required
RedHat Software Version Update	Enabled - Always-on
Rf Interface Support	
Source Port Randomization on VPP for GTP-U Traffic	Disabled - License Required
S6b Interface Enhancement	Disabled - License Required
UE Overload Protection	Disabled - Configuration Required
User Location Information in P-GW CDR	Enabled - Always-on
Update Bearer Request Enhancements to Close Charging Gap	Disabled - Configuration Required

