

Preface

This preface describes the audience, organization, and conventions of the *Cisco Wireless LAN Controller System Message Guide*. It also provides information about how to obtain related documentation.

This chapter contains the following sections:

- Audience, page ix
- Organization, page ix
- · Conventions, page ix
- · Related Documentation, page x
- · Obtaining Documentation and Submitting a Service Request, page xi

Audience

This publication is designed for the installer and user with a working knowledge of Cisco Wireless LAN Controllers (Cisco WLC). Users of this publication might also include network administrators and other people responsible for setting up and maintaining these devices.

Organization

This book is organized into chapters containing information about the various system messages that are displayed in the Cisco WLC console. The chapters are organized according to the alphabetical order of the system messages.

Conventions

Screen examples use the following conventions:

Convention	Description
boldface font	Commands and keywords are in boldface .
italic font	Arguments for which you supply values are in italics.
[]	Elements in square brackets are optional.

Convention	Description
$ \overline{\{x \mid y \mid z\}} $	Alternative keywords are grouped in braces and separated by vertical bars.
[x y z]	Optional alternative keywords are grouped in brackets and separated by vertical bars.
string	A nonquoted set of characters. Do not use quotation marks around the string or the string will include the quotation marks.
screen font	Terminal sessions and information the system displays are in screen font.
boldface screen font	Information you must enter is in boldface screen font.
italic screen font	Arguments for which you supply values are in <i>italic</i> screen font.
	This pointer highlights an important line of text in an example.
۸	The symbol ^ represents the key labeled Control—for example, the key combination ^D in a screen display means hold down the Control key while you press the D key.
< >	Nonprinting characters, such as passwords are in angle brackets.

Notes use the following conventions:



Means *reader take note*. Notes contain helpful suggestions or references to material not covered in the publication.

Related Documentation

- Cisco Wireless Controller Software
 http://www.cisco.com/c/en/us/support/wireless/wireless-lan-controller-software/tsd-products-support-series-home.html
- Cisco Prime Infrastructure
 http://www.cisco.com/c/en/us/support/cloud-systems-management/prime-infrastructure/tsd-products-support-series-home.html
- · Quick start guide and hardware installation guide for your specific lightweight access point

Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, submitting a service request, and gathering additional information, see the monthly *What's New in Cisco Product Documentation*, which also lists all new and revised Cisco technical documentation, at:

http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html

Subscribe to the *What's New in Cisco Product Documentation* as a Really Simple Syndication (RSS) feed and set content to be delivered directly to your desktop using a reader application. The RSS feeds are a free service and Cisco currently supports RSS version 2.0.