



Overview

- [Overview, on page 1](#)

Overview

The Cisco IC3000 Industrial Compute Gateway is an edge computing platform which extends the cloud computing paradigm to the edge of the network. The Cisco IC3000 captures traffic in SPAN mode. It contains two RJ45 10/100/1000 BaseT connectors ports and two SFP fiber ports to connect switches in port mirroring.

To deploy the Cisco Cyber Vision sensor application in the Cisco IC3000, follow the initial configuration:

Take a moment to look at the [Cisco IC3000's parts](#) and [connect the hardware](#). Proceed with the [Cisco IC3000 platform initial configuration](#) if it has never been done to configure a Local Manager IP and admin account. Eventually, [configure the device date and time](#).

Then, proceed with one of the installation methods available:

- [Procedure with the Sensor management extension](#). The file is available on cisco.com (recommended).
- [Procedure with the Local Manager](#).

To upgrade the sensor hosted in the Cisco IC3000, refer to one of the methods available:

- If the sensor management was used to deploy the sensor, [upgrade through the sensor management extension](#).
- [Upgrade through the Local Manager](#).

