



Detecting and Analyzing Network Threats With NetFlow

First Published: June 19, 2006

Last Updated: October 02, 2009

This document contains information about and instructions for detecting and analyzing network threats such as denial of service attacks (DoS) through the use of the following NetFlow features:

- **NetFlow Layer 2 and Security Monitoring Exports**—This feature improves your ability to detect and analyze network threats such as denial of service attacks (DoS) by adding 9 fields that NetFlow can capture the values from. A few examples are:
 - IP Time-to-Live field
 - Packet length field
 - ICMP type and code fields
- **NetFlow Dynamic Top Talkers CLI**—This feature gives you an overview of the highest volume traffic in your network by aggregating flows on a common field. For example, you can aggregate all of the flows for a destination network by aggregating them on the destination prefix. There are over 20 fields from flows that you can aggregate the highest volume traffic on. A few examples are:
 - Source or destination IP address
 - Source or destination prefix
 - Source or destination port
 - ICMP type and code
- **NetFlow Top Talkers**—This feature gives you a more detailed view of the traffic in your network than the NetFlow Dynamic Top Talkers CLI feature because it looks at individual flows. You use the NetFlow Dynamic Top Talkers CLI feature to quickly identify high volume traffic of interest. You use the NetFlow Top Talkers feature to obtain more detailed information on each of the flows in the high volume traffic.
- **NetFlow Input Filters**—This feature tracks a specific subset of NetFlow traffic for the purpose of class-based traffic analysis and monitoring. This feature is used in conjunction with the Top Talkers feature to help you focus your analysis on the traffic that might be a network threat such as a DoS attack.



Americas Headquarters:

Cisco Systems, Inc., 170 West Tasman Drive, San Jose, CA 95134-1706 USA

- **Random Sampled NetFlow**—This feature is typically used for statistical sampling of network traffic for traffic engineering or capacity planning purposes. It is used in the context of monitoring and analyzing network threats because it can be used to reduce the impact on the router using NetFlow to monitor traffic that might be a network threat, such as a DoS attack.

Finding Feature Information

Your software release may not support all the features documented in this module. For the latest feature information and caveats, see the release notes for your platform and software release. To find information about the features documented in this module, and to see a list of the releases in which each feature is supported, see the [“Feature Information for Detecting and Analyzing Network Threats With NetFlow”](#) section on page 56.

Use Cisco Feature Navigator to find information about platform support and Cisco IOS and Catalyst OS software image support. To access Cisco Feature Navigator, go to <http://www.cisco.com/go/cfn>. An account on Cisco.com is not required.

Contents

- [Prerequisites for Detecting and Analyzing Network Threats With NetFlow](#), page 2
- [Information About Detecting and Analyzing Network Threats With NetFlow](#), page 2
- [How to Configure and Use NetFlow to Detect and Analyze Network Threats](#), page 19
- [Configuration Examples for Detecting and Analyzing Network Threats With NetFlow](#), page 40
- [Additional References](#), page 54
- [Feature Information for Detecting and Analyzing Network Threats With NetFlow](#), page 56
- [Glossary](#), page 58

Prerequisites for Detecting and Analyzing Network Threats With NetFlow

Before you can use NetFlow for detecting and analyzing network threats you need to understand NetFlow and how to configure your router to capture IP traffic status and statistics using NetFlow. See the [Cisco IOS NetFlow Overview](#) and [Configuring NetFlow and NetFlow Data Export](#) modules for more details.

NetFlow and Cisco Express Forwarding (CEF) or distributed CEF (dCEF) must be configured on your system before you enable NetFlow.

Information About Detecting and Analyzing Network Threats With NetFlow

To detect and analyze network threats with NetFlow, you should understand the following concepts:

- [NetFlow Layer 2 and Security Monitoring](#), page 3

- [NetFlow Top Talkers, page 13](#)
- [Filtering and Sampling of NetFlow Traffic, page 17](#)

NetFlow Layer 2 and Security Monitoring

The Layer 3 and Layer 2 fields supported by the NetFlow Layer 2 and Security Monitoring Exports feature increase the amount of information that can be obtained by NetFlow about the traffic in your network. You can use this new information for applications such as traffic engineering and usage-based billing.

The Layer 3 IP header fields that the NetFlow Layer 2 and Security Monitoring Exports feature captures the values of are:

- Time-to-Live field
- Packet Length field
- ID field
- ICMP type and code fields
- Fragment offset

See the [Layer 3 Information Capture Using NetFlow Layer 2 and Security Monitoring Exports](#) section for more information on these Layer 3 fields.

The Layer 2 fields that NetFlow Layer 2 and Security Monitoring Exports feature captures the values of are:

- Source MAC address field from frames that are received by the NetFlow router
- Destination MAC address field from frames that are transmitted by the NetFlow router
- VLAN ID field from frames that are received by the NetFlow router
- VLAN ID field from frames that are transmitted by the NetFlow router
- Interface names

See the [Layer 2 Information Capture Using NetFlow Layer 2 and Security Monitoring Exports](#) section for more information on these Layer 2 fields.

The Layer 3 fields captured by the NetFlow Layer 2 and Security Monitoring Exports feature improve NetFlow's capabilities for identifying DoS attacks. The Layer 2 fields captured by the NetFlow Layer 2 and Security Monitoring Exports feature can help you identify the path that the DoS attack is taking through the network.


The Layer 3 and Layer 2 fields captured by the NetFlow Layer 2 and Security Monitoring Exports feature are not key fields. They provide additional information about the traffic in an existing flow. Changes in the values of NetFlow key fields such as the source IP address from one packet to the next packet result in the creation of a new flow. For example if the first packet captured by NetFlow has a source IP address of 10.34.0.2 and the second packet captured by NetFlow has a source IP of 172.16.213.65, NetFlow will create two separate flows.

Many DoS attacks consist of an attacker sending the same type of IP datagram over and over again in an attempt to overwhelm the target systems. In such cases the incoming traffic often has similar characteristics such as the same values in each datagram for one or more of the fields that the NetFlow Layer 2 and Security Monitoring Exports feature can capture.

There is no easy way to identify the originator of many DoS attacks because the IP source address of the device sending the traffic is usually forged. However by capturing the MAC address and VLAN-ID fields using the NetFlow Layer 2 and Security Monitoring Exports feature, you can easily trace the traffic back

through the network to the router that it is arriving on. If the router that the traffic is arriving on supports NetFlow, you can configure the NetFlow Layer 2 and Security Monitoring Exports feature on it to identify the interface where the traffic is arriving. Figure 1 shows an example of an attack in progress.

Figure 1 DoS Attack Arriving over the Internet



Note

You can analyze the data captured by NetFlow directly from the router using the **show ip cache verbose flow** command or remotely with the CNS NetFlow Collector Engine.

Once you have concluded that a DoS attack is taking place by analyzing the Layer 3 fields in the NetFlow flows, you can analyze the Layer 2 fields in the flows to discover the path that the DoS attack is taking through the network.

An analysis of the data captured by the NetFlow Layer 2 and Security Monitoring Exports feature for the scenario shown in Figure 1 indicates that the DoS attack is arriving on Router C because the upstream MAC address is from the interface that connects Router C to Switch A. It is also evident that there are no routers between the target host (the email server) and the NetFlow router because the destination MAC address of the DoS traffic that the NetFlow router is forwarding to the email server is the MAC address of the email server.

You can find out the MAC address that Host C is using to send the traffic to Router C by configuring the NetFlow Layer 2 and Security Monitoring Exports feature on Router C. The source MAC address will be from Host C. The destination MAC address will be for the interface on the NetFlow router.

Once you know the MAC address that Host C is using and the interface on Router C that Host C's DoS attack is arriving on, you can mitigate the attack by reconfiguring Router C to block Host C's traffic. If Host C is on a dedicated interface you can disable the interface. If Host C is using an interface that carries traffic from other users, you must configure your firewall, or add an ACL, to block Host C's traffic but still allow the traffic from the other users to flow through Router C.

The [Configuration Examples for Detecting and Analyzing Network Threats With NetFlow](#) section has two examples for using the NetFlow Layer 2 and Security Monitoring Exports feature to identify an attack in progress and the path that the attack is taking through a network.

Layer 3 Information Capture Using NetFlow Layer 2 and Security Monitoring Exports

The NetFlow Layer 2 and Security Monitoring Exports feature has support for capturing five fields from Layer 3 IP traffic in a flow:

- Time-to-Live field
- Packet Length field
- ID field
- ICMP type and code
- Fragment offset

[Figure 2](#) shows the fields in an IP packet header. [Figure 3](#) shows the fields in an ICMP datagram. ICMP datagrams are carried in the data area of an IP datagram, after the IP header.

Figure 2 IP Packet Header Fields




Table 1 IP Packet Header Fields

Field	Description
Version	The version of the IP protocol. If this field is set to 4 it is an IPv4 datagram. If this field is set to 6 it is an IPv6 datagram. Note The IPv6 header has a different structure from an IPv4 header.
IHL (Internet Header Length)	Internet Header Length is the length of the internet header in 32-bit word and thus points to the beginning of the data. Note The minimum value for a correct header is 5.
ToS	ToS provides an indication of the abstract parameters of the quality of service desired. These parameters are to be used to guide the selection of the actual service parameters when a networking device transmits a datagram through a particular network.
Total Length	Total length is the length of the datagram, measured in octets, including internet header and data.


Table 1 *IP Packet Header Fields (continued)*

Field	Description
Identification (ID)	<p>The value in the ID field is entered by the sender. All of the fragments of an IP datagram have the same value in the ID field. Subsequent IP datagrams from the same sender will have different values in the ID field.</p> <p>It is very common for a host to be receiving fragmented IP datagrams from several senders concurrently. It is also common for a host to be receiving multiple IP datagrams from the same sender concurrently.</p> <p>The value in the ID field is used by the destination host to ensure that the fragments of an IP datagram are assigned to the same packet buffer during the IP datagram reassembly process. The unique value in the ID field is also used to prevent the receiving host from mixing together IP datagram fragments of different IP datagrams from the same sender during the IP datagram reassembly process.</p>
Flags	<p>A sequence of 3 bits used to set and track IP datagram fragmentation parameters.</p> <ul style="list-style-type: none"> • 001 = The IP datagram can be fragmented. There are more fragments of the current IP datagram in transit. • 000 = The IP datagram can be fragmented. This is the last fragment of the current IP datagram. • 010 = The IP Datagram cannot be fragmented. This is the entire IP datagram.
Fragment Offset	This field indicates where in the datagram this fragment belongs.
TTL (Time-to-Live)	This field indicates the maximum time the datagram is allowed to remain in the internet system. If this field contains the value 0, then the datagram must be destroyed. This field is modified in internet header processing. The time is measured in units of seconds, but since every module that processes a datagram must decrease the TTL by at least 1 even if it processes the datagram in less than a second, the TTL must be thought of only as an upper bound on the time a datagram can exist. The intention is to cause undeliverable datagrams to be discarded, and to bound the maximum datagram lifetime.
Protocol	<p>Indicates the type of transport packet included in the data portion of the IP datagram. Common values are:</p> <p>1 = ICMP</p> <p>6 = TCP</p> <p>17 = UDP</p>
Header checksum	A checksum on the header only. Since some header fields, such as the time-to-live field, change every time an IP datagram is forwarded, this value is recomputed and verified at each point that the internet header is processed.
Source IP Address	IP address of the sending station.

Table 1 *IP Packet Header Fields (continued)*

Field	Description
Destination IP Address	IP address of the destination station.
Options and Padding	The options and padding may or may not appear or not in datagrams. If they do appear, they must be implemented by all IP modules (host and gateways). What is optional is their transmission in any particular datagram, not their implementation.

Figure 3 *ICMP Datagram*



127763

Table 2 *ICMP Packet Format*

Type	Name	Codes
0	Echo reply	0—None
1	Unassigned	—
2	Unassigned	—
3	Destination unreachable	0—Net unreachable. 1—Host unreachable. 2—Protocol unreachable. 3—Port unreachable. 4—Fragmentation needed and DF bit set. 5—Source route failed. 6—Destination network unknown. 7—Destination host unknown. 8—Source host isolated. 9—Communication with destination network is administratively prohibited. 10—Communication with destination host is administratively prohibited. 11—Destination network unreachable for ToS. 12—Destination host unreachable for ToS.
4	Source quench	0—None.

Table 2 *ICMP Packet Format (continued)*

Type	Name	Codes
5	Redirect	0—Redirect datagram for the network. 1—Redirect datagram for the host. 2—Redirect datagram for the TOS and network. 3—Redirect datagram for the TOS and host.
6	Alternate host address	0—Alternate address for host.
7	Unassigned	—
8	Echo	0—None.
9	Router advertisement	0—None.
10	Router selection	0—None.
11	Time Exceeded	0—Time to live exceeded in transit.
12	Parameter problem	0—Pointer indicates the error. 1—Missing a required option. 2—Bad length.
13	Timestamp	0—None.
14	Timestamp reply	0—None.
15	Information request	0—None.
16	Information reply	0—None.
17	Address mask request	0—None.
18	Address mask reply	0—None.
19	Reserved (for security)	—
20–29	Reserved (for robustness experiment)	—
30	Trace route	—
31	Datagram conversion error	—
32	Mobile host redirect	—
33	IPv6 where-are-you	—
34	IPv6 I-am-here	—
35	Mobile registration request	—
36	Mobile registration reply	—
37–255	Reserved	—

Layer 2 Information Capture Using NetFlow Layer 2 and Security Monitoring Exports

The NetFlow Layer 2 and Security Monitoring Exports feature has the ability to capture the values of the MAC address and VLAN ID fields from flows. The two supported VLAN types are 802.1q and Cisco’s Inter-Switch Link (ISL).

- [Understanding Layer 2 MAC Address Fields](#)
- [Understanding Layer 2 VLAN ID Fields](#)

Understanding Layer 2 MAC Address Fields

The new Layer 2 fields that the NetFlow Layer 2 and Security Monitoring Exports feature captures the values of are:

- The source MAC address field from frames that are received by the NetFlow router
- The destination MAC address field from frames that are transmitted by the NetFlow router
- The VLAN ID field from frames that are received by the NetFlow router
- The VLAN ID field from frames that are transmitted by the NetFlow router

The Ethernet Type II and Ethernet 802.3 frame formats are shown in [Figure 4](#). The destination address field and the source address field in the frame formats are the MAC addresses whose values NetFlow captures. The fields for the Ethernet frame formats are explained in [Table 3](#).

Figure 4 Ethernet Type II and 802.3 Frame Formats




Table 3 Ethernet Type II and 802.3 Frame Fields

Field	Description
Preamble	The entry in the Preamble field is an alternating pattern of 1s and 0s that tells receiving stations that a frame is coming. It also provides a means for the receiving stations to synchronize their clocks with the incoming bit stream.
SOF (Start of frame)	The SOF field holds an alternating pattern of 1s and 0s, ending with two consecutive 1-bits indicating that the next bit is the first bit of the first byte of the destination MAC address.

Table 3 Ethernet Type II and 802.3 Frame Fields (continued)

Field	Description
Destination Address	<p>The 48-bit destination address identifies which station(s) on the LAN should receive the frame. The first two bits of the destination MAC address are reserved for special functions:</p> <ul style="list-style-type: none"> • The first bit in the DA field indicates whether the address is an individual address (0) or a group address (1). • The second bit indicates whether the DA is globally administered (0) or locally administered (1). <p>The remaining 46 bits are a uniquely assigned value that identifies a single station, a defined group of stations, or all stations on the network.</p>
Source Address	<p>The 48-bit source address identifies which station transmitted the frame. The source address is always an individual address and the left-most bit in the SA field is always 0.</p>
Type or Length	<p>Type—In an Ethernet Type II frame this part of the frame is used for the Type field. The Type field is used to identify the next layer protocol in the frame.</p> <p>Length—In an 802.3 Ethernet frame this part of the frame is used for the Length field. The Length field is used to indicate the length of the Ethernet frame. The value can be between 46 and 1500 bytes.</p>
Data or 802.2 header and data	<p>(Ethernet type II) 46–1500 bytes of data</p> <p>or</p> <p>(802.3/802.2) 8 bytes of header and 38–1492 bytes of data.</p>
FCS (Frame Check Sequence)	<p>This field contains a 32-bit cyclic redundancy check (CRC) value, which is created by the sending station and is recalculated by the receiving station to check for damaged frames. The FCS is generated for the DA, SA, Type, and Data fields of the frame. The FCS does not include the data portion of the frame.</p>

Understanding Layer 2 VLAN ID Fields

NetFlow can capture the value in the VLAN ID field for 802.1q tagged VLANs and Cisco ISL encapsulated VLANs. The section describes the two types of VLANs.



Note

It has become common to refer to both 802.1q and ISL as VLAN encapsulation protocols.

- [Understanding 802.1q VLANs](#)
- [Understanding Cisco ISL VLANs](#)

Understanding 802.1q VLANs

Devices that use 802.1q insert a four-byte tag into the original frame before it is transmitted. [Figure 5](#) shows the format of an 802.1q tagged Ethernet frame. The fields for 802.1q VLANs are described in [Table 4](#).

Figure 5 802.1q Tagged Ethernet Type II or 802.3 Frame




Table 4 802.1q VLAN Encapsulation Fields

Field	Description
DA, SA, Type or Length, Data, and FCS	These fields are described in Table 3 .
Tag Protocol ID (TPID)	This 16-bit field is set to a value of 0x8100 to identify the frame as an IEEE 802.1q tagged frame.
Priority	Also known as user priority, this 3-bit field refers to the 802.1p priority. It indicates the frame priority level which can be used for prioritizing traffic and is capable of representing 8 levels (0–7).
Tag Control Information	The 2-byte Tag Control Information field is comprised of two sub-fields: <ul style="list-style-type: none"> • Canonical Format Indicator (CFI)—If the value of this 1-bit field is 1, then the MAC address is in noncanonical format. If the value of this field is 0, then the MAC address is in canonical format. • VLAN ID—This 12-bit field uniquely identifies the VLAN to which the frame belongs. It can have a value between 0 and 4095.

Understanding Cisco ISL VLANs

ISL is a Cisco proprietary protocol for encapsulating frames on a VLAN trunk. Devices that use ISL add an ISL header to the frame. This process is known as VLAN encapsulation. 802.1Q is the IEEE standard for tagging frames on a VLAN trunk. [Figure 6](#) shows the format of a Cisco ISL-encapsulated Ethernet frame. The fields for 802.1q VLANs are described in [Table 5](#).

Figure 6 Cisco ISL Tagged Ethernet Frame

#of bits in the field	40	4	4	48	16	24	24	15	1	16	16	1 to 24575 bytes	32
Field Name	DA	TYPE	USER	SA	LEN	AAAA03(SNAP)	HSA	VLAN	BPDU	INDEX	RES	Encapsulated FRAME	FCS

127755

Table 5 ISL VLAN Encapsulation

Field	Description
DA (destination address)	This 40-bit field is a multicast address and is set at 0x01-00-0C-00-00 or 0x03-00-0c-00-00. The receiving host determines that the frame is encapsulated in ISL by reading the 40-bit DA field and matching it to one of the two ISL multicast addresses.
Type	This 4-bit field indicates the type of frame that is encapsulated and could be used in the future to indicate alternative encapsulations. TYPE codes: <ul style="list-style-type: none"> • 0000 = Ethernet • 0001 = Token Ring • 0010 = FDDI • 0011 = ATM
USER	This 4-bit field is used to extend the meaning of the Frame TYPE field. The default USER field value is 0000. For Ethernet frames, the USER field bits 0 and 1 indicate the priority of the packet as it passes through the switch. Whenever traffic can be handled more quickly, the packets with this bit set should take advantage of the quicker path. Such paths however are not required. USER codes: <ul style="list-style-type: none"> • XX00 = Normal priority • XX01 = Priority 1 • XX10 = Priority 2 • XX11 = Highest priority
SA	This 48-bit field is the source address field of the ISL packet. It should be set to the 802.3 MAC address of the switch port transmitting the frame. The receiving device can ignore the SA field of the frame.
LEN	This 16-bit value field stores the actual packet size of the original packet. The LEN field represents the length of the packet in bytes, excluding the DA, TYPE, USER, SA, LEN, and FCS fields. The total length of the excluded fields is 18 bytes, so the LEN field represents the total length minus 18 bytes.
AAAA03(SNAP)	The AAAA03 SNAP field is a 24-bit constant value of 0xAAAA03.
HSA	This 24-bit field represents the upper three bytes (the manufacturer's ID portion) of the SA field. It must contain the value 0x00-00-0C.
VLAN	This 15-bit field is the Virtual LAN ID of the packet. This value is used to mark frames on different VLANs.

Table 5 *ISL VLAN Encapsulation (continued)*

Field	Description
BPDU	The bit in the BPDU field is set for all BPDU packets that are encapsulated by the ISL frame. The BPDUs are used by the spanning tree algorithm to find out information about the topology of the network. This bit is also set for CDP and VTP frames that are encapsulated.
INDEX	This 16-bit field indicates the port index of the source of the packet as it exits the switch. It is used for diagnostic purposes only, and may be set to any value by other devices. It is ignored in received packets.
RES	This 16-bit field is used when Token Ring or FDDI packets are encapsulated with an ISL frame.
Encapsulated FRAME	This field contains the encapsulated Layer 2 frame.
FCS	The FCS field consists of 4 bytes. It includes a 32-bit CRC value, which is created by the sending station and is recalculated by the receiving station to check for damaged frames. The FCS covers the DA, SA, Length/Type, and Data fields. When an ISL header is attached to a Layer 2 frame, a new FCS is calculated over the entire ISL packet and added to the end of the frame. Note The addition of the new FCS does not alter the original FCS that is contained within the encapsulated frame.

NetFlow Top Talkers

The usual implementation of NetFlow exports NetFlow data to a collector. The NetFlow Top Talkers features can be used for security monitoring or accounting purposes for top talkers, and matching and identifying key traffic in your network. These features are also useful for a network location where a traditional NetFlow export operation is not possible. The NetFlow Top Talkers features do not require a collector to obtain information regarding flows. Instead, the NetFlow data is displayed on the router when the NetFlow Dynamic Top Talkers CLI **show ip flow top** command, or the NetFlow Top Talkers **show ip flow top-talkers** is used.

Comparison of the NetFlow Dynamic Top Talkers CLI and NetFlow Top Talkers Features

There are two very similar NetFlow features that can be used for monitoring the highest volume traffic in your network. The feature names are:

- [NetFlow Dynamic Top Talkers CLI](#)
- [NetFlow Top Talkers](#)

NetFlow Dynamic Top Talkers CLI

This feature was introduced in 12.4(4)T. The NetFlow Dynamic Top Talkers CLI feature is used to obtain an overview of the highest volume traffic (top talkers) in your network. It provides an overview of the traffic by aggregating the flows in the cache based on the aggregation field that you select when you use the NetFlow Dynamic Top Talkers CLI feature.

The NetFlow Dynamic Top Talkers CLI feature does not require modifications to the configuration of the router. The **show ip flow top** command is the only command that you need to use for the NetFlow Dynamic Top Talkers CLI feature. You can invoke any of the NetFlow Dynamic Top Talkers CLI options directly from the **show ip flow top** command whenever you need them.

**Note**

The information that you want to use the NetFlow Dynamic Top Talkers CLI feature to analyze must be available in the cache. For example, if you want to be able to identify the MAC address in the flows, you must configure the **ip flow-capture mac-addresses** command in order to capture the values from the MAC address fields in the traffic first.

The NetFlow Dynamic Top Talkers CLI feature aggregates flows and allows them to be sorted so that they can be viewed. The flows can be aggregated on fields in the cache such as source or destination IP address, ICMP type and code values, and so forth. For a full list of the fields that you can aggregate the flows on, refer to the **show ip flow top** command in the Cisco IOS NetFlow command reference documentation.

The aggregated top talker flows can be sorted by any of the following criteria:

- The aggregated field in the display data
- The number of bytes in the display data
- The number of flows in the display data
- The by number of packets in the display data
- In ascending or descending order (to find the least used Top talker)

In addition to sorting top talkers, you can further organize your output by specifying criteria that the top talkers must match, such as source or destination IP address or port. The **match** keyword is used to specify this criterion. For a full list of the matching criterion that you can select, refer to the **show ip flow top** command in the Cisco IOS NetFlow command reference documentation.

The NetFlow Dynamic Top Talkers CLI feature can help you quickly identify traffic that is associated with security threats such as DoS attacks because it does not require configuration modifications. You can change the NetFlow Dynamic Top Talkers CLI options for identifying and analyzing network threats in the aggregated flows on-the-fly as you learn more about the traffic that is of interest. For example, after you have identified that there is a lot of ICMP traffic in your network by using the **show ip flow top 10 aggregate icmp** command you can learn what IP networks the traffic is being sent to by using the **show ip flow top 10 aggregate icmp match destination-prefix 172.0.0.0/8** command.

**Note**

A high volume of ICMP traffic might indicate that an ICMP-based DoS attack is in progress.

The **show ip flow top** command:

- Does not require additional NetFlow configuration commands to display top talkers. Therefore you do not need to supply the configuration mode password to the administrators who use the **show ip flow top** command to monitor network traffic. The only prerequisite for using the **show ip flow top** command is that you have configured NetFlow on at least one interface on the router.
- Aggregates flows automatically based on the aggregation method that you select, and independently of any netflow aggregation cache(s).
- Allows you to change the parameters of the command, such as the number of flows to display, the display order, and match criterion, on-the-fly every time that you use the command without having to change the router's configuration.

- Allows you to sort the display output in ascending or descending order based on:
 - The aggregated field
 - The number of bytes
 - The number of flows,
 - The number of packets

show ip flow top and show ip cache verbose flow

Many of the values shown in the display output of the **show ip cache verbose flow** command are in hexadecimal. If you want to match these values using the **show ip flow top** command with the **match** keyword, you must enter the field value that you want to match in hexadecimal. For example, to match on the destination port of 00DC in the following except from the **show ip cache verbose flow** command, you would use the **match destination-port 0x00DC** keywords and argument for the **show ip flow top** command.

SrcIf	SrcIPAddress	DstIf	DstIPAddress	Pr	TOS	Flgs	Pkts
Port Msk AS		Port Msk AS	NextHop			B/Pk	Active
Et0/0.1	10.10.11.4	Et1/0.1	172.16.10.8	06	00	00	209
00DC /0 0		00DC /0 0	0.0.0.0			40	281.4
MAC: (VLAN id)	aaaa.bbbb.cc03	(005)	aaaa.bbbb.cc06	(006)			
Min plen:	40		Max plen:	40			
Min TTL:	59		Max TTL:	59			
IP id:	0						

Match Criteria with the show ip flow top command

You can limit the top talkers that are displayed by the **show ip flow top** command by using the **match** keyword and arguments. For example, you can display the IP destination address top talkers that have a prefix of 224.0.0.0 using the **show ip flow top 10 aggregate destination-address match destination-prefix 224.0.0.0/3** command.

For a full list of the matching criterion that you can select, refer to the **show ip flow top** command in the *Cisco IOS NetFlow Command Reference*. If you do not configure match criteria all of the flows are considered as candidates for aggregation as top talkers based on the volume of traffic they represent.

The Order That Aggregation Occurs in

With the exception of the **flows** keyword, all matches are performed prior to aggregation, and only matching flows are aggregated. For example, the **show ip flow top 5 aggregate destination-address match destination-prefix 172.16.0.0/16** command analyzes all of the available flows looking for any flows that have destination addresses that match the **destination-prefix** value of **172.16.0.0/16**. If it finds any matches it aggregates them, and then displays the number of aggregated **destination-address** flows that is equal to the number of top talkers that were requested in the command—in this case five.

The **flows** keyword matches the number of aggregated flows post-aggregation. For example, the **show ip flow top 2 aggregate destination-address match 6** command aggregates all of the flows on the values in their destination IP address field, and then displays the top talkers that have 6 aggregated flows.

Number of Flows Matched

If you do not specify match criteria and there is traffic in the flows that includes the field that you used to aggregate the flows on, all of the flows will match. For example, if your router has 20 flows with IP traffic and you enter the **show ip flow top 10 aggregate destination-address** command the display will indicate that 20 of 20 flows matched, and the 10 top talkers will be displayed.

If you use the **match** keyword to limit the flows that are aggregated to the flows with a destination prefix of 224.0.0.0/3, and only one flow matches this criterion the output will indicate that one out of six flows matched. For example, if your router has 6 flows with IP traffic, but only one of them has a destination prefix of 224.0.0.0/3, and you enter the **show ip flow top 10 aggregate destination-address match destination-prefix 224.0.0.0/3** command, the display will indicate that 1 of 6 flows matched.

If the total number of top talkers is less than the number of top talkers that were requested in the command, the total number of top talkers is displayed. For example, if you enter a value of five for the number of top talkers to display and there are only three top talkers that match the criteria that you used, the display will only include three top talkers.

When a match criterion is included with the **show ip flow top** command, the display output will indicate “N of M flows matched” where $N \leq M$, N = matched flows, and M = total flows seen. The numbers of flows seen could potentially be more than the total number of flows in the cache if some of the analyzed flows were removed from the cache and new flows were created ahead of the current point, as the top talkers feature sweeps through the cache. Therefore, M is NOT the total number of flows in the cache, but rather, the number of observed flows.

If you attempt to display the top talkers by aggregating them on a field that is not in the cache you will see the “% aggregation-field is not available for this cache” message. For example, if you use the **show ip flow top 5 aggregate source-vlan** command, and you have not enabled the capture of VLAN IDs from the flows, you will see the “% VLAN id is not available for this cache” message.

NetFlow Top Talkers

This feature was introduced in 12.3(11)T. NetFlow Top Talkers is used to obtain information about individual flows in the cache. It does not aggregate the flows like the NetFlow Dynamic Top Talkers CLI feature.

The NetFlow Top Talkers feature compares all of the flows and displays information about each of the flows that have the heaviest traffic volumes (top talkers). The **show ip flow top-talkers** command requires you to pre-configure the router using the NetFlow Top Talkers configuration commands:

- **ip flow-top-talkers**—Enters the NetFlow Top Talkers configuration mode.
- **sort-by**—Selects the sort order for the flows in the display output.
 - **bytes**—Sort the flows based on the numbers of bytes in each flow.
 - **packets**—Sort the flows based on the numbers of packets in each flow.
- **top**—Specifies the number of top talkers to monitor.
- **match** (optional)—Specifies additional criteria, such as IP addresses, port numbers, and so forth, that must be matched in the flow to qualify as a candidate for top talker status.

For a full list of the matching criterion that you can select, refer to the **ip flow top-talkers** command in the *Cisco IOS NetFlow Command Reference*. If you do not configure match criteria all of the flows are considered as candidates as top talkers based on the volume of traffic they represent.

- **show ip flow top talkers [verbose]**—Displays the flows.

For more information on the NetFlow Top Talkers feature, refer to [Configuring NetFlow Top Talkers using Cisco IOS CLI Commands or SNMP Commands](#).

Filtering and Sampling of NetFlow Traffic

NetFlow provides highly granular per-flow traffic statistics in a Cisco router. A flow is a unidirectional stream of packets that arrive at the router on the same subinterface, have the same source and destination IP addresses, Layer 4 protocol, TCP/UDP source and destination ports, and the same ToS (type of service) byte in the IP headers. The router accumulates NetFlow statistics in a NetFlow cache and can export them to an external device (such as the Cisco Networking Services (CNS) NetFlow Collection Engine) for further processing.

Full NetFlow accounts for all traffic entering the subinterface on which it is enabled. But in some cases, you might gather NetFlow data on only a subset of this traffic. The Random Sampled NetFlow feature and the NetFlow Input Filters feature each provide ways to limit incoming traffic to only traffic of interest for NetFlow processing. Random Sampled NetFlow provides NetFlow data for a subset of traffic in a Cisco router by processing only one randomly selected packet out of n sequential packets. The NetFlow Input Filters feature provides the capability to gather NetFlow data on only a specific user-defined subset of traffic.



Note

Random Sampled NetFlow is more statistically accurate than Sampled NetFlow. NetFlow's ability to sample packets was first provided by a feature named Sampled NetFlow. The methodology that the Sampled NetFlow feature uses is *deterministic* sampling, which selects every n th packet for NetFlow processing on a per-interface basis. For example, if you set the sampling rate to 1 out of 100 packets, then Sampled NetFlow samples the 1st, 101st, 201st, 301st, and so on packets. Sampled NetFlow does not allow random sampling and thus can make statistics inaccurate when traffic arrives in fixed patterns.



Note

The Random Sampled NetFlow algorithms are applied after input filtering.

Table 6 compares the NetFlow Input Filters feature and the NetFlow Random Sampled feature.

Table 6 Comparison of the NetFlow Input Filters Feature and the Random Sampled NetFlow Feature

Comparison Category	NetFlow Input Filters Feature	Random Sampled NetFlow Feature
Brief description	This feature enables you to gather NetFlow data on only a specific subset of traffic. You do this by creating filters to select flows for NetFlow processing. For example, you can select flows from a specific group of hosts. This feature also lets you select various sampling rates for selected flows.	This feature provides NetFlow data for a subset of traffic in a Cisco router by processing only one randomly selected packet out of n sequential packets (n is a user-configurable parameter). Packets are sampled as they arrive (before any NetFlow cache entries are made for those packets).
Main uses	You can use this feature for class-based traffic analysis and monitoring on-network or off-network traffic. This feature is also useful if you have too much traffic and you want to limit the traffic that is analyzed.	You can use this feature for traffic engineering, capacity planning, and applications where full NetFlow is not needed for an accurate view of network traffic. This feature is also useful if you have too much traffic and you want to limit the traffic that is analyzed.
Export format support	This feature is supported in the Version 5 and Version 9 NetFlow export formats.	This feature is supported in the Version 5 and Version 9 NetFlow export formats.
Cisco IOS release support	12.3(4)T.	12.3(2)T, 12.2(18)S, and 12.0(26)S.

Table 6 Comparison of the NetFlow Input Filters Feature and the Random Sampled NetFlow Feature (continued)

Comparison Category	NetFlow Input Filters Feature	Random Sampled NetFlow Feature
Subinterface support	<p>You can configure NetFlow Input Filters per subinterface as well as per physical interface.</p> <p>You can select more than one filter per subinterface and have all of the filters run simultaneously.</p>	<p>You can configure the Random Sampled NetFlow feature per subinterface as well as per physical interface.</p> <p>You can not run Full NetFlow and Random Sampled NetFlow concurrently on the same subinterface. You must disable full NetFlow on the subinterface before Random Sampled NetFlow will take effect.</p> <p>Traffic is collected only on the subinterfaces on which Random Sampled NetFlow is configured. As with full NetFlow, enabling Random Sampled NetFlow on a physical interface does not enable Random Sampled NetFlow on subinterfaces automatically—you must explicitly configure it on the subinterfaces.</p>
Memory impact	<p>This feature requires no additional memory. It allows you to use a smaller NetFlow cache than full NetFlow, because it significantly reduces the number of flows. This feature requires an insignificant amount of memory for each configured NetFlow filter.</p>	<p>This feature can create a smaller NetFlow cache than full NetFlow if by reducing the number of packets being analyzed the numbers of flows in the cache is also reduced. This feature requires an insignificant amount of memory for each configured NetFlow sampler.</p>
Performance impact	<p>Accounting of classified traffic saves router resources by reducing the number of flows being processed and exported. The amount of bandwidth saved depends on the usage and the class-map criteria.</p> <p>However, performance might degrade depending on the number and complexity of class maps configured in a policy.</p>	<p>Statistical traffic sampling substantially reduces consumption of router resources (especially CPU resources) while providing valuable NetFlow data.</p> <p>This feature substantially reduces the impact of NetFlow data export on interface traffic. For example, a sampling rate of 1 out of 100 packets reduces the export of NetFlow data by about 99% percent.</p>

NetFlow Input Filters: Flow Classification

For the NetFlow Input Filters feature, classification of packets can be based on any of the following: IP source and destination addresses, Layer 4 protocol and port numbers, incoming interface, MAC address, IP Precedence, DSCP value, Layer 2 information (such as Frame-Relay DE bits or Ethernet 802.1p bits), and Network-Based Application Recognition (NBAR) information. The packets are classified (filtered) on the above criteria, and flow accounting is applied to them on subinterfaces.

The filtering mechanism uses the Modular QoS Command-Line Interface (MQC) to classify flows. You can create multiple filters with matching samplers on a per-subinterface basis. For example, you can subdivide subinterface traffic into multiple classes based on type of service (ToS) values or destination prefixes (or both). For each class, you can also configure sampling at a different rate, using higher rates for higher-priority classes of traffic and lower rates for lower-priority ones.

MQC has many policies (actions) such as bandwidth rate and queuing management. These policies are applied only if a packet matches a criterion in a class map that is applied to the subinterface. A class map contains a set of match clauses and instructions on how to evaluate the clauses and acts as a filter for the policies, which are applied only if a packet's content satisfies the match clause. The NetFlow Input Filters feature adds NetFlow accounting to the MQC infrastructure, which means that flow accounting is done on a packet only if it satisfies the match clauses.

Two types of filter are available:

- ACL-based flow-mask filters
- Fields of filter (source IP address, destination IP address, source application port, destination application port, port protocol, ToS bits, and TCP flags)

For more information on Modular QoS Command-Line Interface (MQC) refer to the *Cisco IOS Quality of Service Solutions Configuration Guide*.

Random Sampled NetFlow: Sampling Mode

Sampling mode makes use of an algorithm that selects a subset of traffic for NetFlow processing. In the random sampling mode that the Random Sampled NetFlow feature uses, incoming packets are randomly selected on average one out of each n sequential packets is selected for NetFlow processing. For example, if you set the sampling rate to 1 out of 100 packets, then NetFlow might sample the 5th packet and then the 120th, 230th, 302nd, and so on. This sample configuration provides NetFlow data on 1 percent of total traffic. The n value is a parameter that you can configure from 1 to 65535 packets.

Random Sampled NetFlow: The NetFlow Sampler Map

Random Sampled NetFlow is useful if you have too much traffic and you want to limit the traffic that is analyzed. A NetFlow sampler map is created with the **flow-sampler-map** *sampler-map-name* command. The sampling mode for the sampler map is configured with the **mode random one-out-of** *sampling-rate* command. The range of values for the *sampling-rate* argument is 1 to 65535. Each NetFlow sampler map can be applied to one or many subinterfaces as well as physical interfaces. The sampler map is applied to an interface or subinterface with the **flow-sampler** *sampler-map-name* command. You can define up to eight NetFlow sampler maps.

How to Configure and Use NetFlow to Detect and Analyze Network Threats

Using NetFlow to detect and analyze network threats requires a combination of configuration commands and show commands. You start by configuring the NetFlow Layer 2 and Security Monitoring Exports feature to capture values of the additional non-key fields from the flows so that they can be displayed in the cache by the NetFlow show commands. Capturing the values in the additional non-key fields is required so that you can identify the path the traffic is taking through the network and other characteristics of the traffic such as TTL values and packet length values.

After you configure the NetFlow Layer 2 and Security Monitoring Exports feature, you use the NetFlow Dynamic Top Talkers CLI command to obtain an overview of the traffic flows the router is forwarding. The overview displays information such as the protocol distribution in the flows, the source ip addresses that are sending the flows, and the networks the flows are being sent to.

After you identify the type of flows that you want to focus, on such as ICMP traffic, and other characteristics such as source IP addresses and destination network prefixes, you use the NetFlow Top Talkers feature to obtain more focused and detailed information on the individual flows. The NetFlow Top Talkers feature is configured with match criteria that focuses it on the types of traffic that you have identified. If your router is keeping track of several flows and you are only interested in analyzing a subset of them you, can configure NetFlow Input Filters to limit the flows that NetFlow is tracking.

Prerequisites

CEF or dCEF must be configured globally, and on the interface that you want to run NetFlow on, before you configure NetFlow Layer 2 and Security Monitoring Exports.

You must have NetFlow enabled on at least one interface in the router before you configure NetFlow Layer 2 and Security Monitoring Exports.

If you want to capture the values of the Layer 3 IP fragment offset field from the IP headers in your IP traffic using the **ip flow-capture fragment-offset** command, your router must be running Cisco IOS 12.4(2)T or later.

This section contains the following procedures:

- [Configuring NetFlow Layer 2 and Security Monitoring Exports, page 20](#)
- [Verifying NetFlow Layer 2 and Security Monitoring Exports, page 22](#)
- [Using NetFlow Dynamic Top Talkers CLI to Display the Protocol Distribution, page 24](#)
- [Using NetFlow Dynamic Top Talkers CLI to Display the Source IP Address Top Talkers Sending ICMP Traffic, page 25](#)
- [Using NetFlow Dynamic Top Talkers CLI to Display the Destination IP Address Top Talkers Receiving ICMP Traffic, page 27](#)
- [Configuring NetFlow Top Talkers to Monitor Network Threats, page 28](#)
- [Monitoring and Analyzing the NetFlow Top Talkers Flows, page 30](#)
- [Configuring NetFlow Filtering and Sampling, page 33](#)
- [Verify NetFlow Filtering and Sampling, page 38](#)
- [Monitoring and Analyzing the Sampled and Filtered NetFlow Top Talkers Flows, page 39](#)

Configuring NetFlow Layer 2 and Security Monitoring Exports

Perform the following task to configure the NetFlow Layer 2 and Security Monitoring Exports feature.

Prerequisites

To export the data captured with the NetFlow Layer 2 and Security Monitoring feature, you must configure NetFlow to use the NetFlow Version 9 data export format.

SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **ip flow-capture fragment-offset**

4. **ip flow-capture icmp**
5. **ip flow-capture ip-id**
6. **ip flow-capture mac-addresses**
7. **ip flow-capture packet-length**
8. **ip flow-capture ttl**
9. **ip flow-capture vlan-id**
10. **interface** *interface-type interface-number*
11. **ip flow ingress**
and/or
ip flow egress
12. **end**

DETAILED STEPS

	Command or Action	Purpose
Step 1	enable Example: Router> enable	Enables privileged EXEC mode. <ul style="list-style-type: none">• Enter your password if prompted.
Step 2	configure terminal Example: Router# configure terminal	Enters global configuration mode.
Step 3	ip flow-capture fragment-offset Example: Router(config)# ip flow-capture fragment-offset	Enables capturing the value of the IP fragment offset field from the first fragmented IP datagram in a flow.
Step 4	ip flow-capture icmp Example: Router(config)# ip flow-capture icmp	Enables you to capture the value of the ICMP type and code fields from the first ICMP datagram in a flow.
Step 5	ip flow-capture ip-id Example: Router(config)# ip flow-capture ip-id	Enables you to capture the value of the IP-ID field from the first IP datagram in a flow.
Step 6	ip flow-capture mac-addresses Example: Router(config)# ip flow-capture mac-addresses	Enables you to capture the values of the source and destination MAC addresses from the first Layer 2 frame in a flow.
Step 7	ip flow-capture packet-length Example: Router(config)# ip flow-capture packet-length	Enables you to capture the minimum and maximum values of the packet length field from IP datagrams in a flow.

	Command or Action	Purpose
Step 8	<code>ip flow-capture ttl</code> Example: Router(config)# ip flow-capture ttl	Enables you to capture the minimum and maximum values of the Time-to-Live (TTL) field from IP datagrams in a flow.
Step 9	<code>ip flow-capture vlan-id</code> Example: Router(config)# ip flow-capture vlan-id	Enables you to capture the 802.1q or ISL VLAN-ID field from first VLAN encapsulated Layer 2 frame in a flow that is received or transmitted on a trunk port.
Step 10	<code>interface type interface-type interface-number]</code> Example: Router(config)# interface ethernet 0/0	Enters interface configuration mode for the type of interface specified in the command.
Step 11	<code>ip flow ingress</code> and/or <code>ip flow egress</code> Example: Router(config-if)# ip flow ingress and/or Example: Router(config-if)# ip flow egress	Enables ingress NetFlow data collection on the interface. and/or Enables egress NetFlow data collection on the interface.
Step 12	<code>end</code> Example: Router(config)# end	Returns to privileged EXEC mode.

Verifying NetFlow Layer 2 and Security Monitoring Exports

This task verifies that NetFlow Layer 2 and Security Monitoring Exports is configured correctly. The **show ip cache verbose flow** command gives a detailed view of the status and statistics for flows in the NetFlow main cache. The values for the NetFlow non-key fields that you have configured with the NetFlow Layer 2 and Security Monitoring Exports feature are included for each flow.

To see the values of the fields that you have configured the NetFlow Layer 2 and Security Monitoring Exports feature to capture, your router must be forwarding IP traffic that meets the criteria for these fields. For example, if you configure the **ip flow-capture vlan-id** command, your router must be forwarding IP datagrams over interfaces that are configured as VLAN trunks to capture the VLAN-ID values from the layer-two frames carrying the IP datagrams in the flow.

Restrictions

Displaying Detailed NetFlow Cache Information on Platforms Running Distributed Cisco Express Forwarding

On platforms running dCEF, NetFlow cache information is maintained on each line card or Versatile Interface Processor. If you want to use the **show ip cache verbose flow** command to display this information on a distributed platform, you must enter the command at a line card prompt.

Cisco 7500 Series Platform

To display detailed NetFlow cache information on a Cisco 7500 series router that is running distributed dCEF, enter the following sequence of commands:

```
Router# if-con slot-number
LC-slot-number# show ip cache verbose flow
```

For Cisco IOS Releases 12.3(4)T, 12.3(6), and 12.2(20)S and later, enter the following command to display detailed NetFlow cache information:

```
Router# execute-on slot-number show ip cache verbose flow
```

Cisco 12000 Series Platform

To display detailed NetFlow cache information on a Cisco 12000 Series Internet Router, enter the following sequence of commands:

```
Router# attach slot-number
LC-slot-number# show ip cache verbose flow
```

For Cisco IOS Releases 12.3(4)T, 12.3(6), and 12.2(20)S and later, enter the following command to display detailed NetFlow cache information:

```
Router# execute-on slot-number show ip cache verbose flow
```

To verify the configuration of NetFlow Layer 2 and Security Monitoring Exports use the following step.

SUMMARY STEPS

1. **show ip cache verbose flow**

DETAILED STEPS

Step 1 **show ip cache verbose flow**

This example shows that NetFlow Layer 2 and Security Monitoring Exports is working properly because the values have been captured from the non-key Layer 3 and Layer 2 fields in the flows. The values captured in the flows are shown in **bold** text.

```
Router# show ip cache verbose flow
IP packet size distribution (33978 total packets):
1-32 64 96 128 160 192 224 256 288 320 352 384 416 448 480
.856 .143 .000 .000 .000 .000 .000 .000 .000 .000 .000 .000 .000 .000 .000

512 544 576 1024 1536 2048 2560 3072 3584 4096 4608
.000 .000 .000 .000 .000 .000 .000 .000 .000 .000 .000

IP Flow Switching Cache, 278544 bytes
14 active, 4082 inactive, 59 added
12452 ager polls, 0 flow alloc failures
Active flows timeout in 10 minutes
Inactive flows timeout in 15 seconds
IP Sub Flow Cache, 25736 bytes
28 active, 996 inactive, 148 added, 59 added to flow
0 alloc failures, 0 force free
1 chunk, 1 chunk added
last clearing of statistics never
Protocol      Total    Flows   Packets Bytes   Packets Active(Sec) Idle(Sec)
-----
              Flows   /Sec    /Flow /Pkt    /Sec    /Flow    /Flow
TCP-SMTP      2        0.0     1730  40      3.6     600.7     0.2
UDP-other     31       0.0      1    54      0.0      3.6     16.8
ICMP          12       0.0     1728  28     22.0     600.1     0.1
```

```

Total:                45      0.0      538    29    25.7    189.2    11.6

SrcIf      SrcIPAddress  DstIf      DstIPAddress  Pr TOS Flgs Pkts
Port Msk AS          Port Msk AS  NextHop      B/Pk Active
.
.
Et0/0.1    10.71.200.138  Et1/0.1    172.16.10.2   01 00 10    696
0000 /0  0          0C01 /0  0          0.0.0.0       28  241.4
MAC: (VLAN id) aaaa.bbbb.cc03 (005)    aaaa.bbbb.cc06 (006)
Min plen:      28                      Max plen:      28
Min TTL:       59                      Max TTL:       59
ICMP type:     12                      ICMP code:     1
IP id:         0

```

Using NetFlow Dynamic Top Talkers CLI to Display the Protocol Distribution

You can obtain a quick overview of the traffic in your network by viewing the protocol distribution. Use this task to display the top talkers (aggregated flows) for these three IPv4 protocol types:

- 1—ICMP
- 6—TCP
- 17—UDP

SUMMARY STEPS

1. **show ip flow top *number* aggregate *aggregate-field* sorted-by packets descending**

DETAILED STEPS

Step 1 **show ip flow top *number* aggregate *aggregate-field* sorted-by packets descending**

The following example looks for up to three top talkers, aggregates them on the protocol field, sorts them by packets, and displays the output in descending order:

```
Router# show ip flow top 3 aggregate protocol sorted-by packets descending
```

There are 3 top talkers:

```

IPV4 PROT      bytes      pkts      flows
=====
1             406196    14507     12
6              96560     2414      2
17              52        1         1

```

15 of 15 flows matched.

Table 7 describes the significant fields shown in the display output.

Table 7 *show ip flow top 3 aggregate protocol sorted-by packets descending Field Descriptions*

Field	Description
There are 3 top talkers	The number of top talkers is displayed.
IPV4 PROT	This position in the display output is used to show the field that you selected to aggregate the flows on. The protocol keyword aggregates IPv4 traffic in the flows based on the IPv4 protocol type. In this example there are three IPv4 protocol types in the flows: <ul style="list-style-type: none"> • 1—ICMP • 6—TCP • 17—UDP
bytes	Displays the numbers of bytes in the aggregated flows for each top talker.
pkts	Displays the numbers of packets in the aggregated flows for each top talker.
flows	Displays the numbers of aggregated flows for each top talker.
15 of 15 flows matched.	Displays the number of flows that matched the command.

All 15 flows in the router are aggregated into three top talkers. In this example all of the flow traffic is top talker traffic.

The majority of the traffic is ICMP traffic (IP protocol type 1). This might indicate an ICMP DoS attack is in progress.

Using NetFlow Dynamic Top Talkers CLI to Display the Source IP Address Top Talkers Sending ICMP Traffic

The display output from the **show ip flow top 10 aggregate protocol sorted-by packets descending** used in [Using NetFlow Dynamic Top Talkers CLI to Display the Protocol Distribution](#) section indicates that there is a possible ICMP-based DoS attack in progress. The next step to take is to identify the flows that are sending the ICMP traffic. In this case the flows will be aggregated on the source IP addresses.

SUMMARY STEPS

1. **show ip flow top number aggregate aggregate-field sorted-by packets match match-field match-value**

DETAILED STEPS

-
- Step 1** **show ip flow top number aggregate aggregate-field sorted-by packets match match-field match-value**

The following command looks for up to 20 top talkers, aggregates them on the source IP address, sorts them by packets, and matches on the protocol icmp:

```
Router# show ip flow top 20 aggregate source-address sorted-by packets match protocol icmp
```

There are 6 top talkers:

```
IPV4 SRC-ADDR      bytes      pkts      flows
=====
10.132.221.111    90440     3230     1
10.10.12.1        90440     3230     1
10.251.138.218    90440     3230     1
10.71.200.138     90384     3228     1
10.231.185.254    90384     3228     1
10.106.1.1        90356     3227     1
```

6 of 15 flows matched.

Router

Table 8 describes the significant fields shown in the display.

Table 8 *show ip flow top 20 aggregate source-address sorted-by packets match protocol icmp Field Descriptions*

Field	Description
There are 6 top talkers	The number of top talkers is displayed. Note Only 6 top talkers are displayed, even though you asked for 20, because only 6 of the 15 flows in the cache matched the criteria you specified. The number 20 is an upper limit that will be applied in the event that there are over 20 top talkers.
IPV4 SRC-ADDR	This position in the display output is used to show the field that you selected to aggregate the flows on. The source-address keyword aggregates flows based on the source IP address. In this example there are 6 IP source addresses with aggregated flows. Each of the IP addresses has 1 flow, therefore no aggregation was performed: <ul style="list-style-type: none"> • 10.132.221.111 • 10.10.12.1 • 10.251.138.218 • 10.71.200.138 • 10.231.185.254 • 10.106.1.1
bytes	Displays the numbers of bytes in the aggregated flows for each top talker.
pkts	Displays the numbers of packets in the aggregated flows for each top talker.

Table 8 *show ip flow top 20 aggregate source-address sorted-by packets match protocol icmp Field Descriptions (continued)*

Field	Description
flows	Displays the numbers of aggregated flows for each top talker.
6 of 15flows matched.	Displays the number of flows that matched the command.

The ICMP traffic is aggregated into six top talkers (source IP addresses). Each top talker has one flow. No aggregation is performed on this traffic because there is a 1-to-1 correlation of IP source addresses and flows.

Using NetFlow Dynamic Top Talkers CLI to Display the Destination IP Address Top Talkers Receiving ICMP Traffic

The display output from the **show ip flow top 5 aggregate source-address sorted-by packets match protocol icmp** command used in [Using NetFlow Dynamic Top Talkers CLI to Display the Source IP Address Top Talkers Sending ICMP Traffic](#) section showed the six top talkers (IP source addresses) that are sending the 12 ICMP traffic flows. The next step to take is to identify the flows that are the target of the ICMP traffic. In this case the flows will be aggregated on the destination IP addresses.

SUMMARY STEPS

1. **show ip flow top number aggregate aggregate-field sorted-by packets match match-field match-value**

DETAILED STEPS

Step 1 **show ip flow top number aggregate aggregate-field sorted-by packets match match-field match-value**

The following command looks for up to 20 top talkers, aggregates them on the destination IP address, sorts them by packets, and matches on the protocol icmp

```
Router# show ip flow top 20 aggregate destination-address sorted-by packets match protocol icmp
```

There is 1 top talker:

```
IPV4 DST-ADDR      bytes      pkts      flows
=====
172.16.10.2        407456    14552     6
```

6 of 14 flows matched.

Router

[Table 9](#) describes the significant fields shown in the display.

Table 9 *show ip flow top 20 aggregate destination-address sorted-by packets match protocol icmp Field Descriptions*

Field	Description
There is 1 top talker	The number of top talkers is displayed. <ul style="list-style-type: none"> The ICMP traffic is aggregated into 6 flows for one destination IP addresses.
IPV4 DST-ADDR	This position in the display output is used to show the field that you selected to aggregate the flows on. The destination-address keyword aggregates flows based on the destination IP address. In this example there are 3 IP destination address with aggregated flows. The IP addresses has 8 aggregated flows: <ul style="list-style-type: none"> 172.16.10.2
bytes	Displays the numbers of bytes in the aggregated flows for each top talker.
pkts	Displays the numbers of packets in the aggregated flows for each top talker.
flows	Displays the numbers of aggregated flows for each top talker.
6 of 14 flows matched.	Displays the number of flows that matched the command.

The previous task identified six ICMP top talkers based on source IP addresses that each had one flow. This task identified that there is one ICMP top talker based on destination IP addresses that is the target for 6 individual flows. There is a 1-to-1 correlation between the number of ICMP flows in the top talkers aggregated on the source IP address and the number of ICMP flows in the top talkers aggregated on the destination IP address. There is a high probability that an ICMP-based DoS attack on the host with the IP address of 172.16.10.2 is in progress.

Configuring NetFlow Top Talkers to Monitor Network Threats

The previous task (Using NetFlow Dynamic Top Talkers CLI to Display the Destination IP Address Top Talkers Receiving ICMP Traffic) identified a probable ICMP-based DoS attack on the host with the IP address 172.16.10.2. This task uses the NetFlow Top Talkers feature to configure the router to monitor the DoS attack by tracking the individual ICMP flows. After you have configured the NetFlow Top Talkers feature to focus on the DoS attack traffic, you can use the **show ip flow top-talkers verbose** command to identify the path the DoS traffic is taking through the network.

Perform the following task to configure the NetFlow Top Talkers feature.

SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **ip flow-top-talkers**
4. **match destination address ip-address/prefix-mask**

5. `top number`
6. `sort by [bytes | packets]`
7. `end`

DETAILED STEPS

	Command or Action	Purpose
Step 1	<p><code>enable</code></p> <p>Example: Router> enable</p>	<p>Enables privileged EXEC mode.</p> <ul style="list-style-type: none"> • Enter your password if prompted.
Step 2	<p><code>configure terminal</code></p> <p>Example: Router# configure terminal</p>	<p>Enters global configuration mode.</p>
Step 3	<p><code>ip flow-top-talkers</code></p> <p>Example: Router(config)# ip flow-top-talkers</p>	<p>Enters NetFlow top talkers configuration mode.</p>
Step 4	<p><code>match destination address</code> <i>ip-address/prefix-mask</i></p> <p>Example: Router(config-flow-top-talkers)# match destination address 172.16.10.2/32</p>	<p>Specifies the destination IP addresses to match.</p>
Step 5	<p><code>top number</code></p> <p>Example: Router(config-flow-top-talkers)# top 50</p>	<p>Specifies the maximum number of top talkers that will be retrieved by a NetFlow top talkers query.</p>
Step 6	<p><code>sort-by [bytes packets]</code></p> <p>Example: Router(config-flow-top-talkers)# sort-by packets</p>	<p>Specifies the sort criterion for the top talkers.</p> <ul style="list-style-type: none"> • The top talkers can be sorted either by the total number of packets of each top talker or the total number of bytes of each top talker.
Step 7	<p><code>end</code></p> <p>Example: Router(config-flow-top-talkers)# end</p>	<p>Exits to privileged EXEC mode.</p>

Monitoring and Analyzing the NetFlow Top Talkers Flows

To monitor and analyze the NetFlow Top Talkers flows, use the following step.

SUMMARY STEPS

1. `show ip flow top-talkers verbose`

DETAILED STEPS

Step 1 `show ip flow top-talkers verbose`

The following sample shows details for the six traffic flows that are being sent to the host with IP address 172.16.10.2.

```
Router# show ip flow top-talkers verbose
```

SrcIf	SrcIPAddress	DstIf	DstIPAddress	Pr	TOS	Flgs	Bytes
Port Msk AS		Port Msk AS	NextHop			B/Pk	Active
Et0/0.1	10.106.1.1	Et1/0.1	172.16.10.2	01	00	10	9408
0000 /0 0		0800 /0 0	0.0.0.0			28	116.3
MAC: (VLAN id)	aaaa.bbbb.cc03	(005)	aaaa.bbbb.cc06	(006)			
Min plen:	28		Max plen:	28			
Min TTL:	59		Max TTL:	59			
ICMP type:	8		ICMP code:	0			
IP id:	0						
Et0/0.1	10.132.221.111	Et1/0.1	172.16.10.2	01	00	10	9408
0000 /0 0		0800 /0 0	0.0.0.0			28	116.4
MAC: (VLAN id)	aaaa.bbbb.cc03	(005)	aaaa.bbbb.cc06	(006)			
Min plen:	28		Max plen:	28			
Min TTL:	59		Max TTL:	59			
ICMP type:	8		ICMP code:	0			
IP id:	0						
Et0/0.1	10.10.12.1	Et1/0.1	172.16.10.2	01	00	10	9408
0000 /0 0		0C01 /0 0	0.0.0.0			28	116.4
MAC: (VLAN id)	aaaa.bbbb.cc03	(005)	aaaa.bbbb.cc06	(006)			
Min plen:	28		Max plen:	28			
Min TTL:	59		Max TTL:	59			
ICMP type:	12		ICMP code:	1			
IP id:	0						
Et0/0.1	10.251.138.218	Et1/0.1	172.16.10.2	01	00	10	9408
0000 /0 0		0C01 /0 0	0.0.0.0			28	116.4
MAC: (VLAN id)	aaaa.bbbb.cc03	(005)	aaaa.bbbb.cc06	(006)			
Min plen:	28		Max plen:	28			
Min TTL:	59		Max TTL:	59			
ICMP type:	12		ICMP code:	1			
IP id:	0						
Et0/0.1	10.71.200.138	Et1/0.1	172.16.10.2	01	00	10	9408
0000 /0 0		0C01 /0 0	0.0.0.0			28	116.5
MAC: (VLAN id)	aaaa.bbbb.cc03	(005)	aaaa.bbbb.cc06	(006)			
Min plen:	28		Max plen:	28			
Min TTL:	59		Max TTL:	59			
ICMP type:	12		ICMP code:	1			
IP id:	0						
Et0/0.1	10.231.185.254	Et1/0.1	172.16.10.2	01	00	10	9408
0000 /0 0		0C01 /0 0	0.0.0.0			28	116.5

```
MAC: (VLAN id) aaaa.bbbb.cc03 (005)          aaaa.bbbb.cc06 (006)
Min plen:      28                          Max plen:      28
Min TTL:       59                          Max TTL:       59
ICMP type:     12                          ICMP code:     1
IP id:         0
```

6 of 50 top talkers shown. 6 of 8 flows matched.



Note Only six of the eight flows matched because the rest of the flows are not top talker flows.



Note The top 50 flows were requested, however there are only eight flows in the cache.

This display output contains the information required for determining the path that the DoS attack traffic is taking through the network. This information will be used to react to the DoS attack by adding security measures such as access-lists to the affected interfaces. [Table 10](#) describes the significant fields in the display from the **show ip flow top-talkers verbose** command for determining the network path the DoS traffic is taking.

Table 10 Significant Field Descriptions for show ip flow top-talkers verbose

Field	Description
SrcIf	Interface on which the packet was received. <ul style="list-style-type: none"> All of the ICMP DoS traffic is being received on Et0/0.1
SrcIPAddress	This is the source IP address of the traffic in the six top talkers. The traffic is using 6 different IP source addresses <ul style="list-style-type: none"> 10.132.221.111 10.10.12.1 10.251.138.218 10.71.200.138 10.231.185.254 10.106.1.1
DstIf	Interface from which the packet was transmitted. <ul style="list-style-type: none"> All of the ICMP DoS traffic is being transmitted over Et1/0.1 <p>Note If an asterisk (*) immediately follows the DstIf field, the flow being shown is an egress flow.</p>
ICMP Type	The ICMP datagram types <ul style="list-style-type: none"> 8—Echo 12—Parameter Problem

Table 10 Significant Field Descriptions for `show ip flow top-talkers verbose` (continued)

Field	Description
ICMP Code	The ICMP codes <ul style="list-style-type: none"> • 0—None (not applicable) • 1—Depends on the ICMP Type <ul style="list-style-type: none"> – A code value of 1 for ICMP type 12 indicates that a required option is missing
DstIPAddress	This is the destination IP address of the traffic. Note 172.17.10.2 is the IP address that is being attacked.
MAC	These are the source and destination MAC addresses from the traffic. The source and destination MAC address are read from left to right in the output. <ul style="list-style-type: none"> • The traffic is being received from MAC address aaa.bbb.cc03. Note This MAC address is interface 1/0.1 on router R2. <ul style="list-style-type: none"> • The traffic is being transmitted to MAC address aaa.bbb.cc06. Note This MAC address is interface 1/0.1 on router R4.
VLAN id	These are the source and destination VLAN IDs. The source and destination VLAN IDs are read from left to right in the output. <ul style="list-style-type: none"> • The traffic is being received from VLAN 5. • The traffic is being transmitted to VLAN 6.

The flows in this example show only the ICMP DoS attack traffic that is destined for the host with IP address 172.16.10.2. These flows were created specifically for documenting this task. In a real network, the host under attack might be communicating with other hosts that are using legitimate applications such as e-mail and web sites. In this case, the Top Talkers match filter on the destination IP address (**match destination address 172.16.10.2/32**) that was configured in the “[Configuring NetFlow Top Talkers to Monitor Network Threats](#)” section on page 28 will not limit the display of the `show ip flow top-talkers` command to the ICMP DoS attack traffic.

**Note**

For more information on the fields in the display output of the `show ip cache verbose flow` command, refer to the *Cisco IOS NetFlow Command Reference*.

If you are using the Top Talkers feature to analyze a network threat and you are not able to use the basic match filters to limit the display of the `show ip flow top-talkers` command to the traffic that you are analyzing, you can use NetFlow filtering and sampling to limit the traffic that shows up in the display of the `show ip flow top-talkers` command. The process for configuring NetFlow filtering and sampling is explained in the “[Configuring NetFlow Filtering and Sampling](#)” section on page 33.

Configuring NetFlow Filtering and Sampling

If you use the **show ip cache flow** command or the **show ip cache verbose flow** command to display the flows in the cache, you will see the ICMP flows that are selected by NetFlow filtering and sampling on interface Ethernet0/0.1, and flows for all NetFlow supported traffic types on any other interfaces that NetFlow is running on. The **show ip flow top-talkers [verbose]** command is used to display the flow status and statistics for the traffic type you configured with the match criteria over interfaces to which you applied the service policy. For example, in this case you configured top talkers to match on ICMP traffic sent from any host that is arriving on Ethernet0/0.1 and destined for 172.16.10.2.

In this task the Top Talkers feature is being used more as a flow filter to separate flows of interest from all of the flows the router is seeing, rather than a filter to display the flows with the highest traffic volumes. Top talkers is used in this manner because in this example all of the ICMP DoS attack flows are of interest, not just the flows with the highest volumes. This is why a large value is assigned to the **top** keyword in the top talkers configuration. Setting the value for the **top** keyword to 50 when the largest number of ICMP DoS attack flows tracked by the router is 12 ensures that all of the ICMP DoS attack flows will be tracked.

If your router sees a significant number of flows involved in a DoS attack, you might want to set the value for the **top** keyword to a number that is less than the total number of flows to limit the number of flows that you see in the display when you use the **show ip flow top-talkers** command. This will ensure that you are seeing the flows that have the highest volume of DoS attack traffic. However, if all of the flows have the same traffic volume, the **show ip flow top-talkers** command will not be able to differentiate between them. It displays the number of flows that you set the value of the **top** keyword to, starting from the first flow in the cache.

Perform the following task to configure NetFlow Filtering and sampling.

Restrictions

Restrictions for NetFlow Input Filters

On Cisco 7500 platforms, the NetFlow Input Filters feature is supported only in distributed mode.

Restrictions for Random Sampled NetFlow

If full NetFlow is enabled on an interface, it takes precedence over Random Sampled NetFlow (which will thus have no effect). Disable full NetFlow on an interface before enabling Random Sampled NetFlow on that interface.

Enabling Random Sampled NetFlow on a physical interface does not automatically enable Random Sampled NetFlow on subinterfaces; you must explicitly configure it on subinterfaces. Also, disabling Random Sampled NetFlow on a physical interface (or a subinterface) does not enable full NetFlow. This restriction prevents the transition to full NetFlow from overwhelming the physical interface (or subinterface). If you want full NetFlow, you must explicitly enable it.

You must use NetFlow Version 9 if you want to use sampler option templates or view NetFlow sampler IDs.

SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **flow-sampler-map** *sampler-map-name*
4. **mode random** *one-out-of packet-interval*

5. **exit**
6. **class-map** [**match-all** | **match-any**] *class-map-name*
7. **match access-group** *access-group*
8. **exit**
9. **policy-map** *policy-map-name*
10. **class** {*class-name* | **class-default**}
11. **netflow-sampler** *sampler-map-name*
12. **exit**
13. **exit**
14. **interface** *interface-type interface-number*
15. **no** [**ip route-cache flow** | **ip flow ingress**]
16. **service-policy** {**input** | **output**} *policy-map-name*
17. **exit**
18. **ip flow-top-talkers**
19. **top** *number*
20. **sort-by** packets
21. **match class-map** *class-name*
22. **no match destination address** *ip-address/prefix-mask*
23. **exit**
24. **access-list** *access-list-number* **permit icmp** *source destination*
25. **end**

DETAILED STEPS

	Command or Action	Purpose
Step 1	enable Example: Router> enable	Enables privileged EXEC mode. <ul style="list-style-type: none"> Enter your password if prompted.
Step 2	configure terminal Example: Router# configure terminal	Enters global configuration mode.
Step 3	flow-sampler-map <i>sampler-map-name</i> Example: Router(config)# flow-sampler-map icmp-dos-fs-map	Defines a statistical sampling NetFlow export flow sampler map. <ul style="list-style-type: none"> The <i>sampler-map-name</i> argument is the name of the flow sampler map to be defined. Entering the flow-sampler-map command enables the flow sampler configuration mode.

	Command or Action	Purpose
Step 4	<p>mode random <i>one-out-of</i> packet-interval</p> <p>Example: Router(config-sampler-map)# mode random one-out-of 2</p>	<p>Specifies a statistical sampling NetFlow export random sampling mode and a packet interval.</p> <ul style="list-style-type: none"> • The random keyword specifies that sampling uses the random sampling mode. • The one-out-of packet-interval argument-keyword pair specifies the packet interval (one out of every <i>n</i> packets) from which to sample. For <i>n</i>, you can specify from 1 to 65535 (packets).
Step 5	<p>exit</p> <p>Example: Router(config-sampler-map)# exit</p>	<p>Exits back to global configuration mode.</p>
Step 6	<p>class-map <i>class-map-name</i> [match-all match-any]</p> <p>Example: Router(config)# class-map match-any icmp-dos-class-map</p>	<p>Creates a class map to be used for matching packets to a specified class.</p> <ul style="list-style-type: none"> • The <i>class-map-name</i> argument is the name of the class for the class map. The name can be a maximum of 40 alphanumeric characters. The class name is used for both the class map and for configuring policy for the class in the policy map. • The match-all match-any keywords determine how packets are evaluated when multiple match criteria exist. Packets must either meet all of the match criteria (match-all) or only one of the match criteria (match-any) to be considered a member of the class. <p>Entering the class-map command enables class-map configuration mode, in which you can enter one of the match commands to configure the match criteria for this class.</p>
Step 7	<p>match access-group <i>access-group</i></p> <p>Example: Router(config-cmap)# match access-group 101</p>	<p>Configures the match criteria for a class map on the basis of the specified access control list (ACL).</p> <ul style="list-style-type: none"> • The <i>access-group</i> argument is a numbered ACL whose contents are used as the match criteria against which packets are checked to determine if they belong to this class. An ACL number can be a number from 1 to 2699.
Step 8	<p>exit</p> <p>Example: Router(config-cmap)# exit</p>	<p>Exits back to global configuration mode.</p>

Command or Action	Purpose
<p>Step 9 <code>policy-map</code> <i>policy-map-name</i></p> <p>Example: Router(config)# <code>policy-map</code> icmp-dos-policy-map</p>	<p>Creates or modifies a policy map that can be attached to one or more interfaces to specify a service policy.</p> <ul style="list-style-type: none"> The <i>policy-map-name</i> argument is the name of the policy map. The name can be a maximum of 40 alphanumeric characters. <p>Entering the policy-map command enables quality of service (QoS) policy-map configuration mode, in which you can configure or modify the class policies for that policy map</p>
<p>Step 10 <code>class</code> {<i>class-name</i> class-default}</p> <p>Example: Router(config-pmap)# <code>class</code> icmp-dos-class-map</p>	<p>Specifies the name of the class whose policy you want to create or change or specifies the default class (commonly known as the class-default class) before you configure its policy.</p> <ul style="list-style-type: none"> The <i>class-name</i> argument is the name of the class for which you want to configure or modify policy. The class-default keyword specifies the default class so that you can configure or modify its policy. <p>Entering the class command enables QoS policy-map class configuration mode.</p>
<p>Step 11 <code>netflow-sampler</code> <i>sampler-map-name</i></p> <p>Example: Router(config-pmap-c)# <code>netflow-sampler</code> icmp-dos-fs-map</p>	<p>Enables a NetFlow input filter sampler.</p> <ul style="list-style-type: none"> The <i>sampler-map-name</i> argument is the name of the NetFlow sampler map to apply to the class. <p>You can assign only one NetFlow input filter sampler to a class. Assigning another NetFlow input filter sampler to a class overwrites the previous one.</p>
<p>Step 12 <code>exit</code></p> <p>Example: Router(config-pmap-c)# <code>exit</code></p>	<p>Exits back to policy-map configuration mode.</p>
<p>Step 13 <code>exit</code></p> <p>Example: Router(config-pmap)# <code>exit</code></p>	<p>Exits back to global configuration mode.</p>
<p>Step 14 <code>interface</code> <i>interface-type</i> <i>interface-number</i>[.subinterface <i>number</i>]</p> <p>Example: Router(config)# <code>interface</code> Ethernet0/0.1</p>	<p>Specifies the interface and enters subinterface configuration mode.</p> <ul style="list-style-type: none"> The <i>interface-type</i> argument is the type of interface to be configured. The <i>interface-number</i> argument is the number of the interface. Refer to the appropriate hardware manual for slot and port information.

	Command or Action	Purpose
Step 15	<p><code>no [ip route-cache flow ip flow ingress]</code></p> <p>Example: Router(config-subif)# no ip flow ingress</p>	<p>Removes the existing NetFlow command from the interface.</p> <p>Note NetFlow sampling and filtering can not start if there is another command on the interface that is enabling NetFlow.</p>
Step 16	<p><code>service-policy {input output} policy-map-name</code></p> <p>Example: Router(config-subif)# service-policy input icmp-dos-policy-map</p>	<p>Attaches a policy map to an input interface or virtual circuit (VC), or an output interface or VC, to be used as the service policy for that interface or VC.</p> <ul style="list-style-type: none"> • The input keyword attaches the specified policy map to the input interface or input VC. • The output keyword attaches the specified policy map to the output interface or output VC. • The <i>policy-map-name</i> is the name of a service policy map (created through use of the policy-map command) to be attached. The name can be a maximum of 40 alphanumeric characters.
Step 17	<p><code>exit</code></p> <p>Example: Router(config-subif)# exit</p>	<p>Exits back to global configuration mode.</p>
Step 18	<p><code>ip flow-top-talkers</code></p> <p>Example: Router(config)# ip flow-top-talkers</p>	<p>Enters NetFlow top talkers configuration mode.</p>
Step 19	<p><code>top number</code></p> <p>Example: Router(config-flow-top-talkers)# top 50</p>	<p>Specifies the maximum number of top talkers that will be retrieved by a NetFlow top talkers query.</p>
Step 20	<p><code>sort-by packets</code></p> <p>Example: Router(config-flow-top-talkers)# sort-by packets</p>	<p>Specifies the sort criterion for the top talkers.</p> <ul style="list-style-type: none"> • The top talkers can be sorted either by the total number of packets of each top talker or the total number of bytes of each top talker.
Step 21	<p><code>match class-map class-name</code></p> <p>Example: Router(config-flow-top-talkers)# match class-map icmp-dos-class-map</p>	<p>Specifies that the match criteria should be obtained from the class-map.</p>
Step 22	<p><code>no match destination address ip-address/prefix-mask</code></p> <p>Example: Router(config-flow-top-talkers)# no match destination address 172.16.10.2/32</p>	<p>(Optional) If you still have a match entry for the destination address you should remove it so that only the class-name match criteria is used.</p>

	Command or Action	Purpose
Step 23	exit Example: Router(config-sampler-map)# exit	Exits back to global configuration mode.
Step 24	access-list access-list-number permit icmp source destination Example: Router(config)# access-list 101 permit icmp any host 172.16.10.2	Creates an extended access list that is used to track any host that is sending ICMP traffic to 172.16.10.2.
Step 25	end Example: Router(config)# end	Exits to privileged EXEC mode.

Verify NetFlow Filtering and Sampling

To verify that filtering and sampling is working properly, use the following step.

SUMMARY STEPS

1. **show flow-sampler**

DETAILED STEPS

Step 1 **show flow-sampler**

Any non-zero value in the display output below indicates that Filtering and sampling is active.

```
Router# show flow-sampler
```

```
Sampler : icmp-dos-fs-map, id : 1, packets matched : 63226, mode : random sampling mode
sampling interval is : 2
Router
```

Monitoring and Analyzing the Sampled and Filtered NetFlow Top Talkers Flows

To monitor and analyze the filtered and sampled NetFlow top talkers flows use the following step.

SUMMARY STEPS

1. **show ip flow top-talkers**
2. **show ip flow top-talkers verbose**

DETAILED STEPS

Step 1 **show ip flow top-talkers**

The following sample output shows the six traffic flows that are being sent to the host with IP address 172.16.10.2.

```
Router# show ip flow top-talkers

SrcIf          SrcIPAddress  DstIf          DstIPAddress   Pr SrcP DstP Bytes
Et0/0.1        10.231.185.254 Et1/0.1        172.16.10.2   01 0000 0C01 5460
Et0/0.1        10.106.1.1    Et1/0.1        172.16.10.2   01 0000 0800 5124
Et0/0.1        10.132.221.111 Et1/0.1        172.16.10.2   01 0000 0800 5012
Et0/0.1        10.251.138.218 Et1/0.1        172.16.10.2   01 0000 0C01 4844
Et0/0.1        10.10.12.1    Et1/0.1        172.16.10.2   01 0000 0C01 4704
Et0/0.1        10.71.200.138 Et1/0.1        172.16.10.2   01 0000 0C01 4396
6 of 50 top talkers shown. 6 of 7 flows matched.
```

Step 2 **show ip flow top-talkers verbose**

The following sample output below shows the details for the six traffic flows that are being sent to the host with IP address 172.16.10.2.

```
Router# show ip flow top-talkers verbose

SrcIf          SrcIPAddress  DstIf          DstIPAddress   Pr TOS Flgs Bytes
Port Msk AS    Port Msk AS    NextHop        B/Pk Active
Et0/0.1        10.106.1.1    Et1/0.1        172.16.10.2   01 00 10 2884
0000 /0 0      0800 /0 0      0.0.0.0        28 64.6
Sampler: 1 Class: 1
MAC: (VLAN id) aaaa.bbbb.cc03 (005)          aaaa.bbbb.cc06 (006)
Min plen:      28          Max plen:      28
Min TTL:       59          Max TTL:       59
ICMP type:     8          ICMP code:     0
IP id:         0

Et0/0.1        10.132.221.111 Et1/0.1        172.16.10.2   01 00 10 2828
0000 /0 0      0800 /0 0      0.0.0.0        28 64.6
Sampler: 1 Class: 1
MAC: (VLAN id) aaaa.bbbb.cc03 (005)          aaaa.bbbb.cc06 (006)
Min plen:      28          Max plen:      28
Min TTL:       59          Max TTL:       59
ICMP type:     8          ICMP code:     0
IP id:         0

Et0/0.1        10.231.185.254 Et1/0.1        172.16.10.2   01 00 10 2716
0000 /0 0      0C01 /0 0      0.0.0.0        28 64.6
Sampler: 1 Class: 1
MAC: (VLAN id) aaaa.bbbb.cc03 (005)          aaaa.bbbb.cc06 (006)
Min plen:      28          Max plen:      28
Min TTL:       59          Max TTL:       59
ICMP type:     8          ICMP code:     0
IP id:         0
```

```

ICMP type:      12
IP id:          0

Et0/0.1        10.71.200.138  Et1/0.1        172.16.10.2    01 00 10    2548
0000 /0 0      0C01 /0 0      0.0.0.0        28    58.0
Sampler: 1 Class: 1
MAC: (VLAN id) aaaa.bbbb.cc03 (005)      aaaa.bbbb.cc06 (006)
Min plen:      28                          Max plen:      28
Min TTL:       59                          Max TTL:       59
ICMP type:     12                          ICMP code:     1
IP id:         0

Et0/0.1        10.251.138.218  Et1/0.1        172.16.10.2    01 00 10    2436
0000 /0 0      0C01 /0 0      0.0.0.0        28    64.6
Sampler: 1 Class: 1
MAC: (VLAN id) aaaa.bbbb.cc03 (005)      aaaa.bbbb.cc06 (006)
Min plen:      28                          Max plen:      28
Min TTL:       59                          Max TTL:       59
ICMP type:     12                          ICMP code:     1
IP id:         0

Et0/0.1        10.10.12.1      Et1/0.1        172.16.10.2    01 00 10    2352
0000 /0 0      0C01 /0 0      0.0.0.0        28    57.7
Sampler: 1 Class: 1
MAC: (VLAN id) aaaa.bbbb.cc03 (005)      aaaa.bbbb.cc06 (006)
Min plen:      28                          Max plen:      28
Min TTL:       59                          Max TTL:       59
ICMP type:     12                          ICMP code:     1
IP id:         0

```

6 of 50 top talkers shown. 6 of 7 flows matched.

Configuration Examples for Detecting and Analyzing Network Threats With NetFlow

This section provides the following configuration examples:

- [Configuring NetFlow Layer 2 and Security Monitoring Exports to Capture Traffic From a Simulated FTP Attack: Example, page 41](#)
- [Analyze an FTP DoS Attack Using the show ip cache verbose flow command: Example, page 43](#)
- [Analyze an FTP DoS Attack Using NetFlow Dynamic Top Talkers CLI: Example, page 45](#)
- [Configuring NetFlow Layer 2 and Security Monitoring Exports to Capture Traffic From a Simulated ICMP Attack: Example, page 46](#)
- [Analyze an ICMP Ping DoS Attack Using the show ip cache verbose flow command: Example, page 48](#)
- [Analyze an ICMP Ping DoS Attack Using NetFlow Dynamic Top Talkers CLI: Example, page 51](#)
- [Configure NetFlow Filtering and Sampling: Example, page 53](#)


Configuring NetFlow Layer 2 and Security Monitoring Exports to Capture Traffic From a Simulated FTP Attack: Example

The following example shows how to use the NetFlow Layer 2 and Security Monitoring Exports feature to find out whether your network is being attacked by a host that is sending fake FTP traffic in an attempt to overwhelm the FTP server. This attack might cause end users to see a degradation in the ability of the FTP server to accept new connections or to service existing connections.

This example uses the network shown in [Figure 7](#). Host A is sending fake FTP packets to the FTP server.

This example also shows you how to use the Layer 2 data captured by the NetFlow Layer 2 and Security Monitoring Exports feature to learn where the traffic is originating and what path it is taking through the network.

Figure 7 Test Network



Tip

Keep track of the MAC addresses and IP addresses of the devices in your network. You can use them to analyze attacks and to resolve problems.



Note

This example does not include the `ip flow-capture icmp` command that captures the value of the ICMP type and code fields. The use of the `ip flow-capture icmp` command is described in “[Configuring NetFlow Layer 2 and Security Monitoring Exports to Capture Traffic From a Simulated ICMP Attack: Example.](#)”

R2

```
!
hostname R2
!
interface Ethernet0/0
  mac-address aaaa.bbbb.cc02
  ip address 172.16.1.2 255.255.255.0
!
interface Ethernet1/0
  mac-address aaaa.bbbb.cc03
  no ip address
!
interface Ethernet1/0.1
  encapsulation dot1Q 5
```

```

ip address 172.16.6.1 255.255.255.0
!
!
router rip
  version 2
  network 172.16.0.0
  no auto-summary
!

```

R3

```

!
hostname R3
!
ip flow-capture fragment-offset
ip flow-capture packet-length
ip flow-capture ttl
ip flow-capture vlan-id
ip flow-capture ip-id
ip flow-capture mac-addresses
!
interface Ethernet0/0
  mac-address aaaa.bbbb.cc04
  no ip address
!
interface Ethernet0/0.1
  encapsulation dot1Q 5
  ip address 172.16.6.2 255.255.255.0
  ip accounting output-packets
  ip flow ingress
!
interface Ethernet1/0
  mac-address aaaa.bbbb.cc05
  no ip address
!
interface Ethernet1/0.1
  encapsulation dot1Q 6
  ip address 172.16.7.1 255.255.255.0
  ip accounting output-packets
  ip flow egress
!
router rip
  version 2
  network 172.16.0.0
  no auto-summary
!

```

R4

```

!
hostname R4
!
interface Ethernet0/0
  mac-address aaaa.bbbb.cc07
  ip address 172.16.10.1 255.255.255.0
!
interface Ethernet1/0
  mac-address aaaa.bbbb.cc06
  no ip address
!
interface Ethernet1/0.1
  encapsulation dot1Q 6
  ip address 172.16.7.2 255.255.255.0
!

```

```
router rip
version 2
network 172.16.0.0
no auto-summary
!
```

Analyze an FTP DoS Attack Using the show ip cache verbose flow command: Example

The **show ip cache verbose flow** command displays the NetFlow flows. You can use this display output to identify the path that the FTP traffic from Host A is taking as it is received and transmitted by R3.



Note

To reduce the space required to display the output from the **show ip flow cache verbose flow** command only the FTP flows are shown.



Tip

Look for the flows that have FTP in them and make a note of the interfaces, MAC addresses, and VLANs (if applicable) for the flows.

```
R3# show ip cache verbose flow
IP packet size distribution (189118 total packets):
  1-32  64  96 128 160 192 224 256 288 320 352 384 416 448 480
  .043 .610 .000 .000 .000 .000 .000 .000 .000 .000 .000 .000 .000 .000 .000

  512  544  576 1024 1536 2048 2560 3072 3584 4096 4608
  .000 .000 .173 .000 .173 .000 .000 .000 .000 .000 .000

IP Flow Switching Cache, 278544 bytes
  25 active, 4071 inactive, 615 added
  263794 aged polls, 0 flow alloc failures
  Active flows timeout in 30 minutes
  Inactive flows timeout in 15 seconds
IP Sub Flow Cache, 25736 bytes
  50 active, 974 inactive, 1648 added, 615 added to flow
  0 alloc failures, 0 force free
  1 chunk, 1 chunk added
  last clearing of statistics never
```

Protocol	Total Flows	Flows /Sec	Packets /Flow	Bytes /Pkt	Packets /Sec	Active(Sec) /Flow	Idle(Sec) /Flow
TCP-FTP	12	0.0	895	40	0.9	1363.8	5.5
TCP-FTPD	12	0.0	895	40	0.9	1363.8	5.6
Total:	590	0.0	317	383	16.1	430.1	12.4

```
Et0/0.1      192.168.87.200 Et1/0.1      172.16.10.2    06 00 00    63
0015 /0 0      0015 /0 0      0.0.0.0      40    94.5
MAC: (VLAN id) aaaa.bbbb.cc03 (005)      aaaa.bbbb.cc06 (006)
Min plen:      40      Max plen:      40
Min TTL:      59      Max TTL:      59
IP id:      0

Et0/0.1      192.168.87.200 Et1/0.1      172.16.10.2    06 00 00    63
0014 /0 0      0014 /0 0      0.0.0.0      40    94.5
MAC: (VLAN id) aaaa.bbbb.cc03 (005)      aaaa.bbbb.cc06 (006)
Min plen:      40      Max plen:      40
Min TTL:      59      Max TTL:      59
```

```

IP id:          0

Et0/0.1        10.10.10.2      Et1/0.1        172.16.10.2    06 00 00      64
0015 /0 0      0015 /0 0      0.0.0.0        40             96.0
MAC: (VLAN id) aaaa.bbbb.cc03 (005)      aaaa.bbbb.cc06 (006)
Min plen:      40             Max plen:      40
Min TTL:       59             Max TTL:       59
IP id:         0

Et0/0.1        10.10.10.2      Et1/0.1        172.16.10.2    06 00 00      64
0014 /0 0      0014 /0 0      0.0.0.0        40             96.0
MAC: (VLAN id) aaaa.bbbb.cc03 (005)      aaaa.bbbb.cc06 (006)
Min plen:      40             Max plen:      40
Min TTL:       59             Max TTL:       59
IP id:         0

Et0/0.1        10.234.53.1     Et1/0.1        172.16.10.2    06 00 00      63
0015 /0 0      0015 /0 0      0.0.0.0        40             94.5
MAC: (VLAN id) aaaa.bbbb.cc03 (005)      aaaa.bbbb.cc06 (006)
Min plen:      40             Max plen:      40
Min TTL:       59             Max TTL:       59
IP id:         0

Et0/0.1        10.234.53.1     Et1/0.1        172.16.10.2    06 00 00      63
0014 /0 0      0014 /0 0      0.0.0.0        40             94.5
MAC: (VLAN id) aaaa.bbbb.cc03 (005)      aaaa.bbbb.cc06 (006)
Min plen:      40             Max plen:      40
Min TTL:       59             Max TTL:       59
IP id:         0

Et0/0.1        172.30.231.193 Et1/0.1        172.16.10.2    06 00 00      63
0015 /0 0      0015 /0 0      0.0.0.0        40             94.5
MAC: (VLAN id) aaaa.bbbb.cc03 (005)      aaaa.bbbb.cc06 (006)
Min plen:      40             Max plen:      40
Min TTL:       59             Max TTL:       59
IP id:         0

Et0/0.1        172.30.231.193 Et1/0.1        172.16.10.2    06 00 00      63
0014 /0 0      0014 /0 0      0.0.0.0        40             94.5
MAC: (VLAN id) aaaa.bbbb.cc03 (005)      aaaa.bbbb.cc06 (006)
Min plen:      40             Max plen:      40
Min TTL:       59             Max TTL:       59
IP id:         0

```

There are 8 FTP flows shown in the output. You can use the Layer 2 information in the flows that is captured by the **ip flow-capture** command to identify the path the traffic is taking through the network. In this example, the traffic is being sent to R3 on VLAN 5 by R2. You can demonstrate that R2 is transmitting the traffic over interface 1/0.1 because the source MAC address (aaaa.bbb.cc03) belongs to 1/0.1 on R2. You can demonstrate that R3 is transmitting the traffic using VLAN 6 on interface 1/0.1 to interface 1/0.1 on R4, because the destination MAC address (aaaa.bbbb.cc06) belongs to interface 1/0.1 on R4.

**Note**

For more information on the **ip flow-capture** command, and the fields in the display output of the **show ip cache verbose flow** command, refer to the *Cisco IOS NetFlow Command Reference*.

You can use this information to mitigate this attack. One possible way to mitigate this attack is by configuring an extended IP access list that blocks all FTP traffic from the source IP addresses that Host A is spoofing and applying it Ethernet 0/0 on R2.

Analyze an FTP DoS Attack Using NetFlow Dynamic Top Talkers CLI: Example

You can use the NetFlow Dynamic Top Talkers CLI feature to quickly identify the FTP top talkers in the network traffic that might be sending the traffic. This will show you the IP source addresses that Host A is using as it sends the DoS attack traffic.

```
R3# show ip flow top 50 aggregate source-address sorted-by bytes descending match destination-port min 20 max 21
```

There are 5 top talkers:

IPV4 SRC-ADDR	bytes	pkts	flows
10.231.185.254	5640	141	2
10.132.221.111	3680	92	2
10.10.12.1	3640	91	2
10.251.138.218	3600	90	2
10.71.200.138	1880	47	1

9 of 34 flows matched.



Note

Only source IP addresses from FTP traffic are shown because of the **match destination-port min 20 max 21** criteria. The source addresses are aggregated together so only the most relevant sources are shown.



Note

Only nine of the 34 flows matched because the rest of the flows are not FTP flows, therefore they do not meet the match criteria (**match destination-port min 20 max 21**).



Tip

The top talkers are displayed in descending order of the aggregated field by default.



Tip

You can enter the port numbers in their decimal values as shown, or in their hexadecimal equivalents of 0x14 and 0x15.

After you have identified FTP top talkers traffic you need to identify the source IP addresses of IP traffic that is being sent to the host that you believe is under attack.

```
R3# show ip flow top 50 aggregate source-address match destination-prefix 172.16.10.2/32
```

There are 6 top talkers:

IPV4 SRC-ADDR	bytes	pkts	flows
10.251.138.218	6642	18	4
10.231.185.254	5068	28	4
10.132.221.111	14818	25	4
10.106.1.1	12324	12	2
10.71.200.138	12564	18	3
10.10.12.1	560	14	2

19 of 33 flows matched.

**Tip**

You can specify the host that you believe is under attack by using a prefix value of 32 with the **match destination-prefix** command.

**Note**

Only 19 of the 33 flows matched because the rest of the flows do not contain traffic that is destined for the host with the IP address of 172.16.10.2, therefore they do not meet the match criteria (**match destination-prefix 172.16.10.2/32**).

The final step is to cross reference the source IP addresses of any hosts that are sending any IP traffic to the host under attack with the list of source IP addresses from the FTP top talkers. This is required because the **show ip flow top** command does not support multiple match criteria. Therefore you cannot limit the top talkers to FTP traffic being sent to a specific host with a single **show ip flow top** command (**match destination-port min 20 max 21 <and> match destination-prefix 172.16.10.2/32**).

The host with the IP address of 10.106.1.1 is apparently not involved in this DoS attack because it is not in the display output from the **show ip flow top 50 aggregate source-address sorted-by bytes descending match destination-port min 20 max 21** command. This means that it is not sending FTP traffic to the host that is under attack.

Therefore the host IP addresses involved in this FTP DoS attack are likely to be:

- 10.231.185.254
- 10.132.221.111
- 10.10.12.1
- 10.251.138.218
- 10.71.200.138

Now that you know the source addresses of the FTP traffic you can configure an extended access list that blocks FTP traffic from these address, and apply it to the interface that is closest to the point the traffic is entering your network.


**Note**

Unless you recognize that some of the source IP addresses are not legitimate IP addresses for your network it might not be possible to identify legitimate FTP traffic from FTP DoS attack traffic.

Configuring NetFlow Layer 2 and Security Monitoring Exports to Capture Traffic From a Simulated ICMP Attack: Example

The following example shows how to use the NetFlow Layer 2 and Security Monitoring Exports feature to find out that your network is being attacked by ICMP traffic. It uses the network shown in [Figure 8](#). Host A is sending ICMP ping packets to the FTP server.

Figure 8 Test Network



Tip

Keep track of the MAC addresses and IP addresses of the devices in your network. You can use them to analyze attacks and to resolve problems.

R2

```

!
hostname R2
!
interface Ethernet0/0
  mac-address aaaa.bbbb.cc02
  ip address 172.16.1.2 255.255.255.0
!
interface Ethernet1/0
  mac-address aaaa.bbbb.cc03
  no ip address
!
interface Ethernet1/0.1
  encapsulation dot1Q 5
  ip address 172.16.6.1 255.255.255.0
!
!
router rip
  version 2
  network 172.16.0.0
  no auto-summary
!
    
```

R3

```

!
hostname R3
!
ip flow-capture fragment-offset
ip flow-capture packet-length
ip flow-capture ttl
ip flow-capture vlan-id
ip flow-capture icmp
ip flow-capture ip-id
ip flow-capture mac-addresses
!
interface Ethernet0/0
  mac-address aaaa.bbbb.cc04
  no ip address
    
```

```

!
interface Ethernet0/0.1
 encapsulation dot1Q 5
 ip address 172.16.6.2 255.255.255.0
 ip accounting output-packets
 ip flow ingress
!
interface Ethernet1/0
 mac-address aaaa.bbbb.cc05
 no ip address
!
interface Ethernet1/0.1
 encapsulation dot1Q 6
 ip address 172.16.7.1 255.255.255.0
 ip accounting output-packets
 ip flow egress
!
router rip
 version 2
 network 172.16.0.0
 no auto-summary
!

```

R4

```

!
hostname R4
!
interface Ethernet0/0
 mac-address aaaa.bbbb.cc07
 ip address 172.16.10.1 255.255.255.0
!
interface Ethernet1/0
 mac-address aaaa.bbbb.cc06
 no ip address
!
interface Ethernet1/0.1
 encapsulation dot1Q 6
 ip address 172.16.7.2 255.255.255.0
!
router rip
 version 2
 network 172.16.0.0
 no auto-summary
!

```

Analyze an ICMP Ping DoS Attack Using the show ip cache verbose flow command: Example

The **show ip cache verbose flow** command displays the NetFlow flows. You can use this display output to identify the path that the ICMP traffic from Host A is taking as it is received and transmitted by R3.

**Note**

To reduce the space required to display the output from the **show ip flow cache verbose flow** command only the ICMP flows are shown.



Look for the flows that have ICMP in them and make a note of the interfaces, MAC addresses, and VLANs (if applicable) for the flows.

```
R3# show ip cache verbose flow
IP packet size distribution (122369 total packets):
  1-32  64  96 128 160 192 224 256 288 320 352 384 416 448 480
  .065 .665 .000 .000 .000 .000 .000 .000 .000 .000 .000 .000 .000 .000 .000

  512  544  576 1024 1536 2048 2560 3072 3584 4096 4608
  .000 .000 .134 .000 .134 .000 .000 .000 .000 .000 .000 .000 .000 .000 .000
```

```
IP Flow Switching Cache, 278544 bytes
 24 active, 4072 inactive, 404 added
176657 aged polls, 0 flow alloc failures
Active flows timeout in 30 minutes
Inactive flows timeout in 15 seconds
IP Sub Flow Cache, 25736 bytes
 48 active, 976 inactive, 1088 added, 404 added to flow
 0 alloc failures, 0 force free
 1 chunk, 1 chunk added
last clearing of statistics never
```

Protocol	Total Flows	Flows /Sec	Packets /Flow	Bytes /Pkt	Packets /Sec	Active(Sec) /Flow	Idle(Sec) /Flow
ICMP	27	0.0	1131	763	3.9	1557.4	3.6
Total:	380	0.0	267	257	13.0	382.8	12.6

SrcIf Port Msk AS	SrcIPAddress	DstIf Port Msk AS	DstIPAddress NextHop	Pr TOS Flgs	Pkts B/Pk Active
Et0/0.1 0000 /0 0	10.106.1.1	Et1/0.1 0800 /0 0	172.16.10.2 0.0.0.0	01 00 10	864 1500 1089.9
MAC: (VLAN id)	aaaa.bbbb.cc03	(005)	aaaa.bbbb.cc06	(006)	
Min plen:	1500		Max plen:	1500	
Min TTL:	59		Max TTL:	59	
ICMP type:	8		ICMP code:	0	
IP id:	0				
Et0/0.1 0000 /0 0	10.71.200.138	Et1/0.1 0000 /0 0	172.16.10.2 0.0.0.0	01 00 00	864 554 1090.0
MAC: (VLAN id)	aaaa.bbbb.cc03	(005)	aaaa.bbbb.cc06	(006)	
Min plen:	554		Max plen:	554	
Min TTL:	59		Max TTL:	59	
ICMP type:	0		ICMP code:	0	
IP id:	0		FO:	185	
Et0/0.1 0000 /0 0	10.231.185.254	Et1/0.1 0000 /0 0	172.16.10.2 0.0.0.0	01 00 00	864 554 1090.0
MAC: (VLAN id)	aaaa.bbbb.cc03	(005)	aaaa.bbbb.cc06	(006)	
Min plen:	554		Max plen:	554	
Min TTL:	59		Max TTL:	59	
ICMP type:	0		ICMP code:	0	
IP id:	0		FO:	185	
Et0/0.1 0000 /0 0	10.10.12.1	Et1/0.1 0000 /0 0	172.16.10.200 0.0.0.0	01 00 00	864 554 1090.0
MAC: (VLAN id)	aaaa.bbbb.cc03	(005)	aaaa.bbbb.cc06	(006)	
Min plen:	554		Max plen:	554	
Min TTL:	59		Max TTL:	59	
ICMP type:	0		ICMP code:	0	
IP id:	0		FO:	185	
Et0/0.1	10.132.221.111	Et1/0.1	172.16.10.2	01 00 10	864

Configuration Examples for Detecting and Analyzing Network Threats With NetFlow

```

0000 /0 0                               0800 /0 0                               0.0.0.0                               1500 1089.9
MAC: (VLAN id) aaaa.bbbb.cc03 (005)      aaaa.bbbb.cc06 (006)
Min plen: 1500                            Max plen: 1500
Min TTL: 59                               Max TTL: 59
ICMP type: 8                              ICMP code: 0
IP id: 0

Et0/0.1 10.251.138.218 Et1/0.1 172.16.10.2 01 00 00 864
0000 /0 0                               0000 /0 0                               0.0.0.0                               554 1089.9
MAC: (VLAN id) aaaa.bbbb.cc03 (005)      aaaa.bbbb.cc06 (006)
Min plen: 554                            Max plen: 554
Min TTL: 59                              Max TTL: 59
ICMP type: 0                            ICMP code: 0
IP id: 0                                  FO: 185

Et0/0.1 10.10.12.1 Et1/0.1 172.16.10.200 01 00 10 864
0000 /0 0                               0C01 /0 0                               0.0.0.0                               1500 1090.0
MAC: (VLAN id) aaaa.bbbb.cc03 (005)      aaaa.bbbb.cc06 (006)
Min plen: 1500                            Max plen: 1500
Min TTL: 59                              Max TTL: 59
ICMP type: 12                            ICMP code: 1
IP id: 0

Et0/0.1 10.106.1.1 Et1/0.1 172.16.10.2 01 00 00 864
0000 /0 0                               0000 /0 0                               0.0.0.0                               554 1089.9
MAC: (VLAN id) aaaa.bbbb.cc03 (005)      aaaa.bbbb.cc06 (006)
Min plen: 554                            Max plen: 554
Min TTL: 59                              Max TTL: 59
ICMP type: 0                            ICMP code: 0
IP id: 0                                  FO: 185

Et0/0.1 10.251.138.218 Et1/0.1 172.16.10.2 01 00 10 864
0000 /0 0                               0C01 /0 0                               0.0.0.0                               1500 1089.9
MAC: (VLAN id) aaaa.bbbb.cc03 (005)      aaaa.bbbb.cc06 (006)
Min plen: 1500                            Max plen: 1500
Min TTL: 59                              Max TTL: 59
ICMP type: 12                            ICMP code: 1
IP id: 0

Et0/0.1 10.71.200.138 Et1/0.1 172.16.10.2 01 00 10 864
0000 /0 0                               0C01 /0 0                               0.0.0.0                               1500 1090.0
MAC: (VLAN id) aaaa.bbbb.cc03 (005)      aaaa.bbbb.cc06 (006)
Min plen: 1500                            Max plen: 1500
Min TTL: 59                              Max TTL: 59
ICMP type: 12                            ICMP code: 1
IP id: 0

Et0/0.1 10.132.221.111 Et1/0.1 172.16.10.2 01 00 00 864
0000 /0 0                               0000 /0 0                               0.0.0.0                               554 1089.9
MAC: (VLAN id) aaaa.bbbb.cc03 (005)      aaaa.bbbb.cc06 (006)
Min plen: 554                            Max plen: 554
Min TTL: 59                              Max TTL: 59
ICMP type: 0                            ICMP code: 0
IP id: 0                                  FO: 185

Et0/0.1 10.231.185.254 Et1/0.1 172.16.10.2 01 00 10 864
0000 /0 0                               0C01 /0 0                               0.0.0.0                               1500 1090.0
MAC: (VLAN id) aaaa.bbbb.cc03 (005)      aaaa.bbbb.cc06 (006)
Min plen: 1500                            Max plen: 1500
Min TTL: 59                              Max TTL: 59
ICMP type: 12                            ICMP code: 1
IP id: 0

```

There are 12 ICMP flows shown in the output. You can use the Layer 2 information in the flows that is captured by the **ip flow-capture** command to identify the path the traffic is taking through the network. In this example, the traffic is being sent to R3 on VLAN 5 by R2. You can demonstrate that R2 is transmitting the traffic over interface 1/0.1 because the source MAC address (aaaa.bbb.cc03) belongs to 1/0.1 on R2. You can demonstrate that R3 is transmitting the traffic using VLAN 6 on interface 1/0.1 to interface 1/0.1 on R4, because the destination MAC address (aaaa.bbbb.cc06) belongs to interface 1/0.1 on R4.



Note

For more information on the **ip flow-capture** command, and the fields in the display output of the **show ip cache verbose flow** command, refer to the *Cisco IOS NetFlow Command Reference*.

You can use this information to mitigate this attack. One possible way to mitigate this attack is by configuring an extended IP access list that blocks all ICMP traffic from the source IP addresses that Host A is spoofing and applying it Ethernet 0/0 on R2.

Analyze an ICMP Ping DoS Attack Using NetFlow Dynamic Top Talkers CLI: Example

You can use the NetFlow Dynamic Top Talkers CLI feature to quickly identify the ICMP top talkers in the network traffic that might be sending the traffic. This will show you the IP source addresses that Host A is using as it sends the DoS attack traffic.

```
R3# show ip flow top 50 aggregate icmp
```

There are 3 top talkers:

ICMP TYPE	ICMP CODE	bytes	pkts	flows
12	1	2466000	1644	4
8	0	1233000	822	2
0	0	1366164	2466	6

12 of 25 flows matched.



Note

Only 12 of the 25 flows matched because the rest of the flows are not ICMP flows.



Tip

The top talkers are displayed in descending order of the aggregated field by default.

After you have identified the ICMP types and code values in the network traffic, you need to determine the source IP addresses for the ICMP traffic that being sent to the FTP server.

```
R3# show ip flow top 50 aggregate source-address match icmp type 12 code 1
```

There are 4 top talkers:

IPV4 SRC-ADDR	bytes	pkts	flows
10.251.138.218	867000	578	1
10.231.185.254	865500	577	1
10.71.200.138	865500	577	1
10.10.12.1	867000	578	1

4 of 24 flows matched.

**Note**

Only source IP addresses from ICMP traffic are shown because of the **match icmp type 12 code 1** criteria. No aggregation is performed on the source IP addresses because there is only one flow for IP each address.

**Note**

Only four of the 24 flows matched because the rest of the flows did not meet the match criteria (**match icmp type 12 code 1**).

```
R3# show ip flow top 50 aggregate source-address match icmp type 8 code 0
```

There are 2 top talkers:

IPV4 SRC-ADDR	bytes	pkts	flows
10.132.221.111	1095000	730	1
10.106.1.1	1095000	730	1

2 of 24 flows matched.

**Note**

Only source IP addresses from ICMP traffic are shown because of the **match icmp type 8 code 0** criteria. No aggregation is performed on the source IP addresses because there is only one flow for IP each address.

**Note**

Only two of the 24 flows matched because the rest of the flows did not meet the match criteria (**match icmp type 8 code 0**).

```
R3# show ip flow top 50 aggregate source-address match icmp type 0 code 0
```

There are 6 top talkers:

IPV4 SRC-ADDR	bytes	pkts	flows
10.251.138.218	416608	752	1
10.231.185.254	416608	752	1
10.132.221.111	416608	752	1
10.106.1.1	416608	752	1
10.71.200.138	416608	752	1
10.10.12.1	416608	752	1

6 of 24 flows matched.

**Note**

Only source IP addresses from ICMP traffic are shown because of the **match icmp type 0 code 0** criteria. No aggregation is performed on the source IP addresses because there is only one flow for IP each address.

**Note**

Only six of the 24 flows matched because the rest of the flows did not meet the match criteria (**match icmp type 0 code 0**).

The next step is to create a list of the source IP addresses that Host A is using.

- 10.251.138.218
- 10.231.185.254
- 10.71.200.138
- 10.10.12.1
- 10.132.221.111
- 10.106.1.1.

Now that you know the source addresses of the ICMP DoS attack traffic, you can mitigate this attack by configuring an extended access list that blocks ICMP traffic from these address and applying it to the interface that is closest to the point that the traffic is entering your network.

Configure NetFlow Filtering and Sampling: Example

This example configuration contains the configuration commands required to use NetFlow filtering and sampling on the NetFlow router.

```
!
hostname Router
!
ip cef
!
flow-sampler-map icmp-dos-fs-map
  mode random one-out-of 2
!
!
class-map match-any icmp-dos-class-map
  match access-group 101
!
!
policy-map icmp-dos-policy-map
  class icmp-dos-class-map
    netflow-sampler icmp-dos-fs-map
!
interface Ethernet0/0
  mac-address aaaa.bbbb.cc04
  no ip address
!
interface Ethernet0/0.1
  encapsulation dot1Q 5
  ip address 172.16.6.2 255.255.255.0
  service-policy input icmp-dos-policy-map
!
interface Ethernet1/0.1
  encapsulation dot1Q 6
  ip address 172.16.7.1 255.255.255.0
  ip flow egress
!
ip flow-capture fragment-offset
ip flow-capture packet-length
ip flow-capture ttl
ip flow-capture vlan-id
```

```

ip flow-capture icmp
ip flow-capture ip-id
ip flow-capture mac-addresses
!
ip flow-top-talkers
  top 5
  sort-by bytes
  match class-map icmp-dos-class-map
!
access-list 101 permit icmp any host 172.16.10.2
!
end

```

Where to Go Next

See the [“Related Documents”](#) section on page 54 for links to configuration information about additional NetFlow features and services.

Additional References

The following sections provide references related to NetFlow Layer 2 and Security Monitoring Exports.

Related Documents

Related Topic	Document Title
Overview of Cisco IOS NetFlow	“Cisco IOS NetFlow Overview”
List of the features documented in the <i>Book Title</i> configuration guide	“Cisco IOS NetFlow Features Roadmap”
The minimum information about and tasks required for configuring NetFlow and NetFlow Data Export	“Getting Started with Configuring NetFlow and NetFlow Data Export”
Tasks for configuring NetFlow to capture and export network traffic data	“Configuring NetFlow and NetFlow Data Export”
Tasks for configuring Configuring MPLS Aware NetFlow	Configuring MPLS Aware NetFlow
Tasks for configuring MPLS egress NetFlow accounting	Configuring MPLS Egress NetFlow Accounting and Analysis
Tasks for configuring NetFlow input filters	“Using NetFlow Filtering or Sampling to Select the Network Traffic to Track”
Tasks for configuring Random Sampled NetFlow	“Using NetFlow Filtering or Sampling to Select the Network Traffic to Track”
Tasks for configuring NetFlow aggregation caches	“Configuring NetFlow Aggregation Caches”
Tasks for configuring NetFlow BGP next hop support	“Configuring NetFlow BGP Next Hop Support for Accounting and Analysis”
Tasks for configuring NetFlow multicast support	“Configuring NetFlow Multicast Accounting”

Related Topic	Document Title
Tasks for configuring NetFlow Reliable Export With SCTP	NetFlow Reliable Export With SCTP
Tasks for configuring NetFlow Layer 2 and Security Monitoring Exports	“ NetFlow Layer 2 and Security Monitoring Exports ”
Tasks for configuring the SNMP NetFlow MIB	“ Configuring SNMP and using the NetFlow MIB to Monitor NetFlow Data ”
Tasks for configuring the NetFlow MIB and Top Talkers feature	“ Configuring NetFlow Top Talkers using Cisco IOS CLI Commands or SNMP Commands ”
Information for installing, starting, and configuring the CNS NetFlow Collection Engine	“ Cisco CNS NetFlow Collection Engine Documentation ”

Standards

Standards	Title
There are no new or modified standards associated with this feature	—

MIBs

MIBs	MIBs Link
There are no new or modified MIBs associated with this feature.	To locate and download MIBs for selected platforms, Cisco IOS releases, and feature sets, use Cisco MIB Locator found at the following URL: http://www.cisco.com/go/mibs

RFCs

RFCs	Title
There are no new or modified RFCs associated with this feature.	—

Technical Assistance

Description	Link
The Cisco Technical Support website contains thousands of pages of searchable technical content, including links to products, technologies, solutions, technical tips, and tools. Registered Cisco.com users can log in from this page to access even more content.	http://www.cisco.com/techsupport

Feature Information for Detecting and Analyzing Network Threats With NetFlow

Table 11 lists the features in this module and provides links to specific configuration information. Only features that were introduced or modified in Cisco IOS Releases 12.2(1) or 12.0(3)S or a later release appear in the table.

Not all commands may be available in your Cisco IOS software release. For details on when support for a specific command was introduced, see the command reference documentation.

For information on a feature in this technology that is not documented here, see the [Cisco IOS NetFlow Features Roadmap](#).

Cisco IOS software images are specific to a Cisco IOS software release, a feature set, and a platform. Use Cisco Feature Navigator to find information about platform support and Cisco IOS software image support. Access Cisco Feature Navigator at <http://www.cisco.com/go/fn>. You must have an account on Cisco.com. If you do not have an account or have forgotten your username or password, click **Cancel** at the login dialog box and follow the instructions that appear.



Note

Table 11 lists only the Cisco IOS software release that introduced support for a given feature in a given Cisco IOS software release train. Unless noted otherwise, subsequent releases of that Cisco IOS software release train also support that feature.

Table 11 Feature Information for NetFlow Layer 2 and Security Monitoring Exports

Feature Name	Releases	Feature Configuration Information
NetFlow Layer 2 and Security Monitoring Exports	12.3(14)T	<p>The NetFlow Layer 2 and Security Monitoring Exports feature enables the capture of values from fields in Layer 3 and Layer 2 of IP traffic for accounting and security analysis.</p> <p>The following sections provide information about this feature:</p> <ul style="list-style-type: none"> • NetFlow Layer 2 and Security Monitoring, page 3 • Configuring NetFlow Layer 2 and Security Monitoring Exports, page 20 • Verifying NetFlow Layer 2 and Security Monitoring Exports, page 22 <p>The following commands were modified by this feature: ip flow-capture, ip flow-export and show ip cache verbose flow.</p>
Support for capturing the value from the fragment offset field of IP headers added to NetFlow Layer 2 and Security Monitoring Exports ¹	12.4(2)T	<p>The fragment-offset keyword for the ip flow-capture command enables capturing the value of the IP fragment offset field from the first fragmented IP datagram in a flow.</p>

Table 11 Feature Information for NetFlow Layer 2 and Security Monitoring Exports (continued)

Feature Name	Releases	Feature Configuration Information
NetFlow Top Talkers	12.3(11)T, 12.2(25)S	<p>This document references the Top Talkers feature from the NetFlow MIB and Top Talkers feature documentation.</p> <p>Please refer to Configuring NetFlow Top Talkers using Cisco IOS CLI Commands or SNMP Commands for complete information on using this feature.</p> <p>Top Talkers uses NetFlow functionality to obtain information regarding heaviest traffic patterns and most-used applications in the network.</p> <p>The following sections provide information about this feature:</p> <ul style="list-style-type: none"> • Configuring NetFlow Top Talkers to Monitor Network Threats, page 28 <p>The following commands were introduced by this feature: cache-timeout, ip flow-top-talkers, match, show ip flow top-talkers, sort-by, and top.</p>
NetFlow Dynamic Top Talkers CLI	12.4(4)T	<p>The NetFlow Dynamic Top Talkers CLI allows you to see an overview of the traffic characteristics on your router by aggregating flows based on the fields such as source IP address, destination prefix, and so forth.</p> <p>The following sections provide information about this feature:</p> <ul style="list-style-type: none"> • Using NetFlow Dynamic Top Talkers CLI to Display the Protocol Distribution, page 24 • Using NetFlow Dynamic Top Talkers CLI to Display the Source IP Address Top Talkers Sending ICMP Traffic, page 25 • Using NetFlow Dynamic Top Talkers CLI to Display the Destination IP Address Top Talkers Receiving ICMP Traffic, page 27 • Monitoring and Analyzing the NetFlow Top Talkers Flows, page 30 • Analyze an FTP DoS Attack Using NetFlow Dynamic Top Talkers CLI: Example, page 45 • Analyze an ICMP Ping DoS Attack Using NetFlow Dynamic Top Talkers CLI: Example, page 51

Table 11 Feature Information for NetFlow Layer 2 and Security Monitoring Exports (continued)

Feature Name	Releases	Feature Configuration Information
NetFlow Input Filters	12.3(4)T, 12.2(25)S	<p>This document references the NetFlow Input Filters feature from the NetFlow Filtering and Sampling feature documentation.</p> <p>Refer to Using NetFlow Filtering or Sampling to Select the Network Traffic to Track for complete information on using this feature.</p> <p>The following sections provide information about this feature:</p> <ul style="list-style-type: none"> • Configuring NetFlow Filtering and Sampling, page 33 • Configure NetFlow Filtering and Sampling: Example, page 53
Random Sampled NetFlow	12.3(4)T, 12.2(18)S, 12.0(26)S	<p>This document references the Random Sampled NetFlow feature from the NetFlow Filtering and Sampling feature documentation.</p> <p>Refer to Using NetFlow Filtering or Sampling to Select the Network Traffic to Track for complete information on using this feature.</p> <p>The following sections provide information about this feature:</p> <ul style="list-style-type: none"> • Configuring NetFlow Filtering and Sampling, page 33

1. This is a minor enhancement. Minor enhancements are not typically listed in Feature Navigator.

Glossary

data flowset—A collection of data records that are grouped in an export packet.

export packet—A type of packet built by a device (for example, a router) with NetFlow services enabled. The packet is addressed to another device (for example, the NetFlow Collection Engine). The packet contains NetFlow statistics. The other device processes the packet (parses, aggregates, and stores information about IP flows).

flow—A set of packets with the same source IP address, destination IP address, protocol, source/destination ports, and type-of-service, and the same interface on which flow is monitored. Ingress flows are associated with the input interface, and egress flows are associated with the output interface.

flowset—A collection of flow records that follow the packet header in an export packet. A flowset contains information that must be parsed and interpreted by the NetFlow Collection Engine. There are two types of flowsets: template flowsets and data flowsets. An export packet contains one or more flowsets, and both template and data flowsets can be mixed in the same export packet.

NetFlow—Cisco IOS accounting feature that maintains per-flow information.

NetFlow Aggregation—A NetFlow feature that lets you summarize NetFlow export data on an IOS router before the data is exported to a NetFlow data collection system such as the NetFlow Collection Engine. This feature lowers bandwidth requirements for NetFlow export data and reduces platform requirements for NetFlow data collection devices.

NetFlow Collection Engine (formerly NetFlow FlowCollector)—Cisco application that is used with NetFlow on Cisco routers and Catalyst series switches. The NetFlow Collection Engine collects packets from the router that is running NetFlow and decodes, aggregates, and stores them. You can generate reports on various aggregations that can be set up on the NetFlow Collection Engine.

NetFlow v9—NetFlow export format Version 9. A flexible and extensible means of carrying NetFlow records from a network node to a collector. NetFlow Version 9 has definable record types and is self-describing for easier NetFlow Collection Engine configuration.

template—Describes the layout of a data flowset.

template flowset—A collection of template records that are grouped in an export packet.

CCDE, CCENT, CCSI, Cisco Eos, Cisco HealthPresence, Cisco IronPort, the Cisco logo, Cisco Lumin, Cisco Nexus, Cisco Nurse Connect, Cisco Pulse, Cisco StackPower, Cisco StadiumVision, Cisco TelePresence, Cisco Unified Computing System, Cisco WebEx, DCE, Flip Channels, Flip for Good, Flip Mino, Flipshare (Design), Flip Ultra, Flip Video, Flip Video (Design), Instant Broadband, and Welcome to the Human Network are trademarks; Changing the Way We Work, Live, Play, and Learn, Cisco Capital, Cisco Capital (Design), Cisco:Financed (Stylized), Cisco Store, and Flip Gift Card are service marks; and Access Registrar, Aironet, AllTouch, AsyncOS, Bringing the Meeting To You, Catalyst, CCDA, CCDP, CCIE, CCIP, CCNA, CCNP, CCSP, CCVP, Cisco, the Cisco Certified Internetwork Expert logo, Cisco IOS, Cisco Press, Cisco Systems, Cisco Systems Capital, the Cisco Systems logo, Cisco Unity, Collaboration Without Limitation, Continuum, EtherFast, EtherSwitch, Event Center, Explorer, Fast Step, Follow Me Browsing, FormShare, GainMaker, GigaDrive, HomeLink, iLYNX, Internet Quotient, IOS, iPhone, iQuick Study, IronPort, the IronPort logo, Laser Link, LightStream, Linksys, MediaTone, MeetingPlace, MeetingPlace Chime Sound, MGX, Networkers, Networking Academy, Network Registrar, PCNow, PIX, PowerKEY, PowerPanels, PowerTV, PowerTV (Design), PowerVu, Prisma, ProConnect, ROSA, ScriptShare, SenderBase, SMARTnet, Spectrum Expert, StackWise, The Fastest Way to Increase Your Internet Quotient, TransPath, WebEx, and the WebEx logo are registered trademarks of Cisco Systems, Inc. and/or its affiliates in the United States and certain other countries.

All other trademarks mentioned in this document or website are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (0908R)

Any Internet Protocol (IP) addresses used in this document are not intended to be actual addresses. Any examples, command display output, and figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses in illustrative content is unintentional and coincidental.

© 2006–2009 Cisco Systems, Inc. All rights reserved.

