Send document comments to nexus1k-docfeedback@cisco.com.

F Commands

This chapter describes the Cisco Nexus 1010 commands that begin with the letter F.

find

To find filenames beginning with a character string, use the **find** command.

find *filename-prefix*

Syntax Description

filename-prefix	First part or all of a filename. The filename prefix is case sensitive.

Defaults

None

Command Modes

Any

SupportedUserRoles

network-admin

Command History

Release	Modification
4.0(4)SP1(1)	This command was introduced.

Usage Guidelines

The **find** command searches all subdirectories under the current working directory. You can use the **cd** and **pwd** commands to navigate to the starting directory.

Examples

This example shows how to display filenames beginning with ospf:

```
n1010# find ospf
/usr/bin/find: ./lost+found: Permission denied
./ospf-gr.cfg
./ospfgrconfig
```

Send document comments to nexus1k-docfeedback@cisco.com.

```
./ospf-gr.conf
```

Related Commands

Command	Description
cd	Changes the current working directory.
pwd	Displays the name of the current working directory.

Send document comments to nexus1k-docfeedback@cisco.com.

format

To format an external Flash device to erase the contents and restore it to its factory-shipped state, use the **format** command.

format *filesystem***:**

Syntax Description

*filesystem***:**	Name of the file system. The valid values are **bootflash, logflash, slot0**, **usb1**, or **usb2**.

Defaults

None

Command Modes

Any

SupportedUserRoles

network-admin

Command History

Release	Modification
4.0(4)SP1(1)	This command was introduced.

Examples

This example shows how to format an external Flash device:

```
n1010# format slot0:
```

Related Commands

Command	Description
cd	Changes the current working directory.
dir	Displays the directory contents.
pwd	Displays the name of the current working directory.

Send document comments to nexus1k-docfeedback@cisco.com.